

# ILLUSTRATED PARTS BREAKDOWN

# BA11-K MOUNTING BOX

## HOW TO USE THE IPB

### GENERAL

This IPB is compiled following the organization and nomenclature of the engineering drawing structure.

### MAJOR ASSEMBLY LOCATOR

The Major Assembly Locator (first illustration) is an index that provides a description and a figure reference for all illustrations used in this manual.

### INDENTED PARTS LIST

This manual identifies each assembly being broken down (figure reference callout), and all parts of that assembly. Further breakdown of an assembly is shown by an asterisk (\*) preceding the item callouts in the Description Column. The number of asterisks preceding an item is used to denote the subordination of that item with respect to the Major Assembly. A single asterisk preceding an item description indicates that the item is part of the major assembly being illustrated. Items that are subordinate to single asterisks items, are denoted by two asterisks (\*\*) and immediately follow the related single asterisk item. Additional asterisks are used, as required, to denote further subordination. This system of part identification, provides a means for the user to identify the next higher assembly item and make alternate selections for parts when the required replacement part or assembly is not immediately available.

### COLUMN CALLOUT DESCRIPTION

**Figure & Item** — Indicates the figure number and item number of each part.

**Description** — Lists the name of the part and pertinent specifications (when required). Asterisks preceding the description denote the subordination of the part to the next higher assembly.

**DEC Part No.** — Lists the DEC part ordering number. A blank in this column indicates a DEC part number was not assigned at the time of publication.

**ECO Cut-In** — The notation at the top of this column indicates the ECO level of the system (option), at which the IPB was initially prepared. Subsequent ECO level designations, that modify existing parts or add new parts to the device, are inserted in the ECO Cut-In column next to the part that is added or modified. A bracket ([]) preceding the item description is used to indicate the parts affected by ECO's.

**Vendor Code/Part No.** — Indicates vendor parts that are not stocked by DEC. Refer to the Field Service Spares Catalog (vendor part number to DEC part number) for the vendor code cross-reference.

**Used On Code** — Letters in this column correspond to the variation codes assigned in Figure 1. Parts with an Alpha notation(s) are used only in those option variations. A blank indicates that the part is used on all option variations.

**Ref Fig No.** — A cross reference between illustrations. For each Major Assembly, the number in this column denotes the figure of the next higher assembly. For all subassemblies, the number in this column denotes the figure showing additional detailed breakdown.

### SYMBOL USAGE

**Hardware Designators** — Alpha designators for screws (S), washers (W), nuts (N), and retaining rings (R) are inserted after the item number callouts on the illustration when stacked item numbers are used.

**Attaching Hardware** — The @ symbol is inserted before any part that is used as attaching hardware. Attaching hardware is denoted as those parts that are not an integral part of the referenced assembly.

**(NFR) Not Field Repairable** — The (NFR) symbol is inserted after any assembly that is not to be field dismantled.

**Other Symbols** — Any other symbols that are required for kits, accessories, etc., will be explained and appear as part of the item description.

## REVISION HISTORY

PRINTING	ECO LEVEL	DATE	PAGES AFFECTED
1st Printing	BA11K 00004-00004	12-26-74	N/A

Copyright ©1974, by Digital Equipment Corporation

DEC reserves the right, without notice, to make substitutions and modifications in the specifications of products documented in this manual and further reserves the right to withdraw any of these products from the market without notice.

DEC is not responsible for errors which may appear in the technical description (including illustrations and photographs) of the products covered by this manual.

None of the descriptions contained in this manual imply the granting of any license whatsoever to make, use or sell equipment constructed in accordance therewith.






FIG & ITEM NO.	DESCRIPTION	DEC PART NO.	ECO CUT-IN BA11K 00004	USED ON CODE	VENDOR		REF FIG NO.
					CODE	PART NO.	
1-	BA11-K MOUNTING BOX ASSEMBLY Code A - Used on Model BA11-KE 115 Vac 50/60 Hz Code B - Used on Model BA11-KF 230 Vac 50/60 Hz Code C - Used on Model BA11-KH 115 Vac 50/60 Hz Code D - Used on Model BA11-KJ 230 Vac 50/60 Hz	BA11-KE BA11-KF BA11-KH BA11-KJ		A B C D			
1	*Chassis	70-09769-00					
2	*H765A Power Supply Assy. 115 V 50/60 Hz	H765-A		A,C	See IPB Manual DEC-H765-IPB		
	*H765B Power Supply Assy. 230 V 50/60 Hz	H765-B		B,D			
3	*Screw, Phl. Flat Hd. No. 10-32 x .50	90-09599-00					
4	*Screw, Phl Flat Hd. No. 6-32 x .25 (Fastens Power Distribution Board to Chassis)	90-06020-02					
5	*Slide, (3 Position Tilt) (1 Pr.)	12-11825-00		A,B			
6	*Screw, Phl. Truss Hd. No. 10-32 x .38	90-06071-03					
7	*Nut, Kep No. 10-32	90-06565-00		A,B			
8	*Washer, Ext. Tooth No. 10	90-07651-00		A,B			
9	*Card Guide	12-11630-00					
10	*Trough, Chassis Cable	74-12184-00		C,D			
11	*Screw, Phl Pan Hd. No. 6-32 x .25 (Self-Tap)	90-08408-01					
12	*Washer, Int. Tooth Lock No. 6	90-06633-00					
13	*Latch Molding	12-09224-00		A,B			
14	*Screw, Phl Flat Hd. No. 10-32 x .31	90-06070-02		A,B			
15	*Cover, Panel, 10½ Bezel	H950-QB		A,B			
16	*Cover, Chassis	70-09768-00		A,B			
17	*Screw, Phl. Truss Hd. No. 6-32 x .25	90-06020-03		A,B			
18	*Sticker, "Configuration" DEC-3-(374)-1825-N1174			A,B			
19	*Shipping Bracket Assembly	70-10059-00		A,B			
20	*Unibus Cable (10 ft.) (Not Shown)	BC11A-10		A,B			

## ILLUSTRATED PARTS BREAKDOWN COMMENT SHEET

Any and all comments and suggestions for correcting errors and/or additional information to improve this manual will be reviewed and researched for possible use when this manual is revised and/or reprinted. Enter your comments and suggestions in the form provided below and return to Technical Documentation.

MODEL \_\_\_\_\_

PUBLICATION NO. \_\_\_\_\_

FIGURE NO. \_\_\_\_\_ ITEM NO. \_\_\_\_\_

FIGURE NO. \_\_\_\_\_ ITEM NO. \_\_\_\_\_

CHANGE FROM \_\_\_\_\_

CHANGE FROM \_\_\_\_\_

CHANGE TO \_\_\_\_\_

CHANGE TO \_\_\_\_\_

FIGURE NO. \_\_\_\_\_ ITEM NO. \_\_\_\_\_

FIGURE NO. \_\_\_\_\_ ITEM NO. \_\_\_\_\_

CHANGE FROM \_\_\_\_\_

CHANGE FROM \_\_\_\_\_

CHANGE TO \_\_\_\_\_

CHANGE TO \_\_\_\_\_

FIGURE NO. \_\_\_\_\_ ITEM NO. \_\_\_\_\_

FIGURE NO. \_\_\_\_\_ ITEM NO. \_\_\_\_\_

CHANGE FROM \_\_\_\_\_

CHANGE FROM \_\_\_\_\_

CHANGE TO \_\_\_\_\_

CHANGE TO \_\_\_\_\_

ADDITIONAL COMMENT(S)

Name \_\_\_\_\_

Cost Center \_\_\_\_\_

date: \_\_\_\_\_

Fold Here

Do Not Tear - Fold Here and Staple

FIRST CLASS  
PERMIT NO. 33  
MAYNARD, MASS.

**BUSINESS REPLY MAIL**  
**NO POSTAGE STAMP NECESSARY IF MAILED IN THE UNITED STATES**

Postage will be paid by:

Digital Equipment Corporation  
Technical Documentation Department  
Digital Park, PK3-2  
Maynard, Massachusetts 01754

