

BA123 Enclosure Maintenance

Order Number EK-188AA-MG-001

**digital equipment corporation
maynard, massachusetts**

October 1988

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation.

Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software, if any, described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license. No responsibility is assumed for the use or reliability of software or equipment that is not supplied by Digital Equipment Corporation or its affiliated companies.

© Digital Equipment Corporation. 1988. All rights reserved.

Printed in U.S.A.

The **READER'S COMMENTS** form on the last page of this document requests the user's critical evaluation to assist in preparing future documentation.

The following are trademarks of Digital Equipment Corporation:

DEC	MicroVAX	ULTRIX
DECmate	MicroVMS	UNIBUS
DECnet	PDP	VAX
DECUS	P:OS	VAXBI
DECwriter	Professional	VAXELN
DELNI	Q-bus	VAXcluster
DEQNA	Rainbow	VAXstation
DESTA	RSTS	VMS
DIBOL	RSX	VT
MASSBUS	RT	Work Processor
MicroPDP-11	ThinWire	

ML-S976

FCC NOTICE: The equipment described in this manual generates, uses, and may emit radio frequency energy. The equipment has been type tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such radio frequency interference when operated in a commercial environment. Operation of this equipment in a residential area may cause interference, in which case the user at his own expense may be required to take measures to correct the interference.

Contents

Preface	vii
---------	-----

Chapter 1 BA123 Enclosure Description

1.1	Mass Storage Device Areas	1-1
1.2	Backplane	1-3
1.3	Signal Distribution Board	1-5
1.4	Power Supply	1-8
1.5	Control Panel	1-11
1.6	I/O Panel	1-14
1.7	Air Circulation	1-16
1.8	Configuration Guidelines	1-18
1.8.1	Module Order and Configuration	1-18
1.8.2	Configuration Worksheet	1-19

Chapter 2 Installation

2.1	Preparing the Site	2-1
2.1.1	Dimensions	2-1
2.1.2	Additional Equipment	2-2
2.1.3	Acoustics	2-3
2.1.4	Operating Environment	2-3
2.1.5	Static Electricity	2-3
2.1.6	Heat Dissipation	2-3
2.1.7	Environmental Specifications	2-4
2.1.8	Electrical Requirements	2-4
2.2	Unpacking the Shipment	2-5
2.3	Installing the BA123 System	2-6

Chapter 3 FRU Removal and Replacement

3.1	FRUs	3-1
3.2	Accessing FRUs	3-3
3.2.1	Right Side Panel	3-4
3.2.2	Left Side Panel	3-6
3.2.3	Top Cover	3-8
3.3	Modules	3-9
3.4	On/Off Switch	3-11
3.5	CPU Console Board	3-11
3.6	Mass Storage Devices	3-13
3.7	Fans	3-13
3.7.1	Mass Storage Fan	3-13
3.7.2	Card Cage Fan	3-15
3.8	Power Supply	3-17
3.9	Door Interlock Switch	3-19
3.10	Temperature Sensor Board	3-21
3.11	Backplane	3-21
3.12	CPU I/O Insert	3-23
3.13	MicroVAX Battery Backup Unit (BBU)	3-23

Appendix A Related Documentation

Index

Figures

1-1	BA123 Enclosure	1-1
1-2	BA123 Mass Storage Slots	1-2
1-3	BA123 Backplane Grant Continuity and Jumpers	1-3
1-4	BA123 Signal Distribution Board (M9058)	1-5
1-5	BA123 Signal Distribution Board Cabling	1-7
1-6	BA123 Power Supply	1-8
1-7	BA123 Power Supply Controls and Connectors (Rear View)	1-10
1-8	BA123 Control Panel	1-11

1-9	BA123 CPU Console Board	1-12
1-10	BA123 I/O Panel	1-14
1-11	BA123 Adapter Plate and Filtered Connectors.....	1-15
1-12	BA123 Temperature Sensor Board	1-17
1-13	BA123 Configuration Worksheet	1-23
2-1	BA123 Enclosure Dimensions	2-2
2-2	Opening the Rear Door	2-7
2-3	BA123 CPU I/O Inserts	2-9
2-4	Connecting the Console Terminal to the CPU I/O Insert (Example).....	2-10
2-5	Connecting External Devices	2-11
2-6	Checking the Voltage Setting	2-12
2-7	Attaching the Power Cord	2-13
3-1	BA123 FRUs	3-3
3-2	Removing the Right Side Panel	3-5
3-3	Removing the Right Inner Panel	3-6
3-4	Removing the Left Side Panel	3-7
3-5	Removing the Inner Left Panel	3-8
3-6	Removing Modules	3-10
3-7	Removing the On/Off Switch	3-11
3-8	Removing the CPU Console Board	3-12
3-9	Removing the Mass Storage Fan	3-14
3-10	Removing the Card Cage Fan (Older Systems)	3-16
3-11	Removing the Power Supply	3-18
3-12	Door Interlock Switch and Temperature Sensor Connection .	3-20
3-13	Removing the Backplane	3-22
3-14	Disconnecting the Battery Backup Unit Cable.....	3-24
3-15	Removing the Battery Backup Unit	3-25

Tables

1-1	BA123 Signal Distribution Board Jumpers	1-6
1-2	Regulators A and B Power and Current.....	1-9
1-3	CPU Console Board Controls and Indicators	1-13
1-4	BA123 Cutout and Insert Panel Size	1-15
1-5	Power, Bus Load, and I/O Insert Data	1-19
2-1	BA123 Environmental Specifications	2-4

2-2	240 V Power Cords	2-5
2-3	BA123 Electrical Requirements	2-5
2-4	BA123 Shipment Contents	2-6
3-1	BA123 FRUs	3-2

Preface

This guide provides reference, installation, and maintenance information for the BA123 enclosure. This enclosure is intended for MicroPDP-11 and MicroVAX systems.

Intended Audience

This document is intended only for DIGITAL Field Service personnel and qualified self-maintenance customers.

Organization

This guide has three chapters and one appendix.

Chapter 1 provides an overview of the system enclosure, describing controls, mass storage area and capacity, backplane, signal distribution, power distribution, I/O connections, and configuration guidelines.

Chapter 2 lists site preparation considerations and shows how to install the BA123 system.

Chapter 3 describes how to remove and replace field replaceable units (FRUs). The beginning of the chapter contains a list of these FRUs.

Appendix A provides a list of related documentation.


Warnings, Cautions, and Notes

Warnings, cautions, and notes appear throughout this guide. They have the following meanings:

WARNING Provides information to prevent personal injury.

CAUTION Provides information to prevent damage to equipment or software.

NOTE Provides general information about the current topic.




Chapter 1

BA123 Enclosure Description

This chapter describes the BA123, which is a caster-mounted office enclosure (Figure 1-1).

Figure 1-1: BA123 Enclosure



MLO-000076

1.1 Mass Storage Device Areas


The BA123 has five 13.3-cm (5.25-in) mass storage slots (Figure 1-2). However, power considerations usually limit the enclosure to a total of four mass storage devices.

Here is a typical configuration:

Slots 1, 2	RD50-series fixed-disk drives or other devices
Slot 4	TK50 tape drive
Slot 5	RX50 diskette drive

You can also connect external mass storage devices to the BA123, if their enclosures meet requirements for electromagnetic interference (EMI). (All DIGITAL enclosures meet requirements for EMI.)

Figure 1-2: BA123 Mass Storage Slots




MLO-000077

1.2 Backplane

The BA123 has a 13-slot backplane that measures 27.9 cm x 19.9 cm (11 in x 7.85 in). The backplane implements the extended LSI-11 bus, which uses 22-bit addressing. The common name for the LSI-11 bus is the Q22-bus.

The first 12 slots of the backplane are for dual- or quad-height modules compatible with the Q22-bus. Each backplane slot has four rows: A, B, C, and D (Figure 1-3).

Figure 1-3: BA123 Backplane Grant Continuity and Jumpers



MLO-000078

A *dual-height* module has connectors that fit into two rows of a backplane slot. Two dual-height modules can occupy one backplane slot.

A *quad-height* module has connectors that fit into all four rows of a backplane slot. One quad-height module occupies one backplane slot.

As a rule, if you use dual-height modules in the AB or CD rows of slots 5 through 8, you must install another dual-height module, or an M9047 grant card, in the other two rows of each slot. The exception is the last dual-height module installed on the grant continuity chain. For example, if the last dual-height module is in the AB rows of slot 9, you do not need a grant card in the CD rows. Figure 1-3 shows the grant continuity chain.

The CD rows of slots 1 through 4 are interconnected. This feature is called the private memory interconnect (PMI). You should only use memory modules in the CD rows.

The backplane has four 120-ohm resistor packs between slots 12 and 13. These resistor packs terminate the Q22-bus. You cannot connect another backplane to the BA123.

Slot 13 of the backplane does not implement the Q22-bus. The CD rows are for the signal distribution board. The AB rows are for future use. Slot 13 provides +5 Vdc, +12 Vdc ground and the DCOK signal, which indicates that the dc voltage from the power supply is stable.

The backplane supports a maximum of 38 ac loads and 20 dc loads for MicroVAX, and 45 ac loads and 20 dc loads for MicroPDP-11 systems. An *ac load* is the amount of capacitance a module presents to a bus signal line. One ac load equals 9.35 picofarads (pf). A *dc load* is the amount of dc leakage a module presents to a bus signal line. One dc load is about 105 microamperes (μ A).

Figure 1-3 shows three J connectors on the backplane. J1 and J2 are 18-pin connectors that receive dc power and signals from two independent regulators in the power supply. The backplane balances the load on each of the two regulators, A and B.


- Regulator A connects to J1, supplying the odd-numbered slots and the resistor packs.
- Regulator B connects to J2, supplying the even-numbered slots.

J3 is a 10-pin connector for a cable to the CPU console board.

1.3 Signal Distribution Board

The signal distribution board (Figure 1-4) *must* be installed in the bottom two rows (CD) of the last slot (13) of the backplane. If needed, a second signal distribution board can be installed in the AB rows of slot 13. Table 1-1 lists the jumper settings for the module.

Figure 1-4: BA123 Signal Distribution Board (M9058)



MLC-000079

Table 1–1: BA123 Signal Distribution Board Jumpers

Jumper	Setting¹	Meaning
W1, W2	Out	Grant continuity not maintained.
W1, W2	In	Grant continuity maintained.
W3	In	DRV SEL 3 connected to DS1–DS4 of J1.
	Out	DRV SEL 3 connected to DS3 of J1.
W4	In	DRV SEL 4 connected to DS1–DS4 of J2.
	Out	DRV SEL 4 connected to DS4 of J2.
W5	In	DRV SEL 1 connected to DS1–DS4 of J3.
	Out	DRV SEL 1 connected to DS1 of J3.
W6	In	DRV SEL 2 connected to DS1–DS4 of J4.
	Out	DRV SEL 2 connected to DS2 of J4.
TP1 to TP2		DRV SEL 1 and 2 connected to DS1 and DS2 of J11.
TP1 to TP3		DRV SEL 2 connected to DS1 and DS2 of J11.


¹The factory position appears first.

Jumpers W3 through W6 determine the connections between the drive select lines from a fixed-disk drive controller (DRV SEL 1 through DRV SEL 4) and a fixed-disk drive (DS1 through DS4). As long as these jumpers are inserted, you can configure the drives to respond to any drive select line.

TP1 and TP2 determine the connections between the drive select lines from a diskette drive controller (DRV1 through DRV4) and a diskette drive (DS1 through DS4). For an RX50, connect TP1 to TP2 for both drives.

You can connect up to four fixed-disk drives (or an RX50 diskette drive and two fixed-disk drives) to the signal distribution board. A 50-conductor ribbon cable connects the board to an RQDX mass storage controller module in the card cage. Another ribbon cable connects the board to the RD console boards behind the control panel. Figure 1–5 shows the cabling between the signal distribution board and the rest of the system.

Figure 1-5: BA123 Signal Distribution Board Cabling



MLO 000080

1.4 Power Supply

The power supply (Figure 1-6) is a 460-watt unit with two regulators. Each regulator supplies power to one-half of the slots in the backplane and to mass storage devices inside the system.

The power supply provides protection against excess voltage and current. The power supply regulators maintain proper output voltages against temporary fluctuations in the ac input to the power supply. Table 1-2 lists the minimum and maximum currents supplied by each regulator.

Figure 1-6: BA123 Power Supply




Table 1–2: Regulators A and B Power and Current

Regulator	Power	+5 Vdc		+12 Vdc	
	Max ¹	Min	Max	Min	Max
A	230 W	4.5 A	36.0 A	0 A	7.0 A
B	230 W	4.5 A	36.0 A	0 A	7.0 A

¹Total power used from each regulator must not exceed 230 W. This means the system cannot draw the maximum current at +5 Vdc and +12 Vdc for both regulators at the same time.


The power supply has two other +12 Vdc outputs that are independent of the main 460-watt output. These outputs drive the two fans that are external to the power supply. The outputs also provide power to the temperature sensors above the card cage.

The power supply also has the following controls and connectors at the rear (Figure 1–7):

- Circuit breaker to protect the power cable
- Connector for remote control of power
- Voltage select switch
 - 120 V = 88 to 128 Vac
 - 240 V = 176 to 256 Vac
- International Electrical Commission (IEC) ac input connector, compatible with international power cables

NOTE: *A minimum of 90 Vac (88 to 128 Vac setting) should be present at the outlet for low-line operation, to compensate for line cord voltage drop.*

Figure 1-7: BA123 Power Supply Controls and Connectors (Rear View)




MLO-000082

1.5 Control Panel

The control panel has six cutouts to provide space for control circuits (Figure 1-8):


- One cutout is for a CPU console board. This cutout contains the Restart button, the DC OK LED, and the Halt button (Figure 1-8). To see the CPU console board (Figure 1-9), you must remove the enclosure's left side panel.
- The other five cutouts are for mass storage console boards. Unused cutouts are covered with removable plates.

Figure 1-8: BA123 Control Panel



MLO-000083

Figure 1-9: BA123 CPU Console Board



MLO-000084

The CPU console board has two regulator LEDs that indicate failures in the regulator supply to the backplane. If the DC OK indicator turns off, these two LEDs indicate which regulator supply failed:

- Left LED off = regulator A failed
- Right LED off = regulator B failed

If a regulator LED is on, that regulator is providing +5 Vdc within tolerance to the backplane.

NOTE: *There should be at least one module in both even- and odd-numbered backplane slots to draw enough current to start each regulator.*

A ribbon cable connects the CPU console board to the backplane. This cable provides the connection between the CPU and the CPU console board.

Table 1-3 lists the controls and indicators on the CPU console board.

Table 1–3: CPU Console Board Controls and Indicators

Control/Indicator	Setting	Description
Restart		Momentary-contact pushbutton. When you press Restart , the system simulates a power-down/power-up sequence to restart CPU operation. You can enable or disable the Restart switch by using switch 2.
DC OK		Green LED indicator.
	On	All dc voltages are present and within tolerance.
	Off	The Q22-bus BDCOK (dc bus power OK) signal is negated.
Halt ¹		Pushbutton switch with red LED indicator.
	Out (LED off)	Puts the CPU in program I/O mode (normal position for running user software).
	In (LED on)	Stops normal software operation. Puts the CPU in console mode, where the system accepts only console commands.
+5 V and +12 V test points		Used to test the system.
Switch 1		Enables the Q22-bus BEVENT timing signal and allows the line time clock to function under software control.
Switch 2		To enable Restart, set switch 2 to on. To disable Restart, set switch 2 to off.


¹MicroVAX: You can disable the Halt switch by setting the halt enable switch on the CPU I/O insert to the disable position (dot outside of circle). In this case, pressing **Halt** turns on the red indicator but does not halt the system.

1.6 I/O Panel

The I/O panel (Figure 1-10) connects external devices to the BA123. Each device connects to a module in the system through a filtered connector. You mount the connector on an insert, then install the insert in a cutout on the I/O panel. Filtered connectors and inserts are included with the option's cabinet kit.

The I/O panel has ten cutouts in two sizes, types A and B. You mount inserts in the order shown (by letter) in Figure 1-10. Usually, the CPU I/O insert is in cutout A. Unused cutouts are covered by removable plates. Table 1-4 lists the size of the cutouts and their corresponding inserts.

Figure 1-10: BA123 I/O Panel




MLO-000085

Table 1-4: BA123 Cutout and Insert Panel Size

Type	Quantity	Description	Inches	Millimeters
A	4	Cutout	0.6 x 3.2	15 x 81
		Insert panel	1.0 x 4.0	25 x 102
B	6	Cutout	2.25 x 3.2	57 x 81
		Insert panel	2.5 x 3.3	64 x 84

You can add three more type-A cutouts by removing the bracket post between the bottom two type-B cutouts and installing an adapter plate (part no. 74-27720-01). Figure 1-11 shows the adapter plate with typical type A and B inserts.

Figure 1-11: BA123 Adapter Plate and Filtered Connectors



1.7 Air Circulation

Three fans draw air in from the top of the enclosure:

- One below the module card cage
- One behind the control panel
- One inside the power supply


A printed circuit board above the card cage contains two temperature sensors (Figure 1-12):

- One regulates the speed of the card cage fan.
- One shuts down the system at high temperature.

The temperature sensors keep the speed of the card cage fan at the minimum level required to maintain a constant temperature within the card cage.

The card cage panel (new systems) or door (older systems) encloses the area surrounding the modules. When the panel or door is removed, an interlock switch is triggered that increases the speed of the card cage fan to maximum. If the proper temperature within the card cage cannot be maintained, even at maximum fan speed, the over-temperature sensor causes the system to shut down.

Figure 1-12: BA123 Temperature Sensor Board



MLO-000087

1.8 Configuration Guidelines

Before you change a system's configuration, consider the following factors:

- Module order in the backplane
- Module configuration
- Mass storage device configuration

If you are adding a device to a system, you must know the capacity of the system enclosure in these areas:

- Backplane
- I/O panel
- Power supply
- Mass storage devices

1.8.1 Module Order and Configuration

The order of modules in the backplane depends on four factors:

- Relative use of devices in the system
- Expected performance of each device relative to other devices
- Ability of a device to tolerate delays between bus requests and bus grants (delay tolerance)
- Tendency of a device to prevent devices farther from the CPU from accessing the bus

The relative use and performance of devices depends on the application. This means the order of modules also depends on the application. Most applications try to balance the use of devices. For balanced applications, use the recommended module order listed in the appropriate CPU maintenance documentation. Make sure you read the rules and guidelines discussed in the CPU documentation; they affect the recommended order.

When devices do not perform as expected, you can change the recommended order of modules to meet the needs of the application. Performance problems often involve a device that is heavily used or has a low delay tolerance. Usually, there are other heavily used devices between the problem device and the CPU. In this case, move the problem device closer to the CPU.

NOTE: *If the option has Q/CD jumpers, check the options documentation for the correct Q/CD jumper configurations. An incorrect jumper configuration can cause damage.*

For information on how to configure modules, refer to *Microsystems Options*.

1.8.2 Configuration Worksheet

Use the BA123 configuration worksheet (Figure 1–13) to make sure a configuration does not exceed a system's limits for expansion space, I/O space, power, and bus loads. If you use standard DIGITAL modules, you will not exceed the limits for bus loads.

Use the worksheet as follows:

1. On the worksheet, list all the devices already installed in the system.
2. List all the devices you plan to install in the system.
3. Fill in the information for each device, using the data listed in Table 1–5.
4. Add up the columns. Make sure the totals are within the limits for the enclosure.

NOTE: Check the CPU documentation to determine which options are supported for a specific system.

Table 1–5: Power, Bus Load, and I/O Insert Data

Option	Module	Current (Amps)		Power	Bus Loads		Insert ¹
		+5 V	+12 V	Watts	AC	DC	
AAV11–D ²	A1009	1.8	0.0	9.0	1.0	1.0	–
ADV11–D ²	A1008	3.2	0.0	16.0	1.0	1.0	–
CXA16–M	M3118–YA	1.6	0.2	10.4	3.0	0.5	–
CXB16–M	M3118–YB	2.0	0.0	10.0	3.0	0.5	–
CXY08–M	M3119–YA	1.64	0.395	12.94	3.2	0.5	–
DEQNA	M7504	3.5	0.5	23.5	2.8	0.5	A
DFA01	M3121–PA	1.97	0.40	14.7	3.0	1.0	–
DHV11	M3104	4.5	0.55	29.1	2.9	0.5	B (2)
DLVEI–DP	M8017	1.0	1.5	23.0	1.6	1.0	A
DLVJ1	M8043	1.0	0.25	8.0	1.0	1.0	B
DMV11–M	M8053	3.4	0.4	21.8	2.0	1.0	A
DMV11–AP	M8053–MA	3.4	0.38	21.6	2.0	1.0	B
DMV11–BP	M8053–MA	3.4	0.38	21.6	2.0	1.0	A

¹A = 2.5 cm x 10.0 cm (1 in x 4 in).

B = 5.0 cm x 7.5 cm (2 in x 3 in).

²Usually connected through a universal data input panel (UDIP), using a 13.3-cm (5.25-in) mass storage slot.

Table 1–5 (Cont.): Power, Bus Load, and I/O Insert Data

Option	Module	Current (Amps)		Power Watts	Bus Loads		Insert ¹
		+5 V	+12 V		AC	DC	
DMV11-CP	M8064-MA	3.35	0.26	19.9	2.0	1.0	B
DMV11-FP	M8053-MA	3.4	0.38	21.6	2.0	1.0	A (2)
DMV11-N	M8064	3.4	0.4	21.8	2.0	1.0	A
DPV11	M8020	1.2	0.3	9.6	1.0	1.0	A
DRV11	M7941	0.9	0.0	4.5	2.8	1.0	A (2)
DRV11-BP	M7950	1.9	0.0	9.5	3.3	1.0	A (2)
DUV11-DP	M7951	1.2	0.39	10.7	3.0	1.0	A (2)
DRV11-J	M8049	1.8	0.0	9.0	2.0	1.0	A (2)
DZQ11	M3106	1.0	0.36	9.32	1.5	1.0	B
DZV11	M7957	1.2	0.39	10.7	3.9	1.0	B
IEQ11	M8634	3.0	0.0	15.0	2.0	1.0	B
KA620-AA	M7478	6.2	0.14	32.7	2.7	1.0	-
KA630-AA	M7606	6.2	0.14	32.7	2.7	1.0	-
KA650-AA	M7620-A	6.0	0.14	31.7	2.7	1.0	-
KDA50-Q ³	M7164	6.93	0.0	34.65	3.0	0.5	-
KDA50-Q	M7165 ⁴ C or D rev	6.57	0.03	33.21	-	-	-
KDA50-Q	M7165 ⁴ E rev	4.07	0.03	20.71	-	-	-
KDF11-BE	M8189	5.5	0.1	28.7	2.3	1.1	B
KDJ11-BC	M8190	5.5	0.1	28.7	2.3	1.1	B
KDJ11-BF	M8190	5.5	0.2	29.9	2.6	1.0	-
KLES1	M7740	3.0	0.0	15.0	2.3	1.0	A
KMV11	M7500	2.6	0.2	15.4	3.0	1.0	B
KWV11-C ²	M4002	2.2	0.013	11.2	1.0	1.0	-
LPV11	M8027	0.8	0.0	4.0	1.4	1.0	A
MRV11-D ⁵	M7942	1.6	0.0	8.0	3.0	0.5	-
MRV11-D	M7942	2.8	0.0	14.0	1.8	1.0	-

¹A = 2.5 cm x 10.0 cm (1 in x 4 in).

B = 5.0 cm x 7.5 cm (2 in x 3 in).

²Usually connected through a universal data input panel (UDIP), using a 13.3-cm (5.25-in) mass storage slot.

³KDA50-Q is a two-module set (M7164/M7165). AC and DC bus loads listed = total for both modules.

⁴The etch revision letter C, D, or E is part of the module part number near the handle. For example, a part number xxxxx-Ex-x is a revision E module.

⁵Unpopulated module.

Table 1-5 (Cont.): Power, Bus Load, and I/O Insert Data

Option	Module	Current (Amps)		Power	Bus Loads		Insert ¹
		+5 V	+12 V	Watts	AC	DC	
M9060-YA		5.3	0.0	26.5	0.0	0.0	-
MS630-AA	M7607	1.0	0.0	5.0	0.0	0.0	-
MS630-BA	M7608	1.8	0.0	9.0	0.0	0.0	-
MS630-BB	M7608	1.8	0.0	9.0	0.0	0.0	-
MS630-CA	M7609	3.1	0.0	15.5	0.0	0.0	-
MS650-AA	M7621-A	2.7	0.0	13.5	0.0	0.0	-
MSV11-JD	M8637-D	3.74	0.0	18.7	2.7	0.5	-
MSV11-JE	M8637-E	4.1	0.0	20.5	2.7	0.5	-
MSV11-PK	M8067-K	3.45	0.0	17.25	2.0	1.0	-
MSV11-PL	M8067-L	3.6	0.0	17.5	2.0	1.0	-
MSV11-QA	M7551-AA	2.4	0.0	12.0	2.0	1.0	-
RA70		3.3	2.9	51.3	-	-	-
RC25		1.0	2.5	35.0	-	-	-
RD51		1.0	1.6	24.2	-	-	-
RD52		1.0	2.5	35.0	-	-	-
RD53		0.9	2.5	34.5	-	-	-
RD54		1.3	1.34	23.7	-	-	-
RD54A-EA		1.3	1.34	22.6	-	-	-
RLV12-AP	M8061	5.0	0.10	26.2	2.7	1.0	A
RQDX1	M8639-YA	6.4	0.25	35.0	2.0	1.0	-
RQDX2	M8639-YB	6.4	0.1	33.2	2.0	1.0	-
RQDX3	M7555	2.48	0.06	13.2	1.0	1.0	-
RQDXE	M7513	0.5	0.0	2.5	1.0	0.0	-
RX33		0.5	0.3	5.6	-	-	-
RX50		0.85	1.8	25.9	-	-	-
TK50		1.35	2.4	33.55	-	-	-
TK50-AA		1.35	2.4	34.5	-	-	-
TK50E-EA		1.35	2.4	35.6	-	-	-
TK70E-EA		1.5	2.4	36.3	-	-	-
TQK25-KA	M7605	4.0	-	20.0	2.0	1.0	A
TQK50	M7546	2.9	0.0	14.5	2.8	0.5	-
TSV05	M7196	6.5	0.0	32.5	3.0	1.0	A

¹A = 2.5 cm x 10.0 cm (1 in x 4 in).

B = 5.0 cm x 7.5 cm (2 in x 3 in).

Table 1–5 (Cont.): Power, Bus Load, and I/O Insert Data

Option	Module	Current (Amps)		Power	Bus Loads		Insert¹
		+5 V	+12 V	Watts	AC	DC	
VCB01	M7602	4.6	1.5	42.0	3.0	1.0	B
VCB02	M7169	5.8	0.75	38.0	3.5	1.0	B
VCB02	M7168	3.4	0.0	17.0	0.0	0.0	–

¹A = 2.5 cm x 10.0 cm (1 in x 4 in).
B = 5.0 cm x 7.5 cm (2 in x 3 in).

Figure 1-13: BA123 Configuration Worksheet

ADD THESE COLUMNS

SLOT	MODULE	REGULATOR A			REGULATOR B			I/O INSERTS	
		CURRENT +5 VDC	(AMPS) +12 VDC	POWER (WATTS)	CURRENT +5 VDC	(AMPS) +12 VDC	POWER (WATTS)	B	A
1	AB								
	CD								
2	AB								
	CD								
3	AB								
	CD								
4	AB								
	CD								
5	AB								
	CD								
6	AB								
	CD								
7	AB								
	CD								
8	AB								
	CD								
9	AB								
	CD								
10	AB								
	CD								
11	AB								
	CD								
12	AB								
	CD								
13	AB	0.52		2.60					
	CD								
MASS STORAGE SHELF DEVICE									
5*		↓	↓	↓	↓	↓	↓	↓	↓
4									
3									
2									
1									
COLUMN TOTALS		—	—	—	—	—	—	—	—
MUST NOT EXCEED:		36 A	7 A	230 W	36 A	7 A	230 W	6	4**

*RECOMMENDED FOUR DRIVES MAXIMUM - TWO IN SHELVES 1 AND 2, TWO IN 3, 4, OR 5
 **IF MORE THAN FOUR 1 X 4 I/O PANELS ARE REQUIRED, AN ADAPTER TEMPLATE MAY BE USED

MLO-000088



Chapter 2

Installation

This chapter provides site preparation and installation guidelines for the BA123 enclosure.

2.1 Preparing the Site


Before you unpack the BA123 enclosure shipment, verify the physical, environmental, and electrical site requirements.

2.1.1 Dimensions

Figure 2–1 shows the dimensions of a BA123 enclosure. The figure also shows the dimensions of the shipping container.

WARNING: *Use two people to handle the shipping container and enclosure. The shipping container and the enclosure together weigh 100 kg (220 lb); the enclosure weighs 59 kg (130 lb).*

Figure 2-1: BA123 Enclosure Dimensions



MLO-000089

2.1.2 Additional Equipment

Make sure there is sufficient space for terminals and other peripheral equipment. The temperature and humidity at which mass storage media are kept should be the same as that of the computer area.

When you plan the cable routing for multiple-terminal systems, consider factors such as safety, convenience, future expansion, and cost. You should have cabling in place and labeled before you install the system.

2-2 BA123 Enclosure Maintenance

2.1.3 Acoustics

The BA123 pedestal enclosure is designed for use in offices and other general working areas. The following are acoustic emission and heat dissipation levels for the BA123. Levels may be lower, depending on the kind and number of mass storage devices in the system. Data is measured in accordance with ANSI S12.10–1985 (American National Standards Institute) and ISO/DIS 7779 (International Standards Organization).

- LNPE (B) is the noise power emission level (A-weighted sound power level) measured in bels re 1 pw (reference 1 picowatt). LNPE for the BA123 enclosure is 6.0.
- LPA is the sound pressure measured in decibels at 1.0 m (3.3 ft) from the front edge of the unit and 1.5 m (5.0 ft) above the floor. LPA for the BA123 enclosure is 46.

2.1.4 Operating Environment

Computer systems located in office areas are subject to discharge of static electricity, temperature changes, and humidity.

You should install the system in a well-ventilated area where the temperature and humidity ranges listed in Section 2.1.7 are maintained throughout the year. Rapid temperature changes may affect system performance. Therefore, systems should not be operated near heating or cooling devices, large windows, or doors that open to the outside. Air should contain a minimum of dust and other abrasive contaminants.

2.1.5 Static Electricity

Static electricity can cause system failure and loss of data. To minimize static buildup, follow these guidelines:

- Maintain relative humidity of at least 40%.
- Place the system away from busy office corridors.
- Avoid using carpeting in the computer area, if possible. If carpeting is to be installed, antistatic carpeting is recommended. If carpeting is already in place, place an antistatic mat under the system.

2.1.6 Heat Dissipation

Heat dissipates in the BA123 enclosure system at the rate of 2355 Btu per hour.

2.1.7 Environmental Specifications

Table 2-1 shows the temperature ranges, humidity ranges, and altitude limits for systems in the BA123 enclosure.

Table 2-1: BA123 Environmental Specifications

Parameter	Range
Temperature	Operating: ¹ 10°C to 40°C 50°F to 104°F
	Nonoperating: -40°C to 60°C -40°F to 140°F
Temperature rate of change	Operating: 11°C per hour maximum 19.8°F per hour maximum
Relative humidity	Operating: 20% to 80% (noncondensing)
	Nonoperating: 10% to 95%
Maximum altitude	Operating: 2440 m (8000 ft)
	Nonoperating: 4900 m (16,000 ft)

¹For operation above sea level, decrease the operating temperature by 1.8°C per 1000 m (or 1°F per 1000 ft).

2.1.8 Electrical Requirements

The power source should be adequate to handle the original system and allow for system expansion. DIGITAL recommends a dedicated circuit from the power source to each micro system. Additional power equipment may be required to avoid power disturbances.

Table 2-2 lists power cord information for 240 V operation of systems in the BA123 enclosure. Table 2-3 lists electrical requirements for systems in the BA123 enclosure.

Table 2–2: 240 V Power Cords

Power Cord Number	Countries
BN02A–2E	United Kingdom and Ireland
BN03A–2E	Austria, Belgium, Czechoslovakia, Finland, France, Germany, Hungary, Netherlands, Norway, Poland, Portugal, Spain, and Sweden
BN04A–2E	Switzerland
BN05A–2E	Australia and New Zealand
BN06A–2E	Denmark
BN07A–2E	Italy

Table 2–3: BA123 Electrical Requirements

Nominal ac Voltage ⇒	100 Vac	120 Vac	220–240 Vac
Voltage range	90–110 Vac	104–128 Vac	191–256 Vac
Power source phase	Single	Single	Single
Nominal frequency	50–60 Hz	50–60 Hz	50–60 Hz
Frequency range	47–63 Hz	47–63 Hz	47–63 Hz
Maximum steady state current at nominal voltage	10.5 A	8.8 A	4.4 A
Maximum steady state current at minimum voltage	12 A	11.0 A	5.5 A
Maximum inrush current	100 A	100 A	100 A
Maximum power consumption	690 W	690 W	690 W

2.2 Unpacking the Shipment

Unpack all boxes and check the contents listed in Table 2–4. Instructions for unpacking the system box are on the shipping carton.

Table 2-4: BA123 Shipment Contents

Description	Qty.	Part No.
Basic BA123 enclosure	1	BA123
Signal distribution board	1	M9058
RQDX-to-M9058 cable	1	17-01520-01
Cable for M9058 to 5 disk control panels	1	17-00862-01
RX cable	1	17-00867-01
TK cable	1	17-01047-01
Disk control panel	4	70-22393-01
Disk data cable	4	17-00282-01
Disk control cable	4	17-00286-01
Half-height filler panel	3	74-31478-01
BA123 accessory kit	1	70-22382-03
Console panel assembly (MicroPDP-11 only)	1	70-21150-02
Console backplane cable	1	17-00624-01
Cable 20-pin console	1	17-00712-02
Function Sel/SLU console connect (MicroVAX only)	1	54-16744-01

In addition to the above parts, the shipment may include some of the following equipment:

- Additional terminal(s)
- Printer(s)
- Modem(s)
- Cables for connecting additional devices


2.3 Installing the BA123 System

To install the BA123-based system, perform the following steps:

1. After unpacking the system enclosure, move it to where it will be used. Carefully roll the enclosure into position. Be sure to:
 - a. Allow enough space around the unit for air circulation and servicing. The system requires 5.08 cm (2 in) for ventilation on each side. You should leave about 61 cm (2 ft) at the rear of the system to connect cables and access controls behind the rear cover.
 - b. Keep food and liquid away from the enclosure.
 - c. Place the enclosure away from heaters, photocopiers, and direct sunlight.

- d. Minimize static by placing the enclosure away from busy office corridors.
- e. Keep the area free from dust and other abrasive materials.
2. Unpack the installation and user guides for the console terminal, which is the first terminal you connect to the system.
3. Follow the installation guide to unpack and install the console terminal.
4. Open the rear door of the enclosure. The door is held in place by a pop fastener (Figure 2-2).

Figure 2-2: Opening the Rear Door



MLO-000090

5. Set the controls on the CPU I/O insert found at the rear of the enclosure to the following positions:

MicroVAX (Figure 2-3)

- a. Set the baud rate for the console terminal serial line to 9600 on the 8-position rotary. Also set the baud rate on the console terminal to 9600; the baud rates must match.
- b. Set the mode to the middle position (language inquiry) on the 3-position rotary.

Arrow—Run (factory position). If the console terminal supports the Multinational Character Set (MCS), you are prompted for language only if the battery backup has failed. Full start-up diagnostics are run.

Face—Language inquiry. If the console terminal supports the MCS, you are prompted for language on every power-up and restart. Full start-up diagnostics are run.

T in a circle—Test. ROM programs run wraparound serial line unit (SLU) tests.

- c. Set the halt enable/disable switch to the disable position (down) on this 2-position rotary.


Dot outside circle—Halts are disabled (factory position). On power-up or restart, the system attempts to load software from one of the devices at the completion of start-up diagnostics.

Dot inside circle—Halts are enabled. On power-up or restart, the system enters console I/O mode at the completion of start-up diagnostics.

MicroPDP-11 (Figure 2-3)

- a. Set the baud rate for the console terminal serial line to 9600. Also set the baud rate on the console terminal to 9600; the baud rates must match.


Figure 2-3: BA123 CPU I/O Inserts



MLO-000091

6. Connect the console terminal cable to the console terminal and the enclosure (Figure 2-4).


Figure 2-4: Connecting the Console Terminal to the CPU I/O Insert (Example)



MLO-000092

7. Install and connect any external devices. Refer to Figure 2-5. External devices may include terminals, printers, modems, and storage devices. The devices may be connected in any order. Refer to the installation guide included with each device.

Figure 2-5: Connecting External Devices




MLO-000093

8. Check the voltage switch setting on the rear of the power supply (Figure 2-5). Peel back the label covering the switch to see the voltage setting. If necessary, change the switch setting to match the voltage source you are using (Figure 2-6).


CAUTION: *Be careful to set the voltage correctly. An incorrect voltage switch setting can damage your system.*

Figure 2-6: Checking the Voltage Setting




9. Set the power switch on the front of the enclosure to 0 (off).
10. Plug the power cord into the power supply and the wall outlet (Figure 2-7). Thread all the cables through the lower cable guide.

Figure 2-7: Attaching the Power Cord



MLO-000095

11. The installation of the BA123 enclosure is now complete. Refer to the CPU maintenance documentation for procedures on running power-up self-tests and diagnostics.



FRU Removal and Replacement

This chapter describes how to remove and replace the field replaceable units (FRUs) in the BA123 enclosure.

Each section describes the removal procedure for that FRU. Unless otherwise specified, you can install an FRU by reversing the steps in the removal procedure.

CAUTION:

- *Only qualified service personnel should remove or install FRUs.*
- *Before you remove any FRU, always power down the system and remove the ac power cord.*
- *Static electricity can damage integrated circuits. Use the wrist strap and antistatic mat found in the Antistatic Kit when you work with the internal parts of a computer system.*

3.1 FRUs


Table 3–1 lists the BA123 FRUs and their part numbers. Refer to the applicable CPU documentation for CPU-specific part numbers and supported options. All options are also FRUs. Refer to *Microsystems Options* for option kit numbers.

Figure 3–1 shows the major FRUs.

Table 3–1: BA123 FRUs

FRU	Part Number
20-conductor RD drive cable	17-00282-01
40-conductor RD drive cable	17-00286-01
50-conductor cable, RQDX to signal distribution board	17-01520-01
AC power switch and cable from switch to power supply	17-00859-01
Battery backup unit, CPU insert panel (MicroVAX)	12-19245-01
Cable, backplane to CPU console board	17-00860-01
Cable, MicroVAX memory interconnect	17-00716-01
Cable, power supply to card cage fan and temperature sensor	17-00863-01
Cable, power supply to mass storage fan	17-00864-01
Cable, regulator A to backplane	17-01311-02
Cable, regulator B to backplane	17-01311-02
Cable, regulator A to 2 drives via 2 plugs	17-01356-01
Cable, regulator B to 3 drives via 3 plugs	17-00911-01
Cable, signal distribution board to 4 RD consoles	17-00862-01
Cable, signal distribution board to RX50	17-00867-01
Cable, TK50-to-M7546 interconnect	17-01047-01
Card cage fan, 12.7 cm (5 in)	12-23395-01
Door interlock switch and cable from switch to temperature sensor board	17-00942-01
Mass storage fan, 11.4 cm (4.5 in)	12-22271-01
Power supply	30-23616-01/ 30-28231-01
Q22-bus quad-height backplane (13 slots)	54-17507-01
RD5n console read/write protect panel	54-16244-02
Signal distribution board	M9058
Shock-isolating caster, fixed (2)	12-23985-01
Shock-isolating caster, swivel (2)	12-23985-02
Temperature sensor board	54-16665-01

Figure 3-1: BA123 FRUs



3.2 Accessing FRUs

Before you can remove most FRUs in the BA123 enclosure, you must remove one or more side panels. Removing a side panel is the first step in many of the FRU procedures.

3.2.1 Right Side Panel


Remove the right side panel as follows:

1. Turn off the system and unplug the ac power cord from the wall socket.
2. Open the rear door.

Refer to Figure 3–2 for steps 3 through 5.

3. Loosen the captive screw that connects the right side panel to the rear of the enclosure frame.
4. Two snap fasteners hold the bottom of the panel to the frame. Pull out the bottom of the panel until you release the fasteners.
5. Lift the panel slightly to release it from the lip at the top of the frame. Remove the panel.


Figure 3–2: Removing the Right Side Panel



MLO-000097

6. Newer systems also have an inner panel. To remove, unscrew the two quarter-turn fasteners at the base of the panel (Figure 3–3).

Figure 3–3: Removing the Right Inner Panel



MLO-000098

3.2.2 Left Side Panel


Remove the left side panel as follows:

1. Turn off the system and unplug the ac power cord from the wall outlet.
2. Open the control panel door.

Refer to Figure 3–4 for steps 3 through 5.

3. Loosen the screw that holds the left side panel to the front of the enclosure frame.
4. Two snap fasteners hold the bottom of the panel to the frame. Pull out the bottom of the panel until you release the fasteners.
5. Lift the panel slightly to release it from the lip at the top of the frame. Remove the panel.


Figure 3-4: Removing the Left Side Panel



MLO-000099

6. Newer systems also have an inner panel. To remove, unscrew the two quarter-turn fasteners at the base of the panel (Figure 3-5).

Figure 3–5: Removing the Inner Left Panel



3.2.3 Top Cover

Remove the top cover as follows:

1. Open the rear door.
2. Remove the screw at the top of the frame, above the I/O panel. This screw holds a bracket connected to the top cover.
3. Four tabs hold the top cover in place. To release the cover, push it back as far as it will go (about 2.5 cm; 1 in).
4. Lift the top cover off the frame.

3.3 Modules

Remove modules as follows:

CAUTION:


- *Static electricity can damage integrated circuits. Use the wrist strap and antistatic mat found in the Antistatic Kit when you work with modules.*
- *Remove and install modules carefully, to avoid damaging the modules or changing switch settings.*
- *New modules come wrapped in special antistatic packaging material, with a silica gel packet to prevent damage from moisture. Use both materials to protect any modules you store, transport, or return.*

1. Remove the outer and inner right side panels (Section 3.2.1).
2. Older systems have a card cage door instead of an inner panel. Release the two clasps at the front end of the door and swing the door open. Remove the door from its hinges. Figure 3–6 shows the removed card cage door.
3. Quad-height modules have levers (Figure 3–6) to lock the module in the backplane. When you remove a quad-height module, use the levers to slide the module partially out of the backplane. Pull the levers firmly toward you. Apply pressure evenly to both levers.

Dual-height modules do not have levers; they simply slide in and out of their slots.

4. Label and disconnect any cables connected to the module.
5. Note the module's location in the backplane, then remove the module.

Figure 3–6: Removing Modules



Installation Notes


- Make sure the jumper and switch settings on the new module are the same as those on the removed module.
- If you install a dual-height module in slots 1 through 4 of the backplane, you must install it in the AB rows. If no modules are installed in the AB rows, you must install a grant continuity card (M9407).
- You can install dual-height modules in either the AB or CD rows of slots 5 through 12. The other two rows of the slot must contain either another dual-height module or a grant continuity card.

3.4 On/Off Switch

Remove the on/off switch as follows:

1. Remove the outer and inner left side panels (Section 3.2.2).
2. Unplug the on/off switch cable from the rear of the power supply (see Figure 3-1 for cable connection).
3. Remove the nut that holds the cable's ground lead (Figure 3-7) to the BA123. Disconnect the ground lead.
4. Press the top and bottom of the on/off switch, then push out the switch and its cable from the inside of the front panel (Figure 3-7).

Figure 3-7: Removing the On/Off Switch



MLO-000102


3.5 CPU Console Board

Remove the CPU console board from the control panel as follows:

1. Remove the outer and inner left side panels (Section 3.2.2).
Refer to Figure 3-8 for steps 2 through 4.
2. Disconnect the ribbon cable from the CPU console board.

3. Remove the two screws that hold the CPU console board assembly to the control panel.
4. Remove the board from the plastic brackets.

Figure 3–8: Removing the CPU Console Board



MLO-000103

3.6 Mass Storage Devices

Remove 13-cm (5.25-in) drives as follows:

CAUTION:

- *Static electricity can damage integrated circuits. Use the wrist strap and antistatic mat found in the Antistatic Kit when you work with mass storage devices.*
 - *Do not turn off the system, or a TK-series tape drive if you have a TK cartridge in place. Never put your hands or other objects in the cartridge opening.*
 - *Handle any fixed-disk drive with care; dropping or bumping the drive can damage the disk surface.*
1. Remove the outer and inner side panels (Sections 3.2.1 and 3.2.2).
 2. The front panel has four snap fasteners that hold the panel to the BA123. Remove the front panel by pulling it from the frame until you release the fasteners.
 3. Disconnect all signal cables and dc power cords from the device.
 4. Push down on the release tab under the front of the drive, then slide the device out of the shelf.

See *Microsystems Options* for procedures on removing mass storage device FRUs.

3.7 Fans

You can remove the mass storage fan and the card cage fan. The fan in the power supply is not an FRU.


3.7.1 Mass Storage Fan

Remove the mass storage fan as follows:

1. Remove the outer and inner left side panels (Section 3.2.2).
2. Unplug the dc power cord from the fan (Figure 3–9). The plug is curved to fit the fan. When you replace the fan, make sure to align the plug the same way.
3. Remove the three screws that hold the fan's metal base plate to the BA123 (Figure 3–9). Note the fan's alignment. Make sure to align the new fan in the same direction.

4. On older systems, remove the four screws that hold the fan to the metal base plate. On newer systems, snap out the fan from the metal base plate.

Figure 3-9: Removing the Mass Storage Fan



MLO-000104

3.7.2 Card Cage Fan


Remove the card cage fan as follows:

1. Remove the outer and inner right side panels (Section 3.2.1).
2. Older systems have a card cage door instead of an inner panel. Remove the door by releasing the two clasps at the front end of the door and swinging the door open.

Refer to Figure 3–10 for steps 3 through 5.

3. Slide the tray below the card cage partially out.
4. Unplug the dc power cord from the fan. The plug is curved to fit the fan. When you replace the fan, make sure to align the plug the same way.
5. On older systems, remove the four screws that hold the fan to the tray. On newer systems, snap out the fan from the tray.

Figure 3-10: Removing the Card Cage Fan (Older Systems)



MLO-000105


3.8 Power Supply

Remove the power supply as follows:

1. Remove the outer and inner left side panels (Section 3.2.2).
2. Note the location and alignment of all cables connected to the power supply. Disconnect all cables, including the ac power cord at the rear of the system.
3. Unfasten the four quarter-turn fasteners holding the power supply to the enclosure (Figure 3–11). Remove the power supply.

CAUTION: *Before you install a new power supply, make sure the setting of the voltage select switch at the rear of the power supply is correct. An incorrect setting can cause damage to the system.*

Figure 3-11: Removing the Power Supply




MLO-000106

3.9 Door Interlock Switch

Remove the door interlock switch as follows:

1. Remove the outer and inner right side panels (Section 3.2.1).
2. Older systems have a card cage door instead of an inner panel. Remove the door by releasing the two clasps at the front end of the door and swinging the door open.
3. Figure 3–12 shows the cable connecting the interlock switch to the temperature sensor board. Disconnect the cable from the temperature sensor board.
4. Remove the two screws that hold the switch to the side of the card cage.
5. Remove the switch and the cable.

Figure 3–12: Door Interlock Switch and Temperature Sensor Connection



ML0-000107

3.10 Temperature Sensor Board

Remove the temperature sensor board as follows:


1. Remove the outer and inner right side panels (Section 3.2.1).
2. Older systems have a card cage door instead of an inner panel. Remove the door by releasing the two clasps at the front end of the door and swinging the door open.
3. Figure 3–12 shows the cable connecting the interlock switch to the temperature sensor board. Disconnect this cable from the temperature sensor board.
4. Find the cable connecting the temperature sensor board to the power supply. Disconnect this cable from the temperature sensor board.
5. Remove the temperature sensor board from the four plastic brackets that hold it to the frame.

3.11 Backplane

Remove the backplane as follows:

1. Remove the outer and inner side panels (Sections 3.2.1 and 3.2.2).
2. Slide all modules partially out of the backplane, including the signal distribution board.
3. Remove the power supply (Section 3.8).
4. Find the metal plate between the backplane and the power supply. Remove the nine screws that hold the plate to the BA123: six on the front and three on the side (Figure 3–13).
5. Lift the metal plate and the backplane out of the rear of the card cage.
6. Remove the screws that hold the metal plate to the backplane.

Figure 3-13: Removing the Backplane



Installation

1. Install the screws that hold the metal plate to the backplane.
2. Place the backplane and the metal plate at the back of the card cage.
3. Insert the nine screws that hold the metal plate to the card cage, but do not tighten.
4. Insert modules in the first and last card guides of the card cage. This step aligns the backplane with the card cage guides.
5. Tighten the screws on the metal plate.
6. Check the alignment of the backplane by inserting all the modules in their original slots.
7. Replace the power supply by reversing the steps in Section 3.8.

3.12 CPU I/O Insert

Remove the CPU I/O insert as follows:

1. Turn off the system and unplug the ac power cord from the wall outlet.
2. Open the rear door.
3. Disconnect the console terminal cable from the CPU I/O insert.
4. Remove the outer and inner right side panels (Section 3.2.1).
5. Older systems have a card cage door instead of an inner panel. Release the two clasps at the front end of the door and swing the door open. Remove the door by disengaging its hinges.

NOTE: *Some internal cables connected to the back of I/O inserts may not be keyed. Note the alignment of internal cables and make sure you reconnect them the same way.*


6. Label and disconnect cables that connect the CPU I/O insert to modules inside the enclosure.
7. Remove the screws that hold the CPU I/O insert to the I/O panel. Figure 1-11 shows the orientation of the inserts on the I/O panel.
8. Remove the CPU I/O insert.

3.13 MicroVAX Battery Backup Unit (BBU)

Remove the battery backup unit for the time-of-year clock as follows:


1. Remove the CPU I/O insert, using the procedure in Section 3.12.
2. Remove the batteries from the CPU I/O insert:
 - a. Disconnect the battery backup unit cable from the CPU I/O insert (Figure 3-14).

Figure 3–14: Disconnecting the Battery Backup Unit Cable



- b. Carefully spread the plastic holder and pop out the battery backup unit (Figure 3–15).

Figure 3–15: Removing the Battery Backup Unit



MLO-000111



Appendix A

Related Documentation

The following documents contain information relating to MicroVAX or MicroPDP-11 systems.

Document Title	Order Number
Modules	
CXA16 Technical Manual	EK-CAB16-TM
CXY08 Technical Manual	EK-CXY08-TM
DEQNA Ethernet User's Guide	EK-DEQNA-UG
DHV11 Technical Manual	EK-DHV11-TM
DLV11-J User's Guide	EK-DLV1J-UG
DMV11 Synchronous Controller Technical Manual	EK-DMV11-TM
DMV11 Synchronous Controller User's Guide	EK-DMV11-UG
DPV11 Synchronous Controller Technical Manual	EK-DPV11-TM
DPV11 Synchronous Controller User's Guide	EK-DPV11-UG
DRV11-J Interface User's Manual	EK-DRV1J-UG
DRV11-WA General Purpose DMA User's Guide	EK-DRVWA-UG
DZQ11 Asynchronous Multiplexer Technical Manual	EK-DZQ11-TM
DZQ11 Asynchronous Multiplexer User's Guide	EK-DZQ11-UG
DZV11 Asynchronous Multiplexer Technical Manual	EK-DZV11-TM
DZV11 Asynchronous Multiplexer User's Guide	EK-DZV11-UG
IEU11-A/IEQ11-A User's Guide	EK-IEUQ1-UG
KA630-AA CPU Module User's Guide	EK-KA630-UG
KA640-AA CPU Module User's Guide	EK-KA640-UG
KA650-AA CPU Module User's Guide	EK-KA650-UG
KDA50-Q CPU Module User's Guide	EK-KDA5Q-UG
KDJ11-B CPU Module User's Guide	EK-KDJ1B-UG
KDJ11-D/S CPU Module User's Guide	EK-KDJ1D-UG
KDF11-BA CPU Module User's Guide	EK-KDFEB-UG
KMV11 Programmable Communications Controller User's Guide	EK-KMV11-UG
KMV11 Programmable Communications Controller Technical Manual	EK-KMV11-TM

Document Title	Order Number
Modules	
LSI-11 Analog System User's Guide	EK-AXV11-UG
Q-Bus DMA Analog System User's Guide	EK-AV11D-UG
RQDX2 Controller Module User's Guide	EK-RQDX2-UG
RQDX3 Controller Module User's Guide	EK-RQDX3-UG
Disk and Tape Drives	
RA60 Disk Drive Service Manual	EK-ORA60-SV
RA60 Disk Drive User's Guide	EK-ORA60-UG
RA81 Disk Drive Service Manual	EK-ORA81-SV
RA81 Disk Drive User's Guide	EK-ORA81-UG
SA482 Storage Array User's Guide (for RA82)	EK-SA482-UG
SA482 Storage Array Service Manual (for RA82)	EK-SA482-SV
RC25 Disk Subsystem User's Guide	EK-ORC25-UG
RC25 Disk Subsystem Pocket Service Guide	EK-ORC25-PS
RRD50 Subsystem Pocket Service Guide	EK-RRD50-PS
RRD50 Digital Disk Drive User's Guide	EK-RRD50-UG
RX33 Technical Description Manual	EK-RX33T-TM
RX50-D, -R Dual Flexible Disk Drive Subsystem Owner's Manual	EK-LEP01-OM
TK50 Tape Drive Subsystem User's Guide	EK-LEP05-UG
TS05 Tape Transport Pocket Service Guide	EK-TSV05-PS
TS05 Tape Transport Subsystem Technical Manual	EK-TSV05-TM
TS05 Tape Transport System User's Guide	EK-TSV05-UG

Document Title	Order Number
Systems	
MicroVAX Special Systems Maintenance	EK-181AA-MG
630QB Maintenance Print Set	MP-02071-01
630QE Maintenance Print Set	MP-02219-01
630QY Maintenance Print Set	MP-02065-01
630QZ Maintenance Print Set	MP-02068-01
BA23 Enclosure Maintenance	EK-186AA-MG
BA123 Enclosure Maintenance	EK-188AA-MG
BA213 Enclosure Maintenance	EK-189AA-MG
BA214 Enclosure Maintenance	EK-190AA-MG
BA215 Enclosure Maintenance	EK-191AA-MG
H9642-J Cabinet Maintenance	EK-187AA-MG
H9644 Cabinet Maintenance	EK-221AA-MG
KA630 CPU System Maintenance	EK-178AA-MG
KA640 CPU System Maintenance	EK-179AA-MG
KA650 CPU System Maintenance	EK-180AA-MG
KDF11-B CPU System Maintenance	EK-245AA-MG
KDJ11-D/S CPU System Maintenance	EK-246AA-MG
KDJ11-B CPU System Maintenance	EK-247AA-MG
MicroPDP-11 Hardware Information Kit (for BA23)	00-ZYAAA-GZ
MicroPDP-11 Hardware Information Kit (for BA123)	00-ZYAAB-GZ
MicroPDP-11 Hardware Information Kit (for H9642-J)	00-ZYAAE-GZ
MicroPDP-11 Hardware Information Kit (for BA213)	00-ZYAAS-GZ
Microsystems Options	EK-192AA-MG
Microsystems Site Preparation Guide	EK-O67AB-PG
MicroVAX II Hardware Information Kit (for BA23)	00-ZNAAA-GZ
MicroVAX II Hardware Information Kit (for BA123)	00-ZNAAB-GZ
MicroVAX II Hardware Information Kit (for H9642-J)	00-ZNAAE-GZ
MicroVAX 3500 Customer Hardware Information Kit	00-ZNAES-GZ
MicroVAX 3600 Customer Hardware Information Kit (for H9644)	00-ZNAEF-GZ
VAXstation 3200 Owner's Manual (BA23)	EK-154AA-OW
VAXstation 3500 Owner's Manual (BA213)	EK-171AA-OW
VAXstation II/GPX Owner's Manual (BA23)	EK-106AA-OW
VAXstation II/GPX Owner's Manual (BA123)	EK-105AA-OW

Document Title	Order Number
Diagnostics	
DEC/X11 Reference Card	AV-F145A-MC
DEC/X11 User's Manual	AC-FO53D-MC
XXDP User's Manual	AZ-GNJAA-MC
XXDP DEC/X11 Programming Card	EK-OXXDP-MC
MicroVAX Diagnostic Monitor Ethernet Server User's Guide	AA-FNTAC-DN
MicroVAX Diagnostic Monitor Reference Card	AV-FMXAA-DN
MicroVAX Diagnostic Monitor User's Guide	AA-FM7AB-DN
Networks	
Ethernet Transceiver Tester User's Manual	EK-ETHTT-UG
VAX/VMS Networking Manual	AA-Y512C-TE
VAX NI Exerciser User's Guide	AA-HI06A-TE

A

Air circulation
fans, 1-16

B

Backplane, 1-3
ac loads, 1-4
connectors, 1-4
dc loads, 1-4
description, 1-3
dimensions, 1-3
dual-height modules, 1-3
grant continuity, 1-4
quad-height modules, 1-3
regulators, 1-4
removal and replacement, 3-21
resistor packs, 1-4
Battery backup unit (BBU), 3-23
Baud rate, 2-8
Bus loads, 1-19 to 1-22

C

Card cage door, 1-16
Configuration
backplane description, 1-4
capacity, 1-18
jumpers, 1-18
module order, 1-18
module power and bus loads,
1-19 to 1-22
rules and guidelines, 1-18
worksheet, 1-19
Connecting external devices, 2-11
Control panel, 1-11 to 1-12
controls and indicators, 1-11

CPU console board, 1-12
controls and indicators, 1-13
removal and replacement, 3-11
CPU I/O insert
removal and replacement, 3-23
setting controls, 2-7

D

Disk drives
removal and replacement, 3-13
typical configuration, 1-2
Door interlock switch
removal and replacement, 3-19

E

Electrical requirements, 2-5

F

Fans
air circulation, 1-16
card cage, removal and
replacement, 3-15
mass storage, removal and
replacement, 3-13
Field replaceable units (FRUs),
3-1 to 3-25
backplane, 3-21
card cage fan, 3-15
CPU console board, 3-11
door interlock switch, 3-19
exterior panels, 3-3
fans, 3-13
left side panel, 3-6
mass storage devices, 3-13
mass storage fan, 3-13
modules, 3-9

Field replaceable units (FRUs)
(cont'd.)

- on/off switch, 3-11
- part numbers, 3-2
- power supply, 3-17
- removal precautions, 3-1
- right side panel, 3-4, 3-5
- temperature sensor board, 3-21
- time-of-year clock battery, 3-23

Filtered connectors, 1-14

G

Grant continuity, backplane, 1-4

H

Humidity ranges, 2-4

I

I/O panel

- adapter plate, 1-15
- cutouts, 1-14
- description, 1-14
- filtered connectors, 1-14
- inserts, 1-14

Inserts, 1-14

Installation

- additional devices, 2-11
- baud rate, MicroPDP-11, 2-8
- baud rate, MicroVAX, 2-8
- console terminal, 2-7
- controls, CPU I/O insert, 2-7
- language selection, MicroVAX, 2-8
- opening rear door, 2-7
- power cord, 2-13
- shipment parts list, 2-6
- SLU tests, MicroVAX, 2-8
- ventilation, 2-6
- voltage switch setting, 2-11

L

Left side panel

- removal and replacement, 3-6

Index-2

M

Mass storage

- locations, 1-1
- removal and replacement, 3-13
- typical configuration, 1-1

Module order, 1-18

Modules

- backplane description, 1-3
- power and bus load data, 1-19 to 1-22
- removal and replacement, 3-9
- removal precautions, 3-9

O

On/off switch

- removal and replacement, 3-11

P

Part numbers, FRUs, 3-2

Parts list, BA123 shipment, 2-6

Power cords, 2-4

Power supply

- attaching power cord, 2-13
- description, 1-8
- minimum/maximum currents, 1-9
- rear controls, 1-9
- removal and replacement, 3-17

Q

Q/CD jumpers, 1-18

R

Rear door, 2-7

Related documentation, A-1 to A-4

Right side panel

- removal and replacement, 3-4, 3-5

S

Signal distribution board

- cabling, 1-7
- connections, 1-6

- jumper settings, 1-6
- location, 1-5
- Site preparation, 2-1
 - acoustics, 2-2
 - altitude limits, 2-4
 - BA123 dimensions, 2-1
 - electrical, 2-5
 - humidity ranges, 2-4
 - operating environment, 2-3
 - static electricity precautions, 2-3
 - temperature ranges, 2-4

T

- Temperature ranges, 2-4
- Temperature sensor board, 1-16

- Temperature sensors
 - removal and replacement, 3-21
- Time-of-year clock battery
 - removal and replacement, 3-23
- Top cover
 - removal and replacement, 3-8

U

- Unpacking the shipment, 2-5

V

- Ventilation, 2-6
- Voltage switch setting, 2-11



NOTES



HOW TO ORDER

ADDITIONAL DOCUMENTATION

From	Call	Write
Alaska, Hawaii, or New Hampshire	603-884-6660	Digital Equipment Corporation P.O. Box CS2008 Nashua, NH 03061
Rest of U.S.A. and Puerto Rico*	1-800-DIGITAL	
* Prepaid orders from Puerto Rico must be placed with DIGITAL's local subsidiary (809-754-7575)		
Canada	800-267-6219 (for software documentation) 613-592-5111 (for hardware documentation)	Digital Equipment of Canada Ltd. 100 Herzberg Road Kanata, Ontario, Canada K2K 2A6 Attn: Direct Order desk
Internal orders (for software documentation)	—	Software Distribution Center (SDC) Digital Equipment Corporation Westminster, MA 01473
Internal orders (for hardware documentation)	DTN: 234-4323 (508) 351-4323	Publishing & Circulation Serv. (P&CS) NR03-1/W3 Digital Equipment Corporation Northboro, MA 01532



Reader's Comments

BA123 Enclosure Maintenance
EK-188AA-MG-001

Your comments and suggestions will help us improve the quality of our future documentation. Please note that this form is for comments on documentation only.

I rate this manual's:	Excellent	Good	Fair	Poor
Accuracy (product works as described)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Completeness (enough information)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Clarity (easy to understand)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Organization (structure of subject matter)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Figures (useful)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Examples (useful)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Index (ability to find topic)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Page layout (easy to find information)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

What I like best about this manual: _____

What I like least about this manual: _____

My additional comments or suggestions for improving this manual:

I found the following errors in this manual:

Page	Description
_____	_____
_____	_____
_____	_____

Please indicate the type of user/reader that you most nearly represent:

- | | |
|---|---|
| <input type="checkbox"/> Administrative Support | <input type="checkbox"/> Scientist/Engineer |
| <input type="checkbox"/> Computer Operator | <input type="checkbox"/> Software Support |
| <input type="checkbox"/> Educator/Trainer | <input type="checkbox"/> System Manager |
| <input type="checkbox"/> Programmer/Analyst | <input type="checkbox"/> Other (please specify) _____ |
| <input type="checkbox"/> Sales | |

Name/Title _____ Dept. _____

Company _____ Date _____

Mailing Address _____

_____ Phone _____

Do Not Tear — Fold Here and Tape

digitalTM



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO.33 MAYNARD MASS.

POSTAGE WILL BE PAID BY ADDRESSEE

**DIGITAL EQUIPMENT CORPORATION
CORPORATE USER PUBLICATIONS
MLO5-5/E45
146 MAIN STREET
MAYNARD, MA 01754-2571**



Do Not Tear — Fold Here

Cut Along Dotted Line