


VTV31-K

VTV31-K VID INTF DIAG
CZVTVAO

AH-T061A-MC
FICHE 1 OF 1

APR 1982
COPYRIGHT © 1982
MADE IN USA



.REM 8

IDENTIFICATION

PRODUCT CODE: AC-T059A-MC
PRODUCT NAME: CZVTVAO VTV31K VID INTF DIAG
PRODUCT DATE: 19-OCT-81
MAINTAINER: C.S.S., READING, U.K.
AUTHOR: DAVE HUNTER

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1982 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES

- 2.0 OPERATING INSTRUCTIONS
 - 2.1 COMMANDS
 - 2.2 SWITCHES
 - 2.3 FLAGS
 - 2.4 HARDWARE QUESTIONS
 - 2.5 SOFTWARE QUESTIONS
 - 2.6 CLOCK QUESTIONS
 - 2.7 QUICK STARTUP PROCEDURE
- 3.0 ERROR INFORMATION
- 4.0 PERFORMANCE AND PROGRESS REPORTS
- 5.0 DEVICE INFORMATION TABLES
- 6.0 TEST SUMMARIES
 - 6.1 LOGIC TESTS
 - 6.2 VISUAL TESTS

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

THIS DIAGNOSTIC PROGRAM CHECKS THE FUNCTIONALITY OF THE VTV31-K VIDEO INTERFACE. TEN TESTS ARE PROVIDED TO VERIFY THE VTV31-K HARDWARE, AND IN ADDITION, ONE TEST OUTPUTS PATTERNS FOR SETTING UP A DISPLAY MONITOR.

THE TESTS ARE AS FOLLOWS:

- TEST 1 - REGISTER NXM
- TEST 2 - REGISTER ACCESS
- TEST 3 - REGISTER ADDRESS UNIQUENESS
- TEST 4 - REGISTER BIT SET
- TEST 5 - PICTURE STORE DATA
- TEST 6 - PICTURE STORE COLUMN ADDRESSING
- TEST 7 - PICTURE STORE LINE ADDRESSING
- TEST 8 - 8-DOT
- TEST 9 - PRESET
- TEST 10 - VIDEO ENABLE
- TEST 11 - DISPLAY ADDRESSING
- TEST 12 - OFFSET
- TEST 13 - PATTERN GENERATOR

IN TESTS 1 TO 9, SPECIFIC VALUES ARE WRITTEN TO THE DEVICE REGISTERS AND THE CSR READ TO CONFIRM THAT THE REQUIRED OPERATION IS PERFORMED. TESTS 10 TO 13 ARE VISUAL ONLY. ALTHOUGH THEY WILL RUN WITHOUT A DISPLAY MONITOR, NO CHECKS ARE MADE BY THE PROGRAM. OBSERVATION BY THE OPERATOR IS THEREFORE REQUIRED TO FULLY CHECK THE VTV31K. IN TEST 13, THE OPERATOR CAN CONTROL THE RATE OF CHANGE OF THE DISPLAYED PATTERNS BY SELECTING MANUAL CONTROL IN THE STARTUP QUESTIONS.

IN SEVERAL OF THE TEST DESCRIPTIONS, PICTURE STORE CONTENTS ARE REFERRED TO BY DATA VALUE. THESE DATA VALUES CORRESPOND TO THE

FOLLOWING COLOURS:-

0 = BLACK
1 = RED
2 = GREEN
3 = YELLOW
4 = BLUE
5 = MAGENTA
6 = CYAN
7 = WHITE

EXECUTION TIMES VARY WITH THE CPU TYPE. THE FOLLOWING ARE TYPICAL TIMES OBSERVED ON A PDP-11/23 SYSTEM:

ALL TESTS	16 MINUTES 25 SECONDS
TESTS 1-9	14 MINUTES 40 SECONDS
TESTS 10-13	1 MINUTE 45 SECONDS
TEST 5	10 MINUTES 30 SECONDS

THE PROGRAM SUPPORTS UP TO 20 UNITS, ALL SELECTED TESTS BEING RUN ON ONE UNIT BEFORE PROCEEDING TO THE NEXT. IF DURING ONE PASS, THE NUMBER OF ERRORS DETECTED ON A UNIT EXCEEDS A MAXIMUM VALUE (REQUESTED AT STARTUP), THE UNIT IS DROPPED FROM TESTING. UNIT DROPPING IS PREVENTED IF EITHER THE IDU OR LOE FLAGS HAVE BEEN SELECTED.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

- A. PDP-11 PROCESSOR WITH 16K OR MORE OF MEMORY.
- B. CONSOLE TERMINAL WITH INTERFACE ADDRESS 777560.
- C. XXDP+ SUPPORTED LOAD DEVICE (RX,RM,RK,TM ETC.) OR PAPER TAPE READER.
- D. COLOUR DISPLAY MONITORS (1 FOR EACH VTV31-K).

1.3 RELATED DOCUMENTS AND STANDARDS

XXDP+ USER'S MANUAL. CHQUS

1.4 DIAGNOSTIC HIERARCY PREREQUISITES

BEFORE RUNNING THIS DIAGNOSTIC, THE APPROPRIATE PDP-11 CPU, MEMORY AND PERIPHERAL DIAGNOSTICS SHOULD BE RUN TO VERIFY CORRECT OPERATION OF THE SYSTEM.

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP+ USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY BRIEF DESCRIPTION OF THEM. THE XXDP+ USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ^C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP+ MONITOR (XXDP+ OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SECTION 4.0)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY 'DDDD'.

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDD	EXECUTE DDDDD PASSES (DDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. FLAGS ARE DESCRIBED IN SECTION 2.3.
/EOP:DDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
HOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBE*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXE*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	'BELL' ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDU	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST
EVL	EXECUTE EVALUATION (ON DIAGNOSTICS WHICH HAVE EVALUATION SUPPORT)

*ERROR MESSAGES ARE DESCRIBED IN SECTION 3.1

SEE THE XXDP+ USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A 'BELL' ON ERROR, YOU MAY USE THE FOLLOWING STRING:

```
/FLAGS:LOE:IER:BOE
```

2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING 'CHANGE HW (L) ?' YOU MUST ANSWER 'Y' AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN 'PRELOADED' USING THE SETUP UTILITY (SEE CHAPTER 6 OF THE XXDP+ USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A 'Y', THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL). YOU WILL THEN BE ASKED THE FOLLOWING QUESTION FOR EACH UNIT:

```
VTV31-K ADDRESS (0) 174000 ?
```

IN REPLY, YOU SHOULD ENTER AN ADDRESS IN OCTAL IN THE RANGE 160000 TO 177776. TO PREVENT THE QUESTIONS BEING OUTPUT FOR EACH UNIT, ALL ADDRESSES COULD BE ENTERED IN RESPONSE TO THE FIRST ADDRESS REQUEST AS IN THE FOLLOWING SAMPLE DIALOGUE:

```
# UNITS (D) ? 4<CR>
```

```
UNIT 0
```

```
VTV31-K ADDRESS (0) 174000 ? 174000,174010,174020,174030<CR>
```

2.5 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY 'CHANGE SW (L) ?' IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING 'Y'. THE FOLLOWING QUESTIONS WILL THEN BE ASKED:

```
RUN TEST 13 MANUALLY? (L) N ?  
AUTODROP ERROR COUNT (D) 5 ?
```

TEST 13 OUTPUTS A NUMBER OF DISPLAY PATTERNS TO THE MONITOR. IF YOU ANSWER 'Y' TO THE FIRST QUESTION, EACH PATTERN WILL BE SHOWN UNTIL YOU PRESS THE CARRIAGE RETURN KEY. IF YOU RESPOND TO THE QUESTION BY TYPING 'N' OR CARRIAGE RETURN, EACH PATTERN WILL LAST APPROXIMATELY 5 SECONDS.

THE SECOND QUESTION REFERS TO THE NUMBER OF ERRORS WHICH MAY OCCUR ON A UNIT WITHIN A GIVEN PASS. IF THE NUMBER EXCEEDS THAT WHICH IS ENTERED (OR 5 IF THE RESPONSE IS A CARRIAGE RETURN), THE UNIT IS DROPPED FROM TESTING UNTIL A NEW COMMAND IS ENTERED. DROPPING IS PREVENTED IF EITHER THE IDU OR LOE FLAGS HAVE BEEN SELECTED.

2.6 CLOCK QUESTIONS

IF THERE IS NO LINE TIME CLOCK ON THE SYSTEM, THE USER IS ASKED TO TYPE 2 CHARACTERS 6 SECONDS APART ON THE CONSOLE.

2.7 QUICK START-UP PROCEDURE (XXDP+)

TO START-UP THIS PROGRAM:

1. BOOT XXDP+
2. GIVE THE DATE AND ANSWER THE LSI AND 50HZ (IF THERE IS A CLOCK) QUESTIONS
3. TYPE 'R NAME', WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH 'Y'
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH 'N'

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. THESE DEFAULTS ARE DESCRIBED IN SECTIONS 2.3 AND 2.5.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE 'IER' FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

```
NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
ERROR MESSAGE
```

WHERE: NAME = DIAGNOSTIC NAME
TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
NUMBER = ERROR NUMBER
UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE 'IER' OR 'IBR' FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE 'IER', 'IBR' OR 'IXR' FLAGS ARE SET (SECTION 2.3).

THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

EXTENDED ERROR MESSAGES ARE NOT USED IN THIS DIAGNOSTIC, ALL SUPPLEMENTARY INFORMATION BEING OUTPUT IN THE BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

ALL FAULTS DETECTED BY THE DIAGNOSTIC CAUSE A ONE LINE GENERAL ERROR MESSAGE TO BE PRINTED. THE TEST NUMBER IN WHICH THE FAULT OCCURS IS CONTAINED IN THE HIGHER THREE DIGITS OF THE ERROR NUMBER. THE LOWER TWO DIGITS ARE NUMBERED FROM ZERO FOR EACH TEST.

EACH GENERAL MESSAGE MAY BE FOLLOWED BY A BASIC ERROR MESSAGE CONSISTING OF SEVERAL LINES.

THE FOLLOWING LIST PROVIDES A BRIEF DESCRIPTION OF EACH OF THE ERRORS.

ERROR	DESCRIPTION
00100	'ADDRESSING THE CSR CAUSES AN NXM TRAP' THIS IS PROBABLY CAUSED BY THE DEVICE CSR ADDRESS BEING ENTERED INCORRECTLY.
00101	'ADDRESSING THE DBUFF REGISTER CAUSES AN NXM TRAP' THIS IS PROBABLY CAUSED BY THE DEVICE CSR ADDRESS BEING ENTERED INCORRECTLY.
00200	'CSR READY BIT NOT SET' 'CSR CONTENTS NNNNNN'
00201	'CSR BITS 3 OR 6 NOT CLEAR' 'CSR CONTENTS NNNNNN' BITS OTHER THAN 3 AND 6 MAY BE SET TO 0 OR 1.
00202	'CSR FIELD BIT DOES NOT GET SET' 'CSR CONTENTS NNNNNN'
00203	'CSR FIELD BIT DOES NOT GET CLEARED' 'CSR CONTENTS NNNNNN'
00300	'CSR CHANGED BY WRITING TO DBUFF' 'OLD CSR CONTENTS NNNNNN' 'NEW CSR CONTENTS NNNNNN (IGNORE BITS 0,1,2 AND 4)' ' DATA WRITTEN TO DBUFF NNNNNN' THIS INDICATES ADDRESS INTERACTION BETWEEN THE CSR AND DBUFF REGISTERS.
00400	'COMBINATION OF CSR BITS 5 AND 8 - 15 COULD NOT BE SET.' 'ATTEMPTED SETTING NNNNNN'

'ACTUAL SETTING NNNNNN (IGNORE BITS 0-4 AND 6-7)

INDICATES BIT 'STICKING' OR BIT INTERACTION.

00401 'COMBINATION OF CSR BITS 0 - 2 COULD NOT BE SET VIA
THE DBUFF REGISTER.'
'ATTEMPTED SETTING NNNNNN'
'ACTUAL SETTING NNNNNN (IGNORE BITS 3-15)'

COULD INDICATE BIT SET ERRORS IN THE CSR OR DBUFF
REGISTERS OR AN ERROR IN THE FIRST LOCATION OF THE
PICTURE STORE RAM.

00500 'BACKGROUND COLOUR READ BACK INCORRECTLY'
'LINE NNN (NNN OCTAL), DOT NNN (NNN OCTAL)'
'EXPECTED CONTENTS N, ACTUAL CONTENTS N'

THE ADDRESS LINES HAVE NOT BEEN TESTED AT THIS STAGE.
THEREFORE, THE LINE AND DOT NUMBERS MAY NOT BE THOSE
ACTUALLY WRITTEN TO.

00501 'DATA READ BACK INCORRECTLY FROM PICTURE STORE'
'LINE NNN (NNN OCTAL), DOT NNN (NNN OCTAL)'
'EXPECTED CONTENTS N, ACTUAL CONTENTS N'

AS FOR ERROR 500, THE LINE AND DOT NUMBERS MAY NOT
BE THOSE ACTUALLY WRITTEN TO.

00600 'PICTURE STORE COLUMN ADDRESSING ERROR'
'LINE NNN (NNN OCTAL), DOT NNN (NNN OCTAL)'
'EXPECTED CONTENTS N, ACTUAL CONTENTS N'
'ADDRESS BITS BEING TESTED NNNNNNNNN'

THIS INDICATES INTERACTION BETWEEN THE PICTURE STORE
COLUMN ADDRESS LINES.

00700 'PICTURE STORE LINE ADDRESSING ERROR'
'LINE NNN (NNN OCTAL), DOT NNN (NNN OCTAL)'
'EXPECTED CONTENTS N, ACTUAL CONTENTS N'
'ADDRESS BITS BEING TESTED NNNNNNNNN'

THIS INDICATES INTERACTION BETWEEN THE PICTURE STORE
LINE ADDRESS LINES.

00800 '8 - DOT WRITE FAILURE'
'DOT ADDRESS WRITTEN NNN, FAILING DOT ADDRESS NNN'
'EXPECTED CONTENTS N, ACTUAL CONTENTS N'

HAVING MADE AN 8-DOT WRITE TO THE ADDRESS SHOWN, THE
EXPECTED COLOUR WAS NOT READ BACK FROM THE ADDRESS
GIVEN AS THE FAILING ADDRESS.

00900 'CSR READY NOT CLEAR DURING A PRESET'
'CSR CONTENTS NNNNNN, EXPECTED COLOUR N'

IMMEDIATELY AFTER ISSUING A PRESET COMMAND, THE CSR
READY BIT DID NOT READ BACK AS ZERO.

00901 'CSR READY NOT SET 50 MILLISECONDS AFTER A PRESET'
'CSR CONTENTS NNNNNN, EXPECTED COLOUR'

AFTER A DELAY OF 50 MILLISECONDS FOLLOWING
A PRESET, THE CSR READY BIT WAS NOT SET. IF THE
PRESET DID ACTUALLY OCCUR, THE EXPECTED COLOUR SHOULD
BE SEEN ON THE MONITOR AND BE REFLECTED IN THE CSR.

00902 'DOT NOT SET CORRECTLY AFTER A PRESET'
'LINE NNN (NNN OCTAL), DOT NNN (NNN OCTAL)'
'EXPECTED CONTENTS N, ACTUAL CONTENTS N'

FOLLOWING THE PRESET, THE PICTURE STORE ADDRESS SHOWN
DID NOT CONTAIN THE PRESET COLOUR.

4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE
TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED.
THE 'EOP' SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END
OF PASS MESSAGE IS PRINTED. SECTION 2.2 DESCRIBES SWITCHES.

5.0 DEVICE INFORMATION TABLES

THE HARDWARE PTABLE CREATED AT START UP CONTAINS A SINGLE
WORD ENTRY FOR EACH DEVICE UNDER TEST. THIS WORD IS LOADED
WITH THE DEVICE CSR ADDRESS AS THE HARDWARE QUESTIONS ARE
ANSWERED. AT THE END OF EACH SUBPASS, THE CSR ADDRESS OF THE
NEXT UNIT TO BE TESTED IS LOADED INTO LOCATION VTVCSR. THE
ADDRESS+2 IS LOADED INTO LOCATION DBUFF. THE TEST CODE
REFERENCES THE DEVICE THROUGH THESE TWO LOCATIONS.

6.0 TEST SUMMARIES

ALL OF THE FOLLOWING TESTS ARE RUN WHENEVER THE PROGRAM IS
RUN (BY DEFAULT) UNLESS SPECIFICALLY EXCLUDED BY THE TEST
SWITCH (SECTION 2.2). TESTS 1 TO 9 REQUIRE NO OPERATOR
INTERVENTION, THE DIAGNOSTIC VERIFYING THAT THE REQUIRED
ACTION IS PERFORMED CORRECTLY. THE REMAINING TESTS MUST BE
VERIFIED BY OPERATOR OBSERVATION, ALTHOUGH THEY WILL RUN
WITHOUT A DISPLAY MONITOR ON THE SYSTEM.

6.1 LOGIC TESTS

TEST 1 - REGISTER NXM

CHECKS ARE MADE THAT ACCESSING THE DEVICE CSR AND DBUFF
REGISTERS DOES NOT CAUSE AN NXM TRAP.

TEST 2 - REGISTER ACCESS

THE DEVICE CSR IS READ AND A CHECK MADE THAT THE READY BIT IS
SET, THAT BITS 3 AND 6 ARE CLEAR, AND THAT THE FIELD BIT IS
SET AND CLEARED BY THE DEVICE.

TEST 3 - REGISTER ADDRESS UNIQUENESS

ALL BITS IN THE DBUFF REGISTER ARE SET AND CLEARED IN ALL COMBINATIONS WITH THE EXCEPTION OF BIT 14 (READ PICTURE STORE), WHICH IS LEFT CLEAR. FOR EACH BIT COMBINATION, THE CSR IS READ AND CHECKED TO BE UNCHANGED. CSR BITS 0,1,2 AND 4 ARE IGNORED IN THIS CHECK.

TEST 4 - REGISTER BIT SET

BITS 5 AND BITS 8 TO 15 IN THE CSR ARE SET AND CLEARED IN ALL COMBINATIONS. FOR EACH COMBINATION, THE CSR IS READ AND A CHECK MADE THAT THE RELEVANT BITS ARE SET.

THE DBUFF REGISTER IS THEN USED IN CONJUNCTION WITH THE FIRST PICTURE STORE ELEMENT TO ENSURE THAT CSR BITS 0 - 2 CAN BE SET. CSR BITS 8 - 15 AND DBUFF BITS 0 - 8 ARE CLEAR THROUGHOUT, ENSURING THAT ONLY THE FIRST PICTURE ELEMENT IS USED.

A 'WRITE PICTURE STORE' OPERATION IS PERFORMED USING THE COLOUR BLACK. THE ELEMENT IS THEN READ AND A CHECK MADE THAT CSR BITS 0 - 2 READ ZERO. THIS PROCESS IS REPEATED FOR EACH COLOUR CODE, VERIFYING THAT THE CORRECT COLOUR IS REFLECTED IN THE CSR.

TEST 5 - PICTURE STORE DATA

A ZERO DATA PATTERN (COLOUR BLACK) IS WRITTEN TO THE FIRST PICTURE STORE LOCATION AND CHECKED TO READ BACK CORRECTLY IN THE CSR. THIS IS REPEATED FOR ALL PICTURE LOCATIONS TO FORM AN ALL BLACK BACKGROUND.

DATA IN ALL 8 COMBINATIONS IS THEN WRITTEN TO EACH PICTURE STORE LOCATION IN TURN AND AFTER EACH WRITE OPERATION, THE CSR IS EXAMINED TO ENSURE THAT THE DATA READS BACK CORRECTLY. EACH LOCATION IS RESET TO THE BACKGROUND COLOUR AFTER THE ABOVE OPERATION.

THE ENTIRE TEST IS THEN REPEATED USING WHITE (DATA 7) AS THE BACKGROUND COLOUR.

TEST 6 - PICTURE STORE COLUMN ADDRESSING

THIS VERIFIES THAT WRITING TO ANY COLUMN OF THE PICTURE STORE DOES NOT AFFECT THE CONTENTS OF ANY OTHER COLUMN. SINCE EACH LOCATION CAN HOLD A 3 BIT DATA VALUE, THE COLUMN ADDRESS LINES ARE CHECKED IN GROUPS OF THREE.

COLUMN ADDRESS BITS 0 - 2 ARE CHECKED BY WRITING THE VALUES 0 - 7 IN CONSECUTIVE LOCATIONS THROUGHOUT THE PICTURE STORE AND THEN CHECKING THAT THE DATA READS BACK CORRECTLY VIA THE CSR.

COLUMN ADDRESS BITS 3 - 5 ARE CHECKED BY WRITING ZERO TO THE FIRST 8 LOCATIONS, 1 TO THE NEXT 8 LOCATIONS ETC. UNTIL THE PICTURE STORE IS FULL. THE DATA IS THEN VERIFIED VIA THE CSR.

COLUMN ADDRESS BITS 6 - 8 ARE CHECKED BY WRITING ZERO TO THE

FIRST 64 LOCATIONS, ONE TO THE NEXT 64 LOCATIONS AND SO ON, UNTIL THE PICTURE STORE IS FULL. THE DATA IS THEN VERIFIED VIA THE CSR.

TEST 7 - PICTURE STORE LINE ADDRESSING

THIS VERIFIES THAT WRITING TO ANY LINE OF THE PICTURE STORE DOES NOT AFFECT THE CONTENTS OF ANY OTHER LINE. SINCE EACH LOCATION CAN HOLD A 3 BIT DATA VALUE, THE LINE ADDRESS LINES ARE CHECKED IN GROUPS OF THREE.

LINE ADDRESS BITS 0 - 2 (CSR BITS 8 - 10) ARE CHECKED BY WRITING ZERO TO ALL LOCATIONS IN THE FIRST LINE, ONE TO ALL LOCATIONS IN THE NEXT LINE AND SO ON, UNTIL ALL LINES ARE WRITTEN TO. THE DATA IS THEN READ BACK AND VERIFIED VIA THE CSR.

LINE ADDRESS BITS 3 - 5 (CSR BITS 11 - 13) ARE CHECKED BY WRITING ZERO TO THE FIRST EIGHT LINES, ONE TO THE NEXT EIGHT LINES ETC. TO THE END OF THE PICTURE STORE. THE DATA IS THEN VERIFIED VIA THE CSR.

LINE ADDRESS BIT 6 AND 7 (CSR BITS 14 AND 15) ARE CHECKED BY WRITING ZERO TO THE FIRST 64 LINES, ONE TO THE NEXT 64 LINES, TWO TO THE NEXT 64 LINES, AND THREE TO THE LAST 64 LINES. THE PICTURE STORE DATA IS THEN READ BACK AND VERIFIED.

TEST 8 - 8 DOT

THIS TEST CHECKS THAT IF DBUFF BIT 15 (8-DOT) IS SET, PICTURE STORE WRITES ARE MADE TO EIGHT DOTS AT A TIME, REGARDLESS OF THE VALUES OF DBUFF BITS 0 - 2. FOR EACH COMBINATION OF THE LOWER DOT ADDRESS BITS, A NEW COLOUR IS USED AND THE 8-DOT WRITE VERIFIED.

TEST 9 - PRESET

DBUFF BITS 10 - 12 ARE SET TO THE COLOUR BLACK (ZERO) AND A PRESET IS PERFORMED. THE READY BIT IN THE CSR IS CHECKED TO CLEAR DURING THE PRESET, AND AFTER 50 MILLISECONDS, TO BE SET. THE PICTURE STORE IS THEN READ TO CONFIRM THAT ALL LOCATIONS HAVE BEEN CORRECTLY SET. THE PROCESS IS THEN REPEATED FOR EACH OF THE EIGHT SELECTABLE COLOURS.

6.2 VISUAL TESTS

TEST 10 - VIDEO ENABLE

THE PICTURE STORE IS PRESET TO BLUE FOR FIVE SECONDS. BIT 5 OF THE CSR (VIDEO ENABLE) IS THEN CLEARED FOR FIVE SECONDS, DURING WHICH TIME THE MONITOR DISPLAY SHOULD BE DARK. THE DISPLAY IS THEN REENABLED FOR A FURTHER FIVE SECONDS.

TEST 11 - DISPLAY ADDRESSING

THE PICTURE STORE IS PRESET TO BLUE. LINES OF MAGENTA ARE THEN

WRITTEN FROM THE TOP OF THE DISPLAY UNTIL THE WHOLE SCREEN HAS CHANGED COLOUR. THE TRANSITION SHOULD BE SMOOTH, TAKING APPROXIMATELY 7 SECONDS. COLUMNS OF WHITE ARE THEN WRITTEN FROM THE LEFT SIDE OF THE DISPLAY UNTIL THE SCREEN IS ALL WHITE. AGAIN, THE TRANSITION SHOULD BE SMOOTH. IF THE DISPLAY DOES NOT APPEAR AS DESCRIBED HERE, AN ADDRESSING FAULT ON THE OUTPUT SIDE OF THE DEVICE IS INDICATED.

TEST 12 - OFFSET

THE PICTURE STORE IS PRESET TO BLUE. A LINE OF MAGENTA IS THEN WRITTEN TO THE TOP OF THE DISPLAY AND THE OFFSET REGISTER CHANGED TO MOVE THE LINE DOWN ONE POSITION. THIS IS REPEATED UNTIL THE WHOLE DISPLAY IS MAGENTA, WHICH SHOULD TAKE ABOUT 7 SECONDS. THE DISPLAY IS THEN CHANGED TO WHITE FROM THE BOTTOM USING THE SAME PROCESS, UNTIL THE SCREEN IS ALL WHITE. IN BOTH CASES, THE LINE BETWEEN COLOURS SHOULD MOVE SMOOTHLY ACROSS THE SCREEN. ANY UNEVEN MOVEMENT INDICATES A PROBLEM IN THE OFFSET REGISTER.

TEST 13 - PATTERN GENERATOR

THIS TEST IS FOR SETTING UP AND CHECKING THE OUTPUT TO THE DISPLAY MONITOR. NINE PATTERNS ARE PROVIDED - EIGHT TO PRESET THE SCREEN TO EACH POSSIBLE COLOUR, AND ONE TO OUTPUT A CROSS HATCH OF 32 COLUMN, 16 LINE RECTANGLES. THE NUMBER OF RECTANGLES WHICH ARE DISPLAYED DEPENDS ON THE CONFIGURATION BEING USED - 12/16 ACROSS THE SCREEN FOR 384/512 DOT VERSIONS, AND 15/16 DOWN THE SCREEN FOR 60/50 HZ VERSIONS.

NORMALLY, THE NINE PATTERNS ARE DISPLAYED IN TURN, EACH REMAINING ON THE SCREEN FOR APPROXIMATELY FIVE SECONDS. HOWEVER, IF MANUAL SELECTION IS SELECTED AT START UP, EACH PATTERN IS KEPT DISPLAYED UNTIL THE RETURN KEY IS HIT ON THE OPERATOR CONSOLE.

```

12          .TITLE PROGRAM HEADER AND TABLES
13          .SBTTL PROGRAM HEADER
39
41 000000          .ENABL ABS,AMA
42          002000          .          =          2000
44
45 002000          BGNMOD
46
47          :++
48          : THE PROGRAM HEADER IS THE INTERFACE BETWEEN
49          : THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
50          :--
51
52 002000          POINTER BGNSW,BGNSFT,BGNDU,BGNSETUP
53
70
71 002000          HEADER CZVTV,A,0,660.,0

```

```

LSNAME::          .ASCII /C/
                  .ASCII /Z/
                  .ASCII /V/
                  .ASCII /T/
                  .ASCII /V/
                  .BYTE 0
                  .BYTE 0
                  .BYTE 0
LSREV::          .ASCII /A/
LSDEPO::          .ASCII /0/
LSUNIT::          .WORD TSPTHV
LSTIML::          .WORD 660.
LSHPCP::          .WORD LSHARD
LSSPCP::          .WORD LSSOFT
LSHPTP::          .WORD LSHW
LSSPTP::          .WORD LSSW
LSLADP::          .WORD L$LAST
LSSTA::          .WORD 0
LSCO::           .WORD 0
LSDTYP::          .WORD 0
LSAPT::           .WORD 0
LSDTP::           .WORD 0
LSPRIO::          .WORD LSDISPATCH
LSENV I::         .WORD 0

```

PROGRAM HEADER AND TABLES
PROGRAM HEADER

002044 000000
 002046
 002046 000000
 002050
 002050 003
 002051 003
 002052
 002052 000000
 002054 000000
 002056
 002056 000000
 002060
 002060 002210
 002062
 002062 000000
 002064
 002064 000000
 002066
 002066 000000
 002070
 002070 000000
 002072
 002072 005562
 002074
 002074 000000
 002076
 002076 002220
 002100
 002100 104035
 002102
 002102 000000
 002104
 002104 004722
 002106
 002106 005510
 002110
 002110 005424
 002112
 002112 004714
 002114
 002114 000000
 002116
 002116 000000
 002120
 002120 000000

L\$EXP1:: .WORD 0
 L\$MREV:: .WORD 0
 L\$EF:: .BYTE CSREVISION
 .BYTE C\$EDIT
 L\$SPC:: .WORD 0
 .WORD 0
 L\$DEVP:: .WORD 0
 L\$REPP:: .WORD L\$DVTYP
 L\$EXP4:: .WORD 0
 L\$EXP5:: .WORD 0
 L\$AUT:: .WORD 0
 L\$DUT:: .WORD 0
 L\$LUN:: .WORD L\$DU
 .WORD 0
 L\$DESP:: .WORD L\$DESC
 L\$LOAD:: EMT ESLOAD
 L\$ETP:: .WORD 0
 L\$ICP:: .WORD L\$INIT
 L\$CCP:: .WORD L\$CLEAN
 L\$ACP:: .WORD L\$AUTO
 L\$PRT:: .WORD L\$PROT
 L\$TEST:: .WORD 0
 L\$DLY:: .WORD 0
 L\$HIME:: .WORD 0

1
2
3
4
5
6
7
8
9

.SBTTL DISPATCH TABLE

:+
: THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
: IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
:--

DISPATCH 13

002122
002122 000015
002124
002124 005640
002126 006140
002130 006452
002132 006606
002134 007200
002136 007632
002140 010164
002142 010520
002144 010714
002146 011316
002150 011424
002152 011610
002154 012030

.WORD 13
LSDISPATCH:
.WORD T1
.WORD T2
.WORD T3
.WORD T4
.WORD T5
.WORD T6
.WORD T7
.WORD T8
.WORD T9
.WORD T10
.WORD T11
.WORD T12
.WORD T13

.SBTTL DEFAULT HARDWARE P-TABLE

:++
: THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
: THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
: IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P-TABLES,
: AND IS USED AS A 'TEMPLATE' FOR BUILDING THE P-TABLES.
:--

```
1  
2  
3  
4  
5  
6  
7  
8  
9  
10 002156          BGNHW  DFPTBL  
    002156 000001  
    002160  
    002160          LSHW:: .WORD  L10000-LSHW/2  
                                DFPTBL::  
11 002160 174000    .WORD  174000    ; VTV31-K CSR ADDRESS  
12  
13 002162          ENDDHW  
    002162          L10000:
```

PROGRAM HEADER AND TABLES
SOFTWARE P-TABLE

```
1      .SBTTL  SOFTWARE P-TABLE
2
3      :++
4      : THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE
5      : PROGRAM AS OPERATIONAL PARAMETERS.  THESE PARAMETERS ARE
6      : SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR
7      : AT RUN TIME.
8      :--
9
10     002162      BGNSW  SFPTBL
11     002162      000002
12     002164
13     002164
14
15     LSSW::      .WORD  L10001-LSSW/2
16     SFPTBL::
17
18     11     002164      000000      MANVEN::      .WORD  0      ; TEST 13 MANUAL INTERVENTION FLAG
19     20     ; 0 FOR NO INTERVENTION (DEFAULT)
20     21     ; 1 FOR RUN MANUALLY
21
22     23     002166      000005      MAXERR::      .WORD  5      ; AUTODROP ERROR COUNT
23
24     25     002170      ENDSW
25     002170
26
27     26
27     002170      ENDMOD
27
28     L10001:
```

12
13
41
51
52 002170
53
54
55
56
57
58
73
74 002170

.TITLE GLOBAL AREAS
.SBTTL GLOBAL EQUATES SECTION

BGNMOD

;++
: THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
: ARE USED IN MORE THAN ONE TEST.
:--

EQUALS

:
: BIT DIFINITIONS
:

100000	BIT15== 100000
040000	BIT14== 40000
020000	BIT13== 20000
010000	BIT12== 10000
004000	BIT11== 4000
002000	BIT10== 2000
001000	BIT09== 1000
000400	BIT08== 400
000200	BIT07== 200
000100	BIT06== 100
000040	BIT05== 40
000020	BIT04== 20
000010	BIT03== 10
000004	BIT02== 4
000002	BIT01== 2
000001	BIT00== 1

001000	BIT9== BIT09
000400	BIT8== BIT08
000200	BIT7== BIT07
000100	BIT6== BIT06
000040	BIT5== BIT05
000020	BIT4== BIT04
000010	BIT3== BIT03
000004	BIT2== BIT02
000002	BIT1== BIT01
000001	BIT0== BIT00

:
: EVENT FLAG DEFINITIONS
: EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
:

000040	EF.START== 32.	: START COMMAND WAS ISSUED
000037	EF.RESTART== 31.	: RESTART COMMAND WAS ISSUED
000036	EF.CONTINUE== 30.	: CONTINUE COMMAND WAS ISSUED
000035	EF.NEW== 29.	: A NEW PASS HAS BEEN STARTED
000034	EF.PWR== 28.	: A POWER-FAIL/POWER-UP OCCURRED

:
: PRIORITY LEVEL DEFINITIONS
:

000340 PRI07== 340

GLOBAL AREAS MACRO V03.01 18-NOV-81 11:10:45 PAGE 8-1
GLOBAL EQUATES SECTION

000300	PRI06== 300
000240	PRI05== 240
000200	PRI04== 200
000140	PRI03== 140
000100	PRI02== 100
000040	PRI01== 40
000000	PRI00== 0
	:
	:OPERATOR FLAG BITS
	:
000004	EVL== 4
000010	LOT== 10
000020	ADR== 20
000040	IDU== 40
000100	ISR== 100
000200	UAM== 200
000400	BOE== 400
001000	PNT== 1000
002000	PRI== 2000
004000	IXE== 4000
010000	IBE== 10000
020000	IER== 20000
040000	LOE== 40000
100000	HOE== 100000

```

1      .SBTTL GLOBAL DATA SECTION
2
3      :++
4      : THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
5      : IN MORE THAN ONE TEST.
6      :--
7
20     ; UUT REGISTER ADDRESS STORAGE
21
22
23     UUT::      .WORD  0      ; CURRENT UNIT UNDER TEST
24     VTVCSR::  .WORD  0      ; CSR ADDRESS
25     DBUFF::   .WORD  0      ; DBUFF ADDRESS
26
27     ERRCNT::  .WORD  0      ; ERROR COUNT FOR CURRENT UNIT
28     DOT::     .WORD  0      ; DOT POSITION FOR ERROR REPORTS
29
30     NXMFLG:: .WORD  0      ; SET IF NXM ERROR OCCURS
31
32     ABITS::   .WORD  0      ; BIT MASK STORE FOR ADDRESS TESTS
33
34     COUNT::  .WORD  0      ; COUNTER FOR WAIT25 SUBROUTINE

```

1
2
3
4
5
6
7
8
9
10
11
12

13
19
20
21
22

23
24
31

.SBTTL GLOBAL TEXT SECTION

:++
: THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
: MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
: MORE THAN ONE TEST.
:--

: NAMES OF DEVICES SUPPORTED BY PROGRAM

DEV TYP <VTV31-K>

LSDVTYP::
.ASCIZ /VTV31-K/

.EVEN

002210
002210
002210 126 124 126
002213 063 061 055
002216 113 000

: TEST DESCRIPTION

DESCRIPT <VTV31-K INTERFACE DIAGNOSTIC>

L\$DESC::
.ASCIZ /VTV31-K INTERFACE D

002220
002220
002220 126 124 126
002223 063 061 055
002226 113 040 111
002231 116 124 105
002234 122 106 101
002237 103 105 040
002242 104 111 101
002245 107 116 117
002250 123 124 111
002253 103 000

.EVEN

.EVEN

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54

.SBTTL GLOBAL SUBROUTINES

: THE GLOBAL SUBROUTINES ARE CALLED BY MORE THAN ONE TEST. *

++
: FUNCTIONAL DESCRIPTION:

SUBROUTINE TO UPDATE UNIT ERROR COUNT. IF DURING ONE PASS, THE
ERROR COUNT EXCEEDS MAXERR (THE AUTODROP COUNT REQUESTED AT
STARTUP), THE UNIT IS DROPPED FROM THE TEST CYCLE.
IF THE PROGRAM IS LOOPING ON AN ERROR OR IF THE FLAG IDU HAS
BEEN SELECTED, THE SUBROUTINE DOES NOTHING.

: CALLING SEQUENCE:

JSR PC,CHKMAX

: INPUTS:

NONE.

: IMPLICIT INPUTS:

THE VARIABLE MAXERR CONTAINS THE NUMBER OF ERRORS AFTER WHICH
TO DROP THE UNIT.
UUT CONTAINS THE NUMBER OF THE UNIT CURRENTLY BEING TESTED.

: OUTPUTS:

NONE.

: IMPLICIT OUTPUTS:

THE SUBPASS ERROR COUNT (ERRCNT) IS INCREMENTED.

: SUBORDINATE ROUTINES USED:

NONE.

: FUNCTIONAL SIDE EFFECTS:

NONE.

--
CHKMAX::INLOOP ; LOOPING ON ERROR? TRAP C\$INLP
BCOMplete 1\$; IF YES, EXIT BCS 1\$
RFLAGS R0 ; GET OPERATOR FLAGS TRAP C\$RFLA
BIT #IDU,R0 ; IS DROPPING INHIBITED?
BNE 1\$; IF YES, EXIT

M
I

```

55
56 002272 005267 177700      INC      ERRCNT      : UPDATE THE ERROR COUNT
57 002276 026767 177674 177662  CMP      ERRCNT,MAXERR : TOO MANY ERRORS?
58 002304 003420      BLE      1$          : IF NOT, JUMP
59 002306      PRINTF   #NERRS,MAXERR,UUT : 'TOO MANY ERRORS'
      002306 016746 177656      MOV      UUT,-(SP)
      002312 016746 177650      MOV      MAXERR,-(SP)
      002316 012746 002350      MOV      #NERRS,-(SP)
      002322 012746 000003      MOV      #3,-(SP)
      002326 010600      MOV      SP,R0
      002330 104417      TRAP    C$PNTF
      002332 062706 000010      ADD     #10,SP
60 002336      DODU     UUT          : DROP THE UNIT
      002336 016700 177626      MOV     UUT,R0
      002342 104451      TRAP   C$DODU
61
62 002344      DOCLN          : END THE SUBPASS
      002344 104444      TRAP   C$DCLN
63
64 002346 000207      1$:   RTS     PC
65
66
67 002350      045      116      045  NERRS: .NLIST  BEX
      .ASCIZ  /%N%AMORE THAN%D3%A ERRORS ON UNIT%D2/
68      .LIST  BEX
69      .EVEN
70
71
72

```

M AI

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27

..**
: FUNCTIONAL DESCRIPTION:
: SUBROUTINE TO WAIT FOR 25 MILLISECONDS
: CALLING SEQUENCE:
: JSR PC, WAIT25
: INPUTS:
: NONE.
: IMPLICIT INPUTS:
: THE VARIABLE COUNT MUST HAVE BEEN SET UP BY ROUTINE SETCLK.
: OUTPUTS:
: NONE.
: IMPLICIT OUTPUTS:
: NONE.
:--

28 002416 016700 177564
29 002422 005300
30 002424 001376
31 002426 000207

WAIT25::MOV COUNT, R0 : GET WAIT COUNT
1\$: DEC R0 : ALL DONE?
 BNE 1\$: IF NOT, WAIT SOME MORE
 RTS PC : ELSE RETURN

1
2
3
4
5
6
7
8
9
10
11
12

.SBTTL GLOBAL INTERRUPT SERVICE ROUTINES

:*****
: THESE ROUTINES ARE USED IN MORE THAN ONE PLACE IN THE PROGRAM. *
:*****

002430
002430 012737 000001 002202
002436 012702 000001
002442
002442 000002

BGNSRV NXMTRP
MOV #1,2,NXMFLG ; FLAG UNIT NXM ERROR NXMTRP::
MOV #1,R2 ; FLAG REGISTER NXM ERROR
ENDSRV
L10002:
RTI

.SBTTL GLOBAL ERROR REPORT SECTION

;++
: THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS
: USED BY MORE THAN TEST TO OUTPUT ADDITIONAL ERROR INFORMATION. PRINTB
: (BASIC) AND PRINTX (EXTENDED) CALLS ARE USED TO CALL PRINT SERVICES.
:--

1
2
3
4
5
6
7
8
9

25
26

27

002444
002446

002452
002456

002460
002462

28 002466
29 002472

002472
002472

30
31 002474

002474

32 002474

002476

002500

002504

002510

002512

002514

33 002520

002520

002522

002526

002532

002534

002536

34 002542
35 002546

002546

36
37 002550

002550

38 002550

002552

002554

002560

002564

002566

002570

39 002574

010146
012746 003636
012746 000002
010600
104414
062706 000006
004767 177564

104423

010346
010146
012746 003663
012746 000003
010600
104414
062706 000010

010246
012746 003776
012746 000002
010600
104414
062706 000006
004767 177510

104423

010446
010146
012746 004036
012746 000003
010600
104414
062706 000010
004767 177456

BGNMSG ER200

PRINTB #E200B,R1 ; PRINT CSR CONTENTS

ER200::

MOV R1,-(SP)
MOV #E200B,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTB
ADD #6,SP

ENDMSG JSR PC,CHKMAX ; CHECK FOR TOO MANY ERRORS

L10003:

TRAP C\$MSG

BGNMSG ER300

PRINTB #E300B,R1,R3 ; PRINT REGISTER CONTENTS

ER300::

MOV R3,-(SP)
MOV R1,-(SP)
MOV #E300B,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C\$PNTB
ADD #10,SP

PRINTB #E300C,R2 ;

MOV R2,-(SP)
MOV #E300C,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C\$PNTB
ADD #6,SP

ENDMSG JSR PC,CHKMAX ; CHECK FOR TOO MANY ERRORS

L10004:

TRAP C\$MSG

BGNMSG ER400

PRINTB #E400B,R1,R4 ; PRINT GOOD AND BAD

ER400::

MOV R4,-(SP)
MOV R1,-(SP)
MOV #E400B,-(SP)
MOV #3,-(SP)
MOV SP,R0
TRAP C\$PNTB
ADD #10,SP

JSR PC,CHKMAX ; CHECK FOR TOO MANY ERRORS

```

40 002600          ENDMSG                                L10005:
    002600          TRAP                                CSMSG
    002600 104423
41
42 002602          BGNMSG ER401                          ER401::
    002602          PRINTB #E401B,R3,R5 ; PRINT GOOD AND BAD
43 002602          MOV R5,-(SP)
    002602 010546    MOV R3,-(SP)
    002604 010346    MOV #E401B,-(SP)
    002606 012746 004152 MOV #3,-(SP)
    002612 012746 000003 MOV SP,R0
    002616 010600    TRAP C$PNTB
    002620 104414    ADD #10,SP
    002622 062706 000010
44 002626 004767 177424    JSR PC,CHKMAX ; CHECK FOR TOO MANY ERRORS
45 002632          ENDMSG                                L10006:
    002632          TRAP                                CSMSG
    002632 104423
46
47 002634          BGNMSG ER500                          ER500::
    002634
48 002634 000303    SWAB R3 ; GET LINE NUMBER
49 002636 042703 177400    BIC #177400,R3 ; CLEAR OTHER BITS
50 002642          PRINTB #LINDOT,R3,R3,R1,R1 ; LINE AND DOT NUMBER
    002642 010146    MOV R1,-(SP)
    002644 010146    MOV R1,-(SP)
    002646 010346    MOV R3,-(SP)
    002650 010346    MOV R3,-(SP)
    002652 012746 004503 MOV #LINDOT,-(SP)
    002656 012746 000005 MOV #5,-(SP)
    002662 010600    MOV SP,R0
    002664 104414    TRAP C$PNTB
    002666 062706 000014 ADD #14,SP
51 002672          PRINTX #GOOBAD,R2,R3 ; GOOD AND BAD
    002672 010346    MOV R3,-(SP)
    002674 010246    MOV R2,-(SP)
    002676 012746 004571 MOV #GOOBAD,-(SP)
    002702 012746 000003 MOV #3,-(SP)
    002706 010600    MOV SP,R0
    002710 104415    TRAP C$PNTX
    002712 062706 000010 ADD #10,SP
52 002716 004767 177334    JSR PC,CHKMAX ; CHECK FOR TOO MANY ERRORS
53 002722          ENDMSG                                L10007:
    002722          TRAP                                CSMSG
    002722 104423
54
55 002724          BGNMSG ER501                          ER501::
    002724
56 002724 000304    SWAB R4 ; GET THE LINE NUMBER
57 002726 042704 177400    BIC #177400,R4 ; CLEAR THE OTHER BITS
58 002732 010137 002200    MOV R1,@#DOT ; GET THE DATA PATTERN
59 002736 042737 177000 002200 BIC #177000,@#DOT ; GET THE DOT NUMBER
60 002744          PRINTB #LINDOT,R4,R4,DOT,DOT ; LINE AND DOT NUMBER
    002744 016746 177230 MOV DOT,-(SP)
    002750 016746 177224 MOV DOT,-(SP)
    002754 010446    MOV R4,-(SP)
    002756 010446    MOV R4,-(SP)

```

```

002760 012746 004503      MOV      #LINDOT,-(SP)
002764 012746 000005      MOV      #5,-(SP)
002770 010600      MOV      SP,R0
002772 104414      TRAP     C$PNTB
002774 062706 000014      ADD      #14,SP
61 003000      PRINTX  #GOOBAD,R2,R3 ; GOOD AND BAD
003000 010346      MOV      R3,-(SP)
003002 010246      MOV      R2,-(SP)
003004 012746 004571      MOV      #GOOBAD,-(SP)
003010 012746 000003      MOV      #3,-(SP)
003014 010600      MOV      SP,R0
003016 104415      TRAP     C$PNTX
003020 062706 000010      ADD      #10,SP
62 003024 004767 177226      JSR      PC,CHKMAX ; CHECK FOR TOO MANY ERRORS
63 003030      ENDMSG
003030      L10010:
003030 104423      TRAP     C$MSG
64
65 003032      BGNMSG  ER600
003032      ER600::
66 003032 000305      SWAB    R5 ; GET THE LINE NUMBER
67 003034 042705 177400      BIC     #177400,R5 ; CLEAR OTHER BITS
68 003040 010137 002200      MOV     R1,@#DOT ; GET THE DOT NUMBER
69 003044 042737 177000 002200      BIC     #177000,@#DOT ; CLEAR THE OTHER BITS
70 003052      PRINTB  #LINDOT,R5,R5,DOT,DOT ; LINE AND DOT NUMBER
003052 016746 177122      MOV     DOT,-(SP)
003056 016746 177116      MOV     DOT,-(SP)
003062 010546      MOV     R5,-(SP)
003064 010546      MOV     R5,-(SP)
003066 012746 004503      MOV     #LINDOT,-(SP)
003072 012746 000005      MOV     #5,-(SP)
003076 010600      MOV     SP,R0
003100 104414      TRAP     C$PNTB
003102 062706 000014      ADD     #14,SP
71 003106      PRINTX  #GOOBAD,R4,R3 ; GOOD AND BAD
003106 010346      MOV     R3,-(SP)
003110 010446      MOV     R4,-(SP)
003112 012746 004571      MOV     #GOOBAD,-(SP)
003116 012746 000003      MOV     #3,-(SP)
003122 010600      MOV     SP,R0
003124 104415      TRAP     C$PNTX
003126 062706 000010      ADD     #10,SP
72 003132 016767 004754 177044      MOV     NCOLS,ABITS ; GET NO. OF COLUMNS PER COLOUR
73 003140 006367 177040      ASL    ABITS ; SHIFT TO FORM
74 003144 006367 177034      ASL    ABITS ; BIT MASK OF
75 003150 006367 177030      ASL    ABITS ; ADDRESS LINES
76 003154 166767 004732 177022      SUB    NCOLS,ABITS ; BEING TESTED
77 003162      PRINTX  #EADD,ABITS ; AND ADDRESS LINES BEING TESTED
003162 016746 177016      MOV     ABITS,-(SP)
003166 012746 004652      MOV     #EADD,-(SP)
003172 012746 000002      MOV     #2,-(SP)
003176 010600      MOV     SP,R0
003200 104415      TRAP     C$PNTX
003202 062706 000006      ADD     #6,SP
78 003206 004767 177044      JSR     PC,CHKMAX ; CHECK FOR TOO MANY ERRORS
79 003212      ENDMSG
003212      L10011:

```

```

80 003212 104423 TRAP CSMSG
81 003214 BGNMSG ER700 ER700::
82 003214 000305 SWAB R5 ; GET THE LINE NUMBER
83 003216 042705 177400 BIC #177400,R5 ; CLEAR OTHER BITS
84 003222 010137 002200 MOV R1,#DOT ; GET THE DOT NUMBER
85 003226 042737 177000 002200 BIC #177000,#DOT ; CLEAR THE OTHER BITS
86 003234 PRINTB #LINDOT,R5,R5,DOT,DOT ; LINE AND DOT NUMBER
    003234 016746 176740 MOV DOT,-(SP)
    003240 016746 176734 MOV DOT,-(SP)
    003244 010546 MOV R5,-(SP)
    003246 010546 MOV R5,-(SP)
    003250 012746 004503 MOV #LINDOT,-(SP)
    003254 012746 000005 MOV #5,-(SP)
    003260 010600 MOV SP,R0
    003262 104414 TRAP CSPNTB
    003264 062706 000014 ADD #14,SP
87 003270 PRINTX #GOOBAD,R4,R3 ; GOOD AND BAD
    003270 010346 MOV R3,-(SP)
    003272 010446 MOV R4,-(SP)
    003274 012746 004571 MOV #GOOBAD,-(SP)
    003300 012746 000003 MOV #3,-(SP)
    003304 010600 MOV SP,R0
    003306 104415 TRAP CSPNTX
    003310 062706 000010 ADD #10,SP
88 003314 016767 005130 176662 MOV NLINS,ABITS ; GET NO. OF LINES PER COLOUR
89 003322 006367 176656 ASL ABITS ; SHIFT TO FORM
90 003326 006367 176652 ASL ABITS ; MASK OF ADDRESS
91 003332 006367 176646 ASL ABITS ; LINES BEING TESTED
92 003336 166767 005106 176640 SUB NLINS,ABITS ;
93 003344 042767 177400 176632 BIC #177400,ABITS ; CLEAR THE TOP BYTE
94 003352 PRINTX #EADD,ABITS ; AND ADDRESS LINES BEING TESTED
    003352 016746 176626 MOV ABITS,-(SP)
    003356 012746 004652 MOV #EADD,-(SP)
    003362 012746 000002 MOV #2,-(SP)
    003366 010600 MOV SP,R0
    003370 104415 TRAP CSPNTX
    003372 062706 000006 ADD #6,SP
95 003376 004767 176654 JSR PC,CHKMAX ; CHECK FOR TOO MANY ERRORS
96 003402 ENDMSG L10012: TRAP CSMSG
    003402 104423
97 003404 BGNMSG ER800 ER800::
98 003404
99 003404 010167 176570 MOV R1,DOT ; GET THE DOT NUMBER
100 003410 042767 177000 176562 BIC #177000,DOT ; CLEAR THE OTHER BITS
101 003416 PRINTB #E800B,R3,DOT ; DOT ADDRESS,GOOD,BAD
    003416 016746 176556 MOV DOT,-(SP)
    003422 010346 MOV R3,-(SP)
    003424 012746 004257 MOV #E800B,-(SP)
    003430 012746 000003 MOV #3,-(SP)
    003434 010600 MOV SP,R0
    003436 104414 TRAP CSPNTB
    003440 062706 000010 ADD #10,SP
102 003444 PRINTB #E800C,R3,R4 ;
    
```


GLOBAL AREAS MACRO V03.01 18-NOV-81 11:10:45 PAGE 14-5
GLOBAL ERROR REPORT SECTION

122					.NLIST	BEX
123	003636	045	101	103	E200B:	.ASCIZ /%ACSR CONTENTS %06%N/
124	003663	045	101	117	E300B:	.ASCII /%AOLD CSR CONTENTS %06/
125	003711	045	116	045		.ASCIZ /%N%ANew CSR CONTENTS %06%A (IGNORE BITS 0,1,2 AND 4)/
126	003776	045	116	045	E300C:	.ASCIZ /%N%ADATA WRITTEN TO DBUFF %06%N/
127	004036	045	101	101	E400B:	.ASCII /%AATTEMPTED SETTING %06/
128	004065	045	116	045		.ASCIZ /%N%AACTUAL SETTING %06%A (IGNORE BITS 0-4 AND 6-7)%N/
129	004152	045	101	101	E401B:	.ASCII /%AATTEMPTED SETTING %06/
130	004201	045	116	045		.ASCIZ /%N%AACTUAL SETTING %06%A (IGNORE BITS 3-15)%N/
131	004257	045	101	104	E800B:	.ASCIZ /%ADOT ADDRESS WRITTEN %01%A, FAILING DOT ADDRESS %01/
132	004344	045	116	045	E800C:	.ASCIZ /%N%AEEXPECTED CONTENTS %01%A, ACTUAL CONTENTS %01%N/
133	004427	045	101	103	E900B:	.ASCIZ /%ACSR CONTENTS %06%A, EXPECTED COLOUR %01%N/
134	004503	045	101	114	LINDOT:	.ASCIZ /%ALINE %D3%A (%03%A OCTAL), DOT %D3%A (%03%A OCTAL)%N/
135	004571	045	101	105	GOOBAD:	.ASCIZ /%AEEXPECTED CONTENTS %01%A, ACTUAL CONTENTS %01%N/
136	004652	045	101	101	EADD:	.ASCIZ /%AADDRESS BITS BEING TESTED %B9%N/
137						.LIST
138						.EVEN
139	004714					ENDMOD

11
12
40
41 004714
42
43
44
45
46
47
48
49 004714
004714
50
51 004714 000000
52 004716 177777
53 004720 177777
54
55 004722
56

.TITLE MISCELLANEOUS SECTIONS
.SBTTL REPORT CODING SECTION

BGNMOD
.SBTTL PROTECTION TABLE

:++
: THIS TABLE IS USED BY THE RUNTIME SERVICES
: TO PROTECT THE LOAD MEDIA.
:--

BGNPROT

L\$PROT::

0 :OFFSET INTO P-TABLE FOR CSR ADDRESS
-1 :OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
-1 :OFFSET INTO P-TABLE FOR DRIVE NUMBER

ENDPROT

```

1          .SBTTL  INITIALIZE SECTION
2
3
4          :++
5          : THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
6          : AT THE BEGINNING OF EACH PASS.
7          :--
8          BGNINIT
9
10         LSINIT::
11
12         33 004722          READEF #EF.START          ; START COMMAND?
13         004722 012700 000040          ;
14         004726 104447          ;
15         34 004730          BNCOMPLETE CONT          ; IF NOT, BRANCH
16         004730 103002          ;
17         35 004732 004767 000114          JSR    PC,SETCLK          ; SET UP CLOCK COUNTER
18         36 004736          CONT: READEF #EF.CONTINUE ; CONTINUE COMMAND?
19         004736 012700 000036          ;
20         004742 104447          ;
21         37 004744          BCOMPLETE END           ; IF YES, NO P TABLE
22         004744 103441          ;
23         38 004746          READEF #EF.NEW          ; NEW PASS?
24         004746 012700 000035          ;
25         004752 104447          ;
26         39 004754          BNCOMPLETE NEXT        ; IF NOT, SKIP SETUP
27         004754 103003          ;
28         40 004756 012767 177777 175204  SETUP: MOV  #-1,UUT          ; INITIALISE LOGICAL UNIT NUMBER
29         41 004764 005267 175200          NEXT: INC  UUT          ; POINT TO NEXT LOGICAL UNIT
30         42 004770 026767 175174 175014  CMP   UUT,LSUNIT        ; ALL DONE?
31         43 004776 001421          BEQ   ABORT          ; IF YES, END OF PASS
32         44 005000          GPHARD UUT,R2          ; ELSE GET P TABLE
33         005000 016700 175164          ;
34         005004 104442          ;
35         005006 010002          ;
36         45 005010          BNCOMPLETE NEXT        ; IF NOT AVAILABLE, GET NEXT
37         005010 103365          ;
38         46 005012 011267 175154          MOV   @R2,VTVCSR        ; SAVE NEW CSR ADDRESS
39         47 005016 016767 175150 175150  MOV   VTVCSR,DBUFF     ; AND DBUFF ADDRESS
40         48 005024 062767 000002 175142  ADD   #2,DBUFF         ;
41         49 005032 005067 175140          CLR   ERRCNT          ; CLEAR SUBPASS ERROR COUNT
42         50 005036          EXIT  INIT            ; AND EXIT
43         005036 104432          ;
44         005040 000010          ;
45         51
46         52 005042          ABORT: DOCLN          ; CLEAN UP AND ABORT THE PASS
47         005042 104444          ;
48         53 005044          EXIT  INIT            ; AND EXIT
49         005044 104432          ;
50         005046 000002          ;
51         65
52         66          .EVEN
53         67
54         68 005050          END:  ENDINIT
55         005050          ;
56         005050 104411          ;
57         69
58         L10017: TRAP  CSINIT
59

```


MISCELLANEOUS SECTIONS
INITIALIZE SECTION

MACRO V03.01 18-NOV-81 11:10:45 PAGE 30-1

K 3

```

43 005202 006204          ASR      R4          ; DIVIDE THE 100 MILLISECOND COUNTER
44 005204 006204          ASR      R4          ; BY 4 TO GIVE 25 MILLISECONDS
45 005206 042704 140000   BIC      #140000,R4  ; ENSURE TOP BITS ARE CLEAR
46 005212 010467 174770   MOV      R4,COUNT   ; AND SAVE THE COUNTER
47 005216 000207          RTS      PC          ; RETURN
48
49
50           ; USE THE CONSOLE FOR TIMING
51           ;
52           TKS=177560   ; KEYBOARD STATUS REGISTER
53           TKB=177562   ; KEYBOARD DATA BUFFER
54           TPS=177564   ; PRINTER STATUS REGISTER
55           TPB=177566   ; PRINTER DATA BUFFER
56
57 NOCLOCK: SETVEC #60,#TTINT,#340 ; SET UP INTERRUPT VECTOR
           MOV          #340,-(SP)
           MOV          #TTINT,-(SP)
           MOV          #60,-(SP)
           MOV          #3,-(SP)
           TRAP        C$SVEC
           ADD          #10,SP
58 005246          PRINTF #TIMMSG      ; 'TYPE 2 CHARACTERS 6 SECONDS APART'
           MOV          #TIMMSG,-(SP)
           MOV          #1,-(SP)
           MOV          SP,R0
           TRAP        C$PNTF
           ADD          #4,SP
59
60 005266 105767 172266   10$:   TSTB     TKS          ; IS FIRST CHARACTER READY?
61 005272 100375          BPL      10$          ; IF NOT, WAIT
62
63 005274 016767 172262 172264   MOV      TKB,TPB     ; NOW ECHO THE CHARACTER
64 005302          SETPRI  #0          ; DROP THE PRIORITY
           MOV          #0,R0
           TRAP        C$SPRI
65 005310 012767 000100 172242   MOV      #100,TKS    ; ALLOW INTERRUPTS
66
67 005316 105205          20$:   INCB     R5          ; START COUNTING
68 005320 001376          BNE     20$          ;
69 005322 005204          INC      R4          ; UPDATE THE COUNTER
70 005324 000774          BR      20$          ;
71
72 005326          TTINT: SETPRI  R2          ; RESTORE THE PRIORITY
           MOV          R2,R0
           TRAP        C$SPRI
73 005332 016767 172224 172226   MOV      TKB,TPB     ; ECHO THE CHARACTER
74 005340 022626          CMP      (SP)+,(SP)+ ; TIDY UP THE STACK
75 005342 005067 172212          CLR      TKS          ; DISABLE INTERRUPTS
76
77 005346 010467 174634          MOV      R4,COUNT   ; SAVE THE COUNTER
78                                     ; 6 SECONDS/256 = 25 MILLISECONDS
79 005352 000207          RTS      PC          ; RETURN
80
81
82 005354 045 116 045 TIMMSG: .NLIST BEX
83                                     ;/X%ATYPE 2 CHARACTERS 6 SECONDS APART >/
84                                     .LIST BEX
                                     .EVEN

```

H/TE

.SBTTL AUTODROP SECTION

```

:++
: THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
: THE 'ADR' FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO
: SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY
: DROPPED FROM TESTING.
:--
  
```

```

1
2
3
4
5
6
7
8
9
10 005424          BGNAUTO
    005424
11
18
19 005424          SETVEC #4,#NXMTRP,#PRI07 ; SET UP NXM TRAP VECTOR
    005424 012746 000340
    005430 012746 002430
    005434 012746 000004
    005440 012746 000003
    005444 104437
    005446 062706 000010
20 005452 005037 002202
21 005456 005777 174510
22 005462 005737 002202
23 005466 001404
24 005470
    005470 016700 174474
    005474 104451
25 005476
    005476 104444
26 005500          10$: CLRVEC #4
    005500 012700 000004
    005504 104436
27
28 005506          ENDAUTO
    005506
    005506 104461
  
```

LSAUTO::

```

MOV #PRI07,-(SP)
MOV #NXMTRP,-(SP)
MOV #4,-(SP)
MOV #3,-(SP)
TRAP C$SVEC
ADD #10,SP
  
```

```

; INITIALISE NXM FLAG
; TEST THE CSR ADDRESS
; WAS THERE A TRAP?
; IF NOT, BRANCH
; ELSE DROP THE UNIT
  
```

```

MOV UUT,R0
TRAP C$DODU
TRAP C$DCLN
MOV #4,R0
TRAP C$CVEC
  
```

```

; AND TIDY UP END OF PASS
; RESTORE THE DRS NXM TRAP
  
```

```

L10020: TRAP C$AUTO
  
```

1
2
3
4
5
6
7
8
9
10
11
12
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
47
48
49
50

.SBTTL CLEANUP CODING SECTION

```

:++
: THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
: AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED OR IF CONTROL/C IS
: TYPED DURING TESTING.
: A PRESET IS PERFORMED TO SET THE SCREEN TO ALL BLACK, THE OFFSET
: REGISTER IS CLEARED, AND THE ERROR COUNT ZEROED.
:--

```

BGNCLN

L\$CLEAN::

005510
005510

005510 005737 002202

005514 001015

005516 005077 174452

005522 012777 000150 174442

005530 012701 177777

005534 105777 174432

005540 100403

005542

005542 104422

005544 005301

005546 001372

005550 005067 174422

005554

005554 104432

005556 000002

1\$:

2\$:

TST @NXMFLG

BNE 2\$

CLR @DBUFF

MOV #150,@VTVCSR

MOV #-1,R1

TSTB @VTVCSR

BMI 2\$

BREAK

DEC R1

BNE 1\$

CLR ERRCNT

EXIT CLN

```

: HAS NXM ERROR OCCURRED?
: IF YES, SKIP CLEAN UP
: SET DBUFF COLOUR TO BLACK
: RESET OFFSET AND DO PRESET

```

```

: SET UP WAIT COUNTER
: PRESET FINISHED?
: IF YES, BRANCH
: ALLOW OPERATOR BREAK IN

```

```

: WAITED TOO LONG?
: IF NOT, WAIT LONGER
: CLEAR SUBPASS ERROR COUNT

```

TRAP C\$BRK

TRAP C\$EXIT
.WORD L10021-

.EVEN

ENDCLN

005560

005560

005560 104412

L10021:

TRAP C\$CLEAN

```

1      .SBTTL  DROP UNIT SECTION
2
3
4      :++
5      : THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
6      : TO NO LONGER BE TESTED.
7      :--
8 005562      BGNDU
9
10      LSDU::
11
12 18 005562      PRINTF  #DROPD,RO      ; 'UNIT DROPPED'
13      005562      010046
14      005564      012746      005610
15      005570      012746      000002
16      005574      010600
17      005576      104417
18      005600      062706      000006
19
20 005604      EXIT      DU
21      005604      000167
22      005606      000026
23
24 21
25 33
26 34 005610      045      116      045  DROPD:  .NLIST  BEX
27 35
28 36
29 37
30 38
31 39 005636
32      005636
33      005636      104453
34 40 005640
35 41

```

```

MOV      RO,-(SP)
MOV      #DROPD,-(SP)
MOV      #2,-(SP)
MOV      SP,RO
TRAP     C$PNTF
ADD      #6,SP

.WORD    JSJMP
.WORD    L10022-2-.

L10022:  TRAP     C$DU

```



```

67 005746          CLRVEC #4          : RESTORE THE DRS NXM TRAP          MOV #4,RO
    005746 012700 000004          :                                TRAP  C$CVEC
    005752 104436
68 005754 005737 002202          TST  @#NXMFLG          : DID EITHER REGISTER TRAP?
69 005760 001410          BEQ   30$              : IF NOT, BRANCH
70 005762          RFLAGS RO          : CHECK THE OPERATOR FLAGS          TRAP  CSRFLA
    005762 104421
71 005764 032700 000040          BIT   #IDU,RO          : IS DROPPING INHIBITED?
72 005770 001004          BNE  30$              : IF YES, BRANCH
73 005772          DODU  UUT          : ELSE DROP THE UNIT
    005772 016700 174172          :                                MOV  UUT,RO
    005776 104451          :                                TRAP  C$DODU
74 006000          DOCLN          : AND TIDY UP END OF PASS          TRAP  C$DCLN
    006000 104444
75 006002          30$. EXIT TST          :
    006002 104432          :                                TRAP  C$EXIT
    006004 000132          :                                .WORD L10023-.
76
77
78 006006          101  104  104  E100: .NLIST BEX
79 006054          101  104  104  E101: .ASCIZ /ADDRESSING THE CSR CAUSES AN NXM TRAP/
80          .ASCIZ /ADDRESSING THE DBUFF REGISTER CAUSES AN NXM TRAP/
81          .LIST BEX
82 006136          .EVEN
    006136          .ENDTST
    006136 104401          :                                L10023: TRAP  C$SETST
  
```

H
T

```

1          .SBTTL TEST 2: REGISTER ACCESS
2
3          :++
4          : THE DEVICE CSR IS READ AND CHECKS ARE MADE THAT THE READY BIT IS
5          : SET, THAT BITS 3 AND 6 ARE ZERO, AND THAT THE FIELD BIT (4) IS
6          : SET AND CLEARED BY THE DEVICE.
7          :--
8
9
10         006140          BGNTST
11         006140
12         006140          BGNSUB          ;***** BEGIN SUBTEST
13         006140 104402          ;***** T2.1:
14         006142 017701 174024          TRAP          CSBSUB
15         006146 105701          MOV          @VTVCSR,R1          ; READ THE CSR
16         006150 100404          TSTB          R1          ; READY BIT SET?
17         006152          BMI          1$          ; IF YES, BRANCH
18         006152 104456          ERRHRD 200,E200,ER200 ; ELSE REPORT THE ERROR
19         006154 000310          ; TRAP          C$ERHRD
20         006156 006266          ; .WORD          200
21         006160 002444          ; .WORD          E200
22         ; .WORD          ER200
23
24         18 006162 032701 000110          1$:          BIT          #110,R1          ; CHECK BITS 3 AND 6
25         19 006166 001404          BEQ          2$          ; IF CLEAR, JUMP
26         20 006170          ERRHRD 201,E201,ER200 ; ELSE REPORT THE ERROR
27         21 006170 104456          ; TRAP          C$ERHRD
28         22 006172 000311          ; .WORD          201
29         23 006174 006314          ; .WORD          E201
30         24 006176 002444          ; .WORD          ER200
31
32         22 006200 005002          2$:          CLR          R2          ; ZERO WAIT COUNTER
33         23 006202 017701 173764          3$:          MOV          @VTVCSR,R1          ; READ THE CSR
34         24 006206 032701 000020          BIT          #20,R1          ; FIELD BIT SET?
35         25 006212 001006          BNE          4$          ; IF YES, BRANCH
36         26 006214 005302          DEC          R2          ; ELSE WAITED TOO LONG?
37         27 006216 001371          BNE          3$          ; IF NOT, KEEP WAITING
38         28 006220          ERRHRD 202,E202,ER200 ; ELSE REPORT THE ERROR
39         29 006220 104456          ; TRAP          C$ERHRD
40         30 006222 000312          ; .WORD          202
41         31 006224 006346          ; .WORD          E202
42         32 006226 002444          ; .WORD          ER200
43
44         29 006230 005002          4$:          CLR          R2          ; ZERO WAIT COUNTER
45         30 006232 017701 173734          5$:          MOV          @VTVCSR,R1          ; READ THE CSR
46         31 006236 032701 000020          BIT          #20,R1          ; FIELD BIT CLEAR?
47         32 006242 001406          BEQ          6$          ; IF YES, BRANCH
48         33 006244 005302          DEC          R2          ; ELSE WAITED TOO LONG?
49         34 006246 001571          BNE          5$          ; IF NOT, KEEP WAITING
50         35 006250          ERRHRD 203,E203,ER200 ; ELSE REPORT THE ERROR
51         36 006250 104456          ; TRAP          C$ERHRD
52         37 006252 000313          ; .WORD          203
53         38 006254 006405          ; .WORD          E203
54         39 006256 002444          ; .WORD          ER200
55
56         37
57         38 006260          6$:          ENDSUB          ;***** END SUBTEST
  
```

006260
006260 104403
39 006262
006262 104432
006264 000164

EXIT TST

L10027: TRAP C\$ESUB
TRAP C\$EXIT
.WORD L10026-

40
41
42 006266 103 123 122 E200:
43 006314 103 123 122 E201:
44 006346 103 123 122 E202:
45 006405 103 123 122 E203:

.NLIST BEX
.ASCIZ /CSR READY BIT NOT SET/
.ASCIZ /CSR BITS 3 OR 6 NOT CLEAR/
.ASCIZ /CSR FIELD BIT DOES NOT GET SET/
.ASCIZ /CSR FIELD BIT DOES NOT GET CLEARED/
.LIST BEX
.EVEN
ENDTST

46
47
48 006450
006450
006450 104401
49

L10026: TRAP C\$ETST


```

1      .SBTTL TEST 4: REGISTER BIT SET
2
3
4      :++
5      : BITS 5 AND BITS 8 TO 15 IN THE CSR ARE SET AND CLEARED IN ALL
6      : COMBINATIONS. FOR EACH COMBINATION, THE CSR IS READ AND A CHECK
7      : MADE THAT THE RELEVANT BITS ARE SET.
8
9      : THE DBUFF REGISTER IS THEN USED IN CONJUNCTION WITH THE FIRST
10     : PICTURE STORE ELEMENT TO ENSURE THAT CSR BITS 0 - 2 CAN BE SET.
11     : CSR BITS 8 - 15 AND DBUFF BITS 0 - 8 ARE CLEAR THROUGHOUT,
12     : ENSURING THAT ONLY THE FIRST PICTURE ELEMENT IS USED.
13     : A 'WRITE PICTURE STORE' OPERATION IS PERFORMED USING THE COLOUR
14     : BLACK. THE ELEMENT IS THEN READ AND A CHECK MADE THAT CSR BITS
15     : 0 - 2 READ ZERO. THIS PROCESS IS REPEATED FOR EACH COLOUR CODE,
16     : VERIFYING THAT THE CORRECT COLOUR IS REFLECTED IN THE CSR.
17     :--
18     BGNTST
19     BGNSUB          ;***** BEGIN SUBTEST
20     006606          T4::
21     006606          T4.1: TRAP C$BSUB
22     006606 104402
23     : DIRECT BIT SET
24     :
25     CLR R1          ; INITIALISE TEST PATTERN
26     T4A: BGNSEG     ;----- BEGIN SEGMENT
27     MOV R1,@VTVCSR ; WRITE TEST PATTERN TO CSR
28     MOV @VTVCSR,R3 ; READ THE CSR
29     MOV R3,R4       ; SAVE THE CONTENTS
30     BIC #337,R3     ; CLEAR UNWANTED BITS
31     CMP R3,R1       ; CORRECT BITS WRITTEN?
32     BEQ 1$          ; IF YES, BRANCH
33     ERRHRD 400,E400,ER400 ; ELSE REPORT THE ERROR
34     TRAP C$ERHRD
35     .WORD 400
36     .WORD E400
37     .WORD ER400
38     1$: ENDSEG     ;----- END SEGMENT
39     10000$: TRAP C$ESEG
40
41     ADD #400,R1     ; NEXT PATTERN
42     BCC T4A         ; IF MORE, BRANCH
43     CMP R1,#40     ; ELSE SECOND TIME THROUGH?
44     BEQ 2$         ; IF YES, BRANCH
45     MOV #40,R1     ; ELSE SET BIT 5
46     BR T4A         ; AND REPEAT PATTERNS
47     2$: ENDSUB     ;***** END SUBTEST
48     L10032: TRAP C$ESUB
49
50     BGNSUB          ;***** BEGIN SUBTEST
51     006674          T4.2: TRAP C$BSUB
52     006674 104402

```

H/ TI

```

44
45      ; BIT SET VIA DBUFF AND PICTURE STORE
46      ;
47 006676 005077 173270      CLR    @VTVCSR      ; CLEAR THE CSR
48 006702 005001      CLR    R1          ; INITIALISE TEST DBUFF PATTERN
49 006704 005003      CLR    R3          ; INITIALISE EXPECTED CSR PATTERN
50
51 006706      1$:  BGNSEG      ;----- BEGIN SEGMENT
52 006706 104404      TRAP    CSBSEG
53 006710 010177 173260      MOV    R1,@DBUFF    ; WRITE DBUFF PATTERN
54 006714 012777 040000 173252  MOV    #4000,@DBUFF ; LATCH PATTERN INTO THE CSR
55 006722 017704 173244      MOV    @VTVCSR,R4   ; READ THE CSR
56 006726 010405      MOV    R4,R5        ; SAVE THE CONTENTS
57 006730 042704 177770      BIC    #177770,R4   ; CLEAR UNWANTED BITS
58 006734 020403      CMP    R4,R3        ; EXPECTED PATTERN?
59 006736 001404      BEQ    2$          ; IF YES, BRANCH
60 006740      ERRHRD 401,E401,ER401 ; ELSE REPORT THE ERROR
61 006740 104456      TRAP    C$ERHRD
62 006742 000621      .WORD  401
63 006744 007067      .WORD  E401
64 006746 002602      .WORD  ER401
65 006750      2$:  ENDSEG      ;----- END SEGMENT
66 006750 104405      TRAP    C$ESEG
67 006752 005203      INC    R3          ; NEXT EXPECTED CSR PATTERN
68 006754 062701 002000      ADD    #2000,R1    ; NEXT DBUFF WRITE PATTERN
69 006760 020127 020000      CMP    R1,#20000  ; ALL PATTERNS DONE?
70 006764 001350      BNE    1$          ; IF NOT, DO NEXT
71 006766      EXIT TST      ; ELSE END OF TEST
72 006766 104432      TRAP    C$EXIT
73 006770 000206      .WORD  L10031-
74 006772      ENDSUB      ;***** END SUBTEST
75 006772 104403      TRAP    C$ESUB
76 006772
77
78 006774      .NLIST  BEX
79 007057 103 117 115 E400: .ASCII /COMBINATION OF CSR BIT 5 AND BITS 8 - 15 COULD NOT /
80 007057 102 105 040 .ASCIZ /BE SET./
81 007067 103 117 115 E401: .ASCII /COMBINATION OF CSR BITS 0 - 2 COULD NOT BE SET VIA /
82 007152 124 110 105 .ASCIZ /THE DBUFF REGISTER./
83
84 .LIST  BEX
85 .EVEN
86
87 007176      ENDTST
88 007176      L10031:
89 007176 104401      TRAP    C$ETST

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49

.SBTTL TEST 5: PICTURE STORE DATA

..++
 : A ZERO DATA PATTERN (COLOUR BLACK) IS WRITTEN TO THE FIRST PICTURE
 : STORE LOCATION AND CHECKED TO READ BACK CORRECTLY IN THE CSR. THIS
 : IS REPEATED FOR ALL OF THE PICTURE STORE LOCATIONS TO FORM AN ALL
 : BLACK BACKGROUND.

.. : DATA IN ALL 8 COLOUR COMBINATIONS IS THEN WRITTEN TO EACH PICTURE
 : STORE LOCATION IN TURN AND AFTER EACH WRITE OPERATION, THE CSR IS
 : EXAMINED TO ENSURE THAT THE DATA READS BACK CORRECTLY. EACH
 : LOCATION IS RESET TO THE BACKGROUND COLOUR AFTER THE ABOVE
 : OPERATION.

.. : THE ENTIRE TEST IS THEN REPEATED USING WHITE (DATA 7) AS THE
 : BACKGROUND COLOUR.

..--

BGNTST

T5::

```

MOV #50,@VTVCSR ; SET VIDEO ENABLE AND ZERO OFFSET
CLR BKGND ; SET BACKGROUND TO BLACK
CLR R4 ; AND EXPECTED BACKGROUND

: SET PICTURE STORE TO BACKGROUND COLOUR
T5A: MOV BKGND,R1 ; INITIALISE DOT NO. AND COLOUR
MOV #40000,R5 ; READ PICTURE STORE MASK

1$: BGNSEG ;----- BEGIN SEGMENT TRAP C$BSEG
MOV R1,@DBUFF ; WRITE BACKGROUND TO DBUFF
MOV R5,@DBUFF ; LATCH COLOUR INTO CSR
MOV @VTVCSR,R2 ; READ THE CSR
MOV R2,R3 ; SAVE THE CONTENTS
BIC #177770,R2 ; GET THE COLOUR
CMP R2,R4 ; BACKGROUND COLOUR?
BEQ 2$ ; IF YES, BRANCH
ERRHRD 500,E500,ER500 ; ELSE REPORT THE ERROR TRAP C$ERHRD
; .WORD 500
; .WORD E500
; .WORD ER500

2$: ENDSEG ;----- END SEGMENT TRAP C$ESEG
; 10000$:

INC R5 ; NEXT DOT TO READ
INC R1 ; AND TO WRITE
BIT #777,R1 ; ALL DOTS DONE?
BNE 1$ ; IF NOT, DO NEXT

ADD #400,@VTVCSR ; NEXT LINE
BCC T5A ; IF MORE LINES, GO BACK

: SET ALL OTHER BIT COMBINATIONS

```

```

50
51 007310 012777 000040 172654 ; MOV #40,@VTVCSR ; SET VIDEO ENABLE ONLY
52 007316 005002 CLR R2 ; FIRST EXPECTED COLOUR
53
54 007320 005001 3$: CLR R1 ; INITIALISE DOT NO. AND DATA
55 007322 012705 040000 MOV #40000,R5 ; READ PICTURE STORE MASK
56
57 007326 4$: BGNSEG ;----- BEGIN SEGMENT
007326 104404 TRAP CSBSEG
58
59 007330 010177 172640 MOV R1,@DBUFF ; WRITE COLOUR TO DBUFF
60 007334 010577 172634 MOV R5,@DBUFF ; LATCH COLOUR INTO CSR
61 007340 017703 172626 MOV @VTVCSR,R3 ; READ THE CSR
62 007344 010304 MOV R3,R4 ; SAVE THE CONTENTS
63 007346 042703 177770 BIC #177770,R3 ; GET THE COLOUR
64 007352 020302 CMP R3,R2 ; EXPECTED VALUE?
65 007354 001404 BEQ 5$ ; IF YES, BRANCH
66 007356 ERRHRD 501,E501,ER501 ; ELSE REPORT THE ERROR
007356 104456 TRAP CSERHRD
007360 000765 .WORD 501
007362 007552 .WORD E501
007364 002724 .WORD ER501
67 007366 5$: ENDSEG ;----- END SEGMENT
007366 10001$: TRAP CSESEG
007366 104405
68
69 007370 005202 INC R2 ; NEXT EXPECTED COLOUR
70 007372 062701 002000 ADD #2000,R1 ; NEXT DBUFF WRITE COLOUR
71 007376 032701 020000 BIT #20000,R1 ; ALL COLOURS DONE?
72 007402 001751 BEQ 4$ ; IF NOT, DO NEXT
73
74 007404 005002 CLR R2 ; ELSE RESET EXPECTED COLOUR
75 007406 042701 020000 BIC #20000,R1 ; CLEAR COLOUR OVERFLOW BIT
76 007412 056701 000062 BIS BKGND,R1 ; SET BACKGROUND COLOUR
77 007416 010177 172552 MOV R1,@DBUFF ; WRITE BACKGROUND COLOUR
78 007422 042701 016000 BIC #16000,R1 ; CLEAR COLOUR BITS
79
80 007426 005205 INC R5 ; NEXT READ DOT POSITION
81 007430 005201 INC R1 ; AND WRITE DOT POSITION
82 007432 032701 001000 BIT #1000,R1 ; ALL DOTS DONE?
83 007436 001733 BEQ 4$ ; IF NOT, DO NEXT
84
85 007440 062777 000400 172524 ADD #400,@VTVCSR ; ELSE NEXT LINE
86 007446 103324 BCC 3$ ; IF MORE, GO BACK
87
88 007450 005767 000024 TST BKGND ; WHITE BACKGROUND DONE?
89 007454 001007 BNE 6$ ; IF YES, BRANCH
90 007456 012767 016000 000014 MOV #16000,BKGND ; ELSE FLAG WHITE BACKGROUND
91 007464 012704 000007 MOV #7,R4 ; AND CSR COLOUR
92 007470 000167 177520 JMP TSA ; AND REPEAT THE TEST
93
94 007474 6$: EXIT TST ; END THE TEST
007474 104432 TRAP CSEXIT
007476 000132 .WORD L10034-
95
96 007500 000000 BKGND: .WORD 0 ; BACKGROUND COLOUR TO WRITE
97

```

98						.NLIST	BEX		
99	007502	102	101	103	E500:	.ASCIZ	/BACKGROUND COLOUR READ BACK INCORRECTLY/		
100	007552	104	101	124	E501:	.ASCIZ	/DATA READ BACK INCORRECTLY FROM PICTURE STORE/		
101						.LIST	BEX		
102						.EVEN			
103	007630					ENDTST			
	007630							L10034:	
	007630	104401						TRAP	CSETST

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56

.SBTTL TEST 6: PICTURE STORE COLUMN ADDRESSING

```

:++
: THIS VERIFIES THAT WRITING TO ANY COLUMN OF THE PICTURE STORE
: DOES NOT AFFECT THE CONTENTS OF ANY OTHER COLUMN. SINCE EACH
: LOCATION CAN HOLD A 3 BIT DATA VALUE, THE COLUMN ADDRESS LINES ARE
: CHECKED IN GROUPS OF 3.

: COLUMN ADDRESS BITS 0 - 2 ARE CHECKED BY WRITING THE VALUES 0 - 7 IN
: CONSECUTIVE LOCATIONS THROUGHOUT THE PICTURE STORE AND CHECKING THAT
: THE DATA READS BACK CORRECTLY VIA THE CSR.

: COLUMN ADDRESS BITS 3 - 5 ARE CHECKED BY WRITING ZERO TO THE FIRST
: 8 LOCATIONS, 1 TO THE NEXT 8 LOCATIONS ETC. UNTIL THE PICTURE STORE
: IS FULL. THE DATA IS THEN VERIFIED VIA THE CSR.

: COLUMN ADDRESS BITS 6 - 8 ARE CHECKED BY WRITING ZERO TO THE FIRST
: 64 LOCATIONS, ONE TO THE NEXT 64 LOCATIONS AND SO ON, UNTIL THE
: PICTURE STORE IS FULL. THE DATA IS THEN VERIFIED VIA THE CSR.
  
```

--

BGNTST

T6::

```

007632      BGNTST
007632
24 007632 012767 000001 000252      MOV      #1,NCOLS      ; INITIALISE 1 COLUMN PER COLOUR
25
26
27
28
29 007640 005002      T6A:    CLR      R2      ; DOT COUNTER FOR CURRENT COLOUR
30 007642 005001      CLR      R1      ; INITIALISE DOT NO. AND COLOUR
31 007644 012777 000050 172320      MOV      #50,@VTVCSR  ; INITIALISE LINE NUMBER
32
33 007652 010177 172316      1$:    MOV      R1,@DBUFF  ; WRITE COLOUR
34 007656 005202      INC      R2      ; INCREMENT DOT COUNTER
35 007660 020267 000226      CMP      R2,NCOLS  ; READY FOR NEXT COLOUR?
36 007664 103410      BLO     2$      ; IF NOT, BRANCH
37 007666 005002      CLR      R2      ; ELSE CLEAR DOT COUNTER
38 007670 062701 002000      ADD     #2000,R1   ; NEXT COLOUR
39 007674 032701 020000      BIT     #20000,R1  ; ALL COLOURS USED?
40 007700 001402      BEQ     2$      ; IF NOT, BRANCH
41 007702 042701 020000      BIC     #20000,R1  ; ELSE CLEAR COLOUR BITS
42
43 007706 005201      2$:    INC      R1      ; NEXT DOT POSITION
44 007710 032701 000777      BIT     #777,R1   ; ALL DOTS DONE?
45 007714 001356      BNE     1$      ; IF NOT, NEXT DOT
46 007716 162701 001000      SUB     #1000,R1  ; ELSE CLEAR DOT NUMBER
47
48 007722 062777 000400 172242      ADD     #400,@VTVCSR ; NEXT LINE
49 007730 103350      BCC     1$      ; IF MORE LINES, BRANCH
50
51
52
53
54
55
56 007732 005002      ; DOT COUNTER FOR CURRENT COLOUR
57 007734 012701 040000      MOV     #40000,R1  ; DOT 0, READ PICTURE STORE
58 007740 005004      CLR     R4      ; INITIALISE EXPECTED COLOUR
59 007742 012777 000040 172222      MOV     #40,@VTVCSR ; INITIALISE LINE NUMBER
  
```

```

57
58 007750          T6B:  BGNSEG          ;----- BEGIN SEGMENT
    007750 104404          ;                               TRAP      C$BSEG
59 007752 010177 172216      MOV      R1,@DBUFF      ; LATCH COLOUR INTO CSR
60 007756 017703 172210      MOV      @VTVCSR,R3    ; READ THE CSR
61 007762 010305          MOV      R3,R5        ; SAVE THE CONTENTS
62 007764 042703 177770      BIC      #177770,R3    ; GET THE COLOUR
63 007770 020304          CMP      R3,R4        ; AS EXPECTED?
64 007772 001404          BEQ      1$           ; IF YES, BRANCH
65 007774          ERRHRD 600,E600,ER600 ; ELSE REPORT THE ERROR
    007774 104456          ;                               TRAP      C$ERHRD
    007776 001130          ;                               .WORD    600
    010000 010114          ;                               .WORD    E600
    010002 003032          ;                               .WORD    ER600
66 010004          1$:  ENDSEG          ;----- END SEGMENT
    010004          ;                               10000$: TRAP      C$ESEG
    010004 104405          ;
67
68 010006 005202          INC      R2           ; INCREMENT DOT COUNTER
69 010010 020267 000076      CMP      R2,NCOLS     ; READY FOR NEXT COLOUR?
70 010014 103406          BLO     2$           ; IF NOT, BRANCH
71 010016 005002          CLR     R2           ; ELSE CLEAR DOT COUNTER
72 010020 005204          INC     R4           ; EXPECT NEXT COLOUR
73 010022 032704 000010      BIT     #10,R4        ; ALL COLOURS USED?
74 010026 001401          BEQ     2$           ; IF NOT, BRANCH
75 010030 005004          CLR     R4           ; ELSE NEXT COLOUR
76
77 010032 005201          2$:  INC     R1           ; NEXT DOT PATTERN
78 010034 032701 000777      BIT     #777,R1       ; ALL DOTS DONE?
79 010040 001343          BNE     T6B          ; IF NOT, NEXT DOT
80 010042 162701 001000      SUB     #1000,R1      ; ELSE CLEAR DOT NUMBER
81
82 010046 062777 000400 172116 ADD     #400,@VTVCSR   ; NEXT LINE
83 010054 103335          BCC     T6B          ; IF MORE LINES, BRANCH
84
85 010056 006367 000030      ASL     NCOLS         ; FLAG NEXT 3
86 010062 006367 000024      ASL     NCOLS         ; ADDRESS LINES
87 010066 006367 000020      ASL     NCOLS         ; TO BE TESTED
88 010072 042767 177400 000012 BIC     #177400,NCOLS  ; STOP IF TOP BYTE USED
89 010100 001402          BEQ     3$           ; IF FINISHED, BRANCH
90 010102 000167 177532      JMP     T6A          ; ELSE NEXT ADDRESS LINES
91
92 010106          3$:  EXIT  TST          ; END OF TEST
    010106 104432          ;                               TRAP      C$EXIT
    010110 000052          ;                               .WORD    L10035-.
93
94 010112 000000          NCOLS: .WORD    0          ; NO. OF COLUMNS OF CURRENT COLOUR
95
96 010114 120 111 103 E600: .NLIST  BEX          ;
    .ASCIZ /PICTURE STORE COLUMN ADDRESSING ERROR/
97 .LIST  BEX
98 .EVEN
99 010162          .ENDTST
    010162          ;                               L10035: TRAP      C$ETST
    010162 104401          ;
    
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56

.SBTTL TEST 7: PICTURE STORE LINE ADDRESSING

```

:++
: THIS VERIFIES THAT WRITING TO ANY LINE OF THE PICTURE STORE
: DOES NOT AFFECT THE CONTENTS OF ANY OTHER LINE. SINCE EACH
: LOCATION CAN HOLD A 3 BIT DATA VALUE, THE LINE ADDRESS LINES ARE
: CHECKED IN GROUPS OF THREE.
:
: LINE ADDRESS BITS 0 - 2 (CSR BITS 8 - 10) ARE CHECKED BY WRITING ZERO
: TO ALL LOCATIONS IN THE FIRST LINE, ONE TO ALL LOCATIONS IN THE
: NEXT LINE AND SO ON, UNTIL ALL LINES ARE WRITTEN TO. THE DATA IS THEN
: READ BACK AND VERIFIED VIA THE CSR.
:
: LINE ADDRESS BITS 3 - 5 (CSR BITS 11 - 13) ARE CHECKED BY WRITING
: ZERO TO THE FIRST EIGHT LINES, ONE TO THE NEXT EIGHT LINES ETC.,
: TO THE END OF THE PICTURE STORE. THE DATA IS THEN VERIFIED VIA THE
: CSR.
:
: LINE ADDRESS BITS 6 AND 7 (CSR BITS 14 AND 15) ARE CHECKED BY WRITING
: ZERO TO THE FIRST 64 LINES, ONE TO THE NEXT 64 LINES, TWO TO THE NEXT
: 64 LINES, AND THREE TO THE LAST 64 LINES. THE PICTURE STORE DATA IS
: THEN READ BACK AND VERIFIED.
:--
  
```

BGNTST

T7::

```

MOV #1,NLINS ; INITIALISE ONE LINE PER COLOUR
: WRITE TO THE PICTURE STORE
17A: CLR R2 ; LINE COUNTER FOR CURRENT COLOUR
CLR R1 ; INITIALISE DOT NO. AND COLOUR
MOV #50,@VTVCSR ; INITIALISE LINE NUMBER
18: MOV R1,@DBUFF ; WRITE COLOUR
INC R1 ; NEXT DOT POSITION
BIT #777,R1 ; ALL DOTS DONE?
BNE 18 ; IF NOT, NEXT DOT
SUB #1000,R1 ; ELSE CLEAR DOT NUMBER
ADD #400,@VTVCSR ; NEXT LINE
BCS 28 ; IF ALL LINES DONE, BRANCH
INC R2 ; ELSE INCREMENT LINE COUNTER
CMP R2,NLINS ; READY FOR NEXT COLOUR?
BLO 18 ; IF NOT, DO NEXT LINE
CLR R2 ; ELSE CLEAR LINE COUNTER
ADD #2000,R1 ; NEXT COLOUR
BIT #2000,R1 ; ALL COLOURS USED?
BEQ 18 ; IF NOT, BRANCH
BIC #2000,R1 ; ELSE CLEAR COLOUR BITS
BR 18 ; AND DO NEXT LINE
: READ BACK THE DATA
28: CLR R2 ; LINE COUNTER FOR CURRENT COLOUR
MOV #40000,R1 ; DOT 0, READ PICTURE STORE
  
```

```

010164
010164
010164 012767 000001 000256
010172 005002
010174 005001
010176 012777 000050 171766
010204 010177 171764
010210 005201
010212 032701 000777
010216 001372
010220 162701 001000
010224 062777 000400 171740
010232 103415
010234 005202
010236 020267 000206
010242 103760
010244 005002
010246 062701 002000
010252 032701 020000
010256 001752
010260 042701 020000
010264 000747
010266 005002
010270 012701 040000
  
```

HARDWARE TESTS MACRO V03.01 18-NOV-81 11:10:45 PAGE 40-1
 TEST 7: PICTURE STORE LINE ADDRESSING

```

57 010274 005004          CLR      R4          ; INITIALISE EXPECTED COLOUR
58 010276 012777 000040 171666  MOV     #40,@VTVCSR ; INITIALISE LINE NUMBER
59
60 010304          T7B:   BGNSEG          ;----- BEGIN SEGMENT
    010304 104404          TRAP          C$BSEG
61 010306 010177 171662    MOV     R1,@DBUFF    ; LATCH COLOUR INTO CSR
62 010312 017703 171654    MOV     @VTVCSR,R3  ; READ THE CSR
63 010316 010305          MOV     R3,R5        ; SAVE THE CONTENTS
64 010320 042703 177770    BIC     #177770,R3  ; GET THE COLOUR
65 010324 020304          CMP     R3,R4        ; AS EXPECTED?
66 010326 001404          BEQ     1$          ; IF YES, BRANCH
67 010330          ERRHRD 700,E700,ER700 ; ELSE REPORT THE ERROR
    010330 104456          TRAP          C$ERHRD
    010332 001274          .WORD       700
    010334 010452          .WORD       E700
    010336 003214          .WORD       ER700
68 010340          1$:   ENDSEG          ;----- END SEGMENT
    010340          10000$: TRAP          C$ESEG
    010340 104405
69
70 010342 005201          INC     R1          ; NEXT DATA PATTERN
71 010344 032701 000777    BIT     #777,R1     ; ALL DOTS DONE?
72 010350 001355          BNE     T7B        ; IF NOT, NEXT DOT
73 010352 162701 001000    SUB     #1000,R1    ; ELSE CLEAR DOT NUMBER
74
75 010356 062777 000400 171606  ADD     #400,@VTVCSR ; NEXT LINE
76 010364 103413          BCS     2$          ; IF ALL LINES DONE, BRANCH
77
78 010366 005202          INC     R2          ; ELSE INCREMENT LINE COUNTER
79 010370 020267 000054    CMP     R2,NLINS    ; READY FOR NEXT COLOUR?
80 010374 103743          BLO     T7B        ; IF NOT, READ NEXT LINE
81
82 010376 005002          CLR     R2          ; ELSE CLEAR LINE COUNTER
83 010400 005204          INC     R4          ; EXPECT NEXT COLOUR
84 010402 032704 000010    BIT     #10,R4      ; ALL COLOURS USED?
85 010406 001736          BEQ     T7B        ; IF NOT, DO NEXT LINE
86 010410 005004          CLR     R4          ; ELSE RESET COLOUR
87 010412 000734          BR     T7B        ; AND READ NEXT LINE
88
89 010414 006367 000030          2$:   ASL     NLINS    ; FLAG NEXT 3
90 010420 006367 000024    ASL     NLINS    ; ADDRESS LINES
91 010424 006367 000020    ASL     NLINS    ; TO BE TESTED
92 010430 026727 000014 001000  CMP     NLINS,#1000 ; ALL FINISHED?
93 010436 001402          BEQ     3$          ; IF YES, BRANCH
94 010440 000167 177526    JMP     T7A        ; ELSE NEXT ADDRESS LINES
95
96 010444          3$:   EXIT     TST          ; END OF TEST
    010444 104432          TRAP          C$EXIT
    010446 000050          .WORD       L10036-.
97
98 010450 000000          NLINS: .WORD     0          ; NO. OF LINES PER COLOUR
99
100
101 010452          120      111      103  E700: .NLIST  BEX
102                                     .ASCIZ  /PICTURE STORE LINE ADDRESSING ERROR/
103                                     .LIST   BEX
104 010516          .EVEN
                                     .ENDTST

```

010516
010516 104401

L10036: TRAP C\$ETST

```

1          .SBTTL TEST 8: 8-DOT
2
3          :++
4          : THIS TEST CHECKS THAT IF DBUFF BIT 15 (8-DOT) IS SET, PICTURE
5          : STORE WRITES ARE MADE TO EIGHT DOTS AT A TIME REGARDLESS OF THE
6          : VALUES OF DBUFF BITS 0 - 2. FOR EACH COMBINATION OF THE LOWER DOT
7          : ADDRESS BITS, A NEW COLOUR IS USED AND THE 8-DOT WRITE VERIFIED.
8          :--
9
10         010520          BGNTST
11         010520
12         010520 005002          CLR      R2          ; INITIALISE DBUFF WRITE COLOUR
13         010522 005003          CLR      R3          ; INITIALISE CSR COLOUR AND DOT NO.
14         010524 012777 000050 171440  MOV     #50,@VTVCSR ; SET VIDEO ENABLE AND ZERO OFFSET
15
16         :
17         : INITIALISE FIRST 8 DOTS
18         :
19         010532 012701 016000          MOV     #16000,R1      ; SET COLOUR TO WHITE
20         010536 010177 171432 1$:     MOV     R1,@DBUFF    ; WRITE DOT
21         010542 005201          INC     R1          ; NEXT DOT
22         010544 032701 000007          BIT     #7,R1        ; 8 DOTS DONE?
23         010550 001372          BNE    1$          ; IF NOT, DO MORE
24
25         : DO 8 DOT TEST
26
27         010552          T8A:     BGNSEG          ;----- BEGIN SEGMENT
28         010552 104404          MOV     #100000,R1   ; SET 8-DOT
29         010554 012701 100000          BIS    R2,R1        ; SET THE COLOUR
30         010560 050201          BIS    R3,R1        ; AND DOT NUMBER
31         010562 050301          MOV     R1,@DBUFF   ; WRITE TO DBUFF
32         010564 010177 171404          BIS    #40000,R1   ; SET READ PICTURE STORE
33         010570 052701 040000          BIC    #100000,R1  ; CLEAR 8-DOT
34         010574 042701 100000
35         010600 010177 171370          T8B:     MOV     R1,@DBUFF ; LATCH COLOUR INTO CSR
36         010604 017704 171362          MOV     @VTVCSR,R4 ; READ THE CSR
37         010610 010405          MOV     R4,R5      ; SAVE THE CONTENTS
38         010612 042704 177770          BIC    #177770,R4  ; GET THE COLOUR
39         010616 020403          CMP    R4,R3      ; EXPECTED COLOUR
40         010620 001404          BEQ    1$          ; IF YES, BRANCH
41         010622          ERRHRD 800,E800,ER800 ; ELSE REPORT THE ERROR
42         010622 104456          TRAP   C$ERHRD
43         010624 001440          .WORD 800
44         010626 010664          .WORD E800
45         010630 003404          .WORD ER800
46         010632 005201          1$:     INC     R1          ; NEXT DOT ADDRESS
47         010634 032701 000010          BIT     #10,R1     ; 8 DOTS READ?
48         010640 001757          BEQ    T8B        ; IF NOT, READ NEXT
49         010642          ENDSEG          ;----- END SEGMENT
50         010642 104405          10000$: TRAP   C$ESEG
51
52         010644 062702 002000          ADD    #2000,R2   ; ELSE NEXT COLOUR
53         010650 005203          INC    R3          ; NEXT READ COLOUR, DOT NO.
54         010652 032703 000010          BIT    #10,R3    ; ALL COLOURS DONE?

```

HARDWARE TESTS MACRO V03.01 18-NOV-81 11:10:45 PAGE 41-1
TEST 8: 8-DOT

```

50 010656 001735          BEQ      T8A      ; IF NOT, DO NEXT
51 010660          EXIT     TST      ; ELSE END OF TEST
   010660 104432
   010662 000030          TRAP     C$EXIT
                                     .WORD  L10037-.
52
53
54 010664      070      040      055  E800:  .NLIST  BEX
55                                     .ASCIZ  /8 - DOT WRITE FAILURE/
56                                     .LIST   BEX
57 010712          .EVEN
   010712          .ENDTST
   010712 104401          L10037:  TRAP     C$ETST

```



```

1      .SBTTL TEST 10: VIDEO ENABLE
2
3
4      :++
5      : THE PICTURE STORE IS PRESET TO BLUE FOR FIVE SECONDS. BIT 5 OF
6      : THE CSR (VIDEO ENABLE) IS THEN CLEARED FOR FIVE SECONDS, DURING
7      : WHICH TIME THE MONITOR DISPLAY SHOULD BE DARK. THE DISPLAY IS THEN
8      : REENABLED FOR A FURTHER FIVE SECONDS.
9      :--
10     BGNTST
11
12     : PRESET TO WHITE, VIDEO ENABLED
13
14     011316 012777 010000 170650      MOV    #10000,@DBUFF  ; SET PRESET COLOUR BLUE
15     011324 012777 000140 170640      MOV    #140,@VTVCSR  ; PERFORM THE PRESET
16     011332 012701 000310              MOV    #200.,R1      ; WAIT FOR 5 SECONDS
17     011336 004767 171054      1$:   JSR    PC,WAIT25   ; 25 MILLISECOND DELAY
18     011342              BREAK      ; ALLOW OPERATOR BREAK-IN
19     011342 104422              ;
20     011344 005301              DEC    R1             ; TIME UP?
21     011346 001373              BNE   1$             ; IF NOT, WAIT LONGER
22
23     : CLEAR VIDEO ENABLE
24
25     011350 005077 170616      CLR    @VTVCSR       ; CLEAR VIDEO ENABLE
26     011354 012701 000310      MOV    #200.,R1      ; WAIT FOR 5 SECONDS
27     011360 004767 171032      2$:   JSR    PC,WAIT25   ; 25 MILLISECOND DELAY
28     011364              BREAK      ; ALLOW OPERATOR BREAK-IN
29     011364 104422              ;
30     011366 005301              DEC    R1             ; TIME UP?
31     011370 001373              BNE   2$             ; IF NOT, WAIT LONGER
32
33     : REENABLE VIDEO
34
35     011372 012777 000040 170572      MOV    #40,@VTVCSR   ; SET VIDEO ENABLE
36     011400 012701 000310      MOV    #200.,R1      ; WAIT FOR 5 SECONDS
37     011404 004767 171006      3$:   JSR    PC,WAIT25   ; 5 MILLISECOND DELAY
38     011410              BREAK      ; ALLOW OPERATOR BREAK-IN
39     011410 104422              ;
40     011412 005301              DEC    R1             ; TIME UP?
41     011414 001373              BNE   3$             ; IF NOT, WAIT LONGER
42
43     011416              EXIT    TST           ; END OF TEST
44     011416 104432              ;
45     011420 000002              ;
46     011422              ENDTST
47     011422              ;
48     011422 104401              ;
49
50     L10041:
51     TRAP    C$BRK
52     TRAP    C$BRK
53     TRAP    C$BRK
54     TRAP    C$EXIT
55     TRAP    L10041-.
56     TRAP    C$SETST

```

```

1      .SBTTL TEST 11: DISPLAY ADDRESSING
2
3      :++
4      : THE PICTURE STORE IS PRESET TO BLUE. LINES OF MAGENTA ARE THEN
5      : WRITTEN FROM THE TOP OF THE DISPLAY UNTIL THE WHOLE SCREEN HAS
6      : CHANGED COLOUR. THE TRANSITION SHOULD BE SMOOTH, TAKING APPROXIMATELY
7      : 7 SECONDS.
8      : COLUMNS OF WHITE ARE THEN WRITTEN FROM THE LEFT SIDE OF THE DISPLAY
9      : UNTIL THE SCREEN IS ALL WHITE. AGAIN THE TRANSITION SHOULD BE SMOOTH.
10     : IF THE DISPLAY DOES NOT APPEAR AS DESCRIBED HERE, AN ADDRESSING
11     : FAULT ON THE OUTPUT SIDE OF THE DEVICE IS INDICATED.
12     :--
13
14     011424      BGNTST
15     011424
16
17     : PRESET SCREEN TO BLUE
18     011424 012777 010000 170542      MOV      #10000,@DBUFF      ; SET PRESET COLOUR BLUE
19     011432 012777 000150 170532      MOV      #150,@VTVCSR     ; PERFORM THE PRESET
20     011440 012701 177777              MOV      #-1,R1           ; SET UP WAIT COUNTER
21     011444 105777 170522      1$:    TSTB      @VTVCSR     ; READY SET?
22     011450 100403              BMI      2$               ; IF YES, BRANCH
23     011452              BREAK                    ; ELSE ALLOW OPERATOR BREAK IN
24     011452 104422              ; TRAP      CSBRK
25     011454 005301              DEC      R1               ; WAITED TOO LONG?
26     011456 001372              BNE     1$               ; IF NOT, WAIT LONGER
27
28     : MOVE MAGENTA DOWN THE DISPLAY
29     011460 012777 000040 170504      2$:    MOV      #40,@VTVCSR  ; START AT LINE 0
30     011466 012701 012000              MOV      #12000,R1       ; SET WRITE COLOUR TO MAGENTA
31
32     011472 010177 170476      3$:    MOV      R1,@DBUFF     ; WRITE DOT
33     011476 005201              INC      R1               ; NEXT DOT ADDRESS
34     011500 032701 000777              BIT      #777,R1         ; LINE FINISHED?
35     011504 001372              BNE     3$               ; IF NOT, DO NEXT DOT
36
37     011506 004767 170704              JSR     PC,WAIT25        ; WAIT FOR 25 MILLISECONDS
38     011512              BREAK                    ; ALLOW OPERATOR BREAK IN
39     011512 104422              ; TRAP      CSBRK
40
41     011514 042701 001000              BIC     #1000,R1         ; RESET TO START OF LINE
42     011520 062777 000400 170444      ADD     #400,@VTVCSR     ; AND NEXT LINE
43     011526 103361              BCC     3$               ; IF MORE LINES, GO BACK
44
45     : MOVE WHITE ACROSS THE DISPLAY
46     011530 012777 000040 170434      MOV     #40,@VTVCSR     ; START AT LINE 0
47     011536 012701 016000              MOV     #16000,R1       ; SET WRITE COLOUR TO WHITE
48
49     011542 010177 170426      5$:    MOV     R1,@DBUFF     ; WRITE DOT
50     011546 062777 000400 170416      ADD     #400,@VTVCSR     ; NEXT LINE ADDRESS
51     011554 103372              BCC     5$               ; IF MORE LINES, GO BACK
52
53     011556 016700 170424              MOV     COUNT,R0        ; GET 25 MILLISECOND COUNT
54     011562 006200              ASR     R0               ; MAKE IT 12 MILLISECONDS

```

```
55 011564 005300          6$: DEC      R0          : WAIT 12 MILLISECONDS
56 011566 001376          BNE     6$          :
57 011570          BREAK          : ALLOW OPERATOR BREAK IN          TRAP    C$BRK
   011570 104422
58
59 011572 005201          INC     R1          : NEXT COLUMN
60 011574 032701 000777  BIT     #777,R1    : ALL COLUMNS DONE?
61 011600 001360          BNE     5$          : IF NOT, DO NEXT
62
63 011602          EXIT TST          : ELSE END OF TEST
   011602 104432          TRAP    C$EXIT
   011604 000002          .WORD  L10042-.
64 011606          ENDTST
   011606          L10042: TRAP    C$ETST
   011606 104401
```

```

1      .SBTTL TEST 12: OFFSET
2
3
4      :++
5      : THE PICTURE STORE IS PRESET TO BLUE. A LINE OF MAGENTA IS THEN WRITTEN
6      : TO THE TOP OF THE DISPLAY AND THE OFFSET REGISTER CHANGED TO MOVE
7      : THE LINE DOWN ONE POSITION. THIS IS REPEATED UNTIL THE WHOLE
8      : DISPLAY IS MAGENTA, WHICH SHOULD TAKE ABOUT 7 SECONDS. THE DISPLAY IS
9      : THEN CHANGED TO WHITE FROM THE BOTTOM USING THE SAME PROCESS,
10     : UNTIL THE SCREEN IS ALL WHITE.
11     : IN BOTH CASES, THE LINE BETWEEN THE COLOURS SHOULD MOVE SMOOTHLY
12     : ACROSS THE SCREEN. ANY UNEVEN MOVEMENT INDICATES A PROBLEM
13     : IN THE OFFSET REGISTER.
14     :--
15     BGNTST
16
17     : PRESET SCREEN TO BLUE
18
19     011610 012777 010000 170356      MOV    #10000,@DBUFF      : SET PRESET COLOUR BLUE
20     011616 012777 000140 170346      MOV    #140,@VTVCSR      : PERFORM THE PRESET
21     011624 012701 177777              MOV    #-1,R1            : SET UP WAIT COUNTER
22     011630 105777 170336      1$:   TSTB   @VTVCSR        : READY SET?
23     011634 100403              BMI    2$                : IF YES, BRANCH
24     011636              BREAK      : ELSE ALLOW OPERATOR BREAK IN
25     011640 005301              DEC    R1                : WAITED TOO LONG?
26     011642 001372              BNE   1$                : IF NOT, WAIT LONGER
27
28     : MOVE MAGENTA DOWN THE DISPLAY
29
30     011644 012701 177450      2$:   MOV    #177450,R1      : OFFSET LAST LINE TO TOP
31     011650 010177 170316      3$:   MOV    R1,@VTVCSR      : WRITE THE OFFSET
32     011654 012702 112000      MOV    #112000,R2        : SET FIRST 8 DOTS MAGENTA
33     011660 010277 170310      5$:   MOV    R2,@DBUFF      : WRITE 8 DOTS
34     011664 062702 000010      ADD    #10,R2            : NEXT DOT
35     011670 032702 000777      BIT    #777,R2          : LINE WRITTEN?
36     011674 001371              BNE   5$                : IF NOT, DO MORE DOTS
37     011676 162702 001000      SUB    #1000,R2         : ELSE CLEAR DOT NUMBER
38     011702 004767 170510      JSR   PC,WAIT25        : WAIT FOR 25 MILLISECONDS
39     011706              BREAK      : ALLOW OPERATOR BREAK-IN
40     011706 104422              TRAP  CSBRK
41     011710 162701 000400      SUB    #400,R1          : REDUCE THE OFFSET
42     011714 103355              BCC   3$                : IF MORE LINES, BRANCH
43
44     : MOVE WHITE UP THE DISPLAY
45
46     011716 012701 000450      MOV    #450,R1          : OFFSET FIRST LINE TO BOTTOM
47     011722 012703 000040      MOV    #40,R3           : FIRST WRITE LINE
48     011726 032777 000020 170236      7$:   BIT    #20,@VTVCSR    : FIELD BIT CLEAR?
49     011734 001374              BNE   7$                : IF NOT, WAIT
50     011736 010177 170230      MOV    R1,@VTVCSR      : WRITE THE OFFSET
51     011742 010377 170224      MOV    R3,@VTVCSR      : SET UP TO WRITE LINE
52     011746 012702 116000      MOV    #116000,R2      : SET FIRST 8 DOTS WHITE
53     011752 010277 170216      8$:   MOV    R2,@DBUFF      : WRITE 8 DOTS
54     011756 062702 000010      ADD    #10,R2          : NEXT DOTS

```

```
55 011762 032702 001000      BIT      #1000,R2      ; LINE WRITTEN?
56 011766 001771              BEQ      8$           ; IF NOT, DO MORE DOTS
57 011770 162702 001000      SUB      #1000,R2     ; ELSE CLEAR THE DOT NUMBER
58 011774 004767 170416      JSR      PC,WAIT25   ; WAIT FOR 25 MILLISECONDS
59 012000              BREAK                     ; ALLOW OPERATOR BREAK-IN
    012000 104422                                TRAP      C$BRK
60
61 012002 062703 000400      ADD      #400,R3     ; NEXT WRITE LINE
62 012006 062701 000400      ADD      #400,R1     ; INCREASE THE OFFSET
63 012012 103345              BCC      7$           ; IF MORE LINES, BRANCH
64 012014 012777 000010 170150  MOV      #10,@VTVCSR ; CLEAR THE OFFSET REGISTER
65
66 012022              EXIT      TST
    012022 104432                                TRAP      C$EXIT
    012024 000002                                .WORD    L10043-
67 012026              ENDTST
    012026              L10043: TRAP      C$SETST
    012026 104401
```

.SBTTL TEST 13: PATTERN GENERATOR

..++
 : THIS TEST IS FOR SETTING UP AND CHECKING THE OUTPUT TO THE DISPLAY
 : MONITOR. NINE PATTERNS ARE PROVIDED - EIGHT TO PRESET THE SCREEN
 : TO EACH POSSIBLE COLOUR, AND ONE TO OUTPUT A CROSS HATCH OF 32
 : COLUMN BY 16 LINE RECTANGLES. THE NUMBER OF RECTANGLES DISPLAYED
 : WILL DEPEND ON THE DEVICE CONFIGURATION.

..--
 : NORMALLY, THE NINE PATTERNS ARE DISPLAYED IN TURN, EACH REMAINING
 : ON THE SCREEN FOR APPROXIMATELY FIVE SECONDS. HOWEVER, IF MANUAL
 : SELECTION IS SELECTED AT START UP, EACH PATTERN IS KEPT DISPLAYED
 : UNTIL THE RETURN KEY IS HIT ON THE OPERATOR CONSOLE.

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16 012030          BGNTST
    012030
17
18 012030 005001          CLR      R1          ; FIRST PRESET COLOUR
19
20 012032 010177 170136  T13A: MOV     R1, @DBUFF      ; SET THE PRESET COLOUR
21 012036 012777 000150 170126  MOV     #150, @VTVCSSR ; DO THE PRESET
22
23
24
25 012044 005767 170114  2$:   TST     MANVEN      ; RUN MANUALLY?
26 012050 001413          BEQ     3$           ; IF NOT, BRANCH
27 012052          MANUAL          ; MANUAL ALLOWED?
28 012054 104450          BNCOMPLETE 3$          ; IF NOT, BRANCH
29 012056 103011          GMANID  READY, FLAG, A, 377, 0, 1, YES ; WAIT FOR <CR>
    012056 104443          TRAP    CS$MANI
    012060 000406          BR      10000$
    012062 012302          .WORD  FLAG
    012064 000152          .WORD  T$CODE
    012066 012304          .WORD  READY
    012070 000377          .WORD  377
    012072 000000          .WORD  T$LOLIM
    012074 000001          .WORD  T$HILIM
    012076          10000$:
30 012076 000407          BR      5$           ; CONTINUE
31
32 012100 012704 000310  3$:   MOV     #200, R4      ; WAIT FOR 5 SECONDS
33 012104 004767 170306  4$:   JSR     PC, WAIT25
34 012110          BREAK          ; ALLOW OPERATOR BREAK-IN
35 012110 104422          TRAP    CS$BRK
36 012112 005304          DEC     R4          ; TIME UP?
37 012114 001373          BNE    4$           ; IF NOT, WAIT LONGER
38
39
40 012116 032701 020000  5$:   BIT     #20000, R1   ; ALL PATTERNS DONE?
41 012122 001065          BNE    12$          ; IF YES, END TEST
42 012124 062701 002000  ADD     #2000, R1    ; ELSE NEXT COLOUR
43 012130 032701 020000  BIT     #20000, R1   ; ALL PRESETS DONE?
44 012134 001736          BEQ    T13A         ; IF NOT, NEXT COLOUR

```

```

45
46      ; GENERATE CROSS HATCH
47
48 012136 005077 170032      CLR   @DBUFF      ; SET PRESET COLOUR BLACK
49 012142 012777 000140 170022  MOV   #140,@VTVCSR ; DO THE PRESET
50 012150 012701 177777      MOV   #-1,R1      ; SET UP WAIT COUNTER
51 012154 105777 170012 6$:  TSTB  @VTVCSR    ; READY SET?
52 012160 100403      BMI   7$          ; IF YES, BRANCH
53 012162      BREAK      ; ELSE ALLOW OPERATOR BREAK IN
54 012164 005301      DEC   R1          ; WAITED TOO LONG?
55 012166 001372      BNE   6$          ; IF NOT, WAIT LONGER
56
57      ; WRITE FULL LINE
58
59 012170 012702 116000 7$:  MOV   #116000,R2   ; INITIALISE DOT NO.,WHITE
60 012174 010277 167774 8$:  MOV   R2,@DBUFF   ; WRITE 8 DOTS
61 012200 062702 000010      ADD   #10,R2      ; NEXT DOTS
62 012204 032702 001000      BIT   #1000,R2   ; LINE WRITTEN?
63 012210 001771      BEQ   8$          ; IF NOT, DO MORE DOTS
64 012212 000414      BR    11$         ; ELSE DO NEXT LINE
65
66      ; WRITE PARTIAL LINE
67
68 012214 012702 016000 9$:  MOV   #16000,R2   ; SET DOT 0, COLOUR WHITE
69 012220 010277 167750 10$: MOV   R2,@DBUFF   ; WRITE FIRST DOT
70 012224 062702 000037      ADD   #31,R2     ; END OF SQUARE
71 012230 010277 167740      MOV   R2,@DBUFF   ; WRITE PENULTIMATE DOT
72 012234 005202      INC   R2          ; NEXT DOT
73 012236 032702 001000      BIT   #1000,R2   ; LINE FINISHED?
74 012242 001766      BEQ   10$         ; IF NOT, GO BACK
75
76 012244 062777 000400 167720 11$: ADD  #400,@VTVCSR ; NEXT LINE
77 012252 103674      BCS   2$          ; IF FINISHED, GO AND WAIT
78 012254 017703 167712      MOV   @VTVCSR,R3 ; ELSE READ CSR
79 012260 042703 170377      BIC   #170377,R3 ; GET LINE NO. LOW BITS
80 012264 001741      BEQ   7$          ; IF ZERO, DO FULL LINE
81 012266 020327 007400      CMP   R3,#7400   ; LAST LINE OF SQUARE?
82 012272 001736      BEQ   7$          ; IF YES, DO FULL LINE
83 012274 000747      BR    9$          ; ELSE PARTIAL LINE
84
85 012276      12$:  EXIT   TST
86 012276 104432      TRAP  C$EXIT
87 012302 000000      .WORD L10044-.
88
89
90 012304 120 122 105  READY: .NLIST BEX
91 .ASCIZ /PRESS 'RETURN' FOR NEXT PATTERN/
92 .LIST BEX
93 012344
012344
012344 104401
L10044: TRAP C$ETST

```

HARDWARE TESTS MACRO V03.01 18-NOV-81 11:10:45 PAGE 47
TEST 13: PATTERN GENERATOR

1 012346
2

ENDMOD

1
12
13
42
43
44
45
46
47
48
49
50
51
52
53
54
55
65
66
67
68
69
76
77

.TITLE PARAMETER CODING

.SBTTL HARDWARE PARAMETER CODING SECTION

BGNMOD

::++

:: THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
:: THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
:: MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
:: INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
:: MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
:: WITH THE OPERATOR.
::--

BGNHRD

012346

012346
012346
012350

000004

.WORD L10045-LSHARD/2
LSHARD::

GPRMA GETADR,0,0,160000,177776,YES

012350
012350
012352
012354
012356

000031
012360
160000
177776

.WORD T\$CODE
.WORD GETADR
.WORD T\$LOLIM
.WORD T\$HILIM

ENDHRD

012360
012360

.EVEN
L10045:

012360
012363
012366
012371
012374
012377

126
063
113
104
105
000

124
061
040
104
123

126
055
101
122
123

GETADR: .ASCIZ /VTV31-K ADDRESS/

```

1      .SBTTL  SOFTWARE PARAMETER CODING SECTION
2
3
4      :++
5      : THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
6      : THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
7      : MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
8      : INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
9      : MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
10     : WITH THE OPERATOR.
11     :--
12     012400      BGNSFT
13     012400      000010
14     012402
15
16     LSSOFT::      .WORD  L10046-LSSOFT/2
17
18     13
19     22 012402      GPRML MANINT,0,1,YES
20     012402      000130
21     012404      012422
22     012406      000001
23
24     23 012410      GPRMD GETMAX,2,D,377,0,255.,YES
25     012410      001052
26     012412      012450
27     012414      000377
28     012416      000000
29     012420      000377
30
31     24
32     25      .EVEN
33     26
34     27 012422      ENDSFT
35
36     012422      L10046:      .EVEN
37
38     28
39     29
40     36
41     37 012422      122      125      116  MANINT: .NLIST  BEX
42     38 012450      101      125      124  GETMAX: .ASCIZ /RUN TEST 13 MANUALLY?/
43     39      .LIST  BEX
44     40      .EVEN
45     41
46     42 012476      $PATCH::
47     49
48     50      .BLKW  50.      ; PATCH AREA
49     51      .BLKB  400-<.8377> ; LASTAD SHIFT FOR LSI BUG
50     52 013000      LASTAD
51
52     013000      013012      .EVEN
53     013002      000003      .WORD  TSFREE
54     013004
55     53 013004      L$LAST::      .WORD  TSSIZE
56
57     ENDMOD

```

```
1  
2  
15  
16 013004            BGNSETUP            1  
17 013004            BGNPTAB  
    013004    000000  
    013006    000001  
    013010  
18 013010    174000            .WORD    174000  
19 013012            ENDPTAB  
    013012  
20 013012            ENDSETUP  
21                    .END  
  
L10047:            .WORD    0  
                  .WORD    L10051-./2-1  
  
L10051:
```

PARAMETER CODING
SYMBOL TABLE

ABITS 002204 G
 ABORT 005042
 ADR = 000020 G
 ASSEMB= 000010
 BIT0 = 000001 G
 BIT00 = 000001 G
 BIT01 = 000002 G
 BIT02 = 000004 G
 BIT03 = 000010 G
 BIT04 = 000020 G
 BIT05 = 000040 G
 BIT06 = 000100 G
 BIT07 = 000200 G
 BIT08 = 000400 G
 BIT09 = 001000 G
 BIT1 = 000002 G
 BIT10 = 002000 G
 BIT11 = 004000 G
 BIT12 = 010000 G
 BIT13 = 020000 G
 BIT14 = 040000 G
 BIT15 = 100000 G
 BIT2 = 000004 G
 BIT3 = 000010 G
 BIT4 = 000020 G
 BIT5 = 000040 G
 BIT6 = 000100 G
 BIT7 = 000200 G
 BIT8 = 000400 G
 BIT9 = 001000 G
 BKGN0 007500
 BOE = 000400 G
 CHKMAX 002256 G
 CONT 004736
 COUNT 002206 G
 CSAU = 000052
 CSAUTO= 000061
 CSBRK = 000022
 CSBSEG= 000004
 CSBSUB= 000002
 CSCEFG= 000045
 CSCCLK= 000062
 CSCLEA= 000012
 CSCLOS= 000035
 CSCLP1= 000006
 CSCVEC= 000036
 CSDCLN= 000044
 CSDODU= 000051
 CSDRPT= 000024
 CSDU = 000053
 CSEDIT= 000003
 CSERDF= 000055
 CSERHR= 000056
 CSERRO= 000060
 CSERSF= 000054
 CSERSO= 000057
 CSESCA= 000010

CSESEG= 000005
 CSESUB= 000003
 CSETST= 000001
 CSEXIT= 000032
 CSGETB= 000026
 CSGETW= 000027
 CSGMAN= 000043
 CSGPHR= 000042
 CSGPLO= 000030
 CSGPRI= 000040
 CSINIT= 000011
 CSINLP= 000020
 CSMANI= 000050
 CSMEM = 000031
 CSMSG = 000023
 CSOPEN= 000034
 CSPNTB= 000014
 CSPNTF= 000017
 CSPNTS= 000016
 CSPNTX= 000015
 CSQIO = 000377
 CSRDBU= 000007
 CSREFG= 000047
 CSRESE= 000033
 CSREVI= 000003
 CSRFLA= 000021
 CSRPT = 000025
 CSSEFG= 000046
 CSSPRI= 000041
 CSSVEC= 000037
 CSTPRI= 000013
 DBUFF 002174 G
 DFPTBL 002160 G
 DIAGMC= 000000
 DOT 002200 G
 DROPD 005610
 EADD 004652
 EF.CON= 000036 G
 EF.NEW= 000035 G
 EF.PWR= 000034 G
 EF.RES= 000037 G
 EF.STA= 000040 G
 END 005050
 ERRCNT 002176 G
 ER200 002444 G
 ER300 002474 G
 ER400 002550 G
 ER401 002602 G
 ER500 002634 G
 ER501 002724 G
 ER600 003032 G
 ER700 003214 G
 ER800 003404 G
 ER900 003476 G
 ER902 003530 G
 EVL = 000004 G
 E\$END = 002100

E\$LOAD= 000035
 E100 006006
 E101 006054
 E200 006266
 E200B 003636
 E201 006314
 E202 006346
 E203 006405
 E300 006544
 E300B 003663
 E300C 003776
 E400 006774
 E400B 004036
 E401 007067
 E401B 004152
 E500 007502
 E501 007552
 E600 010114
 E700 010452
 E800 010664
 E800B 004257
 E800C 004344
 E900 011122
 E900B 004427
 E901 011166
 E902 011247
 FLAG 012302
 FSAU = 000015
 FSAUTO= 000020
 FSBGN = 000040
 F\$CLEA= 000007
 F\$DU = 000016
 F\$END = 000041
 F\$HARD= 000004
 F\$HW = 000013
 F\$INIT= 000006
 F\$JMP = 000050
 F\$MOD = 000000
 F\$MSG = 000011
 F\$PROT= 000021
 F\$PWR = 000017
 F\$RPT = 000012
 F\$SEG = 000003
 F\$SOFT= 000005
 F\$SRV = 000010
 F\$SUB = 000002
 F\$SW = 000014
 F\$TEST= 000001
 GETADR 012360
 GETMAX 012450
 GOOBAD 004571
 G\$CNT0= 000200
 G\$DELM= 000372
 G\$DISP= 000003
 G\$EXCP= 000400
 G\$HILI= 000002
 G\$LOLI= 000001

G\$NO = 000000
 G\$OFFS= 000400
 G\$OFSI= 000376
 G\$PRMA= 000001
 G\$PRMD= 000002
 G\$PRML= 000000
 G\$RADA= 000140
 G\$RADB= 000000
 G\$RADD= 000040
 G\$RADL= 000120
 G\$RADO= 000020
 G\$XFER= 000004
 G\$YES = 000010
 HELP = 000000
 HOE = 100000 G
 IBE = 010000 G
 IDU = 000040 G
 IER = 020000 G
 ISR = 000100 G
 IXE = 004000 G
 ISAU = 000041
 ISAUTO= 000041
 ISCLN = 000041
 ISDU = 000041
 ISHRD = 000041
 ISINIT= 000041
 ISMOD = 000041
 ISMSG = 000041
 ISPROT= 000040
 ISPTAB= 000041
 ISPWR = 000041
 ISRPT = 000041
 ISSEG = 000041
 ISSETU= 000041
 ISSFT = 000041
 ISSRV = 000041
 ISSUB = 000041
 ISTST = 000041
 JSJMP = 000167
 KLINT 005162
 LCLOCK 005074
 LINDOT 004503
 LOE = 040000 G
 LOT = 000010 G
 L\$ACP 002110 G
 L\$APT 002036 G
 L\$AUT 002070 G
 L\$AUTO 005424 G
 L\$CCP 002106 G
 L\$CLEA 005510 G
 L\$CO 002032 G
 L\$DEPO 002011 G
 L\$DESC 002220 G
 L\$DESP 002076 G
 L\$DEVV 002060 G
 L\$DISP 002124 G
 L\$DLY 002116 G

LSDTP 002040 G
 LSDTYP 002034 G
 L\$DU 005562 G
 L\$DUT 002072 G
 L\$DVTY 002210 G
 L\$EF 002052 G
 L\$ENVI 002044 G
 L\$ETP 002102 G
 L\$EXP1 002046 G
 L\$EXP4 002064 G
 L\$EXP5 002066 G
 L\$HARD 012350 G
 L\$HIME 002120 G
 L\$HPCP 002016 G
 L\$HPTP 002022 G
 L\$HW 002160 G
 L\$ICP 002104 G
 L\$INIT 004722 G
 L\$LADP 002026 G
 L\$LAST 013004 G
 L\$LOAD 002100 G
 L\$LUN 002074 G
 L\$MREV 002050 G
 L\$NAME 002000 G
 L\$PRIO 002042 G
 L\$PROT 004714 G
 L\$PRT 002112 G
 L\$REPP 002062 G
 L\$REV 002010 G
 L\$SOFT 012402 G
 L\$SPC 002056 G
 L\$SPCP 002020 G
 L\$SPTP 002024 G
 L\$STA 002030 G
 L\$SW 002164 G
 L\$TEST 002114 G
 L\$TML 002014 G
 L\$UNIT 002012 G
 L1000 002162
 L10001 002170
 L10002 002442
 L10003 002472
 L10004 002546
 L10005 002600
 L10006 002632
 L10007 002722
 L10010 003030
 L10011 003212
 L10012 003402
 L10013 003474
 L10014 003526
 L10015 003634
 L10017 005050
 L10020 005506
 L10021 005560
 L10022 005636
 L10023 006136

PARAMETER CODING
SYMBOL TABLE

MACRO V03.01 18-NOV-81 11:10:45 PAGE 52-2

L10024 005716
L10025 005744
L10026 006450
L10027 006260
L10030 006604
L10031 007176
L10032 006672
L10033 006772
L10034 007630
L10035 010162
L10036 010516
L10037 010712
L10040 011314
L10041 011422
L10042 011606
L10043 012026
L10044 012344
L10045 012360
L10046 012422
L10047 013010
L10051 013012
MANINT 012422
MANVEN 002164 G
MAXERR 002166 G
NCOLS 010112
NERRS 002350
NEXT 004764
NLINS 010450
NOCLOK 005220
NXMFLG 002202 G
NXMTRP 002430 G

ONEFIL= 000001
OSAPTS= 000000
OSAU = 000000
OSBGNR= 000000
OSBGNS= 000001
OSDU = 000001
OSERRT= 000000
OSGNSW= 000001
OSPOIN= 000001
OSSETU= 000001
PNT = 001000 G
PRI = 002000 G
PRI00 = 000000 G
PRI01 = 000040 G
PRI02 = 000100 G
PRI03 = 000140 G
PRI04 = 000200 G
PRI05 = 000240 G
PRI06 = 000300 G
PRI07 = 000340 G
READY 012304
SETCLK 005052
SETUP 004756
SFPTBL 002164 G
SVCGBL= 000000
SVCINS= 000001
SVCSUB= 000001
SVCTAG= 000001
SVCTST= 000001
SSLSYM= 010000
TIMMSG 005354

TKB = 177562
TKS = 177560
TPB = 177566
TPS = 177564
TTINT 005326
T\$ARGC= 000002
T\$CODE= 001052
T\$ERRN= 001606
T\$EXCP= 000000
T\$FLAG= 000040
T\$FREE= 013012
T\$GMAN= 000000
T\$HILI= 000377
T\$LAST= 000001
T\$LOLI= 000000
T\$LSYM= 010000
T\$LTNO= 000015
T\$NEST= 177777
T\$NS0 = 000000
T\$NS1 = 000005
T\$NS2 = 000003
T\$NS3 = 000003
T\$PCNT= 000000
T\$PTAB= 010050
T\$PTHV= 000001
T\$PTNU= 000001
T\$SAVL= 177777
T\$SEGL= 177777
T\$SEK0= 010000
T\$SEK1= 010001
T\$SIZE= 000003

T\$SUBN= 000000
T\$TAGL= 177777
T\$TAGN= 010052
T\$TEMP= 000000
T\$TEST= 000015
T\$TSTM= 177777
T\$TSTS= 000001
T\$SAUT= 010020
T\$SCLE= 010021
T\$SDAT= 010051
T\$SDU = 010022
T\$SHAR= 010045
T\$SHW = 010000
T\$SINI= 010017
T\$SMG= 010015
T\$SPC = 000001
T\$SPRO= 010016
T\$SPTA= 010050
T\$SSEG= 010000
T\$SOF= 010046
T\$SRV= 010002
T\$SSUB= 010033
T\$SSW = 010001
T\$STES= 010044
T1 005640 G
T1.1 005672
T1.2 005720
T10 011316 G
T11 011424 G
T12 011610 G
T13 012030 G

T13A 012032
T2 006140 G
T2.1 006140
T3 006452 G
T4 006606 G
T4A 006612
T4.1 006606
T4.2 006674
T5 007200 G
T5A 007214
T6 007632 G
T6A 007640
T6B 007750
T7 010164 G
T7A 010172
T7B 010304
T8 010520 G
T8A 010552
T8B 010600
T9 010714 G
T9A 010720
T9B 011022
UAM = 000200 G
UUT 002170 G
VTVCSR 002172 G
WAIT25 002416 G
X\$ALWA= 000000
X\$FALS= 000040
X\$OFFS= 000400
X\$TRUE= 000020
\$PATCH 012476 G

. ABS. 013012 000
000000 001
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 20500 WORDS (81 PAGES)
DYNAMIC MEMORY AVAILABLE FOR 70 PAGES
ZVTVA0.BIN,ZVTVA0.LST=RT.MAC/M,ZVTVA0.SRC