

# DR11-C

DEVICE REGISTER TEST  
MD-11-DZDRC-G

EP-DZDRC-G-DL-A  
COPYRIGHT © 72-77  
FICHE 1 OF 1

AUG 1977  
**digital**  
MADE IN USA

The image shows a grid of 18 small, illegible tables or registers arranged in 6 rows and 3 columns on the left side of the page. Each table appears to be a data register or test result, but the text within them is too small and faded to be read. The tables are organized in a structured, repeating pattern.

B01

EOF1DCDCABSEQ

00010000

770720

PDP10 411

: HDR1DZDRCGSEQ

00010000

770720

.REM \*

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZDRC-G-D  
PRODUCT NAME: DR11C DEVICE REGISTER TEST  
DATE RELEASED : APRIL, 1977  
MAINTAINER: DIAGNOSTIC GROUP  
AUTHOR: JOHN HITTELL

COPYRIGHT (C) DIGITAL EQUIPMENT CORPORATION  
1972, 1977

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

1. ABSTRACT

THIS IS A LOGIC TEST OF THE DR11C. FOR THIS TEST TO OPERATE  
A SPECIAL MAINTENANCE CABLE MUST BE CONNECTED (BCOBR).  
THIS TEST WILL CHECK UP TO 32 SEQUENTIAL DR11C'S.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-11 STANDARD COMPUTER

DR11C

BCOBR FOR EACH DR11C

2.2 STORAGE

2.2.1 PROGRAM STORAGE - THE ROUTINE USES MEMORY  
FROM 0000 TO 5200.

3. LOADING PROCEDURE

3.1 METHOD

ABSOLUTE LOADER

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTING

FOR SWITCHLESS PROCESSORS, THE PROGRAM WILL USE THE  
CONTENTS OF LOCATION 176 AS THE VALUE OF THE SWITCHES  
IF NO HARDWARE SWITCH REGISTER IS FOUND. THE PROGRAM  
ALLOWS THE DYNAMIC LOADING OF THE SOFTWARE SWITCH REGISTER  
THROUGH THE CONTROL G (↑G) ROUTINE. LOCATION 174  
WILL BE USED AS THE SOFTWARE DISPLAY REGISTER.

STARTING AT SA 200 ALL SWITCHES SHOULD BE DOWN OR ZERO.  
(IF NOT ZERO, BIT 0 TO 8 WILL BE STARTING VECTOR.)

4.2 STARTING ADDRESS OR ADDRESSES

(A) 200 = START OF TEST--FOR NORMAL TESTING  
(B) 204 = SPECIAL ENTRANCE --FOR TESTING UNIQUE DR11C  
(C) 210 = RESTART--FOR STARTING AFTER SHUT DOWN

4.3 PROGRAM AND/OR OPERATOR ACTION

LOAD PROGRAM INTO MEMORY.

SET SWITCH REGISTER TO STARTING ADDRESS.  
LOAD ADDRESS.  
PRESS START.  
THE PROGRAM WILL STAY IN SECTION AND LOOP.

4.3.1 FOR SPECIAL ENTRANCE - SA204

1ST HALT SET SWITCH REGISTER EQUAL TO CSR ADDRESS OF DR11C  
PRESS CONTINUE  
2ND HALT SET SWITCH REGISTER EQUAL TO VECTOR ADDRESS OF DR11C  
PRESS CONTINUE  
RAISE SWITCH 10 TO "1" TO INHIBIT SEQUENCING TO NEXT DR11C

5. OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

5.1.1 AT SA 200 .. THE INSTRUCTION AND LOGIC TEST.  
WITH ALL SWITCHES DOWN THE PROGRAM WILL PRINT  
OUT ON ERRORS AND CONTINUE IN TEST. (\* WILL  
BE PRINTED AT COMPLETION OF TESTING EACH DR11C)

5.1.2 SWITCH SETTINGS ARE

SW15 = 1 OR UP ... HALT ON ERROR  
SW14 = 1 OR UP ... SCOPE LOOP  
SW13 = 1 OR UP ... INHIBIT PRINTOUT  
SW12 = 1 OR UP ... NOT USED  
SW11 = 1 OR UP ... INHIBIT ITERATION LOOP  
SW10 = 1 OR UP ... DO NOT ADVANCE TO NEXT DR11C  
SW09 = 1 OR UP ... INHIBIT PRINTOUT OF DEVICE TESTED.

5.1.3

5.2. SUBROUTINE ABSTRACTS

5.2.1 BEGIN SA 200

5.2.2 SCOPE

-----  
THIS SUBROUTINE CALL IS PLACED BETWEEN EACH SUBTEST  
IN THE INSTRUCTION SECTION. IT RECORDS THE STARTING  
ADDRESS OF EACH SUB-TEST AS IT IS BEING ENTERED.  
IF A SCOPE LOOP IS REQUESTED, IT WILL JUMP TO THE  
START OF THE SUBTEST THAT THE SCOPE LOOP IS RE-  
QUESTED FOR.

5.2.3 HALT

-----  
IS A ROUTINE THAT PRINTS-OUT AN ADDRESS THAT TAGS  
THE FAILING SUBTEST, AND THE INCORRECT DATA AT  
THE TIME OF THE FAILURE. SEE 6.1

(5. OPERATING PROCEDURE CONT'D)

5.3 PROGRAM AND/OR OPERATOR ACTION

5.3.1 LOADING AND STARTING AT 200 WITH ALL SWITCHES DOWN IS THE INSTRUCTION AND LOGIC TEST. IF AN ERROR IS DETECTED HERE, THERE WILL BE A PRINTOUT. WHEN AN ERROR IS DETECTED AND IT IS NECESSARY TO SCOPE ON IT, PLACE SW15 UP TO HALT ON ERROR, THEN SW14 UP TO LOOP ON ERROR, THEN SW13 UP TO DELETE PRINTOUTS.

6. ERRORS

6.1 ERROR PRINTOUT

ARE IN A FOUR WORD FORMAT. THE 1ST IS THE PC+2 OF THE DETECTED ERROR. THE 2ND IS THE PROCESSOR STATUS REGISTER. THE 3RD IS DEVICE ADDRESS, THE 4TH IS VECTOR ADDRESS.

6.2 ERROR RECOVERY

DEPRESS CONTINUE TO RESTART SECTION

7. RESTRICTIONS

7.1 STARTING RESTRICTION

NONE

7.2 OPERATIONAL RESTRICTION

THE DR11C MUST HAVE THE BCOBR CABLE TO RUN THIS TEST.

NOTE THAT THE DR11C HAS FLOATING VECTORS:

THE BELOW IS THE ASSIGNMENT OF FLOATING VECTORS, THE ASSIGNED SEQUENCES ARE:

1. STARTING AT 300 AND WORKING UPWARD ALL DC11'S WILL BE ASSIGNED.
2. THEN ANY EXTRA KL11 CALLED FOR (VT05, VT06, LC11)
3. THEN ANY DP11 CALLED FOR.
4. THEN ANY DM11 CALLED FOR.
5. THEN ANY DN11 CALLED FOR.
6. THEN ANY DM11BB CALLED FOR.
7. THEN ANY DR11A CALLED FOR.
8. THEN ANY DR11C CALLED FOR.

THE DR11A AND DR11C DEVICE ADDRESSES WILL BE ASSIGNED IN THE USER AREA OF 767776 TO 764000. THE ASSIGNMENT OF ADDRESSES WILL START AT THE HIGH ADDRESS LIMIT AND PROCEED DOWNWARD. USERS AND SPECIAL SYSTEMS SHOULD START THEIR ASSIGNMENTS OF SPECIAL DEVICES AT THE LOW ADDRESS LIMIT AND WORK UP. AFTER ASSIGNING ALL DR11A'S, ASSIGN DR11C'S

767776 TO 767770	DR11C #0	;ASSUMING NO DR11A'S
767766 TO 767760	DR11C #1	
:		
767706 TO 767700	DR11C #7	
:		
767606 TO 767600	DR11C #15	

8. MISCELLANEOUS

WHERE THERE ARE MULTIPLE DR11C OR A SYSTEM AND IT IS DESIRED TO TEST ONLY ONE OF THEM. THIS MAY BE ACHIEVED BY USING THE SPECIAL STARTING ADDRESS AND PLACING SW10 ON A ONE (UP) TO INHIBIT SEQUENCING TO THE NEXT DR11C. SEE 4.3.1.

8.1 EXECUTION TIME

FOR EACH DR11C ABOUT 1 MINUTE

8.2 UNTESTED LOGIC

SIGNALS TO USER NOT TESTED:  
"NEW DATA READY"  
"DATA TRANSMITTED"  
"INIT" TO THE USER

9. PROGRAM DESCRIPTION

THIS PROGRAM WHEN STARTED AT 200 CHECKS THE STANDARD DR11-C'S

THE PROGRAM THEN PERFORMES AN INCREMENTAL LOGIC CHECK FOR THE SELECTED DR11C.

THE DATA REGISTER IS TESTED TO SEE IF "RESET" CLEARS IT, AND IF IT WILL HOLD ALL COMBINATIONS OF NUMBERS.

THE READ/WRITE BITS OF THE STATUS REGISTER ARE ALSO TESTED.

BOTH THE "A" AND "B" INTERRUPTS ARE TESTED TO SEE IF THEY INTERRUPT AT THE CORRECT BUS REQUEST LEVEL BR-5.

AT THE END OF THE TEST AN '\*' IS TYPED AND ALSO THE ADDRESSES OF THE DR11-C CONTROL STATUS REGISTER AND IT'S SIDE INTERRUPT VECTOR IS TYPED (IF SELECTED VIA SWITCH 9.). THE PROGRAM THEN RETESTS THE UNIT (IF SELECTED VIA SWITCH 10) OR SCANS TO THE NEXT DR11-C. IF ANOTHER DR11-C IS ON THE SYSTEM THEN THE PROGRAM RESTARTS TESTING

THE NEW DR11-C.

AFTER ALL DR11-C'S HAVE BEEN TESTED THE PROGRAM WILL  
TYPE 'END PASS' AND RESTART TESTING WITH THE INITIAL DR11-C.

IF NO ERRORS OCCUR AND THREE DR11-C'S ARE AVAILABLE  
AND SWITCH 9 IS DOWN THE PROGRAM WILL TYPE.

160000 770 \*  
157770 1000 \*  
157760 1010 \*

/  
ETC.

IF SWITCH 9 IS UP THEN

\*  
\*  
\*

IF A POWER FAIL OCCURS THE PROGRAM WILL RESTART AT "START".

10. LISTING

%

```

296
297
298
299      177776
300      104000
301      167770
302
303      000000
304      000001
305      000002
306      000003
307      000004
308      000005
309      000006
310      000007
311
312
313
314
315
316
317
318
319
320
321
322
323
324      001200
325
326
327
328
329      000011
330      000012
331      000015
332      000200
333      177776
334
335      177774
336      177772
337      177570
338      177570
339
340
341      000000
342      000001
343      000002
344      000003

;GENERAL REGISTER LOGIC TEST
PSW=177776
HLT=104000
CSR=167770
;REGISTER DEFINITIONS
R0=%0
R1=%1
R2=%2
R3=%3
R4=%4
R5=%5
SP=%6
PC=%7

;SWITCHES
SW9=1000
SW10=2000
SW11=4000
SW13=20000
SW14=40000

.SBTTL BASIC DEFINITIONS
;*INITIAL ADDRESS OF THE STACK POINTER *** 1200 ***
STACK= 1200
.EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL

;*MISCELLANEOUS DEFINITIONS
HT= 11      ;;CODE FOR HORIZONTAL TAB
LF= 12      ;;CODE FOR LINE FEED
CR= 15      ;;CODE FOR CARRIAGE RETURN
CRLF= 200   ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776  ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
STKLMT= 177774 ;;STACK LIMIT REGISTER
PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
DSWR= 177570 ;;HARDWARE SWITCH REGISTER
DDISP= 177570 ;;HARDWARE DISPLAY REGISTER

;*GENERAL PURPOSE REGISTER DEFINITIONS
R0= %0      ;;GENERAL REGISTER
R1= %1      ;;GENERAL REGISTER
R2= %2      ;;GENERAL REGISTER
R3= %3      ;;GENERAL REGISTER

```

BASIC DEFINITIONS

345	000004	R4=	%4	::	GENERAL REGISTER
346	000005	R5=	%5	::	GENERAL REGISTER
347	000006	R6=	%6	::	GENERAL REGISTER
348	000007	R7=	%7	::	GENERAL REGISTER
349	000006	SP=	%6	::	STACK POINTER
350	000007	PC=	%7	::	PROGRAM COUNTER

.\*PRIORITY LEVEL DEFINITIONS

353	000000	PR0=	0	::	PRIORITY LEVEL 0
354	000040	PR1=	40	::	PRIORITY LEVEL 1
355	000100	PR2=	100	::	PRIORITY LEVEL 2
356	000140	PR3=	140	::	PRIORITY LEVEL 3
357	000200	PR4=	200	::	PRIORITY LEVEL 4
358	000240	PR5=	240	::	PRIORITY LEVEL 5
359	000300	PR6=	300	::	PRIORITY LEVEL 6
360	000340	PR7=	340	::	PRIORITY LEVEL 7

.\*"SWITCH REGISTER" SWITCH DEFINITIONS

363	100000	SW15=	100000		
364	040000	SW14=	40000		
365	020000	SW13=	20000		
366	010000	SW12=	10000		
367	004000	SW11=	4000		
368	002000	SW10=	2000		
369	001000	SW09=	1000		
370	000400	SW08=	400		
371	000200	SW07=	200		
372	000100	SW06=	100		
373	000040	SW05=	40		
374	000020	SW04=	20		
375	000010	SW03=	10		
376	000004	SW02=	4		
377	000002	SW01=	2		
378	000001	SW00=	1		
379		.EQUIV	SW09, SW9		
380		.EQUIV	SW08, SW8		
381		.EQUIV	SW07, SW7		
382		.EQUIV	SW06, SW6		
383		.EQUIV	SW05, SW5		
384		.EQUIV	SW04, SW4		
385		.EQUIV	SW03, SW3		
386		.EQUIV	SW02, SW2		
387		.EQUIV	SW01, SW1		
388		.EQUIV	SW00, SW0		

.\*DATA BIT DEFINITIONS (BIT00 TO BIT15)

391	100000	BIT15=	100000		
392	040000	BIT14=	40000		
393	020000	BIT13=	20000		
394	010000	BIT12=	10000		
395	004000	BIT11=	4000		
396	002000	BIT10=	2000		
397	001000	BIT09=	1000		
398	000400	BIT08=	400		
399	000200	BIT07=	200		
400	000100	BIT06=	100		

BASIC DEFINITIONS

401	000040	BIT05=	40
402	000020	BIT04=	20
403	000010	BIT03=	10
404	000004	BIT02=	4
405	000002	BIT01=	2
406	000001	BIT00=	1
407		.EQUIV	BIT09,BIT9
408		.EQUIV	BIT08,BIT8
409		.EQUIV	BIT07,BIT7
410		.EQUIV	BIT06,BIT6
411		.EQUIV	BIT05,BIT5
412		.EQUIV	BIT04,BIT4
413		.EQUIV	BIT03,BIT3
414		.EQUIV	BIT02,BIT2
415		.EQUIV	BIT01,BIT1
416		.EQUIV	BIT00,BIT0

::BASIC "CPU" TRAP VECTOR ADDRESSES

418		ERRVEC=	4	::	TIME OUT AND OTHER ERRORS
419	000004	RESVEC=	10	::	RESERVED AND ILLEGAL INSTRUCTIONS
420	000010	TBITVEC=	14	::	"T" BIT
421	000014	TRTVEC=	14	::	TRACE TRAP
422	000014	BPTVEC=	14	::	BREAKPOINT TRAP (BPT)
423	000014	IOTVEC=	20	::	INPUT/OUTPUT TRAP (IOT) **SCOPE**
424	000020	PWRVEC=	24	::	POWER FAIL
425	000024	EMTVEC=	30	::	EMULATOR TRAP (EMT) **ERROR**
426	000030	TRAPVEC=	34	::	"TRAP" TRAP
427	000034	TKVEC=	60	::	TTY KEYBOARD VECTOR
428	000060	TPVEC=	64	::	TTY PRINTER VECTOR
429	000064	PIRQVEC=	240	::	PROGRAM INTERRUPT REQUEST VECTOR
430	000240				

.ENABLE ABS

431		.=0	
432		.+2	
433	000000	000002	HALT
434	000002	000000	.+2
435	000004	000006	HALT
436	000006	000000	.+2
437	000010	000012	HALT
438	000012	000000	.+2
439	000014	000016	HALT
440	000016	000000	.+2
441	000020	000022	HALT
442	000022	000000	.+2
443	000024	000026	HALT
444	000026	000000	.+2
445	000030	000032	HALT
446	000032	000000	.+2
447	000034	000036	HALT
448	000036	000000	.+2
449	000040	000042	HALT
450	000042	000000	.+2
451	000044	000046	HALT
452	000046	000000	.+2
453	000050	000052	HALT
454	000052	000000	.+2
455	000054	000056	HALT
456	000056	000000	.+2

L01

457	000060	000062	.+2
458	000062	000000	HALT
459	000064	000066	.+2
460	000066	000000	HALT
461	000070	000072	.+2
462	000072	000000	HALT
463	000074	000076	.+2
464	000076	000000	HALT
465	000100	000102	.+2
466	000102	000000	HALT
467	000104	000106	.+2
468	000106	000000	HALT
469	000110	000112	.+2
470	000112	000000	HALT
471	000114	000116	.+2
472	000116	000000	HALT
473	000120	000122	.+2
474	000122	000000	HALT
475	000124	000126	.+2
476	000126	000000	HALT
477	000130	000132	.+2
478	000132	000000	HALT
479	000134	000136	.+2
480	000136	000000	HALT
481	000140	000142	.+2
482	000142	000000	HALT
483	000144	000146	.+2
484	000146	000000	HALT
485	000150	000152	.+2
486	000152	000000	HALT
487	000154	000156	.+2
488	000156	000000	HALT
489	000160	000162	.+2
490	000162	000000	HALT
491	000164	000166	.+2
492	000166	000000	HALT
493	000170	000172	.+2
494	000172	000000	HALT
495	000174	000176	.+2
496	000176	000000	HALT
497	000200	000202	.+2
498	000202	000000	HALT
499	000204	000206	.+2
500	000206	000000	HALT
501	000210	000212	.+2
502	000212	000000	HALT
503	000214	000216	.+2
504	000216	000000	HALT
505	000220	000222	.+2
506	000222	000000	HALT
507	000224	000226	.+2
508	000226	000000	HALT
509	000230	000232	.+2
510	000232	000000	HALT
511	000234	000236	.+2
512	000236	000000	HALT

513	000240	000242	.+2
514	000242	000000	HALT
515	000244	000246	.+2
516	000246	000000	HALT
517	000250	000252	.+2
518	000252	000000	HALT
519	000254	000256	.+2
520	000256	000000	HALT
521	000260	000262	.+2
522	000262	000000	HALT
523	000264	000266	.+2
524	000266	000000	HALT
525	000270	000272	.+2
526	000272	000000	HALT
527	000274	000276	.+2
528	000276	000000	HALT
529	000300	000302	.+2
530	000302	000000	HALT
531	000304	000306	.+2
532	000306	000000	HALT
533	000310	000312	.+2
534	000312	000000	HALT
535	000314	000316	.+2
536	000316	000000	HALT
537	000320	000322	.+2
538	000322	000000	HALT
539	000324	000326	.+2
540	000326	000000	HALT
541	000330	000332	.+2
542	000332	000000	HALT
543	000334	000336	.+2
544	000336	000000	HALT
545	000340	000342	.+2
546	000342	000000	HALT
547	000344	000346	.+2
548	000346	000000	HALT
549	000350	000352	.+2
550	000352	000000	HALT
551	000354	000356	.+2
552	000356	000000	HALT
553	000360	000362	.+2
554	000362	000000	HALT
555	000364	000366	.+2
556	000366	000000	HALT
557	000370	000372	.+2
558	000372	000000	HALT
559	000374	000376	.+2
560	000376	000000	HALT
561	000400	000402	.+2
562	000402	000000	HALT
563	000404	000406	.+2
564	000406	000000	HALT
565	000410	000412	.+2
566	000412	000000	HALT
567	000414	000416	.+2
568	000416	000000	HALT

569	000420	000422	.+2
570	000422	000000	HALT
571	000424	000426	.+2
572	000426	000000	HALT
573	000430	000432	.+2
574	000432	000000	HALT
575	000434	000436	.+2
576	000436	000000	HALT
577	000440	000442	.+2
578	000442	000000	HALT
579	000444	000446	.+2
580	000446	000000	HALT
581	000450	000452	.+2
582	000452	000000	HALT
583	000454	000456	.+2
584	000456	000000	HALT
585	000460	000462	.+2
586	000462	000000	HALT
587	000464	000466	.+2
588	000466	000000	HALT
589	000470	000472	.+2
590	000472	000000	HALT
591	000474	000476	.+2
592	000476	000000	HALT
593	000500	000502	.+2
594	000502	000000	HALT
595	000504	000506	.+2
596	000506	000000	HALT
597	000510	000512	.+2
598	000512	000000	HALT
599	000514	000516	.+2
600	000516	000000	HALT
601	000520	000522	.+2
602	000522	000000	HALT
603	000524	000526	.+2
604	000526	000000	HALT
605	000530	000532	.+2
606	000532	000000	HALT
607	000534	000536	.+2
608	000536	000000	HALT
609	000540	000542	.+2
610	000542	000000	HALT
611	000544	000546	.+2
612	000546	000000	HALT
613	000550	000552	.+2
614	000552	000000	HALT
615	000554	000556	.+2
616	000556	000000	HALT
617	000560	000562	.+2
618	000562	000000	HALT
619	000564	000566	.+2
620	000566	000000	HALT
621	000570	000572	.+2
622	000572	000000	HALT
623	000574	000576	.+2
624	000576	000000	HALT

625	000600	000602	.+2
626	000602	000000	HALT
627	000604	000606	.+2
628	000606	000000	HALT
629	000610	000612	.+2
630	000612	000000	HALT
631	000614	000616	.+2
632	000616	000000	HALT
633	000620	000622	.+2
634	000622	000000	HALT
635	000624	000626	.+2
636	000626	000000	HALT
637	000630	000632	.+2
638	000632	000000	HALT
639	000634	000636	.+2
640	000636	000000	HALT
641	000640	000642	.+2
642	000642	000000	HALT
643	000644	000646	.+2
644	000646	000000	HALT
645	000650	000652	.+2
646	000652	000000	HALT
647	000654	000656	.+2
648	000656	000000	HALT
649	000660	000662	.+2
650	000662	000000	HALT
651	000664	000666	.+2
652	000666	000000	HALT
653	000670	000672	.+2
654	000672	000000	HALT
655	000674	000676	.+2
656	000676	000000	HALT
657	000700	000702	.+2
658	000702	000000	HALT
659	000704	000706	.+2
660	000706	000000	HALT
661	000710	000712	.+2
662	000712	000000	HALT
663	000714	000716	.+2
664	000716	000000	HALT
665	000720	000722	.+2
666	000722	000000	HALT
667	000724	000726	.+2
668	000726	000000	HALT
669	000730	000732	.+2
670	000732	000000	HALT
671	000734	000736	.+2
672	000736	000000	HALT
673	000740	000742	.+2
674	000742	000000	HALT
675	000744	000746	.+2
676	000746	000000	HALT
677	000750	000752	.+2
678	000752	000000	HALT
679	000754	000756	.+2
680	000756	000000	HALT

BASIC DEFINITIONS

681	000760	000762	
682	000762	000000	
683	000764	000766	
684	000766	000000	
685	000770	000772	
686	000772	000000	
687	000774	000776	
688	000776	000000	
689		000020	
690	000020	004652	
691	000022	000340	
692	000024	005124	
693	000026	000340	
694	000030	004126	
695	000032	000340	
696	000034	005316	
697	000036	000340	
698		000046	
699	000046	004112	
700		000052	
701	000052	000000	
702		000174	
703	000174	000000	
704	000176	000000	
705		000200	
706	000200	000137	001250
707	000204	000137	001616
708	000210	000137	001726
709		001200	
710			
711			
712			
713	001200	167770	
714	001202	167772	
715	001204	167774	
716	001206	167773	
717	001210	000300	
718	001212	000302	
719	001214	000304	
720			
721			
722			
723	001216	177570	
724	001220	177570	
725	001222	167770	
726	001224	167772	
727	001226	167774	
728	001230	167773	
729			
730	001232	000300	
731	001234	000302	
732	001236	000304	
733	001240	000000	
734			
735	001242	000000	
736	001244	000240	

```

.+2
HALT
.+2
HALT
.+2
HALT
.+2
HALT
.=20
.SCOPE
340
PFAIL
340
.HLT
340
TYP
340
.=46
$ENDAD
.=52
0
.=174
DISPRE: 0
SWREG: 0
.=200
JMP @#START1 ;INITIAL START
JMP @#SPEC ;TO SELECT UNIQUE ADDRESS AND VECTOR
JMP @#START ;RESTART
.=1200

```

;THIS TABLE CONTAINS INITIAL REGISTER AND VECTOR ADDRESSES

```

RCSR: CSR
      CSR+2
      CSR+4
      CSR+3
RCSR1: 300
        302
        304

```

;THIS TABLE CONTAINS REGISTER AND VECTOR ADDRESSES OF THE DR11-C UNDER TEST

```

SWR: 177570
DISPLA: 177570
DRCSR: 167770 ;ADDRESS OF DR11-C STATUS REGISTER
DROBUF: 167772 ;ADDRESS OF DR OUTPUT BUFFER REG.
DRIBUF: 167774 ;ADDRESS OF DR INPUT BUFFER REG.
DRBHIO: 167773 ;HIGH BYTE OF OUTPUT BUFFER REG.

DRVECA: 300 ;INTERRUPT VECTOR OF UNIT UNDER TEST
DRLVL: 302
DRVECB: 304 ;INTERRUPT VECTOR
XORFLG: 0

COUNT: 0 ;COUNT LOCATION
PL: 240 ;PRIORITY LEVEL

```

```

737 001246 000000 PASCNT: 0 ;NUMBER OF PASSES COMPLETED
738
739 001250 START1:
740 .SBTTL INITIALIZE THE COMMON TAGS
741 001250 012706 001200 MOV #STACK, SP ;SETUP THE STACK POINTER
742 ;:SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
743 ;:EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
744 001254 013746 000004 MOV #ERRVEC, -(SP) ;SAVE ERROR VECTOR
745 001260 012737 001314 000004 MOV #64$, #ERRVEC ;SET UP ERROR VECTOR
746 001266 012767 177570 177722 MOV #DSWR, SWR ;SETUP FOR A HARDWARE SWICH REGISTER
747 001274 012767 177570 177716 MOV #DISP, DISPLAY ;AND A HARDWARE DISPLAY REGISTER
748 001302 022777 177777 177706 CMP #-1, #SWR ;TRY TO REFERENCE HARDWARE SWR
749 001310 001012 BNE 66$ ;BRANCH IF NO TIMEOUT TRAP OCCURRED
750 ;AND THE HARDWARE SWR IS NOT = -1
751 001312 000403 BR 65$ ;BRANCH IF NO TIMEOUT
752 001314 012716 001322 64$: MOV #65$, (SP) ;SET UP FOR TRAP RETURN
753 001320 000002 RTI
754 001322 012767 000176 177666 65$: MOV #SWREG, SWR ;POINT TO SOFTWARE SWR
755 001330 012767 000174 177662 MOV #DISPREG, DISPLAY
756 001336 012637 000004 66$: MOV (SP)+, #ERRVEC ;RESTORE ERROR VECTOR
757
758 001342 023737 000042 000046 CMP #42, #46
759 001350 001433 BEQ 3$ ;YES, SKIP TITLE
760 .SBTTL TYPE PROGRAM NAME
761 ;:TYPE THE NAME OF THE PROGRAM IF FIRST PASS
762 001352 005227 177777 INC #-1 ;FIRST TIME?
763 001356 001027 BNE 67$ ;BRANCH IF NO
764 001360 104401 001416 TYPE 68$ ;TYPE ASCIZ STRING
765 .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
766 001364 005737 000042 TST #42 ;ARE WE RUNNING UNDER XXDP/ACT?
767 001370 001006 BNE 69$ ;BRANCH IF YES
768 001372 026727 177620 000176 CMP SWR, #SWREG ;SOFTWARE SWITCH REG SELECTED?
769 001400 001005 BNE 70$ ;BRANCH IF NO
770 001402 104405 GTSWR ;GET SOFT-SWR SETTINGS
771 001404 000403 BR 70$
772 001406 112767 000001 005144 69$: MOV #1, #AUTOB ;SET AUTO-MODE INDICATOR
773 001414 70$:
774 001414 000410 BR 67$ ;GET OVER THE ASCIZ
775 ;:68$: .ASCIZ <CRLF>#MD-11-DZDRC-G<CRLF>
776 001436 67$:
777 001436 000463 BR 8$ ;SKIP INTERRUPT VECTOR SIZER IF
778 ;IN AUTOMATIC MODE
779 ;SIZE FOR INTERRUPT VECTOR IF IN AUTOMATIC MODE.
780
781 001440 012700 000302 3$: MOV #302, R0 ;SET UP FLOATING VECTOR AREA
782 001444 010060 177776 4$: MOV R0, -2(R0)
783 001450 012720 000003 MOV #3, (R0)+
784 001454 005720 TST (R0)+
785 001456 022700 000776 CMP #776, R0
786 001462 100370 BPL 4$
787 001464 012737 001516 000014 MOV #5$, #14 ;SET UP BPT
788 001472 012737 000340 000016 MOV #340, #16 ;SET UP BPT PSW
789 001500 012777 000101 177472 MOV #101, #RCSR ;FORCE AN INTERRUPT
790 001506 000240 NOP
791 001510 000240 NOP
792 001512 000000 HALT ;NO INTERRUPT OCCURRED

```

793	001514	000423			BR	6\$		
794	001516	162716	000004		5\$: SUB	#4 (SP)		;FIGURE OUT INTERRUPT VECTOR
795	001522	011637	001210		MOV	(SP), @RCSR1		;PUT IT IN TABLE
796	001526	013737	001210	001212	MOV	@RCSR1, @RCSR1+2		
797	001534	062737	000002	001212	ADD	#2, @RCSR1+2		;FILL IN NEXT TABLE ENTRY
798	001542	013737	001210	001214	MOV	@RCSR1, @RCSR1+4		
799	001550	062737	000004	001214	ADD	#4, @RCSR1+4		;FILL IN LAST TABLE ENTRY
800	001556	012737	000016	000014	MOV	#16, @#14		;RESTORE BPT
801	001564	012700	000302		6\$: MOV	#302, R0		;SET UP TRAP CATCHER
802	001570	010060	177776		7\$: MOV	R0, -2(R0)		
803	001574	005020			CLR	(R0)+		
804	001576	005720			TST	(R0)+		
805	001600	022700	000776		CMP	#776, R0		
806	001604	100371			BPL	7\$		
807	001606	004767	000020		8\$: JSR	PC, FIRST		
808	001612	000137	001726		JMP	@START		
809	001616	012706	001200		SPEC: MOV	#STACK, %6		
810	001622	004767	000004		JSR	PC, FIRST		
811	001626	000167	003360		JMP	SPEC0		
812	001632	013746	000004		FIRST: MOV	@#4, -(%6)		
813	001636	012737	001712	000004	MOV	#XORA, @#4		
814	001644	012737	000031	177060	MOV	#31, @#177060		
815	001652	012637	000004		MOV	(%6)+, @#4		
816	001656	012737	177777	001240	MOV	#-1, @#XORFLG		
817	001664	012701	160000		MOV	#160000, R1		
818	001670	004737	005246		JSR	PC, @#SPEC1		
819	001674	012701	000770		MOV	#770, R1		
820	001700	004737	005276		JSR	PC, @#SPEC2		
821	001704	104401			TYPE			
822	001706	006640			MESS1			
823	001710	000207			RTS	PC		
824	001712	022626			XORA: CMP	(%6)+, (%6)+		
825	001714	012637	000004		MOV	(%6)+, @#4		
826	001720	005037	001240		CLR	@#XORFLG		
827	001724	000207			RTS	PC		
828					; INITIALIZE ADDRESS AND VECTORS			
829	001726	012700	001200		START: MOV	@RCSR, R0		;GET ADDRESS OF FIRST POSSIBLE DR11-C'S
830	001732	012701	001222		MOV	@RCSR, R1		
831	001736	012021			MOV	(R0)+, (R1)+		;LOAD INITIAL TEST ADDRESSES
832	001740	012021			MOV	(R0)+, (R1)+		
833	001742	012021			MOV	(R0)+, (R1)+		
834	001744	012021			MOV	(R0)+, (R1)+		
835	001746	012021			MOV	(R0)+, (R1)+		
836	001750	012021			MOV	(R0)+, (R1)+		
837	001752	012021			MOV	(R0)+, (R1)+		
838	001754	012706	001200		RSTART: MOV	#STACK, %6		;SET UP STACK
839	001760	012767	002010	003004	MOV	#BEGIN, RETURN		;SET SCOPE RETURN
840	001766	005037	004770		CLR	@#SCOPEF		
841					; DOES RESET CLEAR REGISTER?			
842					CKSWR			
843	001772	104406			BIT	#SW9, @SWR		
844	001774	032777	001000	177214	BNE	BEGIN		
845	002002	001002			JSR	PC, @#MOREID		
846	002004	004737	005010		BEGIN: MOV	@RCSR, R5		;GET ADDRESS OF STATUS REGISTER
847	002010	016705	177206		MOV	#240, @PSW		;SET PRIORITY LEVEL 6
848	002014	012777	000240	175754				

849	002022	012737	002060	000004		MOV	#15, R4	;SET TIME OUT TRAP VECTOR
850	002030	012767	000010	002730		MOV	#10, ICOUNT	
851	002036	012777	177777	177160		MOV	#-1, DROBUF	;PRESET OUTPUT BUFFER
852	002044	000005				RESET		;CLEAR DATA REGISTER
853	002046	017700	177152			MOV	DROBUF, %0	;GET RESULT OF RESET
854	002052	001403				BEQ	25	
855	002054	104000				HLT		;DATA REGISTER NOT CLEAR
856	002056	000401				BR	25	
857	002060	104000			15:	HLT		;ERROR! TIMED OUT WHEN REFERENCING DROBUF.
858	002062	012706	001200		25:	MOV	#STACK, SP	;RESET STACK POINTER
859	002066	012737	000006	000004		MOV	#6, R4	;RESTORE TIME OUT TRAP
860								
861	002074	000004				SCOPE		
862	002076	012767	004000	002662		MOV	#4000, ICOUNT	
863	002104	012777	177777	177112		MOV	#-1, DROBUF	;ALL ONES TO REGISTER
864	002112	017700	177106			MOV	DROBUF, %0	
865	002116	022700	177777			CMP	#-1, %0	
866	002122	001401				BEQ	+.4	
867	002124	104000				HLT		;REG WILL NOT HOLD ONES
868								
869	002126	000004				SCOPE		
870	002130	012767	000010	002630		MOV	#10, ICOUNT	
871	002136	012777	177777	177060		MOV	#-1, DROBUF	
872	002144	000005				RESET		;SET DATA TO ALL ONES
873	002146	005777	177054			TST	DROBUF	;SHOULD CLEAR REGISTER
874	002152	001401				BEQ	+.4	
875	002154	104000				HLT		;REG FAILED TO CLEAR
876								
877	002156	000004				SCOPE		
878	002160	012767	004000	002600		MOV	#4000, ICOUNT	
879	002166	012777	052525	177030		MOV	#52525, DROBUF	
880	002174	017700	177024			MOV	DROBUF, %0	
881	002200	022700	052525			CMP	#52525, %0	
882	002204	001401				BEQ	+.4	
883	002206	104000				HLT		;DATA NOT=52525
884								
885	002210	000004				SCOPE		
886	002212	012777	125252	177004		MOV	#125252, DROBUF	
887	002220	017700	177000			MOV	DROBUF, %0	
888	002224	022700	125252			CMP	#125252, %0	
889	002230	001401				BEQ	+.4	
890	002232	104000				HLT		;DATA NOT=125252
891								
892								
893	002234	000004						;TEST RELIABILITY OF DR11-C OUTPUT BUFFER REGISTER
894	002236	012737	000040	004766		SCOPE		
895	002244	010502				MOV	#40, R2	
896	002246	005722			BUFTST:	MOV	R5, R2	;GET ADDRESS OF DRCSR
897	002250	012703	000401			TST	(R2)+	;R2=ADDRESS OF OUTPUT BUFFER REG.
898	002254	012704	000400			MOV	#401, R3	;LOAD CONSTANT
899	002260	005000			15:	MOV	#256, R4	;SET COUNT
900	002262	005012				CLR	R0	;PRESET EXPECTED RESULT
901	002264	060300			25:	CLR	(R2)	;CLEAR REGISTER
902	002266	060312				ADD	R3, R0	
903	002270	021200				ADD	R3, (R2)	
904	002272	001401				CMP	(R2), R0	
						BEQ	+.4	

```

905 002274 104000          HLT
906 002276 005304          DEC      R4
907 002300 001371          BNE     2$
908 002302 006303          ASL    R3
909 002304 001363          BNE     1$
910
911          ;TEST THAT BYTE REFERENCE TO DROBUF AFFECT PROPER BYTE ONLY
912
913 002306 000004          SCOPE
914 002310 012777 177777 176706 TAG:  MOV     #-1,DROBUF
915 002316 105077 176702          CLR    DROBUF          ;CLEAR LOW BYTE
916 002322 017700 176676          MOV    DROBUF,%0
917 002326 022700 177400          CMP    #177400,%0
918 002332 001401          BEQ
919 002334 104000          HLT          ;BYTE LOW FAILED TO CLEAR
920
921 002336 000004          SCOPE
922 002340 012777 177777 176656          MOV     #-1,DROBUF
923 002346 105077 176656          CLR    DROBHI0        ;CLEAR HIGH BYTE
924 002352 017700 176646          MOV    DROBUF,%0
925 002356 022700 000377          CMP    #377,%0
926 002362 001401          BEQ
927 002364 104000          HLT          ;HIGH BYTE CLEAR FAILED
928
929 002366 000004          SCOPE
930 002370 005037 002440          CLR
931 002374 012704 002440          MOV    #2$
932 002400 005077 176620          CLR    DROBUF
933 002404 105077 176620          CLR    DROBHI0
934 002410 105277 176614          INCB  DROBHI0          ;INCREMENT HIGH BYTE
935 002414 105264 000001          INCB  1(R4)
936 002420 027714 176600          CMP    DROBUF,(F)
937 002424 001401          BEQ   .+4
938 002426 104000          HLT          ;HIGH BYTE HAS BAD DATA
939 002430 105764 000001          TSTB  1(R4)
940 002434 001402          BEQ   3$
941 002436 000764          BR    1$
942 002440 000000          2$: .WORD 0
943 002442 000004          3$: SCOPE
944          ;CONTROL STATUS REGISTER (DRCSR) TESTS.
945 002444 005015          CLR    (R5)
946 002446 011500          MOV    (R5),R0
947 002450 001401          BEQ   .+4
948 002452 104000          HLT
949 002454 012715 000140          MOV    #140,AR5        ;INTERRUPT ENABLE FOR A+B
950 002460 011500          MOV    AR5,%0
951 002462 022700 000140          CMP    #140,%0        ;ENABLE BITS
952 002466 001401          BEQ   .+4
953 002470 104000          HLT
954
955 002472 000004          SCOPE
956 002474 012767 000010 002264          MOV    #10,ICOUNT
957 002502 012715 000140          MOV    #140,AR5        ;SET INTERRUPT ENABLE FLOPS
958 002506 000005          RESET          ;CLEAR THOSE FLOPS
959 002510 011500          MOV    AR5,%0
960 002512 001401          BEQ   .+4

```



1017	002720	000004			SCOPE	
1018	002722	012777	177777	176274	MOV	#-1, @DROBUF
1019	002730	017777	176272	176266	MOV	@DRIBUF, @DROBUF ; MOV ALL ONES
1020	002736	022777	177777	176260	CMP	#-1, @DROBUF
1021	002744	001401			BEQ	.+4
1022	002746	104000			HLT	; NOT ALL ONES
1023						
1024	002750	000004			SCOPE	
1025	002752	005067	002010		CLR	ICOUNT
1026	002756	005000			CLR	%0
1027	002760	010077	176240		MOV	%0, @DROBUF ; TEST ALL NUMBERS
1028	002764	017777	176236	176232	MOV	@DRIBUF, @DROBUF
1029	002772	020077	176226		CMP	%0, @DROBUF
1030	002776	001401			BEQ	.+4
1031	003000	104000			HLT	; ERROR - CHECK %0 FOR GOOD
1032	003002	005200			INC	%0 ; DROBUF FOR BAD
1033	003004	001403			BEQ	TST9
1034	003006	005077	176212		CLR	@DROBUF
1035	003012	000762			BR	TST6
1036	003014	000004			TST9: SCOPE	
1037	003016	012737	000005	004766	MOV	#5, @ICOUNT
1038					; TEST DATA FROM BLACK BOX (NOT CONNECTED)	
1039	003024	012777	177777	176172	MOV	#-1, @DROBUF
1040	003032	017777	176166	176166	MOV	@DROBUF, @DRIBUF ; STATIC LINES EQUAL ONES
1041	003040	017700	176162		MOV	@DRIBUF, %0 ; DATA REGISTER TO %0
1042	003044	022700	177777		CMP	#-1, %0
1043	003050	001401			BEQ	.+4
1044	003052	104000			HLT	; REG 0 SHOULD = ALL ONES
1045						
1046					; READY BIT IS IN A ONE STATE	
1047	003054	000004			SCOPE	
1048	003056	012715	000003		MOV	#3, @RS ; CSRO AND CSRI
1049	003062	011500			MOV	(RS), R0
1050	003064	022700	100203		CMP	#100203, R0
1051	003070	001401			BEQ	.+4
1052	003072	104000			HLT	
1053						
1054					; CAN WE RAISE INTERRUPT "A"	
1055	003074	000004			SCOPE	
1056	003076	052737	000340	177776	BIS	#340, @PSW ; LOCK OUT INTERRUPTS
1057	003104	012706	001200		MOV	#STACK, %6
1058	003110	012777	003132	176114	MOV	#TST4, @DRVECA ; INTERRUPT RETURN POINTER
1059	003116	012715	000101		MOV	#101, @RS ; INTERRUPT ENABLE AND CSRO
1060	003122	005037	177776		CLR	@PSW
1061	003126	000240			NOP	
1062	003130	104000			HLT	; NO "A" INTERRUPT
1063	003132	005015			TST4: CLR	@RS
1064	003134	016777	176074	176070	MOV	@RVL, @DRVECA ; MOVE .+2 TO "A" INTERRUPT VECTOR
1065						
1066					; RAISE INTERRUPT "B"	
1067	003142	000004			SCOPE	
1068	003144	012706	001200		MOV	#STACK, %6
1069	003150	052737	000340	177776	BIS	#340, @PSW
1070	003156	012777	003202	176052	MOV	#TST5, @DRVECB
1071	003164	012715	000042		MOV	#42, @RS ; IE AND CSRI
1072	003170	042737	000377	177776	BIC	#377, @PSW

1073	003176	000240			NOP		
1074	003200	104000			HLT		;NO B INTERRUPT
1075	003202	005015			TST5: CLR	DR5	
1076							
1077							;TEST FOR INTERRUPT FROM DEVICE
1078	003204	016777	176034	176022	MOV	PL,DRVLV	
1079	003212	042737	000340	177776	BIC	#340,DRPSW	;PROCESSOR LEVEL ZERO
1080	003220	012777	003252	176004	MOV	#TINT1,DRVECA	
1081	003226	012706	001200		MOV	#STACK,%6	;STACK POINTER
1082	003232	042777	000100	175762	BIC	#100,DRCSR	;CLEAR INTERRUPT ENABLE
1083	003240	052777	000101	175754	BIS	#101,DRCSR	;SET INTERRUPT ENABLE-AND CSRO
1084	003246	000240			NOP		
1085	003250	104000			HLT		;NO DEVICE INTERRUPT OCCURED
1086	003252	000004			TINT1: SCOPE		
1087							
1088							;TEST FOR INTERRUPT FROM THE DEVICE
1089	003254	042737	000340	177776	BIC	#340,DRPSW	
1090	003262	052737	000040	177776	BIS	#040,DRPSW	;SET TO PRIORITY LEVEL 1
1091	003270	012777	003322	175734	MOV	#TINT2,DRVECA	;INTERRUPT VECTOR ADDRESS
1092	003276	012706	001200		MOV	#STACK,%6	;SET UP STACK POINTER
1093	003302	042777	000100	175712	BIC	#100,DRCSR	;CLEAR INTERRUPT ENABLE
1094	003310	052777	000101	175704	BIS	#101,DRCSR	;SET INTERRUPT ENABLE-AND CSRO
1095	003316	000240			NOP		
1096	003320	104000			HLT		;NO DEVICE INTERRUPT OCCURED
1097							
1098	003322	000004			TINT2: SCOPE		
1099	003324	042737	000340	177776	BIC	#340,DRPSW	
1100	003332	052737	000100	177776	BIS	#100,DRPSW	;SET TO PRIORITY LEVEL 2
1101	003340	012777	003372	175664	MOV	#TINT3,DRVECA	;INTERRUPT VECTOR ADDRESS
1102	003346	012706	001200		MOV	#STACK,%6	;SET UP STACK POINTER
1103	003352	042777	000100	175642	BIC	#100,DRCSR	;CLEAR INTERRUPT ENABLE
1104	003360	052777	000101	175634	BIS	#101,DRCSR	;SET INTERRUPT ENABLE-AND CSRO
1105	003366	000240			NOP		
1106	003370	104000			HLT		;NO DEVICE INTERRUPT OCCURED
1107							
1108	003372	000004			TINT3: SCOPE		
1109							;TEST FOR INTERRUPT FROM THE DEVICE
1110	003374	042737	000340	177776	BIC	#340,DRPSW	
1111	003402	052737	000140	177776	BIS	#140,DRPSW	;SET TO PRIORITY LEVEL 3
1112	003410	012777	003442	175614	MOV	#TINT4,DRVECA	;INTERRUPT VECTOR ADDRESS
1113	003416	012706	001200		MOV	#STACK,%6	;SET UP STACK POINTER
1114	003422	042777	000100	175572	BIC	#100,DRCSR	;CLEAR INTERRUPT ENABLE
1115	003430	052777	000101	175564	BIS	#101,DRCSR	;SET INTERRUPT ENABLE-AND CSRO
1116	003436	000240			NOP		
1117	003440	104000			HLT		;NO DEVICE INTERRUPT OCCURED
1118	003442	000004			TINT4: SCOPE		
1119							
1120							;TEST FOR INTERRUPT FROM DEVICE
1121	003444	042737	000340	177776	BIC	#340,DRPSW	
1122	003452	052737	000200	177776	BIS	#200,DRPSW	;RAISE PROCESSOR PRIORITY TO LEVEL 4
1123	003460	012777	003522	175544	MOV	#TINT5,DRVECA	;IN CASE OF INTERRUPT
1124	003466	012706	001200		MOV	#STACK,%6	;SET STACK POINTER
1125	003472	042777	000100	175522	BIC	#100,DRCSR	;CLEAR INTERRUPT ENABLE
1126	003500	052777	000101	175514	BIS	#101,DRCSR	;SET INTERRUPT ENABLE AND CSRO
1127	003506	000240			NOP		;LET INTERRUPT OCCUR
1128	003510	042777	000100	175504	BIC	#100,DRCSR	

```

1129 003516 000240          NOP
1130 003520 104000          HLT                    ;NO DEVICE INTERRUPT OCCURED
1131 003522 000004          TINT5: SCOPE
1132
1133          ;TEST FOR NO INTERRUPT FROM DEVICE (HIGHEST PROCESSOR PRIORITY)
1134 003524 052737 000340 177776  BIC  #340,@PSW          ;RAISE PROCESSOR PRIORITY TO HIGHEST LEVEL
1135 003532 012777 003572 175472  MOV  @TINT6,@DRVECA     ;IN CASE OF INTERRUPT
1136 003540 012706 001200          MOV  @STACK,%6          ;SET STACK POINTER
1137 003544 042777 000100 175450  BIC  #100,@DRCSR       ;CLEAR INTERRUPT ENABLE
1138 003552 052777 000101 175442  BIS  #101,@DRCSR
1139 003560 000240          NOP
1140 003562 042777 000100 175432  BIC  #100,@DRCSR
1141 003570 000401          BR   .+4                ;WITH NO INTERRUPT, BRANCH OVER HALT
1142 003572 104000          TINT6: HLT              ;INTERRUPT OCCURED
1143 003574 000004          SCOPE
1144
1145          ;TEST FOR NO INTERRUPT FROM DEVICE
1146 003576 042737 000340 177776  BIC  #340,@PSW
1147 003604 052737 000240 177776  BIS  #240,@PSW          ;RAISE PROCESSOR PRIORITY TO LEVEL 5
1148 003612 012777 003652 175412  MOV  @TINT7,@DRVECA     ;IN CASE OF INTERRUPT
1149 003620 012706 001200          MOV  @STACK,%6          ;SET STACK POINTER
1150 003624 042777 000100 175370  BIC  #100,@DRCSR       ;CLEAR INTERRUPT ENABLE
1151 003632 052777 000101 175362  BIS  #101,@DRCSR       ;SET INTERRUPT ENABLE AND CSRO
1152 003640 000240          NOP
1153 003642 042777 000100 175352  BIC  #100,@DRCSR       ;DON'T LEAVE IT SET
1154 003650 000401          BR   .+4                ;WITH NO INTERRUPT, BRANCH OVER HALT
1155 003652 104000          TINT7: HLT              ;INTERRUPT OCCURED
1156 003654 000004          SCOPE
1157
1158          ;TEST FOR NO INTERRUPT FROM DEVICE
1159 003656 042737 000340 177776  BIC  #340,@PSW
1160 003664 052737 000300 177776  BIS  #300,@PSW          ;RAISE PROCESSOR PRIORITY TO LEVEL 6
1161 003672 012777 003732 175332  MOV  @TINT8,@DRVECA     ;IN CASE OF INTERRUPT
1162 003700 012706 001200          MOV  @STACK,%6          ;SET STACK POINTER
1163 003704 042777 000100 175310  BIC  #100,@DRCSR       ;CLEAR INTERRUPT ENABLE
1164 003712 052777 000101 175302  BIS  #101,@DRCSR       ;SET INTERRUPT ENABLE-AND CSRO
1165 003720 042777 000100 175274  BIC  #100,@DRCSR       ;DON'T LEAVE IT SET
1166 003726 000240          NOP
1167 003730 000401          BR   .+4                ;WITH NO INTERRUPT, BRANCH OVER HALT
1168 003732 104000          TINT8: HLT              ;INTERRUPT OCCURED
1169 003734 000004          SCOPE
1170
1171 003736 016777 175272 175266  MOV  DRVLV,@DRVECA      ;FOR FALSE INTERRUPT
1172 003744 005077 175262          CLR  @DRVECA
1173
1174          ;END OF TEST ROUTINE
1175 003750 012777 000052 000356  END: MOV  #'*,@TDBR      ;TYPE '*'
1176 003756 105777 000354          1$: TSTB @TCSR
1177 003762 100375          BPL  1$
1178 003764 005077 000344          CLR  @TDBR
1179 003770 105777 000342          2$: TSTB @TCSR
1180 003774 100375          BPL  2$
1181 003776 104406          CKSWR
1182 004000 032777 002000 175210  BIT  #SW10,@SWR         ;LOOP ON SELECTED DR?
1183 004006 001402          BEQ  4$
1184 004010 000137 001754          JMP  @RSTART           ;REPEAT TEST ON DR11C SELECTED

```

```

1185 ;STEP TO NEXT DR11-C
1186 004014 012700 000010 4S: MOV #10,R0 ;STEPPING CONSTANT
1187 004020 012737 004072 000004 MOV #5S,@#4 ;SET TIME OUT TRAP
1188 004026 160005 SUB R0,R5 ;STEP TO NEXT DR11-C ADDRESS
1189 004030 005715 TST (R5) ;WILL TIME OUT IF NOT AVAILABLE
1190 004032 012705 001222 MOV #DRCSR,R5 ;SET TABLE POINTER
1191 004036 160025 SUB R0,(R5)+
1192 004040 160025 SUB R0,(R5)+
1193 004042 160025 SUB R0,(R5)+
1194 004044 160025 SUB R0,(R5)+
1195 004046 060025 ADD R0,(R5)+
1196 004050 060025 ADD R0,(R5)+
1197 004052 060025 ADD R0,(R5)+
1198 004054 000137 001754 JMP @#RSTART ;RESTART TEST USING NEXT DR11-C
1199 004060 104406 CKSWR
1200 004062 032777 001000 175126 BIT #SW9,@SWR
1201 004070 001004 BNE BS
1202 004072 104401 5S: TYPE ;TYPE 'END PASS'
1203 004074 006675 MESS3
1204 004076 005267 175144 INC PASCNT ;KEEP TRACK OF PASSES COMPLETED
1205 004102 013700 000042 8S: MOV @#42,R0
1206 004106 001405 BEQ END1
1207 004110 000005 RESET
1208 004112 004710 SENDAD: JSR PC,(R0)
1209 004114 000240 NOP
1210 004116 000240 NOP
1211 004120 000240 NOP
1212 004122 000137 001726 END1: JMP @#START
1213
1214 ;ENTERED WITH SYSTEM TRAP CALL(HLT)
1215 ;PRINT OUT THE ERROR PC AND STATUS REGISTER
1216 004126 104406 .HLT: CKSWR
1217 004130 037727 175062 020000 BIT @SWR,@SW13 ;TEST FOR INHIBIT PRINT OUT
1218 004136 001401 BEQ .+4 ;BRANCH TO PRINT
1219 004140 000002 RTI ;INHIBIT RETURN TO MAIN STREAM
1220 004142 012667 000172 MOV (6)+,SAVPC ;PC OF FAILING ROUTINE
1221 004146 012667 000170 MOV (6)+,SAVCC ;CC OF ERROR CONDITION
1222 004152 024646 CMP -(6),-(6) ;REPOSITION THE STACK
1223 004154 105777 000156 TSTB @TCSR ;WAIT FOR FLAG
1224 004160 100375 BPL .-4 ;IF NOT UP.
1225 004162 012777 000215 000144 MOV #215,@TDBR ;CR
1226 004170 105777 000142 TSTB @TCSR
1227 004174 100375 BPL .-4
1228 004176 012777 000212 000130 MOV #212,@TDBR ;LINE FEED
1229 004204 105777 000126 TSTB @TCSR
1230 004210 100375 BPL .-4
1231 004212 010267 000110 MOV %2,SAVR2 ;SAVE R2
1232 004216 010367 000106 MOV %3,SAVR3 ;SAVE R3
1233 004222 010467 000104 MOV %4,SAVR4 ;SAVE R4
1234 004226 016702 000106 MOV SAVPC,%2
1235 004232 004767 000106 JSR %7,PRTAB ;PRINT OCTAL NUMBER
1236 004236 012777 000240 000070 MOV #240,@TDBR
1237 004244 105777 000066 TSTB @TCSR ;SPACE BETWEEN WORDS
1238 004250 100375 BPL .-4
1239 004252 016702 000064 MOV SAVCC,%2
1240 004256 004767 000062 JSR %7,PRTAB ;PRINT OCTAL NUMBER

```



```

1297 004566 014477 177542      MOV      -(4),@TDBR
1298 004572 005367 000026      DEC      ASCNT
1299 004576 001401                BEQ      HDFHM          ;FINISH PRINTING GET NXT NUM
1300 004600 000767                BR       WAIT2
1301 004602 105777 177530      HDFHM:  TSTB @TCSR
1302 004606 100375                BPL     .-4
1303 004610 000207                RTS     %7          ;HEAD FOR HOME
1304 004612 000000      TOODLE: 0
1305 004614 000000      SEVEN:  0
1306 004616 000000      DECML:  0
1307 004620 000000      WGTCT:  0
1308 004622 000000      BINCT:  0
1309 004624 000000      ASCNT:  0
1310 004626 000000      LIST:   0
1311 004630 000000                0
1312 004632 000000                0
1313 004634 000000                0
1314 004636 000000                0
1315                                ;SCOPE LOOP ROUTINE ENTERED BY USER TRAP
1316 004640 022606      SCOPEB:  CMP      (6)+,%6          ;REPOSITION THE STACK
1317 004642 012637 177776      MOV      (6)+,@#PSW
1318 004646 000177 000120      JMP      @RETURN          ;SCOPE RETURN
1319
1320                                ;SCOPE OR/AND ITERATION LOOP FOR EACH TEST 4000 TIMES
1321 004652 104406      .SCOPE:  CKSWR
1322 004654 032777 040000 174334      BIT      #SW14,@SWR          ;TEST SR FOR SCOPE
1323 004662 001366                BNE     SCOPEB          ;YES SCOPE
1324 004664 005737 001240      TST      @#XORFLG
1325 004670 100012                BPL     1$
1326 004672 013746 000004      MOV      @#4,-(%6)
1327 004676 012737 005000 000004      MOV      #XOR,@#4
1328 004704 012737 000031 177060      MOV      #31,@#177060
1329 004712 012637 000004      MOV      (%6)+,@#4
1330 004716 104406      1$:     CKSWR
1331 004720 032777 004000 174270      BIT      #SW11,@SWR          ;NO - TEST FOR ITERATION
1332 004726 001014                BNE     SCOPEA          ;INHIBIT ITERATION
1333 004730 005767 174312      TST      PASCNT          ;ARE WE IN FIRST PASS?
1334 004734 001411                BEQ     SCOPEA          ;BRANCH IF YES; INHIBIT ITERATIONS
1335 004736 026767 000026 000022      CMP      SCOPEF,ICOUNT
1336 004744 001403                BEQ     SCOPEG          ;EXIT - DONE
1337 004746 005267 000016      INC      SCOPEF          ;INCREMENT COUNT
1338 004752 000732                BR      SCOPEB          ;LOOP SOME MORE
1339 004754 005067 000010      SCOPEG: CLR      SCOPEF          ;CLEAR COUNT
1340 004760 011667 000006      SCOPEA: MOV      @%6,RETURN          ;SAVE SCOPE RETURN POINTER
1341 004764 000002                RTI
1342 004766 004000                ICOUNT: 4000          ;RETURN INLINE-NEXT TEST
1343 004770 000000                SCOPEF: 0
1344 004772 002010                RETURN:  BEGIN          ;COUNT LOCATION FOR ITERATION LOOP
1345 004774 000167 173200                JMP      200          ;ADDRESS OF LAST TEST
1346
1347 005000 022626      XOR:    CMP      (%6)+,(%6)+
1348 005002 012637 000004      MOV      (%6)+,@#4
1349 005006 000714                BR      SCOPEB
1350                                ;PRINT DEVICE ADDRESS AND VECTOR
1351 005010 012777 000240 177316      MOREID: MOV      #240,@TDBR
1352 005016 105777 177314                TSTB   @TCSR

```

1353	005022	100375		BPL	.-4	
1354	005024	013702	001222	MOV	@DRCSR,%2	
1355	005030	004767	177310	JSR	%7,PRTAB	
1356	005034	012777	000240	MOV	@240,@TDBR	177272
1357	005042	105777	177270	TSTB	@TCSR	
1358	005046	100375		BPL	.-4	
1359	005050	016702	174156	MOV	DRVECA,%2	
1360	005054	004767	177264	JSR	%7,PRTAB	
1361	005060	012777	000215	MOV	@215,@TDBR	177246
1362	005066	105777	177244	TSTB	@TCSR	
1363	005072	100375		BPL	.-4	
1364	005074	012777	000212	MOV	@212,@TDBR	177232
1365	005102	105777	177230	TSTB	@TCSR	
1366	005106	100375		BPL	.-4	
1367	005110	005077	177220	CLR	@TDBR	
1368	005114	105777	177216	TSTB	@TCSR	
1369	005120	100375		BPL	.-4	
1370	005122	000207		RTS	%7	;BACK TO PRINT
1371						
1372						
1373						
1374	005124	010046				
1375	005126	010146				
1376	005130	010246				
1377	005132	010346				
1378	005134	010446				
1379	005136	010546				
1380	005140	016746	172660			
1381	005144	010637	005160			
1382	005150	012737	005162			000024
1383	005156	000000				
1384	005160	000000				
1385	005162	016706	177772			
1386	005166	012667	172632			
1387	005172	012605				
1388	005174	012604				
1389	005176	012603				
1390	005200	012602				
1391	005202	012601				
1392	005204	012600				
1393	005206	000137	001754			
1394						
1395						
1396						
1397	005212	000000				
1398	005214	104406				
1399	005216	017701	173774			
1400	005222	004737	005246			
1401	005226	000000				
1402	005230	104406				
1403	005232	017701	173760			
1404	005236	004737	005276			
1405	005242	000137	001726			
1406						
1407	005246	012700	001200			
1408	005252	010120				

  

```

;ENTER HERE FOR POWER FAIL
PFAIL:  MOV    %0,-(6)      ;SAVE REGISTER OR STACK
        MOV    %1,-(6)      ;WHEN POWERING DOWN
        MOV    %2,-(6)
        MOV    %3,-(6)
        MOV    %4,-(6)
        MOV    %5,-(6)
        MOV    24,-(6)
        MOV    %6,@SAVR6    ;STORE STACK POSITION
        MOV    @RESTAR,@24
        HALT                ;HALT ON POWER DOWN NORMAL
                                ;STACK IS SAVED HERE
                                ;RESTORE REGISTER OFF STACK
                                ;WHEN POWERING UP
SAVR6:  0
RESTAR: MOV    SAVR6,%6
        MOV    (6)+,%24
        MOV    (6)+,%5
        MOV    (6)+,%4
        MOV    (6)+,%3
        MOV    (6)+,%2
        MOV    (6)+,%1
        MOV    (6)+,%0
        JMP    @RSTART

;ENTER HERE FOR UNIQUE SELECTION OF DR11C
SPEC0:  HALT                ;PLACE ADDRESS OF DR11-C CONTROL STATUS
        CKSWR
        MOV    @SWR,R1
        JSR    PC,@SPEC1
        HALT
        CKSWR
        MOV    @SWR,R1
        JSR    PC,@SPEC2
        JMP    @START

SPEC1:  MOV    @RCSR,R0      ;SET TABLE ADDRESS
        MOV    R1,(R0)+     ;LOAD INTO TABLE STARTING AT RCSR

```

```

1409 005254 062701 000002
1410 005260 010120
1411 005262 062701 000002
1412 005266 010120
1413 005270 005301
1414 005272 010120
1415 005274 000207
1416
1417 005276 012700 001210
1418 005302 010120
1419 005304 005721
1420 005306 010120
1421 005310 005721
1422 005312 010120
1423 005314 000207
1424
1425
1426 005316
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444 005316 105767 000223
1445 005322 100002
1446 005324 000000
1447 005326 000407
1448 005330 010046
1449 005332 017600 000002
1450 005336 112046
1451 005340 001005
1452 005342 005726
1453 005344 012600
1454 005346 062716 000002
1455 005352 000002
1456 005354 122716 000011
1457 005360 001430
1458 005362 122716 000200
1459 005366 001006
1460 005370 005726
1461 005372 104401
1462 005374 005547
1463 005376 105067 000130
1464 005402 000755

```

```

ADD #2,R1 ;STEP TO ADDRESS OF DROUTBUF
MOV R1,(R0)+ ;LOAD INTO TABLE
ADD #2,R1 ;STEP TO ADDRESS OF DRINBUF
MOV R1,(R0)+ ;LOAD INTO TABLE
DEC R1 ;FORM ADDRESS OF DROUTBUF+1
MOV R1,(R0)+ ;LOAD INTO TABLE
RTS PC

```

```

SPEC2: MOV #RCSR1,R0
MOV R1,(R0)+ ;LOAD INTO TABLE
TST (R1)+
MOV R1,(R0)+
TST (R1)+
MOV R1,(R0)+
RTS PC

```

```

.LIST ME
TYP:
.SBTTL TYPE ROUTINE

```

```

*****
*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1: SNUL contains the character to be used as the filler character.
*NOTE2: SFILLS contains the number of filler characters required.
*NOTE3: SFILLC contains the character to fill after.
*
*CALL:
*1) USING A TRAP INSTRUCTION
* TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
*OR
* TYPE
* MESADR
*

```

```

$TYPE: TSTB $TFPLG ;; IS THERE A TERMINAL?
BPL 1$ ;; BR IF YES
HALT ;; HALT HERE IF NO TERMINAL
BR 3$ ;; LEAVE
1$: MOV RO,-(SP) ;; SAVE RO
MOV @2(SP),RO ;; GET ADDRESS OF ASCIZ STRING
2$: MOVB (RO)+,-(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
BNE 4$ ;; BR IF IT ISN'T THE TERMINATOR
TST (SP)+ ;; IF TERMINATOR POP IT OFF THE STACK
60$: MOV (SP)+,RO ;; RESTORE RO
3$: ADD #2,(SP) ;; ADJUST RETURN PC
RTI ;; RETURN
4$: CMPB #HT,(SP) ;; BRANCH IF <HT>
BEQ 8$
CMPB #CRLF,(SP) ;; BRANCH IF NOT <CRLF>
BNE 5$
TST (SP)+ ;; POP <CR><LF> EQUIV
TYPE ;; TYPE A CR AND LF
$CRLF
CLRB $CHARCNT ;; CLEAR CHARACTER COUNT
BR 2$ ;; GET NEXT CHARACTER

```

TYPE ROUTINE

```

1465 005404 004767 000056 5$: JSR PC,$TYPEC ;:GO TYPE THIS CHARACTER
1466 005410 126726 000130 6$: CMPB $FILLC,(SP)+ ;:IS IT TIME FOR FILLER CHARS.?
1467 005414 001350 BNE 2$ ;:IF NO GO GET NEXT CHAR.
1468 005416 016746 000120 MOV $NULL,-(SP) ;:GET # OF FILLER CHARS. NEEDED
1469 ;:AND THE NULL CHAR.
1470 005422 105366 000001 7$: DECIB i(SP) ;:DOES A NULL NEED TO BE TYPED?
1471 005426 002770 BLT 6$ ;:BR IF NO--GO POP THE NULL OFF OF STACK
1472 005430 004767 000032 JSR PC,$TYPEC ;:GO TYPE A NULL
1473 005434 105367 000072 DECIB $CHARCNT ;:DO NOT COUNT AS A COUNT
1474 005440 000770 BR 7$ ;:LOOP
1475
1476 ;:HORIZONTAL TAB PROCESSOR
1477
1478 005442 112716 000040 8$: MOVB #' (SP) ;:REPLACE TAB WITH SPACE
1479 005446 004767 000014 9$: JSR PC,$TYPEC ;:TYPE A SPACE
1480 005452 132767 000007 000052 BITB #',$CHARCNT ;:BRANCH IF NOT AT
1481 005460 001372 BNE 9$ ;:TAB STOP
1482 005462 005726 TST (SP)+ ;:POP SPACE OFF STACK
1483 005464 000724 BR 2$ ;:GET NEXT CHARACTER
1484 005466 105777 000044 $TYPEC: TSTB $STPS ;:WAIT UNTIL PRINTER IS READY
1485 005472 100375 BPL $TYPEC
1486 005474 116677 000002 000036 MOVB 2(SP),$STPB ;:LOAD CHAR TO BE TYPED INTO DATA REG.
1487 005502 122766 000015 000002 CMPB #CR,2(SP) ;:IS CHARACTER A CARRIAGE RETURN?
1488 005510 001003 BNE 1$ ;:BRANCH IF NO
1489 005512 105067 000014 CLRB $CHARCNT ;:YES--CLEAR CHARACTER COUNT
1490 005516 000406 BR $TYPEX ;:EXIT
1491 005520 122766 000012 000002 1$: CMPB #LF,2(SP) ;:IS CHARACTER A LINE FEED?
1492 005526 001402 BEQ $TYPEX ;:BRANCH IF YES
1493 005530 105227 INCB (PC)+ ;:COUNT THE CHARACTER
1494 005532 000000 $CHARCNT: .WORD 0 ;:CHARACTER COUNT STORAGE
1495 005534 000207 $TYPEX: RTS PC
1496
1497 005536 177564 $STPS: .WORD 177564 ;:TTY PRINTER STATUS REG. ADDRESS
1498 005540 177566 $STPB: .WORD 177566 ;:TTY PRINTER BUFFER REG. ADDRESS
1499 005542 000 $NULL: .BYTE 0 ;:CONTAINS NULL CHARACTER FOR FILLS
1500 005543 002 $FILLS: .BYTE 2 ;:CONTAINS # OF FILLER CHARACTERS REQUIRED
1501 005544 012 $FILLC: .BYTE 12 ;:INSERT FILL CHARS. AFTER A "LINE FEED"
1502 005545 000 $STPLG: .BYTE 0 ;:"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
1503 005546 077 $QUES: .ASCII "?" ;:QUESTION MARK
1504 005547 015 $CRLF: .ASCII <15> ;:CARRIAGE RETURN
1505 005550 000012 $LF: .ASCIZ <12> ;:LINEFEED
1506 ;:SBTTL BINARY TO OCTAL (ASCII) AND TYPE
1507
1508 ;:*****
1509 ;:*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
1510 ;:*OCTAL (ASCII) NUMBER AND TYPE IT.
1511 ;:*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
1512 ;:*CALL:
1513 ;:* MOV NUM,-(SP) ;:NUMBER TO BE TYPED
1514 ;:* TYPOS ;:CALL FOR TYPEOUT
1515 ;:* .BYTE N ;:N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
1516 ;:* .BYTE M ;:M=1 OR 0
1517 ;: ;:1=TYPE LEADING ZEROS
1518 ;: ;:0=SUPPRESS LEADING ZEROS
1519 ;:
1520 ;:*$STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST

```

```

1521 ;*STYPOS OR STYPOC
1522 ;*CALL:
1523 ;*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
1524 ;*   TYPON                ;;CALL FOR TYPEOUT
1525 ;*
1526 ;*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
1527 ;*CALL:
1528 ;*   MOV   NUM,-(SP)      ;;NUMBER TO BE TYPED
1529 ;*   TYPOC                ;;CALL FOR TYPEOUT
1530 ;*
1531 005552 017646 000000 000211 STYPOS: MOV   2(SP),-(SP)      ;;PICKUP THE MODE
1532 005556 116667 000001 000211 MOV   1(SP),SOFILL      ;;LOAD ZERO FILL SWITCH
1533 005564 112667 000207 000211 MOV   (SP)+,SOMODE+1   ;;NUMBER OF DIGITS TO TYPE
1534 005570 062716 000002 000211 ADD   #2,(SP)          ;;ADJUST RETURN ADDRESS
1535 005574 000406 000000 000211 BR    STYPON
1536 005576 112767 000001 000171 STYPOC: MOV   #1,SOFILL      ;;SET THE ZERO FILL SWITCH
1537 005604 112767 000006 000165 MOV   #6,SOMODE+1      ;;SET FOR SIX(6) DIGITS
1538 005612 112767 000005 000154 STYPON: MOV   #5,SOCNT     ;;SET THE ITERATION COUNT
1539 005620 010346 000000 000154 MOV   R3,-(SP)         ;;SAVE R3
1540 005622 010446 000000 000154 MOV   R4,-(SP)         ;;SAVE R4
1541 005624 010546 000000 000154 MOV   R5,-(SP)         ;;SAVE R5
1542 005626 116704 000145 000154 MOV   SOMODE+1,R4      ;;GET THE NUMBER OF DIGITS TO TYPE
1543 005632 005404 000000 000145 NEG   R4
1544 005634 062704 000006 000132 ADD   #6,R4            ;;SUBTRACT IT FOR MAX. ALLOWED
1545 005640 110467 000132 000132 MOV   R4,SOMODE        ;;SAVE IT FOR USE
1546 005644 116704 000125 000132 MOV   SOFILL,R4        ;;GET THE ZERO FILL SWITCH
1547 005650 016605 000012 000132 MOV   12(SP),R5        ;;PICKUP THE INPUT NUMBER
1548 005654 005003 000000 000132 CLR   R3               ;;CLEAR THE OUTPUT WORD
1549 005656 006105 000000 000132 1$:  ROL   R5              ;;ROTATE MSB INTO "C"
1550 005660 000404 000000 000132 BR    3$
1551 005662 006105 000000 000132 2$:  ROL   R5              ;;GO DO MSB
1552 005664 006105 000000 000132 ROL   R5              ;;FORM THIS DIGIT
1553 005666 006105 000000 000132 ROL   R5
1554 005670 010503 000000 000132 MOV   R5,R3
1555 005672 006103 000000 000132 3$:  ROL   R3              ;;GET LSB OF THIS DIGIT
1556 005674 105367 000076 000132 DECB  SOMODE           ;;TYPE THIS DIGIT?
1557 005700 100016 000000 000132 BPL   7$              ;;BR IF NO
1558 005702 042703 177770 000132 BIC   #177770,R3      ;;GET RID OF JUNK
1559 005706 001002 000000 000132 BNE   4$              ;;TEST FOR 0
1560 005710 005704 000000 000132 TST   R4              ;;SUPPRESS THIS 0?
1561 005712 001403 000000 000132 BEQ   5$              ;;BR IF YES
1562 005714 005204 000000 000132 4$:  INC   R4              ;;DON'T SUPPRESS ANYMORE 0'S
1563 005716 052703 000060 000132 BIS   #'0,R3          ;;MAKE THIS DIGIT ASCII
1564 005722 052703 000040 000132 5$:  BIS   #' ,R3          ;;MAKE ASCII IF NOT ALREADY
1565 005726 110367 000040 000132 MOV   R3,#$           ;;SAVE FOR TYPING
1566 005732 104401 005772 000132 TYPE  ,#$            ;;GO TYPE THIS DIGIT
1567 005736 105367 000032 7$:  DECB  $SOCNT           ;;COUNT BY 1
1568 005742 003347 000000 000132 BGT   2$              ;;BR IF MORE TO DO
1569 005744 002402 000000 000132 BLT   6$              ;;BR IF DONE
1570 005746 005204 000000 000132 INC   R4              ;;INSURE LAST DIGIT ISN'T A BLANK
1571 005750 000744 000000 000132 BR    2$              ;;GO DO THE LAST DIGIT
1572 005752 012605 000000 000132 6$:  MOV   (SP)+,R5        ;;RESTORE R5
1573 005754 012604 000000 000132 MOV   (SP)+,R4        ;;RESTORE R4
1574 005756 012603 000000 000132 MOV   (SP)+,R3        ;;RESTORE R3
1575 005760 016666 000002 000004 MOV   2(SP),4(SP)     ;;SET THE STACK FOR RETURNING
1576 005766 012616 000000 000004 MOV   (SP)+,(SP)

```

1577 005770 000002  
1578 005772 000  
1579 005773 000  
1580 005774 000  
1581 005775 000  
1582 005776 000000

RTI ;: RETURN  
8\$: .BYTE 0 ;: STORAGE FOR ASCII DIGIT  
;: .BYTE 0 ;: TERMINATOR FOR TYPE ROUTINE  
SOCNT: .BYTE 0 ;: OCTAL DIGIT COUNTER  
SOFILL: .BYTE 0 ;: ZERO FILL SWITCH  
SOMODE: .WORD 0 ;: NUMBER OF DIGITS TO TYPE  
.SBTTL TTY INPUT ROUTINE

1585  
1586 006000 177560  
1587 006002 177562

\*\*\*\*\*  
\$TKS: .WORD 177560 ;: TTY KBD STATUS  
\$TKB: .WORD 177562 ;: TTY KBD BUFFER  
.ENABL LSB

1589  
1590  
1591  
1592  
1593  
1594

\*\*\*\*\*  
\*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.  
\*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL  
\*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL  
\*WHEN OPERATING IN TTY FLAG MODE.

1595 006004 022767 000176 173204  
1596 006012 001074  
1597 006014 105777 177760  
1598 006020 100071  
1599 006022 117746 177754  
1600 006026 042716 177600  
1601 006032 022726 000007  
1602 006036 001062  
1603 006040 126727 000514 000001  
1604 006046 001456

\$CKSWR: CMP #SWREG, SWR ;: IS THE SOFT-SWR SELECTED?  
BNE 15\$ ;: BRANCH IF NO  
TSTB \$TKS ;: CHAR THERE?  
BPL 15\$ ;: IF NO, DON'T WAIT AROUND  
MOVB \$TKB, -(SP) ;: SAVE THE CHAR  
BIC #177, (SP) ;: STRIP-OFF THE ASCII  
CMP #7, (SP)+ ;: IS IT A CONTROL G?  
BNE 15\$ ;: NO, RETURN TO USER  
CMPB \$AUTOB, #1 ;: ARE WE RUNNING IN AUTO-MODE?  
BEQ 15\$ ;: BRANCH IF YES

1605  
1606 006050 104401 006531  
1607 006054 104401 006536  
1608 006060 016746 172112  
1609 006064 104402  
1610 006066 104401 006547  
1611 006072 005046  
1612 006074 005046  
1613 006076 105777 177676  
1614 006102 100375  
1615  
1616 006104 117746 177672  
1617 006110 042716 177600

\$GTSWR: TYPE ,SCNTLG ;: ECHO THE CONTROL-G (1G)  
TYPE \$MSWR ;: TYPE CURRENT CONTENTS  
MOV SWREG, -(SP) ;: SAVE SWREG FOR TYPEOUT  
TYPOC ;: GO TYPE--OCTAL ASCII(ALL DIGITS)  
TYPE ,SMNEW ;: PROMPT FOR NEW SWR  
19\$: CLR -(SP) ;: CLEAR COUNTER  
CLR -(SP) ;: THE NEW SWR  
7\$: TSTB \$TKS ;: CHAR THERE?  
BPL 7\$ ;: IF NOT TRY AGAIN  
MOVB \$TKB, -(SP) ;: PICK UP CHAR  
BIC #177, (SP) ;: MAKE IT 7-BIT ASCII

1620  
1621 006114 021627 000025  
1622 006120 001005  
1623 006122 104401 006524  
1624 006126 062706 000006  
1625 006132 000757  
1626  
1627

9\$: CMP (SP), #25 ;: IS IT A CONTROL-U?  
BNE 10\$ ;: BRANCH IF NOT  
TYPE ,SCNTLU ;: YES, ECHO CONTROL-U (1U)  
20\$: ADD #6, SP ;: IGNORE PREVIOUS INPUT  
BR 19\$ ;: LET'S TRY IT AGAIN

1628 006134 021627 000015  
1629 006140 001022  
1630 006142 005766 000004  
1631 006146 001403  
1632 006150 016677 000002 173040

10\$: CMP (SP), #15 ;: IS IT A <CR>?  
BNE 16\$ ;: BRANCH IF NO  
TST 4(SP) ;: YES, IS IT THE FIRST CHAR?  
BEQ 11\$ ;: BRANCH IF YES  
MOV 2(SP), \$SWR ;: SAVE NEW SWR

1633	006156	062706	000006		11\$:	ADD	#6,SP	::	CLEAR UP STACK
1634	006162	104401	005547		14\$:	TYPE	\$CRLF	::	ECHO <CR> AND <LF>
1635	006166	126727	000367	000001		CMPB	\$INTAG,#1	::	RE-ENABLE TTY KBD INTERRUPTS?
1636	006174	001003				BNE	15\$	::	BRANCH IF NOT
1637	006176	012777	000100	177574		MOV	#100,@STKS	::	RE-ENABLE TTY KBD INTERRUPTS
1638	006204	000002			15\$:	RTI		::	RETURN
1639	006206	004767	177254		16\$:	JSR	PC,\$TYPEC	::	ECHO CHAR
1640	006212	021627	000060			CMP	(SP),#60	::	CHAR < 0?
1641	006216	002420				BLT	18\$	::	BRANCH IF YES
1642	006220	021627	000067			CMP	(SP),#67	::	CHAR > 7?
1643	006224	003015				BGT	18\$	::	BRANCH IF YES
1644	006226	042726	000060			BIC	#60,(SP)+	::	STRIP-OFF ASCII
1645	006232	005766	000002			TST	2(SP)	::	IS THIS THE FIRST CHAR
1646	006236	001403				BEQ	17\$	::	BRANCH IF YES
1647	006240	006316				ASL	(SP)	::	NO, SHIFT PRESENT
1648	006242	006316				ASL	(SP)	::	CHAR OVER TO MAKE
1649	006244	006316				ASL	(SP)	::	ROOM FOR NEW ONE.
1650	006246	005266	000002		17\$:	INC	2(SP)	::	KEEP COUNT OF CHAR
1651	006252	056616	177776			BIS	-2(SP),(SP)	::	SET IN NEW CHAR
1652	006256	000707				BR	7\$	::	GET THE NEXT ONE
1653	006260	104401	005546		18\$:	TYPE	\$QUES	::	TYPE ?<CR><LF>
1654	006264	000720				BR	20\$	::	SIMULATE CONTROL-U
1655						.DSABL	LSB		

1656  
1657  
1658  
1659  
1660  
1661  
1662  
1663  
1664  
1665  
1666  
1667  
1668  
1669  
1670  
1671  
1672  
1673  
1674  
1675  
1676  
1677  
1678  
1679  
1680  
1681  
1682  
1683  
1684  
1685  
1686  
1687  
1688

```

*****
;THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
;CALL:
;*
;*   RDCHR
;*   RETURN HERE
;*
;: INPUT A SINGLE CHARACTER FROM THE TTY
;: CHARACTER IS ON THE STACK
;: WITH PARITY BIT STRIPPED OFF

```

1666	006266	011646			S:RDCHR:	MOV	(SP),-(SP)	::	PUSH DOWN THE PC
1667	006270	016666	000004	000002		MOV	4(SP),2(SP)	::	SAVE THE PS
1668	006276	105777	177476		1\$:	TSTB	@STKS	::	WAIT FOR
1669	006302	100375				BPL	1\$	::	A CHARACTER
1670	006304	117766	177472	000004		MOVB	@STKB,4(SP)	::	READ THE TTY
1671	006312	042766	177600	000004		BIC	#1C<177>,4(SP)	::	GET RID OF JUNK IF ANY
1672	006320	026627	000004	000023		CMP	4(SP),#23	::	IS IT A CONTROL-S?
1673	006326	001013				BNE	3\$	::	BRANCH IF NO
1674	006330	105777	177444		2\$:	TSTB	@STKS	::	WAIT FOR A CHARACTER
1675	006334	100375				BPL	2\$	::	LOOP UNTIL ITS THERE
1676	006336	117746	177440			MOVB	@STKB,-(SP)	::	GET CHARACTER
1677	006342	042716	177600			BIC	#1C177,(SP)	::	MAKE IT 7-BIT ASCII
1678	006346	022627	000021			CMP	(SP)+,#21	::	IS IT A CONTROL-Q?
1679	006352	001366				BNE	2\$	::	IF NOT DISCARD IT
1680	006354	000750				BR	1\$	::	YES, RESUME
1681	006356	026627	000004	000140	3\$:	CMP	4(SP),#140	::	IS IT UPPER CASE?
1682	006364	002407				BLT	4\$	::	BRANCH IF YES
1683	006366	026627	000004	000175		CMP	4(SP),#175	::	IS IT A SPECIAL CHAR?
1684	006374	003003				BGT	4\$	::	BRANCH IF YES
1685	006376	042766	000040	000004		BIC	#40,4(SP)	::	MAKE IT UPPER CASE
1686	006404	000002			4\$:	RTI		::	GO BACK TO USER

```

*****
;THIS ROUTINE WILL INPUT A STRING FROM THE TTY

```

```

1689
1690
1691
1692
1693
1694 006406 010346
1695 006410 012703 006514
1696 006414 022703 006524
1697 006420 101405
1698 006422 104407
1699 006424 112613
1700 006426 122713 000177
1701 006432 001003
1702 006434 104401 005546
1703 006440 000763
1704 006442 111367 000044
1705 006446 104401 006512
1706 006452 122723 000015
1707 006456 001356
1708 006460 105063 177777
1709 006464 104401 005550
1710 006470 012603
1711 006472 011646
1712 006474 016666 000004 000002
1713 006502 012766 006514 000004
1714 006510 000002
1715 006512 000
1716 006513 000
1717 006514 000010
1718 006524 052536 005015 000
1719 006531 136 006507 000012
1720 006536 005015 053523 020122
1721 006544 020075 000
1722 006547 040 047040 053505
1723 006554 036440 000040
1724 006560 000
1725 006561 000
1726
1727
1728
1729
1730
1731
1732
1733
1734 006562 010046
1735 006564 016600 000002
1736 006570 005740
1737 006572 111000
1738 006574 006300
1739 006576 016000 006616
1740 006602 000200
1741
1742
1743
1744

```

```

;*CALL:
;* RDLIN
;* RETURN HERE
;*
;: INPUT A STRING FROM THE TTY
;: ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
;: TERMINATOR WILL BE A BYTE OF ALL 0'S

SRDLIN: MOV R3, -(SP) ;: SAVE R3
15: MOV #STTYIN, R3 ;: GET ADDRESS
25: CMP #STTYIN+8., R3 ;: BUFFER FULL?
;: BR IF YES
;: GO READ ONE CHARACTER FROM THE TTY
;: GET CHARACTER
105: CMPB #177, (R3) ;: IS IT A RUBOUT
;: SKIP IF NOT
45: TYPE $QUES ;: TYPE A '?'
;: CLEAR THE BUFFER AND LOOP
35: MOVB (R3), 95 ;: ECHO THE CHARACTER
;: CHECK FOR RETURN
;: LOOP IF NOT RETURN
;: CLEAR RETURN (THE 15)
;: TYPE A LINE FEED
;: RESTORE R3
;: ADJUST THE STACK AND PUT ADDRESS OF THE
;: FIRST ASCII CHARACTER ON IT
;: RETURN
95: .BYTE 0 ;: STORAGE FOR ASCII CHAR. TO TYPE
;: TERMINATOR
;: RESERVE 8 BYTES FOR TTY INPUT
;: CONTROL "U"
;: CONTROL "G"
STTYIN: .BLKB 8.
SCNTLU: .ASCIZ /↑U/<15><12>
SCNTLG: .ASCIZ /↑G/<15><12>
SMSWR: .ASCIZ <15><12>/SWR = /
$MNEW: .ASCIZ / NEW = /
$AUTOB: .BYTE 0 ;: AUTO MODE FLAG
$INTAG: .BYTE 0 ;: INTERRUPT MODE FLAG
.SBTTL TRAP DECODER

;: *****
;: *THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
;: *AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
;: *OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
;: *GO TO THAT ROUTINE.
STRAP: MOV R0, -(SP) ;: SAVE R0
;: GET TRAP ADDRESS
;: BACKUP BY 2
;: GET RIGHT BYTE OF TRAP
;: POSITION FOR INDEXING
;: INDEX TO TABLE
;: GO TO ROUTINE

;: THIS IS USE TO HANDLE THE "GETPRI" MACRO

```

```

1745 006604 011646          STRAP2: MOV      (SP),-(SP)      ;; MOVE THE PC DOWN
1746 006606 016666 000004 000002      MOV      4(SP),2(SP)      ;; MOVE THE PSW DOWN
1747 006614 000002          RTI                          ;; RESTORE THE PSW
1748
1749          .SBTTL  TRAP TABLE
1750
1751          ;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
1752          ;*BY THE "TRAP" INSTRUCTION.
1753
1754          ;          ROUTINE
1755          ;          -----
1756 006616 006604          $TRPAD: .WORD  $TRAP2
1757 006620 005316          $TYPE  ;;CALL=TYPE      TRAP+1(104401)  TTY TYPEOUT ROUTINE
1758 006622 005576          $TYPOC ;;CALL=TYPOC     TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
1759 006624 005552          $TYPOS ;;CALL=TYPOS     TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
1760 006626 005612          $TYPON ;;CALL=TYPON     TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
1761
1762 006630 006054          $GTSWR ;;CALL=GTSWR     TRAP+5(104405)  GET SOFT-SWR SETTING
1763
1764 006632 006004          $CKSWR ;;CALL=CKSWR     TRAP+6(104406)  TEST FOR CHANGE IN SOFT-SWR
1765 006634 006266          $RDCHR ;;CALL=RDCHR     TRAP+7(104407)  TTY TYPEIN CHARACTER ROUTINE
1766 006636 006406          $RDLIN ;;CALL=RDLIN     TRAP+10(104410) TTY TYPEIN STRING ROUTINE
1767 006640 005015 047531 020125 MESS1: .ASCIZ <15><12>'YOU ARE ON AN XOR TESTER'<15><12>
1768 006646 051101 020105 047117
1769 006654 040440 020116 047530
1770 006662 020122 042524 052123
1771 006670 051105 005015 000
1772 006675 105 042116 050040 MESS3: .ASCIZ /END PASS/<15><12>
1773 006702 051501 006523 000012
1774          .END
    
```









