

INTRODUCTION

This chapter describes how to prepare your site and equipment for installation. Chapter 2 describes how to install the TK50 UNIBUS kit in PDP-11 computers that include a UNIBUS. (Chapter 3 describes the same installation, but in VAX systems.)

PREPARING THE SITE

Place the TK50 tape drive subsystem where it is to be used.

Minimize static by placing the unit away from busy office corridors.

Place the unit away from heaters, photocopiers, and direct sunlight.

Keep the unit away from magnets and equipment that generate magnetic fields, such as motors, transformers, and terminals.

UNPACKING THE TK50-R (RACKMOUNT) SUBSYSTEM

If any item is missing or damaged:

- Contact your sales representative.
- Contact your delivery agent.

Unpack and check the H9302 rackmount kit (Figure 1-2), which is shipped separately. Refer to documentation provided with the kit for instructions.

The TK50-R tape drive is shipped completely assembled and ready to install in an H9302 rackmount assembly.