DIGITAL SOFTWARE NEWS

FOR THE

PDP-8 & PDP-12

Software Information Service Digital Equipment Corporation Maynard, Massachusetts 01754

		e e
		9
		ā

DIGITAL SOFTWARE NEWS FOR THE PDP-8 AND THE PDP-12

Digital Software News for the PDP-8 & PDP-12 is designed to provide users of PDP-8 and PDP-12 software with up to date information on software problems, programming notes, and new and revised software. Each article, other than announcements and documentation corrections, is coded sequentially by system program in the lower right corner for ease in maintaining a quick reference file. The original material for such a file is supplied in the Software Performance Summary for the PDP-8 & PDP-12. This publication which is placed in each basic software kit, is a collection of all current information on known software problems, patches, and programming notes. new versions correct software problems and obsolete patches, and reprinted manuals include programming notes and manual corrections, new articles in the Digital Software News will announce the revised software and specify by code which article should be removed from your Software Performance Summary file. Articles may also be replaced when new information becomes available; such as, procedure to circumvent a problem may replace the original report of the problem. All articles in the Digital Software News which should be added to your file will be appropriately coded.

Any questions or problems on the articles contained in these publications or concerning the use of Digital's software should be reported to the Software Specialist or Sales Engineer at your nearest Digital Office.

Additional copies of the current <u>Software Performance Summary</u> and updated issues of the PDP-8 and PDP-12 software price lists are available at no charge upon request from the Program Library. As with usual orders for software, the Program Library will accept orders received directly from U.S. customers. All other customer orders must be routed through the nearest Digital Representative.

			6
			,

DIGITAL SOFTWARE NEWS

SEPTEMBER 1971

TABLE OF CONTENTS

NEW & REVISED SOFTWARE			
PDP-12 New program MIDAS			
PDP-12 New program MASH			
PDP-12 Revised LINCtape			
SOFTWARE PROBLEMS			
PDP-12 LAP6-DIAL-MS Two bootstraps to load LAP6-DIAL-MS directly from the disk		LAP6-DIAL-MS	2
PDP-12 MASS SPECTROSCOPY HANDLER Insensitive, drifting or erroneous calibrations		MASH	1
PDP-12 MASS SPECTROSCOPY HANDLER Limitations in MASH		MASH	2
PDP-8 PIP (PS/8) Copy problems with tapes produced by the Binary Punch Routine		PIP (PS/8)	5
DOCUMENTATION CORRECTIONS			
PDP-12 AIPOS User's Manual	PDP-12	DOCUMENTATION	2

			e e
			٠
			*
			ä

MIDAS DEC-12-SQ3A

MIDAS (Multi Instrument Data Acquisition Software) is a general data acquisition program for the LDP system which acquires data from multiple instruments (8) via the AIP-12 in a synchronous or asynchronous manner and throughputs that data to mass storage (RK8 Disk or LINCtape). The maximum data rate for a given instrument or the maximum across a number of them depends on hardware configuration but can be as high as 15000 Hertz. Minimum hardware for MIDAS is a PDP-12/40 and AIP-12.

MIDAS allows control over experiments via Schmitt Triggers, external syncs, analog inputs, clocks, sense lines, relays, and keyboard. The controls may be dependent upon or independent of other on-line instruments in the MIDAS environment. The program recognizes all AIP hardware configurations, extended core, and up to 8 mass storage devices, and also allows setup of intruments while acquiring data from other on-line experiments. Instruments typically found in a MIDAS laboratory would be GC, UV, and IR.

MSORT (MIDAS Sorter) converts the output of MIDAS from a given experiment into a three word floating point format that is interpretable by other LDP software, e.g., DORA.

Customers may order this software for the applicable fee.

ITEM	DEC CODE	FEE
MIDAS User's Manual	DEC-12-SQ3A-D	\$ 5.00
MIDAS Binary on LINCtape	DEC-12-SE6D-UO	35.00
MIDAS Source (part of AIPOS Source Kit)	DEC-12-SEXA-UO	100.00

All prices are in U.S. dollars and apply to U.S. customers only. Because currency and import considerations affect the prices in all countries outside the U.S., all other users must check with the nearest Digital office or representative to place their orders.

U.S. customers may send orders with purchase order, check or money order directly to

Program Library Digital Equipment Corporation 146 Main Street Maynard, Massachusetts 01754 MASH (Mass Spectroscopy Handler) DEC-12-SQ2A

The Mass Spectrometer Handler (MASH) is a complete interactive data acquisition, processing and report generating system, utilizing the interfacing of a PDP-12 computer to any single mass spectrometer (or mass spectrometer/gas chromatograph combination) at a user's site. Three programs provide for the specification of parameters and control of all instrumentation during an experiment. The programs are:

Calibration (CALIB)

The chemist can recalibrate the mass spectrometer to correct for drift. The calibration procedure is efficient, thorough, and easy to use, and enables the MASH system to determine spectrum mass numbers with an accuracy of .2 amu if 15 bits, .3 amu if 12 bits, at masses of up to 600.

Acquisition (ACQUI)

During the acquisition program data can be acquired and processed in either multiple scan (useful if a gas chromatograph is attached to the mass spectrometer) or single scan mode. The data is sampled at high speed and processed in the computer's memory. Only the coordinates of the mass peaks are saved on tape or disk.

Report Generator (LOOK)

The Report program displays the results of the scan(s) to the chemist. Data is manipulated in a line spectra format, using any of the nineteen powerful teletype commands provided by the program. Report's response times for all commands are well under one second.

All three MASH programs are run under the standard AIPOS System, and all MASH files are compatible with standard AIPOS files. Thus, the AIPOS system now has the capability of controllong a mass spectrometer or mass spectrometer/gas chromatograph configuration.

The minimum hardware configuration is a PDP-12/4 \emptyset with a 12 or 15 bit A.I.P. The AIPOS Monitor must be used with the program.

PDP-12 New Software Cont.

MASH

Customers may order this software for the applicable fee.

<u>ITEM</u>					DEC code	Fe	<u>e</u>
MASH	User's	Mar	nual		DEC-12-SQ2A-D	\$	5,00
MASH	Binary	on	LINCtape		DEC-12-SE6D-UO	3	5.00
MASH	Source	on	LINCtape	(Part	III) DEC-12-SEXA-UO	3	5.00

All prices are in U.S. dollars and apply to U.S. customers only. Because currency and import considerations affect the prices in all countries outside the U.S., all other users must check with the nearest Digital office or representative to place their orders.

U.S. customers may send orders with purchase order, check or money order directly to:

Program Library Digital Equipment Corporation 146 Main Street Maynard, Massachusetts 01754 PDP-12 REVISED SOFTWARE

Revised LINCtape

With the addition of MIDAS (Multi Instrument Data Acquisition Software) to the LINCtape DEC-12-SE6C-UO, the library code has been changed to DEC-12-SE6D-UO to reflect this.

PDP-12 REVISED SOFTWARE

Revised LINCtape

With the addition of MASH (Mass Spectroscopy Handler) to the AIPOS system LINCtape DEC-12-SE6C-UO, the code has been changed to DEC-12-SE6D-UO.

LAP6-DIAL-MS

Two bootstraps to load LAP6-DIAL-MS directly from the disk

The following two bootstraps should be used to load LAP6-DIAL-MS directly from the disk (RF08 or RK08). Each bootstrap, when assembled, will yield one block of binary that must be moved to block \emptyset of the respective disk via PDP-12 PIP. The following instructions should be followed to assemble the bootstrap needed:

- l. Type up the program via LAP6-DIAL EDITOR
- 2. \rightarrow ZE (zero binary work area)
- (assemble program) 3. →AS
- 4. →SB (save binary of program)
- (note where the one block of binary is saved) 5. →DX
- 6. →PIP*(load PIP and transfer the one block of binary to $Rl\emptyset$ (disk \emptyset), block \emptyset)
- Toggle in the two or four word bootstrap and LAP6-DIAL-MS 7. will start up.
- * After the PIP transfer, the user should create an index entry (via PDP-12 TED) in the DIAL index so that DIAL will not save a file over this binary.

The procedure above assumes that the disk has been initialized See LAP6-DIAL Manual, DEC-12-SE2D-D; Appendix A, section A.3.

```
#20
                      PMODE
                      *20
             /RF08 BOOTSTRAP FOR DIAL-MS
             /COPYRIGHT 1971
             /DIGITAL EQUIPMENT CORPORATION
             /MAYNARD, MASS. Ø1754
             17/14/71
             1S GW
             /FIRST, ASSEMBLE THE PROGRAM BELOW AND MOVE THE
             /BINARY TO BLOCK Ø OF UNIT 10 (RFØ8 DISK).
             /TO PRESERVE BLOCK ZERO, IT MAY BE WISE TO FAKE
             /AN ENTRY IN THE INDEX OF UNIT 10 SHOWING
             /BLOCK Ø AS USED, SO THAT SOMETHING DOESNT
             /GET SAVED THERE AND DESTROY THE BOOTSTRAP.
             ITHEN,
             /TO USE:
             /TOGGLE IN THE FOLLOWING:
                      *2Ø
                               /PMODE
                      6603
                               /READ
                      5021
                               /JMP .
                      *7750
                      7577
                               /WORD COUNT-1
                      7777
                               /CORE LOC-1
             /SET MODE = PMODE
             /I/O PRESET
             ISTART 20
0020
      6623
                      DISK
                                        /THIS OVERLAYS THE 6603
                                        /AND THIS OVERLAYS THE JMP .
0021
      5020
                      JM P
                               . - 1
ØØ 22
      10 44
                               P6777
                      TAD
0023
      34 45
                               P7 75 Ø
                                        /LOAD WORD COUNT-1
                      DC A I
0024
      10 44
                      TAD
                               P6777
0025
      3446
                      DC A I
                               P7751
                                        /AND ADDRESS-1
0026
      1041
                      TAD
                               P10
ØØ 27
      6615
                                        /LOAD EXTENDED ADDRESS (FIELD 1)
                      DIML
0030
      1042
                      TAD
                               P15
                                        /THIS IS BLOCK 322 IN DISGUISE
0031
      66 43
                      DX AL
0032
      1043
                      TAD
                               P1000
                                        /...MORE OF BLOCK 322
0033
      6603
                      6603
                                        /READ
0034
      6623
                      DISK
                                        ISKIP ON DONE
ØØ35
      5034
                      JMP
                               . - 1
00 36
      6213
                      CIF CDF 10
ØØ37
      5440
                      JMP I
                               , + 1
00 40
      7777
                      7777
                                        /BOOT DIAL NOW
0041
      0010
             P10,
                      10
0042
      0015
             P15.
                      15
0043
      1000
             P1000,
                      1000
      6777
00 44
             P6777,
                      6777
0045
      7750
             P7750,
                      775Ø
                                                        page 2 of 3
      7751
0046
             P7751,
                      7751
                      DX AL = 6643
                                                    LAP6-DIAL-MS
                                                                   2
                      DIML =6615
                      DISK=6623
```

```
#20
             /RKØ8 BOOTSTRAP FOR DIAL-MS
             /COPYRIGHT 1971
             /DIGITAL EQUIPMENT CORPORATION
             /MAYNARD, MASS, Ø1754
             /FIRST, ASSEMBLE THE PROGRAM BELOW AND MOVE
             /THE BINARY TO BLOCK Ø OF UNIT 10 (RKØ8 DISK).
             /IT MAY BE WISE TO FAKE AN ENTRY IN THE INDEX
             /OF UNIT 10 TO PROTECT BLOCK 0 SO THE BOOTSTRAP
             /DOESNT GET DESTROYED.
             /TO USE:
             /TOGGLE IN THE FOLLOWING:
                      #2 Ø
                               /PMODE
             /
                      67 33
                               /READ
             /
                      5021
                               /JMP .
             /SET PMODE
             /I/O PRESET
             /START 20
             /THE PROGRAM BELOW IS ORIGINED AT #17, BUT IT ACTUALLY
             /GETS LOADED AT *20, WHICH IS WHY ALL THE REFERENCES
             /ARE OFF BY 1.
                      PMODE
                      #17
                                        /SKIP DISK DONE (OVERLAYS THE 6733)
L-17
       6745
                      DSKD
                                        /THIS IS REALLY JMP ,-1 (OVERLAYS THE JMP ,)
                      JM P
00 20
       50 20
                               ,-1+1
0021
       1040
                      TAD
                               P1 0+1
0022
      6732
                      DL DC
                                        /FIELD 1
                               P6777+1 /STARTING ADDR. -1
0023
      1041
                      TAD
0024
      6755
                      DL CA
                      TAD
                               P7000+1 /WORD COUNT
0025
      1042
      6753
0026
                      DL WC
0027
       6742
                      DCLS
      1043
                               P322 +1
0030
                      TAD
      6733
                                        /READ BLOCK 322
0031
                      DLDR
0032
       67 45
                      DS KD
                               , -1 +1
0033
      5033
                      JMP
* 6034
       6213
                      CIF CDF 10
0035
       5437
                      JMP I
                                        /BOOT DIAL NOW
                               .+1+1
0036
       77 77
                      77 77
°0037
       0010
             P10,
                      10
       6777
             P6777,
                      6777
00 40
       7000
             P7000.
                      7000
0041
0042
      0322
             P322.
                      322
                      DS KD = 6745
                      DL DC =6732
                      DL CA =6 75 5
                      DL WC =6753
                      DC LS = 6742
                                                                 page 3 of 3
                      DL DR = 6733
```

	A V		
			*
,			
			,

PDP-12 MASS SPECTROSCOPY HANDLER (MASH)

Insensitive, drifting, or erroneous calibrations

The library version of MASH should, during an automated calibration run on a standard spectrum, never have an unassigned mass (one for which no intensity peak could be found.) If one occurs, it will be due to insensitivity, drift or error (wrong spectra used; as for example, low boiling p. f. k. instead of high boiling p. f. k.)

Assuming an unassigned mass does occur in a calibration which the operator does not for some reason wish to discard, then for each unassigned mass occuring among the last 7 peaks of a run of up to 500 peaks, a line will be lost on the display.

For example, assuming 300 peaks, and 2 unassigned masses between peaks 294 and 300, then the last display would show:

PEAK#	$\underline{\mathtt{HALL}}$	INT	MASS	DEVIATION
294	96Ø	3ØØ		
295	995	4Ø5		
ango maso maso	GOOD GROW MINE	GENERAL MARKON APPROVE	58Ø	1000 VINE TO
296	1Ø31	5ØØ		
entre come entre.	***************************************	may 4000 4000	61Ø	NOTICE ADDRESS SAME
297	1732	2ØØ		
298	1917	з́ǿø	62Ø	3

There would be no way to see the values of line 299 and $3\emptyset\emptyset$ via the display.

If neccessary, a printout could be obtained, which would have all lines in it correctly, by hitting P, thus circumnavigating the problem.

			T
			÷
			ş
			k

PDP-12 MASS SPECTROSCOPY HANDLER (MASH)

Limitations in MASH

The current library version of MASH assumes a non-quadrupole mass spectrometer and a 12-bit A/D as part of its standard hardware configuration. The following patches eliminate those restrictions:

A. For a 15-bit A/D:

BLOCK	LOCATION	OLD CONTENTS	NEW CONTENTS	SOURCE
33	122	322Ø	3221	/RESCALE PEAK
	123	1214	1215	/X-Y PARA.
	134	322Ø	3221	

B. For a quadrupole mass spectrometer of the Finnegan variety:

BLOCK	LOCATION	OLD CONTENTS	NEW CONTENTS	SOURCE
6	217 22ø 221 222 223	15Ø1 2323 4Ø22 Ø116 Ø7Ø5	22Ø5 2317 1425 2411 1716	/RESOLUTION IS /NOW MASS RANGE
	315	2225	22Ø1	
21	331 332 333	2 33ØØ Ø	7776 2365 6Ø5Ø	/FINNEGAN PEAK /WIDTH CONSTANT
25	15Ø 151	5 4	4 5	/FINNEGAN RELAY /PROBLEMS
26	166 167 17Ø 171 172 173 174	Ø 73ØØ 3Ø15 115Ø 4563 2Ø15 5371 5766	- - - - -	/WAITM, Ø/WATING ON /RELAY 2 /CLA CLL /DCA 15 /TAD STSCNI /JMS I DOSCNI /ISZ 15 /JMP WAITM+3 /JMP I WAITM
27	46 176	1376 2	115Ø -	/LOAD RELAY 2
3Ø	13 175	4755 566	73ØØ -	/JMP WAITM
52	362 363	4 Ø 4 Ø	1Ø31 1752	/ELIMINATE 5Ø UNIT /MASS CHECK

			8
			*
			¥

PS/8 PIP

Copy problems with tapes produced by the Binary Punch Routine

The current version of PS/8 PIP will not copy binary tapes produced with the Binary Punch Routine (DEC-08-YX1A-PB or DEC-08-YX2A-PB). PIP detects an origin setting as the signal for an absolute binary tape. The Binary Punch Routine outputs a field setting as the first character, not an origin, thus PIP does not recognize the tape as being absolute binary.

			\$ 9
			A
			â
			*

PDP-12 AIPOS USER'S MANUAL (DEC-12-SQ1A)

Documentation correction

Page 4-1, Section 4.3 of the AIPOS User's Manual (DEC-12-SQ1A-D) states that the L R command to FOCAL-12 will cause a return to JDB Control. The is an error. The R must be followed by a comma (,). Therefore, the format should be:

LR, V

,a	
	(American)
	The second secon
	Minimum 12