


Installing and Using the
LQPX2-AA Forms Tractor



Document **AA-L663A-TK**

First Printing, January 1982

Information in this document is
subject to change without notice
and should not be construed as a
commitment by Digital Equipment
Corporation.

Copyright © 1982, Digital
Equipment Corporation


The following are trademarks of
Digital Equipment Corporation,
Maynard, Massachusetts:

DEC
DATASYSTEM
VT

digital

Contents

Instructions in this document assume your printer is installed as described in *Installing and Using the LQP02 Printer*.



Installing Forms Tractor . . . 3

- Preparing Printer 3
- Installing Forms Tractor 4




Inserting Paper 7


- Positioning Tractors 7
- Preparing Printer and
Forms Tractor 10
- Inserting Paper 11
- Removing Forms Tractor. . . . 14



Troubleshooting Forms Tractor 15










Installing Forms Tractor


Preparing Printer

- 1 Make sure power switch is OFF.




- 2 Remove access cover.







3 Pull out two cover inserts.



Installing Forms Tractor

1 Screw rear leveling pads all the way in.



2 Lower forms tractor into printer so that platen shaft fits into both slots.

Then gently push top of forms tractor backward to let clamps grasp bottom of platen shaft.




Inserting Paper


Positioning Tractors


Make sure printer power is off and access cover is removed.

- 1 Loosen left and right tractors by pressing down on locking levers.




- 2 Open front tractor gates.





- 3** Tear off one sheet of sample paper, place it in left tractor, and close gate.




- 4** Position right tractor so that pins enter holes in right side of paper, and close gate.

Make sure paper does not buckle or pull away from tractor pins.





- 5** Position tractors so that left edge of paper is aligned with left edge of platen.

Make sure paper does not buckle.




- 6** Lock both tractors in place by pressing up on levers.






- 7** Open front tractor gates and remove paper.

The tractors are now properly positioned for receiving your paper.



Preparing Printer and Forms Tractor


- 1** Set paper thickness lever for thickness of paper (forward for one sheet, progressively backward for two or more).
- 2** Slide paper edge guide to far left.
- 3** Push paper release lever all the way back (toward rear of printer).
- 4** Pull paper bail forward (toward front of printer).
- 5** Push paper tension lever all the way down.
- 6** Pull upper paper rack forward.




Inserting Paper

- 1 While turning platen knob, guide paper into both rear gates (not front gates) until tractor pins enter several holes.

Make sure bottom of paper is parallel with horizontal bars.



- 2** Turn platen knob again to advance paper around platen, and up between paper bail and platen, until it covers front tractor pins.



- 3** Place paper in front tractors and close gates.


- 4** Move upper paper rack backward.

- 5** Pull printer paper release lever forward (toward front of printer).




- 6** Slowly push up on tension lever to tighten paper.


Do not let tractor pins stretch or rip paper holes.



- 7** Turn platen knob to advance paper to top of next page or to where first line of printing will begin.

Keep the printer paper release lever in the forward position.





8 Reinstall printer access cover.

What Next?

The forms tractor is now ready for use with your system.

Turn on the printer as described in the manual shipped with your LQP02 printer.

Removing Forms Tractor

- 1** Turn platen knob to remove paper.
- 2** Remove forms tractor:
Grasp it on both sides.
Pull it forward.
Lift it out of printer.



Troubleshooting Forms Tractor

- 1** Try to correct the trouble as listed below.
- 2** If you cannot correct the trouble, contact your dealer or the nearest DIGITAL service technician.

Trouble	Probable Cause	Corrective Action
Poor line spacing	Improperly installed forms tractor	Reinstall forms tractor making sure clamps are properly positioned
Slanted print lines	Paper improperly inserted in forms tractor	Remove and replace paper
Paper buckles diagonally or pulls away from tractor pins (holes out of round)	Improperly positioned tractor	Reposition right tractor and lock in place
Paper too loose or too tight in vertical direction (holes out of round)	Improperly set paper tension lever	Reset paper tension lever

Making Your Presence Known

Complete and mail the self-addressed reader comment form on the next page.

Reader's Comments

Your comments and suggestions are welcome. They will help us in our continuous effort to improve the quality and usefulness of our publications.

1. How would you rate this manual for:

	good	fair	poor
completeness of information	_____	_____	_____
accuracy of information	_____	_____	_____
ease of use (clarity, organization)	_____	_____	_____

2. Did you find errors in this manual? Please specify by page and paragraph, or mark corrections on pages and attach copies to this form.

	page	paragraph
a) Incorrect information:	_____	_____
b) Information left out:	_____	_____
c) Hard to understand:	_____	_____

3. What suggestions do you have for improving this manual?

4. What parts of the manual were especially good at helping you understand things?

5. Please check the boxes that apply to you.

<input type="checkbox"/> Technical	<input type="checkbox"/> Used other word processors
<input type="checkbox"/> Nontechnical	<input type="checkbox"/> Used computers
<input type="checkbox"/> Management	<input type="checkbox"/> Use the word processing unit
<input type="checkbox"/> Nonmanagement	<input type="checkbox"/> yourself
<input type="checkbox"/> Other (explain)_____	

Name_____Title_____

Company_____

Street_____City_____

State_____Zip_____Date_____

— — —Do Not Tear - Fold Here and Tape — — —

digital



No Postage
Necessary
if Mailed in the
United States

BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO.33 MAYNARD MASS.

POSTAGE WILL BE PAID BY ADDRESSEE

ATTN: Commercial Engineering Publications MK1-2/E06
Office Products Documentation Group
DIGITAL EQUIPMENT CORPORATION
CONTINENTAL BOULEVARD
MERRIMACK N.H. 03054



— — —Do Not Tear - Fold Here and Tape — — —

Cut Along The Dotted Line

Paper Specifications

The LQPX2-AA forms tractor accepts single or multipart continuous paper with:

Standard 0.5 inch (12.7 mm) hole spacing

A total thickness of no more than 0.020 inch
(0.5 mm)

Widths varying from 1.75 to 15.75 inches (44.5 to
400.1 mm)

Additional Documents, Accessories and Supplies

Order additional documents, accessories and supplies
from one of the following sources.

DECdirect Catalog

DIGITAL Computer Store

Authorized DIGITAL Distributor

Local DIGITAL Sales Office

For additional documents and a copy of the DECdirect
catalog:

Write Digital Equipment Corporation
 PO Box CS2008
 Nashua, NH 03061

or

Telephone (603) 884-6660 — AK, HI, NH residents
 (800) 258-1710 — All others

