


PREPARING THE RACK AND INSTALLING THE TK50-R AND FRONT COVER

The front cover is provided with the H9302 Rackmount Kit (Figure 1-3).

If you are installing a TK50 controller module, go first to Preparing the M7547 UNIBUS Controller Module, then to Installing the M7547 UNIBUS Kit in PDP-11/44 Systems in Chapter 2, or Chapter 3 if you are installing in a VAX.

If your computer already has a TK50 controller module, go to Connecting the TK50-R or TK50-D to Host in Chapter 2, or Chapter 3 if you are installing in a VAX.



MR-15350
SHR-0390-85

Figure 1-3 Installing a TK50-R in a Rackmount Assembly