

Table 4-1 TK50 Subsystem Controls

Controls	Condition	Function
On/Off	1	Switches the subsystem on.
	0	Switches the subsystem off.
Load/Unload	In	Loads the tape (10 to 15 seconds).*
	Out	Rewinds and then unloads the tape.
Cartridge insert/release handle	Up	Unlocks the tape drive. The tape cartridge can now be inserted.
		Unlocks the tape drive to remove cartridge after rewind and unload operations.
	Down	Locks tape in position.

\* If tape is new, the system performs a calibration sequence that takes about two minutes.