

### FRONT PANEL CONTROLS AND INDICATORS

The front panel has controls and indicators for operating the TK50 tape drive. Figure 5-3 shows the layout of the control panel.


The following describes the function of the switches and indicators.

#### ON/OFF Switch

This switch connects and disconnects ac power to the internal power supply.

#### LOAD/UNLOAD Button

When this button is pushed in, the tape loads (10 to 15 seconds). This is the normal operating position. When this switch is released, the tape rewinds and then unloads.



SHR-0384-85

Figure 5-3 TK50 Controls and Indicators