



MR-15373  
SHR-0413-85

Figure 6-5 TK50-R and TK50-D Subsystem  
Groove and Channel Guide

To install a replacement tape drive, align the groove on the bottom of the tape drive with the channel guide on the chassis floor (Figure 6-5).

Reverse steps 1 through 8 of the removal procedure to install the tape drive.

#### POWER SUPPLY REMOVAL

Use the following procedure to remove the power supply.

NOTE: The power supply is a complete FRU. It is not adjustable does not have replaceable printed circuit boards.

1. Remove all cables from the TK50 subsystem.
2. Remove the rear bezel (three screws) and slide the chassis out the rear of the unit.

Remove the front bezel from rackmount units, press the quick release tab, and remove the chassis from the rack.