

INDEX

- A**
- AC connector, power supply 4-5
 - Acronyms, list of x
- B**
- Backplane 2-3, 2-4, 2-5, 2-6, 2-7
 - Backup guidelines, 4-8
 - Bulkhead 2-10
- C**
- Cable
 - controller 2-7, 3-2
 - I/O distribution panel
 - installation 2-6, 2-7, 2-8, 3-6
 - Care and handling, tape drive and tape 4-8
 - Cartridge release handle 4-1
 - using 4-9, 4-12, 4-14
 - Checklist, troubleshooting table 5-13
 - Config, software program 2-14
 - Configuration 5-9
 - address 5-10
 - rules 5-1
 - Connecting a TK50 Subsystem 2-10, 2-11
 - Connector
 - panel 2-10, 2-11
 - power supply signal and number 6-6, 6-7
 - Controller module (M7547)
 - 1-2, 1-4, 1-6, 1-7, 1-8, 2-5, 2-6, 3-2, 3-5, 5-1, 5-3, 5-4
 - Controls 4-1
 - front panel 4-2
 - table 4-3
 - CSR address 1-7, 3-4
- D**
- Digital storage architecture 5-5
- E**
- Environmental requirements 5-1, 5-5
- F**
- Fan 4-5
 - description 5-5
 - FRU procedure 6-8
 - FCC cable 2-11, 3-2, 3-11
 - Field replaceable unit
 - Front panel
 - controls and indicators 5-6
 - FRU
 - part numbers 6-1
- G**
- Grant continuity card 2-3, 3-6