

MAINDEC=11-DON

NEW NUMBER = DAKAA

T14 TRAPS

ABSTRACT

This is a test of all operation and instruction that cause traps. Also tested are trap overflow conditions, oddities of register 6, Interrupts and the reset instructions.

REQUIREMENTS

PDP=11/20, 11/05, 11/10

STORAGE = 0 = 17500

LOADING = Absolute Loader

EXECUTION TIME = Function of core size = Bell will ring

STARTING PROCEDURE

Start and Restart at	200 for a 4K System
	202 for an 8K System
	204 for a 12K System
	206 for a 16K System
	210 for a 20K System
	212 for a 24K System
	214 for a 28K System

PRINTOUTS = No

SWITCH REGISTER OPTIONS = No

This program should not be used to test 11/40 and 11/45's.