

MAINDEC-11-06D-

NEW NUMBER = DZVTA

## VT06 Display Terminal Tests

## ABSTRACT

The VT06 Display Terminal Tests consists of a package of test programs designed to test the VT06 input-output logic, the VT06 display, and the keyboard. All tests are included in one object tape. The available test programs are listed in numerical order:

- PRG0 = Combined input-output logic tests
- PRG1 = Display Test
- PRG2 = Keyboard Test
- PRG3 = Printer Exerciser
- PRG4 = Clock Adjustment Routine
- PRG5 = Clock Adjustment Routine
- PRG6 = Maintenance Mode Single Character Data Test
- PRG7 = Maintenance Mode Special Binary Count Pattern Test
- PRG17 = Roll-Up Display Test

## REQUIREMENTS

PDP-11  
 VT06 Display Terminal  
 High Speed Reader

STORAGE = 200 = 11672

LOADING = Absolute Loader

EXECUTION TIME = Depends on Program selected

STARTING PROCEDURE = Start and Restart at 200

PRINTOUTS = Yes

SWITCH REGISTER OPTIONS = Yes

- SW15 = HALT AT END OF ROUTINE
- SW14 = ENTER SCOPE MODE AFTER ERROR
- SW11 = INHIBIT ITERATION
- SW10 = LOOP PROGRAM
- SW 9 = SELECT ROUTINE
- SW 6 = 0 = NUMBER OF ROUTINE TO BE SELECTED