
MODULE NAME: CBB
REVISION LEVEL: E
MODULE TYPE: BKMOD
I.D. NUM.: 34
DEVICES TESTED: CB11 DISTRIBUTE
DEFAULT PARAMETERS: DVA-0 VCT-0 BR1-0
BR2-0 DVC-1 SR1-0
REQUIRED PARAMETERS: DVA- ADDR OF FIRST CB11 DISTRIBUTE TO BE
TESTED.
SR1- OCTAL NUMBER OF DISTRIBUTE
MODULES TO BE TESTED.
MEANING OF SR1: SR1 MUST BE SET TO OCTAL NUMBER OF
DISTRIBUTE MODULES TO BE TESTED
(MUST BE SEQUENTIAL).

MODULE NAME: CBC
REVISION LEVEL: F
MODULE TYPE: IOMOD
I.D. NUM.: 35
DEVICES TESTED: CB11-HA
DEFAULT PARAMETERS: DVA-164000 VCT-774 BR1-7
BR2-0 DVC-1 SR1-0
REQUIRED PARAMETERS: NONE
MEANING OF SR1: NONE
