


# LA36/LA35 DECwriter II User's Manual



digital

1st Printing, November 1975  
2nd Edition, February 1976

Copyright © 1975, 1976 by Digital Equipment Corporation

The material in this manual is for informational purposes and is subject to change without notice.

Digital Equipment Corporation assumes no responsibility for any errors which may appear in this manual.

Printed in U.S.A.

For additional copies of this document, specify Order No.: EK-LA3635-OP-002

The following are trademarks of Digital Equipment Corporation, Maynard, Massachusetts:

|           |              |
|-----------|--------------|
| FLIP CHIP | DECtape      |
| UNIBUS    | DECsystem-10 |
| PDP       | DECmagtape   |
| DECUS     | DIGITAL      |
| DEC       |              |

# DECWRITER II

## TABLE OF CONTENTS

|  | Page |
|--|------|
| <b>SECTION 1 LA36 USER'S INFORMATION</b>   |      |
| <b>LA36 GENERAL INFORMATION</b> . . . . .  | 1-1  |
| Introduction . . . . .   | 1-1  |
| Options . . . . .  | 1-1  |
| LA36 DECwriter Model Variations . . . . .  | 1-3  |
| LA36 Jumper Configurations . . . . .   | 1-3  |
| LA36 Specifications . . . . .  | 1-4  |
| <b>LA36 OPERATOR'S GUIDE</b> . . . . .   | 1-5  |
| LA36 Operator Controls and Indicators . . . . .  | 1-5  |
| Using the LA36 . . . . .   | 1-11 |
| <b>LA36 INSTALLATION AND CHECKOUT GUIDE</b> . . . . .                                    | 1-12 |
| General Installation Information . . . . .   | 1-12 |
| Unpacking and Repacking . . . . .  | 1-12 |
| Checkout and Acceptance Procedures . . . . .   | 1-12 |
| <b>CONTROLS AND INDICATORS FOR LA36 OPTIONS</b> . . . . .                                | 1-14 |
| Forms Control Option (LAXX-KV) . . . . .   | 1-14 |
| Forms Control, Vertical Tabulation, and Horizontal Tabulation Option (LAXX-KY) . . . . . | 1-14 |
| Scale, Pointer, and Window Option (LAXX-LN) . . . . .                                    | 1-14 |
| Acoustical Coupler Option (LAXX-LM) . . . . .  | 1-14 |
| <b>SETUP AND OPERATING PROCEDURES FOR LA36 OPTIONS</b> . . . . .                         | 1-15 |
| APL Option (LAXX-PK) . . . . .   | 1-15 |
| Forms Control Option (LAXX-KV) . . . . .   | 1-15 |
| Forms Control, Vertical Tabulation, and Horizontal Tabulation Option (LAXX-KY) . . . . . | 1-17 |
| Automatic Line Feed Option (LAXX-LA) . . . . .   | 1-18 |
| Automatic Answerback Option (LAXX-KX) . . . . .  | 1-19 |

# TABLE OF CONTENTS (Continued)

|  | Page |
|--|------|
| Selective Addressing Option (LAXX-KW) . . . . .  | 1-19 |
| Acoustical Coupler Option (LAXX-LM) . . . . .  | 1-24 |
| INSTALLATION AND CHECKOUT OF LA36 OPTION KITS . . . . .  | 1-25 |
| Introduction . . . . .   | 1-25 |
| Expander Option Mounting Kit (LAXX-LB) . . . . .   | 1-25 |
| APL Option Kit (LAXX-PK) . . . . .   | 1-26 |
| Forms Control Option Kit (LAXX-KV) . . . . .   | 1-32 |
| Forms Control, Vertical Tabulation, and Horizontal Tabulation,<br>Option Kit (LAXX-KY) . . . . . | 1-34 |
| Automatic Line Feed Option Kit (LAXX-LA) . . . . .   | 1-36 |
| Selective Addressing Option Kit (LAXX-KW) . . . . .  | 1-37 |
| Automatic Answerback Option Kit (LAXX-KX) . . . . .  | 1-40 |
| EIA Interface Option Kit (LAXX-LG) . . . . .   | 1-42 |
| 14-Key Numeric Pad Option Kit (LAXX-KE) . . . . .  | 1-42 |
| Compressed Font Option Kit (LAXX-KJ) . . . . .   | 1-44 |
| Paper Out Option Kit (LAXX-KZ) . . . . .   | 1-46 |
| 20 mA Cable Option Kit (LAXX-LH) . . . . .   | 1-49 |
| 20 mA (DEC 10) Cable Option Kit (LAXX-LK) . . . . .  | 1-49 |
| Scale, Pointer, and Window Option Kit (LAXX-LN) . . . . .  | 1-52 |
| DF11 Adaptor Kit (LAXX-KH) . . . . .   | 1-54 |
| Acoustical Coupler Option Kit (LAXX-LM) . . . . .  | 1-54 |
| <br><b>SECTION 2     LA35 USER'S INFORMATION</b>   |      |
| LA35 GENERAL INFORMATION . . . . .   | 2-1  |
| Introduction . . . . .   | 2-1  |
| Options . . . . .  | 2-1  |
| LA35 DECwriter Model Variations . . . . .  | 2-2  |
| LA35 Jumper Configurations . . . . .   | 2-2  |
| LA35 Specifications . . . . .  | 2-3  |
| LA35 OPERATOR'S GUIDE . . . . .  | 2-4  |
| LA35 Operator Controls and Indicators . . . . .  | 2-4  |
| Using the LA35 . . . . .   | 2-6  |
| LA35 INSTALLATION AND CHECKOUT GUIDE . . . . .   | 2-7  |
| General Installation Information . . . . .   | 2-7  |
| Unpacking and Repacking . . . . .  | 2-7  |
| Checkout and Acceptance Procedures . . . . .   | 2-7  |
| CONTROLS AND INDICATORS FOR LA35 OPTIONS . . . . .   | 2-9  |
| Forms Control Option (LAXX-KV) . . . . .   | 2-9  |
| Forms Control, Vertical Tabulation, and Horizontal Tabulation Option (LAXX-KY) . . . . .         | 2-9  |
| Scale, Pointer, and Window Option (LAXX-LN) . . . . .  | 2-9  |
| Acoustical Coupler Option (LAXX-LM) . . . . .  | 2-9  |
| SETUP AND OPERATING PROCEDURES FOR LA35 OPTIONS . . . . .  | 2-10 |
| APL Option (LAXX-PK) . . . . .   | 2-10 |
| Forms Control Option (LAXX-KV) . . . . .   | 2-10 |
| Forms Control, Vertical Tabulation, and Horizontal Tabulation Option (LAXX-KY) . . . . .         | 2-10 |

## TABLE OF CONTENTS (Continued)

|   | Page        |
|---|-------------|
| Automatic Line Feed Option (LAXX-LA) . . . . .  | 2-12        |
| Automatic Answerback Option (LAXX-KX) . . . . .   | 2-13        |
| Selective Addressing Option (LAXX-KW) . . . . .   | 2-13        |
| Acoustical Coupler Option (LAXX-LM) . . . . .   | 2-17        |
| <b>INSTALLATION AND CHECKOUT OF LA35 OPTION KITS . . . . .</b>                                  | <b>2-18</b> |
| Introduction . . . . .  | 2-18        |
| Expander Option Mounting Kit (LAXX-LB) . . . . .  | 2-18        |
| APL Option Kit (LAXX-PK) . . . . .  | 2-21        |
| Forms Control Option Kit (LAXX-KV) . . . . .  | 2-21        |
| Forms Control, Vertical Tabulation, and Horizontal Tabulation<br>Option Kit (LAXX-KY) . . . . . | 2-24        |
| Automatic Line Feed Option Kit (LAXX-LA) . . . . .  | 2-27        |
| Selective Addressing Option Kit (LAXX-KW) . . . . .   | 2-27        |
| Automatic Answerback Option Kit (LAXX-KX) . . . . .   | 2-30        |
| EIA Interface Option Kit (LAXX-LG) . . . . .  | 2-32        |
| Compressed Font Option Kit (LAXX-KJ) . . . . .  | 2-32        |
| 20 mA Cable Option Kit (LAXX-LH) . . . . .  | 2-36        |
| 20 mA (DEC 10) Cable Option Kit (LAXX-LK) . . . . .   | 2-36        |
| Scale, Pointer, and Window Option Kit (LAXX-LN) . . . . .                                       | 2-39        |
| DF11 Adaptor Kit (LAXX-KH) . . . . .  | 2-41        |
| Acoustical Coupler Option Kit (LAXX-LM) . . . . .   | 2-41        |
| <br><b>SECTION 3     COMMON INFORMATION</b>   |             |
| <b>LOADING PAPER AND CHANGING THE RIBBON . . . . .</b>  | <b>3-1</b>  |
| Loading Paper . . . . .   | 3-1         |
| Loading New Forms . . . . .   | 3-1         |
| Paper Positioning Procedure . . . . .   | 3-1         |
| Impression Adjustment . . . . .   | 3-4         |
| Horizontal Positioning Adjustment . . . . .   | 3-5         |
| Fine Vertical Positioning . . . . .   | 3-5         |
| Reloading Paper . . . . .   | 3-6         |
| Ribbon Installation . . . . .   | 3-7         |
| <b>DECwriter Interface Information . . . . .</b>  | <b>3-10</b> |
| Interface Description . . . . .   | 3-10        |
| Interface Specifications . . . . .  | 3-10        |
| <b>PROGRAMMER'S GUIDE . . . . .</b>   | <b>3-11</b> |
| LA36 Programmer's Information . . . . .   | 3-11        |
| Transmitting Characters and Commands . . . . .  | 3-11        |
| Special Command Keys . . . . .  | 3-11        |
| Receiving Characters and Commands . . . . .   | 3-11        |
| <b>OPERATOR CARE, PACKING, AND REPACKING . . . . .</b>  | <b>3-16</b> |
| Operator Care . . . . .   | 3-16        |
| Unpacking and Inspection . . . . .  | 3-16        |
| Packing Procedure . . . . .   | 3-18        |
| <b>TROUBLESHOOTING GUIDE . . . . .</b>  | <b>3-19</b> |