




Load Module Instructions

EK-ASIPP-AD. A01

August 1996

Description

The 2T-LDMOD-AA load module ensures that there is a minimum load on the power supply in the Dialogic Telco Platform. If there are two or more ISA bus modules installed in the DTP chassis, the load module is not required and can be removed from the DTP chassis.



MLO-013548

Installation

The 2T-LDMOD-AA load module is typically installed in slot ten (10). If the DTP chassis is ordered with two or more ISA bus modules, the load module need not be installed in the DTP chassis.

Digital Equipment Corporation makes no representations that the use of its products in the manner described in this publication will not infringe on existing or future patent rights, nor do the descriptions contained in this publication imply the granting of licenses to make, use, or sell equipment or software in accordance with the description.

The following are trademarks of Digital Equipment Corporation: DEC, Digital and the DIGITAL logo.

© Digital Equipment Corporation 1996. All rights reserved.

