


MicroVAX 3500
VAXserver 3500

digital™



Addenda to MicroVAX 3500 VAXserver 3500 Customer Hardware Information

Order Number EK-226AA-AD-001

This documentation supplements information in your Customer Hardware Information by describing the differences between the MicroVAX 3500 and VAXserver 3500 systems and the rtVAX 3500 system.

This documentation has three parts: *Addendum to Installation*, *Addendum to Operation*, and *Addendum to Technical Information*. Please add this documentation to your Customer Hardware Information binder.

**digital equipment corporation
maynard, massachusetts**

June 1988

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation.

Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software, if any, described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license. No responsibility is assumed for the use or reliability of software or equipment that is not supplied by Digital Equipment Corporation or its affiliated companies.

Copyright ©1988 by Digital Equipment Corporation.

All Rights Reserved.
Printed in U.S.A.

The READER'S COMMENTS form on the last page of this document requests the user's critical evaluation to assist in preparing future documentation.

The following are trademarks of Digital Equipment Corporation:

DEC	IAS	VAXcluster
DEC/CMS	MASSBUS	VAXELN
DEC/MMS	MicroVAX 3500	VAXserver 3500
DECnet	PDP	VMS
DECsystem-10	PDT	VT
DECSYSTEM-20	RSTS	
DECUS	RSX	
DECwriter	rtVAX 3500	
DIBOL	UNIBUS	
EduSystem	VAX	



FCC NOTICE: The equipment described in this manual generates, uses, and may emit radio frequency energy. The equipment has been type tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such radio frequency interference when operated in a commercial environment. Operation of this equipment in a residential area may cause interference, in which case the user at his own expense may be required to take measures to correct the interference.

Addendum to Installation

This addendum contains information about installing the rtVAX 3500.

About the rtVAX 3500

The rtVAX 3500 is a real-time system that uses the KA650-BA central processing unit and the VAXELN operating system.

Installing the rtVAX 3500

The base model rtVAX 3500 is diskless. If you are installing the diskless rtVAX 3500, disregard all references to disk drives and tape drives in this installation guide. Disk drives and tape drives are available as options for this system. See *Technical Information* in your hardware information kit for more information about options.

Addendum to Operation

This addendum contains information about operating the rtVAX 3500.

About the rtVAX 3500

The rtVAX 3500 is a real-time system that uses the KA650-BA central processing unit and the VAXELN operating system.

Operating the rtVAX 3500

The base model rtVAX 3500 is diskless. If you are operating the diskless system, disregard all references to disk drives and tape drives in this operation guide. Disk drives and tape drives are available as options for this system. See *Technical Information* in your hardware information kit for more information about options.

Addendum to Technical Information

This addendum contains technical information for the rtVAX 3500.

About the rtVAX 3500

The rtVAX 3500 is a real-time system that uses the KA650-BA central processing unit and the VAXELN operating system.

Options

The base model rtVAX 3500 is diskless; however, mass storage options are available for this system. See Chapter 2 of *Technical Information* in your hardware information kit for more information about options.

NOTE: *The rtVAX 3500 is designed for use as a single-user system. Some of the devices described in this guide are designed for use in multi-user environments and may not be suitable for an rtVAX 3500. Contact your Digital representative if you have any questions about whether use of a specific device is appropriate for your rtVAX 3500 system.*



digital