

DUP11

CONFIDENCE TST
CZDPECO

AH-8589C-MC
FICHE 1 OF 1

OCT 1983
COPYRIGHT © 74-83
MADE IN USA



CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 8
CZDPEC.P11 19-JUL-83 17:09

.REM @

IDENTIFICATION

PRODUCT CODE: AC-8588C-MC
PRODUCT NAME: CZDPEC0 DUP11 CONFIDENCE TST
DATE: JUNE 1983
MAINTAINER: MK-DIAGNOSTICS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1974, 1979, 1983 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL
DEC

PDP
DECUS

UNIBUS
DECTAPE

MASSBUS

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 9
CZDPEC.P11 19-JUL-83 17:09

1.0 ABSTRACT

THE FUNCTION OF THE PROGRAM IS TO PROVIDE A LEVEL OF CONFIDENCE IN THE OPERATION OF THE DUP-11 WITHOUT CHANGING JUMPERS OR SWITCHES FROM CUSTOMER CONFIGURATION.

THE OPTION IS TESTED IN SDLC MODE (BIT-STUFFING), THEN IN DEC MODE USING A SIMULATED DDCMP-LINE PROTOCOL WITH AN IMBEDDED CRC CHARACTER. BOTH OF THESE MODES WILL BE TESTED OVER A CABLE IF A TURNAROUND IS POSSIBLE.

THE MODEM CONTROL LEADS WILL ALSO BE TESTED, IF THE H325 TURN-AROUND CONNECTOR IS USED. THE DETERMINATION OF WHAT WILL BE TESTED IS DONE BY ANSWERING A 'PARAMETER DIALOG' (LOAD ADDRESS 200, START ADDRESS 0 OR 1.) ALL QUESTIONS MUST BE ANSWERED. IF AN ERROR SHOULD OCCUR, A TYPEOUT WILL EXPLAIN THE FUNCTIONAL AREA OF THE DEVICE WHICH FAILED. TO REPAIR THE OPTION, THE DIAGNOSTICS WILL HAVE TO BE RUN.

ADDITIONALLY THE MODEM DATA LEADS MAY NOW BE TESTED IF A MODEM HAS THE ANALOG LOOPBACK FEATURE ENABLED.

CURRENTLY THERE ARE THREE OFF-LINE DIAGNOSTICS THAT ARE TO BE RUN IN SEQUENCE TO ENSURE THAT IF AN ERROR SHOULD OCCUR IT WILL BE DETECTED AT AN EARLY STAGE AND ESTABLISH THAT DIAGNOSIS OF THE ERROR WILL BE IMMEDIATE TO DISCOVERING THE PROBLEM.

NOTE: ADDITIONAL DIAGNOSTICS MAY BE ADDED IN THE FUTURE.

THE THREE DIAGNOSTICS ARE:

- 1.1 CZDPB [REV] BASIC AND OFFLINE TRANSMITTER TESTS.
- 1.2 CZDPC [REV] OFFLINE RECEIVER TESTS, MODEM CONTROL AND INTERRUPT TESTS
- 1.3 CZDPD [REV] OFFLINE SDLC DATA AND FUNCTION OFFLINE DECODE DATA AND FUNCTION TESTS
- 1.4 CZDPO [REV] DP11 OVERLAY FOR INTERPROCESSOR TEST PROGRAM

NOTE: THE FOURTH TAPE IS:

- 1.5 CZDPE [REV] THIS CONFIDENCE TEST.

NOTE

CZDPE WILL ONLY TEST ONE DUP11 AT A TIME. IF TESTING OF ANOTHER DUP11 IS DESIRED, RESTART AT 200 AND ENTER NEW PARAMETERS.

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 10
 CZDPEC.P11 19-JUL-83 17:09

2.0 REQUIREMENTS

2.1 EQUIPMENT

- 2.1.1. ANY PDP11 FAMILY CPU (WITH MINIMUM 4K MEMORY)
- 2.1.2. ASR 33 (OR EQUIVALENT)
- 2.1.3. DUP11
- 2.1.4. H325 TEST CONNECTOR
- 2.1.5. MODEM WITH ANALOG LOOPBACK FEATURE

2.2 STORAGE

PROGRAM WILL USE ALL 4K OF MEMORY EXCEPT WHERE ABS AND BOOTSTRAP LOADER RESIDE. LOCATION 1500 THRU 1560 ARE ESPECIALLY TO BE NOTED AND LEFT UNTOUCHED BY THE OPERATOR AFTER THE DUP11 PARAMETER DIALOG HAS BEEN EXECUTED OR AFTER THE DEFAULT SETUP HAS BEEN DONE.

3.0 LOADING PROCEDURE

3.1 METHOD

ALL PROGRAMS ARE IN ABSOLUTE FORMAT AND ARE LOADED USING THE ABSOLUTE LOADER. NOTE: IF THE DIAGNOSTICS ARE ON A MEDIA SUCH AS DISK, MAGTAPE, DECTAPE, OR CASSETTE FOLLOW INSTRUCTIONS FOR THE MONITOR WHICH HAS BEEN PROVIDED ON THAT SPECIFIC MEDIA.

ABSOLUTE LOADER STARTING ADDRESS = **500

MEMORY	SIZE
	(*)=
4K	17
8K	37
12K	57
16K	77
20K	117
24K	137
28K	157

- 3.1.1 PLACE ADDRESS OF ABS LOADER INTO SWITCH REGISTER. (ALSO PLACE 'HALT' SW UP)
- 3.1.2 DEPRESS 'LOAD ADDRESS' KEY ON CONSOLE AND RELEASE.
- 3.1.3 DEPRESS 'START KEY' ON CONSOLE AND RELEASE (PROGRAM SHOULD NOW BE LOADING INTO CPU)

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 11
 CZDPEC.P11 19-JUL-83 17:09

4.0 STARTING PROCEEDURE

- A. SET SWITCH REGISTER TO 000200
- B. DEPRESS 'LOAD ADDRESS' KEY AND RELEASE
- C. LEAVE SWR BIT 7=1 TO USE EXISTING PARAMETERS PREVIOUSLY SET UP BY THE DUP11 PARAMETER DIALOG. WHENEVER PROGRAM IS STARTED AT ADR 200 WITH SWR BIT7=0, NEW PARAMETERS MUST BE LOADED.

'EXAMPLE'

'MAP OF DUP11 STATUS'

1500	160050	CSR OF DUP11
1502	000300	VECTOR OF DUP11

THE ABOVE IS ONLY AN EXAMPLE! THIS WOULD INDICATE THE STATUS TABLE STARTING AT ADDRESS 1500 IN THE PROGRAM. THE STATUS TABLE MUST BE VERIFIED BY THE USER.

IT IS POSSIBLE FOR THE OPERATOR TO MANUALLY CHANGE (TOGGLE IN) THE INFORMATION IN THE MAP TO SUIT A SPECIFIC CONFIGURATION, BUT THE RESPONSIBILITY FOR VERIFYING THAT INFORMATION RESTS WITH THE OPERATOR.

THE PROGRAM WILL TYPE 'R' AND PROCEED TO RUN THE MAINDEC

4.1 CONTROL SWITCH SETTINGS

SW 15	SET:	HALT ON ERROR
SW 14	SET:	LOOP ON CURRENT TEST
SW 13	SET:	INHIBIT ERROR PRINT OUT
SW 12	SET:	INHIBIT TYPE OUT/BELL ON ERROR.
SW 11	SET:	INHIBIT ITERATIONS. (QUICK PASS)
SW 10	SET:	ESCAPE TO NEXT TEST ON ERROR
SW 09	SET:	RESERVED
SW 08	SET:	CATCH ERROR AND LOOP ON IT
SW 07	SET:	USE PREVIOUS STATUS TABLE.
SW 06	SET:	RESERVED
SW 05	SET:	RESERVED
SW 04	SET:	RESERVED
SW 03	SET:	RESERVED
SW 02	SET:	LOCK ON SELECTED TEST
SW 01	SET:	RESTART PROGRAM AT SELECTED TEST
SW 00	SET:	RESERVED

 SWITCHES 8 THROUGH 15 ARE DYNAMIC AND SHOULD BE USED AS NEEDED IN THE DIAGNOSTIC. SWITCHES 0 THROUGH 2 ARE STATIC (ONLY ARE OPERABLE WHEN THE MONITOR PORTION OF THE TAPE IS RUNNING) AND SHOULD BE SET UP PRIOR TO STARTING OR RESTARTING THE

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 12
 CZDPEC.P11 19-JUL-83 17:09

DIAGNOSTIC.

4.1.2 SWITCH REGISTER RESTRICTIONS

SW 01 RESTART PROGRAM AT SELECTED TEST. IT IS STRONGLY SUGGESTED THAT AT LEAST ONE PASS HAS BEEN MADE BEFORE TRYING TO SELECT A TEST THAT IS NOT IN THE ORDER OF SEQUENCE. THE REASON FOR THIS IS THAT THE PROGRAM HAS TO CLEAR AREAS AND SET UP PARAMETERS IN THE MONITOR PORTION OF THE PROGRAM. IT IS POSSIBLE TO LD200, AND RAISE SW01, THEN START, PROVIDED PARAMETERS HAVE BEEN PREVIOUSLY SET UP AS DESCRIBED IN SECTION 4.0. ALSO, WHEN A TEST IS SELECTED, ALWAYS START AT THE VERY BEGINNING OF THAT TEST.

4.1.3 SWITCH REGISTER PRIORITIES

A) ERROR SWITCHES

1. SW 12 DELETE PRINT OUT/BELL ON ERROR.
2. SW 13 DELETE ERROR PRINTOUT.
3. SW 15 HALT ON THE ERROR.
4. SW 08 GOTO BEGINNING OF THE TEST(ON ERROR).
5. SW 10 GOTO NEXT TEST(ON ERROR).

B) SCOPE SWITCHES

1. SW 14 - LOOP ON TEST. WILL LOOP ON TEST UNTIL SWITCH IS LOWERED.
2. SW 11 - INHIBIT ITERATIONS (QUICK PASS). ALLOWS ONLY ONE PASS THROUGH A TEST.

4.2 STARTING ADDRESS

STARTING ADDRESS IS AT 000200. THERE ARE NO OTHER STARTING ADDRESSES FOR THE DUP11 DIAGNOSTICS OR THIS EXERCISER.

NOTE: IF ADDRESS 000042 IS NON-ZERO THE PROGRAM ASSUMES IT IS UNDER ACT11 OR XXDP CONTROL AND WILL ACT ACCORDINGLY. AFTER DUP11 IS TESTED, THE PROGRAM WILL RETURN TO 'XXDP' OR 'ACT-11'. ALSO, UNDER 'ACT11' OR 'XXDP' CONTROL THE FOLLOWING DEFAULT PARAMETERS ARE ASSUMED:

4.2.1. ALL JUMPERS ARE ASSUMED TO BE IN THE FOLLOWING CONFIGURATION:

		IN	OUT
		--	---
W1 =	SEC REC ENABLE	X	
W2 =	SEC REC DISABLE		X
W3 =	CLEAR OPTION	X	
W4 =	SEE TX ENABLE	X	
W5 =	DSC A CONTROL		X
W6 =	A+B DS CONTROL	X	

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 13
CZDPEC.P11 19-JUL-83 17:09

W7 = BUS GRANT CONTROL X

4.2.2. H325 TEST CONNECTOR IS ASSUMED TO BE ON.

4.2.3. THE MANUFACTURING OPTION CSR 160050 AND
VECTOR OF 770 ARE USED.

4.2.4. THE BR LEVEL IS ASSUMED TO BE 5.

5.0 OPERATING PROCEDURE

WHEN THE PROGRAM IS INITIALLY STARTED MESSAGES AS DESCRIBED IN
SECTION FOUR WILL BE PRINTED AND PROGRAM WILL BEGIN RUNNING
THE DIAGNOSTIC.

5.1 PROGRAM AND/OR OPERATOR ACTION

THE TYPICAL APPROACH SHOULD BE

1. HALT ON ERROR (VIA SW 15=1) WHENEVER AN ERROR OCCURS.
2. CLEAR SW 15.

THE TEST NUMBER AND PC WILL BE TYPED OUT AND POSSIBLY AN
ERROR MESSAGE (THIS DEPENDS ON THE TEST), TO GIVE THE OPERATOR
AN IDEA AS TO THE SOURCE OF THE PROBLEM. IF IT IS NECESSARY
TO KNOW MORE INFORMATION CONCERNING THE ERROR REPORT, LOOK IN
THE LISTING FOR THAT TEST NUMBER WHICH WAS TYPED OUT AND THEN
NOTE THE PC OF THE ERROR REPORT. IN THIS WAY THE EXACT
FUNCTIONING OF THE TEST CAN BE INTERPRETED SINCE THE ERROR PC
IS THE HLT+2 LOCATION.

AT THIS POINT IT IS RECOMMENDED THAT THE NORMAL DIAGNOSTICS BE
RUN TO ISOLATE THE ERROR CONDITION.

6.0 ERRORS

AS DESCRIBED PREVIOUSLY THERE WILL ALWAYS BE A TEST NUMBER AND
PC TYPED OUT AT THE TIME OF AN ERROR (PROVIDING SW 13=0 AND SW
12=0). ADDITIONAL INFORMATION WILL BE SUPPLIED TO THE ERROR
MESSAGE WHICH IS TO GIVE THE OPERATOR AN INDICATION OF THE
ERROR.

6.1 ERROR RECOVERY

IF FOR SOME REASON THE DUP11 SHOULD 'HANG THE BUS' (GAIN
CONTROL OF BUS SO THAT CONSOLE MANUAL FUNCTIONS ARE INHIBITED)
AN INIT OR POWER DOWN/UP IS NECESSARY FOR OPERATOR TO REGAIN
CONTROL OF CPU. IF THIS SHOULD HAPPEN LOOK IN LOCATION
'TSTNO' FOR THE NUMBER OF THE TEST THAT WAS RUNNING AT THE
TIME OF THE CATASTROPHIC ERROR. THIS GIVES THE OPERATOR SOME
IDEA AS TO WHAT THE DUP11 WAS DOING AT THE TIME OF THE ERROR.

7.0 RESTRICTIONS

CZDP1 MACY11 30A(1052) 20-JUL-83 13:32 PAGE 14
CZDPEL.P11 19-JUL-83 17:09

7.1 STARTING RESTRICTIONS

SEE SECTION 4 (PLEASE). STATUS TABLE SHOULD BE VERIFIED REGARDLESS OF HOW THE PROGRAM WAS STARTED.

7.2 OPERATING RESTRICTIONS

DUP11 PARAMETER DIALOG MUST BE ANSWERED BEFORE RUNNING THIS PROGRAM.

1. ANSWER THE COMPLETE PARAMETER DIALOG AGAIN.
2. TOGGLE IN THE NEW CSR AT 1500 AND THE VECTOR AT 1502, THEN RESTART THE PROGRAM WITH SW07=1.

8.0 MISCELLANEOUS

8.1 EXECUTION TIME

ALL DUP11 DEVICE DIAGNOSTICS WILL GIVE AN 'END PASS' MESSAGE (PROVIDING NO ERRORS AND SW12=0) WITHIN 4 MINS. THIS IS ASSUMING SW11=1 (DELETE ITERATIONS) IS SET TO GIVE THE FASTEST POSSIBLE EXECUTION. THE ACTUAL EXECUTION TIME DEPENDS GREATLY ON THE PDP11 CPU CONFIGURATION.

8.2 PASS COMPLETE

NOTE: *EVERY* TIME THE PROGRAM IS STARTED, THE TESTS WILL RUN AS IF SW11 (DELETE ITERATIONS) WAS UP (=1). THIS IS TO VERIFY NO *HARD* ERRORS AS SOON AS POSSIBLE. THEREFORE THE FIRST PASS--EACH TIME PROGRAM IS STARTED--WILL BE A 'QUICK PASS' UNTIL ALL DUP11'S IN SYSTEM ARE TESTED. WHEN THE DIAGNOSTIC HAS COMPLETED A PASS WITH THE NORMAL ITERATION COUNT (ICOUNT=50), THE FOLLOWING IS AN EXAMPLE OF THE PRINT OUT TO BE EXPECTED.

END PASS CZDPB? CSR:160050 VEC:300 PASSES:000001 ERRORS:000000

NOTE: THE NUMBERS FOR CSR AND VEC ARE NOT NECESSARILY THE VALUES FOR THE DEVICE. THEY ARE ONLY FOR THIS EXAMPLE.

8.3 KEY LOCATIONS

RETURN	CONTAINS THE ADDRESS WHERE PROGRAM WILL RETURN WHEN ITERATION COUNT IS REACHED OR IF LOOP ON TEST IS ASSERTED.
NEXT	CONTAINS THE ADDRESS OF THE NEXT TEST TO BE PERFORMED.
TSTNO	CONTAINS THE NUMBER OF THE TEST NOW BEING PERFORMED.

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 15
CZDPEC.P11 19-JUL-83 17:09

****NOTE****

IT SHOULD BE REMEMBERED THAT CZDPE IS NOT A DIAGNOSTIC , BUT
IT IS A CONFIDENCE TEST DESIGNED TO EVALUATE ONLY THAT THE
DEVICE IS OPERATIONAL. IF THERE IS A FAILURE, THE DUP11 DAGNOSTICS
WILL HAVE TO BE RUN FOR SPECIFIC FAULT DETECTION.

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 17
 CZDPEC.P11 19-JUL-83 17:09 INTRODUCTION TO DUP11 DIAGNOSTIC

389
 390
 391
 392
 393
 394
 395
 396
 397
 398
 399
 400
 401
 402
 403
 404
 405
 406
 407
 408
 409
 410
 411
 412
 413
 414
 415
 416
 417
 418
 419
 420
 421
 422

;*CZDPECO /<377>/DUP11 CONFIDENCE TST
 ;*COPYRIGHT 1975, DIGITAL EQUIPMENT CORP., MAYNARD, MASS. 01754
 ;*-----

;STARTING PROCEDURE
 ;LOAD PROGRAM
 ;LOAD ADDRESS 000200
 ;PRESS START
 ;PROGRAM WILL TYPE "CZDPECO /<377>/DUP11 CONFIDENCE TST "
 ;PROGRAM WILL TYPE "R" TO INDICATE THAT TESTING HAS STARTED
 ;AT THE END OF A PASS, PROGRAM WILL TYPE PASS COMPLETE MESSAGE
 ;AND THEN RESUME TESTING

;SWITCH REGISTER OPTIONS
 ;-----

100000
 040000
 020000
 010000
 004000
 002000
 001000
 000400
 000200
 000100
 000040
 000020
 000010

 000004
 000002
 000001

SW15=100000
 SW14=40000
 SW13=20000
 SW12=10000
 SW11=4000
 SW10=2000
 SW09=1000
 SW08=400
 SW07=200
 SW06=100
 SW05=40
 SW04=20
 SW03=10

 SW02=4
 SW01=2
 SW00=1

;=1,HALT ON ERROR
 ;=1,LOOP ON CURRENT TEST
 ;=1,INHIBIT ERROR TYPEOUT
 ;=1,DELETE TYPEOUT/BELL ON ERROR.
 ;=1,INHIBIT ITERATIONS
 ;=1,ESCAPE TO NEXT TEST ON ERROR
 ;=1,LOOP WITH CURRENT DATA
 ;=1,LOOP ON ERROR

;SELECT DUP'S DESIRED ACTIVE
 ;NOTE:THIS MUST NOT EXCEED ORIGINAL COUNT
 ;LOCK ON TEST SELECT
 ;RESTART PROGRAM AT SELECTED TEST
 ;ENTER PARAMETERS

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 18
 CZDPEC.P11 19-JUL-83 17:09 GENERAL DEFINITIONS AND EQUIVALENCIES

```

423
424
425      ;REGISTER DEFINITIONS
426      ;-----
427
428      000000      R0=%0      ;GENERAL REGISTER
429      000001      R1=%1      ;GENERAL REGISTER
430      000002      R2=%2      ;GENERAL REGISTER
431      000003      R3=%3      ;GENERAL REGISTER
432      000004      R4=%4      ;GENERAL REGISTER
433      000005      R5=%5      ;GENERAL REGISTER
434      000006      SP=%6      ;PROCESSOR STACK POINTER
435      000007      PC=%7      ;PROGRAM COUNTER
436
437      ;LOCATION EQUIVALENCIES
438      ;-----
439
440      177776      PS=177776    ;PROCESSOR STATUS WORD
441      001150      STACK=1150  ;START OF PROCESSOR STACK
442
443      ;INSTRUCTION DEFINITIONS
444      ;-----
445
446      005746      PUSH1SP=5746 ;DECREMENT PROCESSOR STACK 1 WORD
447      005726      POP1SP=5726  ;INCREMENT PROCESSOR STACK 1 WORD
448      010046      PUSHRO=10046  ;SAVE R0 ON STACK
449      012600      POPRO=12600   ;RESTORE R0 FROM STACK
450      024646      PUSH2SP=24646 ;DECREMENT STACK TWICE
451      022626      POP2SP=22626  ;INCREMENT STACK TWICE
452      .EQUIV EMT,HLT ;BASIC DEFINITION OF ERROR CALL
453
454      100000      BIT15=100000
455      040000      BIT14=40000
456      020000      BIT13=20000
457      010000      BIT12=10000
458      004000      BIT11=4000
459      002000      BIT10=2000
460      001000      BIT9=1000
461      000400      BIT8=400
462      000200      BIT7=200
463      000100      BIT6=100
464      000040      BIT5=40
465      000020      BIT4=20
466      000010      BIT3=10
467      000004      BIT2=4
468      000002      BIT1=2
469      000001      BIT0=1
470
471

```

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 19
 CZDPEC.P11 19-JUL-83 17:09 TRAPCATCHER FOR UNEXPECTED INTERRUPTS

```

472 ;*****
473 ;-----
474 ;TRAPCATCHER FOR ILLEGAL INTERRUPTS
475 ;THE STANDARD 'TRAP CATCHER' IS PLACED
476 ;BETWEEN ADDRESS 0 TO ADDRESS 776.
477 ;IT LOOKS LIKE 'PC+2 HALT'.
478 ;-----
479 ;*****
480
481      000000      . = 0
482      ;STANDARD INTERRUPT VECTORS
483      ;-----
484
485      . = 24
486      000024      004312      .PFAIL      ;POWER FAIL HANDLER
487      000026      000340      340          ;SERVICE AT LEVEL 7
488      000030      003730      .HLT          ;ERROR HANDLER
489      000032      000340      340          ;SERVICE AT LEVEL 7
490      000034      003676      .TRPSRV       ;GENERAL HANDLER DISPATCH SERVICE
491      000036      000340      340          ;SERVICE AT LEVEL 7
492
493      . = 40
494      000040      000000      0            ;SAVE FOR ACT-11 OR DDP2
495      000042      000000      0            ;RETURN ADDRESS IF UNDER ACT-11 OR DDP2
496      000044      000000      0            ;SAVE FOR ACT-11 OR DDP2
497      000046      002464      SENDAD        ;FOR USE WITH ACT-11 OR DDP2
498      000052      000000      . = 52
499
500      . = 174
501      000174      000000      DISPREG:      0      ;SOFTWARE DISPLAY REGISTER
502      000176      000000      SWREG: 0      ;SOFTWARE SWITCH REGISTER
503      . = 200
504      000200      000137      001510      JMP      .START      ;GO TO START OF PROGRAM
505
506
507      . = 1000
508      001000      005377      055103      050104      MTITLE: .ASCIZ <377><12>/CZDPEC0 /<377>/DUP11 CONFIDENCE TST /<377>
509      001200
510      . = 1200
511      ;SWR AND LIGHTS
512      ;-----
513      001200      177570      DISPLAY:      177570      ;11/45 CONSOLE LIGHTS
514      001202      177570      SWR: 177570      ;INDIRECT POINTER TO SWITCH REGISTER
515
516      ;INDIRECT POINTERS TO TELETYPE VECTORS AND REGISTERS
517      ;-----
518
519      001204      177560      TKCSR: 177560      ;TELETYPE KEYBOARD CONTROL REGISTER
520      001206      177562      TKDBR: 177562      ;TELETYPE KEYBOARD DATA BUFFER
521      001210      177564      TPCSR: 177564      ;TELEPRINTER CONTROL REGISTER
522      001212      177566      TPDBR: 177566      ;TELEPRINTER DATA BUFFER
523
524      ;PROGRAM CONTROL PARAMETERS
525      ;-----
526

```


CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 20
 CZDPEC.P11 19-JUL-83 17:09

PROGRAM PARAMETERS, VARIABLES, AND TRAP CALLS.

527	001214	000000	RETURN: 0	:SCOPE ADDRESS FOR LOOP ON TEST
528	001216	000000	NEXT: 0	:ADDRESS OF NEXT TEST TO BE EXECUTED
529	001220	000000	LOCK: 0	:ADDRESS FOR LOCK ON CURRENT DATA
530	001222	000001	ICOUNT: 1	:NUMBER OF ITERATIONS THAT CURRENT TEST WILL BE EXECUTED
531	001224	000000	LPCNT: 0	:NUMBER OF ITERATIONS COMPLETED
532	001226	000000	TSTNO: 0	:NUMBER OF TEST IN PROGRESS
533	001230	000000	PASCNT: 0	:NUMBER OF PASSES COMPLETED
534	001232	000000	ERRCNT: 0	:TOTAL NUMBER OF ERRORS
535	001234	000000	LSTERR: 0	:PC OF LAST ERROR CALL
536			:PROGRAM VARIABLES	
537			:-----	
538				
539	001236	000000	TEMP1: 0	:TEMPORARY STORAGE
540	001240	000000	TEMP2: 0	:TEMPORARY STORAGE
541	001242	000000	TEMP3: 0	:TEMPORARY STORAGE
542	001244	000000	TEMP4: 0	:TEMPORARY STORAGE
543	001246	000000	TEMP5: 0	:TEMPORARY STORAGE
544	001250	000000	SAVR0: 0	:R0 STORAGE
545	001252	000000	SAVR1: 0	:R1 STORAGE
546	001254	000000	SAVR2: 0	:R2 STORAGE
547	001256	000000	SAVR3: 0	:R3 STORAGE
548	001260	000000	SAVR4: 0	:R4 STORAGE
549	001262	000000	SAVR5: 0	:R5 STORAGE
550	001264	000000	SAVSP: 0	:STACK POINTER STORAGE
551	001266	000000	SAVPC: 0	:PROGRAM COUNTER STORAGE
552				
553	001270	000000	SAVR0A: 0	:R0 STORAGE
554	001272	000000	SAVR1A: 0	:R1 STORAGE
555	001274	000000	SAVR2A: 0	:R2 STORAGE
556	001276	000000	SAVR3A: 0	:R3 STORAGE
557	001300	000000	SAVR4A: 0	:R4 STORAGE
558	001302	000000	SAVR5A: 0	:R5 STORAGE
559	001304	000000	SAVSPA: 0	:STACK POINTER STORAGE
560	001306	000000	SAVPCA: 0	:PROGRAM COUNTER STORAGE
561				
562	001310	000005	REPEAT: 5	:REPEAT CTSDLY
563	001312	177777	CTSDLY: -1	:CTS DELAY
564	001314	100000	DELAY: 100000	:DELAY FOR DATA LEAD TESTS
565	001316	000001	DUPACTV: .BLKB 1	:DUP11'S SELECTED ACTIVE.
566	001317	000001	DUPNUM: .BLKB 1	:OCTAL NUMBER OF DUP11'S.
567	001320	000001	SAVNUM: .BLKB 1	:WORKABLE NUMBER.
568		001322	.EVEN	

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 21
 CZDPEC.P11 19-JUL-83 17:09 PROGRAM PARAMETERS, VARIABLES, AND TRAP CALLS.

```

569
570                                     :CONTROL REGISTER DEFINITIONS
571                                     :-----
572                                     :RXCSR BIT DEFINITIONS
573      100000      DSCA=BIT15      :DATA SET CHANGE A
574      040000      RING=BIT14      :RING
575      020000      CTS=BIT13       :CLR TO SEND
576      010000      CARDET=BIT12    :CARRIER DETECT
577      004000      RECACT=BIT11    :REC ACTIVE
578      002000      SRD=BIT10       :SEC REC DATA
579      001000      DSR=BIT9        :DATA SET RDY
580      000400      STPSYN=BIT8     :STRIP SYNC
581      000200      RXDONE=BIT7     :REC DONE
582      000100      RINTEN=BIT6     :REC INTR ENABLE
583      000040      DSINTE=BIT5     :DSC INTR ENABLE
584      000020      RCVEN=BIT4      :REC ENABLE
585      000010      STD=BIT3        :SEC XMIT DATA
586      000004      RTS=BIT2        :REQ TO SEND
587      000002      DTR=BIT1       :DATA TERM RDY
588      000001      DSCB=BIT0       :DATA SET CHANGE B
589                                     :RXDBUF BIT DEFINITIONS
590      100000      RXDERR=BIT15     :REC DATA ERROR
591      040000      OVRUN=BIT14     :OVERRUN ERROR
592      010000      CRCERR=BIT12    :CRC ERROR
593      002000      RABORT=BIT10    :REC ABORT
594      001000      REOM=BIT9       :REC END OF MESSAGE
595      000400      RSOM=BIT8       :REC START OF MESSAGE
596                                     :PARCSR BIT DEFINITIONS
597      100000      DECMOD=BIT15     :DEC MODE (DDCMP)
598      001000      CRCEN=BIT9      :CRC ENABLE
599      010000      PRISEC=BIT12    :PRI/SEC SELECT
600                                     :TXCSR BIT DEFINITIONS
601      100000      TXDLAT=BIT15    :TX DATA LATE
602      040000      MTDATA=BIT14    :MAINT DATA OUT
603      020000      CLK=BIT13      :CLK
604      010000      MMODEB=BIT12    :MAINT MODE B
605      004000      MMODEA=BIT11    :MAINT MODE A
606      002000      BITW=BIT10     :BIT WINDOW INPUT
607      001000      TXACT=BIT9      :TX ACTIVE
608      000400      MRESET=BIT8     :MASTER RESET
609      000200      TXDONE=BIT7     :XMIT DONE
610      000100      TXINTE=BIT6    :XMIT DONE INTR ENABLE
611      000020      SEND=BIT4      :SEND
612      000010      HDXEN=BIT3     :HDX/FDX
613                                     :TXCSR WRD DEFINITIONS
614      000000      USER=0          :USER MODE
615      014000      MMODE=14000     :MAINT INT MODE
616      010000      MEXT=10000     :MAINT EXT MODE
617      004000      SYSTST=4000     :SYSTEM TEST MODE
618
619                                     :TXDBUF BIT DEFINITIONS
620                                     :-----
621      100000      RCRC7T=BIT15    :
622      040000      RCRCIN=BIT14    :
623      020000      TCRC7T=BIT13    :
624      010000      TCRCIN=BIT12    :

```


CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 22
 CZDPEC.P11 19-JUL-83 17:09 PROGRAM PARAMETERS, VARIABLES, AND TRAP CALLS.

625 004000
 626 002000
 627 001000
 628 000400

TIMER=BIT11 ;MAINTENANCE TIMER
 TABORT=BIT10 ;TRANSMIT ABORT
 TEOM=BIT9 ;TRANSMIT END OF MESSAGE
 TSOM=BIT8 ;TRANSMIT START OF MESSAGE

;MISC. PROGRAM DEFINITIONS

631
 632 001322 000000
 633 001324 000001
 634 001325 000001
 635 001326 000000
 636 001330 000000
 637 001332 000000
 638 001334 000000
 639 001336 000001
 640 001340 000001
 641 001342 000000
 642 001344 000000
 643 001346 000000

 PRIRTY: .WORD 0
 TCNFLG: .BLKB 1
 OPCLRJ: .BLKB 1
 DATA: .WORD 0
 SHIFTS: .WORD 0
 MIND: .WORD 0
 FLAG: .WORD 0
 STJMFL: .BLKW 1
 SRJMFL: .BLKW 1
 MDMFLG: .WORD 0
 ALJMFL: .WORD 0
 DSCFLG: .WORD 0

;PROGRAM CONTROL FLAGS

644
 645
 646
 647
 648
 649 001350 000
 650 001351 000
 651 001352 000
 652 001353 000
 653
 654
 655

 INIFLG: .BYTE 0
 ERRFLG: .BYTE 0
 LOKFLG: .BYTE 0
 QV.FLG: .BYTE 0

;PROGRAM INITIALIZATION FLAG
 ;ERROR OCCURED FLAG
 ;LOCK ON CURRENT TEST FLAG
 ;QUICK VERIFY FLAG.
 ;ON FIRST PASS OF EACH DUP11 ITERATIONS
 ;WILL BE SUPPRESSED

.EVEN

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 23
 CZDPEC.P11 19-JUL-83 17:09 PROGRAM PARAMETERS, VARIABLES, AND TRAP CALLS.

656
 657
 658
 659
 660
 661
 662
 663
 664
 665
 666
 667
 668
 669
 670
 671
 672
 673
 674
 675
 676
 677
 678
 679
 680
 681
 682
 683
 684
 685
 686
 687

001354 104400
 001354 002540
 104401
 001356 002672
 104402
 001360 002716
 104403
 001362 002772
 104404
 001364 003076
 104405
 001366 003116
 104406
 001370 003316
 104407
 001372 003356
 104410
 001374 003410
 104411
 001376 003414
 104412
 001400 003622

:DEFINITIONS FOR TRAP SUBROUTINE CALLS
 :POINTERS TO SUBROUTINES CAN BE FOUND
 :IN THE TABLE IMMEDIATELY FOLLOWING THE DEFINITIONS

```

:*****
:-----
:TRPTAB:
SCOPE=TRAP+0      :CALL TO SCOPE LOOP AND ITERATION HANDLER
      .SCOPE
SCOP1=TRAP+1      :CALL TO LOOP ON CURRENT DATA HANDLER
      .SCOP1
TYPE=TRAP+2       :CALL TO TELETYPE OUTPUT ROUTINE
      .TYPE
INSTR=TRAP+3       :CALL TO ASCII STRING INPUT ROUTINE
      .INSTR
INSTER=TRAP+4      :CALL TO INPUT ERROR HANDLER
      .INSTER
PARAM=TRAP+5       :CALL TO NUMERICAL DATA INPUT ROUTINE
      .PARAM
SAV05=TRAP+6       :CALL TO REGISTER SAVE ROUTINE
      .SAV05
RES05=TRAP+7       :CALL TO REGISTER RESTORE ROUTINE
      .RES05
CONVRT=TRAP+10     :CALL TO DATA OUTPUT ROUTINE
      .CONVRT
CNVRT=TRAP+11      :CALL TO DATA OUTPUT ROUTINE WITHOUT CR/LF.
      .CNVRT
SETFLG=TRAP+12     :CALL TO TELETYPE INPUT ROUTINE
      .SETFLG
:-----
:*****

```


CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 24
 CZDPEC.P11 19-JUL-83 17:09 PROGRAM PARAMETERS, VARIABLES, AND TRAP CALLS.

```

688                                     ;DUP11 VECTOR AND REGISTER INDIRECT POINTERS
689
690 001402 000000 DUPRVC: 0 ;POINTER TO DUP11 RECEIVER INTERRUPT VECTOR
691 001404 000000 DUPRPS: 0 ;POINTER TO DUP11 RECEIVER INTERRUPT SERVICE PS
692 001406 000000 DUPTVC: 0 ;POINTER TO DUP11 TRANSMITTER INTERRUPT VECTOR
693 001410 000000 DUPTPS: 0 ;POINTER TO DUP11 TRANSMITTER INTERRUPT SERVICE PS
694 001412 000000 RXCSR: 0 ;POINTER TO DUP11 RECEIVER STATUS REGISTER
695 001414 000000 RXDBUF: 0 ;POINTER TO DUP11 RECEIVER DATA BUFFER
696 001416 000000 PARCSR: 0 ;POINTER TO DUP11 PARAMETER STATUS REGISTER
697 001420 000000 TXCSR: 0 ;POINTER TO DUP11 TRANSMITTER STATUS REGISTER
698 001422 000000 TXDBUF: 0 ;POINTER TO DUP11 TRANSMITTER DATA BUFFER
699 001424 000000 DUPSEC: 0 ;POINTER TO DUP11 SECONDARY REGISTER SELECT REGISTER
700 001426 000000 HUPPSR: 0 ;POINTER TO PARAMETER STATUS HIGH BYTE
701 001430 000000 HUPRBF: 0 ;POINTER TO RECEIVER BUFFER HIGH BYTE
702 001432 000000 HUPRCR: 0 ;POINTER TO RECEIVER CONTROL REG HIGH BYTE
703 001434 000000 HUPTBF: 0 ;POINTER TO TRANSMITTER BUFFER HIGH BYTE
704 001436 000000 HUPTCR: 0 ;POINTER TO TRANSMITTER CONTROL REG HIGH BYTE
705
706                                     ;DUP11 CONTROL INDICATORS FOR CURRENT DUP11 UNDER TEST
707                                     ;-----
708
709
710 001440 000 MASK.A: .BYTE 000 ;LAST CHAR TO TEST AND PARITY MASK
711
712 001441 010 CLK.A: .BYTE 8. ;NUMBER OF CLOCKS NEEDED FOR ONE CHAR
713
714 001442 000000 L00.00: 000000 ;PARAMETERS
715
716                                     ;DUP11 STATUS TABLE AND ADDRESS ASSIGNMENTS
717                                     ;-----
718
719
720 001500 .=1500
721 001500 DUP.MAP:
722 001500 000001 DUPCR0: .BLKW 1 ;CONTROL STATUS REGISTER FOR DUP11 NUMBER 0
723 001502 000001 DUPTR0: .BLKW 1 ;VECTOR 'A' FOR DUP11 NUMBER 0
724 001504 000001 DUPO.A: .BLKW 1 ;PARAMETER FOR DUP11 NUMBER 0
725
726 001506 000000 DUP.END: 000000
727
728
729
730

```

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 25
 CZDPEC.P11 19-JUL-83 17:09 PROGRAM INITIALIZATION AND START UP.

```

731
732      :PROGRAM INITIALIZATION
733      :LOCK OUT INTERRUPTS
734      :SET UP PROCESSOR STACK
735      :SET UP POWER FAIL VECTOR
736      :CLEAR PROGRAM CONTROL FLAGS AND COUNTS
737      :TYPE TITLE MESSAGE
738
739 001510 012737 000340 177776 .START: MOV #340,PS      ;LOCK OUT INTERRUPTS
740 001516 012706 001150      MOV #STACK,SP      ;SET UP STACK
741 001522 012737 004312 000024      MOV #.PFAIL,a#24      ;SET UP POWER FAIL VECTOR
742 001530 005037 001230      CLR PASCNT      ;CLEAR PASS COUNT
743 001534 105037 001351      CLRB ERRFLG      ;CLEAR ERROR FLAG
744 001540 105037 001353      CLRB QV.FLG      ;ZERO QUICK VERIFY FLAG
745 001544 105037 001317      CLRB DUPNUM
746 001550 105037 001320      CLRB SAVNUM
747 001554 105037 001316      CLRB DUPACTV
748 001560 005037 001232      CLR ERRCNT      ;CLEAR ERROR COUNT
749 001564 005037 001234      CLR LSTERR      ;CLEAR LAST ERROR POINTER
750 001570 012737 000001 001226      MOV #1,TSTNO      ;SET UP FOR TEST 1
751 001576 012737 001510 001214      MOV #.START,RETURN      ;SET UP FOR POWER FAIL BEFORE
752                                     ;TESTING STARTS
753 001604 013746 000006      MOV a#6,-(SP)      ;SAVE CURRENT VECTORS
754 001610 013746 000004      MOV a#4,-(SP)
755 001614 012737 001630 000004      MOV #12$,a#4      ;SETUP FOR TIMEOUT
756 001622 005777 177354      TST aSWR      ;REFERENCE HARDWARE SWITCH REG
757 001626 000407      BR 13$      ;BR IF IT EXISTS
758 001630 012737 000176 001202 12$: MOV #SWREG,SWR      ;POINT TO SOFT SWR
759 001636 012737 000174 001200      MOV #DISPREG,DISPLAY      ;POINT TO SOFT DISPLAY REG
760 001644 022626      CMP (SP)+,(SP)+      ;ADJUST STACK
761 001646 012637 000004 13$: MOV (SP)+,a#4      ;RESTORE VECTORS
762 001652 012637 000006      MOV (SP)+,a#6
763 001656 005737 000042 11$: TST a#42      ;IF ACT11 AUTO MODE
764 001662 001123      BNE 66$      ;DON'T TYPE ID
765 001664 104402 001000      TYPE ,MTITLE      ;TYPE TITLE MESSAGE
766 001670 105777 177306 6$: TSTB aSWR      ;USE SAME PARAMETERS?
767 001674 100002      BPL 10$      ;IF NO, BR AND INPUT NEW PARAMETERS
768 001676 000137 002246      JMP .BEGIN      ;IF YES, GO.
769 001702 10$:
770 001702 012700 001500      MOV #DUP.MAP,RO      ;CLR MAP
771 001706 005020 68$: CLR (RO)+
772 001710 020027 001506      CMP RO,#DUP.END      ;DONE WITH MAP?
773 001714 001374      BNE 68$      ;BR IF NO
774 001716 105037 001342      CLRB MDMFLG
775 001722 105037 001344      CLRB ALJMFL
776 001726 104403      INSTR ;OUTPUT MESSAGE & GET INPUT STRING
777 001730 004707      MCSR ;MESSAGE
778 001732 104405      PARAM ;CONVERT STRING
779 001734 160000      160000 ;LOW LIMIT
780 001736 175500      175500 ;HIGH LIMIT
781 001740 001500      DUPCRO ;STORE AT THIS LOCATION
782 001742 001      .BYTE 1 ;MASK
783 001743 001      .BYTE 1 ;HOW MANY TIMES + 2
784 001744 104403      INSTR ;OUTPUT MESSAGE & GET INPUT STRING
785 001746 004726      MVEC ;MESSAGE
786 001750 104405      PARAM ;CONVERT STRING

```


CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 26
 CZDPEC.P11 19-JUL-83 17:09 PROGRAM INITIALIZATION AND START UP.

787	001752	000300		300	:LOW LIMIT
788	001754	000770		770	:HIGH LIMIT
789	001756	001502		DUPTR0	:STORE AT THIS LOCATION
790	001760	001	.BYTE	1	:MASK
791	001761	001	.BYTE	1	:HOW MANY TIMES + 2
792	001762	104403		INSTR	:OUTPUT MESSAGE & GET INPUT STRING
793	001764	004741		MMODEM	:MESSAGE
794	001766	104412		SETFLG	:SET FLAG BASED UPON INPUT STRING
795	001770	001342		MDMFLG	:THIS FLAG
796	001772	105737	001342	TSTB	MDMFLG :MODEM FLAG SET?
797	001776	001405		BEQ	71\$:IF BR.
798	002000	105037	001324	CLRB	TCNFLG
799	002004	105037	001344	CLRB	ALJMFL
800	002010	000436		BR	70\$
801	002012				
802	002012	104403	71\$:	INSTR	:OUTPUT MESSAGE & GET INPUT STRING
803	002014	005112		MTCN	:MESSAGE
804	002016	104412		SETFLG	:SET FLAG BASED UPON INPUT STRING
805	002020	001324		TCNFLG	:THIS FLAG
806	002022	105737	001324	TSTB	TCNFLG
807	002026	001427		BEQ	70\$
808	002030	104403		INSTR	:OUTPUT MESSAGE & GET INPUT STRING
809	002032	005321		MALLJM	:MESSAGE
810	002034	104412		SETFLG	:SET FLAG BASED UPON INPUT STRING
811	002036	001344		ALJMFL	:THIS FLAG
812	002040	105737	001344	TSTB	ALJMFL
813	002044	001020		BNE	70\$
814	002046	104403		INSTR	:OUTPUT MESSAGE & GET INPUT STRING
815	002050	005037		MJMPR	:MESSAGE
816	002052	104412		SETFLG	:SET FLAG BASED UPON INPUT STRING
817	002054	001325		OPCLRJ	:THIS FLAG
818	002056	104403		INSTR	:OUTPUT MESSAGE & GET INPUT STRING
819	002060	005205		MSTJM	:MESSAGE
820	002062	104412		SETFLG	:SET FLAG BASED UPON INPUT STRING
821	002064	001336		STJMFL	:THIS FLAG
822	002066	104403		INSTR	:OUTPUT MESSAGE & GET INPUT STRING
823	002070	005240		MSRJM	:MESSAGE
824	002072	104412		SETFLG	:SET FLAG BASED UPON INPUT STRING
825	002074	001340		SRJMFL	:THIS FLAG
826	002076	104403		INSTR	:OUTPUT MESSAGE & GET INPUT STRING
827	002100	005375		MDSC	:MESSAGE
828	002102	104412		SETFLG	:SET FLAG BASED UPON INPUT STRING
829	002104	001346		DSCFLG	:THIS FLAG
830	002106	105237	001317	INCB	DUPNUM
831	002112	105237	001320	INCB	SAVNUM
832	002116	105237	001316	INCB	DUPACTV
833	002122	012700	001500	MOV	#DUPCRO,RO
834	002126	000137	002246	JMP	.BEGIN :LET'S GO.
835	002132			66\$:	

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 27
 CZDPEC.P11 19-JUL-83 17:09 PROGRAM INITIALIZATION AND START UP.

;** FOLLOWING PARAMETERS ARE LOADED IF UNDER ACT11 OR XXDP CONTROL.**

836											
837											
838	002132	012700	001500			MOV	#DUP.MAP,R0		:SET UP POINTER		
839	002136	105237	001316			INCB	DUPACTV		:DEVICE ACTIVE FOR TESTING		
840	002142	012710	160050			MOV	#160050,(R0)		:CSR		
841	002146	012760	000770	000002		MOV	#770,2(R0)		:VECTOR		
842	002154	012760	140026	000004		MOV	#140026,4(R0)		:STATUS AND SYNC		
843	002162	112737	000005	001322		MOVB	#5,PRIPTY		:PRIORITY		
844	002170	113737	001236	001324		MOVB	TEMP1,TCNFLG		:TURN-AROUND-CONNECTER FLAG		
845	002176	113737	001236	001325		MOVB	TEMP1,OPCLRJ		:OPTIONAL CLEAR JUMPER		
846	002204	105037	001342			CLRB	MDMFLG		:MODEM FLAG		
847	002210	104402	005273			TYPE	,XHEAD		:TYPE HEADER		
848	002214	012737	001500	001236		MOV	#DUP.MAP,TEMP1		:SET POINTER		
849	002222	017737	177010	001240	5\$:	MOV	@TEMP1,TEMP2		:SET DATA		
850	002230	001406				BEQ	.BEGIN		:ALL DONE WITH DATA		
851	002232	104410				CONVRT					
852	002234	005442				XSTATQ					
853	002236	062737	000002	001236		ADD	#2,TEMP1		:UPDATE POINTER		
854	002244	000766				BR	5\$				
855											
856											
857											
858											
859	002246	012737	000340	177776	.BEGIN:	MOV	#340,PS		:LOCK OUT INTERRUPTS		
860	002254	012706	001150			MOV	#STACK,SP		:SET UP STACK		
861	002260	005737	000042			TST	@#42		:IS PROGRAM UNDER MONITOR CONTROL		
862	002264	001023				BNE	2\$		:BR IF YES		
863	002266	032777	000004	176706		BIT	#BIT2,@SWR		:CHECK FOR LOCK ON TEST		
864	002274	001411				BEQ	1\$		:BR IF NO LOCK DESIRED.		
865	002276	104402	004526			TYPE	,MLOCK		:TYPE LOCK SELECTED.		
866	002302	012737	000240	002554		MOV	#NOP,TTST		:ADJUST SCOPE ROUTINE.		
867	002310	012737	000240	002556		MOV	#NOP,TTST+2		:SET UP TO LOCK		
868	002316	000406				BR	2\$		:CONTINUE ALONG.		
869	002320	013737	002666	002554	1\$:	MOV	BRW,TTST		:PREPARE NORMAL SCOPE ROUTINE		
870	002326	013737	002670	002556		MOV	BRX,TTST+2		:LOCK NOT SELECTED, SET UP FOR NORMAL SCOPE LOOP		
871	002334	012737	005624	001214	2\$:	MOV	#CYCLE,RETURN		:START AT 'CYCLE' FIND WHICH DEVICE TO TEST		
872	002342	104402	004416			TYPE	,MR		:TYPE R		
873	002346	000177	176642			JMP	@RETURN		:START TESTING		

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 28
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

874                                     :END OF PASS
875                                     :TYPE NAME OF TEST
876                                     :UPDATE PASS COUNT
877                                     :CHECK FOR EXIT TO ACT-11
878                                     :RESTART TEST
879
880 002352 005037 001234      .EOP: CLR      LSTERR      :CLEAR LAST ERROR PC
881 002356 105037 001351      CLR      ERRFLG      :CLEAR ERROR FLAG
882 002362 005237 001230      INC      PASCNT      :UPDATE PASS COUNT
883 002366 013777 001230 176604 MOV      PASCNT,@DISPLAY :DISPLAY PASS COUNT
884 002374 104402 004373      TYPE      ,MEPASS      :TYPE END PASS
885 002400 104402 004555      TYPE      ,MCSR      :TYPE CSR
886 002404 104411 002510      CNVRT      ,XCSR      :SHOW IT
887 002410 104402 004563      TYPE      ,MVECX      :TYPE VECTOR
888 002414 104411 002516      CNVRT      ,XVEC      :SHOW IT
889 002420 104402 004571      TYPE      ,MPASSX      :TYPE PASSES
890 002424 104411 002524      CNVRT      ,XPASS      :SHOW IT
891 002430 104402 004602      TYPE      ,MERRX      :TYPE ERRORS
892 002434 104411 002532      CNVRT      ,XERR      :SHOW IT
893 002440 112737 000377 001353 MOV      #377,QV.FLG :SET THE QUICK VERIFY FLAG.
894 002446 113737 001317 001320 MOV      DUPNUM,SAVNUM :RESTORE THE COUNT
895 002454 013701 000042      MOV      @#42,R1      :CHECK FOR ACT-11 OR DDP
896 002460 001406      BEQ      RESTRT      :IF NOT, CONTINUE TESTING
897 002462 000005      RESET      :STOP THE SHOW--CLEAR THE WORLD
898
899 002464      SENDAD: JSR      PC,(R1)
900 002466 000240      NOP
901 002470 000240      NOP
902 002472 000240      NOP
903 002474 000240      NOP
904 002476 012737 005624 001214 RESTRT: MOV      #CYCLE,RETURN
905 002504 000137 005624      JMP      CYCLE
906 002510 000001      XCSR: 1
907 002512 006      .BYTE 6.2
908 002514 001412      RXCSR
909 002516 000001      XVEC: 1
910 002520 003      .BYTE 3.2
911 002522 001402      DUPRVC
912 002524 000001      XPASS: 1
913 002526 006      .BYTE 6.2
914 002530 001230      PASCNT
915 002532 000001      XERR: 1
916 002534 006      .BYTE 6.2
917 002536 001232      ERRCNT
918
919                                     :SCOPE LOOP AND INTERATION HANDLER
920
921 002540 005037 001234      .SCOPE: CLR      LSTERR      :CLEAR LAST ERROR PC
922 002544 010016      MOV      R0,(SP)      :SAVE R0 ON STACK
923 002546 032777 040000 176426 BIT      #BIT14,@SWR :LOOP ON TEST?
924 002554 001407      TTST: BEQ      1$      :BR IF NO (IF LOCK SW01 = 1;THIS LOCATION = 240)
925 002556 000437      BR      3$      :GO TO 3$ (DITTO)
926 002560 105777 176420      TSTB      @TKCSR      :KYBD DONE?
927 002564 100034      BPL      3$      :BR IF NO (LOCK: HIT A KEY ON TTY TO GO TO NEXT TEST)
928 002566 017700 176414      MOV      @TKDBR,R0      :CLR DONE BIT
929 002572 000415      BR      2$      :CONTINUE

```

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 29
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

930 002574 032777 004000 176400 1$: BIT #SW11,@SWR ;DELETE ITERATION (QUICK PASS)?
931 002602 001011 BNE 2$ ;BR IF YES
932 002604 105737 001353 TSTB QV.FLG ;HAS FIRST PASS BEEN COMPLETED?
933 002610 001406 BEQ 2$ ;BR IF QUICK VERIFY
934 002612 005237 001224 INC LPCNT ;UPDATE ITERATION COUNTER
935 002616 023737 001224 001222 CMP LPCNT,ICOUNT ;ALL ITERATIONS DONE?
936 002624 001014 BNE 3$ ;BR IF NOT YET
937 002626 105037 001351 2$: CLRB ERRFLG ;PREPARE FOR NEW TEST
938 002632 005037 001224 CLR LPCNT ;START ICOUNT AT ZERO
939 002636 005037 001220 CLR LOCK
940 002642 012737 000050 001222 MOV #50,ICOUNT ;RESET ITERATIONS
941 002650 013737 001216 001214 MOV NEXT,RETURN ;GET NEXT TEST
942 002656 011600 3$: MOV (SP),R0 ;POP R0 OFF STACK
943 002660 022626 POP2SP ;FAKE AN RTI
944 002662 000177 176326 JMP @RETURN ;GO DO THE TEST
945 002666 001407 BRW: 1407
946 002670 000437 BRX: 437
947 ;TELETYPE OUTPUT ROUTINE
948 ;-----
949
950 002716 010546 .TYPE: MOV R5,-(SP) ;SAVE R5 ON THE STACK.
951 002720 017605 000002 MOV @2(SP),R5 ;GET ADDRESS OF MESSAGE.
952 002724 062766 000002 000002 ADD #2,2(SP) ;POP OVER ADDRESS.
953 002732 032777 010000 176242 1$: BIT #SW12,@SWR ;INHIBIT ALL PRINT OUT??
954 002740 001012 BNE 3$ ;BR IF NO PRINT OUT WANTED (SW12=1)
955 002742 105715 TSTB (R5) ;IS NUMBER MINUS? (MSB=1(BIT7))
956 002744 100002 BPL 2$ ;BR IF NUMBER IS PLUS
957 002746 104402 004352 TYPE ,MCRLF ;TYPE A CR/LF!
958 002752 105777 176232 2$: TSTB @TPCSR ;TTY READY?
959 002756 100375 BPL 2$ ;BR IF NO.
960 002760 112577 176226 MOVB (R5)+,@TPDBR ;PRINT CURRENT CHAR.
961 002764 001362 BNE 1$ ;IF NOT ZERO KEEP PRINTING!
962 002766 012605 3$: MOV (SP)+,R5 ;END OF OUTPUT. RESTORE R5
963 002770 000002 RTI ;GO HOME
964 ;-----
965
966 002772 010346 .INSTR: MOV R3,-(SP) ;SAVE R3 ON STACK
967 002774 010446 MOV R4,-(SP) ;SAVE R4 ON STACK
968 002776 017637 000004 003014 MOV @4(SP),MSG
969 003004 062766 000002 000004 ADD #2,4(SP)
970 003012 104402 .INST1: TYPE
971 003014 000000 .MSG: 0
972 003016 012704 005560 MOV #INBUF,R4
973 003022 012703 000007 MOV #7,R3
974 003026 105777 176152 1$: TSTB @TKCSR
975 003032 100375 BPL 1$
976 003034 117714 176146 MOVB @TKDBR,(R4)
977 003040 142714 000200 BICB #200,(R4)
978 003044 122427 000015 CMPB (R4)+,#15
979 003050 001417 BEQ INSTR2
980 003052 105777 176132 2$: TSTB @TPCSR
981 003056 100375 BPL 2$
982 003060 017777 176122 176124 MOV @TKDBR,@TPDBR
983 003066 005303 DEC R3
984 003070 001356 BNE 1$
985 003072 012604 MOV (SP)+,R4

```


CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 30
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

986	003074	012603			MOV	(SP)+,R3	
987	003076	010346			.INSTE: MOV	R3,-(SP)	
988	003100	010446			MOV	R4,-(SP)	
989	003102	104402	004346		TYPE	.MQM	
990	003106	000741			BR	.INST1	
991	003110	012604			INSTR2: MOV	(SP)+,R4	:RESTORE R4
992	003112	012603			MOV	(SP)+,R3	:RESTORE R3
993	003114	000002			RTI		
994							
995						:CONVERT ASCII STRING TO OCTAL	
996						-----	
997							
998	003116	010546			.PARAM: MOV	R5,-(SP)	
999	003120	010446			MOV	R4,-(SP)	
1000	003122	016605	000004		MOV	4(SP),R5	
1001	003126	012537	003306		MOV	(R5)+,LOLIM	
1002	003132	012537	003310		MOV	(R5)+,HILIM	
1003	003136	012537	003312		MOV	(R5)+,DEVADR	
1004	003142	112537	003314		MOVB	(R5)+,LOBITS	
1005	003146	112537	003315		MOVB	(R5)+,ADRCNT	
1006	003152	010566	000004		MOV	R5,4(SP)	
1007	003156	005005			PARAM1: CLR	R5	
1008	003160	012704	005560		MOV	#INBUF,R4	
1009	003164	122714	000015		CMPB	#15,(R4)	
1010	003170	001420			BEQ	PARERR	
1011	003172	121427	000060		1\$: CMPB	(R4),#60	
1012	003176	002415			BLT	PARERR	
1013	003200	121427	000067		CMPB	(R4),#67	
1014	003204	003012			BGT	PARERR	
1015	003206	142714	000060		BICB	#60,(R4)	
1016	003212	152405			BISB	(R4)+,R5	
1017	003214	122714	000015		CMPB	#15,(R4)	
1018	003220	001406			BEQ	LIMITS	
1019	003222	006305			ASL	R5	
1020	003224	006305			ASL	R5	
1021	003226	006305			ASL	R5	
1022	003230	000760			BR	1\$	
1023	003232	104404			PARERR: INSTER		
1024	003234	000750			BR	PARAM1	
1025							
1026						:TEST TO SEE IF NUMBER IS WITHIN LIMITS	
1027						-----	
1028							
1029	003236	020537	003310		LIMITS: CMP	R5,HILIM	
1030	003242	101373			BHI	PARERR	
1031	003244	020537	003306		CMP	R5,LOLIM	
1032	003250	103770			BLO	PARERR	
1033	003252	133705	003314		BITB	LOBITS,R5	
1034	003256	001365			BNE	PARERR	
1035							
1036						:STORE NUMBER AT SPECIFIED ADDRESS	
1037							
1038	003260	013704	003312		1\$: MOV	DEVADR,R4	
1039	003264	010524			MOV	R5,(R4)+	
1040	003266	062705	000002		ADD	#2,R5	
1041	003272	105337	003315		DECB	ADRCNT	

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 31
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

1042	003276	001372			BNE	1\$
1043	003300	012604			MOV	(SP)+,R4
1044	003302	012605			MOV	(SP)+,R5
1045	003304	000002			RTI	
1046	003306	000000			LOLIM:	0
1047	003310	000000			HILIM:	0
1048	003312	000000			DEVADR:	0
1049	003314	000000			LOBITS:	0
1050		003315			ADRCNT=LOBITS+1	
1051					:CONVERT OCTAL NUMBER TO ASCII AND OUTPUT TO TELEPRINTER	
1052					:-----	
1053						
1054	003410	104402	004352		.CONVR: TYPE	.MCRLF
1055	003414	010046			.CNVRT: MOV	R0,-(SP)
1056	003416	010146			MOV	R1,-(SP)
1057	003420	010346			MOV	R3,-(SP)
1058	003422	010446			MOV	R4,-(SP)
1059	003424	010546			MOV	R5,-(SP)
1060	003426	017601	000012		MOV	@12(SP),R1
1061	003432	062766	000002	000012	ADD	#2,12(SP)
1062	003440	012137	003614		MOV	(R1)+,WRDCNT
1063	003444	112137	003616		1\$: MOV	(R1)+,CHRCNT
1064	003450	112137	003617		MOVB	(R1)+,SPACNT
1065	003454	013137	003620		MOV	@(R1)+,BINWRD
1066	003460	013704	003620		2\$: MOV	BINWRD,R4
1067	003464	113705	003616		MOVB	CHRCNT,R5
1068	003470	012700	005454		MOV	#TEMP,R0
1069	003474	010403			3\$: MOV	R4,R3
1070	003476	042703	177770		BIC	#177770,R3
1071	003502	062703	000060		ADD	#060,R3
1072	003506	110320			MOVB	R3,(R0)+
1073	003510	000241			CLC	
1074	003512	006004			ROR	R4
1075	003514	000241			CLC	
1076	003516	006004			ROR	R4
1077	003520	000241			CLC	
1078	003522	006004			ROR	R4
1079	003524	005305			DEC	R5
1080	003526	001362			BNE	3\$
1081	003530	012703	005516		MOV	#MDATA,R3
1082	003534	114023			4\$: MOVB	-(R0),(R3)+
1083	003536	105337	003616		DECB	CHRCNT
1084	003542	001374			BNE	4\$
1085	003544	105737	003617		TSTB	SPACNT
1086	003550	001405			BEQ	6\$
1087	003552	112723	000040		5\$: MOVB	#040,(R3)+
1088	003556	105337	003617		DECB	SPACNT
1089	003562	001373			BNE	5\$
1090	003564	105013			6\$: CLRB	(R3)
1091	003566	104402	005516		TYPE	.MDATA
1092	003572	005337	003614		DEC	WRDCNT
1093	003576	001322			BNE	1\$
1094	003600	012605			MOV	(SP)+,R5
1095	003602	012604			MOV	(SP)+,R4
1096	003604	012603			MOV	(SP)+,R3
1097	003606	012601			MOV	(SP)+,R1

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 32
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

1098 003610 012600      MOV      (SP)+,R0
1099 003612 000002      RTI
1100 003614 000000      WRDCNT: 0
1101 003616 000000      CHRCNT: 0
1102      003617      SPACNT=CHRCNT+1
1103 003620 000000      BINWRD: 0
1104
1105
1106      ;COMPARE THE FIRST CHARACTER IN THE TELETYPE INPUT
1107      ;BUFFER TO THE CHARACTERS 'N' AND 'Y'.
1108      ;IF THE CHARACTER IS 'N' CLEAR THE FLAG
1109      ;IF THE CHARACTER IS 'Y' SET THE FLAG
1110
1111 003622 017605 000000 .SETFLG:MOV      @ (SP),R5
1112 003626 042737 000040 005560 BIC      #40,INBUF
1113 003634 122737 000116 005560 CMPB     #'N',INBUF      ;IS IT 'N' ?
1114 003642 001002      BNE      1$
1115 003644 105015      CLRB     (R5)      ;000
1116 003646 000406      BR       2$
1117 003650 122737 000131 005560 1$: CMPB     #'Y',INBUF      ;IS IT 'Y' ?
1118 003656 001005      BNE      3$
1119 003660 112715 177777      MOVB     #-1,(R5)      ;377
1120 003664 062716 000002      2$: ADD      #2,(SP)
1121 003670 000002      RTI
1122 003672 104404      3$: INSTER   :RETRY
1123 003674 000752      BR       .SETFLG
1124
1125
1126      ;TRAP DISPATCH SERVICE
1127      ;ARGUMENT OF TRAP IS EXTRACTED
1128      ;AND USED AS OFFSET TO OBTAIN POINTER
1129      ;TO SELECTED SUBROUTINE
1130
1131 003676 011646      .TRPSR: MOV      (SP),-(SP)      ;GET PC OF RETURN
1132 003700 162716 000002      SUB      #2,(SP)      ;=PC OF TRAP
1133 003704 017616 000000      MOV      @ (SP), (SP)      ;GET TRP
1134 003710 006316      TRPOK: ASL      (SP)      ;MULTIPLY TRAP ARG BY 2
1135 003712 042716 177001      BIC      #177001,(SP)      ;CLEAR UNWANTED BITS
1136 003716 062716 001354      ADD      #.TRPTAB,(SP)      ;POINTER TO SUBROUTINE ADDRESS
1137 003722 017616 000000      MOV      @ (SP), (SP)      ;SUBROUTINE ADDRESS
1138 003726 000136      JMP      @ (SP)+      ;GO TO SUBROUTINE
1139
1140      ;ERROR HANDLER
1141      ;-----
1142
1143 003730 032777 010000 175244 .HLT: BIT      #SW12,@SWR      ;BELL ON ERROR?
1144 003736 001406      BEQ      XBX      ;BR IF NO BELL
1145 003740 105777 175244      TSTB     @TPCSR      ;TTY READY.
1146 003744 100003      BPL      XBX      ;DON'T WAIT IF TTY NOT READY.
1147 003746 112777 000207 175236 MOVB     #207,@TPDBR      ;PUSH A BELL AT THE TTY.
1148 003754 032777 020000 175220 XBX: BIT      #SW13,@SWR      ;DELETE ERROR PRINT OUT?
1149 003762 001105      BNE      HALTS      ;BR IF NO PRINT OUT WANTED.
1150 003764 021637 001234      CMP      (SP),LSTERR      ;WAS THIS ERROR FOUND LAST TIME?
1151 003770 001404      BEQ      1$      ;BR IF YES
1152 003772 011637 001234      MOV      (SP),LSTERR      ;RECORD BEING HERE
1153 003776 105037 001351      CLRB     ERRFLG      ;PREPARE HEADER

```

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 33
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

1154	004002	104406		1\$:	SAV05		:SAVE ALL PROC REGISTERS
1155	004004	011605			MOV	(SP),R5	:GET THE PC OF ERROR
1156	004006	162705	000002		SUB	#2,R5	:GET ADDRESS OF TRAP CALL
1157	004012	011504			MOV	(R5),R4	:GET HLT INSTRUCTION
1158	004014	006304			ASL	R4	:MULT BY TWO
1159	004016	061504			ADD	(R5),R4	:DOUBLE IT
1160	004020	006304			ASL	R4	:MULT AGAIN
1161	004022	042704	177001		BIC	#177001,R4	:CLEAR JUNK
1162	004026	062704	011544		ADD	#,ERRTAB,R4	:GET POINTER
1163	004032	012437	004146		MOV	(R4)+,ERRMSG	:GET ERROR MESSAGE
1164	004036	012437	004160		MOV	(R4)+,DATAHD	:GET DATA HEADRER
1165	004042	011437	004172		MOV	(R4),DATABP	:GET DATA TABLE
1166	004046	105737	001351		TSTB	ERRFLG	:TYPE HEADREER
1167	004052	001403			BEQ	TYPMSG	:BR IF YES
1168	004054	005737	004172		TST	DATABP	:DOES DATA TABLE EXIST?
1169	004060	001040			BNE	TYPDAT	:BR IF YES.
1170	004062	104402	004352		TYPMSG:	TYPE	
1171	004066	104402	004352			,MCRLF	
1172	004072	005737	001220			,MCRLF	
1173	004076	001402			TST	LOCK	
1174	004100	104402	004625		BEQ	1\$	
1175	004104	104402	004613		TYPE	,MASTEK	
1176	004110	104411	004300		TYPE	,MTSTN	
1177	004114	104402	004702		CNVRT	,XTSTN	:SHOW IT
1178	004120	104411	004272		TYPE	,MERRPC	:TYPE PC.
1179	004124	104402	004352		CNVRT	,ERTABO	:SHOW IT
1180	004130	112737	177777	001351	TYPE	,MCRLF	:GIVE A CR/LF
1181	004136	005737	004146		MOVB	#-1,ERRFLG	:NO MORE HEADER UNLESS NO DATA TABLE.
1182	004142	001402			TST	ERRMSG	:IS THERE AN ERROR MESSAGE?
1183	004144	104402			BEQ	WRKO.FM	:BR IF NO.
1184	004146	000000			TYPE		:TYPE
1185	004150				ERRMSG:	0	:ERROR MESSAGE
1186	004150	005737	004160		WRKO.FM:		
1187	004154	001402			TST	DATAHD	:DATA HEADER?
1188	004156	104402			BEQ	TYPDAT	:BR IF NO
1189	004160	000000			TYPE		:TYPE
1190	004162	005737	004172		DATAHD:	0	:DATA HEADER
1191	004166	001402			TYPDAT:	TST	:DATA TABLE?
1192	004170	104410				DATABP	:BR IF NO.
1193	004172	000000				RESREG	:SHOW
1194	004174	104407			CONVRT		:DATA TABLE
1195	004176	022737	002464	000042	DATABP:	0	:RESTORE PROC REGISTERS
1196	004204	001403			RESREG:	RES05	:IF ACT-11 AUTO MODE--HALT!!
1197	004206	005777	174770		HALTS:	CMP	
1198	004212	100005				#SENDAD,@#42	
1199	004214	010046				1\$	
1200	004216	016600	000002			@SWR	:HALT ON ERROR?
1201	004222	000000				EXITER	:BR IF NO HALT ON ERROR
1202	004224	012600			1\$:	PUSHRO	:SAVE RO
1203	004226	005237	001232			MOV	:SHOW ERROR PC IN DATA LIGHTS
1204	004232	032777	000400	174742		2(SP),R0	:HALT
1205	004240	001007			HALT		:GET RO
1206	004242	032777	002000	174732	POPRO		:UPDATE ERROR COUNT
1207	004250	001407			EXITER:	INC	:GOTO TOP OF TEST?
1208	004252	013737	001216	001214		ERRCNT	:BR IF YES
1209	004260	012706	001150			#SW08,@SWR	:GOTO NEXT TEST?
						1\$	:BR IF NO
						#SW10,@SWR	:SET FOR NEXT TEST
						2\$	:RESET SP
						MOV	
						NEXT,RETURN	
						#STACK,SP	

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 34
CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

1210	004264	000177	174724		JMP	@RETURN	:GOTO SPECIFIED TEST
1211	004270	000002		2\$:	RTI		:RETURN
1212	004272	000001		ERTAB0:	1		
1213	004274	006	002		.BYTE	6.2	
1214	004276	001266			SAVPC		
1215	004300	000001		XTSTN:	1		
1216	004302	003	002		.BYTE	3.2	
1217	004304	001226			TSTNO		
1218							

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 35
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

1219      ;WAIT ROUTINE
1220 004306 000240      SMALL: NOP      ;STALL
1221 004310 000207      RTS      PC      ;RETURN
1222
1223      ;POWER FAIL ROUTINE
1224
1225
1226 004312 012737 004322 000024 .PFAIL: MOV      #PWRUP,24      ;LOAD PFAIL VECTOR FOR POWER UP
1227 004320 000000      HALT
1228 004322 000005      PWRUP: RESET      ;WAIT TTY TO COME UP
1229 004324 012706 001150      MOV      #STACK,SP      ;REINIT STACK POINTER
1230 004330 012737 004312 000024      MOV      #.PFAIL,24      ;LOAD PFAIL VECTOR FOR POWER DOWN
1231 004336 104402      TYPE
1232 004340 004355      MPOWER
1233 004342 000177 174646      JMP      @RETURN
1234
1235 004346 020040 000077      MQM: .ASCIZ / ?/
1236 004352 005015 000      MCRLF: .ASCIZ <15><12>
1237 004355 377 053520 020122      MPOWER: .ASCIZ <377>/PWR FAILED. /
1238 004362 040506 046111 042105
1239 004370 020056 000
1240 004373 015 042777 042116      MEPASS: .ASCIZ <15><377>/END PASS CZDPEC /
1241 004400 050040 051501 020123
1242 004406 055103 050104 041505
1243 004414 000040
1244 004416 051377 000      MR: .ASCIZ <377>/R/
1245 004421 377 051120 043517      MERR2: .ASCIZ <377>/PROGRAM INDICATES NO DEVICES PRESENT./
1246 004426 040522 020115 047111
1247 004434 044504 040503 042524
1248 004442 020123 047516 042040
1249 004450 053105 041511 051505
1250 004456 050040 042522 042523
1251 004464 052116 000056
1252 004470 044777 051516 043125      MERR3: .ASCIZ <377>/INSUFFICIENT DATA!/
1253 004476 044506 044503 047105
1254 004504 020124 040504 040524
1255 004512 000041
1256 004514 052377 051505 020124      MTSTPC: .ASCIZ <377>/TEST PC-/
1257 004522 041520 000055
1258 004526 046377 041517 020113      MLOCK: .ASCIZ <377>/LOCK ON SELECTED TEST/
1259 004534 047117 051440 046105
1260 004542 041505 042524 020104
1261 004550 042524 052123 000
1262 004555 103 051123 020072      MCSRX: .ASCIZ /CSR: /
1263 004562 000
1264 004563 126 041505 020072      MVECX: .ASCIZ /VEC: /
1265 004570 000
1266 004571 120 051501 042523      MPASSX: .ASCIZ /PASSES: /
1267 004576 035123 000040
1268 004602 051105 047522 051522      MERRX: .ASCIZ /ERRORS: /
1269 004610 020072 000
1270 004613 124 051505 020124      MTSTN: .ASCIZ /TEST NO: /
1271 004620 047516 020072 000
1272 004625 052 000      MASTEK: .ASCIZ /*/
1273 004627 377 042523 020124      MNEW: .ASCIZ <377>/SET SWITCH REG TO DUP11'S DESIRED ACTIVE./
1274 004634 053523 052111 044103

```


CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 36
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

1275	004642	051040	043505	052040	
1276	004650	020117	052504	030520	
1277	004656	023461	020123	042504	
1278	004664	044523	042522	020104	
1279	004672	041501	044524	042526	
1280	004700	000056			
1281	004702	041520	020072	000	MERRPC: .ASCIIZ /PC: /
1282	004707	377	042522	020103	MCSR: .ASCIIZ <377>/REC CSR ADRS /
1283	004714	051503	020122	042101	
1284	004722	051522	000040		
1285	004726	053377	041505	040440	MVEC: .ASCIIZ <377>/VEC ADRS /
1286	004734	051104	020123	000	
1287	004741	377	051511	040440	MMODEM: .ASCIIZ <377>/IS A MODEM WITH ANALOG LOOPBACK ENABLED CONNECTED? (Y OR N)
1288	004746	046440	042117	046505	
1289	004754	053440	052111	020110	
1290	004762	047101	046101	043517	
1291	004770	046040	047517	041120	
1292	004776	041501	020113	047105	
1293	005004	041101	042514	020104	
1294	005012	047503	047116	041505	
1295	005020	042524	037504	024040	
1296	005026	020131	051117	047040	
1297	005034	004451	000		
1298	005037	377	051511	052040	MJMPR: .ASCIIZ <377>/IS THE OPTIONAL CLR JMPR IN? (Y OR N) /
1299	005044	042510	047440	052120	
1300	005052	047511	040516	020114	
1301	005060	046103	020122	046512	
1302	005066	051120	044440	037516	
1303	005074	020040	054450	047440	
1304	005102	020122	024516	020040	
1305	005110	000040			
1306	005112	044777	020123	044124	MTCN: .ASCIIZ <377>/IS THE H325 CONNECTOR ON? (Y OR N) /
1307	005120	020105	031510	032462	
1308	005126	041440	047117	042516	
1309	005134	052103	051117	047440	
1310	005142	037516	024040	020131	
1311	005150	051117	047040	020051	
1312	005156	020040	000		
1313	005161	377	051120	047511	MPAR: .ASCIIZ <377>/PRIORITY (4 TO 7) /
1314	005166	044522	054524	024040	
1315	005174	020064	047524	033440	
1316	005202	020051	000		
1317	005205	377	042523	020103	MSTJM: .ASCIIZ <377>/SEC TX JMPR IN? (Y OR N) /
1318	005212	054124	045040	050115	
1319	005220	020122	047111	020077	
1320	005226	054450	047440	020122	
1321	005234	024516	000040		
1322	005240	051777	041505	051040	MSRJM: .ASCIIZ <377>/SEC RX JMPR IN? (Y OR N) /
1323	005246	020130	046512	051120	
1324	005254	044440	037516	024040	
1325	005262	020131	051117	047040	
1326	005270	020051	000		
1327	005273	377	040515	020120	XHEAD: .ASCIIZ <377>/MAP OF DUP11 STATUS/<377>
1328	005300	043117	042040	050125	
1329	005306	030461	051440	040524	
1330	005314	052524	177523	000	

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 37
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

1331	005321	377	051101	020105	MALLJM: .ASCIZ <377>/ARE THE DEFAULT JUMPERS ALL IN? (Y OR N) /
1332	005326	044124	020105	042504	
1333	005334	040506	046125	020124	
1334	005342	052512	050115	051105	
1335	005350	020123	046101	020114	
1336	005356	047111	020077	054450	
1337	005364	047440	020122	024516	
1338	005372	020040	000		
1339	005375	377	051101	020105	MDSC: .ASCIZ <377>/ARE DSC 1 AND 2 BOTH IN? (Y OR N) /
1340	005402	051504	020103	020061	
1341	005410	047101	020104	020062	
1342	005416	047502	044124	044440	
1343	005424	037516	024040	020131	
1344	005432	051117	047040	020051	
1345	005440	000040			
1346					.EVEN
1347	005442	000002			XSTATQ: 2
1348	005444	006	003		.BYTE 6,3
1349	005446	001236			TEMP1
1350	005450	006	002		.BYTE 6,2
1351	005452	001240			TEMP2
1352					.EVEN
1353					
1354	005454	000000			TEMP: 0
1355		005516			.+.40
1356	005516	000000			MDATA: 0
1357		005560			.+.40
1358	005560	000000			INBUF: 0
1359		005622			.+.40
1360	005622	000001			TRP.PC: .BLKW 1
1361					

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 38
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

1362
1363
1364
1365
1366
1367
1368
1369
1370
1371 005624 105737 001316      CYCLE: TSTB      DUPACTV      ;ARE ANY DUP11'S TO BE TESTED?
1372 005630 001004              BNE          1$          ;BR IF OK.
1373 005632 104402 004421      TYPE      ,MERR2      ;NO DUP11'S SELECTED!!
1374 005636 000000              HALT          ;STOP THE SHOW.
1375 005640 000776              BR          -2          ;DISQUALIFY CONT. SW.
1376 005642 012700 001500      1$: MOV      #DUP.MAP,R0      ;RESTORE POINTER.
1377 005646 012037 001412      MOV      (R0)+,RXCSR      ;LOAD SYSTEM CTRL. REG
1378 005652 012037 001402      MOV      (R0)+,DUPRVC      ;LOAD VECTOR
1379 005656 012037 001442      MOV      (R0)+,L00.00      ;GET PARAMETERS
1380 005662 012700 000002      MOV      #2,R0          ;SAVE CORE THIS WAY!
1381 005666 013737 001412 001432 MOV      RXCSR,HUPRCR      ;GET CONTROL REG HIGH BYTE
1382 005674 005237 001432      INC      HUPRCR          ;GOT IT
1383 005700 013737 001432 001414 MOV      HUPRCR,RXDBUF      ;GET RX CONTROL REG BUFFER
1384 005706 005237 001414      INC      RXDBUF          ;GOT IT
1385 005712 013737 001414 001424 MOV      RXDBUF,DUPSEC      ;GOT SECONDARY REG SELECT REG
1386 005720 013737 001414 001416 MOV      RXDBUF,PARCSR      ;GOT PARAMETER STATUS REGISTER
1387 005726 013737 001414 001430 MOV      RXDBUF,HUPRBF      ;GET RX BUFFER HIGH BYTE
1388 005734 005237 001430      INC      HUPRBF          ;GOT IT
1389 005740 013737 001430 001426 MOV      HUPRBF,HUPPSR      ;GOT PAR STATUS REG HIGH BYTE
1390 005746 013737 001426 001420 MOV      HUPPSR,TXCSR      ;GET TX CONTROL REGISTER
1391 005754 005237 001420      INC      TXCSR          ;GOT IT
1392 005760 013737 001420 001436 MOV      TXCSR,HUPTCR      ;GET TX CONTROL REG HIGH BYTE
1393 005766 005237 001436      INC      HUPTCR          ;GOT IT
1394 005772 013737 001436 001422 MOV      HUPTCR,TXDBUF      ;BET TX BUFFER
1395 006000 005237 001422      INC      TXDBUF          ;GOT IT
1396 006004 013737 001422 001434 MOV      TXDBUF,HUPTBF      ;GET TX BUFFER HIGH BYTE
1397 006012 005237 001434      INC      HUPTBF          ;GOT IT
1398
1399 006016 013737 001402 001404 MOV      DUPRVC,DUPRPS      ;RX VECTOR
1400 006024 060037 001404      ADD      R0,DUPRPS      ;RX PRIORITY LEVEL
1401 006030 013737 001404 001406 MOV      DUPRPS,DUPTVC      ;TX VECTOR
1402 006036 060037 001406      ADD      R0,DUPTVC      ;TX VECTOR
1403 006042 013737 001406 001410 MOV      DUPTVC,DUPTPS      ;TX PRIORITY LEVEL
1404 006050 060037 001410      ADD      R0,DUPTPS      ;TX PRIORITY LEVEL
1405
1406
1407 006054 012700 001442      MOV      #L00.00,R0      ;LOAD STAU 00-00
1408 006060 012701 001440      MOV      #MASK.A,R1      ;PREPARE MASK.
1409 006064 012702 001441      MOV      #CLK.A,R2      ;PREPARE CLOCKS
1410 006070 004737 006234      JSR      PC,FIX.00      ;GO AND CALCULATE CONFIGURATION.
1411 006074 005737 000042      TST      @#42
1412 006100 001050              BNE      4$
1413 006102 032777 000002 173072 BIT      #SW01,@SWR      ;IF SW01=1,GET STARTING TEST #
1414 006110 001444              BEQ      4$
1415 006112 104402 004352      7$: TYPE      ,MCRLF
1416 006116 104403              INSTR      ;OUTPUT MESSAGE & GET INPUT STRING
1417 006120 004613              MTSTN      ;MESSAGE

```

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 39
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

1418	006122	104405			PARAM	:CONVERT STRING	
1419	006124	000001			1	:LOW LIMIT	
1420	006126	001000			1000	:HIGH LIMIT	
1421	006130	001226			TSTNO	:STORE AT THIS LOCATION	
1422	006132	000			0	:MASK	
1423	006133	001			.BYTE 1	:HOW MANY TIMES + 2	
1424	006134	012700	006364		MOV	#TST1,R0	
1425	006140	022710	012737		5\$: CMP	#12737,(R0)	
1426	006144	001017			BNE	6\$	
1427	006146	023760	001226	000002	CMP	TSTNO,2(R0)	
1428	006154	001013			BNE	6\$	
1429	006156	022760	001226	000004	CMP	#TSTNO,4(R0)	
1430	006164	001007			BNE	6\$	
1431	006166	010037	001214		MOV	R0,RETURN	:SAVE PC
1432	006172	104402	004352		TYPE	,MCRLF	
1433	006176	104402	004416		TYPE	,MR	
1434	006202	000412			BR	8\$	
1435	006204	005720			6\$: TST	(R0)+	
1436	006206	020027	010036		CMP	R0,#TLAST+10	
1437	006212	001352			BNE	5\$	
1438	006214	104402	004346		TYPE	,MQM	
1439	006220	000734			BR	7\$	
1440							
1441	006222	012737	006364	001214	4\$: MOV	#TST1,RETURN	:PREPARE RETURN ADDRESS
1442	006230	000177	172760		8\$: JMP	@RETURN	:GO START TESTING.
1443							
1444	006234	011003			FIX.00: MOV	(R0),R3	:GET PARAMETERS.
1445	006236	000207			5\$: RTS	PC	:

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 40
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

1446                                     :THIS ROUTINE PICKS UP THE ADDRESS OF
1447                                     :THE JUMPER TABLE AND LOADS R5 WITH
1448                                     :THE CORRECT DATA BASED ON THE STATE
1449                                     :OF THE JUMPER AND CONNECTOR FLAGS.
1450                                     :-----
1451
1452 006240 012100 JUMPER: MOV (R1)+,R0 ;GET THE TABLE ADDRESS
1453 006242 105737 001324 TSTB TCNFLG ;TEST THE TURN AROUND CONNECTOR FLAG
1454 006246 001406 BEQ 2$ ;BRANCH IF CONNECTOR IS MISSING
1455 006250 105737 001325 TSTB OPCLRJ ;TEST CLEAR JUMPER FLAG
1456 006254 001403 BEQ 2$ ;BRANCH IF JUMPER IS MISSING
1457 006256 011005 MOV (R0),R5 ;MOVE THE DATA TO R5, BOTH JUMPER
1458 ;AND CONNECTOR ARE THERE
1459 006260 000137 006304 JMP 5$
1460 006264 022020 2$: CMP (R0)+,(R0)+ ;POP POINTER
1461 006266 105737 001325 TSTB OPCLRJ ;TEST CLEAR JUMPER FLAG
1462 006272 001403 BEQ 3$ ;BRANCH IF MISSING
1463 006274 011005 MOV (R0),R5 ;MOVE DATA- JUMPER IN, CONNECTOR OFF
1464 006276 000137 006304 JMP 5$
1465 006302 012005 3$: MOV (R0)+,R5 ;NO CONNECTOR OR JUMPER
1466 006304 000201 5$: RTS R1 ;RETURN
1467
1468 006306 012100 OJUMPER:MOV (R1)+,R0 ;GET THE POINTER ADDRESS
1469 006310 105737 001324 TSTB TCNFLG ;CHECK FOR TURNAROUND CONNECTOR
1470 006314 001403 BEQ 4$ ;BR IF MISSING
1471 006316 011005 MOV (R0),R5 ;MOVE THE INFO TO R5
1472 006320 000137 006330 JMP 6$ ;GO BACK
1473 006324 022020 4$: CMP (R0)+,(R0)+ ;POP POINTER
1474 006326 011005 MOV (R0),R5 ;LOAD DATA TO R5
1475 006330 000201 6$: RTS R1 ;RETURN
1476
1477
1478 ;ROUTINE TO SET UP INTERRUPT VECTORS
1479 006332 012577 173044 SETVEC: MOV (R5)+,ADUPRVC
1480 006336 012577 173044 MOV (R5)+,ADUPTVC
1481 006342 112577 173036 MOVB (R5)+,ADUPRPS
1482 006346 112577 173036 MOVB (R5)+,ADUPTPS
1483 006352 000205 RTS R5
1484 006354 NO.ATRAP:
1485 006354 104001 HLT 1
1486 006356 000002 RTI
1487
1488 NO.BTRAP:
1489 006360 104002 HLT 2
1490 006362 000002 RTI
1491

```

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 41
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507 006364 012737 000001 001226
1508 006372 012737 006744 001216
1509 006400 012746 173017
1510 006404 012746 173001
1511 006410 012746 001016
1512 006414 012746 000000
1513 006420 105737 001324
1514 006424 001532
1515 006426 105737 001344
1516 006432 001034
1517 006434 012701 002010
1518 006440 105737 001336
1519 006444 001007
1520 006446 040137 006734
1521 006452 040137 006736
1522 006456 040137 006740
1523 006462 000411
1524 006464 105737 001340
1525 006470 001006
1526 006472 040137 006734
1527 006476 040137 006736
1528 006502 040137 006740
1529 006506 105737 001346
1530 006512 001004
1531 006514 005337 006734
1532 006520 005337 006736
1533 006524 004137 006306
1534 006530 006734
1535
1536 006532 005077 172654
1537 006536 052777 000400 172654
1538 006544 004737 004306
1539 006550 013703 001412
1540 006554 052777 010000 172636
1541 006562 052713 000016
1542 006566 012737 000110 006616
1543 006574 032777 004000 172620
1544 006602 001374
1545 006604 032777 004000 172610
1546 006612 001774
1547 006614 005327

:***** TEST 1 *****
:THIS TEST PROVES THE INTERACTION OF DTR!RTS!STD
:WITH RING,DSR,CTS,CARDET,STD,SRD
:AND DATA SET CHANGE ONE AND DATA SET CHANGE TWO.
:SET THE BIT AND VERIFY THE OTHER BITS ARE SET. CLEAR
:THE BIT AND VERIFY CLEAR. REPEAT FOR MRESET.
:*****

:*****
:TEST 1
:*****
:*****

TST1: MOV #1,@TSTNO
      MOV #TST2,NEXT
      MOV #173017,-(SP) ;SAVE
      MOV #173001,-(SP)
      MOV #1016,-(SP)
      MOV #0,-(SP)
      TSTB TCNFLG ;H325 TEST CONNECTOR ON?
      BEQ 6$ ;IF NO, SKIP TEST.
100$: TSTB ALJMFL
      BNE 12$
      MOV #STD!SRD,R1
      TSTB STJMFL
      BNE 101$
      BIC R1,7$
      BIC R1,7$+2
      BIC R1,7$+4
      BR 102$
101$: TSTB SRJMFL
      BNE 102$
      BIC R1,7$
      BIC R1,7$+2
      BIC R1,7$+4
102$: TSTB DSCFLG
      BNE 12$
      DEC 7$
      DEC 7$+2
12$: JSR R1,0JUMPER ;THIS CALL DETERMINES IF TURNAROUND CONNECTOR
                    ;AND OPTIONAL JUMPER ARE USED
                    ;AND LOADS R5 (EXPECTED) ACCORDINGLY.

      CLR @RXCSR
      BIS #MRESET,@TXCSR ;RESET THE DEVICE
      JSR PC,SMALL ;WAIT FOR RESET TO FINISH
      MOV RXCSR,R3 ;LOAD THE RECEIVER CONTROL REGISTER TO R3.
      BIS #MEXT,@TXCSR ;ENTER EXTERNAL MAINT. MODE
      BIS #DTR!RTS!STD,(R3) ;TURN ON DTR!RTS!STD
      MOV #110,68$ ;LOAD THE NUMBER
66$: BIT #TIMER,@TXDBUF ;CHECK THE TIMER BIT
      BNE 66$ ;BR IF SET
67$: BIT #TIMER,@TXDBUF ;CHECK THE BIT
      BEQ 67$ ;BR IF CLEAR
      DEC (PC)+ ;DECREMENT THE NUMBER

```


CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 42
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

1548 006616 000110      68$: 110      ;OF TIMES TO REPEAT
1549 006620 001365      BNE      66$      ;BR IF MORE TO GO
1550 006622 011304      MOV      (R3),R4      ;GET THE BITS FROM THE RXCSR
1551 006624 020504      CMP      R5,R4      ;R5=GOOD R4=?
1552 006626 001401      BEQ      2$      ;BRANCH IF THEY MATCH
1553 006630 104003      HLT      3      ;NO MATCH - SHOW OPR.
1554 006632 012737 006644 001220 2$: MOV      #3$,LOCK      ;SW09 SETUP
1555 006640 042705 073016      BIC      #RING!CTS!CARDET!SRD!DSR!STD!RTS!DTR,R5      ;CLEAR OUT UNWANTED BITS
1556 006644 005013      CLR      (R3)      ;CLEAR OUT THE REGISTER
1557 006646 012737 000005 006676 3$: MOV      #5,73$      ;LOAD THE NUMBER
1558 006654 032777 004000 172540 71$: BIT      #TIMER,@TXDBUF      ;CHECK THE TIMER BIT
1559 006662 001374      BNE      71$      ;BR IF SET
1560 006664 032777 004000 172530 72$: BIT      #TIMER,@TXDBUF      ;CHECK THE BIT
1561 006672 001774      BEQ      72$      ;BR IF CLEAR
1562 006674 005327      DEC      (PC)+      ;DECREMENT THE NUMBER
1563 006676 000005      73$: 5      ;OF TIMES TO REPEAT
1564 006700 001365      BNE      71$      ;BR IF MORE TO GO
1565 006702 011304      MOV      (R3),R4      ;READ BACK THE REGISTER
1566 006704 020504      CMP      R5,R4      ;R5=GOOD R4=?
1567 006706 001401      BEQ      6$      ;BRANCH IF ONLY THE DSC BITS ARE SET
1568 006710 104003      HLT      3      ;NO-GO TELL OPR
1569 006712      6$:      ;RESTORE
1570 006712 012637 006742      MOV      (SP)+,7$+6
1571 006716 012637 006740      MOV      (SP)+,7$+4
1572 006722 012637 006736      MOV      (SP)+,7$+2
1573 006726 012637 006734      MOV      (SP)+,7$
1574 006732 104400      SCOPE      ;SCOPE THE WHOLE TEST
1575 006734 173017      7$: .WORD      173017
1576 006736 173001      .WORD      173001
1577 006740 001016      .WORD      1016
1578 006742 000000      .WORD      0
1579
1580
1581      ;***** TEST 2 *****
1582      ;*TEST OF THE DUP RUNNING A BINARY COUNT
1583      ;*PATTERN WITH A CRC CALCULATION AS A SECONDARY STATION
1584      ;*****
1585
1586      ;*****
1587      ;*
1588      ;* TEST 2
1589      ;*
1590      ;*****
1591      ;*****
1592 006744 012737 000002 001226 TST2: MOV      #2,@TSTNO
1593 006752 012737 010026 001216      MOV      #TST3,NEXT
1594 006760 052777 000400 172432      BIS      #MRESET,@TXCSR      ;RESET THE DEVICE
1595 006766 004737 004306      JSR      PC,SMALL      ;WAIT FOR RESET TO FINISH
1596 006772 105737 001324      TSTB      TCNFLAG      ;H325 TEST CONNECTOR ON?
1597 006776 001403      BEQ      102$      ;IF NO, BR.
1598 007000 012737 010000 007104      MOV      #MEXT,103$+2      ;IF YES, SET MAINT
1599 007006 012737 000005 001244 102$: MOV      #5,TEMP4
1600 007014 005001      CLR      R1      ;CLEAR OUT DATA
1601 007016 012737 102010 010020      MOV      #CRC.CCITT,XPOLY      ;SET UP THE POLYNOMIAL
1602 007024 012737 177777 010024      MOV      #-1,CALBCC      ;SETUP FOR THE FIRST TIME
1603 007032 013737 010024 007054 16$: MOV      CALBCC,20$      ;ALLOW FOR THE NEXT CHARACTER

```

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 43
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

1604 007040 010137 007052      MOV      R1,17$      ;LOAD DATA
1605 007044 004537 007646      JSR      R5,SIMBCC      ;GO CALCULATE SOFTWARE BCC
1606 007050 000010              8.              ;BASED ON THESE PARAMETERS
1607 007052 000001      17$:      .BLKW      1      ;DATA
1608 007054 000001      20$:      .BLKW      1      ;PREVIOUS BCC
1609 007056 105201              INCB      R1      ;INCREMENT DATA
1610 007060 001364              BNE      16$      ;BR IF MORE TO GO
1611 007062 012737 000001 001236      MOV      #1,TEMP1      ;LOAD DATA
1612 007070 005037 001240              CLR      TEMP2      ;CLEAR EXPECTED
1613 007074 012737 000340 177776      MOV      #340,PS      ;PS = 7
1614 007102 052777 004000 172310 103$:      BIS      #SYSTST,@TXCSR      ;ENTER SYSTEM TEST MODE
1615 007110 004537 006332              JSR      R5,SETVEC      ;LOAD INTERRUPT VECTORS
1616 007114 007402              11$              ;RECEIVER
1617 007116 007450              12$              ;TRANSMITTER
1618 007120      340      340      .BYTE      340,340      ;LEVEL
1619
1620      ;*****
1621      ;**FOLLOWING CODE FOR TESTING DUP11 CONNECTED TO MODEM WITH ANALOG LOOPBACK ENABLED**
1622      ;*****
1622 007122 105737 001342      TSTB      MDMFLG      ;MODEM CONNECTED?
1623 007126 001427              BEQ      104$      ;IF NO, BR.
1624 007130 013703 001310      MOV      REPEAT,R3      ;REPEAT CTSDLY
1625 007134 012777 010000 172256      MOV      #MEXT,@TXCSR      ;SET EXTERNAL MAINTENANCE
1626 007142 013737 001314 007372      MOV      DELAY,73$      ;SET TIMER
1627 007150 052777 000006 172234      BIS      #DTR!RTS,@RXCSR      ;ENABLE MODEM.
1628 007156 013702 001312      106$:      MOV      CTSDLY,R2      ;WAIT FOR CTS
1629 007162 032777 020000 172222 105$:      BIT      #CTS,@RXCSR      ;CLEAR TO SEND UP?
1630 007170 001006              BNE      104$      ;IF YES, BR.
1631 007172 005302              DEC      R2      ;STEP COUNTER IF NO.
1632 007174 001372              BNE      105$      ;IF NO TRY AGAIN.
1633 007176 005303              DEC      R3      ;ALLOW CTSDLY TO REPEAT
1634 007200 001366              BNE      106$      ;BR IF NOT COMPLETE
1635 007202 104007              HLT      7      ;CTS STILL NOT ACTIVE
1636 007204 000475              BR      6$      ;DO NOT CONTINUE TEST
1637
1638 007206 052777 000020 172176 104$:      BIS      #RCVEN,@RXCSR      ;TURN ON THE RECEIVER
1639 007214 052777 000100 172170      BIS      #RINTEN,@RXCSR      ;TURN ON REC INTERRUPT ENABLE
1640 007222 105777 172172      1$:      TSTB      @TXCSR      ;TEST FOR TX DONE
1641 007226 100375              BPL      1$      ;BR IF NOT SET
1642 007230 052777 000020 172162 2$:      BIS      #SEND,@TXCSR      ;TURN ON SEND
1643 007236 012777 000400 172156      MOV      #TSOM,@TXDBUF      ;TURN ON START OF MESSAGE
1644 007244
1645 007244 012737 000005 007274 101$:      MOV      #5,68$      ;LOAD THE NUMBER
1646 007252 032777 004000 172142 66$:      BIT      #TIMER,@TXDBUF      ;CHECK THE TIMER BIT
1647 007260 001374              BNE      66$      ;BR IF SET
1648 007262 032777 004000 172132 67$:      BIT      #TIMER,@TXDBUF      ;CHECK THE BIT
1649 007270 001774              BEQ      67$      ;BR IF CLEAR
1650 007272 005327              DEC      (PC)+      ;DECREMENT THE NUMBER
1651 007274 000005      68$:      5      ;OF TIMES TO REPEAT
1652 007276 001365              BNE      66$      ;BR IF MORE TO GO
1653 007300 005337 001244              DEC      TEMP4
1654 007304 001001              BNE      3$
1655 007306 104004              HLT      4
1656 007310 105777 172104      3$:      TSTB      @TXCSR      ;WAIT FOR DONE
1657 007314 100353              BPL      101$      ;BR IF NOT SET
1658 007316 005077 172100      4$:      CLR      @TXDBUF      ;PUSH OUT DATA
1659 007322 052777 000100 172070      BIS      #TXINTE,@TXCSR      ;TURN ON TRANSMITTER INT ENABLE

```


CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 44
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

1660 007330 005037 177776          CLR      PS          ;LOWER PROCESOR STATUS
1661 007334          5$:
1662          ;;*****
1663 007334 105737 001342          TSTB     MDMFLG      ;MODEM FLAG SET?
1664 007340 001003          BNE      71$      ;IF YES, BR
1665          ;;*****
1666 007342 012737 000040 007372    MOV      #32,,73$      ;LOAD THE NUMBER
1667 007350 032777 004000 172044    71$:    BIT      #TIMER,@TXDBUF  ;CHECK THE TIMER BIT
1668 007356 001374          BNE      71$      ;BR IF SET
1669 007360 032777 004000 172034    72$:    BIT      #TIMER,@TXDBUF  ;CHECK THE BIT
1670 007366 001774          BEQ      72$      ;BR IF CLEAR
1671 007370 005327          DEC      (PC)+      ;DECREMENT THE NUMBER
1672 007372 000040          73$:    32.      ;OF TIMES TO REPEAT
1673 007374 001365          BNE      71$      ;BR IF MORE TO GO
1674 007376 104004          HLT      4          ;FAILED TO INTERRUPT IN TIME
1675 007400 104400          6$:    SCOPE      ;SCOPE THIS TEST
1676
1677          ;INTERRUPT SERVICE ROUTINES
1678          ;-----
1679          ;RECEIVER:
1680 007402 017737 172006 001326    11$:    MOV      @RXDBUF,DATA  ;GET THE REGISTER AND DATA
1681 007410 123737 001240 001326    CMPB     TEMP2,DATA  ;CHECK IT
1682 007416 001401          BEQ      .+4      ;BR IF OK
1683 007420 104004          HLT      4          ;COMPARISON ERROR
1684 007422 105237 001240          INCB     TEMP2      ;COUNT UP EXPECTED
1685 007426 105737 001240          TSTB     TEMP2      ;CHECK TO SEE IF DONE
1686 007432 001005          BNE      7$      ;BR IF NO
1687 007434 004537 006332          JSR      R5,SETVEC  ;YES--RESET THE VECTORS
1688 007440 007554          14$      ;RECEIVER
1689 007442 007450          12$      ;TRANSMITTER
1690 007444 340          .BYTE 340,340  ;LEVEL
1691 007446 000002          7$:    RTI          ;RETURN
1692          ;TRANSMITTER:
1693 007450 113777 001236 171744    12$:    MOVB     TEMP1,@TXDBUF  ;LOAD THE TRANSMITTER BUFFER
1694 007456 105237 001236          INCB     TEMP1      ;UP THE COUNT
1695 007462 122737 000377 001236    CMPB     #377,TEMP1  ;ARE WE DONE
1696 007470 001026          BNE      13$      ;BR IF NO
1697 007472 012777 007502 171706    MOV      #21$,@DUPTVC  ;SETUP FOR NEXT PART
1698 007500 000422          BR      13$      ;LEAVE
1699 007502 012777 000377 171712    21$:    MOV      #377,@TXDBUF  ;LOAD BUFFER
1700 007510 012777 007520 171670    MOV      #22$,@DUPTVC  ;SETUP NEXT PART
1701 007516 000413          BR      13$      ;LEAVE
1702 007520 012777 001000 171674    22$:    MOV      #TEOM,@TXDBUF  ;SET END OF MSG
1703 007526 000240          NOP          ;STALL
1704 007530 000240          NOP          ;DITTO
1705 007532 042777 000120 171660    BIC      #SEND!TXINTE,@TXCSR ;TURN OFF TRANSMITTER
1706 007540 012777 006360 171640    MOV      #NO.BTRAP,@DUPTVC ;LOAD VECTOR
1707 007546 012716 007334          13$:    MOV      #5$, (SP)      ;CRUNCH STACK
1708 007552 000002          RTI          ;RETURNS
1709          ;CRC CATCH INT SVC
1710 007554 117737 171634 001326    14$:    MOVB     @RXDBUF,DATA  ;GET FIRST PART OF CRC
1711 007562 105777 171624          TSTB     @RXCSR      ;WAIT FOR SECOND PART
1712 007566 100375          BPL      .-4      ;DITTO
1713 007570 117737 171620 001327    MOVB     @RXDBUF,DATA+1 ;GET THE REST OF THE CRC
1714 007576 012716 007604          MOV      #15$, (SP)      ;SETUP FOR RETURN
1715 007602 000002          RTI          ;RETURN

```

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 45
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

1716 007604 012737 000340 177776 15$: MOV #340,PS ;RAISE PS
1717 007612 005137 010024 COM CALBCC ;INVERT BCC
1718 007616 023737 010024 001326 CMP CALBCC,DATA ;COMPARE SOFTWARE AND HARDWARE BCC
1719 007624 001401 BEQ .+4 ;BR IF OK
1720 007626 104004 HLT 4 ;BCC COMPARISON ERROR
1721 007630 052777 000400 171562 BIS #MRESET,ATXCSR ;RESET THE DEVICE
1722 007636 004737 004306 JSR PC,SMALL ;WAIT FOR RESET TO FINISH
1723 007642 000137 007400 JMP 6$ ;LEAVE

```

```

1724
1725
1726 007646 010046 SIMBCC: MOV R0,-(SP)
1727 007650 010146 MOV R1,-(SP)
1728 007652 010246 MOV R2,-(SP)
1729 007654 012537 001236 MOV (R5)+,TEMP1
1730 007660 012537 001240 MOV (R5)+,TEMP2
1731 007664 012537 001242 MOV (R5)+,TEMP3
1732 007670 005037 010022 1$: CLR BCCFBK
1733 007674 013700 001242 MOV TEMP3,R0
1734 007700 006037 001240 ROR TEMP2
1735 007704 005500 ADC R0
1736 007706 032700 000001 BIT #BIT0,R0
1737 007712 001402 BEQ 2$
1738 007714 005137 010022 COM BCCFBK
1739 007720 013700 010020 2$: MOV XPOLY,R0
1740 007724 005100 COM R0
1741 007726 040037 010022 BIC R0,BCCFBK
1742 007732 000241 CLC
1743 007734 006037 001242 ROR TEMP3
1744 007740 013700 010022 MOV BCCFBK,R0
1745 007744 013701 001242 MOV TEMP3,R1
1746 007750 010102 MOV R1,R2
1747 007752 040100 BIC R1,R0
1748 007754 043702 010022 BIC BCCFBK,R2
1749 007760 050200 BIS R2,R0
1750 007762 043737 010020 001242 BIC XPOLY,TEMP3
1751 007770 050037 001242 BIS R0,TEMP3
1752 007774 005337 001236 DEC TEMP1
1753 010000 001333 BNE 1$
1754 010002 013737 001242 010024 MOV TEMP3,CALBCC
1755 010010 012602 MOV (SP)+,R2
1756 010012 012601 MOV (SP)+,R1
1757 010014 012600 MOV (SP)+,R0
1758 010016 000205 RTS R5
1759 010020 000000 XPOLY: 0
1760 010022 000000 BCCFBK: 0
1761 010024 000000 CALBCC: 0
1762 120001 CRC16=120001
1763 102010 CRC.CCITT=102010
1764
1765
1766
1767
1768
1769
1770
1771

```

```

***** TEST 3 *****
*THIS TEST PROVES THE DEVICE WILL HANDLE THE
*DDCMP PROTOCOL. SEND AND RECEIVE SYNCs,
*FOLLOWED BY DATA,BCC,DATA AND FINAL BCC.
*****

```


CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 46
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

1772      ::*****
1773      ::*
1774      ::TEST 3
1775      ::*
1776      ::*****
1777      ::*****
1778      010026 012737 000003 001226 TST3: MOV #3,@TSTNO
1779      010034 012737 002352 001216      MOV #.EOP,NEXT
1780      010042 105737 001324      TSTB TCNFLG      ;H325 TEST CONNECTOR ON?
1781      010046 001403      BEQ 101$      ;IF NO, BRF
1782      010050 012737 010000 010144      MOV #MEXT,102$+2      ;IF YES, SET MAINTENANCE
1783      010056 012737 000340 177776 101$: MOV #340,PS      ;RAISE PROCESSOR STATUS
1784      010064 004537 006332      JSR R5,SETVEC      ;SET UP VECTORS
1785      010070 010626      10$      ;BASED ON
1786      010072 010450      2$      ;THESE
1787      010074 340 340      .BYTE 340,340      ;PARAMETERS
1788      010076 005037 001236      CLR TEMP1
1789      010102 005037 001240      CLR TEMP2
1790      010106 005037 001242      CLR TEMP3
1791      010112 005037 001244      CLR TEMP4
1792      010116 005037 001246      CLR TEMP5
1793      010122 052777 000400 171270      BIS #MRESET,@TXCSR      ;RESET THE DEVICE
1794      010130 004737 004306      JSR PC,SMALL      ;WAIT FOR RESET TO FINISH
1795      010134 012777 100026 171254      MOV #DECMOD!26,@PARCSR      ;LOAD THE MODE AND SYNC CHARACTER
1796      010142      102$:
1797      010142 052777 004000 171250      BIS #SYSTST,@TXCSR      ;ENTER SYSTEM TEST MODE
1798      1798      ::*****
1799      1799      ::**FOLLOWING CODE FOR TESTING DUP11 CONNECTED TO MODEM WITH ANALOG LOOPBACK ENABLED**
1800      1800      ::*****
1801      010150 105737 001342      TSTB MDMFLG      ;MODEM CONNECTED?
1802      010154 001427      BEQ 103$      ;IF NO, BR.
1803      010156 013703 001310      MOV REPEAT,R3      ;REPEAT CTSDLY
1804      010162 012777 010000 171230      MOV #MEXT,@TXCSR      ;SET EXTERNAL MAINTENANCE
1805      010170 013737 001314 010422      MOV DELAY,74$      ;SET TIMER.
1806      010176 052777 000006 171206      BIS #DTR!RTS,@RXCSR      ;ENABLE MODEM.
1807      010204 013702 001312 105$: MOV CTSDLY,R2      ;WAIT FOR CTS
1808      010210 032777 020000 171174 104$: BIT #CTS,@RXCSR      ;CLEAR TO SEND UP?
1809      010216 001006      BNE 103$      ;IF YES,BR.
1810      010220 005302      DEC R2      ;STEP COUNT IF NO.
1811      010222 001372      BNE 104$      ;TRY AGAIN.
1812      010224 005303      DEC R3      ;ALLOW CTSDLY TO REPEAT
1813      010226 001366      BNE 105$      ;BR IF NOT COMPLETE
1814      010230 104007      HLT 7      ;CTS STILL NOT ACTIVE
1815      010232 000476      BR 1$      ;DO NOT CONTINUE TEST.
1816      1816      ::*****
1817      010234 103$:
1818      010234 052777 000420 171150      BIS #RCVEN!STPSYN,@RXCSR      ;LOAD RCVEN!STPSYN
1819      010242 052777 000020 171150      BIS #SEND,@TXCSR      ;TURN ON TRANSMITTER
1820      010250 012777 000426 171144      MOV #TSOM!26,@TXDBUF      ;OUTPUT A SYNC CHAR
1821      010256 012737 000030 010306      MOV #30,68$      ;LOAD THE NUMBER
1822      010264 032777 004000 171130 66$: BIT #TIMER,@TXDBUF      ;CHECK THE TIMER BIT
1823      010272 001374      BNE 66$      ;BR IF SET
1824      010274 032777 004000 171120 67$: BIT #TIMER,@TXDBUF      ;CHECK THE BIT
1825      010302 001774      BEQ 67$      ;BR IF CLEAR
1826      010304 005327      DEC (PC)+      ;DECREMENT THE NUMBER
1827      010306 000030      68$: 30      ;OF TIMES TO REPEAT

```

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 47
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

1828 010310 001365      BNE      66$      ;BR IF MORE TO GO
1829 010312 105777 171102 TSTB      @TXCSR
1830 010316 100401      BMI      +4
1831 010320 104005      HLT      5      ;EXTERNAL CLOCKING STOPPED
1832 010322 012777 000426 171072 MOV      #TSOM!26,@TXDBUF
1833 010330 105777 171064 69$: TSTB      @TXCSR      ;CHECK DONE
1834 010334 100375      BPL      69$      ;BR IF NOT SET
1835 010336 012777 000426 171056 MOV      #TSOM!26,@TXDBUF      ;SEND SYNC
1836 010344 052777 000100 171040 BIS      #RINTEN,@RXCSR      ;TURN ON INTERRUPTS
1837 010352 052777 000100 171040 BIS      #TXINTE,@TXCSR      ;DITTO
1838 010360 005037 177776      CLR      PS      ;LOWER PROCESSOR STATUS
1839 010364
1840      100$:
1841      ;;*****
1841 010364 105737 001342      TSTB      MDMFLG      ;MODEM FLAG SET?
1842 010370 001003      BNE      72$      ;IF YES, BR
1843      ;;*****
1844 010372 012737 000144 010422 MOV      #100,74$      ;LOAD THE NUMBER
1845 010400 032777 004000 171014 72$: BIT      #TIMER,@TXDBUF      ;CHECK THE TIMER BIT
1846 010406 001374      BNE      72$      ;BR IF SET
1847 010410 032777 004000 171004 73$: BIT      #TIMER,@TXDBUF      ;CHECK THE BIT
1848 010416 001774      BEQ      73$      ;BR IF CLEAR
1849 010420 005327      DEC      (PC)+      ;DECREMENT THE NUMBER
1850 010422 000144      74$: 100.      ;OF TIMES TO REPEAT
1851 010424 001365      BNE      72$      ;BR IF MORE TO GO
1852 010426 104005      HLT      5      ;FAILED TO FINISH TEST
1853 010430
1854 010430 052777 000400 170762 1$: BIS      #MRESET,@TXCSR      ;RESET THE DEVICE
1855 010436 004737 004306      JSR      PC,SMALL      ;WAIT FOR RESET TO FINISH
1856 010442 012706 001150      MOV      #STACK,SP      ;RESET THE STACK
1857 010446 104400      SCOPE      ;SCOPE THIS TEST
1858
1859      ;INTERRUPT SERVICE ROUTINES
1860      ;TRANSMITTER
1861
1862 010450 012777 000252 170744 2$: MOV      #252,@TXDBUF      ;LOAD FIRST DATA CHAR
1863 010456 012737 000026 001236      MOV      #26,TEMP1      ;LOAD DATA
1864 010464 012777 010474 170714      MOV      #3$,@DUPTVC      ;RELOAD VECTOR
1865 010472 000452      BR      7$      ;LEAVE
1866 010474 013777 001236 170720 3$: MOV      TEMP1,@TXDBUF      ;MOV DATA TO BUFFER
1867 010502 105237 001236      INCB      TEMP1      ;UPDATE DATA
1868 010506 122737 000032 001236      CMPB      #32,TEMP1      ;CHECK FOR DONE
1869 010514 001041      BNE      7$      ;BR IF MORE TO SEND
1870 010516 012777 010526 170662      MOV      #4$,@DUPTVC      ;RELOAD VECTOR
1871 010524 000435      BR      7$      ;RETURN
1872 010526 012777 001000 170666 4$: MOV      #TEOM,@TXDBUF      ;PUT OUT BCC
1873 010534 012777 010544 170644      MOV      #5$,@DUPTVC      ;RELOAD VECTOR
1874 010542 000426      BR      7$      ;RETURN
1875 010544 013777 001240 170650 5$: MOV      TEMP2,@TXDBUF      ;LOAD DATA
1876 010552 105237 001240      INCB      TEMP2      ;UPDATE DATA
1877 010556 122737 000100 001240      CMPB      #100,TEMP2      ;CHECK FOR FINISH
1878 010564 001015      BNE      7$      ;BR IF MORE TO GO
1879 010566 012777 010576 170612      MOV      #6$,@DUPTVC      ;RELOAD VECTOR
1880 010574 000411      BR      7$      ;RETURN
1881 010576 012777 001000 170616 6$: MOV      #TEOM,@TXDBUF      ;PUSH OUT DATA BCC
1882 010604 042777 000120 170606      BIC      #SEND!TXINTE,@TXCSR      ;SHUT DOWN TRANSMITTER
1883 010612 012777 006360 170566      MOV      #NO.BTRAP,@DUPTVC      ;RESET VECTOR

```


ADDRESS	OPCODE	OPERAND1	OPERAND2	OPERAND3	OPERAND4	OPERAND5	OPERAND6	OPERAND7	OPERAND8	OPERAND9	OPERAND10	OPERAND11	OPERAND12	OPERAND13	OPERAND14	OPERAND15	OPERAND16	OPERAND17	OPERAND18	OPERAND19	OPERAND20	OPERAND21	OPERAND22	OPERAND23	OPERAND24	OPERAND25	OPERAND26	OPERAND27	OPERAND28	OPERAND29	OPERAND30	OPERAND31	OPERAND32	OPERAND33	OPERAND34	OPERAND35	OPERAND36	OPERAND37	OPERAND38	OPERAND39	OPERAND40	OPERAND41	OPERAND42	OPERAND43	OPERAND44	OPERAND45	OPERAND46	OPERAND47	OPERAND48	OPERAND49	OPERAND50	OPERAND51	OPERAND52	OPERAND53	OPERAND54	OPERAND55	OPERAND56	OPERAND57	OPERAND58	OPERAND59	OPERAND60	OPERAND61	OPERAND62	OPERAND63	OPERAND64	OPERAND65	OPERAND66	OPERAND67	OPERAND68	OPERAND69	OPERAND70	OPERAND71	OPERAND72	OPERAND73	OPERAND74	OPERAND75	OPERAND76	OPERAND77	OPERAND78	OPERAND79	OPERAND80	OPERAND81	OPERAND82	OPERAND83	OPERAND84	OPERAND85	OPERAND86	OPERAND87	OPERAND88	OPERAND89	OPERAND90	OPERAND91	OPERAND92	OPERAND93	OPERAND94	OPERAND95	OPERAND96	OPERAND97	OPERAND98	OPERAND99	OPERAND100	OPERAND101	OPERAND102	OPERAND103	OPERAND104	OPERAND105	OPERAND106	OPERAND107	OPERAND108	OPERAND109	OPERAND110	OPERAND111	OPERAND112	OPERAND113	OPERAND114	OPERAND115	OPERAND116	OPERAND117	OPERAND118	OPERAND119	OPERAND120	OPERAND121	OPERAND122	OPERAND123	OPERAND124	OPERAND125	OPERAND126	OPERAND127	OPERAND128	OPERAND129	OPERAND130	OPERAND131	OPERAND132	OPERAND133	OPERAND134	OPERAND135	OPERAND136	OPERAND137	OPERAND138	OPERAND139	OPERAND140	OPERAND141	OPERAND142	OPERAND143	OPERAND144	OPERAND145	OPERAND146	OPERAND147	OPERAND148	OPERAND149	OPERAND150	OPERAND151	OPERAND152	OPERAND153	OPERAND154	OPERAND155	OPERAND156	OPERAND157	OPERAND158	OPERAND159	OPERAND160	OPERAND161	OPERAND162	OPERAND163	OPERAND164	OPERAND165	OPERAND166	OPERAND167	OPERAND168	OPERAND169	OPERAND170	OPERAND171	OPERAND172	OPERAND173	OPERAND174	OPERAND175	OPERAND176	OPERAND177	OPERAND178	OPERAND179	OPERAND180	OPERAND181	OPERAND182	OPERAND183	OPERAND184	OPERAND185	OPERAND186	OPERAND187	OPERAND188	OPERAND189	OPERAND190	OPERAND191	OPERAND192	OPERAND193	OPERAND194	OPERAND195	OPERAND196	OPERAND197	OPERAND198	OPERAND199	OPERAND200	OPERAND201	OPERAND202	OPERAND203	OPERAND204	OPERAND205	OPERAND206	OPERAND207	OPERAND208	OPERAND209	OPERAND210	OPERAND211	OPERAND212	OPERAND213	OPERAND214	OPERAND215	OPERAND216	OPERAND217	OPERAND218	OPERAND219	OPERAND220	OPERAND221	OPERAND222	OPERAND223	OPERAND224	OPERAND225	OPERAND226	OPERAND227	OPERAND228	OPERAND229	OPERAND230	OPERAND231	OPERAND232	OPERAND233	OPERAND234	OPERAND235	OPERAND236	OPERAND237	OPERAND238	OPERAND239	OPERAND240	OPERAND241	OPERAND242	OPERAND243	OPERAND244	OPERAND245	OPERAND246	OPERAND247	OPERAND248	OPERAND249	OPERAND250	OPERAND251	OPERAND252	OPERAND253	OPERAND254	OPERAND255	OPERAND256	OPERAND257	OPERAND258	OPERAND259	OPERAND260	OPERAND261	OPERAND262	OPERAND263	OPERAND264	OPERAND265	OPERAND266	OPERAND267	OPERAND268	OPERAND269	OPERAND270	OPERAND271	OPERAND272	OPERAND273	OPERAND274	OPERAND275	OPERAND276	OPERAND277	OPERAND278	OPERAND279	OPERAND280	OPERAND281	OPERAND282	OPERAND283	OPERAND284	OPERAND285	OPERAND286	OPERAND287	OPERAND288	OPERAND289	OPERAND290	OPERAND291	OPERAND292	OPERAND293	OPERAND294	OPERAND295	OPERAND296	OPERAND297	OPERAND298	OPERAND299	OPERAND300	OPERAND301	OPERAND302	OPERAND303	OPERAND304	OPERAND305	OPERAND306	OPERAND307	OPERAND308	OPERAND309	OPERAND310	OPERAND311	OPERAND312	OPERAND313	OPERAND314	OPERAND315	OPERAND316	OPERAND317	OPERAND318	OPERAND319	OPERAND320	OPERAND321	OPERAND322	OPERAND323	OPERAND324	OPERAND325	OPERAND326	OPERAND327	OPERAND328	OPERAND329	OPERAND330	OPERAND331	OPERAND332	OPERAND333	OPERAND334	OPERAND335	OPERAND336	OPERAND337	OPERAND338	OPERAND339	OPERAND340	OPERAND341	OPERAND342	OPERAND343	OPERAND344	OPERAND345	OPERAND346	OPERAND347	OPERAND348	OPERAND349	OPERAND350	OPERAND351	OPERAND352	OPERAND353	OPERAND354	OPERAND355	OPERAND356	OPERAND357	OPERAND358	OPERAND359	OPERAND360	OPERAND361	OPERAND362	OPERAND363	OPERAND364	OPERAND365	OPERAND366	OPERAND367	OPERAND368	OPERAND369	OPERAND370	OPERAND371	OPERAND372	OPERAND373	OPERAND374	OPERAND375	OPERAND376	OPERAND377	OPERAND378	OPERAND379	OPERAND380</
---------	--------	----------	----------	----------	----------	----------	----------	----------	----------	----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	------------	--------------

Year	Address	Hex	Dec	Label	Op	Op2	Op3	Op4	Op5	Op6	Op7	Op8	Op9	Op10	Op11	Op12	Op13	Op14	Op15	Op16	Op17	Op18	Op19	Op20	Op21	Op22	Op23	Op24	Op25	Op26	Op27	Op28	Op29	Op30	Op31	Op32	Op33	Op34	Op35	Op36	Op37	Op38	Op39	Op40	Op41	Op42	Op43	Op44	Op45	Op46	Op47	Op48	Op49	Op50	Op51	Op52	Op53	Op54	Op55	Op56	Op57	Op58	Op59	Op60	Op61	Op62	Op63	Op64	Op65	Op66	Op67	Op68	Op69	Op70	Op71	Op72	Op73	Op74	Op75	Op76	Op77	Op78	Op79	Op80	Op81	Op82	Op83	Op84	Op85	Op86	Op87	Op88	Op89	Op90	Op91	Op92	Op93	Op94	Op95	Op96	Op97	Op98	Op99	Op100	Op101	Op102	Op103	Op104	Op105	Op106	Op107	Op108	Op109	Op110	Op111	Op112	Op113	Op114	Op115	Op116	Op117	Op118	Op119	Op120	Op121	Op122	Op123	Op124	Op125	Op126	Op127	Op128	Op129	Op130	Op131	Op132	Op133	Op134	Op135	Op136	Op137	Op138	Op139	Op140	Op141	Op142	Op143	Op144	Op145	Op146	Op147	Op148	Op149	Op150	Op151	Op152	Op153	Op154	Op155	Op156	Op157	Op158	Op159	Op160	Op161	Op162	Op163	Op164	Op165	Op166	Op167	Op168	Op169	Op170	Op171	Op172	Op173	Op174	Op175	Op176	Op177	Op178	Op179	Op180	Op181	Op182	Op183	Op184	Op185	Op186	Op187	Op188	Op189	Op190	Op191	Op192	Op193	Op194	Op195	Op196	Op197	Op198	Op199	Op200	Op201	Op202	Op203	Op204	Op205	Op206	Op207	Op208	Op209	Op210	Op211	Op212	Op213	Op214	Op215	Op216	Op217	Op218	Op219	Op220	Op221	Op222	Op223	Op224	Op225	Op226	Op227	Op228	Op229	Op230	Op231	Op232	Op233	Op234	Op235	Op236	Op237	Op238	Op239	Op240	Op241	Op242	Op243	Op244	Op245	Op246	Op247	Op248	Op249	Op250	Op251	Op252	Op253	Op254	Op255	Op256	Op257	Op258	Op259	Op260	Op261	Op262	Op263	Op264	Op265	Op266	Op267	Op268	Op269	Op270	Op271	Op272	Op273	Op274	Op275	Op276	Op277	Op278	Op279	Op280	Op281	Op282	Op283	Op284	Op285	Op286	Op287	Op288	Op289	Op290	Op291	Op292	Op293	Op294	Op295	Op296	Op297	Op298	Op299	Op300	Op301	Op302	Op303	Op304	Op305	Op306	Op307	Op308	Op309	Op310	Op311	Op312	Op313	Op314	Op315	Op316	Op317	Op318	Op319	Op320	Op321	Op322	Op323	Op324	Op325	Op326	Op327	Op328	Op329	Op330	Op331	Op332	Op333	Op334	Op335	Op336	Op337	Op338	Op339	Op340	Op341	Op342	Op343	Op344	Op345	Op346	Op347	Op348	Op349	Op350	Op351	Op352	Op353	Op354	Op355	Op356	Op357	Op358	Op359	Op360	Op361	Op362	Op363	Op364	Op365	Op366	Op367	Op368	Op369	Op370	Op371	Op372	Op373	Op374	Op375	Op376	Op377	Op378	Op379	Op380	Op381	Op382	Op383	Op384	Op385	Op386	Op387	Op388	Op389	Op390	Op391	Op392	Op393	Op394	Op395	Op396	Op397	Op398	Op399	Op400	Op401	Op402	Op403	Op404	Op405	Op406	Op407	Op408	Op409	Op410	Op411	Op412	Op413	Op414	Op415	Op416
------	---------	-----	-----	-------	----	-----	-----	-----	-----	-----	-----	-----	-----	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 50
 CZDPEC.P11 19-JUL-83 17:09 END OF PASS ROUTINE

```

1955 011176 052777 042516 050130 EM1: .ASCIZ <377>/UNEXPECTED INTERRUPT ON VECTOR 'A' /
(1) 011243 377 047125 054105 EM2: .ASCIZ <377>/UNEXPECTED INTERRUPT ON VECTOR 'B' /
(1) 011310 042777 051122 051117 EM3: .ASCIZ <377>/ERROR WHEN USING MODEM LEADS /
(1) 011347 377 051105 047522 EM4: .ASCIZ <377>/ERROR IN SDLC /
(1) 011367 377 051105 047522 EM5: .ASCIZ <377>/ERROR IN DECMODE /
(1) 011412 051377 047125 042040 EM6: .ASCIZ <377>/RUN DIAGNOSTICS /
(1) 011434 041777 042514 051101 EM7: .ASCIZ <377>/CLEAR TO SEND NOT ACTIVE/
(1) 011466 041777 042514 051101 EM8: .ASCIZ <377>/CLEAR TO SEND STILL NOT ACTIVE-TEST ABORTED/
(1) 011544 .EVEN
(1)
(1) 011544 .ERRTAB:
(1) 011544 000000 0
(1) 011546 000000 0
(1) 011550 000000 0
(1) 011552 011176 EM1
(1) 011554 011412 EM6 ;HALT 1
(1) 011556 000000 0
(1)
(1) 011560 011243 EM2
(1) 011562 011412 EM6 ;HALT 2
(1) 011564 000000 0
(1)
(1) 011566 011310 EM3
(1) 011570 011412 EM6 ;HALT 3
(1) 011572 000000 0
(1)
(1) 011574 011347 EM4
(1) 011576 011412 EM6 ;HALT 4
(1) 011600 000000 0
(1)
(1) 011602 011367 EM5
(1) 011604 011412 EM6 ;HALT 5
(1) 011606 000000 0
(1) 011610 011434 EM7
(1) 011612 000000 0 ;HALT 6
(1) 011614 000000 0
(1)
(1) 011616 011466 EM8
(1) 011620 000000 0 ;HALT 7
(1) 011622 000000 0
(1) 011624
1956 000001 CORMAX:
.END

```

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 52
 CZDPEC.P11 19-JUL-83 17:09 CROSS REFERENCE TABLE -- USER SYMBOLS

ADRCNT= 003315	1005*	1041*	1050#						
ALJMF 001344	642#	775*	799*	811	812	1515			
BCCFBK 010022	1732*	1738*	1741*	1744	1748	1760#			
BINWRD 003620	1065*	1066	1103#						
BITW = 002000	606#								
BIT0 = 000001	469#	588	1736						
BIT1 = 000002	468#	587							
BIT10 = 002000	459#	578	593	606	626				
BIT11 = 004000	458#	577	605	625					
BIT12 = 010000	457#	576	592	599	604	624			
BIT13 = 020000	456#	575	603	623					
BIT14 = 040000	455#	574	591	602	622	923			
BIT15 = 100000	454#	573	590	597	601	621			
BIT2 = 000004	467#	586	863						
BIT3 = 000010	466#	585	612						
BIT4 = 000020	465#	584	611						
BIT5 = 000040	464#	583							
BIT6 = 000100	463#	582	610						
BIT7 = 000200	462#	581	609						
BIT8 = 000400	461#	580	595	608	628				
BIT9 = 001000	460#	579	594	598	607	627			
BRW 002666	869	945#							
BRX 002670	870	946#							
CALBCC 010024	1602*	1603	1717*	1718	1754*	1761#			
CARDET= 010000	576#	1555							
CHRCNT 003616	1063*	1067	1083*	1101#	1102				
CLK = 020000	603#								
CLK.A 001441	712#	1409							
CNVRT = 104411	681#	886	888	890	892	1176	1178		
CONVRT= 104410	679#	851	1192						
CORMAX 011624	1955#	1956							
CRCEN = 001000	598#								
CRCERR= 010000	592#	1922	1948						
CRC.CC= 102010	1601	1763#							
CRC16 = 120001	1762#								
CTS = 020000	575#	1555	1629	1808					
CTSDLY 001312	563#	1628	1807						
CYCLE 005624	871	904	905	1371#					
DATA 001326	635#	1680*	1681	1710*	1713*	1718	1921*	1922	1947*
DATABP 004172	1165*	1168	1190	1193#					
DATAHD 004160	1164*	1186	1189#						
DECMOD= 100000	597#	1795							
DELAY 001314	564#	1626	1805						
DEVADR 003312	1003*	1038	1048#						
DISPLA 001200	513#	759*	883*						
DISPRE 000174	501#	759							
DSCA = 100000	573#								
DSCB = 000001	588#								
DSCFLG 001346	643#	829	1529						
DSINTE= 000040	583#								
DSR = 001000	579#	1555							
DTR = 000002	587#	1541	1555	1627	1806				
DUPACT 001316	565#	747*	832*	839*	1371				
DUPCRO 001500	722#	781	833						
DUPNUM 001317	566#	745*	830*	894					
DUPRPS 001404	691#	1399*	1400*	1401	1481*				

DUPRVC	001402	690#	911	1378*	1399	1479*	1901*	1913*	1919*	1925*	1938*						
DUPSEC	001424	699#	1385*														
DUPTPS	001410	693#	1403*	1404*	1482*												
DUPTRO	001502	723#	789														
DUPTVC	001406	692#	1401*	1402*	1403	1480*	1697*	1700*	1706*	1864*	1870*	1873*	1879*	1883*			
DUP.EN	001506	726#	772														
DUP.MA	001500	721#	770	838	848	1376											
DUP0.A	001504	724#															
EM1	011176	1955#															
EM2	011243	1955#															
EM3	011310	1955#															
EM4	011347	1955#															
EM5	011367	1955#															
EM6	011412	1955#															
EM7	011434	1955#															
EM8	011466	1955#															
ERRCNT	001232	534#	748*	917	1203*												
ERRFLG	001351	650#	743*	881*	937*	1153*	1166	1180*									
ERRMSG	004146	1163*	1181	1184#													
ERTAB0	004272	1178	1212#														
EXIT =	000000	470#															
EXITER	004226	1198	1203#														
FIX.OO	006234	1410	1444#														
FLAG	001334	638#															
HALTS	004176	1149	1195#														
HDXEN =	000010	612#															
HILIM	003310	1002*	1029	1047#													
HUPPSR	001426	700#	1389*	1390													
HUPRBF	001430	701#	1387*	1388*	1389												
HUPRCR	001432	702#	1381*	1382*	1383												
HUPTBF	001434	703#	1396*	1397*													
HUPTCR	001436	704#	1392*	1393*	1394												
ICOUNT	001222	530#	935	940*													
INBUF	005560	972	1008	1112*	1113	1117	1358#										
INIFLG	001350	649#															
INSTER=	104404	671#	1023	1122													
INSTR =	104403	669#	776	784	792	802	808	814	818	822	826	1416					
INSTR2	003110	979	991#														
JUMPER	006240	1452#															
LIMITS	003236	1018	1029#														
LOBITS	003314	1004*	10														

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 54
 CZDPEC.P11 19-JUL-83 17:09 CROSS REFERENCE TABLE -- USER SYMBOLS

MEPASS	004373	884	1240#					
MERRPC	004702	1177	1281#					
MERRX	004602	891	1268#					
MERR2	004421	1245#	1373					
MERR3	004470	1252#						
MEXT =	010000	616#	1540	1598	1625	1782	1804	
MIND	001332	637#	1926*	1932	1935*	1936		
MJMPR	005037	815	1298#					
MLOCK	004526	865	1258#					
MMODE =	014000	615#						
MMODEA=	004000	605#						
MMODEB=	010000	604#						
MMODEM	004741	793	1287#					
MNEW	004627	1273#						
MPAR	005161	1313#						
MPASSX	004571	889	1266#					
MPOWER	004355	1232	1237#					
MQM	004346	989	1235#	1438				
MR	004416	872	1244#	1433				
MRESET=	000400	470#	608#	1537	1594	1721	1793	1854
MSRJM	005240	823	1322#					
MSTJM	005205	819	1317#					
MTCN	005112	803	1306#					
MTDATA=	040000	602#						
MTITLE	001000	508#	765					
MTSTN	004613	1175	1270#	1417				
MTSTPC	004514	1256#						
MVEC	004726	785	1285#					
MVECX	004563	887	1264#					
NEXT	001216	528#	941	1208	1508*	1593*	1779*	
NO.ATR	006354	1484#						
NO.BTR	006360	1488#	1706	1883				
OJUMPE	006306	1468#	1533					
OPCLRJ	001325	634#	817	845*	1455	1461		
OVRRUN=	040000	591#						
PARAM =	104405	673#	778	786	1418			
PARAM1	003156	1007#	1024					
PARBIT=	000000	470#						
PARCSR	001416	696#	1386*	1795*				
PARERR	003232	1010	1012	1014	1023#	1030	1032	1034
PASCNT	001230	533#	742*	882*	883	914		
PERFOR=	000000	470#						
POPPO =	012600	449#	1202					
POP1SP=	005726	447#						
POP2SP=	022626	451#	943					
PRIPTY	001322	632#	843*					
PRISEC=	010000	599#						
PS =	177776	440#	739*	859*	1613*	1660*	1716*	1783* 1838*
PUSHRO=	010046	448#	1199					
PUSH1S=	005746	446#						
PUSH2S=	024646	450#						
PWRUP	004322	1226	1228#					
QV.FLG	001353	652#	744*	893*	932			
RABORT=	002000	593#						
RCRCIN=	040000	622#						
RCRC7T=	100000	621#						

[illegible]

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 56
 CZDPEC.P11 19-JUL-83 17:09 CROSS REFERENCE TABLE -- USER SYMBOLS

SW01 = 000002	421#	1413																		
SW02 = 000004	420#																			
SW03 = 000010	418#																			
SW04 = 000020	417#																			
SW05 = 000040	416#																			
SW06 = 000100	415#																			
SW07 = 000200	414#																			
SW08 = 000400	413#	1204																		
SW09 = 001000	412#	947																		
SW10 = 002000	411#	1206																		
SW11 = 004000	410#	930																		
SW12 = 010000	409#	953	1143																	
SW13 = 020000	408#	1148																		
SW14 = 040000	407#																			
SW15 = 100000	406#																			
SYSTST= 004000	617#	1614	1797																	
TABORT= 002000	626#																			
TCNFLG 001324	633#	798*	805	806	844*	1453	1469	1513	1596	1780										
TCRCIN= 010000	624#																			
TCRC7T= 020000	623#																			
TEMP 005454	1068	1354#																		
TEMP1 001236	539#	844	845	848*	849	853*	1349	1611*	1693	1694*	1695	1729*	1752*							
	1788*	1863*	1866	1867*	1868															
TEMP2 001240	540#	849*	1351	1612*	1681	1684*	1685	1730*	1734*	1789*	1875	1876*	1877							
TEMP3 001242	541#	1731*	1733	1743*	1745	1750*	1751*	1754	1790*	1889*	1891	1876*	1877							
TEMP4 001244	542#	1599*	1653*	1791*	1890*	1894	1897	1903*	1904	1907	1915*	1916	1928*							
	1929	1932	1940*	1941																
TEMP5 001246	543#	1792*	1900*	1907	1910*	1911														
TEOM = 001000	627#	1702	1872	1881																
TIMER = 004000	625#	1543	1545	1558	1560	1646	1648	1667	1669	1822	1824	1845	1847							
TKCSR 001204	519#	926	974																	
TKDBR 001206	520#	928	976	982																
TLAST = 010026	1436	1955#																		
TPCSR 001210	521#	958	980	1145																
TPDBR 001212	522#	960*	982*	1147*																
TRPOK 003710	1134#																			
TRP.PC 005622	1360#																			
TSOM = 000400	628#	1643	1820	1832	1835															
TSTNO 001226	532#	750*	1217	1421	1427	1429	1507*	1592*	1778*											
TST1 006364	1424	1441	1507#																	
TST2 006744	1508	1592#																		
TST3 010026	1593	1778#	1955																	
TST4 = ***** U	1779																			
TTST 002554	866*	867*	869*	870*	924#															
TWOSYN= 000000	470#																			
TXACT = 001000	607#																			
TXCSR 001420	697#	1390*	1391*	1392	1537*	1540*	1594*	1614*	1625*	1640	1642*	1656	1659*							
	1705*	1721*	1793*	1797*	1804*	1819*	1829	1833	1837*	1854*	1882*	1658*	1667							
TXDBUF 001422	698#	1394*	1395*	1396	1543	1545	1558	1560	1643*	1646	1648	1658*	1667							
	1669	1693*	1699*	1702*	1820*	1822	1824	1832*	1835*	1845	1847	1862*	1866*							
	1872*	1875*	1881*																	
TXDLAT= 100000	601#																			
TXDONE= 000200	609#																			
TXINTE= 000100	610#	1659	1705	1837	1882															
TYPDAT 004162	1169	1187	1190#																	
TYPE = 104402	667#	765	847	865	872	884	885	887	889	891	957	970	989							

CROSS REFERENCE TABLE -- USER SYMBOLS

[illegible]

CZDPE MACY11 30A(1052) 20-JUL-83 13:32 PAGE 59
 CZDPEC.P11 19-JUL-83 17:09 CROSS REFERENCE TABLE -- MACRO NAMES

DUPEND	9#	874												
DUPFRN	9#	389												
HLT	452#	1485	1489	1553	1568	1635	1655	1674	1683	1720	1814	1831	1852	1893
	1899	1906	1909	1918	1924	1931	1934	1943	1950					
POP	7#	1569												
PUSH	5#	1509												
QQQ	8#													
\$BINCT	389#	1579												
\$BT	389#	1492												
\$BUFFE	9#	1353												
\$CLRVE	8#													
\$CYCLE	9#	1362												
\$DECST	389#	1793												
\$DEC22	389#	1765												
\$EOP	4#	874												
\$ERRTA	9#													
\$FINI	3#	1955												
\$GETFL	5#	792	802	808	814	818	822	826						
\$GETPA	5#	776	784	1416										
\$HEADE	2#	389												
\$JMPR	389#	1446												
\$MSG	8#	1235												
\$MSGA	1955#													
\$PFAIL	8#	1223												
\$QUEST	5#	770												
\$RESET	9#	1537	1594	1721	1793	1853								
\$SCOPE	3#	918												
\$SETFL	5#	1105												
\$SETVE	389#	1477												
\$SIMBC	389#	1726												
\$SMALL	9#	1218												
\$SYNC	389#	1833												
\$TRPDE	8#	663	665	667	669	671	673	675	677	679	681	683		
\$TSTN	3#	1501	1586	1772										
\$VARIA	2#	506												
\$WAIT	5#	1542	1557	1644	1666	1821	1844							
\$XZ	8#	1493	1499	1581	1584	1766	1770							

. ABS. 011624 000

ERRORS DETECTED: 0

CZDPEC.BIN,CZDPEC.SEQ/CRF/SOL/NL:TOC=CZDPEC.MAC,CZDPEC.P11
 RUN-TIME: 4 6 .6 SECONDS
 RUN-TIME RATIO: 41/11=3.5
 CORE USED: 17K (33 PAGES)