

DH11

DH11 AUTO ECHO LOG
CZDHHCO

AH-FG27C-MC

1 OF 1 OCT 1985

COPYRIGHT© 1972-85

digital
MADE IN USA



.REM !

IDENTIFICATION

PRODUCT CODE: AC-8472C-MC
PRODUCT NAME: CZDHHCO DH11 AUTO-ECHO TEST
DATE: JUNE 1985
MAINTAINER: NAC SOFTWARE ENGINEERING
AUTHOR: G. BAISLEY

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES

COPYRIGHT (C) 1985 BY DIGITAL EQUIPMENT CORPORATION

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48

1.0 ABSTRACT

VERIFIES THAT THE AUTO ECHO FEATURE OF THE DM11 WORKS.

2.0 REQUIREMENTS

2.1 EQUIPMENT

PDP-11 FAMILY STANDARD COMPUTER WITH 4KW OF MEMORY
ASR-33 TELETYPE OR EQUIVALENT
DM11 ASYNCHRONOUS MULTIPLEXER
DM11 MAINTENANCE CARD INSTALLED

2.2 STORAGE

THE PROGRAM LOADS INTO 4KW OF MEMORY

3.0 LOADING PROCEDURE

THE STANDARD PROCEDURE FOR LOADING ABSOLUTE BINARY TAPES IS TO BE USED

4.0 STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

4.1.1 AFTER PROGRAM LOAD (INITIAL PROGRAM START)

ALL CONSOLE SWITCHES DOWN

1
2
3
4 4.1.2 TO MODIFY DEVICE VECTOR AND CONTROL REGISTER ADDRESSES AFTER
5 PROGRAM RESTART
6

7 SW00=1
8
9

10
11 4.1.3 TO START PROGRAM AT SELECTED TEST AFTER PROGRAM RESTART
12

13 SW01=1
14
15

16
17 4.2 STARTING ADDRESS
18

19 THE STARTING ADDRESS FOR ALL TESTS IS 000200
20 THE RESTART ADDRESS FOR ALL TESTS IS 000200
21 THE STARTING ADDRESS TO ENTER A SELECTED TEST IS 000200
22
23

24
25 4.3 PROGRAM AND/OR OPERATOR ACTION
26
27

28
29 4.3.1 INITIAL PROGRAM START
30
31

32
33 4.3.1.1 LOAD PROGRAM INTO MEMORY
34
35

36
37 4.3.1.2 LOAD ADDRESS 000200
38
39

40
41 4.3.1.3 CLEAR CONSOLE SWITCHES
42
43

44
45 4.3.1.4 PRESS START
46
47

48 4.3.1.5 THE PROGRAM WILL TYPE "DH11 AUTO-ECHO TEST" AND WILL
49 THEN TYPE "VECTOR ADDRESS-" AND WAIT FOR AN INPUT FROM THE TELETYPE
50 KEYBOARD.
51

PAGE 4

1
2
3
4 4.3.1.6 TYPE IN THE ADDRESS OF THE RECEIVER INTERRUPT VECTOR FOR THE
5 DH11 TO BE TESTED FOLLOWED BY <CARRIAGE RETURN>
6
7

NOTE

8
9 WORDS IN ANGLE BRACKETS, I.E. <CARRIAGE
10 RETURN> MEAN THAT THE TELETYPE KEY WITH
11 THE NAMED FUNCTION SHOULD BE STRUCK
12
13

14
15 IF AN INCORRECT ADDRESS IS ENTERED, THE PROGRAM WILL TYPE "?" AND WILL
16 REPEAT THE SECOND MESSAGE OF 4.3.1.5
17
18

19
20 4.3.1.7 THE PROGRAM WILL TYPE "CONTROL REGISTER ADDRESS-" AND WAIT
21 FOR AN INPUT FROM THE TELETYPE KEYBOARD
22
23

24
25 4.3.1.8 TYPE IN THE ADDRESS OF THE SYSTEM CONTROL REGISTER OF THE
26 DH11 TO BE TESTED FOLLOWED BY <CARRIAGE RETURN>
27

28 IF AN INCORRECT ADDRESS IS TYPED, THE PROGRAM WILL TYPE "?" AND WILL
29 THEN REPEAT THE OF 4.3.1.7
30
31

32
33 4.3.1.9 THE PROGRAM WILL TYPE "R" TO INDICATE THAT IT IS ABOUT TO
34 START TESTING, AND THEN TESTING WILL BEGIN
35
36

37
38 4.3.2 PROGRAM RESTART WITH ALL SWITCHES DOWN
39
40

41
42 4.3.2.1 PERFORM 4.3.1.2 TO 4.3.1.5
43
44

45
46 4.3.2.2 THE PROGRAM WILL TYPE "DH11 AUTO-ECHO TEST" AND WILL
47 THEN CONTINUE AS DESCRIBED IN 4.3.1.9
48
49

50
51 4.3.3 PROGRAM RESTART WITH SW00=1

1
2
3
4 4.3.3.1 LOAD ADDRESS 000200
5
6
7

8 4.3.3.2 SET SW01=1
9

10
11
12 4.3.3.3 PRESS START
13
14

15
16 4.3.3.4 THE PROGRAM WILL PERFORM AS DESCRIBED IN 4.3.1.5 TO 4.3.1.9
17
18

19
20 4.3.4 PROGRAM RESTART WITH SW01=1
21
22

23
24 4.3.4.1 LOAD ADDRESS 000200
25
26

27
28 4.3.4.2 SET SW01=1
29
30

31
32 4.3.4.3 PRESS START
33
34

35
36 4.3.4.4 THE PROGRAM WILL TYPE "DH11 AUTO-ECHO TEST" AND WILL
37 THEN TYPE "TEST PC-" AND WILL WAIT FOR AN INPUT FROM THE TELETYPE
38 KEYBOARD
39

40
41 4.3.4.5 TYPE IN THE ADDRESS OF THE TEST AT WHICH THE PROGRAM IS TO BE
42 STARTED FOLLOWED BY <CARRIAGE RETURN>
43
44

45
46 4.3.4.6 THE PROGRAM WILL TYPE R TO INDICATE THAT IT HAS STARTED AND
47 WILL START TESTING AT THE SELECTED TEST.
48
49

50
51 NOTE

52 CARE MUST BE TAKEN WHEN THIS FEATURE IS
53 USED, SINCE THERE IS NO PROTECTION
54 AGAINST SELECTING AN ADDRESS THAT IS IN
55 THE MIDDLE OF A TEST
56

NOTE

IF IT IS DESIRED TO LOOP ON THE TEST
THAT IS SELECTED SET SW14=1 BEFORE
ENTERING THE TEST ADDRESS

5.0 OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

SW15=1, HALT ON ERROR
SW14=1, LOOP ON CURRENT TEST
SW13=1, SUPPRESS ERROR TYPEOUT
SW11=1, INHIBIT ITERATIONS
SW10=1, ESCAPE TO NEXT TEST ON ERROR
SW09=1, FREEZE VARIABLE PARAMETER IN CURRENT TEST
SW01=1, START PROGRAM AT SELECTED TEST
SW00=1, CHANGE PARAMETERS AT PROGRAM RESTART

5.2 SUBROUTINE ABSTRACTS

5.2.1 TRAPCATCHER (LOCATIONS 000000-000776)

THIS ROUTINE IS USED TO INTERCEPT UNEXPECTED INTERRUPTS AND TRAPS.
THE AREA FROM 000000-000776 IS LOADED WITH THE FOLLOWING SEQUENCE

2
0
4
0
...
772
0
776
0

IF AN UNEXPECTED INTERRUPT OR TRAP OCCURS, THE PROGRAM WILL HALT WITH
THE PC 2 GREATER THAN THE ADDRESS TO WHICH THE PROGRAM TRAPPED. THE
PROCESSOR STACK MAY BE EXAMINED TO DETERMINE WHERE THE PROGRAM WAS
WHEN THE TRAP OR INTERRUPT OCCURED.

5.2.2 START (PROGRAM INITIALIZATION)

THIS ROUTINE INITIALIZES ALL PROGRAM FLAGS AND COUNTERS, TYPES THE PROGRAM TITLE MESSAGE, AND INPUTS THE VECTOR AND CONTROL REGISTER ADDRESSES OF THE DH11 TO BE TESTED.

5.2.3 BEGIN (PROGRAM START AND RESTART)

THIS ROUTINE IS ENTERED IMMEDIATELY AFTER "START" AND EACH TIME A PROGRAM PASS HAS BEEN COMPLETED. THE ROUTINE SETS UP THE PROCESSOR STACK AND STATUS WORD AND THEN TRANSFERS CONTROL TO THE TEST AT WHICH TESTING WILL BEGIN. IF SW01=0 WHEN THIS ROUTINE IS ENTERED TESTING WILL START AT T1 (TEST 1). IF SW01=1 WHEN THIS ROUTINE IS ENTERED, TESTING WILL START AT THE PC ENTERED FROM THE TELETYPE KEYBOARD.

5.2.4 EOP (END OF PASS)

THIS ROUTINE IS ENTERED ONCE PER PASS AFTER ALL TESTS HAVE BEEN COMPLETED. THIS ROUTINE TYPES THE MAINDEC IDENTIFICATION CODE OF THE PROGRAM, CLEARS ERROR FLAGS AND UPDATES THE PASS COUNT. IF THE PROGRAM WAS LOADED UNDER ACT11 OR DDP, THE ROUTINE CHECKS FOR RETURN TO THE ACT11 OR DDP MONITOR. IF THE PROGRAM IS NOT UNDER MONITOR CONTROL, THE ROUTINE TRANSFERS TO BEGIN.

5.2.5 SCOPER (SCOPE LOOP AND ITERATION HANDLER)

THIS ROUTINE IS ENTERED EACH TIME A TEST IS COMPLETED. THE ROUTINE CHECKS FOR THE FOLLOWING UPON ENTRY

1. IF SW10=1, THE ROUTINE WILL TRANSFER TO THE NEXT TEST IN SEQUENCE, AFTER CLEARING ERROR FLAGS.
2. IF SW11=1, THE ROUTINE WILL TRANSFER TO THE NEXT TEST SEQUENCE, AFTER CLEARING ERROR FLAGS.
3. IF SW14=1, THE ROUTINE WILL LOOP ON THE CURRENT TEST REGARDLESS OF THE ITERATION COUNT.

IF NONE OF THE ABOVE IS TRUE, THE ROUTINE WILL ADD 1 TO THE COUNT OF TEST ITERATIONS, AND COMPARE THIS VALUE TO THE NUMBER OF ITERATIONS THAT SHOULD BE PERFORMED. IF THESE NUMBERS ARE EQUAL, THE ROUTINE WILL TRANSFER TO THE NEXT TEST IN SEQUENCE. IF THE NUMBERS ARE NOT EQUAL, THE TEST CURRENTLY IN PROGRESS WILL BE REPEATED.

5.2.6 SCOP1R (FREEZE ON CURRENT DATA)

THE CALL TO THIS ROUTINE FOLLOWS IMMEDIATELY AFTER THE CALL TO THE ERROR HANDLER IN THOSE TESTS THAT HAVE VARIABLE PARAMETERS. THIS ROUTINE IS ALWAYS ENTERED IN THOSE TESTS, WHETHER OR NOT AN ERROR OCCURS. IF SW09=1, THE ROUTINE WILL TRANSFER CONTROL BACK TO THE TEST AT A POINT WHICH WILL ALLOW REPEATING THE FUNCTION UNDER TEST CONTINUOUSLY WITH THE SAME DATA. IF THIS OPTION IS SELECTED, THE ROUTINE "SCOPER" IS NEVER ENTERED AND ITERATION COUNTS WILL NOT BE UPDATED.

5.2.7 ERRORS (ERROR HANDLER)

THIS ROUTINE IS ENTERED UPON ERROR DETECTION ONLY. WITH ALL CONSOLE SWITCHES DOWN, THE ROUTINE PROCEEDS AS FOLLOWS:

1. THE PC OF THE INSTRUCTION THAT CALLED THE ERROR HANDLER IS ACCESSED THRU THE STACK, AND THEN THE EMT INSTRUCTION ITSELF IS FETCHED. THE 8 LSB OF THE EMT INSTRUCTION ARE THE ERROR CODE. THIS CODE IS USED TO ACCESS A TABLE OF ERROR MESSAGES AND ERROR DATA STORAGE LOCATIONS.
2. IF THE TEST THAT FAILED DID NOT FAIL PREVIOUSLY DURING THIS PASS, A COMPLETE ERROR REPORT IS MADE IF THE TEST THAT FAILED FAILED MORE THAN ONCE DURING THE CURRENT PASS, ONLY THE DATA RELATING TO THE FAILURE IS TYPED. IF SW13=1, NO ERROR TYPEOUT IS MADE.
3. THE ROUTINE NOW CHECKS FOR HALT ON ERROR. IF SW15=1 THE PROGRAM WILL HALT WITH THE PC OF THE CALL TO THE ERROR ROUTINE IN R0. IF SW15=0, THE PROGRAM WILL NOT HALT, BUT WILL CHECK FOR ESCAPE TO NEXT TEST.
4. IF SW10=0, THE ROUTINE WILL RETURN TO THE TEST IN PROGRESS. IF SW10=1, THE ROUTINE WILL ABORT THE CURRENT TEST, AND TRANSFER TO THE NEXT TEST IN SEQUENCE, THRU THE ROUTINE "SCOPER".

5.2.8 TRPSRV (TRAP DECODE AND DISPATCH)

THIS ROUTINE DECODES THE 8 LSB OF THE TRAP INSTRUCTION THAT CAUSED THE PROGRAM INTERRUPT, AND TRANSFERS CONTROL TO THE ROUTINE THRU THE TABLE "TRPTAB" USING THE 8 LSB OF THE TRAP INSTRUCTION AS AN OFFSET TO THE POINTER TO THE ROUTINE TO BE ENTERED.

1
2
3
4 5.3 PROGRAM AND OR OPERATOR ACTION
5
6
7

8 5.3.1 PROGRAM START WITH ALL SWITCHES DOWN
9

10
11
12 5.3.1.1 REFER TO SECTIONS 4.3.1 AND 4.3.2 FOR INITIAL PROGRAM
13 BEHAVIOR.
14

15
16
17 5.3.1.2 AFTER "R" HAS BEEN TYPED BY THE PROGRAM, TEST EXECUTION WILL
18 BEGIN. EACH TEST WILL BE REPEATED A SELECTED NUMBER OF ITERATIONS
19 (SEE LISTING FOR EXACT NUMBER FOR EACH TEST) AND THEN THE PROGRAM WILL
20 PROCEED TO THE NEXT TEST.
21

22
23
24 5.3.1.3 WHEN ALL ITERATIONS HAVE BEEN COMPLETED, THE PROGRAM WILL
25 TYPE "CZDHH-C" AND THEN RESTART TESTING AT TEST 1 (LOCATION T1 IN THE
26 PROGRAM).
27

28
29
30 5.3.1.4 IF AN ERROR OCCURS, THE PROGRAM WILL TYPE AN APPROPRIATE
31 ERROR MESSAGE, AND THEN CONTINUE THE TEST IN PROGRESS.
32

33
34
35 5.3.2 PROGRAM START WITH SW00=1
36

37 THE PROGRAM WILL PERFORM AS DESCRIBED IN 4.3.1 AND 5.3.1
38

39
40
41 5.3.3 PROGRAM START WITH SW01=1
42

43
44
45 5.3.3.1 REFER TO SECTION 4.3.4 FOR INITIAL PROGRAM BEHAVIOR
46

47
48
49 5.3.3.2 TEST EXECUTION WILL START AT THE ADDRESS SPECIFIED AND WILL
50 CONTINUE AS DESCRIBED IN 5.3.1.2

1
2
3
4 5.3.3.3 AFTER "CZDHH-C" HAS BEEN TYPED, THE PROGRAM WILL RESUME TESTING
5 AT TEST 1
6
7
8

9 5.3.4 PROGRAM OPERATION WITH SW15=1

10
11 SAME AS 5.3.1, EXCEPT THAT IN THE CASE OF AN ERROR, THE PROGRAM WILL
12 HALT AFTER THE ERROR TYPEOUT, AND THE PC+2 OF THE CALL TO THE ERROR
13 ROUTINE WILL BE DISPLAYED IN RO.
14

15
16 5.3.5 PROGRAM OPERATION WITH SW13=1

17
18 SAME AS 5.3.1 EXCEPT THAT NO ERROR TYPEOUTS WILL OCCUR
19
20

21
22 5.3.6 PROGRAM OPERATION WITH SW11=1

23
24 SAME AS 5.3.1 EXCEPT THAT EACH TEST WILL BE REPEATED ONCE ONLY
25
26

27
28 5.3.7 PROGRAM OPERATION WITH SW10=1

29
30 SAME AS 5.3.1, EXCEPT THAT IN THE CASE OF AN ERROR THE CURRENT TEST
31 WILL BE ABORTED, AND THE PROGRAM WILL PROCEED TO THE NEXT TEST IN
32 SEQUENCE.
33
34

35
36 5.3.8 PROGRAM OPERATION WITH SW14=1, OR SW09=1

37
38 THESE FUNCTIONS ARE NORMALLY USED FOR TROUBLE SHOOTING. SEE SECTION
39 6.3 FOR THEIR USE.
40
41
42
43

44
45
46
47
48
49
50
51
52
53
54
55
56
57
58

6.0 ERRORS

6.1 ERROR HALTS

THE ERROR MESSAGE FORMAT FOR ALL ERROR TYPEOUTS IS AS FOLLOWS

PC+2 MESSAGE
 HEADER (IF APPLICABLE)
 DATA (IF APPLICABLE)

WHERE

PC+2 IS THE ADDRESS OF THE CALL TO THE ERROR HANDLER + 2;
MESSAGE IS AN ASCII MESSAGE DESCRIBING (BRIEFLY) THE FAILURE;
HEADER IS A DESCRIPTION OF THE DATA TO FOLLOW;
DATA IS OCTAL INFORMATION RELATING TO THE CAUSE OF THE FAILURE. IF

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50

THE SAME ERROR OCCURS IN A GIVEN TEST ON THE SAME PASS, AND IF DATA IS ASSOCIATED WITH THAT ERROR, ONLY DATA IS TYPE ON SUCCEEDING ERROR TYPEOUTS.

IF NO DATA IS ASSOCIATED WITH THE ERROR THE COMPLETE ERROR MESSAGE IS TYPED.

6.1.1 ERROR DESCRIPTIONS

SEE LISTING FOR DETAILS OF ERRORS

6.2 ERROR RECOVERY

6.2.1 SW15=0

IF THE PROGRAM IS RUN WITH SW15=0, NO OPERATOR ACTION IS REQUIRED TO CONTINUE TESTING

6.2.2 SW15=1

IF THE PROGRAM IS RUN WITH SW15=1, TO CONTINUE TESTING AFTER THE PROGRAM HAS HALTED, PRESS THE PROCESSOR CONSOLE CONTINUE SWITCH

6.2.3 ILLEGAL INTERRUPTS

IF AN INTERRUPT OCCURS TO A VECTOR ADDRESS NOT SELECTED DURING PROGRAM INITIALIZATION, THE PROGRAM WILL HALT IN THE TRAPCATCHER. THE ADDRESS AT WHICH THE PROGRAM HALTS IS 2 GREATER THAN THE ADDRESS TO WHICH THE INTERRUPT OCCURED. THE PROGRAM MUST BE RESTARTED AT 200 TO RECOVER FROM THIS ERROR.

6.3 SCOPE LOOPING

PAGE 12

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37

6.3.1 TO SCOPE ON A SPECIFIC TEST, SET SW14-1 AND SW13-1. THIS WILL
CAUSE THE PROGRAM TO CONTINUOUSLY LOOP ON THE SAME TEST, AND WILL
CAUSE ALL ERROR TYPEOUTS TO BE INHIBITED

6.3.2 TO SCOPE ON A SPECIFIC VALUE OF A PARAMETER WITHIN A TEST, SET
SW09-1 TO FREEZE THE DATA. (SEE LISTING FOR THOSE TESTS THAT
INCORPORATE THIS FEATURE)

6.3.3 PROGRAM START TO SCOPE LOOP ON SELECTED TEST
PERFORM SECTION 4.3.4 WITH SW14-1

7.0 RESTRICTIONS

7.1 STARTING

THE DH11 TEST CARD MUST BE INSTALLED

7.2 RUNNING

NONE

8.0 MISCELLANEOUS

8.1 EXECUTION TIME

THE TIME FOR ONE PASS OF THE PROGRAM (END OF TYPEOUT OF CZDHH-C TO END OF TYPEOUT OF CZDHH-C) IS GIVEN FOR VARIOUS PROCESSORS IN THE TABLE BELOW

TIME

PROCESSOR

PDP-11/05.10

PDP-11/20

PDP-11/40

PDP-11/45

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20

9.0 PROGRAM DESCRIPTION

FIRST, VERIFY THAT AUTO-ECHO WORKS ON ALL LINES BY TRANSMITTING ONE CHARACTER WITH AUTO ECHO ENABLED.

THEN A BINARY PATTERN IS TRANSMITTED ON ALL LINES EXCEPT THE ON WITH AUTO-ECHO ENABLED. A SINGLE CHARACTER IS TRANSMITTED ON THAT LINE. ALL DATA IS VERIFIED TO BE CORRECT.

10.0 LISTING

!

1 ; DHMAC-A - DH11 MACRO LIBRARY
2 ; COPYRIGHT 1985, DIGITAL EQUIPMENT CORP., MAYNARD, MASS. 01754
3
4
5
6
7

.LIST ME
.NLIST MC,MD,CND

; 3

; CMS REPLACEMENT HISTORY

104
119
131
148
158
167
303
339
373
520
563
595
607
652
664
691
712
743
744
745
746
747
748
TRAPS."
749
750
CLEAN END OF PASS
MESSAGE.
751
752
753
TCH REGISTER"
754

; *9 SKONETSKI 26-APR-1985 16:23:08 "FIXED TYPO CAUSING ASSEMBLY ERRORS"
; *8 SKONETSKI 22-APR-1985 16:48:03 "TYPO ERROR IN VECTOR CHANGE CODE SOURCE FIXED"
; *7 SKONETSKI 22-APR-1985 16:26:04 "ADDED CODE TO SET VECTORS FOR PMR FAIL, ERRORS, AND EMT
; *6 SKONETSKI 22-APR-1985 14:22:35 "FIXED BRANCH ERROR IN END OF PASS ROUTINE"
; *5 SKONETSKI 22-APR-1985 08:28:54 "FIXED BUG (AN OCTASC MACRO CALL WAS WRONG) AND ADDED A
; *4 SKONETSKI 18-APR-1985 14:20:15 "ADDED SOFTWARE SWITCH REG SUPPORT, BUT UNTESTED"
; *3 SKONETSKI 12-APR-1985 10:34:52 "FIXED PROBLEMS WITH SPURIOUS CR/LFS"
; *2 SKONETSKI 11-APR-1985 16:00:24 "ADDED MACRO FROM SYSHAC.SML THAT SIZES FOR SOFTWARE SWI
; *1 SKONETSKI 11-APR-1985 15:49:05 "LIBRARY FOR DH11 DIAGNOSTICS"

2
3
5 000000

.LIST ME
.NLIST MC,MD,CND
.HEADER †/1972,1985/,†/DH11 AUTO-ECHO TEST/,†/CZDHH-CO/

;STARTING PROCEDURE
;LOAD PROGRAM
;LOAD ADDRESS 000200
;PRESS START
;PROGRAM WILL TYPE DH11 AUTO-ECHO TEST
;PROGRAM WILL TYPE "VECTOR ADDRESS-"
;TYPE IN THE ADDRESS OF THE RECEIVER INTERRUPT VECTOR
;FOR THE DH11 TO BE TESTED, FOLLOWED BY <CARRIAGE RETURN>
;PROGRAM WILL TYPE "CONTROL REGISTER ADDRESS-"
;TYPE IN THE ADDRESS OF THE SYSTEM CONTROL REGISTER
;FOR THE DH11 TO BE TESTED, FOLLOWED BY <CARRIAGE RETURN>
;PROGRAM WILL TYPE "R" TO INDICATE THAT TESTING HAS STARTED
;AT THE END OF A PASS, PROGRAM WILL TYPE " CZDHH-CO "
;AND THEN RESUM TESTING

; 3

000000

6 000000

.TITLE CZDHH-CO
.ENABLE ABS
.NLIST MC,MD,CND
.LIST ME
.SYMBOLS

;SWITCH REGISTER OPTIONS

100000
040000
020000
010000
004000
002000
001000
000400
000100
000040
000020
000010
000004
000002
000001

SW15=100000
SW14=40000
SW13=20000
SW12=10000
SW11=4000
SW10=2000
SW09=1000
SW08=400
SW06=100
SW05=40
SW04=20
SW03=10
SW02=4
SW01=2
SW00=1

;=1,HALT ON ERROR
;=1,LOOP ON CURRENT TEST
;=1,INHIBIT ERROR TIMEOUT
;=1,INHIBIT ITERATIONS
;=1,ESCAPE TO NEXT TEST ON ERROR
;=1,LOOP WITH CURRENT DATA

; 3

;RESTART PROGRAM AT SELECTED TEST
;RESELECT VECTOR AND CONTROL REGISTER
;ADDRESS AFTER PROGRAM RESTART

0

;REGISTER DEFINITIONS

000000	R0=%0	;GENERAL REGISTER
000001	R1=%1	;GENERAL REGISTER
000002	R2=%2	;GENERAL REGISTER
000003	R3=%3	;GENERAL REGISTER
000004	R4=%4	;GENERAL REGISTER
000005	R5=%5	;GENERAL REGISTER
000006	SP=%6	;PROCESSOR STACK POINTER
000007	PC=%7	;PROGRAM COUNTER

;LOCATION EQUIVALENCIES

	;SWR=177570	;CONSOLE SWITCH REGISTER	; 3
	;LIGHTS=177570	;PDP-11/45 DISPLAY REGISTER	; 4
177776	PS=177776	;PROCESSOR STATUS WORD	; 4
015644	STACK=ENDCOD+200	;START OF PROCESSOR STACK	; 3

;INSTRUCTION DEFINITIONS

005746	PUSH1SP=5746	;DECREMENT PROCESSOR STACK 1 WORD
005726	POP1SP=5726	;INCREMENT PROCESSOR STACK 1 WORD
010046	PUSHRO=10046	;SAVE R0 ON STACK
012600	POPPO=12600	;RESTORE R0 FROM STACK
024646	PUSH2SP=24646	;DECREMENT STACK TWICE
022626	POP2SP=22626	;INCREMENT STACK TWICE

```

;
.MACRO HLT      $A
          EMT    $A
.ENDM HLT
;

```

100000	BITS15=100000
040000	BITS14=40000
020000	BITS13=20000
010000	BITS12=10000
004000	BITS11=4000
002000	BITS10=2000
001000	BITS09=1000
000400	BITS08=400
000200	BITS07=200
000100	BITS06=100
000040	BITS05=40
000020	BITS04=20
000010	BITS03=10
000004	BITS02=4
000002	BITS01=2
000001	BITS00=1
1 000000	.CATCH

; 3

0			TRAPCATCAER FOR ILLEGAL INTERRUPTS
	000000	.=0	
	000200	.REPT 200	
		.+2	:UNEXPECTED TRAP TO THIS LOCATION
		HALT	:EXAMINE STACK TO FIND CAUSE
		.ENDR	
000000	000002	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000002	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000004	000006	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000006	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000010	000012	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000012	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000014	000016	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000016	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000020	000022	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000022	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000024	000026	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000026	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000030	000032	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000032	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000034	000036	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000036	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000040	000042	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000042	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000044	000046	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000046	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000050	000052	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000052	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000054	000056	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000056	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000060	000062	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000062	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000064	000066	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000066	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000070	000072	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000072	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000074	000076	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000076	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000100	000102	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000102	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000104	000106	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000106	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000110	000112	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000112	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000114	000116	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000116	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000120	000122	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000122	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000124	000126	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000126	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000130	000132	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000132	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000134	000136	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000136	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000140	000142	.+2	:UNEXPECTED TRAP TO THIS LOCATION
000142	000000	HALT	:EXAMINE STACK TO FIND CAUSE
000144	000146	.+2	:UNEXPECTED TRAP TO THIS LOCATION

000146	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000150	000152	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000152	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000154	000156	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000156	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000160	000162	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000162	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000164	000166	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000166	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000170	000172	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000172	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000174	000176	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000176	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000200	000202	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000202	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000204	000206	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000206	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000210	000212	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000212	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000214	000216	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000216	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000220	000222	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000222	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000224	000226	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000226	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000230	000232	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000232	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000234	000236	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000236	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000240	000242	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000242	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000244	000246	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000246	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000250	000252	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000252	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000254	000256	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000256	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000260	000262	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000262	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000264	000266	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000266	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000270	000272	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000272	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000274	000276	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000276	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000300	000302	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000302	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000304	000306	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000306	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000310	000312	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000312	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000314	000316	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000316	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000320	000322	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000322	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000324	000326	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000326	000000	HALT	;EXAMINE STACK TO FIND CAUSE

000330	000332	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000332	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000334	000336	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000336	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000340	000342	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000342	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000344	000346	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000346	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000350	000352	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000352	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000354	000356	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000356	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000360	000362	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000362	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000364	000366	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000366	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000370	000372	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000372	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000374	000376	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000376	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000400	000402	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000402	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000404	000406	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000406	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000410	000412	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000412	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000414	000416	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000416	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000420	000422	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000422	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000424	000426	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000426	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000430	000432	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000432	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000434	000436	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000436	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000440	000442	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000442	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000444	000446	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000446	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000450	000452	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000452	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000454	000456	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000456	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000460	000462	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000462	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000464	000466	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000466	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000470	000472	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000472	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000474	000476	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000476	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000500	000502	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000502	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000504	000506	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000506	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000510	000512	.+2	;UNEXPECTED TRAP TO THIS LOCATION

000512	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000514	000516	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000516	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000520	000522	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000522	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000524	000526	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000526	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000530	000532	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000532	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000534	000536	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000536	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000540	000542	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000542	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000544	000546	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000546	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000550	000552	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000552	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000554	000556	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000556	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000560	000562	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000562	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000564	000566	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000566	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000570	000572	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000572	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000574	000576	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000576	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000600	000602	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000602	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000604	000606	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000606	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000610	000612	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000612	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000614	000616	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000616	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000620	000622	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000622	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000624	000626	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000626	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000630	000632	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000632	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000634	000636	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000636	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000640	000642	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000642	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000644	000646	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000646	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000650	000652	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000652	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000654	000656	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000656	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000660	000662	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000662	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000664	000666	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000666	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000670	000672	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000672	000000	HALT	;EXAMINE STACK TO FIND CAUSE

000674	000676	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000676	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000700	000702	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000702	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000704	000706	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000706	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000710	000712	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000712	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000714	000716	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000716	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000720	000722	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000722	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000724	000726	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000726	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000730	000732	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000732	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000734	000736	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000736	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000740	000742	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000742	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000744	000746	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000746	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000750	000752	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000752	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000754	000756	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000756	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000760	000762	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000762	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000764	000766	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000766	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000770	000772	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000772	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000774	000776	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000776	000000	HALT	;EXAMINE STACK TO FIND CAUSE
1 001000		.SETVEC	

```

0          000200 000167 000600      .-200      ;STANDARD INTERRUPT VECTORS
          000200      JMP      START      ;GO TO START OF PROGRAM

1 000204      .TRPDEF

          ;DEFINITIONS FOR TRAP SUBROUTINE CALLS
          ;POINTERS TO SUBROUTINES CAN BE FOUND STARTING
          ;AT LOCATION "TRPTAB"

000204      TRPDEF  SCOPE,+/SCOPE LOOP AND ITERATION HANDLER/
          104400      SCOPE=TRAP+Y      ;SCOPE LOOP AND ITERATION HANDLER
          000001      Y=Y+1

000204      TRPDEF  TYPE,+/TELETYPE OUTPUT ROUTINE/
          104401      TYPE=TRAP+Y      ;TELETYPE OUTPUT ROUTINE
          000002      Y=Y+1

000204      TRPDEF  OCTASC,+/OCTAL TO ASCII CONVERSION/
          104402      OCTASC=TRAP+Y      ;OCTAL TO ASCII CONVERSION
          000003      Y=Y+1

000204      TRPDEF  INSTR,+/INPUT ASCII STRING/
          104403      INSTR=TRAP+Y      ;INPUT ASCII STRING
          000004      Y=Y+1

000204      TRPDEF  INSTER,+/STRING INPUT ERROR/
          104404      INSTER=TRAP+Y      ;STRING INPUT ERROR
          000005      Y=Y+1

000204      TRPDEF  PARAM,+/CONVERT STRING TO OCTAL, CHECK LIMITS/
          104405      PARAM=TRAP+Y      ;CONVERT STRING TO OCTAL, CHECK LIMITS
          000006      Y=Y+1

000204      TRPDEF  SAVOSP,+/SAVE R0-R5, PC/
          104406      SAVOSP=TRAP+Y      ;SAVE R0-R5, PC
          000007      Y=Y+1

000204      TRPDEF  RESO5,+/RESTORE R0-R5/
          104407      RESO5=TRAP+Y      ;RESTORE R0-R5
          000010      Y=Y+1

000204      TRPDEF  SCOPE1,+/CHECK FOR FREEZE ON CURRENT DATA/
          104410      SCOPE1=TRAP+Y      ;CHECK FOR FREEZE ON CURRENT DATA
          000011      Y=Y+1

2          .MACRO  CODEM1
3          MOV     DHSSR,DHSLR      ;SET UP ADDRESS OF SILO
4          INC     DHSLR      ;STATUS REGISTER HIGH BYTE
5          .ENDM   CODEM1
6 000204      .START  DHRVEC,3,4,DHSCR,0,177776,7,10,...,1

```


0

001000

.-1000

```

;PROGRAM INITIALIZATION
;LOCK OUT INTERRUPTS
;SET UP PROCESSOR STACK
;SET UP POWER FAIL VECTOR
;CLEAR PROGRAM FLAGS AND COUNTS
;TYPE TITLE MESSAGE
.IIF NB <>, ;DETERMINE MEMORY SIZE
.IIF NB <>, ;SET UP TRACE TRAP RETURN

001000 177570      SWR: .WORD 177570      ; SWITCH DHSCR ADDRESS      ; 4
001002 177570      LIGHTS: .WORD 177570    ; LIGHTS                      ; 4
                                           ; 4

001004 012767 000340 176764 START: MOV #340,PS ;LOCK OUT INTERRUPTS
001012 012706 015644      MOV #STACK,SP ;SET UP PROCESSOR STACK
001016 012702 000024      MOV #24,R2 ;POINT TO VECTOR AREA ; 7
001022 012722 014510      MOV #PFAIL,(R2)+ ;SET UP POWER FAIL TRAP ; 7
001026 012722 000340      MOV #340,(R2)+ ;SERVICE AT LEVEL 7 ; 7
001032 012722 012350      MOV #ERRORS,(R2)+ ;ERROR HANDLER ; 7
001036 012722 000340      MOV #340,(R2)+ ;SERVICE AT LEVEL 7 ; 7
001042 012722 012562      MOV #TRPSRV,(R2)+ ;GENERAL HANDLER DISPATCH SERVICE ; 7
001046 012712 000340      MOV #340,(R2) ;SERVICE AT LEVEL 7 ; 8
001052 005067 012556      CLR STFLG ;CLEAR TEST START FLAG
001056 005067 012512      CLR PASCNT ;CLEAR PASS COUNT
001062 005067 012510      CLR ERRCNT ;CLEAR ERROR COUNT
001066 005067 012500      CLR ERRFLG ;CLEAR ERROR FLAG
001072 005067 012474      CLR ERRFLG ;CLEAR LAST ERROR PC
001076 016746 176702      MOV 4,-(SP) ;PUSH TRAP VECTOR ; 4
001102 016746 176700      MOV 6,-(SP) ; 4
001106 012767 001122 176670 MOV #14,4 ;SET UP TRAP VECTOR ; 4
001114 005777 177660      TST #SWR ;TEST SWITCH REGISTER ADDRESS ; 4
001120 000405      BR 24 ;IF SUCCESSFUL, LEAVE IT ALONE ; 4
001122      14: ; 4
001122 012767 000176 177650 MOV #176,SWR ;POINT TO SOFT SWITCH DHSCR ; 4
001130 005067 177646      CLR LIGHTS ;0 MEANS WE ARE NOT GOING TO USE LIGHTS ; 4
001134      24: ; 5
001134 005726      TST (SP)+ ;CLEAN UP STACK ; 4
001136 005726      TST (SP)+ ; 4
001140 012667 176642      MOV (SP)+,6 ; 4
001144 012667 176634      MOV (SP)+,4 ; 4
001150 104401 014660      TYPE ,MTITLE ;TYPE TITLE MESSAGE
001154 005767 012452      TST INIFLG ;CHECK INITIALIZATION FLAG
;IF NB <DHRVEC>
BNE VEC1 ;IF NOT 0, CHECK SWITCHES
;FOR REINITIALIZATION
;IF NOT 0, START TEST

.IFF
BNE BEGIN

.ENDC
.IF NB <>
SIZE: CLR R0
MOV #24,804
14: TST (R0)+ ;SET UP TIME OUT RETURN ; 9
BR 14 ;WILL TRAP WHEN NO MEMORY
24: MOV R0,HCORE ;LOCATION RESPONDED, CONTINUE
SUB #2,HCORE ;R0 CONTAINS ADDRESS OF
MOV #6,804 ;NON EXISTANT MEMORY ; 9
;RESTORE TRAPCATCHER

```

```

.ENDC
;IF NB
TRACER: MOV    #1#,R0
        SXT    R0
        MOV    #RTT,TRTRET
        BR     2#
1#:     MOV    #RTI,TRTRET
        MOV    #12,R0
        MOV    #TRTRET,R016

;SET UP ILLEGAL INSTRUCTION TRAP RETURN
;DO 11/40, 11/45 INSTRUCTION
;11/40,45 RTT RETURN FROM TRACE TRAP
;1105,10,20 RTI RETURN FROM TRACE TRAP
;RESTORE TRAPCATCHER
;SET UP TRACE TRAP VECTOR

.ENDC
;IF NB
;IF B
001162 000404
        BR     VEC2
;IFF
        TST    INIFLG
        BEQ    VEC2
;IF INITIALIZE FLAG=0
;GET VECTOR AND CSR ADDRESS

.ENDC
VEC1:   BIT    #SW00,SWR
        BEQ    BEGIN
;IF SW00=1, GET NEW VECTOR
;AND CSR
; 4
; 4
; 4
VEC2:   MOV    #300,R1
        MOV    #302,R2
        MOV    #4,R3
1#:     MOV    R2,(R1)
        CLR    (R2)
        ADD    R3,R1
        ADD    R3,R2
        CMP    R1,#1000
        BNE    1#
;RESTORE TRAPCATCHER
;IN FLOATING VECTOR AREA

;INPUT ADDRESS OF DEVICE VECTOR
;MESSAGE "VECTOR ADDRESS-"
;CONVERT STRING TO OCTAL
;LOW LIMIT
;HIGH LIMIT
;LOCATIONS TO BE FILLED
;NUMBER OF LOCATIONS
;LSB MASK
;INPUT ADDRESS OF DEVICE CSR
;MESSAGE "CONTROL REGISTER ADDRESS-"
;CONVERT STRING TO OCTAL
;LOW LIMIT
;HIGH LIMIT
;LOCATIONS TO BE FILLED
;NUMBER OF LOCATIONS
;LSB MASK
; 3

;BYTE 3
;BYTE 4
INSTR   MREGAD
PARAM   0
177776
DHSCR   7
;BYTE 7
;BYTE 10
.ENDC
;IF NB
<1>
CODEM1
MOV     DHSSR,DHSLR
INC     DHSLR
;SET UP ADDRESS OF SILO
;STATUS REGISTER HIGH BYTE

.ENDC
TST     INIFLG
BNE     BEGIN
COM     INIFLG
;IF INITIALIZATION FLAG
;IS CLEARED
;SET IT

;PROGRAM START
;CHECK FOR PROGRAM START AT SELECTED ADDRESS
; 3

```


001306	012767	000340	176462	BEGIN:	MOV	#340,PS	;LOCK OUT INTERRUPTS	
001314	012706	015644			MOV	#STACK,SP	;SET UP PROCESSOR STACK	
001320	032777	000002	177452		BIT	#SW01,#SWR	;IF SW01=1	; 4
001326	001410				BEQ	1#	;GET PC FOR PROGRAM START	
001330	104403				INSTR		;GET PC	
001332	015123				MTSTPC		;MESSAGE "TEST PC"	
001334	104405				PARAM		;CONVERT STRING TO OCTAL	
001336	000000				0			
001340	017500				17500			
001342	013600				RETRN			
001344	001			.BYTE	1			
001345	001			.BYTE	1			
001346	000410				BR	2#		
001350	012767	001400	012222	1#:	MOV	#T1,RETRN	;NORMAL START, TEST 1	
001356	005767	012252			TST	STFLG	;IF LOOPING, BYPASS TYPEOUT	
001362	001004				BNE	3#		
001364	005167	012244			COM	STFLG		
001370	104401	015117		2#:	TYPE	,MR	;TYPE "R" TO INDICATE START	
001374	000177	012200		3#:	JMP	@RETRN	;START TESTING	; 3

```

1      .MACRO  AUTO1  XLINE,XBIT,K
2
3      ;ENABLE AUTO ECHO ON LINE 'XLINE'
4      ;TRANSMIT ONE CHARACTER ON LINE 'XLINE'
5      ;AT 9600 BAUD, 8 BITS.
6      ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
7      ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
8      ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.
9
10     TS \XN,100,4$
11     MOV     @BIT11,@DHSCR      ;MASTER CLEAR INTERFACE
12     1$: JSR     PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
13                                     ;BUS ADDRESS REGISTERS
14     MOV     @'XLINE',@DHSCR   ;SELECT LINE 'XLINE'
15     MOV     @-1,@DHBC        ;SET BYTE COUNT TO 1
16     MOV     @TWRD'K',@DHBA    ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
17     MOV     @100,R0          ;SET UP TO RECEIVE 64 CHARACTERS
18     CLR     R1               ;COUNT OF CHARACTERS RECEIVED
19     MOV     @133503,@DHLPR    ;SET UP SPEED FOR 9600 BAUD
20                                     ;8 BITS PER CHARACTER,
21                                     ;AUTO ECHO ENABLED ON LINE 'XLINE'
22     MOV     @'XBIT',@DHBAR    ;SET BAR BIT FOR LINE 'K'
23     2$: TSTB   @DHSCR         ;WAIT FOR CHARACTER TO
24     BPL     2$               ;BE RECEIVED
25     INC     R1               ;UPDATE RECEIVED CHARACTER COUNT
26     MOV     @DHNR,R4         ;READ CHARACTER
27     CMP     R4,TWRD'K'       ;IS CHARACTER CORRECT
28     BEQ     3$               ;
29     MOV     TWRD'K',R5       ;(R5)-EXPECTED CHARACTER
30     CLR     @DHLPR           ;SHUT OFF AUTO ECHO
31     HLT     0                ;CHARACTER ECHOED INCORRECTLY
32     BR      4$               ;RESTART TEST
33     3$: DEC     R0            ;IF 64 CHARACTERS HAVE NOT
34     BGT     2$               ;BEEN RECEIVED, CONTINUE
35     BMI     4$               ;
36     BIC     @100000,@DHLPR   ;SHUT OFF AUTO-ECHO
37     BR      2$               ;GET 1 MORE CHARACTER
38     4$: SCOPE  AUTO1         ;CHECK FOR ITERATIONS, LOOP
39     .ENDM

```



```

1      .MACRO  AUTO2  XLINE,XBIT,K
2
3      ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 'K'
4      ;TRANSMIT 1 CHARACTER ON LINE 'K' WITH AUTO ECHO ENABLED
5      ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
6      ;CHARACTER LENGTH IS 8 BITS
7      ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES
8
9      TS  \XN,10,5:
10         MOV    @BIT11,@DHSCR      ;MASTER CLEAR INTERFACE
11         JSR    PC,SETALL          ;SET UP ALL LINES TO TRANSMIT
12                                     ;400 (OCTAL) CHARACTERS
13         MOV    @'K',@DHSCR        ;SELECT LINE XLINE FOR TESTING
14         MOV    @TWRD'K',@DHBA     ;CHARACTER TO BE TRANSMITTED
15                                     ;ON LINE XLINE IN AUTO ECHO MODE
16         MOV    @-1,@DHBC          ;TRANSMIT ONLY 1 CHARACTER ON LINE XLINE
17         MOV    @133503,@DHLPR     ;SET AUTO ECHO FOR LINE XLINE
18         BIC    @'XBIT',LINACT     ;CLEAR LINE ACTIVE BIT
19         MOV    @-1,@DHBA          ;SET BAR BITS FOR ALL LINES
20         CLR    R0                 ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
21         1$:    MOV    @DHNR,R4     ;GET A CHARACTER FROM SILO
22         BPL    1$                ;IF NOT VALID DATA, TRY AGAIN
23         MOV    R4,R3              ;EXTRACT LINE NUMBER FORM CHARACTER
24         SWAB   R3
25         BIC    @177760,R3         ;CLEAR STATUS BITS
26         MOV    R3,R2
27         ASL    R2
28         CMP    R3,@'K'            ;IF LINE NUMBER IS XLINE
29         BEQ    4$                ;CHECK FOR CORRECT ECHOED CHARACTER
30         CMP    RBUF(R2),R4        ;IF NOT LINE XLINE, CHECK DATA
31         BEQ    2$                ;
32         MOV    RBUF(R2),R5        ;(R5)=EXPECTED NON ECHOED DATA
33         HLT    1                 ;NON ECHOED DATA ERROR
34         BR     4$
35         2$:    INCB   RBUF(R2)     ;UPDATE EXPECTED RECEIVED DATA
36         BNE    1$                ;CONTINUE IF NOT DONE
37         BIC    LINBIT(R2),LINACT  ;CLEAR ACTIVE BIT
38         3$:    TST    LINACT       ;IF ALL LINES ARE DONE
39         BNE    1$                ;EXIT
40         MOV    @'K',@DHSCR        ;SELECT LINE XLINE
41         BIC    @100000,@DHLPR     ;CLEAR AUTO ECHO FOR LINE XLINE
42         TSTB   @DHSLR             ;GET REST OF CHARACTERS
43         BNE    1$                ;AND CHECK
44         BR     5$
45         4$:    INC    R0           ;UPDATE ECHOED CHARACTER COUNT
46         CMP    R4,TWRD'K'         ;CHECK ECHOED DATA
47         BEQ    3$
48         MOV    TWRD'K',R5         ;(R5)=EXPECTED ECHOED DATA
49         HLT    2                 ;ECHOED DATA ERROR
50         5$:    SCOPE             ;CHECK FOR ITERATIONS, LOOP
51         .ENDM  AUTO2

```

```

1      .MACRO SSETALL
2
3          ;SET BYTE COUNT FOR ALL LINES TO 400
4          ;SET BUS ADDRESS FOR ALL LINES TO TBUF
5          ;CLEAR EXPECTED CHARACTER BUFFERS
6          ;SET LINE ACTIVE BITS FOR ALL LINES
7
8      SETALL: MOV     #20,R0          ;SET UP TO LOAD 16
9                                     ;BYTE COUNT AND BUS ADDRESS
10                                    ;MEMORY LOCATIONS
11                                     ;SET UP TO GENERATE EXPECTED
12                                     ;RECEIVED CHARACTER BUFFER
13                                     ;WILL BE HIGH BYTE
14                                     ;OF EXPECTED RECEIVED CHARACTER
15                                     ;OFFSET FOR HIGH BYTE
16      1$: MOV     #TBUF, @DHBA      ;LOAD BUS ADDRESS
17      MOV     #-400, @DHBC          ;LOAD BYTE COUNT
18      MOV     #31403, @DHLPR        ;SET LINE SPEED TO 4800 BAUD
19      CLRB    RBUF(R1)              ;RECEIVED CHARACTER
20                                     ;LOAD HIGH BYTE
21      MOVB    R2, RBUF(R3)          ;ADVANCE LINE NUMBER TO NEXT LINE
22      INC     @DHSCR                ;UPDATE POINTERS
23      INC     R2
24      ADD     #2, R1
25      ADD     #2, R3
26      DEC     R0
27      BNE     1$
28      MOV     #-1, LINACT           ;SET ACTIVE FLAGS FOR ALL LINES
29      RTS     PC                    ;RETURN TO CALLING ROUTINE
30      .ENDM SSETALL
31
32      .MACRO CCLRALL
33
34          ;CLEAR ALL BYTE COUNT AND BUS ADDRESS REGISTERS
35
36      CLRALL: MOV     #20,R0          ;SET UP TO CLEAR 16
37      1$: CLR     @DHBA              ;CLEAR BUS ADDRESS
38      CLR     @DHBC                  ;CLEAR BYTE COUNT
39      INC     @DHSCR                ;ADVANCE LINE NUMBER
40      DEC     R0
41      BNE     1$
42      RTS     PC                    ;RETURN TO CALLING ROUTINE
43      .ENDM CCLRALL

```



```

2      000020      XLINE=LINE
3      000000      XBIT=BITX
4      000020      K=KX
5      000000      LINE=0
6      000001      BITX=1
7      000000      KX=0
9      000020      .REPT 20
10     AUTO1      \LINE,\BITX,\KX
11     .NLIST
12     LINE=LINE+1
13     BITX=BITX+BITX
14     KX=KX+1
15     .LIST
16     .ENDR
      AUTO1      \LINE,\BITX,\KX

```

001400

```

;ENABLE AUTO ECHO ON LINE 0
;TRANSMIT ONE CHARACTER ON LINE 0
;AT 9600 BAUD, 8 BITS.
;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

```

001400				TS \XN,100,4;		
001400	012767	000340	176370	T1:	MOV	#340,PS
001406	012767	000100	012172		MOV	#100,ICOUNT
001414	012767	001554	012160		MOV	#44,ESCAPE
				.IF NB	<>	
					MOV	#.FREEZ1
				.ENDC		
	000002			XN=XN+1		
001422	012777	004000	012110		MOV	#BIT11,8DHSCR
001430	004767	011744		14:	JSR	PC,CLRALL
001434	012777	000000	012076		MOV	#0,8DHSCR
001442	012777	177777	012100		MOV	#-1,8DHBC
001450	012777	014310	012070		MOV	#THRDO,8DHBA
001456	012700	000100			MOV	#100,R0
001462	005001				CLR	R1
001464	012777	133503	012052		MOV	#133503,8DHLPR
001472	012777	000001	012052		MOV	#1,8DHBAR
001500	105777	012034		24:	TSTB	8DHSCR
001504	100375				BPL	24
001506	005201				INC	R1
001510	017704	012026			MOV	8DHNR,R4
001514	020467	012570			CMP	R4,THRDO
001520	001406				BEQ	34
001522	016705	012562			MOV	THRDO,R5
001526	005077	012012			CLR	8DHLPR
001532					HLT	0
001532	104000				EMT	0
001534	000407				BR	44
001536	005300			34:	DEC	R0
001540	003357				BGT	24
001542	100404				BMI	44

```

;DISABLE ALL INTERRUPTS
;SET UP FOR 100 ITERATIONS
;SET UP TO ESCAPE TO NEXT TEST
;SET UP TO LOOP WITH DATA ; 3

```

```

;MASTER CLEAR INTERFACE
;CLEAR ALL BYTE COUNT AN
;BUS ADDRESS REGISTERS
;SELECT LINE 0
;SET BYTE COUNT TO 1
;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
;SET UP TO RECEIVE 64 CHARACTERS
;COUNT OF CHARACTERS RECEIVED
;SET UP SPEED FOR 9600 BAUD
;8 BITS PER CHARACTER.
;AUTO ECHO ENABLED ON LINE 0
;SET BAR BIT FOR LINE 0
;WAIT FOR CHARACTER TO
;BE RECEIVED
;UPDATE RECEIVED CHARACTER COUNT
;READ CHARACTER
;IS CHARACTER CORRECT
;(R5)=EXPECTED CHARACTER
;SHUT OFF AUTO ECHO
;CHARACTER ECHOED INCORRECTLY
;RESTART TEST
;IF 64 CHARACTERS HAVE NOT
;BEEN RECEIVED, CONTINUE

```

```

001544 042777 100000 011772      BIC      #100000,8DHLPR      ;SHUT OFF AUTO-ECHO
001552 000752                      BR      2#              ;GET 1 MORE CHARACTER
001554 104400                      4#:  SCOPE              ;CHECK FOR ITERATIONS, LOOP
                                LINE=LINE+1
                                BITX=BITX+BITX
                                KX=KX+1
001556                      AUTO1  \LINE,\BITX,\KX

                                ;ENABLE AUTO ECHO ON LINE 1
                                ;TRANSMIT ONE CHARACTER ON LINE 1
                                ;AT 9600 BAUD, 8 BITS.
                                ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
                                ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
                                ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

001556                      TS \XN,100,4#
001556 012767 000340 176212      T2:  MOV      #340,PS              ;DISABLE ALL INTERRUPTS
001564 012767 000100 012014      MOV      #100,ICOUNT          ;SET UP FOR 100 ITERATIONS
001572 012767 001732 012002      MOV      #4#,ESCAPE          ;SET UP TO ESCAPE TO NEXT TEST
                                .IF NB <>
                                MOV      #,FREEZ1              ;SET UP TO LOOP WITH DATA      ; 3
                                .ENDC
                                XN=XN+1
001600 012777 004000 011732      1#:  MOV      #BIT11,8DHSCR      ;MASTER CLEAR INTERFACE
001606 004767 011566             JSR      PC,CLRALL            ;CLEAR ALL BYTE COUNT AN
                                ;BUS ADDRESS REGISTERS
                                MOV      #1,8DHSCR              ;SELECT LINE 1
                                MOV      #-1,8DHBC              ;SET BYTE COUNT TO 1
                                MOV      #TWRD1,8DHBA           ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
                                MOV      #100,R0                ;SET UP TO RECEIVE 64 CHARACTERS
                                CLR      R1                      ;COUNT OF CHARACTERS RECEIVED
                                MOV      #133503,8DHLPR         ;SET UP SPEED FOR 9600 BAUD
                                ;8 BITS PER CHARACTER,
                                ;AUTO ECHO ENABLED ON LINE 1
                                ;SET BAR BIT FOR LINE 1
                                2#:  TSTB      8DHSCR            ;WAIT FOR CHARACTER TO
                                BPL      2#                      ;BE RECEIVED
                                INC      R1                      ;UPDATE RECEIVED CHARACTER COUNT
                                MOV      #8DHNR, R4             ;READ CHARACTER
                                CMP      R4,TWRD1              ;IS CHARACTER CORRECT
                                BEQ      3#
                                MOV      #TWRD1,R5              ;(R5)=EXPECTED CHARACTER
                                CLR      8DHLPR                 ;SHUT OFF AUTO ECHO
                                HLT      0                       ;CHARACTER ECHOED INCORRECTLY
                                EMT      0
                                BR      4#
                                3#:  DEC      R0                  ;RESTART TEST
                                BGT      2#                      ;IF 64 CHARACTERS HAVE NOT
                                BHI      4#                      ;BEEN RECEIVED, CONTINUE
                                BIC      #100000,8DHLPR         ;SHUT OFF AUTO-ECHO
                                BR      2#                      ;GET 1 MORE CHARACTER
                                4#:  SCOPE              ;CHECK FOR ITERATIONS, LOOP
                                LINE=LINE+1
                                BITX=BITX+BITX
                                KX=KX+1
001734                      AUTO1  \LINE,\BITX,\KX

```



```

:ENABLE AUTO ECHO ON LINE 2
:TRANSMIT ONE CHARACTER ON LINE 2
:AT 9600 BAUD, 8 BITS.
:RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
:AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
:EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

```

Address	Offset	Hex	Symbol	Assembly	Comment
001734	012767	000340	176034	TS \XN,100,4	
001742	012767	000100	011636	T3: MOV #340,PS	;DISABLE ALL INTERRUPTS
001750	012767	002110	011624	MOV #100,ICOUNT	;SET UP FOR 100 ITERATIONS
				MOV #4,ESCAPE	;SET UP TO ESCAPE TO NEXT TEST
				.IF NB <>	
				MOV #,FREEZ1	;SET UP TO LOOP WITH DATA ; 3
	000004			.ENDC	
				XN=XN+1	
001756	012777	004000	011554	MOV #BIT11,SDHSCR	;MASTER CLEAR INTERFACE
001764	004767	011410		1\$: JSR PC,CLRALL	;CLEAR ALL BYTE COUNT AN
					;BUS ADDRESS REGISTERS
001770	012777	000002	011542	MOV #2,SDHSCR	;SELECT LINE 2
001776	012777	177777	011544	MOV #-1,SDHBC	;SET BYTE COUNT TO 1
002004	012777	014314	011534	MOV #TWRD2,SDHBA	;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
002012	012700	000100		MOV #100,R0	;SET UP TO RECEIVE 64 CHARACTERS
002016	005001			CLR R1	;COUNT OF CHARACTERS RECEIVED
002020	012777	133503	011516	MOV #133503,SDHLPR	;SET UP SPEED FOR 9600 BAUD
					;8 BITS PER CHARACTER,
					;AUTO ECHO ENABLED ON LINE 2
002026	012777	000004	011516	MOV #4,SDHBAR	;SET BAR BIT FOR LINE 2
002034	105777	011500		2\$: TSTB SDHSCR	;WAIT FOR CHARACTER TO
002040	100375			BPL 2\$	;BE RECEIVED
002042	005201			INC R1	;UPDATE RECEIVED CHARACTER COUNT
002044	017704	011472		MOV SDHNR, R4	;READ CHARACTER
002050	020467	012240		CHP R4, TWRD2	;IS CHARACTER CORRECT
002054	001406			BEQ 3\$	
002056	016705	012232		MOV TWRD2, R5	; (R5)=EXPECTED CHARACTER
002062	005077	011456		CLR SDHLPR	;SHUT OFF AUTO ECHO
002066				HLT 0	;CHARACTER ECHOED INCORRECTLY
002066	104000			ENT 0	
002070	000407			BR 4\$	;RESTART TEST
002072	005300			3\$: DEC R0	;IF 64 CHARACTERS HAVE NOT
002074	003357			BGT 2\$	;BEEN RECEIVED, CONTINUE
002076	100404			BMI 4\$	
002100	042777	100000	011436	BIC #100000,SDHLPR	;SHUT OFF AUTO-ECHO
002106	000752			BR 2\$	;GET 1 MORE CHARACTER
002110	104400			4\$: SCOPE	;CHECK FOR ITERATIONS, LOOP
	000003			LINE=LINE+1	
	000010			BITX=BITX+BITX	
	000003			KX=KX+1	
002112				AUTO1 \LINE, \BITX, \KX	
					;ENABLE AUTO ECHO ON LINE 3
					;TRANSMIT ONE CHARACTER ON LINE 3
					;AT 9600 BAUD, 8 BITS.
					;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
					;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
					;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.
002112				TS \XN,100,4	

```

002112 012767 000340 175656 T4:  MOV  #340,PS      ;DISABLE ALL INTERRUPTS
002120 012767 000100 011460      MOV  #100,ICOUNT ;SET UP FOR 100 ITERATIONS
002126 012767 002266 011446      MOV  #44,ESCAPE  ;SET UP TO ESCAPE TO NEXT TEST
                                <>
                                MOV  #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
                                .ENDC
                                XN=XN+1

002134 012777 004000 011376      MOV  #BIT11,0DHSCR ;MASTER CLEAR INTERFACE
002142 004767 011232 1$:      JSR   PC,CLRALL ;CLEAR ALL BYTE COUNT AN
                                ;BUS ADDRESS REGISTERS
                                ;SELECT LINE 3
                                ;SET BYTE COUNT TO 1
                                ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
                                ;SET UP TO RECEIVE 64 CHARACTERS
                                ;COUNT OF CHARACTERS RECEIVED
                                ;SET UP SPEED FOR 9600 BAUD
                                ;8 BITS PER CHARACTER,
                                ;AUTO ECHO ENABLED ON LINE 3
                                ;SET BAR BIT FOR LINE 3
                                ;WAIT FOR CHARACTER TO
                                ;BE RECEIVED
                                ;UPDATE RECEIVED CHARACTER COUNT
                                ;READ CHARACTER
                                ;IS CHARACTER CORRECT

002146 012777 000003 011364      MOV  #3,0DHSCR
002154 012777 177777 011366      MOV  #-1,0DHBC
002162 012777 014316 011356      MOV  #TWRD3,0DHBA
002170 012700 000100      MOV  #100,R0
002174 005001      CLR   R1
002176 012777 133503 011340      MOV  #133503,0DHLPR

                                ;(R5)-EXPECTED CHARACTER
                                ;SHUT OFF AUTO ECHO
                                ;CHARACTER ECHOED INCORRECTLY

002204 012777 000010 011340      MOV  #10,0DHBAR
002212 105777 011322 2$:      TSTB  0DHSCR
002216 100375      BPL   2$
002220 005201      INC   R1
002222 017704 011314      MOV  #0DHNR, R4
002226 020467 012064      CMP   R4,TWRD3
002232 001406      BEQ   3$
002234 016705 012056      MOV  #TWRD3,R5
002240 005077 011300      CLR   0DHLPR
002244      HLT   0
002244 104000      EMT   0
002246 000407      BR    4$
002250 005300 3$:      DEC   R0
002252 003357      BGT   2$
002254 100404      BMI   4$
002256 042777 100000 011260      BIC   #100000,0DHLPR
002264 000752      BR    2$
002266 104400 4$:      SCOPE
                                LINE=LINE+1
                                BITX=BITX+BITX
                                KX=KX+1
                                AUTO1  \LINE,\BITX,\KX

                                ;ENABLE AUTO ECHO ON LINE 4
                                ;TRANSMIT ONE CHARACTER ON LINE 4
                                ;AT 9600 BAUD, 8 BITS.
                                ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
                                ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
                                ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

002270      000004
                                000020
                                000004

002270 TS \XN,100,4$
002270 012767 000340 175500 T5:  MOV  #340,PS      ;DISABLE ALL INTERRUPTS
002276 012767 000100 011302      MOV  #100,ICOUNT ;SET UP FOR 100 ITERATIONS
002304 012767 002444 011270      MOV  #44,ESCAPE  ;SET UP TO ESCAPE TO NEXT TEST
                                <>
                                MOV  #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
                                .ENDC
                                XN=XN+1

002312 000006 004000 011220      MOV  #BIT11,0DHSCR ;MASTER CLEAR INTERFACE

```



```

002320 004767 011054      1$: JSR    PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
                                ;BUS ADDRESS REGISTERS
002324 012777 000004 011206      MOV    #4,0DHSCR      ;SELECT LINE 4
002332 012777 177777 011210      MOV    #-1,0DHBC      ;SET BYTE COUNT TO 1
002340 012777 014320 011200      MOV    #TWRD4,0DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
002346 012700 000100      MOV    #100,R0      ;SET UP TO RECEIVE 64 CHARACTERS
002352 005001      CLR    R1      ;COUNT OF CHARACTERS RECEIVED
002354 012777 133503 011162      MOV    #133503,0DHLPR      ;SET UP SPEED FOR 9600 BAUD
                                ;8 BITS PER CHARACTER,
                                ;AUTO ECHO ENABLED ON LINE 4
                                ;SET BAR BIT FOR LINE 4
                                ;WAIT FOR CHARACTER TO
                                ;BE RECEIVED
                                ;UPDATE RECEIVED CHARACTER COUNT
                                ;READ CHARACTER
                                ;IS CHARACTER CORRECT

002362 012777 000020 011162      MOV    #20,0DHBAR      ;(R5)-EXPECTED CHARACTER
002370 105777 011144      2$: TSTB    0DHSCR      ;SHUT OFF AUTO ECHO
002374 100375      BPL     2$      ;CHARACTER ECHOED INCORRECTLY
002376 005201      INC     R1      ;RESTART TEST
002400 017704 011136      MOV    0DHNR,R4      ;IF 64 CHARACTERS HAVE NOT
002404 020467 011710      CMP     R4,TWRD4      ;BEEN RECEIVED, CONTINUE
002410 001406      BEQ     3$
002412 016705 011702      MOV    TWRD4,R5
002416 005077 011122      CLR     0DHLPR
002422      HLT     0
002422 104000      ENT     0
002424 000407      BR      4$
002426 005300      3$: DEC     R0
002430 003357      BGT     2$
002432 100404      BMI     4$
002434 042777 100000 011102      BIC     #100000,0DHLPR      ;SHUT OFF AUTO-ECHO
002442 000752      BR      2$      ;GET 1 MORE CHARACTER
002444 104400      4$: SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000005      LINE=LINE+1
      000040      BITX=BITX+BITX
      000005      KX=KX+1
002446      AUTO1   \LINE,\BITX,\KX

      ;ENABLE AUTO ECHO ON LINE 5
      ;TRANSMIT ONE CHARACTER ON LINE 5
      ;AT 9600 BAUD, 8 BITS.
      ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
      ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
      ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

002446      TS     \XN,100,4$
002446 012767 000340 175322      T6:  MOV    #340,PS      ;DISABLE ALL INTERRUPTS
002454 012767 000100 011124      MOV    #100,ICOUNT      ;SET UP FOR 100 ITERATIONS
002462 012767 002622 011112      MOV    #41,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
                                ;IF NB <>
                                MOV    #,FREEZ1      ;SET UP TO LOOP WITH DATA
                                .ENDC
                                XN=XN+1
                                1$: MOV    #BIT11,0DHSCR      ;MASTER CLEAR INTERFACE
                                JSR     PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
                                ;BUS ADDRESS REGISTERS
                                ;SELECT LINE 5
                                ;SET BYTE COUNT TO 1
                                ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
                                ;SET UP TO RECEIVE 64 CHARACTERS
                                ;COUNT OF CHARACTERS RECEIVED
                                ;SET UP SPEED FOR 9600 BAUD

002502 012777 000005 011030      MOV    #5,0DHSCR
002510 012777 177777 011032      MOV    #-1,0DHBC
002516 012777 014322 011022      MOV    #TWRD5,0DHBA
002524 012700 000100      MOV    #100,R0
002530 005001      CLR     R1
002532 012777 133503 011004      MOV    #133503,0DHLPR

```

```

002540 012777 000040 011004      MOV    #40,8DHBAR
002546 105777 010766      2$:  TSTB   8DHSCR
002552 100375              BPL     2$
002554 005201              INC     R1
002556 017704 010760      MOV    8DHNR,R4
002562 020467 011534      CMP     R4,TWRD5
002566 001406              BEQ     3$
002570 016705 011526      MOV    TWRD5,R5
002574 005077 010744      CLR     8DHLPR
002600              HLT     0
002600 104000              EMT     0
002602 000407              BR      4$
002604 005300      3$:  DEC     R0
002606 003357              BGT     2$
002610 100404              BMI     4$
002612 042777 100000 010724      BIC     #100000,8DHLPR
002620 000752              BR      2$
002622 104400      4$:  SCOPE
              LINE=LINE+1
              BITX=BITX+BITX
              KX=KX+1
002624      AUTO1  \LINE,\BITX,\KX

              ;ENABLE AUTO ECHO ON LINE 6
              ;TRANSMIT ONE CHARACTER ON LINE 6
              ;AT 9600 BAUD, 8 BITS.
              ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
              ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
              ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

002624      TS \XN,100,4$
002624 012767 000340 175144      T7:  MOV    #340,PS
002632 012767 000100 010746      MOV    #100,ICOUNT
002640 012767 003000 010734      MOV    #4$,ESCAPE
              .IF NB <>
              MOV    #,FREEZ1
              .ENDC
              XN=XN+1
002646 012777 004000 010664      MOV    #BIT11,8DHSCR
002654 004767 010520      1$:  JSR     PC,CLRALL
              MOV    #6,8DHSCR
              MOV    #-1,8DHBC
              MOV    #TWRD6,8DHBA
              MOV    #100,R0
              CLR     R1
002660 012777 000006 010652      MOV    #133503,8DHLPR
002666 012777 177777 010654
002674 012777 014324 010644
002702 012700 000100
002706 005001
002710 012777 133503 010626

002716 012777 000100 010626      MOV    #100,8DHBAR
002724 105777 010610      2$:  TSTB   8DHSCR
002730 100375              BPL     2$
002732 005201              INC     R1
002734 017704 010602      MOV    8DHNR,R4
002740 020467 011360      CMP     R4,TWRD6

;8 BITS PER CHARACTER,
;AUTO ECHO ENABLED ON LINE 5
;SET BAR BIT FOR LINE 5
;WAIT FOR CHARACTER TO
;BE RECEIVED
;UPDATE RECEIVED CHARACTER COUNT
;READ CHARACTER
;IS CHARACTER CORRECT

;(R5)=EXPECTED CHARACTER
;SHUT OFF AUTO ECHO
;CHARACTER ECHOED INCORRECTLY

;RESTART TEST
;IF 64 CHARACTERS HAVE NOT
;BEEN RECEIVED, CONTINUE

;SHUT OFF AUTO-ECHO
;GET 1 MORE CHARACTER
;CHECK FOR ITERATIONS, LOOP

;DISABLE ALL INTERRUPTS
;SET UP FOR 100 ITERATIONS
;SET UP TO ESCAPE TO NEXT TEST

;SET UP TO LOOP WITH DATA      : 3

;MASTER CLEAR INTERFACE
;CLEAR ALL BYTE COUNT AN
;BUS ADDRESS REGISTERS
;SELECT LINE 6
;SET BYTE COUNT TO 1
;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
;SET UP TO RECEIVE 64 CHARACTERS
;COUNT OF CHARACTERS RECEIVED
;SET UP SPEED FOR 9600 BAUD
;8 BITS PER CHARACTER,
;AUTO ECHO ENABLED ON LINE 6
;SET BAR BIT FOR LINE 6
;WAIT FOR CHARACTER TO
;BE RECEIVED
;UPDATE RECEIVED CHARACTER COUNT
;READ CHARACTER
;IS CHARACTER CORRECT

```



```

002744 001406      BEQ      3#
002746 016705 011352  MOV     TWRD6,R5      ;(R5)=EXPECTED CHARACTER
002752 005077 010566  CLR     @DHLPR      ;SHUT OFF AUTO ECHO
002756      104000      HLT     0      ;CHARACTER ECHOED INCORRECTLY
002760 000407      EMT     0
002762 005300      BR      4#      ;RESTART TEST
002764 003357      3#:    DEC     R0      ;IF 64 CHARACTERS HAVE NOT
002766 100404      BGT     2#      ;BEEN RECEIVED, CONTINUE
002770 042777 100000 010546  BMI     4#
002776 000752      BIC     @100000,@DHLPR      ;SHUT OFF AUTO-ECHO
003000 104400      BR      2#      ;GET 1 MORE CHARACTER
003002 000007      4#:    SCOPE      ;CHECK FOR ITERATIONS, LOOP
003002 000200      LINE=LINE+1
003002 000007      BITX=BITX+BITX
003002 000007      KX=KX+1
003002      AUTO1  \LINE,\BITX,\KX

;ENABLE AUTO ECHO ON LINE 7
;TRANSMIT ONE CHARACTER ON LINE 7
;AT 9600 BAUD, 8 BITS.
;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

003002      TS \XN,100,4#
003002 012767 000340 174766 T10:  MOV     @340,PS      ;DISABLE ALL INTERRUPTS
003010 012767 000100 010570      MOV     @100,ICOUNT      ;SET UP FOR 100 ITERATIONS
003016 012767 003156 010556      MOV     @4#,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
003016      .IF NB <>
003016      MOV     @,FREEZ1      ;SET UP TO LOOP WITH DATA      : 3
003016      .ENDC
003016      XN=XN+1
003024 012777 004000 010506      MOV     @BIT11,@DHSCR
003032 004767 010342      1#:    JSR     PC,CLRALL      ;MASTER CLEAR INTERFACE
003032      ;CLEAR ALL BYTE COUNT AN
003032      ;BUS ADDRESS REGISTERS
003036 012777 000007 010474      MOV     @7,@DHSCR      ;SELECT LINE 7
003044 012777 177777 010476      MOV     @-1,@DHBC      ;SET BYTE COUNT TO 1
003052 012777 014326 010466      MOV     @TWRD7,@DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
003060 012700 000100      MOV     @100,R0      ;SET UP TO RECEIVE 64 CHARACTERS
003064 005001      CLR     R1      ;COUNT OF CHARACTERS RECEIVED
003066 012777 133503 010450      MOV     @133503,@DHLPR      ;SET UP SPEED FOR 9600 BAUD
003066      ;8 BITS PER CHARACTER,
003066      ;AUTO ECHO ENABLED ON LINE 7
003074 012777 000200 010450      MOV     @200,@DHBAR      ;SET BAR BIT FOR LINE 7
003102 105777 010432      2#:    TSTB   @DHSCR      ;WAIT FOR CHARACTER TO
003106 100375      BPL     2#      ;BE RECEIVED
003110 005201      INC     R1      ;UPDATE RECEIVED CHARACTER COUNT
003112 017704 010424      MOV     @DHNR,R4      ;READ CHARACTER
003116 020467 011204      CMP     R4,TWRD7      ;IS CHARACTER CORRECT
003122 001406      BEQ     3#
003124 016705 011176      MOV     TWRD7,R5      ;(R5)=EXPECTED CHARACTER
003130 005077 010410      CLR     @DHLPR      ;SHUT OFF AUTO ECHO
003134      HLT     0      ;CHARACTER ECHOED INCORRECTLY
003134 104000      EMT     0
003136 000407      BR      4#      ;RESTART TEST
003140 005300      3#:    DEC     R0      ;IF 64 CHARACTERS HAVE NOT
003142 003357      BGT     2#      ;BEEN RECEIVED, CONTINUE

```

```

003144 100404      BMI      4#
003146 042777 100000 010370      BIC      #100000,8DHLPR      ;SHUT OFF AUTO-ECHO
003154 000752      BR      2#      ;GET 1 MORE CHARACTER
003156 104400      4#: SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000010      LINE=LINE+1
      000400      BITX=BITX+BITX
      000010      KX=KX+1
003160      AUTO1  \LINE,\BITX,\KX

      ;ENABLE AUTO ECHO ON LINE 10
      ;TRANSMIT ONE CHARACTER ON LINE 10
      ;AT 9600 BAUD, 8 BITS.
      ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
      ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
      ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

003160      TS \XN,100,4#
003160 012767 000340 174610      T11: MOV      #340,PS      ;DISABLE ALL INTERRUPTS
003166 012767 000100 010412      MOV      #100,ICOUNT      ;SET UP FOR 100 ITERATIONS
003174 012767 003334 010400      MOV      #4#,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB      <>
      MOV      #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
003202 012777 004000 010330      MOV      #BIT11,8DHSCR      ;MASTER CLEAR INTERFACE
003210 004767 010164      1#: JSR      PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
      ;BUS ADDRESS REGISTERS
003214 012777 000010 010316      MOV      #10,8DHSCR      ;SELECT LINE 10
003222 012777 177777 010320      MOV      #-1,8DHBC      ;SET BYTE COUNT TO 1
003230 012777 014330 010310      MOV      #TMRD10,8DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
003236 012700 000100      MOV      #100,R0      ;SET UP TO RECEIVE 64 CHARACTERS
003242 005001      CLR      R1      ;COUNT OF CHARACTERS RECEIVED
003244 012777 133503 010272      MOV      #133503,8DHLPR      ;SET UP SPEED FOR 9600 BAUD
      ;8 BITS PER CHARACTER,
      ;AUTO ECHO ENABLED ON LINE 10
      ;SET BAR BIT FOR LINE 10
      ;WAIT FOR CHARACTER TO
      ;BE RECEIVED
      ;UPDATE RECEIVED CHARACTER COUNT
      ;READ CHARACTER
      ;IS CHARACTER CORRECT
003252 012777 000400 010272      MOV      #400,8DHBR      ;(R5)=EXPECTED CHARACTER
003260 105777 010254      2#: TSTB      8DHSCR      ;SHUT OFF AUTO ECHO
003264 100375      BPL      2#      ;CHARACTER ECHOED INCORRECTLY
003266 005201      INC      R1
003270 017704 010246      MOV      8DHNR,R4      ;RESTART TEST
003274 020467 011030      CMP      R4,TMRD10      ;IF 64 CHARACTERS HAVE NOT
003300 001406      BEQ      3#      ;BEEN RECEIVED, CONTINUE
003302 016705 011022      MOV      TMRD10,R5
003306 005077 010232      CLR      8DHLPR
003312      HLT      0
003312 104000      EMT      0
003314 000407      BR      4#
003316 005300      3#: DEC      R0
003320 003357      BGT      2#
003322 100404      BMI      4#
003324 042777 100000 010212      BIC      #100000,8DHLPR      ;SHUT OFF AUTO-ECHO
003332 000752      BR      2#      ;GET 1 MORE CHARACTER
003334 104400      4#: SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000011      LINE=LINE+1
      001000      BITX=BITX+BITX
      000011      KX=KX+1
003336      AUTO1  \LINE,\BITX,\KX

```



```

;ENABLE AUTO ECHO ON LINE 11
;TRANSMIT ONE CHARACTER ON LINE 11
;AT 9600 BAUD, 8 BITS.
;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

```

003336				TS \XN,100,4		
003336	012767	000340	174432	T12:	MOV	#340,PS
003344	012767	000100	010234		MOV	#100,ICOUNT
003352	012767	003512	010222		MOV	#44,ESCAPE
				.IF NB	<>	
					MOV	#,FREEZ1
				.ENDC		
	000013			XN=XN+1		
003360	012777	004000	010152		MOV	#BIT11,SDHSCR
003366	004767	010006		14:	JSR	PC,CLRALL
003372	012777	000011	010140		MOV	#11,SDHSCR
003400	012777	177777	010142		MOV	#-1,SDHBC
003406	012777	014332	010132		MOV	#TMRD11,SDHBA
003414	012700	000100			MOV	#100,R0
003420	005001				CLR	R1
003422	012777	133503	010114		MOV	#133503,SDHLPR
003430	012777	001000	010114		MOV	#1000,SDHBAR
003436	105777	010076		24:	TSTB	SDHSCR
003442	100375				BPL	24
003444	005201				INC	R1
003446	017704	010070			MOV	SDHNR, R4
003452	020467	010654			CMP	R4, TMRD11
003456	001406				BEQ	34
003460	016705	010646			MOV	TMRD11, R5
003464	005077	010054			CLR	SDHLPR
003470					HLT	0
003470	104000				ENT	0
003472	000407				BR	44
003474	005300			34:	DEC	R0
003476	003357				BGT	24
003500	100404				BMI	44
003502	042777	100000	010034		BIC	#100000,SDHLPR
003510	000752				BR	24
003512	104400			44:	SCOPE	
	000012			LINE=LINE+1		
	002000			BITX=BITX+BITX		
	000012			KX=KX+1		
003514				AUTO1	\LINE, \BITX, \KX	

```

;DISABLE ALL INTERRUPTS
;SET UP FOR 100 ITERATIONS
;SET UP TO ESCAPE TO NEXT TEST

```

```

;SET UP TO LOOP WITH DATA ; 3

```

```

;MASTER CLEAR INTERFACE
;CLEAR ALL BYTE COUNT AN
;BUS ADDRESS REGISTERS
;SELECT LINE 11
;SET BYTE COUNT TO 1
;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
;SET UP TO RECEIVE 64 CHARACTERS
;COUNT OF CHARACTERS RECEIVED
;SET UP SPEED FOR 9600 BAUD
;8 BITS PER CHARACTER.
;AUTO ECHO ENABLED ON LINE 11
;SET BAR BIT FOR LINE 11
;WAIT FOR CHARACTER TO
;BE RECEIVED
;UPDATE RECEIVED CHARACTER COUNT
;READ CHARACTER
;IS CHARACTER CORRECT
;(R5)=EXPECTED CHARACTER
;SHUT OFF AUTO ECHO
;CHARACTER ECHOED INCORRECTLY

```

```

;RESTART TEST
;IF 64 CHARACTERS HAVE NOT
;BEEN RECEIVED, CONTINUE

```

```

;SHUT OFF AUTO-ECHO
;GET 1 MORE CHARACTER
;CHECK FOR ITERATIONS, LOOP

```

```

;ENABLE AUTO ECHO ON LINE 12
;TRANSMIT ONE CHARACTER ON LINE 12
;AT 9600 BAUD, 8 BITS.
;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

```

```

003514      TS \XN,100,4#
003514 012767 000340 174254 T13:  MOV  #340,PS      ;DISABLE ALL INTERRUPTS
003522 012767 000100 010056      MOV  #100,ICOUNT ;SET UP FOR 100 ITERATIONS
003530 012767 003670 010044      MOV  #4#,ESCAPE ;SET UP TO ESCAPE TO NEXT TEST
                .IF NB  <>
                MOV  #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
                .ENDC
                XN=XN+1
003536 012777 004000 007774      MOV  #BIT11,SDHSCR ;MASTER CLEAR INTERFACE
003544 004767 007630 1# :      JSR  PC,CLRALL ;CLEAR ALL BYTE COUNT AN
                                ;BUS ADDRESS REGISTERS
003550 012777 000012 007762      MOV  #12,SDHSCR ;SELECT LINE 12
003556 012777 177777 007764      MOV  #-1,SDHBC ;SET BYTE COUNT TO 1
003564 012777 014334 007754      MOV  #TWRD12,SDHBA ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
003572 012700 000100      MOV  #100,R0 ;SET UP TO RECEIVE 64 CHARACTERS
003576 005001      CLR  R1 ;COUNT OF CHARACTERS RECEIVED
003600 012777 133503 007736      MOV  #133503,SDHLPR ;SET UP SPEED FOR 9600 BAUD
                                ;8 BITS PER CHARACTER,
                                ;AUTO ECHO ENABLED ON LINE 12
                                ;SET BAR BIT FOR LINE 12
003606 012777 002000 007736      MOV  #2000,SDHBAR ;WAIT FOR CHARACTER TO
003614 105777 007720 2# :      TSTB SDHSCR ;BE RECEIVED
003620 100375      BPL  2# ;UPDATE RECEIVED CHARACTER COUNT
003622 005201      INC  R1 ;READ CHARACTER
003624 017704 007712      MOV  SDHNR, R4 ;IS CHARACTER CORRECT
003630 020467 010500      CMP  R4,TWRD12
003634 001406      BEQ  3#
003636 016705 010472      MOV  TWRD12,R5 ;(R5)-EXPECTED CHARACTER
003642 005077 007676      CLR  SDHLPR ;SHUT OFF AUTO ECHO
003646      HLT  0 ;CHARACTER ECHOED INCORRECTLY
003646 104000      ENT  0
003650 000407      BR  4# ;RESTART TEST
003652 005300 3# :      DEC  R0 ;IF 64 CHARACTERS HAVE NOT
003654 003357      BGT  2# ;BEEN RECEIVED, CONTINUE
003656 100404      BMI  4#
003660 042777 100000 007656      BIC  #100000,SDHLPR ;SHUT OFF AUTO-ECHO
003666 000752      BR  2# ;GET 1 MORE CHARACTER
003670 104400 4# :      SCOPE ;CHECK FOR ITERATIONS, LOOP
                LINE=LINE+1
                BITX=BITX+BITX
                KX=KX+1
003672      AUTO1 \LINE,\BITX,\KX

                ;ENABLE AUTO ECHO ON LINE 13
                ;TRANSMIT ONE CHARACTER ON LINE 13
                ;AT 9600 BAUD, 8 BITS.
                ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
                ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
                ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

003672      TS \XN,100,4#
003672 012767 000340 174076 T14:  MOV  #340,PS      ;DISABLE ALL INTERRUPTS
003700 012767 000100 007700      MOV  #100,ICOUNT ;SET UP FOR 100 ITERATIONS
003706 012767 004046 007666      MOV  #4#,ESCAPE ;SET UP TO ESCAPE TO NEXT TEST
                .IF NB  <>
                MOV  #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
                .ENDC
                XN=XN+1
000015

```



```

003714 012777 004000 007616      MOV    @BIT11,@DHSCR      ;MASTER CLEAR INTERFACE
003722 004767 007452      JSR      PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
                                           ;BUS ADDRESS REGISTERS
003726 012777 000013 007604      MOV    @13,@DHSCR      ;SELECT LINE 13
003734 012777 177777 007606      MOV    @-1,@DHBC      ;SET BYTE COUNT TO 1
003742 012777 014336 007576      MOV    @TWRD13,@DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
003750 012700 000100      MOV    @100,R0      ;SET UP TO RECEIVE 64 CHARACTERS
003754 005001      CLR      R1      ;COUNT OF CHARACTERS RECEIVED
003756 012777 133503 007560      MOV    @133503,@DHLPR      ;SET UP SPEED FOR 9600 BAUD
                                           ;8 BITS PER CHARACTER,
                                           ;AUTO ECHO ENABLED ON LINE 13
003764 012777 004000 007560      MOV    @4000,@DHBAR      ;SET BAR BIT FOR LINE 13
003772 105777 007542      2$:      TSTB    @DHSCR      ;WAIT FOR CHARACTER TO
003776 100375      BPL      2$      ;BE RECEIVED
004000 005201      INC      R1      ;UPDATE RECEIVED CHARACTER COUNT
004002 017704 007534      MOV    @DHNR,R4      ;READ CHARACTER
004006 020467 010324      CMP      R4,TWRD13      ;IS CHARACTER CORRECT
004012 001406      BEQ      3$
004014 016705 010316      MOV    TWRD13,R5      ;(R5)=EXPECTED CHARACTER
004020 005077 007520      CLR      @DHLPR      ;SHUT OFF AUTO ECHO
004024      HLT      0      ;CHARACTER ECHOED INCORRECTLY
004024 104000      EMT      0
004026 000407      BR      4$
004030 005300      3$:      DEC      R0      ;RESTART TEST
004032 003357      BGT      2$      ;IF 64 CHARACTERS HAVE NOT
004034 100404      BMI      4$      ;BEEN RECEIVED, CONTINUE
004036 042777 100000 007500      BIC    @100000,@DHLPR      ;SHUT OFF AUTO-ECHO
004044 000752      BR      2$      ;GET 1 MORE CHARACTER
004046 104400      4$:      SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000014      LINE=LINE+1
      010000      BITX=BITX+BITX
      000014      KX=KX+1
004050      AUTO1    \LINE,\BITX,\KX

      ;ENABLE AUTO ECHO ON LINE 14
      ;TRANSMIT ONE CHARACTER ON LINE 14
      ;AT 9600 BAUD, 8 BITS.
      ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
      ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
      ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

004050      TS \XN,100,4$
004050 012767 000340 173720      T15:    MOV    @340,PS      ;DISABLE ALL INTERRUPTS
004056 012767 000100 007522      MOV    @100,ICOUNT      ;SET UP FOR 100 ITERATIONS
004064 012767 004224 007510      MOV    @4$,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
                                           ;SET UP TO LOOP WITH DATA      : 3
      .IF NB    <>
      MOV      @,FREEZ1
      .ENDC
      XN=XN+1
004072 012777 004000 007440      MOV    @BIT11,@DHSCR      ;MASTER CLEAR INTERFACE
004100 004767 007274      1$:      JSR      PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
                                           ;BUS ADDRESS REGISTERS
004104 012777 000014 007426      MOV    @14,@DHSCR      ;SELECT LINE 14
004112 012777 177777 007430      MOV    @-1,@DHBC      ;SET BYTE COUNT TO 1
004120 012777 014340 007420      MOV    @TWRD14,@DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
004126 012700 000100      MOV    @100,R0      ;SET UP TO RECEIVE 64 CHARACTERS
004132 005001      CLR      R1      ;COUNT OF CHARACTERS RECEIVED

```

Address	Offset	Hex	Label	Operation	Comment
004134	012777	133503	007402	MOV	#133503, @DHLPR ;SET UP SPEED FOR 9600 BAUD
					;8 BITS PER CHARACTER,
					;AUTO ECHO ENABLED ON LINE 14
004142	012777	010000	007402	MOV	#10000, @DHBAR ;SET BAR BIT FOR LINE 14
004150	105777	007364	24:	TSTB	@DHSCR ;WAIT FOR CHARACTER TO
004154	100375			BPL	24 ;BE RECEIVED
004156	005201			INC	R1 ;UPDATE RECEIVED CHARACTER COUNT
004160	017704	007356		MOV	@DHNR, R4 ;READ CHARACTER
004164	020467	010150		CMP	R4, TWRD14 ;IS CHARACTER CORRECT
004170	001406			BEQ	34
004172	016705	010142		MOV	TWRD14, R5 ;(R5)=EXPECTED CHARACTER
004176	005077	007342		CLR	@DHLPR ;SHUT OFF AUTO ECHO
004202				HLT	0 ;CHARACTER ECHOED INCORRECTLY
004202	104000			EMT	0
004204	000407			BR	44 ;RESTART TEST
004206	005300		34:	DEC	R0 ;IF 64 CHARACTERS HAVE NOT
004210	003357			BGT	24 ;BEEN RECEIVED, CONTINUE
004212	100404			BMI	44
004214	042777	100000	007322	BIC	#100000, @DHLPR ;SHUT OFF AUTO-ECHO
004222	000752			BR	24 ;GET 1 MORE CHARACTER
004224	104400		44:	SCOPE	;CHECK FOR ITERATIONS, LOOP
	000015			LINE=LINE+1	
	020000			BITX=BITX+BITX	
	000015			KX=KX+1	
004226			AUTO1	\LINE, \BITX, \KX	
					;ENABLE AUTO ECHO ON LINE 15
					;TRANSMIT ONE CHARACTER ON LINE 15
					;AT 9600 BAUD, 8 BITS.
					;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
					;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
					;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.
004226			TS \XN, 100, 44		
004226	012767	000340	173542	T16: MOV	#340, PS ;DISABLE ALL INTERRUPTS
004234	012767	000100	007344	MOV	#100, ICOUNT ;SET UP FOR 100 ITERATIONS
004242	012767	004402	007332	MOV	#44, ESCAPE ;SET UP TO ESCAPE TO NEXT TEST
			.IF NB	<>	
				MOV	#, FREEZ1 ;SET UP TO LOOP WITH DATA ; 3
			.ENDC		
	000017			XN=XN+1	
004250	012777	004000	007262	MOV	#BIT11, @DHSCR ;MASTER CLEAR INTERFACE
004256	004767	007116	14:	JSR	PC, CLRALL ;CLEAR ALL BYTE COUNT AN
					;BUS ADDRESS REGISTERS
004262	012777	000015	007250	MOV	#15, @DHSCR ;SELECT LINE 15
004270	012777	177777	007252	MOV	#-1, @DHBC ;SET BYTE COUNT TO 1
004276	012777	014342	007242	MOV	#TWRD15, @DHBA ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
004304	012700	000100		MOV	#100, R0 ;SET UP TO RECEIVE 64 CHARACTERS
004310	005001			CLR	R1 ;COUNT OF CHARACTERS RECEIVED
004312	012777	133503	007224	MOV	#133503, @DHLPR ;SET UP SPEED FOR 9600 BAUD
					;8 BITS PER CHARACTER,
					;AUTO ECHO ENABLED ON LINE 15
					;SET BAR BIT FOR LINE 15
					;WAIT FOR CHARACTER TO
					;BE RECEIVED
					;UPDATE RECEIVED CHARACTER COUNT
					;READ CHARACTER
004320	012777	020000	007224	MOV	#20000, @DHBAR
004326	105777	007206	24:	TSTB	@DHSCR
004332	100375			BPL	24
004334	005201			INC	R1
004336	017704	007200		MOV	@DHNR, R4


```

004342 020467 007774      CMP      R4,TWRD15      ;IS CHARACTER CORRECT
004346 001406              BEQ        3$
004350 016705 007766      MOV      TWRD15,R5      ;(R5)=EXPECTED CHARACTER
004354 005077 007164      CLR      @DHLPR      ;SHUT OFF AUTO ECHO
004360              HLT        0      ;CHARACTER ECHOED INCORRECTLY
004360 104000              EMT        0
004362 000407              BR        4$
004364 005300      3$:      DEC      R0      ;RESTART TEST
004366 003357              BGT      2$      ;IF 64 CHARACTERS HAVE NOT
004370 100404              BMI      4$      ;BEEN RECEIVED, CONTINUE
004372 042777 100000 007144 BIC      @100000,@DHLPR      ;SHUT OFF AUTO-ECHO
004400 003752              BR        2$      ;GET 1 MORE CHARACTER
004402 104400      4$:      SCOPE      ;CHECK FOR ITERATIONS, LOOP
              LINE=LINE+1
              BITX=BITX+BITX
              KX=KX+1
004404      AUTO1  \LINE,\BITX,\KX

              ;ENABLE AUTO ECHO ON LINE 16
              ;TRANSMIT ONE CHARACTER ON LINE 16
              ;AT 9600 BAUD, 8 BITS.
              ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
              ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
              ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

004404      TS  \XN,100,4$
004404 012767 000340 173364 T17:      MOV      @340,PS      ;DISABLE ALL INTERRUPTS
004412 012767 000100 007166      MOV      @100,ICOUNT      ;SET UP FOR 100 ITERATIONS
004420 012767 004560 007154      MOV      @4$,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
              .IF NB      <>
              MOV      @,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
              .ENDC
              XN=XN+1
004426 012777 004000 007104      MOV      @BIT11,@DHSCR      ;MASTER CLEAR INTERFACE
004434 004767 006740      1$:      JSR      PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
              ;BUS ADDRESS REGISTERS
004440 012777 000016 007072      MOV      @16,@DHSCR      ;SELECT LINE 16
004446 012777 177777 007074      MOV      @-1,@DHBC      ;SET BYTE COUNT TO 1
004454 012777 014344 007064      MOV      @TWRD16,@DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
004462 012700 000100      MOV      @100,R0      ;SET UP TO RECEIVE 64 CHARACTERS
004466 005001      CLR      R1      ;COUNT OF CHARACTERS RECEIVED
004470 012777 133503 007046      MOV      @133503,@DHLPR      ;SET UP SPEED FOR 9600 BAUD
              ;8 BITS PER CHARACTER,
              ;AUTO ECHO ENABLED ON LINE 16
004476 012777 040000 007046      MOV      @40000,@DHBAR      ;SET BAR BIT FOR LINE 16
004504 105777 007030      2$:      TSTB      @DHSCR      ;WAIT FOR CHARACTER TO
004510 100375              BPL      2$      ;BE RECEIVED
004512 005201              INC      R1      ;UPDATE RECEIVED CHARACTER COUNT
004514 017704 007022      MOV      @DHNR,R4      ;READ CHARACTER
004520 020467 007620      CMP      R4,TWRD16      ;IS CHARACTER CORRECT
004524 001406              BEQ      3$
004526 016705 007612      MOV      TWRD16,R5      ;(R5)=EXPECTED CHARACTER
004532 005077 007006      CLR      @DHLPR      ;SHUT OFF AUTO ECHO
004536              HLT        0      ;CHARACTER ECHOED INCORRECTLY
004536 104000              EMT        0
004540 000407              BR        4$
004542 005300      3$:      DEC      R0      ;RESTART TEST
              ;IF 64 CHARACTERS HAVE NOT

```

```

004544 003357          BGT      2#
004546 100404          BMI      4#
004550 042777 100000 006766 BIC      #100000, @DHLPR
004556 000752          BR       2#
004560 104400          4# : SCOPE
      000017          LINE=LINE+1
      100000          BITX=BITX+BITX
      000017          KX=KX+1
004562          AUTO1  \LINE, \BITX, \KX

      ;ENABLE AUTO ECHO ON LINE 17
      ;TRANSMIT ONE CHARACTER ON LINE 17
      ;AT 9600 BAUD, 8 BITS.
      ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
      ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
      ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

004562 TS \XN, 100, 4#
004562 012767 000340 173206 T20:  MOV      #340, PS
004570 012767 000100 007010      MOV      #100, ICOUNT
004576 012767 004736 006776      MOV      #4#, ESCAPE
      .IF NB <>
      MOV      #, FREEZ1
      .ENDC
      XN=XN+1
004604 012777 004000 006726      MOV      #BIT11, @DHSCR
004612 004767 006562          1# : JSR      PC, CLRALL
      MOV      #17, @DHSCR
004616 012777 000017 006714      MOV      #-1, @DHBC
004624 012777 177777 006716      MOV      #TWRD17, @DHBA
004632 012777 014346 006706      MOV      #100, R0
004640 012700 000100          CLR      R1
004644 005001          MOV      #133503, @DHLPR
004646 012777 133503 006670

004654 012777 100000 006670      MOV      #100000, @DHBAR
004662 105777 006652          2# : TSTB     @DHSCR
004666 100375          BPL      2#
004670 005201          INC      R1
004672 017704 006644          MOV      @DHNR, R4
004676 020467 007444          CMP      R4, TWRD17
004702 001406          BEQ      3#
004704 016705 007436          MOV      TWRD17, R5
004710 005077 006630          CLR      @DHLPR
004714          HLT      0
004714 104000          EMT      0
004716 000407          BR       4#
004720 005300          3# : DEC      R0
004722 003357          BGT      2#
004724 100404          BMI      4#
004726 042777 100000 006610 BIC      #100000, @DHLPR
004734 000752          BR       2#
004736 104400          4# : SCOPE
      000020          LINE=LINE+1
      000000          BITX=BITX+BITX
      000020          KX=KX+1

      ;DISABLE ALL INTERRUPTS
      ;SET UP FOR 100 ITERATIONS
      ;SET UP TO ESCAPE TO NEXT TEST
      ;SET UP TO LOOP WITH DATA ; 3

      ;MASTER CLEAR INTERFACE
      ;CLEAR ALL BYTE COUNT AN
      ;BUS ADDRESS REGISTERS
      ;SELECT LINE 17
      ;SET BYTE COUNT TO 1
      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
      ;SET UP TO RECEIVE 64 CHARACTERS
      ;COUNT OF CHARACTERS RECEIVED
      ;SET UP SPEED FOR 9600 BAUD
      ;8 BITS PER CHARACTER,
      ;AUTO ECHO ENABLED ON LINE 17
      ;SET BAR BIT FOR LINE 17
      ;WAIT FOR CHARACTER TO
      ;BE RECEIVED
      ;UPDATE RECEIVED CHARACTER COUNT
      ;READ CHARACTER
      ;IS CHARACTER CORRECT

      ;(R5)=EXPECTED CHARACTER
      ;SHUT OFF AUTO ECHO
      ;CHARACTER ECHOED INCORRECTLY

      ;RESTART TEST
      ;IF 64 CHARACTERS HAVE NOT
      ;BEEN RECEIVED, CONTINUE

      ;SHUT OFF AUTO-ECHO
      ;GET 1 MORE CHARACTER
      ;CHECK FOR ITERATIONS, LOOP

```



```

18      000020      XLINE=LINE
19      000000      XBIT=BITX
20      000020      K=KX
21      000000      LINE=0
22      000001      BITX=1
23      000000      KX=0
25      000020      .REPT 20
26      AUTO2      \LINE,\BITX,\KX
27      .NLIST
28      LINE=LINE+1
29      BITX=BITX+BITX
30      KX=KX+1
31      .LIST
32      .ENDR
      004740      AUTO2 \LINE,\BITX,\KX

```

```

;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 0
;TRANSMIT 1 CHARACTER ON LINE 0 WITH AUTO ECHO ENABLED
;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
;CHARACTER LENGTH IS 8 BITS
;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

```

```

004740      000022      TS \XN,10,5
004740      012767      000340      173030      T21:  MOV  #340,PS          ;DISABLE ALL INTERRUPTS
004746      012767      000010      006632      MOV  #10,ICOUNT      ;SET UP FOR 10 ITERATIONS
004754      012767      005174      006620      MOV  #5,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB  <>
      MOV  #,FREEZ1          ;SET UP TO LOOP WITH DATA          ; 3
      .ENDC
      XN=XN+1
004762      012777      004000      006550      MOV  #BIT11,0DHSCR      ;MASTER CLEAR INTERFACE
004770      004767      006432      JSR  PC,SETALL      ;SET UP ALL LINES TO TRANSMIT
      ;400 (OCTAL) CHARACTERS
004774      012777      000000      006536      MOV  #0,0DHSCR      ;SELECT LINE 0 FOR TESTING
005002      012777      014310      006536      MOV  #TMRD0,0DHBA      ;CHARACTER TO BE TRANSMITTED
      ;ON LINE 0 IN AUTO ECHO MODE
005010      012777      177777      006532      MOV  #-1,0DHBC      ;TRANSMIT ONLY 1 CHARACTER ON LINE 0
005016      012777      133503      006520      MOV  #133503,0DHLPR      ;SET AUTO ECHO FOR LINE 0
005024      042767      000001      006610      BIC  #1,LINACT      ;CLEAR LINE ACTIVE BIT
005032      012777      177777      006512      MOV  #-1,0DHBA      ;SET BAR BITS FOR ALL LINES
005040      005000      CLR  R0          ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
005042      017704      006474      1$:  MOV  #0DHNR,R4      ;GET A CHARACTER FROM SILO
005046      100375      BPL  1$          ;IF NOT VALID DATA, TRY AGAIN
005050      010403      MOV  R4,R3      ;EXTRACT LINE NUMBER FORM CHARACTER
005052      000303      SWAB R3
005054      042703      177760      BIC  #177760,R3      ;CLEAR STATUS BITS
005060      010302      MOV  R3,R2
005062      006302      ASL  R2
005064      020327      000000      CMP  R3,#0      ;IF LINE NUMBER IS 0
005070      001432      BEQ  4$          ;CHECK FOR CORRECT ECHOED CHARACTER
005072      026204      014246      CMP  RBUF(R2),R4      ;IF NOT LINE 0, CHECK DATA
005076      001404      BEQ  2$          ;(R5)=EXPECTED NON ECHOED DATA
005100      016205      014246      MOV  RBUF(R2),R5      ;NON ECHOED DATA ERROR
005104      104001      HLT  1
005106      000423      EMT  1
005110      105262      014246      2$:  INCB RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA

```

```

005114 001352      BNE      1$      ;CONTINUE IF NOT DONE
005116 046267 014450 006516      BIC      LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
005124 005767 006512      TST      LINACT      ;IF ALL LINES ARE DONE
005130 001344      BNE      1$      ;EXIT
005132 012777 000000 006400      MOV      #0,0DHSCR      ;SELECT LINE 0
005140 042777 100000 006376      BIC      #100000,0DHLPR      ;CLEAR AUTO ECHO FOR LINE 0
005146 105777 006406      TSTB     0DHSLR      ;GET REST OF CHARACTERS
005152 001333      BNE      1$      ;AND CHECK
005154 000407      BR       5$
005156 005200      4$:      INC      R0      ;UPDATE ECHOED CHARACTER COUNT
005160 020467 007124      CMP      R4,TWRD0      ;CHECK ECHOED DATA
005164 001757      BEQ      3$
005166 016705 007116      MOV      TWRD0,R5      ;(R5)=EXPECTED ECHOED DATA
005172      HLT      2      ;ECHOED DATA ERROR
005172 104002      EMT      2
005174 104400      5$:      SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000001      LINE=LINE+1
      000002      BITX=BITX+BITX
      000001      KX=KX+1
005176      AUTO2     \LINE,\BITX,\KX

      ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 1
      ;TRANSMIT 1 CHARACTER ON LINE 1 WITH AUTO ECHO ENABLED
      ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
      ;CHARACTER LENGTH IS 8 BITS
      ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

005176      TS \XN,10,5$
005176 012767 000340 172572 T22:      MOV      #340,PS      ;DISABLE ALL INTERRUPTS
005204 012767 000010 006374      MOV      #10,ICOUNT      ;SET UP FOR 10 ITERATIONS
005212 012767 005432 006362      MOV      #5$,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB      <>
      MOV      #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
005220 000023      MOV      #BIT11,0DHSCR      ;MASTER CLEAR INTERFACE
005226 004767 006174      JSR      PC,SETALL      ;SET UP ALL LINES TO TRANSMIT
      ;400 (OCTAL) CHARACTERS
005232 012777 000001 006300      MOV      #1,0DHSCR      ;SELECT LINE 1 FOR TESTING
005240 012777 014312 006300      MOV      #TWRD1,0DHBA      ;CHARACTER TO BE TRANSMITTED
      ;ON LINE 1 IN AUTO ECHO MODE
005246 012777 177777 006274      MOV      #-1,0DHBC      ;TRANSMIT ONLY 1 CHARACTER ON LINE 1
005254 012777 133503 006262      MOV      #133503,0DHLPR      ;SET AUTO ECHO FOR LINE 1
005262 042767 000002 006352      BIC      #2,LINACT      ;CLEAR LINE ACTIVE BIT
005270 012777 177777 006254      MOV      #-1,0DHBA      ;SET BAR BITS FOR ALL LINES
005276 005000      CLR      R0      ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
005300 017704 006236      1$:      MOV      0DHNR,R4      ;GET A CHARACTER FROM SILO
005304 100375      BPL      1$      ;IF NOT VALID DATA, TRY AGAIN
005306 010403      MOV      R4,R3      ;EXTRACT LINE NUMBER FORM CHARACTER
005310 000303      SWAB     R3
005312 042703 177760      BIC      #177760,R3      ;CLEAR STATUS BITS
005316 010302      MOV      R3,R2
005320 006302      ASL      R2
005322 020327 000001      CMP      R3,#1      ;IF LINE NUMBER IS 1
005326 001432      BEQ      4$      ;CHECK FOR CORRECT ECHOED CHARACTER
005330 026204 014246      CMP      RBUF(R2),R4      ;IF NOT LINE 1, CHECK DATA
005334 001404      BEQ      2$

```



```

005336 016205 014246      MOV      RBUF(R2),R5      ;(R5)=EXPECTED NON ECHOED DATA
005342      HLT      1      ;NON ECHOED DATA ERROR
005342 104001      EMT      1
005344 000423      BR      4$
005346 105262 014246      2$: INCB     RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
005352 001352      BNE     1$      ;CONTINUE IF NOT DONE
005354 046267 014450 006260 3$: BIC     LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
005362 005767 006254      TST     LINACT      ;IF ALL LINES ARE DONE
005366 001344      BNE     1$      ;EXIT
005370 012777 000001 006142 MOV     #1,0DHSCR      ;SELECT LINE 1
005376 042777 100000 006140 BIC     #100000,0DHLPR ;CLEAR AUTO ECHO FOR LINE 1
005404 105777 006150      TSTB     0DHSLR      ;GET REST OF CHARACTERS
005410 001333      BNE     1$      ;AND CHECK
005412 000407      BR      5$
005414 005200      4$: INC      R0      ;UPDATE ECHOED CHARACTER COUNT
005416 020467 006670      CMP     R4,TWRD1      ;CHECK ECHOED DATA
005422 001757      BEQ     3$
005424 016705 006662      MOV     TWRD1,R5      ;(R5)=EXPECTED ECHOED DATA
005430      HLT      2      ;ECHOED DATA ERROR
005430 104002      EMT      2
005432 104400      5$: SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000002      LINE=LINE+1
      000004      BITX=BITX+BITX
      000002      KX=KX+1
005434      AUTO2   \LINE,\BITX,\KX

      ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 2
      ;TRANSMIT 1 CHARACTER ON LINE 2 WITH AUTO ECHO ENABLED
      ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
      ;CHARACTER LENGTH IS 8 BITS
      ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

005434      TS \XN,10,5$
005434 012767 000340 172334 T23: MOV     #340,PS      ;DISABLE ALL INTERRUPTS
005442 012767 000010 006136 MOV     #10,ICOUNT    ;SET UP FOR 10 ITERATIONS
005450 012767 005670 006124 MOV     #5$,ESCAPE    ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB      <>
      MOV     #,FREEZ1      ;SET UP TO LOOP WITH DATA      : 3
      .ENDC
      XN=XN+1
005456 012777 004000 006054 MOV     #BIT11,0DHSCR  ;MASTER CLEAR INTERFACE
005464 004767 005736      JSR     PC,SETALL      ;SET UP ALL LINES TO TRANSMIT
      ;400 (OCTAL) CHARACTERS
005470 012777 000002 006042 MOV     #2,0DHSCR      ;SELECT LINE 2 FOR TESTING
005476 012777 014314 006042 MOV     #TWRD2,0DHBA    ;CHARACTER TO BE TRANSMITTED
      ;ON LINE 2 IN AUTO ECHO MODE
005504 012777 177777 006036 MOV     #-1,0DHBC      ;TRANSMIT ONLY 1 CHARACTER ON LINE 2
005512 012777 133503 006024 MOV     #133503,0DHLPR ;SET AUTO ECHO FOR LINE 2
005520 042767 000004 006114 BIC     #4,LINACT      ;CLEAR LINE ACTIVE BIT
005526 012777 177777 006016 MOV     #-1,0DHBA      ;SET BAR BITS FOR ALL LINES
005534 005000      CLR     R0      ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
005536 017704 006000      1$: MOV     0DHNR,R4      ;GET A CHARACTER FROM SILO
005542 100375      BPL     1$      ;IF NOT VALID DATA, TRY AGAIN
005544 010403      MOV     R4,R3      ;EXTRACT LINE NUMBER FORM CHARACTER
005546 000303      SWAB    R3
005550 042703 177760      BIC     #177760,R3      ;CLEAR STATUS BITS
005554 010302      MOV     R3,R2

```

```

005556 006302          ASL      R2
005560 020327 000002    CMP      R3,#2          ;IF LINE NUMBER IS 2
005564 001432          BEQ      4$              ;CHECK FOR CORRECT ECHOED CHARACTER
005566 026204 014246    CMP      RBUF(R2),R4      ;IF NOT LINE 2, CHECK DATA
005572 001404          BEQ      2$
005574 016205 014246    MOV      RBUF(R2),R5      ;(R5)=EXPECTED NON ECHOED DATA
005600          HLT      1                      ;NON ECHOED DATA ERROR
005600 104001          EMT      1
005602 000423          BR      4$
005604 105262 014246    2$: INCB    RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
005610 001352          BNE      1$              ;CONTINUE IF NOT DONE
005612 046267 014450 006022 BIC     LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
005620 005767 006016    3$: TST     LINACT        ;IF ALL LINES ARE DONE
005624 001344          BNE      1$              ;EXIT
005626 012777 000002 005704 MOV     #2,0DHSCR      ;SELECT LINE 2
005634 042777 100000 005702 BIC     #100000,0DHLPR ;CLEAR AUTO ECHO FOR LINE 2
005642 105777 005712    TSTB    0DHSLR          ;GET REST OF CHARACTERS
005646 001333          BNE      1$              ;AND CHECK
005650 000407          BR      5$
005652 005200          4$: INC      R0              ;UPDATE ECHOED CHARACTER COUNT
005654 020467 006434    CMP      R4,TWRD2        ;CHECK ECHOED DATA
005660 001757          BEQ      3$
005662 016705 006426    MOV      TWRD2,R5        ;(R5)=EXPECTED ECHOED DATA
005666 104002          HLT      2                      ;ECHOED DATA ERROR
005666 104400          EMT      2
005670 000003          5$: SCOPE
005670 000010          LINE=LINE+1
005670 000003          BITX=BITX+BITX
005672          KX=KX+1
005672          AUTO2  \LINE,\BITX,\KX

;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 3
;TRANSMIT 1 CHARACTER ON LINE 3 WITH AUTO ECHO ENABLED
;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
;CHARACTER LENGTH IS 8 BITS
;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

005672          TS  \XN,10,5$
005672 012767 000340 172076 T24: MOV     #340,PS          ;DISABLE ALL INTERRUPTS
005700 012767 000010 005700 MOV     #10,ICOUNT      ;SET UP FOR 10 ITERATIONS
005706 012767 006126 005666 MOV     #5$,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
005706          .IF NB <>
005706          MOV     #,FREEZ1          ;SET UP TO LOOP WITH DATA ; 3
005706          .ENDC
005706          XN=XN+1
005714 012777 004000 005616 MOV     #BIT11,0DHSCR      ;MASTER CLEAR INTERFACE
005722 004767 005500          JSR     PC,SETALL      ;SET UP ALL LINES TO TRANSMIT
005722          ;400 (OCTAL) CHARACTERS
005726 012777 000003 005604 MOV     #3,0DHSCR        ;SELECT LINE 3 FOR TESTING
005734 012777 014316 005604 MOV     #TWRD3,0DHBA      ;CHARACTER TO BE TRANSMITTED
005734          ;ON LINE 3 IN AUTO ECHO MODE
005742 012777 177777 005600 MOV     #-1,0DHBC        ;TRANSMIT ONLY 1 CHARACTER ON LINE 3
005750 012777 133503 005566 MOV     #133503,0DHLPR ;SET AUTO ECHO FOR LINE 3
005756 042767 000010 005656 BIC     #10,LINACT      ;CLEAR LINE ACTIVE BIT
005764 012777 177777 005560 MOV     #-1,0DHBA        ;SET BAR BITS FOR ALL LINES
005772 005000          CLR      R0              ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
005774 017704 005542    1$: MOV     0DHNR, R4      ;GET A CHARACTER FROM SILO

```



```

006000 100375      BPL      1#
006002 010403      MOV      R4,R3
006004 000303      SWAB     R3
006006 042703 177760 BIC      @177760,R3
006012 010302      MOV      R3,R2
006014 006302      ASL      R2
006016 020327 000003 CMP      R3,#3
006022 001432      BEQ      4#
006024 026204 014246 CMP      RBUF(R2),R4
006030 001404      BEQ      2#
006032 016205 014246 MOV      RBUF(R2),R5
006036          HLT      1
006036 104001      EMT      1
006040 000423      ER      4#
006042 105262 014246 2# : INCB     RBUF(R2)
006046 001352      BNE      1#
006050 046267 014450 005564 BIC      LINBIT(R2),LINACT
006056 005767 005560 3# : TST      LINACT
006062 001344      BNE      1#
006064 012777 000003 005446 MOV      @3,@DHSCR
006072 042777 100000 005444 BIC      @100000,@DHLPR
006100 105777 005454      TSTB     @DHSLR
006104 001333      BNE      1#
006106 000407      BR      5#
006110 005200      4# : INC      R0
006112 020467 006200      CMP      R4,TWRD3
006116 001757      BEQ      3#
006120 016705 006172      MOV      TWRD3,R5
006124          HLT      2
006124 104002      EMT      2
006126 104400      5# : SCOPE
          LINE=LINE+1
          BITX=BITX+BITX
          KX=KX+1
006130          AUTO2  \LINE,\BITX,\KX

          ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 4
          ;TRANSMIT 1 CHARACTER ON LINE 4 WITH AUTO ECHO ENABLED
          ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
          ;CHARACTER LENGTH IS 8 BITS
          ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

006130          TS  \XN,10,5#
006130 012767 000340 171640 T25:  MOV      @340,PS
006136 012767 000010 005442      MOV      @10,ICOUNT
006144 012767 006364 005430      MOV      @5#,ESCAPE
          .IF NB <>
          MOV      @,FREEZ1
          .ENDC
          XN=XN+1
          ;DISABLE ALL INTERRUPTS
          ;SET UP FOR 10 ITERATIONS
          ;SET UP TO ESCAPE TO NEXT TEST
          ;SET UP TO LOOP WITH DATA
          ; 3

006152 012777 004000 005360      MOV      @BIT11,@DHSCR
006160 004767 005242      JSR      PC,SETALL
          ;MASTER CLEAR INTERFACE
          ;SET UP ALL LINES TO TRANSMIT
          ;400 (OCTAL) CHARACTERS
          ;SELECT LINE 4 FOR TESTING
          ;CHARACTER TO BE TRANSMITTED
          ;ON LINE 4 IN AUTO ECHO MODE
          ;TRANSMIT ONLY 1 CHARACTER ON LINE 4
006164 012777 000004 005346      MOV      @4,@DHSCR
006172 012777 014320 005346      MOV      @TWRD4,@DHBA
006200 012777 177777 005342      MOV      @-1,@DHBC

```

```

006206 012777 133503 005330      MOV      #133503, @DHLPR      ;SET AUTO ECHO FOR LINE 4
006214 042767 000020 005420      BIC      #20, LINACT      ;CLEAR LINE ACTIVE BIT
006222 012777 177777 005322      MOV      #1, @DHBAR      ;SET BAR BITS FOR ALL LINES
006230 005000                      CLR      R0      ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
006232 017704 005304      1$: MOV      @DHNR, R4      ;GET A CHARACTER FROM SILO
006236 100375                      BPL      1$      ;IF NOT VALID DATA, TRY AGAIN
006240 010403                      MOV      R4, R3      ;EXTRACT LINE NUMBER FORM CHARACTER
006242 000303                      SWAB     R3
006244 042703 177760      BIC      #177760, R3      ;CLEAR STATUS BITS
006250 010302                      MOV      R3, R2
006252 006302                      ASL      R2
006254 020327 000004      CMP      R3, #4      ;IF LINE NUMBER IS 4
006260 001432                      BEQ      4$      ;CHECK FOR CORRECT ECHOED CHARACTER
006262 026204 014246      CMP      RBUF(R2), R4      ;IF NOT LINE 4, CHECK DATA
006266 001404                      BEQ      2$
006270 016205 014246      MOV      RBUF(R2), R5      ;(R5)=EXPECTED NON ECHOED DATA
006274                      HLT      1      ;NON ECHOED DATA ERROR
006274 104001                      EMT      1
006276 000423                      BR      4$
006300 105262 014246      2$: INCB     RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
006304 001352                      BNE      1$      ;CONTINUE IF NOT DONE
006306 046267 014450 005326      BIC      LINBIT(R2), LINACT      ;CLEAR ACTIVE BIT
006314 005767 005322      3$: TST      LINACT      ;IF ALL LINES ARE DONE
006320 001344                      BNE      1$      ;EXIT
006322 012777 000004 005210      MOV      #4, @DHSCR      ;SELECT LINE 4
006330 042777 100000 005206      BIC      #100000, @DHLPR      ;CLEAR AUTO ECHO FOR LINE 4
006336 105777 005216      TSTB     @DHSLR      ;GET REST OF CHARACTERS
006342 001333                      BNE      1$      ;AND CHECK
006344 000407                      BR      5$
006346 005200      4$: INC      R0      ;UPDATE ECHOED CHARACTER COUNT
006350 020467 005744      CMP      R4, TWRD4      ;CHECK ECHOED DATA
006354 001757                      BEQ      3$
006356 016705 005736      MOV      TWRD4, R5      ;(R5)=EXPECTED ECHOED DATA
006362                      HLT      2      ;ECHOED DATA ERROR
006362 104002                      EMT      2
006364 104400      5$: SCOPE
006364 000005      LINE=LINE+1
006364 000040      BITX=BITX+BITX
006364 000005      KX=KX+1
006366      AUTO2  \LINE, \BITX, \KX

;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 5
;TRANSMIT 1 CHARACTER ON LINE 5 WITH AUTO ECHO ENABLED
;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
;CHARACTER LENGTH IS 8 BITS
;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

006366      TS  \XN, 10, 5$
006366 012767 000340 171402      T26: MOV      #340, PS      ;DISABLE ALL INTERRUPTS
006374 012767 000010 005204      MOV      #10, ICOUNT      ;SET UP FOR 10 ITERATIONS
006402 012767 006622 005172      MOV      #5$, ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB <>
      MOV      #, FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
006410 000027 004000 005122      MOV      @BIT11, @DHSCR      ;MASTER CLEAR INTERFACE
006416 004767 005004      JSR      PC, SETALL      ;SET UP ALL LINES TO TRANSMIT

```



```

006422 012777 000005 005110      MOV    #5, @DHSCR
006430 012777 014322 005110      MOV    @TWRD5, @DHBA      ;CHARACTER TO BE TRANSMITTED
                                ;400 (OCTAL) CHARACTERS
                                ;SELECT LINE 5 FOR TESTING
                                ;ON LINE 5 IN AUTO ECHO MODE
                                ;TRANSMIT ONLY 1 CHARACTER ON LINE 5
                                ;SET AUTO ECHO FOR LINE 5
006436 012777 177777 005104      MOV    #-1, @DHBC
006444 012777 133503 005072      MOV    #133503, @DHLPR
006452 042767 000040 005162      BIC    #40, LINACT      ;CLEAR LINE ACTIVE BIT
006460 012777 177777 005064      MOV    #-1, @DHBAR
                                ;SET BAR BITS FOR ALL LINES
                                ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
006466 005000                      CLR    R0
                                ;GET A CHARACTER FROM SILO
006470 017704 005046      1$:    MOV    @DHNR, R4
                                ;IF NOT VALID DATA, TRY AGAIN
006474 100375                      BPL    1$
                                ;EXTRACT LINE NUMBER FORM CHARACTER
006476 010403                      MOV    R4, R3
                                ;CLEAR STATUS BITS
006500 000303                      SWAB   R3
006502 042703 177760      BIC    #177760, R3
006506 010302                      MOV    R3, R2
006510 006302                      ASL    R2
006512 020327 000005      CMP     R3, #5      ;IF LINE NUMBER IS 5
006516 001432                      BEQ    4$      ;CHECK FOR CORRECT ECHOED CHARACTER
006520 026204 014246      CMP     RBUF(R2), R4      ;IF NOT LINE 5, CHECK DATA
006524 001404                      BEQ    2$
006526 016205 014246      MOV     RBUF(R2), R5
                                ;(R5)-EXPECTED NON ECHOED DATA
006532                      HLT     1
                                ;NON ECHOED DATA ERROR
006532 104001                      EMT     1
006534 000423                      BR     4$
                                ;UPDATE EXPECTED RECEIVED DATA
006536 105262 014246      2$:    INCB   RBUF(R2)
                                ;CONTINUE IF NOT DONE
006542 001352                      BNE    1$
                                ;CLEAR ACTIVE BIT
006544 046267 014450 005070      BIC    LINBIT(R2), LINACT
                                ;IF ALL LINES ARE DONE
006552 005767 005064      3$:    TST    LINACT
                                ;EXIT
006556 001344                      BNE    1$
                                ;SELECT LINE 5
006560 012777 000005 004752      MOV    #5, @DHSCR
                                ;CLEAR AUTO ECHO FOR LINE 5
006566 042777 100000 004750      BIC    #100000, @DHLPR
                                ;GET REST OF CHARACTERS
006574 105777 004760      TSTB   @DHSLR
                                ;AND CHECK
006600 001333                      BNE    1$
006602 000407                      BR     5$
                                ;UPDATE ECHOED CHARACTER COUNT
006604 005200                      4$:    INC    R0
                                ;CHECK ECHOED DATA
006606 020467 005510      CMP     R4, TWRD5
                                ;(R5)-EXPECTED ECHOED DATA
006612 001757                      BEQ    3$
                                ;ECHOED DATA ERROR
006614 016705 005502      MOV     TWRD5, R5
006620                      HLT     2
006620 104002                      EMT     2
006622 104400                      5$:    SCOPE
                                ;CHECK FOR ITERATIONS, LOOP
                                LINE=LINE+1
                                BITX=BITX+BITX
                                KX=KX+1
006624                      AUTO2   \LINE, \BITX, \KX

                                ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 6
                                ;TRANSMIT 1 CHARACTER ON LINE 6 WITH AUTO ECHO ENABLED
                                ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
                                ;CHARACTER LENGTH IS 8 BITS
                                ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

006624                      TS     \XN, 10, 5$
006624 012767 000340 171144      T27:  MOV    #340, PS
                                ;DISABLE ALL INTERRUPTS
006632 012767 000010 004746      MOV    #10, ICOUNT
                                ;SET UP FOR 10 ITERATIONS
006640 012767 007060 004734      MOV    #5, ESCAPE
                                ;SET UP TO ESCAPE TO NEXT TEST
                                .IF NB <>

```

```

                                MOV     #,FREEZ1                ;SET UP TO LOOP WITH DATA      ; 3
                                .ENDC
                                XN=XN+1
006646 000030 004000 004664      MOV     #BIT11, @DHSCR          ;MASTER CLEAR INTERFACE
006654 004767 004546              JSR     PC,SETALL             ;SET UP ALL LINES TO TRANSMIT
                                                                ;400 (OCTAL) CHARACTERS
006660 012777 000006 004652      MOV     #6, @DHSCR          ;SELECT LINE 6 FOR TESTING
006666 012777 014324 004652      MOV     #TWRD6, @DHBA      ;CHARACTER TO BE TRANSMITTED
                                                                ;ON LINE 6 IN AUTO ECHO MODE
006674 012777 177777 004646      MOV     #-1, @DHBC          ;TRANSMIT ONLY 1 CHARACTER ON LINE 6
006702 012777 133503 004634      MOV     #133503, @DHLPR      ;SET AUTO ECHO FOR LINE 6
006710 042767 000100 004724      BIC     #100, LINACT        ;CLEAR LINE ACTIVE BIT
006716 012777 177777 004626      MOV     #-1, @DHBA          ;SET BAR BITS FOR ALL LINES
006724 005000              CLR     R0                ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
006726 017704 004610 10:      MOV     @DHNR, R4          ;GET A CHARACTER FROM SILO
006732 100375              BPL     10                    ;IF NOT VALID DATA, TRY AGAIN
006734 010403              MOV     R4, R3                ;EXTRACT LINE NUMBER FORM CHARACTER
006736 000303              SWAB    R3
006740 042703 177760      BIC     #177760, R3
006744 010302              MOV     R3, R2
006746 006302              ASL     R2
006750 020327 000006      CMP     R3, #6                ;IF LINE NUMBER IS 6
006754 001432              BEQ     40                    ;CHECK FOR CORRECT ECHOED CHARACTER
006756 026204 014246      CMP     RBUF(R2), R4          ;IF NOT LINE 6, CHECK DATA
006762 001404              BEQ     20
006764 016205 014246      MOV     RBUF(R2), R5          ;(R5)-EXPECTED NON ECHOED DATA
006770              HLT     1                ;NON ECHOED DATA ERROR
006770 104001              EMT     1
006772 000423              BR     40
006774 105262 014246 20:      INCB    RBUF(R2)          ;UPDATE EXPECTED RECEIVED DATA
007000 001352              BNE     10                    ;CONTINUE IF NOT DONE
007002 046267 014450 004632      BIC     LINBIT(R2), LINACT    ;CLEAR ACTIVE BIT
007010 005767 004626 30:      TST     LINACT          ;IF ALL LINES ARE DONE
007014 001344              BNE     10                    ;EXIT
007016 012777 000006 004514      MOV     #6, @DHSCR          ;SELECT LINE 6
007024 042777 100000 004512      BIC     #100000, @DHLPR      ;CLEAR AUTO ECHO FOR LINE 6
007032 105777 004522      TSTB    @DHSLR          ;GET REST OF CHARACTERS
007036 001333              BNE     10                    ;AND CHECK
007040 000407              BR     50
007042 005200 40:      INC     R0                ;UPDATE ECHOED CHARACTER COUNT
007044 020467 005254      CMP     R4, TWRD6          ;CHECK ECHOED DATA
007050 001757              BEQ     30
007052 016705 005246      MOV     TWRD6, R5          ;(R5)-EXPECTED ECHOED DATA
007056              HLT     2                ;ECHOED DATA ERROR
007056 104002              EMT     2
007060 104400 50:      SCOPE
                                LINE=LINE+1
                                BITX=BITX+BITX
                                KX=KX+1
                                AUTO2  \LINE, \BITX, \KX
                                                                ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 7
                                                                ;TRANSMIT 1 CHARACTER ON LINE 7 WITH AUTO ECHO ENABLED
                                                                ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
                                                                ;CHARACTER LENGTH IS 8 BITS
                                                                ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES
007062 000007
                                000200
                                000007

```



```

007062      000031      TS \XN,10
007062      012767      000340      170706      T30:      MOV      @340,PS      ;DISABLE ALL INTERRUPTS
007070      012767      000010      004510      MOV      @10,ICOUNT      ;SET UP FOR 10 ITERATIONS
007076      012767      007316      004476      MOV      @5,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB      <>
      MOV      @,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
007104      012777      004000      004426      MOV      @BIT11,@DHSCR      ;MASTER CLEAR INTERFACE
007112      004767      004310      JSR      PC,SETALL      ;SET UP ALL LINES TO TRANSMIT
      ;400 (OCTAL) CHARACTERS
007116      012777      000007      004414      MOV      @7,@DHSCR      ;SELECT LINE 7 FOR TESTING
007124      012777      014326      004414      MOV      @TWRD7,@DHBA      ;CHARACTER TO BE TRANSMITTED
      ;ON LINE 7 IN AUTO ECHO MODE
007132      012777      177777      004410      MOV      @-1,@DHBC      ;TRANSMIT ONLY 1 CHARACTER ON LINE 7
007140      012777      133503      004376      MOV      @133503,@DHLPR      ;SET AUTO ECHO FOR LINE 7
007146      042767      000200      004466      BIC      @200,LINACT      ;CLEAR LINE ACTIVE BIT
007154      012777      177777      004370      MOV      @-1,@DHBA      ;SET BAR BITS FOR ALL LINES
007162      005000      CLR      R0      ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
007164      017704      004352      14:      MOV      @DHNR,R4      ;GET A CHARACTER FROM SILO
007170      100375      BPL      14      ;IF NOT VALID DATA, TRY AGAIN
007172      010403      MOV      R4,R3      ;EXTRACT LINE NUMBER FORM CHARACTER
007174      000303      SWAB      R3
007176      042703      177760      BIC      @177760,R3      ;CLEAR STATUS BITS
007202      010302      MOV      R3,R2
007204      006302      ASL      R2
007206      020327      000007      CMP      R3,@7      ;IF LINE NUMBER IS 7
007212      001432      BEQ      44      ;CHECK FOR CORRECT ECHOED CHARACTER
007214      026204      014246      CMP      RBUF(R2),R4      ;IF NOT LINE 7, CHECK DATA
007220      001404      BEQ      24      ;
007222      016205      014246      MOV      RBUF(R2),R5      ;(R5)=EXPECTED NON ECHOED DATA
007226      HLT      1      ;NON ECHOED DATA ERROR
007226      104001      EMT      1
007230      000423      BR      44
007232      105262      014246      24:      INCB      RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
007236      001352      BNE      14      ;CONTINUE IF NOT DONE
007240      046267      014450      004374      BIC      LINBIT(R2),LINACT      ;CLEAR ACTIVE BIT
007246      005767      004370      34:      TST      LINACT      ;IF ALL LINES ARE DONE
007252      001344      BNE      14      ;EXIT
007254      012777      000007      004256      MOV      @7,@DHSCR      ;SELECT LINE 7
007262      042777      100000      004254      BIC      @100000,@DHLPR      ;CLEAR AUTO ECHO FOR LINE 7
007270      105777      004264      TSTB      @DHSLR      ;GET REST OF CHARACTERS
007274      001333      BNE      14      ;AND CHECK
007276      000407      BR      54
007300      005200      44:      INC      R0      ;UPDATE ECHOED CHARACTER COUNT
007302      020467      005020      CMP      R4,TWRD7      ;CHECK ECHOED DATA
007306      001757      BEQ      34
007310      016705      005012      MOV      TWRD7,R5      ;(R5)=EXPECTED ECHOED DATA
007314      HLT      2      ;ECHOED DATA ERROR
007314      104002      EMT      2
007316      104400      54:      SCOPE      ;CHECK FOR ITERATIONS, LOOP
      LINE=LINE+1
      BITX=BITX+BITX
      KX=KX+1
007320      AUTO2      \LINE,\BITX,\KX
      ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 10

```

Address	Hex	Op	Op2	Op3	Op4	Op5	Op6	Op7	Op8	Op9	Op10	Op11	Op12	Op13	Op14	Op15	Op16	Op17	Op18	Op19	Op20	Op21	Op22	Op23	Op24	Op25	Op26	Op27	Op28	Op29	Op30	Op31	Op32	Op33	Op34	Op35	Op36	Op37	Op38	Op39	Op40	Op41	Op42	Op43	Op44	Op45	Op46	Op47	Op48	Op49	Op50	Op51	Op52	Op53	Op54	Op55	Op56	Op57	Op58	Op59	Op60	Op61	Op62	Op63	Op64	Op65	Op66	Op67	Op68	Op69	Op70	Op71	Op72	Op73	Op74	Op75	Op76	Op77	Op78	Op79	Op80	Op81	Op82	Op83	Op84	Op85	Op86	Op87	Op88	Op89	Op90	Op91	Op92	Op93	Op94	Op95	Op96	Op97	Op98	Op99	Op100	Op101	Op102	Op103	Op104	Op105	Op106	Op107	Op108	Op109	Op110	Op111	Op112	Op113	Op114	Op115	Op116	Op117	Op118	Op119	Op120	Op121	Op122	Op123	Op124	Op125	Op126	Op127	Op128	Op129	Op130	Op131	Op132	Op133	Op134	Op135	Op136	Op137	Op138	Op139	Op140	Op141	Op142	Op143	Op144	Op145	Op146	Op147	Op148	Op149	Op150	Op151	Op152	Op153	Op154	Op155	Op156	Op157	Op158	Op159	Op160	Op161	Op162	Op163	Op164	Op165	Op166	Op167	Op168	Op169	Op170	Op171	Op172	Op173	Op174	Op175	Op176	Op177	Op178	Op179	Op180	Op181	Op182	Op183	Op184	Op185	Op186	Op187	Op188	Op189	Op190	Op191	Op192	Op193	Op194	Op195	Op196	Op197	Op198	Op199	Op200	Op201	Op202	Op203	Op204	Op205	Op206	Op207	Op208	Op209	Op210	Op211	Op212	Op213	Op214	Op215	Op216	Op217	Op218	Op219	Op220	Op221	Op222	Op223	Op224	Op225	Op226	Op227	Op228	Op229	Op230	Op231	Op232	Op233	Op234	Op235	Op236	Op237	Op238	Op239	Op240	Op241	Op242	Op243	Op244	Op245	Op246	Op247	Op248	Op249	Op250	Op251	Op252	Op253	Op254	Op255	Op256	Op257	Op258	Op259	Op260	Op261	Op262	Op263	Op264	Op265	Op266	Op267	Op268	Op269	Op270	Op271	Op272	Op273	Op274	Op275	Op276	Op277	Op278	Op279	Op280	Op281	Op282	Op283	Op284	Op285	Op286	Op287	Op288	Op289	Op290	Op291	Op292	Op293	Op294	Op295	Op296	Op297	Op298	Op299	Op300	Op301	Op302	Op303	Op304	Op305	Op306	Op307	Op308	Op309	Op310	Op311	Op312	Op313	Op314	Op315	Op316	Op317	Op318	Op319	Op320	Op321	Op322	Op323	Op324	Op325	Op326	Op327	Op328	Op329	Op330	Op331	Op332	Op333	Op334	Op335	Op336	Op337	Op338	Op339	Op340	Op341	Op342	Op343	Op344	Op345	Op346	Op347	Op348	Op349	Op350	Op351	Op352	Op353	Op354	Op355	Op356	Op357	Op358	Op359	Op360	Op361	Op362	Op363	Op364	Op365	Op366	Op367	Op368	Op369	Op370	Op371	Op372	Op373	Op374	Op375	Op376	Op377	Op378	Op379	Op380	Op381	Op382	Op383	Op384	Op385	Op386	Op387	Op388	Op389	Op390	Op391	Op392	Op393	Op394	Op395	Op396	Op397	Op398	Op399	Op400	Op401	Op402	Op403	Op404	Op405	Op406	Op407	Op408	Op409	Op410	Op411	Op412	Op413	Op414	Op415	Op416	Op417	Op418
---------	-----	----	-----	-----	-----	-----	-----	-----	-----	-----	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------


```

001000      BITX=BITX+BITX
000011      KX=KX+1
007556      AUTO2  \LINE,\BITX,\KX

;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 11
;TRANSMIT 1 CHARACTER ON LINE 11 WITH AUTO ECHO ENABLED
;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
;CHARACTER LENGTH IS 8 BITS
;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

007556      TS \XN,10,54
007556      T32:  MOV  #340,PS          ;DISABLE ALL INTERRUPTS
007564      012767 000340 170212      MOV  #10,ICOUNT      ;SET UP FOR 10 ITERATIONS
007572      012767 010012 004002      MOV  #54,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
;IF NB      <>
;MOV        #,FREEZ1          ;SET UP TO LOOP WITH DATA          ; 3
.ENDC
XN=XN+1
007600      000033      012777 004000 003732      MOV  #BIT11,0DHSCR      ;MASTER CLEAR INTERFACE
007606      004767 003614      JSR  PC.SETALL      ;SET UP ALL LINES TO TRANSMIT
;400 (OCTAL) CHARACTERS
;SELECT LINE 11 FOR TESTING
007612      012777 000011 003720      MOV  #11,0DHSCR
007620      012777 014332 003720      MOV  #THRD11,0DHBA      ;CHARACTER TO BE TRANSMITTED
;ON LINE 11 IN AUTO ECHO MODE
;TRANSMIT ONLY 1 CHARACTER ON LINE 11
;SET AUTO ECHO FOR LINE 11
007626      012777 177777 003714      MOV  #-1,0DHBC
007634      012777 133503 003702      MOV  #133503,0DHLPB      ;CLEAR LINE ACTIVE BIT
007642      042767 001000 003772      BIC  #1000,LINACT
007650      012777 177777 003674      MOV  #-1,0DHBA      ;SET BAR BITS FOR ALL LINES
007656      005000      CLR  R0          ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
007660      017704 003656      14:  MOV  0DHNR,R4      ;GET A CHARACTER FROM SILO
007664      100375      BPL  14          ;IF NOT VALID DATA, TRY AGAIN
007666      010403      MOV  R4,R3      ;EXTRACT LINE NUMBER FORM CHARACTER
007670      000303      SWAB R3
007672      042703 177760      BIC  #177760,R3      ;CLEAR STATUS BITS
007676      010302      MOV  R3,R2
007700      006302      ASL  R2
007702      020327 000011      CMP  R3,#11      ;IF LINE NUMBER IS 11
007706      001432      BEQ  44          ;CHECK FOR CORRECT ECHOED CHARACTER
007710      026204 014246      CMP  RBUF(R2),R4      ;IF NOT LINE 11, CHECK DATA
007714      001404      BEQ  24
007716      016205 014246      MOV  RBUF(R2),R5      ;(R5)=EXPECTED NON ECHOED DATA
007722      HLT  1          ;NON ECHOED DATA ERROR
007722      104001      EMT  1
007724      000423      BR  44
007726      105262 014246      24:  INCB RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
007732      001352      BNE  14          ;CONTINUE IF NOT DONE
007734      046267 014450 003700      BIC  LINBIT(R2),LINACT      ;CLEAR ACTIVE BIT
007742      005767 003674      34:  TST  LINACT      ;IF ALL LINES ARE DONE
007746      001344      BNE  14          ;EXIT
007750      012777 000011 003562      MOV  #11,0DHSCR      ;SELECT LINE 11
007756      042777 100000 003560      BIC  #100000,0DHLPB      ;CLEAR AUTO ECHO FOR LINE 11
007764      105777 003570      TSTB 0DHSLR      ;GET REST OF CHARACTERS
007770      001333      BNE  14          ;AND CHECK
007772      000407      BR  54
007774      005200      44:  INC  R0          ;UPDATE ECHOED CHARACTER COUNT
007776      020467 004330      CMP  R4,THRD11      ;CHECK ECHOED DATA
010002      001757      BEQ  34

```

```

010004 016705 004322      MOV      TWRD11,R5      ;(R5)=EXPECTED ECHOED DATA
010010                      HLT      2              ;ECHOED DATA ERROR
010010 104002              EMT      2
010012 104400              5$: SCOPE              ;CHECK FOR ITERATIONS, LOOP
                      LINE=LINE+1
                      BITX=BITX+BITX
                      KX=KX+1
010014 AUT02  \LINE,\BITX,\KX

;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 12
;TRANSMIT 1 CHARACTER ON LINE 12 WITH AUTO ECHO ENABLED
;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
;CHARACTER LENGTH IS 8 BITS
;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

010014 012767 000340 167754 TS \XN,10,5$
010022 012767 000010 003556 T33: MOV      #340,PS      ;DISABLE ALL INTERRUPTS
010030 012767 010250 003544      MOV      #10,ICOUNT    ;SET UP FOR 10 ITERATIONS
                      MOV      #5$,ESCAPE    ;SET UP TO ESCAPE TO NEXT TEST
                      .IF NB <>
                      MOV      #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
                      .ENDC
                      XN=XN+1
010036 012777 004000 003474      MOV      #BIT11,0DHSCR    ;MASTER CLEAR INTERFACE
010044 004767 003356          JSR      PC,SETALL    ;SET UP ALL LINES TO TRANSMIT
                      ;400 (OCTAL) CHARACTERS
010050 012777 000012 003462      MOV      #12,0DHSCR    ;SELECT LINE 12 FOR TESTING
010056 012777 014334 003462      MOV      #TWRD12,0DHBA  ;CHARACTER TO BE TRANSMITTED
                      ;ON LINE 12 IN AUTO ECHO MODE
010064 012777 177777 003456      MOV      #-1,0DHBC     ;TRANSMIT ONLY 1 CHARACTER ON LINE 12
010072 012777 133503 003444      MOV      #133503,0DHLPR  ;SET AUTO ECHO FOR LINE 12
010100 042767 002000 003534      BIC      #2000,LINACT  ;CLEAR LINE ACTIVE BIT
010106 012777 177777 003436      MOV      #-1,0DHBAR    ;SET BAR BITS FOR ALL LINES
010114 005000          CLR      R0              ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
010116 017704 003420      1$: MOV      #0DHNR, R4      ;GET A CHARACTER FROM SILO
010122 100375          BPL      1$              ;IF NOT VALID DATA, TRY AGAIN
010124 010403          MOV      R4,R3          ;EXTRACT LINE NUMBER FORM CHARACTER
010126 000303          SWAB      R3
010130 042703 177760      BIC      #177760,R3      ;CLEAR STATUS BITS
010134 010302          MOV      R3,R2
010136 006302          ASL      R2
010140 020327 000012      CMP      R3,#12          ;IF LINE NUMBER IS 12
010144 001432          BEQ      4$              ;CHECK FOR CORRECT ECHOED CHARACTER
010146 026204 014246      CMP      RBUF(R2),R4      ;IF NOT LINE 12, CHECK DATA
010152 001404          BEQ      2$              ;(R5)=EXPECTED NON ECHOED DATA
010154 016205 014246      MOV      RBUF(R2),R5      ;NON ECHOED DATA ERROR
010160          HLT      1
010160 104001          EMT      1
010162 000423          BR      4$
010164 105262 014246      2$: INCB      RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
010170 001352          BNE      1$              ;CONTINUE IF NOT DONE
010172 046267 014450 003442      BIC      LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
010200 005767 003436      3$: TST      LINACT      ;IF ALL LINES ARE DONE
010204 001344          BNE      1$              ;EXIT
010206 012777 000012 003324      MOV      #12,0DHSCR    ;SELECT LINE 12
010214 042777 100000 003322      BIC      #100000,0DHLPR  ;CLEAR AUTO ECHO FOR LINE 12
010222 105777 003332      TSTB      0DHSLR        ;GET REST OF CHARACTERS

```



```

010226 001333      BNE      1$      ;AND CHECK
010230 000407      BR       5$
010232 005200      4$: INC      R0      ;UPDATE ECHOED CHARACTER COUNT
010234 020467 004074 CMP      R4,TWRD12 ;CHECK ECHOED DATA
010240 001757      BEQ      3$
010242 016705 004066 MOV      TWRD12,R5      ;(R5)=EXPECTED ECHOED DATA
010246      HLT      2          ;ECHOED DATA ERROR
010246 104002      EMT      2
010250 104400      5$: SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000013      LINE=LINE+1
      004000      BITX=BITX+BITX
      000013      KX=KX+1
010252      AUTC2  \LINE,\BITX,\KX

      ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 13
      ;TRANSMIT 1 CHARACTER ON LINE 13 WITH AUTO ECHO ENABLED
      ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
      ;CHARACTER LENGTH IS 8 BITS
      ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

010252      TS \XN,10,5$
010252 012767 000340 167516 T34: MOV      #340,PS      ;DISABLE ALL INTERRUPTS
010260 012767 000010 003320      MOV      #10,ICOUNT ;SET UP FOR 10 ITERATIONS
010266 012767 010506 003306      MOV      #5$,ESCAPE ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB      <>
      MOV      #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
010274 012777 004000 003236      MOV      #BIT11,SDHSCR ;MASTER CLEAR INTERFACE
010302 004767 003120      JSR      PC,SETALL ;SET UP ALL LINES TO TRANSMIT
      ;400 (OCTAL) CHARACTERS
010306 012777 000013 003224      MOV      #13,SDHSCR ;SELECT LINE 13 FOR TESTING
010314 012777 014336 003224      MOV      #TWRD13,SDHBA ;CHARACTER TO BE TRANSMITTED
      ;ON LINE 13 IN AUTO ECHO MODE
010322 012777 177777 003220      MOV      #-1,SDHSC ;TRANSMIT ONLY 1 CHARACTER ON LINE 13
010330 012777 133503 003206      MOV      #133503,SDHLPR ;SET AUTO ECHO FOR LINE 13
010336 042767 004000 003276      BIC      #4000,LINACT ;CLEAR LINE ACTIVE BIT
010344 012777 177777 003200      MOV      #-1,SDHBA ;SET BAR BITS FOR ALL LINES
010352 005000      CLR      R0 ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
010354 017704 003162      1$: MOV      SDHNR, R4 ;GET A CHARACTER FROM SILO
010360 100375      BPL      1$ ;IF NOT VALID DATA, TRY AGAIN
010362 010403      MOV      R4,R3 ;EXTRACT LINE NUMBER FORM CHARACTER
010364 000303      SWAB     R3
010366 042703 177760      BIC      #177760,R3 ;CLEAR STATUS BITS
010372 010302      MOV      R3,R2
010374 006302      ASL      R2
010376 020327 000013      CMP      R3,#13 ;IF LINE NUMBER IS 13
010402 001432      BEQ      4$ ;CHECK FOR CORRECT ECHOED CHARACTER
010404 026204 014246      CMP      RBUF(R2),R4 ;IF NOT LINE 13, CHECK DATA
010410 001404      BEQ      2$
010412 016205 014246      MOV      RBUF(R2),R5 ;(R5)=EXPECTED NON ECHOED DATA
010416      HLT      1          ;NON ECHOED DATA ERROR
010416 104001      EMT      1
010420 000423      BR       4$
010422 105262 014246      2$: INCB     RBUF(R2) ;UPDATE EXPECTED RECEIVED DATA
010426 001352      BNE      1$ ;CONTINUE IF NOT DONE
010430 046267 014450 003204      BIC      LINBIT(R2),LINACT ;CLEAR ACTIVE BIT

```

```

010436 005767 003200      3$:  TST  LINACT      ;IF ALL LINES ARE DONE
010442 001344              BNE  1$          ;EXIT
010444 012777 000013 003066  MOV  #13,8DHSCR      ;SELECT LINE 13
010452 042777 100000 003064  BIC  #100000,8DHLPR    ;CLEAR AUTO ECHO FOR LINE 13
010460 105777 003074      TSTB 8DHSLR      ;GET REST OF CHARACTERS
010464 001333              BNE  1$          ;AND CHECK
010466 000407              BR   5$
010470 005200      4$:  INC  R0          ;UPDATE ECHOED CHARACTER COUNT
010472 020467 003640      CMP  R4,TWRD13    ;CHECK ECHOED DATA
010476 001757              BEQ  3$
010500 016705 003632      MOV  TWRD13,R5      ;(R5)=EXPECTED ECHOED DATA
010504              HLT  2          ;ECHOED DATA ERROR
010504 104002              EMT  2
010506 104400      5$:  SCOPE              ;CHECK FOR ITERATIONS, LOOP
      000014      LINE=LINE+1
      010000      BITX=BITX+BITX
      000014      KX=KX+1
010510      AUTO2  \LINE,\BITX,\KX

      ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 14
      ;TRANSMIT 1 CHARACTER ON LINE 14 WITH AUTO ECHO ENABLED
      ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
      ;CHARACTER LENGTH IS 8 BITS
      ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

010510      TS  \XN,10,5$
010510 012767 000340 167260  T35:  MOV  #340,PS      ;DISABLE ALL INTERRUPTS
010516 012767 000010 003062      MOV  #10,ICOUNT    ;SET UP FOR 10 ITERATIONS
010524 012767 010744 003050      MOV  #5$,ESCAPE    ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB  <>
      MOV  #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
010532 012777 004000 003000      MOV  #BIT11,8DHSCR    ;MASTER CLEAR INTERFACE
010540 004767 002662      JSR  PC,SETALL      ;SET UP ALL LINES TO TRANSMIT
      ;400 (OCTAL) CHARACTERS
      ;SELECT LINE 14 FOR TESTING
010544 012777 000014 002766      MOV  #14,8DHSCR      ;CHARACTER TO BE TRANSMITTED
010552 012777 014340 002766      MOV  #TWRD14,8DHBA    ;ON LINE 14 IN AUTO ECHO MODE
      ;TRANSMIT ONLY 1 CHARACTER ON LINE 14
      ;SET AUTO ECHO FOR LINE 14
010560 012777 177777 002762      MOV  #-1,8DHBC      ;CLEAR LINE ACTIVE BIT
010566 012777 133503 002750      MOV  #133503,8DHLPR    ;SET BAR BITS FOR ALL LINES
010574 042767 010000 003040      BIC  #10000,LINACT    ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
010602 012777 177777 002742      MOV  #-1,8DHBA      ;GET A CHARACTER FROM SILO
010610 005000              CLR  R0          ;IF NOT VALID DATA, TRY AGAIN
010612 017704 002724      1$:  MOV  8DHNRC,R4      ;EXTRACT LINE NUMBER FORM CHARACTER
010616 100375              BPL  1$
010620 010403              MOV  R4,R3
010622 000303              SWAB R3
010624 042703 177760      BIC  #177760,R3      ;CLEAR STATUS BITS
010630 010302              MOV  R3,R2
010632 006302              ASL  R2
010634 020327 000014      CMP  R3,#14      ;IF LINE NUMBER IS 14
010640 001432              BEQ  4$          ;CHECK FOR CORRECT ECHOED CHARACTER
010642 026204 014246      CMP  RBUF(R2),R4      ;IF NOT LINE 14, CHECK DATA
010646 001404              BEQ  2$
010650 016205 014246      MOV  RBUF(R2),R5      ;(R5)=EXPECTED NON ECHOED DATA
010654              HLT  1          ;NON ECHOED DATA ERROR

```



```

010654 104001          EMT      1
010656 000423          BR       4$
010660 105262 014246   2$:     INCB  RBUF(R2)          ;UPDATE EXPECTED RECEIVED DATA
010664 001352          BNE      1$          ;CONTINUE IF NOT DONE
010666 046267 014450 002746   3$:     BIC  LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
010674 005767 002742          TST  LINACT          ;IF ALL LINES ARE DONE
010700 001344          BNE      1$          ;EXIT
010702 012777 000014 002630   MOV  #14,SDHSCR          ;SELECT LINE 14
010710 042777 100000 002626   BIC  #100000,SDHLPR        ;CLEAR AUTO ECHO FOR LINE 14
010716 105777 002636          TSTB SDHSLR          ;GET REST OF CHARACTERS
010722 001333          BNE      1$          ;AND CHECK
010724 000407          BR       5$
010726 005200          4$:     INC  R0
010730 020467 003404          CMP  R4,TWRD14          ;UPDATE ECHOED CHARACTER COUNT
010734 001757          BEQ  3$          ;CHECK ECHOED DATA
010736 016705 003376          MOV  TWRD14,R5          ;(R5)=EXPECTED ECHOED DATA
010742          HLT  2          ;ECHOED DATA ERROR
010742 104002          EMT      2
010744 104400          5$:     SCOPE
                                LINE=LINE+1
                                BITX=BITX+BITX
                                KX=KX+1
                                AUTO2 \LINE,\BITX,\KX
                                ;CHECK FOR ITERATIONS. LOOP
                                ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 15
                                ;TRANSMIT 1 CHARACTER ON LINE 15 WITH AUTO ECHO ENABLED
                                ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
                                ;CHARACTER LENGTH IS 8 BITS
                                ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

010746          TS \XN,10,5$
010746 012767 000340 167022   T36:  MOV  #340,PS          ;DISABLE ALL INTERRUPTS
010754 012767 000010 002624   MOV  #10,ICOUNT          ;SET UP FOR 10 ITERATIONS
010762 012767 011202 002612   MOV  #5$,ESCAPE          ;SET UP TO ESCAPE TO NEXT TEST
                                .IF NB <>
                                MOV  #,FREEZ1          ;SET UP TO LOOP WITH DATA ; 3
                                .ENDC
                                XN=XN+1
010770 000037          MOV  #BIT11,SDHSCR          ;MASTER CLEAR INTERFACE
010776 004767 002424          JSR  PC,SETALL          ;SET UP ALL LINES TO TRANSMIT
                                                ;400 (OCTAL) CHARACTERS
011002 012777 000015 002530   MOV  #15,SDHSCR          ;SELECT LINE 15 FOR TESTING
011010 012777 014342 002530   MOV  #TWRD15,SDHBA ;CHARACTER TO BE TRANSMITTED
                                                ;ON LINE 15 IN AUTO ECHO MODE
011016 012777 177777 002524   MOV  #-1,SDHBC          ;TRANSMIT ONLY 1 CHARACTER ON LINE 15
011024 012777 133503 002512   MOV  #133503,SDHLPR        ;SET AUTO ECHO FOR LINE 15
011032 042767 020000 002602   BIC  #20000,LINACT ;CLEAR LINE ACTIVE BIT
011040 012777 177777 002504   MOV  #-1,SDHBAR          ;SET BAR BITS FOR ALL LINES
011046 005000          CLR  R0          ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
011050 017704 002466          1$:  MOV  SDHNR, R4          ;GET A CHARACTER FROM SILO
011054 100375          BPL  1$          ;IF NOT VALID DATA, TRY AGAIN
011056 010403          MOV  R4,R3          ;EXTRACT LINE NUMBER FORM CHARACTER
011060 000303          SWAB R3
011062 042703 177760          BIC  #177760,R3          ;CLEAR STATUS BITS
011066 010302          MOV  R3,R2
011070 006302          ASL  R2
011072 020327 000015          CMP  R3,#15          ;IF LINE NUMBER IS 15

```

011076	001432			BEQ	4\$		;CHECK FOR CORRECT ECHOED CHARACTER
011100	026204	014246		CMP	RBUF(R2),R4		;IF NOT LINE 15, CHECK DATA
011104	001404			BEQ	2\$		
011106	016205	014246		MOV	RBUF(R2),R5		;(R5)=EXPECTED NON ECHOED DATA
011112				HLT	1		;NON ECHOED DATA ERROR
011112	104001			EMT	1		
011114	000423			BR	4\$		
011116	105262	014246	2\$:	INCB	RBUF(R2)		;UPDATE EXPECTED RECEIVED DATA
011122	001352			BNE	1\$		;CONTINUE IF NOT DONE
011124	046267	014450	002510	BIC	LINBIT(R2),LINACT		;CLEAR ACTIVE BIT
011132	005767	002504	3\$:	TST	LINACT		;IF ALL LINES ARE DONE
011136	001344			BNE	1\$		;EXIT
011140	012777	000015	002372	MOV	#15,@DHSCR		;SELECT LINE 15
011146	042777	100000	002370	BIC	#100000,@DHLPR		;CLEAR AUTO ECHO FOR LINE 15
011154	105777	002400		TSTB	@DHSLR		;GET REST OF CHARACTERS
011160	001333			BNE	1\$		;AND CHECK
011162	000407			BR	5\$		
011164	005200		4\$:	INC	R0		;UPDATE ECHOED CHARACTER COUNT
011166	020467	003150		CMP	R4,TWRD15		;CHECK ECHOED DATA
011172	001757			BEQ	3\$		
011174	016705	003142		MOV	TWRD15,R5		;(R5)=EXPECTED ECHOED DATA
011200				HLT	2		;ECHOED DATA ERROR
011200	104002			EMT	2		
011202	104400		5\$:	SCOPE			;CHECK FOR ITERATIONS, LOOP
	000016			LINE=LINE+1			
	040000			BITX=BITX+BITX			
	000016			KX=KX+1			
011204			AUT02	\LINE,\BITX,\KX			
							;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 16
							;TRANSMIT 1 CHARACTER ON LINE 16 WITH AUTO ECHO ENABLED
							;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
							;CHARACTER LENGTH IS 8 BITS
							;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES
011204			TS \XN,10,5\$				
011204	012767	000340	166564	T37:	MOV	#340,PS	;DISABLE ALL INTERRUPTS
011212	012767	000010	002366		MOV	#10,ICOUNT	;SET UP FOR 10 ITERATIONS
011220	012767	011440	002354		MOV	#5\$,ESCAPE	;SET UP TO ESCAPE TO NEXT TEST
				.IF NB	<>		
					MOV	#,FREEZ1	;SET UP TO LOOP WITH DATA ; 3
				.ENDC			
	000040			XN=XN+1			
011226	012777	004000	002304		MOV	@BIT11,@DHSCR	;MASTER CLEAR INTERFACE
011234	004767	002166			JSR	PC,SETALL	;SET UP ALL LINES TO TRANSMIT
							;400 (OCTAL) CHARACTERS
011240	012777	000016	002272		MOV	#16,@DHSCR	;SELECT LINE 16 FOR TESTING
011246	012777	014344	002272		MOV	@TWRD16,@DHBA	;CHARACTER TO BE TRANSMITTED
							;ON LINE 16 IN AUTO ECHO MODE
011254	012777	177777	002266		MOV	#-1,@DHBC	;TRANSMIT ONLY 1 CHARACTER ON LINE 16
011262	012777	133503	002254		MOV	#133503,@DHLPR	;SET AUTO ECHO FOR LINE 16
011270	042767	040000	002344		BIC	#40000,LINACT	;CLEAR LINE ACTIVE BIT
011276	012777	177777	002246		MOV	#-1,@DHBAR	;SET BAR BITS FOR ALL LINES
011304	005000				CLR	R0	;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
011306	017704	002230	1\$:		MOV	@DHNRRC,R4	;GET A CHARACTER FROM SILO
011312	100375				BPL	1\$	;IF NOT VALID DATA, TRY AGAIN
011314	010403				MOV	R4,R3	;EXTRACT LINE NUMBER FORM CHARACTER


```

011316 000303 SWAB R3
011320 042703 177760 BIC #177760,R3 ;CLEAR STATUS BITS
011324 010302 MOV R3,R2
011326 006302 ASL R2
011330 020327 000016 CMP R3,#16 ;IF LINE NUMBER IS 16
011334 001432 BEQ 4$ ;CHECK FOR CORRECT ECHOED CHARACTER
011336 026204 014246 CMP RBUF(R2),R4 ;IF NOT LINE 16, CHECK DATA
011342 001404 BEQ 2$
011344 016205 014246 MOV RBUF(R2),R5 ;(R5)=EXPECTED NON ECHOED DATA
011350 HLT 1 ;NON ECHOED DATA ERROR
011350 104001 EMT 1
011352 000423 BR 4$
011354 105262 014246 2$: INCB RBUF(R2) ;UPDATE EXPECTED RECEIVED DATA
011360 001352 BNE 1$ ;CONTINUE IF NOT DONE
011362 046267 014450 002252 BIC LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
011370 005767 002246 3$: TST LINACT ;IF ALL LINES ARE DONE
011374 001344 BNE 1$ ;EXIT
011376 012777 000016 002134 MOV #16,@DHSCR ;SELECT LINE 16
011404 042777 100000 002132 BIC #100000,@DHLPR ;CLEAR AUTO ECHO FOR LINE 16
011412 105777 002142 TSTB @DHSLR ;GET REST OF CHARACTERS
011416 001333 BNE 1$ ;AND CHECK
011420 000407 BR 5$
011422 005200 4$: INC R0 ;UPDATE ECHOED CHARACTER COUNT
011424 020467 002714 CMP R4,TWRD16 ;CHECK ECHOED DATA
011430 001757 BEQ 3$
011432 016705 002706 MOV TWRD16,R5 ;(R5)=EXPECTED ECHOED DATA
011436 HLT 2 ;ECHOED DATA ERROR
011436 104002 EMT 2
011440 104400 5$: SCOPE ;CHECK FOR ITERATIONS, LOOP
000017 LINE=LINE+1
100000 BITX=BITX+BITX
000017 KX=KX+1
011442 AUTO2 \LINE,\BITX,\KX

;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 17
;TRANSMIT 1 CHARACTER ON LINE 17 WITH AUTO ECHO ENABLED
;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
;CHARACTER LENGTH IS 8 BITS
;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

011442 TS \XN,10,5$
011442 012767 000340 166326 T40: MOV #340,PS ;DISABLE ALL INTERRUPTS
011450 012767 000010 002130 MOV #10,ICOUNT ;SET UP FOR 10 ITERATIONS
011456 012767 011676 002116 MOV #5$,ESCAPE ;SET UP TO ESCAPE TO NEXT TEST
;IF NB <>
MOV #,FREEZ1 ;SET UP TO LOOP WITH DATA ; 3
.ENDC
XN=XN+1
011464 000041 004000 002046 MOV #BIT11,@DHSCR ;MASTER CLEAR INTERFACE
011472 004767 001730 JSR PC,SETALL ;SET UP ALL LINES TO TRANSMIT
;400 (OCTAL) CHARACTERS
011476 012777 000017 002034 MOV #17,@DHSCR ;SELECT LINE 17 FOR TESTING
011504 012777 014346 002034 MOV #TWRD17,@DHBA ;CHARACTER TO BE TRANSMITTED
;ON LINE 17 IN AUTO ECHO MODE
011512 012777 177777 002030 MOV #-1,@DHBC ;TRANSMIT ONLY 1 CHARACTER ON LINE 17
011520 012777 133503 002016 MOV #133503,@DHLPR ;SET AUTO ECHO FOR LINE 17
011526 042767 100000 002106 BIC #100000,LINACT ;CLEAR LINE ACTIVE BIT

```

Address	Hex	Dec	Label	Instruction	Comment
011534	012777	177777	002010	MOV	#-1, @DHBAR
011542	005000			CLR	R0
011544	017704	001772	1#:	MOV	@DHNR, R4
011550	100375			BPL	1#
011552	010403			MOV	R4, R3
011554	000303			SWAB	R3
011556	042703	177760		BIC	#177760, R3
011562	010302			MOV	R3, R2
011564	006302			ASL	R2
011566	020327	000017		CMP	R3, #17
011572	001432			BEQ	4#
011574	026204	014246		CMP	RBUF(R2), R4
011600	001404			BEQ	2#
011602	016205	014246		MOV	RBUF(R2), R5
011606				HLT	1
011606	104001			EMT	1
011610	000423			BR	4#
011612	105262	014246	2#:	INCB	RBUF(R2)
011616	001352			BNE	1#
011620	046267	014450	002014	BIC	LINBIT(R2), LINACT
011626	005767	002010	3#:	TST	LINACT
011632	001344			BNE	1#
011634	012777	000017	001676	MOV	#17, @DHSCR
011642	042777	100000	001674	MOV	#100000, @DHLPR
011650	105777	001704		STB	@DHSLR
011654	001333			BNE	1#
011656	000407			BR	5#
011660	005200		4#:	INC	R0
011662	020467	002460		CMP	R4, TWRD17
011666	001757			BEQ	3#
011670	016705	002452		MOV	TWRD17, R5
011674				HLT	2
011674	104002			EMT	2
011676	104400		5#:	SCOPE	
	000020			LINE=LINE+1	
	000000			BITX=BITX+BITX	
	000020			KX=KX+1	


```

1
2
3
4
5 011700 TS \XN,100,5#
011700 012767 000340 166070 T41: MOV #340,PS ;DISABLE ALL INTERRUPTS
011706 012767 000100 001672 MOV #100,ICOUNT ;SET UP FOR 100 ITERATIONS
011714 012767 012130 001660 MOV #5#,ESCAPE ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB <>
      MOV #,FREEZ1 ;SET UP TO LOOP WITH DATA ; 3
      .ENDC
      XN=XN+1
6 011722 000042 004000 001610 MOV #BIT11,0DHSCR ;MASTER CLEAR INTERFACE
7 011730 012700 000020 001610 MOV #20,R0 ;SET UP PARAMETERS FOR 16 LINES
8 011734 012701 014310 001610 MOV #TWRD0,R1 ;CHARACTER TO BE TRANSMITTED
9 011740 012702 014350 001610 MOV #RCNT0,R2 ;RECEIVED CHARACTER COUNT
10 011744 012703 014410 001610 MOV #RDCT0,R3 ;EXPECTED NUMBER OF CHARACTERS
11 011750 010177 001572 001566 1# : MOV R1,0DHBA ;LOAD BUS ADDRESS
12 011754 012777 177777 001566 1# : MOV #1,0DHBC ;LOAD BYTE COUNT
13 011762 012777 131403 001554 1# : MOV #131403,0DHLPR ;SET AUTO ECHO
14 011770 005022 000100 001554 1# : CLR (R2)+ ;CLEAR RECEIVED CHARACTER COUNT
15 011772 012723 000100 001554 1# : MOV #100,(R3)+ ;NUMBER OF CHARACTERS TO BE RECEIVED
16 011776 062701 000002 001554 1# : ADD #2,R1 ;ADVANCE POINTER
17 012002 005300 000002 001554 1# : DEC R0 ;CONTINUE IF NOT DONE
18 012004 001361 000002 001554 1# : BNE 1#
19 012006 012767 177777 001630 1# : MOV #1,AEACT ;INDICATE AUTO ECHO ACTIVE
20 012014 012777 177777 001530 2# : MOV #1,0DHBAR ;FOR ALL LINES
21 012022 105777 001512 001530 2# : TSTB 0DHSCR ;SET BAR BITS FOR ALL LINES
22 012026 100375 001512 001530 2# : BPL 2# ;WAIT FOR A CHARACTER
23 012030 017704 001506 001530 2# : MOV 0DHNR0,R4 ;GET CHARACTER
24 012034 010403 001506 001530 2# : MOV R4,R3
25 012036 000303 001506 001530 2# : SWAB R3
26 012040 042703 177760 001530 2# : BIC #177760,R3 ;EXTRACT LINE NUMBER
27 012044 010302 001530 001530 2# : MOV R3,R2
28 012046 006302 001530 001530 2# : ASL R2
29 012050 005262 014350 001530 2# : INC RCNT0(R2) ;UPDATE RECEIVED COUNT FOR LINE
30 012054 020462 014310 001530 2# : CMP R4,TWRD0(R2) ;CHECK EXPECTED AND RECEIVED DATA
31 012060 001404 014310 001530 2# : BEQ 3#
32 012062 016205 014310 001530 2# : MOV TWRD0(R2),R5 ;(R5)=EXPECTED ECHOED DATA
33 012066 012066 104002 001530 2# : HLT 2 ;AUTO ECHO ERROR
34 012070 000417 014410 001530 3# : BR 5#
35 012072 005362 014410 001530 3# : DEC RDCT0(R2) ;UPDATE RECEIVED EXPECTED COUNT
36 012076 003351 014410 001530 3# : BGT 2# ;CONTINUE IF NOT 0
37 012100 100413 001432 001530 3# : BMI 5# ;EXIT IOF NEGATIVE
38 012102 010377 001432 001530 3# : MOV R3,0DHSCR ;SELECT LINE THAT FINISHED
39 012106 042777 100000 001430 3# : BIC #100000,0DHLPR ;CLEAR AUTO ECHO
40 012114 046267 014450 001522 3# : BIC LINBIT(R2),AEACT ;CLEAR AUTO ECHO ACTIVE
41 012122 005767 001516 001522 3# : TST AEACT ;ALL LINES DONE
42 012126 001335 001516 001522 3# : BNE 2# ;IF NOT, CONTINUE
43 012130 104400 001516 001522 3# : SCOPE ;CHECK FOR ITERATIONS. LOOP
44

```

1
2 012132

.EOP +/BEGIN/

;END OF PASS
;TYPE NAME OF TEST
;UPDATE PASS COUNT
;CHECK FOR EXIT TO ACT-11
;RESTART TEST

012132 104401
012134 015064
012136 005067 001474
012142 005067 001424
012146 005267 001422
012152 005767 166624
012156 001005
012160 104401
012162 015077
012164 104402
012166 012224
012170 000403
012172
012172 016767 001376 166602
012200
012200 013701 000042
012204 001405
012206 000005
012210 004711
012212 000240
012214 000240
012216 000240
012220 000167 167062
012224 000001
012226 006 002
012230 013574
3 012232

EOP:

TYPE
MEPASS
CLR LAST
CLR ERRFLG
INC PASCNT
TST LIGHTS
BNE 2+
TYPE
PASTXT
OCTASC
PASARG
BR 3+
2+: MOV PASCNT,LIGHTS
3+: MOV @42,R1
BEQ RESTR
RESET
LOGICAL: JSR PC,(R1)
NOP
NOP
NOP
RESTR: JMP BEGIN
PASARG: .WORD 1
.BYTE 6,2
.WORD PASCNT
.SCOPE

;TYPE NAME OF TEST

;CLEAR LAST ERROR PC
;CLEAR ERROR FLAG
;UPDATE PASS COUNT
; ARE WE USING LIGHTS?
; BRANCH IF WE ARE
; TYPE PASCOUNT MESSAGE

: 4

: 6

: 5

: 5

: 4

: 4 : 6

; PRINT PASSCOUNT

; CONTINUE

: 4

: 4

;DISPLAY PASS COUNT

: 4

;CHECK FOR ACT-11 OR DDP
;IF NOT, CONTINUE TESTING

: 4

; PARAMETERS TO PRINT PASSCOUNT

: 5

: 5

: 5

;CHECK FOR LOOP ON CURRENT TEST
;CHECK FOR ITERATION SUPPRESSION

: 3

012232 032777 002000 166540 SCOPER: BIT @SW10,BSMR
012240 001030 BNE 4+
012242 032777 040000 166530 1+: BIT @SW14,BSMR
012250 001021 BNE 3+
012252 032777 004000 166520 BIT @SW11,BSMR
012260 001006 BNE 2+
012262 005267 001322 INC LPCNT
012266 026767 001316 001312 CMP LPCNT,ICOUNT
012274 001007 BNE 3+
012276 005067 001306 2+: CLR LPCNT
012302 005067 001264 CLR ERRFLG
012306 011667 001266 MOV (SP),RETRN
012312 000002 RTI
012314 016716 001260 3+: MOV RETRN,(SP)
012320 000002 RTI
012322 005767 001244 4+: TST ERRFLG
012326 001745 BEQ 1+

012330 000762
4 012332

BR 24
.SCOP1

;CHECK FOR FREEZE ON CURRENT DATA

012332 032777 001000 166440 SCOP1R: BIT 0SW09,BSMR
012340 001402 BEQ 14
012342 016716 001236 MOV FREEZ1,(SP)
012346 000002 14: RTI

; 4

1 012350

.ERROR

;ERROR HANDLER

```

012350 032777 020000 166422 ERRORS: BIT    @SW13,@SWR
012356 001055          BNE    HALTS
012360 021667 001252    CMP    (SP),LAST
012364 001404          BEQ    1$
012366 011667 001244    MOV    (SP),LAST
012372 005067 001174    CLR    ERRFLG
012376 104406          1$: SAV05P
012400 011605          MOV    (SP),R5
012402 162705 000002    SUB    @2,R5
012406 011504          MOV    (R5),R4
012410 006304          ASL    R4
012412 006304          ASL    R4
012414 042704 177001    BIC    @177001,R4
012420 062704 015216    ADD    @ERRTAB,R4
012424 012467 000040    MOV    (R4)+,ERRMSG
012430 011467 000052    MOV    (R4),DATABP
012434 005767 001132    TST    ERRFLG
012440 001403          BEQ    TYPMSG
012442 005767 000040    TST    DATABP
012446 001011          BNE    TYPDAT
012450 104401          TYPMSG: TYPE
012452 014774          MCRLF
012454 104402          OCTASC
012456 012554          ERTAB0
012460 012767 000001 001104    MOV    @1,ERRFLG
012466 104401          TYPE
012470 000000          ERRMSG: 0
012472 005767 000010    TYPDAT: TST    DATABP
012476 001404          BEQ    RESREG
012500 104401          TYPE
012502 014774          MCRLF
012504 104402          OCTASC
012506 000000          DATABP: 0
012510 104407          RESREG: RES05
012512 005777 166262    HALTS: TST    @SWR
012516 100005          BPL    EXITER
012520 010046          PUSHRO
012522 016600 000002    MOV    2(SP),R0
012526 000000          HALT
012530 012600          POPRO
012532 005267 001040    EXITER: INC    ERRCNT
012536 032777 002000 166234    BIT    @SW10,@SWR
012544 001402          BEQ    1$
012546 016716 001030    MOV    ESCAPE,(SP)
012552 000002          1$: RTI
012554 000001          ERTAB0: 1
012556 006      002      .BYTE 6,2
012560 013630          SAVPC

```

; 4

: 3
: 5
: 5
: 5: 5
: 5

: 4

: 4

012562

.TRPSRV

;TRAP DISPATCH SERVICE
;ARGUMENT OF TRAP IS EXTRACTED
;AND USED AS OFFSET TO OBTAIN POINTER
;TO SELECTED SUBROUTINE

; 3

012562 011646
012564 162716 000002
012570 017616 000000
012574 006316
012576 042716 177001
012602 062716 015136
012606 017616 000000
012612 000136
2 012614

TRPSRV: MOV (SP),-(SP) ;GET PC OF RETURN
SUB #2,(SP) ;PC OF TRAP
MOV #0(SP),(SP) ;GET TRP
TRPOK: ASL (SP) ;MULTIPLY TRAP ARG BY 2
BIC #177001,(SP) ;CLEAR UNWANTED BITS
ADD #TRPTAB,(SP) ;POINTER TO SUBROUTINE ADDRESS
MOV #0(SP),(SP) ;SUBROUTINE ADDRESS
JMP #0(SP)+ ;GO TO SUBROUTINE

.SAVREG

;SAVE PC OF TEST THAT FAILED AND R0-R5

012614 016667 000004 001006 SV05P: MOV 4(SP),SAVPC

;SAVE R0-R5

; 3

012622 010567 000776
012626 010467 000770
012632 010367 000762
012636 010267 000754
012642 010167 000746
012646 010067 000740
012652 000002
3 012654

SV05: MOV R5,SAVR5
MOV R4,SAVR4
MOV R3,SAVR3
MOV R2,SAVR2
MOV R1,SAVR1
MOV R0,SAVR0
RTI

.RESREG

;RESTORE R0-R5

012654 016700 000732
012660 016701 000730
012664 016702 000726
012670 016703 000724
012674 016704 000722
012700 016705 000720
012704 000002

RS05: MOV SAVR0,R0
MOV SAVR1,R1
MOV SAVR2,R2
MOV SAVR3,R3
MOV SAVR4,R4
MOV SAVR5,R5
RTI

1 012706

.TYPER

;TELETYPE OUTPUT ROUTINE

; 3

012706 017605 000000
 012712 062716 000002
 012716 105777 000612
 012722 100375
 012724 105715
 012726 001001
 012730 000002
 012732 112577 000600
 012736 000767
 2 012740

TYPER: MOV @ (SP), R5
 ADD @2, (SP)
 1: TSTB @TPCSR
 BPL 1:
 TSTB (R5)
 BNE 2:
 RTI
 2: MOVB (R5)+, @TPDBR
 BR 1:
 .INSTRG

;ASCII STRING INPUT ROUTINE

012740 017667 000000 000006
 012746 062716 000002
 012752 104401
 012754 000000
 012756 012704 015160
 012762 012703 000007
 012766 105777 000536
 012772 100375
 012774 117714 000532
 013000 142714 000200
 013004 122427 000015
 013010 001413
 013012 117777 000514 000516
 013020 105777 000510
 013024 100375
 013026 005303
 013030 001356
 013032 104401
 013034 014770
 013036 000745
 013040 000002

INSTRG: MOV @ (SP), MSG
 ADD @2, (SP)
 INSTR1: TYPE
 MSG: 0
 MOV @INBUF, R4
 MOV @7, R3
 1: TSTB @TKCSR
 BPL 1:
 MOVB @TKDBR, (R4)
 BICB @200, (R4)
 CMPB (R4)+, @15
 BEQ INSTR2
 MOVB @TKLDBR, @TPDBR
 2: TSTB @TPCSR
 BPL 2:
 DEC R3
 BNE 1:
 INSTR2: TYPE
 MQM
 BR INSTR1
 INSTR2: RTI

1 013042

.PARAMS

;CONVERT ASCII STRING TO OCTAL

; 3

013042 011605
 013044 012567 000146
 013050 012567 000144
 013054 012567 000142
 013060 112567 000140
 013064 112567 000135
 013070 010516
 013072 005005
 013074 012704 015160
 013100 122714 000015
 013104 001420
 013106 121427 000060
 013112 002415
 013114 121427 000067
 013120 003012
 013122 142714 000060
 013126 152405
 013130 122714 000015
 013134 001406
 013136 006305
 013140 006305
 013142 006305
 013144 000760
 013146 104404
 013150 000750

PARAMS: MOV (SP),R5
 MOV (R5)+,LOLIM
 MOV (R5)+,HILIM
 MOV (R5)+,DEVADR
 MOV (R5)+,LOBITS
 MOV (R5)+,ADRCNT
 MOV R5,(SP)
 PARAM1: CLR R5
 MOV #INBUF,R4
 CMPB #15,(R4)
 BEQ PARERR
 14: CMPB (R4),#60
 BLT PARERR
 CMPB (R4),#67
 BGT PARERR
 BICB #60,(R4)
 BISB (R4)+,R5
 CMPB #15,(R4)
 BEQ LIMITS
 ASL R5
 ASL R5
 ASL R5
 BR 14
 PARERR: INSTER
 BR PARAM1

;TEST TO SEE IF NUMBER IS WITHIN LIMITS

013152 020567 000042
 013156 101373
 013160 020567 000032
 013164 103770
 013166 136705 000032
 013172 001365

LIMITS: CMP R5,HILIM
 BHI PARERR
 CMP R5,LOLIM
 BLO PARERR
 BITB LOBITS,R5
 BNE PARERR

; 3

;STORE NUMBER AT SPECIFIED ADDRESS

013174 016704 000022
 013200 010524
 013202 062705 000002
 013206 105367 000013
 013212 001372
 013214 000002
 013216 000000
 013220 000000
 013222 000000
 013224 000000
 013225

14: MOV DEVADR,R4
 MOV R5,(R4)+
 ADD #2,R5
 DECB ADRCNT
 BNE 14
 RTI
 LOLIM: 0
 HILIM: 0
 DEVADR: 0
 LOBITS: 0
 ADRCNT=LOBITS+1

013226

.OCTASC

;CONVERT OCTAL NUMBER TO ASCII AND OUTPUT TO TELEPRINTER

```

013226 017601 000000
013232 062716 000002
013236 012167 000130
013242 112167 000126
013246 112167 000123
013252 013167 000120
013256 016704 000114
013262 116705 000106
013266 012700 015172
013272 010403
013274 042703 177770
013300 062703 000260
013304 110320
013306 006204
013310 006204
013312 006204
013314 005305
013316 001365
013320 012703 015204
013324 114023
013326 105367 000042
013332 001374
013334 105767 000035
013340 001405
013342 112723 000240
013346 105367 000023
013352 001373
013354 105013
013356 104401
013360 015204
013362 005367 000004
013366 001325
013370 000002
013372 000000
013374 000000
013375 013375
013376 000000

```

```

OCTASN: MOV      @ (SP), R1
          ADD      @ 2, (SP)
          MOV      (R1)+, WRDCNT
1$:      MOV      (R1)+, CHRCNT
          MOV      (R1)+, SPACNT
          MOV      @ (R1)+, BINWRD
2$:      MOV      BINWRD, R4
          MOV      CHRCNT, R5
          MOV      @TEMP, R0
3$:      MOV      R4, R3
          BIC      @177770, R3
          ADD      @260, R3
          MOV      R3, (R0)+
          ASR      R4
          ASR      R4
          ASR      R4
          DEC      R5
          BNE      3$
          MOV      @MDATA, R3
4$:      MOV      -(R0), (R3)+
          DECB     CHRCNT
          BNE      4$
          TST      SPACNT
          BEQ      6$
5$:      MOV      @240, (R3)+
          DECB     SPACNT
          BNE      5$
6$:      CLRB      (R3)
          TYPE      MDATA
          DEC      WRDCNT
          BNE      1$
          RTI
WRDCNT: 0
CHRCNT: 0
SPACNT=CHRCNT+1
BINWRD: 0

```

; 5

; 3

013400

CCLRALL

;CLEAR ALL BYTE COUNT AND BUS ADDRESS REGISTERS

013400 012700 000020
 013404 005077 000136
 013410 005077 000134
 013414 005277 000120
 013420 005300
 013422 001370
 013424 000207
 2 013426

CLRALL: MOV #20,R0 ;SET UP TO CLEAR 16
 1+: CLR @DHBA ;CLEAR BUS ADDRESS
 CLR @DHBC ;CLEAR BYTE COUNT
 INC @DHSCR ;ADVANCE LINE NUMBER
 DEC R0 ;CONTINUE IF NOT DONE
 BNE 1+
 RTS PC ;RETURN TO CALLING ROUTINE
 SSETALL

;SET BYTE COUNT FOR ALL LINES TO 400
 ;SET BUS ADDRESS FOR ALL LINES TO TBUF
 ;CLEAR EXPECTED CHARACTER BUFFERS
 ;SET LINE ACTIVE BITS FOR ALL LINES

013426 012700 000020

SETALL: MOV #20,R0 ;SET UP TO LOAD 16
 ;BYTE COUNT AND BUS ADDRESS
 ;MEMORY LOCATIONS
 CLR R1 ;SET UP TO GENERATE EXPECTED
 ;RECEIVED CHARACTER BUFFER
 ;WILL BE HIGH BYTE
 ;OF EXPECTED RECEIVED CHARACTER
 ;OFFSET FOR HIGH BYTE
 MOV #200,R2 ;LOAD BUS ADDRESS
 ;LOAD BYTE COUNT
 ;SET LINE SPEED TO 4800 BAUD
 ;RECEIVED CHARACTER
 ;LOAD HIGH BYTE
 ;ADVANCE LINE NUMBER TO NEXT LINE
 ;UPDATE POINTERS
 ;CONTINUE IF NOT DONE
 ;SET ACTIVE FLAGS FOR ALL LINES
 ;RETURN TO CALLING ROUTINE

013432 005001

CLR R1

013434 012702 000200

MOV #200,R2

013440 012703 000001
 013444 012777 013646 000074
 013452 012777 177400 000070
 013460 012777 031403 000056
 013466 105061 014246

1+:

MOV #1,R3
 MOV @TBUF,@DHBA
 MOV #-400,@DHBC
 MOV #31403,@DHLPR
 CLRB RBUF(R1)

013472 110263 014246

MOVB R2,RBUF(R3)

013476 005277 000036

INC @DHSCR

013502 005202

INC R2

013504 062701 000002

ADD #2,R1

013510 062703 000002

ADD #2,R3

013514 005300

DEC R0

013516 001352

BNE 1+

013520 012767 177777 000114

MOV #-1,LINACT

013526 000207

RTS PC

```
1 013530      .POINT  †/DHSCR,DHNRC,DHLPR,DHBA,DHBC,DHBAR,DHBCR,DHSSR,DHSLR,DHRVEC,DHRLVL,DHTVEC,DHTLVL/
               ;INDIRECT POINTERS
               ; 3
013530 177560  TKCSR: 177560
013532 177562  TKDBR: 177562
013534 177564  TPCSR: 177564
013536 177566  TPDBR: 177566
               .IRP  A      <DHSCR,DHNRC,DHLPR,DHBA,DHBC,DHBAR,DHBCR,DHSSR,DHSLR,DHRVEC,DHRLVL,DHTVEC,DH
TLVL>
               A: 0
               .ENDM
013540 000000  DHSCR: 0
013542 000000  DHNRC: 0
013544 000000  DHLPR: 0
013546 000000  DHBA: 0
013550 000000  DHBC: 0
013552 000000  DHBAR: 0
013554 000000  DHBCR: 0
013556 000000  DHSSR: 0
013560 000000  DHSLR: 0
013562 000000  DHRVEC: 0
013564 000000  DHRLVL: 0
013566 000000  DHTVEC: 0
013570 000000  DHTLVL: 0
2 013572      .VARIA  †/ENDFLG,LINACT,AEACT/
               ;PROGRAM VARIABLES
013572 000000  ERRFLG: 0      ;ERROR FLAG
013574 000000  PASCNT: 0      ;PASS COUNT
013576 000000  ERRCNT: 0      ;ERROR COUNT
013600 000000  RETRN: 0       ;SCOPE RETURN ADDRESS FOR TEST LOOPING
013602 000000  ESCAPE: 0      ;ADDRESS FOR ERROR ESCAPE
013604 000000  FREEZ1: 0      ;DATA LOOPING RETURN ADDRESS
013606 000000  ICOUNT: 0      ;ITERATION COUNT FOR TEST IN PROGRESS
013610 000000  LPCNT: 0       ;NUMBER OF ITERATIONS THIS TEST
013612 000000  SAVR0: 0       ;R0 SAVE AREA
013614 000000  SAVR1: 0       ;R1 SAVE AREA
013616 000000  SAVR2: 0       ;R2 SAVE AREA
013620 000000  SAVR3: 0       ;R3 SAVE ARE
013622 000000  SAVR4: 0       ;R4 SAVE AREA
013624 000000  SAVR5: 0       ;R5 SAVE AREA
013626 000000  SAVSP: 0       ;STACK POINTER SAVE AREA
013630 000000  SAVPC: 0       ;CALLING ROUTINE SAVE AREA
013632 000000  INIFLG: 0      ;PROGRAM INITIALIZATION FLAG
013634 000000  STFLG: 0       ;PROGRAM START FLAG
013636 000000  LAST: 0        ;LAST ERROR PC
               .IRP  A      <ENDFLG,LINACT,AEACT>
               A: 0
               .ENDM
013640 000000  ENDFLG: 0
013642 000000  LINACT: 0
013644 000000  AEACT: 0
```

: 3

4	013646	000001	TDAT=1
5		000	TBUF: .BYTE 0
6		000377	.REPT 377
7			.BYTE TDAT
8			.NLIST
9			TDAT=TDAT+1
10			.LIST
	013647	001	.ENDR
		000002	.BYTE TDAT
	013650	002	TDAT=TDAT+1
		000003	.BYTE TDAT
	013651	003	TDAT=TDAT+1
		000004	.BYTE TDAT
	013652	004	TDAT=TDAT+1
		000005	.BYTE TDAT
	013653	005	TDAT=TDAT+1
		000006	.BYTE TDAT
	013654	006	TDAT=TDAT+1
		000007	.BYTE TDAT
	013655	007	TDAT=TDAT+1
		000010	.BYTE TDAT
	013656	010	TDAT=TDAT+1
		000011	.BYTE TDAT
	013657	011	TDAT=TDAT+1
		000012	.BYTE TDAT
	013660	012	TDAT=TDAT+1
		000013	.BYTE TDAT
	013661	013	TDAT=TDAT+1
		000014	.BYTE TDAT
	013662	014	TDAT=TDAT+1
		000015	.BYTE TDAT
	013663	015	TDAT=TDAT+1
		000016	.BYTE TDAT
	013664	016	TDAT=TDAT+1
		000017	.BYTE TDAT
	013665	017	TDAT=TDAT+1
		000020	.BYTE TDAT
	013666	020	TDAT=TDAT+1
		000021	.BYTE TDAT
	013667	021	TDAT=TDAT+1
		000022	.BYTE TDAT
	013670	022	TDAT=TDAT+1
		000023	.BYTE TDAT
	013671	023	TDAT=TDAT+1
		000024	.BYTE TDAT
	013672	024	TDAT=TDAT+1
		000025	.BYTE TDAT
	013673	025	TDAT=TDAT+1
		000026	.BYTE TDAT
	013674	026	TDAT=TDAT+1
		000027	.BYTE TDAT
	013675	027	TDAT=TDAT+1
		000030	.BYTE TDAT
	013676	030	TDAT=TDAT+1
		000031	.BYTE TDAT
	013677	031	

	000032	TDAT=TDAT+1
013700	032	.BYTE TDAT
	000033	TDAT=TDAT+1
013701	033	.BYTE TDAT
	000034	TDAT=TDAT+1
013702	034	.BYTE TDAT
	000035	TDAT=TDAT+1
013703	035	.BYTE TDAT
	000036	TDAT=TDAT+1
013704	036	.BYTE TDAT
	000037	TDAT=TDAT+1
013705	037	.BYTE TDAT
	000040	TDAT=TDAT+1
013706	040	.BYTE TDAT
	000041	TDAT=TDAT+1
013707	041	.BYTE TDAT
	000042	TDAT=TDAT+1
013710	042	.BYTE TDAT
	000043	TDAT=TDAT+1
013711	043	.BYTE TDAT
	000044	TDAT=TDAT+1
013712	044	.BYTE TDAT
	000045	TDAT=TDAT+1
013713	045	.BYTE TDAT
	000046	TDAT=TDAT+1
013714	046	.BYTE TDAT
	000047	TDAT=TDAT+1
013715	047	.BYTE TDAT
	000050	TDAT=TDAT+1
013716	050	.BYTE TDAT
	000051	TDAT=TDAT+1
013717	051	.BYTE TDAT
	000052	TDAT=TDAT+1
013720	052	.BYTE TDAT
	000053	TDAT=TDAT+1
013721	053	.BYTE TDAT
	000054	TDAT=TDAT+1
013722	054	.BYTE TDAT
	000055	TDAT=TDAT+1
013723	055	.BYTE TDAT
	000056	TDAT=TDAT+1
013724	056	.BYTE TDAT
	000057	TDAT=TDAT+1
013725	057	.BYTE TDAT
	000060	TDAT=TDAT+1
013726	060	.BYTE TDAT
	000061	TDAT=TDAT+1
013727	061	.BYTE TDAT
	000062	TDAT=TDAT+1
013730	062	.BYTE TDAT
	000063	TDAT=TDAT+1
013731	063	.BYTE TDAT
	000064	TDAT=TDAT+1
013732	064	.BYTE TDAT
	000065	TDAT=TDAT+1
013733	065	.BYTE TDAT
	000066	TDAT=TDAT+1

013734	066	.BYTE TDAT
	000067	TDAT=TDAT+1
013735	067	.BYTE TDAT
	000070	TDAT=TDAT+1
013736	070	.BYTE TDAT
	000071	TDAT=TDAT+1
013737	071	.BYTE TDAT
	000072	TDAT=TDAT+1
013740	072	.BYTE TDAT
	000073	TDAT=TDAT+1
013741	073	.BYTE TDAT
	000074	TDAT=TDAT+1
013742	074	.BYTE TDAT
	000075	TDAT=TDAT+1
013743	075	.BYTE TDAT
	000076	TDAT=TDAT+1
013744	076	.BYTE TDAT
	000077	TDAT=TDAT+1
013745	077	.BYTE TDAT
	000100	TDAT=TDAT+1
013746	100	.BYTE TDAT
	000101	TDAT=TDAT+1
013747	101	.BYTE TDAT
	000102	TDAT=TDAT+1
013750	102	.BYTE TDAT
	000103	TDAT=TDAT+1
013751	103	.BYTE TDAT
	000104	TDAT=TDAT+1
013752	104	.BYTE TDAT
	000105	TDAT=TDAT+1
013753	105	.BYTE TDAT
	000106	TDAT=TDAT+1
013754	106	.BYTE TDAT
	000107	TDAT=TDAT+1
013755	107	.BYTE TDAT
	000110	TDAT=TDAT+1
013756	110	.BYTE TDAT
	000111	TDAT=TDAT+1
013757	111	.BYTE TDAT
	000112	TDAT=TDAT+1
013760	112	.BYTE TDAT
	000113	TDAT=TDAT+1
013761	113	.BYTE TDAT
	000114	TDAT=TDAT+1
013762	114	.BYTE TDAT
	000115	TDAT=TDAT+1
013763	115	.BYTE TDAT
	000116	TDAT=TDAT+1
013764	116	.BYTE TDAT
	000117	TDAT=TDAT+1
013765	117	.BYTE TDAT
	000120	TDAT=TDAT+1
013766	120	.BYTE TDAT
	000121	TDAT=TDAT+1
013767	121	.BYTE TDAT
	000122	TDAT=TDAT+1
013770	122	.BYTE TDAT

013771	000123	TDAT=TDAT+1
	123	.BYTE TDAT
013772	000124	TDAT=TDAT+1
	124	.BYTE TDAT
013773	000125	TDAT=TDAT+1
	125	.BYTE TDAT
013774	000126	TDAT=TDAT+1
	126	.BYTE TDAT
013775	000127	TDAT=TDAT+1
	127	.BYTE TDAT
013776	000130	TDAT=TDAT+1
	130	.BYTE TDAT
013777	000131	TDAT=TDAT+1
	131	.BYTE TDAT
014000	000132	TDAT=TDAT+1
	132	.BYTE TDAT
014001	000133	TDAT=TDAT+1
	133	.BYTE TDAT
014002	000134	TDAT=TDAT+1
	134	.BYTE TDAT
014003	000135	TDAT=TDAT+1
	135	.BYTE TDAT
014004	000136	TDAT=TDAT+1
	136	.BYTE TDAT
014005	000137	TDAT=TDAT+1
	137	.BYTE TDAT
014006	000140	TDAT=TDAT+1
	140	.BYTE TDAT
014007	000141	TDAT=TDAT+1
	141	.BYTE TDAT
014010	000142	TDAT=TDAT+1
	142	.BYTE TDAT
014011	000143	TDAT=TDAT+1
	143	.BYTE TDAT
014012	000144	TDAT=TDAT+1
	144	.BYTE TDAT
014013	000145	TDAT=TDAT+1
	145	.BYTE TDAT
014014	000146	TDAT=TDAT+1
	146	.BYTE TDAT
014015	000147	TDAT=TDAT+1
	147	.BYTE TDAT
014016	000150	TDAT=TDAT+1
	150	.BYTE TDAT
014017	000151	TDAT=TDAT+1
	151	.BYTE TDAT
014020	000152	TDAT=TDAT+1
	152	.BYTE TDAT
014021	000153	TDAT=TDAT+1
	153	.BYTE TDAT
014022	000154	TDAT=TDAT+1
	154	.BYTE TDAT
014023	000155	TDAT=TDAT+1
	155	.BYTE TDAT
014024	000156	TDAT=TDAT+1
	156	.BYTE TDAT
	000157	TDAT=TDAT+1

014025	157	.BYTE TDAT
	000160	TDAT=TDAT+1
014026	160	.BYTE TDAT
	000161	TDAT=TDAT+1
014027	161	.BYTE TDAT
	000162	TDAT=TDAT+1
014030	162	.BYTE TDAT
	000163	TDAT=TDAT+1
014031	163	.BYTE TDAT
	000164	TDAT=TDAT+1
014032	164	.BYTE TDAT
	000165	TDAT=TDAT+1
014033	165	.BYTE TDAT
	000166	TDAT=TDAT+1
014034	166	.BYTE TDAT
	000167	TDAT=TDAT+1
014035	167	.BYTE TDAT
	000170	TDAT=TDAT+1
014036	170	.BYTE TDAT
	000171	TDAT=TDAT+1
014037	171	.BYTE TDAT
	000172	TDAT=TDAT+1
014040	172	.BYTE TDAT
	000173	TDAT=TDAT+1
014041	173	.BYTE TDAT
	000174	TDAT=TDAT+1
014042	174	.BYTE TDAT
	000175	TDAT=TDAT+1
014043	175	.BYTE TDAT
	000176	TDAT=TDAT+1
014044	176	.BYTE TDAT
	000177	TDAT=TDAT+1
014045	177	.BYTE TDAT
	000200	TDAT=TDAT+1
014046	200	.BYTE TDAT
	000201	TDAT=TDAT+1
014047	201	.BYTE TDAT
	000202	TDAT=TDAT+1
014050	202	.BYTE TDAT
	000203	TDAT=TDAT+1
014051	203	.BYTE TDAT
	000204	TDAT=TDAT+1
014052	204	.BYTE TDAT
	000205	TDAT=TDAT+1
014053	205	.BYTE TDAT
	000206	TDAT=TDAT+1
014054	206	.BYTE TDAT
	000207	TDAT=TDAT+1
014055	207	.BYTE TDAT
	000210	TDAT=TDAT+1
014056	210	.BYTE TDAT
	000211	TDAT=TDAT+1
014057	211	.BYTE TDAT
	000212	TDAT=TDAT+1
014060	212	.BYTE TDAT
	000213	TDAT=TDAT+1
014061	213	.BYTE TDAT

	000214	TDAT=TDAT+1
014062	214	.BYTE TDAT
	000215	TDAT=TDAT+1
014063	215	.BYTE TDAT
	000216	TDAT=TDAT+1
014064	216	.BYTE TDAT
	000217	TDAT=TDAT+1
014065	217	.BYTE TDAT
	000220	TDAT=TDAT+1
014066	220	.BYTE TDAT
	000221	TDAT=TDAT+1
014067	221	.BYTE TDAT
	000222	TDAT=TDAT+1
014070	222	.BYTE TDAT
	000223	TDAT=TDAT+1
014071	223	.BYTE TDAT
	000224	TDAT=TDAT+1
014072	224	.BYTE TDAT
	000225	TDAT=TDAT+1
014073	225	.BYTE TDAT
	000226	TDAT=TDAT+1
014074	226	.BYTE TDAT
	000227	TDAT=TDAT+1
014075	227	.BYTE TDAT
	000230	TDAT=TDAT+1
014076	230	.BYTE TDAT
	000231	TDAT=TDAT+1
014077	231	.BYTE TDAT
	000232	TDAT=TDAT+1
014100	232	.BYTE TDAT
	000233	TDAT=TDAT+1
014101	233	.BYTE TDAT
	000234	TDAT=TDAT+1
014102	234	.BYTE TDAT
	000235	TDAT=TDAT+1
014103	235	.BYTE TDAT
	000236	TDAT=TDAT+1
014104	236	.BYTE TDAT
	000237	TDAT=TDAT+1
014105	237	.BYTE TDAT
	000240	TDAT=TDAT+1
014106	240	.BYTE TDAT
	000241	TDAT=TDAT+1
014107	241	.BYTE TDAT
	000242	TDAT=TDAT+1
014110	242	.BYTE TDAT
	000243	TDAT=TDAT+1
014111	243	.BYTE TDAT
	000244	TDAT=TDAT+1
014112	244	.BYTE TDAT
	000245	TDAT=TDAT+1
014113	245	.BYTE TDAT
	000246	TDAT=TDAT+1
014114	246	.BYTE TDAT
	000247	TDAT=TDAT+1
014115	247	.BYTE TDAT
	000250	TDAT=TDAT+1

014116	250	.BYTE TDAT
	000251	TDAT=TDAT+1
014117	251	.BYTE TDAT
	000252	TDAT=TDAT+1
014120	252	.BYTE TDAT
	000253	TDAT=TDAT+1
014121	253	.BYTE TDAT
	000254	TDAT=TDAT+1
014122	254	.BYTE TDAT
	000255	TDAT=TDAT+1
014123	255	.BYTE TDAT
	000256	TDAT=TDAT+1
014124	256	.BYTE TDAT
	000257	TDAT=TDAT+1
014125	257	.BYTE TDAT
	000260	TDAT=TDAT+1
014126	260	.BYTE TDAT
	000261	TDAT=TDAT+1
014127	261	.BYTE TDAT
	000262	TDAT=TDAT+1
014130	262	.BYTE TDAT
	000263	TDAT=TDAT+1
014131	263	.BYTE TDAT
	000264	TDAT=TDAT+1
014132	264	.BYTE TDAT
	000265	TDAT=TDAT+1
014133	265	.BYTE TDAT
	000266	TDAT=TDAT+1
014134	266	.BYTE TDAT
	000267	TDAT=TDAT+1
014135	267	.BYTE TDAT
	000270	TDAT=TDAT+1
014136	270	.BYTE TDAT
	000271	TDAT=TDAT+1
014137	271	.BYTE TDAT
	000272	TDAT=TDAT+1
014140	272	.BYTE TDAT
	000273	TDAT=TDAT+1
014141	273	.BYTE TDAT
	000274	TDAT=TDAT+1
014142	274	.BYTE TDAT
	000275	TDAT=TDAT+1
014143	275	.BYTE TDAT
	000276	TDAT=TDAT+1
014144	276	.BYTE TDAT
	000277	TDAT=TDAT+1
014145	277	.BYTE TDAT
	000300	TDAT=TDAT+1
014146	300	.BYTE TDAT
	000301	TDAT=TDAT+1
014147	301	.BYTE TDAT
	000302	TDAT=TDAT+1
014150	302	.BYTE TDAT
	000303	TDAT=TDAT+1
014151	303	.BYTE TDAT
	000304	TDAT=TDAT+1
014152	304	.BYTE TDAT

014153	000305	TDAT=TDAT.1
	305	.BYTE TDAT
014154	000306	TDAT=TDAT.1
	306	.BYTE TDAT
014155	000307	TDAT=TDAT.1
	307	.BYTE TDAT
014156	000310	TDAT=TDAT.1
	310	.BYTE TDAT
014157	000311	TDAT=TDAT.1
	311	.BYTE TDAT
014160	000312	TDAT=TDAT.1
	312	.BYTE TDAT
014161	000313	TDAT=TDAT.1
	313	.BYTE TDAT
014162	000314	TDAT=TDAT.1
	314	.BYTE TDAT
014163	000315	TDAT=TDAT.1
	315	.BYTE TDAT
014164	000316	TDAT=TDAT.1
	316	.BYTE TDAT
014165	000317	TDAT=TDAT.1
	317	.BYTE TDAT
014166	000320	TDAT=TDAT.1
	320	.BYTE TDAT
014167	000321	TDAT=TDAT.1
	321	.BYTE TDAT
014170	000322	TDAT=TDAT.1
	322	.BYTE TDAT
014171	000323	TDAT=TDAT.1
	323	.BYTE TDAT
014172	000324	TDAT=TDAT.1
	324	.BYTE TDAT
014173	000325	TDAT=TDAT.1
	325	.BYTE TDAT
014174	000326	TDAT=TDAT.1
	326	.BYTE TDAT
014175	000327	TDAT=TDAT.1
	327	.BYTE TDAT
014176	000330	TDAT=TDAT.1
	330	.BYTE TDAT
014177	000331	TDAT=TDAT.1
	331	.BYTE TDAT
014200	000332	TDAT=TDAT.1
	332	.BYTE TDAT
014201	000333	TDAT=TDAT.1
	333	.BYTE TDAT
014202	000334	TDAT=TDAT.1
	334	.BYTE TDAT
014203	000335	TDAT=TDAT.1
	335	.BYTE TDAT
014204	000336	TDAT=TDAT.1
	336	.BYTE TDAT
014205	000337	TDAT=TDAT.1
	337	.BYTE TDAT
014206	000340	TDAT=TDAT.1
	340	.BYTE TDAT
	000341	TDAT=TDAT.1

014207	341	.BYTE TDAT
	000342	TDAT=TDAT+1
014210	342	.BYTE TDAT
	000343	TDAT=TDAT+1
014211	343	.BYTE TDAT
	000344	TDAT=TDAT+1
014212	344	.BYTE TDAT
	000345	TDAT=TDAT+1
014213	345	.BYTE TDAT
	000346	TDAT=TDAT+1
014214	346	.BYTE TDAT
	000347	TDAT=TDAT+1
014215	347	.BYTE TDAT
	000350	TDAT=TDAT+1
014216	350	.BYTE TDAT
	000351	TDAT=TDAT+1
014217	351	.BYTE TDAT
	000352	TDAT=TDAT+1
014220	352	.BYTE TDAT
	000353	TDAT=TDAT+1
014221	353	.BYTE TDAT
	000354	TDAT=TDAT+1
014222	354	.BYTE TDAT
	000355	TDAT=TDAT+1
014223	355	.BYTE TDAT
	000356	TDAT=TDAT+1
014224	356	.BYTE TDAT
	000357	TDAT=TDAT+1
014225	357	.BYTE TDAT
	000360	TDAT=TDAT+1
014226	360	.BYTE TDAT
	000361	TDAT=TDAT+1
014227	361	.BYTE TDAT
	000362	TDAT=TDAT+1
014230	362	.BYTE TDAT
	000363	TDAT=TDAT+1
014231	363	.BYTE TDAT
	000364	TDAT=TDAT+1
014232	364	.BYTE TDAT
	000365	TDAT=TDAT+1
014233	365	.BYTE TDAT
	000366	TDAT=TDAT+1
014234	366	.BYTE TDAT
	000367	TDAT=TDAT+1
014235	367	.BYTE TDAT
	000370	TDAT=TDAT+1
014236	370	.BYTE TDAT
	000371	TDAT=TDAT+1
014237	371	.BYTE TDAT
	000372	TDAT=TDAT+1
014240	372	.BYTE TDAT
	000373	TDAT=TDAT+1
014241	373	.BYTE TDAT
	000374	TDAT=TDAT+1
014242	374	.BYTE TDAT
	000375	TDAT=TDAT+1
014243	375	.BYTE TDAT

	014244	000376	TDAT=TDAT+1
		376	.BYTE TDAT
		000377	TDAT=TDAT+1
	014245	377	.BYTE TDAT
		000400	TDAT=TDAT+1
11			.EVEN
12	014246	000000	RBUF: 0
13		014310	. = .+40

1		.MACRO WORDS WNAME,K,DATA
2		'WNAME'K': DATA
3		.ENDM WORDS
5	000020	K=KX
6	000000	DATA=DATA
7	000000	KX=0
9	000020	.REPT 20
10		.NLIST
11		DATA=KX*400+100377
12		.LIST
13		WORDS +/TWRD/, \KX, \DATA
14		.NLIST
15		KX=KX+1
16		.LIST
17		.ENDR
	100377	DATA=KX*400+100377
014310		WORDS +/TWRD/, \KX, \DATA
014310	100377	TWRD0: 100377
	000001	KX=KX+1
	100777	DATA=KX*400+100377
014312		WORDS +/TWRD/, \KX, \DATA
014312	100777	TWRD1: 100777
	000002	KX=KX+1
	101377	DATA=KX*400+100377
014314		WORDS +/TWRD/, \KX, \DATA
014314	101377	TWRD2: 101377
	000003	KX=KX+1
	101777	DATA=KX*400+100377
014316		WORDS +/TWRD/, \KX, \DATA
014316	101777	TWRD3: 101777
	000004	KX=KX+1
	102377	DATA=KX*400+100377
014320		WORDS +/TWRD/, \KX, \DATA
014320	102377	TWRD4: 102377
	000005	KX=KX+1
	102777	DATA=KX*400+100377
014322		WORDS +/TWRD/, \KX, \DATA
014322	102777	TWRD5: 102777
	000006	KX=KX+1
	103377	DATA=KX*400+100377
014324		WORDS +/TWRD/, \KX, \DATA
014324	103377	TWRD6: 103377
	000007	KX=KX+1
	103777	DATA=KX*400+100377
014326		WORDS +/TWRD/, \KX, \DATA
014326	103777	TWRD7: 103777
	000010	KX=KX+1
	104377	DATA=KX*400+100377
014330		WORDS +/TWRD/, \KX, \DATA
014330	104377	TWRD10: 104377
	000011	KX=KX+1
	104777	DATA=KX*400+100377
014332		WORDS +/TWRD/, \KX, \DATA
014332	104777	TWRD11: 104777
	000012	KX=KX+1
	105377	DATA=KX*400+100377
014334		WORDS +/TWRD/, \KX, \DATA

014334	105377	TWRD12: 105377
	000013	KX=KX+1
	105777	DATAX=KX*400+100377
014336		WORDS +/TWRD/, \KX, \DATAX
014336	105777	TWRD13: 105777
	000014	KX=KX+1
	106377	DATAX=KX*400+100377
014340		WORDS +/TWRD/, \KX, \DATAX
014340	106377	TWRD14: 106377
	000015	KX=KX+1
	106777	DATAX=KX*400+100377
014342		WORDS +/TWRD/, \KX, \DATAX
014342	106777	TWRD15: 106777
	000016	KX=KX+1
	107377	DATAX=KX*400+100377
014344		WORDS +/TWRD/, \KX, \DATAX
014344	107377	TWRD16: 107377
	000017	KX=KX+1
	107777	DATAX=KX*400+100377
014346		WORDS +/TWRD/, \KX, \DATAX
014346	107777	TWRD17: 107777
	000020	KX=KX+1
19	107777	DATA=DATAX
20	000020	K=KX
21	000000	DATAX=0
22	000000	KX=0
24	000020	.REPT 20
25		WORDS +/RCNT/, \KX, \DATAX
26		.NLIST
27		KX=KX+1
28		.LIST
29		.ENDR
014350		WORDS +/RCNT/, \KX, \DATAX
014350	000000	RCNT0: 0
	000001	KX=KX+1
014352		WORDS +/RCNT/, \KX, \DATAX
014352	000000	RCNT1: 0
	000002	KX=KX+1
014354		WORDS +/RCNT/, \KX, \DATAX
014354	000000	RCNT2: 0
	000003	KX=KX+1
014356		WORDS +/RCNT/, \KX, \DATAX
014356	000000	RCNT3: 0
	000004	KX=KX+1
014360		WORDS +/RCNT/, \KX, \DATAX
014360	000000	RCNT4: 0
	000005	KX=KX+1
014362		WORDS +/RCNT/, \KX, \DATAX
014362	000000	RCNT5: 0
	000006	KX=KX+1
014364		WORDS +/RCNT/, \KX, \DATAX
014364	000000	RCNT6: 0
	000007	KX=KX+1
014366		WORDS +/RCNT/, \KX, \DATAX
014366	000000	RCNT7: 0
	000010	KX=KX+1
014370		WORDS +/RCNT/, \KX, \DATAX

014370	000000	RCNT10: 0
	000011	KX=KX+1
014372		WORDS +/RCNT/, \KX, \DATA
014372	000000	RCNT11: 0
	000012	KX=KX+1
014374		WORDS +/RCNT/, \KX, \DATA
014374	000000	RCNT12: 0
	000013	KX=KX+1
014376		WORDS +/RCNT/, \KX, \DATA
014376	000000	RCNT13: 0
	000014	KX=KX+1
014400		WORDS +/RCNT/, \KX, \DATA
014400	000000	RCNT14: 0
	000015	KX=KX+1
014402		WORDS +/RCNT/, \KX, \DATA
014402	000000	RCNT15: 0
	000016	KX=KX+1
014404		WORDS +/RCNT/, \KX, \DATA
014404	000000	RCNT16: 0
	000017	KX=KX+1
014406		WORDS +/RCNT/, \KX, \DATA
014406	000000	RCNT17: 0
	000020	KX=KX+1
31	000000	DATA=DATA
32	000020	K=KX
33	0000C0	DATA=0
34	000000	KX=0
36	000020	.REPT 20
37		WORDS +/RDCT/, \KX, \DATA
38		.NLIST
39		KX=KX+1
40		.LIST
41		.ENDR
014410		WORDS +/RDCT/, \KX, \DATA
014410	000000	RDCT0: 0
	000001	KX=KX+1
014412		WORDS +/RDCT/, \KX, \DATA
014412	000000	RDCT1: 0
	000002	KX=KX+1
014414		WORDS +/RDCT/, \KX, \DATA
014414	000000	RDCT2: 0
	000003	KX=KX+1
014416		WORDS +/RDCT/, \KX, \DATA
014416	000000	RDCT3: 0
	000004	KX=KX+1
014420		WORDS +/RDCT/, \KX, \DATA
014420	000000	RDCT4: 0
	000005	KX=KX+1
014422		WORDS +/RDCT/, \KX, \DATA
014422	000000	RDCT5: 0
	000006	KX=KX+1
014424		WORDS +/RDCT/, \KX, \DATA
014424	000000	RDCT6: 0
	000007	KX=KX+1
014426		WORDS +/RDCT/, \KX, \DATA
014426	000000	RDCT7: 0
	000010	KX=KX+1

014430		WORDS	↑/RDCT/, \KX, \DATA
014430	000000	RDCT10:	0
	000011	KX=KX+1	
014432		WORDS	↑/RDCT/, \KX, \DATA
014432	000000	RDCT11:	0
	000012	KX=KX+1	
014434		WORDS	↑/RDCT/, \KX, \DATA
014434	000000	RDCT12:	0
	000013	KX=KX+1	
014436		WORDS	↑/RDCT/, \KX, \DATA
014436	000000	RDCT13:	0
	000014	KX=KX+1	
014440		WORDS	↑/RDCT/, \KX, \DATA
014440	000000	RDCT14:	0
	000015	KX=KX+1	
014442		WORDS	↑/RDCT/, \KX, \DATA
014442	000000	RDCT15:	0
	000016	KX=KX+1	
014444		WORDS	↑/RDCT/, \KX, \DATA
014444	000000	RDCT16:	0
	000017	KX=KX+1	
014446		WORDS	↑/RDCT/, \KX, \DATA
014446	000000	RDCT17:	0
	000020	KX=KX+1	
42 014450	000001	LINBIT:	1
43 014452	000002		2
44 014454	000004		4
45 014456	000010		10
46 014460	000020		20
47 014462	000040		40
48 014464	000100		100
49 014466	000200		200
50 014470	000400		400
51 014472	001000		1000
52 014474	002000		2000
53 014476	004000		4000
54 014500	010000		10000
55 014502	020000		20000
56 014504	040000		40000
57 014506	100000		100000

1 014510

.PFAIL

;ENTER HERE ON POWER FAILURE

014510	010046			PFAIL:	MOV	R0,-(SP)		;SAVE R0-R5 ON PROCESSOR STACK
014512	010146				MOV	R1,-(SP)		
014514	010246				MOV	R2,-(SP)		
014516	010346				MOV	R3,-(SP)		
014520	010446				MOV	R4,-(SP)		
014522	010546				MOV	R5,-(SP)		
014524	016746	163274			MOV	24,-(SP)		
014530	010667	177072			MOV	SP,SAVSP		;SAVE STACK POINTER
014534	012767	014546	163262		MOV	#RESTART,24		;SET UP FOR POWER UP TRAP ; 3
014542	000000				HALT			;HALT ON POWER DOWN NORMAL
014544	000777				BR	.		

;PROCESSOR WILL TRAP HERE WHEN POWER IS RESTORED

014546	016706	177054		RESTAR:	MOV	SAVSP,SP		;RESTORE STACK POINTER
014552	012605				MOV	(SP)+,R5		;RESTORE R0-R5
014554	012604				MOV	(SP)+,R4		
014556	012603				MOV	(SP)+,R3		
014560	012602				MOV	(SP)+,R2		
014562	012601				MOV	(SP)+,R1		
014564	012600				MOV	(SP)+,R0		
014566	012767	014510	163230		MOV	#PFAIL,24		;SET UP FOR POWER FAILURE
014574	012767	000340	163174		MOV	#340,PS		
014602	012706	015644			MOV	#STACK,SP		
014606	005067	000360			CLR	TEMP		
014612	005267	000354			INC	TEMP		
014616	001375				BNE	.-4		
014620	104401				TYPE			; 5
014622	014774				MCRLF			; 5
014624	104402				OCTASC			
014626	014650				PFTAB			
014630	104401				TYPE			
014632	014777				MPFAIL			
014634	005067	176732			CLR	ERRFLG		
014640	005067	176772			CLR	LAST		
014644	000177	176730			JMP	#RETRN		
014650	000001			PFTAB:	1			
014652	000006	000002			6,2			
014656	013600				RETRN			

014660				.MSG	↑/DH11 AUTO ECHO TEST/↑/CZDHH-CO/
014660	015	012	012	MTITLE:	.ASCIZ <15><12><12>/DH11 AUTO ECHO TEST /<15><12>
014663	104	110	061		
014666	061	040	101		
014671	125	124	117		
014674	040	105	103		
014677	110	117	040		
014702	124	105	123		
014705	124	040	015		
014710	012	000			
014712	015	012	126	MVECTOR:	.ASCIZ <15><12>/VECTOR ADDRESS-/
014715	105	103	124		
014720	117	122	040		
014723	101	104	104		
014726	122	105	123		
014731	123	055	000		
014734	015	012	103	MREGAD:	.ASCIZ <15><12>/CONTROL REGISTER ADDRESS-/
014737	117	116	124		
014742	122	117	114		
014745	040	122	105		
014750	107	111	123		
014753	124	105	122		
014756	040	101	104		
014761	104	122	105		
014764	123	123	055		
014767	000				
014770	040	040	077	MQM:	.ASCIZ / ?/
014773	000				
014774	015	012	000	MCRLF:	.ASCIZ <15><12>
014777	040	040	120	MPFAIL:	.ASCIZ / POWER FAILURE, PROGRAM RESTART AT TEST IN PROGRESS/
015002	117	127	105		
015005	122	040	106		
015010	101	111	114		
015013	125	122	105		
015016	054	040	120		
015021	122	117	107		
015024	122	101	115		
015027	040	122	105		
015032	123	124	101		
015035	122	124	040		
015040	101	124	040		
015043	124	105	123		
015046	124	040	111		
015051	116	040	120		
015054	122	117	107		
015057	122	105	123		
015062	123	000			
015064	015	012	103	MEPASS:	.ASCIZ <15><12>/CZDHH-CO/
015067	132	104	110		
015072	110	055	103		
015075	060	000			
015077	015	012	120	PASTXT:	.ASCIZ <15><12>/PASS COUNT = /
015102	101	123	123		
015105	040	103	117		
015110	125	116	124		
015113	040	075	040		

015116	000				
015117	015	012	122	MR:	.ASCIZ <15><12>/R/
015122	000				
015123	015	012	124	MTSTPC:	.ASCIZ <15><12>/TEST PC-/
015126	105	123	124		
015131	040	120	103		
015134	055	000			

2
3 015136

.EVEN
.EVEN
.TRPTAB

;TABLE OF POINTERS FOR TRAP DECODING

015136	012232	TRPTAB:	SCOPER
015140	012706		TYPER
015142	013226		OCTASN
015144	012740		INSTRG
015146	013032		INSTRE
015150	013042		PARAMS
015152	012614		SV05P
015154	012654		RS05
015156	012332		SCOP1R

4 015160

.BUFFER

;BUFFERS FOR INPUT-OUTPUT

015160	000000	INBUF:	0
	015172	.+.10	
015172	000000	TEMP:	0
	015204	.+.10	
015204	000000	MDATA:	0
	015216	.+.10	

5 015216

.ERRTAB

;TABLE OF POINTERS TO ERROR MESSAGES AND DATA

015216		ERRTAB:	EM1
6 015216	015232		DT1
7 015220	015414		EM2
8 015222	015267		DT2
9 015224	015426		EM3
10 015226	015343		DT2
11 015230	015426		
12 015232	101	125	124
	117	040	105
015235	103	110	117
015240	040	105	122
015243	122	117	122
015246	015	012	105
015251	130	120	040
015254	040	040	040
015257	040	122	105
015262	103	000	
015265	116	117	116
13 015267	040	105	103
015272	110	117	105

EM1: .ASCIZ /AUTO ECHO ERROR/<15><12>/EXP REC/

EM2: .ASCIZ /NON ECHOED DATA ERROR/<15><12>/EXP REC LINE/

	015300	104	040	104		
	015303	101	124	101		
	015306	040	105	122		
	015311	122	117	122		
	015314	015	012	105		
	015317	130	120	040		
	015322	040	040	040		
	015325	040	122	105		
	015330	103	040	040		
	015333	040	040	040		
	015336	114	111	116		
	015341	105	000			
14	015343	105	103	110	EM3: .ASCIZ /ECHOED DATA ERROR/<15><12>/EXP	REC LINE/
	015346	117	105	104		
	015351	040	104	101		
	015354	124	101	040		
	015357	105	122	122		
	015362	117	122	015		
	015365	012	105	130		
	015370	120	040	040		
	015373	040	040	040		
	015376	122	105	103		
	015401	040	040	040		
	015404	040	040	114		
	015407	111	116	105		
	015412	000				
15					.EVEN	
16	015414	000002			DT1: 2	
17	015416	006	002		.BYTE 6.2	
18	015420	013624			SAVR5	
19	015422	006	000		.BYTE 6.0	
20	015424	013622			SAVR4	
21	015426	000003			DT2: 3	
22	015430	006	002		.BYTE 6.2	
23	015432	013624			SAVR5	
24	015434	006	002		.BYTE 6.2	
25	015436	013622			SAVR4	
26	015440	002	002		.BYTE 2.2	
27	015442	013620			SAVR3	
28	015444				.ENDCOD	
	015444	000000			ENDCOD: 0	
29		000001			.END	

ADRCNT - 013225	ERRTAB 015216	POPRO = 012600	SAVR4 013622	TWRD2 014314
AEACT 013644	ERTAB0 012554	POP1SP= 005726	SAVR5 013624	TWRD3 014316
BEGIN 001306	ESCAPE 013602	POP2SP= 022626	SAVSP 013626	TWRD4 014320
BINWRD 013376	EXITER 012532	PS = 177776	SAV05P= 104406	TWRD5 014322
BITX = 000000	FREEZ1 013604	PUSHRO= 010046	SCOPE = 104400	TWRD6 014324
BIT00 = 000001	HALTS 012512	PUSH1S= 005746	SCOPE1= 104410	TWRD7 014326
BIT01 = 000002	HILIM 013220	PUSH2S= 024646	SCOPE1R 012332	TYPDAT 012472
BIT02 = 000004	ICOUNT 013606	RBUF 014246	SETALL 013426	TYPE = 104401
BIT03 = 000010	INBUF 015160	RCNT0 014350	SPACNT= 013375	TYPER 012706
BIT04 = 000020	INIFLG 013632	RCNT1 014352	STACK = 015644	TYPMSG 012450
BIT05 = 000040	INSTER= 104404	RCNT10 014370	START 001004	T1 001400
BIT06 = 000100	INSTR = 104403	RCNT11 014372	STFLG 013634	T10 003002
BIT07 = 000200	INSTRE 013032	RCNT12 014374	SV05 012622	T11 003160
BIT08 = 000400	INSTRG 012740	RCNT13 014376	SV05P 012614	T12 003336
BIT09 = 001000	INSTR1 012752	RCNT14 014400	SWR 001000	T13 003514
BIT10 = 002000	INSTR2 013040	RCNT15 014402	SW00 = 000001	T14 003672
BIT11 = 004000	K = 000020	RCNT16 014404	SW01 = 000002	T15 004050
BIT12 = 010000	KX = 000020	RCNT17 014406	SW02 = 000004	T16 004226
BIT13 = 020000	LAST 013636	RCNT2 014354	SW03 = 000010	T17 004404
BIT14 = 040000	LIGHTS 001002	RCNT3 014356	SW04 = 000020	T2 001556
BIT15 = 100000	LIMITS 013152	RCNT4 014360	SW05 = 000040	T20 004562
CHRCNT 013374	LINACT 013642	RCNT5 014362	SW06 = 000100	T21 004740
CLRALL 013400	LINBIT 014450	RCNT6 014364	SW08 = 000400	T22 005176
DATA = 000000	LINE = 000020	RCNT7 014366	SW09 = 001000	T23 005434
DATABP 012506	LOBITS 013224	RDCT0 014410	SW10 = 002000	T24 005672
DATAX = 000000	LOGICA 012210	RDCT1 014412	SW11 = 004000	T25 006130
DEVADR 013222	LOLIM 013216	RDCT10 014430	SW12 = 010000	T26 006366
DHBA 013546	LPCNT 013610	RDCT11 014432	SW13 = 020000	T27 006624
DHBAR 013552	MCRLF 014774	RDCT12 014434	SW14 = 040000	T3 001734
DHBC 013550	MDATA 015204	RDCT13 014436	SW15 = 100000	T30 007062
DHBCR 013554	MEPASS 015064	RDCT14 014440	TBUF 013646	T31 007320
DHLPR 013544	MPFAIL 014777	RDCT15 014442	TDAT = 000400	T32 007556
DHNRC 013542	MQM 014770	RDCT16 014444	TEMP 015172	T33 010014
DHRLVL 013564	MR 015117	RDCT17 014446	TKCSR 013530	T34 010252
DHRVEC 013562	MREGAD 014734	RDCT2 014414	TKDBR 013532	T35 010510
DHSCR 013540	MSG 012754	RDCT3 014416	TPCSR 013534	T36 010746
DHSLR 013560	MTITLE 014660	RDCT4 014420	TPDBR 013536	T37 011204
DHSSR 013556	MTSTPC 015123	RDCT5 014422	TRPOK 012574	T4 002112
DHTLVL 013570	MVECTO 014712	RDCT6 014424	TRPSRV 012562	T40 011442
DHTVEC 013566	N = 000001	RDCT7 014426	TRPTAB 015136	T41 011700
DT1 015414	OCTASC= 104402	RESREG 012510	TWRD0 014310	T5 002270
DT2 015426	OCTASN 013226	RESTAR 014546	TWRD1 014312	T6 002446
EM1 015232	PARAM = 104405	RESTR 012220	TWRD10 014330	T7 002624
EM2 015267	PARAMS 013042	RES05 = 104407	TWRD11 014332	VEC1 001164
EM3 015343	PARAM1 013072	RETRN 013600	TWRD12 014334	VEC2 001174
ENDCOD 015444	PARERR 013146	RS05 012654	TWRD13 014336	WRDCNT 013372
ENDFLG 013640	PASARG 012224	SAVPC 013630	TWRD14 014340	X = 000000
EOP 012132	PASCNT 013574	SAVR0 013612	TWRD15 014342	XBIT = 000000
ERRCNT 013576	PASTXT 015077	SAVR1 013614	TWRD16 014344	XLINE = 000020
ERRFLG 013572	PFAIL 014510	SAVR2 013616	TWRD17 014346	XN = 000042
ERRMSG 012470	PFTAB 014650	SAVR3 013620		Y = 000011
ERRCRS 012350				

. ABS. 015446 000
000000 001
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 19200 WORDS (75 PAGES)

DYNAMIC MEMORY AVAILABLE FOR 71 PAGES
CZDHMC.BIN,CZDHMC.SEG-CZDHMC.DOC,DHMACA.MAC,CZDHMC.P11