

## Table of contents

5-	1	INITLN -- Initialize a line
6-	1	NEWUSR -- Start a new time-sharing job
7-	1	STOP -- Stop program execution & enter KMON
8-	1	CLENUP -- Do general cleanup when a job stops
9-	1	CANCPL -- Cancel all pending completion routines
10-	1	LOGOFF -- Log off a job
11-	1	TSXTX -- Trap Handler
14-	1	FPTRPX -- Floating point trap routine
15-	1	CLKRUN -- Clock processing routine
16-	1	CLKDAT -- update time of day and date
17-	1	CLKJOB -- check time slice job status
18-	1	CLK01S -- 0.1 second clock processing
19-	1	CLKIOH -- See if we need to cancel I/O hold timers
20-	1	CHKPRT -- See if we need to print Professional screen
21-	1	WAKEUP -- 0.5 second processing for sleeping users
22-	1	CKTWAT -- Check on jobs doing .TWAIT waits
24-	1	CKMRKT -- check mark-time requests
25-	1	CLKSCR -- Execute completed system mark-time requests
26-	1	CLKPM -- accumulate performance monitoring data
27-	1	CKSCHD -- Check jobs and schedule
28-	1	CLKABD -- Clock processing for autobaud logic
29-	1	TLCHK -- Check Dial-up line status
30-	1	CLKPHN -- Do timer driven checks of dial-up lines
31-	1	DLGDSS -- Get data set status for DL11 line
32-	1	DLSDSS -- Set data set status for DL11 line
33-	1	DLSBRK -- Control break transmission for a DL11 line
34-	1	DLSSPD -- Set transmission speed for DL11 line
35-	1	DZGDSS -- Get data set status for DZ11 line
36-	1	DZSDSS -- Set data set status for a DZ11 line
37-	1	DZSBRK -- Control break transmission for a DZ11 line
38-	1	DZSSPD -- Set transmission speed for a DZ11 line
39-	1	DHGDSS -- Get data set status for a DH11 line
40-	1	DHSDSS -- Set data set status for a DH11 line
41-	1	DHSSPD -- Set transmit/receive speed for DH11 line
42-	1	DHSBRK -- Control break transmission for a DH11 line
43-	1	VHGDS
44-	1	VHSDSS -- Set data set status for a DHV11 line
45-	1	VHSSPD -- Set transmit/receive speed for a DHV11 line
46-	1	VHSBRK -- Control break transmission for a DHV11 line
47-	1	DLCLOK -- Timer driven routine for DL11 lines
48-	1	DZCLOK -- Timer driven routine for DZ11 lines
49-	1	DHCLOK -- Timer driven routine for DH11 lines
50-	1	SYS DIE -- Fatal system halt
52-	1	EXCINI -- Final system initialization
53-	1	INISPD -- Initialize time-sharing line speeds
54-	1	INSINI -- Initialize installed program table

```
1 .TITLE TSEXC2 -- Misc. TSX-Plus Executive Routines
2 .ENABL LC
3 .ENABL AMA
4 .DSABL GBL
5 000000
6 000000 021440 .CSECT TSEXC2
TSEXC2: .RAD50 /EX2/
7
8
9 ;----- TSEXC2 is a TSX-Plus virtual system overlay containing misc. routines.
10
11 ; Copyright (c) 1980, 1981, 1982, 1983, 1984, 1985, 1986, 1987, 1988.
12 ; S&H Computer Systems, Inc.
13 ; Nashville, Tennessee USA
14
15 ; All rights reserved
16
17
18 ;----- Global definitions
19
20 .GLOBL LOGOFF, TRPCOM, TSXTX, FPTRPX, EXCINI, NSIP
21 .GLOBL SYSDIE, ABORT, STOP, NEWUSR, TRPBPT
22 .GLOBL INITLN, CLKRUN, DZSSPD, DLSBRK, DZSBRK
23 .GLOBL DLGDSS, DLSDSS, DZGDSS, DZSDSS, DHGDSS, DHSDSS
24 .GLOBL DLCLOK, DZCLOK, VHGDSS, VHSDSS, DLSSPD
25 .GLOBL DHSSPD, VHSSPD, DHSBRK, VHSBRK, DHCLOK, VHCLOK
26
27 ;----- Global references
28
29 .GLOBL R$SWPC, C. NUMQ, VUSPHN, $RDSAV, DOTRMP, $GEMAR, R$CFST, CFPSAV
30 .GLOBL LSW11, $PWKEY, AF$NPW, LNSPAC, SUCF2, IB$SF2, IB$IJ, SPIJ
31 .GLOBL LTTCR, EMTBLK, AF$DUP, AF$IND, AF$UCL, AF$SET, LCXTBL
32 .GLOBL CINFLG, DIEARG, DIEMSG, DIEPC, DIESP, VSYDMP, DODUMP, SYSHL1
33 .GLOBL VPAR5, TRPAR5, VDMKTP, DMPOVL, DMPHND, DMPTXT, PLSINI
34 .GLOBL VSWPSL, SWPJOB, SWPPOS, SLTSIZ, CSHDEV, CSHDVN
35 .GLOBL $DETCH, LSW, $DILUP, LOTSPC, LOTSIZ, CDSSPD, $DHCD0
36 .GLOBL LSTPL, PVON, LNPRIM, LINSWT, LSECPT, MAXSEC, NUMON, NEDCLO
37 .GLOBL PO$SPV, PO$NAM, PO$SYS, PO$BYP, LPARNT, CL$EPS
38 .GLOBL PO$DBG, SYNAME, PO$MEM, PO$LOK, II$PRV, PO$NFR, PO$NFW
39 .GLOBL INSTBL, INSTBN, II$$SZ, II$NAM, II$FLG, II$NPV, AF$PLK
40 .GLOBL AF$SCA, AF$NOW, AF$HIE, AF$NOI, AF$IDP, AF$MEM, AF$BYA
41 .GLOBL LNMAP, $DISCN, FORCEX, LBASE, LNBLKS, VH$LCR, CLTOTL
42 .GLOBL LP$SPD, LP$7BT, LP$PAR, LP$ODD, SYSXIT, VDBFLG, CXBOWN
43 .GLOBL DZ$LEN, DZ$BBT, DZ$7BT, DZ$PAR, DZ$ODD, SP$LNK
44 .GLOBL HF$LEN, HF$BBT, HF$7BT, HF$PAR, HF$ODD, WINREL
45 .GLOBL VF$LEN, VF$BBT, VF$7BT, VF$PAR, VF$EVN, KMONCE, VMNUAO
46 .GLOBL $AUTO, S9600, $NABRS, SETSPD, LABTIM, PIDPTR, $CTRL0, CSHFIN
47 .GLOBL MXTYPE, CDX$DZ, INTMX1, VF$RIE, VF$TIE, VH$CSR, MH$SCR, FP$IOF
48 .GLOBL HF$TSB, MH$LPR, MH$BRK, VF$SC, VH$LPR, VF$BC, $NOUCR, JOBCCB
49 .GLOBL FRKINI, FQ$$SZ, NUMFRK, FRKGEN, FREFRK, FQ$LNK, SCHED, NPCCB
50 .GLOBL LMEMIN, DEQ, LSW2, LSW4, LSW5, $1STLG, LSW6, $CARUP, TOTON, PMUSER
51 .GLOBL PMRUN, SS, CORUSR, EXEC, JCDB, LSW7, CANIOT, S150, LIOHLD, NSCP
52 .GLOBL UMODE, INTLVL, UTRPAD, CHKABT, UPMODE, UFPTRP, CW$FPU, SCPFHD
53 .GLOBL CONFIG, TRRDY, CTTSR, CTTBR, $DBGMD, $NOLF, LCXPART, $RNMLK
54 .GLOBL FREIOQ, NUMIOQ, IOQSIZ, QLINK, USRINI, LSW9, $SUCF, SYPNCR
55 .GLOBL LSTMX, MXLNT, LSTPL, LMXNUM, MXLNT, CDCLOK, LCDTYP, LINSIZ
56 .GLOBL SNMSHD, NMSNMB, SB$$SZ, SB$LNK, CLKINT, $CARMN, LINSPC, SP$$SZ
57
```

```

58      . GLOBL $START, ILSW2, $DEAD, $PHONE, FSTDL, LSTDL, LSUCF, $TDEAD
59      . GLOBL INITFL, LSW3, PSW, INTPRI, SYSHLT, CHKUSP, MSGABT, CFACFL, $CFABT
60      . GLOBL $INKMN, ABRTAD, ABRTCD, STOP, LMXLN, OVRHC, MAPUSR, MONABT
61      . GLOBL $INIT, LQUAN, LJSW, LINBUF, LINNXT, LSTACT, LINPNT, LINCNT
62      . GLOBL LOTBUF, LOTNXT, LOTPNT, LACTIV, $LOFCF, CSHALC, NUMCCB, CCBHD
63      . GLOBL LCOL, LAFSIZ, LPROJ, LPROG, LSCCA, LBRKCQ, LBRKCH, LCPUHI
64      . GLOBL LCPULO, LCONTM, LINCUR, KPAR6, CURRDB, RPAR, RPDR, CXTRMN
65      . GLOBL VECBAS, MVWDS, ITRMTP, LTRMTP, MSGINI, VMAXMC, S$HICP, KILJOB
66      . GLOBL $CTRLS, $VNOTT, SPLINI, NSPLDV, LOKINI, VMXSF, LITIME, QNSPND
67      . GLOBL SETMAP, DFJMEM, MAXMEM, EMTCAD, EMTRAD, RCBBAS, RCBEND, PLSXIT
68      . GLOBL SPCPS, JSTKND, JSTK, EMTLEV, UERSEV, $DOOFF, $NOIN, ERRLOC
69      . GLOBL VSWPFL, KMNTOP, KMNBSAS, SUTOP, UHIMEM, JSWLOC, R$CH17
70      . GLOBL KMNCHN, CSIARE, KMNSTKM, LQUAN, KMNSTR, $CTRLC, LSLEPH, LSLEPL
71      . GLOBL LSPND, $IDMAP, $MILOCK, LRDTIM, IOHALT, IOSTOP, RTSTOP
72      . GLOBL USRJOB, FREUSR, FRESPD, CANMKT, QFREE, LCMPL, CQ$LNK
73      . GLOBL CLSCDB, HF$TIE, HF$RIE, DLSTRT, DZSTRT, CQ$CP
74      . GLOBL LNSBLK, RCBBAS, RCBEND, FREMEM, VPLAS, TRNSTR, $HARD
75      . GLOBL CXTPAG, KMNPGS, LIOCNT, VPRIDF, LBSPRI, LPRI, LSTHL
76      . GLOBL LHIPCT, QHIPRI, INVEC, INRECV, RSR, STPFLG, $VIRJB
77      . GLOBL RING, TRMRDY, MXRING, MXDTR, CARDET
78      . GLOBL MXCAR, RCVDON, $IITIM, RDINT, RDONE, MXCSR, RIE, NEDCDO, NEDCDI
79      . GLOBL $XCHAR, LOGCHR, LOGCR, LOGFLG, LF$IN, FPUUSE, $MAPOK, R$MFMV
80      . GLOBL SPSTAT, SS$RUN, SS$PRT, LPRG1, LPRG2, $NOABT
81      . GLOBL CURVC, SYSDAT, LSTATE, LSTSL, SWPCOT, DOSCHD, $INWT, $FPUEX
82      . GLOBL LRTCHR, MRKTHD, CQ$LNK, $IOWT, PMBASE, PMTOP, PMNBPC, VPAR6
83      . GLOBL PMPAR, $SOTFN, $OTFN, $DEFER, $DODFR, $GCECD, $OTLO, NEDSOT
84      . GLOBL CLKRUN, TIKCNT, CLKCNT, LCPULO, LCPUHI, TK1VAL, CQ$JOB
85      . GLOBL TK1CNT, TK5CNT, SYTIML, SYTIMH, DATIML, DATIMH, JM$LNK
86      . GLOBL $DHBF1, $DHBF2, LSW10, VF$RIE, HF$RIE
87      . GLOBL VONTM, VOFFTM, VTMOUT, VTMIN, VTMLOC, LOFFTM, LCDTIM
88      . GLOBL VMXWIN, WININI, RDAR, RDDR
89      . GLOBL LMING, MINCTR, MINTIM, DTLX, UIOCNT, STRACT, $DEBUG
90      . GLOBL VPRIHI, VPRILO, VQUANO, VQUAN3, $SGQ0, $SGQ3, LCLUNT
91      . GLOBL TMTTOTL, TMTOTH, TMIOI, TMIOH, INBSY, OUTBSY, DBGTRP
92      . GLOBL TMSWPL, TMSWPH, TMUSR, TMUSRH, TMIOWL, TMIOWH
93      . GLOBL TMSWTL, TMSWTH, TMIDL, TMIDLH, SYSHLT, GETMEM, EMTCAS
94      . GLOBL $$$$HIP, $$$RT, $TMWT, $TWFN, CQ$PRI, $OITIM
95      . GLOBL VQUAN1, VQUN1A, VQUAN2, QCPU, MBFFLG, UREGO, $WSMB
96      . GLOBL LSLEPL, LSLEPH, ENQTL, QCOMPL, VQUN1B, MONFQH, VMXMON, JM$$SZ
97      . GLOBL CQ$HOT, CQ$LOT, CQ$LNK, CQ$RNS, CSHINI, FRKPRI
98      . GLOBL PF$SYS, PF$IOW, PF$OVF, CLKPS, CLKPC, CURCP, SHRRCB, SHRCN
99      . GLOBL PMFLGS, UMODE, LEMTPC, $INCOR, EM$DTL, CP$STD
100     . GLOBL LITIME, VINTIO, VQUN1C, QUNSIG, MS$BRK, TRBRK
101     . GLOBL LSW8, $SGQ1, $SGQ1A, $SGQ1B, $SGQ1C, $SGQ2
102     . GLOBL CC$$SZ, CC$LNK, CXTBAS, CXTWDS, PCCR2, PROFLG
103     . GLOBL CDGDSS, CDSDSS, MS$DTR, MS$CAR, MS$RNG, PROODC, PLSOFF
104     . GLOBL CDX$VH, VH$CSR, VH$LSR, VH$LCR, $DBGPK
105     . GLOBL VF$RNG, VF$DCD, VF$DTR, D.FLAG, D$RUN
106     . GLOBL MF$LIN, DM$CSR, DM$LSR, MF$RNG, MF$CAR, MF$DTR
107     . GLOBL FP$CK1, FRKGET, FORKQ, FQ$PRI, FQ$RTN
108     . GLOBL CDIRTN, CDIFLG, FP$CDI, CDORTN, CDOFLG, FP$CDO
109     . GLOBL TSR, MXBRK, LMXPRM, MXLPR, MXSBRK, FREEXT
110     . GLOBL OVRADD, O. ADR, O. PAR, NUMDEV, HANPAR, PNAME
111     . GLOBL $UDSPC, SR3FLG, USDSPC, SR3MMR
112
113
114
;
```

-----  
; Symbolic equates

115		:			
116	000015	CR	=	15	:Carriage-return
117	000012	LF	=	12	:Line-feed
118	000007	BELL	=	7	:Bell

```
1 ;-----  
2 ; Macro calls  
3 ;  
4 ; . MCALL . READW, . PURGE  
5 ;-----  
6 ; Macro definitions  
7 ;  
8 ; Macro to call a routine in another system overlay.  
9 ;  
10; . MACRO OCALL ENTADD  
11; . IF B, ENTADD  
12; ; . ERROR ; OCALL without entry address  
13; . ENDC  
14; CALL OVRHC ; call the low-core overlay handler  
15; . WORD ENTADD  
16; . ENDM OCALL  
17;  
18 ; Macro to disable interrupts  
19 ;  
20; . MACRO DISABL  
21; BIS #340, @#PSW  
22; . ENDM DISABL  
23;  
24 ; Macro to enable interrupts  
25 ;  
26; . MACRO ENABL  
27; BIC INTPRI, @#PSW  
28; . ENDM ENABL  
29;  
30 ; Macro to print an error message when a system crash occurs.  
31 ;  
32 ; Arguments:  
33 ; MSG = Name of error message to print.  
34 ; ARG = (Optional) argument value to display with error message.  
35 ;  
36 ; . MACRO DIE MSG, ARG  
37; MOV MSG, @#DIEMSG  
38; . IF NB, ARG  
39; MOV ARG, @#DIEARG  
40; . ENDC  
41; CALL @#SYSHLT  
42; . ENDM DIE  
43;  
44 ; Macro to define a system abort error message  
45 ;  
46 ; . MACRO SATXT NAME, TEST  
47; . GLOBL EM$'NAME  
48; EM$'NAME = . - DIEBAS  
49; . ASCIZ \'NAME'-'TEST'\  
50; . ENDM SATXT  
51;
```

```

1 ; -----
2 ; Fatal system abort error messages:
3 ;
4 ; .NLIST BEX
5 DIEBAS:
6 SATXT DTL,<Demonstration system time limit reached>
7 SATXT FRK,<No free FORK blocks>
8 SATXT JMO,<Jump occurred to location 0>
9 SATXT KRE,<KMON read error>
10 SATXT KTP,<Kernel mode trap>
11 SATXT LMF,<Job lock mem failure>
12 SATXT MIO,<Need to increase value of MIONWBI sysgen parameter>
13 SATXT MPR,<Memory parity error>
14 SATXT NQE,<Ran out of free I/O queue elements>
15 SATXT NSP,<No free swap command packets>
16 SATXT PFT,<Power-fail trap>
17 SATXT RIT,<Trap in real-time interrupt service routine>
18 SATXT SFO,<Job swap file overflow>
19 SATXT SIE,<Swap file I/O error>
20 SATXT SSE,<PLAS region swap file I/O error>
21 SATXT SJN,<Job # 0 at STOP>
22 SATXT UEI,<Interrupt occurred at unexpected location>
23 SATXT SOF,<Stack overflow>
24 ;
25 ; Other related text strings.
26 ;
27 001056 015 012 012 TXFSE: .ASCII <CR><LF><LF><BELL>/?TSX-F-Fatal system error at /<200>
28 001120 101 162 147 TXARG: .ASCII /Arg. value = /<200>
29 001136 000 TXNULL: .BYTE 0
30 001137 120 101 122 TXPAR5: .ASCII /PAR5 value = /<200>
31 001155 123 145 147 TXSEG: .ASCII /Seg. value = /<200>
32 001173 117 166 145 TXOID: .ASCII /Overlay: /<200>
33 001205 104 145 166 TXDEV: .ASCII /Device name: /<200>
34 001223 123 120 040 SPTXT: .ASCII /SP at time of crash = /<200>
35 .EVEN
36 ;
37 ; Line select bits for a DH11 mux.
38 ;
39 001252 000001 000002 000004 DHLBIT: .WORD 1,2,4,10,20,40,100,200,400
40 001274 001000 002000 004000 .WORD 1000,2000,4000,10000,20000,40000,100000
41 ;
42 ; Line select bits for DZ11 mux.
43 ;
44 001312 001 002 004 MXLBIT: .BYTE 1,2,4,10,20,40,100,200
45 ;
46 ; Number of days in each month
47 ;
48 001322 037 034 037 MONDAY: .BYTE 31.,28.,31.,30.,31.,30.,31.,30.,31.
49 ;.EVEN
50 001336 000000 FORKIT: .WORD 0 ;Flag to create fork process
51 001340 0000000 PROTIM: .WORD PROODC ;Call PI driver after this many ticks
52 001342 177777 TIKO1S: .WORD -1 ;# pending 0.1 second clock ticks
53 001344 063337 R50PRO: .RAD50 /PRO/
54 001346 063344 R50PRT: .RAD50 /PRT/
55 001350 073376 R50SAV: .RAD50 /SAV/
56 ;
57 ; Table to convert normal TSX-Plus speed codes into DH11 speed codes

```

```
58
59 001352    001    002    003    ; DHSPCT: .BYTE 1,2,3,4,5,7,10,11,12,0,13,0,14,0,15,16
60
61
62
63 001372    000    001    002    ; Table to convert normal TSX-Plus speed codes into DHV11 speed codes
64          ; VHSPCT: .BYTE 0,1,2,3,4,5,6,7,10,11,12,0,13,14,15,16
               .EVEN
```

```

1 ; -----
2 ; Table of programs that have automatic switch assignment when they
3 ; are started by TSKMON. The following flags may be specified following
4 ; the program name words:
5 ;
6 ; AF$NOW = Allow non-wait .TTYIN operation.
7 ; AF$HIE = Run program in high-efficiency mode.
8 ; AF$NOI = Run program in non-interactive mode.
9 ; AF$IOP = Map user PAR 7 to I/O page (requires operator priv. )
10 ; AF$SCA = Enable single character activation.
11 ; AF$MEM = Lock program in low memory.
12 ; AF$PLK = RUN/LOCK program
13 ; AF$DBG = RUN/DEBUG program
14 ; AF$BYA = Bypass user ASSIGNS
15 ; AF$TPO = Use transparent terminal output
16 ; AF$DUP = Program is DUP
17 ; AF$IND = Program is IND
18 ; AF$UCL = Program is TSXUCL
19 ; AF$SET = Program is SETUP
20 ; AF$CCA = Suppress ctrl-C abort
21 ; AF$NPW = No windows during program
22 ;
23 ; Each program entry must consist of two words containing the 6 character
24 ; program name followed by a word with the flags.
25 ;
26     000000          NSIP = 0           ;No system installed programs yet
27 001412 016130 000000      SRPPRG:   . RAD50 /DUP /
28 001412 000000G             . WORD AF$DUP
29 001416 000000G             . WORD 0
30 001420 000000             NSIP = NSIP+1
31 000001                   . RAD50 /IND /
32 001422 035164 000000      . WORD AF$NOW!AF$IND
33 001426 000000C             . WORD 0
34 001430 000000             NSIP = NSIP+1           ;Count another system program
35 000002                   . RAD50 /KED /
36 001432 042614 000000      . WORD AF$SCA!AF$HIE!AF$NOW
37 001436 000000C             . WORD 0
38 001440 000000             NSIP = NSIP+1           ;Count another system program
39 000003                   . RAD50 /KEX /
40 001442 042640 000000      . WORD AF$SCA!AF$HIE!AF$NOW
41 001446 000000C             . WORD 0
42 001450 000000             NSIP = NSIP+1           ;Count another system program
43 000004                   . RAD50 /K52 /
44 001452 045130 000000      . WORD AF$SCA!AF$HIE!AF$NOW
45 001456 000000C             . WORD 0
46 001460 000000             NSIP = NSIP+1           ;Count another system program
47 000005                   . RAD50 /LOGON /
48 001462 046537 057760      . WORD AF$PLK!AF$BYA
49 001466 000000C             . WORD +1,PO$SPV!PO$NAM!PO$SYS!PO$BYP
50 001470 000001 000000C       . WORD 0
51 001474 000000             NSIP = NSIP+1           ;Count another system program
52 000006                   . RAD50 /PATCH /
53 001476 062074 012000      . WORD AF$SCA
54 001502 000000G             . WORD 0
55 001504 000000             NSIP = NSIP+1           ;Count another system program
56 000007                   . RAD50 /SETUP /
57 001506 073634 102700

```

58 001512 000000C		. WORD	AF\$IOP!AF\$SET	
59 001514 000000		. WORD	0	
60 001516 000010	NSIP	=	NSIP+1	; Count another system program
61 001516 075273 051646		. RAD50	/SYSMON/	
62 001522 000000		. WORD	0	
63 001524 000001 000000G		. WORD	+1, PO\$MEM	
64 001530 000000		. WORD	0	
65 000011	NSIP	=	NSIP+1	; Count another system program
66 001532 076713 056700		. RAD50	/TECO /	
67 001536 000000C		. WORD	AF\$SCA!AF\$NOW	
68 001540 000000		. WORD	0	
69 000012	NSIP	=	NSIP+1	; Count another system program
70 001542 077721 055176		. RAD50	/TRANSF/	
71 001546 000000C		. WORD	AF\$SCA!AF\$NOI!AF\$NOW!AF\$NPW	
72 001550 000000		. WORD	0	
73 000013	NSIP	=	NSIP+1	
74 001552 077771 103150		. RAD50	/TSAUTH/	
75 001556 000000G		. WORD	AF\$BYA	
76 001560 000000		. WORD	0	
77 000014	NSIP	=	NSIP+1	; Count another system program
78 001562 100020 101704		. RAD50	/TSXUCL/	
79 001566 000000G		. WORD	AF\$UCL	
80 001570 000000		. WORD	0	
81 000015	NSIP	=	NSIP+1	
82 001572 106243 057710		. RAD50	/VTCOM /	
83 001576 000000C		. WORD	AF\$SCA!AF\$NOW!AF\$MEM	
84 001600 000001 000000G		. WORD	+1, PO\$LOK	
85 001604 000000		. WORD	0	
86 000016	NSIP	=	NSIP+1	; Count another system program
87 001606	SRFEND:			; End of special program flag list

INITLN -- Initialize a line

```

1          .SBTTL INITLN -- Initialize a line
2
3          ;-----  

4          ; INITLN is called to initiate (logon) a line.  

5          ; It initializes a number of line control tables and then places  

6          ; the line in a high-priority execution state.  

7          ; If the system is generated with job swapping turned off (SWAPFL=0)  

8          ; a check is made to see if there is sufficient free memory available  

9          ; for the job before it is initiated. If there is not enough free memory  

10         ; available, the job is not initiated.  

11         ;  

12         ; Inputs:  

13         ; R1 = Number of line to be initiated  

14         ; R0 = Pointer to I/O queue element with name of secondary  

15         ;      start-up command file for the job (0=none).  

16         ;  

17         ; Outputs:  

18         ; C-flag set if swapping is disabled and there is insufficient free  

19         ; memory space available to start job.  

20         ; The queue element with the secondary start-up command file name is  

21         ; freed if the job cannot be started. Otherwise it is freed after the  

22         ; job is initialized.  

23 001606 010246           INITLN: MOV      R2,-(SP)
24 001610 010346           MOV      R3,-(SP)
25 001612 010003           MOV      R0,R3      ;Get pointer to Q element with CF name
26
27         ; Never start a line that is being used as a CL unit
28
29 001614 005761 0000000G   TST      LCLUNT(R1)    ; Is this a CL line?
30 001620 002176           BGE      9$        ; Br if yes
31
32         ; See if we are constrained by max # jobs allowed to be on
33
34 001622 020127 0000000G   CMP      R1,#LSTPL   ; Is this a primary line?
35 001626 101016           BHI      4$        ; Br if not, no limits on virtual or detached
36 001630 105737 0000000G   TSTB     KMONCE    ; Is first job done initializing?
37 001634 001013           BNE      4$        ; Br if not, VMNUAO not set up yet
38 001636 113700 0000000G   MOVB     VMNUAO,R0  ; Get max # jobs allowed to be on
39 001642 042700 177400     BIC      #^C377,R0  ; Mask out any sign extension
40 001646 012702 000123     MOV      #123,R2   ; Set for XOR
41 001652 074200           XOR      R2,R0    ; Decrypt max # jobs allowed on
42 001654 001403           BEQ      4$        ; Br if no limit on # logged on jobs
43 001656 123700 0000000G   CMPB     NUMON,R0  ; Max # jobs already logged on?
44 001662 103155           BHIS     9$        ; Br if yes
45
46         ; Initialize some line control tables
47
48 001664 005061 0000000G   4$:    CLR      LSW(R1)    ; Reset job status flags
49 001670 005061 0000000G   CLR      LNBLKS(R1)  ; JOB HAS NO ASSIGNED MEMORY NOW
50 001674 005061 0000000G   CLR      LIOCNT(R1)  ; JOB HAS NO ACTIVE I/O
51 001700 005061 0000000G   CLR      LCMPL(R1)   ; JOB HAS NOT PENDING COMPLETION ROUTINES
52
53         ; Determine how much memory the line needs to be initiated.
54
55 001704 013700 0000000G   MOV      DFJMEM,RO  ; GET DEFAULT # KB FOR JOB
56 001710 006300           ASL      RO        ; CVT TO # PAGES
57 001712 063700 0000000G   ADD      CXTPAG,RO  ; ADD # PAGES NEEDED FOR JOB CONTEXT BLOCK

```

INITLN -- Initialize a line

```

58 001716 020037 000000G           CMP    R0, KMNPGS      ;COMPARE TO # PAGES NEEDED TO RUN KMON
59 001722 103002 000000G           BHIS   1$              ;BR IF JOB SPACE > KMON SIZE
60 001724 013700 000000G           MOV    KMNPGS, R0     ;MUST HAVE AT LEAST ENOUGH MEMORY FOR KMON
61
62
63
64
65 001730 010061 000000G           1$:   MOV    R0, LMEMIN(R1)  ;SET # MEMORY PAGES NEEDED FOR JOB
66 001734 105737 000000G           TSTB   VSWPFL        ;IS THIS A SWAPPING SYSTEM?
67 001740 001010 000000G           BNE   3$              ;BR IF YES
68 001742 010061 000000G           MOV    R0, LNBLKS(R1)  ;SET SIZE OF ROOT OF JOB REGION
69 001746 004737 000000G           CALL   GETMEM        ;TRY TO ALLOCATE MEMORY FOR THIS JOB
70 001752 103521 000000G           BCS   9$              ;BR IF NOT ENOUGH MEMORY AVAILABLE
71 001754 052761 000000G 000000G  BIS    ##INCOR, LSW(R1)  ;SET FLAG SAYING JOB IS IN MEMORY
72
73
74
75 001762 016102 000000G           3$:   MOV    LINBUF(R1), R2  ;SET UP INFO ABOUT INPUT BUFFER
76 001766 010261 000000G           MOV    R2, LINNXT(R1)
77 001772 010261 000000G           MOV    R2, LSTACT(R1)
78 001776 010261 000000G           MOV    R2, LINPNT(R1)
79 002002 016161 000000G 000000G  MOV    LINSIZ(R1), LINSPC(R1)
80 002010 005061 000000G           CLR    LINCNT(R1)
81 002014 052761 000000G 000000G  BIS    ##$DILUP, LSW(R1)  ;REMEMBER LINE IS ACTIVE
82 002022 052761 000000G 000000G  BIS    ##$NOIN, LSW3(R1)  ;DON'T ACCEPT TT CHARS FOR LINE YET
83 002030 012761 000000G 000000G  MOV    ##$SUCF, LSW9(R1) ;Say we are in startup command file
84 002036 012761 000000G 000000G  MOV    ##$PWKEY, LSW11(R1); Initialize LSW11
85 002044 113761 000000G 000000G  MOVB   VPRIDF, LBSPRI(R1); SET BASE PRIORITY FOR JOB
86 002052 113761 000000G 000000G  MOVB   VPRIDF, LPRI(R1); SET CURRENT PRIORITY FOR JOB
87 002060 013761 000000G 000000G  MOV    VINTIO, LHIPCT(R1); INIT HIGH-PRIORITY HITS FOR JOB
88 002066 013761 000000G 000000G  MOV    VQUAN1, LITIME(R1); SET INTERACTIVE JOB TIME SLICE
89 002074 010361 000000G           MOV    R3, LPROJ(R1)   ;Store ptr to command file buffer in LPROJ
90
91
92
93
94 002100 020127 000000G           CMP    R1, #LSTPL      ;Is this a primary line?
95 002104 101023 000000G           BHI    2$              ;Br if not
96 002106 005061 000000G           CLR    LOFFTM(R1)     ;Don't have to time logoff time any more
97 002112 042761 000000G 000000G  BIC    ##$CARMN, LSW5(R1); Assume we do not need to monitor carrier
98 002120 032761 000000G 000000G  BIT    ##$PHONE, ILSW2(R1); Is this a dial-up line?
99 002126 001412 000000G           BEQ    2$              ;Br if not
100 002130 013761 000000G 000000G  MOV    VTMLOC, LCDTIM(R1) ;Give local line this long to raise carrier
101 002136 032761 000000G 000000G  BIT    ##$CARUP, LSW3(R1); Is carrier up now?
102 002144 001403 000000G           BEQ    2$              ;Br if not
103 002146 052761 000000G 000000G  BIS    ##$CARMN, LSW5(R1); Set flag saying to monitor carrier
104
105
106
107 002154 004737 000000G           2$:   CALL   QHIPRI       ;PUT JOB IN HIGH PRIORITY STATE
108
109
110
111 002160 105237 000000G           INCB   TOTON        ;Total number of logged on jobs
112 002164 020127 000000G           CMP    R1, #LSTPL      ;Is this a primary line?
113 002170 101003 000000G           BHI    5$              ;Br if not
114 002172 105237 000000G           INCB   NUMON        ;Count another real line on

```

## INITLN -- Initialize a line

```
115 002176 000403          BR      6$  
116 002200 020127 000000G  5$:    CMP     R1,#LSTDL    ; Is this a virtual line?  
117 002204 101402          BLOS    8$  
118 002206 105237 000000G  6$:    INCB    PVON     ;Br if not  
119  
120  
121  
122 002212 000241          ; Successful finish  
123 002214 000407          B$:    CLC     ;Signal successful return  
124  
125  
126  
127  
128 002216 010146          9$:    MOV     R1,-(SP)   ;Save job number  
129 002220 010301          MOV     R3,R1    ;Get pointer to Q element  
130 002222 001402          BEQ     11$    ;Br if no Q element to free  
131 002224 004737 000000G  CALL    QFREE   ;Free the Q element  
132 002230 012601          11$:   MOV     (SP)+,R1  ;Restore job number  
133 002232 000261          SEC     ;Signal failure on return  
134  
135  
136  
137 002234 012603          10$:   MOV     (SP)+,R3  
138 002236 012602          MOV     (SP)+,R2  
139 002240 000207          RETURN
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 6  
NEWUSR -- Start a new time-sharing job

```
1 .SBTTL NEWUSR -- Start a new time-sharing job
2 ;
3 ; Do initialization for start-up of a new job.
4 ;
5 002242 NEWUSR:
6 ;
7 ; Initialize LSW tables.
8 ;
9 002242 052761 000000G 000000G      BIS    #$/INIT,LSW(R1) ; SAY JOB INITIALIZATION IS BEING DONE
10 002250 005061 000000G      CLR    LQUAN(R1)   ; INITIALIZE JOB'S TIME QUANTUM
11 002254 005061 000000G      CLR    LJSW(R1)   ; JOB STATUS WORD
12 002260 005061 000000G      CLR    LSW7(R1)
13 002264 005061 000000G      CLR    LSW8(R1)
14 002270 005061 000000G      CLR    LNSBLK(R1) ; NO SPACE FOR ANY PLAS REGIONS
15 002274 012761 000000G 000000G      MOV    #$/INKMN,LSW4(R1); START OUT RUNNING KMON
16 002302 016102 000000G      MOV    LOTBUF(R1),R2 ; SET UP INFO ABOUT OUTPUT BUFFER
17 002306 010261 000000G      MOV    R2,LOTNXT(R1)
18 002312 010261 000000G      MOV    R2,LOTPNT(R1)
19 002316 016161 000000G 000000G      MOV    LOTSIZ(R1),LOTSPC(R1)
20 002324 005061 000000G      CLR    LACTIV(R1) ; SAY NO ACTIVATION CHARS RECEIVED YET
21 002330 005061 000000G      CLR    LCOL(R1)
22 002334 005061 000000G      CLR    LAFSIZ(R1) ; NO ACTIVATION FIELD SIZE
23 002340 005061 000000G      CLR    LPROG(R1)  ; OR PROGRAMMER NUMBER
24 002344 005061 000000G      CLR    LSCCA(R1) ; NO .SCCA DONE YET
25 002350 005061 000000G      CLR    LBRKCQ(R1) ; NO BREAK KEY CONNECTION
26 002354 005061 000000G      CLR    LBRKCH(R1) ; CLEAR BREAK CHARACTER
27 002360 005061 000000G      CLR    LTTCR(R1) ; No TT activation completion routine
28 002364 005061 000000G      CLR    LCPUHI(R1) ; CLEAR RUN-TIME ACCUMULATOR
29 002370 005061 000000G      CLR    LCPULO(R1)
30 002374 005061 000000G      CLR    LCONTM(R1) ; CLEAR CONNTECT-TIME
31 002400 005061 000000G      CLR    LINCUR(R1)
32 ;
33 ; Map kernel mode PAR 6 to job context block.
34 ;
35 002404 016137 000000G 000000G      MOV    LCXPAR(R1),@#KPAR6; MAP KERNEL PAGE 6 TO CONTEXT BLOCK FOR JOB
36 ;
37 ; Zero the job's context block
38 ;
39 002412 012702 000000G      MOV    #CXTBAS,R2 ; Get address of base of context area
40 002416 013703 000000G      MOV    CXTWDS,R3 ; Get # words in context area
41 002422 006203          ASR    R3   ; Get # of doublewords
42 002424 005022          7$:   CLR    (R2)+ ; Clear first word of pair
43 002426 005022          CLR    (R2)+ ; Clear second word of pair
44 002430 077303          SOB    R3,7$ ; Loop if more doublewords left to clear
45 002432 032737 000001 000000G      BIT    #1,CXTWDS ; Is there an odd word at end to clear?
46 002440 001401          BEQ    B$   ; Br if not
47 002442 005012          CLR    (R2)  ; Clear last word of context block
48 ;
49 ; Initialize some cells in job context block
50 ;
51 002444 012737 177777 000000G B$:   MOV    #-1,EMTLEV ; Say job is not executing an EMT
52 002452 012737 000000G 000000G      MOV    #EMTCAS,EMTCAD ; Say completion routine return stack is empty
53 002460 012737 123456 000000G      MOV    #123456,JSTKND ; Set value used to check for stack overflow
54 ;
55 ; Set up simulated RMON fixed offset table.
56 ;
57 002466 013702 000000G      MOV    CXTRMN,R2 ; Get addr of RMON in job context area
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 6-1  
NEWUSR -- Start a new time-sharing job

```
58 002472 012703 000000G      MOV    #VECBAS,R3      ;POINT TO SYSTEM CHANNEL BLOCK
59 002476 012700 000000G      MOV    #MVWDS, R0      ;GET # WORDS TO MOVE
60 002502 012322              4$:   MOV    (R3)+, (R2)+   ;SET UP JOB'S SIMULATED RMON IN CONTEXT BLK
61 002504 077002              SOB    R0, 4$          ;
62
63
64
65
66 002506 013700 000000G      MOV    CXTRMN, R0      ;Get pointer to base of simulated RMON
67 002512 062700 000000G      ADD    #R$SWPC, R0      ;Point to swap file channel in context block
68 002516 105060 000000G      CLRB   C. NUMQ(R0)    ;Zero I/O count in swap file channel block
69
70
71
72
73 002522 013700 000000G      MOV    CXTRMN, R0      ;Get pointer to base of simulated RMON
74 002526 062700 000000G      ADD    #R$MFMV, R0      ;Point to MOV @#PSW, (SP) instruction
75 002532 012720 012716      MOV    #012716, (R0)+   ;Store MOV #0, (SP) instruction
76 002536 005010              CLR    (R0)          ;Store 0 value following instruction
77
78
79
80
81 002540 016104 000000G      MOV    LPROJ(R1), R4    ;Get pointer to buffer with file name
82 002544 001421              BEQ    10$          ;Br if no secondary start-up file
83 002546 116437 000000G 000000G  MOVB   IB$IJ(R4), SPIJ    ;Save index # of initiating job
84 002554 010402              MOV    R4, R2          ;
85 002556 062702 000000G      ADD    #IB$SF2, R2      ;Point to start of name string
86 002562 012703 000000G      MOV    #SUCF2, R3    ;Point to cell in context block
87 002566 112223              11$:   MOVB   (R2)+, (R3)+   ;Move name into context block
88 002570 001376              BNE    11$          ;Loop till asciz null reached
89 002572 010146              MOV    R1, -(SP)    ;Save job number
90 002574 010401              MOV    R4, R1          ;Get pointer to Q element used as buffer
91 002576 004737 000000G      CALL   QFREE        ;Free the Q element
92 002602 012601              MOV    (SP)+, R1    ;Restore job number
93 002604 005061 000000G      CLR    LPROJ(R1)    ;Say no project number
94
95
96
97 002610 020127 000000G      10$:   CMP    R1, #LSTDL    ;REAL OR VIRTUAL LINE?
98 002614 003021              BGT    1$          ;BR IF VIRTUAL
99 002616 020127 000000G      CMP    R1, #LSTPL    ;REAL OR DETACHED LINE?
100 002622 003404             BLE    2$          ;BR IF REAL
101
102
103
104 002624 052761 000000G 000000G  BIS    ##DETCH, LSW(R1) ;REMEMBER THIS IS A DETACHED JOB
105 002632 000430              BR    3$          ;
106
107
108
109 002634 016161 000000G 000000G 2$:   MOV    ILSW2(R1), LSW2(R1); INIT SOME LSW TABLES
110 002642 016161 000000G 000000G  MOV    ITRMTP(R1), LTRMTP(R1); SET DEFAULT TERMINAL TYPE
111 002650 042761 000000C 000000G  BIC    ##CTRLS!$CTRL0, LSW3(R1); Enable terminal output
112 002656 000416              BR    3$          ;
113
114
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 6-2  
NEWUSR -- Start a new time-sharing job

```
115                      ; Copy some information from parent line.  
116  
117 002660 016102 000000G    1$:   MOV    LNPRIM(R1),R2 ; GET PRIMARY LINE #  
118 002664 016261 000000G 000000G    MOV    LSW2(R2),LSW2(R1)  
119 002672 016261 000000G 000000G    MOV    LTRMTP(R2),LTRMTP(R1)  
120 002700 016261 000000G 000000G    MOV    LPROJ(R2),LPROJ(R1)  
121 002706 016261 000000G 000000G    MOV    LPROG(R2),LPROG(R1)  
122  
123                      ; See if we should start line with deferred echo  
124  
125 002714 032761 000000G 000000G 3$:   BIT    #$DEFER,LSW2(R1); Is deferred echo wanted?  
126 002722 001403             BEQ    6$                 ;Br if not  
127 002724 052761 000000C 000000G    BIS    #<$DODFR!$GCEC0>,LSW3(R1) ;Start deferring now  
128  
129                      ; Set up mapping registers for job.  
130  
131 002732 004737 000000G    6$:   CALL   SETMAP          ;SET UP MAPPING REGISTERS FOR THE JOB  
132 002736 013700 000000G    MOV    DFJMEM, R0      ;GET DEFAULT # K-BYTES OF MEMORY FOR JOB  
133 002742 072027 000012        ASH    #10., R0      ;CONVERT TO ADDRESS  
134 002746 010037 000000G    MOV    R0, MAXMEM     ;SET AS DEFAULT UPPER LIMIT FOR JOB  
135  
136                      ; Switch to stack in job's context area.  
137  
138 002752 012706 000000G    ; MOV    #JSTK, SP      ;SWITCH TO CONTEXT-BLOCK STACK  
139  
140                      ; Enter code to load KMON.  
141  
142 002756 000466            BR    LDKMON         ;GO LOAD KMON
```

STOP -- Stop program execution &amp; enter KMON

```

1           .SBTTL STOP    -- Stop program execution & enter KMON
2
3           ; -----
4           ; STOP is jumped to when the job wants to terminate its execution and
5           ; enter KMON. This is usually caused by .EXIT, .CHAIN or CTRL-C.
6
7 002760 113701 000000G      STOP: MOVB   CORUSR,R1      ; GET JOB # OF CURRENT JOB
8 002764 001007               BNE    1$          ; IF SHOULD NOT BE ZERO
9 002766               DIE    #EM$SJN,(SP)  ; DIE IF JOB # = 0
10 003004 012706 000000G     1$:   MOV    #JSTK,SP      ; RUN ON JOB'S CONTEXT-BLOCK STACK
11 003010               ENABL  ; MAKE SURE INTERRUPTS ARE ENABLED
12 003016 052761 000000G 000000G   BIS    ##NOUCR,LSW9(R1); Tell DOCMPL not to run user compl routines
13 003024 012737 177777 000000G   MOV    #-1,EMTLEV   ; SAY JOB IS NOT EXECUTING AN EMT
14 003032 052737 000000G 000000G   BIS    #UPMODE,@#PSW    ; MAKE SURE PREVIOUS-MODE = USER
15 003040 032761 000000G 000000G   BIT    ##INKMN,LSW4(R1); IS KMON RUNNING NOW?
16 003046 001010               BNE    2$          ; BR IF YES
17 003050 106537 000052            MFPD   @#52        ; GET JOB'S ERROR CELLS
18 003054 000316               SWAB   (SP)       ; PUT (53) IN LOW-ORDER BYTE
19 003056 112637 000000G            MOVB   (SP)+,UERSEV ; SAVE USER SPECIFIED ERROR SEVERITY LEVEL
20 003062 005046               CLR    -(SP)      ; NOW CLEAR USER ERROR SEVERITY
21 003064 106637 000052            MTPD   @#52        ;
22
23           ; Do general cleanup on exiting job.
24 003070 004737 003422'          2$:   CALL   CLENUP      ; CLEAN UP STATUS OF JOB
25 003074 042761 000000G 000000G   BIC    ##NOUCR,LSW9(R1); Reenable user completion routine processing
26
27           ; See if we should force logoff of this job.
28
29 003102 032761 000000G 000000G   BIT    ##DISCN,LSW(R1) ; DID A LINE DISCONNECT OCCUR?
30 003110 001411               BEQ    LDKMON    ; BR IF NOT
31 003112 052761 000000G 000000G   BIS    ##DOOFF,LSW(R1) ; FORCE LOGOFF
32 003120 052761 000000G 000000G   BIS    ##NOIN,LSW3(R1) ; IGNORE INPUT FROM LINE DURING LOGOFF
33 003126 042761 000000G 000000G   BIC    ##DISCN,LSW(R1) ; ACKNOWLEDGE DISCONNECT
34
35           ; Read KMON into memory and enter it
36
37 003134 052737 000000G 000000G LDKMON: BIS    #UPMODE,@#PSW    ; SET USER-PREVIOUS-MODE IN PS
38 003142 042761 173330 000000G   BIC    #173330,LJSW(R1); CLEAN OUT SOME FLAGS IN JOB STATUS WORD
39 003150 016146 000000G            MOV    LJSW(R1),-(SP)  ; GET CURRENT JOB STATUS WORD
40 003154 106537 000000G            MFPD   @#ERRLOC    ; GET JOB'S ERROR CELLS
41 003160 052761 000000G 000000G   BIS    ##INKMN,LSW4(R1); SAY KMON IS RUNNING
42 003166 042761 000000G 000000G   BIC    ##MAPOK,LSW7(R1); SAY CONTEXT BLOCK MAPPING DATA IS INVALID
43 003174 042761 000000G 000000G   BIC    ##VIRJB,LSW9(R1); SAY THIS IS NOT A VIRTUAL JOB
44 003202 105737 000000G            TSTB   VSWPFL    ; IS THIS A NON-SWAPPING SYSTEM?
45 003206 001406               BEQ    3$          ; BR IF YES -- DON'T CHANGE MEMORY ALLOCATION
46 003210 013700 000000G            MOV    KMNTOP,RO    ; GET ADDRESS ABOVE TOP OF KMON
47 003214 162700 000000G            SUB    #KMNBAS,RO  ; GET AMT OF MEMORY NEEDED FOR KMON
48 003220 004737 000000G            CALL   SUTOP     ; SET TOP OF MEMORY FOR JOB
49 003224 004737 000000G            3$:   CALL   SETMAP    ; MAKE SURE MEMORY MAPPING SET FOR KMON
50 003230 013737 000000G 000000G   MOV    KMNTOP,UHIMEM ; SAY JOB CAN ACCESS UP TO TOP OF KMON
51 003236 012637 000000G            MOV    (SP)+,@#ERRLOC ; SET ERROR CELLS
52 003242 011637 000000G            MOV    (SP),@#JSWLOC ; SET JSW
53 003246 012661 000000G            MOV    (SP)+,LJSW(R1)
54
55           ; Set up status in user channel # 17 to allow us to access kmon file.
56
57 003252 012703 000017            MOV    #17,R3      ; USE USER CHANNEL # 17

```

STOP -- Stop program execution &amp; enter KMON

```

58 003256          .PURGE R3           ; MAKE SURE CHANNEL 17 IS FREE
59 003266 013703 000000G    MOV CXTRMN,R3   ; BASE OF JOB CHANNEL AREA
60 003272 062703 000000G    ADD #R$CH17,R3  ; POINT TO AREA FOR CHANNEL # 17
61 003276 012700 000005     MOV #5, R0      ; # WORDS TO MOVE
62 003302 012704 000000G    MOV #KMNCNH,R4  ; POINT TO BLOCK WITH KMON SAVED STATUS
63 003306 012423          1$: MOV (R4)+,(R3)+ ; SET UP INFO IN USER CHANNEL 17 BLOCK
64 003310 077002          SOB R0,1$      ; 
65
66          ; Now read Kmon into user's program space.
67
68 003312 013703 000000G    MOV KMNTOP,R3   ; GET TOP OF MEMORY ADDRESS FOR KMON
69 003316 162703 000000G    SUB #KMNBAS,R3  ; SUBTRACT BASE ADDRESS OF KMON
70 003322 000241          CLC
71 003324 006003          ROR R3          ; CVT TO # WORDS TO READ
72 003326          .READW #CSIARE,#17,#0,R3,#32. ; READ IN KMON
73 003362 103005          BCC 2$          ; BR IF READ OK
74 003364          DIE #EM$KRE      ; SYSTEM HALT IF KMON READ ERROR
75
76          ; Set up Kmon user-mode stack pointer.
77
78 003376 013746 0000000    2$: MOV KMNSTK,-(SP) ; GET KMON STACK POINTER
79 003402 106606          MTPD SP        ; SET IN USER-MODE SP
80
81          ; Give Kmon a full time-slice.
82
83 003404 005061 000000G    CLR LQUAN(R1)   ; CLEAR JOB TIME QUANTUM
84
85          ; Use RTI to enter Kmon in user mode.
86
87 003410 012746 000000G    MOV #UMODE,-(SP) ; USER-MODE PS
88 003414 013746 000000G    MOV KMNSTR,-(SP) ; STARTING ADDRESS IN KMON
89 003420 000002          RTI             ; ENTER KMON IN USER MODE

```

CLENUP -- Do general cleanup when a job stops

```

1           .SBTTL CLENUP -- Do general cleanup when a job stops
2
3           ;-----;
4           ; CLENUP is called to do I/O rundown and other general cleanup
5           ; operations when a job stops.
6
7           ; Inputs:
8           ;   R1 = Job index number
9
10          003422 010146
11          003424 010246
12          003426 010446
13          003430 010546
14          003432 042761 000000C 000000G
15          003440 005061 000000G
16          003444 005061 000000G
17          003450 005061 000000G
18          003454 042761 000000C 000000G
19          003462 042761 000000C 000000G
20          003470 005061 000000G
21          003474 005061 000000G
22          003500 005061 000000G
23          003504 005037 000000G
24          003510 005037 000000G
25          003514 012737 000000G 000000G
26          003522 005037 000000G
27
28           ; If double control-C was typed, echo this to the log file
29          003526 032761 000000G 000000G
30          003534 001424
31          003536 105037 000000G
32          003542 032737 000000G 000000G
33          003550 001413
34          003552 012700 000003
35          003556
36          003564
37          003572
38          003600 042761 000000G 000000G 11$:
39
40           ; Abort all I/O for this job
41
42          003606 105737 000000G 12$:
43          003612 001004
44          003614 004737 000000G
45          003620 004737 000000G
46
47           ; Do any real-time associated cleanup
48
49          003624
50
51           ; Free the USR
52
53          003632 120137 000000G 4$:
54          003636 001004
55          003640
56          003646 000771
57

```

The assembly code provided is a macro named CLENUP, which performs general cleanup operations when a job stops. It includes various memory moves, bit operations, and calls to routines like RTSTOP and FREUSR. The code handles I/O rundown, clears flags, and releases resources. It also checks for double control-C inputs and logs them if present. The assembly instructions are annotated with comments explaining their purpose.

CLENUP -- Do general cleanup when a job stops

```

58                                ; Free job context block buffer
59
60 003650 120137 000000G      15$:  CMPB    R1,CXBOWN      ;Are we holding context block buffer?
61 003654 001003              BEQ     3$          ;Br if not
62 003656              OCALL   FRECXT       ;Free context block buffer
63
64                                ; Free the Special Device data base
65
66 003664              3$:  OCALL   FRESPD       ;FREE SPECIAL DEVICE DATA BASE
67
68                                ; Cancel any pending mark-time requests for this job
69
70 003672              OCALL   CANMKT       ;CANCEL ALL MARK-TIME REQUESTS FOR JOB
71
72                                ; Cancel any monitoring requests for this job
73
74 003700              OCALL   MONABT       ;Cancel any monitoring requests
75
76                                ; Cancel any pending message requests for this job
77
78 003706 005737 000000G      TST     VMAXMC       ; Is message system included in system?
79 003712 001403              BEQ     14$          ;Br if not
80 003714              OCALL   MSGABT       ;Cleanup message system
81
82                                ; Undo Break key connection.
83
84 003722 016100 000000G      14$:  MOV     LBRKCQ(R1),R0  ;GET ADDRESS OF BREAK QUEUE ENTRY
85 003726 001407              BEQ     17$          ;BR IF NONE
86 003730 005061 000000G      CLR     LBRKCQ(R1)  ;SAY NO BREAK KEY CONNECTION
87 003734 010146              MOV     R1,-(SP)    ;SAVE JOB INDEX NUMBER
88 003736 010001              MOV     R0,R1      ;GET QUEUE ENTRY ADDRESS FOR QFREE
89 003740 004737 000000G      CALL   QFREE        ;FREE THE QUEUE ENTRY
90 003744 012601              MOV     (SP)+,R1    ;GET BACK JOB NUMBER
91
92                                ; Undo TT input completion routine connection
93
94 003746 016100 000000G      17$:  MOV     LTTCR(R1),R0  ;GET ADDRESS OF QUEUE ENTRY
95 003752 001407              BEQ     1$          ;BR IF NONE
96 003754 005061 000000G      CLR     LTTCR(R1)  ;SAY NO COMPL ROUTINE
97 003760 010146              MOV     R1,-(SP)    ;SAVE JOB INDEX NUMBER
98 003762 010001              MOV     R0,R1      ;GET QUEUE ENTRY ADDRESS FOR QFREE
99 003764 004737 000000G      CALL   QFREE        ;FREE THE QUEUE ENTRY
100 003770 012601             MOV     (SP)+,R1    ;GET BACK JOB NUMBER
101
102                                ; Clean up all pending completion routine requests for this job
103
104 003772 004737 004146'     1$:   CALL   CANCPL       ;Cancel all pending completion routines
105
106                                ; Close all shared files for this job.
107
108 003776 013704 000000G      5$:   MOV     JCDB,R4      ;GET ADDRESS OF NEXT CDB FOR JOB
109 004002 001405              BEQ     6$          ;BR IF NO MORE
110 004004 013705 000002G      MOV     JCDB+2,R5    ;Get par pointer for CDB
111 004010 004777 000000G      CALL   @CLSCDB     ;CLOSE THE CDB
112 004014 000770              BR     5$          ;SEE IF THERE ARE MORE TO DO
113
114                                ; Release any PLAS regions created for the job

```

CLENUP -- Do general cleanup when a job stops

```

115 ;  

116 004016 005737 000000G 6$: TST VPLAS ; IS PLAS SUPPORT GENMED INTO SYSTEM?  

117 004022 001403 BEQ 13$ ; BR IF NOT  

118 004024 OCALL PLSXIT ; FREE ANY PLAS REGIONS AND WINDOWS  

119 ;  

120 ; Release trap control for job  

121 ;  

122 004032 005037 000000G 13$: CLR UTRPAD ; Undo .TRPSET  

123 004036 005037 000000G CLR UFPTRP ; Undo .SFPA  

124 004042 105037 000000G CLRB FPUUSE ; Tell system that FPU is not in use  

125 ;  

126 ; Release any associated shared run-time systems  

127 ;  

128 004046 005037 000000G CLR CURRDB ; DISASSOCIATE RUN-TIME SYSTEM  

129 004052 105037 000000G CLRB DOTRMP ; Disable fast TRAP mapping  

130 004056 005002 CLR R2 ; INIT PAR INDEX  

131 004060 005062 000000G 9$: CLR RPAR(R2) ; RESET PAR MAPPING INFO  

132 004064 005062 000000G CLR RPDR(R2)  

133 004070 005062 000000G CLR RDAR(R2)  

134 004074 005062 000000G CLR RDDR(R2)  

135 004100 062702 000002 ADD #2, R2 ; ADVANCE INDEX  

136 004104 020227 000016 CMP R2, #2*7 ; DONE ALL?  

137 004110 101763 BLOS 9$ ; LOOP IF MORE TO DO  

138 004112 042761 000000G 000000G BIC #$UDSPC, LSW11(R1) ; Clear flag saying user wants I/D-space  

139 004120 105737 000000G TSTB SR3FLG ; Does hardware support I/D space?  

140 004124 001403 BEQ 10$ ; Br if not  

141 004126 042737 000000G 000000G BIC #USDSPC, SR3MMR ; Disable user D-space  

142 ;  

143 ; Finished  

144 ;  

145 004134 012605 10$: MOV (SP)+, R5  

146 004136 012604 MOV (SP)+, R4  

147 004140 012602 MOV (SP)+, R2  

148 004142 012601 MOV (SP)+, R1  

149 004144 000207 RETURN

```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 9  
CANCPL -- Cancel all pending completion routines

```
1 .SBTTL CANCPL -- Cancel all pending completion routines
2 ;-----
3 ; CANCPL is called during job exit cleanup to cancel any pending completion
4 ; routines. User-mode completion routines are removed from the pending
5 ; list, system-mode completion routines are forced to be called.
6 ;
7 ; Inputs:
8 ; R1 = Job index number.
9
10 004146 010546
11
12 ; Say we are not in a completion routine now
13
14 004150 105037 0000000
15 1$: CLR B CURCP ;Say not executing in completion rtn now
16
17 ; If any I/O is in progress for job, suspend execution while we
18 ; wait for it to finish.
19
20 004154
21 004162 126137 000000G 000000G
22 004170 003404
23 004172 012700 000000G
24 004176 004737 000000G
25
26 ; See if there are any pending completion routines
27 004202
28 004210 005761 000000G
29 004214 001005
30 004216 126137 000000G 000000G
31 004224 003351
32 004226 000403
33
34 ; There is at least one pending completion routine.
35 ; Now call SCHED to force pending system-mode routines to be run
36
37 004230 004737 000000G
38
39 ; Go back and make sure all completion routines have been taken care of
40
41 004234 000745
42
43 ; All I/O has terminated and there are no pending completion routines.
44 ; Free any cache control blocks that were pending when job aborted.
45
46 004236 005737 000000G
47 004242 001406
48 004244 013705 000000G
49 004250 001737
50 004252 004777 000000G
51 004256 000772
52
53 ; Finished
54
55 004260 012605
56 004262 000207
;
; -----
; Cancpl is called during job exit cleanup to cancel any pending completion
; routines. User-mode completion routines are removed from the pending
; list, system-mode completion routines are forced to be called.
;
; Inputs:
; R1 = Job index number.
;
; Cancpl: MOV      R5,-(SP)
;
; Say we are not in a completion routine now
;
; 1$: CLR B CURCP ;Say not executing in completion rtn now
;
; If any I/O is in progress for job, suspend execution while we
; wait for it to finish.
;
; 2$: DISABL      ;;;** Disable interrupts **
; CMPB      LIOCNT(R1),NPCCB; Is any I/O in progress for job?
; BLE       2$        ;;Br if not
; MOV       #S$IOWT,RO ;;Suspend job till I/O completes
; CALL      QNSPND    ;;Suspend execution of job
;
; See if there are any pending completion routines
;
; 2$: ENABL      ;** Enable interrupts **
; TST       LCMPL(R1) ;Is there a pending completion routine?
; BNE       3$        ;;Br if yes
; CMPB      LIOCNT(R1),NPCCB; Is all I/O finished too?
; BGT       1$        ;If not, then wait till it is
; BR        5$        ;All I/O is finished and no compl rtns pend
;
; There is at least one pending completion routine.
; Now call SCHED to force pending system-mode routines to be run
;
; 3$: CALL      SCHED   ;Force completion routine execution
;
; Go back and make sure all completion routines have been taken care of
;
; BR        1$        ;Loop till all completion routines finished
;
; All I/O has terminated and there are no pending completion routines.
; Free any cache control blocks that were pending when job aborted.
;
; 5$: TST       JOBCCB   ;Any pending cache control blocks
; BEQ       9$        ;;Br if not
; 6$: MOV       JOBCCB,R5 ;Get pointer to 1st pending control block
; BEQ       1$        ;;Br if none left pending
; CALL      @CSHFIN   ;Free the cache control block
; BR        6$        ;Loop to free any others
;
; Finished
;
; 9$: MOV      (SP)+,R5
; RETURN
```

```
1           .SBTTL LOGOFF -- Log off a job
2
3           ; -----
4           ; LOGOFF is jumped to log off the current job.
5           ; All tables for the job are reset and then the scheduler is entered
6           ; to look for another job to run.
7
8           ; Inputs:
9           ;   R1 = Job number of job being logged off.
10          004264 032761 000000G 000000G LOGOFF: BIT    ##$DETCH, LSW(R1) : IS THIS A DETACHED JOB LOGGING OFF?
11          004272 001402             BEQ    26$               ;Br if not
12          004274 000137 004754'             JMP    4$               ; -----
13
14           ; Wait for all TT output for the job to complete.
15
16          004300 032761 000000G 000000G 26$:   BIT    ##$VNOTT, LSW(R1) : IS JOB CONNECTED TO TERMINAL?
17          004306 001045             BNE    12$               ;BR IF NOT (DON'T WAIT FOR OUTPUT)
18          004310 013704 000000G             MOV    SYTIMH, R4      ;Get high-order time-of-day
19          004314 013705 000000G             MOV    SYTML, R5      ;Get low-order time-of day
20          004320 062705 000454             ADD    #5.*60., R5     ;Add time to allow for logoff message
21          004324 005504             ADC    R4                 ;Propogate carry
22          004326 023704 000000G             CMP    SYTIMH, R4     ;Have we waited long enough?
23          004332 101033             BHI    12$               ;Br if yes
24          004334 103403             BLO    16$               ;Br if not
25          004336 023705 000000G             CMP    SYTML, R5     ;Compare low-order time
26          004342 103027             BHIS   12$               ;Br if have waited long enough
27          004344 116103 000000G             MOVB   LNPRIM(R1), R3  ;GET PRIMARY LINE NUMBER
28          004350 032763 000000G 000000G 16$:   BIT    ##$DILUP, LSW(R3) : IS PRIMARY LINE STILL LOGGED ON?
29          004356 001421             BEQ    12$               ;BR IF NOT
30          004360 042763 000000G 000000G             BIC    ##$CTRLS, LSW3(R3); CLEAR CTRL-S SUSPEND
31          004366 004777 000000G             CALL   @TRNSTR        ;MAKE SURE OUTPUT IS GOING
32          004372 026161 000000G 000000G             CMP    LOTSPEC(R1), LOTSIZ(R1); ANY CHARS LEFT TO TRANSMIT?
33          004400 001352             BNE    10$               ;WAIT FOR ALL OUTPUT TO COMPLETE
34          004402 032761 000000C 000000G             BIT    #<$DHBF1!$DHBF2>, LSW10(R1); DH11 buffer being transmitted?
35          004410 001346             BNE    10$               ;Wait for DH11 to finish
36          004412 032761 000000G 000000G             BIT    ##$XCHAR, LSW3(R1); Wait for last char to go out
37          004420 001342             BNE    10$               ; -----
38
39           ; See if this is a primary or virtual line logging off.
40
41          004422 020127 000000G 12$:   CMP    R1, #LSTPL       ;PRIMARY OR VIRTUAL LINE?
42          004426 003466             BLE    1$                 ;BR IF PRIMARY LINE
43
44           ; Log off a virtual line.
45
46          004430 105337 000000G             DECB   PVON            ;Count # primary & virtual lines on
47          004434 010102             MOV    R1, R2            ;Save virtual line number
48          004436 113703 000000G             MOVB   SPIJ, R3          ;Get # of process that started us
49          004442 001422             BEQ    22$               ;Br if unknown
50          004444 032763 000000G 000000G             BIT    ##$DISCN, LSW(R3) ; Is that process terminating now?
51          004452 001016             BNE    22$               ;Br if yes -- Switch to primary
52          004454 016100 000000G             MOV    LNPRIM(R1), R0  ;Get our primary process #
53          004460 020300             CMP    R3, R0            ;Switching back to primary process?
54          004462 001412             BEQ    22$               ;Br if yes
55          004464 016000 000000G             MOV    LSECPT(R0), R0  ;Get pointer to subprocess # table
56          004470 005005             CLR    R5                 ;Init subprocess #
57          004472 005205             24$:   INC    R5                 ;Increment subprocess #
```

LOGOFF -- Log off a job

```

58 004474 020527 000000G      CMP    R5, #MAXSEC   ; Checked all subprocess entries?
59 004500 101003      BHI    22$      ; Br if yes -- Switch back to primary
60 004502 120320      CMPB   R3, (R0)+  ; Search for originating process in table
61 004504 001372      BNE    24$      ; Loop till found
62 004506 000407      BR     23$      ; Found subprocess to switch back to (R5=#)
63 004510 005005      22$:    CLR    R5       ; Say we are switching to primary process
64 004512 016103 000000G      MOV    LNPRIM(R1), R3 ; Get primary line number
65 004516 032763 000000G 000000G    BIT    #$DILUP, LSW(R3) ; Is the primary line still logged on?
66 004524 001423      BEQ    2$       ; Br if not
67 004526 016203 000000G      23$:    MOV    LNPRIM(R2), R3 ; Get primary process index
68 004532 120163 000000G      CMPB   R1, LNMAP(R3) ; Are we running on line being logged off?
69 004536 001003      BNE    6$       ; Br if not -- Someone must have killed us
70 004540      OCALL   LNSWT    ; Switch back to initiating process
71
72
73
74
75
76 004546 005004      6$:    CLR    R4       ; CHECK 1ST VIRTUAL LINE ENTRY
77 004550 016305 000000G      MOV    LSECPT(R3), R5 ; POINT TO TABLE OF VIRTUAL LINE #'S
78 004554 120225      5$:    CMPB   R2, (R5)+  ; IS THIS THE VIRTUAL LINE ENTRY?
79 004556 001405      BEQ    3$       ; BR IF YES
80 004560 005204      INC    R4       ; CHECK NEXT ENTRY
81 004562 020427 000000G      CMP    R4, #MAXSEC ; CHECKED ALL?
82 004566 002772      BLT    5$       ; BR IF MORE TO CHECK
83 004570 000401      BR     2$       ; STRANGE -- COULDN'T FIND VIRTUAL LINE
84 004572 105045      3$:    CLRB   -(R5)    ; SAY VIRTUAL LINE NOT OWNED BY PRIMARY LINE
85 004574 005062 000000G      2$:    CLR    LNPRIM(R2) ; REMOVE PRIMARY LINE NUMBER FOR VIRTUAL LINE
86 004600 010201      MOV    R2, R1    ; GET BACK VIRTUAL LINE NUMBER
87 004602 000464      BR     4$       ;
88
89
90
91
92 004604 105337 000000G      1$:    DECB   NUMON    ; # PRIMARY LINES ON
93 004610 105337 000000G      DECB   PVON     ; # PRIMARY & VIRTUAL LINES ON
94 004614 013700 000004G      MOV    EMTBLK+4, R0 ; Get time to drop DTR
95 004620 001002      BNE    21$      ; Br if time parameter specified
96 004622 013700 000000G      MOV    VOFFTM, R0 ; Get sysgen specified time
97 004626 010061 000000G      21$:    MOV    R0, LOFFTM(R1) ; Drop DTR after this much time
98 004632 016161 000000G 000000G    MOV    ILSW2(R1), LSW2(R1); Reset line status flags
99 004640 010103      MOV    R1, R3    ; SAVE PRIMARY LINE NUMBER
100 004642 010161 000000G     MOV    R1, LNMAP(R1) ; REASSOCIATE TS LINE WITH PRIMARY LINE
101
102
103
104
105 004646 032761 000000G 000000G    BIT    #$AUTO, ILSW2(R1); Is autobaud selected for this line?
106 004654 001406      BEQ    14$      ; Br if not
107 004656 012761 000012 000000G    MOV    #10., LABTIM(R1) ; Start autobaud timer for this line
108 004664 052761 000000G 000000G    BIS    #$NABRS, LSW9(R1); Set flag saying we need to reset the speed
109
110
111
112 004672 016104 000000G      14$:    MOV    LCXTBL(R1), R4 ; Get pointer to lines translation table
113 004676 001401      BEQ    25$      ; Br if no translation table
114 004700 005014      CLR    (R4)    ; Say no translation in effect

```

115 ;  
116 ; Force disconnect of all associated virtual lines.  
117 ;  
118 004702 005004 25\$: CLR R4 ;START WITH 1ST VIRTUAL LINE  
119 004704 016305 000000G MOV LSECPT(R3),R5 ;GET ADDRESS OF VIRTUAL LINE TABLE  
120 004710 020427 000000G 9\$: CMP R4,#MAXSEC ;CHECKED ALL VIRTUAL LINE ENTRIES  
121 004714 002016 BGE 7\$ ;BR IF YES  
122 004716 111501 MOVB (R5),R1 ;GET VIRTUAL LINE NUMBER  
123 004720 001411 BEQ 8\$ ;BR IF NO ASSOCIATED VIRTUAL LINE HERE  
124 004722 032761 000000G 000000G BIT #\\$LOFCF,LSW9(R1); IS JOB DOING LOGOFF PROCESSING NOW?  
125 004730 001005 BNE 8\$ ;BR IF YES  
126 004732 052761 000000G 000000G BIS #\\$DISCN,LSW(R1) ;FORCE LOG OFF OF THIS VIRTUAL LINE  
127 004740 004737 000000G CALL FORCEX ;FORCE ITS EXECUTION  
128 004744 105025 8\$: CLRB (R5)+ ;CLEAR ENTRY IN PRIMARY LINE'S TABLE  
129 004746 005204 INC R4 ;CHECK NEXT ENTRY  
130 004750 000757 BR 9\$  
131 004752 010301 7\$: MOV R3,R1 ;GET BACK PRIMARY LINE NUMBER  
132 ;  
133 ; Release any display windows for job  
134 ;  
135 004754 005737 000000G 4\$: TST VMXWIN ;Is window support included in system?  
136 004760 001403 BEQ 20\$ ;Br if not  
137 004762 OCALL WINREL ;Release windows for job  
138 ;  
139 ; Do cleanup of PLAS regions  
140 ;  
141 004770 005737 000000G 20\$: TST VPLAS ;Is PLAS support included?  
142 004774 001403 BEQ 17\$ ;Br if not  
143 004776 OCALL PLSOFF ;Do PLAS cleanup  
144 ;  
145 ; Say we are no other job's parent  
146 ;  
147 005004 012702 000000G 17\$: MOV #LSTS1,R2 ;Get # of last job  
148 005010 026201 000000G 18\$: CMP LPARNT(R2),R1 ;Are we that job's parent?  
149 005014 001002 BNE 19\$ ;Br if not  
150 005016 005062 000000G CLR LPARNT(R2) ;No longer its parent  
151 005022 162702 000002 19\$: SUB #2,R2 ;Check other jobs  
152 005026 003370 BGT 18\$  
153 ;  
154 ; Free all memory assigned to the job.  
155 ;  
156 005030 016102 000000G MOV LBASE(R1),R2 ;GET BASE PAGE # ASSIGNED TO JOB  
157 005034 016100 000000G MOV LNBLKS(R1),R0 ;GET # PAGES ASSIGNED TO JOB  
158 005040 004737 000000G CALL FREMEM ;RELEASE THE MEMORY SPACE  
159 005044 005061 000000G CLR LNBLKS(R1) ;SAY ALL MEMORY DEASSIGNED  
160 005050 005061 000000G CLR LMEMIN(R1)  
161 005054 005061 000000G CLR LBASE(R1)  
162 ;  
163 ; Now clear line tables.  
164 ;  
165 005060 004737 000000G CALL DEQ ;REMOVE JOB FROM RUN QUEUE \*\* DISABLE \*\*  
166 005064 005061 000000G CLR LSW(R1) ;CLEAR LINE STATUS TABLES  
167 005070 005061 000000G CLR LSW4(R1)  
168 005074 005061 000000G CLR LSW5(R1)  
169 005100 042761 000000C 000000G BIC #^C<#1STLG>,LSW6(R1);CLEAR ALL BUT 1ST-LOGON FLAG  
170 005106 005061 000000G CLR LSW7(R1)  
171 005112 012700 000000C MOV #<\$DEAD!\$HARD!\$CARUP!\$XCHAR>,R0 ;FLAGS TO PRESERVE IN LSW3

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 10-3  
LOGOFF -- Log off a job

172 005116 005100	COM	RO	; MASK TO CLEAR ALL OTHERS
173 005120 040061 000000G	BIC	RO, LSW3(R1)	
174 005124 005061 000000G	CLR	LPARNT(R1)	; Say we have no parent job
175 005130 005061 000000G	CLR	LNSPAC(R1)	; Say no user-defined activation characters
176 005134 105337 000000G	DEC8	TOTON	; TOTAL # JOBS
177 005140 120137 000000G	CMPB	R1, PMUSER	; ARE WE DOING A PERFORMANCE ANALYSIS?
178 005144 001004	BNE	13\$	; BR IF NOT
179 005146 005037 000000G	CLR	PMUSER	; SAY WE ARE DONE
180 005152 005037 000000G	CLR	PMRUN	
181			
182			; Job is logged off.
183			; Enter scheduler to find another one to run.
184			
185 005156 012706 000000G	13\$: MOV	#SS, SP	; SWITCH TO SYSTEM STACK
186 005162 105037 000000G	CLRB	CORUSR	; NO USER RUNNING
187 005166	ENABL		; ** ENABLE **
188 005174 105037 000000G	CLRB	MAPUSR	; SAY MEMORY MAPPING NOT SET UP FOR ANY JOB
189 005200 000137 000000G	JMP	EXEC	; GO LOOK FOR ANOTHER JOB TO RUN

```
1 .SBTTL TSXTX -- Trap Handler
2 ;-----
3 ; TSXTX is entered from the resident routines that catch traps to 4 and 10.
4 ;
5 ; Inputs:
6 ; The following items are on the stack:
7 ; 0(SP) = Saved R5
8 ; 2(SP) = Saved R4
9 ; 4(SP) = Trap PC
10 ; 6(SP) = Trap PS
11 ; R5 = Trap code (1==>Trap 4, 2==>Trap 10)
12 ;
13 ; See if trap occurred in user or kernel mode.
14 ;
15 005204 016604 000004 TSXTX: MOV 4(SP),R4 ;GET ADDRESS OF TRAP
16 005210 032766 000000G 000006 BIT #UMODE,6(SP) ;DID TRAP OCCUR IN USER OR KERNEL MODE?
17 005216 001036 BNE 1$ ;BR IF TRAP IN USER MODE
18 005220 012705 000016 MOV #16,R5 ;SET KERNEL-MODE-TRAP ERROR CODE
19 005224 105737 000000G TSTB CORUSR ;IS A JOB RUNNING NOW?
20 005230 001416 BEQ 6$ ;IF NOT THEN TRAP MUST BE IN SYSTEM
21 005232 005737 000000G TST CURVC ;IN REAL-TIME INTERRUPT SERVICE ROUTINE?
22 005236 001013 BNE 6$ ;BR IF YES
23 005240 105737 000000G TSTB FRKPRI ;IN A FORK ROUTINE?
24 005244 001010 BNE 6$ ;BR IF YES
25 005246 105737 000000G TSTB INTLVL ;ARE WE RUNNING AT INTERRUPT LEVEL?
26 005252 002005 BGE 6$ ;BR IF YES
27 005254 105737 000000G TSTB VDMKTP ;SHOULD WE ALWAYS CRASH ON KERNEL TRAP?
28 005260 001002 BNE 6$ ;BR IF YES
29 005262 000137 005546' JMP TRPCOM ;ALWAYS ABORT IF KERNEL MODE TRAP
30 ;
31 ; We had a trap within a critical system routine.
32 ; Cause a system crash.
33 ;
34 005266 010437 000000G 6$: MOV R4,DIEARG ;Set address of trap location
35 005272 012737 000170 000000G MOV #EM$KTP,DIEMSG ;Set address of abort message
36 005300 012605 MOV (SP)+,R5 ;Restore R5
37 005302 012604 MOV (SP)+,R4 ;Restore R4
38 005304 062706 000004 ADD #4,SP ;Pop trap PC and PS
39 005310 004737 000000G CALL SYSHL1 ;Die without changing TRPAR5
40 ;
41 ; Trap in user mode.
42 ; See if user was executing a real-time interrupt service routine.
43 ;
44 005314 005737 000000G 1$: TST CURVC ;ARE WE EXECUTING IN A REAL-TIME INT ROUTINE?
45 005320 001407 BEQ 7$ ;BR IF NOT
46 005322 DIE #EM$RIT,R4 ;TRAP IN REAL-TIME INTERRUPT SERVICE ROUTINE
47 ;
48 ; See if a stack overflow occurred.
49 ;
50 005340 004737 000000G 7$: CALL CHKUSP ;IS USER STACK POINTER OK?
51 005344 103002 BCC 2$ ;BR IF OK
52 005346 000137 005732' JMP ABORT ;ABORT JOB
53 ;
54 ; See if user did a .TRPSET
55 ;
56 005352 005737 000000G 2$: TST UTRPAD ;DID USER DO A .TRPSET?
57 005356 001010 BNE 3$ ;BR IF YES
```

```
58 005360 012704 000004      MOV    #4,R4          ;SET TRAP VECTOR ADDRESS TO 4
59 005364 020527 000001      CMP    R5,#1         ;DID WE GET TRAP TO 4 OR 10?
60 005370 001466              BEQ    TRPCOM        ;BR IF TRAP 4
61 005372 012704 000010      MOV    #10,R4        ;SET TRAP VECTOR ADDRESS TO 10
62 005376 000463              BR     TRPCOM        ;GO DO COMMON TRAP HANDLING
63
64
65
66 005400 004737 000000G      ; User did a .TRPSET
67
68 005404 106506              ; Move trap PC & PS from kernel stack to user's stack.
69 005406 012604              MFPD   SP             ;GET USER'S SP
70 005410 016646 000006      MOV    (SP)+,R4       ;MOV (SP),-(SP)
71 005414 106644              MTPD   -(R4)         ;PUSH TRAP PS ON USER'S STACK
72 005416 016646 000004      MOV    4(SP),-(SP)    ;PUSH TRAP PC ON USER'S STACK
73 005422 106644              MTPD   -(R4)         ;STORE UPDATED USER SP
74 005424 010446              MOV    R4,-(SP)       ;STORE UPDATED USER SP
75 005426 106606              MTPD   SP             ;STORE UPDATED USER SP
76
77
78
79 005430 012704 000000C      MOV    #UMODE!UPMODE,R4; GET USER-MODE PS
80 005434 020527 000002      CMP    R5,#2          ;WAS TRAP TO 4 OR 10?
81 005440 001001              BNE    4$             ;BR IF TRAP TO 4
82 005442 005204              INC    R4             ;SET C-FLAG IN PS TO SIGNAL TRAP TO 10
83 005444 010466 000006      4$:   MOV    R4,6(SP)     ;STORE NEW PS OVER TRAP PS
84 005450 013766 000000G 000004  MOV    UTRPAD,4(SP)   ;SET ADDRESS OF USER'S ROUTINE
85 005456 005037 000000G      CLR    UTRPAD        ;RESET .TRPSET
86 005462 012605              MOV    (SP)+,R5       ;STORE NEW PS OVER TRAP PS
87 005464 012604              MOV    (SP)+,R4       ;ENTER USER'S TRAP ROUTINE
88 005466 000002              RTI
```

```
1 ;-----  
2 ; TRPBPT is entered when a breakpoint (BPT) trap occurs to location 14  
3 ; and the system debugger is not connected to the user's job.  
4 ;  
5 ; Inputs:  
6 ; R4 = Job index number  
7 ; Information that has been pushed on the stack:  
8 ; PS-PC-R4  
9 ;  
10 005470 TRPBPT:  
11 ;  
12 ; If breakpoint occurred in TSKMON, enter debugger  
13 ;  
14 005470 032764 000000G 000000G BIT #$_INKMN,LSW4(R4); Is kmon running?  
15 005476 001004 BNE 1$ ;Br if yes  
16 ;  
17 ; See if user provided a PC in location 14  
18 ;  
19 005500 106537 000014 MFPD @#14 ;Get contents of loc 14 from user's job  
20 005504 005726 TST (SP)+ ;Did user provide a PC for trap?  
21 005506 001011 BNE 9$ ;Br if yes  
22 ;  
23 ; User did not provide a PC for trap.  
24 ; Enter system debugger.  
25 ;  
26 005510 105737 000000G 1$: TSTB VDBFLG ;Is system debugger included in system?  
27 005514 001406 BEQ 9$ ;Br if not  
28 005516 052764 000000G 000000G BIS #$_DBQBK,LSW9(R4); Set flag to force entry to debugger  
29 005524 012604 MOV (SP)+,R4 ;Restore R4  
30 005526 000137 000000G JMP SYSXIT ;Exit through routine that will test flag  
31 ;  
32 ; User provided a PC for BPT trap, enter his routine.  
33 ;  
34 005532 010546 9$: MOV R5,-(SP)  
35 005534 012705 000012 MOV #12,R5 ;Get error code  
36 005540 012704 000014 MOV #14,R4 ;Get trap location  
37 005544 000400 BR TRPCOM ;Enter trap processing routine
```

```
1 ;-----  
2 ; General trap handling routine.  
3 ;  
4 ; Inputs:  
5 ; R4 = Address of trap vector.  
6 ; R5 = Error message number.  
7 ;  
8 ; If user provided a PC & PS in the user-mode trap vector, then we enter  
9 ; his routine. Otherwise we abort the job.  
10;  
11 005546 010146 TRPCOM: MOV R1,-(SP)  
12;  
13 ; At this point the stack contains PS, PC, R4, R5, and R1  
14;  
15 005550 032766 000000G 000010 BIT #UMODE,B.(SP) ; DID TRAP OCCUR IN USER OR KERNEL MODE?  
16 005556 001005 BNE 4$ ; Br if in user mode  
17 005560 032737 000000G 000000G BIT #D$RUN,D.FLAG ; Is the debugger program running now?  
18 005566 001046 BNE 3$ ; Br if yes -- reenter the debugger  
19 005570 000456 BR 2$ ; Trap occurred within the system  
20 005572 004737 000000G 4$: CALL CHKUSP ; SEE IF USER STACK POINTER IS OK  
21 005576 103453 BCS 2$ ; BR IF INVALID STACK POINTER  
22 005600 113701 000000G MOVB CORUSR,R1 ; GET CURRENT JOB NUMBER  
23 005604 032761 000000G 000000G BIT #$_INKMN,LSW4(R1); DID TRAP OCCUR IN KMON?  
24 005612 001045 BNE 2$ ; ALWAYS ABORT IF YES  
25 005614 106524 MFPD (R4)+ ; GET PC FROM USER SPACE  
26 005616 005726 TST (SP)+ ; DID USER PROVIDE PC?  
27 005620 001430 BEQ 1$ ; BR IF NOT -- ABORT THE JOB  
28;  
29 005622 004737 000000G ; User supplied a PC.  
30 ; Move trap PC & PS from kernel stack to user stack.  
31 005626 106506 MFPD SP ; GET USER'S SP  
32 005630 012605 MOV (SP)+,R5  
33 005632 016646 000010 MOV B.(SP),-(SP) ; GET PS FROM TRAP  
34 005636 106645 MTPD -(R5) ; PUSH ONTO USER'S STACK  
35 005640 016646 000006 MOV 6(SP),-(SP) ; GET PC FROM TRAP  
36 005644 106645 MTPD -(R5) ; PUSH ONTO USER'S STACK  
37 005646 010546 MOV R5,-(SP) ; UPDATE USER'S SP  
38 005650 106606 MTPD SP  
39;  
40 ; Enter user's trap routine  
41;  
42 005652 106514 MFPD (R4) ; GET PS FROM TRAP VECTOR  
43 005654 052716 000000C BIS #UMODE!UPMODE,(SP); MAKE SURE USER-MODE IS SET  
44 005660 012666 000010 MOV (SP)+,B.(SP) ; STORE OVER TRAPPED PS  
45 005664 106544 MFPD -(R4) ; GET PC FROM TRAP VECTOR  
46 005666 012666 000006 MOV (SP)+,6(SP) ; STORE OVER TRAPPED PC  
47 005672 012601 MOV (SP)+,R1  
48 005674 012605 MOV (SP)+,R5 ; RESTORE REGISTERS  
49 005676 012604 MOV (SP)+,R4  
50 005700 000002 RTI ; ENTER USER'S TRAP ROUTINE  
51;  
52 ; User did not specify a trap routine.  
53 ; If program is running with the debugger, enter it.  
54;  
55 005702 005004 1$: CLR R4 ; Set flag saying trap was not in debugger  
56 005704 113701 000000G 3$: MOVB CORUSR,R1 ; Get job index number  
57 005710 032761 000000G 000000G BIT #$_DEBUG,LSW9(R1); Is program running with debugger?
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 13-1  
TSXTX -- Trap Handler

```
58 005716 001403          BEQ    2$           ;Br if not
59 005720 012601          MOV    (SP)+, R1      ;Recover R1
60 005722 000137 000000G   JMP    DBGTRP       ;Enter debugger
61
62          ; Abort the job
63
64 005726 016604 000006   2$:    MOV    6(SP), R4      ;GET PC WHERE TRAP OCCURED
65
66          ; Enter at ABORT to abort the current job.
67          ; Inputs:
68          ; R4 = Address of aborted instruction.
69          ; R5 = Abort error code.
70
71 005732 010437 000000G   ABORT: MOV    R4, ABRTAD    ;SAVE ADDRESS OF ABORT
72 005736 110537 000000G   MOVB  R5, ABRTCD    ;SAVE ABORT ERROR CODE
73 005742 004737 002760'    CALL   STOP         ;TERMINATE THE JOB
```

```
1           .SBTTL  FPTRPX -- Floating point trap routine
2
3           ;-----  

4           ; FPTRPX processed Floating Point Unit (FPU) exception interrupts.  

5           ; This routine is jumped to when we are about to exit from an interrupt  

6           ; back to user mode.  

7           ; On entry, the current job index number is in R1.  

8           ; The saved contents of R1 are on the top of the stack followed by the  

9           ; interrupt PC and PS ready to do an RTI.  

10          ;-----  

10 005746 052737 000000G 000000G FPTRPX: BIS      #UPMODE, @#PSW    ; Make sure previous mode = user
11 005754 042761 000000G 000000G             BIC      #$FPUEX, LSW(R1) ; Reset FPU exception flag for job
12 005762 012601                           MOV      (SP)+, R1      ; Recover R1 contents
13 005764 023727 000000G 000001             CMP      UFPTRP, #1    ; Did user do a .SFPA?
14 005772 101004                           BHI      1$          ; Br if yes
15
16           ; User did not do a .SFPA, Abort the job.
17
18 005774 012705 000005                   MOV      #5, R5      ; Set abort code
19 006000 011604                           MOV      (SP), R4    ; Get address of aborted instruction
20 006002 000753                           BR       ABORT      ; Abort the job
21
22           ; User gets trap control.
23           ; Push trap PC & PS onto user's stack
24
25 006004 004737 000000G 1$: CALL   CHKUSP      ; IS USER'S STACK POINTER OK?
26 006010 103002                           BCC   2$          ; BR IF OK
27 006012 011604                           MOV   (SP), R4      ; GET ADDRESS WHERE TRAP OCCURED
28 006014 000746                           BR    ABORT      ; ABORT THE JOB
29 006016 010346 2$: MOV   R3, -(SP)    ; GET A WORK REGISTER
30 006020 106506                           MFPD  SP          ; GET USER'S STACK POINTER
31 006022 012603                           MOV   (SP)+, R3
32 006024 016646 000004                   MOV   4(SP), -(SP) ; GET TRAP PS
33 006030 106643                           MTPD  -(R3)      ; PUSH ONTO USER'S STACK
34 006032 016646 000002                   MOV   2(SP), -(SP) ; GET TRAP PC
35 006036 106643                           MTPD  -(R3)      ; PUSH ONTO USER'S STACK
36
37           ; See if hardware has a FPU
38
39 006040 032737 000000G 000000G  BIT   #CW$FPU, CONFIG ; DOES HARDWARE HAVE AN FPU UNIT?
40 006046 001407                           BEQ   3$          ; BR IF NOT
41 006050 170346                           STST  -(SP)      ; GET FPU STATUS
42 006052 106663 177774                   MTPD  -4(R3)    ; MOVE FPU STATUS ONTO USER'S STACK
43 006056 106663 177776                   MTPD  -2(R3)
44 006062 162703 000004                   SUB   #4, R3      ; UPDATE USER'S SP
45
46           ; Reset user's SP
47
48 006066 010346 3$: MOV   R3, -(SP)    ; NEW USER SP
49 006070 106606                           MTPD  SP          ; RESET USER SP
50 006072 012603                           MOV   (SP)+, R3    ; RESTORE WORK REGISTER
51
52           ; Enter user's trap routine
53           ; Note, when user's trap routine does an RTI, it will transfer
54           ; control to the point we would have exited to if the FPU trap hadn't
55           ; have occurred.
56
57 006074 013716 000000G                   MOV   UFPTRP, (SP) ; SET PC FOR TRAP ROUTINE
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 14-1  
FPTRPX -- Floating point trap routine

58 006100 012766 000000C 000002	MOV #UMODE!UPMODE, 2(SP); SET PS
59 006106 012737 000001 000000G	MOV #1, UFPTRP ; RESET .SFPA TO AVOID REENTRANCY
60 006114 000002	RTI ; ENTER USER'S TRAP ROUTINE

```
1 .SBTTL CLKRUN -- Clock processing routine
2 ;-----
3 ; CLKRUN is the clock interrupt service routine entered from TSEEXEC
4 ; running at fork level.
5 ;
6 006116 013703 000000G CLKRUN: MOV TIKCNT, R3 ; GET # CLOCK TICKS THAT HAVE OCCURED
7 006122 005203 4$: INC R3 ; CONVERT TO ACTUAL NUMBER (STARTED AT -1)
8 006124 010337 000000G MOV R3, CLKCNT ; ADVANCE ALL TIMERS BY THIS AMOUNT
9 ;
10 ; Keep track of time of day
11 ;
12 006130 004737 006432' CALL CLKDAT ; ADVANCE TIME-OF-DAY AND DATE
13 ;
14 ; Keep track of time used by currently running job (if any)
15 ;
16 006134 113701 000000G MOVB CORUSR, R1 ; GET INDEX # OF CURRENTLY RUNNING JOB
17 006140 001405 BEQ 3$ ; BR IF NO JOB RUNNING NOW
18 006142 063761 000000G 000000G ADD CLKCNT, LCPULO(R1) ; ACCUMULATE RUN-TIME FOR JOB
19 006150 005561 000000G ADC LCPUHI(R1) ; PROPOGATE CARRY
20 ;
21 ; Check on .MRKT and .TIMIO requests
22 ;
23 006154 004737 010264' 3$: CALL CKMRKT ; Check on .MRKT and .TIMIO requests
24 ;
25 ; Check on jobs doing .TWAIT's
26 ;
27 006160 004737 010164' CALL CKTWAT ; Check on jobs doing .TWAIT's
28 ;
29 ; Check on job output buffer scheduling requests
30 ;
31 006164 005737 000000G TST NEDSOT ; Output scheduling needed?
32 006170 001404 BEQ 8$ ; Br if not
33 006172 005037 000000G CLR NEDSOT ; Say output scheduling done
34 006176 004737 011024' CALL CKSCHD ; Do job scheduling for output buffer low
35 ;
36 ; See if we need to do performance monitoring.
37 ;
38 006202 005737 000000G 8$: TST PMRUN ; IS PERFORMANCE MONITORING TO BE DONE?
39 006206 001402 BEQ 2$ ; BR IF NOT
40 006210 004737 010614' CALL CLKPM ; DO PERFORMANCE MONITORING
41 ;
42 ; If we are running on a Professional, call the PI output service
43 ; routine every 20th of a second.
44 ;
45 006214 013700 000000G 2$: MOV PIDPTR, R0 ; Are we running on a Pro?
46 006220 001407 BEQ 6$ ; Br if not
47 006222 005337 001340' DEC PROTIM ; Time to call PI driver?
48 006226 003004 BGT 6$ ; Br if not
49 006230 004710 CALL (R0) ; Call PI output driver
50 006232 012737 000000G 001340' MOV #PROODC, PROTIM ; Reset time counter
51 ;
52 ; Do clock driven processing of serial lines.
53 ; We do this as a lower priority fork request since this processing
54 ; could be lengthy.
55 ;
56 006240 005737 000000G 6$: TST NEDCDI ; Input character processing needed?
57 006244 001417 BEQ 5$ ; Br if not
```

```
58 006246 105737 000000G      TSTB   CDIFLG      ; Are we still doing input char processing?  
59 006252 001014      BNE    5$          ; Br if yes  
60 006254 105237 000000G      INCB   CDIFLG      ; Set flag saying processing is being done  
61 006260 004737 000000G      CALL    FRKGET     ; Get a fork request block  
62 006264 112764 000000G 000000G  MOVB   #FP$CDI,FQ$PRI(R4); Set low priority for fork request  
63 006272 013764 000000G 000000G  MOV    CDIRTN,FQ$RTN(R4); Set address of routine to call  
64 006300 004737 000000G      CALL    FORKQ      ; Queue the fork request  
65 006304 005737 000000G      5$:    TST    NEDCDO     ; Output character processing needed?  
66 006310 001417      BEQ    7$          ; Br if not  
67 006312 105737 000000G      TSTB   CDOFLG      ; Are we still doing output char processing?  
68 006316 001014      BNE    7$          ; Br if yes  
69 006320 105237 000000G      INCB   CDOFLG      ; Say output processing being done  
70 006324 004737 000000G      CALL    FRKGET     ; Get a fork request block  
71 006330 112764 000000G 000000G  MOVB   #FP$CDO,FQ$PRI(R4); Set priority for fork request  
72 006336 013764 000000G 000000G  MOV    CDORTN,FQ$RTN(R4); Set address of routine to call  
73 006344 004737 000000G      CALL    FORKQ      ; Queue the fork request  
74  
;  
75 ; Processing done on 0.1 second frequency.  
76 ; This is also done by queueing a lower priority fork request.  
77  
;  
78 006350 163737 000000G 000000G 7$:  SUB    CLKCNT,TK1CNT ; Has 0.1 seconds of time passed?  
79 006356 003020      BGT    1$          ; Br if not  
80 006360 063737 000000G 000000G  ADD    TK1VAL,TK1CNT ; Reset 0.1 counter  
81 006366 005237 001342'      INC    TIKO1S      ; Say another 0.1 seconds has elapsed  
82 006372 003012      BGT    1$          ; Br if haven't finished last 0.1 sec routine  
83 006374 004737 000000G      CALL    FRKGET     ; Get a fork request block  
84 006400 112764 000000G 000000G  MOVB   #FP$CK1,FQ$PRI(R4); Set low priority for fork request  
85 006406 012764 007172' 000000G  MOV    #CLKO1S,FQ$RTN(R4); Set address of routine to be called  
86 006414 004737 000000G      CALL    FORKQ      ; Queue the fork request  
87  
;  
88 ; Finished clock processing  
89  
;  
90 006420 163737 000000G 000000G 1$:  SUB    CLKCNT,TIKCNT ; SUBTRACT # CLOCK TICKS ACCOUNTED FOR  
91 006426 002233      BGE    CLKRUN     ; BR IF WE NEED TO CYCLE AGAIN  
92 006430 000207      RETURN           ; FINISHED
```

```
1 .SBTTL CLKDAT -- update time of day and date
2 ; -----
3 ; CLKDAT is the timer subroutine called to keep track of the current
4 ; time-of-day and date.
5 ;
6 ; Inputs:
7 ; CLKCNT = # clock ticks to account for.
8 ;
9 ; Outputs:
10 ; SYTML & SYTIMH = Updated time of day.
11 ; SYSDAT = Updated date.
12 ;
13 006432 010146 CLKDAT: MOV R1,-(SP)
14 006434 010246 MOV R2,-(SP)
15 006436 010346 MOV R3,-(SP)
16 ;
17 ; Advance system time counter.
18 ;
19 006440 063737 000000G 000000G ADD CLKCNT,SYTML ;ADD TO LOW-ORDER WORD
20 006446 005537 000000G ADC SYTIMH ;PROPAGATE CARRY
21 ;
22 ; See if we need to do a date roll-over.
23 ;
24 006452 023737 000000G 000000G CMP SYTIMH,DATIMH ;COMPARE HIGH-ORDER TIME VALUE
25 006460 103465 BLO 9$ ;BR IF NOT UP TO 24 HOURS YET
26 006462 023737 000000G 000000G CMP SYTML,DATIML ;COMPARE LOW-ORDER TIME
27 006470 103461 BLO 9$ ;BR IF NOT THERE YET
28 ;
29 ; Do a date roll-over.
30 ;
31 006472 163737 000000G 000000G SUB DATIML,SYTML ;RESET SYSTEM TIMER RELATIVE TO START OF DAY
32 006500 005037 000000G CLR SYTIMH
33 006504 013700 000000G MOV SYSDAT,R0 ;GET SYSTEM DATE VALUE
34 006510 001451 BEQ 9$ ;BR IF NO DATE WAS ENTERED
35 006512 010003 MOV R0,R3 ;GET YEAR FIELD
36 006514 042703 177740 BIC #^C<37>,R3
37 006520 072027 177773 ASH #-5,R0 ;RIGHT JUSTIFY DAY #
38 006524 010001 MOV R0,R1
39 006526 042700 177740 BIC #^C<37>,R0 ;GET DAY # ONLY
40 006532 072127 177773 ASH #-5,R1 ;RIGHT JUSTIFY MONTH VALUE
41 006536 042701 177740 BIC #^C<37>,R1 ;GET MONTH VALUE ONLY
42 006542 005200 INC R0 ;INCREMENT CURRENT DAY NUMBER
43 006544 116102 001321 MOVB MONDAY-1(R1),R2 ;GET # DAYS IN CURRENT MONTH
44 006550 020127 000002 CMP R1,#2 ;IS THIS FEBRUARY?
45 006554 001004 BNE 5$ ;BR IF NOT
46 006556 032703 000003 BIT #3,R3 ;IS THIS A LEAP YEAR?
47 006562 001001 BNE 5$ ;BR IF NOT
48 006564 005202 INC R2 ;SAY FEB HAS 29 DAYS
49 006566 020002 5$: CMP R0,R2 ;HAVE WE PASSED LAST DAY IN THIS MONTH?
50 006570 101411 BLOS 6$ ;BR IF NOT
51 006572 012700 000001 MOV #1,R0 ;RESET DAY # TO 1
52 006576 005201 INC R1 ;ADVANCE MONTH NUMBER
53 006600 020127 000014 CMP R1,#12. ;DID WE JUST ADVANCE PAST DECEMBER?
54 006604 101403 BLOS 6$ ;BR IF NOT
55 006606 012701 000001 MOV #1,R1 ;RESET MONTH TO JANUARY
56 006612 005203 INC R3 ;ADVANCE YEAR NUMBER (HAPPY NEW YEAR)
57 006614 072027 000005 6$: ASH #5,R0 ;POSITION DAY # VALUE
```

CLKDAT -- update time of day and date

```
58 006620 050003           BIS    R0,R3      ; OR INTO YEAR WORD
59 006622 072127 000012     ASH    #10.,R1    ; POSITION MONTH #
60 006626 050103           BIS    R1,R3      ; COMBINE DATE VALUES
61 006630 010337 000000G    MOV    R3,SYSDAT ; SAVE UPDATED DATE VALUE
62
63
;   Finished
64
65 006634 012603           ?$:    MOV    (SP)+,R3
66 006636 012602           MOV    (SP)+,R2
67 006640 012601           MOV    (SP)+,R1
68 006642 000207           RETURN
```

CLKJOB -- check time slice job status

```

1           .SBTTL CLKJOB -- check time slice job status
2
3           ; -----
4           ; CLKJOB is the timer subroutine called every 0.1 seconds to check for
5           ; time-slice expiration of the currently running job.
6
7           006644 010146
8           CLKJOB: MOV      R1,-(SP)
9                   MOV      R2,-(SP)
10
11          006650 113701 000000G
12          006654 001543
13
14          ; See if there is a job currently executing
15
16          006656 005261 000000G
17
18          ; Increment time quantum for job
19
20
21          006662 016100 000000G
22          006666 116102 000000G
23          006672 120237 000000G
24          006676 103412
25          006700 020037 000000E
26          006704 101527
27          006706 005737 000000G
28          006712 001524
29          006714 004037 000000G
30          006720 000000G
31          006722 000411
32          006724 120237 000000G
33          006730 101015
34          006732 020037 000000G
35          006736 101512
36          006740 004037 000000G
37          006744 000000G
38
39
40
41
42          006746 016100 000000G
43          006752 004737 000000G
44          006756 005061 000000G
45          006762 000500
46
47
48
49
50
51          006764 005761 000000G
52          006770 001407
53          006772 005361 000000G
54          006776 001004
55          007000 004037 000000G
56          007004 000000G
57          007006 000464

```

-----

```

; -----
; CLKJOB is the timer subroutine called every 0.1 seconds to check for
; time-slice expiration of the currently running job.
;
; CLKJOB: MOV      R1,-(SP)
;           MOV      R2,-(SP)
;
; See if there is a job currently executing
;
; MOVB    CORUSR,R1      ; GET INDEX # FOR CURRENTLY RUNNING JOB
; BEQ     3$                ; BR IF NO JOB RUNNING NOW
;
; Increment time quantum for job
;
; INC     LQUAN(R1)       ; Increment time quantum for job
;
; Check for time slice expiration for fixed-priority real-time
; and low priority jobs.
;
; MOV     LQUAN(R1),R0      ; Get current time quantum for job
; MOVB   LPRI(R1),R2       ; Get job's execution priority
; CMPB   R2,VPRIHI        ; Is this a high priority (real time) job?
; BLO    10$               ; Br if not
; CMP    R0,VQUANO         ; Have we exceeded QUANO time?
; BLOS   3$                ; Br if not
; TST    VQUANO            ; Are we doing time slicing for real-time jobs?
; BEQ    3$                ; Br if not
; JSR    R0,QUNSIG          ; Signal that QUANO expired
; .WORD  $SGQ0
;
; BR     11$               ; Requeue the job at the tail of the list
; 10$:  CMPB   R2,VPRILO  ; Is this a low priority job?
; BHI    12$               ; Br if not
; CMP    R0,VQUAN3         ; Exceeded low priority quantum?
; BLOS   3$                ; Br if not
; JSR    R0,QUNSIG          ; Signal that QUAN3 has expired
; .WORD  $SGQ3
;
; A real time or low priority job has exceeded its time quantum.
; Requeue the job at the tail of its execution queue.
;
; 11$:  MOV    LSTATE(R1),R0  ; Get job's current execution state
; CALL   ENQTL             ; Requeue job at tail of execution queue
; CLR    LQUAN(R1)          ; Reset job time quantum
; BR     3$                ; Br if not
;
; This job is not a low priority or real time job.
; See if current job is an interactive job, and if so decrement
; its interactive-CPU time.
;
; 12$:  TST    LITIME(R1)   ; Is job interactive?
; BEQ    2$                ; Br if not
; DEC    LITIME(R1)          ; Reduce time remaining for job
; BNE    2$                ; Br if still interactive
; JSR    R0,QUNSIG          ; Signal that QUAN1 has expired
; .WORD  $SGQ1
; BR     6$                ; Now schedule job as compute bound

```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 17-1  
CLKJOB -- check time slice job status

```
58 ; Check for job quantum expiration.
59
60
61 007010 016100 000000G 2$: MOV LQUAN(R1),R0
62 ;
63 ; See if this job is currently running in a high-priority state.
64
65 007014 026127 000000G 000000G CMP LSTATE(R1),#S$$HIP; Is job in high-priority state now?
66 007022 101050 BHI 4$ ;Br if not
67 ;
68 ; Don't do time-slicing for real-time jobs.
69
70 007024 026127 000000G 000000G CMP LSTATE(R1),#S$$RT; Is job in high-priority real-time state?
71 007032 101454 BLOS 3$ ;Br if yes -- skip time-quantum checking
72 ;
73 ; Job is running in a high-priority state.
74 ; See if job is interactive.
75
76 007034 005761 000000G TST LITIME(R1) ; Is this an interactive job?
77 007040 001007 BNE 5$ ;Br if yes
78 007042 020037 000000G CMP RO,VQUN1A ; Time to requeue as compute bound?
79 007046 101446 BLOS 3$ ;Br if not
80 007050 004037 000000G JSR RO,QUNSIG ; Signal that QUAN1A expired
81 007054 000000G .WORD $SGQ1A
82 007056 000440 BR 6$ ; Schedule as compute bound job
83 ;
84 ; Job is "interactive"
85
86 007060 026127 000000G 000000G 5$: CMP LSTATE(R1),#S$$HICP; High priority interactive?
87 007066 103011 BHIS 9$ ;Br if not
88 007070 020037 000000G CMP RO,VQUN1C ; Time to drop to lower level?
89 007074 101406 BLOS 9$ ;Br if not
90 007076 004037 000000G JSR RO,QUNSIG ; Signal that QUAN1C expired
91 007102 000000G .WORD $SGQ1C
92 007104 012700 000000G MOV #S$$HICP,RO ; Drop to interactive computation state
93 007110 000410 BR 7$ ; If QUAN1B has expired, requeue job at tail of current queue
94
95 ; If QUAN1B has expired, requeue job at tail of current queue
96
97 007112 020037 000000G 9$: CMP RO,VQUN1B ; Time to shuffle queue?
98 007116 101422 BLOS 3$ ;Br if not
99 007120 004037 000000G JSR RO,QUNSIG ; Signal that QUAN1B expired
100 007124 000000G .WORD $SGQ1B
101 ;
102 ; Requeue job at tail of current execution queue
103
104 007126 016100 000000G MOV LSTATE(R1),R0 ; Get job's execution state
105 007132 004737 000000G 7$: CALL ENGTL ; Requeue job at tail of execution queue
106 007136 005061 000000G CLR LQUAN(R1) ; Give job a fresh time quantum
107 007142 000410 BR 3$ ; Job is not in high-priority state.
108 ; Schedule jobs on quan2 basis.
109
110 ; Schedule jobs on quan2 basis.
111
112 007144 020037 000000G 4$: CMP RO,VQUAN2 ; HAS JOB USED UP QUAN2 UNITS OF TIME?
113 007150 101405 BLOS 3$ ; BR IF NOT -- DON'T RESCHEDULE JOB YET
114 007152 004037 000000G JSR RO,QUNSIG ; Signal that QUAN2 expired
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 17-2  
CLKJOB -- check time slice job status

```
115 007156 000000G           .WORD    $SGQ2
116
117           ; Reschedule job in CPU-bound run state.
118
119 007160 004737 000000G   6$:    CALL     QCPU      ; RESCHEDULE JOB IN CPU-BOUND STATE
120
121           ; Finished
122
123 007164 012602           3$:    MOV      (SP)+,R2
124 007166 012601           MOV      (SP)+,R1
125 007170 000207           RETURN
```

```
1 .SBTTL CLK01S -- 0.1 second clock processing
2 ;-----
3 ; CLK01S is the timer called every 0.1 seconds to do processing
4 ; at this frequency.
5 ;
6 007172 010246 CLK01S: MOV R2,-(SP)
7 007174 010346 MOV R3,-(SP)
8 ;
9 ; Get # 0.1 second units that have elapsed since the last time we
10 ; were called.
11 ;
12 007176 013703 001342' 16$: MOV TIK01S,R3 ;Get tick counter
13 007202 005203 INC R3 ;Actual time = counter + 1
14 ;
15 ; See if any jobs need to be restarted because they were waiting for
16 ; a free message buffer and one was freed.
17 ;
18 007204 005737 000000G TST MBFFLG ;Were any message buffers freed?
19 007210 001406 BEQ 15$ ;Br if not
20 007212 005037 000000G CLR MBFFLG ;Reset message-buffer-freed flag
21 007216 012700 000000G MOV #S$WSMB, R0 ;Restart any jobs that are
22 007222 004737 000000G CALL UREGO ; waiting for message buffers
23 ;
24 ; Decrement minimum core residency time for jobs in memory.
25 ;
26 007226 012702 000000G 15$: MOV #LSTSL,R2 ;GET # OF LAST JOB
27 007232 032762 000000G 000000G 13$: BIT ##INCR, LSW(R2) ;IS JOB IN MEMORY NOW?
28 007240 001415 BEQ 14$ ;BR IF NOT
29 007242 005762 000000G TST LMING(R2) ;HAS ITS MIN CORE TIME ALREADY EXPIRED?
30 007246 001412 BEQ 14$ ;BR IF YES -- DON'T MAKE IT GO NEGATIVE
31 007250 005362 000000G DEC LMING(R2) ;DEC MIN CORE TIME REMAINING FOR JOB
32 007254 001007 BNE 14$ ;BR IF MIN CORE TIME DID NOT EXPIRE
33 007256 105737 000000G TSTB SWPCOT ;DOES SCHEDULER WANT TO BE CALLED?
34 007262 001404 BEQ 14$ ;BR IF NOT
35 007264 105237 000000G INCB DOSCHD ;REQUEST A JOB SCHEDULER CYCLE
36 007270 105037 000000G CLR B SWPCOT ;CLEAR MIN-TIME SCHEDULER REQUEST
37 007274 162702 000002 14$: SUB #2,R2 ;CHECK NEXT LINE
38 007300 001354 BNE 13$ ;
39 ;
40 ; Keep track of number of minutes of uptime for system.
41 ;
42 007302 160337 000000G SUB R3,MINCTR ;HAS 1 MINUTE PASSED?
43 007306 003013 BGT 1$ ;BR IF NOT
44 007310 062737 001130 000000G ADD #600.,MINCTR ;RESET COUNTER
45 007316 005237 000000G INC MINTIM ;COUNT # MINUTES OF SYSTEM UPTIME
46 007322 005737 000000G TST DTLX ;IS THIS A DEMO VERSION OF THE SYSTEM?
47 007326 001403 BEQ 1$ ;BR IF NOT
48 007330 005337 000000G DEC DTLX ;HAS DEMO TIME LIMIT EXPIRED?
49 007334 001537 BEQ 99$ ;BR IF DEMO TIME LIMIT REACHED
50 ;
51 ; Keep track of user/idle/swap-wait time
52 ;
53 007336 010302 1$: MOV R3,R2 ;Get timer ticks
54 007340 006302 ASL R2 ;Count 2 time units per interval
55 007342 060237 000000G ADD R2,TMTOTL ;COUNT TOTAL TIME
56 007346 005537 000000G ADC TMTOTH ;PROPAGATE CARRY
57 007352 005737 000000G TST UIOCNT ;IS ANY USER I/O IN PROGRESS NOW?
```

CLK01S -- 0.1 second clock processing

```

58 007356 001404           BEQ    7$      ; BR IF NOT
59 007360 060237 000000G     ADD    R2,TMIOL   ; COUNT TIME THAT USER I/O IS ACTIVE
60 007364 005537 000000G     ADC    TMIOH
61 007370 105737 000000G     7$:   TSTB    OUTBSY   ; IS OUTSWAP IN PROGRESS?
62 007374 001003             BNE    8$      ; BR IF YES
63 007376 105737 000000G     TSTB    INBSY    ; IS INSWAP IN PROGRESS?
64 007402 001404             BEQ    9$      ; BR IF NOT
65 007404 060237 000000G     ADD    R2,TMSWPL  ; COUNT TIME SWAP IS IN PROGRESS
66 007410 005537 000000G     ADC    TMSWPH
67 007414 105737 000000G     9$:   TSTB    CORUSR   ; IS A USER JOB IN EXECUTION NOW?
68 007420 001405             BEQ    2$      ; BR IF NOT
69 007422 060237 000000G     ADD    R2,TMUSRL  ; COUNT TIME FOR USER JOB EXECUTION
70 007426 005537 000000G     ADC    TMUSRH
71 007432 000437             BR     3$      ; No user is running.

72                                     ; See if we should count time as swap-wait, i/o-wait or idle.
73                                     ; See if we should count time as swap-wait, i/o-wait or idle.
74 007434 105737 000000G     2$:   TSTB    OUTBSY   ; IS AN OUTSWAP IN PROGRESS?
75 007440 001003             BNE    4$      ; BR IF YES
76 007442 105737 000000G     TSTB    INBSY    ; IS AN INSWAP IN PROGRESS?
77 007446 001415             BEQ    10$     ; BR IF NOT
78                                     ; Swapping is in progress. See if user I/O is also going on.
79 007450 005737 000000G     4$:   TST    UIOCNT   ; IS USER I/O IN PROGRESS?
80 007454 001405             BEQ    11$     ; BR IF NOT
81 007456 006202             ASR    R2      ; SPLIT TIME BETWEEN SWAP-WAIT AND I/O-WAIT
82 007460 060237 000000G     ADD    R2,TMIOWL  ; CHARGE TO I/O-WAIT
83 007464 005537 000000G     ADC    TMIOWH
84 007470 060237 000000G     11$:  ADD    R2,TMSWTL  ; CHARGE TO SWAP-WAIT
85 007474 005537 000000G     ADC    TMSWTH
86 007500 000414             BR     3$      ; No swapping going on. See if user I/O is in progress.
87                                     ; No swapping going on. See if user I/O is in progress.
88 007502 005737 000000G     10$:  TST    UIOCNT   ; IS USER I/O IN PROGRESS?
89 007506 001405             BEQ    12$     ; BR IF NOT
90 007510 060237 000000G     ADD    R2,TMIOWL  ; CHARGE TO I/O-WAIT
91 007514 005537 000000G     ADC    TMIOWH
92 007520 000404             BR     3$      ; System is idle.
93                                     ; System is idle.
94 007522 060237 000000G     12$:  ADD    R2,TMIDLH  ; CHARGE TO IDLE TIME
95 007526 005537 000000G     ADC    TMIDLH
96                                     ;
97                                     ; Check for time-slice expiration of current job
98                                     ;
99 007532 004737 006644'     3$:   CALL   CLKJOB    ; CHECK FOR TIME-SLICE EXPIRATION OF CUR JOB
100                                    ;
101                                    ; Check to see if we need to cancel I/O hold flag for any jobs
102                                    ;
103 007536 004737 007646'     CALL   CLKIOH    ; Check for I/O hold flags
104                                    ;
105                                    ; Check for processing needed for autobaud logic
106                                    ;
107 007542 004737 011116'     CALL   CLKABD    ; Check for autobaud timer processing
108                                    ;
109                                    ; Processing done with 0.5 second frequency.
110                                    ;
111 007546 160337 000000G     SUB    R3,TK5CNT  ; Has 0.5 seconds passed?
112 007552 003020             BGT    6$      ; BR IF NOT
113 007554 062737 000005 000000G    ADD    #5.,TK5CNT ; RESET TIMER
114 007562 004737 011210'     CALL   TLCHK    ; DO TIMED CHECKS ON TIMESHARING LINES

```

```
115 007566 004737 010102'          CALL    WAKEUP      ; SEE IF WE NEED TO WAKE UP SLEEPING JOBS
116 007572 004737 007746'          CALL    CHKPRT     ; See if we need to print professional screen
117 007576 005727 0000000G        TST     #CLTOTL    ; Are there any CL lines?
118 007602 001404                 BEQ     6$          ; Br if not
119 007604 005237 0000000G        INC     NEDCDO     ; Say output character processing needed
120 007610 005237 0000000G        INC     NEDCLO     ; Trigger CL clock-driven processing
121
122
123
124 007614 160337 001342'          6$:    SUB     R3,TIKO1S   ; Have any more 0.1 second intervals passed?
125 007620 002402                 BLT     17$          ; Br if not
126 007622 000137 007176'          JMP     16$          ; Go back and process again
127
128
129
130 007626 012603                 17$:   MOV     (SP)+,R3
131 007630 012602                 MOV     (SP)+,R2
132 007632 000207                 RETURN
133
134
135
136
137 007634                 99$:   DIE     #EM$DTL    ; SYSTEM CRASH -- DEMO TIME LIMIT REACHED
```

CLKIOH -- See if we need to cancel I/O hold timers

```

1           .SBTTL CLKIOH -- See if we need to cancel I/O hold timers
2
3           ; -----
4           ; This routine is called every 0.1 second to see if we should cancel
5           ; the I/O hold timers for any jobs. The I/O hold timer is set when we
6           ; want to swap a job out of memory but the job has I/O in progress.
7           ; To avoid holding the I/O for a job forever, we release the I/O hold
8           ; after a certain period of time (IOHLM) if a swap has not taken place.
9
10          9 007646 010146
11
12          CLKIOH: MOV      R1,-(SP)
13
14          13 007650 012701 0000000
15
16          ; Begin loop to check I/O hold time for each job
17          ; MOV      #LSTSL,R1      ;Get index to last job
18
19          ; See if I/O hold flag is set for this job
20
21          ; 1$:   TST      LIOHLD(R1)    ; Is I/O hold flag set for job?
22          ; BEQ      2$                  ; Br if not
23
24          ; Decrement the remaining I/O hold time
25
26          ; 22 007662 005361 0000000
27          ; DEC      LIOHLD(R1)    ; Less I/O hold time left
28          ; BGT      2$                  ; Br if some time left
29
30          ; We just cancelled the I/O hold time for this job.
31          ; If the job is in a wait state, restart it.
32
33          ; 25 007670 026127 0000000 0000000
34          ; CMP      LSTATE(R1),#S$IOWT ; Is job in I/O wait state?
35          ; BNE      3$                  ; Br if not
36          ; CALL     FORCEX      ; Start the job running
37          ; BR       2$                  ; Br if not
38
39          ; 32 007704 000413
40          ; If the job has any pending completion routines, make sure the job
41          ; priority is at least as high as that of the 1st completion routine.
42          ; This is necessary since we held off user completion routines while
43          ; we were waiting for I/O to stop.
44
45          ; 38 007706 016100 0000000
46          ; 3$:   MOV      LCMPL(R1),R0    ; Does job have any pending compl routines?
47          ; BEQ      2$                  ; Br if not
48          ; 40 007712 001410
49          ; CMPB     LSTATE(R1),CQ$RNS(R0); Is job priority high as cpl rtn prio?
50          ; BLOS      2$                  ; Br if yes
51          ; 42 007722 101404
52          ; MOVB     CQ$RNS(R0),R0    ; Get job state for compl routine
53          ; CALL     ENQTL      ; Change job state
54
55          ; 44 007724 116000 0000000
56          ; Process next job
57
58          ; 47 007734 162701 000002
59          ; 2$:   SUB      #2,R1      ; Get index of next job
60          ; BGT      1$                  ; Loop if more jobs to check
61
62          ; 49 007740 003345
63          ; Finished
64
65          ; 52 007742 012601
66          ; MOV      (SP)+,R1
67          ; RETURN

```

CHKPRT -- See if we need to print Professional screen

```

1           .SBTTL  CHKPRT -- See if we need to print Professional screen
2
3           ; -----
4           ;   CHKPRT is called to see if the PI handler has requested that the
5           ;   contents of the professional screen be printed. If so, an asynchronous
6           ;   completion routine in the PROPRPT program is triggered.
7
8           007746  010246      CHKPRT: MOV      R2,-(SP)
9           007750  010446          MOV      R4,-(SP)
10          ;   Return immediately if we are not running on a professional
11          ;
12 007752  105737  000000G      TSTB    PROFLOG      ; Are we running on a Professional?
13 007756  001446          BEQ      9$          ; Br if not
14          ;
15          ;   See if the PROPRPT program is running
16          ;
17 007760  012702  000000G      MOV      #LSTSL,R2      ; Get index to last line
18 007764  026237  000000G 001344' 1$:  CMP      LPRG1(R2),R5OPRO; 1st 3 chars of name = "PRO"?
19 007772  001004          BNE      2$          ; Br if not
20 007774  026237  000000G 001346' 2$:  CMP      LPRG2(R2),R5OPRT; 2nd 3 chars of name = "PRT"?
21 010002  001404          BEQ      3$          ; Br if found program
22 010004  162702  000002          SUB      #2,R2      ; More lines to check?
23 010010  003365          BGT      1$          ; Loop if yes
24 010012  000425          BR       4$          ; PROPRPT program is not running
25          ;
26          ;   The PROPRPT program is running. See if it has scheduled a
27          ;   completion routine.
28          ;
29 010014  005762  000000G 3$:  TST      LBRKCQ(R2)      ; Did it specify a completion routine?
30 010020  001422          BEQ      4$          ; Br if not
31 010022  052737  000000G 000000G      BIS      #SS$RUN,SPSTAT      ; Set flag saying spooler is running
32          ;
33          ;   See if PI handler requested that screen be printed
34          ;
35 010030  032737  000000G 000000G      BIT      #SS$PRT,SPSTAT      ; Did PI request that screen be printed?
36 010036  001416          BEQ      9$          ; Br if not
37          ;
38          ;   Trigger completion routine in PROPRPT
39          ;
40 010040  016204  000000G      MOV      LBRKCQ(R2),R4      ; Get address of completion queue element
41 010044  001404          BEQ      5$          ;
42 010046  005062  000000G      CLR      LBRKCQ(R2)      ; Say completion Q element used up
43 010052  004737  000000G      CALL    QCOMPL      ; Queue completion routine for the job
44 010056  042737  000000C 000000G 5$:  BIC      #SS$PRT!SS$RUN,SPSTAT      ; Clear print-screen flag
45 010064  000403          BR       9$          ;
46          ;
47          ;   The PROPRPT program is not running
48          ;
49 010066  042737  000000C 000000G 4$:  BIC      #SS$RUN!SS$PRT,SPSTAT      ; Say program not running
50          ;
51          ;   Finished
52          ;
53 010074  012604          9$:  MOV      (SP)+,R4
54 010076  012602          MOV      (SP)+,R2
55 010100  000207          RETURN

```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 21  
WAKEUP -- 0.5 second processing for sleeping users

```
1 .SBTTL WAKEUP -- 0.5 second processing for sleeping users
2 ;-----
3 ; Timer routine called ever 0.5 seconds to see if sleeping users
4 ; need to be awaken.
5 ;
6 010102 010146
7 010104 012701 000000G
8 ;
9 ; Check for jobs that need to have TT reads timed out
10 ;
11 010110 026127 000000G 000000G 1$: CMP LSTATE(R1),#$INWT; IS JOB WAITING FOR TT INPUT?
12 010116 001015 BNE 2$ ;BR IF NOT
13 010120 005761 000000G TST LRDTIM(R1) ;DOES JOB HAVE A TT READ TIME VALUE SPECIFIED?
14 010124 001412 BEQ 2$ ;BR IF NOT
15 010126 005361 000000G DEC LRDTIM(R1) ;HAS TIME EXPIRED?
16 010132 001007 BNE 2$ ;BR IF NOT
17 010134 010546 MOV R5,-(SP)
18 010136 016105 000000G MOV LRTCHR(R1),R5 ;GET TIME-OUT ACTIVATION CHARACTER
19 010142 OCALL STRACT ;STORE ACTIVATION CHARACTER
20 010150 012605 MOV (SP)+,R5
21 ;
22 ; Check next line
23 ;
24 010152 162701 000002 2$: SUB #2,R1 ;GET NEXT LINE INDEX
25 010156 001354 BNE 1$ ;BR IF THERE IS ANOTHER LINE TO CHECK
26 ;
27 ; Finished
28 ;
29 010160 012601 MOV (SP)+,R1
30 010162 000207 RETURN
```

CKTWAT -- Check on jobs doing .TWAIT waits

```

1           .SBTTL CKTWAT -- Check on jobs doing .TWAIT waits
2
3           ; -----
4           ; CKTWAT is called every clock tick to see if any jobs doing .TWAIT waits
5           ; need to be restarted.
6
7           CKTWAT: MOV      R1,-(SP)
8
9           ; Check for jobs doing timed waits (.twait)
10          ;
11          010164 010146
12          010166 012701 000000G
13          010172 026127 000000G 000000G 4$:    MOV      #LSTSL,R1      ; GET HIGHEST JOB INDEX NUMBER
14          010200 001024
15          010202 163761 000000G 000000G        CMP      LSTATE(R1),#S$TMWT; IS THIS JOB DOING A TIMED WAIT?
16          010210 005661 000000G        BNE      5$          ; BR IF NOT
17          010214 002404
18          010216 001015
19          010220 005761 000000G        SUB      CLKCNT,LSLEPL(R1); DEC SLEEP TIME
20          010224 001012
21          010226 005761 000000G        SBC      LSLEPH(R1)       ; PROPOGATE CARRY
22          010232 001403
23          010234 012700 000000G        BLT      6$          ; BR IF COUNT WENT NEGATIVE
24          010240 000402
25          010242 012700 000000G        BNE      5$          ; BR IF GREATER THAN ZERO
26          010246 004737 000000G        TST      LSLEPL(R1)       ; CHECK LOW-ORDER VALUE
27          010252 162701 000002
28          010256 001345
29          010260 012601
30          010262 000207        BNE      5$          ; BR IF NOT ZERO
31
32          ; Timed wait is completed.
33          ; Put job in high priority execution state.
34          ; Finished
35          ;           MOV      (SP)+,R1
36          ;           RETURN

```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 24  
CKMRKT -- check mark-time requests

```
1           .SBTTL CKMRKT -- check mark-time requests
2
3           ; -----
4           ; CKMRKT is called every clock tick to see if any mark-time requests have
5           ; reached their specified time to be triggered.
6
7           CKMRKT: MOV      R1,-(SP)
8               MOV      R2,-(SP)
9               MOV      R4,-(SP)
10
11          ; Check for pending mark-time requests
12
13          CLR      FORKIT      ;Clear fork request flag
14          MOV      #MRKTHD-CQ$LNK,R2;FAKE POINTER TO QUEUE HEAD
15          DISABL
16          1$:    MOV      CQ$LNK(R2),R4   ;;;GET ADDRESS OF NEXT ELEMENT IN LIST
17          BEQ      8$       ;;;BR IF END OF LIST REACHED
18
19          ; Subtract time that has past from specified mark-time interval.
20
21          20 010316 163764 000000G 000000G      SUB      CLKCNT,CQ$LOT(R4);;SUBTRACT FROM LOW-ORDER TIME VALUE
22          21 010324 005664 000000G      SBC      CQ$HOT(R4)      ;;;PROPAGATE BORROW TO HIGH-ORDER VALUE
23          22 010330 002406
24          23 010332 001003
25          24 010334 005764 000000G      BLT      3$       ;;;BR IF TIME WENT NEGATIVE
26          25 010340 001402
27          26 010342 010402      BNE      2$       ;;;BR IF TIME STILL POSITIVE
28          27 010344 000761      TST      CQ$LOT(R4)      ;;;CHECK LOW-ORDER VALUE
29          BEQ      3$       ;;;Br if zero (time has elapsed)
30          2$:    MOV      R4,R2      ;;;Chain forward to next entry in list
31          BR      1$
32
33          ; This mark-time request has expired.
34          ; Remove the mark-time request entry from the waiting list.
35
36          32 010346 016462 000000G 000000G 3$:    MOV      CQ$LNK(R4),CQ$LNK(R2);;Remove from pending mark-time chain
37
38          37 010354 005064 000000G      CLR      CQ$LNK(R4)      ;;;Clear forward link in completed element
39          38 010360 013700 000000G      MOV      SYPNCR,RO      ;;;Get address of 1st pending compl request
40          39 010364 001005      BNE      9$       ;;;Br if there are pending requests
41
42          ; First entry of completion requires a fork process to be executed.
43
44          43 010366 010437 000000G 5$:    MOV      R4,SYPNCR      ;;;Set us as 1st pending compl routine
45          44 010372 010437 001336'      MOV      R4,FORKIT      ;;;Set fork request flag
46          45 010376 000744      BR      1$       ;;;Go check for more finished requests
47
48          ; Other completion entries exist so add current completion to list tail.
49
50          49 010400 005760 000000G 9$:    TST      CQ$LNK(RO)      ;;;Is there another pending request?
51          50 010404 001403      BEQ      6$       ;;;Br if not
52          51 010406 016000 000000G      MOV      CQ$LNK(RO),RO      ;;;Chain forward to next pending request
53          52 010412 000772      BR      9$       ;;;Follow list to end
54          53 010414 010460 000000G 6$:    MOV      R4,CQ$LNK(RO)      ;;;Add our entry to end of list
55          54 010420 000733      BR      1$       ;;;Check for more completed requests
56
57          ; Finished. Create fork process if needed.
```

CKMRKT -- check mark-time requests

58 010422		B\$: ENABL	; ** Enable interrupts **
59 010430	005737	TST FORKIT	; Check fork request flag
60 010434	001412	BEQ 10\$	; Br if fork is not needed
61 010436	004737	CALL FRKGET	; Get a free fork request block
62 010442	112764	MOV#FP\$IDF, FQ\$PRI(R4)	; Set fork priority
63 010450	012764	MOV#CLKSCR, FQ\$RTN(R4)	; Set address of routine to execute
64 010456	004737	CALL FORKQ	; Queue the fork request
65 010462	012604	10\$: MOV(SP)+, R4	
66 010464	012602	MOV(SP)+, R2	
67 010466	012601	MOV(SP)+, R1	
68 010470	000207	RETURN	

```
1 .SBTTL CLKSCR -- Execute completed system mark-time requests
2 ;
3 ; This routine is at a lower-priority clock-driven fork priority
4 ; to process all completed mark-time completion requests for system
5 ; routines.
6 ;
7 010472 010146
8 010474 010446
9 ;
10 ; Unlink next completed entry from pending list
11 ;
12 010476 1$: DISABL ;** Disable interrupts **
13 010504 013704 000000G MOV SYPNCR,R4 ;;Get address of next completion block
14 010510 001433 BEQ 9$ ;;Br if no more pending
15 010512 016437 000000G 000000G MOV CQ$LNK(R4),SYPNCR ;;Unlink block from list
16 010520 ENABL ;** Enable interrupts **
17 ;
18 ; See if this mark-time request is for a user job or the system.
19 ;
20 010526 112764 000000G 000000G MOVB #CP$STD,CQ$CP(R4);Set completion routine class priority
21 010534 116401 000000G MOVB CQ$JOB(R4),R1 ;Get index # of job that did the .MRKT
22 010540 001414 BEQ 4$ ;Br if timer request came from the system
23 ;
24 ; Timer request is for a user job.
25 ; Call QCOMPL to queue the completion routine for the user job.
26 ;
27 010542 012700 000000G MOVB #S$TWFN,R0 ;Get compl prio for non-interactive jobs
28 010546 005761 000000G TST LITIME(R1) ;Is this job interactive?
29 010552 001402 BEQ 2$ ;Br if not
30 010554 012700 000000G MOVB #S$HICP,R0 ;Get compl prio for interactive jobs
31 010560 110064 000000G 2$: MOVB R0,CQ$RNS(R4) ;Set execution state for compl routine
32 010564 116164 000000G 000000G MOVB LPRI(R1),CQ$PRI(R4);Set execution priority value
33 ;
34 ; Process this completion request
35 ;
36 010572 004737 000000G 4$: CALL QCOMPL ;Process the completed request
37 ;
38 ; Go back and see if there are more pending requests
39 ;
40 010576 000737 BR 1$
41 ;
42 ; Finished all pending requests
43 ;
44 010600 9$: ENABL
45 010606 012604 MOV (SP)+,R4
46 010610 012601 MOV (SP)+,R1
47 010612 000207 RETURN
```

```
1           .SBTTL CLKPM -- accumulate performance monitoring data
2
3           ;-----  

4           ; CLKPM is called to accumulate performance monitoring information.  

5           ; Inputs:  

6           ; CLKCNT = Number of clock ticks to charge to job.  

7           ; CLKPC = PC when clock interrupt occurred.  

8           ; CLKPS = PS when clock interrupt occurred.  

9           ; PMUSER = Job number of user who is doing performance analysis.  

10          ; PMBASE = Base address of region being monitored.  

11          ; PMTOP = Top address of region being monitored.  

12          ; PMFLGS = PF$ control flags  

13          ; LEMTPC(Job) = PC when last EMT was executed for job.  

14
15          ; Outputs:  

16          ; Appropriate cell in performance counter table is incremented.  

17
18 010614 010146          CLKPM: MOV      R1,-(SP)
19 010616 010246          MOV      R2,-(SP)
20 010620 010346          MOV      R3,-(SP)
21
22          ; See if we are monitoring system execution or user job execution.  

23
24 010622 032737 000000G 000000G          BIT      #PF$SYS,PMFLGS ;MONITORING SYSTEM OR USER JOB?
25 010630 001407          BEQ      4$                   ;BR IF MONITORING USER JOB
26
27 010632 032737 000000G 000000G          ; We are monitoring the system.
28 010640 001065          BIT      #UMODE,CLKPS   ;DID INTERRUPT OCCUR IN KERNEL MODE?
29 010642 013703 000000G          BNE      9$                   ;BR IF NOT -- USER WAS RUNNING
30 010646 000432          MOV      CLKPC,R3    ;GET ADDRESS WHERE INTERRUPT OCCURED
31
32          ; We are monitoring user job execution.
33          ; Determine if we should count a hit against running job.
34
35 010650 013701 000000G          4$:    MOV      PMUSER,R1    ;GET # OF JOB BEING MONITORED
36 010654 032761 000000G 000000G          BIT      #$_INKMN,LSW4(R1); IS KMON RUNNING?
37 010662 001054          BNE      9$                   ;DON'T MONITOR KMON
38 010664 120137 000000G          CMPB    R1,CORUSR   ;IS JOB BEING MONITORED THE CURRENT JOB?
39 010670 001007          BNE      1$                   ;BR IF NOT
40
41          ; Monitored job is running now.
42 010672 032737 000000G 000000G          ; See if interrupt occurred in user or kernel mode.
43 010700 001413          BIT      #UMODE,CLKPS   ;DID INTERRUPT OCCUR IN USER OR KERNEL MODE?
44 010700 001413          BEQ      2$                   ;BR IF IN KERNEL MODE
45 010702 013703 000000G          ; Job was in user mode so use interrupted PC.
46 010706 000412          MOV      CLKPC,R3    ;COUNT HIT AGAINST THIS PC
47
48          ; Monitored job is not now running.
49 010710 032737 000000G 000000G          ; See if we should charge I/O wait time to job.
50 010716 001436          1$:    BIT      #PF$IOW,PMFLGS ;SHOULD WE CHARGE FOR I/O WAIT TIME?
51 010716 001436          BEQ      9$                   ;BR IF NOT
52 010720 026127 000000G 000000G          ; See if monitored job is waiting for I/O.
53 010726 001032          CMP      LSTATE(R1),#S$IOWT; IS MONITORED JOB WAITING FOR I/O?
54 010726 001032          BNE      9$                   ;BR IF NOT
55 010730 016103 000000G          ; Use last EMT address as cell to charge hit to.
56 010730 016103 000000G          2$:    MOV      LEMTPC(R1),R3 ;GET ADDRESS OF LAST EMT DONE BY JOB
57
58          ; At this point we have in R3 the PC that we are to charge this time to.
```

CLKPM -- accumulate performance monitoring data

```
58 ; See if the PC is in the region being monitored.  
59  
60 010734 020337 000000G 3$: CMP R3, PMBASE ; IS IT BELOW BASE OF REGION?  
61 010740 103425 BLO 9$ ; BR IF YES  
62 010742 020337 000000G CMP R3, PMTOP ; IS IT ABOVE TOP OF REGION?  
63 010746 103022 BHIS 9$ ; BR IF YES  
64 ; PC is in region being monitored.  
65 010750 163703 000000G SUB PMBASE, R3 ; SUBTRACT BASE TO GET OFFSET  
66 010754 005002 CLR R2 ; SET FOR DIVIDE  
67 010756 071237 000000G DIV PMNBPC, R2 ; DIVIDE BY # BYTES PER CELL  
68 010762 006302 ASL R2 ; CONVERT CELL # TO BYTE #  
69 010764 062702 000000G ADD #VPAR6, R2 ; ADD VIRTUAL ADDRESS OF PAR6 REGION  
70 010770 013737 000000G 000000G MOV PMPAR, @#KPAR6 ; MAP PAR6 TO PM DATA AREA  
71 010776 063712 000000G ADD CLKCNT, (R2) ; ADD TIME TO COUNTER FOR THIS CELL  
72 011002 103004 BCC 9$ ; BR IF NO OVERFLOW OF CELL  
73 011004 005312 DEC (R2) ; SET COUNTER VALUE BACK TO -1  
74 011006 052737 000000G 000000G BIS #PF$OVF, PMFLGS ; REMEMBER THAN AN OVERFLOW OCCURED  
75 ;  
76 ; Finished  
77  
78 011014 012603 9$: MOV (SP)+, R3  
79 011016 012602 MOV (SP)+, R2  
80 011020 012601 MOV (SP)+, R1  
81 011022 000207 RETURN
```

CKSCHD -- Check jobs and schedule

```

1           .SBTTL CKSCHD -- Check jobs and schedule
2
3           ; -----
4           ; CKSCHD will check all the jobs and schedule those that have been flagged
5           ; as needing a priority boost because of output buffer empty or low.
6
7           ; Inputs:
8           ;       LSW7 - job scheduling flag
9 011024 010046
10 011026 010146
11 011030 012701 000000G
12
13           ; Check all jobs to see if any need a priority boost for terminal buffer
14           ; empty or low.
15
16 011034 032761 000000G 000000G 1$:    BIT    ##$OTFN, LSW7(R1)      ; Check for scheduling flag enable
17 011042 001417          BEQ    1$                   ; Br if no scheduling required
18 011044 042761 000000G 000000G          BIC    ##$OTFN, LSW7(R1)      ; Reset job scheduling flag
19 011052 012700 000000G          MOV    #S$OTFN, R0        ; Get output-buffer empty state
20 011056 005761 000000G          TST    LITIME(R1)        ; Is this an interactive job?
21 011062 001002          BNE    2$                   ; Br if yes
22 011064 012700 000000G          MOV    #S$OTLO, R0        ; If not interactive then use lower pri
23 011070 026100 000000G          2$:   CMP    LSTATE(R1), R0      ; Is job already in this prio or better
24 011074 101402          BLOS   10$                  ; Br if yes
25 011076 004737 000000G          CALL   ENQTL            ; Queue job at tail of execution list
26
27           ; Check the next line.
28
29 011102 162701 000002          10$:  SUB    #2, R1        ; Check the next job
30 011106 003352          BGT    1$                   ; Continue until all job tested
31 011110 012601          MOV    (SP)+, R1        ; Restore registers
32 011112 012600          MOV    (SP)+, RO
33 011114 000207          RETURN

```

CLKABD -- Clock processing for autobaud logic

```

1           .SBTTL CLKABD -- Clock processing for autobaud logic
2
3           ; -----
4           ; CLKABD is called on a 1/10 second basis to do clock driven processing
5           ; related to autobaud logic.
6 011116 010146
7           CLKABD: MOV      R1,-(SP)
8
9           ; Begin loop to check each line
10 011120 012701 000000G
11           MOV      #LSTPL,R1          ;Get index # of last line
12
13           ; See if this line has autobaud control
14 011124 032761 000000G 000000G 1$:   BIT      #$AUTO,ILSW2(R1); Does this line have autobaud control?
15 011132 001421
16           BEQ      2$              ;Br if not
17
18           ; Decrement autobaud timer for this line
19 011134 005761 000000G
20 011140 001416
21 011142 005361 000000G
22 011146 001013
23
24           TST      LABTIM(R1)    ; Is the autobaud timer active?
25           BEQ      2$              ;Br if not
26           DEC      LABTIM(R1)    ;Decrement timer
27           BNE      2$              ;Br if timer did not time out
28
29           ; Timer timed out for this line.
30           ; See if we need to reset the line speed.
31
32           ; Do we need to reset the line speed?
33 011150 032761 000000G 000000G
34           BIT      #$NABRS,LSW9(R1); Do we need to reset the line speed?
35 011156 001407
36 011160 042761 000000G 000000G
37           BEQ      2$              ;Br if not
38           BIC      #$NABRS,LSW9(R1); Clear the flag
39           MOV      #S9600,R0      ;Reset line speed to 9600 baud
40           CALL     SETSPD        ;Reset speed
41
42           ; Check next line
43
44 011176 162701 000002
45           2$:   SUB      #2,R1          ;More lines to do?
46           BGT      1$              ;Loop if yes
47
48           ; Finished
49
50 011204 012601
51 011206 000207
52           MOV      (SP)+,R1
53           RETURN

```

TLCHK -- Check Dial-up line status

```

1           .SBTTL TLCHK -- Check Dial-up line status
2
3           ;-----  

4           ; TLCHK is called from the clock interrupt routine every 0.5 seconds  

5           ; to see if dial-up lines need to be answered or hung up.  

6           ;  

7 011210 010146      TLCHK: MOV      R1,-(SP)
8 011212 010246          MOV      R2,-(SP)
9
10          ; Begin loop to check each physical line
11 011214 012701 000000G      MOV      #LSTHL,R1      ; Index to last real line
12
13          ; See if this line is installed
14
15 011220 032761 000000G 000000G 1$:    BIT      #$DEAD,LSW3(R1) ; Is this line installed?
16 011226 001024          BNE      2$          ; Br if not
17 011230 032761 000000G 000000G          BIT      #$HARD,LSW3(R1) ; Is this line connected to hardware?
18 011236 001420          BEQ      2$          ; Br if not
19
20          ; Call processing routine based on type of communications device
21
22 011240 016102 000000G      MOV      LCDTYP(R1),R2      ; Get comm device index number
23 011244 004772 000000G      CALL     @CDCCLK(R2)      ; Call processing routine for this line
24
25          ; If this is a dial-up line, check on line ringing, lost carrier, etc.
26
27 011250 005761 000000G      TST      LCLUNT(R1)      ; Is this line in use as a CL unit?
28 011254 002011          BGE      2$          ; Br if this is a CL line
29 011256 032761 000000G 000000G          BIT      #$PHONE,ILSW2(R1); Is this a dial-up line?
30 011264 001405          BEQ      2$          ; Br if not
31 011266 020127 000000G          CMP      R1,#LSTPL      ; Is this a time-sharing or CL line?
32 011272 101002          BHI      2$          ; Don't do phone checks for CL lines
33 011274 004737 011314'          CALL     CLKPHN      ; Check phone line
34
35          ; See if there are more lines to be checked
36
37 011300 162701 000002      2$:    SUB      #2,R1      ; Get index number for next line
38 011304 001345          BNE      1$          ; Loop if more lines to check
39
40          ; Finished
41
42 011306 012602      MOV      (SP)+,R2
43 011310 012601      MOV      (SP)+,R1
44 011312 000207      RETURN

```

```
1 .SBTTL CLKPHN -- Do timer driven checks of dial-up lines
2 ;
3 ; CLKPHN is called periodically to perform checks on dial-up lines.
4 ; Checks are made to see if the phone is ringing or if carrier
5 ; has been detected or lost.
6 ;
7 ; Inputs:
8 ; R1 = Physical line index number.
9
10 011314 010246
11 CLKPHN: MOV R2,-(SP)
12 ;
13 ; Call device-dependent routine to get the data set status for this line
14 011316 016102 000000G
15 011322 004772 000000G
16 ;
17 ; At this point, the generic modem status (MS$xxx flags) is in R0.
18 ; See if the phone is ringing
19 ;
20 011326 105737 000000G
21 011332 001020
22 011334 032700 000000G
23 011340 001415
24 011342 032700 000000G
25 011346 001012
26 ;
27 ; Time to answer ringing phone
28 ;
29 011350 052700 000000G
30 011354 004772 000000G
31 011360 013761 000000G 000000G
32 011366 013761 000000G 000000G
33 ;
34 ; Check status of carrier on dial-up lines.
35 ;
36 011374 032700 000000G
37 011400 001054
38 ;
39 ; Carrier is down
40 ;
41 011402 005361 000000G
42 011406 003057
43 011410 042761 000000G 000000G
44 011416 032761 000000G 000000G
45 011424 001407
46 011426 105737 000000G
47 011432 001004
48 011434 032761 000000G 000000G
49 011442 001436
50 011444 052761 000000G 000000G
51 011452 032761 000000G 000000G
52 011460 001415
53 011462 032761 000000C 000000G
54 011470 001026
55 011472 032761 000000G 000000G
56 011500 001022
57 011502 010100
11$: DEC LCDTIM(R1) ;Has it been down very long?
BGT 8$ ;Br if not
BIC ##CARUP,LSW3(R1);Remember that we have lost carrier
BIT ##DILUP,LSW(R1) ;Is line active?
BEQ 1$ ;Br if not
TSTB VUSPHN ;Should we always mon. carrier for line?
BNE 1$ ;Br if so
BIT ##CARMN,LSW5(R1);Are we monitoring carrier for this line?
BEQ 17$ ;Br if not
BIS ##NOIN,LSW3(R1) ;Ignore tt input from the line
BIT ##DILUP,LSW(R1) ;Is line active?
BEQ 21$ ;Br if not
BIT #<$DISCN+$DOOFF>,LSW(R1);Are we logging off line now?
BNE 8$ ;Br if yes -- that takes care of it
BIT ##LOFCF,LSW9(R1);Are we doing logoff command file now?
BNE 8$ ;Br if yes
MOV R1,R0 ;Get index of job being aborted
```

CLKPHN -- Do timer driven checks of dial-up lines

```
58 011504          OCALL   KILJOB      ;Kill the job
59 011512 000415    BR      8$          ;
60 011514 042700 000000G 21$: BIC     #MS$DTR, R0      ;Drop data terminal ready (hang up)
61 011520 004772 000000G          CALL    @CDSDSS(R2)  ;Set data set status
62 011524 005061 000000G          CLR     LOFFTM(R1)   ;Clear logoff timer
63 011530 000403          BR      17$          ;
64          ;
65          ; Carrier is up
66          ;
67 011532 052761 000000G 000000G 16$: BIS     ##$CARUP, LSW3(R1); Remember carrier is up
68          ;
69          ; Reset lost-carrier timer
70          ;
71 011540 013761 000000G 000000G 17$: MOV     VTMOUT, LCDTIM(R1); Reset carrier-lost timer
72          ;
73          ; If jobs on dial-up lines remain in a logged off state for more than
74          ; a specified interval, drop DTR to hang up on them.
75          ;
76 011546 005761 000000G 8$: TST     LOFFTM(R1)   ;Do we need to check time for this job?
77 011552 001407          BEQ     6$          ;Br if not
78 011554 005361 000000G          DEC     LOFFTM(R1)   ;Is it time to drop DTR for this line?
79 011560 003004          BGT     6$          ;Br if not
80 011562 042700 000000G          BIC     #MS$DTR, R0      ;Drop data terminal ready (hang up)
81 011566 004772 000000G          CALL    @CDSDSS(R2)  ;Set data set status
82          ;
83          ; Finished
84          ;
85 011572 012602 6$: MOV     (SP)+, R2
86 011574 000207          RETURN
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 31  
DLGDSS -- Get data set status for DL11 line

```
1 .SBTTL DLGDSS -- Get data set status for DL11 line
2 ;-----
3 ; DLGDSS is called to get the data set status for a DL11 line.
4 ;
5 ; Inputs:
6 ; R1 = Physical line index number.
7 ;
8 ; Outputs:
9 ; RO = Generic data set status flags (MS$xxx)
10;
11 011576 010346
12 011600 005000
13;
14; Get contents of DL11 receiver status register
15;
16 011602 017103 000000G
17;
18; See if line is ringing
19;
20 011606 032703 000000G
21 011612 001402
22 011614 052700 000000G
23;
24; See if carrier is up or down
25;
26 011620 032703 000000G
27 011624 001402
28 011626 052700 000000G
29;
30; See if Data Terminal Ready is asserted
31;
32 011632 032703 000000G
33 011636 001402
34 011640 052700 000000G
35;
36; Finished
37;
38 011644 012603
39 011646 000207
```

DLGDSS: MOV R3,-(SP)  
CLR RO ;Form result in RO

MOV @RSR(R1),R3 ;Get receiver status register contents

BIT #RING,R3 ; Is phone ringing?  
BEQ 1\$ ;Br if not  
BIS #MS\$RNG,RO ;Set ring flag

BIT #CARDET,R3 ; Is carrier up or down?  
BEQ 2\$ ;Br if down  
BIS #MS\$CAR,RO ;Set carrier-up flag

BIT #TRMRDY,R3 ; Is DTR asserted?  
BEQ 3\$ ;Br if not  
BIS #MS\$DTR,RO ;Set DTR flag

MOV (SP)+,R3  
RETURN

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 32  
DLSDSS -- Set data set status for DL11 line

```
1           .SBTTL  DLSDSS -- Set data set status for DL11 line
2
3           ; -----
4           ; DLSDSS is called to set data set control status for a DL11 line.
5
6           ; Inputs:
7           ; R1 = Physical line index number.
8           ; R0 = Control flags (MS$DTR)
9
10          011650
11
12          DLSDSS:
13          011650  032700  000000G      BIT    #MS$DTR, R0      ; Set or drop DTR?
14          011654  001404            BEQ    1$                  ; Br to drop DTR
15
16          ; Set DTR
17
18          011656  052771  000000G  000000G      BIS    #TRMRDY, @RSR(R1); Set Data Terminal Ready
19          011664  000403            BR     9$                  ;
20
21          ; Drop DTR
22
23          011666  042771  000000G  000000G      1$:    BIC    #TRMRDY, @RSR(R1); Drop DTR
24
25          ; Finished
26
27          011674  000207            9$:    RETURN
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 33  
DLSBRK -- Control break transmission for a DL11 line

```
1           .SBTTL DLSBRK -- Control break transmission for a DL11 line
2
3           ; -----
4           ; DLSBRK is called to start or stop sending a break character to a DL11 line.
5
6           ; Inputs:
7           ; R1 = Physical line number.
8           ; R0 = Break control flag (MS$BRK)
9
10          DLSBRK:
11
12          ; See if we are to start or stop transmitting a break
13 011676  032700  000000G      BIT     #MS$BRK,R0    ;Start or stop break?
14 011702  001404            BEQ     1$                 ;Br if stop
15
16          ; Start transmitting a break
17
18 011704  052771  000000G 000000G      BIS     #TRBRK,@TSR(R1) ;Start transmitting a break
19 011712  000403            BR      9$                ;Stop transmitting a break
20
21          ; Stop transmitting a break
22
23 011714  042771  000000G 000000G 1$:   BIC     #TRBRK,@TSR(R1) ;Stop transmitting a break
24
25          ; Finished
26
27 011722  000207            9$:    RETURN
```

DLSSPD -- Set transmission speed for DL11 line

```
1           .SBTTL DLSSPD -- Set transmission speed for DL11 line
2
3           ; -----
4           ; DLSSPD is called to set the transmission speed for a DL11 line.
5           ;
6           ; Inputs:
7           ;   R0 = Speed code.
8           ;   R1 = Physical line index number.
9
9 011724 010246
10          DLSSPD: MOV      R2,-(SP)
11          ;
12          ; Set speed in DL11 control register
13 011726 110061 000001G      MOVB    R0,LMXPRM+1(R1) ; Store new code flags for line
14 011732 010002      MOV     R0,R2      ; Get speed code
15 011734 072227 000014      ASH     #12.,R2      ; Position the speed code
16 011740 052702 004000      BIS     #004000,R2    ; Set programmable-baud-rate-enable bit
17 011744          DISABL   ;;;,** Disable interrupts **
18 011752 017146 000000G      MOV     @TSR(R1),-(SP)  ;;; Get current transmitter status
19 011756 042716 170000      BIC     #170000,(SP)  ;;; Clear the baud rate field
20 011762 050216          BIS     R2,(SP)      ;;; Set new baud rate value
21 011764 012671 000000G      MOV     (SP)+,@TSR(R1) ;;; Store new value for transmitter
22 011770          ENABL   ;** Enable interrupts **
23
24          ;
25          ; Finished
26 011776 012602          MOV     (SP)+,R2
27 012000 000207          RETURN
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 35  
DZGDSS -- Get data set status for DZ11 line

```
1          .SBTTL  DZGDSS -- Get data set status for DZ11 line
2
3          ; -----
4          ; DZGDSS is called to get the data set status for a DZ11 line
5
6          ; Inputs:
7          ;   R1 = Physical line index number.
8
9          ; Outputs:
10         ;   R0 = Generic data set status flags (MS$xxx)
11        012002 010246
12        012004 010346
13        012006 005000
14
15          ; Get DZ11 index number
16
17        012010 016102 0000000G
18        012014 016103 0000000G
19        012020 116303 001312'
20
21          ; See if line is ringing
22
23        012024 130372 0000000G
24        012030 001402
25        012032 052700 0000000G
26
27          ; See if carrier is up
28
29        012036 130372 0000000G
30        012042 001402
31        012044 052700 0000000G
32
33          ; See if Data Terminal Ready is asserted
34
35        012050 130372 0000000G
36        012054 001402
37        012056 052700 0000000G
38
39          ; Finished
40
41        012062 012603
42        012064 012602
43        012066 000207
44
45          DZGDSS: MOV      R2,-(SP)
46                  MOV      R3,-(SP)
47                  CLR      R0                   ;Build result in R0
48
49          ; DZGDSS: MOV      LMNUM(R1),R2    ;Get DZ11 number
50          ;           MOV      LMXLN(R1),R3   ;Get # of line within DZ11 group (0-7)
51          ;           MOVB    MXLBIT(R3),R3   ;Get line select bit for DZ11 registers
52
53          ; See if line is ringing
54
55          ; BITB    R3,@MXRING(R2)  ; Is this line ringing?
56          ; BEQ     1$                 ; Br if not
57          ; BIS     #MS$RNG,R0       ; Set ring flag
58
59          ; See if carrier is up
60
61          ; 1$:    BITB    R3,@MXCAR(R2)  ; Is carrier up or down?
62          ; BEQ     2$                 ; Br if down
63          ; BIS     #MS$CAR,R0       ; Set carrier-up flag
64
65          ; See if Data Terminal Ready is asserted
66
67          ; 2$:    BITB    R3,@MxDTR(R2)  ; Is DTR asserted?
68          ; BEQ     3$                 ; Br if not
69          ; BIS     #MS$DTR,R0       ; Set DTR flag
70
71          ; Finished
72
73          ; 3$:    MOV      (SP)+,R3
74          ;           MOV      (SP)+,R2
75          ;           RETURN
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 36  
DZSDSS -- Set data set status for a DZ11 line

```
1           .SBTTL  DZSDSS -- Set data set status for a DZ11 line
2
3           ;-----;
4           ; DZSDSS is called to set data set status for a DZ11 line.
5
6           ; Inputs:
7           ;   R1 = Physical line number.
8           ;   R0 = Data set status flags (MS$DTR).
9 012070 010246
10 012072 010346
11
12           ; Get DZ11 index number
13
14 012074 016102 000000G
15 012100 016103 000000G
16 012104 116303 001312'
17
18           ; See if we should set or drop Data Terminal Ready
19
20 012110 032700 000000G
21 012114 001003
22
23           ; Drop DTR
24
25 012116 140372 000000G
26 012122 000402
27
28           ; Set DTR
29
30 012124 150372 000000G
31           1$:    BISB    R3, @MXDTR(R2)  ; Set DTR flag for our line
32           ; Finished
33
34 012130 012603
35 012132 012602
36 012134 000207
           9$:    MOV     (SP)+, R3
                   MOV     (SP)+, R2
                   RETURN
```

```
1           .SBTTL  DZSBRK -- Control break transmission for a DZ11 line
2
3           ; -----
4           ; DZSBRK is called to start or stop transmitting a break character
5           ; to a DZ11 line.
6
7           ; Inputs:
8           ;   R0 = Break control flag (MS$BRK)
9           ;   R1 = Physical line index number.
10          ;
11          012136 010246      DZSBRK: MOV      R2,-(SP)
12          012140 010346      MOV      R3,-(SP)
13          012142 010446      MOV      R4,-(SP)
14
15          ; Get DZ11 index number
16          012144 016102 000000G      MOV      LMXNUM(R1),R2    ;Get DZ11 number
17          012150 016103 000000G      MOV      LMXLN(R1),R3    ;Get line # within DZ11 (0-7)
18          012154 116303 001312'     MOVB    MXLBIT(R3),R3    ;Get line select bit
19
20          ; We keep a "shadow" copy of the break register in memory since we
21          ; cannot read the status of the hardware break register.
22
23          012160 116204 000000G      MOVB    MXSBRK(R2),R4    ;Get contents of shadow register
24          012164 140304      BICB    R3,R4        ;Assume we want to stop sending break
25          012166 032700 000000G      BIT     #MS$BRK, R0    ;Do we want to start sending break?
26          012172 001401      BEQ    1$          ;Br if not
27          012174 150304      BISB    R3,R4        ;Set break flag for the line
28
29          ; Set new break control flags in hardware register and shadow register
30
31          012176 110472 000000G      1$:    MOVB    R4,@MXBRK(R2)  ;Set status in hardware register
32          012202 110462 000000G      MOVB    R4,MXSBRK(R2)  ;Update shadow register
33
34          ; Finished
35
36          012206 012604      9$:    MOV      (SP)+,R4
37          012210 012603      MOV      (SP)+,R3
38          012212 012602      MOV      (SP)+,R2
39          012214 000207      RETURN
```

DZSSPD -- Set transmission speed for a DZ11 line

```

1           .SBTTL  DZSSPD -- Set transmission speed for a DZ11 line
2
3           ;-----;
4           ; DZSSPD is called to set the transmit/receive speed for a DZ11 line.
5           ;
6           ; Inputs:
7           ; R0 = Speed code.
8           ; R1 = Physical line index number.
9
9 012216 010346
10          DZSSPD: MOV      R3,-(SP)
11
12          ; Build line parameter register value
13 012220 110061 000001G
14 012224 010003
15 012226 042703 000000C
16 012232 000303
17 012234 032700 000000G
18 012240 001003
19 012242 052703 000000G
20 012246 000402
21 012250 052703 000000G
22 012254 032700 000000G
23 012260 001407
24 012262 052703 000000G
25 012266 032700 000000G
26 012272 001402
27 012274 052703 000000G
28
29          ; Store LPR value for line
30
31 012300 052703 010000
32 012304 056103 000000G
33 012310 016100 000000G
34 012314 010370 000000G
35
36          ; Finished
37
38 012320 012603
39 012322 000207

```

MOV (SP)+, R3  
RETURN

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 39  
DHGDSS -- Get data set status for a DH11 line

```
1           .SBTTL  DHGDSS -- Get data set status for a DH11 line
2
3           ;-----  

4           ; DHGDSS is called to get the data set status for a DH11 line.
5
6           ; Inputs:  

7           ;   R1 = Physical line number
8
9           ; Outputs:  

10          ;   R0 = Generic modem status flags (MS$xxx)
11 012324 010246
12 012326 010346
13 012330 005000
14
15           ; Get DH11 index number
16
17 012332 016102 000000G
18 012336 016103 000000G
19
20           ; Get modem status
21
22 012342
23 012350 042772 000000G 000000G
24 012356 050372 000000G
25 012362 017203 000000G
26 012366
27
28           ; See if phone is ringing
29
30 012374 032703 000000G
31 012400 001402
32 012402 052700 000000G
33
34           ; See if carrier is detected
35
36 012406 032703 000000G
37 012412 001402
38 012414 052700 000000G
39
40           ; See if Data Terminal Ready is asserted
41
42 012420 032703 000000G
43 012424 001402
44 012426 052700 000000G
45
46           ; Finished
47
48 012432 012603
49 012434 012602
50 012436 000207
      DHGDSS: MOV      R2,-(SP)
                  MOV      R3,-(SP)
                  CLR      R0
                           ;Build result in R0
      ;-----  

      ; Get DH11 index number
      ; MOV      LMXNUM(R1),R2 ;Get DH11 index number
      ; MOV      LMXLN(R1),R3 ;Get line within DH11 (0-15)
      ;-----  

      ; Get modem status
      ;-----  

      ; DISABL          ;;; ** Disable interrupts **
      ; BIC      #MF$LIN,@DM$CSR(R2) ; ;Clear DM11 line select field
      ; BIS      R3,@DM$CSR(R2) ; ;Select line
      ; MOV      @DM$LSR(R2),R3 ; ;Get line status value
      ; ENABL          ;** Enable interrupts **  

      ;-----  

      ; See if phone is ringing
      ;-----  

      ; BIT      #MF$RNG,R3 ; Is the phone ringing?
      ; BEQ      1$          ;Br if not
      ; BIS      #MS$RNG,R0 ; Set ring flag
      ;-----  

      ; See if carrier is detected
      ;-----  

      ; 1$:    BIT      #MF$CAR,R3 ; Is carrier detected?
      ; BEQ      2$          ;Br if not
      ; BIS      #MS$CAR,R0 ; Set carrier flag
      ;-----  

      ; See if Data Terminal Ready is asserted
      ;-----  

      ; 2$:    BIT      #MF$DTR,R3 ; Is DTR asserted?
      ; BEQ      3$          ;Br if not
      ; BIS      #MS$DTR,R0 ; Set DTR flag
      ;-----  

      ; Finished
      ;-----  

      ; 3$:    MOV      (SP)+,R3
      ;         MOV      (SP)+,R2
      ; RETURN
```

```
1 .SBTTL DHSDSS -- Set data set status for a DH11 line
2 ;-----
3 ; DHSDSS is called to set the data set status for a DH11 line.
4 ;
5 ; Inputs:
6 ; R1 = Physical line index number.
7 ; R0 = Data set status flags (MS$DTR)
8 ;
9 012440 010246
10 012442 010346
11 ;
12 ; Get modem index number and select our line
13 ;
14 012444 016102 000000G      MOV     LMXNUM(R1),R2    ;Get DH11 index number
15 012450 016103 000000G      MOV     LMXLN(R1),R3    ;Get line # within DH11 (0-15)
16 012454          DISABL      ;;; ** Disable interrupts **
17 012462 042772 000000G 000000G  BIC     #MF$LIN,@DM$CSR(R2) ;;Clear DM11 line # field
18 012470 050372 000000G      BIS     R3,@DM$CSR(R2)   ;;Select our line
19 ;
20 ; See if we should set or drop Data Terminal Ready
21 ;
22 012474 032700 000000G      BIT     #MS$DTR,R0      ;;Set or drop DTR?
23 012500 001004          BNE     1$                  ;;Br to set DTR
24 012502 042772 000000G 000000G  BIC     #MF$DTR,@DM$LSR(R2) ;;Drop DTR
25 012510 000403          BR      9$                ;;
26 012512 052772 000000G 000000G 1$:    BIS     #MF$DTR,@DM$LSR(R2);;Set DTR
27 ;
28 ; Finished
29 ;
30 012520          9$:    ENABL      ;** Enable interrupts **
31 012526 012603          MOV     (SP)+,R3
32 012530 012602          MOV     (SP)+,R2
33 012532 000207          RETURN
```

```
1           .SBTTL  DHSSPD -- Set transmit/receive speed for DH11 line
2
3           ;-----;
4           ; DHSSPD is called to set the transmit/receive speed for a DH11 line.
5           ; The parity and character length parameters are also set.
6
7           ; Inputs:
8           ; R0 = Speed, length, and parity codes.
9           ; R1 = Physical line index number.
10          ;
11          012534 010246      DHSSPD: MOV      R2,-(SP)
12          012536 010346      MOV      R3,-(SP)
13          012540 010446      MOV      R4,-(SP)
14
15          ; Update the LMXPRM table for this line
16          012542 110061 0000001G    MOVB    R0,LMXPRM+1(R1) ;Store new codes for line
17
18          ; Convert TSX-Plus speed code into DH11 speed code
19
20          012546 010003      MOV      R0,R3      ;Get speed code
21          012550 042703 0000000C    BIC      #^C<CLP$SPD>,R3 ;Clear all but speed code
22          012554 116303 001352'    MOVB    DHSPCT(R3),R3 ;Convert to DH11 speed code
23
24          ; Get DH11 index number
25
26          012560 016102 0000000G    MOV      LMXNUM(R1),R2 ;Get DH11 index number
27          012564 116104 0000000G    MOVB    LMXLN(R1),R4 ;Get # of line within mux group
28          012570 052704 0000000G    BIS      #HF$RIE,R4 ;Set receiver interrupt enable flag
29
30          ; Build value to use for line parameter register
31
32          012574 072327 000006      ASH      #6,R3      ;Position speed code for receive speed
33          012600 010346      MOV      R3,-(SP)   ;Save positioned receive speed
34          012602 072327 000004      ASH      #4,R3      ;Position code for transmit speed
35          012606 052603      BIS      (SP)+,R3   ;Combine transmit and receive speed codes
36          012610 032700 0000000G    BIT      #LP$7BT,R0 ;7 bit characters wanted?
37          012614 001003      BNE      1$       ;Br if yes
38          012616 052703 0000000G    BIS      #HF$8BT,R3 ;Select 8 bit characters
39          012622 000402      BR      2$       ;2$:
40          012624 052703 0000000G    1$:    BIS      #HF$7BT,R3 ;Select 7 bit characters
41          012630 032700 0000000G    2$:    BIT      #LP$PAR,R0 ;Parity wanted?
42          012634 001407      BEQ      3$       ;Br if not
43          012636 052703 0000000G    BIS      #HF$PAR,R3 ;Enable parity
44          012642 032700 0000000G    BIT      #LP$ODD,R0 ;Odd parity wanted?
45          012646 001402      BEQ      3$       ;Br if not
46          012650 052703 0000000G    BIS      #HF$ODD,R3 ;Select odd parity
47
48          ; Select LPR register for line being set and store the LPR value
49
50          012654      3$:    DISABL      ;;;** Disable interrupts **
51          012662 110472 0000000G    MOVB    R4,@MH$SCR(R2) ;;;Select our mux line
52          012666 010372 0000000G    MOV     R3,@MH$LPR(R2) ;;;Store the LPR value for this line
53          012672      ENABL      ;** Enable interrupts **
54
55          ; Finished
56
57          012700 012604      MOV      (SP)+,R4
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 41-1  
DHSSPD -- Set transmit/receive speed for DH11 line

58 012702 012603	MOV (SP)+, R3
59 012704 012602	MOV (SP)+, R2
60 012706 000207	RETURN

```
1 .SBTTL DHSBRK -- Control break transmission for a DH11 line
2 ; -----
3 ; DHSBRK is called to start or stop transmitting a break to a DH11 line.
4 ;
5 ; Inputs:
6 ; R0 = Break control flag (MS$BRK)
7 ; R1 = Line index number
8 ;
9 012710 010246
10 012712 010346
11
12 ; Get DH11 index number and line select flag
13
14 012714 016102 000000G
15 012720 016103 000000G
16 012724 006303
17 012726 016303 001252'
18
19 ; See if we should start or stop sending a break
20
21 012732 032700 000000G
22 012736 001403
23
24 ; Start sending a break to this line
25
26 012740 050372 000000G
27 012744 000402
28
29 ; Stop sending a break to this line
30
31 012746 040372 000000G
32
33 ; Finished
34
35 012752 012603
36 012754 012602
37 012756 000207
         MOV      R2,-(SP)
         MOV      R3,-(SP)
;
         MOV      LMXNUM(R1),R2 ;Get DH11 index number
         MOV      LMXLN(R1),R3 ;Get line within DH11 (0-15)
         ASL      R3            ;Convert line # to word table index
         MOV      DHLBIT(R3),R3 ;Get flag bit corresponding to line #
;
         BIT      #MS$BRK,R0   ;Start or stop sending break?
         BEQ      1$              ;Br if stop
;
         BIS      R3,@MH$BRK(R2) ;Set break flag for our line
         BR      9$
;
         BIC      R3,@MH$BRK(R2) ;Stop sending a break to this line
;
         MOV      (SP)+,R3
         MOV      (SP)+,R2
         RETURN
```

```
1 .SBTTL VHGDS -- Get data set status for a DHV11 line
2 ;
3 ; VHGDS is called to get the data set status for a DHV11 line.
4 ;
5 ; Inputs:
6 ; R1 = Physical line index number.
7 ;
8 ; Outputs:
9 ; RO = Generic modem status flags (MS$xxx)
10;
11 012760 010246          VHGDSS: MOV      R2,-(SP)
12 012762 010346          MOV      R3,-(SP)
13 012764 010446          MOV      R4,-(SP)
14 012766 005000          CLR      RO           ;Form result in RO
15;
16; Get DHV11 index number and line number
17;
18 012770 016102 000000G   MOV      LMXNUM(R1),R2  ;Get mux index number
19 012774 016103 000000G   MOV      LMXLN(R1),R3  ;Get line # within mux group
20 013000 052703 000000G   BIS      #VF$RIE,R3  ;Set receiver interrupt enable flag
21;
22; Get modem status
23;
24 013004                 DISABL          ;;; ** Disable interrupts **
25 013012 110372 000000G   MOVB    R3,@VH$CSR(R2) ;Select our line in mux
26 013016 017204 000000G   MOV     @VH$LCR(R2),R4 ;Get line control register
27 013022 017203 000000G   MOV     @VH$LSR(R2),R3 ;Get current line status
28 013026                 ENABL          ;** Enable interrupts
29;
30; See if line is ringing
31;
32 013034 032703 000000G   BIT     #VF$RNG,R3  ;Is the line ringing?
33 013040 001402          BEQ     1$           ;Br if not
34 013042 052700 000000G   BIS     #MS$RNG,RO  ;Set ringing flag
35;
36; See if carrier is up
37;
38 013046 032703 000000G   1$:    BIT     #VF$DCD,R3  ;Is carrier detected?
39 013052 001402          BEQ     2$           ;Br if not
40 013054 052700 000000G   BIS     #MS$CAR,RO  ;Set carrier flag
41;
42; See if Data Terminal Ready is asserted
43;
44 013060 032704 000000G   2$:    BIT     #VF$DTR,R4  ;Is Data Terminal Ready asserted?
45 013064 001402          BEQ     3$           ;Br if not
46 013066 052700 000000G   BIS     #MS$DTR,RO  ;Set DTR flag
47;
48; Finished
49;
50 013072 012604          3$:    MOV     (SP)+,R4
51 013074 012603          MOV     (SP)+,R3
52 013076 012602          MOV     (SP)+,R2
53 013100 000207          RETURN
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 44  
VHSDSS -- Set data set status for a DHV11 line

```
1           .SBTTL  VHSDSS -- Set data set status for a DHV11 line
2
3           ; -----
4           ; VHSDSS is called to set the data set status for a DHV11 line.
5
6           ; Inputs:
7           ; R1 = Physical line index number.
8           ; R0 = Data set status flags (MS$DTR).
9 013102 010246
10 013104 010346
11
12           ; Get DHV11 mux index number and line number
13
14 013106 016102 000000G      MOV     LMXNUM(R1),R2    ;Get mux index number
15 013112 016103 000000G      MOV     LMXLN(R1),R3    ;Get # of line within mux group
16 013116 052703 000000G      BIS     #VF$RIE,R3    ;Set receiver interrupt enable flag
17
18           ; Set or drop the Data Terminal Ready flag
19
20 013122          DISABL      ;;;** Disable interrupts **
21 013130 110372 000000G      MOVB   R3,@VH$CSR(R2)  ;;;Select our line in mux
22 013134 032700 000000G      BIT    #MS$DTR,R0      ;;;Set or drop DTR?
23 013140 001004          BNE    1$                 ;;;Br if want to set DTR
24 013142 042772 000000G 000000G  BIC    #VF$DTR,@VH$LCR(R2);;Clear DTR bit
25 013150 000403          BR     2$                 ;;;Set DTR bit
26 013152 052772 000000G 000000G 1$:    BIS    #VF$DTR,@VH$LCR(R2);;Set DTR bit
27
28           ; Finished
29
30 013160          2$:    ENABL      ;** Enable interrupts **
31 013166 012603          MOV    (SP)+,R3
32 013170 012602          MOV    (SP)+,R2
33 013172 000207          RETURN
```

```
1 .SBTTL VHSSPD -- Set transmit/receive speed for a DHV11 line
2 ;
3 ; Set the transmit/receive speed for a DHV11 line.
4 ;
5 ; Inputs:
6 ; R0 = Speed code.
7 ; R1 = Line index number
8 ;
9 013174 010246           VHSSPD: MOV      R2,-(SP)
10 013176 010346          MOV      R3,-(SP)
11 013200 010446          MOV      R4,-(SP)
12 ;
13 ; Update the LMXPRM table for this line
14 ;
15 013202 110061 000001G   MOVB    R0,LMXPRM+1(R1) ;Store flags for line
16 ;
17 ; Convert TSX-Plus speed code into DHV11 speed code
18 ;
19 013206 010003           MOV      R0,R3      ;Get flags
20 013210 042703 000000C   BIC     #^C<LP$SPD>,R3 ;Clear all but speed flags
21 013214 116303 001372'   MOVB    VHSPCT(R3),R3 ;Convert to DHV11 speed code
22 ;
23 ; Get DHV11 index number
24 ;
25 013220 016102 000000G   MOV      LMXNUM(R1),R2 ;Get DHV11 index number
26 013224 116104 000000G   MOVB    LMXLN(R1),R4 ;Get line # within mux group
27 013230 052704 000000G   BIS     #VF$RIE,R4 ;Set receiver interrupt enable flag
28 ;
29 ; Construct line parameter value for this line
30 ;
31 013234 000303           SWAB    R3      ;Position speed for receive speed
32 013236 010346           MOV      R3,-(SP)
33 013240 072327 000004   ASH     #4,R3      ;Position speed for transmit speed
34 013244 052603           BIS     (SP)+,R3   ;Combine receive and transmit speeds
35 013246 032700 000000G   BIT     #LP$7BT,R0 ;7 bit characters wanted
36 013252 001003           BNE     2$      ;Br if yes
37 013254 052703 000000G   BIS     #VF$BBT,R3 ;Set 8 bit characters
38 013260 000402           BR      3$      ;
39 013262 052703 000000G   2$:    BIS     #VF$7BT,R3 ;Set 7 bit characters
40 013266 032700 000000G   3$:    BIT     #LP$PAR,R0 ;Parity wanted?
41 013272 001407           BEQ     1$      ;Br if not
42 013274 052703 000000G   BIS     #VF$PAR,R3 ;Enable parity
43 013300 032700 000000G   BIT     #LP$ODD,R0 ;Odd parity wanted?
44 013304 001002           BNE     1$      ;Br if yes
45 013306 052703 000000G   BIS     #VF$EVN,R3 ;Select even parity
46 ;
47 ; Select our line and store the parameter value
48 ;
49 013312                 1$:    DISABL   ;;; ** Disable interrupts **
50 013320 110472 000000G   MOVB    R4,@VH$CSR(R2) ;;; Select our mux line
51 013324 010372 000000G   MOV     R3,@VH$LPR(R2) ;;; Set LPR value for this line
52 013330                 ENABL   ;** Enable interrupts **
53 ;
54 ; Finished
55 ;
56 013336 012604           MOV     (SP)+,R4
57 013340 012603           MOV     (SP)+,R3
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 45-1  
VHSSPD -- Set transmit/receive speed for a DHV11 line

58 013342 012602  
59 013344 000207

MOV (SP)+, R2  
RETURN

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 46  
VHSBRK -- Control break transmission for a DHV11 line

```
1 .SBTTL VHSBRK -- Control break transmission for a DHV11 line
2 ; -----
3 ; Start or stop transmitting a break to a DHV11 line.
4 ;
5 ; Inputs:
6 ; R0 = Break control flag (MS$BRK)
7 ; R1 = Line index number
8 ;
9 013346 010246
10 013350 010346
11 ;
12 ; Get mux index number and line number
13 ;
14 013352 016102 000000G
15 013356 016103 000000G
16 013362 052703 000000G
17 ;
18 ; Set or drop the break control flag within the line control register
19 ;
20 013366
21 013374 110372 000000G
22 013400 032700 000000G
23 013404 001404
24 013406 052772 000000G 000000G
25 013414 000403
26 013416 042772 000000G 000000G
27 ;
28 ; Finished
29 ;
30 013424
31 013432 012603
32 013434 012602
33 013436 000207
      VHSBRK: MOV      R2,-(SP)
                  MOV      R3,-(SP)
;
; Get mux index number and line number
      MOV      LMXNUM(R1),R2    ;Get mux index number
      MOV      LMXLN(R1),R3    ;Get # of line within mux
      BIS      #VF$RIE,R3    ;Set receiver interrupt enable flag
;
; Set or drop the break control flag within the line control register
      DISABL          ;;;** Disable interrupts **
      MOVB   R3,@VH$CSR(R2)  ;;;Select our mux line
      BIT    #MS$BRK,R0       ;;;Start or stop break?
      BEQ    1$                ;;;Br if stop
      BIS    #VF$BC,@VH$LCR(R2);; Set the break flag for the line
      BR     2$                ;;;Clear the break flag for the line
      BIC    #VF$BC,@VH$LCR(R2);; Clear the break flag for the line
;
; Finished
;
      ENABL          ;** Enable interrupts **
      MOV    (SP)+,R3
      MOV    (SP)+,R2
      RETURN
```

DLCLOK -- Timer driven routine for DL11 lines

```

1           .SBTTL  DLCLOK -- Timer driven routine for DL11 lines
2
3           ; -----
4           ;   DLCLOK is a timer-driven routine called periodically to check on the
5           ;   status of a DL11 line.
6
7           ;   Inputs:
8           ;       R1 = Physical line index number
9 013440
10          ;
11          ;   See if this line has been stolen by some special device handler
12          ;
13 013440 027127 000000G 000000G      CMP     @INVEC(R1),#INRECV; HAS LX HANDLER STOLEN INTERRUPT VECTOR
14 013446 101050                      BHI     20$                ;BR IF YES
15          ;
16          ;   Check for lost input interrupts
17          ;
18 013450 032771 000000G 000000G      BIT     #RCVDDON,@RSR(R1); IS AN INPUT CHAR PENDING NOW?
19 013456 001424                      BEQ     1$                  ;BR IF NOT
20 013460 032761 000000G 000000G      BIT     #$_IITIM,LSW5(R1); HAVE WE STARTED TIMER YET?
21 013466 001415                      BEQ     15$                ;BR IF NOT
22 013470                         DISABL   ;** DISABLE ** (NEEDED FOR FLKEY DL11'S)
23 013476 042771 000000G 000000G      BIC     #RDINT,@RSR(R1) ;WE SEEM TO HAVE LOST AN INTERRUPT
24 013504 052771 000000G 000000G      BIS     #RDINT,@RSR(R1) ;TRY TO FORCE AN INTERRUPT
25 013512                         ENABL   ;** ENABLE **
26 013520 000403                      BR      1$                ;BR IF NOT
27 013522 052761 000000G 000000G 15$: BIS     #$_IITIM,LSW5(R1); START INPUT INTERRUPT TIMER
28          ;
29          ;   Check for lost output interrupts
30          ;
31 013530 032761 000000G 000000G 1$:  BIT     #$_OITIM,LSW5(R1); Have we started timer interval?
32 013536 001411                      BEQ     13$                ;Br if not
33 013540 032761 000000G 000000G      BIT     #$_XCHAR,LSW3(R1); Are we still waiting for interrupt?
34 013546 001410                      BEQ     20$                ;Br if not
35 013550 042761 000000G 000000G      BIC     #$_XCHAR,LSW3(R1); Say wait is over
36 013556 004737 000000G              CALL    DLSTRT             ;Try to start transmitter
37 013562 052761 000000G 000000G 13$: BIS     #$_OITIM,LSW5(R1); Start timed interval
38          ;
39          ;   Finished
40          ;
41 013570 000207                      20$:    RETURN

```

```
1 .SBTTL DZCLOK -- Timer driven routine for DZ11 lines
2 ; -----
3 ; DZCLOK is called periodically from the clock routine to check on the
4 ; status of DZ11 lines.
5 ;
6 ; Inputs:
7 ; R1 = Physical line index number
8 ;
9 013572 010246
10 013574 010346
11
12 ; Get DZ11 mux index number and number of line within mux
13
14 013576 016102 000000G
15 013602 016103 000000G
16 013606 116303 001312'
17
18 ; Check for lost input interrupts
19
20 013612 032772 000000G 000000G
21 013620 001415
22 013622 032761 000000G 000000G
23 013630 001406
24 013632 042772 000000G 000000G
25 013640 052772 000000G 000000G
26 013646 052761 000000G 000000G 1$:
27
28 ; Check for lost output interrupts
29
30 013654 032761 000000G 000000G 3$:
31 013662 001415
32 013664 032761 000000G 000000G
33 013672 001414
34 013674 032761 000000G 000000G
35 013702 001010
36 013704 042761 000000G 000000G
37 013712 004737 000000G
38 013716 052761 000000G 000000G 13$:
39
40 ; Finished
41
42 013724 012603
43 013726 012602
44 013730 000207
      MOV      R2,-(SP)
      MOV      R3,-(SP)
      MOV      LMXNUM(R1),R2 ;Get DZ11 mux index number
      MOV      LMXLN(R1),R3 ;Get # of line within mux (0-7)
      MOVB    MXLBIT(R3),R3 ;Get line select bit for mux register
      BIT      #RDONE,@MXCSR(R2); Does DZ11 have a pending input character?
      BEQ    3$;Br if not
      BIT      #$_IITIM,LSW5(R1);Have we started input interrupt timer?
      BEQ    1$;Br if not
      BIC      #RIE,@MXCSR(R2) ;Drop receiver interrupt enable
      BIS      #RIE,@MXCSR(R2) ;and raise it again to try to force interrupt
      BIS      #$_IITIM,LSW5(R1);Start input interrupt timer
      BIT      #$_OITIM,LSW5(R1);Have we started timer interval?
      BEQ    13$;Br if not
      BIT      #$_XCHAR,LSW3(R1);Are we still waiting for interrupt?
      BEQ    9$;Br if not
      BIT      #$_CTRLS,LSW3(R1);Is output suspended due to ctrl-S?
      BNE    9$;Br if yes
      BIC      #$_XCHAR,LSW3(R1);Say wait is over
      CALL   DZSTRT ;Try to start transmitter
      BIS      #$_OITIM,LSW5(R1);Start timed interval
      (SP)+,R3
      (SP)+,R2
      RETURN
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 49  
DHCLK -- Timer driven routine for DH11 lines

```
1           .SBTTL  DHCLK -- Timer driven routine for DH11 lines
2           ; -----
3           ; DHCLK is called every 0.5 seconds from the clock driven routine to
4           ; do checking for DH11 and DHV11 lines
5           ;
6           ; Inputs:
7           ;   R1 = Physical line index number.
8           ;
9 013732
10 013732
11
12           ; Set flag which requests clock driven output processing for the line
13
14 013732  052761  000000G 000000G      BIS      ##$DHCD0,LSW10(R1)    ; Request clock-driven output
15 013740  005237  000000G      INC      NEDCDO          ; Say clock processing needed
16
17           ; Finished
18
19 013744  000207           RETURN
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 50  
SYS DIE -- Fatal system halt

```
1           .SBTTL  SYS DIE -- Fatal system halt
2
3           ;-----  

4           ;  SYS DIE is entered from the system SYSHLT routine when a system  

5           ;  crash is occurring because a DIE macro was executed.  

6
7           ;  Inputs:  

8           ;    DIEMSG = Address of error message to print.  

9           ;    DIEARG = Argument value to print with error message.  

10          ;   DIEPC  = Address of call to SYSHLT.  

11          ;   DIESP  = Stack pointer at time of crash.  

12          ;   TRPAR5 = Kernel PAR5 contents at time of crash.  

13
14          ;  Save all registers on the stack.  

15 013746 010046          SYS DIE: MOV      R0,-(SP)
16 013750 010146          MOV      R1,-(SP)
17 013752 010246          MOV      R2,-(SP)
18 013754 010346          MOV      R3,-(SP)
19 013756 010446          MOV      R4,-(SP)
20 013760 010546          MOV      R5,-(SP)
21
22          ; Initialize some cells that are used to pass information to TSDUMP
23
24 013762 005037 0000000G          CLR      DMPOVL      ; Overlay name
25 013766 005037 0000000G          CLR      DMPHND      ; Handler name
26
27          ; Print message heading.
28
29 013772 012701 001056'          MOV      #TXFSE,R1      ; "FATAL SYSTEM ERROR... "
30 013776 004737 014330'          CALL     HLTPRT      ; PRINT IT
31
32          ; Print abort location.
33
34 014002 013701 0000000G          MOV      DIEPC,R1      ; GET ADDRESS OF CALL TO SYSHLT
35 014006 004737 014376'          CALL     HLTOCT      ; PRINT OCTAL VALUE
36
37          ; Print error message.
38
39 014012 013701 0000000G          MOV      DIEMSG,R1      ; GET ADDRESS OF ERROR MESSAGE
40 014016 062701 000002'          ADD      #DIEBAS,R1
41 014022 004737 014330'          CALL     HLTPRT      ; PRINT IT
42
43          ; Print argument value.
44
45 014026 012701 001120'          MOV      #TXARG,R1      ; "ARGUMENT VALUE = "
46 014032 004737 014330'          CALL     HLTPRT      ; PRINT HEADING
47 014036 013701 0000000G          MOV      DIEARG,R1      ; GET ARGUMENT VALUE
48 014042 004737 014376'          CALL     HLTOCT      ; PRINT OCTAL VALUE
49
50          ; If the argument value is in the par 5 range, it is probably in
51          ; a system overlay.
52
53 014046 013701 0000000G          MOV      TRPAR5,R1      ; Get the KPAR5 value
54 014052 001422                 BEQ      21$          ; Br if zero - print value
55
56          ; Check for base address of system overlay region.
57
```

SYSDIE -- Fatal system halt

```

58 014054 013700 000000G      1$:   MOV    OVRADD, R0      ;Find address of the overlay table
59 014060 026001 000000G      CMP    O. PAR(R0), R1      ;Check PAR5 with mapped overlay address
60 014064 001426               BEQ    2$                  ;Br if values match
61 014066 062700 000006       ADD    #6, R0      ;Find the next overlay region
62 014072 021027 004537       CMP    (R0), #4537      ;Check for end of table, a <JSR R5, $OVRHD>
63 014076 001370               BNE    1$                  ;Br to check next table entry
64
65
66
67 014100 013700 000000G      11$:  MOV    NUMDEV, R0      ;Get highest byte index for loaded devices
68 014104 026001 000000G      CMP    HANPAR(R0), R1      ;Check PAR5 with mapped handler address
69 014110 001446               BEQ    12$                 ;Br if values match
70 014112 162700 000002       SUB    #2, R0      ;Offset to next device handler
71 014116 002372               BGE    11$                 ;Br to check next handler entry
72
73
74
75 014120 012701 001137'      21$:  MOV    #TXPAR5, R1      ;"PAR5 VALUE = "
76 014124 004737 014330'      CALL   HLTPRT          ;PRINT HEADING
77 014130 013701 000000G      MOV    TRPAR5, R1      ;GET ARGUMENT VALUE
78 014134 004737 014376'      CALL   HLTOCT          ;PRINT OCTAL VALUE
79 014140 000445               BR    3$                  ;Go halt the system
80
81
82
83 014142 016004 000000G      2$:   MOV    O. ADR(R0), R4      ;Get the rad50 overlay identifier
84 014146 163700 000000G      SUB    OVRADD, R0      ;Sub the base address of the overlay table
85 014152 010003               MOV    R0, R3      ;Move to low-order address
86 014154 005002               CLR    R2                  ;Clear high-order address
87 014156 071227 000006       DIV    #6, R2      ;Divide by 6 (# bytes/ overlay table entry)
88 014162 005202               INC    R2                  ;Normalize base to one
89 014164 012701 001155'      MOV    #TXSEQ, R1      ;"Seg. value ="
90 014170 004737 014330'      CALL   HLTPRT          ;Print heading
91 014174 010201               MOV    R2, R1      ;Get the segment number
92 014176 004737 014376'      CALL   HLTOCT          ;Print the octal segment number
93 014202 012701 001173'      MOV    #TXOID, R1      ;"Overlay: "
94 014206 004737 014330'      CALL   HLTPRT          ;Print heading
95 014212 010401               MOV    R4, R1      ;Restore the overlay identifier
96 014214 010137 000000G      MOV    R1, DMPOVL      ;Pass overlay name to TSDUMP
97 014220 004737 014454'      CALL   HLTRAD          ;Print the rad50 overlay identifier
98 014224 000413               BR    3$                  ;Go halt the system
99
100
101
102 014226 016002 000000G      12$:  MOV    PNAME(R0), R2      ;Get the RAD50 device name
103 014232 012701 001205'      MOV    #TXDEV, R1      ;"Device name :"
104 014236 004737 014330'      CALL   HLTPRT          ;Print heading
105 014242 010201               MOV    R2, R1      ;Get the device name
106 014244 010137 000000G      MOV    R1, DMPHND      ;Pass device name to TSDUMP
107 014250 004737 014454'      CALL   HLTRAD          ;Print the rad50 device name
108
109
110
111 014254 012701 001223'      3$:   MOV    #SPTXT, R1      ;Point to message heading
112 014260 004737 014330'      CALL   HLTPRT          ;Print the heading
113 014264 013701 000000G      MOV    DIESP, R1      ;Get SP at time of crash
114 014270 004737 014376'      CALL   HLTOCT          ;Print it

```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 50-2  
SYSDIE -- Fatal system halt

```
115 ;  
116 ; See if we should call the system crash dump module or halt the system  
117 ;  
118 014274 105737 000000G TSTB VSYDMP ;Should we do a system dump?  
119 014300 001001 BNE 4$ ;Br if yes  
120 014302 000000 HALT ;Halt the system  
121 ;  
122 ; Enter system overlay to produce a crash dump  
123 ;  
124 014304 013701 000000G 4$: MOV DIEMSG,R1 ;Get address of error message text  
125 014310 062701 000002' ADD #DIEBAS,R1  
126 014314 012702 000000G MOV #DMPTXT,R2 ;Point to area where we pass message  
127 014320 112122 5$: MOVB (R1)+, (R2)+ ;Store message text  
128 014322 001376 BNE 5$ ;Loop till all of message moved  
129 014324 000137 000000G JMP DODUMP ;Enter dump routine
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 51  
SYS DIE -- Fatal system halt

```
1 ; -----
2 ;      HLTPRT is called to print an ASCIZ string on the console terminal.
3 ;
4 ;      Inputs:
5 ;          R1 = Address of ASCIZ string to print.
6 ;
7 014330 010146          HLTPRT: MOV    R1,-(SP)
8 014332 112100          1$:    MOVB   (R1)+,R0      ; GET NEXT CHAR FROM TEXT STRING
9 014334 001406          BEQ    2$      ; BR IF HIT END OF STRING
10 014336 120027 000200     CMPB   R0,#200   ; END WITHOUT CR-LF?
11 014342 001413          BEQ    3$      ; BR IF YES
12 014344 004737 014612'    CALL   HLTCHR  ; SEND CHAR TO TERMINAL
13 014350 000770          BR     1$      ; GO GET NEXT CHAR
14 ;
15 014352 012700 000015    ; Print CR-Lf.
16 014356 004737 014612'    2$:    MOV    #CR,R0      ; PRINT CR
17 014362 012700 000012    CALL   HLTCHR  ; PRINT LF
18 014366 004737 014612'    MOV    #LF,R0
19 ;
20 014372 012601          ; Finished
21 014374 000207          3$:    MOV    (SP)+,R1
22 ;
23 ;
24 ;      HLTOCT is called to convert a binary value to an octal character string
25 ;      and print that string on the console terminal.
26 ;
27 ;      Inputs:
28 ;          R1 = Binary value to be converted and printed.
29 ;
30 014376 010146          HLTOCT: MOV    R1,-(SP)
31 014400 010246          MOV    R2,-(SP)
32 014402 012702 000006    MOV    #6.,R2      ; GET # OF OCTAL DIGITS IN RESULT STRING
33 014406 005000          CLR    R0      ; SET FOR SHIFT
34 014410 073027 000001    ASHC   #1,R0      ; SHIFT 1ST BIT INTO R0
35 014414 000403          BR     2$      ; ENTER CONVERSION LOOP
36 014416 005000          1$:    CLR    R0      ; SET FOR SHIFT
37 014420 073027 000003    ASHC   #3,R0      ; SHIFT AN OCTAL DIGIT INTO R0
38 014424 062700 000060    2$:    ADD    #'0,R0      ; CONVERT BINARY VALUE TO ASCII CHARACTER
39 014430 004737 014612'    CALL   HLTCHR  ; PRINT A CHARACTER
40 014434 077210          SOB    R2,1$      ; LOOP TO PRINT REST OF VALUE
41 014436 012701 001136'    MOV    #TXNUL,R1
42 014442 004737 014330'    CALL   HLTPRT  ; NOW PRINT CR-LF
43 014446 012602          MOV    (SP)+,R2
44 014450 012601          MOV    (SP)+,R1
45 014452 000207          RETURN
46 ;
47 ;
48 ;      HLTRAD is called to convert a RAD50 value to an ascii character string
49 ;      and print that string on the console terminal.
50 ;
51 ;      Inputs:
52 ;          R1 = RAD50 value to be converted and printed.
53 ;
54 014454 010146          HLTRAD: MOV    R1,-(SP)
55 014456 010246          MOV    R2,-(SP)
56 014460 005000          CLR    R0      ; Clear high order
57 014462 071027 003100    DIV    #50*50,R0  ; Divide for 1st byte
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 51-1  
SYSDIE -- Fatal system halt

```
58 014466 116000 014542'           MOVB   R50CHR(R0),R0    ;Get output character
59 014472 004737 014612'           CALL   HLTCHR      ;Print a character
60 014476 005000                  CLR    R0          ;Clear high order
61 014500 071027 000050            DIV    #50,R0      ;Divide for 2nd byte
62 014504 116000 014542'           MOVB   R50CHR(R0),R0    ;Get output character
63 014510 004737 014612'           CALL   HLTCHR      ;Print a character
64 014514 116100 014542'           MOVB   R50CHR(R1),R0    ;Get output character
65 014520 004737 014612'           CALL   HLTCHR      ;Print a character
66 014524 012701 001136'           MOV    #TXNUL,R1    ;Now print cr-lf
67 014530 004737 014330'           CALL   HLTPRT      ;Print a character
68 014534 012602                  MOV    (SP)+,R2
69 014536 012601                  MOV    (SP)+,R1
70 014540 000207                  RETURN

71
72     . EVEN
73
74
75 014542    040      101      102  R50CHR: . ASCII / ABCDEFGHIJKLMNOPQRSTUVWXYZ$. 0123456789/
76
77
78     . EVEN
79
80
81 ; -----
82 ;   HLTCHR is called to print a single character on the console terminal
83 ;   during a system crash.
84 ;
85 ;   Inputs:
86 ;   RO = Character to print.
87 014612 032737 000000G 000000G HLTCHR: BIT    #TRRDY,@#CTTSR ; IS TERMINAL READY FOR ANOTHER CHARACTER?
88 014620 001774                  BEQ    HLTCHR      ; BR IF NOT
89 014622 110037 000000G          MOVB   RO,@#CTTBR    ; SEND CHARACTER TO CONSOLE TERMINAL
90 014626 000207                  RETURN
```

```
1 .SBTTL EXCINI -- Final system initialization
2 ; -----
3 ; EXCINI is the last part of the system start-up initialization routine.
4 ; It is placed in TSEEXEC rather than TSINIT so that tables that are allocated
5 ; over TSINIT can be clobbered during this part of the initialization.
6 ;
7 014630
8 ;
9 ; Set up I/O queue free chain
10 ;
11 014630 013701 000000G      MOV    FREIOQ,R1      ; BASE OF I/O QUEUE AREA
12 014634 012702 177777G      MOV    #NUMIOQ-1,R2   ; # I/Q QUEUE ELEMENTS - 1
13 014640 010103
14 014642 062703 000000G      10$:   MOV    R1,R3      ; GET ADDRESS OF CURRENT QUEUE ELEMENT
15 014646 010361 000000G      ADD    #IOQSIZ,R3   ; POINT TO NEXT QUEUE ELEMENT
16 014652 010301
17 014654 077207
18 014656 005063 000000G      MOV    R3,Q.LINK(R1) ; SET FORWARD LINK IN OUR ELEMENT
19
20 ; Set up fork blocks that are allocated in init area
21 ;
22 014662 012702 000000C      MOV    #<<NUMFRK-FRKGEN>-1>,R2 ; Get # fork blocks to allocate - 1
23 014666 003417
24 014670 013701 000000G      BLE    31$      ; Br if none to allocate
25 014674 010103
26 014676 062703 000000G      30$:   MOV    FRKINI,R1   ; Point to start of fork area
27 014702 010361 000000G      ADD    R1,R3      ; Get address of current block
28 014706 010301
29 014710 077207
30 014712 013763 000000G 000000G  MOV    #FQ$$SZ,R3   ; Point to next block
31 014720 013737 000000G 000000G  MOV    R3,FQ$LNK(R1) ; Set forward link in our element
32
33 ; Set up cache control block free chain
34 ;
35 014726 005737 000000G      31$:   TST    CSHALC      ; Is data caching wanted?
36 014732 001415
37 014734 012702 177777G      BEQ    20$      ; Br if not
38 014740 013701 000000G      MOV    #NUMCCB-1,R2   ; Get # cache control blocks - 1
39 014744 010103
40 014746 062703 000000G      21$:   MOV    CCBHD,R1   ; Base of control block area
41 014752 010361 000000G      ADD    R1,R3      ; Get address of current control block
42 014756 010301
43 014760 077207
44 014762 005061 000000G      MOV    #CC$$SZ,R3   ; Get address of next control block
45
46 ; Initialize device mount table
47 ;
48 014766 013701 000000G      20$:   MOV    CSHDEV,R1   ; Point to start of area
49 014772 005021
50 014774 020137 000000G      40$:   CLR    (R1)+      ; Zero the entire table
51 015000 103774
52
53 ; Initialize shared PLAS region control blocks
54 ;
55 015002 013701 000000G      36$:   MOV    SHRRCB,R1   ; Point to 1st region control block
56 015006 020137 000000G      CMP    R1,SHRRCN   ; Have we initialized entire area?
57 015012 103002
58
59
```

58 015014 005021 CLR (R1)+ ; Zero the area  
59 015016 000773 BR 36\$  
60 ;  
61 ; Initialize free list of swap command packets  
62 ;  
63 015020 013701 000000G 35\$: MOV SCPFHD, R1 ; Point to area where packets are  
64 015024 001413 BEQ 37\$ ; Br if nothing to initialize  
65 015026 012702 177777G MOV #NSCP-1, R2 ; Get # packets -1  
66 015032 010103 38\$: MOV R1, R3 ; Get pointer to current packet  
67 015034 062703 000000G ADD #SP\$\$SZ, R3 ; Get pointer to next packet  
68 015040 010361 000000G MOV R3, SP\$LNK(R1) ; Make our packet point to next  
69 015044 010301 MOV R3, R1 ; Get pointer to next packet  
70 015046 077207 SOB R2, 38\$ ; Loop till all packets but last linked in  
71 015050 005061 000000G CLR SP\$LNK(R1) ; Say last packet is end of list  
72 ;  
73 ; Initialize the free chain of monitor control blocks  
74 ;  
75 015054 013701 000000G 37\$: MOV MONFQH, R1 ; Get base of area for control blocks  
76 015060 013702 000000G MOV VMXMON, R2 ; Get # monitor blocks  
77 015064 001413 BEQ 28\$ ; Br if none wanted  
78 015066 005302 DEC R2 ; Get one less than # wanted  
79 015070 001407 BEQ 42\$ ; Br if only one wanted  
80 015072 010103 29\$: MOV R1, R3 ; Get address of current block  
81 015074 062703 000000G ADD #JM\$\$SZ, R3 ; Get address of next control block  
82 015100 010361 000000G MOV R3, JM\$LNK(R1) ; Make current block point to next  
83 015104 010301 MOV R3, R1 ; Get address of next block  
84 015106 077207 SOB R2, 29\$ ; Br if more to allocate  
85 015110 005061 000000G 42\$: CLR JM\$LNK(R1) ; Zero last link  
86 ;  
87 ; Initialize the tables that keep track of free space in job swap file  
88 ;  
89 015114 013700 000000G 28\$: MOV VSWPSL, R0 ; Get # slots in swap file  
90 015120 001412 BEQ 33\$ ; Br if no swap file  
91 015122 013702 000000G MOV SWPPOS, R2 ; Point to table that has starting blk #'s  
92 015126 013703 000000G MOV SWPJOB, R3 ; Point to table that has job #'s  
93 015132 005004 CLR R4 ; 1st slot is at block 0  
94 015134 010422 32\$: MOV R4, (R2)+ ; Set block # for this slot  
95 015136 005023 CLR (R3)+ ; Say no job using this slot now  
96 015140 063704 000000G ADD SLTSIZ, R4 ; Add # blocks used by a slot  
97 015144 077005 SOB R0, 32\$ ; Loop till all slots initialized  
98 ;  
99 ; Initialize vector for each multiplexor that is used to map from  
100 ; the Mux line number to the TSX-Plus logical line number  
101 ;  
102 015146 012701 000000G 33\$: MOV #LSTMX, R1 ; Get index # of last mux  
103 015152 001470 BEQ 27\$ ; Branch if no mux's to initialize  
104 015154 016103 000000G 15\$: MOV MXLNT(R1), R3 ; GET ADDRESS OF MUX MAPPING TABLE  
105 015160 012700 000020 MOV #16., R0 ; ZERO 16 BYTES IN TABLE  
106 015164 105023 17\$: CLRB (R3)+  
107 015166 077002 SOB R0, 17\$  
108 015170 162701 000002 SUB #2, R1 ; More mux tables to init?  
109 015174 003367 BGT 15\$ ; Loop if yes  
110 015176 012701 000000G 16\$: MOV #LSTHL, R1 ; GET INDEX # OF LAST PHYSICAL LINE  
111 015202 032761 000000G 000000G 19\$: BIT ##HARD, LSW3(R1) ; Is this line connected to hardware?  
112 015210 001410 BEQ 18\$ ; Br if not  
113 015212 016102 000000G MOV LMXNUM(R1), R2 ; IS THIS LINE CONNECTED TO A MUX?  
114 015216 001405 BEQ 18\$ ; BR IF NOT

115 015220 016202 000000G MOV MXLNT(R2), R2 ; GET ADDRESS OF MAP VECTOR FOR THIS MUX  
116 015224 066102 000000G ADD LMXLN(R1), R2 ; ADD OFFSET WITHIN VECTOR  
117 015230 110112 MOVB R1, (R2) ; SET TSX LINE # WITHIN MAP VECTOR  
118 015232 162701 000002 18\$: SUB #2, R1 ; GET INDEX # OF NEXT LINE  
119 015236 003361 BGT 19\$ ; LOOP IF MORE LINES  
120 ;  
121 ; Enable interrupts for multiplexors  
122 ;  
123 015240 105737 000000G TSTB PROFLG ; Are we running on a Pro?  
124 015244 001033 BNE 27\$ ; Br if yes -- Don't have any mux's on pro  
125 015246 012701 000000G MOV #LSTMX, R1 ; Get index # of last mux  
126 015252 005761 000000G 23\$: TST MXCSR(R1) ; Is this mux installed?  
127 015256 001423 BEQ 25\$ ; Br if not  
128 015260 016100 000000G MOV MXTYPE(R1), R0 ; Get mux type code  
129 015264 020027 000000G CMP R0, #CDX\$DZ ; Is this a DZ11?  
130 015270 001004 BNE 24\$ ; Br if not  
131 015272 012771 000000G 000000G MOV #INTMX1, @MXCSR(R1); Enable DZ11 interrupts  
132 015300 000412 BR 25\$  
133 015302 020027 000000G 24\$: CMP R0, #CDX\$VH ; Is this a DHV11?  
134 015306 001004 BNE 26\$ ; Br if not  
135 015310 052771 000000C 000000G BIS #<VF\$TIE!VF\$RIE>, @VH\$CSR(R1); Enable DHV11 interrupts  
136 015316 000403 BR 25\$  
137 015320 052771 000000C 000000G 26\$: BIS #<HF\$TIE!HF\$RIE>, @MH\$SCR(R1); Enable DH11 interrupts  
138 015326 162701 000002 25\$: SUB #2, R1 ; More mux's to initialize?  
139 015332 003347 BGT 23\$ ; Loop if yes  
140 ;  
141 ; Initialize system message buffer free list.  
142 ;  
143 015334 013703 000000G 27\$: MOV SNMSHD, R3 ; GET ADDRESS OF 1ST MESSAGE BUFFER  
144 015340 012704 177777G MOV #<CNMSNMB-1>, R4 ; GET # MESSAGE BUFFERS -1  
145 015344 010302 7\$: MOV R3, R2 ; GET ADDRESS OF MESSAGE BUFFER  
146 015346 062702 000000G ADD #SB\$\$SZ, R2 ; POINT TO FOLLOWING BUFFER  
147 015352 010263 000000G MOV R2, SB\$LNK(R3) ; CHAIN TOGETHER THE ENTRIES  
148 015356 010203 MOV R2, R3 ; MOVE ON TO NEXT ENTRY  
149 015360 077407 SOB R4, 7\$ ; DO ALL BUT LAST  
150 015362 005063 000000G CLR SB\$LNK(R3) ; SET FORWARD LINK FOR LAST ENTRY TO ZERO  
151 ;  
152 ; Initialize INSTALLED program table  
153 ;  
154 015366 004737 016034' CALL INSINI ; Initialize installed program table  
155 ;  
156 ; Initialize CL table information  
157 ;  
158 015372 012704 000000C MOV #2\*<CLLTOTL-1>, R4; Get index to last CL unit  
159 015376 002407 BLT 39\$ ; Br if there are no CL units  
160 015400 016400 000000G 41\$: MOV CL\$EPS(R4), R0 ; Get pointer to EOF string buffer  
161 015404 001401 BEQ 45\$ ; Br if no string buffer  
162 015406 105010 CLRB (R0) ; Say no EOF string  
163 015410 162704 000002 45\$: SUB #2, R4 ; Get next index  
164 015414 002371 BGE 41\$ ; Loop if more CL units  
165 ;  
166 ; Initialize the file management tables  
167 ;  
168 015416 39\$: OCALL USRINI ; Call TSUSR initialization routine  
169 ;  
170 ; Initialize spool buffer list  
171 ;

```
172 015424 105737 000000G          TSTB    NSPLDV      ; Are there any spooled devices?  
173 015430 001403          BEQ     11$       ; Br if not  
174 015432          OCALL   SPLINI      ; Initialize the spooling system  
175          ;  
176          ; Initialize the record locking system  
177          ;  
178 015440 005737 000000G          11$:   TST     VMXSF      ; Is record locking support wanted?  
179 015444 001402          BEQ     12$       ; Br if not  
180 015446 004777 000000G          CALL    @ELOKINI    ; Initialize the shared file system  
181          ;  
182          ; Initialize the message communication system  
183          ;  
184 015452 005737 000000G          12$:   TST     VMAXMC    ; Is message communication support wanted?  
185 015456 001403          BEQ     13$       ; Br if not  
186 015460          OCALL   MSGINI      ; Initialize the message system  
187          ;  
188          ; Initialize the data caching facility  
189          ;  
190 015466 005737 000000G          13$:   TST     CSHALC    ; Is data caching wanted?  
191 015472 001402          BEQ     43$       ; Br if not  
192 015474 004777 000000G          CALL    @ECSHINI    ; Initialize data caching facility  
193          ;  
194          ; Initialize the PLAS system  
195          ;  
196 015500 005737 000000G          43$:   TST     VPLAS      ; Is PLAS support included in system?  
197 015504 001403          BEQ     44$       ; Br if not  
198 015506          OCALL   PLSINI      ; Do PLAS initialization  
199          ;  
200          ; Initialize the display window management system  
201          ;  
202 015514 005737 000000G          44$:   TST     VMXWIN    ; Is window support wanted?  
203 015520 001403          BEQ     34$       ; Br if not  
204 015522          OCALL   WININI      ; Initialize window system  
205          ;  
206          ; Connect clock interrupt to clock interrupt routine  
207          ;  
208 015530 012737 000000G 000100  34$:   MOV     #CLKINT, @#100  ; Set up clock interrupt vector  
209 015536 105737 000000G          TSTB    PROFLG      ; Is this a PRO?  
210 015542 001410          BEQ     22$       ; Br if not  
211 015544 012737 000000G 000230  MOV     #CLKINT, @#230  ; 380 clock interrupt vector  
212 015552 012737 000340 000232  MOV     #340, @#232  
213 015560 005737 000000G          TST    @#PCCR2      ; Access CSR2 to start clock interrupts  
214          ;  
215          ; Initialize time-sharing line parameters and speeds  
216          ;  
217 015564 004737 015714'        22$:   CALL   INISPD      ; Initialize time-sharing line speeds  
218          ;  
219          ; Start lines that specified $START when genned.  
220          ;  
221 015570 012701 000002          MOV     #2, R1       ; INDEX # OF 1ST LINE  
222 015574 032761 000000G 000000G 2$:  BIT    #$START, ILSW2(R1); DOES THIS LINE WANT AUTO STARTUP?  
223 015602 001413          BEQ     3$        ; BR IF NOT  
224 015604 032761 000000G 000000G  BIT    #$DEAD, LSW3(R1) ; IS THIS LINE INSTALLED?  
225 015612 001007          BNE     3$        ; BR IF NOT  
226 015614 032761 000000G 000000G  BIT    #$PHONE, ILSW2(R1); IS THIS A DIAL-UP LINE?  
227 015622 001003          BNE     3$        ; BR IF IT IS (NO AUTO STARTUP THEN)  
228 015624 005000          CLR     RO         ; No secondary start-up command file
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 52-4  
EXCINI -- Final system initialization

```
229 015626 004737 001606'          CALL    INITLN      ; INITIATE THE LINE
230 015632 062701 000002          3$:    ADD     #2,R1      ; ADVANCE JOB #
231 015636 020127 000000G         CMP     R1,#LSTPL   ; MORE TO CHECK?
232 015642 101754               BLOS    2$       ; BR IF YES
233
234           ; Start any detached jobs
235
236 015644 012701 000000G         MOV     #FSTDL,R1   ; # OF FIRST DETACHED JOB
237 015650 020127 000000G         6$:    CMP     R1,#LSTDL   ; DONE ALL DETACHED JOBS?
238 015654 101013               BHI    4$       ; BR IF YES
239 015656 016102 000000G         MOV     LSUCF(R1),R2  ; DOES THIS JOB HAVE A START-UP COMMAND FILE?
240 015662 001405               BEQ    5$       ; BR IF NOT
241 015664 105712               TSTB   (R2)      ; IS COMMAND FILE NAME NULL?
242 015666 001403               BEQ    5$       ; BR IF YES
243 015670 005000               CLR     R0        ; No secondary start-up command file
244 015672 004737 001606'         CALL   INITLN      ; INITIATE THE LINE
245 015676 062701 000002          5$:    ADD     #2,R1      ; CHECK NEXT LINE
246 015702 000762               BR     6$       ; 
247 015704
248
249           ; Finished system initialization
250 015704 105037 000000G         CLRB   INITFL      ; SAY SYSTEM INITIALIZATION IS FINISHED
251
252           ; Enter job scheduler to wait for first job to run
253
254 015710 000137 000000G         JMP    EXEC       ; ENTER JOB SCHEDULER
```

INISPD -- Initialize time-sharing line speeds

```

1           .SBTTL INISPD -- Initialize time-sharing line speeds
2
3           ;-----;
4           ; INISPD is called to initialize the transmit/receive speeds for
5           ; time-sharing lines.
6
7 015714 010146           INISPD: MOV      R1,-(SP)
8 015716 010246           MOV      R2,-(SP)
9
10          ; Begin loop to set each line
11 015720 012701 000000G     MOV      #LSTHL,R1      ;Get index to last hardware line
12
13          ; Skip this line if it is dead or not connected to hardware
14
15 015724 032761 000000G 000000G 1$:   BIT      #$HARD,LSW3(R1) ;Is this line connected to hardware?
16 015732 001432           BEQ      2$          ;Br if not
17 015734 032761 000000G 000000G           BIT      #$DEAD,LSW3(R1) ;Is this line installed?
18 015742 001026           BNE      2$          ;Br if not
19
20          ; Set the speed of this line
21
22 015744 116100 000001G     MOVB    LMXPRM+1(R1),R0 ;Get speed parameters
23
24          ; Initialize speed to 9600 baud if autobaud was specified for line
25
26 015750 032761 000000G 000000G           BIT      #$AUTO,ILSW2(R1); Is autobaud wanted for this line?
27 015756 001402           BEQ      3$          ;Br if not
28 015760 012700 000000G           MOV      #S9600,R0      ;Set speed to 9600
29 015764 016102 000000G           3$:   MOV      LCDTYP(R1),R2 ;Get device type code for this line
30 015770 004772 000000G           CALL    @CDSSPD(R2) ;Call hardware-dependent routine to set speed
31
32          ; Convert $TDEAD lines (deaded with TSXMOD) to $DEAD lines
33
34 015774 020127 000000G           CMP      R1,#LSTPL      ;Is this a time-sharing line?
35 016000 101007           BHI      2$          ;Skip if not (skip sub, det & io lines)
36 016002 032761 000000G 000000G           BIT      #$TDEAD,LSW11(R1) ;Do we want this line to be dead?
37 016010 001403           BEQ      2$          ;Br if not
38 016012 052761 000000G           BIS      #$DEAD,LSW3(R1) ;Flag line as dead
39
40          ; See if there are more lines
41
42 016020 162701 000002           2$:   SUB      #2,R1      ;Are there more lines to do?
43 016024 003337           BGT      1$          ;Br if yes
44
45          ; Finished
46
47 016026 012602           MOV      (SP)+,R2
48 016030 012601           MOV      (SP)+,R1
49 016032 000207           RETURN

```

```
1 .SBTTL INSINI -- Initialize installed program table
2 ;-----
3 ; Initialize the installed program table.
4 ;
5 016034 010246           INSINI: MOV      R2,-(SP)
6 016036 010346           MOV      R3,-(SP)
7 ;
8 ; Initially, zero the entire table
9 ;
10 016040 013702 000000G    MOV      INSTBL,R2      ;Point to start of table
11 016044 005022           1$: CLR      (R2)+      ;Zero the table
12 016046 020237 000000G    CMP      R2,INSTBN    ;Reached end of table?
13 016052 103774           BLO      1$          ;Loop if not
14 ;
15 ; Now install certain system programs
16 ;
17 016054 013702 000000G    MOV      INSTBL,R2      ;Point to 1st table entry
18 016060 012703 001412'   MOV      #SRFPRG,R3    ;Point to table with info about sys programs
19 ;
20 ; Set file spec for program
21 ;
22 016064 013762 000000G 000000G 2$: MOV      SYNAME,II$NAM(R2);Set SY as device name
23 016072 012362 000002G   MOV      (R3)+,II$NAM+2(R2);Set 1st 3 chars of program name
24 016076 012362 000004G   MOV      (R3)+,II$NAM+4(R2);Set 2nd 3 chars of program name
25 016102 013762 001350' 000006G   MOV      R50SAV,II$NAM+6(R2);Set SAV as file extension
26 ;
27 ; Set run attribute flags
28 ;
29 016110 012362 000000G   MOV      (R3)+,II$FLG(R2);Set run attribute flags
30 ;
31 ; Set privileges for program
32 ;
33 016114 052762 000000G 000000G   BIS      #PO$DBG,II$NPV(R2) ;Set NODEBUG privilege flag
34 016122 012704 000000G           3$: MOV      #II$PRV,R4      ;Assume we will set some privileges
35 016126 012300               MOV      (R3)+,R0      ;Are there any privilege flags?
36 016130 001412               BEQ      4$          ;Br if not
37 016132 002003               BGE      5$          ;Br if we are to set privileges
38 016134 005400               NEG      R0          ;Get positive offset
39 016136 012704 000000G           MOV      #II$NPV,R4      ;Point to reset-privilege vector
40 016142 005300               5$: DEC      R0          ;Convert to offset
41 016144 006300               ASL      R0          ;Convert to word offset
42 016146 060004               ADD      R0,R4      ;Point to word in vector to change
43 016150 060204               ADD      R2,R4      ;Add address of install table entry
44 016152 012314               MOV      (R3)+,(R4)    ;Set bits in install table entry
45 016154 000762               BR      3$          ;Go see if more privileges for program
46 ;
47 ; See if there are more programs to install
48 ;
49 016156 062702 000000G   4$: ADD      #II$$SZ,R2      ;Point to next install table entry
50 016162 020327 001606'   CMP      R3,#SRFEND    ;Installed all system programs?
51 016166 103736           BLO      2$          ;Loop if not
52 ;
53 ; Finished
54 ;
55 016170 012603           MOV      (SP)+,R3
56 016172 012602           MOV      (SP)+,R2
57 016174 000207           RETURN
```

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 54-1  
INSINI -- Initialize installed program table

58  
59 000001 .END  
Errors detected: 0

\*\*\* Assembler statistics

Work file reads: 0  
Work file writes: 0  
Size of work file: 9760 Words ( 39 Pages)  
Size of core pool: 18176 Words ( 71 Pages)  
Operating system: RT-11

Elapsed time: 00:01:31.51  
,LP:TSEXC2=DK:TSEXC2/C/N:SYM

\$1STLG	1-51	10-169				
\$AUTO	1-47	10-105	28-14	53-26		
\$CARMN	1-57	5-97	5-103	30-48		
\$CARUP	1-51	5-101	10-171	30-43	30-67	
\$CFABT	1-59					
\$CTRLC	1-70	8-29	8-38			
\$CTRLO	1-47	6-111				
\$CTRLS	1-66	6-111	10-30	48-34		
\$DBGBK	1-104	8-18	12-28			
\$DBGMD	1-54	8-17				
\$DEAD	1-58	10-171	29-15	52-224	53-17	53-38
\$DEBUG	1-89	13-57				
\$DEFER	1-83	6-125				
\$DETCH	1-36	6-104	10-10			
\$DHBF1	1-86	10-34				
\$DHBF2	1-86	10-34				
\$DHCD0	1-36	49-14				
\$DILUP	1-36	5-81	10-28	10-65	30-44	30-51
\$DISCN	1-42	7-29	7-33	10-50	10-126	30-53
\$DODFR	1-83	6-127				
\$DOOFF	1-68	7-31	30-53			
\$FPUEX	1-81	14-11				
\$GCECO	1-83	6-127				
\$GEMAR	1-30	8-13				
\$HARD	1-74	10-171	29-17	52-111	53-15	
\$IITIM	1-78	47-20	47-27	48-22	48-26	
\$INCOR	1-99	5-71	18-27			
\$INIT	1-61	6-9				
\$INKMN	1-60	6-15	7-14	7-41	12-14	13-23
\$IOMAP	1-71	8-17				26-36
\$LOFCF	1-62	10-124	30-55			
\$MAPOK	1-79	7-42				
\$MLOCK	1-71	8-17				
\$NABRS	1-47	10-108	28-27	28-29		
\$NOABT	1-80	8-18				
\$NOIN	1-68	5-82	7-32	30-50		
\$NOLF	1-54	8-17				
\$NOUCR	1-49	7-11	7-25			
\$OITIM	1-94	47-31	47-37	48-30	48-38	
\$PHONE	1-58	5-98	29-29	52-226		
\$PWKEY	1-31	5-84				
\$RDSAV	1-30	8-13				
\$RNMLK	1-54	8-18				
\$SGQ0	1-90	17-30				
\$SGQ1	1-101	17-56				
\$SGQ1A	1-101	17-81				
\$SGQ1B	1-101	17-100				
\$SGQ1C	1-101	17-91				
\$SGQ2	1-101	17-115				
\$SGQ3	1-90	17-37				
\$SOTFN	1-83	27-16	27-18			
\$START	1-58	52-222				
\$SUCF	1-55	5-83				
\$TDEAD	1-58	53-36				
\$UDSPC	1-111	8-138				
\$VIRJB	1-76	7-43				

\$VNOTT	1-66	10-16						
\$XCHAR	1-79	10-36	10-171	47-33	47-35	48-32	48-36	
. . . V1	7-58	7-72	7-72					
. . . V2	7-58	7-58#	7-72	7-72	7-72#	7-72#		
ABORT	1-22	11-52	13-71#	14-20	14-28			
ABRTAD	1-60	13-71*						
ABRTCD	1-60	13-72*						
AF\$BYA	1-41	4-49	4-75					
AF\$DUP	1-32	4-29						
AF\$HIE	1-41	4-37	4-41	4-45				
AF\$IND	1-32	4-33						
AF\$IOP	1-41	4-58						
AF\$MEM	1-41	4-83						
AF\$NOI	1-41	4-71						
AF\$NOW	1-41	4-33	4-37	4-41	4-45	4-67	4-71	4-83
AF\$NPW	1-31	4-71						
AF\$PLK	1-40	4-49						
AF\$SCA	1-41	4-37	4-41	4-45	4-54	4-67	4-71	4-83
AF\$SET	1-32	4-58						
AF\$UCL	1-32	4-79						
BELL	1-118#	3-27						
C. NUMQ	1-30	6-68*						
CANCPL	8-104	9-10#						
CANIOT	1-52	8-44						
CANMKT	1-72	8-70						
CARDET	1-77	31-26						
CC\$\$SZ	1-102	52-40						
CC\$LNK	1-102	52-41*	52-44*					
CCBHD	1-62	52-38						
CDCLOK	1-56	29-23						
CDGDSS	1-103	30-15						
CDIFLG	1-108	15-58	15-60*					
CDIRTN	1-108	15-63						
CDOFLG	1-108	15-67	15-69*					
CDORTN	1-108	15-72						
CDSDSS	1-103	30-30	30-61	30-81				
CDSSPD	1-36	53-30						
CDX\$DZ	1-48	52-129						
CDX\$VH	1-104	52-133						
CFACFL	1-59							
CFPSAV	1-30							
CHKABT	1-53	11-66	13-29					
CHKPRT	18-116	20-7#						
CHKUSP	1-59	11-50	13-20	14-25				
CINFLG	1-33	8-31*	8-42					
CKMRKT	15-23	24-6#						
CKSCHD	15-34	27-9#						
CKTWAT	15-27	22-6#						
CL\$EPS	1-38	52-160						
CLENUP	7-24	8-9#						
CLK01S	15-85	18-6#						
CLKABD	18-107	28-6#						
CLKCNT	1-84	15-8*	15-18	15-78	15-90	16-19	22-13	24-20
CLKDAT	15-12	16-13#						
CLKINT	1-57	52-208	52-211					
CLKIOH	18-103	19-9#						



DIESP	1-33	50-113			
DLCLOK	1-25	47-9#			
DLGDSS	1-24	31-11#			
DLSBRK	1-23	33-9#			
DLSDSS	1-24	32-9#			
DLSSPD	1-25	34-9#			
DLSTRT	1-73	47-36			
DM\$CSR	1-106	39-23*	39-24*	40-17*	40-18*
DM\$LSR	1-106	39-25	40-24*	40-26*	
DMPHND	1-34	50-25*	50-106*		
DMPDVL	1-34	50-24*	50-96*		
DMPTXT	1-34	50-126			
DODUMP	1-33	50-129			
DOSCHD	1-81	18-35*			
DOTRMP	1-30	8-129*			
DTLX	1-89	18-46	18-48*		
DZ\$7BT	1-44	38-21			
DZ\$8BT	1-44	38-19			
DZ\$LEN	1-44				
DZ\$ODD	1-44	38-27			
DZ\$PAR	1-44	38-24			
DZCLOK	1-25	48-9#			
DZGDSS	1-24	35-11#			
DZSBRK	1-23	37-10*			
DZSDSS	1-24	36-9#			
DZSSPD	1-23	38-9#			
DZSTRT	1-73	48-37			
EM\$DTL	1-99	3-6	3-6#	18-137	
EM\$FRK	3-7	3-7#			
EM\$JMO	3-8	3-8#			
EM\$KRE	3-9	3-9#	7-74		
EM\$KTP	3-10	3-10#	11-35		
EM\$LMF	3-11	3-11#			
EM\$MIO	3-12	3-12#			
EM\$MPR	3-13	3-13#			
EM\$NQE	3-14	3-14#			
EM\$NSP	3-15	3-15#			
EM\$PFT	3-16	3-16#			
EM\$RIT	3-17	3-17#	11-46		
EM\$SFO	3-18	3-18#			
EM\$SIE	3-19	3-19#			
EM\$SJN	3-21	3-21#	7-8		
EM\$SOF	3-23	3-23#			
EM\$SSE	3-20	3-20#			
EM\$UEI	3-22	3-22#			
EMTBLK	1-32	10-94			
EMTCAD	1-67	6-52*	8-24*		
EMTCAS	1-93	6-52	8-24		
EMTLEV	1-68	6-51*	7-12*		
EMTRAD	1-67	8-22*			
ENQTL	1-96	17-43	17-105	19-43	22-28
ERRLOC	1-68	7-40	7-51*		27-25
EXCINI	1-21	52-7#			
EXEC	1-52	10-189	52-254		
FORCEX	1-42	10-127	19-30		
FORKIT	3-50#	24-12*	24-44*	24-59	



INVEC	1-76	47-13						
IOHALT	1-71	8-45						
IOQSIZ	1-55	52-14						
IOSTOP	1-71							
ITRMTP	1-65	6-110						
Jcdb	1-52	8-108	8-110					
JM\$\$SZ	1-96	52-81						
JM\$LNK	1-85	52-82*	52-85*					
JOBCCB	1-49	9-46	9-48					
JSTK	1-68	6-138	7-9					
JSTKND	1-68	6-53*						
JSWLOC	1-69	7-52*						
KILJOB	1-65	30-58						
KMNBSAS	1-69	7-47	7-69					
KMNCHN	1-70	7-62						
KMNPGS	1-75	5-58	5-60					
KMNSTK	1-70	7-78						
KMNSTR	1-70	7-88						
KMNTOP	1-69	7-46	7-50	7-68				
KMONCE	1-46	5-36						
KPAR6	1-64	6-35*	26-70*					
LABTIM	1-47	10-107*	28-19	28-21*				
LACTIV	1-62	6-20*						
LAFSIZ	1-63	6-22*						
LBASE	1-42	10-156	10-161*					
LBRKCH	1-63	6-26*	8-21*					
LBRKCQ	1-63	6-25*	8-84	8-86*	20-29	20-40	20-42*	
LBSPRI	1-75	5-85*						
LCDTIM	1-87	5-100*	30-31*	30-41*	30-71*			
LCDTYP	1-56	29-22	30-14	53-29				
LCLUNT	1-90	5-29	29-27					
LCMPL	1-72	5-51*	9-28	19-38				
LCOL	1-63	6-21*						
LCONTM	1-64	6-30*						
LCPUHI	1-63	1-84	6-28*	15-19*				
LCPULO	1-64	1-84	6-29*	15-18*				
LCXPAR	1-54	6-35						
LCXTBL	1-32	10-112						
LDKMON	6-142	7-30	7-37#					
LEMTPC	1-99	26-55						
LF	1-117#	3-27	3-27	51-17				
LF\$IN	1-79	8-32						
LHIPCT	1-76	5-87*						
LINBUF	1-61	5-75						
LINCNT	1-61	5-80*						
LINCUR	1-64	6-31*						
LINNXT	1-61	5-76*						
LINPNT	1-61	5-78*						
LINSIZ	1-56	5-79						
LINSPC	1-57	5-79*						
LINSWT	1-37	10-70						
LIOCNT	1-75	5-50*	9-20	9-30				
LIOHLD	1-52	19-17	19-22*					
LITIME	1-66	1-100	5-88*	17-51	17-53*	17-76	22-23	25-28
LJSW	1-61	6-11*	7-38*	7-39	7-53*			27-20
LMEMIN	1-51	5-65*	10-160*					

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page 9-7  
 Cross reference table (CREF V05.05)

LMING	1-89	18-29	18-31*									
LMXLN	1-60	35-18	36-15	37-17	38-32	39-18	40-15	41-27	42-15	43-19	44-15	45-26
	46-15	48-15	52-116									
LMXNUM	1-56	35-17	36-14	37-16	38-33	39-17	40-14	41-26	42-14	43-18	44-14	45-25
	46-14	48-14	52-113									
LMXPRM	1-109	34-13*	38-13*	41-16*	45-15*	53-22						
LNBLSK	1-42	5-49*	5-68*	10-157	10-159*							
LNMAP	1-42	10-68	10-100*									
LNPRIM	1-37	6-117	10-27	10-52	10-64	10-67	10-85*					
LNSBLK	1-74	6-14*										
LNSPAC	1-31	10-175*										
LOFFTM	1-87	5-96*	10-97*	30-32*	30-62*	30-76	30-78*					
LOGCHR	1-79	8-35	8-36									
LOGCR	1-79	8-37										
LOGFLG	1-79	8-32										
LOGOFF	1-21	10-10#										
LOKINI	1-66	52-180										
LOTBUF	1-62	6-16										
LOTNXT	1-62	6-17*										
LOTPNT	1-62	6-18*										
LOTSIZ	1-36	6-19	10-32									
LOTSPC	1-36	6-19*	10-32									
LP\$7BT	1-43	38-17	41-36	45-35								
LP\$ODD	1-43	38-25	41-44	45-43								
LP\$PAR	1-43	38-22	41-41	45-40								
LP\$SPD	1-43	38-15	41-21	45-20								
LPARNT	1-38	10-148	10-150*	10-174*								
LPRG1	1-80	20-18										
LPRG2	1-80	20-20										
LPRI	1-75	5-86*	17-22	25-32								
LPROG	1-63	6-23*	6-121	6-121*								
LPROJ	1-63	5-89*	6-81	6-93*	6-120	6-120*						
LQUAN	1-61	1-70	6-10*	7-83*	17-16*	17-21	17-44*	17-61	17-106*			
LRDTIM	1-71	8-19*	21-13	21-15*								
LRTCHR	1-82	21-18										
LSCCA	1-63	6-24*	8-20*									
LSECPT	1-37	10-55	10-77	10-119								
LSLEPH	1-70	1-96	8-14*	22-14*								
LSLEPL	1-70	1-96	8-15*	22-13*	22-17							
LSPND	1-71	8-16*										
LSTACT	1-61	5-77*										
LSTATE	1-81	17-42	17-65	17-70	17-86	17-104	19-28	19-40	21-11	22-11	26-52	27-23
LSTDL	1-58	5-116	6-97	52-237								
LSTHL	1-75	29-11	52-110	53-11								
LSTMX	1-56	52-102	52-125									
LSTPL	1-37	1-56	5-34	5-94	5-112	6-99	10-41	28-10	29-31	52-231	53-34	
LSTS1	1-81	10-147	18-26	19-13	20-17	21-7	22-10	27-11				
LSUCF	1-58	52-239										
LSW	1-36	5-48*	5-71*	5-81*	6-9*	6-104*	7-29	7-31*	7-33*	8-29	8-38*	10-10
	10-16	10-28	10-50	10-65	10-126*	10-166*	14-11*	18-27	30-44	30-51	30-53	
LSW10	1-86	10-34	49-14*									
LSW11	1-31	5-84*	8-13*	8-138*	53-36							
LSW2	1-51	6-109*	6-118	6-118*	6-125	10-98*						
LSW3	1-59	5-82*	5-101	6-111*	6-127*	7-32*	10-30*	10-36	10-173*	29-15	29-17	30-43*
	30-50*	30-67*	47-33	47-35*	48-32	48-34	48-36*	52-111	52-224	53-15	53-17	53-38*
LSW4	1-51	6-15*	7-14	7-41*	10-167*	12-14	13-23	26-36				





R50PRT	3-54#	20-20				
R50SAV	3-55#	54-25				
RCBBAS	1-67	1-74				
RCBEND	1-67	1-74				
RCVDON	1-78	47-18				
RDAR	1-88	8-133*				
RDDR	1-88	8-134*				
RDINT	1-78	47-23	47-24			
RDONE	1-78	48-20				
RIE	1-78	48-24	48-25			
RING	1-77	31-20				
RPAR	1-64	8-131*				
RPDR	1-64	8-132*				
RSR	1-76	31-16	32-18*	32-23*	47-18	47-23*
RTSTOP	1-71	8-49				
S\$\$HIP	1-94	17-65				
S\$\$RT	1-94	17-70				
S\$HICP	1-65	17-86	17-92	22-25	25-30	
S\$INWT	1-81	21-11				
S\$IOWT	1-82	9-22	19-28	26-52		
S\$OTFN	1-83	27-19				
S\$OTLO	1-83	27-22				
S\$TMWT	1-94	22-11				
S\$TWFN	1-94	22-27	25-27			
S\$WSMB	1-95	18-21				
S150	1-52					
S9600	1-47	28-30	53-28			
SB\$\$SZ	1-57	52-146				
SB\$LNK	1-57	52-147*	52-150*			
SCHED	1-50	9-37				
SCPFHD	1-53	52-63				
SETMAP	1-67	6-131	7-49			
SETSPD	1-47	28-31				
SHRRCB	1-98	52-55				
SHRRCN	1-98	52-56				
SLTSIZ	1-35	52-96				
SNMSHD	1-57	52-143				
SP\$\$SZ	1-57	52-67				
SP\$LNK	1-44	52-68*	52-71*			
SPCPSS	1-68	8-23*				
SPIJ	1-31	6-83*	10-48			
SPLINI	1-66	52-174				
SPSTAT	1-80	20-31*	20-35	20-44*	20-49*	
SPTXT	3-34#	50-111				
SR3FLG	1-111	8-139				
SR3MMR	1-111	8-141*				
SRFEND	4-87#	54-50				
SRFPRG	4-27#	54-18				
SS	1-52	10-185				
SS\$PRT	1-80	20-35	20-44	20-49		
SS\$RUN	1-80	20-31	20-44	20-49		
STOP	1-22	1-60	7-6#	13-73		
STPFLG	1-76	30-20				
STRACT	1-89	21-19				
SUCF2	1-31	6-86				
SUTOP	1-69	7-48				

SWPCOT	1-81	18-33	18-36*						
SWPJOB	1-35	52-92							
SWPPOS	1-35	52-91							
SYNAME	1-39	54-22							
SYPNCR	1-55	24-38	24-43*	25-13	25-15*				
SYSDAT	1-81	16-33	16-61*						
SYSDIE	1-22	50-15#							
SYSHL1	1-33	11-39							
SYSHLT	1-59	1-93	7-8	7-74	11-46	18-137			
SYSXIT	1-43	12-30							
SYTIMH	1-85	10-18	10-22	16-20*	16-24	16-32*			
SYTIML	1-85	10-19	10-25	16-19*	16-26	16-31*			
TIKO1S	3-52#	15-81*	18-12	18-124*					
TIKCNT	1-84	15-6	15-90*						
TK1CNT	1-85	15-78*	15-80*						
TK1VAL	1-84	15-80							
TK5CNT	1-85	18-111*	18-113*						
TLCHK	18-114	29-6#							
TMIDLH	1-93	18-95*							
TMIDLL	1-93	18-94*							
TMI0H	1-91	18-60*							
TMIOL	1-91	18-59*							
TMIOWH	1-92	18-83*	18-91*						
TMIOWL	1-92	18-82*	18-90*						
TMSWPH	1-92	18-66*							
TMSWPL	1-92	18-65*							
TMSWTH	1-93	18-85*							
TMSWTL	1-93	18-84*							
TMTOTH	1-91	18-56*							
TMTOTL	1-91	18-55*							
TMUSRH	1-92	18-70*							
TMUSRL	1-92	18-69*							
TOTON	1-51	5-111*	10-176*						
TRBRK	1-100	33-18	33-23						
TRMRDY	1-77	31-32	32-18	32-23					
TRNSTR	1-74	10-31							
TRPAR5	1-34	50-53	50-77						
TRPBPT	1-22	12-10#							
TRPCOM	1-21	11-29	11-60	11-62	12-37	13-11#			
TRRDY	1-54	51-87							
TSEXC2	1-6#								
TSR	1-109	33-18*	33-23*	34-18	34-21*				
TSXTX	1-21	11-15#							
TXARG	3-28#	50-45							
TXDEV	3-33#	50-103							
TXFSE	3-27#	50-29							
TXNUL	3-29#	51-41	51-66						
TXOID	3-32#	50-93							
TXPAR5	3-30#	50-75							
TXSEG	3-31#	50-89							
UERSEV	1-68	7-18*							
UFPTRP	1-53	8-123*	14-13	14-57	14-59*				
UHIMEM	1-69	7-50*							
UIOCNT	1-89	18-57	18-79	18-88					
UMODE	1-53	1-99	7-87	11-16	11-79	13-15	13-43	14-58	26-27
UPMODE	1-53	7-13	7-37	11-79	13-43	14-10	14-58	26-42	

UREGO	1-95	18-22				
USDSPC	1-111	8-141				
USRINI	1-55	52-168				
USRJOB	1-72	8-53				
UTRPAD	1-53	8-122*	11-56	11-84	11-85*	
VDBFLG	1-43	12-26				
VDMKTP	1-34	11-27				
VECBAS	1-65	6-58				
VF\$7BT	1-46	45-39				
VF\$8BT	1-46	45-37				
VF\$BC	1-49	46-24	46-26			
VF\$DCD	1-105	43-38				
VF\$DTR	1-105	43-44	44-24	44-26		
VF\$EVN	1-46	45-45				
VF\$LEN	1-46					
VF\$PAR	1-46	45-42				
VF\$RIE	1-48	1-86	43-20	44-16	45-27	46-16
VF\$RNG	1-105	43-32				52-135
VF\$SC	1-49					
VF\$TIE	1-48	52-135				
VH\$CSR	1-48	1-104	43-25*	44-21*	45-50*	46-21*
VH\$LCR	1-42	1-104	43-26	44-24*	44-26*	46-24*
VH\$LPR	1-49	45-51*				46-26*
VH\$LSR	1-104	43-27				
VHCLOK	1-26	49-9#				
VHGDS	1-25	43-11#				
VHSBRK	1-26	46-9#				
VHSDSS	1-25	44-9#				
VHSPCT	3-63#	45-21				
VHSSPD	1-26	45-9#				
VINTIO	1-100	5-87				
VMAXMC	1-65	8-78	52-184			
VMNUAO	1-46	5-38				
VMXMON	1-96	52-76				
VMXSF	1-66	52-178				
VMXWIN	1-88	10-135	52-202			
VOFFTM	1-87	10-96				
VONTM	1-87	30-32				
VPAR5	1-34					
VPAR6	1-82	26-69				
VPLAS	1-74	8-116	10-141	52-196		
VPRIDF	1-75	5-85	5-86			
VPRIHI	1-90	17-23				
VPRILO	1-90	17-32				
VQUANO	1-90	17-25	17-27			
VQUAN1	1-95	5-88				
VQUAN2	1-95	17-112				
VQUAN3	1-90	17-34				
VQUN1A	1-95	17-78				
VQUN1B	1-96	17-97				
VQUN1C	1-100	17-88				
VWPFL	1-69	5-66	7-44			
VWPSL	1-35	52-89				
VSYDMP	1-33	50-118				
VTMIN	1-87	30-31				
VTMLOC	1-87	5-100				

TSEXC2 -- Misc. TSX-Plus Execu MACRO V05.05 Wednesday 18-Jan-89 15:26 Page S-13  
Cross reference table (CREF V05.05)

VTMOUT	1-87	30-71
VUSPHN	1-30	30-46
WAKEUP	18-115	21-6#
WININI	1-88	52-204
WINREL	1-45	10-137

... CM1	7-72												
... CM2	7-72	7-72	7-72	7-72									
... CM3	7-58												
... CM5	7-72												
... CM7	7-72												
PURGE	2-4#	7-58											
READW	2-4#	7-72											
DIE	2-37#	7-8	7-74	11-46	18-137								
DISABL	2-21#	9-19	24-14	25-12	34-17	39-22	40-16	41-50	43-24	44-20	45-49	46-20	
		47-22											
ENABL	2-27#	7-10	9-27	10-187	24-58	25-16	25-44	34-22	39-26	40-30	41-53	43-28	
	44-30	45-52	46-30	47-25									
OCALL	2-11#	8-35	8-36	8-37	8-49	8-55	8-62	8-66	8-70	8-74	8-80	8-118	
	10-70	10-137	10-143	21-19	30-58	52-168	52-174	52-186	52-198	52-204			
SATXT	2-47#	3-6	3-7	3-8	3-9	3-10	3-11	3-12	3-13	3-14	3-15	3-16	
	3-17	3-18	3-19	3-20	3-21	3-22	3-23						