

MAINDEC-08-DO5B-D

IDENTIFICATION

| | |
|---------------|---------------------|
| Product Code: | MAINDEC-08-DO5B-D |
| Product Name: | Random JMP-JMS Test |
| Date Created: | December 28, 1967 |
| Maintainer: | Diagnostic Group |
| Author: | R. Green |

1. ABSTRACT

This is a diagnostic program to test the JMS instruction of the PDP-8. Random FROM and TO addresses are selected for each test. The JMP instruction is tested in that each test requires a JMP to reach the JMS.

2. REQUIREMENTS

2.1 Equipment

PDP-8 equipped with Teletype.

2.2 Storage

Locations 0000 - 0574

The Binary Loader must be stored in the last memory page.

2.3 Preliminary Programs

It is assumed that MAINDEC 08-D01(n), 08-D02(n), 08-D03(n), and 08-D04(n) have been run successfully.

3. LOADING PROCEDURE

3.1 Method

Use the standard Binary Loader

4. STARTING PROCEDURE

4.1 Control Switch Settings

| | |
|-----|--|
| SR0 | Halt on error. |
| SR2 | Hold the FROM address constant (1). Select random FROM addresses (0). |
| SR3 | Hold the TO address constant (1). Select random TO addresses (0). |

4.2 Starting Address

0200

Restart Address - 0215

4.3 Operator Action

- a. Set SR to 0200 and press LOAD ADDRESS.
- b. If it is desired to set either SR2 or SR3, the FROM or TO address may be specified by entering the address into the locations shown below.

FROM = Location 130

TO = Location 126

If SR2 or SR3 is set after the program has been started, the last address taken from the random number generator is used repeatedly.

- c. Push START.

5. OPERATING PROCEDURE

Same as section 4.

6. ERRORS

6.1 Error Halts

All unused memory locations are loaded with HLT instructions. If the program executes one of these background HLTs, it is probable that the interrupt failed to occur following the JMS instruction. The FROM and TO address may be checked at any time to locate the test JMS instructions.

6.2 Error Printouts

F xxxx TO yyyy

(TO) = mmmm

(nnnn) = rrrr

6.2.1 Explanation

(FROM) F xxxx: xxxx = address of JMS instruction being tested.

(TO) TO yyyy: yyyy = address that the JMS instruction is going to.

(TO) = mmmm; mmmm = the contents of the address TO. This should equal xxxx + 1.

(nnnn) = rrrr: nnnn is the address minus one that was stored in location 0000 during the interrupt. rrrr is the content of address nnnn.

6.2.2 Examples

- a. The following is a forced error printout where no error occurred.

F 5236 TO 6354

(TO) = 5237

(6354) = 5237

The test JMS instruction was in location 5236. The JMS was trying to jump to location 6354. The contents of TO (location 6354) was 5237. This is correct since the PC is stored on a JMS instruction.

To gain any knowledge from the third line of the printout, the user must understand the sequence of events when a JMS instruction is followed by an interrupt. As an end result of this sequence, the address of the location following the cell where the PC is stored is placed into cell 0. To derive this third line of the printout, the address in cell 0 is decremented by one and printed on the Teletype; then the contents of that address are printed.

- b. The following is a typical error printout.

F 5236 TO 6354

(TO) = 7402

(4354) = 5237

Line 1 is simply a statement of the problem. Line 2 says that the contents of location 6354 are not 5237 as they should be, but are 7402 instead. 7402 is a HLT instruction. Since memory is filled with a background of HLT orders, it is evident that the PC was not stored in location 6354 during the JMS.

Line 3 of the printout reveals where the PC was stored. Since on the interrupt 4355 was stored in location zero and (4354) contains the correctly stored PC, 5237, it is apparent that a jump error occurred. The JMS instruction should have jumped to 6354, but it actually jumped to 4354. Bit 1 was lost.

- c. The following is another typical error printout.

F 5236 TO 6354

(TO) = 7237

(6354) = 7237

Line 1 is again simply a statement of the problem. Line 2 says that the contents of location 6354 are not 5237 as expected, but are instead 7237. Since the contents are not a HLT order, 7402, it is evident that the PC was stored here, but the number stored was wrong. Comparing the good (5237), and the bad (7237), it is apparent that bit 1 was "picked up" during the store PC operation of the JMS instruction.

6.3 Error Recovery

The program continues testing following an error printout. When enough information has been gathered from the error printouts, a FROM and TO address is selected for use in the scope mode loop. Enter the chosen addresses into proper locations (see section 4.3.b). Enter 5531 into location 1 and restart the program with SR2 and SR3 set.

The scope mode loop is:

| <u>Location</u> | <u>Coding</u> |
|-----------------|---------------|
| 0000 | |
| 0001 | JMP 1 FROM 1 |
| xxxx | A, ION |
| xxxx | JMS 1 TO |
| 0131 | FROM 1 A |

To discontinue the scope mode loop, restore the original contents (7200) of location 1 and restart.

7. RESTRICTIONS

(None)

8. MISCELLANEOUS

8.1 Execution Time

4,726 random tests/second

9. PROGRAM DESCRIPTION

The JMS instruction is checked through use of the interrupt function. A random number generator selects a FROM and a TO address. An ION instruction is then placed at FROM -1 and the JMS instruction at FROM. The program jumps to the address specified by TO. After executing the ION and JMS instructions, an interrupt occurs starting the program counter at location 1. A checking routine located here verifies that the operation was successful before starting the next test.

Random addresses are restricted as follows: $0600 < \text{random address} < 7600$.

The area between 0600 and 7600 is filled with HLT instructions in case the interrupt fails.

"05" is printed after every 61,000 tests.

0200

*200

/RANDOM JMP-JMS TEST
 /SR0=HALT ON ERROR
 /SR2=FIXED FROM
 /SR3=FIXED TO
 /SPREAD HALTS THROUGH MEMORY
 /BETWEEN THE LIMLO AND LIMHI
 /LIMITS

0200 4154
 0201 1135
 0202 7041
 0203 3126
 0204 1152
 0205 3526
 0206 1126
 0207 7001
 0210 3126
 0211 1126
 0212 1136
 0213 7640
 0214 5204
 0215 1042
 0216 3041
 0217 3040

BEGIN, JMS PATCH /CLA
 TAD LIMLO
 CIA
 DCA TO
 GON, TAD HALT
 DCA I TO
 TAD TO
 IAC
 DCA TO
 TAD TO
 TAD LIMHI
 SEA CLA
 JMP GON
 TAD M15
 DCA CT1
 DCA CT

/CHECK FOR FIXED FROM

0220 7604
 0221 7004
 0222 7006
 0223 7630
 0224 5246

LOOP, LAS
 RAL
 RTL
 SEL CLA
 JMP LOOP1=6

/GET RANDOM FROM

0225 1133
 0226 7104
 0227 7430
 0230 1134
 0231 3133
 0232 1133
 0233 7510
 0234 5241
 0235 1135
 0236 7710
 0237 5225
 0240 5244
 0241 1136
 0242 7700
 0243 5225

GETRAN, TAD RANUM
 RAL CLL
 SEL
 TAD THREE
 DCA RANUM
 TAD RANUM
 SPA
 JMP ,+5
 TAD LIMLO
 SPA CLA
 JMP GETRAN
 JMP ,+4
 TAD LIMHI
 SMA CLA
 JMP GETRAN

0244 1133
 0245 3130

TAD RANUM
 DCA FROM

1/11/68 3:28.10

PAGE 1-1

0246 1130
0247 7001
0250 3132
0251 7040
0252 1130
0253 3131

TAD FROM
IAC
DCA FRMP1
CMA
TAD FROM
DCA FROM1

/CHECK FOR FIXED TO

0254 7604
0255 7006
0256 7006
0257 7630
0260 5302

LOOP1, LAS
RTL
RTL
S&L CLA
JMP CRSCCK=3

/GET RANDOM TO

0261 1133
0262 7104
0263 7430
0264 1134
0265 3133
0266 1133
0267 7510
0270 5275
0271 1135
0272 7710
0273 5261
0274 5300
0275 1136
0276 7700
0277 5261
0300 1133
0301 3126
0302 1126
0303 7001
0304 3127
0305 1130
0306 7041
0307 1126
0310 7650
0311 5220

GTRAN1, TAD RANUM
RAL CLL
S&L
TAD THREE
DCA RANUM
TAD RANUM
SPA
JMP ,+5
TAD LIMLO
SPA CLA
JMP GTRAN1
JMP ,+4
TAD LIMHI
SMA CLA
JMP GTRAN1
TAD RANUM
DCA TO
TAD TO
IAC
DCA TOP1
CRSCCK, TAD FROM
CIA
TAD TO
SNA CLA
JMP LOOP

/BRING UP THE FLAG

0312 7040
0313 6041
0314 6046
0315 6041
0316 5315

CMA
TSF
TLS
TSF
JMP ,=1

/PLACE THE INSTRUCTIONS

| | | |
|------|------|-------------|
| 0317 | 7200 | CLA |
| 0320 | 1137 | TAD ITON |
| 0321 | 3531 | DCA I FROM1 |
| 0322 | 1153 | TAD JMP1 |
| 0323 | 3530 | DCA I FROM |
| 0324 | 3000 | DCA 0 |

/GO DO IT

| | | |
|------|------|-------------|
| 0325 | 5531 | JMP I FROM1 |
| 0326 | 7402 | HLT |

/PRINTOUT SUBROUTINE

| | | |
|------|------|-------------|
| 0327 | 0000 | TYPAC, 0 |
| 0330 | 3143 | DCA SAVE+3 |
| 0331 | 1143 | TAD SAVE+3 |
| 0332 | 7012 | RTR |
| 0333 | 7010 | RAR |
| 0334 | 3142 | DCA SAVE+2 |
| 0335 | 1142 | TAD SAVE+2 |
| 0336 | 7012 | RTR |
| 0337 | 7010 | RAR |
| 0340 | 3141 | DCA SAVE+1 |
| 0341 | 1141 | TAD SAVE+1 |
| 0342 | 7012 | RTR |
| 0343 | 7010 | RAR |
| 0344 | 3140 | DCA SAVE |
| 0345 | 5727 | JMP I TYPAC |

/SUCCESS PRINTOUT

| | | |
|------|------|---------------|
| 0346 | 1041 | SUP, TAD CT1 |
| 0347 | 7001 | IAC |
| 0350 | 3041 | DCA CT1 |
| 0351 | 1041 | TAD CT1 |
| 0352 | 7640 | SEA CLA |
| 0353 | 5437 | JMP I ALOOP |
| 0354 | 1373 | TAD AMSG2 |
| 0355 | 3124 | DCA WORK |
| 0356 | 1124 | LP1, TAD WORK |
| 0357 | 7001 | IAC |
| 0360 | 3124 | DCA WORK |
| 0361 | 1524 | TAD I WORK |
| 0362 | 6046 | TLS |
| 0363 | 6041 | TSF |
| 0364 | 5363 | JMP I=-1 |
| 0365 | 1043 | TAD M265 |
| 0366 | 7640 | SEA CLA |
| 0367 | 5356 | JMP LP1 |
| 0370 | 1042 | TAD M15 |
| 0371 | 3041 | DCA CT1 |

1/11/68 3:28,22

PAGE 3-1

03/2 5437

JMP I ALDOP

| | | | | |
|------|------|---------|-------------|-------------------------------|
| 0373 | 0373 | AMSG2, | . | |
| 0374 | 0215 | | 215 | /CR |
| 0375 | 0212 | | 212 | /LF |
| 0376 | 0260 | | 260 | /0 |
| 0377 | 0265 | | 265 | /5 |
| | 0000 | *0 | | |
| 0000 | 0000 | | 0 | /FOR SCOPE MODE INSERT |
| 0001 | 5001 | | JMP 1 | /JMP 1 FROM 1 (5531) IN LOC1 |
| 0002 | 0002 | | 2 | /GET STORED ADDRESS |
| 0003 | 0003 | | 3 | |
| 0004 | 1132 | | TAD FRMP1 | |
| 0005 | 7640 | | SZA CLA | |
| 0006 | 5546 | | JMP I AER | /ADDRESS STORED IN (TO) WRONG |
| 0007 | 1127 | | TAD TOP1 | |
| 0010 | 7041 | | CIA | |
| 0011 | 1000 | | TAD 0 | |
| 0012 | 7640 | | SZA CLA | |
| 0013 | 5546 | | JMP I AER | /ADDRESS STORED IN (0) WRONG |
| 0014 | 1152 | RETURN, | TAD HALT | |
| 0015 | 3530 | | DCA I FROM | |
| 0016 | 1152 | | TAD HALT | |
| 0017 | 3526 | | DCA I TO | |
| 0020 | 7040 | | CMA | |
| 0021 | 1000 | | TAD 0 | |
| 0022 | 3000 | | DCA 0 | |
| 0023 | 1152 | | TAD HALT | |
| 0024 | 3400 | | DCA I 0 | |
| 0025 | 1152 | | TAD HALT | |
| 0026 | 3531 | | DCA I FROM1 | |
| 0027 | 7001 | | IAC | |
| 0030 | 1040 | | TAD CT | |
| 0031 | 3040 | | DCA CT | |
| 0032 | 1040 | | TAD CT | |
| 0033 | 7640 | | SZA CLA | |
| 0034 | 5437 | | JMP I ALOOP | |
| 0035 | 5436 | | JMP I ,+1 | |
| 0036 | 0346 | | SUP | |
| 0037 | 0220 | ALoop, | LOOP | |
| 0040 | 0000 | CT, | 0 | |
| 0041 | 0000 | CT1, | 0 | |
| 0042 | 7763 | M15, | -15 | |
| 0043 | 7513 | M265, | -265 | |

| | | | | |
|------|------|--------|------|-------------------------------|
| 0044 | 0215 | MSG1, | 215 | /CR |
| 0045 | 0212 | | 212 | /LF |
| 0046 | 0212 | | 212 | /LF |
| 0047 | 0306 | | 306 | /F = FROM |
| 0050 | 0240 | | 240 | /SPACE |
| 0051 | 0000 | INS1, | 0 | /X ADDRESS OF JMS INSTRUCTION |
| 0052 | 0000 | INS2, | 0 | /X |
| 0053 | 0000 | INS3, | 0 | /X |
| 0054 | 0000 | INS4, | 0 | /X |
| 0055 | 0240 | | 240 | /SPACE |
| 0056 | 0324 | | 324 | /T |
| 0057 | 0317 | | 317 | /U |
| 0060 | 0240 | | 240 | /SPACE |
| 0061 | 0000 | INS5, | 0 | /X |
| 0062 | 0000 | INS6, | 0 | /X |
| 0063 | 0000 | INS7, | 0 | /X |
| 0064 | 0000 | INS8, | 0 | /X |
| 0065 | 0215 | | 215 | /CR |
| 0066 | 0212 | | 212 | /LF |
| 0067 | 0377 | | 377 | /RUBOUT |
| 0070 | 0250 | | 250 | /I |
| 0071 | 0324 | MSG2, | 324 | /T |
| 0072 | 0317 | | 317 | /U |
| 0073 | 0251 | | 251 | /I |
| 0074 | 0240 | | 240 | /SPACE |
| 0075 | 0275 | | 275 | /E |
| 0076 | 0240 | | 240 | /SPACE |
| 0077 | 0000 | INS9, | 0 | /X STORED ADDRESS |
| 0100 | 0000 | INS10, | 0 | /X S/B FRMP1 |
| 0101 | 0000 | INS11, | 0 | /X |
| 0102 | 0000 | INS12, | 0 | /X |
| 0103 | 0215 | | 215 | /CR |
| 0104 | 0212 | | 212 | /LF |
| 0105 | 0377 | | 377 | /RUBOUT |
| 0106 | 0250 | | 250 | /I |
| 0107 | 0000 | MSG3, | 0 | /X ADDRESS=1 STORED |
| 0110 | 0000 | INS13, | 0 | /X IN LOC 0 AT INTERRUPT |
| 0111 | 0000 | INS14, | 0 | /X |
| 0112 | 0000 | INS15, | 0 | /X |
| 0113 | 0251 | | 251 | /I |
| 0114 | 0240 | | 240 | /SPACE |
| 0115 | 0275 | | 275 | /E |
| 0116 | 0240 | | 240 | /SPACE |
| 0117 | 0000 | INS16, | 0 | /X CONTENTS OF ABOVE |
| 0120 | 0000 | INS17, | 0 | /X ADDRESS |
| 0121 | 0000 | INS18, | 0 | /X |
| 0122 | 0000 | INS19, | 0 | /X |
| 0123 | 0207 | | 207 | /END MARK |
| 0124 | 0000 | WORK, | 0 | |
| 0125 | 7571 | M207, | =207 | |

/CONSTANTS

| | | | |
|------|------|--------|----------|
| 0126 | 0000 | TO, | 0 |
| 0127 | 0000 | TOP1, | 0 |
| 0130 | 0000 | FROM, | 0 |
| 0131 | 0000 | FROM1, | 0 |
| 0132 | 0000 | FRMP1, | 0 |
| 0133 | 2525 | RANUM, | 2525 |
| 0134 | 0003 | THREE, | 3 |
| 0135 | 7200 | LIMLO, | -600 |
| 0136 | 0200 | LIMHI, | -7600 |
| 0137 | 6001 | ITON, | ION |
| 0140 | 0000 | SAVE, | 0 |
| 0141 | 0000 | | 0 |
| 0142 | 0000 | | 0 |
| 0143 | 0000 | | 0 |
| 0144 | 0007 | MSK7, | 7 |
| 0145 | 0260 | TW6, | 260 |
| 0146 | 0400 | AER, | ER |
| 0147 | 0327 | ATYP, | TYPAC |
| 0150 | 0330 | ATYP1, | TYPAC+1 |
| 0151 | 0044 | AMSG1, | MSG1 |
| 0152 | 7402 | HALT, | HLT |
| 0153 | 4526 | JMP1, | JMS I TO |

| | | | | |
|------|------|--------|-------------|-----------------------|
| 0154 | 0000 | PATCH, | 0 | /RESTORE THEN GO AWAY |
| 0155 | 3000 | | DCA 0 | |
| 0156 | 1167 | | TAD X1 | |
| 0157 | 3001 | | DCA 1 | |
| 0160 | 1170 | | TAD X2 | |
| 0161 | 3002 | | DCA 2 | |
| 0162 | 1171 | | TAD X3 | |
| 0163 | 3003 | | DCA 3 | |
| 0164 | 1172 | | TAD X4 | |
| 0165 | 3573 | | DCA I X5 | |
| 0166 | 5554 | | JMP I PATCH | |
| 0167 | 7200 | X1, | 7200 | |
| 0170 | 1526 | X2, | 1526 | /TAD I TO |
| 0171 | 7041 | X3, | 7041 | |
| 0172 | 7200 | X4, | CLA | |
| 0173 | 0200 | X5, | 200 | |

| | | | |
|------|------|------|-------------|
| 0400 | 1204 | *400 | |
| 0401 | 3547 | ER, | TAD ,+4 |
| 0402 | 1130 | | DCA I ATYP |
| 0403 | 5550 | | TAD FROM |
| 0404 | 0405 | | JMP I ATYP1 |
| 0405 | 1140 | | ,+1 |
| 0406 | 0144 | | TAD SAVE |
| 0407 | 1145 | | AND MSK7 |
| 0410 | 3051 | | TAD TW6 |
| 0411 | 1141 | | DCA INS1 |
| 0412 | 0144 | | TAD SAVE+1 |
| 0413 | 1145 | | AND MSK7 |
| 0414 | 3052 | | TAD TW6 |
| 0415 | 1142 | | DCA INS2 |
| 0416 | 0144 | | TAD SAVE+2 |
| 0417 | 1145 | | AND MSK7 |
| 0420 | 3053 | | TAD TW6 |
| 0421 | 1143 | | DCA INS3 |
| 0422 | 0144 | | TAD SAVE+3 |
| 0423 | 1145 | | AND MSK7 |
| 0424 | 3054 | | TAD TW6 |
| | | | DCA INS4 |
| 0425 | 1231 | | TAD ,+4 |
| 0426 | 3547 | | DCA I ATYP |
| 0427 | 1126 | | TAD TO |
| 0430 | 5550 | | JMP I ATYP1 |
| 0431 | 0432 | | ,+1 |
| 0432 | 1140 | | TAD SAVE |
| 0433 | 0144 | | AND MSK7 |
| 0434 | 1145 | | TAD TW6 |
| 0435 | 3061 | | DCA INS5 |
| 0436 | 1141 | | TAD SAVE+1 |
| 0437 | 0144 | | AND MSK7 |
| 0440 | 1145 | | TAD TW6 |
| 0441 | 3062 | | DCA INS6 |
| 0442 | 1142 | | TAD SAVE+2 |
| 0443 | 0144 | | AND MSK7 |
| 0444 | 1145 | | TAD TW6 |
| 0445 | 3063 | | DCA INS7 |
| 0446 | 1143 | | TAD SAVE+3 |
| 0447 | 0144 | | AND MSK7 |
| 0450 | 1145 | | TAD TW6 |
| 0451 | 3064 | | DCA INS8 |
| 0452 | 1256 | | TAD ,+4 |
| 0453 | 3547 | | DCA I ATYP |
| 0454 | 1526 | | TAD I TO |
| 0455 | 5550 | | JMP I ATYP1 |
| 0456 | 0457 | | ,+1 |

0457 1140
0460 0144
0461 1145
0462 3077
0463 1141
0464 0144
0465 1145
0466 3100
0467 1142
0470 0144
0471 1145
0472 3101
0473 1143
0474 0144
0475 1145
0476 3102
0477 7040
0500 1000
0501 3000

0502 1306
0503 3547
0504 1000
0505 5550
0506 0507
0507 1140
0510 0144
0511 1145
0512 3107
0513 1141
0514 0144
0515 1145
0516 3110
0517 1142
0520 0144
0521 1145
0522 3111
0523 1143
0524 0144
0525 1145
0526 3112
0527 1333
0530 3547
0531 1400
0532 5550
0533 0534
0534 1140
0535 0144
0536 1145
0537 3117
0540 1141
0541 0144
0542 1145
0543 3120
0544 1142

TAD SAVE
AND MSK7
TAD TW6
DCA INS9
TAD SAVE+1
AND MSK7
TAD TW6
DCA INS10
TAD SAVE+2
AND MSK7
TAD TW6
DCA INS11
TAD SAVE+3
AND MSK7
TAD TW6
DCA INS12
CMA
TAD 0
DCA 0

TAD ,+4
DCA I ATYP
TAD 0
JMP I ATYP1
,+1
TAD SAVE
AND MSK7
TAD TW6
DCA MSG3
TAD SAVE+1
AND MSK7
TAD TW6
DCA INS13
TAD SAVE+2
AND MSK7
TAD TW6
DCA INS14
TAD SAVE+3
AND MSK7
TAD TW6
DCA INS15
TAD ,+4
DCA I ATYP
TAD I 0
JMP I ATYP1
,+1
TAD SAVE
AND MSK7
TAD TW6
DCA INS16
TAD SAVE+1
AND MSK7
TAD TW6
DCA INS17
TAD SAVE+2

0545 0144
0546 1145
0547 3121
0550 1143
0551 0144
0552 1145
0553 3122

AND MSK7
TAD TW6
DCA INS18
TAD SAVE*3
AND MSK7
TAD TW6
DCA INS19

| | | | | |
|------|------|-------|------------|----------------|
| 0554 | 1151 | | TAD AMSG1 | |
| 0555 | 3124 | | DCA WORK | |
| 0556 | 1524 | TYPE, | TAD I WORK | |
| 0557 | 6046 | | TLS | |
| 0560 | 6041 | | TSF | |
| 0561 | 5360 | | JMP ,=1 | |
| 0562 | 7201 | | CLA IAC | |
| 0563 | 1124 | | TAD WORK | |
| 0564 | 3124 | | DCA WORK | |
| 0565 | 1524 | | TAD I WORK | |
| 0566 | 1125 | | TAD M207 | |
| 0567 | 7640 | | SZA CLA | |
| 0570 | 5356 | | JMP TYPE | |
| 0571 | 7604 | | LAS | |
| 0572 | 7710 | | SPA CLA | |
| 0573 | 7402 | | HLT | /HALT ON ERROR |
| 0574 | 5014 | | JMP RETURN | |

5

THERE ARE NO ERRORS

SYMBOL TABLE

| | |
|--------|------|
| AER | 0146 |
| ALOUP | 0037 |
| AMSG1 | 0151 |
| AMSG2 | 0373 |
| ATYP | 0147 |
| ATYP1 | 0150 |
| BEGIN | 0200 |
| CRSCK | 0305 |
| CT | 0040 |
| CT1 | 0041 |
| ER | 0400 |
| FRMP1 | 0132 |
| FROM | 0130 |
| FROM1 | 0131 |
| GETRAN | 0225 |
| GUN | 0204 |
| GTRAN1 | 0261 |
| HALT | 0152 |
| INS1 | 0051 |
| INS10 | 0100 |
| INS11 | 0101 |
| INS12 | 0102 |
| INS13 | 0110 |
| INS14 | 0111 |
| INS15 | 0112 |
| INS16 | 0117 |
| INS17 | 0120 |
| INS18 | 0121 |
| INS19 | 0122 |
| INS2 | 0052 |
| INS3 | 0053 |
| INS4 | 0054 |
| INS5 | 0061 |
| INS6 | 0062 |
| INS7 | 0063 |
| INS8 | 0064 |
| INS9 | 0077 |
| ITION | 0137 |
| JMP1 | 0153 |
| LIMHI | 0136 |
| LIMLO | 0135 |
| LOOP | 0220 |
| LOOP1 | 0254 |
| LP1 | 0356 |
| MSG1 | 0044 |
| MSG2 | 0071 |
| MSG3 | 0107 |
| MSK7 | 0144 |
| M15 | 0042 |
| M207 | 0125 |
| M265 | 0043 |
| PATCH | 0154 |
| RANUM | 0133 |

SYMBOL TABLE

| | |
|--------|------|
| RETURN | 0014 |
| SAVE | 0140 |
| SUP | 0346 |
| THREE | 0134 |
| TU | 0126 |
| TUP1 | 0127 |
| TW6 | 0145 |
| TYPAC | 0327 |
| TYPE | 0556 |
| WORK | 0124 |
| X1 | 0167 |
| X2 | 0170 |
| X3 | 0171 |
| X4 | 0172 |
| X5 | 0173 |

SYMBOL TABLE

| | |
|--------|------|
| RETURN | 0014 |
| ALoop | 0037 |
| CT | 0040 |
| CT1 | 0041 |
| M15 | 0042 |
| M265 | 0043 |
| MSG1 | 0044 |
| INS1 | 0051 |
| INS2 | 0052 |
| INS3 | 0053 |
| INS4 | 0054 |
| INS5 | 0061 |
| INS6 | 0062 |
| INS7 | 0063 |
| INS8 | 0064 |
| MSG2 | 0071 |
| INS9 | 0077 |
| INS10 | 0100 |
| INS11 | 0101 |
| INS12 | 0102 |
| MSG3 | 0107 |
| INS13 | 0110 |
| INS14 | 0111 |
| INS15 | 0112 |
| INS16 | 0117 |
| INS17 | 0120 |
| INS18 | 0121 |
| INS19 | 0122 |
| WORK | 0124 |
| M207 | 0125 |
| TU | 0126 |
| TUP1 | 0127 |
| FROM | 0130 |
| FROM1 | 0131 |
| FRMP1 | 0132 |
| RANUM | 0133 |
| THREE | 0134 |
| LIMLO | 0135 |
| LIMHI | 0136 |
| ITON | 0137 |
| SAVE | 0140 |
| MSK7 | 0144 |
| TW6 | 0145 |
| ALR | 0146 |
| ATYP | 0147 |
| ATYP1 | 0150 |
| AMSG1 | 0151 |
| HALT | 0152 |
| JMP1 | 0153 |
| PATCH | 0154 |
| X1 | 0167 |
| X2 | 0170 |
| X3 | 0171 |

SYMBOL TABLE

| | |
|--------|------|
| X4 | 0172 |
| X5 | 0173 |
| BEGIN | 0200 |
| GUN | 0204 |
| LOOP | 0220 |
| GETRAN | 0225 |
| LOOP1 | 0254 |
| GTRAN1 | 0261 |
| CRSCK | 0305 |
| TYPAC | 0327 |
| SUP | 0346 |
| LP1 | 0356 |
| AMSG2 | 0373 |
| ER | 0400 |
| TYPE | 0556 |

