

IDENTIFICATION

| | |
|---------------|-------------------------------|
| PRODUCT CODE: | MAINDEC-08-DHRKC-E-D |
| PRODUCT NAME: | RKSE DATA RELIABILITY PROGRAM |
| DATE CREATED: | APRIL 15, 1975 |
| MAINTAINER: | DIAGNOSTIC GROUP |
| AUTHOR: | JOHN VROBEL |

COPYRIGHT (C) 1972-1973-1974-1975, DIGITAL EQUIP. CORP., MAYNARD, MASS.

THE INFORMATION IN THIS STATEMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

ACTUAL DISTRIBUTION OF THE SOFTWARE DESCRIBED IN THIS DOCUMENT WILL BE SUBJECT TO TERMS AND CONDITIONS TO BE ANNOUNCED ON SOME FUTURE DATE BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

THIS SOFTWARE IS FURNISHED TO PURCHASER UNDER A LICENSE TO USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DEC'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DEC.

TABLE OF CONTENTS

| | |
|-----|--|
| 1. | ABSTRACT |
| 2. | REQUIREMENTS |
| 2.1 | HARDWARE |
| 2.2 | PROGRAM STORAGE |
| 2.3 | PRELIMINARY PROGRAMS |
| 2.4 | EXECUTION TIME |
| 3. | SWITCH REGISTER SETTINGS |
| 4. | OPERATOR AND/OR PROGRAM ACTION |
| 4.1 | STANDARD TEST PROCEDURE |
| 4.2 | RK05 DRIVE CARTRIDGE MOUNTING PROCEDURE |
| 4.3 | RK8E DATA RELIABILITY (ACCEPT MODE) |
| 4.4 | RK8E DATA RELIABILITY (MANUAL INTERVENTION MODE) |
| 4.5 | CHANGE PROGRAM IOT CODES |
| 5. | ERRORS |
| 5.1 | USEFUL INFORMATION |
| 5.2 | ERROR HALTS |
| 5.3 | ERROR TYPEOUTS |
| 5.4 | ERROR RECOVERY AND ERROR DISCONNECT |
| 5.5 | STATUS COMPLETE TYPEOUT AND PASS COMPLETE DISCONNECT |
| 5.6 | TYPICAL ERROR TYPEOUTS |
| 6. | RESTRICTIONS |
| 7. | TROUBLE SHOOTING INFORMATION |
| 8. | PROGRAM DESCRIPTION (ACCEPT MODE) |
| 9. | PROGRAM LISTING |

1.

ABSTRACT

THE RK8E DATA RELIABILITY PROGRAM IS DESIGNED PRIMARILY AS AN ACCEPTANCE TEST TO VERIFY DISK DATA TRANSFERS WITHIN THE DISK SYSTEM.

THE "ACCEPT MODE" OF OPERATION VERIFIES THE CAPABILITY OF TRANSFERRING A TOTAL 3 X 10⁹ BITS OF DATA TO AND FROM EACH INDIVIDUAL DISK DRIVE ON THE DISK SYSTEM.

THE "MANUAL INTERVENTION MODE" IS AVAILABLE AS A HARDWARE DEBUGGING AID TO ALLOW THE OPERATOR TO SELECT DATA PATTERNS, TRANSFER LENGTHS, AND ADDRESSING.

(NOTE: LOCATION 0 CONTAINS REVSION LEVEL (IN ASCII) OF PROGRAM ON PROGRAM LOAD).

2.

REQUIREMENTS

2.1

HARDWARE

A. PDP-8/A, 8/E, 8/F, OR 8/M COMPUTER OR OTHER FAMILY OF 8 COMPATIBLE COMPUTER WITH NECESSARY DW8E BUS ADAPTER.

B. AT LEAST 4K OF READ/WRITE MEMORY

C. ASR-33 TELETYPE OR EQUIVALENT

D. RK8E DISK CONTROL

E. RK05 DISK DRIVE(S)

F. FORMATTED 2200 BPI-16 SECTOR PACK(S).

2.2

PROGRAM STORAGE

THE PROGRAM OCCUPIES OR UTILIZES LOCATION 0000 TO LOCATION 7577 OF FIELD 0. ALL EXTENDED MEMORY LOCATIONS, IF AVAILABLE, ARE UTILIZED FOR TESTING.

2.3

PRELIMINARY PROGRAMS

THIS PROGRAM REQUIRES A FORMATTED CARTRIDGE ON ALL DRIVES TO BE TESTED.

ALL BASIC AND EXTENDED MEMORY DIAGNOSTICS, THE RK8E DISKLESS CONTROL TEST, THE RK8E DRIVE CONTROL TEST, AND THE RK8E DISK FORMATTER PROGRAM SHOULD BE RUN IF THIS TEST FAILS TO OPERATE CORRECTLY.

2.4 EXECUTION TIME

THE PROGRAM EXECUTION TIME (I.E. PASSING 3 X 10⁹ BITS OF DATA ON A DISK DRIVE), IS APROX. 3 HOURS PER DISK DRIVE ON A 4K MEMORY SYSTEM OR APROX. 2.5 HOURS PER DISK DRIVE ON SYSTEMS WITH EXTENDED MEMORY.

3. SWITCH REGISTER SETTINGS

SWR0=1 LOOP ON WRITE SEQUENCE.
 SWR1=1 LOOP ON READ SEQUENCE.
 SWR2=1 INHIBIT ALL ERROR TYPEOUTS
 SWR3=1 TYPE "STATUS-COMPLETE" REPORT.
 SWR4=1 PROGRAM STOP OR HALT.
 SWR5=1 DRIVE DISCONNECT AFTER PASS COMPLETION.
 SWR6=1 PERFORM ONLY "OVERLAP SEEKS", DO NOT
 EXECUTE DATA BREAKS.

4. OPERATOR AND/OR PROGRAM ACTION

4.1 STANDARD TEST PROCEDURE

- A. START AS SPECIFIED THROUGH OUT THIS DOCUMENTATION IS KEY CLEAR AND THEN KEY CONTINUE ON PDP8/E, PDP8/M, AND PDP8/F COMPUTERS.
- B. LOAD THE PROGRAM INTO MEMORY FIELD 0 USING THE STANDARD BINARY LOADER TECHNIQUE.
- C. IF IT IS DESIRED TO CHANGE THE IOT CODES WITHIN THE PROGRAM, FOLLOW THE PROCEDURE IN SECTION 4.5.
- D. RUN THE ACCEPTANCE MODE OF DATA RELIABILITY WITH ALL DRIVES AND MEMORY AVAILABLE BY FOLLOWING THE PROCEDURE IN SECTION 4.3.
- E. THE MANUAL INTERVENTION MODE, SECTION 4.4, MAY BE USED FOR TROUBLE SHOOTING, IF DESIRED.
- F. IF POSSIBLE SWR4=1 SHOULD ALWAYS BE USED TO STOP THE PROGRAM.

- G. IF THE PROGRAM HAS BEEN STOPPED DUE TO SWR4=1, THE PROGRAM CAN BE RESTARTED, AND THE INITIAL STARTUP QUESTIONS BYPASSED, BY USING 0202 AS THE RESTART ADDRESS.
- H. FOR THE ABSOLUTE LOCATIONS OF ALL KNOWN HALTS IN THIS PROGRAM, ACCESS PAGE 1 OF THE PROGRAM LISTING.

4.2

RK05 DRIVE CARTRIDGE MOUNTING PROCEDURE

THE FOLLOWING IS THE CORRECT CARTRIDGE MOUNTING PROCEDURE FOR THE RK05 DISK DRIVE. ANY DEVIATION ENCOUNTERED DURING THIS PROCEDURE WILL BE CONSIDERED AN ERROR CONDITION.

- A. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION.
- B. TURN AC POWER TO DISK DRIVE ON.
- C. VERIFY THAT THE LIGHT LABELED "PWR" IS ON.
- D. WAIT FOR THE LIGHT LABELED "LOAD" TO COME ON.
- E. VERIFY THAT THE LIGHTS LABELED "RDY", "ON CYL", "FAULT", "WT", AND "RD" ARE OFF.
- F. OPEN ACCESS DOOR.
- G. INSERT CARTRIDGE.
- H. CLOSE ACCESS DOOR.
- I. SET SWITCH LABELED "RUN/LOAD" TO THE "RUN" POSITION.
- J. WAIT FOR THE LIGHTS LABELED "RDY" AND "ON CYL" TO COME ON.
- K. TOGGLE SWITCH LABELED "WT PROT" AND VERIFY THAT THE LIGHT LABELED "WT PROT" GOES ON AND OFF.
- L. TOGGLE SWITCH LABELED "WT PROT" UNTIL THE LIGHT LABELED "WT PROT" IS OFF.
- M. VERIFY THAT LIGHTS LABELED "FAULT", "WT", "RD", AND "LOAD" ARE OFF.

4.3

RK8E DATA RELIABILITY (ACCEPT MODE)

- A. MAKE READY ALL DRIVES TO BE TESTED USING THE RK05 DRIVE CARTRIDGE MOUNTING PROCEDURE SECTION 4.2.
- B. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION ON ALL DRIVES NOT BEING TESTED.
- C. VERIFY THAT AC POWER IS ON, ON ALL DRIVES NOT BEING TESTED.
- D. SET THE SWITCH REGISTER TO 0200 AND PRESS LOAD ADDRESS.
- E. SET THE SWITCH REGISTER TO 0000 AND PRESS START.
- F. THE OPERATOR MAY SET SWR5=1 IF IT IS DESIRED TO HAVE THE PROGRAM AUTOMATICALLY DISCONNECT EACH DISK DRIVE AS EACH MAKE THEIR PASS COMPLETION. (NOTE: IF SWR5=0, ALL DISK DRIVES WILL CONTINUE TO RUN AFTER THEIR PASS COMPLETION)
- G. THE TTY WILL PRINT THE FOLLOWING PROGRAM NAME AND QUESTION.

RK8E DATA RELIABILITY
AMOUNT OF EXTENDED R/W MEMORY (0-7)?

THE OPERATOR SHOULD THEN TYPE THE AMOUNT OF EXTENDED READ/ WRITE MEMORY BANKS NUMBERED SEQUENTIALLY FROM BANK 0, AS INDICATED BY THE TTY QUESTION.

- H. THE TTY WILL PRINT THE FOLLOWING QUESTION(S), ASKING THE DESIRED DISK DRIVE(S) TO BE USED IN TESTING.

EXERCISE DISK0? DISK1? DISK2? DISK3?

FOR THE QUESTION(S) ABOVE, TYPE Y FOR YES, IF IT IS DESIRED TO TEST THE DISK DRIVE IN QUESTION, OTHERWISE, TYPE N FOR NO.

- I. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ACCEPT MODE?

THE OPERATOR SHOULD THEN TYPE Y FOR YES TO RUN THE ACCEPTANCE MODE OF OPERATION.

- J. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ARE YOU SURE?

IF THE OPERATOR IS CERTAIN OF THE AMOUNT OF MEMORY, THE DISK DRIVE(S) SELECTED, AND THE MODE OF OPERATION, TYPE Y FOR YES. TYPING N FOR NO WILL RESULT IN A REPEAT OF ALL MESSAGES AND QUESTIONS ENCOUNTERED THUS FAR.

- K. THE PROGRAM SHOULD START TESTING THE DISK DRIVE(S) AND MEMORY SELECTED.
- L. THE "STATUS-COMPLETE" TYPEOUT SHOULD OCCUR UPON PASS COMPLETION OF EACH DISK DRIVE. ALL OTHER TYPEOUTS OR HALTS WILL BE CONSIDERED AS AN ERROR CONDITION. SEE SECTION 5.5 FOR "STATUS-COMPLETE" TYPEOUT.
- M. A SUCCESSFUL PASS COMPLETE ON A DISK DRIVE WILL BE CONSIDERED AS NO "HARD" ERRORS AND NO MORE THAN ONE (1) "SOFT" ERROR PER PASS COMPLETE.
- N. IF ANY ERRORS DO OCCUR, THE OPERATOR SHOULD ACCESS SECTION 5 IN THIS DOCUMENTATION.

4.4

RK8E DATA RELIABILITY (MANUAL INTERVENTION MODE)

THE MANUAL INTERVENTION MODE IS AVAILABLE AS A TROUBLE SHOOTING AID AND SHOULD ONLY BE USED FOR SUCH PURPOSES, IF DESIRED.

- A. MAKE READY ALL DISK DRIVES TO BE TESTED USING THE RK05 DRIVE CARTRIDGE MOUNTING PROCEDURE SETION 4.2.
- B. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION ON ALL DRIVES NOT BEING TESTED.
- C. VERIFY THAT AC POWER IS ON, ON ALL DRIVES NOT BEING TESTED.
- D. SET THE SWITCH REGISTER TO 0200 AND PRESS LOAD ADDRESS.
- E. SET THE SWITCH REGISTER TO 0000 AND PRESS START.
- F. THE TTY WILL PRINT THE FOLLOWING PROGRAM NAME AND QUESTION.

RK8E DATA RELIABILITY
AMOUNT OF EXTENDED R/W MEMORY (0-7)?

THE OPERATOR SHOULD THEN TYPE THE AMOUNT OF EXTENDED READ/ WRITE MEMORY BANKS NUMBERED SEQUENTIALLY FROM BANK 0, AS INDICATED BY THE TTY QUESTION.

- G. THE TTY WILL PRINT THE FOLLOWING QUESTION(S), ASKING THE DESIRED DISK DRIVE(S) TO BE USED IN TESTING.

EXERCISE DISK0? DISK1? DISK2? DISK3?

FOR THE QUESTION(S) ABOVE, TYPE Y FOR YES, IF IT IS DESIRED TO TEST THE DISK DRIVE IN QUESTION, OTHERWISE, TYPE N FOR NO.

H. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ACCEPT MODE?

THE OPERATOR SHOULD THEN TYPE N FOR NO TO RUN THE MANUAL INTERVENTION MODE OF OPERATION.

I. THE TTY WILL THEN PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT A CONSTANT MEMORY FIELD, RATHER THAN THE NORMAL RANDOM FIELD SELECTION.

FIELD?

IF THE OPERATOR DESIRES TO SELECT A CONSTANT FIELD, TYPE Y FOR YES, OTHERWISE, TYPE N FOR NO. IF Y WAS TYPED THE TTY WILL SPACE OUT ONCE AND WAIT FOR THE OPERATOR TO TYPE THE DESIRED FIELD IN OCTAL (0-7).

J. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT A CONSTANT TRACK, RATHER THAN THE NORMAL RANDOM TRACK SELECTION.

TRACK?

IF THE OPERATOR DESIRES TO SELECT A CONSTANT TRACK, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED, THE TTY WILL SPACE OUT ONCE AND WAIT FOR THE OPERATOR TO INPUT THE DESIRED TRACK ADDRESS (00000-14537).

K. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT HALF BLOCK OR FULL BLOCK TRANSFERS, RATHER THAN THE NORMAL RANDOM SELECTION.

BLOCK LENGTH?

IF THE OPERATOR DESIRES TO CHANGE THE BLOCK LENGTH, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED THE TTY WILL SPACE OUT ONCE AND WAIT FOR THE OPERATOR TO TYPE THE BLOCK LENGTH DESIRED (0=256 WORD BLOCK OR 1=128 WORD BLOCK).

L. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT A CONSTANT NUMBER OF SECTORS TO BE TRANSFERED, RATHER THAN THE NORMAL RANDOM SECTOR SELECTION.

EXTRA SECTORS?

IF THE OPERATOR DESIRES TO SELECT A CONSTANT AMOUNT OF SECTORS, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED THE TTY WILL SPACE OUT ONCE, AND WAIT FOR THE OPERATOR TO TYPE IN THE EXTRA SECTORS DESIRED (00-17). (NOTE: IF THE FIELD AND THE BLOCK LENGTH PREVIOUSLY SELECTED WAS 0, THE AMOUNT OF EXTRA SECTORS WILL BE LIMITED TO 07. OTHERWISE THE MAXIMUM AMOUNT IS LIMITED TO 17.)

- M. IF A CONSTANT TRACK WAS NOT SELECTED, AS MENTION ABOVE, THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT AN INCREMENT SEEK SEQUENCE, RATHER THAN THE NORMAL RANDOM SEQUENCE.

SEQUENCE?

IF THE OPERATOR DESIRES TO SELECT SEQUENTIAL SEEK SEQUENCE, TYPE Y FOR YES, OTHERWISE, N FOR NO.

- N. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT A DATA PATTERN, RATHER THAN NORMAL RANDOM DATA SELECTION.

DATA?

IF THE OPERATOR DESIRES TO SELECT A DATA PATTERN, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED, THE TTY WILL DO A "CRLF" AND WAIT FOR THE OPERATOR TO TYPE IN 12 OCTAL DATA WORDS TO BE USED IN TESTING.

- P. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ARE YOU SURE?

IF THE OPERATOR IS CERTAIN OF THE INFORMATION SELECTED, TYPE Y FOR YES. TYPING N FOR NO WILL RESULT IN A REPEAT OF ALL MESSAGES AND QUESTIONS ENCOUNTERED THUS FAR.

- R. THE PROGRAM SHOULD START EXECUTING THE OPERATIONS SELECTED.
S. IF ERRORS ARE ENCOUNTERED, ACCESS SECTION 5 IN THIS DOCUMENTATION.

4.5 CHANGE PROGRAM DEVICE IOT CODES

THE PROGRAM NORMALLY RECOGNIZES DEVICE IOT CODE X74X. TO CHANGE THE DEVICE IOT CODES WITHIN THE PROGRAM:

- A. SET THE SWITCH REGISTER TO 0201 AND PRESS LOAD ADDRESS.
B. SET THE SWITCH REGISTER TO 0000, SET SWITCH REGISTER BITS 3-8 TO THE DESIRED DEVICE IOT CODE, AND PRESS START.
C. THE PROGRAM WILL CHANGE THE DEVICE IOT CODES WITHIN THE PROGRAM AND THEN HALT.
D. THE REGULAR TESTS CAN THEN BE RUN (SEE SECTIONS 4.3 OR 4.4)

5. ERRORS -----

5.1 USEFUL INFORMATION -----

ALL STATUS ERRORS WILL BE REPORTED AS STATUS ERRORS. ALL DATA ERRORS WILL BE REPORTED AS DISK DATA ERRORS.

WHEN DATA IS BEING READ OFF THE DISK AND A CRC ERROR OCCURRES THE PROGRAM WILL REPORT THE ERROR AS A READ STATUS ERROR. THE PROGRAM WILL THEN CHECK THE DATA READ FOR DATA ERRORS. IF DATA ERRORS EXIST THEY WILL BE REPORTED AS DISK DATA ERRORS.

5.2 ERROR HALTS -----

ERROR HALTS FOR WHICH THERE ARE NO ERROR TYPEOUTS ARE LISTED AND DEFINED AS FOLLOWS.

| | |
|--------|--|
| INTER1 | NO DISK INTERRUPT |
| INTER2 | UNDEFINED INTERRUPT |
| ERHLT2 | SKIP TRAP FOR IOT "DCLR" |
| ERHLT3 | SKIP TRAP FOR IOT "DLAG" |
| ERHLT4 | SKIP TRAP FOR IOT "DLCA" |
| ERHLT5 | SKIP TRAP FOR IOT "DRST" |
| ERHLT6 | SKIP TRAP FOR IOT "DLDC" |
| BADHLT | CHECKSUM FAILED BUT WORD-BY-WORD COMPARE WORKED |
| NODSKS | NO DISKS AVAILABLE TO RUN |
| KHLT | PROGRAM WILL ONLY RUN IN FIELD 0 |

FOR THE ABSOLUTE LOCATIONS OF THE HALTS LISTED ABOVE, ACCESS PAGE 1 OF THE PROGRAM LISTING.

5.3

ERROR TYPEOUTS

WHEN AN ERROR OCCURRES THE PROGRAM WILL PRINT AN "ERROR HEADER" WHICH WILL SPECIFY THE PARTICULAR TYPE OF ERROR FOUND AT THE TIME OF THE FAILURE.

POSSIBLE "ERROR HEADERS" ARE AS FOLLOWS.

SEEK STATUS ERROR
WRITE STATUS ERROR
READ STATUS ERROR
DISK DATA ERROR
RECALIBRATE STATUS ERROR

AFTER THE "ERROR HEADER" MENTIONED ABOVE IS TYPED, THE PROGRAM WILL PRINT THE FOLLOWING ERROR INFORMATION FOUND AT THE TIME OF THE FAILURE, PERTAINING TO THE FAILURE. POSSIBLE TYPEOUTS ARE AS FOLLOWS.

PC: PROGRAM LOCATION OF THE ACTUAL FAILURE.

ST: CONTENTS OF THE STATUS REGISTER.

CM: SOFTWARE COMMAND REGISTER.

IA: INITIAL SOFTWARE DISK ADDRESS REGISTER OR THE CYLINDER, SURFACE, AND SECTOR BITS.

DA: FINAL SOFTWARE DISK ADDRESS REGISTER OR THE CYLINDER, SURFACE, AND SECTOR BITS.

CA: SOFTWARE INITIAL CURRENT ADDRESS

WC: SOFTWARE INITIAL WORD COUNT

FW: SOFTWARE FINAL WORD COUNT

AS: SECTOR IN ERROR ON THE PARTICULAR CYLINDER AND SURFACE IN QUESTION.

WA: WORD ADDRESS WITHIN THE SECTOR IN ERROR

AD: BREAK ADDRESS OF DATA BREAK IN COMPUTER.

DG: EXPECTED DATA

DB: DATA FOUND DURING DATA BREAK.

5.4

ERROR RECOVERY AND ERROR DISCONNECT

WHEN A READ, WRITE, OR DISK DATA ERROR OCCURS(SEE SECTION 5.3), THE PROGRAM WILL TRY TO REPEAT THE FAILING SEQUENCE FOUR (4) TIMES. IF THE ERROR HAS OCCURRED FOUR (4) TIMES SIMULTAINIOUSLY, THE ERROR WILL BE CONSIDERED AS A NON-RECOVERABLE ERROR, THE "ERROR HEADER" WILL BE CHANGED TO INDICATE "NON-RECOVERABLE" ERROR, ANOTHER DISK ADDRESS WILL BE SELECTED FOR TESTING, AND THE CURRENT DRIVE WILL BE SENT ON A "SEEK" TO THE ADDRESS SELECTED. IF A "SOFT" ERROR SHOULD OCCUR ON A TRACK, THE PROGRAM WILL RETRY THE READ SEQUENCE (64) TIMES BEFORE SELECTING ANOTHER TRACK FOR TESTING.(NOTE:THIS 64 RETRYS ON "SOFT" ERRORS WILL BE TERMINATED ON A "HARD" ERROR).

POSSIBLE NON-RECOVERABLE ERROR HEADERS ARE AS FOLLOWS.

NON-RECOVERABLE READ STATUS ERROR
NON-RECOVERABLE WRITE STATUS ERROR
NON-RECOVERABLE DISK DATA ERROR

IF A "SEEK" ERROR SHOULD OCCUR TO THE NEW ADDRESS, THE DISK IN QUESTION WILL THEN BE RECALIBRATED (RESTORED TO CYLINDER 0). IF THE RECALIBRATE SEQUENCE FAILS, THE DISK DRIVE IN ERROR WILL BE DISCONNECTED BY THE PROGRAM AND NO LONGER BE TESTED.

THE FOLLOWING "DISCONNECT" AND "STATUS-COMPLETE" TYPEOUTS SHOULD OCCUR.

RECALIBRATE ERROR DISCONNECT!
DISK X DISCONNECTED!
DSK HARD SOFT COMP
X 0030 0010 0001
X 0240 5670 0001

IF ALL DISKS ON THE SYSTEM HAVE BEEN DISCONNECTED DO TO RECALIBRATE ERRORS THE FOLLOWING TYPEOUT WILL OCCUR AND THE PROGRAM WILL HALT.

DISK SYSTEM SHUT DOWN, NO DISKS TO RUN!

5.5

STATUS-COMPLETE TYPEOUT AND PASS COMPLETE DISCONNECT

ALL ERRORS AND PASS COMPLETES ARE TALLIED BY THE PROGRAM PER DISK DRIVE.

THE FOLLOWING IS AN EXAMPLE OF THE "STATUS-COMPLETE" TYPEOUT THAT WILL OCCUR WHEN SWR3=1 INDICATING TYPE THIS REPORT, A PASS COMPLETE OCCURES ON A DRIVE UNDER TEST, OR A DRIVE IS DISCONNECTED DO TO A RECALIBRATE ERROR.

```

DSK HARD SOFT COMP
X  XXXX XXXX XXXX
X  XXXX XXXX XXXX
X  XXXX XXXX XXXX
X  XXXX XXXX XXXX

```

THE TIMEOUT AS MENTIONED ABOVE IS DESCRIBED AS FOLLOWS.

```

DSK          DISK DRIVE IN QUESTION.

HARD         ALL ERRORS OTHER THAN THAT DEFINED AS
              A SOFT ERROR.

SOFT         A READ CRC STATUS ERROR WITH BAD DATA PER
              TRANSFER WITH RECOVERY POSSIBLE WITHIN FOUR (4)
              RETRYS. (NOTE: FOUR (4) CONSECUTIVE RETRYS WILL
              BE CONSIDERED AS A NON-RECOVERABLE ERROR OR A
              "HARD" ERROR).

COMP         PASS COMPLETES. <3 X 10(9) BITS>

```

IF SWR5=1 INDICATING "DISCONNECT ON PASS COMPLETION", AND A DISK DRIVE UNDER TEST MAKES A PASS COMPLETION, THE FOLLOWING TIMEOUT WILL OCCUR AND THE DRIVE WILL BE DISCONNECTED.

```

DISK X PASS COMPLETE!
DISK X DISCONNECTED!
DSK HARD SOFT COMP
X  XXXX XXXX XXXX
X  XXXX XXXX XXXX

```

IF SWR5=0 INDICATING DON'T "DISCONNECT ON PASS COMPLETION", AND A DISK DRIVE UNDER TEST MAKES A PASS COMPLETION, THE FOLLOWING TIMEOUT WILL OCCUR AND THE DRIVE WILL CONTINUE TO RUN.

```

DISK X PASS COMPLETE!
DSK HARD SOFT COMP
X  XXXX XXXX XXXX
X  XXXX XXXX XXXX

```

IF SWR5=1 AND ALL DRIVES HAVE MADE THEIR PASS COMPLETION AND HAVE BEEN DISCONNECTED, THE FOLLOWING TIMEOUT WILL OCCUR AND THE COMPUTER WILL HALT.

DISK SYSTEM SHUT DOWN, NO DISKS TO RUN!

5.6

TYPICAL ERROR TYPEOUTS

THE FOLLOWING IS AN EXAMPLE OF AN "ERROR HEADER" AND ERROR TYPEOUT THAT COULD HAVE OCCURRED ON A WRITE STATUS ERROR. (NOTE CRC IN THE STATUS INDICATOR "ST:")

WRITE STATUS ERROR
PC:2371 ST:4010 CM:4000 IA:0001 DA:0002
CA:3600 WC:7000 FW:0000

THE FOLLOWING IS AN EXAMPLE OF AN ERROR TYPEOUT THAT COULD HAVE OCCURRED IF THE STATUS REGISTER FAILED ON A SEEK ONLY FUNCTION.

SEEK STATUS ERROR
PC:2076 ST:4002 CM:3000 DA:4007

THE FOLLOWING IS A TYPICAL EXAMPLE OF AN "ERROR HEADER" AND ERROR TYPEOUT THAT COULD HAVE OCCURRED ON A DISK DATA ERROR. (NOTE: ADDITION DATA ERRORS IN BUFFER)

DISK DATA ERROR
PC:1674 ST:4010 CM:1432 IA:1035 DA:1021
CA:0001 WC:5000 FW:7400
AS:0015 WA:0007 AD:0010 DG:0537 DB:0536
AS:0015 WA:0077 AD:0100 DG:7777 DB:7776
AS:0016 WA:0002 AD:0403 DG:6167 DB:6166

6.

RESTRICTIONS

ALL DISK DRIVES SHOULD BE SET TO THE LOAD POSITION THAT ARE NOT BEING TESTED.

7.

TROUBLE SHOOTING INFORMATION

IOT

FUNCTION

6741 DSKP

"SKIP" SKIP IF TRANSFER DONE FLAG OR ERROR FLAG IS SET.

6742 DCLR

"CLEAR" FUNCTION IS REGULATED BY AC BITS 10 AND 11. THE AC IS THEN CLEARED.

| AC10 ---- | AC11 ---- | |
|--------------|--------------|---|
| 0 | 0 | CLEAR THE AC AND STATUS REGISTER. |
| 0 | 1 | CLEAR THE AC, CONTROL, AND MAJOR REGISTERS. THIS INSTRUCTION WILL STOP THE CONTROL EVEN IF IT IS WRITING A HEADER. THIS IS THE ONLY INSTRUCTION THAT CLEARS MAINTENANCE MODE. |
| 1 | 0 | CLEAR AC, RECALIBRATE DISK DRIVE, AND CLEAR STATUS REGISTER. |
| 6743 | DLAG | "LOAD DISK ADDRESS AND GO" LOAD THE DISK CYLINDER, SURFACE, AND SECTOR FROM THE AC, CLEAR THE AC, AND DO THE COMMAND IN THE COMMAND REGISTER. |
| AC -- | | |
| 0-6 | | CYLINDER |
| 7 | | SURFACE (1=UPPER) (0=LOWER) |
| 8-11 | | SECTOR |
| 6744 | DLCA | "LOAD CURRENT ADDRESS" LOAD THE CURRENT ADDRESS FROM AC. THE AC IS THEN CLEARED. |
| AC -- | | |
| 0-11 | | CURRENT ADDRESS |
| 6745 | DRST | "READ STATUS" CLEAR THE AC AND READ THE CONTENTS OF THE STATUS REGISTER INTO THE AC. |

AC
--

| | |
|----|--------------------------------|
| 0 | TRANSFER DONE |
| 1 | READY TO SEEK, READ, OR WRITE. |
| 2 | NOT USED |
| 3 | SEEK FAIL |
| 4 | DISK FILE READY |
| 5 | CONTROL BUSY ERROR |
| 6 | TIME OUT ERROR |
| 7 | WRITE LOCK ERROR |
| 8 | CRC ERROR |
| 9 | DATA RATE ERROR |
| 10 | DRIVE STATUS ERROR |
| 11 | CYLINDER ADDRESS ERROR |

6746 DLDC

"LOAD COMMAND" LOAD THE COMMAND REGISTER FROM AC, CLEAR THE AC, AND CLEAR THE STATUS REGISTER.

AC
--

| | |
|-------|---------------------------------------|
| 0-2=0 | READ DATA |
| 0-2=1 | READ ALL |
| 0-2=2 | WRITE LOCK |
| 0-2=3 | SEEK ONLY |
| 0-2=4 | WRITE DATA |
| 0-2=5 | WRITE ALL |
| 0-2=6 | NOT USED |
| 0-2=7 | NOT USED |
| 3 | ENABLE INTERRUPT |
| 4 | ENABLE SET TRANSFER DONE ON SEEK DONE |
| 5 | HALF BLOCK 128 WORDS |
| 6 | EXTENDED MEMORY ADDRESS |
| 7 | EXTENDED MEMORY ADDRESS |
| 8 | EXTENDED MEMORY ADDRESS |
| 9 | UNIT SELECT |
| 10 | UNIT SELECT |
| 11 | EXTENDED CYLINDER ADDRESS |

6747 DMAN

"MAINTENANCE IOT" LOAD THE MAINTENANCE REGISTER FROM THE AC. THE FUNCTION IS REGULATED BY THE AC BITS. MAINTENANCE MODE CAN ONLY BE CLEARED BY DCLR "CLEAR CONTROL".

AC
--

| | |
|----|--|
| 0 | ENTER MAINTENANCE MODE |
| 1 | ENABLE SHIFT TO LOWER BUFFER |
| 2 | AC BIT 10, CRC REGISTER, AND THE LOWER DATA BUFFER ARE CONNECTED AS A SHIFT REGISTER. AC BIT 10 DATA SHIFTS TO THE CRC, THE CRC SHIFTS TO THE LOWER DATA BUFFER. |
| 3 | SHIFT COMMAND REGISTER TO THE LOWER DATA BUFFER. |
| 4 | SHIFT THE SURFACE AND SECTOR REGISTER TO THE LOWER DATA BUFFER. |
| 5 | SHIFT AC 10 DATA TO THE UPPER DATA BUFFER. THE UPPER BUFFER SHOULD SINK IN THE SILO WHEN FULL. |
| 6 | ONE SINGLE CYCLE BREAK REQUEST. DIRECTION IS REGULATED BY FUNCTION IN THE COMMAND REGISTER. |
| 7 | CLEAR AC THEN READ THE LOWER DATA BUFFER TO THE AC. |
| 8 | NOT USED. |
| 9 | NOT USED. |
| 10 | USED AS DATA WITH OTHER BITS IN THE MAINTENANCE MODE. |
| 11 | NOT USED |

8. PROGRAM DESCRIPTION (ACCEPT MODE)

THE FOLLOWING IS BRIEF DESCRIPTION OF THE STEPS TAKEN BY THE PROGRAM WHEN RUNNING THE ACCEPT MODE.

- A. ALL DISKS SELECTED ARE FIRST RECALIBRATED, THEN SENT ON AN OVERLAP SEEK TO A RANDOM TRACK. THE TRACKS SELECTED ARE SAVED BY THE PROGRAM FOR FUTURE USE.
- B. A RANDOM FIELD IS GENERATED. IF FIELD GENERATED IS A NON-EXISTING FIELD, THE MAXIMUM FIELD AVAILABLE WILL BE USED.
- C. A RANDOM BLOCK LENGTH IS GENERATED (128 OR 256 WORD SECTORS).
- D. A RANDOM AMOUNT OF SEQUENTIAL SECTORS TO TRANSFER IS GENERATED. IF THE FIELD PREVIOUSLY SELECTED WAS AN EXTENDED FIELD OR IF HALF BLOCK TRANSFERS WERE SELECTED (128 WORD SECTORS), THE AMOUNT OF SECTORS WILL BE LIMITED TO 17(8). IF THE FIELD SELECTED WAS FIELD 0 AND IF FULL BLOCK TRANSFERS WERE SELECTED (256 WORD SECTORS), THE AMOUNT OF SECTORS WILL BE LIMITED TO 7(8).

- E. A RANDOM STARTING SECTOR WILL BE GENERATED. THE RANDOM AMOUNT OF EXTRA SECTORS PREVIOUSLY GENERATED WILL BE ADDED TO THIS STARTING SECTOR, DETERMINING THE ACTUAL LENGTH OF THE DATA TRANSFER. IF THE STARTING SECTOR WAS 14 AND THE AMOUNT OF EXTRA SECTORS WAS 6, SECTORS 14, 15, 16, 17, 00, 01, AND 02 WILL BE USED FOR TRANSFERING DATA.
- F. AN INITIAL SOFTWARE WORD COUNT WILL BE CALCULATED.
- G. AN INITIAL RANDOM CURRENT ADDRESS WILL BE GENERATED. IF THE FIELD PREVIOUSLY GENERATED WAS FIELD 0, THE CURRENT ADDRESS WILL BE LIMITED WITHIN THE END OF THE PROGRAM +4000 LOCATIONS.
- H. THE BUFFER SELECTED WILL BE FILLED WITH RANDOM DATA, CHECKSUMMED, AND THE CHECKSUM SAVED. (NOTE: BUFFER IS DEPENDENT ON FIELD, WORD COUNT, BLOCK LENGTH, AND CURRENT ADDRESS PREVIOUSLY SELECTED.)
- I. THE PROGRAM WILL THEN POLE THE DISK DRIVES PREVIOUSLY SENT ON OVERLAP SEEK OPERATIONS.
- J. DATA WILL BE WRITTEN ON THE FIRST DISK DRIVE TO COMPLETE THE SEEK OPERATION USING THE RANDOM PARAMETERS GENERATED ABOVE. AS DATA IS WRITTEN, A BACK GROUND PROGRAM WILL CLEAR THE BUFFER AREA ALREADY WRITTEN ON THE DISK.
- K. WHEN THE WRITE AND CLEAR IS COMPLETE, DATA WILL BE READ OFF THE CURRENT DRIVE INTO THE BUFFER AREA. AS DATA IS READ, A BACK GROUND PROGRAM WILL CHECKSUM THE BUFFER INFORMATION ALREADY READ OFF THE DISK.
- L. WHEN THE READ AND CHECKSUM IS COMPLETE, THE CHECKSUM FOUND WILL BE COMPARED TO THE CHECKSUM SAVED PREVIOUS TO THE WRITE OPERATION. IF CHECKSUMS DO NOT COMPARE OR IF A CRC ERROR HAS OCCURRED, A WORD BY WORD COMPARE WILL BE MADE TO DETERMINE AND TYPE OUT THE BAD DATA FOUND.
- M. THE CURRENT DRIVE WILL BE SENT OUT ON AN OVERLAP SEEK OPERATION AND THE TRACK SAVED.
- N. STEPS B-H WILL BE REPEATED AND THE DRIVE POLE WILL BE STARTED AT THE CURRENT DRIVE +1.
- O. FOR ALL POSSIBLE ERRORS, SEE SECTION 5 IN THIS DOCUMENT.

9. PROGRAM LISTING

```

/
/RK8E DATA RELIABILITY PROGRAM
/MAINDEC=00-DHRKC=E-L
/COPYRIGHT (C) 1972-1973-1974-1975, DIGITAL EQUIP. CORP., MAYNARD, MASS.
/NOTE: LOCATION 0 CONTAINS THE REVISION
/LEVEL (IN ASCII) ON PROGRAM LOAD.
/
/ALL KNOWN HALTS
/
0200 1410 ERHLT2 /SKIP TRAP DCLR
0201 2563 ERHLT3 /SKIP TRAP DLAG
0202 2555 ERHLT4 /SKIP TRAP DLCA
0203 2546 ERHLT5 /SKIP TRAP DRST
0204 2732 ERHLT6 /SKIP TRAP DLDC
0205 3126 INTER1 /NO DISK INTERRUPT
0206 2357 INTER2 /UNDEFINED INTERRUPT
0207 0206 KHLT /PROGRAM WILL ONLY RUN IN FIELD W
0210 2671 NODSKS /NO DISKS AVAILABLE TO RUN
0211 2006 STPHLT /PROGRAM STOP FROM SWR4=1
0212 2753 CHNHLT /IOT CHANGE HALT
0213 1707 BADHLT /COMPUTER MUST BE DOWN, CHECKSUM FAILED
/ BUT WORD-BY-WORD COMPARE WORKED.

6741 DSKP=6741 /SKIP ON TRANSFER DONE OR ERROR
6742 DCLR=6742 /CLEAR DISK CONTROL LOGIC
6743 DLAG=6743 /LOAD ADDRESS AND GO
6744 DLCA=6744 /LOAD CURRENT ADDRESS
6745 DRST=6745 /READ STATUS REGISTER
6746 DLDC=6746 /LOAD COMMAND REGISTER

/
4421 RANDAT=JMS I XRNWRD
4422 DISCON=JMS I XDUMP
4423 SPACE=JMS I XSPAC
4424 ONEIN=JMS I XOCT1
4425 FORIN=JMS I XOCT4
4426 SETGEN=JMS I XSTGEN
4427 SETFLD=JMS I XSTFLD
4431 YESNO=JMS I XCHKYN
4430 SELCHK=JMS I XCKPOT
4432 SEEK=JMS I XSKOUT
4433 RANGEN=JMS I XRNDOM
4435 RESPAN=JMS I XRSRAN
4434 DISKGO=JMS I XDSKGO
4436 RECAL=JMS I XRESTR
4437 RECEIV=JMS I XWAIT
4441 ERROR=JMS I XERRO
4442 RDSTAT=JMS I XRDST
4446 LDADD=JMS I XLDAD
4443 DSKSKP=JMS I XSDKP
4444 LDCMD=JMS I XLDCM
4445 LDCUR=JMS I XLDCA

```

```

4447 CLRALL=JMS I XCLDR
4450 PRNTER=JMS I XPRN
4451 OCTEL=JMS I XFROCT
4440 TYPE=JMS I XPRINT
4452 CRLF=JMS I XCRLF
4420 GENDAT=JMS I XGNDAT

0000 /
/
0000 0305 0305 /REVISION "E"; INTERRUPT SERVICE RETURN
0001 5001 5001 /DCA SAVAC SAVE AC AT INT.
0002 0002 0002 /RAL SHIFT LINK AT TIME OF INT.
0003 0003 0003 /DCA SYLNK SAVE LINK AT TIME OF INT.
0004 0004 0004 /JMP I 5 RETURN TO INT. SERVICE
0005 0005 0005 /RETURN POINTER

0010 *10
/
0010 0000 AUTO10, 0
/
0011 0000 AUTO11, 0
/
0012 0000 AUTO12, 0
/
0013 0020 K0020, 0020
0014 0070 K0070, 0070
0015 0100 K0100, 0100
0016 0200 K0200, 0200
/
0020 *20
/
0020 1740 XGNDAT, GNDAT
0021 2600 XRNWRD, RNWRD
0022 2627 XDUMP, DUMP
0023 1503 XSPAC, SPAC
0024 2400 XOCT1, OCT1
0025 2430 XOCT4, OCT4
0026 1754 XSTGEN, STGEN
0027 2673 XSTFLD, STFLD
0030 2143 XCKPOT, CKPOT
0031 2122 XCHKYN, CHKYN
0032 2000 XSKOUT, SKOUT
0033 1716 XRNDOM, RNDOM
0034 2200 XDSKGO, DSKGO
0035 1762 XRSRAN, RSRAN
0036 3047 XRESTR, RESTOR
0037 2102 XWAIT, WAIT
0040 2620 XPRINT, PRINT
0041 1200 XERRO, ERRO
0042 2543 XRDST, RDST
0043 2720 XSDKP, SDKP
0044 2725 XLDCM, LDCM
0045 2552 XLDCA, LDCA
0046 2556 ALDAD, LDAD

```

```

0047 1405 XCLDR, CLDR
0050 1445 XPRN, PRN
0051 1423 XFROCT, FROCT
0052 1411 XCRLF, UPONE
0053 0000 AMOUNT, 0
0054 0003 K0003, 0003
0055 0006 K0006, 0006
0056 0007 K0007, 0007
0057 0010 K0010, 0010
0060 0017 K0017, 0017
0061 0260 K0260, 0260
0062 0240 K0240, 0240
0063 0316 K0316, 0316
0064 0331 K0331, 0331
0065 0277 K0277, 0277
0066 0400 K0400, 0400
0067 2000 K2000, 2000
0070 4000 K4000, 4000
0071 6000 K6000, 6000
0072 1000 K1000, 1000
0073 1777 K1777, 1777
0074 7700 K7700, 7700
0075 7760 K7760, 7760
0076 7761 K7761, 7761
0077 7772 K7772, 7772
0100 7775 K7775, 7775
0101 7777 K7777, 7777
0102 0077 K0077, 0077
0103 6201 KCDF, CDF
0104 7400 K7400, 7400

```

DECIMAL

```

0105 7764 M12, -12

```

OCTAL

```

0106 7774 M4, -4
0107 7773 M5, -5

```

```

0110 0000 TRASH1, 0
0111 0000 TRASH2, 0
0112 0000 TRASH3, 0
0113 0000 UPDATE, 0
0114 0000 POLDSK, 0
0115 0000 OPRTAL, 0
0116 0000 BUFTAL, 0
0117 0000 PCREG, 0
0120 0000 STREG, 0
0121 0000 CMREG, 0
0122 0000 INTDA, 0
0123 0000 DAREG, 0
0124 0000 CAREG, 0
0125 0000 WCREG, 0
0126 0000 FWREG, 0

```

```

0127 0000 ASREG, 0
0130 0000 WAREG, 0
0131 0000 ADREG, 0
0132 0000 DGREG, 0
0133 0000 DBREG, 0
0134 0000 INTCM, 0
0135 0000 STATRY, 0
0136 0000 DATRY, 0
0137 0000 CHKSAV, 0
0140 0000 FNDSDM, 0
0141 0000 MAXFLD, 0
0142 7607 MAXTIM, 7607
0143 3240 MAXTRK, 3240
0144 3600 BGNHUF, STRBUF
0145 0000 CONSEC, 0

```

```

0146 3556 DATPOT, DAT1
0147 3515 TIMPOT, D0TM1
0150 3522 STAPOT, D0HRD -3
0151 3546 DSKPOT, DSK0A
0152 3552 RUNPOT, DSK0B

```

```

0153 0000 CRCCNT, 0
0154 0000 CRCFLG, 0
0155 0000 DATFLG, 0
0156 0000 SPFLD, 0
0157 0000 SPTRK1, 0
0160 0000 SPTRK2, 0
0161 0000 SPSEC, 0
0162 0000 SPBLK, 0
0163 0000 ERFLG, 0
0164 0000 SEKSW, 0
0165 0000 SAVAC, 0
0166 0000 SVLNK, 0
0167 0000 FIRTIM, 0
0170 0000 TRYCNT, 0
0171 3203 XTEXT, TEXPC
0172 3132 PRNDAT, TYPDAT
0173 0000 SAVCM, 0
0174 0000 CLPBAK, 0

```

0200 *200

```

/START OF PROGRAM BY OPERATOR!
/AT 0200, TTY INTERIGATION!
/AT 0201, CHANGE IOT DEVICE CODES!
/AT 0202, RESTART AT SEEK ROUTINE!

```

```

0200 5203 BGN, JMP ,+3
0201 5777 JMP CHANG
0202 5776 JMP STRSTP
0203 3154 DCA CRCFLG
0204 6224 RIF
0205 7440 SZA

```

```

/TO REGULAR TEST
/CHANGE IOT ROUTINE
/RESTART
/CLEAR CRC FLAG
/FIELD 07777

```

```

0206 7402 KHLT, HLT /WILL ONLY RUN IN FIELD 0777?
0207 1103 TAD KCDF
0210 3211 DCA ,+1
0211 7402 HLT /MAKE DF=IF
/
/SETUP INTERRUPT SERVICE!
/
0212 1366 TAD ACDC A /SETUP AC DCA
0213 3001 DCA 1
0214 1247 TAD KROT /SETUP ROTATE LINK
0215 3002 DCA 2
0216 1365 TAD LNKDCA /SETUP SAVE LINK
0217 3003 DCA 3
0220 1364 TAD K5405 /SETUP JMP RETURN
0221 3004 DCA 4
0222 1367 TAD BRKRET /RETURN POINTER
0223 3005 DCA 5
/
/CLEAR DATA INFORMATION TABLE
/AT END OF PROGRAM!
/
0224 1074 STRTEX, TAD K7700 /CLEAR COUNTER
0225 3110 DCA TRASH1
0226 1775 TAD RANJMS /SET INSTRUCTION SWITCH
0227 3774 DCA SWDAT
0230 7340 CLA CLL CMA
0231 1147 TAD TIMPOT /LOCATION POINTER
0232 3010 DCA AUTO10 /CLEAR
0233 3410 DCA I AUTO10
0234 2110 ISZ TRASH1 /MORE TO CLEAR
0235 5233 JMP ,+2
0236 3155 DCA DATFLG
/
/PRINT PROGRAM NAME AND
/ASK OPERATOR ABOUT AMOUNT
/OF MEMORY!
/
0237 4452 CRLF /PRINT "RKSE DATA RELIABILITY"
0240 4450 PRNTER /PRINT "AMOUNT OF MEMORY"
0241 3303 MES1
0242 4450 PRNTER
0243 3337 MES5
0244 4424 ONEIN /RECEIVE ONE OCTAL
0245 0070 0070 /LIMITS
0246 5242 JMP ,+4 /INPUT ERROR
0247 7004 KROT, RAL
0250 7006 RTL
0251 7040 CMA /COMPLEMENT
0252 3141 DCA MAXFLD /MAXIMUM FIELD POINTER
0253 4450 ALLAGN, PRNTER /PRINT "EXERCISE"
0254 3316 MES2
0255 3110 DCA TRASH1
0256 1106 TAD M4
0257 3111 DCA TRASH2

```

```

0260 3053 DCA AMOUNT /A FEW POINTERS
/
/ASK OPERATOR ABOUT DISK(S) TO TEST!
/
0261 1110 NEXT, TAD TRASH1
0262 1152 TAD RUNPOT /SAVE RUN POINTER
0263 3112 DCA TRASH3
0264 7340 CLA CLL CMA /PRINT " DISK"
0265 4450 PRNTER
0266 3323 MES3
0267 1061 TAD K0260
0270 1110 TAD TRASH1 /ADD IN DISK NUMBER
0271 4440 TYPE /TYPE DISK NUMBER
0272 1065 TAD K0277
0273 4440 TYPE /TYPE ?
0274 4437 RECEIV /RECEIVE KEY INPUT
0275 4431 YESNO /WAS IT YES OR NO
0276 5253 JMP ALLAGN /NEITHER
0277 5302 JMP ,+3 /WAS A NO
0300 2053 ISZ AMOUNT /AMOUNT OF DISK FOUND
0301 7340 CLA CLL CMA /AC TO 7777 FOR EXISTING DISK
0302 3512 DCA I TRASH3 /SETUP RUN POINTER
0303 2110 ISZ TRASH1
0304 2111 ISZ TRASH2
0305 5261 JMP NEXT /ASK ABOUT NEXT DISK
/
/ASK IF ACCEPT MODE!
/
0306 1053 TAD AMOUNT /GET AMOUNT FOUND
0307 7650 SNA CLA /WERE ANY FOUND
0310 5224 JMP STRTEX /OPERATOR ERROR NO DISK INPUT
0311 4450 PRNTER /PRINT "ACCEPT MODE?"
0312 3361 MES6
0313 4437 RECEIV /RECEIVE INPUT
0314 4431 YESNO /YES OR NO???
0315 5311 JMP ,+4 /NEITHER ALL AGAIN
0316 7610 SKP CLA /MANUAL TEST
0317 5773 JMP ASKSUR /ASK "ARE YOU SURE"
/
/IF ACCEPT MODE, INTERAGATE
/ABOUT CONSTANT FIELD!
/
0320 4450 MANUAL, PRNTER /PRINT "FIELD?"
0321 3402 MES8
0322 4437 RECEIV /RECEIVE Y OR N
0323 4431 YESNO /CHECK FOR Y OR N
0324 5320 JMP MANUAL /NEITHER Y OR N
0325 5343 JMP ASKNXI /WAS A N, ASK ABOUT NEXT
0326 4423 SPACE /SPACE OUT ONE
0327 4424 ONEIN /GET 1 OCTAL
0330 0070 0070 /LIMITS
0331 5320 JMP MANUAL /INPUT ERROR ASK AGAIN
0332 7104 CLL RAL

```

```

0333 7006      RTL
0334 3156      DCA  SPFLD
0335 1156      TAD  SPFLD
0336 1141      TAD  MAXFLD
0337 7700      SMA CLA
0340 5320      JMP  MANUAL
0341 7340      CLA CLL CMA
0342 3772      DCA  FLDFLG
/
/INTERGATE ABOUT CONSTANT TRACK1
/
0343 4450      ASKNX1, PRNTER
0344 3406      MES9
0345 4437      RECEIV
0346 4431      YESNO
0347 5343      JMP  ASKNX1
0350 5771      JMP  ASKNX2
0351 4423      SPACE
0352 4424      ONEIN
0353 0010      0010
0354 5343      JMP  ASKNX1
0355 3157      DCA  SPTRK1
0356 4425      FORIN
0357 5343      JMP  ASKNX1
0360 3160      DCA  SPTRK2
0361 7340      CLA CLL CMA
0362 3770      DCA  TRKFLG
0363 5771      JMP  ASKNX2
/
0364 5405      K5405, 5405
0365 3166      LNKDCA, DCA  SVLNK
0366 3165      ACDCA, DCA  SAVAC
0367 2304      BRKRET, RETURN
/
0370 3542
0371 0400
0372 3541
0373 0520
0374 2601
0375 0554
0376 2003
0377 2733
0400 0400
PAGE
/
/INTERGATE ABOUT CONSTANT
/BLOCK LENGTH1
/
0400 4450      ASKNX2, PRNTER
0401 3422      MES11
0402 4437      RECEIV
0403 4431      YESNO
0404 5200      JMP  ASKNX2
0405 5217      JMP  ASKNX3
/PRINT "BLOCK LENGTH?"
/RECEIVE INPUT
/CHECK FOR Y OR N
/ERROR, ASK AGAIN
/N, ASK ABOUT NEXT

```

```

0406 4423      SPACE
0407 4424      ONEIN
0410 0010      0010
0411 5200      JMP  ASKNX2
0412 7640      SZA CLA
0413 7340      CLA CLL CMA
0414 3162      DCA  SPBLK
0415 7340      CLA CLL CMA
0416 3777      DCA  HLFPLG
/SETUP BLOCK FLAG
/
/INTERGATE ABOUT CONSTANT
/SECTORS1
/
0417 4450      ASKNX3, PRNTER
0420 3412      MES10
0421 4437      RECEIV
0422 4431      YESNO
0423 5217      JMP  ASKNX3
0424 5256      JMP  ASKNX4
0425 4423      SPACE
0426 4424      ONEIN
0427 0010      0010
0430 5217      JMP  ASKNX3
0431 7104      CLL RAL
0432 7006      RTL
0433 3161      DCA  SPSEC
0434 4424      ONEIN
0435 0070      0070
0436 5217      JMP  ASKNX3
0437 1161      TAD  SPSEC
0440 3161      DCA  SPSEC
0441 1162      TAD  SPBLK
0442 7640      SZA CLA
0443 5246      JMP  .+3
0444 1156      TAD  SPFLD
0445 7640      SZA CLA
0446 1057      TAD  K0010
0447 1056      TAD  K0007
0450 7140      CLL CMA
0451 1161      TAD  SPSEC
0452 7630      SZL CLA
0453 5217      JMP  ASKNX3
0454 7340      CLA CLL CMA
0455 3776      DCA  SECFLG
/SETUP SECTOR FLAG
/
/INTERGATE ABOUT SEQUENCE1
/
0456 1775      ASKNX4, TAD  TRKFLG
0457 7640      SZA CLA
0460 5271      JMP  ASKNX5
0461 4450      PRNTER
0462 3431      MES12
0463 4437      RECEIV
/GET TRACK FLAG
/WAS IT SET?
/YES, DON'T ASK SEQUENCE
/PRINT "SEQUENCE?"
/RECEIVE INPUT

```

```

0464 4431      YESNO      /Y OR N
0465 5256      JMP      ASKNX4 /ERROR, ASK AGAIN
0466 5271      JMP      ASKNX5 /N, ASK ABOUT NEXT
0467 7340      CLA CLL CMA
0470 3774      DCA      SEQFLG /SETUP SEQUENCE FLAG

/
/INTERIGATE ABOUT "OPERATOR
/SELECT DATA"!
/
0471 4450      ASKNX5, PRNTER /PRINT "DATA?"
0472 3436      MES13
0473 1354      TAD      RANJMS
0474 3773      DCA      SWDAT /SET INSTRUCTION SWITCH
0475 4437      RECEIV /RECEIVE INPUT
0476 4431      YESNO      /Y OR N
0477 5271      JMP      ASKNX5 /ERROR, ASK AGAIN
0500 5320      JMP      ASKSUR /ASK "ARE YOU SURE"
0501 1340      TAD      KSKP
0502 3773      DCA      SWDAT /SET INSTRUCTION SWITCH
0503 1105      TAD      M12
0504 3110      DCA      TRASH1 /SETUP WORD COUNTER
0505 7340      CLA CLL CMA
0506 1146      TAD      DATPOT /GET POT POINTER
0507 3010      DCA      AUTO10
0510 4452      CRLF
0511 4425      FORIN
0512 5271      JMP      ASKNX5 /RECEIVE 4 IN OCTAL
0513 3410      DCA I      AUTO10 /INPUT ERROR, ASK AGAIN
0514 2110      ISZ      TRASH1 /SAVE DATA
0515 5310      JMP      ,=5 /UPDATE COUNTER
0516 7340      CLA CLL CMA /GET NEXT
0517 3155      DCA      DATFLG /SETUP DATA FLAG

/
/ASK IF HE'S SURE!
/
0520 4450      ASKSUR, PRNTER /PRINT "ARE YOU SURE"
0521 3441      MES14
0522 4437      RECEIV /GET INPUT
0523 4431      YESNO      /Y OR N
0524 5320      JMP      ASKSUR /INPUT ERROR
0525 5772      JMP      STRTEX /ALL AGAIN

/
/SEND EXISTING DRIVES TO A RANDOM TRACK
/AND SAVE THE TRACK ADDRESS
/
0526 3110      STRSEK, DCA TRASH1
0527 1053      TAD      AMOUNT
0530 7041      CIA
0531 3111      DCA      TRASH2 /SOME POINTERS
0532 1110      NXTSEK, TAD TRASH1
0533 4430      SELCHK /CHECK RUN POINTER
0534 5352      JMP      NTSEK /WAS A ZERO DON'T RUN
0535 1110      RESET, TAD TRASH1

```

```

0536 7104      CLL RAL
0537 4436      RECAL
0540 7610      KSKP, SKP CLA /RECALIBRATE DRIVE
0541 5347      JMP      NTSEK =3 /RECALIBRATE IS O.K.
0542 1110      TAD      TRASH1 /DUMPED BUT MORE AVAILABLE
0543 7104      CLL RAL
0544 4432      SEEK
0545 7610      SKP CLA /SEEK ONLY A RANDOM TRACK
0546 5335      JMP      RESET
0547 2111      ISZ      TRASH2 /ERROR, TRY TO RECALIBRATE
0550 7610      SKP CLA /UPDATE POINTER
0551 5771      JMP      RUN /MORE TO SEND OUT
0552 2110      NTSEK, ISZ TRASH1 /START RANDOM DATA
0553 5332      JMP      NXTSEK /SEND OUT NEXT EXISTING DISK

/
0554 4420      RANJMS, GENDAT
/
0571 0600
0572 0224
0573 2601
0574 3545
0575 3542
0576 3543
0577 3544
0600 0600      PAGE
/
/
/SETUP ADDRESSING, COMMAND,
/AND DATA PARAMETERS!
/IF SW6 IS SET, INHIBIT DATA
/TESTING!
/
0600 3163      RUN, DCA ERFLG /CLEAR ERROR POINTER
0601 7604      LAS
0602 0360      AND      K0040 /MASK SWITCH 6
0603 3164      DCA      SEKSW /LATCH
0604 1164      TAD      SEKSW
0605 7640      SZA CLA /SEEK ONLY SET????
0606 5777      JMP      POLNEX /YES, SEEK ONLY

/
/MAKE FIELD!
/
0607 1776      TAD      FLDFLG /GET FIELD FLAG
0610 7650      SNA CLA /WAS IT SET?
0611 5214      JMP      ,+3 /NO, USE RANDOM FIELD
0612 1156      TAD      SPFLD /YES, GET OPERATOR FIELD
0613 5233      JMP      RNFLD /GO
0614 7301      CLA CLL IAC
0615 1141      TAD      MAXFLD /GET MAXIMUM FIELD POINTER
0616 7650      SNA CLA /ANY FIELDS THERE
0617 5233      JMP      RNFLD /NO EXTENDED FIELDS TO USE
0620 4433      RANGEN /YES, GET A RANDOM FIELD
0621 0014      AND      K0070 /MASK
0622 7450      SNA /COULD BE 0
0623 5233      JMP      RNFLD /WAS DON'T HAVE TO CHECK LIMITS

```

```

/ PAL10 V142A 19-MAR-75 15:21 PAGE 1-10

0624 3134 DCA INTCM /SAVE FIELD FOUND
0625 1134 TAD INTCM
0626 1141 TAD MAXFLD /ADD IN MAXIMUM FIELD POINTER
0627 7710 SPA CLA /IN LIMITS???
0630 5234 JMP RNFLD +1 /YES, USE IT
0631 1141 TAD MAXFLD /NO, USE MAXIMUM IN THE MACHINE
0632 7040 CMA
0633 3134 RNFLD, DCA INTCM
/
/MAKE BLOCK LENGTH1
/
0634 1775 TAD HLFFLG /GET BLOCK FLAG
0635 7650 SNA CLA /WAS IT SET???
0636 4433 RANGEN /NO, USE RANDOM
/
0637 1162 TAD SPBLK /MASK
0640 0015 AND K0100
0641 1134 TAD INTCM /INITIAL HALF BLOCK BIT ****
0642 3134 DCA INTCM
0643 1134 TAD INTCM
0644 0015 AND K0100 /MASK
0645 7640 SZA CLA /HALF BLOCK SET???
0646 1016 TAD K0200 /YES, SETUP WC POINTER
0647 1104 TAD K7400
0650 3111 DCA TRASH2 /WC BUILDER
0651 1111 TAD TRASH2
0652 7041 CIA
0653 3113 DCA UPDATE /UPDATER FOR FWREG
0654 1134 TAD INTCM
0655 0361 AND A0170 /MASK FIELD BITS
0656 7640 SZA CLA /WERE THERE ANY
0657 1057 TAD K0010 /YES
0658 1056 TAD K0007 /MAKE MAXIMUM SECTOR POINTER
0659 3110 DCA TRASH1 /SAVE IT
/
/MAKE AMOUNT OF SECTORS
/TO TRANSFER1
/
0662 1774 TAD SECFLG /GET SECTOR FLAG
0663 7650 SNA CLA /WAS IT SET???
0664 4433 RANGEN /USE RANDOM
0665 1161 TAD SPSEC /GET OPERATOR INPUT
0666 0110 AND TRASH1 /MASK OUT
0667 3145 DCA CONSEC /SAVE
0670 1145 TAD CONSEC
0671 7040 CMA
0672 3110 DCA TRASH1 /CONSECUTIVE TO DO
/
/MAKE CYLINDER, SURFACE, AND
/STARTING SECTOR1
/
0673 1773 TAD TRKFLG /GET TRACK FLAG
0674 7650 SNA CLA /WAS IT SET???
0675 4433 RANGEN /USE RANDOM
0676 1160 TAD SPTRK2 /GET INPUT
0677 0060 AND K0017 /MASK

```

```

/ PAL10 V142A 19-MAR-75 15:21 PAGE 1-11

0700 3112 DCA TRASH3 /STARTING SECTOR
0701 1111 TAD TRASH2 /COMPUTE INITIAL WC
0702 2110 ISZ TRASH1
0703 5301 JMP .+2 /UPDATE BY BUILDER
0704 3125 DCA WCREG /INITIAL WORD COUNT ****
/
/MAKE CURRENT ADDRESS1
/
0705 4433 RANGEN /GENERATE RANDOM CA
0706 3124 DCA CAREG /SAVE IT
0707 1134 TAD INTCM
0710 0014 AND K0070 /MASK FIELD BITS
0711 7640 SZA CLA /EXTENDED FIELD???
0712 5330 JMP FILLER /INITIAL CA O.K.****
0713 1144 TAD BGNSUF
0714 7140 CMA CLL
0715 1124 TAD CAREG
0716 7620 SNL CLA /GREATER THAN PROGRAM +1
0717 5326 JMP CONCUR /NO, USE CONSTANT VALUE
0720 1125 TAD WCREG /GET WORD COUNT
0721 7041 CIA
0722 1124 TAD CAREG /ADD IN CA
0723 1016 TAD K0200
0724 7630 SZL CLA /WITHIN BOUNDS???
0725 5330 JMP FILLER /YES, INITIAL CA O.K.****
0726 1144 CONCUR, TAD BGNSUF /NO, USE PROGRAM +1
0727 3124 DCA CAREG /SAVE IT
/
/ROUTINE TO FILL AND CHECK SUM BUFFER
/
0730 4426 FILLER, SETGEN /SETUP AND SAVE GENERATER
0731 1106 TAD M4
0732 3135 DCA STATRY /SETUP TRY COUNTER
0733 4427 REFILL, SETFLD /FIELD + BUFTAL + AUTO 11 + 12
0734 3335 DCA .+1 /FIELD TO BUFFER IN AC
0735 7402 HLT /CDF TO BUFFER
0736 3137 DCA CHKSAV /START WITH 0
0737 4421 NEWRD, RANDAT /GENERATE DATA
0740 3110 DCA TRASH1 /SAVE OUTPUT WORD
0741 1110 TAD TRASH1 /GET BACK WORD
0742 3411 DCA I AUTO11 /STORE IN BUFFER
0743 7100 CLL
0744 1110 TAD TRASH1 /GET BACK WORD
0745 1137 TAD CHKSAV /ADD IN LAST
0746 7430 SZL /LINK SET??
0747 7001 IAC /ADD IT IN
0750 3137 DCA CHKSAV /SAVE FOR NEXT
0751 2116 ISZ BUFTAL /UPDATE BUFFER TALLY
0752 5337 JMP NEWRD /MORE WORDS TO GO
0753 6201 CDF 0
0754 1163 TAD ERFLG
0755 7650 SNA CLA /ERROR FLAG SET???
0756 5777 JMP POLNEX /POLE DRIVES
0757 5772 JMP REWRT /YES, MUST BE A WRITE ERROR
/

```

0760 0040 K0040, 0040
0761 0170 A0170, 0170
/

0772 1054
0773 3542
0774 3543
0775 3544
0776 3541
0777 1000
1000

PAGE

/ROUTINE TO POLE DRIVES; WAIT FOR FIRST DRIVE COMPLETION,
/THEN START WRITE SEQUENCE!

1000 2114 POLNEX, ISZ POLDISK /UPDATE POLE POINTER
1001 7000 NOP
1002 1114 SAMPOL, TAD POLDISK /GET POINTER
1003 4430 SELCHK /CHECK RUN POINTER
1004 5200 JMP POLNEX /TRY NEXT DRIVE
1005 1114 TAD POLDISK /GET POINTER
1006 0054 AND K0003 /MASK
1007 7104 CLL RAL /MAKE DRIVE NUMBER
1010 4444 LDCMD /LOAD COMMAND REGISTER
1011 4442 RDSTAT /READ STATUS REGISTER
1012 1071 TAD K6000
1013 7450 SNA /WAS DRIVE BUSY
1014 5200 JMP POLNEX /YES, TRY NEXT DRIVE
1015 1067 TAD K2000 /NO, THEN IT MUST BE DONE
1016 7650 SNA CLA /WAS IT DONE ?
1017 5235 JMP GOTIT /YES, DONE
1020 4441 ERROR /ERROR ON DRIVE POLE
1021 0003 0003 /HEADER POINTER
1022 7200 7200 /MESSAGE POINTER
1023 1114 BDREC, TAD POLDISK /LAST DRIVE USED
1024 7104 CLL RAL
1025 4436 RECAL /RECALIBRATE DISK
1026 7610 SKP CLA /RECALIBRATE O.K.
1027 5200 JMP POLNEX /DUMPED, BUT MORE AVAILABLE
1030 1114 TAD POLDISK /GET DISK NO.
1031 7104 CLL RAL
1032 4432 SEEK /SEEK A RANDOM TRACK
1033 5200 JMP POLNEX /ENTER POLE DISKS
1034 5223 JMP BDREC /ERROR, RECALIBRATE

/DRIVE COMPLETED, START
/WRITE SEQUENCE!

1035 1114 GOTIT, TAD POLDISK /GET POINTER
1036 0054 AND K0003 /MASK
1037 1151 TAD DSKPOT /GET DISK ADDRESS POINTER
1040 3110 DCA TRASH1
1041 1510 TAD I TRASH1 /GET DISK ADDRESS
1042 0056 AND K0007 /MASK DRIVE + EXTENDED BIT
1043 1134 TAD INTCM /ADD IN COMMAND

1044 3134 DCA INTCM /DRIVE NUMBER + EXTENDED BIT ***
1045 1164 TAD SEKSW /GET SEEK SWITCH LATCH
1046 7640 SZA CLA /LOOP ON SEEK ONLYS???
1047 5354 JMP RESEEK /YES!!!!
1050 1510 TAD I TRASH1 /GET DISK ADDRESS
1051 0075 AND K7760 /MASK OFF TRACK
1052 1112 TAD TRASH3 /ADD IN STARTING SECTOR
1053 3122 DCA INTDA /INITIAL DISK ADDRESS ****

/WRITE INFORMATION!
/CLEAR BUFFER ON THE FLY!

1054 4434 REWRT, DISKGO /GO WRITE
1055 4400 4400 /WRITE DATA POINTER
1056 5270 JMP GOREAD /WRITE O.K.
1057 7340 CLA CLL CMA
1060 3163 DCA ERFLG /SET WRITE ERROR FLAG
1061 4435 RESRAN /RESET GENERATOR
1062 2135 ISZ STATRY /UPDATE WRITE RE=TRY
1063 5777 JMP REFILL /TRY AGAIN

/CHECK FOR LOOP ON WRITE!

1064 7604 LAS /GET SWITCH 0
1065 7700 TRYTIM, SMA CLA /LOOP ON WRITE????
1066 5354 JMP RESEEK /NO, TRY TO SEEK IT
1067 5776 JMP REFILL =2 /TRY WRITE AGAIN
1070 7604 GOREAD, LAS /GET SWITCH 0
1071 7700 SMA CLA /LOOP SWITCH SET????
1072 5277 JMP REREAD /NO
1073 7340 CLA CLL CMA
1074 3163 DCA ERFLG /SET ERROR FLAG
1075 4435 RESRAN /RESET DATA GENERATOR
1076 5776 JMP REFILL =2
1077 1265 REREAD, TAD TRYTIM
1100 3170 DCA TRYCNT /SETUP FOR SOFT ERROR RETRY
1101 3163 DCA ERFLG /CLEAR ERROR FLAG
1102 1106 TAD M4
1103 3135 DCA STATRY /SETUP TRY COUNTER
1104 1106 TAD M4
1105 3136 DCA DATTRY /SETUP TRY COUNTER
1106 3153 DCA CRCCNT /CLEAR CRC COUNTER!!!!

/READ INFORMATION!
/CHECK BUFFER ON THE FLY!

1107 4434 RDTRY, DISKGO /READ DATA
1110 0400 0400 /READ DATA POINTER
1111 7610 SKP CLA /DATA READ O.K.
1112 5321 JMP RDSTA /STATUS ERROR
1113 3153 DCA CRCCNT /CLEAR CRC COUNTER!

/CHECK DATA ON NO STATUS ERRORS!

1114 4775 JMS DTCHK /CHECK DATA

```

1115 5340      JMP      SEKGO      /DATA O.K.
1116 2136      ISZ      DATTRY     /UPDATE READ RE-TRY
1117 5307      JMP      RDTRY      /TRY AGAIN
1120 5337      JMP      SEKGO =1    /TRY TO SEEK IT
1121 1120      RDSTA, TAD      STREG /GET STATUS READ
1122 0057      AND      K0010      /MASK CRC
1123 7450      SNA      /CRC ERROR????
1124 5334      JMP      UPTRY      /NO, TRY READ AGAIN
1125 3154      DCA      CRCFLG     /YES, SET FLAG
1126 2153      ISZ      CRCCNT     /UPDATE CRC POINTER

/
/CHECK DATA AFTER CRC ERROR!
/
1127 4775"     JMS      DTCHK      /CHECK DATA
1130 7610      SKP      CLA        /IS A HARD ERROR!
1131 7340      CLA      CLL CMA     /SET RETRY COUNTER!
1132 3163      DCA      ERFLG     /SETUP FOR 64 RETRYS IF AC=7777
1133 7410      SKP      /CHECK ON RETRY!!!!
1134 3153      UPTRY, DCA      CRCCNT
1135 2135      ISZ      STATRY     /UPDATE TRY POINTER
1136 5307      JMP      RDTRY      /TRY AGAIN
1137 3163      DCA      ERFLG     /IS A HARD ERROR
1140 3153      SEKGO, DCA      CRCCNT /CLEAR CRC COUNT
1141 3154      DCA      CRCFLG     /CLEAR CRC FLAG
1142 4774"     JMS      CKTIM      /CHECK TIME POINTERS
1143 1163      TAD      ERFLG
1144 7650      SNA      CLA        /IS IT 64 RETRYS FOR SOFT ERROR?
1145 5350      JMP      +3         /NO DON'T BOTHER
1146 2170      ISZ      TRYCNT     /YES, UPDATE RETRY COUNTER
1147 5302      JMP      REREAD +3  /TRY AGAIN

/
/CHECK FOR LOOP ON READ!
/
1150 7604      LAS      /GET SWITCH 1
1151 7104      CLL      RAL
1152 7710      SPA      CLA        /LOOP????
1153 5277      JMP      REREAD     /YES, LOOP
1154 3163      RESEK, DCA      ERFLG /CLEAR ERROR FLAG

/
/CHECK FOR TYPE STATUS
/REPORT!
/
1155 7604      LAS      /
1156 0066      AND      K0400      /MASK
1157 7650      SNA      CLA        /TYPE STATUS REPORT????
1160 5363      JMP      +3         /NO
1161 4452      CRLF
1162 4773"     JMS      TPSTA      /YES
1163 1121      TAD      CMREG      /GET DRIVE NUMBER
1164 4432      SEEK      /SEEK A RANDOM TRACK
1165 5772"     JMP      RUN        /DO NEXT DRIVE
1166 1121      TAD      CMREG
1167 4436      RECAL      /RECALIBRATE DRIVE
1170 5363      JMP      +5         /TRY, SEEK AGAIN
1171 5772"     JMP      RUN        /DUMPED, BUT MORE AVAILABLE

```

```

1172 0600
1173 3000
1174 2450
1175 1600
1176 0731
1177 0733
1200 1200      PAGE
/
/ERROR HANDLER!
/UPDATE "SOFT" OR "HARD" TALLYS!
/PRINT ERROR TEXT AND DATA!
/CHECK INHIBIT ERROR SW!
/
1200 0000      ERRO, 0
1201 7001      IAC
1202 3373      DCA      PCNTR2     /UPDATE AC FLAG
/SAVE NON-RECOVERABLE POINTER!

/
/COMPUTE WAY TO "HARD"/"SOFT" TALLYS!
/
1203 1077      TAD      K7772
1204 3374      DCA      PCNTR3     /LINE COUNTER
1205 1121      TAD      CMREG      /GET LAST COMMAND
1206 0055      AND      K0006      /MASK DRIVE NUMBER
1207 7170      CLL      CMA RAR
1210 3372      DCA      PCNTR1     /SETUP COUNTER
1211 1054      TAD      K0003
1212 2372      ISZ      PCNTR1
1213 5211      JMP      +2         /COMPUTE WAY TO BUFFER
1214 1150      TAD      STAPOT
1215 3372      DCA      PCNTR1     /POINTER TO BUFFER

/
/DETERMINE IF ERROR IS "HARD" OR "SOFT"!
/
1216 1154      TAD      CRCFLG     /GET CRC FLAG
1217 7650      SNA      CLA        /CRC ERROR????
1220 5251      JMP      NTSOFT     /NO, WAS DEFINITELY A HARD ERROR!
1221 1600      TAD      I      ERRO /GET ERROR POINTER!
1222 7650      SNA      CLA        /WAS IT FIRST TIME?
1223 5255      JMP      NTERR      /NO ERROR, ADDITIONAL CRC DATA!
1224 1123      TAD      DAREG      /COMPARE FAILING SECTOR TO
1225 0060      AND      K0017      /SECTOR WHERE DATA ERROR
1226 7041      CIA      /OCCURRED!
1227 1127      TAD      ASREG
1230 7640      SZA      CLA        /SAME SECTOR?
1231 5251      JMP      NTSOFT     /NO, "HARD" ERROR
1232 7340      CLA      CLL CMA     /GET CRC COUNTER
1233 1153      TAD      CRCCNT     /WAS THIS FIRST POSSIBLE "SOFT"?
1234 7450      SNA      /YES, UPDATE "SOFT" TALLY!
1235 5245      JMP      SOFT       /CHECK IF NONRECOVERABLE "SOFT"!
1236 1100      TAD      K7775
1237 7650      SNA      CLA        /WAS IT?
1240 2372      ISZ      PCNTR1     /NO, DUMP "SOFT" TALLY!
1241 1772      TAD      I      PCNTR1 /OTHERWISE DUMP "HARD" TALLY!
1242 7440      SZA      /DONT GO BACK *ARDS!!!!!!

```



```

/ PAL10 V142A 19-MAR-75 15:21 PAGE 1-16

1243 1101 TAD K7777 /DUMP APPROPRIATE TALLY!!
1244 5254 JMP NTERR -1 /DUMP IT!
1245 1101 SOFT, TAD K7777
1246 1772 TAD I PCNTR1 /REDUCE HARD ERROR COUNT
1247 3772 DCA I PCNTR1
1250 2372 ISZ PCNTR1 /YES, UPDATE POINTER
1251 1101 NTSOFT, TAD K7777
1252 2772 ISZ I PCNTR1 /UPDATE ERROR COUNT
1253 7610 SKP CLA
1254 3772 DCA I PCNTR1 /HOLD AT 7777

/
/CHECK INHIBIT SWI
/
1255 7604 NTERR, LAB
1256 7106 CLL RTL
1257 7710 SPA CLA /INHIBIT ERRORS????
1260 5355 JMP ERROEX +1 /YES

/
/CHECK FOR NO HEADER ON SECOND DATA ERROR!
/
1261 1600 DONEAD, TAD I ERRO /GET TEXT POINTER
1262 7650 SMA CLA /DATA ERROR?
1263 5354 JMP ERROEX /EXIT

/
/TYPE ERROR MESSAGE!
/
1264 4452 CRLF
1265 4452 CRLF
1266 1373 TAD PCNTR2 /GET NON-RECOV, FLAG
1267 7640 SZA CLA /WAS IT SET
1270 5274 JMP ,+4 /NO DON'T TYPE IT
1271 7340 CLA CLL CMA
1272 4450 PRNTER /PRINT "NON-RECOVERABLE "
1273 3326 MES4
1274 1600 TAD I ERRO /GET TEXT POINTER!
1275 1375 TAD HEDTAD /MAKE ERROR HEADER POINTER!
1276 3117 DCA PCREG /SAVE POINTER!
1277 1517 TAD I PCREG /GET CORRECT TEXT!
1300 3303 DCA ,+3
1301 7340 CLA CLL CMA
1302 4450 PRNTER /PRINT HEADER
1303 7402 HLT
1304 7340 CLA CLL CMA
1305 4450 PRNTER /PRINT "ERROR"
1306 3277 MES0
1307 4452 CRLF
1310 1200 TAD ERRO
1311 3117 DCA PCREG /SAVE PC
1312 2200 ISZ ERRO
1313 1600 TAD I ERRO
1314 3370 DCA ESAVE
1315 2200 ISZ ERRO /UPDATE FOR RETURN
1316 1171 TAD XTEXT
1317 3373 DCA PCNTR2
1320 1371 TAD XREG

```

```

/ PAL10 V142A 19-MAR-75 15:21 PAGE 1-17

1321 3010 DCA AUTO10
1322 1105 TAD M12
1323 3372 DCA PCNTR1 /COUNTER FOR # OF HEADS
1324 1370 STRAUT, TAD ESAVE /GET TEXT POINTER
1325 7500 SMA
1326 5362 JMP NOTEX /NOT THIS ONE
1327 7104 CLL RAL
1330 3370 DCA ESAVE
1331 2374 ISZ PCNTR3 /UPDATE LINE FILL COUNTER
1332 7610 SKP CLA /NO CRLF
1333 4452 CRLF
1334 1373 TAD PCNTR2 /GET TEXT MESSAGE POINTER
1335 2373 ISZ PCNTR2
1336 2373 ISZ PCNTR2
1337 3342 DCA ,+3 /STORE FOR PRNTER
1340 7340 CLA CLL CMA
1341 4450 PRNTER /PRINT XX1
1342 7402 HLT /MODIFIED TEXT POINTER
1343 1410 TAD I AUTO10
1344 4451 OCTEL /PRINT FOUR OCTAL
1345 2372 AGAIN, ISZ PCNTR1
1346 5324 JMP STRAUT /CHECK FOR NEXT XX1
1347 1517 TAD I PCREG /GET ERROR POINTER!
1350 1107 TAD M5
1351 7650 SMA CLA /FIRST DATA ERROR?
1352 4572 JMS I PRNDAT /YES, PRINT DATA
1353 5357 JMP ,+4
1354 4572 ERROEX, JMS I PRNDAT /PRINT ONLY DATA!
1355 2200 ISZ ERRO
1356 2200 ISZ ERRO /UPDATE FOR RETURN
1357 7301 CLA CLL IAC /ENABLE CLEAR CONTROL
1360 4447 CLRALL /CLEAR CONTROL
1361 5600 JMP I ERRO /EXIT
1362 7104 NOTEX, CLL RAL
1363 3370 DCA ESAVE
1364 2373 ISZ PCNTR2
1365 2373 ISZ PCNTR2
1366 2010 ISZ AUTO10
1367 5345 JMP AGAIN

/
ESAVE, 0
1371 0116 XREG, PCREG -1
1372 0000 PCNTR1, 0
1373 0000 PCNTR2, 0
1374 0000 PCNTR3, 0
1375 1377 HEDTAD, BUFPNT -1

/
PAGE
/
/POINTERS FOR TEXT INFORMATION!
/
1400 3235 BUFPNT, ERTX1
1401 3243 ERTX2
1402 3252 ERTX3
1403 3260 ERTX4

```

```

1404 3272          ERTX5
/
/SUBROUTINE TO ISSUE "DCLR" CLEAR IOT
/
1405 0000        CLDR, 0
1406 6742        IOT2, DCLR
1407 5605        JMP I   CLDR
1410 7402        ERHLT2, HLT
/
/ROUTINE TO DO CRLF
/
1411 0000        UPONE, 0
1412 7300        CLA CLL
1413 1221        TAD      K0215
1414 4440        TYPE
1415 1222        TAD      K0212
1416 4440        TYPE
1417 4440        JMP I   UPONE
1420 5611
/
K0215, 0215
K0212, 0212
/
/ROUTINE TO PRINT FOUR OCTAL
/
1423 0000        FROCT, 0
1424 7006        RTL
1425 7006        RTL
1426 3211        DCA      UPONE
1427 1106        TAD      M4
1430 3245        DCA      PRN
1431 1211        TAD      UPONE
1432 0056        AND      K0007
1433 1061        TAD      K0260
1434 4440        TYPE
1435 1211        TAD      UPONE
1436 7006        RTL
1437 7004        RAL
1440 3211        DCA      UPONE
1441 2245        ISZ      PRN
1442 5231        JMP      *-11
1443 4423        SPACE
1444 5623        JMP I   FROCT
/
/SUBROUTINE TO PRINT TEXT
/
1445 0000        PRN, 0
1446 7650        SNA CLA
1447 4452        CRLF
1450 1645        TAD I   PRN
1451 2245        ISZ      PRN
1452 3223        DCA      FROCT
1453 7300        MRPRN, CLA CLL
1454 1623        TAD I   FROCT
1455 0074        AND      K7700

```

```

/TYPE CRLF
/YES!!!!
/GET POINTER

```

```

1456 7450        SNA
1457 5301        JMP      EXIT
1460 7500        SMA
1461 7020        CML
1462 7001        IAC
1463 7012        RTR
1464 7012        RTR
1465 7012        RTR
1466 4440        TYPE
1467 1623        TAD I   FROCT
1470 0102        AND      K0077
1471 7450        SNA
1472 5301        JMP      EXIT
1473 1310        TAD      K3740
1474 7500        SMA
1475 1307        TAD      K4100
1476 4423        SPACE
1477 2223        ISZ      FROCT
1500 5253        JMP      MRPRN
1501 7300        EXIT,  CLA CLL
1502 5645        JMP I   PRN
/
/ROUTINE TO SPACE OUT 1
/
1503 0000        SPAC, 0
1504 1062        TAD      K0240
/
1505 4440        TYPE
1506 5703        JMP I   SPAC
/
K4100, 4100
K3740, 3740
/
PAGE
/
/ROUTINE TO CHECK DATA READ
/
1600 0000        DTCHK, 0
1601 1154        TAD      CRCFLG
1602 7640        SZA CLA
1603 5212        JMP      WRDCHK
1604 1140        TAD      FNDSUM
1605 7041        CIA
1606 1137        TAD      CHKSAV
1607 7650        SNA CLA
1610 5600        JMP I   DTCHK
1611 7340        CLA CLL CMA
1612 3441        WRDCHK, DCA I   XERRO
1613 1121        TAD      CMREG
/
AND      K0100
SZA CLA
TAD      K0200
TAD      K7400
DCA      TRASH2

```

```

/SPACE OUT 1
/MORE TO PRINT

```

```

/GET CRC FLAG
/WAS IT SET?
/YES, THEN WORD BY WORD CHECK!!!
/GET CHECK SUM FOUND
/COMPARE TO GOOD VALUE SAVED
/WERE THEY THE SAME
/YES, DATA O.K.
/SETUP CHECKSUM ERROR FLAG
/HALF BLOCK SET??
/YES!

```

```

1621 1111 TAD TRASH2
1622 7040 CMA
1623 3315 DCA MSKER
1624 7340 CLA CLL CMA
1625 3140 DCA FND SUM
1626 4435 RESRAN
1627 1126 TAD FWREG
1630 4427 SETFLD
1631 3246 DCA GOCDF
1632 1111 TAD TRASH2
1633 3362 DCA RSRAN
1634 1122 TAD INTDA
1635 3354 DCA STGEN
1636 1362 DTR1, TAD RSRAN
1637 0315 AND MSKER
1640 3130 DCA WAREG
1641 1354 TAD STGEN
1642 0060 AND K0017
1643 3127 DCA ASREG
1644 4421 RANDAT
1645 3132 DCA DGREG
1646 7402 GOCDF, HLT/CDP
1647 1411 TAD I AUTO11
1650 6201 CDF 0
1651 3133 DCA DBREG
1652 1011 TAD AUTO11
1653 3131 DCA ADREG
1654 1133 TAD DBREG
1655 7041 CIA
1656 1132 TAD DGREG
1657 7650 SNA CLA
1660 5272 JMP NOERR
1661 2140 ISZ FND SUM
1662 5311 JMP NTRKS
1663 1154 TAD CMCFLG
1664 7650 SNA CLA
1665 1136 TAD DATTRY
1666 2200 ISZ DTCHK
1667 4441 ERROR
1670 0005 0005
1671 7760 7760
1672 2362 NOERR, ISZ RSRAN
1673 5300 JMP .+5
1674 2354 ISZ STGEN
1675 7000 NOP
1676 1111 TAD TRASH2
1677 3362 DCA RSRAN
1678 2116 ISZ BUFTAL
1679 5236 JMP DTR1
1680 1441 TAD I XERRO
1681 7650 SNA CLA
1682 3153 DCA CRCCNT
1683 2441 ISZ I XERRO
1684 5600 JMP I DTCHK
1685 7402 BADHLT, HLT

```

/SET FIRST TIME FLAG
/NO, SETUP RANDOM GENERATOR
/GET FINAL WC
/GET AUTO11 + BUFTAL + FIELD
/SAVE FIELD CDF

/GENERATE DATA
/SAVE GOOD DATA POINTER
/CDF TO BUFFER FIELD
/GET BAD DATA WORD
/HOME DF
/SAVE BAD WORD
/GET ADDRESS
/SAVE FOR PRINTER
/GET DATA READ

/COMPARE TO GOOD VALUE
/WERE THEY THE SAME
/YES, NO ERROR
/FIRST TIME PRINT???
/NO, JUST ADDRESS AND DATA
/GET CRC FLAG
/IF SET NO NON-RECOVERABLE.
/NO, GET NON-RECOVERABLE FLAG.
/UPDATE FOR ERROR RETURN
/ERROR DATA
/POINTER
/POINTER

/UPDATE BUFFER TALLY
/MORE WORDS TO CHECK
/GET ERROR INDICATOR1
/WAS THERE AN ERROR?
/NO, CLEAR CRC COUNTER
/CHECK FOR COMPUTER ERROR?
/ALL O.K.
/COMPUTER MUST BE DOWN, CHECKSUM

```

1710 5307 JMP .-1
1711 4441 NTRKS, ERROR
1712 0000 0000
1713 0000 0000
1714 5272 JMP NOERR
1715 0000 /
MSKER, 0
/
/ROUTINE TO GENERATE RANDOM NUMBERS
/
RANDOM, 0
1716 0000 CLA CLL IAC
1717 7301 TAD RAD1
1720 1374 TAD RAD2
1721 1375 TAD RAD3
1722 1376 DCA RAD1
1723 3374 RAL
1724 7004 TAD RAD1
1725 1374 TAD RAD2
1726 1375 TAD RAD3
1727 1376 DCA RAD2
1730 3375 RAL
1731 7004 TAD RAD1
1732 1374 TAD RAD2
1733 1375 TAD RAD3
1734 1376 DCA RAD3
1735 3376 TAD RAD3
1736 1376 JMP I RANDOM
1737 5716 /EXIT, RANDOM NUMBER IN AC
/
/GENERATOR FOR RANDOM DATA
/
GNDAT, 0
1740 0000 CLA CLL IAC
1741 7301 TAD RAN1
1742 1370 TAD RAN2
1743 1371 CLL RTL
1744 7106 DCA RAN1
1745 3370 TAD RAN2
1746 1371 TAD RAN2
1747 7012 RTR
1750 1370 TAD RAN1
1751 3371 DCA RAN2
1752 1371 TAD RAN2
1753 5740 JMP I GNDAT
/
/ROUTINE TO SAVE RANDOM GENERATOR
/
STGEN, 0
1754 0000 TAD RAN1
1755 1370 DCA SAV1
1756 3372 TAD RAN2
1757 1371 DCA SAV2
1760 3373 JMP I STGEN
1761 5754 /
/ROUTINE TO RESET RANDOM GENERATOR
/

```

/FAILED WORD-BY-WORD COMPARE WORKED.
/OTHER ERRORS IN BUFFER

/CHECK REST OF BUFFER

```

/ PAL10 V142A 19-MAR-75 15:21 PAGE 1-22

1762 0000 RSRAN, 0
1763 1372 TAD SAV1
1764 3370 DCA RAN1
1765 1373 TAD SAV2
1766 3371 DCA RAN2
1767 5762 JMP I RSRAN

/
1770 1234 RAN1, 1234
1771 5670 RAN2, 5670

/
1772 0000 SAV1, 0
1773 0000 SAV2, 0
1774 1234 RAD1, 1234
1775 5670 RAD2, 5670
1776 4321 RAD3, 4321

/
/
2000 PAGE
/
/ROUTINE TO SEND A DRIVE TO A RANDOM TRACK
/AND SAVE THE TRACK
/
2000 0000 SEKOUT, 0
2001 0055 AND K0006 /MASK DRIVE NUMBER
2002 3302 DCA WAIT /SAVE POINTER
2003 7604 STRSTP, LAS
2004 0016 AND K0200 /MASK
2005 7640 SZA CLA /PROGRAM STOP????
2006 7402 STPHLT, HLT /PROGRAM STOP ON SWITCH 4
2007 1302 RESEK, TAD WAIT
2008 7110 CLL RAR
2009 1151 TAD DSKPOT /GET ADDRESS SAVE POINTER
2010 3322 DCA CHKYN /SAVE MADE POINTER
2011 1777 TAD TRKFLG /GET TRACK FLAG
2012 7650 SNA CLA /WAS IT SET??
2013 5222 JMP ,+5 /NO, USE OTHER
2014 1160 TAD SPTRK2 /GET OPERATOR TRACK
2015 0075 AND K7760 /MASK
2016 1157 TAD SPTRK1 /GET OPERATOR TRACK
2017 5253 JMP DSKOUT =2 /DO IT
2018 1776 TAD SEQFLG /GET SEQUENCE FLAG
2019 7650 SNA CLA /WAS IT SET??
2020 5232 JMP ,+6 /NO, USE RANDOM
2021 1722 TAD I CHKYN /GET LAST USED
2022 1013 TAD K0020 /UPDATE
2023 7430 SZL /LINK SET?
2024 7001 IAC /YES, SET EXTENDED BIT
2025 7410 SKP /UPDATE AND CHECK BOUNDARIES
2026 4433 RANGEN /GENERATE RANDOM ADDRESS
2027 0076 AND K7761 /MASK OFF
2028 1302 TAD WAIT /ADD IN DRIVE NUMBER
2029 3722 DCA I CHKYN /SAVE MADE ADDRESS
2030 1722 TAD I CHKYN
2031 7110 CLL RAR
2032 7620 SNL CLA /WAS IT SET

```

```

/ PAL10 V142A 19-MAR-75 15:21 PAGE 1-23

2041 5255 JMP DSKOUT /NO, DON'T CHECK LIMITS
2042 1143 TAD MAXTRK /ADD IN FUDGE FACTOR
2043 1722 TAD I CHKYN /GET ADDRESS FOUND
2044 7630 SZL CLA /IN LIMITS?
2045 5255 JMP DSKOUT /YES, O.K.
2046 1776 TAD SEQFLG /GET SEQUENCE FLAG
2047 7640 SZA CLA /WAS IT SET????
2048 5253 JMP DSKOUT =2 /DO
2049 1722 TAD I CHKYN /NO
2050 0075 AND K7760 /MASK
2051 1302 TAD WAIT /ADD IN DRIVE NUMBER
2052 3722 DCA I CHKYN /SAVE IT NOW
2053 1722 TAD I CHKYN /GET ADDRESS
2054 0056 DSKOUT, AND K0007 /MASK DRIVE NUMBER + EXTENDED
2055 1317 TAD K3000 /FUNCTION SEEK ONLY
2056 4444 LDCMD /LOAD COMMAND
2057 1722 TAD I CHKYN /GET ADDRESS
2058 0075 AND K7760
2059 4446 LDADD /LOAD DISK ADDRESS + GO
2060 4443 DSKSKP /WAIT FOR DONE FLAG
2061 5264 JMP ,+1
2062 4442 RDSTAT /READ STATUS
2063 7500 SNA /DONE FLAG SET????
2064 5274 JMP SEKER /SEEK ERROR, NO DONE FLAG
2065 0073 AND K1777 /MASK OTHER ERROR BITS
2066 7650 SNA CLA /ANY SET????
2067 5300 JMP SEKEX /NO, EXIT
2068 4441 SEKER, ERROR /PRINT ERROR
2069 0003 0003 /HEADER POINTER
2070 7200 7200 /MESSAGE POINTER
2071 2200 ISZ /UPDATE FOR RETURN
2072 4447 SEKEX, CLRALL /CLEAR STATUS
2073 5600 JMP I SEKOUT

/
/ROUTINE TO WAIT FOR KEY FROM OPERATOR
/
2102 0000 WAIT, 0
2103 7300 CLA CLL
2104 6032 KCC
2105 6031 NSF
2106 5305 JMP ,+1
2107 6036 KRB
2108 0320 AND K177
2109 1321 TAD K200
2110 6046 TLS
2111 6041 TSF
2112 5313 JMP ,+1
2113 6042 TCF
2114 5702 JMP I WAIT /EXIT

2117 3000 K3000, 3000
2118 0177 K177, 0177
2119 0200 K200, 0200

/
/ROUTINE TO CHECK FOR YES OR NO

```

```

2122 0000      /CHKYN, 0
2123 3302      DCA    WAIT      /SAVE POINTER
2124 1322      TAD    CHKYN     /GET PC STORED
2125 3343      DCA    CHKPOT    /SAVE IT
2126 1302      TAD    WAIT
2127 2322      ISZ    CHKYN
2130 7041      CIA
2131 1063      TAD    K0316
2132 7650      SNA CLA      /WAS IT A NO
2133 5722      JMP I  CHKYN    /YES
2134 1302      TAD    WAIT
2135 2322      ISZ    CHKYN
2136 7041      CIA
2137 1064      TAD    K0331
2140 7650      SNA CLA      /WAS IT A YES
2141 5722      JMP I  CHKYN    /YES
2142 5743      JMP I  CHKPOT    /WAS NEITHER

```

```

/ROUTINE TO CHECK DISK RUN POINTERS
/

```

```

2143 0000      /CHKPOT, 0
2144 0054      AND     K0003
2145 1152      TAD     RUNPOT
2146 3302      DCA     WAIT      /GET RUN POINTER
2147 1702      TAD I  WAIT      /RUN THIS DRIVE
2150 7640      SZA CLA      /NO
2151 2343      ISZ     CHKPOT    /EXIT
2152 5743      JMP I  CHKPOT

```

```

/ROUTINE TO RESET REGISTERS FOR ERROR PRINTER
/

```

```

2153 0000      /SETREG, 0
2154 1070      TAD     K4000      /GET STATUS
2155 3120      DCA     STREG      /SAVE FOR ERROR PRINTER
2156 7340      CLA CLL CMA      /DECREASE BY 1
2157 1110      TAD     TRASH1     /GET SECTOR POINTER
2160 0060      AND     K0017
2161 1111      TAD     TRASH2     /ADD IN ADDRESS
2162 3123      DCA     DAREG      /SAVE FOR ERROR PRINTER
2163 1167      TAD     FIRTIM     /CHECK IF FIRST SECTOR?
2164 7640      SZA CLA      /IF SO, DON'T UPDATE COMMAND
2165 5753      JMP I  SETREG      /NO, DON'T!
2166 1173      TAD     SAVCM      /GET COMMAND REG.
2167 3121      DCA     CMREG      /SAVE FOR ERROR PRINTER
2170 5753      JMP I  SETREG      /RETURN

```

```

2176 3545
2177 3542
2200 2200

```

```

PAGE
/

```

```

/ROUTINE TO WRITE OR READ SECTORS SELECTED
/

```

```

2200 0000      /DSKGO, 0
2201 7340      CLA CLL CMA

```

```

2202 3167      DCA     FIRTIM     /SETUP FIRST TIME POINTER
2203 3154      DCA     CRCFLG     /CLEAR CRC FLAG
2204 1124      TAD     CAREG      /GET INITIAL CURRENT ADDRESS
2205 4445      LDCUR      /LOAD CURRENT ADDRESS
2206 1125      TAD     WCREG
2207 3126      DCA     FWREG      /SETUP FINAL WC
2210 1122      TAD     INTDA      /GET INITIAL STARTING SECTOR
2211 3110      DCA     TRASH1     /SAVE
2212 1122      TAD     INTDA      /GET DISK ADDRESS
2213 0075      AND     K7760      /MASK
2214 3111      DCA     TRASH2     /SAVE
2215 1134      TAD     INTCM      /GET INITIAL COMMAND
2216 1500      TAD I  DSKGO      /GET READ OR WRITE
2217 4444      LDCMD      /LOAD COMMAND
2220 1121      TAD     CMREG
2221 1072      TAD     K1000      /MAKE READ ALL OR WRITE ALL
2222 3173      DCA     SAVCM      /SAVE FOR SWITCH TO CONSECUTIVE MODE
2223 1110      TAD     TRASH1     /SECTOR TO DO
2224 0060      AND     K0017      /MASK
2225 1111      TAD     TRASH2     /ADD TO TRACK
2226 4446      LDADD      /LOAD AND GO
2227 6001      ION          /TURN INTERRUPT ON

```

```

/ROUTINE TO CLEAR OR CHECK SUM BUFFER ON THE FLY!
/

```

```

2230 3777      /GOBAK, DCA    TIMER2      /CLEAR LONG TIMER
2231 3140      DCA     FNDSUM     /CLEAR SUM CHECK
2232 4427      SETFLD      /GET FIELD TO BUFFER
2233 3254      DCA     CHNCDF     /SAVE CDF
2234 1167      TAD     FIRTIM
2235 7650      SNA CLA      /TIME TO GO
2236 5241      JMP     STRWRK      /YES!!!!
2237 4776      JMS     TIME       /WAIT FOR FIRST INTERRUPT
2240 5234      JMP     .-4        /NOT HERE YET
2241 1116      STRWRK, TAD     BUFTAL
2242 7041      CIA
2243 1126      TAD     FWREG      /COMPARE TO SOFTWARE FINAL
2244 7450      SNA          /WAIT FOR DISK????
2245 5274      JMP     WRKDON      /YES!!!!
2246 7041      CIA
2247 3174      DCA     CLRBK      /SAVE DIFFERENCE
2250 1174      TAD     CLRBK
2251 7041      CIA
2252 1116      TAD     BUFTAL
2253 3116      DCA     BUFTAL
2254 7402      CHNCDF, HLT
2255 1121      TAD     CMREG      /UPDATE BUFFER TALLY
2256 7700      SNA CLA      /CDF TO BUFFER FIELD
2257 5264      JMP     WASRD      /READ OR WRITE
2260 3411      GOCLR, DCA I  WASRD    /WAS A READ!!
2261 2174      ISZ     CLRBK      /WAS A WRITE, CLEAR BUFFER
2262 5260      JMP     GOCLR      /UPDATE TALLY
2263 5274      JMP     WRKDON      /MORE TO CLEAR
2264 1140      WASRD, TAD     FNDSUM  /DONE WITH SOME
2265 7100      GOCHK, CLL

```

```

/ PAL10 V142A 19-MAR-75 15:21 PAGE 1-26

2266 1411 TAD I AUTO11 /GET WORD
2267 7430 SZL
2270 7001 IAC
2271 2174 ISZ CLRAK /UPDATE CLEAR POINTER
2272 5265 JMP GOCHK /MORE TO CHECKSUM
2273 3140 DCA FND SUM /SAVE IT
2274 6201 WRKDON, CDF 0
2275 1116 TAD BUFTAL
2276 7650 SNA CLA /LAST WORD DONE????
2277 5302 JMP DSKEK /EXIT
2300 4776 JMS TIME /TIME AND WAIT
2301 5241 JMP STRWRK /WAIT FOR INT. OR DONE!!!!
2302 2200 DSKEK, ISZ DSKGO
2303 5600 JMP I DSKGO /EXIT

/
/ INTERRUPT SERVICE
/
2304 6741 RETURN, DSKP /DISK SKIP IOT
2305 5353 JMP NODSKP /NOT THE DISK
2306 2110 ISZ TRASH1 /UPDATE SECTOR NUMBER
2307 7000 NOP /IT WON'T WORK WITHOUT IT!
2310 1113 TAD UPDATE
2311 1126 TAD FWREG /UPDATE WORD COUNT
2312 3126 DCA FWREG
2313 6745 STATUS, DRST /READ STATUS
2314 1070 TAD K4000
2315 7440 SZA /ONLY DONE FLAG?
2316 5337 JMP STATER /STATUS ERROR
2317 1126 TAD FWREG
2320 7650 SNA CLA /LAST TRANSFER?
2321 5366 JMP TRDONE /TRANSFER IS DONE
2322 3167 DCA FIRTIM /CLEAR FIRST TIME POINTER!
2323 1173 TAD SAVCM /GET READ OR WRITE COMMAND
2324 6746 RDLWRL, DLDC /LOAD COMMAND REGISTER
2325 1110 TAD TRASH1 /GET SECTOR TO DO
2326 0000 AND K0017 /MASK OFF
2327 1111 TAD TRASH2 /ADD IN TRACK
2330 6743 LODGO, DLAG /LOAD DISK ANFD GO
2331 1166 RETRN, TAD SVLNK /GET LINK
2332 7110 CLL RAR
2333 1165 TAD SAVAC /GET AC
2334 6244 RMF /RESTORE FIELDS
2335 6001 ION /TURN INTERRUPT ON
2336 5400 JMP I 0 /EXIT
2337 4775 STATER, JMS SETREG /SETUP REGISTERS!
2340 1121 TAD CMREG
2341 7710 SPA CLA /WRITE OR READ
2342 7001 IAC /WRITE
2343 7001 IAC
2344 3347 DCA ,+3 /MODIFY HEADER POINTER
2345 1135 TAD STATRY /GET TRY POINTER
2346 4441 ERROR /PRINT MESSAGE
2347 0000 0000 /MODIFIED HEADER POINTER
2350 7760 7760 /MESSAGE POINTER
2351 2200 ISZ DSKGO /UPDATE FOR ERROR

```

```

/ PAL10 V142A 19-MAR-75 15:21 PAGE 1-27

2352 5302 JMP DSKEK /EXIT
2353 6031 NODSKP, KSF /CHECK READER FLAG
2354 7610 SKP CLA /NOT READER
2355 5362 JMP KEYRET /WAS THE READER
2356 6041 TSF /CHECK PUNCH FLAG
2357 7402 INTER2, HLT /UNDEFINED INTERRUPT
2360 6042 TCF /WAS THE PUNCH, CLEAR FLAG
2361 5331 JMP RETRN /RETURN
2362 6034 KEYRET, KRS /GET INPUT
2363 6046 TLS /PRINT
2364 6032 KCC /CLEAR READER FLAG
2365 5331 JMP RETRN /RETURN TO DISK ROUTINE
2366 4775 TRDONE, JMS SETREG /SETUP REGISTERS!
2367 3167 DCA FIRTIM /CLEAR FIRST TIME POINTER!
2370 1166 TAD SVLNK
2371 7110 CLL RAR /REPLACE LINK
2372 1165 TAD SAVAC /REPLACE AC
2373 6244 RMF /RESTORE MEMORY FIELDS + FLAGS
2374 5400 JMP I 0 /RETURN TO BACK GROUND

/
2375 2153
2376 3121
2377 3131
2400 PAGE
/
/ ROUTINE TO GET ONE IN OCTAL
/
2400 0000 OCT1, 0
2401 4437 RECEIV /RECEIVE
2402 3365 DCA ISAVE1 /SAVE IT
2403 1600 TAD I OCT1 /GET LIMITS
2404 0056 AND K0007 /MASK
2405 1061 TAD K0260
2406 7141 CLL CIA
2407 1365 TAD ISAVE1 /GET INPUT
2410 7620 SNL CLA /IN LIMITS????
2411 5226 JMP INERR /NO, ERROR EXIT
2412 1600 TAD I OCT1 /GET LIMITS
2413 0014 AND K0070 /MASK
2414 7110 CLL RAR
2415 7012 RTR
2416 1061 TAD K0260
2417 7040 CMA
2420 1365 TAD ISAVE1 /GET INPUT
2421 7630 SZL CLA /IN LIMITS????
2422 5226 JMP INERR /NO, ERROR
2423 1365 TAD ISAVE1 /GET INPUT
2424 0056 AND K0007 /MASK
2425 2200 ISZ OCT1
2426 2200 INERR, ISZ OCT1
2427 5600 JMP I OCT1 /GOOD EXIT

/
/ ROUTINE TO RECEIVE FOUR OCTAL
/
2430 0000 OCT4, 0

```

```

2431 1106 TAD M4
2432 3366 DCA ISAVE2 /SETUP COUNTER
2433 3367 DCA ISAVE3 /START WITH 0
2434 4424 ONEIN /RECEIVE ONE OCTAL
2435 0070 0070 /LIMITS
2436 5630 JMP I OCT4 /ERROR EXIT
2437 1367 TAD ISAVE3 /GET LAST
2440 2366 ISZ ISAVE2 /UPDATE COUNTER
2441 7410 SKP
2442 5246 JMP ,+4 /EXIT
2443 7004 RAL
2444 7006 RTL
2445 5233 JMP OCT4 +3
2446 2230 ISZ OCT4
2447 5630 JMP I OCT4 /EXIT OCTAL IN AC

/ROUTINE TO UPDATE AND CHECK FOR PASS COMPLETE
/
2450 0000 CKTIM, 0
2451 1121 TAD CMREG /GET CURRENT DRIVE NUMBER
2452 0055 AND K0006 /MASK
2453 7110 CLL RAR
2454 3366 DCA ISAVE2 /POINTER
2455 1366 TAD ISAVE2
2456 1147 TAD TIMPOT /GET TIME POINTER
2457 3365 DCA ISAVE1 /SAVE IT
2460 7301 CLA CLL IAC /ONE FOR 0
2461 1145 TAD CONSEC /GET AMOUNT DONE
2462 1765 TAD I ISAVE1 /ADD IN AMOUNT COMPLETED SO FAR
2463 3765 DCA I ISAVE1 /SAVE IT
2464 7620 SNL CLA /LINK UP???
2465 5650 JMP I CKTIM /NO, EXIT
2466 4433 RANGEN /GET RANDOM NUMBER
2467 3777 DCA RAN1 /RE-PRIME GENERATOR
2470 4433 RANGEN /GET RANDOM NUMBER
2471 3776 DCA RAN2 /RE-PRIME GENERATOR
2472 7100 CLL
2473 1365 TAD ISAVE1
2474 1370 TAD K0004
2475 3365 DCA ISAVE1 /SECOND TIME POINTER
2476 2765 ISZ I ISAVE1 /UPDATE IT
2477 1765 TAD I ISAVE1 /GET COUNT
2500 1142 TAD MAXTIM /ADD IN FUDGE FACTOR
2501 7620 SNL CLA /PASS COMPLETE???
2502 5650 JMP I CKTIM /NO, EXIT
2503 3765 DCA I ISAVE1 /ZERO SECOND COUNTER
2504 1366 TAD ISAVE2
2505 7040 CMA
2506 3366 DCA ISAVE2 /SETUP COUNTER
2507 1364 TAD CMPPOT /ADD IN POINTER
2510 1054 TAD K0003
2511 2366 ISZ ISAVE2 /COMPUTE BUFFER
2512 5310 JMP ,+2
2513 3366 DCA ISAVE2 /SAVE ADDRESS POINTER
2514 7340 CLA CLL CMA

```

```

2515 2766 ISZ I ISAVE2 /UPDATE PASS COMPLETE POINTER
2516 7610 SKP CLA
2517 3766 DCA I ISAVE2 /HOLD AT 7777
2520 4452 CRLF
2521 4450 PRNTER /PRINT "DISK"
2522 3502 MES17
2523 1121 TAD CMREG /GET LAST COMMAND
2524 0055 AND K0006 /MASK
2525 7110 CLL RAR
2526 1061 TAD K0260
2527 4440 TYPE /TYPE DISK NO.
2530 7340 CLA CLL CMA
2531 4450 PRNTER /PRINT "PASS COMPLETE"
2532 3505 MES18
2533 7604 LAS
2534 0015 AND K0100 /MASK
2535 7650 SNA CLA /PASS COMPLETE DISCONNECT???
2536 5341 JMP ,+3 /NO WAY!!!!
2537 4422 DISCON /DUMP DRIVE
2540 5775 JMP RUN /MORE TO TEST!!!!
2541 4774 JMS TPSTA /STATUS-COMplete TYPEOUT
2542 5650 JMP I CKTIM /EXIT

/SUBROUTINE TO READ STATUS REGISTER
/
2543 0000 RDST, 0
2544 6745 IOT5, DRST /READ STATUS IOT
2545 7410 SKP
2546 7402 ERHLTS, HLT /SKIP TRAP
2547 3120 DCA STREG /SAVE RESULTS
2550 1120 TAD STREG
2551 5743 JMP I RDST /EXIT

/SUBROUTINE TO LOAD CURRENT ADDRESS REGISTER
/
2552 0000 LDCA, 0
2553 6744 IOT4, DLCA /LOAD CURRENT ADDRESS IOT
2554 5752 JMP I LDCA /EXIT

2555 7402 ERHLT4, HLT /SKIP TRAP

/SUBROUTINE TO LOAD TRACK ADDRESS REGISTER
/
2556 0000 LDAD, 0
2557 3123 DCA DAREG
2560 1123 TAD DAREG
2561 6743 IOT3, DLAG /LOAD DISK ADDRESS REGISTER
2562 5756 JMP I LDAD /EXIT
2563 7402 ERHLT3, HLT /SKIP TRAP

/
2564 3524 CMPPOT, DUCMP -3
2565 0000 ISAVE1, 0
2566 0000 ISAVE2, 0
2567 0000 ISAVE3, 0
2570 0004 K0004, 0004

```

```

2574 3000
2575 0600
2576 1771
2577 1770
2600 2600

PAGE
/ROUTINE TO GET RANDOM OR OPERATOR DATA
/
2600 0000 RNWRD, 0
2601 7402 SWDAT, HLT /MODIFIED SWITCH
2602 5600 JMP I RNWRD /EXIT
2603 6201 CDF 0 /HOME CDF
2604 1412 TAD I AUTO12 /GET DATA
2605 7402 RECD, HLT /BUFFER CDF
2606 2115 ISZ OPRTAL /UPDATE TALLY
2607 5600 JMP I RNWRD /EXIT
2610 3220 DCA PRINT /SAVE WORD
2611 1105 TAD M12
2612 3115 DCA OPRTAL /REPLACE TALLY
2613 7340 CLA CLL CMA
2614 1146 TAD DATPOT
2615 3012 DCA AUTO12 /REPLACE AUTO INDEX
2616 1220 TAD PRINT /GET SAVED WORD
2617 5600 JMP I RNWRD /EXIT

/ROUTINE TO TYPE
/
2620 0000 PRINT, 0
2621 6046 TLS
2622 6041 TSF
2623 5222 JMP .-1
2624 6042 TCF
2625 7200 CLA
2626 5620 JMP I PRINT

/ROUTINE TO DUMP AND REPORT DISK STATUS
/
2627 0000 DUMP, 0
2630 4450 PRINTER /PRINT "DISK "
2631 3502 MES17
2632 1121 TAD CMREG /GET LAST COMMAND
2633 0055 AND K0006
2634 7110 CLL RAR
2635 3200 DCA RNWRD /SAVE
2636 1200 TAD RNWRD /GET DISK NUMBER
2637 1061 TAD K0260
2640 4440 TYPE /TYPE DISK NUMBER
2641 7340 CLA CLL CMA
2642 4450 PRINTER /PRINT "DISCONNECTED!"
2643 3450 MES15
2644 4777 JMS TPSTA /TYPE STATUS REPORT
2645 1200 TAD RNWRD
2646 1152 TAD RUNPOT
2647 3200 DCA RNWRD /SAVE POINTER ADDRESS

```

```

2650 3600 DCA I RNWRD /CLEAR RUN POINTER
2651 3200 DCA RNWRD
2652 1106 TAD M4
2653 3220 DCA PRINT /CHECK FOR MORE POINTER
2654 1200 TAD RNWRD
2655 4430 SELCHK /CHECK SELECT POINTERS
2656 7610 SKP CLA /DISK NOT HERE
2657 5627 JMP I DUMP /MORE AVAILABLE
2660 2200 ISZ RNWRD
2661 2220 ISZ PRINT /UPDATE POINTERS
2662 5254 JMP .-6
2663 4452 CRLF
2664 4450 PRINTER /PRINT "DISK"
2665 3502 MES17
2666 7340 CLA CLL CMA
2667 4450 PRINTER /PRINT "SYSTEM DOWN"
2670 3460 MES16
2671 7402 NODSKS, HLT /ERROR, NO DISK AVAILABLE
2672 5271 JMP .-1

/ROUTINE TO SETUP FIELD TO BUFFER + AUTO11 + BUFFER TALLY
/
2673 0000 STFLD, 0
2674 7041 CIA
2675 1125 TAD WCREG
2676 3116 DCA BUFTAL
2677 7340 CLA CLL CMA
2700 1124 TAD CAREG /GET INITIAL CA
2701 3011 DCA AUTO11 /SAVE
2702 1155 TAD DATFLG /GET DATA FLAG
2703 7650 SNA CLA /WAS IT SET???
2704 5312 JMP .+6 /NO, USE REGULAR
2705 1105 TAD M12
2706 3115 DCA OPRTAL /SETUP SPECIAL TALLY
2707 7340 CLA CLL CMA
2710 1146 TAD DATPOT
2711 3012 DCA AUTO12 /SETUP SPECIAL AUTO INDEX
2712 1134 TAD INTCM /GET LAST COMMAND
2713 0014 AND K0070 /MASK FIELD BITS
2714 1103 TAD KCDF /MAKE BUFFER CDF
2715 3205 DCA RECD, /SETUP SPECIAL CDF
2716 1205 TAD RECD, /GET BACK CDF
2717 5673 JMP I STFLD /EXIT, FIELD IN AC

/SUBROUTINE TO ISSUE "DSKP" DISK SKIP IOT
/
2720 0000 SDKP, 0
2721 6741 IOT1, DSKP /DISK SKIP IOT
2722 7410 SKP /DID NOT SKIP
2723 2320 ISZ SDKP
2724 5720 JMP I SDKP /EXIT

/SUBROUTINE TO LOAD COMMAND REGISTER
/
2725 0000 LDCM, 0

```



```

2726 3121      DCA  CMREG
2727 1121      TAD  CMREG
2730 6746      IOT6, DLDC
2731 5725      JMP I  LDCM
2732 7402      ERHLT6, HLT
/
/ROUTINE TO CHANGE DEVICE IOT CODES
/
2733 7604      CHANG, LAS
2734 0355      AND  A0770
2735 3325      DCA  LDCM
2736 1360      TAD  CHNPOT
2737 3110      DCA  TRASH1
2740 1357      TAD  CCNTR1
2741 3111      DCA  TRASH2
2742 1510      CHANGR, TAD I TRASH1
2743 3112      DCA  TRASH3
2744 1512      TAD I TRASH3
2745 0356      AND  A7007
2746 1325      TAD  LDCM
2747 3512      DCA I TRASH3
2750 2110      ISZ  TRASH1
2751 2111      ISZ  TRASH2
2752 5342      JMP  CHANGR
2753 7402      CHNHLT, HLT
2754 5353      JMP  .-1
/
2755 0770      A0770, 0770
2756 7007      A7007, 7007
2757 7766      CCNTR1, 7766
/
2760 2761      CHNPOT, CHNPOT +1
2761 2304      RETURN
2762 2313      STATUS
2763 2324      ROLWRL
2764 2330      LODGO
2765 2721      IOT1
2766 1406      IOT2
2767 2561      IOT3
2770 2553      IOT4
2771 2544      IOT5
2772 2730      IOT6
/
2777 3000      PAGE
3000 3000      /
/ROUTINE TO TYPE STATUS REPORT
/
3000 0000      TPSTA, 0
3001 4450      PRNTR
3002 3370      MES7
3003 1106      TAD  M4
3004 3242      DCA  TSAVE1
3005 3243      DCA  TSAVE2
3006 3244      DCA  TSAVE3
/PRINT "DSK HARD SOFT COMP"
/MAXIMUM TO DO
/CLEAR SOME COUNTERS

```

```

3007 1243      CHKRES, TAD  TSAVE2
3010 1054      TAD  K0003
3011 3243      DCA  TSAVE2
3012 1243      TAD  TSAVE2
3013 1150      TAD  STAPOT
3014 3246      DCA  TSAVE5
3015 1244      TAD  TSAVE3
3016 4430      SELCHK
3017 5236      JMP  NOTSTA
3020 4452      CRLF
3021 4423      SPACE
3022 1244      TAD  TSAVE3
3023 1061      TAD  K0260
3024 4440      TYPE
3025 4423      SPACE
3026 4423      SPACE
3027 7346      CLA CLL CMA RTL
3030 3245      DCA  TSAVE4
3031 1646      TAD I TSAVE5
3032 4451      OCTEL
3033 2246      ISZ  TSAVE5
3034 2245      ISZ  TSAVE4
3035 5231      JMP  .-4
3036 2244      NOTSTA, ISZ  TSAVE3
3037 2242      ISZ  TSAVE1
3040 5207      JMP  CHKRES
3041 5600      JMP I TPSTA
/UPDATE DRIVE NUMBER
/MORE TO REPORT
/EXIT
/
3042 0000      TSAVE1, 0
3043 0000      TSAVE2, 0
3044 0000      TSAVE3, 0
3045 0000      TSAVE4, 0
3046 0000      TSAVE5, 0
/
/ROUTINE TO RECALIBRATE SELECTED DRIVE
/DISCONNECT DRIVE ON ERROR!
/
3047 0000      RESTOR, 0
3050 0055      AND  K0006
3051 3200      DCA  TPSTA
3052 1074      TAD  K7700
3053 3331      DCA  TIMER2
3054 2330      ISZ  TIMER1
3055 5254      JMP  .-1
3056 2331      ISZ  TIMER2
3057 5254      JMP  .-3
3060 1200      TAD  TPSTA
3061 4444      LDCMD
3062 7326      CLA CLL CML RTL
3063 4447      CLRALL
3064 4443      DSKSKP
3065 5264      JMP  .-1
3066 4442      RDSTAT
3067 7500      SMA
3070 5306      JMP  RESERR
/SAVE DRIVE NUMBER
/SETUP COUNTER
/WAIT FOR DISK TO COOL OFF!
/CURRENT DRIVE
/LOAD COMMAND
/ENABLE RECALIBRATE BIT
/"RECALIBRATE"
/DISK SKIP IOT
/WAIT FOR FIRST DONE FLAG
/READ STATUS
/DONE FLAG SET???
/NO, ERROR

```

```

3071 0073      AND      K1777      /MASK OTHER ERROR BITS
3072 7640      SZA CLA      /ANY SET???
3073 5306      JMP      RESERR      /YES, ERROR
3074 4447      RESTA, CLRALL      /CLEAR STATUS
3075 1016      TAD      K0200      /ENABLE SET SECOND DONE FLAG
3076 1200      TAD      TPSTA      /ORIGINAL COMMAND
3077 4444      LDCMD      /LOAD COMMAND
3100 4443      DSKSKP      /DISK SKIP IOT
3101 5300      JMP      ,=1      /WAIT FOR SECOND DONE
3102 4442      RDSTAT      /READ STATUS
3103 1070      TAD      K4000
3104 7650      SNA CLA      /WAS IT ONLY DONE FLAG
3105 5647      JMP I      RESTOR      /YES, RETURN
3106 7300      RESERR, CLA CLL
3107 4441      ERROR      /ERROR
3110 0004      0004
3111 7200      7200
3112 4452      CRLF
3113 4452      CRLF
3114 4450      PRNTER      /PRINT"RECALIBRATE ERROR DISCONNECT"
3115 3164      MES19
3116 4422      DISCON      /DISCONNECT DISK
3117 2247      ISZ      RESTOR
3120 5647      JMP I      RESTOR      /MORE DISK AVAILABLE

/
/ROUTINE TO TIME AND WAIT
/
3121 0000      TIME, 0
3122 2330      ISZ      TIMER1
3123 5721      JMP I      TIME      /EXIT
3124 2331      ISZ      TIMER2
3125 5721      JMP I      TIME      /EXIT
3126 7402      INTER1, HLT      /NO INTERRUPT OCCURRED, I GUESS!
3127 5326      JMP      ,=1

/
3130 0000      TIMER1, 0
3131 0000      TIMER2, 0

/
/ROUTINE TO TYPE OUT DATA INFORMATION
/
3132 0000      TYPDAT, 0
3133 4450      PRNTER      /PRINT "AS:"
3134 3223      TEXAS
3135 1127      TAD      ASREG
3136 4451      OCTEL
3137 7340      CLA CLL CMA
3140 4450      PRNTER      /PRINT "WA:"
3141 3225      TEXWA
3142 1130      TAD      WAREG
3143 4451      OCTEL
3144 7340      CLA CLL CMA
3145 4450      PRNTER      /PRINT "AD:"
3146 3227      TEXAD
3147 1131      TAD      ADREG
3150 4451      OCTEL

```

```

3151 7340      CLA CLL CMA
3152 4450      PRNTER      /PRINT "DG:"
3153 3231      TEXDG
3154 1132      TAD      DGREG
3155 4451      OCTEL
3156 7340      CLA CLL CMA
3157 4450      PRNTER      /PRINT "DB:"
3160 3233      TEXDB
3161 1133      TAD      DBREG
3162 4451      OCTEL
3163 5732      JMP I      TYPDAT

/
3164 2205      MES19, TEXT      "RECALIBRATE ERROR DISCONNECT!"
3165 0301
3166 1411
3167 0222
3170 0124
3171 0540
3172 0522
3173 2217
3174 2240
3175 0411
3176 2303
3177 1716
3200 1605
3201 0324
3202 4100

/
3203 2003      TEXPC, TEXT      "PC:"
3204 7200
3205 2324      TEXST, TEXT      "ST:"
3206 7200
3207 0315      TEXCM, TEXT      "CM:"
3210 7200
3211 1101      TEXIA, TEXT      "IA:"
3212 7200
3213 0401      TEXDA, TEXT      "DA:"
3214 7200
3215 0301      TEXCA, TEXT      "CA:"
3216 7200
3217 2703      TEXWC, TEXT      "WC:"
3220 7200
3221 0627      TEXFW, TEXT      "FW:"
3222 7200
3223 0123      TEXAS, TEXT      "AS:"
3224 7200
3225 2701      TEXWA, TEXT      "WA:"
3226 7200
3227 0104      TEXAD, TEXT      "AD:"
3230 7200
3231 0407      TEXDG, TEXT      "DG:"
3232 7200
3233 0402      TEXDB, TEXT      "DB:"
3234 7200

```

```

/ PAL10 V142A 19-MAR-75 15:21 PAGE 1-36

3235 2205 ERTX1, TEXT "READ STATUS"
3236 0104
3237 4023
3240 2401
3241 2425
3242 2300
3243 2722 ERTX2, TEXT "WRITE STATUS"
3244 1124
3245 0540
3246 2324
3247 0124
3250 2523
3251 0000
3252 2305 ERTX3, TEXT "SEEK STATUS"
3253 0513
3254 4023
3255 2401
3256 2425
3257 2300
3260 2205 ERTX4, TEXT "RECALIBRATE STATUS"
3261 0301
3262 1411
3263 0222
3264 0124
3265 0540
3266 2324
3267 0124
3270 2523
3271 0000
3272 0411 ERTX5, TEXT "DISK DATA"
3273 2313
3274 4004
3275 0124
3276 0100

/
3277 4005 MES0, TEXT " ERROR"
3300 2222
3301 1722
3302 0000
3303 2213 MES1, TEXT "RKBE DATA RELIABILITY"
3304 7005
3305 4004
3306 0124
3307 0140
3310 2205
3311 1411
3312 0102
3313 1114
3314 1124
3315 3100
3316 0530 MES2, TEXT "EXERCISE"
3317 0522
3320 0311
3321 2305
3322 0000

```

```

/ PAL10 V142A 19-MAR-75 15:21 PAGE 1-37

3323 4004 MES3, TEXT " DISK"
3324 1123
3325 1300
3326 1617 MES4, TEXT "NON-RECOVERABLE "
3327 1655
3330 2205
3331 0317
3332 2605
3333 2201
3334 0214
3335 0540
3336 0000
3337 0115 MES5, TEXT "AMOUNT OF EXTENDED R/W MEMORY(0-7)?"
3340 1725
3341 1624
3342 4017
3343 0540
3344 0530
3345 2405
3346 1604
3347 0504
3350 4022
3351 5727
3352 4013
3353 0515
3354 1722
3355 3150
3356 6055
3357 6751
3360 7700
3361 0103 MES6, TEXT "ACCEPT MODE?"
3362 0305
3363 2024
3364 4015
3365 1704
3366 0577
3367 0000
3370 0423 MES7, TEXT "DBK HARD SOFT COMP"
3371 1340
3372 1001
3373 2204
3374 4023
3375 1706
3376 2440
3377 0317
3400 1520
3401 0000
3402 0611 MES8, TEXT "FIELD?"
3403 0514
3404 0477
3405 0000
3406 2422 MES9, TEXT "TRACK?"
3407 0103
3410 1377
3411 0000

```

```

/ PAL10 V142A 19-MAR-75 15121 PAGE 1-38

3412 0530 MES10, TEXT "EXTRA SECTORS?"
3413 2422
3414 0140
3415 2305
3416 0324
3417 1722
3420 2377
3421 0000
3422 0214 MES11, TEXT "BLOCK LENGTH?"
3423 1703
3424 1340
3425 1405
3426 1607
3427 2410
3430 7700
3431 2305 MES12, TEXT "SEQUENCE?"
3432 2125
3433 0516
3434 0305
3435 7700
3436 0401 MES13, TEXT "DATA?"
3437 2401
3440 7700
3441 0122 MES14, TEXT "ARE YOU SURE?"
3442 0540
3443 3117
3444 2540
3445 2325
3446 2205
3447 7700
3450 4004 MES15, TEXT " DISCONNECTED!"
3451 1123
3452 0317
3453 1616
3454 0503
3455 2405
3456 0441
3457 0000 MES16, TEXT "SYSTEM SHUT DOWN, NO DISKS TO RUN!"
3460 2331
3461 2324
3462 0515
3463 4023
3464 1025
3465 2440
3466 0417
3467 2716
3470 5440
3471 1617
3472 4004
3473 1123
3474 1323
3475 4024
3476 1740
3477 2225
3500 1641

```

```

/ PAL10 V142A 19-MAR-75 15121 PAGE 1-39

3501 0000
3502 0411 MES17, TEXT "DISK "
3503 2313
3504 4000
3505 4020 MES18, TEXT " PASS COMPLETE!"
3506 0123
3507 2340
3510 0317
3511 1520
3512 1405
3513 2405
3514 4100

3515 0000 D0TM1, 0
3516 0000 D1TM1, 0
3517 0000 D2TM1, 0
3520 0000 D3TM1, 0
3521 0000 D0TM2, 0
3522 0000 D1TM2, 0
3523 0000 D2TM2, 0
3524 0000 D3TM2, 0

3525 0000 D0HRD, 0
3526 0000 D0SOF, 0
3527 0000 D0CMP, 0
3530 0000 D1HRD, 0
3531 0000 D1SOF, 0
3532 0000 D1CMP, 0
3533 0000 D2HRD, 0
3534 0000 D2SOF, 0
3535 0000 D2CMP, 0
3536 0000 D3HRD, 0
3537 0000 D3SOF, 0
3540 0000 D3CMP, 0

3541 0000 FLDPLG, 0
3542 0000 TRKFLG, 0
3543 0000 SECFLG, 0
3544 0000 HLFFLG, 0
3545 0000 SEQFLG, 0

3546 0000 DSK0A, 0
3547 0000 DSK1A, 0
3550 0000 DSK2A, 0
3551 0000 DSK3A, 0

3552 0000 DSK0B, 0
3553 0000 DSK1B, 0
3554 0000 DSK2B, 0
3555 0000 DSK3B, 0

/
/PLACE FOR DATA IN MANUAL MODE

3556 0000 DAT1, 0000
3557 0000 DAT2, 0000

```

PAL10 V142A 19-MAR-75 15121 PAGE 1-40

```

3560 0000 DAT3, 0000
3561 0000 DAT4, 0000
3562 0000 DAT5, 0000
3563 0000 DAT6, 0000
3564 0000 DAT7, 0000
3565 0000 DAT8, 0000
3566 0000 DAT9, 0000
3567 0000 DAT10, 0000
3570 0000 DAT11, 0000
3571 0000 DAT12, 0000

```

3600 PAGE

3600 STRBUP_π.

§ 5 5 5 5

PAL10 V142A 19-MAR-75 15121 PAGE 1-41

| | | | | | | | | | |
|------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| 0000 | 11111100 | 11111110 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 |
| 0100 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11110000 |
| 0200 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 |
| 0300 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 |
| 0400 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 |
| 0500 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11110000 | 00000000 | 01111111 |
| 0600 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 |
| 0700 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11111111 | 11000000 | 00111111 |

[illegible][illegible][illegible]

3600
3700

4000
4100

4200
4300

4400
4500

4600
4700

5000
5100

5200
5300

5400
5500

5600
5700

6000
6100

6200
6300

6400
6500

6600
6700

7000
7100

200
7300

7400
7500

7600
7700

| | | | | | | | |
|--------|------|--------|------|--------|------|--------|------|
| A0170 | 0761 | D1CMP | 3532 | DSKP | 6741 | ISAVE3 | 2567 |
| A0770 | 2755 | D1HRD | 3530 | DSKPOT | 0151 | K0003 | 0054 |
| A7007 | 2756 | D1SOF | 3531 | DSKSKP | 4443 | K0004 | 2570 |
| ACDCA | 0366 | D1TM1 | 3516 | DTCHK | 1600 | K0006 | 0055 |
| ADREG | 0131 | D1TM2 | 3522 | DTR1 | 1636 | K0007 | 0056 |
| AGAIN | 1345 | D2CMP | 3535 | DUMP | 2627 | K0010 | 0057 |
| ALLAGN | 0253 | D2HRD | 3533 | ERFLG | 0163 | K0017 | 0060 |
| AMOUNT | 0053 | D2SOF | 3534 | ERHLT2 | 1410 | K0020 | 0013 |
| ASKNX1 | 0343 | D2TM1 | 3517 | ERHLT3 | 2563 | K0040 | 0760 |
| ASKNX2 | 0400 | D2TM2 | 3523 | ERHLT4 | 2555 | K0070 | 0014 |
| ASKNX3 | 0417 | D3CMP | 3540 | ERHLT5 | 2546 | K0077 | 0102 |
| ASKNX4 | 0456 | D3HRD | 3536 | ERHLT6 | 2732 | K0100 | 0015 |
| ASKNX5 | 0471 | D3SOF | 3537 | ERR0 | 1200 | K0200 | 0016 |
| ASKSUR | 0520 | D3TM1 | 3520 | ERROEX | 1354 | K0212 | 1422 |
| ASPEC | 0127 | D3TM2 | 3524 | ERROR | 4441 | K0215 | 1421 |
| AUTO10 | 0010 | DAREG | 0123 | ERTX1 | 3235 | K0240 | 0062 |
| AUTO11 | 0011 | DAT1 | 3556 | ERTX2 | 3243 | K0260 | 0061 |
| AUTO12 | 0012 | DAT10 | 3567 | ERTX3 | 3252 | K0277 | 0065 |
| BADHLT | 1707 | DAT11 | 3570 | ERTX4 | 3260 | K0316 | 0063 |
| BPREC | 1023 | DAT12 | 3571 | ERTX5 | 3272 | K0331 | 0064 |
| BGN | 0200 | DAT2 | 3557 | ESAVE | 1370 | K0400 | 0066 |
| BGNBUF | 0144 | DAT3 | 3560 | EXIT | 1501 | K1500 | 0072 |
| BKRET | 0367 | DAT4 | 3561 | FILLER | 0730 | K177 | 2120 |
| BUFPNT | 1400 | DAT5 | 3562 | FIRTIM | 0167 | K1777 | 0073 |
| BUFTAL | 0116 | DAT6 | 3563 | FLDFLG | 3541 | K200 | 2121 |
| CAREG | 0124 | DAT7 | 3564 | FNDSUM | 0140 | K2000 | 0067 |
| CENR1 | 2757 | DAT8 | 3565 | FORIN | 4425 | K3000 | 2117 |
| CHANG | 2733 | DAT9 | 3566 | FROCT | 1423 | K3740 | 1510 |
| CHANGR | 2742 | DATFLG | 0155 | FWREG | 0126 | K4000 | 0070 |
| CHKPOT | 2143 | DATPOT | 0146 | GENDAT | 4420 | K4100 | 1507 |
| CHKRES | 3407 | DATTRY | 0136 | GNDAT | 1740 | K5405 | 0364 |
| CHKSAR | 0137 | DBREG | 0133 | GOBAC | 2230 | K6000 | 0071 |
| CHKYN | 2122 | DCLR | 6742 | GOCDF | 1646 | K7400 | 0104 |
| CHNCDF | 2254 | DGREG | 0132 | GOCHE | 2265 | K7700 | 0074 |
| CHNHLT | 2753 | DISCON | 4422 | GOCLE | 2260 | K7760 | 0075 |
| CHNPOT | 2760 | DISGO | 4434 | GOREAD | 1070 | K7761 | 0076 |
| CTIM | 2450 | DLAG | 6743 | GOTIT | 1035 | K7772 | 0077 |
| CLDR | 1405 | DLCA | 6744 | HEDTAD | 1375 | K7775 | 0100 |
| CLRALL | 4447 | DLDC | 6746 | HLFFLG | 3544 | K7777 | 0101 |
| CLRBAB | 0174 | DOHEAD | 1261 | INERR | 2420 | KCDF | 0103 |
| CMPPOT | 2564 | DRST | 6745 | INTCM | 0134 | KEYRET | 2362 |
| CMREG | 0121 | DSK0A | 3546 | INTDA | 0122 | KHLT | 0206 |
| CONCUR | 0726 | DSK0B | 3552 | INTER1 | 3126 | KROT | 0247 |
| CONSEC | 0145 | DSK1A | 3547 | INTER2 | 2357 | KSKP | 0540 |
| CRCENT | 0153 | DSK1B | 3553 | LOT1 | 2721 | LDAD | 2556 |
| CRCFLG | 0154 | DSK2A | 3550 | LOT2 | 1406 | LDADD | 4446 |
| CRLF | 4452 | DSK2B | 3554 | LOT3 | 2561 | LDCA | 2552 |
| D0CMP | 3527 | DSK3A | 3551 | LOT4 | 2553 | LDCEM | 2725 |
| D0HRD | 3525 | DSK3B | 3555 | LOTS | 2544 | LDCEM2 | 4444 |
| D0SOF | 3526 | DSKEX | 2302 | LOT6 | 2730 | LDCEM3 | 4445 |
| D0TM1 | 3515 | DSKGO | 2200 | ISAVE1 | 2565 | LNKDC | 0365 |
| D0TM2 | 3521 | DSKOUT | 2055 | ISAVE2 | 2566 | LDGGO | 2330 |

| | | | | | | | |
|--------|------|--------|------|--------|------|--------|------|
| M12 | 0105 | PRINT | 2620 | SEQFLG | 3545 | TRYTIM | 1065 |
| M4 | 0106 | PRN | 1445 | SETFLD | 4427 | TSAVE1 | 3042 |
| M5 | 0107 | PRNDAT | 0172 | SETGEN | 4426 | TSAVE2 | 3043 |
| MANUAL | 0320 | PRNTER | 4450 | SETREG | 2153 | TSAVE3 | 3044 |
| MAXFLD | 0141 | RAD1 | 1774 | SOFT | 1245 | TSAVE4 | 3045 |
| MAXTIM | 0142 | RAD2 | 1775 | SPAC | 1503 | TSAVE5 | 3046 |
| MAXTRK | 0143 | RAD3 | 1776 | SPACE | 4423 | TYPDAT | 3132 |
| MES0 | 3277 | RAN1 | 1770 | SPBLK | 0162 | TYPE | 4440 |

| | | | | | | | |
|--------|------|--------|------|--------|------|---------|------|
| MES1 | 3303 | RAN2 | 1771 | SPFLD | 0156 | UPDATE | 0113 |
| MES10 | 3412 | RANDAT | 4421 | SPSEC | 0161 | UPONE | 1411 |
| MES11 | 3422 | RANDOM | 1716 | SPTRK1 | 0157 | UPTRY | 1134 |
| MES12 | 3431 | RANGEN | 4433 | SPTRK2 | 0160 | WAIT | 2102 |
| MES13 | 3436 | RANJMS | 0554 | STAPOT | 0150 | WAREG | 0130 |
| MES14 | 3441 | RDLWRL | 2324 | STATER | 2337 | WASRD | 2264 |
| MES15 | 3450 | RDS1 | 2543 | STATRY | 0135 | WCREG | 0125 |
| MES16 | 3460 | RDS2A | 1121 | STATUS | 2313 | WRDCHK | 1612 |
| MES17 | 3502 | RDS2B | 4442 | STFLD | 2673 | WRKDON | 2274 |
| MES18 | 3505 | RDRY | 1107 | STGEN | 1754 | XCHKYN | 0031 |
| MES19 | 3164 | RECAL | 4436 | STPHLT | 2006 | XCKPOT | 0030 |
| MES2 | 3316 | RECDF | 2605 | STRAUT | 1324 | XCLDR | 0047 |
| MES3 | 3323 | RECEIV | 4437 | STRBUF | 3600 | XCLFL | 0052 |
| MES4 | 3326 | REFILL | 0733 | STREG | 0120 | XDSKGO | 0034 |
| MES5 | 3337 | REREAD | 1077 | STRSEK | 0526 | XDUMP | 0022 |
| MES6 | 3361 | RESEK | 1154 | STRSTP | 2003 | XERRO | 0041 |
| MES7 | 3370 | RESEK | 2007 | STRTEX | 0224 | XFROCT | 0051 |
| MES8 | 3402 | RESERR | 3106 | STRWRK | 2241 | XGNDAT | 0020 |
| MES9 | 3406 | RESET | 0535 | SVLNK | 0166 | XLDAD | 0046 |
| MRPRN | 1453 | RESRAN | 4435 | SWDAT | 2601 | XLDCA | 0045 |
| MSKER | 1715 | RESTA | 3074 | TEXAD | 3227 | XLDCEM | 0044 |
| NEWRD | 0737 | RESTOR | 3047 | TEXAS | 3223 | XOCT1 | 0024 |
| NEXT | 0261 | RETRN | 2331 | TEXCA | 3215 | XOCT4 | 0025 |
| NODSKP | 2353 | RETURN | 2304 | TEXCM | 3207 | XPRINT | 0040 |
| NODSKS | 2671 | REWRT | 1054 | TEXDA | 3213 | XPRN | 0050 |
| NOERR | 1672 | RNFLD | 0633 | TEXD6 | 3233 | XRDST | 0042 |
| NOIEX | 1362 | RNWRD | 2600 | TEXDG | 3231 | XREG | 1371 |
| NOTSTA | 3036 | RSRAN | 1762 | TEXF | 3221 | XRESTR | 0036 |
| NTERR | 1255 | RUN | 0600 | TEXIA | 3211 | XRANDOM | 0033 |
| NTSEK | 0552 | RUNFOT | 0152 | TEXPC | 3203 | XRNWRD | 0021 |

| | | | | | | | |
|--------|------|--------|------|--------|------|--------|------|
| NTSOFT | 1251 | SAMPOL | 1002 | TEXT | 3205 | XSRAN | 0035 |
| NTWRKS | 1711 | SAV1 | 1772 | TEXWA | 3225 | XSDKP | 0043 |
| NATSEK | 0532 | SAV2 | 1773 | TEXWC | 3217 | XSKOUT | 0032 |
| UCT1 | 2400 | SAVAC | 0165 | TIME | 3121 | XSPAC | 0023 |
| OCT4 | 2430 | SAVCM | 0173 | TIMER1 | 3130 | XSTFLD | 0027 |
| OCTEL | 4451 | SDKP | 2720 | TIMER2 | 3131 | XSTGEN | 0026 |
| ONEIN | 4424 | SECFLG | 3543 | TIMPOT | 0147 | XTEXT | 0171 |
| OPRTAL | 0115 | SEK | 4432 | TPSTA | 3000 | XWAIT | 0037 |
| PCNTR1 | 1372 | SEKER | 2074 | TRASH1 | 0110 | YESNO | 4431 |
| PCNTR2 | 1373 | SEKEX | 2100 | TRASH2 | 0111 | | |
| PCNTR3 | 1374 | SEKGO | 1140 | TRASH3 | 0112 | | |
| PCREG | 0117 | SEKOUT | 2000 | TRDONE | 2366 | | |
| POLDSK | 0114 | SEKSW | 0164 | TRKFLG | 3542 | | |
| POLNEX | 1000 | SELCHK | 4430 | TRYCNT | 0170 | | |

/ PAL10 V142A 19-MAR-75 15:21 PAGE 1-45

ERRORS DETECTED: 0

LINKS GENERATED: 46

RUN-TIME: 11 SECONDS

3K CORE USED