

IDENTIFICATION

PRODUCT CODE: MAINDEC-08-DJKMA-A-D
PRODUCT NAME: KMS-A OPTION TEST #2
DATE CREATED: DECEMBER 16, 1974
MAINTAINER: DIAGNOSTIC GROUP
AUTHOR: BRUCE HANSEN

COPYRIGHT 1974
DIGITAL EQUIPMENT CORPORATION
MAYNARD, MASS, 01754

"THE MATERIAL IN THIS DOCUMENT IS FOR INFORMATION PURPOSES ONLY AND IS SUBJECT TO CHANGE WITHOUT NOTICE; DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OF SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC; DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS WHICH MAY APPEAR IN THE DOCUMENT."

TABLE OF CONTENTS

1,0	ABSTRACT
2,0	REQUIREMENTS
2,1	HARDWARE
2,2	STORAGE
2,3	PREREQUISITE SOFTWARE
3,0	RESTRICTIONS
4,0	STANDARD TEST PROCEDURE
4,1	CHANGING DEVICE IOT CODES
4,2	HARDWARE SETUP
4,3	LOADING THE PROGRAM
4,4	PROGRAM INITIALIZATION
4,5	RUN MEMORY EXTENSION/TIME SHARE TEST
4,6	RUN TIME SHARE DISABLE TEST
4,7	RUN BOOTSTRAP/SIMULATOR TEST
4,7,1	RUN SIMULATOR TEST
4,7,2	RUN BOOTSTRAP TEST
4,8	RUN AUTO RESTART/POWER FAIL TEST
5,0	ERRORS
5,1	MEMORY EXTENSION/TIME SHARE TEST ERRORS
5,1,1	MEMORY EXTENSION/TIME SHARE TEST ERROR RECOVERY
5,2	TIME SHARE DISABLE TEST ERRORS
5,2,1	TIME SHARE DISABLE TEST ERROR RECOVERY
5,3	BOOTSTRAP TEST ERRORS
5,3,1	BOOTSTRAP TEST ERROR RECOVERY
5,4	AUTO RESTART/POWER FAIL TEST ERRORS
5,4,1	AUTO RESTART/POWER FAIL TEST ERROR RECOVERY
6,0	SWITCH REGISTER SETTINGS
6,1	NORMAL OPERATING SWITCHES
6,2	ERROR SWITCHES
7,0	REVISIONS
8,0	PROGRAM DESCRIPTION
9,0	FLOWCHARTS
10,0	LISTING

1,0 ABSTRACT

KMB=A OPTION TEST 2 IS A PROGRAM TO CHECKOUT THE PDP-8A OPTION BOARD #2 (M8317). THE DEVICES TESTED BY THE PROGRAM ARE THE MEMORY EXTENSION/TIME SHARE CONTROL LOGIC, POWER FAIL/AUTO-RESTARTS, AND THE BOOTSTRAP LOADERS. A OPTION 1 + 2 TEST MODULE (G5041) CAN BE USED IN CONJUNCTION WITH THE M8317 AND THE PROGRAM TO DECREASE THE TEST TIME AND TO ALLEVIATE OPERATOR INTERVENTION.

THE PROGRAM IS STRUCTURED SO THAT IT MAY RUN ON OR OFF THE PDP-8A AGT TEST LINE, WITH OR WITHOUT THE OPTION 1 + 2 TEST MODULE, OR ANY COMBINATION OF THE ABOVE WITH THE PDP-8A OPTION BOARD #2.

THE PROGRAM IS A 4K PROGRAM BUT IT IS ALSO SUPPLIED IN FOUR 1K SEGMENTS FOR USE ON COMPUTERS WITH LESS THAN 4K OF MEMORY.

2,0 REQUIREMENTS

2,1 HARDWARE

THE FOLLOWING HARDWARE IS REQUIRED FOR THE EXECUTION OF THIS PROGRAM,

PROCESSOR(S):

PDP-8A

MEMORY:

MINIMUM OF 4K OF MEMORY FOR THE COMPLETE PROGRAM
MINIMUM OF 1K OF MEMORY FOR THE SEGMENTED 1K VERSIONS OF THE PROGRAM.

OPTIONS:

IF OPTION BOARD #2 IS TO BE TESTED ALONE WITHOUT THE OPTION 1 + 2 TEST MODULE, THE FOLLOWING HARDWARE IS REQUIRED, OTHERWISE, SEE THE HARDWARE REQUIRED UNDER THE NEXT SECTION LABELED "SPECIAL",

1. PDP-8A OPTION BOARD #2 (M8317)
2. ONE QUAD EXTENDER MODULE

SPECIAL:

1. PDP-8A OPTION BOARD #2 (M8317)
2. OPTION 1 + 2 TEST MODULE (G5041)
3. ONE QUAD EXTENDER MODULE
4. TWO IC SOCKET CONNECTOR CABLES (PN=7008612)

2,2 STORAGE

THE 4K VERSION AND THE 1K VERSIONS OF THE KMB=A OPTION TEST 2 MUST RESIDE IN FIELD 0. THE 4K VERSION OF THE PROGRAM OCCUPIES LOCATIONS 0000 TO 5177 AND USES LOCATIONS 5200 TO 7777 AS A BUFFER AREA. THE 1K VERSIONS OF THE PROGRAM OCCUPIES FOR THE MOST PART LOCATIONS 0000 TO 1777, AND IT MUST RESIDE IN THE 1ST 1K.

2,3 PREREQUISITE SOFTWARE

PDP-8A CPU TEST
PDP-8A MEMORY TEST
IF 4K OF MEMORY = 2K TO 32K PDP-8A PROCESSOR EXERCISER
IF LESS THAN 4K = 1K TO 32K RANDOM MEMORY REFERENCE INSTRUCTION EXERCISER,

3,0 RESTRICTIONS

- 1, ONCE THE PROGRAM HAS BEEN STARTED, BINARY LOADER WILL BE DESTROYED IF USED.
2, ALL OPTIONS ASSOCIATED WITH THE BOOTSTRAP LOADERS MUST BE UNPLUGGED FROM THE COMPUTER.

4,0 STANDARD TEST PROCEDURE

THE FOLLOWING PARAGRAPHS MUST BE FOLLOWED EXPLICITLY TO SETUP THE HARDWARE, LOAD THE PROGRAM, AND TO INITIALIZE THE PROGRAM,

- 4,2 HARDWARE SETUP
4,3 LOADING THE PROGRAM
4,4 PROGRAM INITIALIZATION

THE PROGRAM IS DIVIDED INTO FOUR SECTIONS AND EACH SECTION MUST BE RUN SEPARATELY UNLESS A OPTION 1 + 2 TEST MODULE IS UTILIZED WITH THE PROGRAM. IF THE OPTION 1 + 2 TEST MODULE IS USED, RUN MEMORY EXTENSION/TIME SHARE TEST, PARAGRAPH 4,5, WHICH WILL INCLUDE THE MEMORY EXTENSION/TIME SHARE TESTS ENABLED AND DISABLED, THE BOOTSTRAP TEST, AND AUTO RESTART TEST, IF THE OPTION 1 + 2 TEST MODULE IS NOT USED, DO THE FOLLOWING TEST:

- RUN MEMORY EXTENSION/TIME SHARE TEST = PARAGRAPH 4,5
RUN TIME SHARE DISABLE TEST = PARAGRAPH 4,6
RUN BOOTSTRAP/SIMULATOR TEST = PARAGRAPH 4,7
RUN AUTO RESTART/POWER FAIL TEST = PARAGRAPH 4,8

4,1 CHANGING IOT CODES

NOT APPLICABLE

4,2 HARDWARE SETUP

BEFORE LOADING THE PROGRAM, THE FOLLOWING STEPS MUST BE DONE:

- A, POWER THE COMPUTER DOWN
B, UNPLUG THE M8317 MODULE FROM THE COMPUTER
C, PLUG THE QUAD EXTENDER INTO THE SLOT THE M8317 OCCUPIED
D, PLUG THE M8317 MODULE INTO THE QUAD EXTENDER
E, SET ALL THE SWITCHES ON THE M8317 MODULE TO THE OFF POSITION
F, IF THE OPTION 1 + 2 TEST MODULE IS TO BE USED DO THE FOLLOWING, IF NOT GO TO STEP G IN THIS SECTION,
1, TAKE ONE END OF THE IC SOCKET CONNECTOR CABLE AND PLUG IT INTO E93 ON THE M8317 MODULE(OBSERVING PIN 1 ORIENTATION).

2. TAKE THE OTHER END OF THE CABLE AND PLUG IT INTO TS-1 (ABOVE E63) ON THE G5041 MODULE.
 3. TAKE ONE END OF THE NEXT IC SOCKET CONNECTOR CABLE AND PLUG IT INTO E88 ON THE M8317 MODULE.
 4. TAKE THE OTHER END OF THE CABLE AND PLUG IT INTO TS-2 (ABOVE E70) ON THE G5041 MODULE.
 5. PLUG THE OPTION 1 + 2 TEST MODULE (G5041) INTO THE COMPUTER.
- G. POWER THE COMPUTER BACK UP.
- H. GO TO PARAGRAPH 4.3, LOADING THE PROGRAM.

4.3

LOADING THE PROGRAM

COMPUTERS WITH 4K OF MEMORY WILL USE THE BINARY PAPER TAPE LABELED MAINDEC-08-DJKMA-A-P81. COMPUTERS WITH LESS THAN 4K OF MEMORY WILL USE THE FOUR 1K SEGMENTED RIM PAPER TAPES WHICH ARE LABELED AS FOLLOWS:

1. MAINDEC-08-DJKMA-A-PM1 = 1K VERSION PART 1
 2. MAINDEC-08-DJKMA-A-PM2 = 1K VERSION PART 2
 3. MAINDEC-08-DJKMA-A-PM3 = 1K VERSION PART 3
 4. MAINDEC-08-DJKMA-A-PM4 = 1K VERSION PART 4
- A. IF THE COMPUTER CONTAINS 4K OF MEMORY OR MORE, DO STEP B, OTHERWISE, DO STEP C BELOW FOR COMPUTERS WITH LESS THAN 4K OF MEMORY.
- B. LOAD THE BINARY TAPE MENTIONED ABOVE USING THE STANDARD BINARY LOADER TECHNIQUE. AFTER THE TAPE HAS BEEN SUCCESSFULLY LOADED GO TO PARAGRAPH 4.4, PROGRAM INITIALIZATION.
- C. TO LOAD THE 1K SEGMENTED RIM PAPER TAPES MENTIONED ABOVE, DEPOSIT INTO LOCATIONS LISTED BELOW THE APPROPRIATE RIM LOADER FOR THE LOADING DEVICE TO BE USED.

HIGH SPEED HEADER

LOW SPEED READER

ADDRESS	CONTENT
0156	6014
0157	6011
0160	5357
0161	6016
0162	7106
0163	7006
0164	7510
0165	5374
0166	7006
0167	6011
0170	5367
0171	6016
0172	7420
0173	3776
0174	3376
0175	5357

ADDRESS	CONTENT
0156	6032
0157	6031
0160	5357
0161	6036
0162	7106
0163	7006
0164	7510
0165	5357
0166	7006
0167	6031
0170	5367
0171	6034
0172	7420
0173	3776
0174	3376
0175	5356

- D, PLACE THE APPROPRIATE 1K SEGMENT INTO THE READER, "LOAD ADDRESS" TO 0156, PRESS "INIT" AND THEN "RUN",
- E, WHEN THE TAPE HAS BEEN LOADED, STOP THE COMPUTER, GO TO PARAGRAPH 4.4, PROGRAM INITIALIZATION,

4.4 PROGRAM INITIALIZATION

THE PROGRAM WHEN LOADED IS INITIALIZED TO RUN WITHOUT THE HARDWARE FRONT PANEL SWITCH REGISTER, WITHOUT OPTION 1 + 2 TEST MODULE, AND THE AMOUNT OF MEMORY REQUIRED TO RUN THE PROGRAM (4K FOR THE COMPLETE PROGRAM AND 1K FOR THE SEGMENTED 1K VERSIONS OF THE PROGRAM), IF IT IS DESIRED TO CHANGE THE HARDWARE CONFIGURATION, LOAD ADDRESS TO 0021 AND DEPOSIT INTO THIS LOCATION THE APPROPRIATE HARDWARE CONFIGURATION FOR THE BITS LISTED BELOW:

NOTE: IF MEMORY SIZE IS LARGER OR SMALLER THAN LISTED ABOVE, IT SHOULD BE CHANGED IN LOCATION 0021,

BIT 0 = 0 THE PROGRAM WILL USE LOCATION 0020 AS A PSEUDO SWITCH REGISTER
BIT 0 = 1 THE PROGRAM WILL USE THE HARDWARE FRONT PANEL SWITCH REGISTER

BIT 2 = 1 HAS A M8317 OPTION 2 MODULE

BIT 4 = 0 THE PROGRAM WILL NOT USE THE OPTION 1 + 2 TEST MODULE TO TEST THE M8317;
BIT 4 = 1 THE PROGRAM WILL USE THE OPTION 1 + 2 TEST MODULE TO TEST THE M8317,

BITS 7-11 SPECIFIES THE POP-8A'S MEMORY SIZE, ALL ZEROS INDICATES 1K OF MEMORY, AN ADDITION OF 1 TO THE NUMBER IN BITS 7-11 INCREASES MEMORY SIZE BY 1K,

GO TO PARAGRAPH 4.5, MEMORY EXTENSION/TIME SHARE TEST,

4.5 RUN MEMORY EXTENSION/TIME SHARE TEST,

THE TAPE(S) TO BE USED TO RUN THIS TEST ARE AS FOLLOWS:

COMPUTERS WITH AT LEAST 4K OF MEMORY

MAINDEC=08-DJKMA-A-PM1

COMPUTERS WITH LESS THAN 4K OF MEMORY

MAINDEC=08-DJKMA-A-PM1
MAINDEC=08-DJKMA-A-PM2

NOTE: IF OPTION 1 + 2 TEST MODULE IS SELECTED AND THE COMPUTER CONTAINS 4K OF MEMORY OR MORE, THIS TEST IS THE ONLY TEST REQUIRED TO BE RUN WITH THE 4K PROGRAM LISTED ABOVE,

- A, LOAD ADDRESS TO ONE OF THE FOLLOWING ADDRESSES FOR THE TAPE(S) TO BE RUN:
- ADDRESS 0200 (RESTART 0201 IF OPTION 1 + 2 TEST MODULE IS USED) =MAINDEC=08-DJKMA=A
 ADDRESS 0200 =MAINDEC=08-DJKMA=A-PM1
 ADDRESS 0200 =MAINDEC=08-DJKMA=A-PM2
- B, SET THE SWITCH REGISTER OR PSEUDO SWITCH REGISTER, WHICHEVER WAS SELECTED, TO 0000,
- C, PRESS "INIT" AND THEN "RUN",
- D, SETTING THE SWITCH REGISTER OR PSEUDO SWITCH REGISTER, WHICHEVER WAS SELECTED, TO 0400 WILL CAUSE THE COMPUTER TO HALT AT THE END OF A PROGRAM PASS, THE LOCATION AT WHICH IT WILL HALT, WILL BE ONE OF THE FOLLOWING FOR THE TAPE THAT IS BEING RUN:
- LOCATION 5040 = MAINDEC=08-DJKMA=A-PB1
 LOCATION 1634 = MAINDEC=08-DJKMA=A-PM1
 LOCATION 1634 = MAINDEC=08-DJKMA=A-PM2
- E, THE PROGRAM WILL NOW RUN UNTIL AN ERROR IS ENCOUNTERED OR THE PROGRAM IS STOPPED BY THE OPERATOR OR SR3=1,
- F, AN ERROR MAY RESULT IN AN ERROR HALT OR A JMP SELF,

4,6

RUN TIME SHARE DISABLE TEST

 THE TAPE(S) TO BE USED TO RUN THIS TEST ARE AS FOLLOWS:

COMPUTERS WITH AT LEAST 4K OF MEMORY

 MAINDEC=08-DJKMA=A-PB1

COMPUTERS WITH LESS THAN 4K OF MEMORY

 MAINDEC=08-DJKMA=A-PM3

- A, ON THE MB317 MODULE, SET SWITCH 1 TO THE ON POSITION ON THE SWITCH PACKAGE WHICH LIES ABOVE I,C, E87, SETTING OF THIS SWITCH WILL DISABLE THE TIME SHARE LOGIC,
- B, LOAD ADDRESS TO ONE OF THE FOLLOWING ADDRESSES FOR THE TAPE TO BE RUN:
- ADDRESS 4255 = MAINDEC=08-DJKMA=A-PB1
 ADDRESS 1255 = MAINDEC=08-DJKMA=A-PM3
- C, SET SWITCH REGISTER OR PSEUDO SWITCH REGISTER, WHICHEVER WAS SELECTED, TO 0000, PRESS "INIT" AND THEN "RUN",
- D, THE PROGRAM SHOULD HALT ON A SUCCESSFULL PASS AT LOCATION 4275 FOR MAINDEC=08-DJKMA=A-PB1 AND AT LOCATION 1275 FOR MAINDEC=08-DJKMA=A-PM3
- E, SET THE SWITCH THAT WAS SET IN STEP A ABOVE TO THE OFF POSITION,
- F, GO TO PARAGRAPH 4,7, RUN BOOTSTRAP/SIMULATOR TEST,

4,7 RUN BOOTSTRAP/SIMULATOR TEST

IF A OPTION 1 + 2 TEST MODULE IS NOT USED WITH THE PROGRAM, GO TO PARAGRAPH 4,7,2, RUN BOOTSTRAP TEST,

IF A OPTION 1 + 2 TEST MODULE IS USED WITH THE PROGRAM AND THE COMPUTER CONTAINS LESS THAN 4K OF MEMORY, GO TO PARAGRAPH 4,7,1, RUN SIMULATOR TEST,

4,7,1, RUN SIMULATOR TEST

THE TAPE TO BE USED WITH THIS TEST IS MAINDEC=08-DJKMA=A-PM3,

THIS TEST USES THE OPTION 1 + 2 TEST MODULE TO CHECK THE EMA LINES, TIME SHARE DISABLE, AC LOW AND BATTERY EMPTY FLIP-FLOPS,

- A, LOAD ADDRESS TO 0201
- B, SET THE SWITCH REGISTER OR THE PSEUDO SWITCH REGISTER, WHICHEVER WAS SELECTED, TO 0000,
- C, PRESS "INIT" , AND THEN "RUN" ;
- D, THE PROGRAM WILL NOW RUN UNTILL AN ERROR IS ENCOUNTERED, STOPPED BY THE OPERATOR, OR SWITCH REGISTER 3 SET TO A 1,
- E, SETTING SWITCH REGISTER 3 TO A 1 WILL CAUSE THE COMPUTER TO HALT AT LOCATION 1690,
- F, WHILE RUNNING THIS PROGRAM THE RUN LIGHT WILL BE BLINKING ON AND OFF,

4,7,2 RUN BOOTSTRAP TEST

THE TAPE(S) TO BE USED TO RUN THIS TEST ARE AS FOLLOWS:

COMPUTERS WITH AT LEAST 4K OF MEMORY

MAINDEC=08-DJKMA=A-PB1

COMPUTERS WITH LESS THAN 4K OF MEMORY

MAINDEC=08-DJKMA=A-PM3

NOTE: DISABLE OR UPLUG FROM THE COMPUTER ANY DEVICES ASSOCIATED WITH THE BOOTSTRAPS,

- A, SET ALL THE SWITCHES ON THE M8317 MODULE TO THE OFF POSITION,
- B, SET THE SWITCHES S1=6, S1=7, S1=8 ON THE SWITCH PACKAGE WHICH LIES ABOVE I,C, E79 ON THE M8317 MODULE TO THE ON POSITION,
- C, SET THE SWITCHES ON THE M8317 MODULE TO THE BOOTSTRAP TO BE TESTED FROM THE TABLE BELOW:

NOTE: ONLY THE RK8E BOOTSTRAP CAN BE TESTED ON 1K COMPUTERS,

WHEN REFERENCING SWITCHES IN THE TABLE BELOW, S2 IS THE SWITCH PACKAGE LOCATED ABOVE I,C, E87, AND S1 IS LOCATED ABOVE I,C, E79.

BOOTSTRAP	S2 SWITCHES				S1 SWITCHES		
-----	S2=5	S2=6	S2=7	S2=8	S1=1	S1=2	S1=3
HI=LO PT RDR	ON	ON	ON	OFF	ON	ON	ON
RK8E	ON	OFF	ON	OFF	ON	OFF	ON
TC08	ON	OFF	OFF	ON	OFF	ON	ON
RF08/DF320	OFF	ON	ON	ON	ON	OFF	OFF
TABE	OFF	ON	ON	OFF	ON	OFF	OFF

- D. LOAD ADDRESS TO ONE OF THE FOLLOWING ADDRESSES FOR THE TAPE THAT IS TO BE RUN:

ADDRESS 4465 = MAINDEC=08-DJKMA=A-PB1
 ADDRESS 1465 = MAINDEC=08-DJKMA=A-PM3

- E. PRESS "INIT" AND THEN "RUN", THIS WILL CLEAR THE BOOTSTRAP LOCATIONS IN MEMORY THAT THE BOOTSTRAPS WILL LOAD INTO,
 F. THE PROGRAM WILL HALT AT LOCATION 4515 FOR MAINDEC=08-DJKMA=A-PB1 OR 1515 FOR MAINDEC=08-DJKMA=A-PM3,
 G. TOGGLE THE BOOT SWITCH OR BOOT KEY, THE MODULE SHOULD DO A BOOTSTRAP AND THE COMPUTER SHOULD BE RUNNING,
 H. HALT THE COMPUTER AND LOAD ADDRESS TO ONE OF THE FOLLOWING ADDRESSES FOR THE TAPE THAT IS BEING RUN:

ADDRESS 4400 = MAINDEC=08-DJKMA=A-PB1
 ADDRESS 1400 = MAINDEC=08-DJKMA=A-PM3

- I. THE PROGRAM WILL HALT AT ADDRESS 4400 FOR MAINDEC=08-DJKMA=A-PB1 OR 1400 FOR MAINDEC=08-DJKMA=A-PM3,
 J. SET THE SWITCH REGISTER OR THE PSEUDO SWITCH REGISTER, WHICHEVER WAS SELECTED, TO THE BOOTSTRAP TO BE COMPARED FROM THE TABLE BELOW:

BOOTSTRAP	S,R, SETTINGS
-----	-----
HI=LO PT RDR	0000
TC08	0001
RF08/DF320	0002
TABE	0003
RK8E	0004

- K. PRESS "INIT" AND THEN "RUN" ,
 L. THE PROGRAM SHOULD HALT AT LOCATION 4461 FOR MAINDEC=08-DJKMA=A-PB1 OR 1461 FOR MAINDEC=08-DJKMA=A-PM3 IF THE BOOTSTRAP COMPARED OK,
 M. DO STEPS A THROUGH L FOR EACH BOOTSTRAP
 N. GO TO PARAGRAPH 4.8, RUN AUTO RESTART/POWER FAIL TEST,

RUN AUTO RESTART/POWER FAIL TEST

THE TAPE(S) TO BE USED TO RUN THIS TEST ARE AS FOLLOWS:

COMPUTERS WITH AT LEAST 4K OF MEMORY

 MAINDEC-08-DJKMA-A-PB1

COMPUTERS WITH LESS THAN 4K OF MEMORY

 MAINDEC-08-DJKMA-A-PM4

THE BATTERY SUPPLY SHOULD BE FULLY CHARGED TO RUN THIS TEST

- A. SET ALL SWITCHES TO THE OFF POSITION ON THE M8317 MODULE.
- B. SET SWITCHES 1, 3, 6, 7, AND 8 TO THE ON POSITION ON THE SWITCH PACKAGE WHICH IS LOCATED ABOVE E79 ON THE M8317 MODULE.
- C. SET SWITCHES 5 AND 7 TO THE ON POSITION ON THE SWITCH PACKAGE WHICH IS LOCATED ABOVE E87 ON THE M8317 MODULE.
- D. SET THE SWITCHES ON THE M8317 MODULE TO THE AUTO RESTART TO BE TESTED FROM THE TABLE BELOW.

NOTE: ON 1K COMPUTERS THE ONLY RESTARTS THAT CAN BE TESTED ARE AT 0000 AND 0200.

<u>AUTO RESTART</u>	<u>S2 SWITCHES (ABOVE E87)</u>		
	S2=2	S2=3	S2=4
0000	OFF	OFF	OFF
0200	OFF	ON	OFF
2000	ON	OFF	OFF
4200	ON	ON	OFF

- F. LOAD ADDRESS TO 4000 FOR MAINDEC-08-DJKMA-A-PB1 OR TO 0201 FOR MAINDEC-08-DJKMA-A-PM4.
- G. PRESS "INIT" AND THEN "RUN".
- H. THE PROGRAM WILL NOW FILL A BUFFER AREA WITH A COMPLEMENTING 5252 DATA PATTERN, AND THEN HALT AT LOCATION 4640 FOR MAINDEC-08-DJKMA-A-PB1 OR AT 0227 FOR MAINDEC-08-DJKMA-A-PM4.
- I. NOW SET THE SWITCH REGISTER OR THE PSEUDO SWITCH REGISTER, WHICHEVER WAS SELECTED, TO THE AUTO RESTART TO BE TESTED FROM THE TABLE BELOW.

<u>AUTO RESTART</u>	<u>S,R, SETTINGS</u>
0000	0003
0200	0002
2000	0001
4200	0000

- J, PRESS "INIT" AND THEN "RUN" ,
- K, THE PROGRAM NOW STARTS COMPARING THE DATA THAT WAS PUT IN THE BUFFER AREA,
- L, THE OPERATOR AT THIS TIME MUST UNPLUG THE AC LINE CORD; WHEN THE LINE CORD HAS BEEN UNPLUGGED, THE PROGRAM SHOULD HALT AT LOCATION 4763 FOR MAINDEC-08-DJKMA-A-PB1, OR AT LOCATION 0352 FOR MAINDEC-08-DJKMA-A-PM4,
- M, WITH A MINIMAL AMOUNT OF DELAY, THE OPERATOR MUST PLUG THE AC LINE CORD BACK IN. AT THIS TIME THE M8317 SHOULD DO A AUTO RESTART TO THE AUTO RESTART SELECTED; THE PROGRAM THEN CHECKS FOR THE CORRECT AUTO RESTART AND THEN GOES BACK TO COMPARING DATA,
- N, STEPS L AND M SHOULD BE REPEATED SEVERAL TIMES FOR EACH OF THE AUTO RESTARTS,

5.0 ERRORS

5.1 MEMORY EXTENSION/TIME SHARE TEST ERRORS

ALL ERRORS DETECTED UNDER THIS TEST WILL RESULT IN A HALT, AN ERROR HALT OR A JMP SELF FOR THE TAPES LISTED BELOW:

MAINDEC-08-DJKMA-A-PB1
MAINDEC-08-DJKMA-A-PM1
MAINDEC-08-DJKMA-A-PM2

REFER TO THE APPROPRIATE LISTING FOR THE ERROR, THE TEST BEING EXERCISED AND FOR THE TEST SEQUENCE BEING EXECUTED,

5.1.1 MEMORY EXTENSION/TIME SHARE TEST ERROR RECOVERY

REFER TO THE APPROPRIATE SECTION BELOW FOR THE ACTION TO BE TAKEN:

ERROR HALT ERRORS

A ERROR HALT IS WHEN THE COMPUTER HALTS AT LOCATION 5133 FOR PAPER TAPE MAINDEC-08-DJKMA-A-PB1 OR AT LOCATION 1727 FOR PAPER TAPES MAINDEC-08-DJKMA-A-PM1 AND -PM2; THE CONTENTS OF THE ACCUMULATOR FOR THIS ERROR HALT WILL CONTAIN THE LOCATION AT WHICH THE ERROR WAS DETECTED BY THE PROGRAM; REFER TO THE APPROPRIATE PROGRAM LISTING FOR THE CAUSE OF THE ERROR; SET THE SWITCH REGISTER TO 7000 AND PRESS "INIT" AND THEN "RUN"; THERE MAY BE 1 OR MORE ERROR HALTS; IF THE ERROR WAS A DATA ERROR, OR THE OPTION 1 + 2 TEST MODULE WAS BEING USED, THE PROGRAM IS NOW IN A SCOPE LOOP,

HALT/JMP SELF ERRORS

ANY ERROR ENCOUNTERED DURING A TEST SEQUENCE WHICH RESULTS IN A HALT OR A JMP SELF, REPLACE THE HALT OR JMP SELF WITH A JMP TEST(X) (X=TEST BEING EXECUTED I.E, JMP TEST1, JMP TEST2, ETC.),

5,2 TIME SHARE DISABLE TEST ERRORS

ANY ERRORS DETECTED BY THIS TEST WILL RESULT IN A HALT AT LOCATION 5133 FOR TAPE MAINDEC-08-DJKMA-A-PB1, OR AT LOCATION 1733 FOR TAPE MAINDEC-08-DJKMA-A-PM3, THE CONTENTS OF THE AC WILL CONTAIN THE ADDRESS WHERE THE ERROR WAS DETECTED BY THE PROGRAM,

5,2,1 TIME SHARE DISABLE TEST ERROR RECOVERY

SET THE SWITCH REGISTER OR PSEUDO SWITCH REGISTER WHICHEVER WAS SELECTED AT PROGRAM INITIALIZATION TO 7000 AND PRESS "INIT" AND "RUN", THE PROGRAM IS NOW IN A SCOPE LOOP,

5,3 BOOTSTRAP TEST ERRORS

BOOTSTRAP ERRORS WILL BE GENERALLY OF TWO TYPES, WHICH ARE:
1) FAILED TO DO A BOOTSTRAP; 2) BOOTSTRAP FAILED TO COMPARE,
ANY ERRORS DUE TO 2 ABOVE WILL RESULT IN A ERROR HALT AT LOCATION 5133 FOR MAINDEC-08-DJKMA-A-PB1 OR AT LOCATION 1733 FOR MAINDEC-08-DJKMA-A-PM3, THE CONTENTS OF THE AC WILL CONTAIN THE ADDRESS WHERE THE ERROR WAS DETECTED BY THE PROGRAM,

5,3,1 BOOTSTRAP TEST ERROR RECOVERY

FOR FAILURE TYPE 1 ABOVE, CHECK FOR CORRECT SWITCH SETTINGS ON THE MB317 MODULE AND TRY AGAIN, IF THIS STILL DOES NOT PRODUCE A BOOTSTRAP, USE A SCOPE AND THE LOGIC PRINTS TO TROUBLE SHOOT THE ERROR,

FOR FAILURE TYPE 2 ABOVE, PRESSING CONTINUE 3 MORE TIMES WILL RESULT IN 3 MORE HALTS, WHICH WILL GIVE THE ADDRESS WHICH DIDN'T COMPARE, THE EXPECTED CONTENT OF THAT ADDRESS AND THE ACTUAL CONTENT OF THAT ADDRESS, IF THE OPTION 1 + 2 TEST MODULE WAS UTILIZED WITH THE PROGRAM, SET THE SWITCH REGISTER OR PSEUDO SWITCH REGISTER WHICH EVER WAS SELECTED TO 7000 AND PRESS "INIT" AND THEN "RUN", THE PROGRAM MAY HALT ONE MORE TIME AND THEN REPEAT THE SEQUENCE, THE PROGRAM IS NOW IN A SCOPE LOOP DOING THE BOOTSTRAPS, IF THE TEST MODULE WAS NOT USED, REPEAT THE BOOTSTRAP SEQUENCE SEVERAL TIMES, USING THE SCOPE AND LOGIC PRINTS TO TROUBLE SHOOT WITH,

5,4 AUTO RESTART/POWER FAIL TEST ERRORS

ANY ERRORS ENCOUNTERED DURING THIS TEST MAY BE DO TO THE BATTERY BEING DISCHARGED, IMPROPER MODULE SWITCH SETUP, FAILURE TO DO A AUTO RESTART, A AUTO RESTART TO THE WRONG ADDRESS, OR A DATA COMPARE ERROR,

5,4,1 AUTO RESTART/POWER FAIL TEST ERROR RECOVERY

AFTER ASSURING THE MODULE TO BE SETUP CORRECTLY AND RETRYING THE TEST, USE A SCOPE AND THE LOGIC PRINTS TO TROUBLE SHOOT THE PROBLEM,

6,0 SWITCH REGISTER SETTINGS

6,1 NORMAL OPERATING SWITCHES

SR3=1 (0400) HALT PROGRAM AT COMPLETION OF A PROGRAM PASS,

6,2 ERROR RELATED SWITCHES

SR0=1 (4000) INHIBIT ERROR HALT
SR1=1 (2000) LOOP ON ERROR
SR2=1 (1000) LOOP ON TEST SUCH AS TEST1, TEST2, ETC.,

7,0 REVISIONS

NONE

8,0 PROGRAM DESCRIPTION

TEST 1 - CHECKS THE GDF AND RDF INSTRUCTIONS TO LOAD AND READ THE DATA FIELD REGISTER, A RIF INSTRUCTION IS ISSUED AFTER EACH DATA FIELD CHANGE TO CHECK THAT THE INSTRUCTION FIELD REMAINS A ZERO; THE INCLUSIVE OR FUNCTION OF THE DATA FIELD AND THE AC IS CHECKED WITH THE RDF INSTRUCTION,

TEST 2 - CHECKS THAT USER MODE CAN BE ENTERED AND EXITED BY DOING A ION=SUF=JMP=HLT, THE USER INTERRUPT IS CHECKED TO BE SET BY SINT AND CLEARED BY CINT, GTF AND RIB INSTRUCTIONS ARE ISSUED TO CHECK THAT THE SAVE FIELD REGISTERS GOT LOADED AND THAT THE INSTRUCTIONS CAN READ THE SAVE FIELD REGISTERS,

TEST 3 - CHECKS THAT USR WILL TRAP IN USER MODE AND THAT IT WILL NOT AFTER A USER INTERRUPT, RIB,GTF,RIF AND RDF INSTRUCTIONS ARE ISSUED TO CHECK THAT THEY READ THE APPROPRIATE REGISTERS,

TEST 4 - CHECKS THAT AN IOT WILL TRAP IN USER MODE AND THAT IT WILL NOT AFTER A USER INTERRUPT, THE USER INTERRUPT IS CHECKED TO BE CLEARED BY CAF, RIB AND GTF INSTRUCTIONS ARE ALSO ISSUED AND CHECKED,

TEST 5 - CHECKS THAT THE CUF INSTRUCTION WILL CLEAR THE USER MODE FLIP-FLOP BY DOING A SUF-CUF-JMP-IOT, THE IOT INSTRUCTION SHOULD NOT TRAP, RIB AND GTF INSTRUCTIONS ARE ISSUED AND CHECKED,

TEST 6 - CHECKS THAT USER MODE IS NOT ENTERED UNTIL A JMS INSTRUCTION IS ISSUED BY DOING A ION-SUF-IOT-OSR-LAS-JMS-HLT, INTERRUPT REQUEST AND LINK ARE CHECKED WITH THE GTF INSTRUCTION,

TEST 7 - CHECKS THAT THE USER FLAG IN THE SAVE FIELD REGISTER CAN BE CLEARED, THIS IS DONE BY LEAVING THE USER INTERRUPT F/F SET AFTER A TRAP AND THEN TURNING THE INTERRUPT BACK ON,

TEST 8 - CHECKS THAT THE RIF INSTRUCTION WILL RESET THE USER MODE AFTER A INTERRUPT,

TEST 9 - CHECKS THAT THE RME INSTRUCTION WILL RESET THE USER MODE AFTER A INTERRUPT,

TEST 10 - CHECKS THAT USER MODE, LINK, AND ION CAN BE SET BY THE AQ AND THE RTF INSTRUCTION AND THAT IT CAN BE CLEARED BY RTF,

TEST 11 - USING THE USER INTERRUPT F/F AND INTERRUPT ENABLE, THE INSTRUCTION FIELD REGISTER CAN BE INDIRECTLY CHECKED TO HAVE SET BY CHECKING THE SAVE FIELD REGISTER AFTER A INTERRUPT, THE INSTRUCTION FIELD REGISTER IS CHECKED NOT TO CHANGE UNTIL A JMP OR JMS INSTRUCTION IS ISSUED, THE INTERRUPT INHIBIT F/F IS CHECKED NOT TO CLEAR BEFORE A JMP OR JMS IS ISSUED,

TEST 12 - USES THE USER INTERRUPT F/F TO CAUSE INTERRUPTS TO CHECK THAT THE CIF AND CDF INSTRUCTIONS WILL LOAD THE APPROPRIATE SAVE FIELD REGISTERS, A DCA INDIRECT IS CHECKED NOT TO CHANGE A LOCATION IN FIELD ZERO WHEN THE DATA FIELD IS NON ZERO, A JMS INDIRECT IS CHECKED NOT TO CHANGE A LOCATION IN FIELD ZERO WHEN THE INSTRUCTION FIELD IS NON ZERO,

TEST 13 - CHECKS THE MICRO PROGRAM INSTRUCTIONS CUPCIF (62X3), A DCA INDIRECT AND A JMS INSTRUCTION ARE ALSO ISSUED TO CHECK THAT THESE INSTRUCTIONS DO NOT DESTROY LOCATIONS IN FIELD ZERO, THE USER INTERRUPT F/F IS USED TO CAUSE INTERRUPTS,

TEST 14 - CHECKS THAT THE RIF INSTRUCTION CAN LOAD THE INSTRUCTION FIELD AND DATA FIELD, AND THAT THE RME INSTRUCTION CAN RELOAD IT, THE USER INTERRUPT F/F IS USED TO CAUSE INTERRUPTS,

TEST 15 - SETS THE USER BUFFER F/F, THE IF AND DF ARE SET TO FIELD 6, THE PROGRAM THEN ISSUES A DCA, TAD, AND, AND ISZ INDIRECTS TO CHECK THAT THE PROGRAM DOESN'T INTERRUPT UNTIL A JMP INSTRUCTION IS ISSUED,

TEST 16 - REQUIRES MORE THAN 4K OF MEMORY TO BE RUN, THIS TEST IS A SIMPLE DATA TEST TO CHECK THAT THE DATA CAN BE DEPOSITED INTO EACH SELECTED EXTENDED FIELD, DATA IS DEPOSITED INTO THE LAST ADDRESS OF EACH 1K MEMORY SEGMENT IN THE EXTENDED MEMORY FIELD, THE USER INTERRUPT IS SET FOR THIS TEST, THE PROGRAM CHANGES THE DATA FIELD TO A EXTENDED FIELD, CHECKS THE DF, THEN TURNS THE INTERRUPT ON AND DOES A DCA INDIRECT TO THE LAST ADDRESS IN A 1K MEMORY SEGMENT OF THAT FIELD, THE PROGRAM THEN DOES THE SAME AS ABOVE ONLY DOING A TAD INDIRECT TO THE LAST ADDRESS OF A 1K MEMORY SEGMENT, THE DATA THAT IS PUT INTO THE LAST ADDRESS OF EACH EXTENDED 1K MEMORY SEGMENT CONTAINS THE FIELD IN BITS 6-8 AND THE NUMBER

OF THE 1K SEGMENT IN BITS 9-11.

TEST 17 - REQUIRES MORE THAN 4K OF MEMORY TO BE RUN. THIS TEST CHECKS THE RIF INSTRUCTION TO READ THE INSTRUCTION FIELD REGISTER. THE PROGRAM DEPOSITS THE FOLLOWING CODE INTO LOCATIONS 0000 TO 0003 OF EACH SELECTED EXTENDED FIELD; RIF-ION=JMP I 3-T17RET=1. THE PROGRAM USES THE USER INTERRUPT F/F TO RETURN TO THE PROGRAM.

TEST 18 - IS ONLY EXECUTED IF THE OPTION 1 + 2 TEST MODULE IS SELECTED. THIS TEST CHECKS THAT THE CORRECT EMA LINE IS LOADED ONTO THE BUS DURING A OCA INDIRECT FOLLOWING A CDF 10, CDF 20 AND A CDF 40. THE TEST MODULE IS USED TO CAUSE A INTERRUPT FOLLOWING A EMA CHANGE ON THE BUS. THE TEST MODULE STORES THE EMA INTO A EMA CATCHER REGISTER AND THEN THE PROGRAM READS AND COMPARES IT.

TEST 19 - IS ONLY EXECUTED IF THE OPTION 1 + 2 TEST MODULE IS SELECTED. THIS TEST IS THE SAME AS TEST 18, ONLY IT CHECKS THAT THE CIP INSTRUCTION LOADS THE APPROPRIATE EMA LINES.

TEST 20 - IS ONLY EXECUTED IF THE OPTION 1 + 2 TEST MODULE IS SELECTED. THIS TEST CHECKS THAT THE TIME SHARE LOGIC CAN BE DISABLED. THIS IS DONE WITH THE TEST MODULE BY PULLING KMTS TIME SHARE DISABLE L LOW. THE PROGRAM THEN ISSUES A IOT, LAS, OSR AND CHECKS THAT THE PROGRAM DIDN'T INTERRUPT.

TEST 21 - USES THE OPTION 1 + 2 TEST MODULE TO CAUSE THE M8317 MODULE TO DO A BOOTSTRAP. AFTER EACH BOOTSTRAP, THE PROGRAM CHECKS THE BOOTSTRAPS TO COMPARE CORRECTLY.

TEST 22 - USES THE OPTION 1 + 2 TEST MODULE TO CAUSE A AUTO RESTART ON THE M8317 MODULE. AFTER EACH AUTO RESTART, THE PROGRAM CHECKS THAT THE AUTO RESTART OCCURED AT THE APPROPRIATE LOCATION.

TEST 23 - USES THE OPTION 1 + 2 TEST MODULE TO TEST THAT THE AC LOW AND BATTERY EMPTY F/F'S CAN BE SET, CAUSE A INTERRUPT, AND THAT THEY CAN BE CLEARED.

TIMDIS - IS A OPERATOR INTERVENTION TEST TO CHECK THAT THE TIME SHARE LOGIC CAN BE DISABLED.

ROTCMP - IS A OPERATOR INTERVENTION TEST TO CHECK THAT THE BOOTSTRAPS GOT LOADED CORRECTLY.

AUTO - IS A OPERATOR INTERVENTION TEST TO CHECK AUTO RESTARTS AND POWER FAIL.

9,0 FLOWCHARTS

NOT APPLICABLE

10,0 LISTING

ATTACHED

/KMB=A OPTION TEST 2 MAINDEC=08=DJKMA=A=L 4K
/COPYRIGHT (C) 1974, DIGITAL EQUIPMENT CORPORATION
/PROGRAMMER: BRUCE HANSEN

////////////////////////////////////
/THE FOLLOWING LISTING WILL CORRESPOND TO THE PAPER TAPE LABELED MAINDEC=08=DJKMA=A-PB1,
/THIS PAPER TAPE AND LISTING WILL BE USED WITH COMPUTERS WITH 4K OF MEMORY OR MORE,
/THERE ARE FOUR 1K SEGMENTED LISTINGS ATTACHED TO THE END OF THIS LISTING FOR
/COMPUTERS WITH LESS THAN 4K OF MEMORY; REFER TO THE APPROPRIATE 1K LISTING FOR
/FOR ANY ERRORS WHICH MAY HAVE OCCURED WHILE RUNNING THE 1K SEGMENTED PROGRAMS,
////////////////////////////////////

/KMB=A OPTION TEST 2 MAINDEC=08=DJKMA=A=L 4K
/COPYRIGHT 1974, DIGITAL EQUIPMENT COMP., MAYNARD, MASS., 01754
/PDP=8A OPTION TEST 2 TESTS THE MEMORY EXTENTION/TIME SHARE CONTROL,
/POWER FAIL/AUTO RESTART, AND BOOTSTRAP LOADERS

6000 SKON=0000
6007 CAF=0007
7402 HLT=7402

/SWITCH REGISTER SETTINGS

/SR0=1 INHIBIT ERROR HALT
/SR1=1 LOOP ON ERROR
/SR2=1 LOOP ON TEST
/SR3=1 HALT AT COMPLETION OF A PROGRAM PASS

/MEMORY EXTENTION/TIME SHARE INSTRUCTIONS

6004 GTF=0004 /GET FLAGS; READS THE FOLLOWING MACHINE STATES
/INTO THE INDICATED BITS OF THE AC1
/AC0 LINE
/AC2 INTERRUPT REQUEST
/AC4 INTERRUPT ENABLE F/F
/AC5 USER FLAG
/AC6=11 SAVE FIELD REGISTER

6005 RTF=0002 /RESTORE THE FLAGS; RTF LOADS THE LINK FROM AC0,
/LOADS THE USER BUFFER F/F, INSTRUCTION BUFFER AND
/DATA FIELD WITH AC5, AC6=8, AC 9=11 AND INHIBITS
/PROCESSOR INTERRUPTS UNTIL NEXT JMP OR JMS INSTRUCTION,
/AT THE END OF THE JMP OR JMS, THE CONTENTS OF THE U.B. + 1,8,
/ARE LOADED INTO USER FIELD F/F, AND THE I.F., INTERRUPT ENABLE
/IS SET AND INTERRUPT INHIBIT IS CLEARED

6234 RIB=0234 /READ THE INTERRUPT BUFFER

6244 RMF=0244 /RESTORES MEMORY FLAGS

6204 CINT=0204 /CLEAN USER INTERRUPT FLIP=FLOP

6254 SINT=0254 /SKIP ON USER INTERRUPT FLIP=FLOP

6204 CUF=0204 /CLEAN USER BUFFER FLIP=FLOP

6274 SUP=0274 /SET USER BUFFER FLIP=FLOP (ENTER TIME SAME MODE)AND
/INHIBITS PROCESSOR INTERRUPTS UNTIL THE NEXT JMP OR
/JMS INSTRUCTION, AT THE END OF THE JMP OR JMS
/INSTRUCTION, THE USER BUFR IS LOADED INTO THE USER
/FIELD F/F;

6201 CDF=0201 /CHANGE DATA FIELD

```

6202 CIF#0202 /CHANGE INSTRUCTION FIELD
6214 RDP#0214 /READ THE DATA FIELD INTO AC BITS 6=8
6224 RIF#0224 /READ THE INSTRUCTION FIELD INTO AC BITS 6=8
6203 CIFGPF#0203 /PERFORMS THE CIF AND CDF FUNCTIONS

/POWER FAIL INSTRUCTIONS

6102 SPL#0102 /SKIP ON AC LOW FLIP=FLOP
6103 CAL#0103 /CLEAN AC LOW FLIP=FLOP
6101 SBE#0101 /SKIP ON BATTERY EMPTY FLIP=FLOP

/OPTION BOARD 2 SIMULATOR IOT/IS

6150 CLRSM#0150 /CLEAN CONTROL REGISTERS
6192 LODMG2#0192 /LOAD CONTROL REGISTER 2
6193 LODMG3#0193 /LOAD CONTROL REGISTER 3
6194 CLREMA#0194 /CLEAN EMA CATCHER LOGIC
6195 REDEMA#0195 /READ EMA CATCHER REGISTER
6160 CLRMOU#0160 /CLEAN TEST MODULE LOGIC
6164 EXECUT#0164 /EXECUT AND CONTROL WORD 3 BIT 7 =1 ISSUE A POWER ON PULSE
/EXECUT AND CONTROL WORD 3 BIT 7 =0 ISSUE A SWITCH SW PULSE
6166 SKPEMA#0166 /SKPEMA AND CONTROL WORD 3 BIT 3 =1 EMA INTERRUPT AND SKIP ENABLE
/ SKPEMA AND CONTROL WORD 3 BIT 3 =0 EMA INTERRUPT AND SKIP DISABLE

/OPTION BOARD2 SIMULATOR CONTROL WORD 2 BIT ASSIGNMENTS
/
/BITS 0 = 1 NOT USED
/BITS 2 = 3 BOOT STRAP PROGRAM SELECT
/BITS 9 = 11 AUTO=RESTART ADDRESS SELECT

/OPTION BOARD 2 SIMULATOR CONTROL WORD 3 BIT ASSIGNMENTS
/
/BIT 0 TIME SHARE 0=ENABLED 1=DISABLED
/BIT 1 AC LOW (L) 1=PULLED LOW 0=FREE STATE
/BIT 2 BATT EMPTY 1=BATT EMPTY PULLED LOW 0=FREE STATE
/BIT 3 1=EMA INTERRUPT/SKIP ENABLE 0=EMA INTERRUPT SKIP DISABLE
/BITS 4 = 6 NOT USED
/BIT 7 1=POWER ON PULSE WITH EXECUT 0=SWITCH SW PULSE WITH EXECUT
/BIT 8 1=DISABLES BOOTSTRAP WHILE RUNNING 0=ENABLES BOOTSTRAP WHILE RUNNING
/BIT 9 = 11 AUTO=RESTART/BOOT STRAP ENABLE CODE
    
```

```

0000 *0
0000 0000 INTSER, 0 /JMS I AUTHST PLACED HERE FOR SIMULATOR AUTO RESTART
0001 3035 DCA DATREC
0002 6102 SPL /SKIP ON AC LOW
0003 7410 SKP
0004 5457 JMP I XPHRFL /POWER GOING DOWN
0005 6101 SBE /SKIP ON BATTERY EMPTY
    
```

```

0006 7410 SKP
0007 5460 JMP I XBAT /GO HALT THE COMPUTER ,ITS ALL OVER
0010 6224 RIF /READ THE INSTRUCTION FIELD
0011 7640 SEA CLA
0012 4454 ERROR /I,F, IS NOT 0 AFTER A INTERRUPT
0013 6214 RDP /READ THE DATA FIELD
0014 7640 SEA CLA
0015 4454 ERROR /O,F, IS NOT 0 AFTER A INTERRUPT
0016 2000 ISE INTSER /ADD 1 TO THE INTERRUPTED PC
0017 5400 JMP I INTSER /RETURN TO THE PROGRAM

0020 *20
0020 0000 SWITCH, 0 /PSEUDO SWITCH REGISTER IF BIT 0=0 OF OP1SEL
0021 1003 OP1SEL, 1003
/BIT 0=0 USE LOC 20 AS A PSEUDO S,R,
/BIT 0=1 USE HARDWARE FRONT PANEL S,R,
/BIT 1=1 HAS BA OPTION 1
/BIT 2=1 HAS BA OPTION 2
/BIT 3=1 HAS BA CPU SIMULATOR
/BIT 4=1 HAS BA OPTION 1 + 2 TEST MODULE
/BIT 5=1 PROGRAM ON BA XOR
/BIT 6=1 HAS PDP-8E TYPE CPU
/BITS 7=11 MEMORY SIZE = 0'S = 1K, 37=32K,
/MEMORY SIZE CAN BE INCREASED IN 1K INCREMENTS
/BY ADDING A 1 TO THE NUMBER IN BITS 7=11,

0022 0000 OP2SEL, 0
/RRKE BOOT STRAP WILL LOAD INTO THE FOLLOWING LOCATIONS

0023 7402 RRKE, HLT /2000
0024 7402 HLT /6745
0025 7402 HLT /0023
0026 7402 HLT /7650
0027 7402 HLT /5024
0030 7402 HLT /6733
0031 7402 HLT /5031
0032 7402 HLT /TERMINATOR
0033 0000 CDFCHK, 0
0034 0033 CHKOP, CDFCHK
0035 0000 DATHEQ, 0
0036 0000 SAVESZ, 0
0037 0000 FLDLIM, 0
0040 0000 UPENLM, 0
0041 0000 WRKFLU, 0
0042 0000 DATPAT, 0
0043 0000 WRKADD, 0
0044 0000 HQLLIM, 0
0045 6201 K6201, 6201
0046 0000 SAVWPU, 0
0047 0000 ADDQNT, 0
0050 6520 BDDPAS, 6520
0051 6500 GDDUPS, 6500
0052 5053 AUTHST, PRGRST
0053 0000 TEST, 0 /SCOPE LOOP AND TEST LOOP ADDRESS
    
```

```

0054 4454 ERROR# JMS I ;
      5110          ; ERRORX
0055 4455 LOOP# JMS I ;
0056 5152          ; TSTLOP
      4456 SCOPLP# JMS I ;
0056 5060          ; TESTAD

0057 5043 XPWFPL; POWFAL
0060 5067 XBAT; BATEMT
0061 5017 PASENU; ENDPAS
    
```

/CONSTANTS USED BY THE PROGRAM

```

0062 7777 M1; =1
0063 7776 M2; =2
0064 7774 M4; =4
0065 7773 M5; =5
0066 7771 M7; =7
0067 7770 M10; =10
0070 7767 M11; =11
0071 7762 M16; =16
0072 7760 M20; =20
0073 7756 M22; =22
0074 7753 M25; =25
0075 7750 M30; =30
0076 7745 M33; =33
0077 7744 M34; =34
0100 7740 M40; =40
0101 7735 M43; =43
0102 7734 M44; =44
0103 7730 M50; =50
0104 7726 M52; =52
0105 7723 M55; =55
0106 7720 M60; =60
0107 7717 M61; =61
0110 7712 M66; =66
0111 7710 M70; =70
0112 7701 M77; =77
0113 7700 M100; =100
0114 7693 M125; =125
0115 7626 M152; =152
0116 7500 M300; =300
0117 7000 M1000; =1000
0120 6771 M1007; =1007
0121 6762 M1016; =1016
0122 6753 M1025; =1025
0123 6744 M1034; =1034
0124 6735 M1043; =1043
0125 6726 M1052; =1052
0126 6717 M1061; =1061
0127 6710 M1070; =1070
0130 6700 M1100; =1100
0131 3700 M4100; =4100
    
```

```

0132 3000 M5000; =5000
0133 2700 M5100; =5100

0134 0007 K7; 7
0135 0010 K10; 10
0136 0037 K37; 37
0137 0070 K70; 70
0140 0077 K77; 77
0141 0125 K125; 125
0142 0152 K152; 152
0143 0200 K200; 200
0144 0400 K400; 400
0145 1777 K1777; 1777
0146 2000 K2000; 2000
0147 7774 K7774; 7774
0150 7707 K7707; 7707
0151 7757 K7757; 7757
0152 7677 K7677; 7677
0153 4100 K4100; 4100

0200 =200
    
```

```

/*****
/TEST 1 = CHECKS THE CDF AND RDF INSTRUCTIONS TO LOAD AND READ
/THE DATA FIELD, A RIF IS ISSUED AFTER EACH DATA FIELD CHANGE
/TO CHECK THAT THE INSTRUCTION FIELD REMAINS A ZERO,
/THE INCLUSIVE OR OF THE D,F, WITH THE AC IS CHECKED WITH THE RDF INSTRUCTION,
/SET TIME SHARE ENABLE SWITCH TO TIME SHARE ENABLE POSITION
/*****
    
```

```

0200 7000 TEST1; NOP/JMS I ATRST /IF SIMULATOR SELECTED THIS LOCATION WILL CHANGE TO JMS I ATRST
0201 6160          CLRMOD /CLEAR SIMULATOR TEST LOGIC
0202 3777          DCA ACNLOK
0203 4456          SCOPLP /SETUP SCOPE ANND TEST LOOPING ADDRESS
0204 6007          CAF /CLEAR ALL FLAGS
0205 6264          CUF /CLEAR USER FLAG
0206 7410          SKP
0207 4454          ERROR /CUF SKIPPED
0210 6254          SINT /SKIP IF USER INTERRUPT FLIP=FLOW SET
0211 7410          SKP
0212 4454          ERROR /SINT SKIPPED OR CAF FAILED TO 0 USER INTERRUPT
0213 0001          IOV /TURN THE INTERRUPT ON
0214 6201          CDF 00 /CHANGE DATA FIELD TO FIELD 0
0215 7410          SKP
0216 4454          ERROR /CDF SKIPPED
0217 6214          RDF /READ THE DATA FIELD
0220 7410          SKP
0221 4454          ERROR /RDF SKIPPED
0222 7640          SEA CLA /WAS IF FIELD 0?
0223 4454          ERROR /RDF READ BACK SOMETHING OTHER THAN D,F, 0
0224 6224          RIF /READ THE INSTRUCTION FIELD
0225 7410          SKP
0226 4454          ERROR /RIF SKIPPED
    
```

```

0227 7640 SEA CLA /WAS THE I,F, 0?
0230 4454 ERROR /RIF HEAD BACK SOMETHING OTHER THAN I,F, 0
0231 6271 CDF 70 /CHANGE DATA FIELD TO FIELD 7
0232 6214 RDF /READ THE DATA FIELD
0233 1111 TAD M70 /CHECK THAT DATA FIELD 7 WAS READ BACK
0234 7640 SEA CLA /INTD AC BITS 6,7 = 5?
0235 4454 ERROR /CDF OR RDF TO FIELD 7 FAILED
0236 1190 TAD K7787 /CHECK THE INCLUSIVE OR FUNCTION OF RDF
0237 6214 RDF /READ THE DATA FIELD
0240 7040 CMA
0241 7640 SEA CLA
0242 4454 ERROR /THE INCLUSIVE OR OF THE DF WITH AC FAILED
0243 6224 RIF /READ THE INSTRUCTION FIELD
0244 7640 SEA CLA /IS IT STILL 0?
0245 4454 ERROR /THE INSTRUCTION FIELD CHANGED
0246 6221 CDF 20 /CHANGE TO DATA FIELD 2
0247 6214 RDF /READ THE DATA FIELD
0250 1072 TAD M20 /CHECK TO SEE IF DF 2 WAS READ BACK
0251 7640 SEA CLA /WAS IT DATA FIELD 2?
0252 4454 ERROR /NO, CDF 20 OR RDF FAILED
0253 1191 TAD K7787 /CHECK THE INCLUSIVE OR OF THE DF WITH THE AC
0254 6214 RDF /READ THE DATA FIELD
0255 7040 CMA
0256 7640 SEA CLA
0257 4454 ERROR /THE INCLUSIVE OR OF DF WITH AC FAILED
0260 6224 RIF /READ THE INSTRUCTION FIELD
0261 7640 SEA CLA /IS THE IF STILL 0?
0262 4454 ERROR /THE INSTRUCTION FIELD CHANGED
0263 6251 CDF 50 /CHANGE TO DATA FIELD 5
0264 6214 RDF /READ THE DATA FIELD
0265 1103 TAD M50 /
0266 7640 SEA CLA /WAS IT DATA FIELD 5?
0267 4454 ERROR /NO, CDF 50 OR RDF FAILED
0270 6224 RIF /READ THE INSTRUCTION FIELD
0271 7640 SEA CLA /IS THE I,F, STILL 0?
0272 4454 ERROR /NO, THE INSTRUCTION FIELD CHANGED
0273 6231 CDF 30 /CHANGE THE DATA FIELD TO 3
0274 6214 RDF /READ THE DATA FIELD
0275 1075 TAD M30 /
0276 7640 SEA CLA /IS IT EQUAL TO FIELD 3?
0277 4454 ERROR /NO, CDF 30 OR RDF FAILED
0300 6224 RIF /READ THE INSTRUCTION FIELD
0301 7640 SEA CLA /IS THE I,F, STILL EQUAL TO 0?
0302 4454 ERROR /NO, THE I,F, CHANGED
0303 6241 CDF 40 /CHANGE THE DATA FIELD TO FIELD 4
0304 6214 RDF /READ THE DATA FIELD
0305 1100 TAD M40 /
0306 7640 SEA CLA /IS IT EQUAL TO D,F, 4?
0307 4454 ERROR /NO, CDF 40 OR RDF FAILED
0310 6224 RIF /READ THE INSTRUCTION FIELD
0311 7640 SEA CLA /IS IT STILL EQUAL TO 0?
0312 4454 ERROR /NO, THE I,F, CHANGED
0313 6211 CDF 10 /CHANGE THE DATA FIELD TO FIELD 1
0314 6214 RDF /READ THE DATA FIELD
0315 1067 TAD M10 /

```

```

0316 7640 SEA CLA /IS IT EQUAL TO DATA FIELD 1
0317 4454 ERROR /NO, CDF 10 OR RDF FAILED
0320 6224 RIF /READ THE INSTRUCTION FIELD
0321 7640 SEA CLA /IS IT STILL EQUAL TO 0?
0322 4454 ERROR /NO, THE I,F, CHANGED
0323 6261 CDF 60 /CHANGE DATA FIELD TO FIELD 6
0324 6214 RDF /READ THE DATA FIELD
0325 1106 TAD M60 /
0326 7640 SEA CLA /IS THE D,F, EQUAL TO 6?
0327 4454 ERROR /NO, CDF 60 OR RDF FAILED
0330 6224 RIF /READ THE INSTRUCTION FIELD
0331 7640 SEA CLA /IS IT STILL EQUAL TO ZERO?
0332 4454 ERROR /NO, INSTRUCTION FIELD CHANGED
0333 6201 CDF 00 /CHANGE DATA FIELD TO FIELD 0
0334 6214 RDF /READ THE DATA FIELD
0335 7640 SEA CLA /IS IT EQUAL TO FIELD 0?
0336 4454 ERROR /NO, CDF 00 OR RDF FAILED
0337 6224 RIF /READ THE INSTRUCTION FIELD
0340 7640 SEA CLA /IS IT STILL EQUAL TO ZERO?
0341 4454 ERROR /NO, INSTRUCTION FIELD CHANGED,
0342 4455 LOOP /LOOP ON TEST IF SR = 1000

```

.....
 /TEST 2 = CHECKS THAT USER MODE CAN BE ENTERED AND EXITED BY DOING A
 /ION=SUJ=JMP=HLT, THE USER INTERRUPT IS CHECKED TO BE SET BY SINT AND
 /CLEARED BY CINT, GTF AND RIB ARE ISSUED TO CHECK THAT THE SAVE FIELD
 /GOI LOADED AND THAT THE INSTRUCTIONS CAN READ THE SAVE FIELD,


```

0343 4456 TEST2, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0344 6007 CAF /CLEAR ALL FLAGS
0345 6264 CUF /CLEAR USER BUFFER F/F
0346 7410 SKP
0347 4454 ERROR /CUF SKIPPED
0350 6204 CINT /CLEAR USER INTERRUPT FLIP=FLOP
0351 7410 SKP
0352 4454 ERROR /CINT SKIPPED
0353 6294 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
0354 7410 SKP
0355 4454 ERROR /SINT SKIPPED OR USER INTERRUPT F/F SET
0356 6001 ION /TURN THE INTERRUPT ON
0357 6274 SUP /SET USER BUFFER F/F, SET INT INHIBIT AT TP3
0360 5362 JMP ,*2 /LOAD 08 INTO I,F, REGISTER, CLEAR INT INHIBIT F/F
0361 5361 JMP /SUJ SKIPPED OR TRAPPED,
0362 7402 HLT /USER INTERRUPT FAILED TO SET OR HALT FAILED TO TRAP
0363 5363 JMP /HLT FAILED TO TRAP
0364 6294 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
0365 5365 JMP /USER INTERRUPT NOT SET OR SINT FAILED TO SKIP,
0366 6204 CINT /CLEAR USER INTERRUPT FLIP=FLOP
0367 6294 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
0370 7410 SKP
0371 5371 JMP /CINT FAILED TO 2 USER INTERRUPT FLIP=FLOP
0372 5776 JMP /CONTINUE THE TEST

```

```

0477 5173
0480 5601
0481 3671
0482 6004
0483 7410
0484 9204
0485 1113
0486 7640
0487 9207
0488 7300
0489 6234
0490 7410
0491 9213
0492 1113
0493 7640
0494 9218
0495 1192
0496 6234
0497 7040
0498 7640
0499 9223
0500 7340
0501 6004
0502 1113
0503 7640
0504 9230
0505 4455
0506 4455
0507 4455
0508 4455
0509 4455
0510 4455
0511 4455
0512 4455
0513 4455
0514 4455
0515 4455
0516 4455
0517 4455
0518 4455
0519 4455
0520 4455
0521 4455
0522 4455
0523 4455
0524 4455
0525 4455
0526 4455
0527 4455
0528 4455
0529 4455
0530 4455
0531 4455
0532 4455
0533 4455
0534 4455
0535 4455
0536 4455
0537 4455
0538 4455
0539 4455
0540 4455
0541 4455
0542 4455
0543 4455
0544 4455
0545 4455
0546 4455
0547 4455
0548 4455
0549 4455
0550 4455
0551 4455
0552 4455
0553 4455
0554 4455
0555 4455
0556 4455
0557 4455
0558 4455
0559 4455
0560 4455
0561 4455
0562 4455
0563 4455
0564 4455
0565 4455
0566 4455
0567 4455
0568 4455
0569 4455
0570 4455
0571 4455
0572 4455
0573 4455
0574 4455
0575 4455
0576 4455
0577 4455
0578 4455
0579 4455
0580 4455
0581 4455
0582 4455
0583 4455
0584 4455
0585 4455
0586 4455
0587 4455
0588 4455
0589 4455
0590 4455
0591 4455
0592 4455
0593 4455
0594 4455
0595 4455
0596 4455
0597 4455
0598 4455
0599 4455
0600 4455
0601 4455
0602 4455
0603 4455
0604 4455
0605 4455
0606 4455
0607 4455
0608 4455
0609 4455
0610 4455
0611 4455
0612 4455
0613 4455
0614 4455
0615 4455
0616 4455
0617 4455
0618 4455
0619 4455
0620 4455
0621 4455
0622 4455
0623 4455
0624 4455
0625 4455
0626 4455
0627 4455
0628 4455
0629 4455
0630 4455
0631 4455
0632 4455
0633 4455
0634 4455
0635 4455
0636 4455
0637 4455
0638 4455
0639 4455
0640 4455
0641 4455
0642 4455
0643 4455
0644 4455
0645 4455
0646 4455
0647 4455
0648 4455
0649 4455
0650 4455
0651 4455
0652 4455
0653 4455
0654 4455
0655 4455
0656 4455
0657 4455
0658 4455
0659 4455
0660 4455
0661 4455
0662 4455
0663 4455
0664 4455
0665 4455
0666 4455
0667 4455
0668 4455
0669 4455
0670 4455
0671 4455
0672 4455
0673 4455
0674 4455
0675 4455
0676 4455
0677 4455
0678 4455
0679 4455
0680 4455
0681 4455
0682 4455
0683 4455
0684 4455
0685 4455
0686 4455
0687 4455
0688 4455
0689 4455
0690 4455
0691 4455
0692 4455
0693 4455
0694 4455
0695 4455
0696 4455
0697 4455
0698 4455
0699 4455
0700 4455
0701 4455
0702 4455
0703 4455
0704 4455
0705 4455
0706 4455
0707 4455
0708 4455
0709 4455
0710 4455
0711 4455
0712 4455
0713 4455
0714 4455
0715 4455
0716 4455
0717 4455
0718 4455
0719 4455
0720 4455
0721 4455
0722 4455
0723 4455
0724 4455
0725 4455
0726 4455
0727 4455
0728 4455
0729 4455
0730 4455
0731 4455
0732 4455
0733 4455
0734 4455
0735 4455
0736 4455
0737 4455
0738 4455
0739 4455
0740 4455
0741 4455
0742 4455
0743 4455
0744 4455
0745 4455
0746 4455
0747 4455
0748 4455
0749 4455
0750 4455
0751 4455
0752 4455
0753 4455
0754 4455
0755 4455
0756 4455
0757 4455
0758 4455
0759 4455
0760 4455
0761 4455
0762 4455
0763 4455
0764 4455
0765 4455
0766 4455
0767 4455
0768 4455
0769 4455
0770 4455
0771 4455
0772 4455
0773 4455
0774 4455
0775 4455
0776 4455
0777 4455
0778 4455
0779 4455
0780 4455
0781 4455
0782 4455
0783 4455
0784 4455
0785 4455
0786 4455
0787 4455
0788 4455
0789 4455
0790 4455
0791 4455
0792 4455
0793 4455
0794 4455
0795 4455
0796 4455
0797 4455
0798 4455
0799 4455
0800 4455
0801 4455
0802 4455
0803 4455
0804 4455
0805 4455
0806 4455
0807 4455
0808 4455
0809 4455
0810 4455
0811 4455
0812 4455
0813 4455
0814 4455
0815 4455
0816 4455
0817 4455
0818 4455
0819 4455
0820 4455
0821 4455
0822 4455
0823 4455
0824 4455
0825 4455
0826 4455
0827 4455
0828 4455
0829 4455
0830 4455
0831 4455
0832 4455
0833 4455
0834 4455
0835 4455
0836 4455
0837 4455
0838 4455
0839 4455
0840 4455
0841 4455
0842 4455
0843 4455
0844 4455
0845 4455
0846 4455
0847 4455
0848 4455
0849 4455
0850 4455
0851 4455
0852 4455
0853 4455
0854 4455
0855 4455
0856 4455
0857 4455
0858 4455
0859 4455
0860 4455
0861 4455
0862 4455
0863 4455
0864 4455
0865 4455
0866 4455
0867 4455
0868 4455
0869 4455
0870 4455
0871 4455
0872 4455
0873 4455
0874 4455
0875 4455
0876 4455
0877 4455
0878 4455
0879 4455
0880 4455
0881 4455
0882 4455
0883 4455
0884 4455
0885 4455
0886 4455
0887 4455
0888 4455
0889 4455
0890 4455
0891 4455
0892 4455
0893 4455
0894 4455
0895 4455
0896 4455
0897 4455
0898 4455
0899 4455
0900 4455
0901 4455
0902 4455
0903 4455
0904 4455
0905 4455
0906 4455
0907 4455
0908 4455
0909 4455
0910 4455
0911 4455
0912 4455
0913 4455
0914 4455
0915 4455
0916 4455
0917 4455
0918 4455
0919 4455
0920 4455
0921 4455
0922 4455
0923 4455
0924 4455
0925 4455
0926 4455
0927 4455
0928 4455
0929 4455
0930 4455
0931 4455
0932 4455
0933 4455
0934 4455
0935 4455
0936 4455
0937 4455
0938 4455
0939 4455
0940 4455
0941 4455
0942 4455
0943 4455
0944 4455
0945 4455
0946 4455
0947 4455
0948 4455
0949 4455
0950 4455
0951 4455
0952 4455
0953 4455
0954 4455
0955 4455
0956 4455
0957 4455
0958 4455
0959 4455
0960 4455
0961 4455
0962 4455
0963 4455
0964 4455
0965 4455
0966 4455
0967 4455
0968 4455
0969 4455
0970 4455
0971 4455
0972 4455
0973 4455
0974 4455
0975 4455
0976 4455
0977 4455
0978 4455
0979 4455
0980 4455
0981 4455
0982 4455
0983 4455
0984 4455
0985 4455
0986 4455
0987 4455
0988 4455
0989 4455
0990 4455
0991 4455
0992 4455
0993 4455
0994 4455
0995 4455
0996 4455
0997 4455
0998 4455
0999 4455
1000 4455

```

TEST 3 = CHECKS THAT OSR WILL TRAP IN USER MODE AND THAT IT WILL NOT AFTER A INTERRUPT, RIB, GTF, RIF, RDF ARE CHECKED TO READ THE SAVE FIELDS AND I,F, AND Q,F,

```

0432 4456 TEST3; SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0433 6007 CAF /CLEAN ALL FLAGS
0434 6001 IOV /TURN THE INTERRUPT ON
0435 6274 SUP /SET USER BUFFER F/F, SET INT INH AT TP3
0436 9237 JMP ,+1 /ENTER USER MODE
0437 7404 OSR /OSR SHOULD SET USER INTERRUPT F/F + CAUSE A TRAP
0438 9240 JMP /OSR FAILED TO TRAP
0439 6294 SINT /SKIP ON USER INTERRUPT F/F
0440 9242 JMP /USER INTERRUPT F/F NOT SET
0441 6294 CINT /CLEAN USER INTERRUPT F/F
0442 6294 SINT /SKIP ON USER INTERRUPT F/F
0443 7410 SKP
0444 9246 JMP /CINT FAILED TO CLEAR USER INTERRUPT F/F
0445 6001 IOV /TURN THE INTERRUPT ON
0446 9251 JMP ,+1 /CHECK THAT THE INTERRUPT HAD CLEARED THE USER FIELD F/F
0447 7404 OSR /OSR SHOULD NOT TRAP
0448 7610 SKP CLA
0449 9253 JMP /OSR TRAPPED AFTER A INTERRUPT OCCURED ABOVE
 /CHECK THE USER BUFFER AND I,F,

```

```

0454 6234 RIB /READ THE INTERRUPT BUFFER
0455 1113 TAD M100 /CHECK THE SAVE FIELD FOR USER FLAG
0456 7640 SZA CLA
0457 4454 ERROR /USER FLAG NOT SET OR OTHER BITS SET
0458 7340 CLA CLL CMA /SET THE AC TO ALL ONES
0459 6004 GTF /GET THE FLAGS
0460 1116 TAD M300 /CHECK FOR INT ENA, AND USER FLAG
0461 7640 SZA CLA
0462 4454 ERROR /USER FLAG AND INT ENA NOT SET OR OTHER BITS SET
0463 6224 RIF /READ THE INSTRUCTION FIELD
0464 7640 SZA CLA
0465 4454 ERROR /THE INSTRUCTION FIELD IS NON ZERO
0466 6214 RDF
0467 7640 SZA CLA
0468 4454 ERROR /THE DATA FIELD IS NON ZERO
0469 4455 LOOP /LOOP ON TEST IF SR = 1000

```

TEST 4 = CHECKS THAT AN IOT WILL TRAP OUT IN USER MODE AND NOT AFTER A USER INTERRUPT, THE USER INTERRUPT IS CHECKED TO BE CLEARED BY CAF, RIB AND GTF ARE ISSUED AND CHECKED,

```

0474 4456 TEST4; SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0475 6007 CAF /CLEAN ALL FLAGS
0476 6001 IOV /TURN THE INTERRUPT ON
0477 6274 SUP /SET THE USER BUFFER FLIP=FLOP
0478 5301 JMP ,+1 /TRANSFER USER BUFFER TO THE USER FIELD F/F
0479 6001 IOV /SHOULD TRAP HERE
0480 5302 JMP /THE IOT FAILED TO TRAP
0481 6294 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
0482 5304 JMP /USER INTERRUPT F/F FAILED TO SET ON SINT FAILED
0483 6007 CAF /CLEAN USER INTERRUPT WITH INITIALIZE
0484 6294 SINT /SKIP ON USER INTERRUPT
0485 7410 SKP
0486 5310 JMP /CAF FAILED TO CLEAN USER INTERRUPT
0487 6001 IOV /TURN THE INTERRUPT ON
0488 5313 JMP ,+1 /CHECK THAT THE INTERRUPT CLEARED OF F/F
0489 6001 IOV /IOT SHOULD NOT TRAP HERE
0490 7410 SKP
0491 5315 JMP /IOT TRAPPED
0492 6234 RIB /READ THE INTERRUPT BUFFER
0493 1113 TAD M100
0494 7640 SZA CLA
0495 4454 ERROR /USER FLAG NOT SET OR OTHER BITS SET
0496 7340 CLA CLL CMA /SET THE AC TO ALL ONES
0497 6004 GTF /GET THE FLAGS
0498 1116 TAD M300
0499 7640 SZA CLA
0500 4454 ERROR /USER FLAG AND INT ENA NOT SET OR GTF FAILED
0501 4455 LOOP /LOOP ON TEST IF SR = 1000

```

TEST 5 = CHECKS THAT CUF WILL CLEAR THE USER MODE BY DOING IOV, SUP, IOV, JMP, IOT, THE IOT, SHOULD NOT TRAP, RIB AND GTF ARE

/ISSUED AND CHECKED,

```

0030 4456 TEST9, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0031 6007 CAP /CLEAN ALL FLAGS
0032 6001 IOV /TURN THE INTERRUPT ON
0033 6274 SUP /SET THE USER BUFFER F/F
0034 5335 JMP ,+1 /ENTER USER MODE
0035 7402 HLT /HLT FAILED TO TRAP
0036 5336 JMP /HLT FAILED TO TRAP
0037 6254 SINT /SKIP ON USER INTERRUPT
0040 4454 ERROR /USER INTERRUPT NOT SET
0041 6007 CAP /CLEAN ALL FLAGS
0042 6254 SINT /SKIP ON USER INTERRUPT F/F
0043 7410 SKP
0044 4454 ERROR /CAP FAILED TO CLEAN USER INTERRUPT
0045 6234 RIB /READ THE INTERRUPT BUFFER
0046 1113 TAD M100 /CHECK FOR THE USER FLAG
0047 7640 SEA CLA
0050 4454 ERROR /USER FLAG NOT SET OR OTHER BITS SET
0051 6001 IOV /TURN THE INTERRUPT BACK ON
0052 6274 SUP /SET USER FLAG
0053 6264 CUF /CLEAN USER FLAG
0054 7410 SKP
0055 5355 JMP /CUF TRAPPED BEFORE A JMP WAS ISSUED
0056 5357 JMP ,+1
0057 6001 IOV /ISSUE A IOT TO CHECK THAT PROGRAM DOESN'T TRAP,
0060 7410 SKP
0061 5361 JMP /CUF FAILED TO CLEAN USER BUFFER FLIP=FLOP
0062 6254 SINT /SKIP ON USER INTERRUPT SET
0063 7410 SKP
0064 4454 ERROR /SINT SKIPPED, USER INTERRUPT SHOULD NOT BE SET
0065 7340 CLA CLL CMA
0066 6004 GTF /GET THE FLAGS
0067 1116 TAD M300 /
0070 7640 SEA CLA /CHECK FOR INTERRUPT ENABLE + USER FLAG
0071 4454 ERROR /INTERRUPT ENABLE OR USER FLAG NOT SET
0072 6234 RIB /READ THE INTERRUPT BUFFER
0073 1113 TAD M100
0074 7640 SEA CLA
0075 4454 ERROR /USER FLAG NOT SET OR OTHER BITS SET
0076 4455 LOOP /LOOP ON TEST IF SR = 1000

```

.....
 /TEST #9 CHECKS THAT USER MODE IS NOT ENTERED UNTIL A JMS INSTRUCTION IS ISSUED BY DOING A
 /ION, SUP, IOV, OSR, LAS, JMS, HLT, INTERRUPT REQUEST AND LINK ARE CHECKED TO
 /BE SET AND CLEARED BY GTF,


```

0077 4456 TEST6, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0080 6007 CAP /CLEAN ALL FLAGS
0081 6001 IOV /TURN THE INTERRUPT ON
0082 6274 SUP /SET USER BUFFER F/F
0083 6001 IOV /ISSUE A IOT
0084 7410 SKP

```

```

0085 5205 JMP /ION TRAPPED, USER MODE NOT SET UNTIL A JMP, JMS
0086 7404 OSR /OR THE SWITCH REGISTER WITH AC
0087 7610 SKP CLA
0090 5210 JMP /
0091 7604 LAS /USH TRAPPED OR USER MODE SET
0092 7610 SKP CLA /LOAD THE AC WITH THE SWITCH REGISTER
0093 5213 JMP /
0094 4215 JMS ,+1 /LAS TRAPPED OR USER MODE SET
0095 7402 HLT/XXXX /SET USER BUFFER F/F
0096 7402 HLT /THE PC OF THE JMS
0097 5217 JMP /SHOULD TRAP HERE - IF NOT USER FIELD F/F PROBABLY NOT SET
0098 6254 SINT /HALT FAILED TO TRAP
0099 4454 ERROR /SKIP ON USER INTERRUPT F/F
0102 6234 RIB /USER INTERRUPT F/F NOT SET
0103 1113 TAD M100 /READ THE INTERRUPT BUFFER
0104 7640 SEA CLA /CHECK FOR USER FLAG
0105 4454 ERROR /USER FLAG NOT SET OR OTHER FLAGS SET
0106 7340 CLA CLL CMA /SET THE AC TO ALL ONE'S
0107 6004 GTF /GET THE FLAGS
0110 1130 TAD M1100 /CHECK FOR INTERRUPT REQUEST AND USER FLAG
0111 7640 SEA CLA
0112 4454 ERROR /INTERRUPT REQUEST OR USER FLAG NOT SET
0113 6204 CINT /CLEAN USER INTERRUPT FLIP=FLOP
0114 7360 CLA CLL CML CMA /SET AC + LINK TO A 1
0115 6004 GTF
0116 1131 TAD M4100 /CHECK FOR LINK AND USER FLAG
0117 7640 SEA CLA
0120 4454 ERROR /SHOULD ONLY BE LINK AND USER FLAG SET
0121 7100 CLL /CLEAN THE LINK
0122 6004 GTF /GET THE FLAGS
0123 1113 TAD M100 /CHECK FOR USER FLAG
0124 7640 SEA CLA /IS IT SET?
0125 4454 ERROR /USER FLAG SHOULD BE ONLY FLAG SET,
0126 4455 LOOP /LOOP ON TEST IF SR = 1000

```

.....
 /TEST 7= CHECKS THAT THE USER FLAG IN THE SAVE FIELD CAN BE CLEARED,
 /THIS IS DONE BY LEAVING THE USER INTERRUPT F/F SET AFTER A TRAP AND
 /THEN TURNING THE INTERRUPT BACK ON,


```

0047 4456 TEST7, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0050 6007 CAP /CLEAN ALL FLAGS
0051 6001 IOV /TURN THE INTERRUPT ON
0052 6274 SUP /SET USER BUFFER FLIP=FLOP
0053 5254 JMP ,+1 /ENTER USER MODE
0054 7402 HLT /HLT FAILED TO TRAP
0055 5255 JMP /HLT FAILED TO TRAP
0056 6254 SINT /SKIP ON USER INTERRUPT
0057 4454 ERROR /USER INTERRUPT NOT SET
0060 7240 CLA CMA /SET THE AC TO ALL ONES
0061 6004 GTF /GET THE FLAGS
0062 1130 TAD M1100 /CHECK FOR USER FLAG AND INTERRUPT REQUEST
0063 7640 SEA CLA /IS IT THERE?
0064 4454 ERROR /SHOULD ONLY BE INT, REG, AND USER FLAG

```

```

0665 6001 IOV /TURN THE INTERRUPT ON
0666 7000 NOP /SHOULD INTERRUPT HERE
0667 4454 ERROR /FAILED TO INTERRUPT
0670 7340 CLA CLL CMA /SET THE AC TO ALL ONES
0671 6004 GTF /GET THE FLAGS
0672 1117 TAD M1000 /CHECK FOR INTERRUPT REQUEST
0673 7640 SEA CLA
0674 4454 ERROR /SHOULD ONLY BE INTERRUPT REQUEST SET
0675 6204 CINT /CLEAR USER INTERRUPT REQUEST
0676 6254 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
0677 7410 SKP
0700 4454 ERROR /CINT FAILED TO CLEAR USER INT F/F
0701 7340 CLA CLL CMA
0702 6004 GTF
0703 7640 SEA CLA
0704 4454 ERROR /INTERRUPT REQUEST FAILED TO CLEAR
0705 4455 LOOP /LOOP ON TEST IF SR = 1000
    
```

.....
 /TEST0= CHECKS THAT RTF WILL RESET THE USER MODE AFTER A
 /USER INTERRUPT.


```

0706 4456 TEST0, SC0PLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0707 6007 CAF /CLEAR ALL FLAGS
0710 6001 IOV /TURN THE INTERRUPT ON
0711 5274 SUP /SET USER BUFFER FLIP FLOP
0712 5313 JMP ,+1
0713 7402 HLT /HLT FAILED TO TRAP OR USER FIELD FAILED TO SET
0714 5314 JMP /HLT FAILED TO TRAP
0715 6254 SINT /SKIP ON USER INTERRUPT F/F
0716 4454 ERROR /USER INTERRUPT FAILED TO SET
0717 6204 CINT /CLEAR USER INTERRUPT FLIP=FLOP
0720 6254 SINT
0721 7410 SKP
0722 4454 ERROR /CINT FAILED TO CLEAR USER INTERRUPT
0723 6234 RIB /READ THE INTERRUPT BUFFER
0724 1113 TAD M100 /CHECK FOR USER FLAG
0725 7640 SEA CLA
0726 4454 ERROR /USER FLAG NOT SET OR PICKED UP BITS
0727 7100 CLL
0730 1153 TAD K4100 /SET AC0 +5 TO A 1 TO SET LINK + USER BUFFER
0731 6005 RTF /RESTORE THE FLAGS = SET USER BUFFER F/F
0732 7610 SKP CLA
0733 5333 JMP /RTF SKIPPED
0734 6224 RIF /READ THE INSTRUCTION FIELD
0735 7640 SEA CLA /IS IT NON ZERO
0736 5336 JMP /RIF TRAPPED WITH OUT USER INT OR I,F, NON ZERO
0737 6214 ROP /READ THE DATA FIELD
0740 7640 SEA CLA
0741 5341 JMP /ROP TRAPPED WITH OUT USER INT OR D,F, IS NON=ZERO
0742 5343 JMP /SET USER FIELD F/F, USER MODE, AND TURN INT ENA ON
0743 7402 HLT /RTF FAILED TO SET USER BUFFER F/F OR ION NOT SET
0744 5344 JMP /HLT FAILED TO TRAP
0745 6254 SINT /SKIP ON USER INTERRUPT F/F
    
```

```

0746 4454 ERROR /USER INTERRUPT NOT SET
0747 6004 GTF /GET THE FLAGS
0750 1133 TAD M5100 /CHECK FOR LINK, INTERRUPT REQUEST AND USER FLAG
0751 7640 SEA CLA
0752 4454 ERROR /THE LINK, OR INTERRUPT REQUEST OR USER FLAG NOT SET
0753 7100 CLL /CLEAR THE LINK BUT LEAVE INTERRUPT REQUEST UP
0754 6001 IOV /TURN THE INTERRUPT ON
0755 5356 JMP ,+1 /SHOULD INTERRUPT AT TP4
0756 4454 ERROR /PROGRAM FAILED TO INTERRUPT WITH INT REQUEST SET
0757 6004 GTF /GET THE FLAGS
0760 1117 TAD M1000 /CHECK FOR INTERRUPT REQUEST
0761 7640 SEA CLA /IS IT THE ONLY BIT SET
0762 4454 ERROR /NO, OTHER BITS SET BESIDES INT REG OR INT REQ NOT SET
0763 6254 SINT /SKIP ON USER INTERRUPT F/F
0764 4454 ERROR /USER INTERRUPT NOT SET
0765 6204 CINT /CLEAR USER INTERRUPT F/F
0766 6254 SINT
0767 7610 SKP CLA
0770 4454 ERROR /CINT FAILED TO CLEAR USER INTERRUPT F/F
0771 7340 CLA CLL CMA /SET THE AC TO ALL ONES
0772 6004 GTF /GET THE FLAGS
0773 7640 SEA CLA /SHOULD BE ALL ZEROS
0774 4454 ERROR /THE SAVE FIELD OR STATUS IS NON=ZERO
0775 4455 LOOP /LOOP ON TEST IF SR = 1000
    
```

.....
 /TEST1= CHECKS THAT RMF WILL RESET THE USER MODE AFTER A USER
 /INTERRUPT.


```

0776 4456 TEST1, SC0PLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0777 7000 NOP /CLEAR ALL FLAGS
1000 6007 CAF /TURN THE INTERRUPT ON
1001 6001 IOV /SET USER BUFFER FLIP=FLOP
1002 6274 SUP /GO INTO USER MODE
1003 5204 JMP ,+1 /HLT FAILED TO TRAP OR NOT IN USER MODE
1004 7402 HLT /HLT FAILED TO TRAP
1005 5205 JMP /SKIP ON USER INTERRUPT
1006 6254 SINT /SINT FAILED OR USER INTERRUPT NOT SET
1007 4454 ERROR /CLEAR USER INTERRUPT FLIP=FLOP
1010 6204 CINT /SKIP ON USER INTERRUPT
1011 6254 SINT
1012 7410 SKP
1013 4454 ERROR /CINT FAILED TO CLEAR USER INTERRUPT
1014 5274 RIB /READ THE INTERRUPT BUFFER
1015 1113 TAD M100 /USER FLAG NOT SET OR OTHER BITS SET
1016 7640 SEA CLA /TURN THE INTERRUPT ON
1017 4454 ERROR /RESTORE IB, DP AND UB
1020 6001 IOV
1021 6244 RMF
1022 7610 SKP CLA
1023 5223 JMP /RMF SKIPPED
1024 5225 JMP ,+1 /ENTER USER MODE
1025 7402 HLT /RMF + JMP FAILED TO SET USER FIELD OR RMF FAILED
1026 5226 JMP /HLT FAILED TO TRAP
    
```

```

1027 6254 SINT /SKIP ON USER INTERRUPT
1030 4454 ERROR /USER INTERRUPT NOT SET
1031 7100 CLL
1032 6004 GTF /GET THE FLAGS
1033 1130 TAD M1100 /CHECK FOR INTERRUPT REQUEST AND USER FLAG
1034 7640 SEA CLA /WHERE THEY SET
1035 4454 ERROR /NO, INT REQUEST OR USER FLAG NOT SET OR RMF
/SET OTHER BITS IN THE IF AND DF
/TURN THE INTERRUPT BACK ON
/INTERRUPT WITH INTERRUPT REQUEST SET
/PROGRAM FAILED TO INTERRUPT
/READ THE INTERRUPT BUFFER
1036 6001 IOV
1037 5240 JMP ,*1
1040 4454 ERROR /USER FLAG NOT CLEARED ON INTERRUPT
1041 6234 RIB /CHECK USER INTERRUPT TO BE SET
1042 7640 SEA CLA /USED INTERRUPT GOT CLEARED
1043 4454 ERROR /CLEAN USER INTERRUPT
1044 6254 SINT /SKIP ON USER INTERRUPT
1045 4454 ERROR /USER INTERRUPT SET
1046 6204 CINT /LOOP ON TEST IF SR = 1000
1047 6254 SINT
1050 7410 SKP
1051 4454 ERROR
1052 4455 LOOP

```

.....
 /TEST 10 - CHECKS THAT USER MODE AND LINK AND IOV CAN BE SET BY THE AC AND
 /THE RTF INSTRUCTION AND THAT IT CAN BE CLEAR BY RTF.


```

1053 4456 TEST10, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
1054 6007 CAP /CLEAN ALL FLAGS
1055 1153 TAD K4100 /SET THE LINK AND USER BIT INTO THE AC
1056 6005 RTF /RESTORE THE FLAGS
1057 7620 SNL CLA /CHECK THE LINK
1060 7402 HLT /LINK NOT SET BY RTF
1061 6000 SKON /SKIP IF INTERRUPT ON AND TURN OFF
1062 7402 HLT /RTF FAILED TO SET INTERRUPT ENABLE
1063 6000 SKON /SKIP IF INTERRUPT ON AND TURN OFF
1064 7410 SKP
1065 7402 HLT /SKON FAILED TO CLEAR INTERRUPT ENABLE
1066 6001 IOV /TURN THE INTERRUPT ON
1067 5270 JMP ,*1 /ENTER USER MODE
1070 7402 HLT /RTF FAILED TO SET U,B OR JMP FAILED TO LOAD I,F,
1071 5271 JMP /HLT FAILED TO TRAP
1072 6254 SINT /SKIP ON USER INTERRUPT
1073 4454 ERROR /USER INTERRUPT NOT SET
1074 6004 GTF /GET THE FLAGS
1075 1133 TAD M9100 /CHECK LINK, INTERRUPT REQUEST AND USER FLAG
1076 7640 SEA CLA
1077 4454 ERROR /LINK, INT REQ OR USER FLAG NOT SET
1100 7300 CLA CLL /LEAVE INTERRUPT REQUEST SET
1101 6005 RTF /RESTORE THE FLAGS TO 0
1102 5303 JMP ,*1 /SHOULD INTERRUPT
1103 4454 ERROR /FAILED TO INTERRUPT
1104 6254 SINT /SKIP ON USER INTERRUPT
1105 4454 ERROR /USER INTERRUPT GOT CLEARED
1106 6204 CINT /CLEAN USER INTERRUPT

```

```

1107 6234 RIB /READ THE INTERRUPT BUFFER
1110 7640 SEA CLA
1111 4454 ERROR /THE SAVE FIELDS ARE NON ZERO
1112 6074 GTF /GET THE FLAGS
1113 7640 SEA CLA
1114 4454 ERROR /THE SAVE FIELDS ARE NON ZERO
1115 4455 LOOP /LOOP ON TEST IF SR = 1000

```

.....
 /TEST 11 - USING THE USER INTERRUPT FLIP-FLOP AND INTERRUPT ENABLE
 /THE IF REGISTER CAN BE INDIRECTLY CHECKED TO SET BY CHECKING THE
 /SAVE FIELD REGISTER AFTER A INTERRUPT, THE I,F IS CHECKED NOT TO CHANGE
 /UNTIL A JMP OR JMS IS ISSUED, THE INT INHIBIT F/F IS CHECKED NOT
 /TO CLEAR BEFORE A JMP OR JMS IS ISSUED.


```

1116 4456 TEST11, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
1117 6007 CAP /CLEAN ALL FLAGS
1120 6001 IOV /TURN THE INTERRUPT ON
1121 6274 SUP /SET USER BUFFER F/F
1122 5323 JMP ,*1 /ENTER USER MODE
1123 7402 HLT /FAILED TO ENTER USER MODE
1124 5324 JMP /HLT FAILED TO TRAP IN USER MODE
1125 6254 SINT /SKIP ON USER INTERRUPT
1126 4454 ERROR /USER INTERRUPT FLIP-FLOP NOT SET
1127 6004 GTF /GET THE FLAGS
1130 1130 TAD M1100 /CHECK FOR INTERRUPT REQUEST AND USER FLAG
1131 7640 SEA CLA
1132 4454 ERROR /USER FLAG OR INT REQUEST NOT SET
1133 6234 RIB /READ THE INTERRUPT BUFFER
1134 1113 TAD M100
1135 7640 SEA CLA
1136 4454 ERROR /USER FLAG GOT CLEARED
1137 6202 TST11A, CIF 00 /CHANGE INSTRUCTION FIELD TO FIELD 0
1140 7300 CLA CLL /CLEAN THE LINK
1141 6001 IOV /TURN THE INTERRUPT ON
1142 6224 RIF /READ THE INSTRUCTION FIELD
1143 7440 SEA /IS IT ZERO
1144 7402 HLT /THE IF IS NON ZERO OR INTERRUPTED
1145 5346 JMP ,*1 /CLEAN INTERRUPT INHIBIT
1146 4454 ERROR /PROGRAM FAILED TO INTERRUPT
1147 6004 GTF /GET THE FLAGS
1150 1117 TAD M1000 /CHECK FOR USER INTERRUPT REQUEST
1151 7640 SEA CLA
1152 4454 ERROR /INT REG NOT SET OR SAVE FIELD NON ZERO
1153 6234 RIB /READ THE INTERRUPT BUFFER
1154 7640 SEA CLA /IS THE SAVE FIELD 0?
1155 4454 ERROR /NO, SAVE FIELD OR USER FIELD NON ZERO
1156 7240 TST11B, CLA CMA /SET A LOCATION TO ALL ONE'S TO CHECK THAT
1157 3366 DCA CUMS01 /THE JMS TO FIELD 7 DIDN'T JMS TO FIELD 7
1160 6272 CIF 70 /CHANGE INSTRUCTION FIELD TO FIELD 7
1161 6001 IOV /SET INTERRUPT ENABLE
1162 6224 RIF /READ THE INSTRUCTION FIELD
1163 7440 SEA /IS IT STILL ZERO
1164 7402 HLT /THE IF IS NON ZERO OR IT INTERRUPTED

```

```

1165 4366 JMS ,*1 /CLEAR INTERRUPT INHIBIT
1166 7402 HLT /THIS LOCATION PRESET TO 1'S SHOULDN'T CHANGE
1167 4454 CJMS01, ERROR /PROGRAM FAILED TO INTERRUPT
1170 7360 CLA CLL CML CMA /SET AC AND LINK TO ALL ONES
1171 6004 GTF /GET THE FLAGS
1172 1132 TAD M5000 /CHECK FOR LINK, USER INTERRUPT REQUEST,
1173 1111 TAD M70 /AND SAVE FIELD REGISTER OF 70
1174 7640 SEA CLA
1175 4454 ERROR /GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1176 6234 R13 /READ THE INTERRUPT BUFFER
1177 1111 TAD M70 /IN THE SF SET TO 1,S,P, 7 ONLY?
1200 7640 SEA CLA
1201 4454 ERROR /SAVE FIELD IS NOT EQUAL TO FIELD 7
1202 2777, ISB CJMS01 /CHECK THAT THE JMS DIDN'T GO TO FIELD 0
1203 4454 ERROR /THE JMS TO FIELD 7 WENT TO FIELD 0
1204 7240 TST110, CLA CMA /SET A LOCATION TO ALL ONE'S TO CHECK THAT A
1205 3210 DCA CJMS02 /JMS TO FIELD 5 DIDN'T CHANGE FIELD 0
1206 6254 SINT /SKIP ON USER INTERRUPT REQUEST
1207 4454 ERROR /USER INTERRUPT F/P GOT CLEARED
1210 6252 CIF 50 /CHANGE TO INSTRUCTION FIELD 5
1211 6001 IOV /SET INTERRUPT ENABLE
1212 6224 RIF /READ THE INSTRUCTION FIELD
1213 7440 SEA /IS IT STILL ZERO
1214 7402 HLT /THE IF IS NON ZERO OR IT INTERRUPTED
1215 4210 JMS ,*1 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
1216 7402 HLT /THIS LOCATION PRESET TO 1'S SHOULDN'T CHANGE
1217 4454 ERROR /PROGRAM FAILED TO INTERRUPT
1220 7340 CLA CLL CMA /SET THE AC TO ALL ONES
1221 6004 GTF /GET THE FLAGS
1222 1117 TAD M1000 /CHECK FOR USER INTERRUPT REQUEST AND SAVE
1223 1103 TAD M50 /FIELD REGISTER OF 50
1224 7640 SEA CLA
1225 4454 ERROR /GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1226 6234 R13 /READ THE INTERRUPT BUFFER
1227 1103 TAD M50 /CHECK THE INTERRUPT BUFFER FOR ISF 50
1230 7640 SEA CLA
1231 4454 ERROR /SAVE FIELD IS NOT EQUAL TO I,P, 5
1232 2210 ISB CJMS02 /CHECK THAT JMS DIDN'T GO TO FIELD 0
1233 4454 ERROR /THE JMS TO I,P,S, WENT TO FIELD 0
1234 7240 TST110, CLA CMA /SET A LOCATION TO ALL ONE'S TO CHECK THAT A JMS
1235 3244 DCA CJMS03 /TO FIELD 2 DIDN'T CHANGE FIELD 0
1236 6222 CIF 20 /CHANGE INSTRUCTION FIELD TO FIELD 2
1237 6001 IOV /SET INTERRUPT ENABLE
1240 6224 RIF /READ THE INSTRUCTION FIELD
1241 7440 SEA /IS IT STILL EQUAL TO ZERO
1242 7402 HLT /THE IF IS NON ZERO OR IT INTERRUPTED
1243 4244 JMS ,*1 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
1244 7402 HLT /THIS LOCATION PRESET TO 1'S SHOULDN'T CHANGE
1245 4454 ERROR /PROGRAM FAILED TO INTERRUPT
1246 7360 CLA CLL CML CMA /SET THE AC AND LINK TO 1'S
1247 6004 GTF /GET THE FLAGS
1250 1132 TAD M5000 /CHECK FOR LINK AND USER INTERRUPT REQUEST
1251 1072 TAD M20 /AND SAVE FIELD REGISTER OF 20
1252 7640 SEA CLA
1253 4454 ERROR /GTF FAILED OR READ SOMETHING OTHER THAN ABOVE

```

```

1254 6234 R13 /READ THE INTERRUPT BUFFER
1255 1072 TAD M20
1256 7640 SEA CLA /DOES THE INTERRUPT BUFFER CONTAIN 20
1257 4454 ERROR /NO, ERROR SAVE FIELD IS NOT EQUAL TO 20
1260 2244 ISB CJMS03 /CHECK THAT JMS DIDN'T GO TO FIELD 0
1261 4454 ERROR /THE JMS TO FIELD 2 WENT TO FIELD 0
1262 7240 TST11E, CLA CMA /SET A LOCATION TO ALL ONE'S TO CHECK THAT THE
1263 3272 DCA CJMS04 /JMS TO FIELD 1 DIDN'T JMS TO FIELD 0
1264 6212 CIF 10 /CHANGE INSTRUCTION FIELD TO FIELD 1,
1265 6001 IOV /TURN THE INTERRUPT ON
1266 6224 RIF /READ THE INSTRUCTION FIELD
1267 7440 SEA /IS IT STILL ZERO
1270 7402 HLT /THE IF IS NON ZERO OR IT INTERRUPTED
1271 4272 JMS ,*1 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
1272 7402 HLT /THIS LOCATION PRESET TO ALL ONE'S SHOULDN'T CHANGE
1273 4454 ERROR /PROGRAM FAILED TO INTERRUPT
1274 7340 CLA CLL CMA /SET THE AC TO ALL ONE'S
1275 6004 GTF /GET THE FLAGS
1276 1117 TAD M1000 /CHECK FOR USER INTERRUPT REQUEST AND
1277 1067 TAD M10 /SAVE FIELD OF 10
1300 7640 SEA CLA
1301 4454 ERROR /GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1302 6234 R13 /READ THE INTERRUPT BUFFER
1303 1067 TAD M10
1304 7640 SEA CLA
1305 4454 ERROR /SAVE FIELD IS NOT EQUAL TO FIELD 10
1306 2272 ISB CJMS04 /CHECK THAT THE JMS DIDN'T GO TO FIELD 0
1307 4454 ERROR /THE JMS TO FIELD 1 WENT TO FIELD 0
1310 7240 TST11F, CLA CMA /SET A LOCATION TO ALL ONES TO CHECK THAT THE
1311 3320 DCA CJMS05 /JMS TO FIELD 6 DIDN'T JMS TO FIELD 0
1312 6262 CIF 60 /CHANGE INSTRUCTION FIELD TO FIELD 6
1313 6001 IOV /TURN THE INTERRUPT ON
1314 6224 RIF /READ THE INSTRUCTION FIELD
1315 7440 SEA /IS IT STILL ZERO
1316 7402 HLT /THE IF IS NON ZERO OR IT INTERRUPTED
1317 4320 JMS ,*1 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
1320 7402 HLT /THIS LOCATION SET TO ALL ONE'S, IT SHOULDN'T CHANGE
1321 4454 ERROR /PROGRAM FAILED TO INTERRUPT
1322 7360 CLA CLL CML CMA /SET THE AC AND LINK TO ALL ONE'S
1323 6004 GTF /GET THE FLAG
1324 1132 TAD M5000 /CHECK FOR LINK, USER INTERRUPT REQUEST
1325 1106 TAD M60 /AND SAVE FIELD OF 60
1326 7640 SEA CLA
1327 4454 ERROR /GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1330 6234 R13 /READ THE INTERRUPT BUFFER
1331 1106 TAD M60
1332 7640 SEA CLA
1333 4454 ERROR /SAVE FIELD IS NOT EQUAL TO FIELD 60
1334 2320 ISB CJMS05 /CHECK THAT THE JMS DIDN'T GO TO FIELD 0
1335 4454 ERROR /THE JMS TO FIELD 6 WENT TO FIELD 0
1336 7240 TST11G, CLA CMA /SET A LOCATION TO ALL 1'S TO CHECK THAT THE
1337 3346 DCA CJMS06 /JMS TO FIELD 3 DIDN'T JMS TO FIELD 0
1340 6232 CIF 30 /CHANGE INSTRUCTION FIELD TO FIELD 3
1341 6001 IOV /TURN THE INTERRUPT ON
1342 6224 RIF /READ THE INSTRUCTION FIELD

```

```

1343 7440          SEA          /IS THE IF STILL ZERO
1344 7402          HLT          /THE IF IS NON ZERO OR IT INTERRUPTED
1345 4349          JMS          /CLEAN INTERRUPT INHIBIT AND INTERRUPT
1346 7402          CJMS00, HLT    /THIS LOCATION PRESET TO ALL ONES, IT SHOULDN'T CHANGE
1347 4494          ERROR        /PROGRAM FAILED TO INTERRUPT
1348 7340          CLA CLL CMA   /SET THE AC TO ALL ONE'S
1349 6004          GTF          /GET THE FLAGS
1350 1137          TAD          M1000  /CHECK FOR USER INTERRUPT REQUEST AND
1351 1079          TAD          M30   /SAVE FIELD OF 30
1352 7640          SEA CLA     /GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1353 4494          ERROR        /READ THE INTERRUPT BUFFER
1354 6234          RIB          /SAVE FIELD NOT EQUAL TO FIELD 3
1355 1079          TAD          M30   /JMS TO FIELD 3 WENT TO FIELD 0
1356 7640          SEA CLA     /GO TO NEXT SECTION
1357 4494          ERROR        /SAVE FIELD NOT EQUAL TO FIELD 3
1358 2346          ISR          CJMS06
1359 4494          ERROR        /JMS TO FIELD 3 WENT TO FIELD 0
1360 4494          ERROR        /GO TO NEXT SECTION
1361 5776          JMR          TST11H

1376 1400          PAGE
1377 1166          TST11H, CLA CMA   /SET A LOCATION TO ALL ONES TO CHECK
1378 1400          DCA          CJMS07  /THAT A JMS TO FIELD 4 DIDN'T JMS TO FIELD 0
1379 3210          CIP          40    /CHANGE INSTRUCTION FIELD TO FIELD 4
1380 4242          IOV          /SET INTERRUPT ENABLE
1381 8001          RIF          /READ THE INSTRUCTION FIELD
1382 6224          SEA          /IS THE IF STILL ZERO
1383 7440          HLT          /THE IF IS NON ZERO OR IT INTERRUPTED
1384 4210          JMS          /THIS LOCATION PRESET TO ALL ONE'S
1385 7402          CJMS07, HLT    /PROGRAM FAILED TO INTERRUPT
1386 4494          ERROR        /SET THE AC AND LINK TO 1'S
1387 7360          CLA CLL CML CMA /GET THE FLAGS
1388 6004          GTF          /CHECK FOR USER INTERRUPT REQUEST AND LINK
1389 1132          TAD          M3000  /AND SAVE FIELD OF 40
1390 1100          TAD          M40   /GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1391 7640          SEA CLA     /READ THE INTERRUPT BUFFER
1392 4494          ERROR        /SAVE FIELD NOT EQUAL TO 40
1393 6234          RIB          /JMS TO FIELD 4 WENT TO FIELD 0
1394 1100          TAD          M40   /SETUP A LOCATION TO CHECK THAT A JMS TO
1395 7640          SEA CLA     /FIELD 0 GETS EXECUTED
1396 4494          ERROR        /CHANGE INSTRUCTION FIELD TO FIELD 00
1397 7340          TST11I, CLA CLL CMA /TURN THE INTERRUPT ON
1398 3236          DCA          CJMS10  /READ THE INSTRUCTION FIELD
1399 6202          CIP          00    /IS THE IF STILL ZERO
1400 8001          IOV          /THE IF IS NON ZERO OR IT INTERRUPTED
1401 6224          RIF          /CLEAN INTERRUPT ENABLE AND INTERRUPT
1402 7440          SEA          /THIS LOCATION PREVIOUSLY SET TO 1'S
1403 7402          HLT          /PROGRAM FAILED TO INTERRUPT
1404 4236          JMS          /GET THE FLAGS
1405 7402          CJMS10, HLT   /THIS LOCATION PREVIOUSLY SET TO 1'S
1406 4494          ERROR        /PROGRAM FAILED TO INTERRUPT
1407 6004          GTF          /GET THE FLAGS

```

```

1441 1117          TAD          M1000  /CHECK FOR INTERRUPT REQUEST AND
1442 7640          SEA CLA     /SAVE FIELD OF 0
1443 4494          ERROR        /GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1444 6234          RIB          /READ THE INTERRUPT BUFFER
1445 7640          SEA CLA     /SAVE FIELD NON ZERO OR RIB FAILED
1446 4494          ERROR        /CHECK THAT THE JMS DID CHANGE LOCATION CJMS10
1447 2236          ISR          CJMS10
1448 7610          SKP          CLA
1449 4494          ERROR        /JMS TO FIELD 0 FAILED TO STORE ITS PC IN CJMS10
1450 6007          CAP          /CLEAN ALL FLAGS INCLUDING USER INTERRUPT
1451 6004          GTF          /GET THE FLAGS
1452 7640          SEA CLA     /INIT FAILED TO CLEAR USER INTERRUPT F/F
1453 4494          ERROR        /LOOP ON TEST IF SR = 1000
1454 4494          LOOP
1455 5777          JMP          TEST12

```

1577 1600
1600

PAGE

```

/.....
/TEST 12 = CHECKS THAT A CIP AND CDF WILL LOAD THE APPROPRIATE
/SAVE FIELD REGISTERS; A DCA INDIRECT IS CHECKED NOT TO CHANGE
/A LOCATION IN FIELD 0 WHEN THE DATA FIELD IS NON ZERO; A
/JMS I IS CHECKED NOT TO CHANGE A LOCATION IN FIELD ZERO WHEN
/THE INSTRUCTION FIELD IS NON ZERO;
/.....

```

```

1600 4494          TEST12, SCDFLP    /SETUP TEST AND SCOPE LOOPING ADDRESS
1601 6007          CAP          /CLEAN ALL FLAGS
1602 6201          IOV          /TURN THE INTERRUPT ON
1603 6274          BUF          /SET USER BUFFER FLIP=FLIP
1604 5205          JMP          /ENTER TIME SHARE MODE
1605 7402          HLT          /PROGRAM FAILED TO ENTER USER MODE
1606 5206          JMP          /HLT FAILED TO TRAP
1607 6294          SINT         /SKIP ON USER INTERRUPT
1608 4494          ERROR        /SINT FAILED OR USER INTERRUPT NOT SET
1609 6004          GTF          /GET THE FLAGS
1610 1130          TAD          M1100  /CHECK FOR USER INTERRUPT AND USER FLAG
1611 7640          SEA CLA     /GTF READ SOMETHING DIFFERENT THAN ABOVE
1612 4494          ERROR        /SET THE AC TO ALL ONES
1613 7340          TST12A, CLA CLL CMA /STORE IT TO CHECK THAT THE DATA FIELD CHANGED
1614 3033          DCA          CDFCHK   /SET THE AC TO ALL ONES
1615 7340          CLA CLL CMA   /SAVE IT TO CHECK THE JMS TO ANOTHER FIELD
1616 3227          DCA          CKJMS1  /CHANGE DATA FIELD TO FIELD 6
1617 6261          CDF          60    /CHANGE INSTRUCTION FIELD TO FIELD 1
1618 6212          CIP          10   /CHANGE EMA LINES TO CHECK THAT THE
1619 3434          DCA I      CHKCDF  /DCA WENT TO ANOTHER FIELD THAN FIELD 0
1620 6001          IOV          /TURN THE INTERRUPT ON
1621 4626          JMS I      /CLEAN INTERRUPT INHIBIT AND INTERRUPT
1622 1627          CKJMS1, HLT   /THIS LOCATION PRESET TO ONE'S TO CHECK JMS TO ANOTHER FIELD
1623 7402          HLT          /PROGRAM FAILED TO INTERRUPT
1624 4494          ERROR

```

```

1031 6004      GTF
1032 1121      TAD
1033 7640      SEA CLA M1016
1034 4454      ERROR
1035 6234      RIB
1036 1071      TAD
1037 7640      SEA CLA M16
1040 4454      ERROR
1041 2033      ISB
1042 4454      ERROR CDFCHK
1043 2227      ISB
1044 4454      ERROR CKJMS1
1045 7340      TST120, CLA CLL CMA
1046 3033      DCA CDFCHK
1047 7340      CLA CLL CMA
1050 3237      DCA CKJMS2
1051 6211      CDF
1052 6262      CIF
1053 3434      DCA I CHKCDF

1054 6001      IOV
1055 4656      JMS I
1056 1657      CKJMS2
1057 7402      HLT
1060 4454      ERROR
1061 7340      CLA CLL CMA
1062 6004      GTF
1063 1126      TAD
1064 7640      SEA CLA M1061
1065 4454      ERROR
1066 6234      RIB
1067 1107      TAD
1068 7640      SEA CLA M61
1071 4454      ERROR
1072 2033      ISB
1073 4454      ERROR CDFCHK
1074 2257      ISB
1075 4454      ERROR CKJMS2
1076 7340      TST120, CLA CLL CMA
1077 3033      DCA CDFCHK
1078 7340      CLA CLL CMA
1081 3310      DCA CKJMS3
1082 6232      CIF
1083 6241      CDF
1084 3434      DCA I CHKCDF
1085 6001      IOV
1086 4707      JMS I
1087 1710      CKJMS3
1090 7402      HLT
1091 4454      ERROR
1092 7340      CLA CLL CMA
1093 6004      GTF
1094 1123      TAD
1095 7640      SEA CLA M1034
1096 4454      ERROR

```

```

/GET THE FLAGS
/CHECK FOR INT REQ, ISF OF 12 AND DSF OF 6
/IN SAVE FIELD REGISTER
/SAVE FIELD NOT EQUAL TO ABOVE
/READ THE INTERRUPT BUFFER
/CHECK FOR ISF OF 10 AND DSF OF 6
/RIB FAILED OR SAVE FIELD NOT EQUAL TO 16
/CHECK THAT THE DCA I WENT TO ANOTHER FIELD
/DCA I WENT TO FIELD 0 INSTEAD OF FIELD 6
/CHECK THAT JMS I WENT TO ANOTHER FIELD
/JMS I WENT TO FIELD 0 INSTEAD OF FIELD 1
/SET LOCATION CDFCHK AND CKJMS2 TO ONES
/TO CHECK DCA I AND JMS I WENT TO
/ANOTHER FIELD THAN FIELD 0
/CHANGE DATA FIELD TO FIELD 1
/CHANGE INSTRUCTION FIELD TO FIELD 6
/CHANGE EMA LINES TO FIELD 1
/CDFCHK SHOULD NOT CHANGE IN FIELD 0
/TURN THE INTERRUPT ON
/CLEAR INTERRUPT INHIBIT
/INDIRECT ADDRESS
/THIS LOCATION PRESET TO ONE'S TO CHECK JMS TO FIELD 6
/PROGRAM FAILED TO INTERRUPT
/SET THE AC TO ALL ONES
/GET THE FLAGS
/CHECK FOR INT REQ, ISF OF 62 AND DSF OF 1
/THE SAVE FIELD NOT EQUAL TO ABOVE
/READ THE INTERRUPT BUFFER
/CHECK FOR I,S,F, OF 6 AND I,D,F, OF 1
/THE SAVE FIELD NOT EQUAL TO ABOVE
/CHECK THAT DCA I WENT TO ANOTHER FIELD
/DCA I WENT TO FIELD 0 INSTEAD OF FIELD 1
/CHECK THAT JMS I WENT TO ANOTHER FIELD
/JMS I WENT TO FIELD 0 INSTEAD OF FIELD 16,
/SET LOCATIONS CDFCHK AND CKJMS3 TO ONE'S
/TO CHECK THAT DCA I AND JMS I WENT
/TO ANOTHER FIELD THAN FIELD 0
/CHANGE INSTRUCTION FIELD TO FIELD 3
/CHANGE DATA FIELD TO FIELD 4
/CHANGE EMA LINES TO FIELD 4
/TURN THE INTERRUPT ON
/CLEAR INTERRUPT INHIBIT
/INDIRECT ADDRESS
/THIS LOCATION PRESET TO ONES TO CHECK JMS TO FIELD 3
/PROGRAM FAILED TO INTERRUPT
/SET THE AC TO ALL ONES
/GET THE FLAGS
/CHECK FOR INT REG, ISF OF 3 AND DSF OF 4
/THE SAVE FIELD REGISTER NOT EQUAL TO ABOVE

```

```

1717 6234      RIB
1720 1077      TAD
1721 7640      SEA CLA M34
1722 4454      ERROR
1723 2033      ISB
1724 4454      ERROR CDFCHK
1725 2310      ISB
1726 4454      ERROR CKJMS3
1727 7340      TST120, CLA CLL CMA
1730 3033      DCA CDFCHK
1731 7340      CLA CLL CMA
1732 3341      DCA CKJMS4
1733 6232      CIF
1734 6221      CDF
1735 3434      DCA I CHKCDF
1736 6001      IOV
1737 4740      JMS I
1740 1741      CKJMS4
1741 7402      HLT
1742 4454      ERROR
1743 7340      CLA CLL CMA
1744 6004      GTF
1745 1125      TAD
1746 7640      SEA CLA M1052
1747 4454      ERROR
1750 6234      RIB
1751 1104      TAD
1752 7640      SEA CLA M92
1753 4454      ERROR
1754 2033      ISB
1755 4454      ERROR CDFCHK
1756 2341      ISB
1757 4454      ERROR CKJMS4
1760 5777      JMP TST12E

1777 2001      PAGE
2000 4452      TST12E, JMS I ATRST
2001 7340      CLA CLL CMA
2002 3033      DCA CDFCHK
2003 7240      CLA CMA
2004 3213      DCA CKJMS5
2005 6251      CDF
2006 6222      CIF
2007 3434      DCA I CHKCDF
2010 6001      IOV
2011 6012      JMS I
2012 2013      CKJMS5
2013 7402      HLT
2014 4454      ERROR
2015 7340      CLA CLL CMA
2016 6004      GTF
2017 1122      TAD
2020 7640      SEA CLA M1025

```

```

/READ THE INTERRUPT BUFFER
/CHECK FOR ISF OF 3 AND DSF OF 4
/THE SAVE FIELD REGISTER NOT EQUAL TO ABOVE
/DCA I WENT TO FIELD 0 INSTEAD OF FIELD 4
/JMS I WENT TO FIELD 0 INSTEAD OF FIELD 3
/SET LOCATIONS CDFCHK AND CKJMS4 TO ONES
/TO CHECK THAT DCA I OR JMS I TO ANOTHER
/FIELD DOESN'T GO TO FIELD 0
/CHANGE INSTRUCTION FIELD TO FIELD 5
/CHANGE DATA FIELD TO FIELD 2
/CHANGE EMA LINES TO FIELD 2
/TURN THE INTERRUPT ON
/CLEAR INTERRUPT INHIBIT
/INDIRECT ADDRESS
/THIS LOCATION PRESET TO ONES TO CHECK JMS TO FIELD 5
/PROGRAM FAILED TO INTERRUPT
/SET THE AC TO ALL ONES
/GET THE FLAGS
/CHECK FOR INT, REQ,, ISF OF 5, AND DSF OF 2
/THE SAVE FIELD REGISTER NOT EQUAL TO ABOVE
/READ THE INTERRUPT BUFFER
/CHECK FOR ISF OF 5 AND DSF OF 2
/SAVE FIELD NOT EQUAL TO ABOVE
/DCA I TO FIELD 2 WENT TO FIELD 0
/JMS I TO FIELD 5 WENT TO FIELD 0
/AUTO RESTART HANDLER
/SETUP LOCATIONS CDFCHK AND CKJMS5 TO ONES
/TO CHECK THAT DCA I OR JMP I TO ANOTHER
/FIELD DOESN'T GO TO FIELD 0
/CHANGE DATA FIELD TO FIELD 5
/CHANGE INSTRUCTION FIELD TO 2
/CHANGE EMA LINES TO 5 (OF ON)
/TURN INTERRUPT ENABLE ON
/CLEAR INTERRUPT INHIBIT
/INDIRECT ADDRESS
/THIS LOCATION PRESET TO ONES TO CHECK JMS TO FIELD 2
/PROGRAM FAILED TO INTERRUPT
/SET THE AC TO ALL ONES
/GET THE FLAGS
/CHECK FOR INT, REQ,, ISF=2 AND DSF=5

```

2021	4454	ERROR		/THE SAVE FIELD REGISTER NOT EQUAL TO ABOVE
2022	6234	R1B		/READ THE INTERRUPT BUFFER
2023	1074	TAD	M25	/CHECK FOR ISF OF 2 AND DSF#5
2024	7640	SEA CLA		
2025	4454	ERROR		/SAVE FIELD REGISTER NOT EQUAL TO ABOVE
2026	2033	ISE	COPCHK	
2027	4454	ERROR		/DCA I TO FIELD 5 WENT TO FIELD 0
2030	2213	ISE	CKJMS5	
2031	4454	ERROR		/JMS I TO FIELD 2 WENT TO FIELD 0
2032	7340	TST12F, CLA CLL CMA		/SET LOCATIONS COPCHK AND CKJMS6 TO
2033	3033	DCA	COPCHK	/ONES TO CHECK THAT DCA I AND JMS I
2034	7240	CLA CMA		/TO ANOTHER FIELD DOESN'T GO TO FIELD 0
2035	3244	DCA	CKJMS6	
2036	6231	CDF	30	/CHANGE DATA FIELD TO FIELD 3
2037	6242	CIF	40	/CHANGE INSTRUCTION FIELD TO FIELD 4
2040	3434	DCA I	CHKCDF	/CHANGE EMA LINES TO 3
2041	6001	IOV		/TURN THE INTERRUPT ON
2042	4643	JMS I	,*1	/CLEAR INTERRUPT INHIBIT
2043	2044	CKJMS6		/INDIRECT ADDRESS
2044	7402	CKJMS9, HLT		/THIS LOCATION PRESET TO ONES TO CHECK JMS TO FIELD 4
2045	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
2046	7340	CLA CLL CMA		/SET THE AC TO ALL ONE'S
2047	6004	GTF		/GET THE FLAGS
2050	1124	TAD	M1043	/CHECK FOR INT, REQ,, ISF OF 4 AND DSF OF 3,
2051	7640	SEA CLA		
2052	4454	ERROR		/SAVE FIELD NOT EQUAL TO ABOVE
2053	6234	R1B		/READ THE INTERRUPT BUFFER
2054	1101	TAD	M43	/CHECK FOR ISF OF 4 AND DSF OF 3
2055	7640	SEA CLA		
2056	4454	ERROR		/SAVE FIELD NOT EQUAL TO ABOVE
2057	2033	ISE	COPCHK	
2060	4454	ERROR		/DCA I WENT TO FIELD 0 INSTEAD OF FIELD 3
2061	2244	ISE	CKJMS6	
2062	4454	ERROR		/JMS I WENT TO FIELD 0 INSTEAD OF FIELD 4
2063	7340	TST12G, CLA CLL CMA		/SET COPCHK AND CKJMS7 TO ONES TO
2064	3033	DCA	COPCHK	/CHECK FOR DCA I TO ANOTHER FIELD AND A
2065	7240	CLA CMA		/JMS I TO ANOTHER FIELD
2066	3275	DCA	CKJMS7	
2067	6271	CDF	70	/CHANGE DATA FIELD TO FIELD 7
2070	6202	CIF	00	/CHANGE INSTRUCTION FIELD TO FIELD 0
2071	3434	DCA I	CHKCDF	/CHANGE EMA LINES TO 7
2072	6001	IOV		/TURN INTERRUPT ON
2073	4674	JMS I	,*1	/CLEAR INTERRUPT INHIBIT
2074	2075	CKJMS7		/INDIRECT ADDRESS
2075	7402	CKJMS7, HLT		/THIS LOCATION WAS SET TO ONE'S BUT SHOULD CHANGE
2076	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
2077	7340	CLA CLL CMA		
2100	6004	GTF		/GET THE FLAGS
2101	1120	TAD	M1007	/CHECK FOR INT, REQ,, ISF#0, DSF#7
2102	7640	SEA CLA		
2103	4454	ERROR		/SAVE FIELD NOT EQUAL TO ABOVE
2104	6234	R1B		/READ THE INTERRUPT BUFFER
2105	1066	TAD	M7	/CHECK FOR DSF OF 7
2106	7640	SEA CLA		
2107	4454	ERROR		/SAVE FIELD NOT EQUAL TO DSF OF 7

2110	2033	ISE	COPCHK	
2111	4454	ERROR		/DCA I WENT TO FIELD 0 INSTEAD OF FIELD 7
2112	2275	ISE	CKJMS7	
2113	7410	SKP		
2114	4454	ERROR		/JMS I TO FIELD 0 WENT TO ANOTHER FIELD
2115	7340	TST12H, CLA CLL CMA		/SET UP COPCHK TO ONES TO CHECK THAT
2116	3033	DCA	COPCHK	/DCA I TO FIELD 0 WILL CLEAR IT AND SET
2117	7340	CLA CLL CMA		/LOCATION CKJMS8 TO 1'S TO CHECK THAT
2120	3327	DCA	CKJMS8	/JMS I TO FIELD 7 WON'T CLEAR IT
2121	6201	CDF	00	/CHANGE DATA FIELD TO FIELD 0
2122	6272	CIF	70	/CHANGE INSTRUCTION FIELD TO FIELD 7
2123	3434	DCA I	CHKCDF	/CLEAR LOCATION COPCHK IF EMA LINES WENT TO ZERO
2124	6001	IOV		/TURN THE INTERRUPT ON
2125	4720	JMS I	,*1	/CLEAR INTERRUPT INHIBIT
2126	2127	CKJMS8		/INDIRECT ADDRESS
2127	7402	CKJMS9, HLT		/THIS LOCATION PRESET TO 1'S, IT SHOULD NOT CHANGE
2130	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
2131	7340	CLA CLL CMA		/SET THE AC TO ALL ONES
2132	6004	GTF		/GET THE FLAGS
2133	1127	TAD	M1070	/CHECK FOR INT, REQ,, ISF#7 AND DSF#0
2134	7640	SEA CLA		
2135	4454	ERROR		/SAVE FIELD REGISTER NOT EQUAL TO ABOVE
2136	6234	R1B		/READ THE INTERRUPT BUFFER
2137	1111	TAD	M70	/CHECK SAVE FIELDS FOR ISF OF 7 AND DSF OF 0
2140	7640	SEA CLA		
2141	4454	ERROR		/SAVE FIELD NOT EQUAL TO ABOVE
2142	2033	ISE	COPCHK	
2143	7410	SKP		
2144	4454	ERROR		/DCA I TO FIELD 0 WENT TO ANOTHER FIELD
2145	2027	ISE	CKJMS8	
2146	4454	ERROR		/JMS I TO FIELD 7 WENT TO FIELD 0
2147	7240	TST12I, CLA CMA		/SET UP COPCHK AND CKJMS9 TO ONES TO
2150	3033	DCA	COPCHK	/CHECK THAT DCA I AND JMS I TO FIELD 0
2151	7340	CLA CLL CMA		/WILL CHANGE THESE LOCATIONS
2152	3361	DCA	CKJMS9	
2153	6201	CDF	00	/CHANGE DATA FIELD TO FIELD 0
2154	6202	CIF	00	/CHANGE INSTRUCTION FIELD TO FIELD 0
2155	3434	DCA I	CHKCDF	/CLEAR LOCATION COPCHK
2156	6001	IOV		/SET INTERRUPT ENABLE
2157	4760	JMS I	,*1	/CLEAR INTERRUPT INHIBIT
2160	2161	CKJMS9		/INDIRECT ADDRESS
2161	7402	CKJMS9, HLT		/THIS LOCATION PRESET TO ONES, SHOULD CHANGE
2162	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
2163	7340	CLA CLL CMA		/SET THE AC TO ALL ONE'S
2164	6004	GTF		/GET THE FLAGS
2165	1117	TAD	M1000	/CHECK FOR INTERRUPT REQUEST
2166	7640	SEA CLA		
2167	4454	ERROR		/SAVE FIELD NOT EQUAL TO ABOVE
2170	6234	R1B		/READ THE INTERRUPT BUFFER
2171	7640	SEA CLA		/IS THE SAVE FIELD EQUAL TO 0
2172	4454	ERROR		/SAVE FIELD NOT EQUAL TO ZERO
2173	2033	ISE	COPCHK	
2174	7410	SKP		
2175	4454	ERROR		/DCA I TO FIELD 0 DID NOT GO TO FIELD 0
2176	2361	ISE	CKJMS9	

```

2177 7410 SKP
2200 4454 ERROR /JMS I TO FIELD 0 DID NOT GO TO FIELD 0
2201 1150 TAD K7707 /CHECK THE INCLUSIVE OR OF RIF WITH AC
2202 6224 RIF
2203 1137 TAD K70
2204 7040 CMA
2205 7640 SEA CLA
2206 4454 ERROR /THE INCLUSIVE OR OF IF WITH AC FAILED
2207 6254 SINT /SKIP ON USER INTERRUPT
2210 4454 ERROR /USER INTERRUPT FLIP=FLOP GOT CLEARED
2211 6007 CAF /CLEAR ALL FLAGS
2212 6254 SINT /SKIP ON USER INTERRUPT
2213 7410 SKP
2214 4454 ERROR /INIT FAILED TO CLEAR USER INTERRUPT F/F
2215 4455 LOOP /LOOP ON TEST IF SR = 1000

```

.....
 /TEST 13 = CHECKS THE MICRO PROGRAM INSTRUCTIONS CDF CIF (62X3), A DCA I
 /AND JMS ARE ALSO ISSUED TO CHECK THAT THESE INSTRUCTIONS DO NOT DESTROY
 /LOCATIONS IN FIELD 0; THE USER INTERRUPT F/F IS USED TO CAUSE INTERRUPTS,


```

2216 4456 TEST13, SCOPLP /SETUP TEST AND SCOPLE LOOPING ADDRESS
2217 6007 CAF /CLEAR ALL FLAGS
2220 6202 CDF 00 /INITIALIZE THE IF AND DF TO FIELD 0
2221 6201 CDF 00 /
2222 5223 JMP ,+1 /LOAD THE IF BY A JMP
2223 6001 JON /TURN THE INTERRUPT ON
2224 6274 SUP /SET THE USER BUFFER F/F
2225 5226 JMP ,+1 /ENTER USER MODE
2226 7402 HLT /PROGRAM FAILED TO TRAP
2227 5227 JMP /HALT FAILED TO TRAP
2230 6254 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
2231 4454 ERROR /USER INTERRUPT FLIP=FLOP NOT SET
2232 6234 RIB /READ THE INTERRUPT BUFFER
2233 1113 TAD M100
2234 7640 SEA CLA
2235 4454 ERROR /USER FLAG NOT SET OR SAVE FIELD NON ZERO
2236 7240 TST13A, CLA CMA /SETUP TWO LOCATIONS TO CHECK THAT A CIF,CDF
2237 3033 DCA CDFCHK /WENT TO ANOTHER FIELD BY DOING A DCA I AND JMS
2240 7240 CLA CMA
2241 3246 DCA JMSCK1
2242 6273 CIFCDF 70 /CHANGE IF AND DF TO FIELD 7
2243 3434 DCA I CHKCDF /TRY TO CLEAR CDFCHK IN FIELD 7
2244 6001 JON /SET INTERRUPT ENABLE
2245 4246 JMS JMSCK1 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
2246 7402 HLT /THIS LOCATION PRESET TO 7777
2247 4454 ERROR /PROGRAM FAILED TO INTERRUPT
2250 6234 RIB /READ THE INTERRUPT BUFFER
2251 1112 TAD M77 /CHECK SAVE FIELD FOR ISF OF 7 AND DSF OF 7
2252 7640 SEA CLA
2253 4454 ERROR /CIFCDF TO FIELD 7 FAILED OR SAVE FIELD NOT=TO 77
2254 2033 ISE CDFCHK
2255 4454 ERROR /DCA I TO FIELD 7 WENT TO FIELD 0
2256 2246 ISE JMSCK1

```

```

2257 4454 ERROR /JMS TO FIELD 7 WENT TO FIELD 0
2260 6254 SINT /SKIP ON USER INTERRUPT F/F
2261 4454 ERROR /USER INTERRUPT F/F GOT CLEARED
2262 7240 TST13B, CLA CMA /SETUP TWO LOCATIONS TO CHECK THAT CIFCDF 20
2263 3033 DCA CDFCHK /WENT TO ANOTHER FIELD THAN FIELD 0
2264 7240 CLA CMA
2265 3272 DCA JMSCK2
2266 6223 CIFCDF 20 /CHANGE INSTRUCTION FIELD AND DATA FIELD TO 2
2267 3434 DCA I CHKCDF /TRY TO CLEAR CDFCHK IN FIELD 2
2270 6001 JON /SET INTERRUPT ENABLE
2271 4272 JMS JMSCK2 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
2272 7402 HLT /THIS LOCATIONS PRESET TO 7777
2273 4454 ERROR /PROGRAM FAILED TO INTERRUPT
2274 6234 RIB /READ THE INTERRUPT BUFFER
2275 1073 TAD M22 /CHECK SAVE FIELD FOR ISF=2 + DSF=2
2276 7640 SEA CLA
2277 4454 ERROR /SAVE FIELD NOT EQUAL TO CIFCDF 20 FAILED
2300 2033 ISE CDFCHK
2301 4454 ERROR /DCA I TO FIELD 2 WENT TO FIELD 0
2302 2272 ISE JMSCK2
2303 4454 ERROR /JMS TO FIELD 2 WENT TO FIELD 0
2304 7240 TST13C, CLA CMA /SETUP TWO LOCATIONS TO CHECK THAT CIFCDF 50
2305 3033 DCA CDFCHK /WENT TO ANOTHER FIELD THAN FIELD 0
2306 7240 CLA CMA
2307 3314 DCA JMSCK3
2310 6253 CIFCDF 50 /CHANGE INSTRUCTION FIELD AND DATA FIELD TO FIELD 5
2311 3434 DCA I CHKCDF /TRY TO CLEAR CDFCHK IN FIELD 5
2312 6001 JON /SET INTERRUPT ENABLE
2313 4314 JMS JMSCK3 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
2314 7402 HLT /THIS LOCATIONS PRESET TO 7777
2315 4454 ERROR /PROGRAM FAILED TO INTERRUPT
2316 6234 RIB /READ THE INTERRUPT BUFFER
2317 1105 TAD M55 /CHECK FOR ISF OF 5 AND DSF OF 5
2320 7640 SEA CLA
2321 4454 ERROR /SAVE FIELD NOT EQUAL TO ISF,DSF OF 5
2322 2033 ISE CDFCHK
2323 4454 ERROR /DCA I TO FIELD 5 WENT TO FIELD 0
2324 2314 ISE JMSCK3
2325 4454 ERROR /JMS TO FIELD 5 WENT TO FIELD 0
2326 6254 SINT /SKIP ON USER INTERRUPT F/F
2327 4454 ERROR /USER INTERRUPT F/F GOT CLEARED
2330 7240 TST13D, CLA CMA /SETUP TWO LOCATIONS TO CHECK
2331 3033 DCA CDFCHK /THAT CIFCDF TO FIELD 4 WENT TO ANOTHER
2332 7240 CLA CMA /FIELD THAN FIELD 0
2333 3340 DCA JMSCK4
2334 6243 CIFCDF 40 /CHANGE INSTRUCTION FIELD AND DATA FIELD TO FIELD 4
2335 3434 DCA I CHKCDF /TRY TO CLEAR CDFCHK IN FIELD 4
2336 6001 JON /SET INTERRUPT ENABLE
2337 4340 JMS JMSCK4 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
2340 7402 HLT /THIS LOCATION PRESET TO ONE'S
2341 4454 ERROR /PROGRAM FAILED TO INTERRUPT
2342 6234 RIB /READ THE INTERRUPT BUFFER
2343 1102 TAD M44 /CHECK ISF FOR 4 AND DSF FOR 4
2344 7640 SEA CLA
2345 4454 ERROR /SAVE FIELD NOT EQUAL TO 44

```

```

2346 2033      ISR   CDFCHK
2347 4494      ERROR
2350 2340      ISR   JMSCK4
2351 4494      ERROR
2352 6294      SINT
2353 4494      ERROR
2354 7340      TST13E, CLA CLA CMA
2355 3033      DCA   CDFCHK
2356 7240      CLA CMA
2357 3364      DCA   JMSCK5
2360 6233      CDFCF 30
2361 3434      DCA I  CHKCDF
2362 6001      IOV
2363 4364      JMS   JMSCK5
2364 7402      JMSCK5, HLT
2365 4494      ERROR
2366 6234      RIB
2367 1076      TAD   M33
2370 7640      SEA CLA
2371 4494      ERROR
2372 2033      ISR   CDFCHK
2373 4494      ERROR
2374 2364      ISR   JMSCK5
2375 4494      ERROR
2376 6294      SINT
2377 4494      ERROR
2400 7240      TST13F, CLA CMA
2401 3033      DCA   CDFCHK
2402 7240      CLA CMA
2403 3210      DCA   JMSCK6
2404 6263      CDFCF 60
2405 3434      DCA I  CHKCDF
2406 6001      IOV
2407 4210      JMS   JMSCK6
2410 7402      JMSCK6, HLT
2411 4494      ERROR
2412 6234      RIB
2413 1110      TAD   M66
2414 7640      SEA CLA
2415 4494      ERROR
2416 2033      ISR   CDFCHK
2417 4494      ERROR
2420 2210      ISR   JMSCK6
2421 4494      ERROR
2422 6294      SINT
2423 4494      ERROR
2424 7240      TST13G, CLA CMA
2425 3033      DCA   CDFCHK
2426 7240      CLA CMA
2427 3234      DCA   JMSCK7
2430 6213      CDFCF 10
2431 3434      DCA I  CHKCDF
2432 6001      IOV
2433 4234      JMS   JMSCK7
2434 7402      JMSCK7, HLT

```

```

2435 4494      ERROR
2436 6234      RIB
2437 1070      TAD   M11
2440 7640      SEA CLA
2441 4494      ERROR
2442 2033      ISR   CDFCHK
2443 4494      ERROR
2444 2234      ISR   JMSCK7
2445 4494      ERROR
2446 6294      SINT
2447 4494      ERROR
2450 7240      TST13H, CLA CMA
2451 3033      DCA   CDFCHK
2452 7240      CLA CMA
2453 3260      DCA   JMSCK8
2454 6203      CDFCF 00
2455 3434      DCA I  CHKCDF
2456 6001      IOV
2457 4260      JMS   JMSCK8
2460 7402      JMSCK8, HLT
2461 4494      ERROR
2462 6234      RIB
2463 7640      SEA CLA
2464 4494      ERROR
2465 2033      ISR   CDFCHK
2466 7410      SKP
2467 4494      ERROR
2470 2260      ISR   JMSCK8
2471 7410      SKP
2472 4494      ERROR
2473 6204      CINT
2474 6294      SINT
2475 7410      SKP
2476 4494      ERROR
2477 4495      LOOP

```

.....
/TEST 14 = CHECKS THAT RTF CAN LOAD THE IF AND DF AND THAT RMF CAN
/RELOAD IT.
.....

```

2500 4456      TEST14, SCDFP
2501 6007      CAP
2502 6001      IOV
2503 6274      SUP
2504 5305      JMP   *4
2505 7402      HLT
2506 5306      JMP
2507 6294      SINT
2510 4494      ERROR
2511 6234      RIB
2512 1113      TAD   M100
2513 7640      SEA CLA
2514 4494      ERROR
2515 1144      TST14A, TAD   K125

```

2516	6005	RTP		/LOAD THE UB, IB, + DF WITH USER FLAG; IF DF OF 2 + DF OF 5
2517	7300	CLA CLL		/AND SET INTERRUPT ENABLE
2520	6214	RDF		/READ THE DATA FIELD
2521	1103	TAJ	M50	/CHECK THAT FIELD 5 GOT LOADED
2522	7640	SEA CLA		
2523	7402	HLT		/RTP FAILED TO LOAD DATA FIELD TO 5
2524	5325	JMP	+1	/ENTER USER MODE, CLEAR INT INHIBIT, AND INTERRUPT
2525	4454	ERRM		/FAILED TO INTERRUPT; RTP OR JMP FAILED
2526	6254	SINT		/SKIP ON USER INTERRUPT F/F
2527	4454	ERRM		/SINT FAILED OR USER INTERRUPT F/F CLEARED
2530	6234	RIB		/CHECK FOR USER FLAG, ISF OF 2 AND DSF OF 5
2531	1114	TAJ	M125	
2532	7640	SEA CLA		
2533	4454	ERRM		/SAVE FIELD NOT EQUAL TO ABOVE
2534	6244	RMP		/LOAD THE UB, IB, + DF FROM THE SAVE FIELD
2535	6214	RDF		/READ THE DATA FIELD
2536	1103	TAJ	M50	/CHECK THAT RMP LOADED THE DF
2537	7640	SEA CLA		
2540	4454	ERRM		/RMP FAILED TO LOAD DF TO FIELD 5
2541	6001	IOV		/SET INTERRUPT ENABLE
2542	5343	JMP	+1	/LOAD THE IF, CLEAR INTERRUPT INHIBIT, ENTER USER MODE
2543	4454	ERRM		/FAILED TO INTERRUPT OR RMP JMP FAILED
2544	6254	SINT		/SKIP ON USER INTERRUPT FLIP-FLOP FAILED
2545	4454	ERRM		/USER INTERRUPT FLIP-FLOP NOT SET
2546	6234	RIB		/READ THE INTERRUPT BUFFER
2547	1114	TAJ	M125	/CHECK FOR USER FLAG, ISF OF 2 AND DSF OF 5
2550	7640	SEA CLA		
2551	4454	ERRM		/RMP FAILED TO LOAD THE ABOVE
2552	1142	TST140, TAJ	K152	
2553	6005	RTP		/LOAD THE UB, IB, + DF WITH UF, ISF OF 5 AND DSF OF 2
2554	7300	CLA CLL		/AND SET INTERRUPT ENABLE
2555	6214	RDF		/READ THE DATA FIELD
2556	1072	TAJ	M20	/CHECK FOR A DF SET TO FIELD 2
2557	7640	SEA CLA		
2560	7402	HLT		/RTP FAILED TO LOAD DF WITH 2
2561	5362	JMP	+1	/ENTER USER MODE CLEAR INTERRUPT INHIBIT
2562	4454	ERRM		/FAILED TO INTERRUPT
2563	6254	SINT		/SKIP ON USER INTERRUPT
2564	4454	ERRM		/USER INTERRUPT NOT SET
2565	6234	RIB		/READ THE INTERRUPT BUFFER
2566	1115	TAJ	M152	/CHECK FOR USER FLAG, ISF OF 5 AND DSF OF 2
2567	7640	SEA CLA		
2570	4454	ERRM		/SAVE FIELD NOT EQUAL TO ABOVE
2571	6244	RMP		/RESTORE MEMORY FIELDS
2572	6214	RDF		/READ THE DATA FIELD
2573	1072	TAJ	M20	/CHECK THAT RMP LOADED DF TO FIELD 2
2574	7640	SEA CLA		
2575	4454	ERRM		/RMP FAILED TO LOAD DF TO FIELD 2
2576	7000	NOP		
2577	6001	IOV		/SET INTERRUPT ENABLE
2600	5201	JMP	+1	/CLEAR INTERRUPT INHIBIT, LOAD IF, ENTER USER MODE
2601	4454	ERRM		/FAILED TO INTERRUPT
2602	6254	SINT		/SKIP ON USER INTERRUPT
2603	4454	ERRM		/USER INTERRUPT NOT SET
2604	6234	RIB		/READ THE INTERRUPT BUFFER

2605	1115	TAJ	M152	/CHECK SF FOR USER FLAG, ISF OF 5 AND DSF OF 2
2606	7640	SEA CLA		
2607	4454	ERRM		/RMP FAILED TO LOAD THE ABOVE
2610	6254	TST140, SINT		/SKIP ON USER INTERRUPT FLIP-FLOP
2611	4454	ERRM		/USER INTERRUPT FLIP-FLOP GOT CLEARED,
2612	1140	TAJ	K77	/LOAD DATA FIELD AND IB TO FIELD 7
2613	6005	RTP		/RESTORE THE FLAGS AND SET INTERRUPT ENABLE
2614	7300	CLA CLL		
2615	6214	RDF		/READ THE DATA FIELD
2616	1111	TAJ	M70	/CHECK FOR DATA FIELD SET TO FIELD 7
2617	7640	SEA CLA		
2620	7402	HLT		/RTP FAILED TO SET UP TO FIELD 7
2621	5222	JMP	+1	/CLEAR INTERRUPT INHIBIT AND INTERRUPT
2622	4454	ERRM		/PROGRAM FAILED TO INTERRUPT ON USER INTERRUPT
2623	6234	RIB		/READ THE INTERRUPT BUFFER
2624	1112	TAJ	M77	/CHECK FOR UF=0, ISF=7 AND DSF=7
2625	7640	SEA CLA		
2626	4454	ERRM		/SAVE FIELD NOT EQUAL TO ABOVE
2627	6254	SINT		/SKIP ON USER INTERRUPT
2630	4454	ERRM		/USER INTERRUPT GOT CLEARED
2631	6244	RMP		/RESTORE MEMORY FIELDS
2632	6214	RDF		/CHECK THAT RMP RESTORED THE DF
2633	1111	TAJ	M70	
2634	7640	SEA CLA		
2635	4454	ERRM		/RMP FAILED TO LOAD DF TO 7
2636	6274	RIF		/CHECK INSTRUCTION FIELD TO BE SET 0
2637	7640	SEA CLA		
2640	4454	ERRM		/IF IS NON ZERO AFTER A RMP
2641	6001	IOV		/SET INTERRUPT ENABLE
2642	5243	JMP	+1	/CLEAR INTERRUPT INHIBIT AND INTERRUPT
2643	4454	ERRM		/PROGRAM FAILED TO INTERRUPT;
2644	6234	RIB		/READ THE INTERRUPT BUFFER
2645	1112	TAJ	M77	/CHECK FOR ISF AND DSF = TO 7
2646	7640	SEA CLA		
2647	4454	ERRM		/RMP FAILED TO RESTORE IF AND DF TO 7
2650	6254	TST140, SINT		/SKIP ON USER INTERRUPT FLIP-FLOP
2651	4454	ERRM		/USER INTERRUPT CLEARED
2652	6005	RTP		/RESTORE THE FLAGS, SET IB+DF TO ZERO
2653	5254	JMP	+1	/CLEAR INTERRUPT INHIBIT AND INTERRUPT
2654	4454	ERRM		/PROGRAM FAILED TO INTERRUPT
2655	6234	RIB		/READ THE INTERRUPT BUFFER
2656	7640	SEA CLA		
2657	4454	ERRM		/THE ISF OR DSF IS NON ZERO
2660	6244	RMP		/RESTORE MEMORY FIELDS
2661	6001	IOV		/SET INTERRUPT ENABLE
2662	5263	JMP	+1	/CLEAR INTERRUPT INHIBIT AND INTERRUPT
2663	4454	ERRM		/PROGRAM FAILED TO INTERRUPT
2664	6234	RIB		/READ THE INTERRUPT BUFFER
2665	7640	SEA CLA		
2666	4454	ERRM		/RMP FAILED TO RELOAD IF AND DF TO ZERO
2667	6204	SINT		/CLEAR USER INTERRUPT FLIP-FLOP
2670	6254	SINT		/SKIP ON USER INTERRUPT FLIP-FLOP
2671	7610	SKP	CLA	
2672	4454	ERRM		/SINT FAILED TO CLEAR USER INTERRUPT
2673	4455	LOOP		/LOOP ON TEST IF SR = 1000

.....
 /TEST 19 = SETS THE UB TO A 1, THE IF AND OF TO FIELD 6, THE PROGRAM
 /THEN ISSUES AND, TAD, ISZ, AND DCA INDIRECTS TO CHECK THAT THE
 /PROGRAM DOESN'T INTERRUPT UNTIL A JUMP INSTRUCTION IS ISSUED,

2674	4456	TEST19, SCOPLP	/SETUP SCOPE AND TEST LOOPING ADDRESS
2675	6007	CAF	/CLEAN ALL FLAGS
2676	6203	CIFCOF	/CHANGE DATA AND INSTRUCTION FIELD TO 0
2677	5300	JMP	/CLEAN INTERRUPT INHIBIT
2700	6264	CUP	/CLEAN USER FLAG
2701	6204	CINT	/CLEAN USER INTERRUPT FLIP=FLOP
2702	6001	IOV	/SET INTERRUPT ENABLE
2703	6274	SUP	/SET USER BUFFER FLIP=FLOP
2704	5305	JMP	/CLEAN INTERRUPT INHIBIT
2705	7402	HLT	/FAILED TO ENTER USER MODE
2706	5306	JMP	/HLT FAILED TO TRAP
2707	6294	SINT	/SKIP ON USER INTERRUPT FLIP=FLOP
2710	4494	ERROR	/USER INTERRUPT FLIP=FLOP NOT SET
2711	6234	R13	/HEAD THE INTERRUPT BUFFER
2712	1113	TAD	/CHECK FOR USER FLAG
2713	7640	SEA CLA	
2714	4494	ERROR	/USER FLAG NOT SET
2715	6263	CIFCOF	/CHANGE IB AND OF TO FIELD 6 AND SET INTERRUPT INHIBIT
2716	6001	IOV	/SET INTERRUPT ENABLE, THE PROGRAM
			/SHOULDN'T INTERRUPT UNTIL A JMP OR JMS IS ISSUED,
			/CHECK THAT PROGRAM DOESN'T INTERRUPT
2717	7000	NOF	
2720	7410	SKP	
2721	7402	HLT	/PROGRAM INTERRUPTED BEFORE A JMP WAS ISSUED
2722	3723	DCA I	/DO A DCA I TO NEXT LOCATIONS
2723	7410	SKP	
2724	7402	HLT	/PROGRAM INTERRUPTED BEFORE A JMP WAS ISSUED
2725	1726	TAD I	/DO A TAD I TO NEXT LOCATION
2726	7410	SKP	
2727	7402	HLT	/PROGRAM INTERRUPTED BEFORE A JMP WAS ISSUED
2730	0731	AND I	/DO A AND I TO THE NEXT LOCATION
2731	7410	SKP	
2732	7402	HLT	/PROGRAM INTERRUPTED BEFORE A JMP WAS ISSUED
2733	2734	ISZ I	/DO A ISZ I TO THE NEXT LOCATION
2734	7410	SKP	
2735	7402	HLT	/PROGRAM INTERRUPTED BEFORE A JMP WAS ISSUED
2736	5337	JMP	/CLEAN INTERRUPT INHIBIT AND INTERRUPT
2737	4494	ERROR	/PROGRAM FAILED TO INTERRUPT
2740	6234	R13	/HEAD THE INTERRUPT BUFFER
2741	1110	TAD	/CHECK FOR ISF AND USF OF 6
2742	7640	SEA CLA	
2743	4494	ERROR	/SAVE FIELD NOT EQUAL TO 66
2744	6294	SINT	/SKIP ON USER INTERRUPT F/F
2745	4494	ERROR	/USER INTERRUPT F/F NOT SET
2746	7300	CLA CLL	/CLEAN AC AND LINK
2747	6203	CIFCOF	/SET IB AND OF TO 2
2750	6001	IOV	/SET INTERRUPT ENABLE
2751	5392	JMP	/CLEAN INTERRUPT INHIBIT
2752	4494	ERROR	/PROGRAM FAILED TO INTERRUPT

2753	6294	SINT	/SKIP ON USER INTERRUPT
2754	4494	ERROR	/USER INTERRUPT NOT SET
2755	6204	CINT	/CLEAN USER INTERRUPT
2756	7340	CLA CLL CMA	/SET THE AC TO ONES AND LINK TO 0
2757	6004	GTF	/GET THE FLAGS
2760	7640	SEA CLA	
2761	4494	ERROR	/THE LINK, INT REQ, OR SAVE FIELD NON ZERO
2762	4495	LOOP	/LOOP ON TEST IF SR = 1000

.....
 /TEST 19 = IS A DATA TEST TO CHECK THAT DATA CAN BE DEPOSITED INTO EACH
 /SELECTED EXTENDED FIELD, DATA IS DEPOSITED INTO THE LAST ADDRESS OF
 /EACH 1K MEMORY SEGMENT IN THE EXTENDED MEMORY FIELD, THE USER INTERRUPT
 /IS SET FOR THIS TEST, THE PROGRAM CHANGES THE DATA FIELD TO THE NEW FIELD
 /CHECKS, IT THEN TURNS THE INTERRUPT ON AND DOES A DCA I TO THE LAST
 /ADDRESS IN A 1K MEMORY SEGMENT OF THAT FIELD, THE PROGRAM THEN DOES THE
 /SAME AS ABOVE, ONLY DOING A TAD I TO THE LAST ADDRESS OF A 1K MEMORY
 /SEGMENT, THE DATA THAT IS PUT INTO THE LAST ADDRESS OF EACH EXTENDED
 /1K MEMORY SEGMENT CONTAINS THE FIELD IN BITS 6-8 AND THE 1K SEGMENT IN
 /BITS 9=11,

2763	4456	TEST19, SCOPLP	/SETUP TEST AND SCOPE LOOPING ADDRESS
2764	6007	CAF	/CLEAN ALL FLAGS
2765	6001	IOV	/TURN THE INTERRUPT ON
2766	1021	TAD	/GET MEMORY SIZE FROM LOCATION 21
2767	0136	AND	/MASK OFF THE MEMORY BITS
2770	7104	CLL	/ROTATE BITS LEFT ONCE TO SETUP FOR FIELD
2771	3036	DCA	/LIMIT AND LAST ADDRESS IN LAST FIELD
2772	1036	TAD	/GET THE NUMBER
2773	0137	AND	/MASK OFF BITS 6-8 FOR FIELD LIMIT
2774	3037	DCA	/SAVE THE NUMBER AS THE LAST SELECTED FIELD
2775	1036	TAD	/GET THE ROTATED NUMBER
2776	0134	AND	/MASK OFF ADDRESS BITS
2777	7112	CLL	/ROTATE THE NUMBER 4 PLACES TO THE RIGHT
3000	7012	RTR	
3001	1145	TAD	/ADD 1K TO THE NUMBER
3002	3040	DCA	/SAVE THIS NUMBER AS THE LAST ADDRESS IN LAST FIELD
3003	1037	TAD	/GET THE FIELD LIMIT
3004	7650	SNA	/IS THE LAST FIELD 0 TO FIELD 0
3005	5777	JMP	/YES, ABORT THIS TEST, GO CHECK FOR SIMULATOR EMA TEST
3006	4776	JMS	/CHECK FOR ACT LINE AND 32K OF MEMORY
3007	6001	IOV	/TURN THE INTERRUPT ON
3010	6274	SUP	/SET USER BUFFER F/F
3011	5212	JMP	
3012	7402	HLT	/SHOULD TRAP HERE
3013	5213	JMP	/HALT FAILED TO TRAP
3014	6294	SINT	/SKIP ON USER INTERRUPT
3015	4494	ERROR	/USER INTERRUPT NOT SET
3016	7340	CLA CLL CMA	/SET THE AC TO ALL ONES
3017	6004	GTF	/GET THE FLAGS
3020	1130	TAD	/CHECK FOR USER FLAG AND INT REQ
3021	7640	SEA CLA	
3022	4494	ERROR	/SAVE FIELD NOT EQUAL TO ABOVE

3023	3041	DCA	WRKFLD	/CLEAN WORKING FIELD
3024	3042	DCA	DATPAT	/CLEAN DATA PATTERN
3025	1149	TAD	K1777	/GET UPPER ADDRESS OF 1K FIELD
3026	3043	DCA	WRKADD	/SET FIRST ADDRESS EQUAL TO 1777
3027	1041	TAD	WRKFLD	/GET THE WORKING FIELD
3030	1135	TAD	K10	/ADD A FIELD TO IT
3031	3041	DCA	WRKFLD	
3032	1041	TAD	WRKFLD	
3033	7041	CIA		/GET THE WORKING FIELD
3034	1037	TAD	FLDLIM	/NEGATE IT
3035	7510	SPA		/COMPARE IT TO THE FIELD LIMIT
3036	5344	JMP	ENDTST	/IS THE NEW FIELD GREATER THAN FIELD LIMIT
3037	7640	SEA	CLA	/YES END OF TEST
3040	7240	CLA	CMA	/IS NEW FIELD EQUAL TO LAST FIELD
3041	7450	SNA		/NO, THE LAST ADDRESS IN THIS FIELD WILL BE 7777
3042	1040	TAD	UPERLH	/YES, THE LAST ADDRESS WILL BE EQUAL TO UPERLH
3043	3044	DCA	HGHLIM	
3044	1044	TAD	HGHLIM	/SAVE THE LAST ADDRESS IN THIS FIELD
3045	7040	CMA		/GET THE HIGH LIMIT
3046	7106	CLL	RTL	/COMPLEMENT IT
3047	7004	RAL		/ROTATE 3 PLACES TO THE RIGHT
3050	1147	TAD	K7774	/
3051	3047	DCA	ADDCNT	/ADD IN 4K ADDRESS CONSTANT
3052	1041	TAD	WRKFLD	/SAVE IT
3053	7001	IAC		/GET THE NEW FIELD
3054	3042	DCA	DATPAT	/ADD 1 TO IT
3055	6254	T16LCO, SINT		/SAVE THE WORD AS THE DATA PATTERN
3056	4454	ERROR		/SKIP ON USER INTERRUPT
3057	1041	TAD	WRKFLD	/USER INTERRUPT GOT CLEARED
3060	1045	TAD	K6201	/GET THE NEW FIELD
3061	3262	DCA	,*1	/GET THE GDF INSTRUCTION
				/PUT GDF TO NEW FIELD IN NEXT ADDRESS
3062	7402	CDPNEW, HLT/GDF		
3063	6214	RDF		/CHANGE DATA FIELD TO NEW FIELD
3064	7041	CIA		/READ THE DATA FIELD
3065	1041	TAD	WRKFLD	/NEGATE IT
3066	7640	SEA	CLA	/GET THE NEW FIELD
3067	4454	ERROR		
3070	1042	TAD	DATPAT	/GDF TO NEW FIELD FAILED
3071	6001	IOV		/GET THE DATA PATTERN
3072	3443	DCA	WRKADD	/TURN THE INTERRUPT ON
3073	4454	ERROR		/PUT THE WORD UP IN NEW FIELD AND INTERRUPT
3074	1041	TAD	WRKFLD	/PROGRAM FAILED TO INTERRUPT
3075	7112	CLL	RTR	
3076	7010	SAR		
3077	3046	DCA	SAVWFD	
3100	6234	RIB		/SAVE THE WORKING FIELD IN BITS 9=11
3101	7041	CIA		/READ THE INTERRUPT BUFFER
3102	1040	TAD	SAVWFD	/NEGATE IT
3103	7640	SEA	CLA	/GET THE EXPECTED WORKING SAVE FIELD
3104	4454	ERROR		
3105	6254	SINT		/SAVE FIELD NOT EQUAL TO EXPECTED FIELD
3106	4454	ERROR		/SKIP ON USER INTERRUPT F/F
3107	1262	TAD	CDPNEW	/USER INTERRUPT GOT CLEARED
3110	3311	DCA	,*1	/GET THE GDF INSTRUCTION TO THE NEW FIELD
				/PUT IT IN THE NEXT LOCATION

3111	7402	HLT/GDF		
3112	6214	RDF		/GDF TO NEW FIELD
3113	7041	CIA		/READ THE DATA FIELD
3114	1041	TAD	WRKFLD	/NEGATE IT
3115	7640	SEA	CLA	/GET THE WORKING FIELD
3116	4454	ERROR		
3117	6001	IOV		/GDF TO NEW FIELD FAILED
3120	1443	TAD	WRKADD	/TURN THE INTERRUPT ON
3121	4454	ERROR		/GET DATA PATTERN FROM NEW FIELD
3122	6234	RIB		/PROGRAM FAILED TO INTERRUPT
3123	7041	CIA		/READ THE INTERRUPT BUFFER
3124	1040	TAD	SAVWFD	/NEGATE IT
3125	7640	SEA	CLA	/GET THE EXPECTED SAVE FIELD
3126	4454	ERROR		/ARE THEY EQUAL
3127	1042	TAD	DATPAT	/NO, EXPECTED SAVE FIELD NOT EQUAL TO FIELD READ
3130	7041	CIA		/GET THE DATA PATTERN
3131	1035	TAD	DATREC	/NEGATE IT
3132	7640	SEA	CLA	/GET THE WORD RECEIVED
3133	4454	ERROR		/ARE THEY EQUAL?
3134	2047	ISE	ADDCNT	/NO, DATA ERROR IN WRKFLD
3135	7610	SKP	CLA	/GET NEXT ADDRESS IN THIS FIELD?
3136	9225	JMP	BEGT16	/YES
3137	1043	TAD	WRKADD	/NO, GO GET NEXT FIELD IF ANY LEFT
3140	1146	TAD	K2000	/GET THE WORKING ADDRESS
3141	3043	DCA	WRKADD	/ADD 1K TO IT
3142	2042	ISE	DATPAT	/SAVE NEW 1K UPPER ADDRESS BOUNDARY
3143	9255	JMP	T16LCO	/ADD ANOTHER 1K TO DATA WORD
3144	6204	EYDIST, CINT		/GO LOAD AND COMPARE THIS ADDRESS
3145	6254	SINT		/CLEAN USER INTERRUPT
3146	7610	SKP	CLA	/SKIP ON USER INTERRUPT
3147	4454	ERROR		
3150	4455	LOOP		/CINT FAILED TO CLEAR USER INTERRUPT
3151	5775	JMP	TEST17	/LOOP ON TEST IF SR = 1000
3175	3200			
3176	5000			
3177	3321			
	3200	PAGE		

.....
 /TEST 17 = CHECKS THE RIF INSTRUCTION TO READ THE INSTRUCTION FIELD
 /REGISTER THE PROGRAM DEPOSITS THE FOLLOWING CODE INTO LOCATIONS 0000=
 /0004 OF EACH SELECTED EXTENDED FIELD: RIF=10N- JMP I 3=1; RET=1;
 /THE PROGRAM USES THE USER INTERRUPT TO RETURN TO THE PROGRAM,

3200	4456	TEST17, SCORLP		/SETUP TEST AND SCOPE LOOP ADDRESS
3201	6007	CAF		/CLEAN ALL FLAGS
3202	6001	IOV		/TURN THE INTERRUPT ON
3203	6274	SUP		/SET USER BUFFER F/F
3204	5205	JMP	,*1	/ENTER TIME SHARE MODE
3205	7402	HLT		/RAISE INTERRUPT REQUEST AND INTERRUPT
3206	5206	JMP		/HALT FAILED TO TRAP

```

3207 6254 SINT /SKIP ON USER INTERRUPT FLIP = FLOP
3210 4454 ERROR /USER INTERRUPT F/F NOT SET
3211 7340 CLA CLL CMA /SET THE AC TO ALL ONES
3212 6004 CTF /GET THE FLAGS
3213 1130 TAO H1100 /CHECK FOR USER FLAG AND INT REQ
3214 7640 SEA CLA
3215 4454 ERROR /USER FLAG OR USER INT NOT SET
3216 3041 DCA WRKFLO /CLEAN THE WORKING FIELD
3217 3043 DCA WRKADD /SET THE FIRST ADDRESS TO 0
3220 1041 TAO WRKFLO /GET THE FIELD
3221 1130 TAO K10 /ADD ONE FIELD TO IT
3222 3041 DCA WRKFLO /SAVE THIS AS THE NEW FIELD
3223 1041 TAO WRKFLO /GET THE FIELD
3224 7041 CIA /NEGATE IT
3225 1037 TAO FL0LIM /COMPARE IT TO THE FIELD LIMIT
3226 7710 SPA CLA /IS THE NEW FIELD GREATER THAN FIELD LIMIT
3227 5314 JMP ENDT17 /YES DO CHECK LOOP ON TEST
3230 1300 TAO TABLE /GET THE BEGINNING OF THE TABLE TO
3231 3313 DCA POINTR /LOAD UP THE FIRST 4 LOCATIONS IN THE
3232 1147 TAO K7774 /NEW FIELD, SET UP A COUNT OF FOUR
3233 3047 DCA ADDCNT /SAVE THE COUNT
3234 1041 TAO WRKFLO /GET THE NEW FIELD
3235 7112 CLL RTR /SETUP LOCATION HGH1IM TO EQUAL
3236 7010 RAR /THE EXPECTED SAVE FIELD AFTER A INT,
3237 1041 TAO WRKFLO /
3240 3044 DCA HGH1IM /SAVE THE NUMBER AS THE EXPECTED S;F,
3241 1041 TAO WRKFLO /GET THE NEW FIELD
3242 1045 TAO K0201 /GET THE CDF INSTRUCTION
3243 3240 DCA T17CDF /STORE IT
3244 0201 CDF /CHANGE DATA FIELD TO PROGRAM FIELD
3245 1713 TAO I POINTR /GET THE INSTRUCTION FROM PROGRAM FIELD
3246 7402 T17CDF, HLT/CDF /CHANGE DATA FIELD TO NEW FIELD
3247 3443 DCA I WRKADD /PUT THE INSTRUCTION INTO NEW FIELD
3250 1443 TAO I WRKADD /BRING IT BACK OUT
3251 0201 CDF /CHANGE THE DATA FIELD BACK TO PROG
3252 7041 CIA /NEGATE IT
3253 1713 TAO I POINTR /GET THE WORD THAT WAS PUT UP THERE
3254 7640 SEA CLA
3255 4454 ERROR /WORDS DO NOT COMPARE BETWEEN 2 FIELDS
3256 2313 ISR POINTR /ADD ONE TO THE POINTER ADDRESS
3257 2043 ISR WRKADD /ADD ONE TO THE ADDRESS
3260 2047 ISR ADDCNT /ADD ON TO THE LOCATION COUNTER
3261 5245 JMP T17CDF=1 /GO ON NEXT LOCATION
3262 3043 DCA WRKADD /RESET THE ADDRESS TO 2
3263 7326 CLA CLL CML RTL /ADD TWO TO THE CDF INSTR TO NEW FIELD
3264 1240 TAO T17CDF /GET THE CDF INSTRUCTION TO NEW FIELD
3265 3266 DCA ,+1 /PUT CDF TO NEW FIELD IN NEXT ADDRESS
3266 7402 HLT/CDF CIP /CHANGE DF AND IF TO NEW FIELD
3267 5443 JMP I WRKADD /GO UP TO THE NEW FIELD
3270 4454 ERROR /PROGRAM RETURNED TO THE WRONG LOC;
3271 0234 T17RET, R10 /READ THE SAVE FIELD REGISTER
3272 7041 CIA /NEGATE IT
3273 1044 TAO HGH1IM /GET THE EXPECTED SAVE FIELD REGISTER
3274 7640 SEA CLA /ARE THEY EQUAL
3275 4454 ERROR /NO,SAVE FIELD NOT EQUAL EXPECTED

```

```

3276 1035 TAO DATREC /GET THE I,F. THAT WAS READ IN NEW FIELD
3277 7041 CIA /NEGATE IT
3300 1041 TAO WRKFLO /GET THE EXPECTED FIELD
3301 7640 SEA CLA /ARE THEY EQUAL
3302 4454 ERROR /RIP FAILED OR WENT TO WRONG FIELD
3303 6254 SINT /SKIP ON USER INTERRUPT F/F
3304 4454 ERROR /USER INTERRUPT GOT CLEARED
3305 9217 JMP BEGT17 /GO ON NEXT FIELD IF SELECTED

3306 3307 TABLE, ,+1
3307 6224 RIP
3310 0001 IOV
3311 5403 JMP I 3
3312 3270 T17RET=1
3313 0000 POINTR, 0

3314 6204 ENDT17, CINT /CLEAN USER INTERRUPT F/F
3315 6294 SINT /SKIP ON USER INTERRUPT F/F
3316 7610 SKP CLA /CINT FAILED TO CLEAR USER INT F/F,
3317 4454 ERROR /LOOP ON TEST IF SR = 1000
3320 4455 LOOP

/*****
/TEST 10 = IS ONLY EXECUTED WHEN THE SIMULATOR IS SELECTED (BIT 4 OF LOCATION 21 SET TO A 1).
/TEST 10 CHECKS THAT THE EMA IS LOADED ONTO THE BUS DURING A DCA I FOLLOWING
/TA CDF 10) CDF 20) CDF 40, THE SIMULATOR IS USED TO CAUSE A INTERRUPT
/FOLLOWING A EMA CHANGE ON THE BUS, THE SIMULATOR STORES THE EMA INTO A
/EMA CATCHER REGISTER AND THEN THE PROGRAM READS AND COMPARES IT.
/*****

3321 4456 TEST10, SCOPLP /SETUP TEST AND SCOPE LOOPING ADDRESS
3322 0007 CAF /CLEAR ALL FLAGS
3323 1021 TAO OP1SEL /CHECK BIT 4 OF LOCATION 21 FOR SIMULATOR SELECT
3324 0143 AND K200 /
3325 7650 SNA CLA /WAS THE SIMULATOR SELECTED ?
3326 5461 JMP I PASEND /NO, END OF ONE PROGRAM PASS
3327 4331 JMS EMACLR /LOAD CONTROL WORD AND CLEAR EMA REGISTER
3330 5345 JMP TST10A /GO TO FIRST TEST
3331 0000 EMACLR, 0 /ROUTINE TO LOAD CONTROL WORD AND CLEAR EMA CATCHER REGISTER
3332 1144 TAO K400
3333 6153 LDMG3 /LOAD CONTROL REGISTER 3 FOR INT AND SKIP ENABLE
3334 6154 CLREMA /CLEAN EMA CATCHER REGISTER
3335 6166 SKPEMA /SKIP ON EMA CATCHER REGISTER SET
3336 7610 SKP CLA
3337 4454 ERROR /CLREMA FAILED TO CLEAR CATCHER F/F
3340 6155 REDEMA /READ THE EMA CATCHER REGISTER
3341 1066 TAO M7 /CLEANING THE REGISTER SET IT TO 7
3342 7640 SEA CLA /IS THE REGISTER SET TO 7 ?
3343 4454 ERROR /NO, CLREMA FAILED TO SET REGISTER TO 7
3344 5731 JMP I EMACLR
3345 6211 TST10A, CDF 10 /CHANGE DATA FIELD TO FIELD 10
3346 0001 IOV /TURN THE INTERRUPT ON
3347 3750 DCA I ,+1 /CHANGE THE EMA LINES TO 1 AND INTERRUPT

```

```

3350 7402      HLT                               /SIMULATOR FAILED TO INT, OR EMA DIDN'T CHANGE
3351 6166      SKPEMA                          /SKIP ON EMA REGISTER SET
3352 4454      ERROR                             /SIMULATOR EMA CATCHER REGISTER NOT SET
3353 6234      R13                              /READ THE INTERRUPT BUFFER
3355 1062      TAD           M1
3356 7640      SEA           CLA                               /IS THE SAVE FIELD EQUAL TO 1 ?
3357 4454      ERROR                             /NO,SAVE FIELD NOT EQUAL TO 1
3358 1062      REDEMA                          /READ THE SIMULATOR EMA CATCHER REGISTER
3361 7640      TAD           M1
3362 4454      SEA           CLA                               /IS THE EMA CATCHER REGISTER = 1 ?
3363 4331      ERROR                             /NO,EMA LINES OTHER THAN EMA2 MUST HAVE BEEN SET
3364 6221      JMS           EMACLR                    /LOAD CONTROL WORD AND CLEAR EMA CARCHER REGISTER
3365 6001      TST18B, CDF           20                      /CHANGE DATA FIELD TO FIELD 2
3366 3767      IOV                               /TURN THE INTERRUPT ON
3367 7402      DCA           I, -1                      /CHANGE THE EMA LINES TO 2 AND INTERRUPT
3370 6166      HLT                               /PROGRAM FAILED TO INTERRUPT OR EMA DID NOT CHANGE
3371 4454      SKPEMA                          /SKIP ON EMA REGISTER SET
3372 6155      ERROR                             /EMA CATCHER REGISTER NOT SET
3373 1063      REDEMA                          /READ THE EMA CATCHER REGISTER
3374 7640      TAD           M2
3375 4454      SEA           CLA                               /DID THE DF SET EMA1 ON TO THE BUS
3376 4331      ERROR                             /NO, EMA REGISTER NOT EQUAL TO 2
3377 6241      JMS           EMACLR                    /LOAD CONTROL WORD CLEAR EMA REGISTER
3378 6001      TST18C, CDF           40                      /CHANGE DATA FIELD TO FIELD 4
3379 6001      IOV                               /TURN THE INTERRUPT ON
3380 3602      DCA           I, *1                    /CHANGE EMA LINES TO 4 AND INTERRUPT
3381 7402      HLT                               /PROGRAM FAILED TO INTERRUPT OR EMA DID NOT CHANGE
3383 6166      SKPEMA                          /SKIP ON EMA CATCHER REGISTER SET
3384 4454      ERROR                             /EMA CATCHER F/F NOT SET
3385 6155      REDEMA                          /READ THE EMA CATCHER REGISTER
3386 1064      TAD           M4
3387 7640      SEA           CLA                               /DID THE DF SET EMA0 ONTO THE BUS
3388 4454      ERROR                             /NO,EMA CATCHER REGISTER NOT EQUAL TO 4
3389 4612      JMS           I, *1                    /LOAD CONTROL WORD AND CLEAR EMA CATCHER REGISTER
3391 3331      EMACLR
3393 6150      CLR$IM
3394 4455      LOOP

```

.....
/TEST 19 = IS A CONTINUATION OF TEST 18 ONLY TESTING THAT THE CIF
/INSTRUCTION LOADS THE APPROPRIATE EMA LINE, THE TEST WILL BE FOR CIF 101
/CIF 201 AND CIF 401, THE SIMULATOR IS USED FOR INTERRUPTS AND TO READ
/THE EMA LINES,
.....

```

3415 4456      TEST19, SCQPLP                          /SETUP TEST AND SCOPE LOOPING ADDRESS
3416 6007      CAF                               /CLEAR ALL FLAGS
3417 6160      CLRMOD                          /CLEAR SIMULATOR MODULE
3420 6211      CDF           10                      /CHANGE DATA FIELD TO FIELD 1
3421 3741      DCA           I, EMA1                    /CLEAR THE FIRST TEST LOCATION
3422 6221      CDF           20                      /CHANGE DATA FIELD TO FIELD 2
3423 3742      DCA           I, EMA2
3424 6241      CDF           40                      /CHANGE DATA FIELD TO FIELD 4
3425 3743      DCA           I, EMA3
3426 6201      CDF           00                      /CHANGE DATA FIELD BACK TO FIELD 0

```

```

3427 4740      JMS           I, CLRERG                    /LOAD CONTROL WORD AND CLEAR EMA CATCHER REGISTER
3430 6212      CIF           10                      /CHANGE INSTRUCTION FIELD TO 1
3431 6001      IOV                               /TURN THE INTERRUPT ON
3432 5232      EMAIF1, JMP           ,                      /CLEAR INT INHIBIT AND INTERRUPT
3433 7402      HLT                               /PROGRAM FAILED TO INTERRUPT
3434 6166      SKPEMA                          /SKIP ON EMA CATCHER F/F SET
3435 4454      ERROR                             /EMA CATCHER F/F NOT SET
3436 6234      R13                              /READ THE INTERRUPT BUFFER
3437 1067      TAD           M10
3440 7640      SEA           CLA                               /IS THE SAVE FIELD EQUAL TO IF OF 1
3441 4454      ERROR                             /SAVE FIELD NOT EQUAL TO IF OF 1
3442 6155      REDEMA                          /READ THE EMA CATCHER REGISTER
3443 1062      TAD           M1
3444 7640      SEA           CLA                               /IS THE EMA CATCHER REGISTER EQUAL TO 1
3445 4454      ERROR                             /NO,EMA CATCHER REGISTER NOT EQUAL TO 1
3446 4740      JMS           I, CLRERG                    /LOAD CONTROL WORD, CLEAR EMA CATCHER REGISTER
3447 6222      CIF           20                      /CHANGE INSTRUCTION FIELD TO FIELD 2
3450 6001      IOV                               /TURN THE INTERRUPT ON
3451 5251      EMAIF2, JMP           ,                      /CLEAR INT INHIBIT AND INTERRUPT
3452 7402      HLT                               /PROGRAM FAILED TO INTERRUPT OR EMA DID NOT CHANGE
3453 6166      SKPEMA                          /SKIP ON EMA CATCHER F/F SET
3454 4454      ERROR                             /EMA CATCHER REGISTER NOT SET
3455 6155      REDEMA                          /READ THE EMA CATCHER REGISTER
3456 1063      TAD           M2
3457 7640      SEA           CLA                               /IS THE EMA CATCHER REGISTER EQUAL TO 2
3460 4454      ERROR                             /NO, EMA WASN'T SET TO 2
3461 4740      JMS           I, CLRERG                    /LOAD CONTROL WORD, CLEAR EMA REGISTER
3462 6242      CIF           40                      /CHANGE INSTRUCTION FIELD TO FIELD 4
3463 6001      IOV                               /TURN THE INTERRUPT ON
3464 5264      EMAIF3, JMP           ,                      /CLEAR INTERRUPT INHIBIT AND INTERRUPT
3465 7402      HLT                               /PROGRAM FAILED TO INTERRUPT
3466 6166      SKPEMA                          /SKIP ON EMA CATCHER F/F SET
3467 4454      ERROR                             /EMA CATCHER REGISTER NOT SET
3470 6155      REDEMA                          /READ THE EMA CATCHER REGISTER
3471 1064      TAD           M4
3472 7640      SEA           CLA                               /IS THE EMA CATCHER REGISTER SET TO 4
3473 4454      ERROR                             /NO, EMA WASN'T SET TO 4
3474 4740      JMS           I, CLRERG                    /LOAD CONTROL WORD CLEAR CATCHER F/F'S
3475 6150      CLR$IM
3476 4455      LOOP

```

.....
/TEST 20 = IS EXECUTED WHEN THE SIMULATOR IS SELECTED, TEST 20 CHECKS
/THAT THE TIME SHARE LOGIC CAN BE DISABLED, THIS IS DONE WITH THE
/SIMULATOR BY PULLING KMTS TIME SHARE DISA, L LOW, THE PROGRAM THEN
/TRIES TO LOAD THE USER BUFFER AND THEN DOES A TOT, LAS, OSR AND CHECKS
/THAT THE PROGRAM DIDN'T INTERRUPT,
.....

```

3477 4456      TEST20, SCQPLP                          /SETUP TEST AND SCOPE LOOPING ADDRESS
3480 6007      CAF                               /CLEAR ALL FLAGS
3481 6160      CLRMOD                          /CLEAR SIMULATOR LOGIC
3482 7330      CLA CLL CML RAR                      /SET BIT 0 TO A ONE
3483 6153      LOOK63                             /LOAD CONTROL REGISTER 3 WITH TIME SHARE DISABLE

```

```

3904 7300      CLA      CLL
3905 6001      IOY
3906 6274      SUP
3907 5310      JMP      ,+1
3910 7404      OSR
3911 7410      SKP
3912 4454      ERROR
3913 7604      LAS
3914 7410      SKP
3915 4454      ERROR
3916 6001      IOY
3917 7610      SKP      CLA
3920 4454      ERROR
3921 6007      CAF
3922 7610      SKP      CLA
3923 4454      ERROR
3924 6150      CLRSM
3925 6001      IOY
3926 6274      SUP
3927 5330      JMP      ,+1
3930 7402      HLT
3931 5331      JMP
3932 6254      SINT
3933 4454      ERROR
3934 6007      CAF
3935 4455      LOOP
3936 5737      JMP I ,+1
3937 3627      TEST21

3940 3331      CLRREG, EMACLR

3941 3432      EMA1,  EMA1F1
3942 3451      EMA2,  EMA1F2
3943 3464      EMA3,  EMA1F3

```

/THE FOLLOWING LOCATIONS CONTAIN THE CONTENTS OF THE TAPE CASSETTE BOOTSTRAP

```

3944 4000      TABADU, 4000      /BOOTSTRAP WILL START LOADING INTO THIS ADDRESS
3945 7740      TABCMP=TABEND=1
3946 1237      TABCMP, 1237
3947 1206      1206
3950 6704      6704
3951 6706      6706
3952 6703      6703
3953 5204      5204
3954 7264      7264
3955 6702      6702
3956 7610      7610
3957 3211      3211
3960 3636      3636
3961 1205      1205
3962 6704      6704
3963 6706      6706
3964 6701      6701

```

```

3965 9216      9216
3966 7002      7002
3967 7430      7430
3970 1636      1636
3971 7022      7022
3972 3636      3636
3973 7420      7420
3974 2236      2236
3975 2235      2235
3976 9215      9215
3977 7346      7346
3980 7002      7002
3981 3235      3235
3982 9201      9201
3983 7737      7737
3984 3557      3557
3985 7730      TABEND, 7730
3986 0000      0000      /TERMINATOR

3987 4301      BOOTB,  PTPADD
3910 4343      TC8ADD
3911 4363      OS4ADD
3912 3544      TABADD
3913 3615      RK8ADD
3914 0000      0

```

/THE FOLLOWING LOCATIONS CONTAIN THE CONTENTS OF THE RK8E BOOTSTRAP

```

3915 0023      RK8ADU, 0023      /BOOTSTRAP WILL LOAD INTO THIS ADDRESS
3916 7771      RK8CMP=HK8END=1 /NUMBER OF LOCATIONS TO COMPARE
3917 2000      RK8CMP, 2000
3920 6745      6745
3921 0023      0023
3922 7650      7650
3923 5024      5024
3924 6743      6743
3925 5031      RK8END, 5031
3926 0000      0000      /TERMINATOR

```

.....
/THE FOLLOWING TEST CHECKS THE BOOTSTRAP TO LOAD AND TO COMPARE CORRECTLY
.....

```

3927 4456      TEST21, SCOPLP      /SETUP TEST COUNT AND SCOPE LOOPING ADDRESS
3930 1377      TA)      (JMS I ATRST /SETUP LOCATIONS 0 AND 200
3931 3000      DCA      INTSER

```

```

3632 1377      TAD      (JMS I ATRST
3633 3776      DCA      TEST1=1
3634 1375      TAD      (NOBOOT
3635 3052      DCA      ATRST
3636 3241      JMP      ,43
3637 0000      NOBOOT, 0
3638 4454      ERROR
3639 6160      CLRMOD
3640 4774      JMS      SETUP
3641 1373      NXTBOT, TAD      (BOTSEL
3642 1347      TAD      (SIMBOT
3643 3351      DCA      CONTW2
3644 1372      TAD      (BOTENA
3645 3352      DCA      CONTW3
3646 7346      CLA CLL CMA RTL
3647 3354      DCA      BTSUBT
3648 6160      BTST1, CLRMOD
3649 4774      JMS      CLEARB
3650 1022      TAD      DP2SEL
3651 7710      SPA      CLA
3652 6305      6300
3653 7300      TAD I CONTW2
3654 1355      LOOP2
3655 7300      CLA CLL
3656 1355      TAD      ROOTR1
3657 3753      DCA I ADD401
3658 1752      TAD I CONTW3
3659 6153      LOOP3
3660 7300      CLA CLL
3661 6164      EXECUT
3662 5270      JMP      ,
3671 6160      BOTHT1, CLRMOD
3672 7301      CLA CLL IAC
3673 1022      TAD      DP2SEL
3674 7510      SPA      CLA
3675 6305      6300
3676 7300      TAD I CONTW2
3677 1347      LOOP2
3678 4770      CLA CLL
3679 2352      TAD      BOTCMP#2
3680 2354      ISE      CONTW3
3681 5252      ISE      BTSUBT
3682 4767      JMP      BTYST1
3683 1065      JMS      GOODBD
3684 3354      TAD      M9
3685 6160      DCA      BTSUBT
3686 4774      BTST2, CLRMOD
3687 1022      JMS      CLEARB
3688 7710      TAD      DP2SEL
3689 6305      SPA      CLA
3690 1751      6300
3691 6152      TAD I CONTW2
3692 1352      LOOP2

```

```

3716 7300      CLA CLL
3717 1356      TAD      ROOTR2
3718 3753      DCA I ADD401
3719 1752      TAD I CONTW3
3720 6153      LOOP3
3721 7300      CLA CLL
3722 6164      EXECUT
3723 7602      WLT      CLA
3726 6160      BOTHT2, CLRMOD
3727 7301      CLA CLL IAC
3728 1022      TAD      DP2SEL
3729 7510      SPA      CLA
3730 6305      6300
3731 7300      TAD I CONTW3
3732 1347      LOOP2
3733 4770      CLA CLL
3734 2352      TAD      BOTCMP#2
3735 2354      ISE      CONTW3
3736 5252      ISE      BTSUBT
3737 4767      JMP      RTFST2
3738 1065      JMS      GOODBD
3739 3354      TAD      M9
3740 6160      DCA      BTSUBT
3741 4774      BTYST2, CLRMOD
3742 1022      JMS      CLEARB
3743 7710      TAD      DP2SEL
3744 6305      SPA      CLA
3745 1751      6300
3746 6152      TAD I CONTW2
3747 1352      LOOP2
3748 1352      JMP      TEST22
3749 0000      SIMBOT, 0
3750 0000      CNTBOT, 0
3751 0000      CONTW2, 0
3752 0000      CONTW3, 0
3753 0401      ADD401, 2421
3754 0000      RTSUBT, 0

```

```

/BOOTSTRAP RETURN ADDRESSES
3755 3671      BOOTHT1, BOTHT1
3756 3726      BOOTHT2, BOTHT2
3766 4041
3767 5101
3770 4402
3771 4463
3772 4159
3773 4150
3774 4517
3775 3637
3776 0200
3777 4452
4000

```

/THE GAP88 CASSETTE BOOT STRAP WILL LOAD INTO THE FOLLOWING LOCATIONS,

4000	7402	CAP88:	HLT	/1237
4001	7402		HLT	/1206
4002	7402		HLT	/6704
4003	7402		HLT	/6706
4004	7402		HLT	/6703
4005	7402		HLT	/9204
4006	7402		HLT	/7204
4007	7402		HLT	/6702
4010	7402		HLT	/7410
4011	7402		HLT	/3211
4012	7402		HLT	/3636
4013	7402		HLT	/1205
4014	7402		HLT	/6704
4015	7402		HLT	/6706
4016	7402		HLT	/6701
4017	7402		HLT	/9216
4020	7402		HLT	/7002
4021	7402		HLT	/7430
4022	7402		HLT	/1636
4023	7402		HLT	/7022
4024	7402		HLT	/3636
4025	7402		HLT	/7420
4026	7402		HLT	/2236
4027	7402		HLT	/2235
4030	7402		HLT	/9215
4031	7402		HLT	/7346
4032	7402		HLT	/7002
4033	7402		HLT	/3235
4034	7402		HLT	/9201
4035	7402		HLT	/7737
4036	7402		HLT	/3597
4037	7402		HLT	/7730
4040	7402		HLT	/TERMINATOR

.....
 /TEST 22 CHECKS THAT THE AUTO RESTART OCCURS AT THE APPROPRIATE ADDRESS, THIS
 /TEST USES THE SIMULATOR TO SELECT AND CAUSE A AUTO RESTART,

4041	4456	TEST22:	SCDPLP	/SETUP TEST AND SCOPE LOOP ADDRESS
4042	1377		TAD	(JMS I ATRST /SETUP LOCATIONS 0 AND 200
4043	3000		DCA	INTSER /
4044	1377		TAD	(JMS I ATRST /
4045	3776		DCA	TEST1=1 /
4046	1375		TAD	(RSTAUT /GET THE AUTO RESTART ADDRESS
4047	3052		DCA	ATRST /SAVE IT
4050	1374		TAD	(NOAUTO /GET BOOT STRAP ADDRESS
4051	3653		DCA	I ,+2
4052	5255		JMP	,+3

4053	0401		0401	
4054	4454	NOAUTO:	ERR0M	/LOGIC DID A BOOT INSTEAD OF A AUTO RESTART
4055	4773		JMS	SETUP /GO SETUP FOR TEST
4056	6160	AUTST:	CLRMOO	/CLEAR SIMULATOR MODULE
4057	1372		TAD	(RESADD /GET THE ADDRESS OF AUTO RESTART TABLE
4060	1334		TAD	AUTSEL /GET THE PROGRAM AUTO = RESTART TO BE EXECUTED
4061	3335		DCA	ADDRESS /SAVE THE TABLE ADDRESS
4062	1371		TAD	(SELAUT /GET THE CONTROL WORD 2 TABLE ADDRESS
4063	1334		TAD	AUTSEL /ADD IN THE RESTART TO BE EXECUTED
4064	3336		DCA	CONW2 /SAVE THIS ADDRESS TO GET THE CONTROL WORD
4065	1022		TAD	OP2SEL /CHECK TO SEE IF PROGRAM IS ON ACT LINE
4066	7710		SPA	CLA
4067	6305		6305	CLA
4070	1736		TAD	I CONW2 /DISABLE ACT LINE UNTIL AUTO RESTART IS DONE
4071	6152		LOADR2	CLA /GET THE CONTROL WORD
4072	7300		CLA	CLA /LOAD CONTROL REGISTER 2
4073	1347		TAD	AUTENA /GET THE ENABLE CONTROL WORD
4074	6153		LOADR3	CLA /LOAD CONTROL REGISTER 3
4075	7300		CLA	CLA
4076	6164		EXECUT	CLA /EXECUTE A AUTO RESTART
4077	7602		HLT	CLA /SHOULD DO A AUTO RESTART HERE=PRESS CONT FOR RETRY
4100	5256		JMP	AUTST /RETRY
4101	0000	RSTAUT:	0	CLA /A AUTO RESTART SHOULD COME HERE
4102	6160		CLRMOO	CLA /CLEAR SIMULATOR LOGIC
4103	7301		CLA	CLA IAC /SET BIT 11 TO A ONE
4104	1022		TAD	OP2SEL /CHECK FOR THE ACT LINE
4105	7510		SPA	CLA /IS IT RUNNING ON ACT LINE
4106	6305		6305	CLA /YES, ENABLE ACT LINE
4107	7340		CLA	CLA CMA /SET THE AC TO MINUS 1
4110	1304		TAD	RSTAUT /GET THE PC FROM THE AUTO RESTART
4111	7044		CIA	CLA /NEGATE IT
4112	1735		TAD	I ADDRESS /GET THE EXPECTED AUTO RESTART PC
4113	7650		SNA	CLA /ARE THEY EQUAL?
4114	5255		JMP	GODAUT /YES GO DO NEXT ADDRESS
4115	4454		ERR0M	CLA /EXPECTED AUTO RESTART ADDRESS NOT EQUAL TO
				RETURN ADDRESS, PRESS CONT TO GET EXP AND ACT ADDRESS
4116	1735		TAD	I ADDRESS /
4117	7402		HLT	CLA /AC EQUALS EXPECTED AUTO RESTART ADDRESS
4120	7340		CLA	CLA CMA /
4121	1304		TAD	RSTAUT /
4122	7402		HLT	CLA /AC EQUALS ACTUAL AUTO RESTART ADDRESS
4123	7200		CLA	CLA /
4124	5256		JMP	AUTST /DO SAME RESTART OVER AGAIN
4125	2334	GODAUT:	IS#	AUTSEL /ADD 1 TO PROGRAM SELECT RESTART
4126	2333		IS#	AUTCNT /DONE ALL FOUR AUTO RESTARTS?
4127	5256		JMP	AUTST /NO, GO DO NEXT ONE
4130	4770		JMS	GOODBO /SIGNAL ACT LINE OF A GOOD PASS IF ON IT
4131	4455		LOOP	CLA /LOOP ON TEST IF SR = 1000
4132	9767		JMP	TEST23
4133	0000	AUTCNT:	0	
4134	0000	AUTSEL:	0	
4135	0000	ADDRESS:	0	
4136	0000	CONW2:	0	

```

4137 4200 RESADU, 4200
4140 2000          2000
4141 0200          0200
4142 0000          0000

4143 1676 SELAUT, 1676          /AUTO RESTART AT 4200
4144 1674          1674          /AUTO RESTART AT 2000
4145 1672          1672          /AUTO RESTART AT 200
4146 1670          1670          /AUTO RESTART AT 0000

4147 0037 AUTENA, 0037          /POWER ON TRIGGERED AUTO RESTART

/CONTROL WORD 2 BOOTSTRAP SELECT

4150 1672 BOTSEL, 1672          /HI=LOW PAPER TAPE SELECT
4151 1132          1132          /TC00 BOOTSTRAP SELECT
4152 0742          0742          /RP00/DP320 BOOTSTRAP SELECT

4153 0642          0642          /TAPE CASSETTE BOOTSTRAP SELECT
4154 1252          1252          /RK0=C BOOTSTRAP SELECT

/CONTROL WORD 3 BOOTSTRAP ENABLES (POWER ON OR SWITCH SW)

4155 0001 BOTENA, 0001          /SW=SW ENABLE BOOT WHEN RUNNING
4156 0003          0003          /SW=SW ENABLE BOOT WHEN RUNNING
4157 0007          0007          /SW=SW ENABLE BOOT WHEN RUNNING
4160 0011          0011          /SW=SW DISABLE BOOT WHEN RUNNING
4161 0032          0032          /POWER ON DISABLE BOOT WHEN RUNNING
4162 0013          0013          /SW=SW DISABLE BOOT WHEN RUNNING
4163 0033          0033          /POWER ON DISABLE BOOT WHEN RUNNING
4164 0017          0017          /SW=SW DISABLE BOOT WHEN RUNNING

4167 4201
4170 5101
4171 4143
4172 4137
4173 4517
4174 4094
4175 4101
4176 0200
4177 4492
4200          PAGE

```

```

/.....
/TEST 23= USES THE SIMULATOR TO CHECK THAT AC LOW AND BATTERY EMPTY F/F'S
/CAN SKIP AND INTERRUPT AND THAT THEY CAN BE CLEARED.
/.....
4200 4492 JMS I ATRST          /AUTO RESTART HANDLER
4201 4496 TEST23, SC0PLP          /SETUP TEST AND SCOPE LOOP ADDRESS
4202 1377 TAD          (ACLBAT
4203 3092 DCA          ATRST
4204 6007 CAF          /CLEAN ALL FLAGS

```

```

4205 6160 CLRMOD          /CLEAN SIMULATOR MODULE
4206 3776 DCA          ACNLOK
4207 6101 SBE          /SKIP ON BATTERY EMPTY
4210 7410 SK#          /BATTERY EMPTY IS SET
4211 4494 ERRORM          /SKIP ON AC LOW
4212 6102 SPL          /AC LOW F/F IS SET
4213 7410 SK#          /SET BITS 2 + 3 TO A 1
4214 4494 ERRORM          /LOAD REGISTER 3 TO PULL AC LOW AND BATTERY EMPTY LOW
4215 1253 TAD          K3000
4216 6153 LODRG3
4217 7300 CLA          CLL
4220 6001 IOV          /TURN THE INTERRUPT ON
4221 5222 JMP          ,+1
4222 4494 ERRORM          /AC LOW NOT SET OR FAILED TO INTERRUPT
4223 7610 SK#          CLA
4224 4494 ERRORM          /AC LOW NOT SET BUT BATTERY EMPTY IS
4225 6102 SPL          /SKIP ON AC LOW AS A LEVEL
4226 4494 ERRORM          /AC LOW AS A LEVEL DID NOT SKIP
4227 5101 SBE          /SKIP ON BATTERY EMPTY
4230 4494 ERRORM          /BATTERY EMPTY NOT SET WITH BATTERY EMPTY WELD LOW
4231 1254 TAD          K1000
4232 6153 LODRG3          /SET CONTROL BIT 3 HIGH
4233 7340 CLA          CLL CMA
4234 3776 DCA          ACNLOK
4235 6001 IOV          /TURN THE INTERRUPT ON
4236 5237 JMP          ,+1
4237 4494 ERRORM          /BATTERY EMPTY NOT SET OR FAILED TO INT
4240 4494 ERRORM          /AC LOW SET BUT BATTERY EMPTY ISN'T
4241 6153 LODRG3          /OK, BATTERY EMPTY SET, LET AC LOW GO HIGH
4242 6101 SBE          /SKIP ON BATTERY EMPTY
4243 7410 SK#
4244 4494 ERRORM          /AC LOW FAILED TO CLEAR BATTERY EMPTY
4245 6102 SPL          /SKIP ON AC LOW
4246 7410 SK#
4247 4494 ERRORM          /AC LOW AS A LEVEL STILL SKIPPED
4250 6160 CLRMOD          /CLEAN SIMULATOR TEST MODULE
4251 4495 LOOP          /LOOP ON TEST IF SR = 1000
4252 5461 JMP I          PASEND          /END OF PROGRAM

4253 3000 K3000, 3000
4254 1000 K1000, 1000

```

```

/.....
/TINDIS = IS AN OPERATOR INTERVENTION TEST; THE OPERATOR MUST SET THE
/TIME SHARE ENABLE SWITCH TO THE TIME SHARE DISABLE POSITION; THE PROGRAM
/TRIES TO SET THE USER FLAG AND CHECKS THAT LAB, OSK, IOT, AND HALT
/DO NOT TRAP AND THAT HLT HALTS.
/.....

```

```

4255 4496 TIMDIS, SC0PLP          /SETUP TEST AND SCOPE LOOPING ADDRESS
4256 6007 CAF          /CLEAN ALL FLAGS
4257 6264 CUF          /CLEAN USER BUFFER F/F
4260 6204 CINT          /CLEAN USER INTERRUPT F/F

```

```

4261 6001 IOV /TURN THE INTERRUPT ON
4262 6274 SUP /TRY TO SET THE USEK BUFFER P/P
4263 5264 JMP /TRY TO ENTER TIME SHARE MODE
4264 7404 OSR /SHOULD TRAP HERE IF TIME SHARE NOT DISABLED
4265 7610 SK* CLA /TIME SHARE NOT DISABLED=PROGRAM INTERRUPTED
4266 4454 ERROR /SHOULD TRAP HERE IF TIME SHARE NOT DISABLED
4267 7604 LAS /TIME SHARE NOT DISABLED=PROGRAM INTERRUPTED
4270 7610 SK* CLA /SHOULD TRAP HERE IF TIME SHARE NOT DISABLED
4271 4454 ERROR /LAS TRAPPED WITHOUT TIME SHARE ENABLED
4272 8254 SINT /SKIP ON USER INTERRUPT
4273 7610 SK* CLA /LAS TRAPPED OR USEK INTERRUPT SET
4274 4454 ERROR /PROGRAM SHOULD HALT HERE FOR COMPLETION
4275 7402 HLT /OF TIME SHARE DISABLE TEST

4276 7610 SK* CLA /HLT TRAPPED
4277 4454 ERROR /RETRY THE TEST
4300 5255 JMP TINDIS
    
```

/THE FOLLOWING LOCATIONS CONTAINS THE CONTENTS OF THE HI=LOW PAPER TAPE /BOOTSTRAP

```

4301 7737 PTPADU, 7737 /BOOTSTRAP WILL START LOADING INTO THIS ADDRESS
4302 7741 PTPCMP=PTPEND=1 /NUMBER OF LOCATIONS TO COMPARE
4303 6014 PTPCMP, 6014
4304 0776 0776
4305 7326 7326
4306 1337 1337
4307 2376 2376
4310 5340 5340
4311 6011 6011
4312 5350 5350
4313 3361 3361
4314 1361 1361
4315 3371 3371
4316 1345 1345
4317 3357 3357
4320 1345 1345
4321 3367 3367
4322 6032 6032
4323 6031 6031
4324 5357 5357
4325 6036 6036
4326 7106 7106
4327 7006 7006
4330 7510 7510
4331 5374 5374
4332 7006 7006
4333 6031 6031
4334 5367 5367
4335 6034 6034
4336 7420 7420
4337 3776 3776
4340 3376 3376
    
```

```

4341 5356 PTPEND, 5356
4342 0000 0000 /TERMINATOR
    
```

/THE FOLLOWING LOCATIONS CONTAIN THE CONTENTS OF THE TC08 BOOTSTRAP

```

4343 7613 TQBADU, 7613 /BOOTSTRAP WILL START LOADING INTO THIS ADDRESS
4344 7767 TQB CMP=TQBEND=1 /NUMBER OF LOCATIONS TO COMPARE
4345 6774 TQB CMP, 6774
4346 1222 1222
4347 6766 6766
4350 6771 6771
4351 5216 5216
4352 1223 1223
4353 5215 5215
4354 0600 0600
4355 0220 TQBEND, 0220
4356 7754 7754 /BOOTSTRAP WILL ALSO LOAD INTO 7754 + 7755
4357 7776 =2 /NUMBER OF LOCATIONS TO COMPARE
4360 7577 7577
4361 7577 7577
4362 0000 0 /TERMINATOR
    
```

/THE FOLLOWING LOCATIONS CONTAINS THE CONTENTS OF THE RF08/DF320 BOOTSTRAP

```

4363 7750 DSKADU, 7750 /BOOTSTRAP WILL START LOADING INTO THIS ADDRESS
4364 7773 RFDPCP=RFDPEP=1 /NUMBER OF LOCATIONS TO COMPARE
4365 7600 RFDPCP, 7600
4366 6603 6603
4367 6622 6622
4370 5392 5392
4371 5752 RFDPEU, 5752
4372 0000 0 /TERMINATOR

4376 5173
4377 5140
4400 PAGE
    
```

```

/*****
/TO RUN THE OPERATOR INTERVENTION BOOT STRAP COMPARE TEST, DO THE FOLLOWING:
/1, RUN CLRBOOT TO CLEAR THE BOOTSTRAP LOCATIONS IN MEMORY
/2, DISABLE ALL OPTIONS ASSOCIATED WITH THE BOOTSTRAP
/3, SET THE APPROPRIATE SELECT AND ENABLE SWITCHES FOR THE BOOTSTRAP
/4, SET THE HALT KEY
/5, TOGGLE THE BOOT KEY OR SWITCH
/6, START THE BOOT COMPARE TEST (BOTCMP)
/7, THE PROGRAM WILL HALT
/8, SET THE APPROPRIATE SWITCH REGISTER OR PSEUDO SWITCH REGISTER
/ TO THE BOOTSTRAP TO COMPARE AND PRESS CONTINUE,
/ SR0000=HI=LOW PAPER TAPE READER BOOTSTRAP
/ SR0001=TC08 BOOTSTRAP
/ SR0002=RF08/DF320 BOOTSTRAP
    
```

```

/ SR0003=TAPE CASSETTE BOOTSTRAP
/ SR0004=RKBE BOOTSTRAP
/9: THE PROGRAM SHOULD HALT AT ADDRESS BOOTOK IF NO ERRORS
/.....
4400 7402 BOTCMP, HLT
4401 5204 JMP ,+3 /SET THE SR FOR THE APPROPRIATE BOOTSTRAP COMPARE
4402 0000 0 /SIMULATOR BOOTSTRAP CHECK ENTERS HERE
4403 5213 JMP ,+10
4404 1021 TAO DP1SEL /GET THE HARDWARE OPTIONS
4405 7700 SMA CLA /IS THE HARDWARE SR BIT SET
4406 5211 JMP ,+3 /NO, USE THE PSEUDO SWITCH REGISTER
4407 7604 LAR /USE THE HARDWARE SWITCH REGISTER
4410 7410 SK0
4411 1020 TAO SWITCH /GET THE PSEUDO SWITCH REGISTER
4412 0134 AND K7 /MASK OFF BITS 9-11
4413 1377 TAO (BOOTTB /ADD IT TO THE BOOTSTRAP TABLE ADDRESS
4414 3366 DCA SAVSTR /SAVE IT
4415 1766 TAO I SAVSTR /GET THE ADDRESS FROM THE TABLE
4416 3367 DCA BOTADD /SAVE IT
4417 1767 TAO I BOTADD /GET THE BOOTSTRAP STARTING ADDRESS
4420 3370 DCA BOTSAD /THIS IS THE BOOTSTRAP STARTING ADDRESS
4421 2367 ISE BOTADD
4422 1767 TAO I BOTADD /GET THE WORD COUNT
4423 3371 DCA BOTCNT /SAVE IT
4424 2367 ISE BOTADD /BOTAUD IS THE STARTING ADDRESS OF BOOT COMPARE
4425 1770 COMPAN, TAO I BOTSAD /GET THE CONTENTS THAT BOOTSTRAP LOADED
4426 7041 CIA /NEGATE IT
4427 1767 TAO I BOTADD /GET THE EXPECTED BOOTSTRAP CONTENTS
4430 7650 SNA CLA /ARE THEY EQUAL
4431 5243 JMP GOODCP /YES, GO GET NEXT WORD
4432 4454 ERROR /BOOTSTRAP COMPARE ERROR, PRESS "CONT" TO
/GET BAD PG, GOOD CONTENTS, AND BAD CONTENTS
/GET BOOTSTRAP ADDRESS THAT WAS BAD
/AC=THE ADDRESS THAT DIDN'T COMPARE
4433 1370 TAO BOTSAD
4434 7402 HLT
4435 7200 CLA
4436 1767 TAO I BOTADD
4437 7402 HLT /AC=EXPECTED CONTENTS OF BOOTSTRAP
4440 7200 CLA
4441 1770 TAO I BOTSAD
4442 7402 HLT /AC=ACTUAL CONTENTS OF BOOTSTRAP
4443 7300 GOODCP, CLA CLL
4444 2370 ISE BOTSAD
4445 7000 NOP
4446 2367 ISE BOTADD
4447 7000 NOP
4450 2371 ISE BOTCNT /END OF COMPARE
4451 5225 JMP COMPAR /NO, GO GET NEXT WORD
4452 1767 TAO I BOTADD /CONTINUE FOR TC08
4453 7440 SEA
4454 5220 JMP COMPAR=5
4455 1021 TAO DP1SEL /GET HARDWARE OPTIONS
4456 0143 AND K200
4457 7640 SEA CLA /HAS THE SIMULATOR BEING USED
4460 5602 JMP I BOTCMP+2 /YES, RETURN TO SIMULATOR BOOTSTRAP CHECK

```

```

4461 7402 BOOTOK, HLT
4462 5200 JMP BOTCMP /BOOT STRAP COMPARED OK
/DO AGAIN
/.....
/ THE FOLLOWING SECTIONS WILL CLEAR THE LOCATIONS THAT THE BOOT STRAP WILL LOAD INTO,
/ THIS SHOULD BE DONE BEFORE EACH BOOTSTRAP IS ATTEMPTED,
/.....
4463 0000 CLEARB, 0 /SIMULATOR ENTERS HERE
4464 7610 SK0 CLA
4465 4317 CLRBOT, JMS SETUP /GET MEMORY SIZE TO SEE WHAT BOOTS TO CLEAR
4466 1365 TAO BOTCLR /GET THE NUMBER TO START CLEARING BOOT
4467 1377 TAO (BOOTTB /GET THE ADDRESS OF BOOT STRAP TABLE
4470 3366 DCA SAVSTR /SAVE IT
4471 1766 TAO I SAVSTR /GET THE ADDRESS FROM TABLE
4472 7490 SNA
4473 5311 JMP BOTEND /END OF CLEARING BOOTSTRAP LOCATIONS
4474 3367 DCA BOTADD /SAVE IT
4475 1767 TAO I BOTADD /GET THE BOOTSTRAP STARTING ADDRESS
4476 3370 DCA BOTSAD /SAVE IT
4477 2367 ISE BOTADD
4480 1767 TAO I BOTADD /GET THE WORD COUNT
4481 3371 DCA BOTCNT /SAVE IT
4482 3770 DCA I BOTSAD
4483 2370 ISE BOTSAD
4484 7000 NOP
4485 2371 ISE BOTCNT
4486 5302 JMP ,+4
4487 2366 ISE SAVSTR
4490 5271 JMS CLRBOT=4
4491 1021 BOTEND, TAO DP1SEL
4492 0143 AND K200
4493 7640 SEA CLA
4494 5663 JMP I CLEARB /RETURN TO SIMULATOR BOOTSTRAP TEST
4495 7402 HLT /END OF CLEARING BOOTSTRAPS
4496 5265 JMP CLRBOT /DO IT AGAIN

4517 0000 SETUP, 0
4520 3776 DCA AUTSEL
4521 3775 DCA SIMBOT
4522 1021 TAO DP1SEL /GET THE HARDWARE CONFIGURATION
4523 7104 CLL RAL /MOVE FIELD BITS INTO BITS 6=8
4524 0137 AND K70 /MASK OUT FIELD BITS
4525 7650 SNA CLA /IS MEMORY SIZE GREATER THAN 4K
4526 5341 JMP SETUP2 /NO, GO GET THE MEMORY SIZE
4527 3775 DCA SIMBOT /YES THAN DO ALL BOOT'S
4530 1775 TAO SIMBOT /GET BOOTSTRAP SELECT
4531 1065 TAO M5 /SUBTRACT 5
4532 3774 DCA CNTBOT /SAVE IT
4533 1775 TAO SIMBOT /GET BOOT NUMBER
4534 3365 DCA BOTCLR /SAVE IT
4535 1776 TAO AUTSEL /GET AUTO RESTART SELECT

```

```

4936 1064      TAO      M4
4937 3773      DCA      AUTCNT      /SAVE THE NUMBER OF AUTO'S TO DO
4940 5717      JMP      I      SETUP      /RETURN TO DO ROOT OR AUTO=RESTART
4941 1021      SETUP2, TAO      OP1SEL      /GET THE HARDWARE CONFIGURATION
4942 0372      AND      KK3      /MASK OFF FIELD 2 MEMORY SIZE
4943 7450      SNA      /IS IT 1K OF MEMORY
4944 9354      JMP      SET1K      /YES, SETUP TO DO 1 BOOT OR 2 AUTO=RESTART
4945 1062      TAO      M1      /SUBTRACT 1
4946 7450      SNA      /IS IT 2K OF MEMORY
4947 9360      JMP      SET2K      /YES, DO ONE BOOT AND 3 AUTO'S
4950 1062      TAO      M1      /SUBTRACT 1
4951 7650      SNA      CLA      /IS IT 3K OF MEMORY
4952 9363      JMP      SET3K      /YES, SETUP TO DO 2 BOOTS AND 4 AUTO'S
4953 9327      JMP      SETUP1      /MUST BE 4K OF MEMORY=NO ALL
4954 7305      SET1K,  CLA  CLL  IAC  RAL
4955 3776      DCA      AUTSEL
4956 7307      CLA  CLL  IAC  RTL
4957 9327      JMP      SETUP1
4960 7301      SET2K,  CLA  CLL  IAC
4961 3776      DCA      AUTSEL
4962 9356      JMP      ,=4
4963 7325      SET3K,  CLA  CLL  CML  IAC  RAL
4964 9327      JMP      SETUP1

4965 0000      BOTQLH, 0
4966 0000      SAVSTN, 0
4967 0000      BOTADU, 0
4970 0000      BOTSAU, 0
4971 0000      BOTUNT, 0
4972 0003      KK3, 3

4973 4133
4974 3750
4975 3747
4976 4134
4977 3607
4980 4600

```

PAGE

```

/*****
/AUTO = IS AN OPERATOR INTERVENTION TEST TO CHECK POWER=FAIL/AUTO=RESTART,
/WHEN THE PROGRAM IS STARTED, IT FILLS LOCATIONS 5200 TO 7777 (4K) OR 5200 TO 5777 (3K) WITH A
/COMPLEMENTING DATA PATTERN (5252 = 2929), AND THEN HALTS, THE OPERATOR
/AT THIS TIME MUST SET THE APPROPRIATE AUTO RESTART SWITCHES ON THE
/MODULE, HE THEN MUST SIGNIFY TO THE PROGRAM VIA FRONT PANEL SWITCH
/REGISTER OR THE PSEUDO SWITCH REGISTER, WHICHEVER IS SELECTED, THE
/AUTO RESTART TO BE TESTED (0000=RESTART AT 4200; 0001=RESTART AT 2000;
/0002=RESTART AT 0200; 0003=RESTART AT 0000), THE OPERATOR THEN PRESSES
/"CONTINUE", THE PROGRAM THEN STARTS COMPARING DATA, WAITING FOR THE

```

```

/OPERATOR TO PULL THE LINE CORD, WHEN THE AC LINE CORD IS PULLED, THE
/PROGRAM SHOULD HALT AT LOCATION ACDOWN, THE OPERATOR SHOULD THEN PLUG
/THE LINE CORD BACK IN, AT THIS TIME THE PROGRAM SHOULD DO A AUTO RESTART
/TO THE ADDRESS SELECTED, THE PROGRAM THEN CHECKS FOR THE CORRECT
/AUTO RESTART AND THEN GOES BACK TO COMPARING DATA, THE ABOVE SEQUENCE
/OF UNPLUGGING AND PLUGGING LINE CORD SHOULD BE DONE SEVERAL TIMES FOR EACH
/AUTO RESTART.
///WARNING=THE BATTERY SUPPLY SHOULD BE FULLY CHARGED////////
/*****

```

```

4000 4456      AUTO,  SCOPLP      /SETUP TEST AND SCOPE LOOP ADDRESS
4001 6007      CAF      /CLEAN ALL FLAGS
4002 1021      TAO      OP1SEL      /GET THE HARDWARE CONFIGURATION
4003 0143      AND      K200
4004 7640      SZA      CLA
4005 6160      CLRMOD      /SIMULATOR SELECTED CLEAR TEST MODULE
4006 1377      TAO      (OPRINT      /GET THE ADDRESS FOR THE INTERRUPT ROUTINE
4007 3052      DCA      AURST      /SAVE IT
4010 1376      TAO      (BUFFER      /GET THE ADDRESS OF TEST BUFFER
4011 3313      DCA      FILLIT      /SAVE IT
4012 1021      TAO      OP1SEL      /GET HARDWARE CONFIGURATION
4013 0352      AND      K34      /CHECK TO SEE IF MORE THAN 4K
4014 7640      SZA      CLA      /IS IT GREATER THEN 4K?
4015 5222      JMP      ,=5      /YES, THAN FIELD 0 EQUALS 4K
4016 1021      TAO      OP1SEL      /NO, THAN IT MUST BE 3K OR 4K
4017 0353      AND      K1      /CHECK FOR 3K OR 4K
4020 7650      SNA      CLA      /IS IT 3K OR 4K?
4021 7332      CLA  CLL  CML  RTR      /ONLY 3K ADD 2000 TO COUNTER
4022 1376      TAO      (BUFFER
4023 3314      DCA      BUPCNT
4024 1314      TAO      BUPCNT      /GET THE NUMBER OF WORDS TO FILL THE BUFFER
4025 3315      DCA      CNTBUP      /SAVE IT
4026 1317      TAO      K9252      /THE FIRST WORD IN THE BUFFER WILL BE 5252
4027 3316      DCA      BUPPAT      /SAVE THE WORD
4030 1316      TAO      BUPPAT      /GET THE WORD
4031 3713      DCA  I  FILLIT      /PUT IT IN THE BUFFER
4032 1316      TAO      BUPPAT      /GET THE WORD
4033 7040      CMA      /COMPLEMENT IT
4034 3316      DCA      BUPPAT
4035 2313      ISB      FILLIT      /INCREMENT BUFFER ADDRESS
4036 2315      ISB      CNTBUP      /DONE?
4037 5230      JMP      ,=7      /NO KEEP FILLING THE BUFFER
4040 7402      HLT      /SET THE SWITCH REGISTER OR PSEUDO S,R
/TO THE AUTO=RESTART TO BE EXECUTED
4041 1021      TAO      OP1SEL      /GET THE HARDWARE CONFIGURATION
4042 7500      SNA      /IS THE HARDWARE S,R, BEING USED
4043 5246      JMP      ,=3      /NO USE THE PSEUDO SWITCH REGISTER
4044 7604      LAR
4045 7410      SKP
4046 1020      TAO      SWITCH
4047 0320      AND      K3
4050 1375      TAO      (RESADD      /MASK OFF BITS 10 AND 11
4051 3321      DCA      HANRST      /ADD THE AUTO RESTART TABLE ADDRESS TO IT
4052 1721      TAO  I  HANRST      /SAVE IT
4053 3321      DCA      HANRST      /GET THE AUTO RESTART TO BE EXECUTED
/SAVE IT FOR COMPARISON AFTER RESTART

```

```

4854 1378 STRCMP, TAD (BUFFER /GET THE BUFFER ADDRESS
4855 3313 DCA FILLIT /SAVE IT
4856 1314 TAD BUFCNT /GET THE BUFFER SIZE
4857 3315 DCA CNTBUF /SAVE IT
4860 1317 TAD K9292
4861 3318 DCA BUFPAT /SETUP INITIAL PATTERN
4862 6081 CMPBUF, IOV /TURN THE INTERRUPT ON
4863 1713 TAD I FILLIT /GET THE WORD FROM BUFFER
4864 7041 CIA /NEGATE IT
4865 1316 TAD BUFPAT /GET THE WORD EXPECTED
4866 7650 SNA CLA
4867 5303 JMP BUFGOD /WORD COMPARED GO INCREMENT COUNTER
4870 4454 ERROR /DATA WORDS DID'NT COMPARE- PRESS
/ "CONT" FOR ADDRESS AND GOOD AND BAD DATA
/
4871 1313 TAD FILLIT
4872 7402 HLT /AC=BUFFER ADDRESS WHERE ERROR WAS DETECTED
4873 7300 CLA CLL
4874 1316 TAD BUFPAT
4875 7402 HLT /AC = GOOD DATA WORD
4876 7300 CLA CLL
4877 1713 TAD I FILLIT
4878 7402 HLT /AC = BAD DATA WORD = PRESS "CONT" TO
4879 7300 CLA CLL /RETRY THE COMPLETE TEST
4880 5493 JMP I TEST /DO THE TEST OVER
4881 1316 BUFGOD, TAD BUFPAT /GET THE DATA PATTERN
4882 7040 CMA /NEGATE IT
4883 3316 DCA BUFPAT /SAVE IT FOR NEXT COMPARE
4884 2313 ISZ FILLIT /INCREMENT ADDRESS TO COMPARE
4885 7000 NOP /THIS IS NEEDED FOR ISZ OVERFLOW
4886 2315 ISZ CNTBUF /DONE COMPLETE BUFFER?
4887 5262 JMP CMPBUF /NO CONTINUE
4888 5254 JMP STRCMP /RE=INITIALIZE COMPARE LOOP AND COMPARE

4713 0000 FILLIT, 0
4714 5200 BUFCNT, 5200=7777=1
4715 0000 CNTBUF, 0
4716 0000 BUFPAT, 0
4717 5252 K9292, 5252
4720 0003 K3, 3
4721 0000 MANHST, 0

4722 0000 OPRRET, 0 /PROGRAM COMES HERE FROM AN AUTO RESTART
4723 7340 CLA CLL CMA
4724 1322 TAD OPRRET /GET THE ADDRESS FROM AUTO RESTART
4725 7041 CIA /NEGATE IT
4726 1321 TAD MANRST /GET EXPECTED RESTART
4727 7650 SNA CLA /ARE THEY EQUAL?
4730 5337 JMP RESET /YES RESET AC AND LINK AND RETURN TO COMPARE
4731 4454 ERROR /THE AUTO RESTART ADDRESS SELECTED BY
/OPERATOR DOES NOT COMPARE WITH AUTO
/AUTO RESTART THAT RETURNED, PRESS "CONT"
/POH EXPECTED AND ACTUAL RETURN ADDRESS
/GET THE EXPECTED AUTO RESTART ADDRESS
/AC = EXPECTED AUTO RESTART ADDRESS

4732 1321 TAD MANRST
4733 7402 HLT
4734 7340 CLA CLL CMA

```

```

4735 1322 TAD OPRRET /GET ACTUAL
4736 7402 HLT /AC = ADDRESS RETURNED FROM AUTO RESTART
4737 7300 RESET, CLA CLL
4740 1377 TAD (OPRINT /SETUP RETURN ADDRESS FOR POWER FAIL
4741 3052 DCA ATRST /SAVE IT
4742 1774 TAD PC
4743 3351 DCA RETPRG
4744 1773 TAD LINK /GET THE LINK
4745 7004 RAL /PUT IT IN THE LINK
4746 1035 TAD DATREC /GET THE AC
4747 6001 IOV /TURN THE INTERRUPT ON
4750 5751 JMP I RETPRG

4751 0000 RETPRG, 0

4752 0034 K34, 34
4753 0001 K1, 1

4754 0000 OPRINT, 0 /OPERATOR INTERVENTION AUTO RESTART
4755 1372 TAD (JMS I ATRST
4756 3000 DCA INTSER
4757 1372 TAD (JMS I ATRST
4760 3771 DCA TEST1=1
4761 1370 TAD OPRRET /SETUP FOR A AUTO RESTART
4762 3052 DCA ATRST
4763 7402 ADDOWN, HLT /WAIT FOR LINE CORD TO BE PLUGGED IN
4764 5453 JMP I TEST /RETRY TEST

4770 4722
4771 0200
4772 4452
4773 5051
4774 5052
4775 4137
4776 5200
4777 4754
5000 PAGE

5000 0000 ACTLIN, 0
5001 1022 TAD OP2SEL
5002 7700 SNA CLA /IS THE PROGRAM RUNNING ON ACT LINE?
5003 5600 JMP I ACTLIN /NO, RETURN
5004 1037 TAD FLDLIN /GET THE FIELD LIMIT
5005 1111 TAD M70
5006 7440 SZA CLA /IS THE FIELD LIMIT EQUAL TO FIELD 7?
5007 5600 JMP I ACTLIN /NO, RETURN TO TEST
5010 1040 TAD UPERLM /GET THE UPPER ADDRESS LIMIT

```

```

5011 7001 IAG /ADD 1 TO IT
5012 7640 SEA CLA /WAS IT 7777
5013 5600 JMP I ACTLIN /NO, RETURN
5014 7392 CLA CLL CMA RTR /SET LAST ADDRESS = 5777
5015 3040 DCA UPERLM /SAVE IT
5016 5600 JMP I ACTLIN /RETURN TO PROGRAM

5017 1022 ENDPAS, TAD OP2SEL /CHECK FOR ACT LINE
5020 7700 SMA CLA /IS THE PROGRAM RUNNING ON ACT LINE
5021 5234 JMP ENDING /NO GO CHECK FOR SR 3 TO HALT AT END OF A PASS
5022 1021 TAD OP1SEL /GET THE HARDWARE CONFIGURATION
5023 0143 AND K200 /CHECK FOR THE SIMULATOR
5024 7640 SEA CLA /WAS THE SIMULATOR SELECTED
5025 5234 JMP ENDING /YES, ALREADY NOTIFIED PROM OF GOOD PAS
5026 2242 ISB PRGPAS /CHECK 1/2 SECOND COUNT
5027 5234 JMP ENDING /NOT 1/2 SECOND YET
5030 1377 TAD (=144 /RESET THE COUNTER
5031 3242 DCA PRGPAS
5032 6272 CIP 70 /CHANGE INSTRUCTION FIELD TO 7
5033 4451 JMS I GOODPS /SIGNAL THE PROM
5034 4341 ENDPAS, JMS SWCHK /CHECK SR 3 TO HALT ON A PROGRAM PASS
5035 7006 RTL
5036 7004 RAL
5037 7710 SPA CLA
5040 7402 HLT /END OF A COMPLETE PROGRAM PASS
5041 5776 JMP 0201 /RESTART THE PROGRAM

5042 7634 PRGPAS, =144

5043 7010 POWEAL, RAR
5044 3251 DCA LINK
5045 1000 TAD INTSER
5046 3292 DCA PC
5047 6103 CAL /CLEAN AC LOW F/F
5050 4452 JMS I ATRST /RETURN TO THE PROGRAM

5051 0000 LINK, 0
5052 0000 PC, 0

5053 0000 PRGST, 0
5054 6102 SPL /SKIP ON AC LOW AS A LEVEL
5055 7610 SKP CLA
5056 5254 JMP =2
5057 5453 JMP I TEST /RETURN TO TEST BEING EXECUTED AND START OVER

5060 0000 TESTAD, 0
5061 7340 CLA CLL CMA
5062 1260 TAD TESTAD
5063 3053 DCA TEST
5064 1375 TAD (PRGST
5065 3052 DCA ATRST
    
```

```

5066 5660 JMP I TESTAD

5067 1021 BATEMT, TAD OP1SEL /GET HARDWARE CONFIGURATION
5070 0143 AND K200
5071 7650 SNA CLA /MACHINE GOING DOWN = STOP EVERYTHING
5072 5277 JMP DEAD
5073 3373 DCA ACNLOK
5074 2000 ISB INTSER
5075 2000 ISB INTSER
5076 5400 JMP I INTSER
5077 7402 DEAU, HLT /ITS ALL OVER NOW = GOOD-BYE
5080 5453 JMP I TEST

5101 0000 GOODBD, 0
5102 1022 TAD OP2SEL /GET HARDWARE CONFIGURATION
5103 7700 SMA CLA /IS THE PROGRAM RUNNING ON ACT LINE
5104 5701 JMP I GOODBD /NO RETURN TO PROGRAM
5105 6272 CIP 70 /CHANGE INSTRUCTION FIELD TO FIELD 7
5106 4451 JMS I GOODPS /SIGNAL ACT LINE PROGRAM STILL RUNNING
5107 5701 JMP I GOODBD /RETURN TO PROGRAM

5110 0000 ERRRX, 0 /ERROR ROUTINE
5111 7300 CLA CLL OP2SEL
5112 1022 TAD OP2SEL /CHECK FOR ACT LINE
5113 7700 SMA CLA
5114 5326 JMP CHKINH
5115 1021 TAD OP1SEL
5116 0143 AND K200
5117 7640 SEA CLA
5120 6160 CLRMOD
5121 6002 IOP /TURN THE INTERRUPT OFF
5122 7240 CLA CMA
5123 1310 TAD ERRRX
5124 6272 CIP 70
5125 5450 JMP I BADPAS /GO TO MOM FOR ERROR
5126 4341 CHKINH, JMS SWCHK /CHECK FOR SR 0(1) TO INHIBIT ERROR HALT
5127 7710 SPA CLA /IS SR 0 SET TO A ONE
5130 5334 JMP ERLPSH /YES, GO CHECK SR 1 TO LOOP ON ERROR
5131 7340 CLA CLL CMA
5132 1310 TAD ERRRX
5133 7402 HLT /SUBTRACT ONE FROM JMS ERROR PC
/AC CONTAINS THE ADDRESS WHERE THE ERROR
/WAS DETECTED BY THE PROGRAM, REFER
/TO THE PROGRAM LISTING FOR ERROR
/EXPLANATION AND THE TEST DESCRIPTION,
/CHECK THE SWITCH REGISTER TO LOOP ON ERROR

5134 4341 ERLPSH, JMS SWCHK
5135 7004 RAL
5136 7710 SPA CLA /IS SR 1 SET TO A ONE TO LOOP ON TEST
5137 5453 JMP I TEST /YES GO LOOP ON THE TEST
5140 5710 JMP I ERRRX /NO, RETURN TO THE PROGRAM

5141 0000 SWCHK, 0
5142 7300 CLA CLL
    
```

5143	1021	TAD	DP1SEL	/GET THE HARDWARE STATUS WORD
5144	7700	SMA	CLA	/IS THE HARDWARE FRONT PANEL SELECTED
5145	5350	JMP	,*3	/NO, USE THE PSEUDO SWITCH REGISTER
5146	7004	LAS		
5147	5741	JMP	I SWCHK	/RETURN
5150	1020	TAD	SWTCH	/THE PSEUDO SWITCH REGISTER
5151	5741	JMP	I SWCHK	/RETURN

5152	0000	TSTLOP, 0		/ROUTINE TO CHECK SM 2 TO LOOP ON TEST
5153	4341	JMS	SWCHK	/GO GET THE SWITCH REGISTER
5154	7006	RTL		
5155	7700	SMA	CLA	
5156	5752	JMP	I TSTLOP	/GO TO NEXT TEST
5157	5453	JMP	I TEST	/LOOP ON SAME TEST

5160	0000	ACLBAT, 0		
5161	1373	TAD	ACNLOK	/LOOK AT RETURN FOR AC LOW OR BATTERY EMPTY
5162	7640	SEA	CLA	
5163	5366	JMP	,*3	
5164	2000	ISE	INTSER	
5165	5400	JMP	I INTSER	
5166	3373	DCA	ACNLOK	
5167	6101	SBE		/SKIP ON BATTERY EMPTY
5170	5364	JMP	,*4	
5171	2000	ISE	INTSER	
5172	5364	JMP	,*6	
5173	0000	ACNLOK, 0		

5175	5053			
5176	0201			
5177	7634			
	5200	PAGE		

5200	0000	BUFFER, 0		/BUFFER IS FROM 5200 TO 7777 FOR 4k
				/BUFFER IS FROM 5200 TO 9777 FOR 3k

0200 *200

0000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0100	11111111	11111111	11111111	11111111	11111111	11110000	00000000	00000000
0200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0300	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11110011
0400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0500	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0700	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1100	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1300	11111111	11111111	11111111	11111111	11111111	11111111	11111000	00000011
1400	11111111	11111111	11111111	11111111	11111111	11111111	00000000	00000000
1500	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000001
1600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1700	11111111	11111111	11111111	11111111	11111111	11111111	10000000	00000001
2000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
2100	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
2200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
2300	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
2400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
2500	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
2600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
2700	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
3000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
3100	11111111	11111111	11111111	11111111	11111111	11000000	00000000	00000011
3200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
3300	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
3400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
3500	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
3600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
3700	11111111	11111111	11111111	11111111	11111111	11111110	00000011	11111111

```

4000 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
4100 11111111 11111111 11111111 11111111 11111111 11111111 11111071 11111111

4200 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
4300 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11100011

4400 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
4500 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111

4600 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
4700 11111111 11111111 11111111 11111111 11111111 11111111 11111000 11111111

5000 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
5100 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11110111

5200 10000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000
5300 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000

5400
5500

5600
5700

6000
6100

6200
6300

6400
6500

6600
6700

7000
7100

7200
7300

7400
7500

7600
7700
    
```

```

ACQDHN 4763 CJMS04 1272 GOODPY 0051 41070 0127
ACLBAT 5160 CJMS05 1320 GTF 6004 411 0070
ACNLOK 5173 CJMS06 1346 HQHLIM 0044 41100 0130
ACTLIN 5000 CJMS07 1410 HLT 7402 4125 0114
ADD401 3753 CJMS10 1436 INTSER 0000 4152 0115
ADDCNT 0047 CKJMS1 1627 JMSCK1 2246 416 0071
ADDRES 4135 CKJMS2 1657 JMSCK2 2272 42 0063
AUTCNT 4133 CKJMS3 1750 JMSCK3 2314 420 0072
AUTENA 4147 CKJMS4 1741 JMSCK4 2340 422 0073
AUTO 4600 CKJMS5 2013 JMSCK5 2364 425 0074
AUTHST 0052 CKJMS6 2044 JMSCK6 2410 430 0075
AUTSEL 4134 CKJMS7 2075 JMSCK7 2434 4300 0116
AUTTST 4056 CKJMS8 2127 JMSCK8 2480 433 0076
BADPAS 0050 CKJMS9 2161 K1 4753 434 0077
BATEMT 5067 CLFAB 4463 K10 0135 44 0064
REGI16 3025 CLRBOT 4465 K1000 4254 440 0100
REGI17 3217 CLREMA 6154 K125 0141 44100 0131
RODTRK 4461 CLREG 3540 K152 0142 443 0101
RODTR1 3755 CLRMD 6160 K1777 0145 444 0102
RODTR2 3756 CLRSIM 6170 K200 0143 45 0065
RODTRB 3607 CMRBUF 4662 K2000 0146 450 0103
ROTADD 4567 CNTBOT 3750 K3 4720 45000 0132
ROTCLR 4565 CNTBUF 4715 K3000 4293 45100 0133
ROTCHP 4400 COMPAR 4425 K34 4792 452 0104
ROTCNT 4571 CNT#2 3751 K37 0136 455 0105
ROTENA 4155 CONT#3 3752 K400 0144 460 0106
ROTEHD 4511 COVW2 4136 K4100 0193 461 0107
ROTRT1 3671 CUP 6264 K5252 4717 466 0110
ROTRT2 3726 DATPAT 0042 K6201 0045 47 0066
ROTSAD 4570 DATREC 0035 K7 0134 470 0111
ROTSSEL 4150 DEAD 5077 K70 0137 477 0112
RTSURT 3754 DS4ADD 4363 K7677 0192 478 0112
RTTST1 3652 EMA1 3941 K77 0140 479 0112
RTTST2 3707 EMA2 3942 K7707 0190 480 0112
RUFCHT 4714 EMA3 3943 K7757 0191 481 0112
RUFPER 5200 EMACLR 3331 K7774 0147 482 0112
RUFQOD 4703 EMAF1 3432 KKS 4572 483 0112
RUFFPAT 4716 EMAF2 3451 LINK 5051 484 0112
CAF 6007 EMAF3 3464 LODMG2 6152 485 0112
CAL 6103 ENJNG 5034 LODMG3 6153 486 0112
CAPSB 4000 ENJPAS 5017 LOOP 4455 487 0112
CDF 6201 ENJ17 3314 M1 0062 488 0112
CDFCHK 0033 ENJ18 3144 M10 0067 489 0112
CDFNEW 3062 ERLPW 5134 M100 0113 490 0112
CHKCDF 0034 ERROR 4454 M1000 0117 491 0112
CHKINH 5126 ERRORX 5110 M1007 0120 492 0112
CIF 6202 EXECUT 6164 M1016 0121 493 0112
CIFCDF 6203 FILLLT 4713 M1025 0122 494 0112
CINT 6204 FLJLIM 0037 M1034 0123 495 0112
CJMS01 1166 GODAUT 4125 M1043 0124 496 0112
CJMS02 1210 GDDDD 5101 M1052 0125 497 0112
CJMS03 1244 GDDDCP 4443 M1061 0126 498 0112
    
```

HESET	4737	TEST16	2763	TST19H	3446
RETFRG	4751	TEST17	3200	TST19Q	3461
RFDFCP	4365	TEST18	3321	TST20N	0402
RFDFED	4371	TEST19	3415	TSTLOP	5152
RIB	6234	TEST2	0343	UPPHLM	0040
RIF	6224	TEST20	3477	WRKADD	0043
RK8ADD	3615	TEST21	3627	WRKFLD	0041
RK8CMP	3617	TEST22	4041	XBAT	0060
RK8E	0023	TEST23	4201	XPWRFL	0057
RK8END	3625	TEST3	0432		
RNF	6244	TEST4	0474		
RSTAUT	4101	TEST5	0530		
RTF	6005	TEST6	0577		
SAVESE	0036	TEST7	0647		
SAVSTR	4566	TEST8	0706		
SAVWFD	0046	TEST9	0776		
SBE	6101	TESTAD	0660		
SCOPLP	4456	TIM01S	4255		
SELAUT	4143	TST11A	1137		
SET3K	4534	TST11B	1156		
SET2K	4540	TST11C	1204		
SET3K	4563	TST11D	1234		
SETUP	4517	TST11E	1262		
SETUP1	4527	TST11F	1310		
SETUP2	4541	TST11G	1336		
SIMBOT	3747	TST11H	1400		
SINT	6234	TST11I	1426		
SKON	6000	TST12A	1615		
SKPEMA	6166	TST12B	1645		
SPL	6102	TST12C	1576		
STRCMP	4654	TST12D	1727		
SUP	6274	TST12E	2001		
SWCHK	5141	TST12F	2032		
SWITCH	0020	TST12G	2063		
T16LCD	3055	TST12H	2115		
T17ODP	3246	TST12I	2147		
T17HET	3271	TST13A	2236		
TABADD	3544	TST13B	2262		
TABCMP	3548	TST13C	2304		
TABEND	3605	TST13D	2330		
TABLE	3306	TST13E	2354		
T08ADD	4343	TST13F	2400		
T08CMP	4345	TST13G	2424		
T08END	4355	TST13H	2450		
TEST	0053	TST14A	2515		
TEST1	0201	TST14B	2552		
TEST10	1053	TST14C	2610		
TEST11	1116	TST14D	2650		
TEST12	1600	TST14A	3345		
TEST13	2216	TST14B	3364		
TEST14	2500	TST14C	3377		
TEST15	2674	TST14A	3430		

ERRORS DETECTED: 0
 LINKS GENERATED: 38
 RUN-TIME: 23 SECONDS
 3K CORE USED

/KMB=A OPTION TEST 2 MAINDEC=08=DJKMA=A=L 1K PART 1
/COPYRIGHT (C) 1974, DIGITAL EQUIPMENT CORPORATION
/PROGRAMMER: BRUCE HANSEN
/

////////////////////////////////////
/THE FOLLOWING LISTING WILL CORRESPOND TO THE PAPER TAPE LABELED MAINDEC=08=DJKMA=A=PH1,
/1K PART 1. THIS PAPER TAPE AND LISTING WILL BE THE FIRST OF FOUR 1K SEGMENTED
/PAPER TAPES AND LISTINGS FOR COMPUTERS WITH LESS THAN 4K OF MEMORY.
////////////////////////////////////

/KMB=A OPTION TEST 2 MAINDEC=08=DJKMA=A=L 1K PART 1
/COPYRIGHT 1974, DIGITAL EQUIPMENT CORP., MAYNARD, MASS., 01754
/POP=0A OPTION TEST 2 TESTS THE MEMORY EXTENTION/TIME SHARE CONTROL,
/POWER FAIL/AUTO RESTART, AND BOOTSTRAP LOADERS

6000 SKON#0000
6007 CAP#6007
7402 HLT#7402

/SWITCH REGISTER SETTINGS

/SR0#1 INHIBIT ERROR HALT
/SR1#1 LOOP ON ERROR
/SR2#1 LOOP ON TEST
/SR3#1 HALT AT COMPLETION OF A PROGRAM PASS

/MEMORY EXTENTION/TIME SHARE INSTRUCTIONS

6004 GTF#0004 /GET FLAGS, READS THE FOLLOWING MACHINE STATES
/INTO THE INDICATED BITS OF THE AC1
/AC0 LINE
/AC2 INTERRUPT REQUEST
/AC4 INTERRUPT ENABLE F/F
/AC5 USER FLAG
/AC6=11 SAVE FIELD REGISTER

6005 RTF#0005 /RESTORE THE FLAGS, RTF LOADS THE LINK FROM AC0,
/LOADS THE USER BUFFER F/F, INSTRUCTION BUFFER AND
/DATA FIELD WITH AC5, AC6=0, AC 9=11 AND INHIBITS
/PROCESSOR INTERRUPTS UNTIL NEXT JMP OR JMS INSTRUCTION,
/AT THE END OF THE JMP OR JMS, THE CONTENTS OF THE U.B. + 1,8,
/ARE LOADED INTO USER FIELD F/F, AND THE I.F., INTERRUPT ENABLE
/IS SET AND INTERRUPT INHIBIT AS CLEARED

6234 RIB#0234 /READ THE INTERRUPT BUFFER

6244 RHF#0244 /RESTORES MEMORY FLAGS

6204 CINT#0204 /CLEAN USER INTERRUPT FLIP=FLOP

6254 SINT#0254 /SKIP ON USER INTERRUPT FLIP=FLOP

6264 CUF#0264 /CLEAN USER BUFFER FLIP=FLOP

6274 SUP#0274 /SET USER BUFFER FLIP=FLOP (ENTER TIME SHARE MODE)AND
/INHIBITS PROCESSOR INTERRUPTS UNTIL THE NEXT JMP OR
/JMS INSTRUCTION, AT THE END OF THE JMP OR JMS
/INSTRUCTION, THE USFR BUFR IS LOADED INTO THE USER
/FIELD F/F;

6201 CDF#0201 /CHANGE DATA FIELD

```

6202 CIF#6202 /CHANGE INSTRUCTION FIELD
6214 RDP#6214 /READ THE DATA FIELD INTO AC BITS 6=8
6224 RIF#6224 /READ THE INSTRUCTION FIELD INTO AC BITS 6=8
6203 CIPCF#6203 /PERFORMS THE CIF AND CDF FUNCTIONS

/POWER FAIL INSTRUCTIONS

6102 SPL#6102 /SKIP ON AC LOW FLIP=FLOP
6103 CAL#6103 /CLEAR AC LOW FLIP=FLOP
6104 SBE#6104 /SKIP ON BATTERY EMPTY FLIP=FLOP

/OPTION BOARD 2 SIMULATOR IOT/IS

6150 CLRSIM#6150 /CLEAR CONTROL REGISTERS
6152 LODRG2#6152 /LOAD CONTROL REGISTER 2
6153 LODRG3#6153 /LOAD CONTROL REGISTER 3
6154 CLRMA#6154 /CLEAR EMA CATCHER LOGIC
6155 REDEMA#6155 /READ EMA CATCHER REGISTER
6156 CLRMDJ#6156 /CLEAR TEST MODULE LOGIC
6164 EXECUT#6164 /EXECUT AND CONTROL WORD 3 BIT 7 #1 ISSUE A POWER ON PULSE
/EXECUT AND CONTROL WORD 3 BIT 7 #0 ISSUE A SWITCH SW PULSE
6166 SKPEMA#6166 /SKPEMA AND CONTROL WORD 3 BIT 3 #1 EMA INTERRUPT AND SKIP ENABLE
/SKPEMA AND CONTROL WORD 3 BIT 3 #0 EMA INTERRUPT AND SKIP DISABLE
    
```

/OPTION BOARD2 SIMULATOR CONTROL WORD 2 BIT ASSIGNMENTS

```

/
/BITS 0 = 1 NOT USED
/BITS 2 = 3 BOOT STRAP PROGRAM SELECT
/BITS 9 = 11 AUTO-RESTART ADDRESS SELECT
    
```

/OPTION BOARD 2 SIMULATOR CONTROL WORD 3 BIT ASSIGNMENTS

```

/
/BIT 0 TIME SHAME 0=ENABLED 1=DISABLED
/BIT 1 AC LOW (L) 1=PULLED LOW 0=FREE STATE
/BIT 2 BATT EMPTY 1=BATT EMPTY PULLED LOW 0=FREE STATE
/BIT 3 1=EMA INTERRUPT/SKIP ENABLE 0=EMA INTERRUPT SKIP DISABLE
/BITS 4 = 5 NOT USED
/BIT 7 1=POWER ON PULSE WITH EXECUT 0=SWITCH SW PULSE WITH EXECUT
/BIT 8 1=DISABLES BOOTSTRAP WHILE RUNNING 0=ENABLES BOOTSTRAP WHILE RUNNING
/BIT 9 = 11 AUTO-RESTART/BOOT STRAP ENABLE CODE
    
```

0000 *0

```

0000 0000 INTSER, 0 /JMS I AUTHST PLACED HERE FOR SIMULATOR AUTO RESTART
0001 3035 DCA DATREC
0002 6102 SPL /SKIP ON AC LOW
0003 7410 SKP
0004 5457 JMP I XPRFL /POWER GOING DOWN
0005 6104 SBE /SKIP ON BATTERY EMPTY
    
```

```

0006 7410 SKP
0007 5400 JMP I XBAT /GO HALT THE COMPUTER ,ITS ALL OVER
0010 6224 RIF /READ THE INSTRUCTION FIELD
0011 7640 SEA CLA
0012 4454 ERROR /I,F, IS NOT 0 AFTER A INTERRUPT
0013 6214 RDP /READ THE DATA FIELD
0014 7640 SEA CLA
0015 4454 ERROR /O,F, IS NOT 0 AFTER A INTERRUPT
0016 2000 ISZ INTSER /ADD 1 TO THE INTERRUPTED PC
0017 5400 JMP I INTSER /RETURN TO THE PROGRAM
    
```

0020 *20

```

0020 0000 SWITCH, 0 /PSEUDO SWITCH REGISTER IF BIT 0=0 OF OP1SEL
0021 1000 OP1SEL, 1000

/BIT 0=0 USE LOC 20 AS A PSEUDO S,R,
/BIT 0=1 USE HARDWARE FRONT PANEL S,R,
/BIT 1=1 HAS 8A OPTION 1
/BIT 2=1 HAS 8A OPTION 2
/BIT 3=1 HAS 8A CPU SIMULATOR
/BIT 4=1 HAS 8A OPTION 1 + 2 TEST MODULE
/BIT 5=1 PROGRAM ON AA XOR
/BIT 6=1 HAS PDP=8E TYPE CPU
/BITS 7=11 MEMORY SIZE = 0'S = 1K, 37=32K,
/MEMORY SIZE CAN BE INCREASED IN 1K INCREMENTS
/BY ADDING A 1 TO THE NUMBER IN BITS 7=11.
    
```

```

0022 0000 OP2SEL, 0
/ARK8E BOOT STRAP WILL LOAD INTO THE FOLLOWING LOCATIONS
    
```

```

0023 7402 RKB#, WLT /2000
0024 7402 WLT /6745
0025 7402 WLT /0023
0026 7402 WLT /7650
0027 7402 WLT /5024
0030 7402 WLT /6733
0031 7402 WLT /5031
0032 7402 WLT /TERMINATOR
0033 0000 CDFCHK, 0
0034 0033 CHKCDF, CDFCHK
0035 0000 DATHEG, 0
0036 0000 SAVES4, 0
0037 0000 FLOLIN, 0
0040 0000 UPEMLM, 0
0041 0000 NRKFLU, 0
0042 0000 DATPAT, 0
0043 0000 WRKADJ, 0
0044 0000 HGHLIN, 0
0045 6201 K6201, 6201
0046 0000 SAVNFD, 0
0047 0000 ADDCNT, 0
0050 6520 BADP#1, 6520
0051 6500 GOODP#, 6500
0052 1647 AUTHST, PRGRST
0053 0000 TEST, 0 /SCOPE LOOP AND TEST LOOP ADDRESS
    
```

```

0054 4454 ERROR# JMS I ;
      1704          ; ERRORX
      4455 LOOP# JMS I ;
0055 1746          ; TSTLOP
      4456 SCOPLP# JMS I ;
0056 1654          ; TESTAD

0057 1637 XPHHFL, POWFAL
0060 1663 XBAT, BATEMT
0061 1617 PASENU, ENDPAS
    
```

/CONSTANTS USED BY THE PROGRAM

```

0062 7777 M1, =1
0063 7776 M2, =2
0064 7774 M4, =4
0065 7773 M5, =5
0066 7771 M7, =7
0067 7770 M10, =10
0070 7767 M11, =11
0071 7762 M16, =16
0072 7760 M20, =20
0073 7756 M22, =22
0074 7753 M25, =25
0075 7750 M30, =30
0076 7745 M33, =33
0077 7744 M34, =34
0100 7740 M40, =40
0101 7735 M43, =43
0102 7734 M44, =44
0103 7730 M50, =50
0104 7726 M52, =52
0105 7723 M55, =55
0106 7720 M60, =60
0107 7717 M61, =61
0110 7712 M66, =66
0111 7710 M70, =70
0112 7701 M77, =77
0113 7700 M100, =100
0114 7653 M120, =120
0115 7626 M152, =152
0116 7500 M300, =300
0117 7000 M1000, =1000
0120 6771 M1007, =1007
0121 5762 M1016, =1016
0122 6753 M1020, =1020
0123 6744 M1034, =1034
0124 6735 M1043, =1043
0125 6726 M1052, =1052
0126 6717 M1061, =1061
0127 6710 M1070, =1070
0130 6700 M1100, =1100
0131 3700 M4100, =4100
    
```

```

0132 3000 M5000, =5000
0133 2700 M5100, =5100

0134 0007 K7, 7
0135 0010 K10, 10
0136 0037 K37, 37
0137 0070 K70, 70
0140 0077 K77, 77
0141 0125 K125, 125
0142 0152 K152, 152
0143 0200 K200, 200
0144 0400 K400, 400
0145 1777 K1777, 1777
0146 2000 K2000, 2000
0147 7774 K7774, 7774
0150 7707 K7707, 7707
0151 7757 K7757, 7757
0152 7677 K7677, 7677
0153 4100 K4100, 4100
    
```

0200 =200

```

.....
/TEST 1 = CHECKS THE CDF AND RDF INSTRUCTIONS TO LOAD AND READ
/THE DATA FIELD, A RIF IS ISSUED AFTER EACH DATA FIELD CHANGE
/TO CHECK THAT THE INSTRUCTION FIELD REMAINS A ZERO,
/THE INCLUSIVE OR OF THE D,F, WITH THE AC IS CHECKED WITH THE RDF INSTRUCTION,
/SET TIME SHARE ENABLE SWITCH TO TIME SHARE ENABLE POSITION
.....
    
```

```

0200 7000 TEST1: NOP/JMS I ATRST /IF SIMULATOR SELECTED THIS LOCATION WILL CHANGE TO JMS I ATRST
0201 6100 CLRMOD /CLEAN SIMULATOR TEST LOGIC
0202 3777 DCA ACNLOK
0203 4456 SCOPLP /SETUP SCOPE ANND TEST LOOPING ADDRESS
0204 6007 CAF /CLEAN ALL FLAGS
0205 6244 CUF /CLEAN USER FLAG
0206 7410 SKP
0207 4454 ERROR /CUF SKIPPED
0210 6254 SINT /SKIP IF USER INTERRUPT FLIP=FLOP SET
0211 7410 SKP
0212 4454 ERROR /SINT SKIPPED OR CAF FAILED TO 0 USER INTERRUPT
0213 6001 IOV /TURN THE INTERRUPT ON
0214 6201 CDF 00 /CHANGE DATA FIELD TO FIELD 0
0215 7410 SKP
0216 4454 ERROR /CDF SKIPPED
0217 6214 RDF /READ THE DATA FIELD
0220 7410 SKP
0221 4454 ERROR /RDF SKIPPED
0222 7640 SEA CLA /HAS IF FIELD 0?
0223 4454 ERROR /RDF HEAD BACK SOMETHING OTHER THAN D,F, 0
0224 6224 RIF /READ THE INSTRUCTION FIELD
0225 7410 SKP
0226 4454 ERROR /RIF SKIPPED
    
```

```

0227 7640 SEA CLA /HAS THE I,F, 0?
0230 4454 ERROR /RIF READ BACK SOMETHING OTHER THAN I,F, 0
0231 6271 CDF 70 /CHANGE DATA FIELD TO FIELD 7
0232 6214 RDF /READ THE DATA FIELD
0233 1111 TAD M70 /CHECK THAT DATA FIELD 7 WAS READ BACK
0234 7640 SEA CLA /INTO AC BITS 6,7 & 8
0235 4454 ERROR /CDF OR RDF TO FIELD 7 FAILED
0236 1150 TAD K7707 /CHECK THE INCLUSIVE OR FUNCTION OF RDF
0237 6214 RDF /READ THE DATA FIELD
0240 7040 CMA
0241 7640 SEA CLA
0242 4454 ERROR /THE INCLUSIVE OR OF THE DF WITH AC FAILED
0243 6224 RIF /READ THE INSTRUCTION FIELD
0244 7640 SEA CLA /IS IT STILL 0?
0245 4454 ERROR /THE INSTRUCTION FIELD CHANGED
0246 6221 CDF 20 /CHANGE TO DATA FIELD 2
0247 6214 RDF /READ THE DATA FIELD
0250 1072 TAD M20 /CHECK TO SEE IF DF 2 WAS READ BACK
0251 7640 SEA CLA /HAS IT DATA FIELD 2?
0252 4454 ERROR /NO, CDF 20 OR RDF FAILED
0253 1151 TAD K7757 /CHECK THE INCLUSIVE OR OF THE DF WITH THE AC
0254 6214 RDF /READ THE DATA FIELD
0255 7040 CMA
0256 7640 SEA CLA
0257 4454 ERROR /THE INCLUSIVE OR OF DF WITH AC FAILED
0260 6224 RIF /READ THE INSTRUCTION FIELD
0261 7640 SEA CLA /IS THE IF STILL 0?
0262 4454 ERROR /THE INSTRUCTION FIELD CHANGED
0263 6251 CDF 50 /CHANGE TO DATA FIELD 5
0264 6214 RDF /READ THE DATA FIELD
0265 1103 TAD M50
0266 7640 SEA CLA
0267 4454 ERROR /HAS IT DATA FIELD 5?
0270 6224 RIF /NO, CDF 50 OR RDF FAILED
0271 7640 SEA CLA /READ THE INSTRUCTION FIELD
0272 4454 ERROR /IS THE I,F, STILL 0?
0273 6231 CDF 30 /NO, THE INSTRUCTION FIELD CHANGED
0274 6214 RDF /CHANGE THE DATA FIELD TO 3
0275 1075 TAD M30 /READ THE DATA FIELD
0276 7640 SEA CLA /
0277 4454 ERROR /IS IT EQUAL TO FIELD 3
0300 6224 RIF /NO, CDF 30 OR RDF FAILED
0301 7640 SEA CLA /READ THE INSTRUCTION FIELD
0302 4454 ERROR /IS THE I,F, STILL EQUAL TO 0?
0303 6241 CDF 40 /NO, THE I,F, CHANGED
0304 6214 RDF /CHANGE THE DATA FIELD TO FIELD 4
0305 1100 TAD M40 /READ THE DATA FIELD
0306 7640 SEA CLA /IS IT EQUAL TO D,F, 4
0307 4454 ERROR /NO, CDF 40 OR RDF FAILED
0310 6224 RIF /READ THE INSTRUCTION FIELD
0311 7640 SEA CLA /IS IT STILL EQUAL TO 0?
0312 4454 ERROR /NO, THE I,F, CHANGED
0313 6211 CDF 10 /CHANGE THE DATA FIELD TO FIELD 1
0314 6214 RDF /READ THE DATA FIELD
0315 1067 TAD M10

```

```

0316 7640 SEA CLA /IS IT EQUAL TO DATA FIELD 1
0317 4454 ERROR /NO, CDF 10 OR RDF FAILED
0320 6224 RIF /READ THE INSTRUCTION FIELD
0321 7640 SEA CLA /IS IT STILL EQUAL TO 0?
0322 4454 ERROR /NO, THE I,F, CHANGED
0323 6261 CDF 60 /CHANGE DATA FIELD TO FIELD 6
0324 6214 RDF /READ THE DATA FIELD
0325 1106 TAD M60
0326 7640 SEA CLA /IS THE D,F, EQUAL TO 6?
0327 4454 ERROR /NO, CDF 60 OR RDF FAILED
0330 6224 RIF /READ THE INSTRUCTION FIELD
0331 7640 SEA CLA /IS IT STILL EQUAL TO ZERO?
0332 4454 ERROR /NO, INSTRUCTION FIELD CHANGED
0333 6201 CDF 00 /CHANGE DATA FIELD TO FIELD 0
0334 6214 RDF /READ THE DATA FIELD
0335 7640 SEA CLA /IS IT EQUAL TO FIELD 0?
0336 4454 ERROR /NO, CDF 00 OR RDF FAILED
0337 6224 RIF /READ THE INSTRUCTION FIELD
0340 7640 SEA CLA /IS IT STILL EQUAL TO ZERO?
0341 4454 ERROR /NO, INSTRUCTION FIELD CHANGED,
0342 4455 LOOP /LOOP ON TEST IF SR = 1000

```

```

.....
/TEST 2 = CHECKS THAT USER MODE CAN BE ENTERED AND EXITED BY DOING A
/ION=SUP=JMP=HLT, THE USER INTERRUPT IS CHECKED TO BE SET BY SINT AND
/CLEARED BY CINT, GTF AND RIB ARE ISSUED TO CHECK THAT THE SAVE FIELD
/GET LOADED AND THAT THE INSTRUCTIONS CAN READ THE $AVE FIELD,
.....

```

```

0343 4456 TEST2, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0344 6007 CAP /CLEAN ALL FLAGS
0345 6264 CDF /CLEAN USER BUFFER F/F
0346 7410 SKP /
0347 4454 ERROR /GTF SKIPPED
0350 6204 CINT /CLEAN USER INTERRUPT FLIP=FLOP
0351 7410 SKP /
0352 4454 ERROR /CINT SKIPPED
0353 6254 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
0354 7410 SKP /
0355 4454 ERROR /SINT SKIPPED OR USER INTERRUPT F/F SET
0356 6001 IOV /TURN THE INTERRUPT ON
0357 6274 SUP /SET USER BUFFER F/F, SET INT INHIBIT AT TP3
0360 5362 JMP ,42 /LOAD UB INTO I,F, REGISTER, CLEAR INT INHIBIT F/F
0361 5361 JMP /SUP SKIPPED OR TRAPPED,
0362 7402 HLT /USER INTERRUPT FAILED TO SET OR HALT FAILED TO TRAP
0363 5363 JMP /HLT FAILED TO TRAP
0364 6254 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
0365 5365 JMP /USER INTERRUPT NOT SET OR SINT FAILED TO SKIP,
0366 6204 CINT /CLEAN USER INTERRUPT FLIP=FLOP
0367 6254 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
0370 7410 SKP /
0371 5371 JMP /CINT FAILED TO 0 USER INTERRUPT FLIP=FLOP
0372 5776 JMP TST2CN /CONTINUE THE TEST

0376 0402

```

```

0377 1767
0400 0400 PAGE
0400 7000 NOP
0401 7000 NOP
0402 6004 TSTCON, GTF /GET THE FLAGS
0403 7410 SKP
0404 9204 JMF /GTF SKIPPED
0405 1113 TAD M100 /CHECK USER FLAG TO BE SET
0406 7640 SEA CLA /WAS THE CORRECT IF, D,F, AND USER FIELD FLIP=FLOP LOADED?
0407 9207 JMF /NO, USER FIELD F/F NOT LOADED OR OTHER BITS SET
0410 7300 CLA CLL /OR GTF FAILED
0411 6234 RIB /HEAD THE INTERRUPT BUFFER
0412 7410 SKP
0413 9213 JMF /RIB SKIPPED
0414 1113 TAD M100 /CHECK FOR USER FLAG
0415 7640 SEA CLA
0416 9219 JMF /RIB FAILED OR SAVE FIELDS CLEARED
0417 1152 TAD M7677 /CHECK THE INCLUSIVE OR OF SP WITH AC
0420 6234 RIB /HEAD THE INTERRUPT BUFFER
0421 7040 CMA
0422 7640 SEA CLA
0423 9223 JMF
0424 7340 CLA CLL CMA /INCLUSIVE OR OF SAVE FIELD WITH AC FAILED
0425 6004 GTF /SET THE AC TO ALL ONES
0426 1113 TAD M100 /GET THE FLAGS
0427 7640 SEA CLA
0430 9230 JMF
0431 4455 LOOP /GTF FAILED TO DO A JAM TRANSFER TO AC
/ OR SAVE FIELDS CLEARED,
/ LOOP ON TEST IF SR = 1000

```

```

/*****
/TEST 3= CHECKS THAT OSR WILL TRAP IN USER MODE AND THAT
/IT WILL NOT AFTER A INTERRUPT, RIB, GTF, RIF, RDF ARE CHECKED TO
/HEAD THE SAVE FIELDS AND I,F, AND D,F,
/*****

```

```

0432 4456 TEST3, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0433 6007 CAF /CLEAN ALL FLAGS
0434 6001 IOV /TURN THE INTERRUPT ON
0435 6274 SUP /SET USER BUFFER F/F, SET INT INH AT TP3
0436 9297 JMF /ENTER USER MODE
0437 7404 OSR /USH SHOULD SET USER INTERRUPT F/F + CAUSE A TRAP
0440 9240 JMF /USH FAILED TO TRAP
0441 6294 SINT /SKIP ON USER INTERRUPT F/F
0442 9242 JMF /USER INTERRUPT F/F NOT SET
0443 6204 CINT /CLEAN USER INTERRUPT F/F
0444 6254 SINT /SKIP ON USER INTERRUPT F/F
0445 7410 SKP
0446 9246 JMF /SINT FAILED TO CLEAR USER INTERRUPT F/F
0447 6001 IOV /TURN THE INTERRUPT ON
0450 9251 JMF /CHECK THAT THE INTERRUPT HAD CLEARED THE USER FIELD F/F
0451 7404 OSR /USH SHOULD NOT TRAP
0452 7610 SKP CLA
0453 9253 JMF /USH TRAPPED AFTER A INTERRUPT OCCURED ABOVE
/ CHECK THE USER BUFFER AND I,F,

```

```

0454 6234 RIB /HEAD THE INTERRUPT BUFFER
0455 1113 TAD M100 /CHECK THE SAVE FIELD FOR USER FLAG
0456 7640 SEA CLA
0457 4454 ERROR /USER FLAG NOT SET OR OTHER BITS SET
0460 7340 CLA CLL CMA /SET THE AC TO ALL ONES
0461 6004 GTF /GET THE FLAGS
0462 1116 TAD M300 /CHECK FOR INT ENA, AND USER FLAG
0463 7640 SEA CLA
0464 4454 ERROR /USER FLAG AND INT ENA NOT SET OR OTHER BITS SET
0465 6224 RIF /HEAD THE INSTRUCTION FIELD
0466 7640 SEA CLA
0467 4454 ERROR /THE INSTRUCTION FIELD IS NON ZERO
0470 6214 RDF
0471 7640 SEA CLA
0472 4454 ERROR /THE DATA FIELD IS NON ZERO,
0473 4455 LOOP /LOOP ON TEST IF SR = 1000

```

```

/*****
/TEST 4= CHECKS THAT AN IOT WILL TRAP OUT IN USER MODE AND NOT
/AFTER A USER INTERRUPT, THE USER INTERRUPT IS CHECKED TO BE
/CLEANED BY CAF, RIB AND GTF ARE ISSUED AND CHECKED,
/*****

```

```

0474 4456 TEST4, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0475 6007 CAF /CLEAN ALL FLAGS
0476 6001 IOV /TURN THE INTERRUPT ON
0477 6274 SUP /SET THE USER BUFFER FLIP=FLOP
0500 5301 JMF /TRANSFER USER BUFFER TO THE USER FIELD F/F
0501 6001 IOV /SHOULD TRAP HERE
0502 5302 JMF /THE IOT FAILED TO TRAP
0503 6294 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
0504 5304 JMF /USER INTERRUPT F/F FAILED TO SET ON SINT FAILED
0505 6007 CAF /CLEAN USER INTERRUPT WITH INITIALIZE
0506 6294 SINT /SKIP ON USER INTERRUPT
0507 7410 SKP
0510 5310 JMF /CAF FAILED TO CLEAN USER INTERRUPT,
0511 6001 IOV /TURN THE INTERRUPT ON
0512 5313 JMF /CHECK THAT THE INTERRUPT CLEARED UP F/F
0513 6001 IOV /IOT SHOULD NOT TRAP HERE
0514 7410 SKP
0515 5315 JMF /ION TRAPPED,
0516 6234 RIB /HEAD THE INTERRUPT BUFFER
0517 1113 TAD M100
0520 7640 SEA CLA
0521 4454 ERROR /USER FLAG NOT SET OR OTHER BITS SET
0522 7340 CLA CLL CMA /SET THE AC TO ALL ONES
0523 6004 GTF /GET THE FLAGS
0524 1116 TAD M300
0525 7640 SEA CLA
0526 4454 ERROR /USER FLAG AND INT ENA NOT SET OR GTF FAILED
0527 4455 LOOP /LOOP ON TEST IF SR = 1000

```

```

/*****
/TEST 5= CHECKS THAT CUF WILL CLEAR THE USER MODE BY DOING IOV, SUP,
/IOV, JMF, IOT, THE IOT, SHOULD NOT TRAP, RIB AND GTF ARE
/*****

```

/ISSUED AND CHECKED,
/.....

```

0530 4456 TEST6, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0531 6007 CAP /CLEAN ALL FLAGS
0532 6001 IOV /TURN THE INTERRUPT ON
0533 6274 SUP /SET THE USER BUFFER F/F
0534 5335 JMP ,*1 /ENTER USER MODE
0535 7402 HLT /HLT FAILED TO TRAP
0536 5336 JMP /HLT FAILED TO TRAP
0537 6254 SINT /SKIP ON USER INTERRUPT
0540 4454 ERROR /USER INTERRUPT NOT SET
0541 6007 CAP /CLEAN ALL FLAGS
0542 6254 SINT /SKIP ON USER INTERRUPT F/F
0543 7410 SKP
0544 4454 ERROR /CAP FAILED TO CLEAN USER INTERRUPT
0545 6234 RIB /READ THE INTERRUPT BUFFER
0546 1113 TAD M100 /CHECK FOR THE USER FLAG
0547 7640 SEA CLA
0550 4454 ERROR /USER FLAG NOT SET OR OTHER BITS SET
0551 6001 IOV /TURN THE INTERRUPT BACK ON
0552 6274 SUP /SET USER FLAG
0553 6264 CUP /CLEAN USER FLAG
0554 7410 SKP
0555 5355 JMP /CUP TRAPPED BEFORE A JMP WAS ISSUED
0556 5357 JMP ,*1
0557 6001 IOV /ISSUE A IOT TO CHECK THAT PROGRAM DOESN'T TRAP.
0560 7410 SKP
0561 5361 JMP /CUP FAILED TO CLEAN USER BUFFER FLIP=FLOP
0562 6254 SINT /SKIP ON USER INTERRUPT SET
0563 7410 SKP
0564 4454 ERROR /SINT SKIPPED, USER INTERRUPT SHOULD NOT BE SET
0565 7340 CLA CLL CMA
0566 6004 GTF /GET THE FLAGS
0567 1116 TAD M300 /
0570 7640 SEA CLA /CHECK FOR INTERRUPT ENABLE + USER FLAG
0571 4454 ERROR /INTERRUPT ENABLE OR USER FLAG NOT SET
0572 6234 RIB /READ THE INTERRUPT BUFFER
0573 1113 TAD M100
0574 7640 SEA CLA
0575 4454 ERROR /USER FLAG NOT SET OR OTHER BITS SET
0576 4456 LOOP /LOOP ON TEST IF SR = 1000

```

/.....
/TEST 6 CHECKS THAT USER MODE IS NOT ENTERED UNTIL A JMS INSTRUCTION IS ISSUED BY DOING A /ION, SUP, IOT, OSR, LAS, JMS, HLT, INTERRUPT REQUEST AND LINK ARE CHECKED TO /BE SET AND CLEARED BY GTF.
/.....

```

0577 4456 TEST6, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0600 6007 CAP /CLEAN ALL FLAGS
0601 6001 IOV /TURN THE INTERRUPT ON
0602 6274 SUP /SET USER BUFFER F/F
0603 6001 IOV /ISSUE A IOT
0604 7410 SKP

```

```

0605 5205 JMP /ION TRAPPED, USER MODE NOT SET UNTIL A JMP, JMS
0606 7404 OSR /OR THE SWITCH REGISTER WITH AC
0607 7610 SKP CLA
0610 5210 JMP /OSR TRAPPED OR USER MODE SET
0611 7604 LAB /LOAD THE AC WITH THE SWITCH REGISTER
0612 7610 SKP CLA
0613 5213 JMP /LAS TRAPPED OR USER MODE SET
0614 4215 JMS ,*1 /SET USER BUFFER F/F
0615 7402 HLT/XXXX /THE PC OF THE JMS
0616 7402 HLT /SHOULD TRAP HERE - IF NOT USER FIELD F/F PROBABLY NOT SET
0617 5217 JMP /HLT FAILED TO TRAP
0620 6254 SINT /SKIP ON USER INTERRUPT F/F
0621 4454 ERROR /USER INTERRUPT F/F NOT SET
0622 6234 RIB /READ THE INTERRUPT BUFFER
0623 1113 TAD M100 /CHECK FOR USER FLAG
0624 7640 SEA CLA
0625 4454 ERROR /USER FLAG NOT SET OR OTHER FLAGS SET
0626 7340 CLA CLL CMA /SET THE AC TO ALL ONE'S
0627 6004 GTF /GET THE FLAGS
0630 1130 TAD M1100 /CHECK FOR INTERRUPT REQUEST AND USER FLAG
0631 7640 SEA CLA
0632 4454 ERROR /INTERRUPT REQUEST OR USER FLAG NOT SET
0633 6204 CINT /CLEAN USER INTERRUPT FLIP=FLOP
0634 7360 CLA CLL CML CMA /SET AC + LINK TO A 1
0635 6004 GTF
0636 1131 TAD M4100 /CHECK FOR LINK AND USER FLAG
0637 7640 SEA CLA
0640 4454 ERROR /SHOULD ONLY BE LINK AND USER FLAG SET
0641 7100 CLL /CLEAN THE LINK
0642 6004 GTF /GET THE FLAGS
0643 1113 TAD M100 /CHECK FOR USER FLAG
0644 7640 SEA CLA /IS IT SET?
0645 4454 ERROR /USER FLAG SHOULD BE ONLY FLAG SET,
0646 4456 LOOP /LOOP ON TEST IF SR = 1000

```

/.....
/TEST 7 CHECKS THAT THE USER FLAG IN THE SAVE FIELD CAN BE CLEARED, /THIS IS DONE BY LEAVING THE USER INTERRUPT F/F SET AFTER A TRAP AND /THEN TURNING THE INTERRUPT BACK ON.
/.....

```

0647 4456 TEST7, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0650 6007 CAP /CLEAN ALL FLAGS
0651 6001 IOV /TURN THE INTERRUPT ON
0652 6274 SUP /SET USER BUFFER FLIP=FLOP
0653 5254 JMP ,*1 /ENTER USER MODE
0654 7402 HLT /HLT FAILED TO TRAP
0655 5255 JMP /HLT FAILED TO TRAP
0656 6254 SINT /SKIP ON USER INTERRUPT
0657 4454 ERROR /USER INTERRUPT NOT SET
0660 7240 CLA CMA /SET THE AC TO ALL ONES
0661 6004 GTF /GET THE FLAGS
0662 1130 TAD M1100 /CHECK FOR USER FLAG AND INTERRUPT REQUEST
0663 7640 SEA CLA /IS IT THERE?
0664 4454 ERROR /SHOULD ONLY BE INT, REG, AND USER FLAG

```

```

0065 0001 ION /TURN THE INTERRUPT ON
0066 7000 NOP /SHOULD INTERRUPT HERE
0067 4494 ERROR /FAILED TO INTERRUPT
0070 7340 CLA CLL CMA /SET THE AD TO ALL ONE'S
0071 0004 GTF /GET THE FLAGS
0072 1117 TAD M1000 /CHECK FOR INTERRUPT REQUEST
0073 7640 SEA CLA
0074 4494 ERROR /SHOULD ONLY BE INTERRUPT REQUEST SET
0075 0204 CINT /CLEAN USER INTERRUPT REQUEST
0076 0294 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
0077 7410 SKP
0700 4494 ERROR /CINT FAILED TO CLEAR USER INT F/F
0701 7340 CLA CLL CMA
0702 0004 GTF
0703 7640 SEA CLA
0704 4494 ERROR /INTERRUPT REQUEST FAILED TO CLEAR
0705 4455 LOOP /LOOP ON TEST IF SR = 1000
    
```

.....
 /TESTS= CHECKS THAT RTF WILL RESET THE USER MODE AFTER A
 /USER INTERRUPT.


```

0706 4456 TESTS, SCQPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0707 0007 CAF /CLEAN ALL FLAGS
0710 0001 ION /TURN THE INTERRUPT ON
0711 0274 SUP /SET USER BUFFER FLIP=FLOP
0712 0313 JMP ,+1
0713 7402 HLT /HLT FAILED TO TRAP OR USER FIELD FAILED TO SET
0714 0314 JMP /HLT FAILED TO TRAP
0715 0254 SINT /SKIP ON USER INTERRUPT F/F
0716 4454 ERROR /USER INTERRUPT FAILED TO SET
0717 0204 CINT /CLEAN USER INTERRUPT FLIP=FLOP
0720 0294 SINT
0721 7410 SKP
0722 4454 ERROR /CINT FAILED TO CLEAR USER INTERRUPT
0723 0234 RIB /READ THE INTERRUPT BUFFER
0724 1113 TAD M1000 /CHECK FOR USER FLAG
0725 7640 SEA CLA
0726 4454 ERROR /USER FLAG NOT SET OR PICKED UP BITS
0727 7100 CLL
0730 1153 TAD K4100 /SET AC0 +5 TO A 1 TO SET LINK + USER BUFFER
0731 0005 RTF /RESTORE THE FLAGS = SET USER BUFFER F/F
0732 7610 SKP CLA
0733 0333 JMP /RTF SKIPPED
0734 0224 RIF /READ THE INSTRUCTION FIELD
0735 7640 SEA CLA /IS IT NON ZERO
0736 0336 JMP /RIF TRAPPED WITH OUT USER INT OR I,F, NON ZERO
0737 0214 ROP /READ THE DATA FIELD
0740 7640 SEA CLA
0741 0341 JMP /ROP TRAPPED WITH OUT USER INT OR D,F, IS NON-ZERO
0742 0343 JMP /SET USER FIELD F/F, USER MODE, AND TURN INT EMA ON
0743 7402 HLT /RTF FAILED TO SET USER BUFFER F/F OR ION NOT SET
0744 0344 JMP
0745 0254 SINT /HLT FAILED TO TRAP
    /SKIP ON USER INTERRUPT F/F
    
```

```

0746 4454 ERROR /USER INTERRUPT NOT SET
0747 0004 GTF /GET THE FLAGS
0750 1133 TAD M9100 /CHECK FOR LINK, INTERRUPT REQUEST AND USER FLAG
0751 7640 SEA CLA
0752 4454 ERROR /THE LINK, OR INTERRUPT REQUEST OR USER FLAG NOT SET
0753 7100 CLL /CLEAN THE LINK BUT LEAVE INTERRUPT REQUEST UP
0754 0001 ION /TURN THE INTERRUPT ON
0755 0356 JMP ,+1 /SHOULD INTERRUPT AT TP4
0756 4454 ERROR /PROGRAM FAILED TO INTERRUPT WITH INT REQUEST SET
0757 0004 GTF /GET THE FLAGS
0760 1117 TAD M1000 /CHECK FOR INTERRUPT REQUEST
0761 7640 SEA CLA /IS IT THE ONLY BIT SET
0762 4454 ERROR /NO, OTHER BITS SET RESIDES INT REG OR INT REQ NOT SET
0763 0254 SINT /SKIP ON USER INTERRUPT F/F
0764 4454 ERROR /USER INTERRUPT NOT SET
0765 0204 CINT /CLEAN USER INTERRUPT F/F
0766 0254 SINT
0767 7610 SKP CLA
0770 4454 ERROR /CINT FAILED TO CLEAR USER INTERRUPT F/F
0771 7340 CLA CLL CMA /SET THE AD TO ALL ONES
0772 0004 GTF /GET THE FLAGS
0773 7640 SEA CLA /SHOULD BE ALL ZEROS
0774 4454 ERROR /THE SAVE FIELD OR STATUS IS NON-ZERO
0775 4455 LOOP /LOOP ON TEST IF SR = 1000
    
```

.....
 /TESTS= CHECKS THAT RMF WILL RESET THE USER MODE AFTER A USER
 /INTERRUPT.


```

0776 4456 TESTS, SCQPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
0777 7000 NOP ///////////////////////////////////////////////////
1000 0007 CAF /CLEAN ALL FLAGS
1001 0001 ION /TURN THE INTERRUPT ON
1002 0274 SUP /SET USER BUFFER FLIP=FLOP
1003 0204 JMP ,+1 /GO INTO USER MODE
1004 7402 HLT /HLT FAILED TO TRAP OR NOT IN USER MODE
1005 0205 JMP /HLT FAILED TO TRAP
1006 0294 SINT /SKIP ON USER INTERRUPT
1007 4454 ERROR /SINT FAILED OR USER INTERRUPT NOT SET
1010 0204 CINT /CLEAN USER INTERRUPT FLIP=FLOP
1011 0294 SINT /SKIP ON USER INTERRUPT
1012 7410 SKP
1013 4454 ERROR /CINT FAILED TO CLEAR USER INTERRUPT
1014 0234 RIB /READ THE INTERRUPT BUFFER
1015 1113 TAD M1000
1016 7640 SEA CLA
1017 4454 ERROR /USER FLAG NOT SET OR OTHER BITS SET
1020 0001 ION /TURN THE INTERRUPT ON
1021 0244 RMF /RESTORE IB, DP AND UB
1022 7610 SKP CLA
1023 0223 JMP /RMF SKIPPED
1024 0225 JMP ,+1 /ENTER USER MODE
1025 7402 HLT /RMF + JMP FAILED TO SET USER FIELD OR RMF FAILED
1026 0226 JMP /HLT FAILED TO TRAP
    
```

```

1027 6254 SINT /SKIP ON USER INTERRUPT
1030 4454 ERROR /USER INTERRUPT NOT SET
1031 7100 CLL
1032 6004 GTF /GET THE FLAGS
1033 1130 TAD M1100 /CHECK FOR INTERRUPT REQUEST AND USER FLAG
1034 7640 SEA CLA /WHERE THEY SET
1035 4454 ERROR /NO, INT REQUEST OR USER FLAG NOT SET OR RMF
/SET OTHER BITS IN THE IF AND OF
/TURN THE INTERRUPT BACK ON
/INTERRUPT WITH INTERRUPT REQUEST SET
/PROGRAM FAILED TO INTERRUPT
/HEAD THE INTERRUPT BUFFER
1036 6001 ION
1037 5240 JMP ,*1
1040 4454 ERROR /USER FLAG NOT CLEARED ON INTERRUPT
1041 6234 RIB
1042 7640 SEA CLA /CHECK USER INTERRUPT TO BE SET
1043 4454 ERROR /USED INTERRUPT GOT CLEARED
1044 6254 SINT /CLEAN USER INTERRUPT
1045 4454 ERROR /SKIP ON USER INTERRUPT
1046 6204 CINT
1047 6254 SINT
1050 7410 SKP
1051 4454 ERROR /USER INTERRUPT SET
1052 4455 LOOP /LOOP ON TEST IF SR = 1000

```

```

/*****
/TEST 10 = CHECKS THAT USER MODE AND LINK AND ION CAN BE SET BY THE AC AND
/THE RTF INSTRUCTION AND THAT IT CAN BE CLEAR BY RTF,
/*****

```

```

1053 4456 TEST10, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
1054 6007 CAF /CLEAR ALL FLAGS
1055 1153 TAD K4100 /SET THE LINK AND USER BIT INTO THE AC
1056 6005 RTF /RESTORE THE FLAGS
1057 7620 SNL CLA /CHECK THE LINK
1060 7402 HLT /LINK NOT SET BY RTF
1061 6000 SKON /SKIP IF INTERRUPT ON AND TURN OFF
1062 7402 HLT /RTF FAILED TO SET INTERRUPT ENABLE
1063 6000 SKON /SKIP IF INTERRUPT ON AND TURN OFF
1064 7410 SKP
1065 7402 HLT /SKON FAILED TO CLEAR INTERRUPT ENABLE
1066 6001 ION /TURN THE INTERRUPT ON
1067 5270 JMP ,*1 /ENTER USER MODE
1070 7402 HLT /RTF FAILED TO SET U,B OR JMP FAILED TO LOAD I,F,
1071 5271 JMP /HLT FAILED TO TRAP
1072 6254 SINT /SKIP ON USER INTERRUPT
1073 4454 ERROR /USER INTERRUPT NOT SET
1074 6004 GTF /GET THE FLAGS
1075 1133 TAD M9100 /CHECK LINK, INTERRUPT REQUEST AND USER FLAG
1076 7640 SEA CLA
1077 4454 ERROR /LINK, INT REQ OR USER FLAG NOT SET
1100 7300 CLA CLL /LEAVE INTERRUPT REQUEST SET
1101 6005 RTF /RESTORE THE FLAGS TO 2
1102 5303 JMP ,*1 /SHOULD INTERRUPT
1103 4454 ERROR /FAILED TO INTERRUPT
1104 6254 SINT /SKIP ON USER INTERRUPT
1105 4454 ERROR /USER INTERRUPT GOT CLEARED
1106 6204 CINT /CLEAN USER INTERRUPT

```

```

1107 6234 RIB /HEAD THE INTERRUPT BUFFER
1110 7640 SEA CLA
1111 4454 ERROR /THE SAVE FIELDS ARE NON ZERO
1112 6004 GTF /GET THE FLAGS
1113 7640 SEA CLA
1114 4454 ERROR /THE SAVE FIELDS ARE NON ZERO
1115 4455 LOOP /LOOP ON TEST IF SR = 1000

```

```

/*****
/TEST 11 = USING THE USER INTERRUPT FLIP=FLOP AND INTERRUPT ENABLE
/THE IF REGISTER CAN BE INDIRECTLY CHECKED TO SET BY CHECKING THE
/SAVE FIELD REGISTER AFTER A INTERRUPT, THE I,F IS CHECKED NOT TO CHANGE
/UNTIL A JMP OR JMS IS ISSUED, THE INT INHIBIT F/F IS CHECKED NOT
/TO CLEAR BEFORE A JMP OR JMS IS ISSUED,
/*****

```

```

1116 4456 TEST11, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
1117 6007 CAF /CLEAR ALL FLAGS
1120 6001 ION /TURN THE INTERRUPT ON
1121 6274 SUF /SET USER BUFFER F/F
1122 5323 JMP ,*1 /ENTER USER MODE
1123 7402 HLT /FAILED TO ENTER USER MODE
1124 5324 JMP /HLT FAILED TO TRAP IN USER MODE
1125 6254 SINT /SKIP ON USER INTERRUPT
1126 4454 ERROR /USER INTERRUPT FLIP=FLOP NOT SET
1127 6004 GTF /GET THE FLAGS
1130 1130 TAD M1100 /CHECK FOR INTERRUPT REQUEST AND USER FLAG
1131 7640 SEA CLA
1132 4454 ERROR /USER FLAG OR INT REQUEST NOT SET
1133 6234 RIB /HEAD THE INTERRUPT BUFFER
1134 1113 TAD M100
1135 7640 SEA CLA
1136 4454 ERROR /USER FLAG GOT CLEARED
1137 6202 CIP /CHANGE INSTRUCTION FIELD TO FIELD 0
1140 7300 CLA CLL /CLEAR THE LINK
1141 6001 ION /TURN THE INTERRUPT ON
1142 6224 RTF /HEAD THE INSTRUCTION FIELD
1143 7440 SEA /IS IT ZERO
1144 7402 HLT /THE IF IS NON ZERO OR INTERRUPTED
1145 5340 JMP ,*1 /CLEAR INTERRUPT INHIBIT
1146 4454 ERROR /PROGRAM FAILED TO INTERRUPT
1147 6004 GTF /GET THE FLAGS
1150 1117 TAD M1000 /CHECK FOR USER INTERRUPT REQUEST
1151 7640 SEA CLA
1152 4454 ERROR /INT REG NOT SET OR SAVE FIELD NON ZERO
1153 6234 RIB /HEAD THE INTERRUPT BUFFER
1154 7640 SEA CLA /IS THE SAVE FIELD 0?
1155 4454 ERROR /NO, SAVE FIELD OR USER FIELD NON ZERO
1156 7240 TST11B, CLA CMA /SET A LOCATION TO ALL ONE'S TO CHECK THAT
1157 3366 DCA CUMS01 /THE JMS TO FIELD 7 DIDN'T JMS TO FIELD 0
1160 6272 CIP /CHANGE INSTRUCTION FIELD TO FIELD 7
1161 6001 ION /SET INTERRUPT ENABLE
1162 6224 RTF /HEAD THE INSTRUCTION FIELD
1163 7440 SEA /IS IT STILL ZERO
1164 7402 HLT /THE IF IS NON ZERO OR IT INTERRUPTED

```

1165	4366		JMS	,*1	/CLEAN INTERRUPT INHIBIT
1166	7402	CJMS01,	HLT		/THIS LOCATION PRESET TO 1'S SHOULDN'T CHANGE
1167	4454		ERRON		/PRUGHAM FAILED TO INTERRUPT
1170	7360		CLA CLL CML CMA		/SET AC AND LINK TO ALL ONES
1171	6004		GTF		/GET THE FLAGS
1172	1132		TAJ	M5000	/CHECK FOR LINK, USER INTERRUPT REQUEST,
1173	1111		TAJ	M70	/AND SAVE FIELD REGISTER OF 70
1174	7640		SEA CLA		
1175	4454		ERRON		/GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1176	6234		RIB		/READ THE INTERRUPT BUFFER
1177	1111		TAJ	M70	/IN THE SF SET TO I,S,F, 7 ONLY?
1200	7640		SEA CLA		
1201	4454		ERRON		/SAVE FIELD IS NOT EQUAL TO FIELD 7
1202	2777,		ISE	CJMS01	/CHECK THAT THE JMS DIDN'T GO TO FIELD 0
1203	4454		ERRON		/THE JMS TO FIELD 7 WENT TO FIELD 0
1204	7240	TST110,	CLA CMA		/SET A LOCATION TO ALL ONE'S TO CHECK THAT A
1205	3210		DCA	CJMS02	/JMS TO FIELD 5 DIDN'T CHANGE FIELD 0
1206	6234		SINT		/SKIP ON USER INTERRUPT REQUEST
1207	4454		ERRON		/USER INTERRUPT F/F GOT CLEARED
1210	6252		CIF	50	/CHANGE TO INSTRUCTION FIELD 5
1211	6001		IOV		/SET INTERRUPT ENABLE
1212	6224		RIF		/READ THE INSTRUCTION FIELD
1213	7440		SEA		/IS IT STILL ZERO
1214	7402		HLT		/THE IF IS NON ZERO OR IT INTERRUPTED
1215	4210		JMS	,*1	/CLEAN INTERRUPT INHIBIT AND INTERRUPT
1216	7402	CJMS02,	HLT		/THIS LOCATION PRESET TO 1'S SHOULDN'T CHANGE
1217	4454		ERRON		/PRUGHAM FAILED TO INTERRUPT
1220	7340		CLA CLL CMA		/SET THE AC TO ALL ONES
1221	6004		GTF		/GET THE FLAGS
1222	1117		TAJ	M1000	/CHECK FOR USER INTERRUPT REQUEST AND SAVE
1223	1103		TAJ	M50	/FIELD REGISTER OF 50
1224	7640		SEA CLA		
1225	4454		ERRON		/GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1226	6234		RIB		/READ THE INTERRUPT BUFFER
1227	1103		TAJ	M50	/CHECK THE INTERRUPT BUFFER FOR ISF 50
1230	7640		SEA CLA		
1231	4454		ERRON		/SAVE FIELD IS NOT EQUAL TO I,F, 5
1232	2210		ISE	CJMS02	/CHECK THAT JMS DIDN'T GO TO FIELD 0
1233	4454		ERRON		/THE JMS TO I,F,S, WENT TO FIELD 0
1234	7240	TST110,	CLA CMA		/SET A LOCATION TO ALL ONE'S TO CHECK THAT A JMS
1235	3244		DCA	CJMS03	/TO FIELD 2 DIDN'T CHANGE FIELD 0
1236	6222		CIF	20	/CHANGE INSTRUCTION FIELD TO FIELD 2
1237	6001		IOV		/SET INTERRUPT ENABLE
1240	6224		RIF		/READ THE INSTRUCTION FIELD
1241	7440		SEA		/IS IT STILL EQUAL TO ZERO
1242	7402		HLT		/THE IF IS NON ZERO OR IT INTERRUPTED
1243	4244		JMS	,*1	/CLEAN INTERRUPT INHIBIT AND INTERRUPT
1244	7402	CJMS03,	HLT		/THIS LOCATION PRESET TO 1'S SHOULDN'T CHANGE
1245	4454		ERRON		/PRUGHAM FAILED TO INTERRUPT
1246	7360		CLA CLL CML CMA		/SET THE AC AND LINK TO 1'S
1247	6004		GTF		/GET THE FLAGS
1250	1132		TAJ	M5000	/CHECK FOR LINK AND USER INTERRUPT REQUEST
1251	1072		TAJ	M20	/AND SAVE FIELD REGISTER OF 20
1252	7640		SEA CLA		
1253	4454		ERRON		/GTF FAILED OR READ SOMETHING OTHER THAN ABOVE

1254	6234		RIB		/READ THE INTERRUPT BUFFER
1255	1072		TAJ	M20	
1256	7640		SEA CLA		/DOES THE INTERRUPT BUFFER CONTAIN 20
1257	4454		ERRON		/NO, ERROR SAVE FIELD IS NOT EQUAL TO 20
1260	2244		ISE	CJMS03	/CHECK THAT JMS DIDN'T GO TO FIELD 0
1261	4454		ERRON		/THE JMS TO FIELD 2 WENT TO FIELD 0
1262	7240	TST110,	CLA CMA		/SET A LOCATION TO ALL ONE'S TO CHECK THAT THE
1263	3272		DCA	CJMS04	/JMS TO FIELD 1 DIDN'T JMS TO FIELD 0
1264	6212		CIF	10	/CHANGE INSTRUCTION FIELD TO FIELD 1,
1265	6001		IOV		/TURN THE INTERRUPT ON
1266	6224		RIF		/READ THE INSTRUCTION FIELD
1267	7440		SEA		/IS IT STILL ZERO
1270	7402		HLT		/THE IF IS NON ZERO OR IT INTERRUPTED
1271	4272		JMS	,*1	/CLEAN INTERRUPT INHIBIT AND INTERRUPT
1272	7402	CJMS04,	HLT		/THIS LOCATION PRESET TO ALL ONE'S SHOULDN'T CHANGE
1273	4454		ERRON		/PRUGHAM FAILED TO INTERRUPT
1274	7340		CLA CLL CMA		/SET THE AC TO ALL ONE'S
1275	6004		GTF		/GET THE FLAGS
1276	1117		TAJ	M1000	/CHECK FOR USER INTERRUPT REQUEST AND
1277	1067		TAJ	M10	/SAVE FIELD OF 10
1300	7640		SEA CLA		
1301	4454		ERRON		/GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1302	6234		RIB		/READ THE INTERRUPT BUFFER
1303	1067		TAJ	M10	
1304	7640		SEA CLA		
1305	4454		ERRON		/SAVE FIELD IS NOT EQUAL TO FIELD 10
1306	2272		ISE	CJMS04	/CHECK THAT THE JMS DIDN'T GO TO FIELD 0
1307	4454		ERRON		/THE JMS TO FIELD 1 WENT TO FIELD 0
1310	7240	TST110,	CLA CMA		/SET A LOCATION TO ALL ONES TO CHECK THAT THE
1311	3320		DCA	CJMS05	/JMS TO FIELD 8 DIDN'T JMS TO FIELD 0
1312	6262		CIF	60	/CHANGE INSTRUCTION FIELD TO FIELD 6
1313	6001		IOV		/TURN THE INTERRUPT ON
1314	6224		RIF		/READ THE INSTRUCTION FIELD
1315	7440		SEA		/IS IT STILL ZERO
1316	7402		HLT		/THE IF IS NON ZERO OR IT INTERRUPTED
1317	4320		JMS	,*1	/CLEAN INTERRUPT INHIBIT AND INTERRUPT
1320	7402	CJMS05,	HLT		/THIS LOCATION SET TO ALL ONE'S, IT SHOULDN'T CHANGE
1321	4454		ERRON		/PRUGHAM FAILED TO INTERRUPT
1322	7360		CLA CLL CML CMA		/SET THE AC AND LINK TO ALL ONE'S
1323	6004		GTF		/GET THE FLAG
1324	1132		TAJ	M5000	/CHECK FOR LINK, USER INTERRUPT REQUEST
1325	1106		TAJ	M60	/AND SAVE FIELD OF 60
1326	7640		SEA CLA		
1327	4454		ERRON		/GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1330	6234		RIB		/READ THE INTERRUPT BUFFER
1331	1106		TAJ	M60	
1332	7640		SEA CLA		
1333	4454		ERRON		/SAVE FIELD IS NOT EQUAL TO FIELD 60
1334	2320		ISE	CJMS05	/CHECK THAT THE JMS DIDN'T GO TO FIELD 0
1335	4454		ERRON		/THE JMS TO FIELD 6 WENT TO FIELD 0
1336	7240	TST110,	CLA CMA		/SET A LOCATION TO ALL 1'S TO CHECK THAT THE
1337	3346		DCA	CJMS06	/JMS TO FIELD 3 DIDN'T JMS TO FIELD 0
1340	6232		CIF	30	/CHANGE INSTRUCTION FIELD TO FIELD 3
1341	6001		IOV		/TURN THE INTERRUPT ON
1342	6224		RIF		/READ THE INSTRUCTION FIELD

1343	7440	SEA		/IS THE IF STILL ZERO
1344	7402	HLT		/THE IF IS NON ZERO OR IT INTERRUPTED
1345	4346	JMS	,+1	/CLEAR INTERRUPT INHIBIT AND INTERRUPT
1346	7402	CJMS00,	HLT	/THIS LOCATION PRESET TO ALL ONES, IT SHOULDN'T CHANGE
1347	4454	ERRDM		/PROGRAM FAILED TO INTERRUPT
1350	7340	CLA CLL CMA		/SET THE AC TO ALL ONE'S
1351	6004	GTF		/GET THE FLAGS
1352	1117	TAJ	M1000	/CHECK FOR USER INTERRUPT REQUEST AND
1353	1075	TAJ	M30	/SAVE FIELD OF 30
1354	7640	SEA CLA		
1355	4454	ERRDM		/GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1356	6234	RIB		/READ THE INTERRUPT BUFFER
1357	1075	TAJ	M30	
1360	7640	SEA CLA		
1361	4454	ERRDM		/SAVE FIELD NOT EQUAL TO FIELD 3
1362	2346	ISE	CJMS06	
1363	4454	ERRDM		/JMS TO FIELD 3 WENT TO FIELD 0
1364	5776	JMP	TST11H	/GO TO NEXT SECTION
1376	1400			
1377	1166			
1400	7240	TST11H,	PAGE	
1401	3210	CLA CMA		/SET A LOCATION TO ALL ONES TO CHECK
1402	6242	OCA	CJMS07	/THAT A JMS TO FIELD 4 DIDN'T JMS TO FIELD 0
1403	6001	CIF	40	/CHANGE INSTRUCTION FIELD TO FIELD 4
1404	6224	ION		/SET INTERRUPT ENABLE
1405	7440	RIF		/READ THE INSTRUCTION FIELD
1406	7402	SEA		/IS THE IF STILL ZERO
1407	4210	HLT		/THE IF IS NON ZERO OR IT INTERRUPTED
1410	7402	JMS	,+1	
1411	4454	ERRDM		/THIS LOCATION PRESET TO ALL ONE'S
1412	7360	CLA CLL CML CMA		/PROGRAM FAILED TO INTERRUPT
1413	6004	GTF		/SET THE AC AND LINK TO 1'S
1414	1132	TAJ	M5000	/GET THE FLAGS
1415	1100	TAJ	M40	/CHECK FOR USER INTERRUPT REQUEST AND LINK
1416	7640	SEA CLA		/AND SAVE FIELD OF 40
1417	4454	ERRDM		/GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1420	6234	RIB		/READ THE INTERRUPT BUFFER
1421	1100	TAJ	M40	
1422	7640	SEA CLA		
1423	4454	ERRDM		/SAVE FIELD NOT EQUAL TO 40
1424	2210	ISE	CJMS07	
1425	4454	ERRDM		/JMS TO FIELD 4 WENT TO FIELD 0
1426	7340	TST11I,	CLA CLL CMA	/SETUP A LOCATION TO CHECK THAT A JMS TO
1427	3236	OCA	CJMS10	/FIELD 0 GETS EXECUTED
1430	6202	CIF	00	/CHANGE INSTRUCTION FIELD TO FIELD 00
1431	6001	ION		/TURN THE INTERRUPT ON
1432	6224	RIF		/READ THE INSTRUCTION FIELD
1433	7440	SEA		/IS THE IF STILL ZERO
1434	7402	HLT		/THE IF IS NON ZERO OR IT INTERRUPTED
1435	4236	JMS	,+1	/CLEAR INTERRUPT ENABLE AND INTERRUPT
1436	7402	HLT		/THIS LOCATION PREVIOUSLY SET TO 1'S
1437	4454	ERRDM		/PROGRAM FAILED TO INTERRUPT
1440	6004	GTF		/GET THE FLAGS

1441	1117	TAJ	M1000	/CHECK FOR INTERRUPT REQUEST AND
1442	7640	SEA CLA		/SAVE FIELD OF 0
1443	4454	ERRDM		/GTF FAILED OR READ SOMETHING OTHER THAN ABOVE
1444	6234	RIB		/READ THE INTERRUPT BUFFER
1445	7640	SEA CLA		
1446	4454	ERRDM		/SAVE FIELD NON ZERO OR RIB FAILED
1447	2236	ISE	CJMS10	/CHECK THAT THE JMS DID CHANGE LOCATION CJMS10
1450	7610	SKP	CLA	
1451	4454	ERRDM		/JMS TO FIELD 0 FAILED TO STORE ITS PC IN CJMS10
1452	6007	CAF		/CLEAR ALL FLAGS INCLUDING USER INTERRUPT
1453	6004	GTF		/GET THE FLAGS
1454	7640	SEA CLA		
1455	4454	ERRDM		/INIT FAILED TO CLEAR USER INTERRUPT F/F
1456	4455	LODP		/LOUP ON TEST IF SR = 1000
1457	5461	JMP	I PASEND	/END OF 1ST 1K SEGMENT
1600			PAGE	
1000	0000	ACTLIN,	0	
1001	1022	TAJ	OP2SEL	
1002	7700	SMA	CLA	/IS THE PROGRAM RUNNING ON ACT LINE?
1003	5600	JMP	I ACTLIN	/NO, RETURN
1004	1037	TAJ	FLDLIM	/GET THE FIELD LIMIT
1005	1111	TAJ	M70	
1006	7640	SEA	CLA	/IS THE FIELD LIMIT EQUAL TO FIELD 7?
1007	5600	JMP	I ACTLIN	/NO, RETURN TO TEST
1010	1040	TAJ	UPERLM	/GET THE UPPER ADDRESS LIMIT
1011	7001	IAC		/ADD 1 TO IT
1012	7640	SEA	CLA	/WAS IT 7777
1013	5600	JMP	I ACTLIN	/NO, RETURN
1014	7392	CLA CLL CMA RTR		/SET LAST ADDRESS = 5777
1015	3040	OCA	UPERLM	/SAVE IT
1016	5600	JMP	I ACTLIN	/RETURN TO PROGRAM
1017	1022	ENDPAS,	TAJ	/CHECK FOR ACT LINE
1020	7700	SMA	CLA	/IS THE PROGRAM RUNNING ON ACT LINE
1021	5230	JMP	ENDING	/NO GO CHECK FOR SR 3 TO HALT AT END OF A PASS
1022	2236	ISE	PROPAS	/CHECK 1/2 SECOND COUNT
1023	5230	JMP	ENDING	/NOT 1/2 SECOND YET
1024	1377	TAJ	(=144	/RESET THE COUNTER
1025	3236	OCA	PRGPAS	
1026	6272	CIF	70	/CHANGE INSTRUCTION FIELD TO 7
1027	4451	JMS	I GOODPS	/SIGNAL THE PROM
1030	4335	ENDING,	JMS	/CHECK SR 3 TO HALT ON A PROGRAM PASS
1031	7006	HLT		
1032	7004	RAL		
1033	7710	SPA	CLA	
1034	7402	HLT		/END OF A COMPLETE PROGRAM PASS
1035	5776	JMP	0200	/RESTART THE PROGRAM

4000
4100

4200
4300

4400
4500

4600
4700

5000
5100

5200
5300

5400
5500

5600
5700

6000
6100

6200
6300

6400
6500

6600
6700

7000
7100

7200
7300

7400
7500

7600
7700

ACLBAT	1754	K4100	0153	H7	0066	TSTL0P	1746
ACNLOK	1767	K6201	0045	H7M	0111	UPERLM	0040
ACTLTI	1800	K7	0134	H77	0112	WRKADD	0043
ADDQNT	0047	K78	0137	OP1SEL	0021	WRKFLD	0041
AUTHST	0052	K7877	0152	OP2IK1	0000	XBAT	0060
BADPHS	0050	K77	0140	OP2SEL	0022	XPWRFL	0057
BATEMT	1663	K7707	0150	PASENU	0001		
CAP	0007	K7757	0151	PC	1646		
CAL	0103	K7774	0147	POWFL	1637		
CDP	0201	L1VK	1645	PRGHAS	1636		
CDPCHK	0033	LOJHG2	0152	PRGHST	1647		
CHKCDF	0034	LOJHG3	0153	RUP	0214		
CHKINH	1722	LODP	4455	REDEMA	0195		
CIF	0202	M1	0062	RIB	0234		
CIFCDF	0203	M10	0067	RIF	0224		
CINT	0204	M100	0113	RK0E	0023		
CJMS01	1166	M1000	0117	RMF	0244		
CJMS02	1210	M1007	0120	RTF	0005		
CJMS03	1244	M1010	0121	SAVESE	0036		
CJMS04	1272	M1020	0122	SAVWFU	0046		
CJMS05	1320	M1034	0123	SBE	0101		
CJMS06	1346	M1043	0124	SCOPLP	4456		
CJMS07	1410	M1052	0125	SINT	0294		
CJMS10	1436	M1061	0126	SKON	0000		
CLREMA	0154	M1070	0127	SKPEMA	0106		
CLRMOD	0160	M11	0070	SPL	0102		
CLRSIM	0150	M1100	0130	SUF	0274		
CUF	0264	M120	0114	SWCHK	1735		
DATPAT	0042	M132	0115	SWITCH	0020		
DATHEC	0035	M16	0071	TEST	0053		
DEAD	1673	M2	0063	TEST1	0201		
ENDING	1630	M20	0072	TEST10	1093		
ENDPAS	1617	M22	0073	TEST11	1110		
ERLPSW	1730	M25	0074	TEST2	0343		
ERRUR	4454	M30	0075	TEST3	0432		
ERRURX	1704	M300	0116	TEST4	0474		
EXECUT	0164	M33	0076	TEST5	0530		
FLDLIM	0037	M34	0077	TEST6	0577		
GOODDB	1675	M4	0064	TEST7	0647		
GOODPS	0051	M40	0100	TEST8	0706		
GTF	0004	M4100	0131	TEST9	0776		
HGHLIM	0044	M43	0101	TESTAU	1654		
HLT	7402	M44	0102	TST11A	1137		
INTSER	0000	M5	0065	TST11B	1196		
K10	0130	M50	0103	TST11C	1204		
K125	0141	M5000	0132	TST11U	1234		
K152	0142	M5100	0133	TST11E	1262		
K1777	0145	M52	0104	TST11F	1310		
K200	0143	M55	0105	TST11G	1336		
K2000	0146	M50	0106	TST11H	1400		
K37	0136	M61	0107	TST11I	1426		
K400	0144	M60	0110	TST20N	0402		

ERRORS DETECTED: 0
LINKS GENERATED: 5
RUN-TIME: 18 SECONDS
3K CORE USED

/KMB=A OPTION TEST 2 MAINDEC=08-DJKMA=A=L 1K PART 2
/
/COPYRIGHT (C) 1974, DIGITAL EQUIPMENT CORPORATION
/
/PROGRAMMER: BRUCE HANSEN
/

////////////////////////////////////
/THE FOLLOWING LISTING WILL CORRESPOND TO THE PAPER TAPE LABELED MAINDEC=08-DJKMA=A=PM2,
/1K PART 2, THIS PAPER TAPE AND LISTING WILL BE THE SECOND OF FOUR 1K SEGMENTED
/PAPER TAPES AND LISTINGS FOR COMPUTERS WITH LESS THAN 4K OF MEMORY.
////////////////////////////////////

/KMB=A OPTION TEST 2 MAINDEC=08=DJKMA=A=L 1K PART 2
/COPYRIGHT 1974, DIGITAL EQUIPMENT CORP., MAYNARD, MASS., 01754
/POP=8A OPTION TEST 2 TESTS THE MEMORY EXTENTION/TIME SHARE CONTROL,
/POWER FAIL/AUTO RESTART, AND BOOTSTRAP LOADERS

6000 SKON=6000
6007 CAF=6007
7402 HLT=7402

/SWITCH REGISTER SETTINGS
/SR0=1 INHIBIT ERROR HALT
/SR1=1 LOOP ON ERROR
/SR2=1 LOOP ON TEST
/SR3=1 HALT AT COMPLETION OF A PROGRAM PASS

/MEMORY EXTENTION/TIME SHARE INSTRUCTIONS

6004 GTF=6004 /GET FLAGS, READS THE FOLLOWING MACHINE STATES
/INTO THE INDICATED BITS OF THE AC1
/AC0 LINE
/AC2 INTERRUPT REQUEST
/AC4 INTERRUPT ENABLE F/F
/AC5 USER FLAG
/AC6=11 SAVE FIELD REGISTER
6005 RTF=6005 /RESTORE THE FLAGS, RTF LOADS THE LINK FROM AC0,
/LOADS THE USER BUFFER F/F, INSTRUCTION BUFFER AND
/DATA FIELD WITH AC5, AC6=8, AC 9=11 AND INHIBITS
/PROCESSOR INTERRUPTS UNTIL NEXT JMP OR JMS INSTRUCTION,
/AT THE END OF THE JMP OR JMS, THE CONTENTS OF THE U,B, + I,B,
/ARE LOADED INTO USER FIELD F/F, AND THE I,F,, INTERRUPT ENABLE
/IS SET AND INTERRUPT INHIBIT AS CLEARED
6234 RIB=6234 /READ THE INTERRUPT BUFFER
6244 RIF=6244 /RESTORES MEMORY FLAGS
6204 CINT=6204 /CLEAN USER INTERRUPT FLIP=FLOP
6254 SINT=6254 /SKIP ON USER INTERRUPT FLIP=FLOP
6264 CUF=6264 /CLEAN USER BUFFER FLIP=FLOP
6274 SUF=6274 /SET USER BUFFER FLIP=FLOP (ENTER TIME SAME MODE)AND
/INHIBITS PROCESSOR INTERRUPTS UNTIL THE NEXT JMP OR
/JMS INSTRUCTION, AT THE END OF THE JMP OR JMS
/INSTRUCTION, THE USER BUFER IS LOADED INTO THE USER
/FIELD F/F,
6201 CDF=6201 /CHANGE DATA FIELD

6202 CIF=6202 /CHANGE INSTRUCTION FIELD
6214 RDF=6214 /READ THE DATA FIELD INTO AC BITS 6=8
6224 RIF=6224 /READ THE INSTRUCTION FIELD INTO AC BITS 6=8
6203 CIFCDF=6203 /PERFORMS THE CIF AND CDF FUNCTIONS

/POWER FAIL INSTRUCTIONS

6102 SPL=6102 /SKIP ON AC LOW FLIP=FLOP
6103 CAL=6103 /CLEAN AC LOW FLIP=FLOP
6101 SBE=6101 /SKIP ON BATTERY EMPTY FLIP=FLOP

/OPTION BOARD 2 SIMULATOR IOT'S

6150 CLRIM=6150 /CLEAN CONTROL REGISTERS
6152 LODHG2=6152 /LOAD CONTROL REGISTER 2
6153 LODHG3=6153 /LOAD CONTROL REGISTER 3
6154 CLREMA=6154 /CLEAN EMA CATCHER LOGIC
6155 REDEMA=6155 /READ EMA CATCHER REGISTER
6160 CLRMDU=6160 /CLEAN TEST MODULE LOGIC
6164 EXECUT=6164 /EXECUT AND CONTROL WORD 3 BIT 7 =1 ISSUE A POWER ON PULSE
/EXECUT AND CONTROL WORD 3 BIT 7 =0 ISSUE A SWITCH SW PULSE
6166 SKPEMA=6166 /SKPEMA AND CONTROL WORD 3 BIT 3 =1 EMA INTERRUPT AND SKIP ENABLE
/SKPEMA AND CONTROL WORD 3 BIT 3 =0 EMA INTERRUPT AND SKIP DISABLE

/OPTION BOARD 2 SIMULATOR CONTROL WORD 2 BIT ASSIGNMENTS

/BITS 0 = 1 NOT USED
/BITS 2 = 8 BOOT STRAP PROGRAM SELECT
/BITS 9 = 11 AUTO=RESTART ADDRESS SELECT

/OPTION BOARD 2 SIMULATOR CONTROL WORD 3 BIT ASSIGNMENTS

/BIT 0 TIME SHARE 0=ENABLED 1=DISABLED
/BIT 1 AC LOW (L) 1=PULLED LOW 0=FREE STATE
/BIT 2 BATT EMPTY 1=BATT EMPTY PULLED LOW 0=FREE STATE
/BIT 3 1=EMA INTERRUPT/SKIP ENABLE 0=EMA INTERRUPT SKIP DISABLE
/BITS 4 = 6 NOT USED
/BIT 7 1=POWER ON PULSE WITH EXECUT 0=SWITCH SW PULSE WITH EXECUT
/BIT 8 1=DISABLES BOOTSTRAP WHILE RUNNING 0=ENABLES BOOTSTRAP WHILE RUNNING
/BIT 9 = 11 AUTO=RESTART/BOOT STRAP ENABLE CODE

0000 *0

0000 0000 INTSER, 8 /JMS I AUTHST PLACED HERE FOR SIMULATOR AUTO RESTART
0001 3035 DCA DATREC
0002 6102 SPL /SKIP ON AC LOW
0003 7410 SKP
0004 5457 JMP I XPRFL /POWER GOING DOWN
0005 6101 SBE /SKIP ON BATTERY EMPTY

```

0006 7410 SKP
0007 5660 JMP I XBAT /GO HALT THE COMPUTER ,ITS ALL OVER
0010 0224 RIF /HEAD THE INSTRUCTION FIELD
0011 7640 SZA CLA
0012 4454 ERROR /RIF, IS NOT 0 AFTER A INTERRUPT
0013 0214 RDP /HEAD THE DATA FIELD
0014 7640 SZA CLA
0015 4454 ERROR /RIF, IS NOT 0 AFTER A INTERRUPT
0016 2000 ISZ INTSER /ADD 1 TO THE INTERRUPTED PC
0017 5400 JMP I INTSER /RETURN TO THE PROGRAM

0020 0020 *20
0020 0000 SWITCH, 0 /PSEUDO SWITCH REGISTER IF BIT 0=0 OF OP1SEL
0021 1000 OP1SEL, 1000
/BIT 0=0 USE LOC 20 AS A PSEUDO S,R,
/BIT 0=1 USE HARDWARE FRONT PANEL S,R,
/BIT 1=1 HAS 8A OPTION 1
/BIT 2=1 HAS 8A OPTION 2
/BIT 3=1 HAS 8A CPU SIMULATOR
/BIT 4=1 HAS 8A OPTION 1 + 2 TEST MODULE
/BIT 5=1 PROGRAM ON 8A XOR
/BIT 6=1 HAS PDP-8E TYPE CPU
/BITS 7=11 MEMORY SIZE = 01S = 1K, 17=32K,
/MEMORY SIZE CAN BE INCREASED IN 1K INCREMENTS
/BY ADDING A 1 TO THE NUMBER IN BITS 7=11,

0022 0000 OP2SEL, 0
/RRQE BOOT STRAP WILL LOAD INTO THE FOLLOWING LOCATIONS

0023 7402 RKB6, HLT /2000
0024 7402 HLT /0745
0025 7402 HLT /0023
0026 7402 HLT /7650
0027 7402 HLT /5024
0030 7402 HLT /0733
0031 7402 HLT /5031
0032 7402 HLT /TERMINATOR
0033 0000 CDFCHK, 0
0034 0033 CHKWDF, CDFCHK
0035 0000 DATHEQ, 0
0036 0000 SAV6SZ, 0
0037 0000 FLDLIM, 0
0040 0000 UPELIM, 0
0041 0000 WRKFLD, 0
0042 0000 DATPAT, 0
0043 0000 WRKADD, 0
0044 0000 HGHWIM, 0
0045 0201 K6201, 0201
0046 0000 SAV4FD, 0
0047 0000 ADDQNT, 0
0050 0520 BADPAS, 0520
0051 0500 GOODPS, 0500
0052 1647 AUTHST, PRGMYT
0053 0000 TEST, 0 /SCOPE LOOP AND TEST LOOP ADDRESS
    
```

```

0054 4454 ERROR# JMS I ,
1704 1704 ERRORX
0055 4455 LOOP# JMS I ,
1740 1740 TESTLOP
0056 4450 SCOPLP# JMS I ,
1654 1654 TESTAD

0057 1637 XPHWFL, POWFAL
0060 1663 XBAT, BATEMT
0061 1617 PAS6NU, ENDPAS
    
```

/CONSTANTS USED BY THE PROGRAM

```

0062 7777 M1, =1
0063 7776 M2, =2
0064 7774 M4, =4
0065 7773 M5, =5
0066 7771 M7, =7
0067 7770 M10, =10
0070 7767 M11, =11
0071 7762 M16, =16
0072 7760 M20, =20
0073 7756 M22, =22
0074 7753 M25, =25
0075 7750 M30, =30
0076 7745 M33, =33
0077 7744 M34, =34
0100 7740 M40, =40
0101 7735 M43, =43
0102 7734 M44, =44
0103 7730 M50, =50
0104 7720 M52, =52
0105 7723 M55, =55
0106 7720 M60, =60
0107 7717 M61, =61
0110 7712 M66, =66
0111 7710 M70, =70
0112 7701 M77, =77
0113 7700 M100, =100
0114 7655 M125, =125
0115 7620 M150, =150
0116 7500 M300, =300
0117 7000 M1000, =1000
0120 0771 M1007, =1007
0121 0762 M1010, =1010
0122 0753 M1020, =1020
0123 0744 M1040, =1040
0124 0735 M1043, =1043
0125 0720 M1052, =1052
0126 0717 M1061, =1061
0127 0710 M1070, =1070
0130 0700 M1100, =1100
0131 3700 M4100, =4100
    
```

```

0132 3000 M9000, =5000
0133 2700 M9100, =5100

0134 0007 K7, 7
0135 0010 K10, 10
0136 0037 K37, 37
0137 0070 K70, 70
0140 0077 K77, 77
0141 0125 K125, 125
0142 0152 K152, 152
0143 0200 K200, 200
0144 0400 K400, 400
0145 1777 K1777, 1777
0146 2000 K2000, 2000
0147 7774 K7774, 7774
0150 7707 K7707, 7707
0151 7757 K7757, 7757
0152 7677 K7677, 7677
0153 4100 K4100, 4100

0200 *200

```

```

.....
/TEST 12 = CHECKS THAT A CIF AND DCF WILL LOAD THE APPROPRIATE
/SAVE FIELD REGISTERS, A DCA INDIRECT IS CHECKED NOT TO CHANGE
/A LOCATION IN FIELD 0 WHEN THE DATA FIELD IS NON ZERO, A
/JMS 1 IS CHECKED NOT TO CHANGE A LOCATION IN FIELD ZERO WHEN
/THE INSTRUCTION FIELD IS NON ZERO;
.....

```

```

0200 4456 TEST12, SCOPLP /SETUP TEST AND SCOPE LOOPING ADDRESS
0201 6007 CAF /CLEAN ALL FLAGS
0202 6001 IOY /TURN THE INTERRUPT ON
0203 6274 SUP /SET USER BUFFER FLIP=FLOP
0204 5205 JMP ,*1 /ENTER TIME SHARE MODE
0205 7402 HLT /PROGRAM FAILED TO ENTER USER MODE
0206 5206 JMP /HLT FAILED TO TRAP
0207 6254 HINT /SKIP ON USER INTERRUPT
0210 4454 ERROR /SINT FAILED OR USER INTERRUPT NOT SET
0211 6004 GTF /GET THE FLAGS
0212 1130 TAD M1100 /CHECK FOR USER INTERRUPT AND USER FLAG
0213 7640 SEA CLA
0214 4454 ERROR /GTF HEAD SOMETHING DIFFERENT THAN ABOVE
0215 7340 TST12A, CLA CLL CMA /SET THE AC TO ALL ONES
0216 3033 DCA CDFCHK /STORE IT TO CHECK THAT THE DATA FIELD CHANGED
0217 7340 CLA CLL CMA /SET THE AC TO ALL ONES
0220 3227 DCA CKJMS1 /SAVE IT TO CHECK THE JMS TO ANOTHER FIELD
0221 6261 CDF 60 /CHANGE DATA FIELD TO FIELD 6
0222 6212 CIF 10 /CHANGE INSTRUCTION FIELD TO FIELD 1
0223 3434 DCA I CHKCDF /CHANGE EMA LINES TO CHECK THAT THE
/ DCA WENT TO ANOTHER FIELD THAN FIELD 0
/TURN THE INTERRUPT ON
0224 6001 IOY /CLEAN INTERRUPT INHIBIT AND INTERRUPT
0225 4626 JMS 1 ,*1
0226 6227 CKJMS1

```

```

0227 7402 CKJMS1, HLT /THIS LOCATION PRESET TO ONE'S TO CHECK JMS TO ANOTHER FIELD
0230 4454 ERROR /PROGRAM FAILED TO INTERRUPT
0231 6004 GTF /GET THE FLAGS
0232 1121 TAD M1016 /CHECK FOR INT REQ, ISF OF 12 AND DSF OF 6
0233 7640 SEA CLA /IN SAVE FIELD REGISTER
0234 4454 ERROR /SAVE FIELD NOT EQUAL TO ABOVE
0235 6234 RIB /HEAD THE INTERRUPT BUFFER
0236 1071 TAD M16 /CHECK FOR ISF OF 10 AND DSF OF 6
0237 7640 SEA CLA
0240 4454 ERROR /RIB FAILED OR SAVE FIELD NOT EQUAL TO 16
0241 2033 IS2 CDFCHK /CHECK THAT THE DCA I WENT TO ANOTHER FIELD
0242 4454 ERROR /DCA I WENT TO FIELD 0 INSTEAD OF FIELD 6
0243 2227 IS2 CKJMS1 /CHECK THAT JMS 1 WENT TO ANOTHER FIELD 6
0244 4454 ERROR /JMS 1 WENT TO FIELD 0 INSTEAD OF FIELD 1
0245 7340 TST12B, CLA CLL CMA /SET LOCATION CDFCHK AND CKJMS2 TO ONES
0246 3033 DCA CDFCHK /TO CHECK DCA I AND JMS 1 WENT TO
0247 7340 CLA CLL CMA /ANOTHER FIELD THAN FIELD 0
0250 3257 DCA CKJMS2
0251 6211 CDF 10 /CHANGE DATA FIELD TO FIELD 1
0252 6262 CIF 60 /CHANGE INSTRUCTION FIELD TO FIELD 6
0253 3434 DCA I CHKCDF /CHANGE EMA LINES TO FIELD 1
/ DCFCHK SHOULD NOT CHANGE IN FIELD 0
/TURN THE INTERRUPT ON
0254 6001 IOY /CLEAN INTERRUPT INHIBIT
0255 4656 JMS 1 ,*1 /INDIRECT ADDRESS
0256 6257 CKJMS2
0257 7402 CKJMS2, HLT /THIS LOCATION PRESET TO ONE'S TO CHECK JMS TO FIELD 6
0260 4454 ERROR /PROGRAM FAILED TO INTERRUPT
0261 7340 CLA CLL CMA /SET THE AC TO ALL ONES
0262 6004 GTF /GET THE FLAGS
0263 1126 TAD M1061 /CHECK FOR INT REQ, ISF OF 60 AND DSF OF 1
0264 7640 SEA CLA
0265 4454 ERROR /THE SAVE FIELD NOT EQUAL TO ABOVE
0266 6234 RIB /HEAD THE INTERRUPT BUFFER
0267 1107 TAD M61 /CHECK FOR I,S,F, OF 6 AND I,D,F, OF 1
0270 7640 SEA CLA
0271 4454 ERROR /THE SAVE FIELD NOT EQUAL TO ABOVE
0272 2033 IS2 CDFCHK /CHECK THAT DCA I WENT TO ANOTHER FIELD
0273 4454 ERROR /DCA I WENT TO FIELD 0 INSTEAD OF FIELD 1
0274 2257 IS2 CKJMS2 /CHECK THAT JMS 1 WENT TO ANOTHER FIELD
0275 4454 ERROR /JMS 1 WENT TO FIELD 0 INSTEAD OF FIELD 16,
0276 7340 TST12C, CLA CLL CMA /SET LOCATIONS CDFCHK AND CKJMS3 TO ONE'S
0277 3033 DCA CDFCHK /TO CHECK THAT DCA I AND JMS 1 WENT
0280 7340 CLA CLL CMA /TO ANOTHER FIELD THAN FIELD 0
0281 3310 DCA CKJMS3
0282 6232 CIF 30 /CHANGE INSTRUCTION FIELD TO FIELD 3
0283 6241 CDF 40 /CHANGE DATA FIELD TO FIELD 4
0284 3434 DCA I CHKCDF /CHANGE EMA LINES TO FIELD 4
0285 6001 IOY /TURN THE INTERRUPT ON
0286 4707 JMS 1 ,*1 /CLEAN INTERRUPT INHIBIT
0287 6310 CKJMS3 /INDIRECT ADDRESS
0290 7402 CKJMS3, HLT /THIS LOCATION PRESET TO ONES TO CHECK JMS TO FIELD 3
0310 4454 ERROR /PROGRAM FAILED TO INTERRUPT
0311 7340 CLA CLL CMA /SET THE AC TO ALL ONES
0312 6004 GTF /GET THE FLAGS
0314 1123 TAD M1034 /CHECK FOR INT REQ, ISF OF 3 AND DSF OF 4

```

0315	7640	SEA CLA		
0316	4494	ERROR		/THE SAVE FIELD REGISTER NOT EQUAL TO ABOVE
0317	6234	R13		/READ THE INTERRUPT BUFFER
0320	1077	TAD	M34	/CHECK FOR ISF OF 3 AND DSF OF 4
0321	7640	SEA CLA		
0322	4494	ERROR		/THE SAVE FIELD REGISTER NOT EQUAL TO ABOVE
0323	2033	ISE	CDPCHK	
0324	4494	ERROR		/DCA I WENT TO FIELD 0 INSTEAD OF FIELD 4
0325	2310	ISE	CKJMS3	
0326	4454	ERROR		/JMS I WENT TO FIELD 0 INSTEAD OF FIELD 3
0327	7340	TST12U, CLA CLL CMA		/SET LOCATIONS CDPCHK AND CKJMS4 TO ONES,
0330	3035	DCA	CDPCHK	/TO CHECK THAT DCA I OR JMS I TO ANOTHER
0331	7340	CLA CLL CMA		/FIELD DOESN'T GO TO FIELD 0
0332	3341	DCA	CKJMS4	
0333	6252	CIF	50	/CHANGE INSTRUCTION FIELD TO FIELD 5
0334	6221	COF	20	/CHANGE DATA FIELD TO FIELD 2
0335	3434	DCA I	CHKCDF	/CHANGE EMA LINES TO FIELD 2
0336	6001	IOV		/TURN THE INTERRUPT ON
0337	4740	JMS I	,+1	/CLEAN INTERRUPT INHIBIT
0340	0341	CKJMS4		/INDIRECT ADDRESS
0341	7402	HLT		/THIS LOCATION PRESET TO ONES TO CHECK JMS TO FIELD 5
0342	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
0343	7340	CLA CLL CMA		/SET THE AC TO ALL ONES
0344	6004	GTF		/GET THE FLAGS
0345	1125	TAD	M1092	/CHECK FOR INT, REQ,, ISF OF 5, AND DSF OF 2
0346	7640	SEA CLA		
0347	4494	ERROR		/THE SAVE FIELD REGISTER NOT EQUAL TO ABOVE
0350	6234	R13		/READ THE INTERRUPT BUFFER
0351	1104	TAD	M52	/CHECK FOR ISF OF 5 AND DSF OF 2
0352	7640	SEA CLA		
0353	4454	ERROR		/SAVE FIELD NOT EQUAL TO ABOVE
0354	2033	ISE	CDPCHK	
0355	4494	ERROR		/DCA I TO FIELD 2 WENT TO FIELD 0
0356	2341	ISE	CKJMS4	
0357	4454	ERROR		/JMS I TO FIELD 5 WENT TO FIELD 0
0360	5777	JMP	TST12E	
0377	0401			
0400	0400	PAGE		
0400	7000	NOP		
0401	7340	TST12E, CLA CLL CMA		/SETUP LOCATIONS CDPCHK AND CKJMS5 TO ONES
0402	3035	DCA	CDPCHK	/TO CHECK THAT DCA I OR JMP I TO ANOTHER
0403	7240	CLA CMA		/FIELD DOESN'T GO TO FIELD 0
0404	3215	DCA	CKJMS5	
0405	6253	COF	50	/CHANGE DATA FIELD TO FIELD 5
0406	6222	CIF	20	/CHANGE INSTRUCTION FIELD TO 2
0407	3434	DCA I	CHKCDF	/CHANGE EMA LINES TO 5 (DF ON)
0410	6001	IOV		/TURN INTERRUPT ENABLE ON
0411	4612	JMS I	,+1	/CLEAN INTERRUPT INHIBIT
0412	0413	CKJMS5		/INDIRECT ADDRESS
0413	7402	HLT		/THIS LOCATION PRESET TO ONES TO CHECK JMS TO FIELD 2
0414	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
0415	7340	CLA CLL CMA		/SET THE AC TO ALL ONES
0416	6004	GTF		/GET THE FLAGS

0417	1122	TAD	M1025	/CHECK FOR INT, REQ,, ISF#2 AND DSF#5
0420	7640	SEA CLA		
0421	4454	ERROR		/THE SAVE FIELD REGISTER NOT EQUAL TO ABOVE
0422	6234	R13		/READ THE INTERRUPT BUFFER
0423	1074	TAD	M25	/CHECK FOR ISF OF 2 AND DSF#5
0424	7640	SEA CLA		
0425	4454	ERROR		/SAVE FIELD REGISTER NOT EQUAL TO ABOVE
0426	2033	ISE	CDPCHK	
0427	4454	ERROR		/DCA I TO FIELD 5 WENT TO FIELD 0
0430	2213	ISE	CKJMS5	
0431	4454	ERROR		/JMS I TO FIELD 2 WENT TO FIELD 0
0432	7340	TST12F, CLA CLL CMA		/SET LOCATIONS CDPCHK AND CKJMS6 TO
0433	3035	DCA	CDPCHK	/ONES TO CHECK THAT DCA I AND JMS I
0434	7240	CLA CMA		/TO ANOTHER FIELD DOESN'T GO TO FIELD 0
0435	3244	DCA	CKJMS6	
0436	6251	COF	30	/CHANGE DATA FIELD TO FIELD 3
0437	6242	CIF	40	/CHANGE INSTRUCTION FIELD TO FIELD 4
0440	3434	DCA I	CHKCDF	/CHANGE EMA LINES TO 3
0441	6001	IOV		/TURN THE INTERRUPT ON
0442	4643	JMS I	,+1	/CLEAN INTERRUPT INHIBIT
0443	0444	CKJMS6		/INDIRECT ADDRESS
0444	7402	HLT		/THIS LOCATION PRESET TO ONES TO CHECK JMS TO FIELD 4
0445	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
0446	7340	CLA CLL CMA		/SET THE AC TO ALL ONES
0447	6004	GTF		/GET THE FLAGS
0450	1124	TAD	M1043	/CHECK FOR INT, REQ,, ISF OF 4 AND DSF OF 3,
0451	7640	SEA CLA		
0452	4454	ERROR		/SAVE FIELD NOT EQUAL TO ABOVE
0453	6234	R13		/READ THE INTERRUPT BUFFER
0454	1101	TAD	M43	/CHECK FOR ISF OF 4 AND DSF OF 3
0455	7640	SEA CLA		
0456	4454	ERROR		/SAVE FIELD NOT EQUAL TO ABOVE
0457	2033	ISE	CDPCHK	
0460	4454	ERROR		/DCA I WENT TO FIELD 0 INSTEAD OF FIELD 3
0461	2244	ISE	CKJMS6	
0462	4454	ERROR		/JMS I WENT TO FIELD 0 INSTEAD OF FIELD 4
0463	7340	TST12G, CLA CLL CMA		/SET CDPCHK AND CKJMS7 TO ONES TO
0464	3035	DCA	CDPCHK	/CHECK FOR DCA I TO ANOTHER FIELD AND A
0465	7240	CLA CMA		/JMS I TO ANOTHER FIELD
0466	3275	DCA	CKJMS7	
0467	6271	COF	70	/CHANGE DATA FIELD TO FIELD 7
0470	6202	CIF	00	/CHANGE INSTRUCTION FIELD TO FIELD 0
0471	3434	DCA I	CHKCDF	/CHANGE EMA LINES TO 7
0472	6001	IOV		/TURN INTERRUPT ON
0473	4674	JMS I	,+1	/CLEAN INTERRUPT INHIBIT
0474	0475	CKJMS7		/INDIRECT ADDRESS
0475	7402	HLT		/THIS LOCATION WAS SET TO ONE'S BUT SHOULD CHANGE
0476	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
0477	7340	CLA CLL CMA		
0500	6004	GTF		/GET THE FLAGS
0501	1120	TAD	M1007	/CHECK FOR INT, REQ,, ISF#0, DSF#7
0502	7640	SEA CLA		
0503	4454	ERROR		/SAVE FIELD NOT EQUAL TO ABOVE
0504	6234	R13		/READ THE INTERRUPT BUFFER
0505	1066	TAD	M7	/CHECK FOR DSF OF 7

```

0506 7640      SEA CLA
0507 4454      ERROR
0510 2033      ISE          CDFCHK
0511 4454      ERROR
0512 2275      ISE          CKJMS7
0513 7410      SKP
0514 4454      ERROR
0515 7340      TST12H, CLA CLL CMA
0516 3033      DCA          CDFCHK
0517 7340      CLA CLL CMA
0520 3327      DCA          CKJMS8
0521 6201      CDF          00
0522 4272      CIF          70
0523 3434      DCA I          CHKCDF
0524 6001      IOV
0525 4726      JMS I          ,*1
0526 0527      CKJMS8
0527 7402      CKJMS8, HLT
0530 4454      ERROR
0531 7340      CLA CLL CMA
0532 6004      GTF
0533 1127      TAD          M1070
0534 7640      SEA CLA
0535 4454      ERROR
0536 6234      R13
0537 1111      TAD          M70
0540 7640      SEA CLA
0541 4454      ERROR
0542 2033      ISE          CDFCHK
0543 7410      SKP
0544 4454      ERROR
0545 2327      ISE          CKJMS8
0546 4454      ERROR
0547 7240      TST12I, CLA CMA
0550 3033      DCA          CDFCHK
0551 7340      CLA CLL CMA
0552 3361      DCA          CKJMS9
0553 6201      CDF          00
0554 6202      CIF          00
0555 3434      DCA I          CHKCDF
0556 6001      IOV
0557 4760      JMS I          ,*1
0560 0561      CKJMS9
0561 7402      CKJMS9, HLT
0562 4454      ERROR
0563 7340      CLA CLL CMA
0564 6004      GTF
0565 1117      TAD          M1000
0566 7640      SEA CLA
0567 4454      ERROR
0570 6234      R13
0571 7640      SEA CLA
0572 4454      ERROR
0573 2033      ISE          CDFCHK
0574 7410      SKP

```

```

0575 4454      ERROR
0576 2361      ISE          CKJMS9
0577 7410      SKP
0600 4454      ERROR
0601 1150      TAD          K7707
0602 6224      RIF
0603 1137      TAD          K70
0604 7040      CMA
0605 7640      SEA CLA
0606 4454      ERROR
0607 6234      SINT
0610 4454      ERROR
0611 6007      CAF
0612 6234      SINT
0613 7410      SKP
0614 4454      ERROR
0615 4455      LOOP

/*****
/TEST 13 = CHECKS THE MICRO PROGRAM INSTRUCTIONS CDF CIF (62X3), A DCA I
/AND JMS ARE ALSO ISSUED TO CHECK THAT THESE INSTRUCTIONS DO NOT DESTROY
/LOCATIONS IN FIELD 0, THE USER INTERRUPT F/F IS USED TO CAUSE INTERRUPTS,
/*****/

0616 4456      TEST14, SCOPLP
0617 6007      CAF
0620 6202      CIF          00
0621 6201      CDF          00
0622 5223      JMP          ,*1
0623 6001      IOV
0624 6274      SUP
0625 5226      JMP          ,*1
0626 7402      HLT
0627 5227      JMP          ,
0630 6254      SINT
0631 4454      ERROR
0632 6234      R13
0633 1113      TAD          M100
0634 7640      SEA CLA
0635 4454      ERROR
0636 7240      TST13A, CLA CMA
0637 3033      DCA          CDFCHK
0640 7240      CLA CMA
0641 3246      DCA          JMSCK1
0642 6273      CDFCDF          70
0643 3434      DCA I          CHKCDF
0644 6001      IOV
0645 4246      JMS          JMSCK1
0646 7402      JMSCK1, HLT
0647 4454      ERROR
0650 6234      R13
0651 1112      TAD          M77
0652 7640      SEA CLA
0653 4454      ERROR
0654 2033      ISE          CDFCHK

```

0055	4454	ERROR		/DCA I TO FIELD 7 WENT TO FIELD 0
0056	2246	ISE	JMSCK1	
0057	4454	ERROR		/JMS TO FIELD 7 WENT TO FIELD 0
0060	0254	SINT		/SKIP ON USER INTERRUPT F/F
0061	4454	ERROR		/USER INTERRUPT F/F GOT CLEARED
0062	7240	TST130, CLA CMA		/SETUP TWO LOCATIONS TO CHECK THAT CIFCDF 20
0063	3033	DCA	CDPCHK	/WENT TO ANOTHER FIELD THAN FIELD 0
0064	7240	CLA CMA		
0065	3272	DCA	JMSCK2	
0066	0223	CIFCDF 20		/CHANGE INSTRUCTION FIELD AND DATA FIELD TO 2
0067	3434	DCA I	CHKCDF	/TRY TO CLEAR CDPCHK IN FIELD 2
0070	0001	ION		/SET INTERRUPT ENABLE
0071	4272	JMS	JMSCK2	/CLEAR INTERRUPT INHIBIT AND INTERRUPT
0072	7402	JMSCK2, HLT		/THIS LOCATIONS PRESET TO 7777
0073	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
0074	0234	RIB		/READ THE INTERRUPT BUFFER
0075	1073	TAJ	M22	/CHECK SAVE FIELD FOR ISF#2 * DSF#2
0076	7640	SEA CLA		
0077	4454	ERROR		/SAVE FIELD NOT EQUAL TO CIFCDF 20 FAILED
0700	2033	ISE	CDPCHK	
0701	4454	ERROR		/DCA I TO FIELD 2 WENT TO FIELD 0
0702	2272	ISE	JMSCK2	
0703	4454	ERROR		/JMS TO FIELD 2 WENT TO FIELD 0
0704	7240	TST130, CLA CMA		/SETUP TWO LOCATIONS TO CHECK THAT CIFCDF 50
0705	3033	DCA	CDPCHK	/WENT TO ANOTHER FIELD THAN FIELD 0
0706	7240	CLA CMA		
0707	3314	DCA	JMSCK3	
0710	0253	CIFCDF 50		/CHANGE INSTRUCTION FIELD AND DATA FIELD TO FIELD 5
0711	3434	DCA I	CHKCDF	/TRY TO CLEAR CDPCHK IN FIELD 5
0712	0001	ION		/SET INTERRUPT ENABLE
0713	4314	JMS	JMSCK3	/CLEAR INTERRUPT INHIBIT AND INTERRUPT
0714	7402	JMSCK3, HLT		/THIS LOCATIONS PRESET TO 7777
0715	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
0716	0234	RIB		/READ THE INTERRUPT BUFFER
0717	1105	TAJ	M55	/CHECK FOR ISF OF 5 AND DSF OF 5
0720	7640	SEA CLA		
0721	4454	ERROR		/SAVE FIELD NOT EQUAL TO ISF,DSF OF 5
0722	2033	ISE	CDPCHK	
0723	4454	ERROR		/DCA I TO FIELD 5 WENT TO FIELD 0
0724	2314	ISE	JMSCK3	
0725	4454	ERROR		/JMS TO FIELD 5 WENT TO FIELD 0
0726	0254	SINT		/SKIP ON USER INTERRUPT F/F
0727	4454	ERROR		/USER INTERRUPT F/F GOT CLEARED
0730	7240	TST130, CLA CMA		/SETUP TWO LOCATIONS TO ONE'S TO CHECK
0731	3033	DCA	CDPCHK	/THAT CIFCDF TO FIELD 4 WENT TO ANOTHER
0732	7240	CLA CMA		/FIELD THAN FIELD 0
0733	3340	DCA	JMSCK4	
0734	0243	CIFCDF 40		/CHANGE INSTRUCTION FIELD AND DATA FIELD TO FIELD 4
0735	3434	DCA I	CHKCDF	/TRY TO CLEAR CDPCHK IN FIELD 4
0736	0001	ION		/SET INTERRUPT ENABLE
0737	4340	JMS	JMSCK4	/CLEAR INTERRUPT INHIBIT AND INTERRUPT
0740	7402	JMSCK4, HLT		/THIS LOCATION PRESET TO ONE'S
0741	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
0742	0234	RIB		/READ THE INTERRUPT BUFFER
0743	1102	TAJ	M44	/CHECK ISF FOR 4 AND DSF FOR 4

0744	7640	SEA CLA		/SAVE FIELD NOT EQUAL TO 44
0745	4454	ERROR		
0746	2033	ISE	CDPCHK	
0747	4454	ERROR		/DCA I TO FIELD 4 WENT TO FIELD 0
0750	2340	ISE	JMSCK4	
0751	4454	ERROR		/JMS TO FIELD 4 WENT TO FIELD 0
0752	0254	SINT		/SKIP ON USER INTERRUPT F/F
0753	4454	ERROR		/USER INTERRUPT F/F GOT CLEARED
0754	7340	TST135, CLA CLL CMA		/SETUP TWO LOCATIONS TO CHECK THAT CIFCDF 30
0755	3033	DCA	CDPCHK	/WENT TO ANOTHER FIELD THAN FIELD 0
0756	7240	CLA CMA		
0757	3364	DCA	JMSCK5	
0760	0233	CIFCDF 30		/CHANGE INSTRUCTION AND DATA FIELD TO FIELD 3
0761	3434	DCA I	CHKCDF	/TRY TO CLEAR CDPCHK IN FIELD 3
0762	0001	ION		/SET INTERRUPT ENABLE
0763	4364	JMS	JMSCK5	/CLEAR INTERRUPT INHIBIT AND INTERRUPT
0764	7402	JMSCK5, HLT		/THIS LOCATION PRESET TO ONES
0765	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
0766	0234	RIB		/READ THE INTERRUPT BUFFER
0767	1076	TAJ	M33	/CHECK FOR ISF OF 3 AND DSF OF 3
0770	7640	SEA CLA		
0771	4454	ERROR		/SAVE FIELD NOT EQUAL TO ABOVE OR CIFCDF 30 FAILED
0772	2033	ISE	CDPCHK	
0773	4454	ERROR		/DCA I TO FIELD 3 WENT TO FIELD 0
0774	2364	ISE	JMSCK5	
0775	4454	ERROR		/JMS TO FIELD 3 WENT TO FIELD 0
0776	0254	SINT		/SKIP ON USER INTERRUPT F/F
0777	4454	ERROR		/USER INTERRUPT F/F GOT CLEARED
1000	7240	TST13F, CLA CMA		/SETUP TWO LOCATIONS TO CHECK THAT
1001	3033	DCA	CDPCHK	/CIFCDF 60 WENT TO ANOTHER FIELD
1002	7240	CLA CMA		/THEN FIELD ZERO
1003	3210	DCA	JMSCK6	
1004	0263	CIFCDF 60		/CHANGE INSTRUCTION AND DATA FIELD TO FIELD 6,
1005	3434	DCA I	CHKCDF	/TRY TO CLEAR CDPCHK IN FIELD 6
1006	0001	ION		/SET INTERRUPT ENABLE
1007	4210	JMS	JMSCK6	/CLEAR INTERRUPT INHIBIT AND INTERRUPT
1010	7402	JMSCK6, HLT		/THIS LOCATIONS PRESET TO ONES
1011	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
1012	0234	RIB		/READ THE INTERRUPT BUFFER
1013	1110	TAJ	M66	/CHECK FOR ISF OF 6 AND DSF OF 6
1014	7640	SEA CLA		
1015	4454	ERROR		/SAVE FIELD NOT EQUAL ABOVE OR CIFCDF 60 FAILED
1016	2033	ISE	CDPCHK	
1017	4454	ERROR		/DCA I TO FIELD 6 WENT TO FIELD 0
1020	2210	ISE	JMSCK6	
1021	4454	ERROR		/JMS TO FIELD 6 WENT TO FIELD 0
1022	0254	SINT		/SKIP ON USER INTERRUPT F/F
1023	4454	ERROR		/USER INTERRUPT GOT CLEARED
1024	7240	TST13G, CLA CMA		/SETUP 2 LOCATIONS TO CHECK THAT
1025	3033	DCA	CDPCHK	/CIFCDF 10 WENT TO ANOTHER FIELD
1026	7240	CLA CMA		/THAN FIELD 0
1027	3234	DCA	JMSCK7	
1030	0213	CIFCDF 10		/CHANGE INSTRUCTION FIELD + DATA FIELD TO FIELD 1
1031	3434	DCA I	CHKCDF	/TRY TO CLEAR CDPCHK IN FIELD 1
1032	0001	ION		/SET INTERRUPT ENABLE

```

1033 4234 JMS JMSCK7 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
1034 7402 HLT /THIS LOCATION PRESET TO ONES
1035 4494 JMSCK7, ERRM /PROGRAM FAILED TO INTERRUPT
1036 6234 RIB /READ THE INTERRUPT BUFFER
1037 1070 TAD H11 /CHECK FOR ISF OF 1 AND DSF OF 1
1040 7640 SEA CLA /SAVE FIELD NOT EQUAL ABOVE OR CIFCDF 10 FAILED
1041 4494 ERRM
1042 2033 ISR CDFCHK
1043 4494 ERRM /DCA I TO FIELD 1 WENT TO FIELD 0
1044 2234 ISR JMSCK7
1045 4494 ERRM /JMS TO FIELD 1 WENT TO FIELD 0
1046 6254 SINT /SKIP ON USER INTERRUPT F/F
1047 4494 ERRM /USER INTERRUPT F/F GOT CLEARED
1050 7240 TST13H, CLA GMA /SET UP 2 LOCATIONS TO CHECK THAT
1051 3033 DCA I CDFCHK /CIFCUP 00 WENT TO FIELD 0 INSTEAD
1052 7240 CLA GMA /UP ANOTHER FIELD
1053 3260 DCA JMSCK8
1054 6203 CIFCDF 00 /CHANGE INSTRUCTION AND DATA FIELD TO 0
1055 3434 DCA I CHKCDF /CLEAR CDFCHK IN FIELD 0
1056 6001 IOV /SET INTERRUPT ENABLE
1057 4260 JMS JMSCK8 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
1060 7402 JMSCK8, HLT /THIS LOCATIONS PRESET TO ONES
1061 4494 ERRM /PROGRAM FAILED TO INTERRUPT
1062 6234 RIB /READ THE INTERRUPT BUFFER
1063 7640 SEA CLA
1064 4494 ERRM /SAVE FIELD IS NOT EQUAL TO 0
1065 2033 ISR CDFCHK
1066 7410 SKP
1067 4454 ERRM /DCA I FAILED TO CLEAR CDFCHK IN FIELD 0
1070 2260 ISR JMSCK8
1071 7410 SKP
1072 4454 ERRM /JMS FAILED TO CHANGE JMSCK8 IN FIELD 0
1073 6204 CINT /CLEAR USER INTERRUPT F/F
1074 6254 SINT /SKIP ON USER INTERRUPT F/F
1075 7410 SKP
1076 4454 ERRM /CINT FAILED TO CLEAR USER INTERRUPT F/F
1077 4455 LOOP /LOOP ON TEST IF SR 2 = 1000

```

.....
 /TEST 14 = CHECKS THAT RTF CAN LOAD THE IF AND DF AND THAT RMF CAN
 /RELOAD IT,


```

1100 4456 TEST14, SCPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
1101 6007 CAF /CLEAR ALL FLAGS
1102 6001 IOV /SET INTERRUPT ENABLE
1103 6274 SUF /SET USER BUFFER
1104 5305 JMP ,+1 /LOAD THE UB INTO THE IF
1105 7402 HLT /HALT SHOULD TRAP
1106 5306 JMP /HLT FAILED TO TRAP
1107 6254 SINT /SKIP ON USER INTERRUPT
1110 4494 ERRM /USER INTERRUPT NOT SET
1111 6234 RIB /READ THE INTERRUPT BUFFER
1112 1113 TAD H100 /CHECK FOR USER FLAG
1113 7640 SEA CLA

```

```

1114 4454 ERRM /USER FLAG OR INT RED NOT SET
1115 1141 TST14A, TAD K125
1116 6005 RTF
1117 7300 CLA CLL /LOAD THE UB, IB, + DF WITH USER FLAG, IF OF 2 + DF OF 5
1120 6214 RDF /AND SET INTERRUPT ENABLE
1121 1103 TAD H50 /READ THE DATA FIELD TO CHECK THAT FIELD 5 GOT LOADED
1122 7640 SEA CLA
1123 7402 HLT
1124 5325 JMP ,+1 /RTF FAILED TO LOAD DATA FIELD TO 5
1125 4454 ERRM /ENTER USER MODE, CLEAR INT INHIBIT, AND INTERRUPT
1126 6254 SINT /FAILED TO INTERRUPT, RTF OR JMP FAILED
1127 4454 ERRM /SKIP ON USER INTERRUPT F/F
1130 6234 RIB /SINT FAILED OR USER INTERRUPT F/F CLEARED
1131 1114 TAD H125 /CHECK FOR USER FLAG, ISF OF 2 AND DSF OF 5
1132 7640 SEA CLA
1133 4454 ERRM /SAVE FIELD NOT EQUAL TO ABOVE
1134 6244 RMF /LOAD THE UB, IB, + DF FROM THE SAVE FIELD
1135 6214 RDF /READ THE DATA FIELD
1136 1103 TAD H50 /CHECK THAT RMF LOADED THE DF
1137 7640 SEA CLA
1140 4454 ERRM /RMF FAILED TO LOAD DF TO FIELD 5
1141 6001 IOV /SET INTERRUPT ENABLE
1142 5343 JMP ,+1 /LOAD THE IF, CLEAR INTERRUPT INHIBIT, ENTER USER MODE
1143 4454 ERRM /FAILED TO INTERRUPT OR RMF JMP FAILED
1144 6254 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
1145 4454 ERRM /USER INTERRUPT FLIP=FLOP NOT SET
1146 6234 RIB /READ THE INTERRUPT BUFFER
1147 1114 TAD H125 /CHECK FOR USER FLAG, ISF OF 2 AND DSF OF 5
1150 7640 SEA CLA
1151 4454 ERRM /RMF FAILED TO LOAD THE ABOVE
1152 1142 TAD K152
1153 6005 RTF /LOAD THE UB, IB, + DF WITH UF, ISF OF 5 AND DSF OF 2
1154 7300 CLA CLL /AND SET INTERRUPT ENABLE
1155 6214 RDF /READ THE DATA FIELD
1156 1072 TAD H20 /CHECK FOR A DF SET TO FIELD 2
1157 7640 SEA CLA
1158 7402 HLT
1159 5362 JMP ,+1 /RTF FAILED TO LOAD DF WITH 2
1160 4454 ERRM /ENTER USER MODE CLEAR INTERRUPT INHIBIT
1163 6254 SINT /FAILED TO INTERRUPT
1164 4454 ERRM /SKIP ON USER INTERRUPT
1165 6234 RIB /USER INTERRUPT NOT SET
1166 1119 TAD H152 /READ THE INTERRUPT BUFFER
1167 7640 SEA CLA /CHECK FOR USER FLAG, ISF OF 5 AND DSF OF 2
1170 4454 ERRM
1171 6244 RMF /SAVE FIELD NOT EQUAL TO ABOVE
1172 6214 RDF /RESTORE MEMORY FIELDS
1173 1072 TAD H20 /READ THE DATA FIELD
1174 7640 SEA CLA /CHECK THAT RMF LOADED DF TO FIELD 2
1175 4454 ERRM /RMF FAILED TO LOAD DF TO FIELD 2
1176 7000 NOP
1177 6001 IOV /SET INTERRUPT ENABLE
1180 9201 JMP ,+1 /CLEAR INTERRUPT INHIBIT, LOAD IF, ENTER USER MODE
1201 4454 ERRM /FAILED TO INTERRUPT
1202 6254 SINT /SKIP ON USER INTERRUPT

```

```

1203 4454 ERROR /USER INTERRUPT NOT SET
1204 6234 RIB /READ THE INTERRUPT BUFFER
1205 1115 TAJ M152 /CHECK SF FOR USER FLAG, ISF OF 5 AND DSF OF 2
1206 7640 SEA CLA
1207 4454 ERROR /RMF FAILED TO LOAD THE ABOVE
1210 6254 TST140, SINT /SKIP ON USER INTERRUPT FLIP=FLOP
1211 4454 ERROR /USER INTERRUPT FLIP=FLOP GOT CLEARED,
1212 1140 TAJ K77 /LOAD DATA FIELD AND IS TO FIELD 7
1213 8005 RTF /RESTORE THE FLAGS AND SET INTERRUPT ENABLE
1214 7300 CLA CLL
1215 6214 RUF /READ THE DATA FIELD
1216 1111 TAJ M70 /CHECK FOR DATA FIELD SET TO FIELD 7
1217 7640 SEA CLA
1220 7402 HLT /RTF FAILED TO SET DF TO FIELD 7
1221 5222 JMP ,*1 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
1222 4454 ERROR /PROGRAM FAILED TO INTERRUPT ON USER INTERRUPT
1223 6234 RIB /READ THE INTERRUPT BUFFER
1224 1112 TAJ M77 /CHECK FOR UF=0, ISF=7 AND DSF=7
1225 7640 SEA CLA
1226 4454 ERROR /SAVE FIELD NOT EQUAL TO ABOVE
1227 6254 SINT /SKIP ON USER INTERRUPT
1230 4454 ERROR /USER INTERRUPT GOT CLEARED
1231 6244 RMF /RESTORE MEMORY FIELDS
1232 6214 RUF /CHECK THAT RMF RESTORED THE DF
1233 1111 TAJ M70
1234 7640 SEA CLA
1235 4454 ERROR /RMF FAILED TO LOAD DF TO 7
1236 6224 RTF /CHECK INSTRUCTION FIELD TO BE SET 0
1237 7640 SEA CLA
1240 4454 ERROR /IF IS NON ZERO AFTER A RMF
1241 6001 IOV /SET INTERRUPT ENABLE
1242 5243 JMP ,*1 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
1243 4454 ERROR /PROGRAM FAILED TO INTERRUPT,
1244 6234 RIB /READ THE INTERRUPT BUFFER
1245 1112 TAJ M77 /CHECK FOR ISF AND DSF = TO 7
1246 7640 SEA CLA
1247 4454 ERROR /RMF FAILED TO RESTORE IF AND DF TO 7
1250 6254 TST140, SINT /SKIP ON USER INTERRUPT FLIP=FLOP
1251 4454 ERROR /USER INTERRUPT CLEARED
1252 6005 RTF /RESTORE THE FLAGS, SET IB*DF TO ZERO
1253 5254 JMP ,*1 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
1254 4454 ERROR /PROGRAM FAILED TO INTERRUPT
1255 6234 RIB /READ THE INTERRUPT BUFFER
1256 7640 SEA CLA
1257 4454 ERROR /THE ISF OR DSF IS NON ZERO
1260 6244 RMF /RESTORE MEMORY FIELDS
1261 6001 IOV /SET INTERRUPT ENABLE
1262 5263 JMP ,*1 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
1263 4454 ERROR /PROGRAM FAILED TO INTERRUPT
1264 6234 RIB /READ THE INTERRUPT BUFFER
1265 7640 SEA CLA
1266 4454 ERROR /RMF FAILED TO RELOAD IF AND DF TO ZERO
1267 6204 CINT /CLEAR USER INTERRUPT FLIP=FLOP
1270 6254 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
1271 7610 SKP CLA

```

```

1272 4454 ERROR /CINT FAILED TO CLEAR USER INTERRUPT
1273 4455 LOOP /LOOP ON TEST IF SR = 1000

```

.....

```

/TEST 10 = SETS THE UB TO A 1, THE IF AND DF TO FIELD 6, THE PROGRAM
/THEN ISSUES AND, TAD, ISZ, AND DCA INDIRECTS TO CHECK THAT THE
/PROGRAM DOESN'T INTERRUPT UNTIL A JUMP INSTRUCTION IS ISSUED,
/.....

```

```

1274 4456 TEST10, SCOPLP /SETUP SCOPE AND TEST LOOPING ADDRESS
1275 6007 CAF /CLEAN ALL FLAGS
1276 6203 CIFGOF /CHANGE DATA AND INSTRUCTION FIELD TO 0
1277 5300 JMP ,*1 /CLEAR INTERRUPT INHIBIT
1300 6264 CUF /CLEAR USER FLAG
1301 6204 CINT /CLEAR USER INTERRUPT FLIP=FLOP
1302 6001 IOV /SET INTERRUPT ENABLE
1303 6274 SUP /SET USER BUFFER FLIP=FLOP
1304 5305 JMP ,*1 /CLEAR INTERRUPT INHIBIT
1305 7402 HLT /FAILED TO ENTER USER MODE
1306 5306 JMP /HLT FAILED TO TRAP
1307 6294 SINT /SKIP ON USER INTERRUPT FLIP=FLOP
1310 4494 ERROR /USER INTERRUPT FLIP=FLOP NOT SET
1311 6234 RIB /READ THE INTERRUPT BUFFER
1312 1113 TAJ M100 /CHECK FOR USER FLAG
1313 7640 SEA CLA
1314 4454 ERROR /USER FLAG NOT SET
1315 6263 CIFGOF 60 /CHANGE IB AND DF TO FIELD 6 AND SET INTERRUPT INHIBIT
1316 6001 IOV /SET INTERRUPT ENABLE, THE PROGRAM
/SHOULDN'T INTERRUPT UNTIL A JMP OR JMS IS ISSUED,
/CHECK THAT PROGRAM DOESN'T INTERRUPT

```

```

1317 7000 NOP
1320 7410 SKP
1321 7402 HLT /PROGRAM INTERRUPTED BEFORE A JMP WAS ISSUED
1322 3723 DCA I ,*1 /DO A DCA I TO NEXT LOCATIONS
1323 7410 SKP
1324 7402 HLT /PROGRAM INTERRUPTED BEFORE A JMP WAS ISSUED
1325 1726 TAD I ,*1 /DO A TAD I TO NEXT LOCATION
1326 7410 SKP
1327 7402 HLT /PROGRAM INTERRUPTED BEFORE A JMP WAS ISSUED
1330 0731 AND I ,*1 /DO A AND I TO THE NEXT LOCATION
1331 7410 SKP
1332 7402 HLT /PROGRAM INTERRUPTED BEFORE A JMP WAS ISSUED
1333 2734 ISZ I ,*1 /DO A ISZ I TO THE NEXT LOCATION
1334 7410 SKP
1335 7402 HLT /PROGRAM INTERRUPTED BEFORE A JMP WAS ISSUED
1336 5337 JMP ,*1 /CLEAR INTERRUPT INHIBIT AND INTERRUPT
1337 4494 ERROR /PROGRAM FAILED TO INTERRUPT
1340 6234 RIB /READ THE INTERRUPT BUFFER
1341 1110 TAJ M06 /CHECK FOR ISF AND DSF OF 6
1342 7640 SEA CLA
1343 4494 ERROR /SAVE FIELD NOT EQUAL TO 66
1344 6294 SINT /SKIP ON USER INTERRUPT F/F
1345 4494 ERROR /USER INTERRUPT F/F NOT SET
1346 7300 CLA CLL /CLEAN AC AND LINK
1347 6203 CIFGOF /SET IB AND DF TO 3
1350 6001 IOV /SET INTERRUPT ENABLE

```

1351	5392	JMP	,+1	/CLEAN INTERRUPT INHIBIT
1352	4494	ERROR		/PROGRAM FAILED TO INTERRUPT
1353	6294	SINT		/SKIP ON USER INTERRUPT
1354	4494	ERROR		/USER INTERRUPT NOT SET
1355	6204	CINT		/CLEAN USER INTERRUPT
1356	7340	CLA CLL CMA		/SET THE AC TO ONES AND LINK TO 0
1357	6004	GTF		/GET THE FLAGS
1360	7640	SEA CLA		
1361	4494	ERROR		/THE LINK, INT REQ, OR SAVE FIELD NON ZERO
1362	4495	LOOP		/LOOP ON TEST IF SR = 1000

.....
 /TEST 10 = IS A DATA TEST TO CHECK THAT DATA CAN BE DEPOSITED INTO EACH
 /SELECTED EXTENDED FIELD, DATA IS DEPOSITED INTO THE LAST ADDRESS OF
 /EACH 1K MEMORY SEGMENT IN THE EXTENDED MEMORY FIELD, THE USER INTERRUPT
 /IS SET FOR THIS TEST, THE PROGRAM CHANGES THE DATA FIELD TO THE NEW FIELD
 /CHECKS, IT THEN TURNS THE INTERRUPT ON AND DOES A DCA I TO THE LAST
 /ADDRESS IN A 1K MEMORY SEGMENT OF THAT FIELD, THE PROGRAM THEN DOES THE
 /SAME AS ABOVE, ONLY DOING A TAD I TO THE LAST ADDRESS OF A 1K MEMORY
 /SEGMENT, THE DATA THAT IS PUT INTO THE LAST ADDRESS OF EACH EXTENDED
 /1K MEMORY SEGMENT CONTAINS THE FIELD IN BITS 6-8 AND THE 1K SEGMENT IN
 /BITS 9-11

1363	4496	TEST10, SCOPLP		/SETUP TEST AND SCOPE LOOPING ADDRESS
1364	6007	CAF		/CLEAR ALL FLAGS
1365	6001	IOV		/TURN THE INTERRUPT ON
1366	1021	TAD	OP1SEL	/GET MEMORY SIZE FROM LOCATION 21
1367	0136	AND	K37	/MASK OFF THE MEMORY BITS
1370	7104	CLL	HAL	/ROTATE BITS LEFT ONCE TO SETUP FOR FIELD
1371	3036	DCA	SAVESE	/LIMIT AND LAST ADDRESS IN LAST FIELD
1372	1036	TAD	SAVESE	/GET THE NUMBER
1373	0137	AND	K70	/MASK OFF BITS 6-8 FOR FIELD LIMIT
1374	3037	DCA	FLDLIM	/SAVE THE NUMBER AS THE LAST SELECTED FIELD
1375	1036	TAD	SAVESE	/GET THE ROTATED NUMBER
1376	0134	AND	K7	/MASK OFF ADDRESS BITS
1377	7112	CLL	RTR	/ROTATE THE NUMBER 4 PLACES TO THE RIGHT
1400	7012	RTR		
1401	1145	TAD	K1777	/ADD 1K TO THE NUMBER
1402	3040	DCA	UPERLM	/SAVE THIS NUMBER AS THE LAST ADDRESS IN LAST FIELD
1403	1037	TAD	FLDLIM	/GET THE FIELD LIMIT
1404	7690	CLA	SNA	/IS THE LAST FIELD = TO FIELD 0
1405	5461	JMP	I PASEND	/END OF 2ND 1K SEGMENT
1406	4777	JMS	ACTLIN	/CHECK FOR ACT LINE AND 32K OF MEMORY
1407	6001	IOV		/TURN THE INTERRUPT ON
1410	6274	SUF		/SET USER BUFFER F/F
1411	5212	JMP	,+1	
1412	7402	HLT		/SHOULD TRAP HERE
1413	5213	JMP		/HALT FAILED TO TRAP
1414	6254	SINT		/SKIP ON USER INTERRUPT
1415	4494	ERROR		/USER INTERRUPT NOT SET
1416	7340	CLA CLL CMA		/SET THE AC TO ALL ONES
1417	6004	GTF		/GET THE FLAGS
1420	1130	TAD	M1100	/CHECK FOR USER FLAG AND INT REQ

1421	7640	SEA	CLA	
1422	4494	ERROR		/SAVE FIELD NOT EQUAL TO ABOVE
1423	3041	DCA	WRKFLD	/CLEAN WORKING FIELD
1424	3042	DCA	DATPAT	/CLEAN DATA PATTERN
1425	1145	BEGT10, TAD	K1777	/GET UPPER ADDRESS OF 1K FIELD
1426	3043	DCA	WRKADD	/SET FIRST ADDRESS EQUAL TO 1777
1427	1041	TAD	WRKFLD	/GET THE WORKING FIELD
1430	1139	TAD	K10	/ADD A FIELD TO IT
1431	3041	DCA	WRKFLD	
1432	1041	TAD	WRKFLD	/GET THE WORKING FIELD
1433	7041	TAD	WRKFLD	/NEGATE IT
1434	1037	CIA		/COMPARE IT TO THE FIELD LIMIT
1435	7310	SFA	FLDLIM	/IS THE NEW FIELD GREATER THAN FIELD LIMIT
1436	5344	JMP		/YES END OF TEST
1437	7640	JMS	ENDST	/YES END OF TEST
1440	7240	SEA	CLA	/IS NEW FIELD EQUAL TO LAST FIELD
1441	7450	CLA	CMA	/NO, THE LAST ADDRESS IN THIS FIELD WILL BE 777
1442	1040	SNA		/YES, THE LAST ADDRESS WILL BE EQUAL TO UPERLM
1443	3044	TAD	UPERLM	
1444	1044	DCA	HGHLIM	/SAVE THE LAST ADDRESS IN THIS FIELD
1445	7040	TAD	HGHLIM	/GET THE HIGH LIMIT
1446	7106	CMA		/COMPLEMENT IT
1447	7004	CLL	RTL	/ROTATE 3 PLACES TO THE RIGHT
1450	1147	HAL		/
1451	3047	TAD	K7774	/ADD IN 4K ADDRESS CONSTANT
1452	1041	DCA	ADDCNT	/SAVE IT
1453	7001	TAD	WRKFLD	/GET THE NEW FIELD
1454	3042	IAD		/ADD 1 TO IT
1455	6254	DCA	DATPAT	/SAVE THE WORD AS THE DATA PATTERN
1456	4454	T16LCU, SINT		/SKIP ON USER INTERRUPT
1457	1041	ERROR		/USER INTERRUPT GOT CLEARED
1460	1049	TAD	WRKFLD	/GET THE NEW FIELD
1461	3262	TAD	K6201	/GET THE GDF INSTRUCTION
		DCA	,+1	/PUT GDF TO NEW FIELD IN NEXT ADDRESS
1462	7402	COFNEW, HLT/COF		/CHANGE DATA FIELD TO NEW FIELD
1463	6214	RDF		/READ THE DATA FIELD
1464	7041	CIA		/NEGATE IT
1465	1041	TAD	WRKFLD	/GET THE NEW FIELD
1466	7640	SEA	CLA	
1467	4454	ERROR		/COF TO NEW FIELD FAILED
1470	1042	TAD	DATPAT	/GET THE DATA PATTERN
1471	6001	IOV		/TURN THE INTERRUPT ON
1472	3443	DCA	I WRKADD	/PUT THE WORD UP IN NEW FIELD AND INTERRUPT
1473	4454	ERROR		/PROGRAM FAILED TO INTERRUPT
1474	1041	TAD	WRKFLD	
1475	7112	CLL	RTR	
1476	7010	RAR		
1477	3040	DCA	SAVWFD	/SAVE THE WORKING FIELD IN BITS 9-11
1500	6234	RIB		/READ THE INTERRUPT BUFFER
1501	7041	CIA		/NEGATE IT
1502	1040	TAD	SAVWFD	/GET THE EXPECTED WORKING SAVE FIELD
1503	7640	SEA	CLA	
1504	4454	ERROR		/SAVE FIELD NOT EQUAL TO EXPECTED FIELD
1505	6254	SINT		/SKIP ON USER INTERRUPT F/F
1506	4454	ERROR		/USER INTERRUPT GOT CLEARED

1907	1262	TAD	COFNH	/GET THE COF INSTRUCTION TO THE NEW FIELD
1910	3311	DCA	,=1	/PUT IT IN THE NEXT LOCATION
1911	7402	HLT/GDF		/GDF TO NEW FIELD
1912	6214	RDF		/READ THE DATA FIELD
1913	7041	CIA		/NEGATE IT
1914	1041	TAD	WRKFLO	/GET THE WORKING FIELD
1915	7640	SEA	CLA	
1916	4454	ERROR		/GDF TO NEW FIELD FAILED
1917	0001	IDN		/TURN THE INTERRUPT ON
1920	1443	TAD	WRKADD	/GET DATA PATTERN FROM NEW FIELD
1921	4494	ERROR		/PROGRAM FAILED TO INTERRUPT
1922	6234	RIB		/READ THE INTERRUPT BUFFER
1923	7041	CIA		/NEGATE IT
1924	1040	TAD	SAVHFD	/GET THE EXPECTED SAVE FIELD
1929	7640	SEA	CLA	/ARE THEY EQUAL
1926	4454	ERROR		/NO, EXPECTED SAVE FIELD NOT EQUAL TO FIELD READ
1927	1042	TAD	DATPAT	/GET THE DATA PATTERN
1930	7041	CIA		/NEGATE IT
1931	1033	TAD	DATREC	/GET THE WORD RECEIVED
1932	7640	SEA	CLA	/ARE THEY EQUAL?
1933	4454	ERROR		/NO, DATA ERROR IN WRKFLO
1934	2047	ISE	ADDCNT	/GET NEXT ADDRESS IN THIS FIELD?
1935	7610	SKP	CLA	/YES
1936	5225	JMP	HEGT16	/NO, GO GET NEXT FIELD IF ANY LEFT
1937	1045	TAD	WRKADD	/GET THE WORKING ADDRESS
1940	1146	TAD	K2000	/ADD 1K TO IT
1941	3043	DCA	WRKADD	/SAVE NEW 1K UPPER ADDRESS BOUNDARY
1942	2042	ISE	DATPAT	/ADD ANOTHER 1K TO DATA WORD
1943	5255	JMP	T16LCD	/GO LOAD AND COMPARE THIS ADDRESS
1944	6204	ENDIST, CINT		/CLEAR USER INTERRUPT
1945	6204	SINT		/SKIP ON USER INTERRUPT
1946	7610	SKP	CLA	
1947	4494	ERROR		/CINT FAILED TO CLEAR USER INTERRUPT
1950	4455	LOOP		/LOOP ON TEST IF SR = 1000
1951	5461	JMP	PASEND	
1977	1600			
	1600	PAGE		

1990	7000	ACTLIN, 0		
1991	1022	TAD	DP2SEL	/IS THE PROGRAM RUNNING ON ACT LINE?
1992	7700	SMA	CLA	/NO, RETURN
1994	5600	JMP	ACTLIN	/GET THE FIELD LIMIT
1995	1037	TAD	FLOLIM	
1996	1111	TAD	M70	
1996	7640	SEA	CLA	/IS THE FIELD LIMIT EQUAL TO FIELD 7?
1997	5600	JMP	ACTLIN	/NO, RETURN TO TEST
1910	1040	TAD	UPERLM	/GET THE UPPER ADDRESS LIMIT
1911	7001	TAD		/ADD 1 TO IT
1912	7640	SEA	CLA	/WAS IT 7777?
1913	5600	JMP	ACTLIN	/NO, RETURN
1914	7392	CLA	CMA RTR	/SET LAST ADDRESS = 5777
1915	3040	DCA	UPERLM	/SAVE IT

1016	5600	JMP	ACTLIN	/RETURN TO PROGRAM
1017	1022	ENDPAS, TAD	DP2SEL	/CHECK FOR ACT LINE
1020	7700	SMA	CLA	/IS THE PROGRAM RUNNING ON ACT LINE
1021	5230	JMP	ENDING	/NO GO CHECK FOR SR 3 TO HALT AT END OF A PASS
1022	2236	ISE	PRGPAS	/CHECK 1/2 SECOND COUNT
1023	5230	JMP	ENDING	/NOT 1/2 SECOND YET
1024	1377	TAD	(=144	/RESET THE COUNTER
1025	3236	DCA	PRGPAS	
1026	6272	CIF	70	/CHANGE INSTRUCTION FIELD TO 7
1027	4451	JMS	GOODPS	/SIGNAL THE PROM
1030	4335	ENDING, JMS	SWCHK	/CHECK SR 3 TO HALT ON A PROGRAM PASS
1031	7006	HTL		
1032	7004	RAL		
1033	7710	SPA	CLA	
1034	7402	HLT		/END OF A COMPLETE PROGRAM PASS
1035	5776	JMP	0200	
1036	7634	PRGPAS, =144		
1037	7010	POWVAL, RAR		
1040	3245	DCA	LINK	
1041	1000	TAD	INTSER	
1042	3246	DCA	PC	
1043	6103	CAL		/CLEAR AC LOW F/F
1044	4452	JMS	AUTRST	/RETURN TO THE PROGRAM
1045	0000	LINK, 0		
1046	0000	PC, 0		
1047	0000	PRGRST, 0		
1050	6102	SPL		/SKIP ON AC LOW AS A LEVEL
1051	7610	SKP	CLA	
1052	5250	JMP	,=2	
1053	5453	JMP	TEST	/RETURN TO TEST BEING EXECUTED AND START OVER
1054	0000	TESTAD, 0		
1055	7340	CLA	CMA	
1056	1254	TAD	TESTAD	
1057	3053	DCA	TEST	
1060	1375	TAD	PRGRST	
1061	3052	DCA	AUTRST	
1062	5654	JMP	TESTAD	
1063	1021	BATEMT, TAD	DP1SEL	/GET HARDWARE CONFIGURATION
1064	0143	AND	K200	
1065	7650	SNA	CLA	
1066	5273	JMP	DEAD	/MACHINE GOING DOWN = STOP EVERYTHING
1067	3367	DCA	ACNLOK	
1070	2000	ISE	INTSER	

```

1071 2000      ISE  INTSER
1072 5400      JMP  I INTSER
1073 7402      DEAU, HLT
1074 5453      JMP  I TEST

1075 0000      GOODBU, 0
1076 1022      TAD  DP2SEL
1077 7700      SMA  CLA
1078 5675      JMP  I GOODBD
1079 6272      CIP  70
1080 4451      JMS  I GOODPS
1081 5675      JMP  I GOODBD

1082 0000      ERRURY, 0
1083 7300      CLA  CLL
1084 1022      TAD  DP2SEL
1085 7700      SMA  CLA
1086 5322      JMP  CHKINH
1087 1021      TAD  DP1SEL
1088 0143      AND  K200
1089 7640      SEA  CLA
1090 0160      CLRMOD
1091 0002      IOF
1092 7240      CLA  CMA
1093 1304      TAD  ERRORX
1094 0272      CIP  70
1095 5450      JMP  I BADPAS
1096 4335      JMS  SWCHK
1097 7710      SPA  CLA
1098 5330      JMP  ERLPSH
1099 7340      CLA  CLL CMA
1100 1304      TAD  ERRORX
1101 7402      HLT

1102 4335      ERLPSH, JMS  SWCHK
1103 7004      RA  CLA
1104 7710      SPA  CLA
1105 5453      JMP  I TEST
1106 5704      JMP  I ERRORX

1107 0000      SWCHK, 0
1108 7300      CLA  CLL
1109 1021      TAD  DP1SEL
1110 7700      SMA  CLA
1111 5344      JMP  I *3
1112 7604      LAS
1113 5735      JMP  I SWCHK
1114 1020      TAD  SWITCH
1115 5735      JMP  I SWCHK

```

/ITS ALL OVER NOW = GOOD=BYE

/GET HARDWARE CONFIGURATION
/IS THE PROGRAM RUNNING ON ACT LINE
/NO RETURN TO PROGRAM
/CHANGE INSTRUCTION FIELD TO FIELD 7
/SIGNAL ACT LINE PROGRAM STILL RUNNING
/RETURN TO PROGRAM

/ERROR ROUTINE

/CHECK FOR ACT LINE

/TURN THE INTERRUPT OFF

/GO TO ROM FOR ERROR
/CHECK FOR SR 0(1) TO INHIBIT ERROR HALT
/IS SR 0 SET TO A ONE
/YES, GO CHECK SR 1 TO LOOP ON ERROR

/SUBTRACT ONE FROM JMS ERROR PC
/AC CONTAINS THE ADDRESS WHERE THE ERROR
/WAS DETECTED BY THE PROGRAM, REFER
/TO THE PROGRAM LISTING FOR ERROR
/EXPLANATION AND THE TEST DESCRIPTION,
/CHECK THE SWITCH REGISTER TO LOOP ON ERROR

/IS SR 1 SET TO A ONE TO LOOP ON TEST
/YES GO LOOP ON THE TEST
/NO, RETURN TO THE PROGRAM

/GET THE HARDWARE STATUS WORD
/IS THE HARDWARE FRONT PANEL SELECTED
/NO, USE THE PSEUDO SWITCH REGISTER

/RETURN
/THE PSEUDO SWITCH REGISTER
/RETURN

```

1746 0000      TSTLOP, 0
1747 4335      JMS  SWCHK
1748 7006      RTN
1749 7700      SMA  CLA
1750 5746      JMP  I TSTLOP
1751 5453      JMP  I TEST

1752 0000      AQLBAT, 0
1753 1367      TAD  ACNLOK
1754 7640      SEA  CLA
1755 5362      JMP  I *3
1756 2000      ISE  INTSER
1757 5400      JMP  I INTSER
1758 3367      DCA  ACNLOK
1759 0101      SBE
1760 5360      JMP  I *4
1761 2000      ISE  INTSER
1762 5360      JMP  I *6
1763 0000      ACNLOK, 0

1775 1647
1776 0200
1777 7634
2000          PAGE
0200          *200

```

/ROUTINE TO CHECK SR 2 TO LOOP ON TEST
/GO GET THE SWITCH REGISTER

/GO TO NEXT TEST
/LOOP ON SAME TEST

/LOOK AT RETURN FOR AC LOW OR BATTERY EMPTY

/SKIP ON BATTERY EMPTY

0000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0100	11111111	11111111	11111111	11111111	11111111	11110000	00000000	00000000	00000000
0200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0300	11111111	11111111	11111111	11111111	11111111	11111111	11111111	10000000	00000001
0400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0500	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0700	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1100	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1300	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1500	11111111	11111111	11111111	11111111	11111111	11111111	11000000	00000000	00000001
1600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1700	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	00000111

2000
2100

2200
2300

2400
2500

2600
2700

3000
3100

3200
3300

3400
3500

3600
3700

4000
4100

4200
4300

4400
4500

4600
4700

5000
5100

5200
5300

5400
5500

5600
5700

6000
6100

6200
6300

6400
6500

6600
6700

7000
7100

7200
7300

7400
7500

7600
7700

ACLBAT	1734	JMSCK5	0764	M4100	0131	TST12D	0327
ACNLOK	1767	JMSCK6	1010	M43	0101	TST12E	0401
AGTLIN	1600	JMSCK7	1034	M44	0102	TST12F	0432
ADDGNT	0047	JMSCK8	1060	M5	0005	TST12G	0463
AUTRST	0052	K10	0135	M50	0103	TST12H	0515
BADPAS	0050	K125	0141	M5000	0132	TST12I	0547
BATEMT	1663	K192	0142	M5100	0133	TST13A	0636
REGT10	1425	K1777	0145	M52	0104	TST13B	0662
CAL	6007	K200	0143	M55	0105	TST13C	0704
CAL	6103	K2000	0146	M50	0106	TST13D	0730
CDP	6201	K37	0136	M51	0107	TST13E	0754
CDPCHK	0033	K400	0144	M56	0110	TST13F	1000
CDPNEW	1464	K4100	0153	M7	0006	TST13G	1024
CHKCDF	0034	K6201	0045	M70	0111	TST13H	1050
CHKINH	1722	K7	0134	M77	0112	TST14A	1115
CIP	6202	K70	0137	OP1SEL	0021	TST14B	1152
CIPCDF	6203	K7677	0152	OP21K2	0000	TST14C	1210
CINT	6204	K77	0140	OP2SEL	0022	TST14D	1250
CKJMS1	0227	K7707	0150	PASEVU	0061	TSTL0P	1746
CKJMS2	0257	K7757	0151	PC	1640	UPERLH	0040
CKJMS3	0310	K7774	0147	PONFAL	1637	WRKADD	0043
CKJMS4	0341	LINK	1645	PRGPAS	1636	WRKFLD	0041
CKJMS5	0413	LDORG2	0152	PRGMST	1647	XBAT	0000
CKJMS6	0444	LDORG3	0153	ROP	0214	XPRFL	0057
CKJMS7	0475	LOOP	4455	REDEMA	0155		
CKJMS8	0527	M1	0062	RIB	0234		
CKJMS9	0561	M10	0067	RIF	0224		
CLREMA	6154	M100	0113	RKBE	0023		
CLRMOD	6160	M1000	0117	RNF	0244		
CLRSIM	6150	M1007	0120	RTF	0005		
CUF	6244	M1010	0121	SAVES4	0036		
DATPAT	0042	M1020	0122	SAVHFU	0040		
DATREC	0035	M1034	0123	SBE	0101		
DEAD	1673	M1043	0124	SCOPLP	4450		
ENDING	1630	M1052	0125	SINT	0254		
ENDPAS	1617	M1061	0126	SKON	0000		
ENDTST	1544	M1070	0127	SKREMA	0166		
ERLPSH	1730	M11	0070	SPL	0102		
ERROR	4454	M1100	0130	SUF	0274		
ERRORX	1704	M125	0114	SWCHK	1735		
EXECUT	0164	M152	0115	SWITCH	0020		
FLOLIN	0037	M15	0071	T16LCU	1455		
GOODRD	1675	M2	0063	TEST	0053		
GOODPS	0051	M20	0072	TEST12	0200		
GTF	6004	M22	0073	TEST13	0616		
HGHLIN	0044	M25	0074	TEST14	1100		
HLY	7402	M30	0075	TEST15	1274		
INTSER	0000	M300	0116	TEST16	1363		
JMSCK1	0646	M33	0076	TESTAU	1654		
JMSCK2	0672	M34	0077	TST12A	0215		
JMSCK3	0714	M4	0064	TST12B	0245		
JMSCK4	0740	M40	0100	TST12C	0276		

ERRORS DETECTED: 0
 LINKS GENERATED: 3
 RUN-TIME: 18 SECONDS
 3K CORE USED

/KMB=A OPTION TEST 2 MAINDEC=08=DJKMA=A=L 1K PART 3
/COPYRIGHT (C) 1974, DIGITAL EQUIPMENT CORPORATION
/PROGRAMMER: BRUCE HANSEN

////////////////////////////////////
/THE FOLLOWING LISTING WILL CORRESPOND TO THE PAPER TAPE LABELED MAINDEC=08=DJKMA=A-PM3,
/1K PART 3, THIS PAPER TAPE AND LISTING WILL BE THE THIRD OF FOUR 1K SEGMENTED
/PAPER TAPES AND LISTINGS FOR COMPUTERS WITH LESS THAN 4K OF MEMORY,
////////////////////////////////////

/KMB=A OPTION TEST 2 MAINDEC=08=DJKMA=A=L 1K PART 3
/COPYRIGHT 1974, DIGITAL EQUIPMENT CORP., MAYNARD, MASS., 01754
/PDP-11A OPTION TEST 2 TESTS THE MEMORY EXTENTION/TIME SHARE CONTROL,
/POWER FAIL/AUDIO RESTART, AND BOOTSTRAP LOADERS

6000 SKON#6000
6007 CAF#6007
7402 HLT#7402

/SWITCH REGISTER SETTINGS
/SR0#1 INHIBIT ERROR HALT
/SR1#1 LOOP ON ERROR
/SR2#1 LOOP ON TEST
/SR3#1 HALT AT COMPLETION OF A PROGRAM PASS

/MEMORY EXTENTION/TIME SHARE INSTRUCTIONS

6004 GTF#6004 /GET FLAGS, READS THE FOLLOWING MACHINE STATES
/INTO THE INDICATED BITS OF THE AC1
/AC0 LINE
/AC2 INTERRUPT REQUEST
/AC4 INTERRUPT ENABLE F/F
/AC5 USER FLAG
/AC6-11 SAVE FIELD REGISTER
6005 RTF#6005 /RESTORE THE FLAGS, RTF LOADS THE LINK FROM AC0,
/LOADS THE USER BUFFER F/F, INSTRUCTION BUFFER AND
/DATA FIELD WITH AC5, AC6-8, AC 9-11 AND INHIBITS
/PROCESSOR INTERRUPTS UNTIL NEXT JMP OR JMS INSTRUCTION,
/AT THE END OF THE JMP OR JMS, THE CONTENTS OF THE U.B. + 1,8,
/ARE LOADED INTO USER FIELD F/F, AND THE I.F., INTERRUPT ENABLE
/IS SET AND INTERRUPT INHIBIT IS CLEARED
6234 RIB#6234 /READ THE INTERRUPT BUFFER
6244 RMF#6244 /RESTORES MEMORY FLAGS
6204 CINT#6204 /CLEAR USER INTERRUPT FLIP=FLOP
6254 SINI#6254 /SKIP ON USER INTERRUPT FLIP=FLOP
6264 CUF#6264 /CLEAR USER BUFFER FLIP=FLOP
6274 SUP#6274 /SET USER BUFFER FLIP=FLOP (ENTER TIME SAME MODE)AND
/INHIBITS PROCESSOR INTERRUPTS UNTIL THE NEXT JMP OR
/JMS INSTRUCTION, AT THE END OF THE JMP OR JMS
/INSTRUCTION, THE USER BUFER IS LOADED INTO THE USER
/FIELD F/F,
6201 CDF#6201 /CHANGE DATA FIELD

```

0202 CIF#0202 /CHANGE INSTRUCTION FIELD
0214 RDP#0214 /READ THE DATA FIELD INTO AC BITS 6=8
0224 RIF#0224 /READ THE INSTRUCTION FIELD INTO AC BITS 6=8
0203 CIFCDF#0203 /PERFORMS THE CIF AND CDF FUNCTIONS

/POWER FAIL INSTRUCTIONS

6102 SPL#0102 /SKIP ON AC LOW FLIP=FLOP
6103 CAL#0103 /CLEAR AC LOW FLIP=FLOP
6101 SBE#0101 /SKIP ON BATTERY EMPTY FLIP=FLOP

/OPTION BOARD 2 SIMULATOR IOT'S

6150 CLRSIM#0150 /CLEAR CONTROL REGISTERS
6152 LODHG2#0152 /LOAD CONTROL REGISTER 2
6154 LODHG3#0154 /LOAD CONTROL REGISTER 3
6154 CLREMA#0154 /CLEAR EMA CATCHER LOGIC
6155 REDLMA#0155 /READ EMA CATCHER REGISTER
6160 CLRMOU#0160 /CLEAR TEST MODULE LOGIC
6164 EXECUT#0164 /EXECUT AND CONTROL WORD 3 BIT 7 #1 ISSUE A POWER ON PULSE
6166 SKPEMA#0166 /EXECUT AND CONTROL WORD 3 BIT 7 #0 ISSUE A SWITCH SW PULSE
/SKPEMA AND CONTROL WORD 3 BIT 3 #1 EMA INTERRUPT AND SKIP ENABLE
/SKPEMA AND CONTROL WORD 3 BIT 3 #0 EMA INTERRUPT AND SKIP DISABLE

/OPTION BOARD 2 SIMULATOR CONTROL WORD 2 BIT ASSIGNMENTS
/
/BITS 0 = 1 NOT USED
/BITS 2 = 3 BOOT STRAP PROGRAM SELECT
/BITS 9 = 11 AUTO=RESTART ADDRESS SELECT

/OPTION BOARD 2 SIMULATOR CONTROL WORD 3 BIT ASSIGNMENTS
/
/BIT 0 TIME SHARE 0=ENABLED 1=DISABLED
/BIT 1 AC LOW (L) 1=PULLED LOW 0=FREE STATE
/BIT 2 BATT EMPTY 1=BATT EMPTY PULLED LOW 0=FREE STATE
/BIT 3 1=EMA INTERRUPT/SKIP ENABLE 0=EMA INTERRUPT SKIP DISABLE
/BITS 4 = 6 NOT USED
/BIT 7 1=POWER ON PULSE WITH EXECUT 0=SWITCH SW PULSE WITH EXECUT
/BIT 8 1=DISABLES BOOTSTRAP WHILE RUNNING 0=ENABLES BOOTSTRAP WHILE RUNNING
/BIT 9 = 11 AUTO=RESTART/BOOT STRAP ENABLE CODE

0000 *0

0000 0000 INTSER, 0 /JMS I AUTHST PLACED HERE FOR SIMULATOR AUTO RESTART
0001 3035 DCA DATREC
0002 6102 SPL /SKIP ON AC LOW
0003 7410 SKP
0004 5457 JMP I XPRFL /POWER GOING DOWN
0005 6101 SBE /SKIP ON BATTERY EMPTY
    
```

```

0006 7410 SKP
0007 5460 JMP I XBAT /GO HALT THE COMPUTER ,ITS ALL OVER
0010 6224 RIF /READ THE INSTRUCTION FIELD
0011 7640 SEA CLA
0012 4454 ERKON /I,F, IS NOT 0 AFTER A INTERRUPT
0013 6214 RDP /READ THE DATA FIELD
0014 7640 SEA CLA
0015 4454 ERKON /D,F, IS NOT 0 AFTER A INTERRUPT
0016 2000 ISE INTSER /ADD 1 TO THE INTERRUPTED PC
0017 5400 JMP I INTSER /RETURN TO THE PROGRAM

0020 *20
0020 0000 SWITCH, 0 /PSEUDO SWITCH REGISTER IF BIT 0=0 OF OP1SEL
0021 1000 OP1SEL, 1000

/BIT 0=0 USE LOC 20 AS A PSEUDO S,R,
/BIT 0=1 USE HARDWARE FRONT PANEL S,R,
/BIT 1=1 HAS 8A OPTION 1
/BIT 2=1 HAS 8A OPTION 2
/BIT 3=1 HAS 8A CPU SIMULATOR
/BIT 4=1 HAS 8A OPTION 1 + 2 TEST MODULE
/BIT 5=1 PROGRAM ON 8A XOR
/BIT 6=1 HAS PDP=8E TYPE CPU
/BITS 7=11 MEMORY SIZE = 0'S = 1K, 37=32K,
/MEMORY SIZE CAN BE INCREASED IN 1K INCREMENTS
/BY ADDING A 1 TO THE NUMBER IN BITS 7=11,

0022 0000 OP2SEL, 0
/RTGE BOOT STRAP WILL LOAD INTO THE FOLLOWING LOCATIONS

0023 7402 RKBE, HLT /2000
0024 7402 HLT /6745
0025 7402 HLT /0023
0026 7402 HLT /7650
0027 7402 HLT /9024
0030 7402 HLT /6733
0031 7402 HLT /9031
0032 7402 HLT /TERMINATOR
0033 0000 CDFCHK, 0
0034 0033 CHKCDF, CDFCHK
0035 0000 DATREC, 0
0036 0000 SAVES#, 0
0037 0000 FLDLIM, 0
0040 0000 UPENLM, 0
0041 0000 WRKFLU, 0
0042 0000 DATPAT, 0
0043 0000 WRKADU, 0
0044 0000 HGHLIM, 0
0045 6201 K6201, 6201
0046 0000 SAVWFD, 0
0047 0000 ADDQNT, 0
0050 6520 BADMAS, 6520
0051 6500 CODJPS, 6500
0052 1653 AUTHST, PRGRST
0053 0000 TEST, 0 /SCOPE LOOP AND TEST LOOP ADDRESS
    
```

```

0054 4454 ERROR# JMS I ;
      1710          ; ERRORX
      4455 LOOP# JMS I ;
0055 1752          ; TSTLOP
      4456 SCOPL# JMS I ;
0056 1660          ; TESTAD

0057 1645 XPNHFL# POWFAL
0060 1667 XBAT# BATEMT
0061 1617 PASEMU# ENDPAS
    
```

/CONSTANTS USED BY THE PROGRAM

```

0062 7777 M1, =1
0063 7776 M2, =2
0064 7774 M4, =4
0065 7773 M5, =5
0066 7771 M7, =7
0067 7770 M10, =10
0070 7767 M11, =11
0071 7762 M18, =18
0072 7760 M20, =20
0073 7756 M22, =22
0074 7753 M25, =25
0075 7750 M30, =30
0076 7745 M33, =33
0077 7744 M34, =34
0100 7740 M40, =40
0101 7735 M43, =43
0102 7734 M44, =44
0103 7730 M50, =50
0104 7726 M52, =52
0105 7723 M55, =55
0106 7720 M60, =60
0107 7717 M61, =61
0110 7712 M66, =66
0111 7710 M70, =70
0112 7701 M77, =77
0113 7700 M100, =100
0114 7693 M125, =125
0115 7626 M152, =152
0116 7500 M300, =300
0117 7000 M1000, =1000
0120 6771 M1007, =1007
0121 6762 M1010, =1010
0122 6753 M1025, =1025
0123 6744 M1034, =1034
0124 6735 M1043, =1043
0125 6726 M1052, =1052
0126 6717 M1061, =1061
0127 6710 M1070, =1070
0130 6700 M1100, =1100
0131 3700 M4100, =4100
    
```

```

0132 3000 M5000, =5000
0133 2700 M5100, =5100

0134 0007 K7, 7
0135 0010 K10, 10
0136 0037 K37, 37
0137 0070 K70, 70
0140 0077 K77, 77
0141 0125 K125, 125
0142 0152 K152, 152
0143 0200 K200, 200
0144 0400 K400, 400
0145 1777 K1777, 1777
0146 2000 K2000, 2000
0147 7774 K7774, 7774
0150 7707 K7707, 7707
0151 7757 K7757, 7757
0152 7677 K7677, 7677
0153 4100 K4100, 4100

0200 *200
    
```

```

/.....
/TEST 18 = IS ONLY EXECUTED WHEN THE SIMULATOR IS SELECTED (BIT 4 OF LOCATION 21 SET TO A 1),
/TEST 18 CHECKS THAT THE EMA IS LOADED ONTO THE BUS DURING A DCA ; FOLLOWING
/ A CDF 10; CDF 20; CDF 40, THE SIMULATOR IS USED TO CAUSE A INTERRUPT
/FOLLOWING A EMA CHANGE ON THE BUS, THE SIMULATOR STORES THE EMA INTO A
/EMA CATCHER REGISTER AND THEN THE PROGRAM READS AND COMPARES IT,
/.....
    
```

```

0200 7000 NOP/JMS I AURST /THIS LOCATION USED FOR AUTO-RESTARTS
0201 4456 TEST18, SCOPLP /SETUP TEST AND SCOPE LOOPING ADDRESS
0202 6007 CDF /CLEAR ALL FLAGS
0203 1021 TAD DP1SEL /CHECK BIT 4 OF LOCATION 21 FOR SIMULATOR SELECT
0204 0143 AND K200 /
0205 7650 SNA CLA /WAS THE SIMULATOR SELECTED ?
0206 5461 JMP I PASEND /NO, END OF ONE PROGRAM PASS
0207 4211 JMS EMACLR /LOAD CONTROL WORD AND CLEAR EMA REGISTER
0210 5225 JMP TST18A /GO TO FIRST TEST
0211 0000 EMACLR, 0 /ROUTINE TO LOAD CONTROL WORD AND CLEAR EMA CATCHER REGISTER
0212 1144 TAD K400
0213 0153 LODMG3 /LOAD CONTROL REGISTER 3 FOR INT AND SKIP ENABLE
0214 0154 CLREMA /CLEAR EMA CATCHER REGISTER
0215 0166 SKPEMA /SKIP ON EMA CATCHER REGISTER SET
0216 7610 SKP CLA
0217 4454 ERRDM /CLREMA FAILED TO CLEAR CATCHER F/F
0220 0155 REDEMA /READ THE EMA CATCHER REGISTER
0221 1060 TAD M7 /CLEARING THE REGISTER SET IT TO 7
0222 7640 SZA CLA /IS THE REGISTER SET TO 7 ?
0223 4454 ERRDM /NO, CLREMA FAILED TO SET REGISTER TO 7
0224 5611 JMP I EMACLR
0225 6211 TST18A, CDF 10 /CHANGE DATA FIELD TO FIELD 10
0226 6001 JCV 10 /TURN THE INTERRUPT ON
    
```

```

0227 3630      DCA I ,+1      /CHANGE THE EMA LINES TO 1 AND INTERRUPT
0230 7402      HLT              /SIMULATOR FAILED TO INT, OR EMA DIDN'T CHANGE
0231 6166      SKPEMA     /SKIP ON EMA REGISTER SET
0232 4454      ERROR      /SIMULATOR EMA CATCHER REGISTER NOT SET
0233 6234      R13        /HEAD THE INTERRUPT BUFFER
0234 1062      SEA        M1
0235 7640      TAD        CLA
0236 4454      ERROR      /IS THE SAVE FIELD EQUAL TO 1 ?
0237 6155      REDEMA     /NO,SAVE FIELD NOT EQUAL TO 1
0240 1062      TAD        M1
0241 7640      SEA        CLA
0242 4454      ERROR      /IS THE EMA CATCHER REGISTER = 1 ?
0243 4211      JMS        EMACLR /NO,EMA LINES OTHER THAN EMA2 MUST HAVE BEEN SET
0244 6221      CDF        20    /LOAD CONTROL WORD AND CLEAR EMA CARCHER REGISTER
0245 6001      TST100, IOV      /CHANGE DATA FIELD TO FIELD 2
0246 3647      DCA I ,+1      /TURN THE INTERRUPT ON
0247 7402      HLT              /CHANGE THE EMA LINES TO 2 AND INTERRUPT
0250 6166      SKPEMA     /PROGRAM FAILED TO INTERRUPT OR EMA DID NOT CHANGE
0251 4454      ERROR      /SKIP ON EMA REGISTER SET
0252 6155      REDEMA     /EMA CATCHER REGISTER NOT SET
0253 1063      TAD        M2
0254 7640      SEA        CLA
0255 4454      ERROR      /DID THE OF SET EMA1 ON TO THE BUS
0256 4211      JMS        EMACLR /NO, EMA REGISTER NOT EQUAL TO 2
0257 6241      CDF        40    /LOAD CONTROL WORD CLEAR EMA REGISTER
0260 6001      TST100, IOV      /CHANGE DATA FIELD TO FIELD 4
0261 3662      DCA I ,+1      /TURN THE INTERRUPT ON
0262 7402      HLT              /CHANGE EMA LINES TO 4 AND INTERRUPT
0263 6166      SKPEMA     /PROGRAM FAILED TO INTERRUPT OR EMA DID NOT CHANGE
0264 4454      ERROR      /SKIP ON EMA CATCHER REGISTER SET
0265 6155      REDEMA     /EMA CATCHER F/F NOT SET
0266 1064      TAD        M4
0267 7640      SEA        CLA
0270 4454      ERROR      /DID THE OF SET EMA2 ON TO THE BUS
0271 4672      JMS I ,+1      /NO,EMA CATCHER REGISTER NOT EQUAL TO 4
0272 6211      EMACLR     /LOAD CONTROL WORD AND CLEAR EMA CATCHER REGISTER
0273 6150      CLR5IM     /CLEAN SIMULATOR CONTROL WORD
0274 4455      LOOP        /LOOP ON TEST IF SR = 1000

```

```

/.....
/TEST 19 = IS A CONTINUATION OF TEST 18 ONLY TESTING THAT THE CIF
/INSTRUCTION LOADS THE APPROPRIATE EMA LINE, THE TEST WILL BE FOR CIF 101
/CIF 201 AND CIF 40, THE SIMULATOR IS USED FOR INTERRUPTS AND TO READ
/THE EMA LINES;
/.....

```

```

0275 4456      TEST19, SCOPLP /SETUP TEST AND SCOPE LOOPING ADDRESS
0276 6007      CDF              /CLEAN ALL FLAGS
0277 6168      CLRMOD     /CLEAN SIMULATOR MODULE
0300 6211      CDF        10    /CHANGE DATA FIELD TO FIELD 1
0301 3761      DCA I EMA1   /CLEAN THE FIRST TEST LOCATION
0302 6221      CDF        20    /CHANGE DATA FIELD TO FIELD 2
0303 3762      DCA I EMA2   /CHANGE DATA FIELD TO FIELD 2
0304 6241      CDF        40    /CHANGE DATA FIELD TO FIELD 4
0305 3763      DCA I EMA3   /CLEAN A LOCATION IN FIELD 4

```

```

0306 6201      CDF        00      /CHANGE DATA FIELD BACK TO FIELD 0
0307 4760      JMS I CLRERG /LOAD CONTROL WORD AND CLEAR EMA CATCHER REGISTER
0310 6212      TST19A, CIF 10    /LOAD CONTROL WORD AND CLEAR EMA CATCHER REGISTER
0311 6001      TST19A, IOV      /CHANGE INSTRUCTION FIELD TO 1
0312 9312      EMA1F1, JMP , /TURN THE INTERRUPT ON
0313 7402      HLT              /CLEAN INT INHIBIT AND INTERRUPT
0314 6166      SKPEMA     /PROGRAM FAILED TO INTERRUPT
0315 4454      ERROR      /SKIP ON EMA CATCHER F/F SET
0316 6234      R13        /EMA CATCHER F/F NOT SET
0317 1067      TAD        M10
0320 7640      SEA        CLA
0321 4454      ERROR      /IS THE SAVE FIELD EQUAL TO IF OF 1
0322 6155      REDEMA     /SAVE FIELD NOT EQUAL TO IF OF 1
0323 1062      TAD        M1
0324 7640      SEA        CLA
0325 4454      ERROR      /IS THE EMA CATCHER REGISTER EQUAL TO 1
0326 4760      TST19B, JMS I CLRERG /NO,EMA CATCHER REGISTER NOT EQUAL TO 1
0327 6222      CDF        20    /LOAD CONTROL WORD, CLEAR EMA CATCHER REGISTER
0330 6001      TST19B, IOV      /CHANGE INSTRUCTION FIELD TO FIELD 2
0331 9331      EMA1F2, JMP , /TURN THE INTERRUPT ON
0332 7402      HLT              /CLEAN INT INHIBIT AND INTERRUPT
0333 6166      SKPEMA     /PROGRAM FAILED TO INTERRUPT OR EMA DID NOT CHANGE
0334 4454      ERROR      /SKIP ON EMA CATCHER F/F SET
0335 6155      REDEMA     /EMA CATCHER REGISTER NOT SET
0336 1063      TAD        M2
0337 7640      SEA        CLA
0340 4454      ERROR      /IS THE EMA CATCHER REGISTER EQUAL TO 2
0341 4760      TST19C, JMS I CLRERG /NO, EMA WASN'T SET TO 2
0342 6242      CDF        40    /LOAD CONTROL WORD, CLEAR EMA REGISTER
0343 6001      TST19C, IOV      /CHANGE INSTRUCTION FIELD TO FIELD 4
0344 9344      EMA1F3, JMP , /TURN THE INTERRUPT ON
0345 7402      HLT              /CLEAN INTERRUPT INHIBIT AND INTERRUPT
0346 6166      SKPEMA     /PROGRAM FAILED TO INTERRUPT
0347 4454      ERROR      /SKIP ON EMA CATCHER F/F SET
0350 6155      REDEMA     /EMA CATCHER REGISTER NOT SET
0351 1064      TAD        M4
0352 7640      SEA        CLA
0353 4454      ERROR      /IS THE EMA CATCHER REGISTER SET TO 4
0354 4760      TST19D, JMS I CLRERG /NO, EMA WASN'T SET TO 4
0355 6150      CLR5IM     /LOAD CONTROL WORD CLEAR CATCHER F/F'S
0356 4455      LOOP        /CLEAN SIMULATOR CONTROL WORDS
0357 9777      JMP        TEST20 /LOOP ON TEST IF SR = 1000
                                /GO TO THE NEXT TEST

0360 6211      CLRERG, EMACLR /CLEAR EMA CATCHER REGISTER
0361 9312      EMA1,   EMA1F1 /CLEAR EMA CATCHER REGISTER
0362 9331      EMA2,   EMA1F2 /CLEAR EMA CATCHER REGISTER
0363 9344      EMA3,   EMA1F3 /CLEAR EMA CATCHER REGISTER

0377 0402      PAGE
0400 0400      JMP I ,+1
0401 0642      BOINTR1 /SIMULATOR COMES HERE AFTER A BOOTSTRAP

```

```

/.....

```

/TEST 20 = IS EXECUTED WHEN THE SIMULATOR IS SELECTED, TEST 20 CHECKS
 /THAT THE TIME SHARE LOGIC CAN BE DISABLED, THIS IS DONE WITH THE
 /SIMULATOR BY PULLING KMTS TIME SHARE DISA, L LOW, THE PROGRAM THEN
 /TRIES TO LOAD THE USER BUFFER AND THEN DOES A JOT, LAS, OSR AND CHECKS
 /THAT THE PROGRAM DIDN'T INTERRUPT;

```

0402 4456 TEST20, SCOPLP /SETUP TEST AND SCOPE LOOPING ADDRESS
0403 6007 CAF /CLEAR ALL FLAGS
0404 6100 CLRMOD /CLEAR SIMULATOR LOGIC
0405 7330 CLA CLL CML RAR /SET BIT 0 TO A ONE
0406 6153 LOADKGS /LOAD CONTROL REGISTER 3 WITH TIME SHARE DISABLE
0407 7300 CLA CLL
0410 6001 IOV /TURN THE INTERRUPT ON
0411 6274 SUF /TRY TO SET USER BUFFER
0412 5213 JMP ,+1 /TRY TO ENTER TIME SHARE MODE
0413 7404 OSR /SHOULD TRAP HERE IF TIME SHARE NOT DISABLED
0414 7410 SKP
0415 4454 ERROR /TIME SHARE NOT DISABLED=PROGRAM INTERRUPTED
0416 7604 LAS /SHOULD TRAP HERE IF TIME SHARE NOT DISABLED
0417 7410 SKP
0420 4454 ERROR /LAS TRAPPED WITHOUT TIME SHARE ENABLED
0421 6001 IOV /ISSUE A JOT
0422 7610 SKP CLA
0423 4454 ERROR /JOT TRAPPED WITHOUT TIME SHARE ENABLED
0424 6007 CAF /CLEAR ALL FLAGS
0425 7610 SKP CLA
0426 4454 ERROR /CAF TRAPPED
0427 6150 CLRSM /CLEAR THE SIMULATOR CONTROL REGISTERS
0430 6001 IOV /TURN INTERRUPT ENABLE ON
0431 6274 SUF /SET THE USER BUFFER F/F
0432 5233 JMP ,+1 /ENTER TIME SHARE MODE
0433 7402 WLT /SHOULD TRAP HERE
0434 5234 JMP /HALT FAILED TO TRAP IN USER MODE
0435 6254 SINT /SKIP ON USER INTERRUPT F/F SET
0436 4454 ERROR /USER INTERRUPT F/F NOT SET
0437 6007 CAF /CLEAR USER INTERRUPT F/F
0440 4455 LOOP /LOOP ON TEST IF SR = 1000
0441 5642 JMP I ,+1
0442 6000 TEST21
    
```

/THE FOLLOWING LOCATIONS CONTAIN THE CONTENTS OF THE TABE CASSETTE BOOTSTRAP

```

0443 4000 TABADD, 4000 /BOOTSTRAP WILL START LOADING INTO THIS ADDRESS
0444 7740 TABCMP=TABEND=1
0445 1237 TABCMP, 1237
0446 1200
0447 6704 6704
0450 6706 6706
0451 6703 6703
0452 5204 5204
0453 7264 7264
0454 6702 6702
    
```

```

0455 7610 7610
0456 3211 3211
0457 3636 3636
0460 1205 1205
0461 6704 6704
0462 6706 6706
0463 6701 6701
0464 5210 5210
0465 7002 7002
0466 7430 7430
0467 1636 1636
0470 7022 7022
0471 3636 3636
0472 7420 7420
0473 2236 2236
0474 2235 2235
0475 5215 5215
0476 7346 7346
0477 7002 7002
0500 3235 3235
0501 5201 5201
0502 7737 7737
0503 3557 3557
0504 7730 TABEND, 7730
0505 0000 0000 /TERMINATOR

0506 1301 BOOTB, PTADD
0507 1343 TCBAOD
0510 1363 DSBAOD
0511 0443 TABAOD
0512 0514 RKBADD
0513 0000
    
```

/THE FOLLOWING LOCATIONS CONTAIN THE CONTENTS OF THE RKB BOOTSTRAP

```

0514 0023 RKBADD, 0023 /BOOTSTRAP WILL LOAD INTO THIS ADDRESS
0515 7771 RKBMP=RKBEND=1 /NUMBER OF LOCATIONS TO COMPARE
0516 2000 RKBMP, 2000
0517 6745 6745
0520 0023 0023
0521 7650 7650
0522 5024 5024
0523 6743 6743
0524 5031 RKBEND, 5031
0525 0000 0000 /TERMINATOR
0600 PAGE
    
```

.....
/THE FOLLOWING TEST CHECKS THE BOOTSTRAP TO LOAD AND TO COMPARE CORRECTLY
.....

```

0600 4456 TEST21, SCOPUP /SETUP TEST COUNT AND SCOPE LOOPING ADDRESS
0601 1377 TAD (JMS I AURST /SETUP LOCATIONS 0 AND 200
0602 3000 DCA INTSER
0603 1377 TAD (JMS I AURST
0604 3776' DCA TEST18=1
0605 1375 TAD (NOBOOT /SET UP A LOCATION IN CASE LOGIC DID A AUTO RESTART
0606 3092 DCA AURST /SAVE IT
0607 5212 JMP ,+3
0610 0000 NOBOOT, 0
0611 4494 ERROR /PROGRAM DID A AUTO-RESTART INSTEAD OF A BOOT
0612 6160 CLRMOD /CLEAN SIMULATOR TEST LOGIC
0613 4774' JMS SETUP /GO SETUP FOR BOOTSTRAPS
0614 1373 NXTBOT, TAD (BOTSEL /GET THE ADDRESS OF THE BOOT SELECT TABLE
0615 1320 TAD SIMBOT /GET THE BOOTSTRAP TO BE EXECUTED
0616 3322 DCA CONTW2 /SAVE THE ADDRESS OF BOOTSTRAP SELECT
0617 1372 TAD (BOTENA /GET THE ADDRESS OF THE BOOTSTRAP ENABLE BITS
0620 3323 DCA CONTW3 /SAVE THE ADDRESS OF BOOT ENABLE CODE
0621 7346 CLA CLL CMA RTL /SETUP TO DO 3 BOOTSTRAP COMBINATIONS
0622 3325 DCA HTSUBT /SAVE SUB-TEST COUNT
0623 6160 CLRMOD /CLEAN SIMULATOR MODULE
0624 4771' JMS CLEARB /CLEAN BOOTSTRAP LOCATIONS IN MEMORY
0625 1022 TAD OP2SEL /CHECK FOR THE ACT LINE
0626 7710 SPA CLA /IS PROGRAM RUNNING ON ACT LINE?
0627 6305 6305 /YES, DISABLE ACT UNTIL BOOTSTRAP IS COMPLETED
0630 1722 TAD I CONTW2 /GET THE BOOTSTRAP SELECT ADDRESS
0631 6152 LOCHR2 /LOAD SIMULATOR CONTROL REGISTER 2
0632 7300 CLA CLL
0633 1326 TAD BOOTR1 /GET BOOT STRAP RETURN ADDRESS FOR BOOT RETURN
0634 3724 DCA I ADD401 /PUT IT INTO LOCATION 401
0635 1723 TAD I CONTW3 /GET BOOTSTRAP ENABLING CODE
0636 6153 LOCHR3 /LOAD SIMULATOR CONTROL REGISTER 3
0637 7300 CLA CLL
0640 A164 EXECUT /LOAD THE BOOTSTRAP
0641 5241 JMP , /PROGRAM FAILED TO BOOTSTRAP ON 1 OF THE FOLLOWING CONDITIONS
/0001 SW=SW ENABLE BOOT WHEN RUNNING
/0003 SW=SW ENABLE BOOT WHEN RUNNING
/0005 SW=SW ENABLE BOOT WHEN RUNNING
/CLEAN SIMULATOR LOGIC
/BOOTSTRAP SHOULD RETURN HERE VIA SIMULATOR
/CHECK FOR THE ACT LINE
/IS THE PROGRAM ON THE ACT LINE
/YES, ENABLE THE ACT LINE
0642 A160 BOTHT1, CLRMOD
0643 7301 CLA CLL IAC /BOOTSTRAP SHOULD RETURN HERE VIA SIMULATOR
0644 1022 TAD OP2SEL /CHECK FOR THE ACT LINE
0645 7510 SPA /IS THE PROGRAM ON THE ACT LINE
0646 6305 6305 /YES, ENABLE THE ACT LINE
0647 7300 CLA CLL
0650 1320 TAD SIMBOT /GET THE BOOT BEING EXECUTED
0651 4770' JMS BOTCMP+2 /GO COMPARE THE BOOT THAT WAS LOADED
0652 2323 ISL CONTW3 /ADD 1 TO THE BOOTSTRAP ENABLE ADDRESS
0653 2325 ISL HTSUBT /DONE WITH THIS SUB TEST?
0654 5223 JMP BOTHT1 /NO, DO NEXT ENABLING CONDITION
0655 4767' JMS GOODBD /SIGNAL ACT LINE IF SELECTED
0656 1065 TAD M5 /SETUP TO DO NEXT SUB TEST 5 TIMES

```

```

0657 3325 DCA HTSUBT /SAVE SUB-TEST COUNT
0660 6160 BOTHT2, CLRMOD /CLEAN SIMULATOR MODULE
0661 4771' JMS CLEARB /CLEAN BOOTSTRAP LOCATIONS IN MEMORY
0662 1022 TAD OP2SEL /CHECK FOR THE ACT LINE
0663 7710 SPA CLA /IS IT ON THE ACT LINE
0664 6305 6305 /YES, DISABLE ACT LINE UNTIL BOOT IS DONE
0665 1722 TAD I CONTW2 /GET THE BOOTSTRAP SELECT ADDRESS
0666 6152 LOCHR2 /LOAD CONTROL REGISTER 2
0667 7300 CLA CLL
0670 1327 TAD BOOTR2 /GET BOOT RETURN ADDRESS FOR BOOT RETURN
0671 3724 DCA I ADD401 /PUT IT IN LOCATION 401
0672 1723 TAD I CONTW3 /GET BOOT STRAP ENABLE CODE
0673 6153 LOCHR3 /LOAD CONTROL REGISTER 3
0674 7300 CLA CLL
0675 6164 EXECUT /LOAD THE BOOTSTRAP
0676 7602 HLT CLA /IF PROGRAM HALTED IT FAILED TO DO 1 OF FOLLOWING
/0011 SW=SW DISABLE BOOT WHEN RUNNING
/0032 POWER ON DISABLE BOOT WHEN RUNNING
/0013 SW=SW DISABLE BOOT WHEN RUNNING
/0033 POWER ON DISABLE BOOT WHEN RUNNING
/0015 SW=SW DISABLE BOOT WHEN RUNNING
/CLEAN SIMULATOR LOGIC
0677 6160 BOTHT2, CLRMOD
0700 7301 CLA CLL IAC
0701 1022 TAD OP2SEL
0702 7510 SPA
0703 6305 6305
0704 7300 CLA CLL
0705 1320 TAD SIMBOT /GET THE BOOTSTRAP BEING EXECUTED
0706 4770' JMS BOTCMP+2 /GO COMPARE THE BOOTSTRAP THAT WAS LOADED
0707 2323 ISL CONTW3 /ADD 1 TO BOOTSTRAP ENABLE ADDRESS
0710 2325 ISL HTSUBT /DONE WITH THE SUB-TEST ?
0711 5260 JMP BOTHT2 /NO, DO NEXT ENABLING CODE
0712 4767' JMS GOODBD /SIGNAL ACT LINE IF SELECTED
0713 2320 ISL SIMBOT /ADD 1 TO THE BOOTSTRAP SELECT
0714 2321 ISL CNTBOT /DONE ALL 3 BOOTSTRAPS?
0715 5214 JMP NXTBOT /NO, GO DO NEXT BOOTSTRAP
0716 4455 LOOP /LOOP ON TEST IF SR = 1000
0717 5766' JMP TEST22 /GO TO THE NEXT TEST
0720 0000 SIMBOT, 0
0721 0000 CNTBOT, 0
0722 0000 CONTW2, 0
0723 0000 CONTW3, 0
0724 0401 ADD401, 0401
0725 0000 HTSUBT, 0

```

/BOOTSTRAP RETURN ADDRESSES

```

0726 0642 BOOTR1, BOTHT1
0727 0677 BOOTR2, BOTHT2
0766 1041
0767 1701
0770 1402
0771 1463

```

0772 1155
 0773 1150
 0774 1517
 0775 0610
 0776 0200
 0777 4452
 1000

PAGE

/THE CAPS8 CASSETTE BOOT STRAP WILL LOAD INTO THE FOLLOWING LOCATIONS;

1000	7402	CAPS8, HLT	/1237
1001	7402	HLT	/1206
1002	7402	HLT	/6704
1003	7402	HLT	/6706
1004	7402	HLT	/6703
1005	7402	HLT	/5204
1006	7402	HLT	/7264
1007	7402	HLT	/6702
1010	7402	HLT	/7610
1011	7402	HLT	/3211
1012	7402	HLT	/3636
1013	7402	HLT	/1205
1014	7402	HLT	/6704
1015	7402	HLT	/6706
1016	7402	HLT	/6701
1017	7402	HLT	/5216
1020	7402	HLT	/7002
1021	7402	HLT	/7430
1022	7402	HLT	/1636
1023	7402	HLT	/7322
1024	7402	HLT	/3636
1025	7402	HLT	/7420
1026	7402	HLT	/2236
1027	7402	HLT	/2245
1030	7402	HLT	/5215
1031	7402	HLT	/7346
1032	7402	HLT	/7002
1033	7402	HLT	/3235
1034	7402	HLT	/5201
1035	7402	HLT	/7737
1036	7402	HLT	/3597
1037	7402	HLT	/7730
1040	7402	HLT	/TERMINATOR

.....
 /TEST 22 CHECKS THAT THE AUTO RESTART OCCURS AT THE APPROPRIATE ADDRESS, THIS
 /TEST USES THE SIMULATOR TO SELECT AND CAUSE A AUTO RESTART,

1041	4456	TEST22, SCOPLP	/SETUP TEST AND SCOPE LOOP ADDRESS
1042	1377	TAD (JMS I ATRST	/SETUP LOCATIONS 0 AND 200

1043	3000	DCA	INTSER	/
1044	1377	TAD	(JMS I ATRST	/
1045	3776	DCA	TEST18=1	/
1046	1375	TAD	(RSTAUT	/GET THE AUTO RESTART ADDRESS
1047	3022	DCA	AUTRST	/SAVE IT
1050	1374	TAD	(NOAUTO	/GET BOOT STRAP ADDRESS
1051	3653	DCA	I	/
1052	5255	JMS	,*2	/
1053	0401		,*3	/
1054	4454	NOAUTO, ERROM		/LOGIC DID A BOOT INSTEAD OF A AUTO RESTART
1055	4773	JMS	SETUP	/GO SETUP FOR TEST
1056	6160	AUTIST, CLRMOD		/CLEAR SIMULATOR MODULE
1057	1372	TAD	(RESADD	/GET THE ADDRESS OF AUTO RESTART TABLE
1060	1334	TAD	AUTSEL	/GET THE PROGRAM AUTO = RESTART TO BE EXECUTED
1061	3335	DCA	ADDRESS	/SAVE THE TABLE ADDRESS
1062	1371	TAD	(SELAUT	/GET THE CONTROL WORD 2 TABLE ADDRESS
1063	1334	TAD	AUTSEL	/ADD IN THE RESTART TO BE EXECUTED
1064	3336	DCA	CONW2	/SAVE THIS ADDRESS TO GET THE CONTROL WORD
1065	1022	TAD	OP2SEL	/CHECK TO SEE IF PROGRAM IS ON ACT LINE
1066	7710	SPA	CLA	/
1067	6305	6305		/DISABLE ACT LINE UNTIL AUTO RESTART IS DONE
1070	1736	TAD	I CONW2	/GET THE CONTROL WORD
1071	6152	LOJHG2		/LOAD CONTROL REGISTER 2
1072	7300	CLA	CLL	/
1073	1347	TAD	AUTENA	/GET THE ENABLE CONTROL WORD
1074	6153	LOJHG3		/LOAD CONTROL REGISTER 3
1075	7300	CLA	CLL	/
1076	6164	EXECUT		/EXECUTE A AUTO RESTART
1077	7602	HLT	CLA	/SHOULD DO A AUTO RESTART HERE=PRESS CONT FOR RETRY
1100	5256	JMP	AUTTST	/RETRY
1101	0000	RSTAUT, 0		/A AUTO RESTART SHOULD COME HERE
1102	6160	CLRMOD		/CLEAR SIMULATOR LOGIC
1103	7301	CLA	CLL	/SET BIT 11 TO A ONE
1104	1022	TAD	OP2SEL	/CHECK FOR THE ACT LINE
1105	7510	SPA		/IS IT HUNNING ON ACT LINE
1106	6305	6305		/YES, ENABLE ACT LINE
1107	7340	CLA	CLL	/SET THE AC TO MINUS 1
1110	1301	TAD	RSTAUT	/GET THE PC FROM THE AUTO RESTART
1111	7041	CIA		/NEGATE IT
1112	1735	TAD	I	/GET THE EXPECTED AUTO RESTART PC
1113	7650	SNA	CLA	/ARE THEY EQUAL?
1114	5325	JMP	GODAUT	/YES GO DO NEXT ADDRESS
1115	4454	ERROM		/EXPECTED AUTO RESTART ADDRESS NOT EQUAL TO /RETURN ADDRESS, PRESS CONT TO GET EXP AND ACT ADDRESS
1116	1735	TAD	I	/
1117	7402	HLT		/AC EQUALS EXPECTED AUTO RESTART ADDRESS
1120	7340	CLA	CLL	/
1121	1301	TAD	RSTAUT	/
1122	7402	HLT		/AC EQUALS ACTUAL AUTO RESTART ADDRESS
1123	7200	CLA	CLL	/
1124	5256	JMP	AUTTST	/DO SAME RESTART OVER AGAIN
1125	2334	GODAUT, IS2	AUTSEL	/ADD 1 TO PROGRAM SELECT RESTART
1126	2333	IS2	AUTCNT	/DONE ALL FOUR AUTO RESTARTS?
1127	5256	JMP	AUTTST	/NO,GO DO NEXT ONE
1130	4770	JMS	GOODBD	/SIGNAL ACT LINE OF A GOOD PASS IF ON IT

```

1131 4455      LOOP
1132 3767'     JMP      TEST23 /LOOP ON TEST IF SR = 1000

1133 0000      AUTONT, 0
1134 0000      AUTSEL, 0
1135 0000      ADDRHY, 0
1136 0000      CONWZ, 0

1137 4200      RESADU, 4200
1140 2000      2000
1141 0200      0200
1142 0000      0000

1143 1676      SELAUT, 1676 /AUTO RESTART AT 4200
1144 1674      1674 /AUTO RESTART AT 2000
1145 1672      1672 /AUTO RESTART AT 200
1146 1670      1670 /AUTO RESTART AT 0000

1147 0037      AUTENA, 0037 /POWER ON TRIGGERED AUTO RESTART

/CONTROL WOKD 2 BOOTSTRAP SELECT

1150 1672      BOTSEL, 1672 /HI=LOW PAPER TAPE SELECT
1151 1132      1132 /TC08 BOOTSTRAP SELECT
1152 0742      0742 /RF08/DF320 BOOTSTRAP SELECT

1153 0642      0642 /TAP6 CASSETTE BOOTSTRAP SELECT
1154 1252      1252 /RKB=E BOOTSTRAP SELECT

/CONTROL WOKD 3 BOOTSTRAP ENABLES (POWER ON OR SWITCH SW)

1155 0001      BOTENA, 0001 /SW=SW ENABLE BOOT WHEN RUNNING
1156 0003      0003 /SW=SW ENABLE BOOT WHEN RUNNING
1157 0007      0007 /SW=SW ENABLE BOOT WHEN RUNNING
1158 0011      0011 /SW=SW DISABLE BOOT WHEN RUNNING
1161 0032      0032 /POWER ON DISABLE BOOT WHEN RUNNING
1162 0013      0013 /SW=SW DISABLE BOOT WHEN RUNNING
1163 0033      0033 /POWER ON DISABLE BOOT WHEN RUNNING
1164 0017      0017 /SW=SW DISABLE BOOT WHEN RUNNING

1167 1201
1170 1701
1171 1143
1172 1137
1173 1517
1174 1054
1175 1101
1176 1200
1177 4452
1200

```

PAGE

.....

```

/TEST 29= USES THE SIMULATOR TO CHECK THAT AC LOW AND BATTERY EMPTY F/F'S
/CAN SKIP AND INTERRUPT AND THAT THEY CAN BE CLEARED,
/.....
1200 4452      JMS I  ATRST /AUTO RESTART HANDLER
TEST23, SC0PLP /SETUP TEST AND SCOPE LOOP ADDRESS

1201 4456      TAD      (ACLBAT
1202 1377      DCA      ATRST
1203 3052
1204 6007      CAF
1205 6160      CLRMOO /CLEAN ALL FLAGS
1206 3776'     DCA      ACNLOK /CLEAN SIMULATOR MODULE
1207 6101      SBE
1210 7410      SKP
1211 4454      ERRORM /BATTERY EMPTY IS SET
1212 6102      SPL
1213 7410      SKP /SKIP ON AC LOW
1214 4454      ERRORM /AC LOW F/F IS SET
1215 1253      TAD      K3000 /SET BITS 2 + 3 TO A 1
1216 6153      LO0RG3 /LOAD REGISTER 3 TO PULL AC LOW AND BATTERY EMPTY LOW
1217 7300      CLA      CLL
1220 6001      IOV
1221 0222      JMP      ,+1 /TURN THE INTERRUPT ON
1222 4454      ERRORM /AC LOW NOT SET OR FAILED TO INTERRUPT
1223 7610      SKP      CLA
1224 4454      ERRORM /AC LOW NOT SET BUT BATTERY EMPTY IS
1225 6102      SPL /SKIP ON AC LOW AS A LEVEL
1226 4454      ERRORM /AC LOW AS A LEVEL DID NOT SKIP
1227 6101      SBE /SKIP ON BATTERY EMPTY
1230 4454      ERRORM /BATTERY EMPTY NOT SET WITH BATTERY EMPTY WELD LOW
1231 1254      TAD      K1000 /SET CONTROL BIT 3 HIGH
1232 6153      LO0RG3 /LOAD THE CONTROL REGISTER
1233 7340      CLA CLL CMA
1234 3776'     DCA      ACNLOK /
1235 6001      IOV /TURN THE INTERRUPT ON
1236 0237      JMP      ,+1
1237 4454      ERRORM /BATTERY EMPTY NOT SET OR FAILED TO INT
1240 4454      ERRORM /AC LOW SET BUT BATTERY EMPTY ISNIT
1241 6153      LO0RG3 /OK, BATTERY EMPTY SET, LET AC LOW GO HIGH
1242 6101      SBE /SKIP ON BATTERY EMPTY
1243 7410      SKP
1244 4454      ERRORM /AC LOW FAILED TO CLEAR BATTERY EMPTY
1245 6102      SPL /SKIP ON AC LOW
1246 7410      SKP
1247 4454      ERRORM /AC LOW AS A LEVEL STILL SKIPPED
1250 6160      CLRMOO /CLEAN SIMULATOR TEST MODULE
1251 4455      LOOP
1252 0461      JMP I  PASEND /LOOP ON TEST IF SR = 1000
/END OF PROGRAM

1253 3000      K3000, 3000
1254 1000      K1000, 1000

```

.....

/TIMDIS = IS AN OPERATOR INTERVENTION TEST, THE OPERATOR MUST SET THE
/TIME SHARE ENABLE SWITCH TO THE TIME SHARE DISABLE POSITION, THE PROGRAM

/TRIES TO SET THE USER FLAG AND CHECKS THAT LAS, OSH, IOT, AND HALT
/DO NOT TRAP AND THAT HLT HALTS,
/*****

1255	4456	TIMDIS,	SCDPLP	/SETUP TEST AND SCOPE LOOPING ADDRESS
1256	6007	CAF		/CLEAR ALL FLAGS
1257	6264	CUF		/CLEAR USER BUFFER F/F
1260	6204	CINT		/CLEAR USER INTERRUPT F/F
1261	6001	IOW		/TURN THE INTERRUPT ON
1262	6274	SUF		/TRY TO SET THE USER BUFFER F/F
1263	6264	JMP	,*1	/TRY TO ENTER TIME SHARE MODE
1264	7494	OSR		/SHOULD TRAP HERE IF TIME SHARE NOT DISABLED
1265	7610	SKP	CLA	
1266	4454	ERRDN		/TIME SHARE NOT DISABLED=PROGRAM INTERRUPTED
1267	7604	LAS		/SHOULD TRAP HERE IF TIME SHARE NOT DISABLED
1270	7610	SKP	CLA	
1271	4454	ERRDN		/LAS TRAPPED WITHOUT TIME SHARE ENABLED
1272	6254	SINT		/SKIP ON USER INTERRUPT
1273	7610	SKP	CLA	
1274	4454	ERRDN		/IOT TRAPPED OR USER INTERRUPT SET
1275	7402	HLT		/PROGRAM SHOULD HALT HERE FOR COMPLETION
				/OF TIME SHARE DISABLE TEST
1276	7610	SKP	CLA	
1277	4454	ERRDN		/HLT TRAPPED
1300	6255	JMP	TIMDIS	/RETRY THE TEST

/THE FOLLOWING LOCATIONS CONTAINS THE CONTENTS OF THE HIGH PAPER TAPE
/BOOTSTRAP

1301	7737	PTPADU,	7737	/BOOTSTRAP WILL START LOADING INTO THIS ADDRESS
1302	7741		PTPCMP=PTPEND=1	/NUMBER OF LOCATIONS TO COMPARE
1303	6014	PTPUMP,	6014	
1304	3776		6776	
1305	7326		7326	
1306	1337		1337	
1307	2376		2376	
1310	5340		5340	
1311	6011		6011	
1312	5356		5356	
1313	3361		3361	
1314	1361		1361	
1315	3371		3371	
1316	1345		1345	
1317	3357		3357	
1320	1345		1345	
1321	3367		3367	
1322	6032		6032	
1323	6031		6031	
1324	5357		5357	
1325	6036		6036	
1326	7106		7106	
1327	7006		7006	
1330	7510		7510	

1331	5374		5374	
1332	7006		7006	
1333	6031		6031	
1334	5367		5367	
1335	6034		6034	
1336	7420		7420	
1337	3776		3776	
1340	3376		3376	
1341	5356	PTPEND,	5356	
1342	0000		0000	/TERMINATOR

/THE FOLLOWING LOCATIONS CONTAIN THE CONTENTS OF THE TC08 BOOTSTRAP

1343	7613	TCBADU,	7613	/BOOTSTRAP WILL START LOADING INTO THIS ADDRESS
1344	7767		TCBCMP=TCBEND=1	
1345	6774	TCBCMP,	6774	
1346	1222		1222	
1347	6766		6766	
1350	6771		6771	
1351	5210		5210	
1352	1223		1223	
1353	5215		5215	
1354	6600		6600	
1355	6220	TCBEND,	6220	
1356	7754		7754	
1357	7776		=2	/BOOTSTRAP WILL ALSO LOAD INTO 7754 + 7755
1360	7577		7577	/NUMBER OF LOCATIONS TO COMPARE
1361	7577		7577	
1362	0000		0	/TERMINATOR

/THE FOLLOWING LOCATIONS CONTAINS THE CONTENTS OF THE RF28/DF320 BOOTSTRAP

1363	7750	DSKADU,	7750	/BOOTSTRAP WILL START LOADING INTO THIS ADDRESS
1364	7773		RFDFCP=RFDFED=1	/NUMBER OF LOCATIONS TO COMPARE
1365	7600	RFDFCP,	7600	
1366	6633		6633	
1367	6622		6622	
1370	5352		5352	
1371	5752	RFDFED,	5752	
1372	0000		0000	/TERMINATOR

1376	1773			
1377	1740			
	1400	PAGE		

/*****
/TO RUN THE OPERATOR INTERVENTION BOOT STRAP COMPARE TEST, DO THE FOLLOWING:
/1, RUN CLRBOOT TO CLEAR THE BOOTSTRAP LOCATIONS IN MEMORY
/2, DISABLE ALL OPTIONS ASSOCIATED WITH THE BOOTSTRAP
/3, SET THE APPROPRIATE SELECT AND ENABLE SWITCHES FOR THE BOOTSTRAP
/4, SET THE HALT KEY


```

1526 5341      JMP      SETUP2
1527 3775'    SETUP1, DCA      SIMBOT /NO, GO GET THE MEMORY SIZE
1530 1775'    TAJ      SIMBOT /YES THAT DO ALL BOOT'S
1531 1065     TAJ      M5 /GET BOOTSTRAP SELECT
1532 3774'    DCA      CNTBOT /SUBTRACT 5
1533 1775'    TAJ      SIMBOT /SAVE IT
1534 3365     DCA      BOTCLR /GET BOOT NUMBER
1535 1776'    TAJ      AUTSEL /SAVE IT
1536 1064     TAJ      M4 /GET AUTO RESTART SELECT
1537 3773'    DCA      AUTCNT /SAVE THE NUMBER OF AUTO'S TO DO
1540 5717     JMP      I SETUP /RETURN TO DO BOOT OR AUTO=RESTART
1541 1021     SETUP2, TAJ  OP1SEL /GET THE HARDWARE CONFIGURATION
1542 0372     AND      KK3 /MASK OFF FIELD 7 MEMORY SIZE
1543 7450     SNA      SNA /IS IT 1K OF MEMORY
1544 5354     JMP      SET1K /YES, SETUP TO DO 1 BOOT OR 2 AUTO=RESTART
1545 1062     TAJ      M1 /SUBTRACT 1
1546 7450     SNA      SNA /IS IT 2K OF MEMORY
1547 5360     JMP      SET2K /YES, DO ONE BOOT AND 3 AUTO'S
1550 1062     TAJ      M1 /SUBTRACT 1
1551 7650     SNA      CLA /IS IT 3K OF MEMORY
1552 5363     JMP      SET3K /YES, SETUP TO DO 2 BOOTS AND 4 AUTO'S
1553 5327     JMP      SETUP1 /MUST BE 4K OF MEMORY=DO ALL
1554 7305     SET1K, CLA  CLL IAC RAL
1555 3776'    DCA      AUTSEL
1556 7307     CLA  CLL IAC RTL
1557 5327     JMP      SETUP1
1560 7301     SET2K, CLA  CLL IAC
1561 3776'    DCA      AUTSEL
1562 5356     JMP      I=4
1563 7325     SET3K, CLA  CLL CML IAC RAL
1564 5327     JMP      SETUP1

1565 0000     BOTCLR, 0
1566 0000     SAVSTH, 0
1567 0000     BOTADU, 0
1570 0000     BOTSAU, 0
1571 0000     BOTCNT, 0
1572 0003     KK3, 3

1573 1133
1574 0721
1575 0720
1576 1134
1577 0506
1600      PAGE
    
```

```

1600 0000     ACTLIN, 0
1601 1022     TAJ      OP2SEL
1602 7700     SNA      CLA
1603 5600     JMP      I ACTLIN /IS THE PROGRAM RUNNING ON ACT LINE?
1604 1037     TAJ      FLDLIM /NO, RETURN
1605 1111     TAJ      M70 /GET THE FIELD LIMIT
    
```

```

1606 7640     SEA      CLA /IS THE FIELD LIMIT EQUAL TO FIELD 7?
1607 5600     JMP      I ACTLIN /NO, RETURN TO TEST
1608 1040     TAJ      UPERLM /GET THE UPPER ADDRESS LIMIT
1609 7001     IAC
1610 7640     SEA      CLA /ADD 1 TO IT
1611 5600     JMP      I ACTLIN /WAS IT 7777
1612 7392     CLA  CLL CMA RTR /NO, RETURN
1613 3040     DCA      UPERLM /SET LAST ADDRESS = 5777
1614 5600     JMP      I ACTLIN /SAVE IT
1615 5600     JMP      I ACTLIN /RETURN TO PROGRAM

1617 1022     ENDPAS, TAJ  OP2SEL /CHECK FOR ACT LINE
1618 7700     SNA      CLA /IS THE PROGRAM RUNNING ON ACT LINE
1619 5234     JMP      ENDING /NO GO CHECK FOR SR 3 TO HALT AT END OF A PASS
1620 1021     TAJ      OP1SEL /GET THE HARDWARE CONFIGURATION
1621 0143     AND      K200 /CHECK FOR THE SIMULATOR
1622 7640     SEA      CLA /WAS THE SIMULATOR SELECTED
1623 5234     JMP      ENDING /YES, ALREADY NOTIFIED PROM OF GOOD PAS
1624 2242     ISE      PRGPAS /CHECK 1/2 SECOND COUNT
1625 5234     JMP      ENDING /NOT 1/2 SECOND YET
1626 1377     TAJ      I=144 /RESET THE COUNTER
1627 3242     DCA      PRGPAS
1628 6272     CIF      70 /CHANGE INSTRUCTION FIELD TO 7
1629 4451     JMS      I GOODPS /SIGNAL THE PROM
1630 4341     ENDING, JMS  SWCHK /CHECK SR 3 TO HALT ON A PROGRAM PASS
1631 7006     RTN
1632 7004     RAL
1633 7710     SPA      CLA
1634 7402     HLT
1635 5776'    JMP      0201 /END UP A COMPLETE PROGRAM PASS
1636 5776'    /RESTART THE PROGRAM

1642 7634     PRGPAS, =144

1643 7010     POWPAL, RAR
1644 3251     DCA      LINK
1645 1000     TAJ      INTSER
1646 3252     DCA      PC
1647 6103     CAL
1648 4452     JMS      I ATRST /CLEAN AC LOW F/F
1649 4452     /RETURN TO THE PROGRAM

1651 0000     LINK, 0
1652 0000     PC, 0

1653 0000     PRGHST, 0
1654 6102     SPL
1655 7610     SKP      CLA /SKIP ON AC LOW AS A LEVEL
1656 4254     JMP      I=2
1657 5453     JMP      I TEST /RETURN TO TEST BEING EXECUTED AND START OVER

1660 0000     TESTAU, 0
1661 7340     CLA  CLL CMA
1662 1260     TAJ      TESTAD
    
```

1663	3053		DCA	TEST	
1664	1379		TAD	(PRGRST	
1665	3052		DCA	AUTRST	
1666	5660		JMP	TESTAD	
1667	1021	BAT5MT,	TAD	OP1SEL	/GET HARDWARE CONFIGURATION
1670	0143		AND	K200	
1671	7650		SNA	CLA	
1672	5277		JMP	DEAD	/MACHINE GOING DOWN = STOP EVERYTHING
1673	3373		DCA	ACNLOK	
1674	2000		ISE	INTSER	
1675	2000		ISE	INTSER	
1676	5400		JMP	INTSER	
1677	7402	DEAD,	HLT		/ITS ALL OVER NOW = GOOD=BYE
1700	5453		JMP	TEST	
1701	0000	GOODBU,	0		
1702	1022		TAD	OP2SEL	/GET HARDWARE CONFIGURATION
1703	7700		SMA	CLA	/IS THE PROGRAM RUNNING ON ACT LINE
1704	5701		JMP	GOODBD	/NO RETURN TO PROGRAM
1705	5272		CIF	70	/CHANGE INSTRUCTION FIELD TO FIELD 7
1706	4451		JMS	GOODPS	/SIGNAL ACT LINE PROGRAM STILL RUNNING
1707	5701		JMP	GOODBD	/RETURN TO PROGRAM
1710	0000	ERRORX,	0		/ERROR ROUTINE
1711	7300		CLA	CLL	
1712	1022		TAD	OP2SEL	/CHECK FOR ACT LINE
1713	7700		SMA	CLA	
1714	5326		JMP	CHKINH	
1715	1021		TAD	OP1SEL	
1716	0143		AND	K200	
1717	7640		SEA	CLA	
1720	6160		CLRMOD		
1721	6002		IOF		/TURN THE INTERRUPT OFF
1722	7240		CLA	CHA	
1723	1314		TAD	ERRORX	
1724	6272		CIF	70	
1725	5450		JMP	BADPAS	/GO TO ROM FOR ERROR
1726	4341	CHKINH,	JMS	SWCHK	/CHECK FOR SR 0(1) TO INHIBIT ERROR HALT
1727	7710		SPA	CLA	/IS SR 0 SET TO A ONE
1730	5634		JMP	ERLPSW	/YES, GO CHECK SR 1 TO LOOP ON ERROR
1731	7340		CLA	CLL	
1732	1310		TAD	CHA	/SUBTRACT ONE FROM JMS ERROR PC
1733	7402		HLT	ERRORX	/AC CONTAINS THE ADDRESS WHERE THE ERROR
1734	4341	ERLPSW,	JMS	SWCHK	/WAS DETECTED BY THE PROGRAM, REFER
1735	7004		RAI		/TO THE PROGRAM LISTING FOR ERROR
1736	7710		SPA	CLA	/EXPLANATION AND THE TEST DESCRIPTION,
1737	5453		JMP	TEST	/CHECK THE SWITCH REGISTER TO LOOP ON ERROR
1740	5710		JMP	ERRORX	

1741	0000	SWCHK,	0		
1742	7300		CLA	CLL	
1743	1021		TAD	OP1SEL	/GET THE HARDWARE STATUS WORD
1744	7700		SMA	CLA	/IS THE HARDWARE FRONT PANEL SELECTED
1745	5350		JMP	,+3	/NO, USE THE PSEUDO SWITCH REGISTER
1746	7604		LAS		
1747	5741		JMP	SWCHK	/RETURN
1750	1020		TAD	SWITCH	/THE PSEUDO SWITCH REGISTER
1751	5741		JMP	SWCHK	/RETURN
1752	0000	TSTLOP,	0		/ROUTINE TO CHECK SK 2 TO LOOP ON TEST
1753	4341		JMS	SWCHK	/GO GET THE SWITCH REGISTER
1754	7006		RTI		
1755	7700		SMA	CLA	
1756	5752		JMP	TSTLOP	/GO TO NEXT TEST
1757	5453		JMP	TEST	/LOOP ON SAME TEST
1760	0000	ACLBAT,	0		
1761	1373		TAD	ACNLOK	/LOOK AT RETURN FOR AC LOW OR BATTERY EMPTY
1762	7640		SEA	CLA	
1763	5366		JMP	,+3	
1764	2000		ISE	INTSER	
1765	5400		JMP	INTSER	
1766	3373		DCA	ACNLOK	
1767	6101		SBE		/SKIP ON BATTERY EMPTY
1770	5364		JMP	,+4	
1771	2000		ISE	INTSER	
1772	5364		JMP	,+6	
1773	0000	ACNLOK,	0		
1775	1653				
1776	0201				
1777	7634				
	2000		PAGE		
	0200		*200		

0000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0100	11111111	11111111	11111111	11111111	11111111	11111111	11110000	00000000	00000000
0200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0300	11111111	11111111	11111111	11111111	11111111	11111111	11110000	00000000	00000001
0400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0500	11111111	11111111	11111111	00000000	00000000	00000000	00000000	00000000	00000000
0600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0700	11111111	11111111	11111111	00000000	00000000	00000000	00000000	00000011	11111111
1000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1100	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111001	11111111
1200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1300	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11100011
1400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1500	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1700	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11110011

2000
2100

2200
2300

2400
2500

2600
2700

3000
3100

3200
3300

3400
3500

3600
3700

4000
4100

4200
4300

4400
4500

4600
4700

5000
5100

5200
5300

5400
5500

5600
5700

6000
6100

6200
6300

6400
6500

6600
6700

7000
7100

7200
7300

7400
7500

7600
7700

ACLBAT	1760	DATPAT	0042	4100	0113	PYPCMP	1303
ACNL0K	1773	DATREC	0035	4100	0117	PYPEND	1341
ACTLIN	1600	DEAD	1677	4100	0120	RDF	6214
ADD401	0724	DS<ADD	1363	41016	0121	REDEMA	6155
ADDONT	0047	EM41	0361	41025	0122	RESADD	1137
ADDRES	1135	EM42	0362	41034	0123	RFDPCP	1365
AUTCNT	1133	EM43	0363	41043	0124	RFDPCD	1371
AUTENA	1147	EMACLR	0211	41052	0125	RIB	6234
AUTHST	0052	EMAI F1	0312	41061	0126	RIF	6224
AUTSEL	1134	EMAI F2	0331	41070	0127	RKBADD	0514
AUTTST	1056	EMAI F3	0344	411	0070	RKBCMP	0516
ADDPAS	0050	ENDPAS	1634	41100	0130	RKBE	0023
RATEHT	1667	ENDPAS	1617	4125	0114	RKEND	0524
BOOTOK	1461	ERLPSW	1734	4152	0115	RMP	6244
BOOTR1	0726	ERR0R	4454	416	0071	RSTAUT	1101
BOOTR2	0727	ERR0RX	1710	42	0063	RYF	6005
BOOTTB	0506	EXECUT	0164	420	0072	SAVESZ	0036
BOOTAD	1567	FLDLIM	0037	422	0073	SAVSTR	1566
BOOTCLR	1565	G03AUT	1125	425	0074	SAVWFD	0046
BOOTCMP	1400	G030HD	1701	430	0075	SBE	6101
BOOTCNT	1571	G030UP	1443	4300	0110	SC0PLP	4456
BOYLENA	1155	G03UPS	0051	433	0076	SELAUT	1143
BOYEND	1511	GTF	0004	434	0077	SET1K	1554
BOYRT1	0642	HG4LIM	0044	44	0064	SET2K	1560
BOYRT2	0677	HLT	7402	440	0100	SET3K	1563
BOYSAD	1570	INTSER	0000	44100	0131	SETUP	1517
BOYSEL	1150	K10	0135	443	0101	SETUP1	1527
BOYSRT	0725	K1200	1254	444	0102	SETUP2	1541
BOYST1	0623	K125	0141	45	0065	SIMBOT	0720
BOYST2	0660	K132	0142	450	0103	SINT	6254
CAP	6007	K1777	0145	45000	0132	SKON	6000
CAL	6103	K200	0143	45100	0133	SKPEMA	6166
CAPSR	1000	K2000	0146	452	0104	SPL	6102
CDF	6201	K3000	1253	455	0105	SUF	6274
CDPCNK	0033	K37	0136	460	0106	SWCHK	1741
CHKCDF	0034	K400	0144	461	0107	SWTCH	0020
CHKINH	1726	K4100	0153	466	0110	TABADD	0443
CIF	6202	K6201	0049	47	0066	TABCHP	0445
CIFCDF	6203	K7	0134	470	0111	TABEND	0504
CINT	6204	K70	0137	477	0112	TCBADD	1343
CLEARB	1463	K7677	0152	480AUTO	1094	TCBCHP	1345
CLRBOT	1465	K77	0140	480R00T	0610	TCBEND	1355
CLREMA	6154	K7707	0150	480R00T	0614	TEST	0053
CLREMG	0360	K7757	0151	0P1SEL	0021	TEST18	0201
CLRH0D	6160	K7774	0147	0P21K3	0000	TEST19	0275
CLRSIM	6150	KK3	1572	0P2SEL	0022	TEST20	0402
CNTBOT	0721	LINK	1651	PASEND	0061	TEST21	0600
COMPAR	1425	LOJRG2	6152	PC	1652	TEST22	1041
CONTR2	0722	LOJRG3	6153	P0WFAL	1643	TEST23	1201
CONTR3	0723	LOOP	4455	PRGPHS	1642	TESTAD	1660
CONR2	1136	M1	0062	PRGPHS	1653	TIMJIS	1255
CUF	6264	M10	0067	PTPADU	1301	TST1RA	0225

TST18B	0244
TST18C	0297
TST19A	0310
TST19B	0326
TST19C	0341
TST1OP	1752
UPERLM	0040
MRKADD	0043
MRKFLD	0041
XBAT	0060
XPHRFL	0057

ERRORS DETECTED: 0
 LINKS GENERATED: 27
 RUN=TIME: 18 SECONDS
 3K CORE USED

/KMB=A OPTION TEST 2 MAINDEC=08-DJKMA=A=L 1K PART 4
/
/COPYRIGHT (C) 1974, DIGITAL EQUIPMENT CORPORATION
/
/PROGRAMMER: BRUCE HANSEN
/

////////////////////////////////////
/THE FOLLOWING LISTING WILL CORRESPOND TO THE PAPER TAPE LABELED MAINDEC=08-DJKMA=A=PM4,
/1K PART 4, THIS PAPER TAPE AND LISTING WILL BE THE LAST OF FOUR 1K SEGMENTED
/PAPER TAPES AND LISTINGS FOR COMPUTERS WITH LESS THAN 4K OF MEMORY,
////////////////////////////////////

/KMB=A OPTION TEST 2 MAINDEC=08-DJKMA=A=L 1K PART 4
/
/COPYRIGHT 1974, DIGITAL EQUIPMENT CORP., MAYNARD, MASS., 01754
/
/PDP=8A OPTION TEST 2 TESTS THE MEMORY EXTENTION/TIME SHARE CONTROL,
/POWER FAIL/AUTO RESTART, AND BOOTSTRAP LOADERS

6000 SKN=6000
6007 CAF=6007
7402 HLT=7402

/SWITCH REGISTER SETTINGS

/SR0=1 INHIBIT ERROR HALT
/SR1=1 LOOP ON ERROR
/SR2=1 LOOP ON TEST
/SR3=1 HALT AT COMPLETION OF A PROGRAM PASS

/MEMORY EXTENTION/TIME SHARE INSTRUCTIONS

6004 GTF=6004 /GET FLAGS, READS THE FOLLOWING MACHINE STATES
/INTO THE INDICATED BITS OF THE AC1
/AC0 LINE
/AC2 INTERRUPT REQUEST
/AC4 INTERRUPT ENABLE F/F
/AC5 USER FLAG
/AC6=11 SAVE FIELD REGISTER

6005 RTF=6005 /RESTORE THE FLAGS, RTF LOADS THE LINK FROM AC0,
/LOADS THE USER BUFFER F/F, INSTRUCTION BUFFER AND
/DATA FIELD WITH AC5, AC6=8, AC 9=11 AND INHIBITS
/PROCESSOR INTERRUPTS UNTIL NEXT JMP OR JMS INSTRUCTION,
/AT THE END OF THE JMP OR JMS, THE CONTENTS OF THE U,B, + I,B,
/ARE LOADED INTO USER FIELD F/F, AND THE I,F,, INTERRUPT ENABLE
/IS SET AND INTERRUPT INHIBIT IS CLEARED

6234 RIB=6234 /READ THE INTERRUPT BUFFER

6244 RNF=6244 /RESTORES MEMORY FLAGS

6206 CINT=6206 /CLEAR USER INTERRUPT FLIP=FLOP

6254 SINT=6254 /SKIP ON USER INTERRUPT FLIP=FLOP

6264 CUF=6264 /CLEAR USER BUFFER FLIP=FLOP

6274 SUF=6274 /SET USER BUFFER FLIP=FLOP (ENTER TIME SAME MODE)AND
/INHIBITS PROCESSOR INTERRUPTS UNTIL THE NEXT JMP OR
/JMS INSTRUCTION, AT THE END OF THE JMP OR JMS
/INSTRUCTION, THE USER BUFR IS LOADED INTO THE USER
/FIELD F/F,

6201 CDF=6201 /CHANGE DATA FIELD

```

6202 CIF=6202 /CHANGE INSTRUCTION FIELD
6214 RDP=6214 /READ THE DATA FIELD INTO AC BITS 6=8
6224 RIF=6224 /READ THE INSTRUCTION FIELD INTO AC BITS 6=8
6203 CIFCDF=6203 /PERFORMS THE CIF AND CDF FUNCTIONS

/POWER FAIL INSTRUCTIONS
6102 SPL=6102 /SKIP ON AC LOW FLIP=FLOP
6103 CAL=6103 /CLEAR AC LOW FLIP=FLOP
6101 SBE=6101 /SKIP ON BATTERY EMPTY FLIP=FLOP

/OPTION BOARD 2 SIMULATOR IOT/IS
6190 CLRSM=6190 /CLEAR CONTROL REGISTERS
6192 LODRG2=6192 /LOAD CONTROL REGISTER 2
6193 LODRG3=6193 /LOAD CONTROL REGISTER 3
6194 CLREMA=6194 /CLEAR EMA CATCHER LOGIC
6195 REDEMA=6195 /READ EMA CATCHER REGISTER
6160 CLRM0U=6160 /CLEAR TEST MODULE LOGIC
6164 EXECUT=6164 /EXECUT AND CONTROL WORD 3 BIT 7 =1 ISSUE A POWER ON PULSE
/EXECUT AND CONTROL WORD 3 BIT 7 =0 ISSUE A SWITCH SW PULSE
6166 SKPEMA=6166 /SKPEMA AND CONTROL WORD 3 BIT 3 =1 EMA INTERRUPT AND SKIP ENABLE
/SKPEMA AND CONTROL WORD 3 BIT 3 =0 EMA INTERRUPT AND SKIP DISABLE

/OPTION BOARD2 SIMULATOR CONTROL WORD 2 BIT ASSIGNMENTS
/
/BITS 0 = 1 NOT USED
/BITS 2 = 5 BOOT STRAP PROGRAM SELECT
/BITS 9 = 11 AUTO=RESTART ADDRESS SELECT

/OPTION BOARD2 SIMULATOR CONTROL WORD 3 BIT ASSIGNMENTS
/
/BIT 0 TIME SHARE 0=ENABLED 1=DISABLED
/BIT 1 AC LOW (L) 1=PULLED LOW 0=FREE STATE
/BIT 2 BATT EMPTY 1=BATT EMPTY PULLED LOW 0=FREE STATE
/BIT 3 1=EMA INTERRUPT/SKIP ENABLE 0=EMA INTERRUPT SKIP DISABLE
/BITS 4 = 6 NOT USED
/BIT 7 1=POWER ON PULSE WITH EXECUT 0=SWITCH SW PULSE WITH EXECUT
/BIT 8 1=DISABLES BOOTSTRAP WHILE RUNNING 0=ENABLES BOOTSTRAP WHILE RUNNING
/BIT 9 = 11 AUTO=RESTART/BOOT STRAP ENABLE CODE
    
```

```

0000 00 /
0000 0000 INTSER, 0 /JMS I AUTHST PLACED HERE FOR SIMULATOR AUTO RESTART
0001 3035 DCA DATREC
0002 6102 SP /SKIP ON AC LOW
0003 7410 SKP
0004 5487 JMP I XPRFL /POWER GOING DOWN
0005 6101 SBE /SKIP ON BATTERY EMPTY
    
```

```

0006 7410 SKP
0007 5480 JMP I XBAT /GO HALT THE COMPUTER ,ITS ALL OVER
0010 6224 RIF /READ THE INSTRUCTION FIELD
0011 7640 SZA CLA
0012 4454 ERRON /I,F, IS NOT 0 AFTER A INTERRUPT
0013 6214 RDP /READ THE DATA FIELD
0014 7640 SZA CLA
0015 4454 ERRON /D,I,F, IS NOT 0 AFTER A INTERRUPT
0016 2000 ISE INTSER /ADD 1 TO THE INTERRUPTED PC
0017 5480 JMP I INTSER /RETURN TO THE PROGRAM

0020 0020 *20
0020 0000 SWITCH, 0 /PSEUDO SWITCH REGISTER IF BIT 0=0 OF OP1SEL
0021 1000 OP1SEL, 1000
/
/BIT 0=0 USE LOC 20 AS A PSEUDO S,R,
/BIT 0=1 USE HARDWARE FRONT PANEL S,R,
/BIT 1=1 HAS BA OPTION 1
/BIT 2=1 HAS BA OPTION 2
/BIT 3=1 HAS BA CPU SIMULATOR
/BIT 4=1 HAS BA OPTION 1 + 2 TEST MODULE
/BIT 5=1 PROGRAM ON BA XOR
/BIT 6=1 HAS PDP-8E TYPE CPU
/BITS 7=11 MEMORY SIZE = 0'S = 1K, 37=32K,
/MEMORY SIZE CAN BE INCREASED IN 1K INCREMENTS
/BY ADDING A 1 TO THE NUMBER IN BITS 7=11,

0022 0000 OP2SEL, 0
/RRKGE BOOT STRAP WILL LOAD INTO THE FOLLOWING LOCATIONS

0023 7402 RRKE, HLT /2000
0024 7402 HLT /6745
0025 7402 HLT /0023
0026 7402 HLT /7650
0027 7402 HLT /5024
0030 7402 HLT /6733
0031 7402 HLT /5031
0032 7402 HLT /TERMINATOR
0033 0000 CDFCHK, 0
0034 0033 CHKCDF, CDFCHK
0035 0000 DATHEG, 0
0036 0000 SAVESE, 0
0037 0000 FLDLIM, 0
0040 0000 UPEHLM, 0
0041 0000 WRKFLD, 0
0042 0000 DATPAT, 0
0043 0000 WRKADU, 0
0044 0000 HGHLIM, 0
0045 6201 K6201, 6201
0046 0000 SAVHFD, 0
0047 0000 ADDCNT, 0
0050 6520 BADPAS, 6520
0051 6500 COOUPS, 6500
0052 0453 AUTHST, PRGNST
0053 0000 TEST, 0 /SCOPE LOOP AND TEST LOOP ADDRESS
    
```

```

0054 4454 ERROR= JMS I ;
0510 ; ERRORX
0055 4455 LOOP= JMS I ;
0552 ; TSTLOP
0056 4456 SCOPLP= JMS I ;
0460 ; TESTAD

0057 0443 XPWFAL, POWFAL
0060 0467 XBAT, BATEMT
0061 0417 PASENU, ENDPAS
    
```

/CONSTANTS USED BY THE PROGRAM

```

0062 7777 M1, =1
0063 7776 M2, =2
0064 7774 M4, =4
0065 7773 M5, =5
0066 7771 M7, =7
0067 7770 M10, =10
0070 7767 M11, =11
0071 7762 M16, =16
0072 7760 M20, =20
0073 7756 M22, =22
0074 7753 M25, =25
0075 7750 M30, =30
0076 7745 M33, =33
0077 7744 M34, =34
0100 7740 M40, =40
0101 7735 M43, =43
0102 7734 M44, =44
0103 7730 M50, =50
0104 7726 M52, =52
0105 7723 M55, =55
0106 7720 M60, =60
0107 7717 M61, =61
0110 7712 M66, =66
0111 7710 M70, =70
0112 7701 M77, =77
0113 7700 M100, =100
0114 7653 M125, =125
0115 7626 M152, =152
0116 7500 M300, =300
0117 7000 M1000, =1000
0120 6771 M1007, =1007
0121 6742 M1010, =1010
0122 6753 M1025, =1025
0123 6744 M1034, =1034
0124 6735 M1043, =1043
0125 6726 M1052, =1052
0126 6717 M1061, =1061
0127 6710 M1070, =1070
0130 6700 M1100, =1100
0131 5700 M4100, =4100
    
```

```

0132 3000 M5000, =5000
0133 2700 M5100, =5100

0134 0007 K7, 7
0135 0010 K10, 10
0136 0037 K37, 37
0137 0070 K70, 70
0140 0077 K77, 77
0141 0125 K125, 125
0142 0152 K152, 152
0143 0200 K200, 200
0144 0400 K400, 400
0145 1777 K1777, 1777
0146 2000 K2000, 2000
0147 7774 K7774, 7774
0150 7707 K7707, 7707
0151 7757 K7757, 7757
0152 7677 K7677, 7677
0153 4100 K4100, 4100

0200 =200
    
```

```

/.....
/AUTO = IS AN OPERATOR INTERVENTION TEST TO CHECK POWER-FAIL/AUTO-RESTART,
/WHEN THE PROGRAM IS STARTED, IT FILLS LOCATIONS 5200 TO 7777 (4K) OR 5200 TO 5777 (3K) WITH A
/COMPLEMENTING DATA PATTERN (5250 = 2929), AND THEN HALTS. THE OPERATOR
/AT THIS TIME MUST SET THE APPROPRIATE AUTO RESTART SWITCHES ON THE
/MODULE, HE THEN SIGNIFY TO THE PROGRAM VIA FRONT PANEL SWITCH
/REGISTER OR THE PSEUDO SWITCH REGISTER, WHICHEVER IS SELECTED, THE
/AUTO RESTART TO BE TESTED (0000=RESTART AT 4200) 0001=RESTART AT 2000)
/0002=RESTART AT 0200) 0003=RESTART AT 0000), THE OPERATOR THEN PASSES
/CONTINUE", THE PROGRAM THEN STARTS COMPARING DATA, WAITING FOR THE
/OPERATOR TO PULL THE LINE CORD, WHEN THE AC LINE CORD IS PULLED, THE
/PROGRAM SHOULD HALT AT LOCATION AC000N, THE OPERATOR SHOULD THEN PLUG
/THE LINE CORD BACK IN, AT THIS TIME THE PROGRAM SHOULD DO A AUTO RESTART
/TO THE ADDRESS SELECTED, THE PROGRAM THEN CHECKS FOR THE CORRECT
/AUTO RESTART AND THEN GOES BACK TO COMPARING DATA, THE ABOVE SEQUENCE
/OF UNPLUGGING AND PLUGGING LINE CORD SHOULD BE DONE SEVERAL TIMES FOR EACH
/AUTO RESTART.
///WARNING=THE BATTERY SUPPLY SHOULD BE FULLY CHARGED/////
/.....
    
```

```

0200 7000 NOP/JMS I ATRST
0201 4456 AUTG, SCOPLP /SETUP TEST AND SCOPE LOOP ADDRESS
0202 6007 CDF /CLEAR ALL FLAGS
0203 1021 TAJ DPSEL /GET THE HARDWARE CONFIGURATION
0204 0143 AND K200
0205 7640 SEA CLA
0206 6160 CLRMOO /SIMULATOR SELECTED CLEAR TEST MODULE
    
```

```

0207 1377      TAJ  (OPRINT
0210 3092      DCA  ATRST
0211 1376      DCA  (BUFFER
0213 3302      DCA  FILLIT
0215 1303      TAJ  BUFPNT
0219 3304      DCA  CNTBUF
0219 1306      TAJ  K5252
0216 3305      DCA  BUFPAT
0217 1305      TAJ  BUFPAT
0220 3702      DCA  I  FILLIT
0221 1305      TAJ  BUFPAT
0222 7040      CMA
0223 3305      DCA  BUFPAT
0224 2302      ISZ  FILLIT
0225 2304      ISZ  CNTBUF
0226 5217      JMP*
0227 7402      HLI  ,=7
0230 1021      TAJ
0231 7500      SMA  OP1SEL
0232 5235      JMP
0233 7604      LAS  ,+3
0234 7410      SKP
0235 1020      TAJ  SWITCH
0236 0307      AND  K3
0237 1375      TAJ  (RESADD
0240 3310      DCA  MANRST
0241 1710      TAJ  I  MANRST
0242 3310      DCA  MANRST
0243 1376      STRCMP, TAJ  (BUFFER
0244 3302      DCA  FILLIT
0245 1303      TAJ  BUFPNT
0246 3304      DCA  CNTBUF
0247 1306      TAJ  K5252
0250 3305      DCA  BUFPAT
0251 6001      CMPBUF, IOV
0252 1702      TAJ  I  FILLIT
0253 7041      CIA  I
0254 1305      TAJ  BUFPAT
0255 7650      SNA  CLA
0256 5272      JMP  HUFQOD
0257 4454      ERROR

0260 1302      TAJ  FILLIT
0261 7402      HLI
0262 7300      CLA  CLL
0263 1305      TAJ  BUFPAT
0264 7402      HLI
0265 7300      CLA  CLL
0266 1702      TAJ  I  FILLIT
0267 7402      HLI
0270 7300      CLA  CLL
0271 5453      JMP  I  TEST
0272 1305      BUFGOU, TAJ  BUFPAT
0273 7040      CMA

```

```

/GET THE ADDRESS FOR THE INTERRUPT ROUTINE
/SAVE IT
/GET THE ADDRESS OF TEST BUFFER
/SAVE IT
/GET THE NUMBER OF WORDS TO FILL THE BUFFER
/SAVE IT
/THE FIRST WORD IN THE BUFFER WILL BE 5252
/SAVE THE WORD
/GET THE WORD
/PUT IT IN THE BUFFER
/GET THE WORD
/COMPLEMENT IT
/INCREMENT BUFFER ADDRESS
/DOONE?
/NO KEEP FILLING THE BUFFER
/SET THE SWITCH REGISTER OR PSEUDO S,R
/TO THE AUTO-RESTART TO BE EXECUTED
/GET THE HARDWARE CONFIGURATION
/IS THE HARDWARE S,R, BEING USED
/NO USE THE PSEUDO SWITCH REGISTER
/MASK OFF BITS 12 AND 11
/ADD THE AUTO RESTART TABLE ADDRESS TO IT
/SAVE IT
/GET THE AUTO RESTART TO BE EXECUTED
/SAVE IT FOR COMPARISON AFTER RESTART
/GET THE BUFFER ADDRESS
/SAVE IT
/GET THE BUFFER SIZE
/SAVE IT
/SETUP INITIAL PATTERN
/TURN THE INTERRUPT ON
/GET THE WORD FROM BUFFER
/NEGATE IT
/GET THE WORD EXPECTED
/WORD COMPARED GO INCREMENT COUNTER
/DATA WORDS DIDNT COMPARE. PRESS
/CONT" FOR ADDRESS AND GOOD AND BAD DATA
/
/AC=BUFFER ADDRESS WHERE ERROR WAS DETECTED
/
/AC = GOOD DATA WORD
/
/AC = BAD DATA WORD = PRESS "CONT" TO
/RETRY THE COMPLETE TEST
/DO THE TEST OVER
/GET THE DATA PATTERN
/NEGATE IT

```

```

0274 3305      DCA  BUFPAT
0275 2302      ISZ  FILLIT
0276 7000      NOP
0277 2304      ISZ  CNTBUF
0300 5231      JMP  CMPBUF
0301 5243      JMP  STRCMP

0302 0000      FILLIT, 0
0303 6000      BUFPNT, =1200
0304 0000      CNTBUF, 0
0305 0000      BUFPAT, 0
0306 5252      K5252, 5252
0307 0003      K3, 3
0310 0000      MANRST, 0

0311 0000      OPRRET, 0
0312 7340      CLA  CLL  CMA
0313 1311      TAJ  OPRRET
0314 7041      CIA
0315 1310      TAJ  MANRST
0316 7650      SNA  CLA
0317 5326      JMP  RESET
0320 4494      ERROR

0321 1310      TAJ  MANRST
0322 7402      HLI
0323 7340      CLA  CLL  CMA
0324 1311      TAJ  OPRRET
0325 7402      HLI
0326 7300      RESET, CLA  CLL
0327 1377      TAJ  (OPRINT
0330 3092      DCA  ATRST
0331 1774      TAJ  PC
0332 3340      DCA  RETPRG
0333 1773      TAJ  LINK
0334 7004      RAL
0335 1035      TAJ  DATREC
0336 6001      IOV
0337 5740      JMP  I  RETPRG

0340 0000      RETPRG, 0
0341 0034      K34, 34
0342 0001      K1, 1

0343 0000      OPRINT, 0
0344 1372      TAJ  (JMS I ATRST
0345 3000      DCA  INTSER
0346 1372      TAJ  (JMS I ATRST
0347 3200      DCA  AUTO=1
0350 1371      TAJ  (OPRRET

```

```

/SAVE IT FOR NEXT COMPARE
/INCREMENT ADDRESS TO COMPARE
/THIS IS NEEDED FOR ISZ OVERFLOW
/DOONE COMPLETE BUFFER?
/NO CONTINUE
/RE=INITIALIZE COMPARE LOOP AND COMPARE

/PROGRAM COMES HERE FROM AN AUTO RESTART
/GET THE ADDRESS FROM AUTO RESTART
/NEGATE IT
/GET EXPECTED RESTART
/ARE THEY EQUAL?
/YES RESET AC AND LINK AND RETURN TO COMPARE
/THE AUTO RESTART ADDRESS SELECTED BY
/OPERATOR DOES NOT COMPARE WITH AUTO
/AUTO RESTART THAT RETURNED, PRESS "CONT"
/POH EXPECTED AND ACTUAL RETURN ADDRESS
/GET THE EXPECTED AUTO RESTART ADDRESS
/AC = EXPECTED AUTO RESTART ADDRESS
/GET ACTUAL
/AC = ADDRESS RETURNED FROM AUTO RESTART
/SETUP RETURN ADDRESS FOR POWER FAIL
/SAVE IT
/GET THE LINK
/PUT IT IN THE LINK
/GET THE AC
/TURN THE INTERRUPT ON
/OPERATOR INTERVENTION AUTO RESTART
/SETUP FOR A AUTO RESTART

```

```

0391 3052      DCA   AURST
0392 7402      ADDWNI, HLT
0393 5453      JMP   I TEST      /WAIT FOR LINE CORD TO BE PLUGGED IN
                                /RETRY TEST

0394 4200      RESADU, 4200
0395 2000      DCA   2000
0396 0200      DCA   0200
0397 0000      DCA   0000

0371 0311
0372 4452
0373 0451
0374 0452
0375 0354
0376 0600
0377 0343      PAGE
0400 0000

```

```

0401 1022      ACTLIN, 0
0402 7700      TAD   OP2SEL
0403 5600      SMA   CLA
0404 1037      JMP   I ACTLIN      /IS THE PROGRAM RUNNING ON ACT LINE?
0405 1111      TAD   FLDLIM      /NO, RETURN
0406 7640      TAD   M70          /GET THE FIELD LIMIT
0407 5600      SEA   CLA
0408 1040      JMP   I ACTLIN      /IS THE FIELD LIMIT EQUAL TO FIELD 7?
0409 1040      TAD   UPERLM      /NO, RETURN TO TEST
0410 7001      IAC
0411 7640      SEA   CLA          /GET THE UPPER ADDRESS LIMIT
0412 5600      JMP   I ACTLIN      /ADD 1 TO IT
0413 5600      CLA   CLL CMA RTR      /WAS IT 7777
0414 7352      DCA   CMA RTR      /NO, RETURN
0415 3040      DCA   UPERLM      /SET LAST ADDRESS = 5777
0416 5600      JMP   I ACTLIN      /SAVE IT
                                /RETURN TO PROGRAM

0417 1022      ENDPAS, TAD   OP2SEL      /CHECK FOR ACT LINE
0418 7700      SMA   CLA          /IS THE PROGRAM RUNNING ON ACT LINE
0419 5234      JMP   ENDING      /NO GO CHECK FOR SR 3 TO HALT AT END OF A PASS
0420 1021      TAD   OP1SEL      /GET THE HARDWARE CONFIGURATION
0421 0143      AND   K200      /CHECK FOR THE SIMULATOR
0422 7640      SEA   CLA          /WAS THE SIMULATOR SELECTED
0423 5234      JMP   ENDING      /YES, ALREADY NOTIFIED PROM OF GOOD PAS
0424 2242      ISB   PRGPAS      /CHECK 1/2 SECOND COUNT
0425 5234      JMP   ENDING      /NOT 1/2 SECOND YET
0426 1377      TAD   C144      /RESET THE COUNTER
0427 3242      DCA   PRGPAS
0428 6272      CIP   70          /CHANGE INSTRUCTION FIELD TO 7
0429 4451      JMS   I GOODPS      /SIGNAL THE PROM
0430 4341      ENDING, JMS   SMCHK      /CHECK SR 3 TO HALT ON A PROGRAM PASS
0431 7006      RTN

```

```

0436 7004      RAL
0437 7710      SPA   CLA
0440 7402      HLT
0441 5776      JMP   M201      /END OF A COMPLETE PROGRAM PASS
                                /RESTART THE PROGRAM

0442 7634      PRGPAS, =144

0443 7010      POWPAL, 0
0444 3251      DCA   LINK
0445 1000      TAD   INTSER
0446 3252      DCA   PC
0447 6103      CAL
0448 4452      JMS   I AURST      /CLEAR AC LOW F/F
                                /RETURN TO THE PROGRAM

0451 0000      LINK, 0
0452 0000      PC, 0

0453 0000      PRGHST, 0
0454 6102      SPL
0455 7610      SK*   CLA
0456 5254      JMP   I #2
0457 5453      JMP   I TEST      /SKIP ON AC LOW AS A LEVEL
                                /RETURN TO TEST BEING EXECUTED AND START OVER

0460 0000      TESTAD, 0
0461 7340      CLA   CLL CMA
0462 1260      TAD   TESTAD
0463 3053      DCA   TEST
0464 1375      TAD   (PRORST
0465 3052      DCA   AURST
0466 5660      JMP   I TESTAD

0467 1021      RATEMT, TAD   OP1SEL      /GET HARDWARE CONFIGURATION
0468 0143      AND   K200
0469 7650      SNA   CLA
0470 5277      JMP   DEAD          /MACHINE GOING DOWN = STOP EVERYTHING
0471 3373      DCA   ACNLOK
0472 2000      ISB   INTSER
0473 2000      ISB   INTSER
0474 5400      JMP   I INTSER
0475 7402      DEAU, HLT
0476 5453      JMP   I TEST      /ITS ALL OVER NOW = GOOD=BYE

0501 0000      GOODBU, 0
0502 1022      TAD   OP2SEL
0503 7700      SMA   CLA
0504 5701      JMP   I GOODBD      /GET HARDWARE CONFIGURATION
0505 6272      CIP   70          /IS THE PROGRAM RUNNING ON ACT LINE
0506 4451      JMS   I GOODPS      /NO RETURN TO PROGRAM
0507 5701      JMP   I GOODBD      /CHANGE INSTRUCTION FIELD TO FIELD 7
                                /SIGNAL ACT LINE PROGRAM STILL RUNNING
                                /RETURN TO PROGRAM

```

```

0510 0000  ERRURX, 0
0511 7300          CLA  CLL
0512 1022          TAD  OP2SEL
0513 7700          SMA  CLA
0514 5326          JMP  CHKINH
0515 1021          TAD  OP1SEL
0516 0143          AND  K200
0517 7640          SEA  CLA
0520 0100          CLRMOD
0521 0002          JOF
0522 7240          CLA  CMA
0523 1310          TAD  ERRORX
0524 0272          CIP  70
0525 5450          JMP  I  BADPAS
0526 4341  CHKINH, JMS  SWCHK
0527 7710          SPA  CLA
0530 5334          JMP  ERLPSW
0531 7340          CLA  CLL
0532 1310          TAD  ERRORX
0533 7402          HLT

```

```

/ERROR ROUTINE
/CHECK FOR ACT LINE

/TURN THE INTERRUPT OFF

/GO TO HOM FOR ERROR
/CHECK FOR SR 0(1) TO INHIBIT ERROR HALT
/IS SR 0 SET TO A ONE
/YES, GO CHECK SR 1 TO LOOP ON ERROR

/SUBTRACT ONE FROM JMS ERROR PC
/AC CONTAINS THE ADDRESS WHERE THE ERROR
/HAS DETECTED BY THE PROGRAM, REFER
/TO THE PROGRAM LISTING FOR ERROR
/EXPLANATION AND THE TEST DESCRIPTION,
/CHECK THE SWITCH REGISTER TO LOOP ON ERROR

/IS SR 1 SET TO A ONE TO LOOP ON TEST
/YES GO LOOP ON THE TEST
/NO, RETURN TO THE PROGRAM

```

```

0534 4341  ERLPSW, JMS  SWCHK
0535 7004          RAL
0536 7710          SPA  CLA
0537 5453          JMP  I  TEST
0540 5710          JMP  I  ERRORX

```

```

0541 0000  SWCHK, 0
0542 7300          CLA  CLL
0543 1021          TAD  OP1SEL
0544 7700          SMA  CLA
0545 5350          JMP  ,+3
0546 7604          LAS
0547 5741          JMP  I  SWCHK
0550 1020          TAD  SWITCH
0551 5741          JMP  I  SWCHK

```

```

/GET THE HARDWARE STATUS WORD
/IS THE HARDWARE FRONT PANEL SELECTED
/NO, USE THE PSEUDO SWITCH REGISTER

/RETURN
/THE PSEUDO SWITCH REGISTER
/RETURN

```

```

0552 0000  TSTLOP, 0
0553 4341          JMS  SWCHK
0554 7006          RTL
0555 7700          SMA  CLA
0556 5752          JMP  I  TSTLOP
0557 5453          JMP  I  TEST

```

```

/ROUTINE TO CHECK SR 2 TO LOOP ON TEST
/GO GET THE SWITCH REGISTER

/GO TO NEXT TEST
/LOOP ON SAME TEST

```

```

0560 0000  ACLBAT, 0
0561 1373          TAD  ACNLOK
0562 7640          SEA  CLA
0563 5366          JMP  ,+3
0564 2000          ISR  INTSER

```

```

/LOCK AT RETURN FOR AC LOW OR BATTERY EMPTY

```

```

0565 5400          JMP  I  INTSER
0566 5373          DCA  ACNLOK
0567 6101          SBE
0570 5364          JMP  ,+4
0571 2000          ISR  INTSER
0572 5364          JMP  ,+6
0573 0000  ACNLOK, 0

0575 0453
0576 0201
0577 7634
0600          PAGE

```

```

/SKIP ON BATTERY EMPTY

```

```

0600 0000  BUFFER, 0
0200          *200

```

```

/BUFFER IS FROM 600 TO 1777

```

0000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0100	11111111	11111111	11111111	11111111	11111111	11110000	00000000	00000000
0200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0300	11111111	11111111	11111111	11111111	11111111	11111111	00000000	01111111
0400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0500	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11110111
0600	10000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
0700	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000

1000
1100

1200
1300

1400
1500

1600
1700

2000
2100

2200
2300

2400
2500

2600
2700

3000
3100

3200
3300

3400
3500

3600
3700

4000
4100

4200
4300

4400
4500

4600
4700

5000
5100

5200
5300

5400
5500

5600
5700

6000
6100

6200
6300

6400
6500

6600
6700

7000
7100

7200
7300

7400
7500

7600
7700

ACDOWI	0352	K3	0307	M92	0104
ACLBAT	0360	K34	0341	M95	0105
ACNLOK	0373	K37	0136	M60	0106
ACTLIN	0400	K400	0144	M61	0107
ADDGNT	0247	K4100	0153	M66	0110
AUTO	0201	K5252	0306	M7	0066
AUTRST	0052	K6201	0045	M70	0111
BADPAS	0050	K7	0134	M77	0112
BATEMT	0467	K73	0137	MANHST	0310
BUFFONT	0303	K7677	0152	OP1SEL	0021
BUFFER	0600	K77	0140	OP21K4	0000
BUFFGND	0272	K7707	0150	OP2SEL	0022
BUFFPAT	0305	K7757	0151	OPRINT	0343
CAF	6007	K7774	0147	OPRRET	0311
CAL	6103	LINK	0451	PASEND	0061
COF	6201	LOJHG2	6152	PC	0492
COFCHK	0033	LOJHG3	6153	POWFAL	0443
CHKGDF	0034	LOOP	4455	PHOPAS	0442
CHKINH	0526	M1	0062	PHONST	0493
CIF	4202	M10	0067	ROP	6214
CIFCDF	4203	M100	0113	REDEMA	0155
CINT	4204	M1000	0117	RESADD	0394
CLREMA	4154	M1007	0120	RESET	0326
CLRMDD	4160	M1016	0121	RETPRG	0340
CLRSIM	4150	M1020	0122	RIB	6234
CMPBUF	0251	M1034	0123	RIF	6224
CNTBUF	0304	M1043	0124	RKAE	0023
CUP	6264	M1052	0125	RMP	6244
DATPAT	0042	M1061	0126	RTP	0005
DATREC	0035	M1070	0127	SAVESE	0036
DEAD	0477	M11	0070	SAVWFU	0046
ENDING	0434	M1100	0130	SBE	0101
ENDPAS	0417	M120	0114	SCDPLP	4496
ERLPSM	0534	M192	0115	SINT	6294
ERROR	4454	M16	0071	SKON	0000
ERRORX	0510	M2	0063	SKPEMA	0106
EXECUT	4164	M20	0072	SPL	0102
FILLIT	0302	M22	0073	STRCMP	0243
FLLDLM	0037	M25	0074	SUP	6274
GOODRD	0501	M30	0075	SWCHK	0541
GOODPS	0051	M300	0116	SWITCH	0020
GTF	6004	M33	0076	TEST	0093
HGHLIM	0044	M34	0077	TESTAU	0400
HLT	7402	M4	0064	TSTLOP	0592
INTSER	0000	M40	0100	UPENLM	0040
K1	0342	M4100	0131	WRKADD	0043
K10	0135	M43	0101	WRKFLD	0041
K120	0141	M44	0102	YBAT	0060
K152	0142	M5	0065	XPWFLL	0057
K177	0145	M50	0103		
K200	0143	M5000	0132		
K2000	0146	M5100	0133		

ERRORS DETECTED 0
 LINKS GENERATED 3
 RUN=TIME 17 SECONDS
 3K CORE USED

