

ANALOG KNOB @ # KMODE
 CLOCK SOURCE TO KING FREE
 THRESHOLD KNOB TO MIDRANGE
 L SW = 0000 ; RSW = 0000
 B-MODE 1/0 PRES1 START 20
 RSW OR FI INHIBIT PASS PRINT

KW12A

IDENTIFICATION

PRODUCT CODE: MAINDEC 12-D8CD-D
 PRODUCT NAME: KW12A CLOCK TEST
 DATE CREATED: DECEMBER 1, 1971
 MAINTAINER: DIAGNOSTIC GROUP
 AUTHOR: RAYMOND SHOOP

COPYRIGHT © 1971
 EQUIPMENT CORPORATION

1.0

ABSTRACT

1.1 THE KW12 REAL TIME CLOCK TEST IS DESIGNED TO VERIFY THE CORRECT OPERATION OF THE BUFFER PRESET REGISTER, CLOCK COUNTER REGISTER, CLOCK CONTROL REGISTER, CLOCK ENABLE REGISTER, CLOCK I/O INTERFACE, EXTERNAL INPUT CHANNELS, AND FAST SAMPLE MODE (IF THE AD12 OPTION IS CONCURRENTLY INSTALLED.)

1.2

PROGRAM CONTROL IS MAINTAINED BY A MONITOR RESIDENT IN BANK 0. SEVERAL OPTIONS ARE AVAILABLE TO THE OPERATOR FOR ERROR HANDLING.

2.0

REQUIREMENTS:

2.1

EQUIPMENT:

- A. A PDP-12 WITH KW12 INSTALLED.
- B. AN AD12 ANALOG-TO DIGITAL CONVERTER IF FAST SAMPLE TESTING IS REQUIRED.
- C. AN ASR-33 OR EQUIVALENT.

2.2

PRELIMINARY PROGRAMS

- A. ALL CENTRAL PROCESSOR AND MEMORY DIAGNOSTIC PROGRAMS FOR A BASIC PDP-12 MUST BE ABLE TO RUN SUCCESSFULLY PRIOR TO TESTING THE KW12.

2.3

STORAGE:

- A. 4K MINIMUM CORE.
- B. PROGRAM OCCUPIES LOCATIONS 0000 TO 7600.

3.0

LOADING PROCEDURES

3.1

METHOD

LOAD THIS PROGRAM USING THE STANDARD METHOD OF LOADING A BINARY PROGRAM.

4.0

STARTING PROCEDURES

4.1

METHOD

- A. SET THE MODE SWITCH TO 8 MODE.
- B. SET THE LEFT SWITCHES TO 0000.
- C. SET THE RIGHT SWITCHES TO THE DESIRED OPTIONS.
- D. DEPRESS I/O PRESET.
- E. DEPRESS START 20.
- F. THE PROGRAM IS NOW RUNNING. THE TELETYPE BELL WILL RING AT THE END OF EACH PASS. IN ADDITION, THE CONTENTS OF THE PASS COUNTER WILL BE TYPED OUT.

ca 40 seconds

4.2

SWITCH SETTINGS

- A. IF FAST SAMPLE TESTING IS TO BE ATTEMPTED, SET KNOB 0 FULLY COUNTERCLOCKWISE AND KNOB 1 FULLY CLOCKWISE.
- B. SET THE SELECTOR SWITCHES ON THE FRONT PANEL TO LINE FREQUENCY.
- C. SET THE INPUT LEVEL KNOBS TO MID-RANGE.
- D. SELECT ANY DESIRED ERROR HANDLER OPTIONS. WITH RSW = 0000, THE FOLLOWING SEQUENCE WILL OCCUR FOR AN ERROR: (MESSAGE TYPEOUT, ERROR HALT) THE OPERATOR SELECTS ANY FURTHER ERROR OPTIONS AND DEPRESSES CONTINUE.... (MONITOR EXECUTES NEXT SEQUENTIAL TEST)

RSW 00 = 1, INHIBIT ERROR HALT
 RSW 01 = 1, INHIBIT ERROR PRINTOUT
 RSW 02 = 1, SCOPE LOOP ON ERROR
 RSW 03 = 1, SCOPE LOOP ON NON-FAILING TEST
 RSW 04 = 1, INHIBIT PASSY SAMPLE TESTING
 RSW 05 = 1, INHIBIT BELL RINGING
 RSW 06 = 1, INHIBIT PASS COUNTER PRINTOUT

5.0

ERROR ROUTINE

5.1

ERROR PRINTOUT

- A. THE ERROR MESSAGES HAVE THE FOLLOWING GENERAL FORM:

TEST NC, TEST MESSAGE
 REG1 REG2 REG3 ...

- B. TEST NC, REFERS TO THE TEST NUMBER AS ORGANIZED IN THE LISTING. THIS IS INCLUDED TO AID THE OPERATOR IN FINDING THE TEST IN THE LISTING.

- C. TEST MESSAGE IS THE BODY OF THE TEXT, DESCRIBING WHAT WAS TESTED, AND INDICATING ANY AREAS OF PROBABLE FAILURE.

- D. REG1, REG2, REG3, ARE SPECIFIC DATA WORDS PERTAINING TO THE FAILURE.

ERROR MESSAGES

TST10 CLAB CHANGED AC
7741 7020
TST11 CLBA FAILED
0402 7020
TST12 CLAB FAILED
0402 7020
TST13 CLAB FAILED
7741 7020
TST14 CLAB FAILED
0402 7020
TST15 CLBA CHANGED BUFFER
0402 7020
TST16 CLAB <> CLBA FAILED
7741 7020
TST17 CLAB <> CLBA FAILED
0402 7020
TST18 CLAB <> CLBA FAILED
0402 7020
TST19 CLEN CHANGED AC
7741 7020
TST20 CLEN CHANGED BUFFER
7741 7020
TST21 CLCA FAILED
0402 7020
TST22 "CLR CNT" FAILED
0402 7020
TST23 CLEN FAILED
7741 7020
TST24 CLEN FAILED
0402 7020
TST25 CLCA CHANGES COUNT
0402 7020
TST26 BUFFER <> COUNTER FAILED
0402 7020
TST27 "LOAD CNT" FAILS TO "OR"
0402 7020
TST28 "LOAD CNT" LOADED IN ERROR
0402 7020
TST29 "LOAD CNT" LOADED IN ERROR
0402 7020
TST30 MODE REG CAUSES "LOAD CNT"
0402 7020
TST31 MODE REG CAUSES "LOAD CNT" OR "CLR BUF"
0402 7020
TST32 MODE 2: 1>0 CLOKED CNTR
0402 7020
TST33 MODE 2: 0>1 CLOKED CNTR
0000 7020
TST34 0'FLO FAILED TO SET 0'FLO FLOP
TST35 CLSA FAILED TO CLEAR 0'FLO FLOP

TST36 CLSK SKIPPED IN ERROR
TST37 ILLEGAL CLOCK INTERRUPT!
TST38 CLSK FAILED TO SKIP
TST39 CLOCK INTERRUPT FAILED
TST40 O'FLO ENABLE WON'T ZERO
TST41 O'FLO FLAG WON'T CLEAR
TST42 CLOCK INTR WON'T CLEAR
TST43 BIT 11 FAILED.
0402 7020
TST44 BIT 10 FAILED.
0402 7020
TST45 BIT 09 FAILED.
0402 7020
TST46 BIT 08 FAILED.
0402 7020
TST47 BIT 07 FAILED.
0402 7020
TST48 BIT 06 FAILED.
0402 7020
TST49 BIT 05 FAILED.
0402 7020
TST50 BIT 04 FAILED.
0402 7020
TST51 BIT 03 FAILED.
0402 7020
TST52 BIT 02 FAILED.
0402 7020
TST53 BIT 01 FAILED.
0402 7020
TST54 BIT 00 FAILED.
0402 7020
TST55 RATE 400KC FAILS
TST56 RATE 100KC FAILS
TST57 RATE 10KC FAILS
TST58 RATE 1KC FAILS
TST59 RATE 100CPS FAILS
TST60
CHAN 1 INPUT LOCKED OUT
TST61 CHAN 3 WON'T TOGGLE
0402 7020
TST62 CHAN 2 WON'T TOGGLE
0402 7020
TST63 CHAN 1 WON'T TOGGLE
0402 7020
TST64 CHAN 1 WON'T TOGGLE

TST65 CHAN 1 INTR IN ERROR
TST66 CHAN 2 WON'T INTR.
0402 7020
TST67 CHAN 2 INTR IN ERROR

TST68 CHAN 3 WON'T INTR.
0402 7020
TST69 CHAN 3 INTR IN ERROR

TST70 CHAN 3 INPUT LINE FREQ FAILED
7020
TST71 CHAN 2 INPUT LINE FREQ FAILED
7020
TST72 CHAN 1 INPUT LINE FREQ FAILED
7020
TST73 FAST SAM FAILS
0402 7020
TST74 O'FLC WON'T FAST SAO
0402 7020
TST75 FAST SAM WON'T SET
0402 7020
TST76 MODES 2-1 INHIBIT FAST SAM
0402 7020
TST77 RATE 10KC FAILS
0402
TST78 I/O PRESET WON'T STOP CLOCK
(RATE BITS 1 & 2)

TST79 1KC FAILS
0402

TST80 I/O PRSET WON'T STOP CLOCK
(RATE BIT 0)

TST81 I/O PRESET WON'T CLEAR O'FLO

TST82 I/O PRESET WON'T CLEAR INTERRUPT ENABLE

TST83 I/O PRESET WON'T CLEAR INPUTS

TST83 I/O PRESET WON'T CLEAR MODE 2

TST85 I/O PRESET WON'T CLEAR MODE 0

TST 86 FAST SAM NOT CLEARED

TST 87 CHAN 1 WON'T TRANS CNT TO BUF
0200
TST88 CHAN 2 WON'T TRANS CNT TO BUF
0200
TST89 CHAN 3 WON'T TRANS CNT TO BUF
0200
TST90 CHAN 1 WON'T TRANS CNT TO BUF
0300
TST91 CHAN 2 WON'T TRANS CNT TO BUF
0300
TST92 CHAN 3 WON'T TRANS CNT TO BUF

0300 CHA3 INPUT FAILED TO CLR CNT
TST93 7020
TST94 ECO EM12-00034 IS EITHER NOT WORKING OR NOT
INSTALLED
TST95 ECO EM12-00055 IS EITHER NOT WORKING OR NOT
INSTALLED PROPERLY
KW12 PASS-0000

/PDP-12 KW12A CLOCK TEST, MAINDEC 12-D8CD=L
/COPYRIGHT 1970, DIGITAL EQUIPMENT CORP., MAYNARD, MASS.

/THIS TEST IS DESIGNED TO VERIFY PROPER OPERATION
/OF THE KW-12A REAL TIME CLOCK AND TO DIAGNOSE
/MALFUNCTIONS IN REGISTERS, REGISTER TRANSFERS, IO
/BUS INTERFACE, AND EXTERNAL INPUT CHANNELS.

/AUTHORS: JAMES KELLY, STEVE TEICHER, HAROLD LONG
/RAYMOND SHOOP
/MAJOR START

/I/O PRESET 8 MODE

/SET LEFT SWITCHES TO 0000

/SET RIGHT SWITCHES TO DESIRED OPTIONS

/DEPRESS START 20

/SWITCH SETTINGS (NORMALLY 0000)

/RSW 00=1, INHIBIT ERROR HALT

/RSW 01=1, INHIBIT ERROR PRINTOUT

/RSW 02=1, SCOPE LOOP ON FAILING TEST

/RSW 03=1, SCOPE LOOP ON NON-FAILING TEST

/RSW 04=1, INHIBIT FAST SAMPLE TESTING.

/RSW 05=1, INHIBIT BELL RINGING

/RSW 06=1, INHIBIT TEST COMPLETION ALARM

/SOME IOT DEFINITIONS:

6131
6132
6133
6134
6135
6136
6137

CLSK=6131
CLLR=6132
CLAB=6133
CLEN=6134
CLSA=6135
CLBA=6136
CLCA=6137

0000
7777
4444

EXIT=0000
EXITA=7777
EXITB=4444

/SKIP ON CLOCK INTERRUPT
/AC TO CLOCK CONTROL REGISTER
/AC TO BUFFER PRESET REGISTER
/AC TO CLOCK ENABLE REGISTER
/CLOCK STATUS TO AC, CLEAR STATUS FLIP-FLOPS
/BUFFER PRESET REGISTER TO AC
/COUNTER TO AC

/MESSAGE TERMINATOR
/MESSAGE SWITCH
/RESTART SWITCH

/SOME LINC PROGRAMMING DEFINITIONS:

6141
0002
0011
0004
0100
0101
1020

LINC=6141
PDP=0002
CLR=0011
ESF=0004
SAM0=0100
SAM1=0101
LDAI=1020

0001	0001	0001	*1		JMP I RETURN	
0001	5451	0010	*10			
0010	0000	0000	PINT,	0		
0020	0000	0020	*20			
0020	5177	0020	JMP	177	/MAJOR START 8 MODE	
			/		/PAGE 0 REGISTERS AND CROSS-PAGE TAGS	
			/			
0021	5200	0021	BELL,		BELLS	
0022	1561	0022	DN43,		BK43	
0023	2362	0023	DN55,		BK55	
0024	0000	0024	CNTR,		0000	
0025	5020	0025	ERROR,		ERRORS	
0026	0000	0026	LSTERR,		0000	
0027	5000	0027	NERROR,		NERROS	
0030	5051	0030	OUTPAS,		ASCII	
0031	0000	0031	PASS,		0000	
0032	1425	0032	PNTA,		LOCA	
0033	1457	0033	PNTB,		LOCB	
0034	1527	0034	PNTC,		LOCC	
0035	2720	0035	PNTD,		LOCD	
0036	2742	0036	PNTE,		LOCE	
0037	2763	0037	PNTF,		LOCF	
0040	3005	0040	PNTG,		LOGG	
0041	3027	0041	PNTH,		LOGH	
0042	3051	0042	PNTI,		LOCI	
0043	4307	0043	PNTJ,		LOGJ	
0044	5210	0044	RANDOM,		RANDY	
0045	0000	0045	REGA,		0000	
0046	0000	0046	REGB,		0000	
0047	0000	0047	REGC,		0000	
0050	0000	0050	REGT,		0000	
0051	0000	0051	RETURN,		0000	
0052	0000	0052	RXED,		0000	
0053	0000	0053	SEND,		0000	
0054	5252	0054	SET,		SETN	
0055	0000	0055	SPACE,		0000	
0056	1342	0056	TST35N,		TST35-2	
0057	2753	0057	TST66N,		TST66	
0060	3313	0060	TST75N,		TST75	
0061	3375	0061	TST77N,		TST77	
0062	3436	0062	TST79N,		TST79	
0063	4040	0063	TST90N,		TST90	
0064	5243	0064	TYPE,		TYPQUT	
0065	1572	0065	UP43,		F043	
0066	2201	0066	UP51,		F051	
0067	2372	0067	UP55,		F055	
0070	2617	0070	UP61,		F061	

/PAGE 0 CONSTANTS

0071	0000	K0000,	0000
0072	0001	K0001,	0001
0073	0002	K0002,	0002
0074	0003	K0003,	0003
0075	0004	K0004,	0004
0076	0007	K0007,	0007
0077	0010	K0010,	0010
0100	0014	K0014,	0014
0101	0017	K0017,	0017
0102	0020	K0020,	0020
0103	0037	K0037,	0037
0104	0040	K0040,	0040
0105	0060	K0060,	0060
0106	0077	K0077,	0077
0107	0100	K0100,	0100
0110	0177	K0177,	0177
0111	0200	K0200,	0200
0112	0240	K240,	0240
0113	0300	K0300,	0300
0114	0377	K0377,	0377
0115	0400	K0400,	0400
0116	0500	K0500,	0500
0117	0600	K0600,	0600
0120	0700	K0700,	0700
0121	0777	K0777,	0777
0122	1000	K1000,	1000
0123	1026	K1026,	1026
0124	1777	K1777,	1777
0125	2000	K2000,	2000
0126	3000	K3000,	3000
0127	3777	K3777,	3777
0130	4000	K4000,	4000
0131	4100	K4100,	4100
0132	5100	K5100,	5100
0133	5252	K5252,	5252
0134	5555	K5555,	5555
0135	6000	K6000,	6000
0136	7774	K7774,	7774

/PAGE 0 NEGATIVE CONSTANTS

0137	7777	M0001,	-1
0140	7776	M0002,	-2
0141	7774	M0004,	-4
0142	7770	M0010,	-10
0143	7760	M0020,	-20
0144	7740	M0040,	-40
0145	7736	M0042,	-42
0146	7700	M0100,	-100
0147	7600	M0200,	-200
0150	7400	M0400,	-400
0151	7000	M1000,	-1000
0152	6400	M1400,	-1400
0153	6000	M2000,	-2000
0154	4000	M4000,	-4000
0155	3334	M4444,	-4444
0156	2400	M5400,	-5400

/GENERATE AN PROGRAM I-O POWER CLEAR

0157	0000	CLAR.	0	LINC	/CHANGE TO LINC MODE
0160	6141			LDAL	/LOAD AC WITH 20
0161	1020			0020	/
0162	0020			ESP	/I-O POWER CLEAR
0163	0004			PDP	
0164	0002			CLA	
0165	7200			JMP I	/EXIT
0166	5557			CLAR	
				CLAR	
4157		CLEAR=JMS			

```

0176      0176      SKP      /RESTART ADDRESS; DON'T CLEAR COUNTERS
0177      0177      JMS I    /RESET BUFFERS
0200      *176
0201      *200
0202      /MAJOR START 8 MODE, AC=0
0203      /TEST BUFFER AND PRESET REGISTER DATA INTERCHANGE
0204      /CLAB=6133 AC TO CLOCK PRESET REGISTER
0205      /CLBA=6136 CLOCK PRESET REGISTER TO AC
0206      /DOES AC CHANGE AFTER A TRANSFER TO BUFFER REG?
0207      /
0208      JMS I    BELL
0209      CLA CLL
0210      TAD REGA
0211      CLAB
0212      DCA
0213      TAD
0214      CIA
0215      TAD REGA
0216      SNA CLA
0217      JMS I    NERROR
0218      JMS I    ERROR
0219      TST10M
0220      HLT
0221      SKP CLA
0222      TST10
0223      /DOES BUFFER DATA JAM INTO THE AC?
0224      /
0225      TST11,
0226      CLA CLL
0227      DCA
0228      CLAB
0229      CLA CMA
0230      CLBA
0231      DCA
0232      TAD
0233      SNA CLA
0234      JMS I    NERROR
0235      JMS I    ERROR
0236      TST11M
0237      HLT
0238      SKP CLA
0239      TST11
0240      /CLEAR AC
0241      /SEND REG
0242      /SET BUFFER AND PRESET REGISTER TO 0000
0243      /SET AC TO 7777
0244      /JAM BUFFER PRESET (0000) OVER AC (7777)
0245      /SAVE AC
0246      /RESTORE AC
0247      /DID AC BECOME (0000)?
0248      /CHECK MONITOR
0249      /CLBA FAILED TO JAM THE AC
0250      /MESSAGE POINTER
0251      /ERROR HALT
0252      /TO NEXT TEST
0253      /ISE LOOP; SCOPE LOOP
0254      /
0255      /RING BELL
0256      /CLEAR AC
0257      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0258      /LOAD BUFFER
0259      /STORE WHAT WAS LEFT IN AC
0260      /FETCH IT
0261      /INVERT CONTENTS OF AC
0262      /SUBTRACT SEND
0263      /EQUAL?
0264      /CHECK MONITOR
0265      /CLAB CHANGED AC?
0266      /MESSAGE POINTER
0267      /ERROR HALT
0268      /TO NEXT TEST
0269      /ISE LOOP; SCOPE LOOP
0270      /
0271      /CLEAR AC
0272      /SEND REG
0273      /SET BUFFER AND PRESET REGISTER TO 0000
0274      /SET AC TO 7777
0275      /JAM BUFFER PRESET (0000) OVER AC (7777)
0276      /SAVE AC
0277      /RESTORE AC
0278      /DID AC BECOME (0000)?
0279      /CHECK MONITOR
0280      /CLBA FAILED TO JAM THE AC
0281      /MESSAGE POINTER
0282      /ERROR HALT
0283      /TO NEXT TEST
0284      /ISE LOOP; SCOPE LOOP
0285      /
0286      /RING BELL
0287      /CLEAR AC
0288      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0289      /LOAD BUFFER
0290      /STORE WHAT WAS LEFT IN AC
0291      /FETCH IT
0292      /INVERT CONTENTS OF AC
0293      /SUBTRACT SEND
0294      /EQUAL?
0295      /CHECK MONITOR
0296      /CLAB CHANGED AC?
0297      /MESSAGE POINTER
0298      /ERROR HALT
0299      /TO NEXT TEST
0300      /ISE LOOP; SCOPE LOOP
0301      /
0302      /CLEAR AC
0303      /SEND REG
0304      /SET BUFFER AND PRESET REGISTER TO 0000
0305      /SET AC TO 7777
0306      /JAM BUFFER PRESET (0000) OVER AC (7777)
0307      /SAVE AC
0308      /RESTORE AC
0309      /DID AC BECOME (0000)?
0310      /CHECK MONITOR
0311      /CLBA FAILED TO JAM THE AC
0312      /MESSAGE POINTER
0313      /ERROR HALT
0314      /TO NEXT TEST
0315      /ISE LOOP; SCOPE LOOP
0316      /
0317      /RING BELL
0318      /CLEAR AC
0319      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0320      /LOAD BUFFER
0321      /STORE WHAT WAS LEFT IN AC
0322      /FETCH IT
0323      /INVERT CONTENTS OF AC
0324      /SUBTRACT SEND
0325      /EQUAL?
0326      /CHECK MONITOR
0327      /CLAB CHANGED AC?
0328      /MESSAGE POINTER
0329      /ERROR HALT
0330      /TO NEXT TEST
0331      /ISE LOOP; SCOPE LOOP
0332      /
0333      /CLEAR AC
0334      /SEND REG
0335      /SET BUFFER AND PRESET REGISTER TO 0000
0336      /SET AC TO 7777
0337      /JAM BUFFER PRESET (0000) OVER AC (7777)
0338      /SAVE AC
0339      /RESTORE AC
0340      /DID AC BECOME (0000)?
0341      /CHECK MONITOR
0342      /CLBA FAILED TO JAM THE AC
0343      /MESSAGE POINTER
0344      /ERROR HALT
0345      /TO NEXT TEST
0346      /ISE LOOP; SCOPE LOOP
0347      /
0348      /RING BELL
0349      /CLEAR AC
0350      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0351      /LOAD BUFFER
0352      /STORE WHAT WAS LEFT IN AC
0353      /FETCH IT
0354      /INVERT CONTENTS OF AC
0355      /SUBTRACT SEND
0356      /EQUAL?
0357      /CHECK MONITOR
0358      /CLAB CHANGED AC?
0359      /MESSAGE POINTER
0360      /ERROR HALT
0361      /TO NEXT TEST
0362      /ISE LOOP; SCOPE LOOP
0363      /
0364      /CLEAR AC
0365      /SEND REG
0366      /SET BUFFER AND PRESET REGISTER TO 0000
0367      /SET AC TO 7777
0368      /JAM BUFFER PRESET (0000) OVER AC (7777)
0369      /SAVE AC
0370      /RESTORE AC
0371      /DID AC BECOME (0000)?
0372      /CHECK MONITOR
0373      /CLBA FAILED TO JAM THE AC
0374      /MESSAGE POINTER
0375      /ERROR HALT
0376      /TO NEXT TEST
0377      /ISE LOOP; SCOPE LOOP
0378      /
0379      /RING BELL
0380      /CLEAR AC
0381      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0382      /LOAD BUFFER
0383      /STORE WHAT WAS LEFT IN AC
0384      /FETCH IT
0385      /INVERT CONTENTS OF AC
0386      /SUBTRACT SEND
0387      /EQUAL?
0388      /CHECK MONITOR
0389      /CLAB CHANGED AC?
0390      /MESSAGE POINTER
0391      /ERROR HALT
0392      /TO NEXT TEST
0393      /ISE LOOP; SCOPE LOOP
0394      /
0395      /CLEAR AC
0396      /SEND REG
0397      /SET BUFFER AND PRESET REGISTER TO 0000
0398      /SET AC TO 7777
0399      /JAM BUFFER PRESET (0000) OVER AC (7777)
0400      /SAVE AC
0401      /RESTORE AC
0402      /DID AC BECOME (0000)?
0403      /CHECK MONITOR
0404      /CLBA FAILED TO JAM THE AC
0405      /MESSAGE POINTER
0406      /ERROR HALT
0407      /TO NEXT TEST
0408      /ISE LOOP; SCOPE LOOP
0409      /
0410      /RING BELL
0411      /CLEAR AC
0412      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0413      /LOAD BUFFER
0414      /STORE WHAT WAS LEFT IN AC
0415      /FETCH IT
0416      /INVERT CONTENTS OF AC
0417      /SUBTRACT SEND
0418      /EQUAL?
0419      /CHECK MONITOR
0420      /CLAB CHANGED AC?
0421      /MESSAGE POINTER
0422      /ERROR HALT
0423      /TO NEXT TEST
0424      /ISE LOOP; SCOPE LOOP
0425      /
0426      /CLEAR AC
0427      /SEND REG
0428      /SET BUFFER AND PRESET REGISTER TO 0000
0429      /SET AC TO 7777
0430      /JAM BUFFER PRESET (0000) OVER AC (7777)
0431      /SAVE AC
0432      /RESTORE AC
0433      /DID AC BECOME (0000)?
0434      /CHECK MONITOR
0435      /CLBA FAILED TO JAM THE AC
0436      /MESSAGE POINTER
0437      /ERROR HALT
0438      /TO NEXT TEST
0439      /ISE LOOP; SCOPE LOOP
0440      /
0441      /RING BELL
0442      /CLEAR AC
0443      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0444      /LOAD BUFFER
0445      /STORE WHAT WAS LEFT IN AC
0446      /FETCH IT
0447      /INVERT CONTENTS OF AC
0448      /SUBTRACT SEND
0449      /EQUAL?
0450      /CHECK MONITOR
0451      /CLAB CHANGED AC?
0452      /MESSAGE POINTER
0453      /ERROR HALT
0454      /TO NEXT TEST
0455      /ISE LOOP; SCOPE LOOP
0456      /
0457      /CLEAR AC
0458      /SEND REG
0459      /SET BUFFER AND PRESET REGISTER TO 0000
0460      /SET AC TO 7777
0461      /JAM BUFFER PRESET (0000) OVER AC (7777)
0462      /SAVE AC
0463      /RESTORE AC
0464      /DID AC BECOME (0000)?
0465      /CHECK MONITOR
0466      /CLBA FAILED TO JAM THE AC
0467      /MESSAGE POINTER
0468      /ERROR HALT
0469      /TO NEXT TEST
0470      /ISE LOOP; SCOPE LOOP
0471      /
0472      /RING BELL
0473      /CLEAR AC
0474      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0475      /LOAD BUFFER
0476      /STORE WHAT WAS LEFT IN AC
0477      /FETCH IT
0478      /INVERT CONTENTS OF AC
0479      /SUBTRACT SEND
0480      /EQUAL?
0481      /CHECK MONITOR
0482      /CLAB CHANGED AC?
0483      /MESSAGE POINTER
0484      /ERROR HALT
0485      /TO NEXT TEST
0486      /ISE LOOP; SCOPE LOOP
0487      /
0488      /CLEAR AC
0489      /SEND REG
0490      /SET BUFFER AND PRESET REGISTER TO 0000
0491      /SET AC TO 7777
0492      /JAM BUFFER PRESET (0000) OVER AC (7777)
0493      /SAVE AC
0494      /RESTORE AC
0495      /DID AC BECOME (0000)?
0496      /CHECK MONITOR
0497      /CLBA FAILED TO JAM THE AC
0498      /MESSAGE POINTER
0499      /ERROR HALT
0500      /TO NEXT TEST
0501      /ISE LOOP; SCOPE LOOP
0502      /
0503      /RING BELL
0504      /CLEAR AC
0505      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0506      /LOAD BUFFER
0507      /STORE WHAT WAS LEFT IN AC
0508      /FETCH IT
0509      /INVERT CONTENTS OF AC
0510      /SUBTRACT SEND
0511      /EQUAL?
0512      /CHECK MONITOR
0513      /CLAB CHANGED AC?
0514      /MESSAGE POINTER
0515      /ERROR HALT
0516      /TO NEXT TEST
0517      /ISE LOOP; SCOPE LOOP
0518      /
0519      /CLEAR AC
0520      /SEND REG
0521      /SET BUFFER AND PRESET REGISTER TO 0000
0522      /SET AC TO 7777
0523      /JAM BUFFER PRESET (0000) OVER AC (7777)
0524      /SAVE AC
0525      /RESTORE AC
0526      /DID AC BECOME (0000)?
0527      /CHECK MONITOR
0528      /CLBA FAILED TO JAM THE AC
0529      /MESSAGE POINTER
0530      /ERROR HALT
0531      /TO NEXT TEST
0532      /ISE LOOP; SCOPE LOOP
0533      /
0534      /RING BELL
0535      /CLEAR AC
0536      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0537      /LOAD BUFFER
0538      /STORE WHAT WAS LEFT IN AC
0539      /FETCH IT
0540      /INVERT CONTENTS OF AC
0541      /SUBTRACT SEND
0542      /EQUAL?
0543      /CHECK MONITOR
0544      /CLAB CHANGED AC?
0545      /MESSAGE POINTER
0546      /ERROR HALT
0547      /TO NEXT TEST
0548      /ISE LOOP; SCOPE LOOP
0549      /
0550      /CLEAR AC
0551      /SEND REG
0552      /SET BUFFER AND PRESET REGISTER TO 0000
0553      /SET AC TO 7777
0554      /JAM BUFFER PRESET (0000) OVER AC (7777)
0555      /SAVE AC
0556      /RESTORE AC
0557      /DID AC BECOME (0000)?
0558      /CHECK MONITOR
0559      /CLBA FAILED TO JAM THE AC
0560      /MESSAGE POINTER
0561      /ERROR HALT
0562      /TO NEXT TEST
0563      /ISE LOOP; SCOPE LOOP
0564      /
0565      /RING BELL
0566      /CLEAR AC
0567      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0568      /LOAD BUFFER
0569      /STORE WHAT WAS LEFT IN AC
0570      /FETCH IT
0571      /INVERT CONTENTS OF AC
0572      /SUBTRACT SEND
0573      /EQUAL?
0574      /CHECK MONITOR
0575      /CLAB CHANGED AC?
0576      /MESSAGE POINTER
0577      /ERROR HALT
0578      /TO NEXT TEST
0579      /ISE LOOP; SCOPE LOOP
0580      /
0581      /CLEAR AC
0582      /SEND REG
0583      /SET BUFFER AND PRESET REGISTER TO 0000
0584      /SET AC TO 7777
0585      /JAM BUFFER PRESET (0000) OVER AC (7777)
0586      /SAVE AC
0587      /RESTORE AC
0588      /DID AC BECOME (0000)?
0589      /CHECK MONITOR
0590      /CLBA FAILED TO JAM THE AC
0591      /MESSAGE POINTER
0592      /ERROR HALT
0593      /TO NEXT TEST
0594      /ISE LOOP; SCOPE LOOP
0595      /
0596      /RING BELL
0597      /CLEAR AC
0598      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0599      /LOAD BUFFER
0600      /STORE WHAT WAS LEFT IN AC
0601      /FETCH IT
0602      /INVERT CONTENTS OF AC
0603      /SUBTRACT SEND
0604      /EQUAL?
0605      /CHECK MONITOR
0606      /CLAB CHANGED AC?
0607      /MESSAGE POINTER
0608      /ERROR HALT
0609      /TO NEXT TEST
0610      /ISE LOOP; SCOPE LOOP
0611      /
0612      /CLEAR AC
0613      /SEND REG
0614      /SET BUFFER AND PRESET REGISTER TO 0000
0615      /SET AC TO 7777
0616      /JAM BUFFER PRESET (0000) OVER AC (7777)
0617      /SAVE AC
0618      /RESTORE AC
0619      /DID AC BECOME (0000)?
0620      /CHECK MONITOR
0621      /CLBA FAILED TO JAM THE AC
0622      /MESSAGE POINTER
0623      /ERROR HALT
0624      /TO NEXT TEST
0625      /ISE LOOP; SCOPE LOOP
0626      /
0627      /RING BELL
0628      /CLEAR AC
0629      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0630      /LOAD BUFFER
0631      /STORE WHAT WAS LEFT IN AC
0632      /FETCH IT
0633      /INVERT CONTENTS OF AC
0634      /SUBTRACT SEND
0635      /EQUAL?
0636      /CHECK MONITOR
0637      /CLAB CHANGED AC?
0638      /MESSAGE POINTER
0639      /ERROR HALT
0640      /TO NEXT TEST
0641      /ISE LOOP; SCOPE LOOP
0642      /
0643      /CLEAR AC
0644      /SEND REG
0645      /SET BUFFER AND PRESET REGISTER TO 0000
0646      /SET AC TO 7777
0647      /JAM BUFFER PRESET (0000) OVER AC (7777)
0648      /SAVE AC
0649      /RESTORE AC
0650      /DID AC BECOME (0000)?
0651      /CHECK MONITOR
0652      /CLBA FAILED TO JAM THE AC
0653      /MESSAGE POINTER
0654      /ERROR HALT
0655      /TO NEXT TEST
0656      /ISE LOOP; SCOPE LOOP
0657      /
0658      /RING BELL
0659      /CLEAR AC
0660      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0661      /LOAD BUFFER
0662      /STORE WHAT WAS LEFT IN AC
0663      /FETCH IT
0664      /INVERT CONTENTS OF AC
0665      /SUBTRACT SEND
0666      /EQUAL?
0667      /CHECK MONITOR
0668      /CLAB CHANGED AC?
0669      /MESSAGE POINTER
0670      /ERROR HALT
0671      /TO NEXT TEST
0672      /ISE LOOP; SCOPE LOOP
0673      /
0674      /CLEAR AC
0675      /SEND REG
0676      /SET BUFFER AND PRESET REGISTER TO 0000
0677      /SET AC TO 7777
0678      /JAM BUFFER PRESET (0000) OVER AC (7777)
0679      /SAVE AC
0680      /RESTORE AC
0681      /DID AC BECOME (0000)?
0682      /CHECK MONITOR
0683      /CLBA FAILED TO JAM THE AC
0684      /MESSAGE POINTER
0685      /ERROR HALT
0686      /TO NEXT TEST
0687      /ISE LOOP; SCOPE LOOP
0688      /
0689      /RING BELL
0690      /CLEAR AC
0691      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0692      /LOAD BUFFER
0693      /STORE WHAT WAS LEFT IN AC
0694      /FETCH IT
0695      /INVERT CONTENTS OF AC
0696      /SUBTRACT SEND
0697      /EQUAL?
0698      /CHECK MONITOR
0699      /CLAB CHANGED AC?
0700      /MESSAGE POINTER
0701      /ERROR HALT
0702      /TO NEXT TEST
0703      /ISE LOOP; SCOPE LOOP
0704      /
0705      /CLEAR AC
0706      /SEND REG
0707      /SET BUFFER AND PRESET REGISTER TO 0000
0708      /SET AC TO 7777
0709      /JAM BUFFER PRESET (0000) OVER AC (7777)
0710      /SAVE AC
0711      /RESTORE AC
0712      /DID AC BECOME (0000)?
0713      /CHECK MONITOR
0714      /CLBA FAILED TO JAM THE AC
0715      /MESSAGE POINTER
0716      /ERROR HALT
0717      /TO NEXT TEST
0718      /ISE LOOP; SCOPE LOOP
0719      /
0720      /RING BELL
0721      /CLEAR AC
0722      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0723      /LOAD BUFFER
0724      /STORE WHAT WAS LEFT IN AC
0725      /FETCH IT
0726      /INVERT CONTENTS OF AC
0727      /SUBTRACT SEND
0728      /EQUAL?
0729      /CHECK MONITOR
0730      /CLAB CHANGED AC?
0731      /MESSAGE POINTER
0732      /ERROR HALT
0733      /TO NEXT TEST
0734      /ISE LOOP; SCOPE LOOP
0735      /
0736      /CLEAR AC
0737      /SEND REG
0738      /SET BUFFER AND PRESET REGISTER TO 0000
0739      /SET AC TO 7777
0740      /JAM BUFFER PRESET (0000) OVER AC (7777)
0741      /SAVE AC
0742      /RESTORE AC
0743      /DID AC BECOME (0000)?
0744      /CHECK MONITOR
0745      /CLBA FAILED TO JAM THE AC
0746      /MESSAGE POINTER
0747      /ERROR HALT
0748      /TO NEXT TEST
0749      /ISE LOOP; SCOPE LOOP
0750      /
0751      /RING BELL
0752      /CLEAR AC
0753      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0754      /LOAD BUFFER
0755      /STORE WHAT WAS LEFT IN AC
0756      /FETCH IT
0757      /INVERT CONTENTS OF AC
0758      /SUBTRACT SEND
0759      /EQUAL?
0760      /CHECK MONITOR
0761      /CLAB CHANGED AC?
0762      /MESSAGE POINTER
0763      /ERROR HALT
0764      /TO NEXT TEST
0765      /ISE LOOP; SCOPE LOOP
0766      /
0767      /CLEAR AC
0768      /SEND REG
0769      /SET BUFFER AND PRESET REGISTER TO 0000
0770      /SET AC TO 7777
0771      /JAM BUFFER PRESET (0000) OVER AC (7777)
0772      /SAVE AC
0773      /RESTORE AC
0774      /DID AC BECOME (0000)?
0775      /CHECK MONITOR
0776      /CLBA FAILED TO JAM THE AC
0777      /MESSAGE POINTER
0778      /ERROR HALT
0779      /TO NEXT TEST
0780      /ISE LOOP; SCOPE LOOP
0781      /
0782      /RING BELL
0783      /CLEAR AC
0784      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0785      /LOAD BUFFER
0786      /STORE WHAT WAS LEFT IN AC
0787      /FETCH IT
0788      /INVERT CONTENTS OF AC
0789      /SUBTRACT SEND
0790      /EQUAL?
0791      /CHECK MONITOR
0792      /CLAB CHANGED AC?
0793      /MESSAGE POINTER
0794      /ERROR HALT
0795      /TO NEXT TEST
0796      /ISE LOOP; SCOPE LOOP
0797      /
0798      /CLEAR AC
0799      /SEND REG
0800      /SET BUFFER AND PRESET REGISTER TO 0000
0801      /SET AC TO 7777
0802      /JAM BUFFER PRESET (0000) OVER AC (7777)
0803      /SAVE AC
0804      /RESTORE AC
0805      /DID AC BECOME (0000)?
0806      /CHECK MONITOR
0807      /CLBA FAILED TO JAM THE AC
0808      /MESSAGE POINTER
0809      /ERROR HALT
0810      /TO NEXT TEST
0811      /ISE LOOP; SCOPE LOOP
0812      /
0813      /RING BELL
0814      /CLEAR AC
0815      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0816      /LOAD BUFFER
0817      /STORE WHAT WAS LEFT IN AC
0818      /FETCH IT
0819      /INVERT CONTENTS OF AC
0820      /SUBTRACT SEND
0821      /EQUAL?
0822      /CHECK MONITOR
0823      /CLAB CHANGED AC?
0824      /MESSAGE POINTER
0825      /ERROR HALT
0826      /TO NEXT TEST
0827      /ISE LOOP; SCOPE LOOP
0828      /
0829      /CLEAR AC
0830      /SEND REG
0831      /SET BUFFER AND PRESET REGISTER TO 0000
0832      /SET AC TO 7777
0833      /JAM BUFFER PRESET (0000) OVER AC (7777)
0834      /SAVE AC
0835      /RESTORE AC
0836      /DID AC BECOME (0000)?
0837      /CHECK MONITOR
0838      /CLBA FAILED TO JAM THE AC
0839      /MESSAGE POINTER
0840      /ERROR HALT
0841      /TO NEXT TEST
0842      /ISE LOOP; SCOPE LOOP
0843      /
0844      /RING BELL
0845      /CLEAR AC
0846      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0847      /LOAD BUFFER
0848      /STORE WHAT WAS LEFT IN AC
0849      /FETCH IT
0850      /INVERT CONTENTS OF AC
0851      /SUBTRACT SEND
0852      /EQUAL?
0853      /CHECK MONITOR
0854      /CLAB CHANGED AC?
0855      /MESSAGE POINTER
0856      /ERROR HALT
0857      /TO NEXT TEST
0858      /ISE LOOP; SCOPE LOOP
0859      /
0860      /CLEAR AC
0861      /SEND REG
0862      /SET BUFFER AND PRESET REGISTER TO 0000
0863      /SET AC TO 7777
0864      /JAM BUFFER PRESET (0000) OVER AC (7777)
0865      /SAVE AC
0866      /RESTORE AC
0867      /DID AC BECOME (0000)?
0868      /CHECK MONITOR
0869      /CLBA FAILED TO JAM THE AC
0870      /MESSAGE POINTER
0871      /ERROR HALT
0872      /TO NEXT TEST
0873      /ISE LOOP; SCOPE LOOP
0874      /
0875      /RING BELL
0876      /CLEAR AC
0877      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0878      /LOAD BUFFER
0879      /STORE WHAT WAS LEFT IN AC
0880      /FETCH IT
0881      /INVERT CONTENTS OF AC
0882      /SUBTRACT SEND
0883      /EQUAL?
0884      /CHECK MONITOR
0885      /CLAB CHANGED AC?
0886      /MESSAGE POINTER
0887      /ERROR HALT
0888      /TO NEXT TEST
0889      /ISE LOOP; SCOPE LOOP
0890      /
0891      /CLEAR AC
0892      /SEND REG
0893      /SET BUFFER AND PRESET REGISTER TO 0000
0894      /SET AC TO 7777
0895      /JAM BUFFER PRESET (0000) OVER AC (7777)
0896      /SAVE AC
0897      /RESTORE AC
0898      /DID AC BECOME (0000)?
0899      /CHECK MONITOR
0900      /CLBA FAILED TO JAM THE AC
0901      /MESSAGE POINTER
0902      /ERROR HALT
0903      /TO NEXT TEST
0904      /ISE LOOP; SCOPE LOOP
0905      /
0906      /RING BELL
0907      /CLEAR AC
0908      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0909      /LOAD BUFFER
0910      /STORE WHAT WAS LEFT IN AC
0911      /FETCH IT
0912      /INVERT CONTENTS OF AC
0913      /SUBTRACT SEND
0914      /EQUAL?
0915      /CHECK MONITOR
0916      /CLAB CHANGED AC?
0917      /MESSAGE POINTER
0918      /ERROR HALT
0919      /TO NEXT TEST
0920      /ISE LOOP; SCOPE LOOP
0921      /
0922      /CLEAR AC
0923      /SEND REG
0924      /SET BUFFER AND PRESET REGISTER TO 0000
0925      /SET AC TO 7777
0926      /JAM BUFFER PRESET (0000) OVER AC (7777)
0927      /SAVE AC
0928      /RESTORE AC
0929      /DID AC BECOME (0000)?
0930      /CHECK MONITOR
0931      /CLBA FAILED TO JAM THE AC
0932      /MESSAGE POINTER
0933      /ERROR HALT
0934      /TO NEXT TEST
0935      /ISE LOOP; SCOPE LOOP
0936      /
0937      /RING BELL
0938      /CLEAR AC
0939      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0940      /LOAD BUFFER
0941      /STORE WHAT WAS LEFT IN AC
0942      /FETCH IT
0943      /INVERT CONTENTS OF AC
0944      /SUBTRACT SEND
0945      /EQUAL?
0946      /CHECK MONITOR
0947      /CLAB CHANGED AC?
0948      /MESSAGE POINTER
0949      /ERROR HALT
0950      /TO NEXT TEST
0951      /ISE LOOP; SCOPE LOOP
0952      /
0953      /CLEAR AC
0954      /SEND REG
0955      /SET BUFFER AND PRESET REGISTER TO 0000
0956      /SET AC TO 7777
0957      /JAM BUFFER PRESET (0000) OVER AC (7777)
0958      /SAVE AC
0959      /RESTORE AC
0960      /DID AC BECOME (0000)?
0961      /CHECK MONITOR
0962      /CLBA FAILED TO JAM THE AC
0963      /MESSAGE POINTER
0964      /ERROR HALT
0965      /TO NEXT TEST
0966      /ISE LOOP; SCOPE LOOP
0967      /
0968      /RING BELL
0969      /CLEAR AC
0970      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
0971      /LOAD BUFFER
0972      /STORE WHAT WAS LEFT IN AC
0973      /FETCH IT
0974      /INVERT CONTENTS OF AC
0975      /SUBTRACT SEND
0976      /EQUAL?
0977      /CHECK MONITOR
0978      /CLAB CHANGED AC?
0979      /MESSAGE POINTER
0980      /ERROR HALT
0981      /TO NEXT TEST
0982      /ISE LOOP; SCOPE LOOP
0983      /
0984      /CLEAR AC
0985      /SEND REG
0986      /SET BUFFER AND PRESET REGISTER TO 0000
0987      /SET AC TO 7777
0988      /JAM BUFFER PRESET (0000) OVER AC (7777)
0989      /SAVE AC
0990      /RESTORE AC
0991      /DID AC BECOME (0000)?
0992      /CHECK MONITOR
0993      /CLBA FAILED TO JAM THE AC
0994      /MESSAGE POINTER
0995      /ERROR HALT
0996      /TO NEXT TEST
0997      /ISE LOOP; SCOPE LOOP
0998      /
0999      /RING BELL
1000      /CLEAR AC
1001      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
1002      /LOAD BUFFER
1003      /STORE WHAT WAS LEFT IN AC
1004      /FETCH IT
1005      /INVERT CONTENTS OF AC
1006      /SUBTRACT SEND
1007      /EQUAL?
1008      /CHECK MONITOR
1009      /CLAB CHANGED AC?
1010      /MESSAGE POINTER
1011      /ERROR HALT
1012      /TO NEXT TEST
1013      /ISE LOOP; SCOPE LOOP
1014      /
1015      /CLEAR AC
1016      /SEND REG
1017      /SET BUFFER AND PRESET REGISTER TO 0000
1018      /SET AC TO 7777
1019      /JAM BUFFER PRESET (0000) OVER AC (7777)
1020      /SAVE AC
1021      /RESTORE AC
1022      /DID AC BECOME (0000)?
1023      /CHECK MONITOR
1024      /CLBA FAILED TO JAM THE AC
1025      /MESSAGE POINTER
1026      /ERROR HALT
1027      /TO NEXT TEST
1028      /ISE LOOP; SCOPE LOOP
1029      /
1030      /RING BELL
1031      /CLEAR AC
1032      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
1033      /LOAD BUFFER
1034      /STORE WHAT WAS LEFT IN AC
1035      /FETCH IT
1036      /INVERT CONTENTS OF AC
1037      /SUBTRACT SEND
1038      /EQUAL?
1039      /CHECK MONITOR
1040      /CLAB CHANGED AC?
1041      /MESSAGE POINTER
1042      /ERROR HALT
1043      /TO NEXT TEST
1044      /ISE LOOP; SCOPE LOOP
1045      /
1046      /CLEAR AC
1047      /SEND REG
1048      /SET BUFFER AND PRESET REGISTER TO 0000
1049      /SET AC TO 7777
1050      /JAM BUFFER PRESET (0000) OVER AC (7777)
1051      /SAVE AC
1052      /RESTORE AC
1053      /DID AC BECOME (0000)?
1054      /CHECK MONITOR
1055      /CLBA FAILED TO JAM THE AC
1056      /MESSAGE POINTER
1057      /ERROR HALT
1058      /TO NEXT TEST
1059      /ISE LOOP; SCOPE LOOP
1060      /
1061      /RING BELL
1062      /CLEAR AC
1063      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
1064      /LOAD BUFFER
1065      /STORE WHAT WAS LEFT IN AC
1066      /FETCH IT
1067      /INVERT CONTENTS OF AC
1068      /SUBTRACT SEND
1069      /EQUAL?
1070      /CHECK MONITOR
1071      /CLAB CHANGED AC?
1072      /MESSAGE POINTER
1073      /ERROR HALT
1074      /TO NEXT TEST
1075      /ISE LOOP; SCOPE LOOP
1076      /
1077      /CLEAR AC
1078      /SEND REG
1079      /SET BUFFER AND PRESET REGISTER TO 0000
1080      /SET AC TO 7777
1081      /JAM BUFFER PRESET (0000) OVER AC (7777)
1082      /SAVE AC
1083      /RESTORE AC
1084      /DID AC BECOME (0000)?
1085      /CHECK MONITOR
1086      /CLBA FAILED TO JAM THE AC
1087      /MESSAGE POINTER
1088      /ERROR HALT
1089      /TO NEXT TEST
1090      /ISE LOOP; SCOPE LOOP
1091      /
1092      /RING BELL
1093      /CLEAR AC
1094      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
1095      /LOAD BUFFER
1096      /STORE WHAT WAS LEFT IN AC
1097      /FETCH IT
1098      /INVERT CONTENTS OF AC
1099      /SUBTRACT SEND
1100      /EQUAL?
1101      /CHECK MONITOR
1102      /CLAB CHANGED AC?
1103      /MESSAGE POINTER
1104      /ERROR HALT
1105      /TO NEXT TEST
1106      /ISE LOOP; SCOPE LOOP
1107      /
1108      /CLEAR AC
1109      /SEND REG
1110      /SET BUFFER AND PRESET REGISTER TO 0000
1111      /SET AC TO 7777
1112      /JAM BUFFER PRESET (0000) OVER AC (7777)
1113      /SAVE AC
1114      /RESTORE AC
1115      /DID AC BECOME (0000)?
1116      /CHECK MONITOR
1117      /CLBA FAILED TO JAM THE AC
1118      /MESSAGE POINTER
1119      /ERROR HALT
1120      /TO NEXT TEST
1121      /ISE LOOP; SCOPE LOOP
1122      /
1123      /RING BELL
1124      /CLEAR AC
1125      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
1126      /LOAD BUFFER
1127      /STORE WHAT WAS LEFT IN AC
1128      /FETCH IT
1129      /INVERT CONTENTS OF AC
1130      /SUBTRACT SEND
1131      /EQUAL?
1132      /CHECK MONITOR
1133      /CLAB CHANGED AC?
1134      /MESSAGE POINTER
1135      /ERROR HALT
1136      /TO NEXT TEST
1137      /ISE LOOP; SCOPE LOOP
1138      /
1139      /CLEAR AC
1140      /SEND REG
1141      /SET BUFFER AND PRESET REGISTER TO 0000
1142      /SET AC TO 7777
1143      /JAM BUFFER PRESET (0000) OVER AC (7777)
1144      /SAVE AC
1145      /RESTORE AC
1146      /DID AC BECOME (0000)?
1147      /CHECK MONITOR
1148      /CLBA FAILED TO JAM THE AC
1149      /MESSAGE POINTER
1150      /ERROR HALT
1151      /TO NEXT TEST
1152      /ISE LOOP; SCOPE LOOP
1153      /
1154      /RING BELL
1155      /CLEAR AC
1156      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
1157      /LOAD BUFFER
1158      /STORE WHAT WAS LEFT IN AC
1159      /FETCH IT
1160      /INVERT CONTENTS OF AC
1161      /SUBTRACT SEND
1162      /EQUAL?
1163      /CHECK MONITOR
1164      /CLAB CHANGED AC?
1165      /MESSAGE POINTER
1166      /ERROR HALT
1167      /TO NEXT TEST
1168      /ISE LOOP; SCOPE LOOP
1169      /
1170      /CLEAR AC
1171      /SEND REG
1172      /SET BUFFER AND PRESET REGISTER TO 0000
1173      /SET AC TO 7777
1174      /JAM BUFFER PRESET (0000) OVER AC (7777)
1175      /SAVE AC
1176      /RESTORE AC
1177      /DID AC BECOME (0000)?
1178      /CHECK MONITOR
1179      /CLBA FAILED TO JAM THE AC
1180      /MESSAGE POINTER
1181      /ERROR HALT
1182      /TO NEXT TEST
1183      /ISE LOOP; SCOPE LOOP
1184      /
1185      /RING BELL
1186      /CLEAR AC
1187      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
1188      /LOAD BUFFER
1189      /STORE WHAT WAS LEFT IN AC
1190      /FETCH IT
1191      /INVERT CONTENTS OF AC
1192      /SUBTRACT SEND
1193      /EQUAL?
1194      /CHECK MONITOR
1195      /CLAB CHANGED AC?
1196      /MESSAGE POINTER
1197      /ERROR HALT
1198      /TO NEXT TEST
1199      /ISE LOOP; SCOPE LOOP
1200      /
1201      /CLEAR AC
1202      /SEND REG
1203      /SET BUFFER AND PRESET REGISTER TO 0000
1204      /SET AC TO 7777
1205      /JAM BUFFER PRESET (0000) OVER AC (7777)
1206      /SAVE AC
1207      /RESTORE AC
1208      /DID AC BECOME (0000)?
1209      /CHECK MONITOR
1210      /CLBA FAILED TO JAM THE AC
1211      /MESSAGE POINTER
1212      /ERROR HALT
1213      /TO NEXT TEST
1214      /ISE LOOP; SCOPE LOOP
1215      /
1216      /RING BELL
1217      /CLEAR AC
1218      /GET A NUMBER= BINARY UP-COUNT SEQUENCE 0 THRU 7777
1219      /LOAD BUFFER
1220      /STORE WHAT WAS LEFT IN AC
1221      /FETCH IT
1222      /INVERT CONTENTS OF AC
1223      /SUBTRACT SEND
1224      /EQUAL?
1225      /CHECK MONITOR
1226      /CLAB CHANGED AC?
1227      /MESSAGE POINTER
122
```

```

/DOES THE AC JAM INTO THE BUFFER?
/
TST12, CLA CMA          /SET AC=7777
0235 7240                /SET BUFF=7777
0236 6133                /CLEAR AC
0237 7300                /LOAD BUFFER TO ALL ZEROS
0240 6133                /SAVE AC
0241 3053                /READ BUFFER AND PRESET REGISTER
0242 6136                /SAVE TEST VALUE
0243 3052                /RESTORE IT
0244 1052                /DID BUFFER AND PRESET REGISTER GET CLEARED
0245 7650                /CHECK MONITOR
0246 4427                /AC JAM INTO BUFFER FAILED
0247 4425                /MESSAGE POINTER
0250 5317                /ERROR HALT
0251 7402                /TO NEXT TEST
0252 7610                /IS2 LOOP; SCOPE LOOP
0253 0235

/DO ALL NUMBERS TRANSFER BETWEEN AC AND BUFFER PROPERLY?
/
TST13, CLA CLL          /CLEAR AC
0254 7300                /GET TEST NUMBER
0255 1045                /SEND IT
0256 6133                /CLEAR AC
0257 7200                /RETRIEVE IT
0260 6136                /SAVE IT
0261 3052                /RESTORE IT
0262 1052                /COMPLEMENT
0263 7041                /ADD TEST NUMBER
0264 1045                /WERE THEY EQUAL?
0265 7650                /CHECK MONITOR
0266 4427                /AC - BUFFER TO AC DATA TRANSFER FAILED
0267 4425                /MESSAGE POINTER
0270 5335                /ERROR HALT
0271 7402                /TO NEXT TEST
0272 7610                /IS2 LOOP; SCOPE LOOP
0273 0254

```

```

/DO RANDOM NUMBERS TRANSFER BETWEEN AC AND BUFFER PROPERLY?
/
TST14: JMS I RANDOM /LOAD BUFFER AND PRESET REGISTER WITH A RANDOM NUMBER
      DCA SEND /SAVE IT
      TAD SEND /RESTORE IT
      CLAB /SEND IT
      JMS I RANDOM /LOAD THE AC WITH A RANDOM NUMBER
      CLBA /READ BACK RANDOM NUMBER FROM BUFFER PRESET REGISTER
      DCA RXED /SAVE TEST RETURN
      TAD RXED /RESTORE IT
      CIA /COMPLEMENT
      TAD SEND /SUBTRACT TEST NUMBER
      SNA CLA /EQUAL?
      JMS I NERROR /CHECK MONITOR
      JMS I ERROR /AC - BUFFER - AC DATA INTERCHANGE FAILED
      TST14M /MESSAGE POINTER
      HLT /ERROR HALT
      SKP CLA /TO NEXT TEST
      TST14 /ISE LOOP; SCOPE LOOP

```

/DOES READING THE BUFFER CHANGE ITS CONTENTS?

```

TST15: JMS I RANDOM /GET RANDOM NUMBER
      DCA SEND /SAVE IT
      TAD SEND /RESTORE IT
      CLAB /SEND IT
      JMS I RANDOM /LOAD AC WITH A RANDOM NUMBER
      CLBA /BRING BACK TEST NUMBER
      JMS I RANDOM /LOAD AC WITH A RANDOM NUMBER
      CLBA RXED /READ BUFFER AGAIN
      DCA RXED /SAVE TEST VALUE
      TAD /RESTORE IT
      CIA /COMPLEMENT
      TAD SEND /SUBTRACT TEST NUMBER
      SNA CLA /EQUAL
      JMS I NERROR /CHECK MONITOR
      JMS I ERROR /CLBA CHANGED THE CONTENTS OF THE BUFFER
      TST15M /MESSAGE POINTER
      HLT /ERROR HALT
      SKP CLA /TO NEXT TEST
      TST15 /ISE LOOP; SCOPE LOOP

```


/CAN THE BUFFER SURVIVE CHECKERBOARD?

0403	7320	TST17,	CLA CLL	K5252	/CLEAR AC
0404	1133	TAD		SEND	/GET TEST PATTERN
0405	3053	DCA		SEND	/SAVE TEST PATTERN
0406	1053	TAD			/RESTORE IT
0407	6133	CLAB			/SEND IT
0410	6136	CLBA			/GET IT
0411	7040	CMA			
0412	6133	CLAB			
0413	6136	CLBA			
0414	7040	CMA			
0415	6133	CLAB			
0416	6136	CLBA			
0417	7040	CMA			
0420	6133	CLAB			
0421	6136	CLBA			
0422	7040	CMA			
0423	6133	CLAB			
0424	6136	CLBA			
0425	7040	CMA			
0426	6133	CLAB			
0427	6136	CLBA			
0430	7040	CMA			
0431	6133	CLAB			
0432	6136	CLBA			
0433	7040	CMA			
0434	6133	CLAB			
0435	6136	CLBA			
0436	7040	CMA			
0437	6133	CLAB			
0440	6136	CLBA			
0441	7040	CMA			
0442	6133	CLAB			
0443	6136	CLBA			
0444	7040	CMA			
0445	6133	CLAB			
0446	6136	CLBA			
0447	7040	CMA			
0450	6133	CLAB			
0451	6136	CLBA			
0452	7040	CMA			
0453	3052	DCA		RXED	/SEND IT
0454	1052	TAD		RXED	/GET IT
0455	7041	CIA			/SAVE FINAL PATTERN
0456	1053	TAD		SEND	/RESTORE IT
0457	7650	SNA CLA			/COMPLEMENT
0460	4427	JMS I			/SUBTRACT TEST PATTERN
0461	4425	JMS I			/EQUAL?
0462	5434	TST17M			/CHECK MONITOR
0463	7402	HLT			/BUFFER FAILED CHECKBOARD TEST
0464	7610	SKP CLA			/MESSAGE POINTER
0465	0403	TST17			/ERROR HALT
					/TO NEXT TEST
					/ISZ LOOP; SCOPE LOOP

/CAN THE BUFFER SURVIVE RANDOM COMPLEMENT PATTERNS?

```

0466      4444      JMS I      RANDOM      /GENERATE A RANDOM NUMBER
0467      3053      DCA          SEND      /SAVE IT
0470      1053      TAD          SEND      /RESTORE IT
0471      6133      CLAB        /SEND IT
0472      6136      CLBA        /GET IT
0473      7040      CMA
0474      6133      CLAB
0475      6136      CLBA
0476      7040      CMA
0477      6133      CLAB
0500      6136      CLBA
0501      7040      CMA
0502      6133      CLAB
0503      6136      CLBA
0504      7040      CMA
0505      6133      CLAB
0506      6136      CLBA
0507      7040      CMA
0510      6133      CLAB
0511      6136      CLBA
0512      7040      CMA
0513      6133      CLAB
0514      6136      CLBA
0515      7040      CMA
0516      6133      CLAB
0517      6136      CLBA
0520      7040      CMA
0521      6133      CLAB
0522      6136      CLBA
0523      7040      CMA
0524      6133      CLAB
0525      6136      CLBA
0526      7040      CMA
0527      6133      CLAB
0530      6136      CLBA
0531      7040      CMA
0532      6133      CLAB
0533      6136      CLBA
0534      7040      CMA
0535      3052      DCA          RXED
0536      1052      TAD          RXED
0537      7041      CIA          SEND
0540      1053      TAD          SNA CLA
0541      7650      JMS I      NERROR
0542      4427      JMS I      NERROR
0543      4425      TST18M
0544      5455      HLT
0545      7402      SKP CLA
0546      7610      TST18
0547      0466

```

```

/SEND IT
/GET IT
/SAVE FINAL PATTERN
/RESTORE IT
/COMPLEMENT
/SUBTRACT TEST PATTERN
/EQUAL?
/CHECK MONITOR
/BUFFER FAILED RANDOM COMPLEMENT PATTERN
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/IS2 LOOP; SCOPE LOOP

```

/CLEV=6134 AC TO CLOCK ENABLE REGISTER
/DOES CLEN AFFECT THE AC?
/

0550	7300	TST19,	CLL CLA	REGA	/CLEAR AC
0551	1045		TAD		/RESTORE TEST NUMBER
0552	6134		CLEN		/DOES CLEN AFFECT AC
0553	3052		DCA	RXED	/SAVE AC
0554	1052		TAD	RXED	/RESTORE IT
0555	7041		CIA		/COMPLEMENT
0556	1045		TAD	REGA	/SUBTRACT TEST NUMBER
0557	7650		SNA CLA		/EQUAL?
0560	4427		JMS I	NERROR	/CHECK MONITOR
0561	4425		JMS I	ERROR	/AC TO CLOCK ENABLE REG CHANGED AC
0562	5476		TST19M		/MESSAGE POINTER
0563	7402		HLT		/ERROR HALT
0564	7610		SKP CLA		/TO NEXT TEST
0565	0550		TST19		/ISZ LOOP; SCOPE LOOP

/PRESET REGISTER AND COUNTER DATA INTERCHANGE
/CLSA#6135 STATUS REGISTER TO AC
/CLLR#6132 AC TO CLOCK CONTROL REGISTER
/

/DOES BUFFER CHANGE AFTER A TRANSFER TO THE COUNTER?
/

0566	7300	TST20,	CLL CLA		/CLEAR AC
0567	6135		CLSA		/CLEAR STATUS
0570	7300		CLA CLL		/CLEAR AC
0571	1045		TAD	REGA	/RESTORE TEST NUMBER
0572	6133		CLAB		/LOAD BUFFER PRESET REGISTER WITH A BINARY UPCOUNT NUMBER
0573	7300		CLA CLL		/CLEAR AC
0574	6132		CLLR		/STOP CLOCK, SET ALL MODES=0
0575	1107		TAD	K0100	/MODE CONTROL REG BIT 2=1
0576	6132		CLLR		/SET MODE 2, ENABLING CLR LOAD CNT
0577	7200		CLA		/CLEAR AC
0600	1111		TAD	K0200	/AC BIT 4=1, SIMULATE CLR OFLOW ON 6134
0601	6134		CLEN		/TRANSFER PRESET COUNT TO CLOCK COUNTER
0602	6136		CLRA		/READ THE BUFFER
0603	3052		DCA	RXED	/SAVE IT
0604	1052		TAD	RXED	/RESTORE IT
0605	7041		CIA		/COMPLEMENT
0606	1045		TAD	REGA	/SUBTRACT TEST NUMBER
0607	7650		SNA CLA		/EQUAL?
0610	4427		JMS I	NERROR	/CHECK MONITOR
0611	4425		JMS I	ERROR	/TRANSFER FROM BUFFER TO COUNTER CHANGES BUFFER
0612	5516		TST20M		/MESSAGE POINTER
0613	7402		HLT		/ERROR HALT
0614	7610		SKP CLA		/TO NEXT TEST
0615	0570		TST20+2		/ISZ LOOP; SCOPE LOOP

```

0616 6135          /CLEAR STATUS
0617 7300          /CLEAR AC
0620 6133          /LOAD BUFFER TO 0000
0621 6132          /STOP CLOCK, SET ALL MODES=0
0622 1107          /SET AC 05=1
0623 6132          /SET MODE 2=1, THEREBY CLEARING CLOCK COUNTER
0624 6134          /ENABLE INTERRUPT ON OVERFLOW
0625 7240          /SET AC 7777
0626 3053          /SAVE IT
0627 1053          /FETCH IT
0630 6133          /SET BUFFER 7777
0631 6137          /READ COUNTER
0632 3052          /SAVE COUNT
0633 1052          /RESTORE IT
0634 7650          /ZERO?
0635 4427          /CHECK MONITOR
0636 4425          /COUNTER FAILED TO JAM 0000 INTO 7777
0637 5540          /MESSAGE POINTER
0640 7402          /ERROR HALT
0641 7610          /TO NEXT TEST
0642 0616          /IS2 LOOP; SCOPE LOOP

```

/DOES SIGNAL CLR CNT WORK

```

0643 6135          /CLEAR STATUS
0644 7350          /SET AC=3777
0645 3053          /SAVE AC
0646 1053          /FETCH IT
0647 6133          /SET BUFFER TO 3777 (USE 3777 SO WE DON'T SET OVERFLOW FLOP)
0650 7300          /CLEAR AC
0651 1111          /ENABLE LOAD COUNT GATES
0652 6134          /LOAD COUNTER TO 3777 (GENERATE LOAD CNT)
0653 7300          /CLEAR AC
0654 6132          /ZERO MODE 2
0655 1107          /SET AC 05=1
0656 6132          /SET MODE 2, THEREBY GENERATING "CLC CLR CNT"
0657 7300          /CLEAR AC
0660 6137          /READ THE COUNTER
0661 3052          /SAVE IT
0662 1052          /RESTORE IT
0663 7650          /ZERO?
0664 4427          /CHECK MONITOR
0665 4425          /CLR CNT FAILED TO CLEAR THE COUNTER FROM 3777 TO 0000
0666 5556          /MESSAGE POINTER
0667 7402          /ERROR HALT
0670 7610          /TO NEXT TEST
0671 0643          /IS2 LOOP; SCOPE LOOP

```

```

0672 6135
0673 7300
0674 1045
0675 6133
0676 7300
0677 6132
0700 1107
0701 6132
0702 7200
0703 1111
0704 6134
0705 6137
0706 3052
0707 1052
0710 7041
0711 1045
0712 7650
0713 4427
0714 4425
0715 5576
0716 7402
0717 7610
0720 0672

/DO ALL NUMBERS TRANSFER BETWEEN THE BUFFER AND COUNTER?
/
TST23, CLSA
CLA CLL
TAD REGA
CLAB
CLA CLL
CLLR
TAD K0100
CLLR
CLA K0200
TAD
CLEN
CLCA
DCA
RXED
TAD RXED
CIA
TAD REGA
SNA CLA
JMS I NERROR
JMS I ERROR
TST23M
HLT
SKP CLA
TST23

/CLEAR STATUS
/CLEAR AC
/LOAD AC WITH TEST NUMBER
/SET BUFFER TO TEST NUMBER
/CLEAR AC
/STOP CLOCK, SET ALL MODES=0
/SET AC 05=1
/GENERATE "CLR CNT"
/CLEAR AC
/SET AC 04=1
/GENERATE "LOAD CNT"
/COUNTER TO AC
/SAVE IT
/RESTORE IT
/COMPLEMENT
/SUBTRACT TEST NUMBER
/EQUAL?
/CHECK WITH MONITOR
/BUFFER TO COUNTER DATA INTERCHANGE FAILED
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/IS2 LOOP; SCOPE LOOP

```

```

/DO RANDOM NUMBERS TRANSFER BETWEEN BUFFER AND COUNTER?
/
TST24, JMS I RANDOM
CLAB SEND
DCA
CLSA
CLA
CLLR
TAD K0100
CLLR
CLA K0200
TAD
CLEN
JMS I RANDOM
CLAB RANDOM
JMS I RANDOM
CLCA RXED
DCA RXED
TAD
CIA
TAD SEND
SNA CLA
JMS I NERROR
JMS I ERROR
TST24M
HLT
SKP CLA
TST24
0721 4444
0722 6133
0723 3053
0724 6135
0725 7200
0726 6132
0727 1107
0730 6132
0731 7200
0732 1111
0733 6134
0734 4444
0735 6133
0736 4444
0737 6137
0740 3052
0741 1052
0742 7041
0743 1053
0744 7650
0745 4427
0746 4425
0747 5614
0750 7402
0751 7610
0752 0721

/GET RANDOM NUMBER
/LOAD BUFFER RANDOM
/SAVE TEST NUMBER
/CLEAR CLOCK STATUS
/CLEAR AC
/STOP CLOCK, SET ALL MODES=0
/SET AC 05=1
/GENERATE "CLR CNT"
/CLEAR AC
/SET AC 04=1
/GENERATE "LOAD CNT"
/GET RANDOM NUMBER
/LOAD BUFFER RANDOM
/LOAD AC RANDOM
/READ COUNTER
/SAVE TEST VALUE
/RESTORE IT
/COMPLEMENT
/SUBTRACT TEST NUMBER
/EQUAL?
/CHECK MONITOR
/BUFFER TO COUNTER
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP/ SCOPE LOOP
INTERCHANGE FAILED

```

/ DOES READING THE COUNTER CHANGE ITS STATE?

0753	444	JMS I	RANDOM	/GET RANDOM TEST NUMBER
0754	6133	CLAB		/SEND IT TO BUFFER
0755	3053	DCA	SEND	/SAVE IT
0756	6132	CLLR		/STOP CLOCK, SET ALL MODES=0
0757	1107	TAD	K0100	/SET AC 05=1
0760	6132	CLLR		/GENERATE "CLR CNT"
0761	6135	CLSA		/CLEAR CLOCK STATUS
0762	7200	CLA		/CLEAR AC
0763	1111	TAD	K0200	/SET AC 04=1
0764	6134	CLEN		/GENERATE "LOAD CNT"
0765	4444	JMS I	RANDOM	/GET RANDOM NUMBER
0766	6133	CLAB		/SEND IT TO BUFFER
0767	4444	JMS I	RANDOM	/GET RANDOM NUMBER
0770	6137	CLCA		/READ CLOCK COUNTER
0771	4444	JMS I	RANDOM	/GET RANDOM NUMBER
0772	6133	CLAB		/SEND IT TO BUFFER
0773	4444	JMS I	RANDOM	/GET RANDOM NUMBER
0774	6137	CLCA		/READ CLOCK COUNTER
0775	3052	DCA	RXED	/SAVE IT
0776	1052	TAD	RXED	/RESTORE IT
0777	7041	CIA		/COMPLEMENT
1000	1053	TAD	SEND	/SUBTRACT TEST NUMBER
1001	7650	SNA CLA		/EQUAL?
1002	4427	JMS I	NERROR	/CHECK MONITOR
1003	4425	JMS I	ERROR	/CLCA) READ THE COUNTER CHANGES THE COUNTERS STATE
1004	5632	TST25M		/MESSAGE POINTER
1005	7402	HLT		/ERROR HALT
1006	7610	SKP CLA		/TO NEXT TEST
1007	0753	TST25		/IS2 LOOP) SCOPE LOOP
1010	7340	CLA CLL	CMA	/SET AC=777
1011	3045	DCA	REGA	/PRESET COUNTER FOR NEXT TEST

/CAN THE BUF TO COUNTER AND COUNTER TO BUF FUNCTION AT HIGH SPEED?

```

1012 4444      JMS I   RANDOM
1013 6133      CLAB
1014 3053      DCA     SEND
1015 7200      CLA
1016 6132      CLLR
1017 1107      TAD     K0100
1020 6132      CLLR
1021 6135      CLSA
1022 7200      CLA
1023 1111      TAD     K0200
1024 6134      CLEN
1025 6137      CLCA
1026 2046      ISZ
1027 5215      JMP
1030 3052      DCA     TST26+3
1031 1052      TAD     RXED
1032 7041      CIA
1033 1053      TAD     SEND
1034 7650      SNA CLA
1035 4427      JMS I   NERROR
1036 4425      JMS I   ERROR
1037 5653      TST26M
1040 7402      HLT
1041 7610      SKP CLA
1042 1012      TST26

      /GET RANDOM NUMBER
      /SEND IT TO BUFFER
      /SAVE IT
      /CLEAR AC
      /STOP CLOCK
      /SET AC 05#1
      /GENERATE "CLR CNT"
      /CLEAR CLOCK STATUS
      /CLEAR AC
      /SET AC 04#1
      /GENERATE "LOAD CNT"
      /READ COUNTER
      /DONE?
      /BACK TO START 4096 TIMES
      /SAVE FINAL NUMBER
      /RESTORE IT
      /COMPLEMENT
      /SUBTRACT TEST NUMBER
      /EQUAL?
      /CHECK MONITOR
      /THE BUFFER COUNTER BUFFER DATA INTERCHANGE FAILED AT HIGH SPEED
      /MESSAGE POINTER
      /ERROR HALT
      /TO NEXT TEST
      /ISZ LOOP1 SCOPE LOOP

```

```

1043 7300 /DOES (LOAD CNT) PERFORM LOGIC OR?
1044 6132 /
1045 1107 TST27,
1046 6132 CLA CLL
1047 6135 CLR K0100
1050 4444 CLLR
1051 6133 CLSA
1052 3053 JMS I RANDOM
1053 1111 CLAB
1054 6134 DCA SEND
1055 7300 TAD K0200
1056 1053 CLEN
1057 7040 CLA CLL
1060 6133 TAD SEND
1061 7300 CMA
1062 1111 CLAB
1063 6134 CLA CLL
1064 6137 TAD K0200
1065 3052 CLEN
1066 1052 CLCA
1067 7040 DCA RXED
1070 7650 TAD RXED
1071 4427 CMA SNA CLA
1072 4425 JMS I NERROR
1073 5676 JMS I ERROR
1074 7402 TST27M
1075 7610 HLT
1076 1043 SKP CLA
TST27
/CLEAR AC
/STOP CLOCK
/SET AC 05=1
/GENERATE "CLR CNT"
/CLEAR CLOCK STATUS
/GET RANDOM TEST NUMBER
/LOAD BUFFER WITH A RANDOM NUMBER
/SAVE IT
/SET AC 04=1
/LOAD COUNTER FROM THE BUFFER REGISTER; GENERATE "LOAD CNT"
/CLEAR AC
/GET TEST NUMBER
/COMPLEMENT
/LOAD BUFFER WITH THE COMPLEMENT OF THE PREVIOUS NUMBER
/CLEAR AC
/SET AC 04=1
/LOAD COUNTER (OR) IN COMPLEMENT OF THE FIRST NUMBER
/READ COUNTER,
/SAVE IT
/RESTORE IT
/CONVERT TO ALL ZEROS FOR TESTING
/ZERO?
/CHECK MONITOR
/THE (LOAD CNT) SIGNAL FAILED TO "OR" DATA INTO COUNTER
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISE LOOP; SCOPE LOOP

```

```

1077 7300 /TEST LOAD CNT GENERATION GATES (CLR CLOCK RATE) MODE 2 (0)
1100 6133 /TST28,
1101 6132 CLA CLL
1102 1107 CLAB
1103 6132 CLLR
1104 6135 TAD K0100
1105 4444 CLLSA
1106 6133 JMS I RANDOM
1107 3053 CLAB SEND
1110 6132 DCA K0100
1111 1107 CLLR
1112 6132 TAD K0200
1113 7200 CLLSA
1114 6132 CLLR
1115 1111 TAD
1116 6134 CLEN
1117 6137 CLCA
1120 3052 DCA
1121 1052 TAD
1122 7650 SNA CLA
1123 4427 JMS I NERROR
1124 4425 JMS I ERROR
1125 5722 TST28M
1126 7402 HLT
1127 7610 SKP CLA
1130 1077 TST28

1107 7300 /CLEAR AC
1100 6133 /CLEAR BUFFER
1101 6132 /CLEAR ALL MODES
1102 1107 /SET AC 05=1
1103 6132 /GEN. "CLR CNT"
1104 6135 /CLEAR STATUS
1105 4444 /GET RANDOM NUMBER
1106 6133 /SEND IT TO BUFFER
1107 3053 /SAVE IT
1110 6132 /STOP CLOCK, SET ALL MODES=0
1111 1107 /SET AC 05=1
1112 6132 /GENERATE "CLR CNT"
1113 7200 /CLEAR AC
1114 6132 /SET ALL MODES=0
1115 1111 /SET AC 04=1
1116 6134 /TRY TO GENERATE "LOAD CNT"
1117 6137 /GET COUNTER
1120 3052 /SAVE IT
1121 1052 /RESTORE IT
1122 7650 /WAS IT ZERO?
1123 4427 /CHECK MONITOR
1124 4425 /LOAD CNT GATES FUNCTIONED WITH MODE 2=0 IN ERROR
1125 5722 /MESSAGE POINTER
1126 7402 /ERROR HALT
1127 7610 /TO NEXT TEST
1130 1077 /IS2 LOOP; SCOPE LOOP

```

```

/TEST LOAD CNT GENERATION GATES (CLR CLOCK RATE) MODE 1(1)
/
TST29, JMS I RANDOM
1131 4444 CLAB
1132 6133 DCA SEND
1133 3053 TAD K0600
1134 1117 CLLR
1135 6132 CLSA
1136 6135 CLA
1137 7200 TAD K0200
1140 1111 CLEN
1141 6134 CLCA
1142 6137 DCA
1143 3052 TAD SNA CLA
1144 1052 JMS I NERROR
1145 7650 JMS I ERROR
1146 4427 TST29M
1147 4425 HLT
1150 5747 SKP CLA
1151 7402 TST29
1152 7610 CLA CLL CMA
1153 1131 DCA REGA
1154 7340
1155 3045

/GET RANDOM NUMBER
/SEND IT TO BUFFER
/SAVE IT
/SET AC 04,05#1
/GENERATE "CLR CNT", SET MODE 1 AND 2 #1
/CLEAR CLOCK STATUS
/CLEAR AC
/SET AC 04#1
/TRY TO GENERATE "LOAD CNT"
/READ COUNTER
/SAVE TEST VALUE
/RESTORE IT
/ZERO?
/CHECK MONITOR
/LOAD CNT GATES FUNCTIONED WITH MODE 1#1 IN ERROR
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/IS2 LOOP SCOPE LOOP
/SET AC#7777
/PRESET REGA FOR NEXT TEST

```

/GLITCH TEST OF LOAD CNT GATES

1156	4444	TST30,	JMS I	RANDOM	/GET RANDOM NUMBER
1157	6133	CLAB			/SEND IT TO BUFFER
1160	3053	DCA	SEND		/SAVE IT
1161	1111	TAD	K0200		/SET AC 04#1
1162	6132	CLLR			/SET MODE 1#1
1163	7200	CLA			/CLEAR AC
1164	1113	TAD	K0300		/SET AC 04,05#1
1165	6132	CLLR			/SET MODE 2#1
1166	7200	CLA			/CLEAR AC
1167	2046	ISE	REGB		/DONE?
1170	5361	JMP	.#7		/BACK 4096 TIMES
1171	6137	CLCA			/READ COUNTER
1172	3052	DCA	RXED		/SAVE IT
1173	1052	TAD	RXED		/RESTORE IT
1174	7650	SNA CLA			/ZERO?
1175	4427	JMS I	NERROR		/CHECK MONITOR
1176	4425	JMS I	ERROR		/THE MODE REGISTER CAUSES ILLEGAL LOAD COUNTER
1177	5774	TST30M			/MESSAGE POINTER
1200	7402	HLT			/ERROR HALT
1201	7200	CLA			/TO NEXT TEST
1202	1156	TST30			/IS2 LOOP/ SCOPE LOOP
1203	7340	CLA CLL	CMA		/SET AC=7777
1204	3045	DCA	REGA		/PRESET REGA FOR NEXT TEST

```

/GENERAL GATE SHAKING TEST OF THE MODE FLIP FLOPS
/
TST31,      JMS I  RANDOM
             CLAB
             DCA      SEND
             TAD      REGB
1205 4444
1206 6133
1207 3053
1210 1046
1211 7006
1212 7006
1213 7006
1214 0120
1215 6132
1216 7040
1217 0120
1220 6132
1221 2046
1222 5210
1223 6136
1224 3052
1225 1052
1226 7041
1227 1053
1230 7640
1231 5237
1232 6137
1233 3046
1234 1046
1235 7650
1236 4427
1237 4425
1240 6021
1241 7402
1242 7200
1243 1205
1244 3046

             RTL
             RTL
             AND
             CLLR
             CMA
             AND
             CLLR
             ISZ
             JMP
             CLBA
             DCA
             TAD
             CIA
             TAD
             SZA CLA
             JMP
             CLCA
             DCA
             TAD
             SNA CLA
             JMS I  NERROR
             JMS I  ERROR
             TST31M
             HLT
             CLA
             TST31
             DCA

             K0700
             K0700
             REGB
             TST31+3
             RXED
             RXED
             SEND
             +6
             REGB
             REGB
             NERROR
             ERROR
             HLT
             CLA
             TST31
             DCA

             /GET RANDOM NUMBER
             /SEND IT TO BUFFER
             /SAVE IT
             /GET TEST COUNTER
             /ROTATE TWO LEFT
             /ROTATE TWO LEFT
             /ROTATE TWO LEFT
             /INSURE THAT MODE 0,1,2=1
             /SEND RANDOM NUMBER TO CONTROL REGISTER
             /COMPLEMENT
             /INSURE THAT MODE 0,1,2=1
             /SET TO COMPLEMENT OF THE NUMBER
             /DONE?
             /BACK 4096 TIMES
             /GET TEST VALUE FROM BUFFER
             /SAVE IT
             /RESTORE IT
             /COMPLEMENT
             /SUBTRACT TEST NUMBER
             /EQUAL?
             /BUFF CHANGED IN ERROR
             /READ COUNTER
             /SAVE IT
             /RESTORE IT
             /STILL ZERO?
             /CHECK MONITOR
             /COUNTER CHANGED IN ERROR
             /MESSAGE POINTER
             /ERROR HALT
             /TO NEXT TEST
             /ISZ LOOPJ SCOPE LOOP
             /CLEAR FOR NEXT ISZ LOOP

```

/DOES MODE 2 1-0 CLK CNT?

1245 4444
1246 6133
1247 3053
1250 6132
1251 1107
1252 6132
1253 6135
1254 7200
1255 1111
1256 6134
1257 7200
1260 6132
1261 6137
1262 3052
1263 6133
1264 1052
1265 7041
1266 1053
1267 7650
1270 4427
1271 4425
1272 6056
1273 7422
1274 7410
1275 1245

TST32, JMS I RANDOM
CLAB SEND
DCA K0100
CLLR
TAD K0200
CLLR
CLSA
CLA
TAD
CLEN
CLA
CLLR
CLCA
DCA
CLAB
TAD
CIA
TAD
SNA CLA
JMS I NERROR
JMS I ERROR
TST32M
HLT
SKP
TST32

/GET RANDOM NUMBER
/SEND IT TO BUFFER
/SAVE IT
/ZERO MODE 2
/AC 05=1
/GENERATE "CLR CNT"
/CLEAR STATUS
/CLEAR AC
/SET AC 04=1
/GENERATE "LOAD CNT"
/CLEAR AC
/0 MODE 2
/READ COUNTER
/SAVE IT
/CLEAR BUF OR OVERFLOW WILL RELOAD CNT
/RESTORE IT
/COMPLEMENT
/SUBTRACT TEST NUMBER
/EQUAL?
/CHECK MONITOR
/MODE 2 1-0 DID IT
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/IS2 LOOP1 SCOPE LOOP

/DOES MODE 2 0-1 CLOCK CNT?

1276 1107
1277 6132
1300 6137
1301 3052
1302 1052
1303 7650
1304 4427
1305 4425
1306 6102
1307 7402
1310 7410
1311 1276
1312 7340
1313 3045
1314 5715
1315 1542

TST33, TAD K0100
CLLR
CLCA
DCA
CLLR
TAD
SNA CLA
JMS I NERROR
JMS I ERROR
TST33M
HLT
SKP
TST33
CLA CLL CMA
DCA REGA
JMP I .+1
TST43

/SET AC 05=1
/GENERATE "CLR CNT"
/READ COUNTER
/SAVE IT
/RESTORE IT
/ZERO?
/CHECK MONITOR
/MODE 2 0-1 FAILED
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/IS2 LOOP1 SCOPE LOOP
/SET AC=777
/PRESET IS2 COUNT
/NEXT TEST

```

/DOES COUNTER OVERFLOW SET OVERFLOW FLOW?
/
TST34, CLA CLL /CLEAR AC
1316 7300 CLLR /CLEAR STATUS
1317 6132 TAD K0100 /SET AC 05=1
1320 1107 CLLR /O TO COUNTER
1321 6132 CLSA /CLEAR CLOCK STATUS
1322 6135 CLA CLL CMA /SET AC=7777
1323 7340 CLAB /SET BUFFER TO 7777
1324 6133 CLA CLL /CLEAR AC
1325 7300 TAD /SET AC 04=1
1326 1111 CLEN /LOAD CNT (00)=1
1327 6134 CLEAR /GENERATE I-O PRESET
1330 4157 CLSA /GET STATUS OF CLOCK
1331 6135 SPA CLA /OVERFLOW SET?
1332 7710 JMS I NERROR /CHECK MONITOR
1333 4427 JMS I ERROR /OVERFLOW NOT SET
1334 4425 TST34M /MESSAGE POINTER
1335 6126 HLT /ERROR HALT
1336 7402 / OR ECO EM12=55 IS NOT WORKING PROPERLY
1337 7410 SKP /TO NEXT TEST
1340 1316 TST34 /IS2 LOOP/ SCOPE LOOP
1341 7340 CLA CLL CMA /SET AC=7777
1342 3046 DCA REGB /PRESET IS2 COUNTER FOR NEXT TEST
1343 3045 DCA REGA /RESET REGA

```

```

/DOES CLSA (6135) CLEAR OVERFLOW FLOP?
/
TST35, CLA CLL
CLLR
TAD K0100
CLLR
CLSA
CLA CLL CMA
CLAB
CLA CLL
TAD K0200
CLEN
CLEAR
CLSA
CLA CLL
CLSA CLA
SMA CLA
JMS I NERROR
JMS I ERROR
TST35M
HLT
SKP
TST35
CLA CLL CMA
DCA
1344 7300
1345 6132
1346 1107
1347 6132
1350 6135
1351 7340
1352 6133
1353 7300
1354 1111
1355 6134
1356 4157
1357 6135
1360 7300
1361 6135
1362 7700
1363 4427
1364 4425
1365 6152
1366 7402
1367 7410
1370 1344
1371 7340
1372 3045

/CLEAR AC
/CLEAR ALL MODES
/SET AC 05#1
/GEN "CLR CNT"
/CLEAR CLOCK STATUS
/SET AC=7777
/SET BUF=7777 OCTAL
/CLEAR AC
/SET AC 04#1
/GEN LOAD CNT
/GENERATE I=0 PRESET
/GET STATUS BIT 0#1

/GET STATUS BIT 0#0
/OVERFLOW SET?
/CHECK MONITOR
/CLSA FAILED TO CLEAR OVERFLOW FLOP
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP1 SCOPE LOOP
/SET AC=7777
/PRESET REGA FOR NEXT TEST

```

```

1373 7300
1374 6132
1375 1107
1376 6132
1377 6135
1400 7340
1401 6133
1402 7300
1403 1111
1404 6134
1405 4197
1406 6131
1407 4427
1410 4425
1411 6177
1412 7402
1413 7410
1414 1373
1415 7340
1416 3045

/TEST OVERFLOW SKIP
/
TST36, CLA CLL
      CLR
      TAD K0100
      CLR
      CLSA
      CLA CLL CMA
      CLAB
      CLA CLL K0200
      TAD
      CLEN
      CLEAR
      CLSK
      JMS I NERROR
      JMS I ERROR
      TST36M
      HLT
      SKP
      TST36
      CLA CLL CMA
      DCA

/TEST FOR NO INTERRUPT
/
TST37, TAD PNTA
      DCA RETURN
      ION
      NOP
      IOF
      JMS I NERROR
      JMS I ERROR
      TST37M
      HLT
      SKP
      TST37
      CLA CLL CMA
      DCA

1417 1032
1420 3051
1421 6001
1422 7000
1423 6002
1424 4427
1425 4425
1426 6217
1427 7402
1430 7410
1431 1417
1432 7340
1433 3045

/CLEAR AC
/CLEAR ALL MODES
/SET AC 05=1
/GEN "CLR CNT"
/CLEAR CLOCK STATUS
/SET AC=7777
/SET BUF=7777 OCTAL
/CLEAR AC
/SET AC 04=1
/GEN LOAD CNT
/GENERATE I-O PRESET
/OVERFLOW SET?
/CHECK MONITOR
/CLOCK PRESET DIDN'T 0 OVERFLOW ENABLE
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISE LOOP/ SCOPE LOOP
/SET AC=7777
/RESET REGA FOR NEXT TEST

/GET RETURN POINTER TO LOCA
/PUT IT IN INTERRUPT HANDLER
/ENABLE INTERRUPTS
/WAIT
/DISABLE INTERRUPTS
/CHECK MONITOR
/ILLEGAL INTERRUPT OVERFLOW=1 OVERFLOW ENABLE=0
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISE LOOP/ SCOPE LOOP
/SET AC=7777
/PRESET REGA FOR NEXT TEST

```

```

1434 1107 /SET INT ENABLE
1435 6134 /
1436 7300 TST38, TAD K0100
1437 6131 CLEN
1440 7410 CLA CLL
1441 4427 CLSK
1442 4425 SKP
1443 6240 JMS I NERROR
1444 7402 JMS I ERROR
1445 7410 TST38M
1446 1434 HLT
1447 7340 SKP
1450 3045 TST38
        CLA CLL CMA
        DCA REGA
        /PRESET REGA FOR NEXT TEST

/TEST FOR CLOCK INTERRUPT
/
TST39, TAD PNTB
        DCA RETURN
        ION
        NOP
        IOF
        SKP
        JMS I NERROR
        JMS I ERROR
        TST39M
        HLT
        SKP
        TST39
        CLA CLL CMA
        DCA REGA
        /PRESET REGA FOR NEXT TEST

1451 1033 /GET RETURN POINTER TO LOCB
1452 3051 /PUT IT IN INTERRUPT HANDLER
1453 6001 /ENABLE INTERRUPTS
1454 7000 /WAIT
1455 6002 /DISABLE INTERRUPTS
1456 7410 /TO HERE IF NO INTERRUPT
1457 4427 /CHECK WITH MONITOR
1460 4425 /CLOCK INT FAILED TO INTERRUPT
1461 6257 /MESSAGE POINTER
1462 7402 /ERROR HALT
1463 7410 /TO NEXT TEST
1464 1451 /IS2 LOOP1 SCOPE LOOP
1465 7340 /SET AC=7777
1466 3045 /PRESET REGA FOR NEXT TEST

```

```

1467 7300 /TEST WITH FLAG UP ZERO OVERFLOW INT ENABLE
1470 6134 /
1471 6131 /CLEAR AC
1472 4427 /O CLOCK ENABLE
1473 4425 /INTERRUPT AVAILABLE?
1474 6277 /CHECK MONITOR
1475 7402 /OVERFLOW ENABLE WON'T ZERO
1476 7410 /MESSAGE POINTER
1477 1467 /ERROR HALT
1500 7340 /TO NEXT TEST
1501 3045 /IS2 LOOP1 SCOPE LOOP
/SET AC=7777
/PRESET REGA FOR NEXT TEST

/TEST WITH FLAG ZERO OVERFLOW SET
/
TST41, TAD K0100
CLEN /SET AC 05=1
CLA CLL /ENABLE INTERRUPTS
CLLR /CLEAR AC
CLSA /STOP THE CLOCK
CLSK /READ AND ZERO FLAG
JMS I NERROR /CLEAR AC
JMS I ERROR /INTERRUPT SET?
TST41M /CHECK MONITOR
HLT /BAD INTERRUPT CONDITION STILL EXISTS
SKP /MESSAGE POINTER
TST41 /ERROR HALT
CLA CLL CMA /TO NEXT TEST
DCA REGA /IS2 LOOP1 SCOPE LOOP
/SET AC=7777
/PRESET REGA FOR NEXT TEST

/TEST INT OVERFLOW=0
/
TST42, TAD PNTC
DCA RETURN
ION /ENABLE INTERRUPTS
NOP /WAIT
IOF /DISABLE INTERRUPTS
JMS I NERROR /CHECK MONITOR
JMS I ERROR /ILLEGAL CLOCK INTERRUPT
TST42M /MESSAGE POINTER
HLT /ERROR HALT
SKP /TO NEXT TEST
TST42 /IS2 LOOP1 SCOPE LOOP
ISZ REGB /INCREMENT PASS COUNTER
JMP I TST35N /CROSS-PAGE TO TEST 35 4096 TIMES
CLA CLL CMA /SET AC=7777
DCA REGA /PRESET REGA FOR NEXT TEST
JMP I .+1 /NEXT TEST
TST55

```

```

1542 7200
1543 6132
1544 6133
1545 1107
1546 6132
1547 6135
1550 7200
1551 3024
1552 3053
1553 6133
1554 1111
1555 6134
1556 7300
1557 1132
1560 6132
1561 6137
1562 3052
1563 1052
1564 1137
1565 7650
1566 5465
1567 2024
1570 5422
1571 7410
1572 4427
1573 4425
1574 6360
1575 7402
1576 7410
1577 1542
1600 7340
1601 3045

/COUNTER CARRY TESTING
/COUNTER PRESET SUCH THAT CLOCK CNT RAISES BIT IN QUESTION
/DOES BIT 11 SET UP?
TST43, CLA
CLLR
CLAB
TAD K0100
CLLR
CLSA
CLA
DCA
DCA
DCA
CLAB
TAD
CLEN
CLA CLL
TAD K5100
CLLR
CLCA
DCA
TAD
SNA CLA
JMP I
ISZ CNTR
JMP I DN43
SKP I
JMS I NERROR
JMS I ERROR
TST43M
HLT
SKP
TST43
CLA CLL CMA
DCA REGA

BK43,
RXED
RXED
M0001
TAD
SNA CLA
JMP I
ISZ CNTR
JMP I DN43
SKP I
JMS I NERROR
JMS I ERROR
TST43M
HLT
SKP
TST43
CLA CLL CMA
DCA REGA

FD43,
RXED
RXED
M0001
TAD
SNA CLA
JMP I
ISZ CNTR
JMP I DN43
SKP I
JMS I NERROR
JMS I ERROR
TST43M
HLT
SKP
TST43
CLA CLL CMA
DCA REGA

/CLEAR AC
/CLEAR ALL MODES
/CLEAR BUF
/SET AC 05=1
/GEN "CLR CNT"
/CLEAR STATUS
/CLEAR AC
/CLEAR COUNTER
/CLEAR SEND
/CLEAR BUFFER
/MODE 1
/ENABLE MODE
/CLEAR AC
/SELECT 100 HZ RATE TO BE USED IN TST 43 TO TST 54
/ENABLE RATE
/READ COUNTER
/SAVE IT
/FETCH IT
/BIT 11 AND ONLY BIT 11 SET?
/IF NOT, WAIT A WHILE
/SET, GO CHECK MONITOR (I+4)
/TIMER DONE?
/NO, GO BACK (I=7)
/TO HERE IF BAD BIT
/CHECK MONITOR
/BIT 11 FAILED TO GET SET BY A CLOCK PULSE
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP, SCOPE LOOP
/SET AC=7777
/PRESET REGA FOR NEXT TEST

```

/DOES BIT 10 SET UP?

1602	7200	CLA	CNTR
1603	6132	CLLR	K0001
1604	6133	CLAB	SEND
1605	6132	CLLR	K0200
1606	6135	CLSA	
1607	7200	CLA	
1610	3024	DCA	
1611	1072	TAD	
1612	6133	CLAB	
1613	3053	DCA	
1614	1111	TAD	
1615	6134	CLEN	
1616	7300	CLA CLL	K5100
1617	1132	TAD	
1620	6132	CLLR	
1621	6137	CLCA	
1622	3052	DCA	
1623	1052	TAD	
1624	1140	TAD	
1625	7650	SNA CLA	
1626	5232	JMP	.4
1627	2024	ISZ	CNTR
1630	5221	JMP	.7
1631	7410	SKP	
1632	4427	JMS I	NERROR
1633	4425	JMS I	ERROR
1634	6377	TST44M	
1635	7402	HLT	
1636	7410	SKP	
1637	1602	TST44	
1640	7340	CLA CLL	CMA
1641	3045	DCA	REGA

/PRESET FOR BIT 10

/BIT 10, AND ONLY BIT 10, SET?

/CHECK MONITOR
 /BIT 10 FAILED TO GET SET BY COUNTING
 /MESSAGE POINTER
 /ERROR HALT
 /TO NEXT TEST
 /ISZ LOOP/ SCOPE LOOP
 /SET AC=7777
 /PRESET REGA FOR NEXT TEST

/DOES BIT 9 SET UP?

1642	7200	CLA	
1643	6132	CLLR	
1644	6133	CLAB	
1645	1107	TAD	K0100
1646	6132	CLLR	
1647	6135	CLSA	
1650	7200	CLA	
1651	3024	DCA	CNTR
1652	1074	TAD	K0003
1653	6133	CLAB	
1654	3053	DCA	SEND
1655	1111	TAD	K0200
1656	6134	CLEN	
1657	7300	CLA CLL	
1660	1132	TAD	K5100
1661	6132	CLLR	
1662	6137	CLCA	
1663	3052	DCA	RXED
1664	1052	TAD	RXED
1665	1141	TAD	M0004
1666	7650	SNA CLA	
1667	5273	JMP	.+4
1670	2024	ISE	CNTR
1671	5262	JMP	.-7
1672	7410	SKP	
1673	4427	JMS I	NERROR
1674	4425	JMS I	ERROR
1675	6416	TST45M	
1676	7402	HLT	
1677	7410	SKP	
1700	1642	TST45	
1701	7340	CLA CLL	CMA
1702	3045	DCA	REGA

/PRESET FOR BIT 09

/BIT 09, AND ONLY BIT 09, SET?

/CHECK MONITOR
 /BIT 9 FAILED TO GET SET BY COUNTING
 /MESSAGE POINTER
 /ERROR HALT
 /TO NEXT TEST
 /ISE LOOP SCOPE LOOP
 /SET AC=7777
 /PRESET REGA FOR NEXT TEST

/DOES BIT 8 SET UP?

```

1703 7200 CLA
1704 6132 CLLR
1705 6133 CLAB
1706 1107 TAD K0100
1707 6132 CLLR
1710 6135 CLSA
1711 7200 CLA
1712 3024 DCA CNTR
1713 1076 TAD K0007
1714 6133 CLAB
1715 3053 DCA SEND
1716 1111 TAD K0200
1717 6134 CLEN
1720 7300 CLA CLL
1721 1132 TAD K5100
1722 6132 CLLR
1723 6137 CLCA
1724 3052 DCA RXED
1725 1052 TAD RXED
1726 1142 TAD M0010
1727 7650 SNA CLA
1730 5334 JMP
1731 2024 ISZ
1732 5323 JMP
1733 7410 SKP
1734 4427 JMS I NERROR
1735 4425 JMS I ERROR
1736 6435 TST46M
1737 7422 HLT
1740 7410 SKP
1741 1703 TST46
1742 7340 CLA CLL CMA
1743 3045 DCA REGA

```

/PRESET FOR BIT 08

/BIT 08, AND ONLY BIT 08, SET?

```

/CHECK MONITOR
/BIT 8 FAILED TO GET SET BY COUNTING
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP/ SCOPE LOOP
/SET AC=7777
/PRESET REGA FOR NEXT TEST

```

```

/DOES BIT 7 SET UP?
/
TST47,
1744 7200      CLA
1745 6132      CLLR
1746 6133      CLAB
1747 1107      TAD      K0100
1750 6132      CLLR
1751 6135      CLSA
1752 7200      CLA
1753 3024      DCA      CNTR
1754 1101      TAD      K0017
1755 6133      CLAB
1756 3053      DCA      SEND
1757 1111      TAD      K0200
1760 6134      CLEN
1761 7300      CLA CLL      K5100
1762 1132      TAD
1763 6132      CLLR
1764 6137      CLCA
1765 3052      DCA      RXED
1766 1052      TAD      RXED
1767 1143      TAD      M0020
1770 7650      SNA CLA
1771 5375      JMP      .+4
1772 2024      ISZ      CNTR
1773 5364      JMP      .+7
1774 7410      SKP
1775 4427      JMS I      NERROR
1776 4425      JMS I      ERROR
1777 6454      TST47M
2000 7402      HLT
2001 7410      SKP
2002 1744      TST47
2003 7340      CLA CLL      CMA
2004 3045      DCA      REGA

BK47,

/BIT 07, AND ONLY BIT 07, SET?

/CHECK MONITOR
/BIT 7 FAILED TO GET SET BY COUNTING
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP1 SCOPE LOOP
/SET AC=7777
/PRESET REGA FOR NEXT TEST
    
```

```

2005 7200
2006 6132
2007 6133
2010 1107
2011 6132
2012 6135
2013 7200
2014 3024
2015 1103
2016 6133
2017 3053
2020 1111
2021 6134
2022 7300
2023 1132
2024 6132
2025 6137
2026 3052
2027 1052
2030 1144
2031 7650
2032 5236
2033 2024
2034 5225
2035 7410
2036 4427
2037 4425
2040 6473
2041 7402
2042 7410
2043 2005
2044 7340
2045 3045

/DOES BIT 6 SET UP?
/
TST48:
CLA
CLLR
CLAB
TAD K0100
CLLR
CLSA
CLA
DCA CNTR
TAD K0037
CLAB SEND
DCA K0200
TAD
CLEN
CLA CLL K5100
TAD
CLLR
CLCA
DCA
TAD
TAD M0040
SNA CLA
JMP
ISZ CNTR
JMP
SKP
JMS I NERROR
JMS I ERROR
TST48M
HLT
SKP
TST48
CLA CLL CMA
DCA REGA

```

/PRESET FOR BIT 06

/BIT 06, AND ONLY BIT 06, SET?

```

/CHECK MONITOR
/BIT 6 FAILED TO GET SET BY COUNTING
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP/ SCOPE LOOP
/SET AC=7777
/PRESET REGA FOR NEXT TEST

```

```

2046 7200
2047 6132
2050 6133
2051 1107
2052 6132
2053 6135
2054 7200
2055 3024
2056 1106
2057 6133
2060 3053
2061 1111
2062 6134
2063 7300
2064 1132
2065 6132
2066 6137
2067 3052
2070 1052
2071 1146
2072 7650
2073 5277
2074 2024
2075 5266
2076 7410
2077 4427
2100 4425
2101 6512
2102 7402
2103 7410
2104 2046
2105 7340
2106 3045

/DOES BIT 5 SET UP?
/
TST49,
CLA
CLLR
CLAB
TAD K0100
CLLR
CLSA
CLA
DCA CNTR
TAD K0077
CLAB
DCA SEND
TAD K0200
CLEN
CLA CLL K5100
TAD
CLLR
CLCA
DCA RXED
TAD RXED
TAD M0100
SNA CLA
JMP .+4
ISZ CNTR
JMP .+7
SKP
JMS I NERROR
JMS I ERROR
TST49M
HLT
SKP
TST49
CLA CLL CMA
DCA REGA

```

/PRESET FOR BIT 05

/BIT 05, AND ONLY BIT 05, SET?

/CHECK MONITOR
 /BIT 5 FAILED TO GET SET BY COUNTING
 /MESSAGE POINTER
 /ERROR HALT
 /TO NEXT TEST
 /IS2 LOOP/ SCOPE LOOP
 /SET AC=7777
 /PRESET REGA FOR NEXT TEST

```

/DOES BIT 4 SET UP?
/
TST50,
2107 7200 CLA
2110 6132 CLLR
2111 6133 CLAB
2112 1107 TAD
2113 6132 CLLR
2114 6135 CLSA
2115 7200 CLA
2116 3024 DCA
2117 1110 TAD
2120 6133 CLAB
2121 3053 DCA
2122 1111 TAD
2123 6134 CLEN
2124 7300 CLA CLL
2125 1132 TAD
2126 6132 CLLR
2127 6137 CLCA
2130 3052 DCA
2131 1052 RXED
2132 1147 TAD
2133 7650 SNA CLA
2134 5340 JMP
2135 2024 ISZ
2136 5327 JMP
2137 7410 SKP
2140 4427 JMS I
2141 4425 JMS I
2142 6531 TST50M
2143 7402 HLT
2144 7410 SKP
2145 2107 TST50
2146 7340 CLA CLL CMA
2147 3045 DCA REGA

/PRESET FOR BIT 04

/BIT 04, AND ONLY BIT 04, SET?

/CHECK MONITOR
/BIT 4 FAILED TO GET SET BY COUNTING
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/IS2 LOOP/ SCOPE LOOP
/SET AC=7777
/PRESET REGA FOR NEXT TEST

```

```

/DOES BIT 3 SET UP?
/
TST51,
2150 7200 CLA
2151 6132 CLLR
2152 6133 CLAB
2153 1107 TAD K0100
2154 6132 CLLR
2155 6135 CLSA
2156 7200 CLA
2157 3024 DCA CNTR
2160 1114 TAD K0377
2161 6133 CLAB
2162 3053 DCA SEND
2163 1111 TAD K0200
2164 6134 CLEN
2165 7300 CLA CLL K5100
2166 1132 TAD
2167 6132 CLLR
2170 6137 CLCA
2171 3052 DCA RXED
2172 1052 TAD RXED
2173 1150 TAD M0400
2174 7650 SNA CLA
2175 3466 JMP I UP51
2176 2024 ISZ CNTR
2177 5370 JMP .27
2200 7410 SKP
2201 4427 JMS I NERROR
2202 4425 JMS I ERROR
2203 6550 TST51M
2204 7402 HLT
2205 7410 SKP
2206 2150 TST51
2207 7340 CLA CLL CMA
2210 3045 DCA REGA

```

/PRESET FOR BIT 03

/BIT 03, AND ONLY BIT 03, SET?

/(.04)

```

/CHECK MONITOR
/BIT 3 FAILED TO GET SET BY COUNTING
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP, SCOPE LOOP
/SET AC=7777
/PRESET REGA FOR NEXT TEST

```

/DOES BIT 2 SET UP?

```

2211 7200 CLA
2212 6132 CLLR
2213 6133 CLAB
2214 1107 TAD K0100
2215 6132 CLLR
2216 6135 CLSA
2217 7200 CLA
2220 3024 DCA CNTR
2221 1121 TAD K0777
2222 6133 CLAB
2223 3053 DCA SEND
2224 1111 TAD K0200
2225 6134 CLEN
2226 7300 CLA CLL
2227 1132 TAD K5100
2230 6132 CLLR
2231 6137 CLCA
2232 3052 DCA RXED
2233 1052 TAD RXED
2234 1151 TAD M1000
2235 7650 SNA CLA
2236 5242 JMP
2237 2024 ISZ
2240 5231 JMP
2241 7410 SKP
2242 4427 JMS I NERROR
2243 4425 JMS I ERROR
2244 6567 TST52M
2245 7402 HLT
2246 7410 SKP
2247 2211 TST52
2250 7340 CLA CLL CMA
2251 3045 DCA REGA

```

/PRESET FOR BIT 02

/BIT 02, AND ONLY BIT 02, SET?

```

/CHECK MONITOR
/BIT 2 FAILED TO GET SET BY COUNTING
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP/ SCOPE LOOP
/SET AC=7777
/PRESET REGA FOR NEXT TEST

```

```

/DOES BIT 1 SET UP?
/
TST53,
2252 7200 CLA
2253 6132 CLLR
2254 6133 CLAB
2255 1107 TAD K0100
2256 6132 CLLR
2257 6135 CLSA
2260 7200 CLA
2261 3024 DCA CNTR
2262 1124 TAD K1777
2263 6133 CLAB
2264 3053 DCA SEND
2265 1111 TAD K0200
2266 6134 CLEN
2267 7300 CLA CLL
2270 1132 TAD K5100
2271 6132 CLLR
2272 6137 CLCA
2273 3052 DCA RXED
2274 1052 TAD RXED
2275 1153 TAD M2000
2276 7650 SNA CLA
2277 5303 JMP .+4
2300 2024 ISZ CNTR
2301 5272 JMP .+7
2302 7410 SKP
2303 4427 JMS I NERROR
2304 4425 JMS I ERROR
2305 6606 TST53M
2306 7402 HLT
2307 7410 SKP
2310 2252 TST53
2311 7340 CLA CLL CMA
2312 3045 DCA REGA

```

/PRESET FOR BIT 01

/BIT 01, AND ONLY BIT 01, SET?

```

/CHECK MONITOR
/BIT 1 FAILED TO GET SET BY COUNTING
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/IS2 LOOP1 SCOPE LOOP
/SET AC=7777
/PRESET REGA FOR NEXT TEST

```

```

/DOES BIT 0 SET UP?
/
TST54,
2313 7200 CLA
2314 6132 CLLR
2315 6133 CLAB
2316 1107 TAD K0100
2317 6132 CLLR
2320 6135 CLSA
2321 7200 CLA
2322 3024 DCA CNTR
2323 1127 TAD K3777
2324 6133 CLAB
2325 3053 DCA SEND
2326 1111 TAD K0200
2327 6134 CLEN
2330 7300 CLA CLL
2331 1132 TAD K5100
2332 6132 CLLR
2333 6137 CLCA
2334 3052 DCA RXED
2335 1052 TAD RXED
2336 1154 TAD M4000
2337 7650 SNA CLA
2340 5344 JMP .+4
2341 2024 ISZ CNTR
2342 5333 JMP .+7
2343 7410 SKP
2344 4427 JMS I NERROR
2345 4425 JMS I ERROR
2346 6625 TST54M
2347 7402 HLT
2350 7410 SKP
2351 2313 TST54
2352 5753 JMP I .+1
2353 1316 TST34
/PRESET FOR BIT 00
/
/BIT 00, AND ONLY BIT 00, SET?
/
/CHECK MONITOR
/BIT 0 FAILED TO GET SET BY COUNTING
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP) SCOPE LOOP

```



```

2426 7300
2427 1142
2430 3047
2431 1151
2432 3046
2433 1126
2434 6132
2435 7300
2436 2046
2437 7410
2440 2047
2441 7410
2442 9250
2443 6135
2444 7000
2445 7700
2446 5236
2447 4427
2450 4425
2451 6676
2452 7402
2453 7410
2454 2426
2455 7340
2456 3045
2457 3046

/
/CHECK 10 KHZ RATE
/
TST57, CLA CLL M0010
      TAD REGC
      DCA M1000
      TAD REGB
      DCA K3000
      CLLR
      CLA CLL REGB
      ISZ REGC
      SKP REGC
      ISZ REGC
      SKP .+6
      JMP CLSA
      NOP SMA CLA
      JMP .+10
      JMS I NERROR
      JMS I ERROR
      TST57M
      HLT
      SKP
      TST57 CLA CLL CMA
      DCA REGA
      DCA REGB

```

/TEST 1KHZ RATE

```

2460 7300
2461 1146
2462 3047
2463 1131
2464 6132
2465 7300
2466 2046
2467 7410
2470 2047
2471 7410
2472 5300
2473 6135
2474 7000
2475 7700
2476 5266
2477 4427
2500 4425
2501 6713
2502 7402
2503 7410
2504 2460
2505 7340
2506 3045

/
/CHECK 10 KHZ RATE
/
TST58, CLA CLL M0100
      TAD REGC
      DCA K4100
      CLLR
      CLA CLL REGB
      ISZ REGC
      SKP REGC
      ISZ REGC
      SKP REGC
      JMP .+6
      CLSA
      NOP SMA CLA
      JMP .+10
      JMS I NERROR
      JMS I ERROR
      TST58M
      HLT
      SKP
      TST58 CLA CLL CMA
      DCA REGA
      DCA REGB

```

/TEST 1KHZ RATE

```

/CLEAR AC
/GET PRESET
/SET UP FOR X10

/SET 10KC RATE

/INCREMENT COUNT
/TIMER OK
/INCREMENT MULTIPLIER
/MULTIPLIER OK
/TIMER NOT OK
/GET STATUS
/WAIT
/OVERFLOW?
/TRY AGAIN
/CHECK MONITOR
/10KC FAILED
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP1 SCOPE LOOP
/SET AC = 7777
/PRESET REGA
/CLEAR REGB

```

```

/CLEAR AC
/GET PRESET
/SET UP FOR X100
/SET 1KC RATE

/INCREMENT COUNT
/TIMER OK
/INCREMENT MULTIPLIER
/MULTIPLIER OK
/TIMER NOT OK
/GET STATUS
/WAIT
/OVERFLOW?
/TRY AGAIN
/CHECK MONITOR
/1KC FAILED
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP1 SCOPE LOOP
/SET AC = 7777
/PRESET REGA

```


/CHECK CHANNEL 1 INPUT RATE (RATE MUST BE BETWEEN 47 CPS AND 180 KHZ)
/((INSURE THAT AN INPUT IS PROVIDED)

2546	7300				/CLEAR AC
2547	1102	CLA CLL	K0020		/GET AC 05
2550	6134	TAD			/ENABLE CHANNEL 1 INPUT
2551	7200	CLEN			
2552	1135	CLA	K6000		/GET AC 00, 01
2553	6132	TAD			/ENABLE RATE=CHANNEL 1 INPUT
2554	7300	CLLR			/CLEAR AC
2555	6137	CLA CLL			/GET COUNTER
2556	3053	CLCA			/SAVE IT
2557	2046	DCA	SEND		/WAIT
2560	5357	ISZ	REGB		
2561	6137	JMP	=1		
2562	7041	CLCA			/GET COUNTER
2563	1053	CIA			/2'S COMPLEMENT
2564	7640	TAD	SEND		/COMPARE
2565	4427	SZA CLA			/HAS IT CHANGED?
2566	4425	JMS I	NERROR		/CHECK MONITOR
2567	6745	JMS I	ERROR		/CHAN 1 LOCKED UP
2570	7402	TST60M			/MESSAGE POINTER
2571	7410	HLT			/ERROR HALT
2572	2554	SKP			/TO NEXT TEST
		TST60N			/SCOPE LOOP; ISZ LOOP

```

2573 1072
2574 6134
2575 6132
2576 6132
2577 7300
2600 6134
2601 6135
2602 0127
2603 3053
2604 6135
2605 0074
2606 3052
2607 1052
2610 7640
2611 5470
2612 1053
2613 7041
2614 1074
2615 7650
2616 4427
2617 4425
2620 6766
2621 7402
2622 7410
2623 2573

/
/SIMULATED INPUT TESTS CHANNEL 3
/
TST61, TAD K0001
      CLEN
      CLLR
      CLLR
      CLA CLL
      CLEN
      CLSA
      AND
      DCA
      CLSA
      AND
      DCA
      TAD
      SZA CLA
      JMP I
      TAD
      CIA
      TAD
      SNA CLA
      JMS I
      JMS I
      TST61M
      HLT
      SKP
      TST61

      K3777
      SEND
      K0003
      RXED
      RXED
      TAD
      SZA CLA
      JMP I
      TAD
      CIA
      TAD
      SNA CLA
      JMS I
      JMS I
      TST61M
      HLT
      SKP
      TST61

      /SET AC 11=1
      /ENABLE CHANNEL 3
      /SET EVENT FLOP
      /SET SET PRE-EVENT FLOP
      /CLEAR AC
      /CLEAR ENABLES
      /GET STATUS
      /IGNORE OIFLO
      /SAVE IT
      /GET STATUS AGAIN
      /SAVE CHANNEL 3
      /SAVE IT
      /FETCH IT
      /CHANNEL 3 0?
      /CLSA DOESN'T 0 INPUT CHANNEL 3 (.+6)
      /GET STATUS
      /2'S COMPLEMENT
      /SUBTRACT SET
      /EQUAL?
      /CHECK MONITOR
      /BOTH PRE-EVENT AND EVENT NOT SET
      /MESSAGE POINTER
      /ERROR HALT
      /TO NEXT TEST
      /ISZ LOOP; SCOPE LOOP

```

```

/
/SIM INPUT TESTS CHAN 2
TST62, TAD K0004
        CLEN
        CLLR
        CLLR
        CLA CLL
        CLEN
        CLSA
        AND
        DCA
        CLSA
        AND
        DCA
        TAD
        SZA CLA
        JMP
        TAD
        CIA
        TAD
        SNA CLA
        JMS I
        JMS I
        TST62M
        HLT
        SKP
        TST62

2624 1075
2625 6134
2626 6132
2627 6132
2628 7300
2629 6134
2630 6135
2631 0127
2632 3053
2633 6135
2634 0100
2635 3052
2636 1052
2637 7640
2638 5250
2639 1053
2640 7041
2641 1100
2642 7650
2643 4427
2644 4425
2645 7010
2646 7402
2647 7410
2648 2624

        /SET AC 09#1
        /ENABLE CHAN 2
        /SET EVENT FLOP
        /SET PREVENT FLOP
        /CLEAR AC
        /CLEAR ENABLES
        /GET STATUS
        /IGNORE 01FLO
        /SAVE IT
        /GET STATUS
        /SAVE CHANNEL 2
        /SAVE IT
        /FETCH IT
        /0?
        /CLSA DOESN'T 0 INPUT CHANNEL 2
        /GET FIRST STATUS
        /2'S COMPLEMENT
        /SUBTRACT SET
        /EQUAL?
        /CHECK MONITOR
        /BOTH PRE-EVENT AND EVENT NOT SET
        /MESSAGE POINTER
        /ERROR HALT
        /TO NEXT TEST
        /ISZ LOOP; SCOPE LOOP

```

```

/
/SIM INPUT TESTS CHAN 1
/
TST63, TAD K0020
1102 2655
6134 2656
6132 2657
6132 2660
7300 2661
6134 2662
6135 2663
0127 2664
3053 2665
6135 2666
0105 2667
3052 2670
1052 2671
7640 2672
5301 2673
1053 2674
7041 2675
1105 2676
7650 2677
4427 2700
4425 2701
7032 2702
7402 2703
7410 2704
2655 2705
7340 2706
3045 2707

CLEN
CLLR
CLLR
CLA CLL
CLEN
CLSA
AND
DCA
CLSA
AND
DCA
TAD
SEA CLA
JMP
TAD
CIA
TAD
SNA CLA
JMS I
JMS I
TST63M
HLT
SKP
TST63
CLA CLL CMA
DCA REGA

K3777
SEND
K0060
RXED
RXED
+6
SEND
K0060
NERROR
ERROR

/SET AC 07=1
/SET ENABLE
/SET EVENT FLOP
/SET PREVENT FLOP
/CLEAR AC
/CLEAR ENABLES
/GET STATUS
/IGNORE 01FLO
/SAVE IT
/GET STATUS
/SAVE CHANNEL 1
/SAVE IT
/FETCH IT
/ZERO?
/CLSA DOESN'T 0 INPUT CHANNEL 1
/GET FIRST STATUS
/2'S COMPLEMENT
/SUBTRACT SET
/EQUAL?
/CHECK MONITOR
/BOTH PRE-EVENT AND EVENT NOT SET
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/IS2 LOOP1 SCOPE LOOP
/SET AC=7777
/PRESET REGA

```

```

1035
2710
2711
2712
2713
2714
2715
2716
2717
2720
2721
2722
2723
2724
2725
2726
2727

1102
2730
2731
2732
2733
2734
2735
2736
2737
2740
2741
2742
2743
2744
2745
2746
2747
2750
2751
2752

/TEST INPUT CHANNEL INTERRUPT CHAN 1
/
TST64, TAD PNTD /GET RETURN POINTER TO LOCD
DCA RETURN /SET UP INTERRUPT RETURN
TAD K0060 /ENABLE INPUT AND INTERRUPT
CLEN /ENABLE
CLLR /SIMULATE INPUT CHANNEL ONE
ION /ENABLE INTERRUPTS
NOP /WAIT
SKP /NO INTERRUPT
JMS I NERROR /CHECK MONITOR
JMS I ERROR /NO INTERRUPT ERROR
TST64M /MESSAGE POINTER
HLT /ERROR HALT
SKP CLA /TO NEXT TEST
TST64 /ISE LOOP
CLA CLL CMA /SET AC=7777
DCA REGA /PRESET REGA

/TEST WITH INTERRUPTS DISABLED
/
TST65, TAD K0020
CLEN
CLA CLL
TAD PNTD
DCA RETURN
ION
NOP
IOF
CLSA
JMS I NERROR
JMS I ERROR
TST65M
HLT
SKP CLA
TST65
CLA CLL CMA
DCA REGA
ISE REGB
JMP TST64

/LOC,
/LOC,
/LOC,

/TEST WITH INTERRUPTS DISABLED
/
TST65, TAD K0020
/ENABLE
/CLEAR AC
/GET RETURN POINTER TO LOCD
/PUT IT IN INTERRUPT HANDLER
/ENABLE INTERRUPTS
/WAIT
/DISABLE INTERRUPTS
/CLEAR CLOCK STATUS
/CHECK MONITOR
/INTERRUPT IN ERROR
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISE LOOPJ SCOPE LOOP
/SET AC=7777
/PRESET REGA
/DO THE PAIR OF TESTS 4096 TIMES
/BACK

```

```

/TEST INPUT CHANNEL INTERRUPT CHAN 2
/
TST66,      TAD      PNTF      /GET RETURN POINTER TO LOCF
            DCA      RETURN    /SET UP INTERRUPT RETURN
            TAD      K0014     /SET AC 08, 09=1
            CLEN      /ENABLE CHANNEL 2
            CLLR      /ENABLE RATES
            ION       /ENABLE INTERRUPTS
            NOP       /WAIT
            SKP       /TO HERE IF NO INTERRUPT
            JMS I     NERROR    /CHECK MONITOR
            JMS I     ERROR    /NO INTERRUPT
            TST66M     /MESSAGE POINTER
            HLT       /ERROR HALT
            SKP       /TO NEXT TEST
            TST66     /ISZ LOOPJ SCOPE LOOP
            CLA CLL   CMA      /SET AC=7777
            DCA      REGA     /PRESET REGA
/
/TEST WITH INTERRUPTS DISABLED
/
TST67,      TAD      K0004     /SET AC 09=1
            CLEN      /ENABLE CHANNEL 2
            CLA CLL   /CLEAR AC
            TAD      PNTG     /GET RETURN POINTER TO LOCG
            DCA      RETURN   /PUT IT IN INTERRUPT HANDLER
            ION       /ENABLE INTERRUPTS
            NOP       /WAIT
            IOF       /DISABLE INTERRUPTS
            CLSA      /CLEAR CLOCK STATUS
            JMS I     NERROR    /CHECK MONITOR
            JMS I     ERROR    /INTERRUPT IN ERROR--CLEA EN EVENT 2 INT BAD
            TST67M     /MESSAGE POINTER
            HLT       /ERROR HALT
            SKP       /TO NEXT TEST
            TST67     /ISZ LOOPJ SCOPE LOOP
            CLA CLL   CMA      /SET AC=7777
            DCA      REGA     /PRESET REGA
            ISZ      /DO THIS PAIR OF TESTS 4096 TIMES
            JMP I     TST66N   /BACK
/

```

2753 1037
2754 3051
2755 1100
2756 6134
2757 6132
2760 6001
2761 7000
2762 7410
2763 4427
2764 4425
2765 7112
2766 7402
2767 7410
2770 2753
2771 7340
2772 3045

2773 1075
2774 6134
2775 7300
2776 1040
2777 3051
3000 6001
3001 7000
3002 6002
3003 6135
3004 4427
3005 4425
3006 7133
3007 7402
3010 7410
3011 2773
3012 7340
3013 3045
3014 2046
3015 5457

```

3016 1041
3017 3051
3020 1074
3021 6134
3022 6132
3023 6001
3024 7000
3025 6002
3026 7410
3027 4427
3030 4425
3031 7152
3032 7402
3033 7410
3034 3016
3035 7340
3036 3045

/TEST INPUT CHANNEL INTERRUPT CHAN 3
/
TST68; TAD PNTH /GET RETURN POINTER TO LOCH
DCA RETURN /SET UP INTERRUPT RETURN
K0003 /SET AC10,11=1
CLEN /ENABLE CHANNEL 3
CLLR /ENABLE RATES
ION /ENABLE INTERRUPTS
NOP /WAIT
IOF /DISABLE INTERRUPTS
SKP /NO INTERRUPT
JMS I NERROR /CHECK MONITOR
JMS I ERROR /NO INTERRUPT
TST68M /MESSAGE POINTER
HLT /ERROR HALT
SKP /TO NEXT TEST
TST68 /IS2 LOOPJ SCOPE LOOP
CLA CLL CMA /SET AC=7777
DCA REGA /PRESET REGA

/TEST WITH INTERRUPTS DISABLED
/
TST69; AND K0001
CLEN /SET AC 11=1
CLA CLL /ENABLE CHANNEL 3
TAD PNTI /CLEAR AC
DCA RETURN /GET RETURN POINTER TO LOCI
ION /PUT IT IN INTERRUPT HANDLER
NOP /ENABLE INTERRUPTS
IOF /WAIT
CLSA /DISABLE INTERRUPTS
JMS I NERROR /CLEAR CLOCK STATUS
JMS I ERROR /CHECK MONITOR
TST69M /INTERRUPT IN ERROR
HLT /MESSAGE POINTER
SKP /ERROR HALT
TST69 /TO NEXT TEST
CLA CLL /IS2 LOOPJ SCOPE LOOP
DCA REGA /SET AC=7777
IS2 /PRESET REGA
JMP REGB /DO THIS PAIR OF TESTS 4096 TIMES
TAD TST68 /BACK
DCA M0040 /PRESET REGA IF NEXT TEST IS TO BE EXECUTED
3037 0072
3040 6134
3041 7300
3042 1042
3043 3051
3044 6001
3045 7000
3046 6002
3047 6135
3050 4427
3051 4425
3052 7173
3053 7402
3054 7410
3055 3037
3056 7340
3057 3045
3060 2046
3061 5216
3062 1144
3063 3045

```

3064	6135	/	TEST OF INPUT CHANNEL 3
3065	7300	/	KNOB OF CHAN1, CHAN2, CHAN3 SET TO LINEFREQ. LEVEL IS DISABLED.
3066	6132	/	TST70, CLSA
3067	1074		CLA CLL
3070	6134		CLR AC
3071	7200		CLR ALL MODES
3072	2046		SET AC 10, 11, 1
3073	7410		ENABLE CHAN3 INPUT AND INTER.
3074	5277		CLR AC
3075	6131		INCREMENT TIMER
3076	5272		NOT DONE YET
3077	6135		TIMER OUT, ERROR CONDITION
3100	3052		SKIP ON CLOCK INTER.
3101	3046		WAIT
3102	1052		GET CLOCK STATUS
3103	7041		SAVE IT
3104	1073		CLR COUNT
3105	7650		RESTORE IT
3106	4427		2'S COMPLEMENT
3107	4425		ADD EVENT 3
3110	7212		EQUAL?
3111	7402		CHECK WITH MONITOR
3112	7410		CHAN 3 EVENT NOT SET, OR PRE-EVENT WAS SET, OR OTHER CHAN UP
3113	3064		MESSAGE POINTER
3114	1144		ERROR HALT
3115	3045		TO NEXT TEST
			ISZ LOOP, SCOPE LOOP
			PRESET REGA
			REGA
			REGA

/TEST OF INPUT CHANNEL 2

3116	6135	CLSA	16133	3-DEC-71	16133	PAGE 51
3117	7300	CLA CLL				
3120	6132	CLLR				
3121	1100	TAD	K0014			
3122	6134	CLEN				
3123	7200	CLA				
3124	2046	ISZ	REG8			
3125	7410	SKP				
3126	5331	JMP	.+3			
3127	6131	CLSK				
3130	5324	JMP	.+4			
3131	6135	CLSA				
3132	3052	DCA	RXED			
3133	3046	DCA	REG8			
3134	1052	TAD	RXED			
3135	7041	CIA				
3136	1077	TAD	K0010			
3137	7650	SNA CLA				
3140	4427	JMS I	NERROR			
3141	4425	JMS I	ERROR			
3142	7240	TST71M				
3143	7402	HLT				
3144	7410	SKP				
3145	3116	TST71				
3146	1144	TAD	M0040			
3147	3045	DCA	REGA			

/CLEAR STATUS	/PRESET REGA
/CLEAR AC	
/ZERO ALL MODES	
/ENAB, CHAN, 2 INPUT AND INTERRUPT FLOPS	
/ENABLE	
/CLEAR AC	
/INCREMENT TIMER	
/NOT DONE YET	
/TIMER OUT, ERROR CONDITION	
/CHECK FOR CLOCK INTER.	
/WAIT	
/GET STATUS	
/SAVE IT	
/CLEAR COUNT	
/RESTORE IT	
/2'S COMPLEMENT	
/ADD EVENT 2	
/EQUAL?	
/CHECK MONITOR	
/CHAN 2 EVENT NOT SET, OR PRE-EVENT WAS SET, OR OTHER CHAN UP	
/MESSAGE POINTER	
/ERROR HALT	
/TO NEXT TEST	
/ISZ LOOP, SCOPE LOOP	

/TEST OF INPUT CHAN 1
/

3150	6135	CLSA	/CLEAR STATUS
3151	7300	CLA CLL	/CLEAR AC
3152	6132	CLLR	/CLEAR ALL MODES
3153	1105	TAD K0060	/SET AC6,7#1
3154	6134	CLEN	/ENABLE CHAN 1 INPUT AND INTERRUPT
3155	7200	CLA	/CLEAR AC
3156	2046	ISZ	/INCREMENT TIMER
3157	7410	SKP	/NOT DONE YET
3160	5363	JMP	/TIMER OUT; ERROR CONDITION
3161	6131	CLSK	/CHECK FOR CLOCK INTER.
3162	5356	JMP	/WAIT
3163	6135	CLSA	/GET CLOCK STATUS
3164	3052	DCA	/SAVE IT
3165	3046	DCA	/CLEAR COUNT
3166	1052	TAD	/RESTORE IT
3167	7041	CIA	/COMPLEMENT
3170	1104	TAD	/ADD INPUT 1
3171	7650	SNA CLA	/EQUAL?
3172	4427	JMS I	/CHECK MONITOR
3173	4425	JMS I	/CHAN 1 EVENT NOT SET; OR PREVENT WAS SET; OR OTHER CHAN UP
3174	7266	TST72M	/MESSAGE POINTER
3175	7402	HLT	/ERROR HALT
3176	7410	SKP	/TO NEXT TEST
3177	3150	TST72	/ISZ LOOP; SCOPE LOOP
3200	7340	CLA CLL	/SET AC=7777
3201	3045	DCA REGA	/PRESET REGA

/TEST FAST SAMPLE MODE IF BIT 04=0

3202	7424	OSR	/IF RIGHT SW BIT 2(1)
3203	7006	RTL	/SKIP FAST SAM TEST?
3204	7006	RTL	
3205	7004	RAL	/RSW 04=1?
3206	7710	SPA CLA	
3207	5461	JMP I	/INDIRECT REF TO TST77
3210	6141	LINC	/ENTER LINC MODE
3211	0011	CLR	/CLEAR AC
3212	0004	ESF	/CLEAR SPEC. IN REG.
3213	0100	SAM0	/READ KNOB ZERO
3214	0002	PDP	/BACK TO PMODE
3215	3053	DCA	/TO PAGE 0
3216	6141	LINC	/BACK TO LMODE
3217	0101	SAM1	/READ KNOB 1
3220	0011	CLR	/CLEAR AC
3221	1020	LDAL	/PICK UP AC BIT 03
3222	0100	0100	
3223	0004	ESF	
3224	0002	PDP	/ENABLE FAST SAM
3225	6135	CLSA	/ENTER PDP-8 MODE
3226	7300	CLA CLL	/CLEAR CLOCK STATUS
3227	1115	TAD	/CLEAR AC
3230	6132	CLLR	/SET MODE BIT0=1
3231	6141	LINC	/ENABLE COUNT
3232	0100	SAM0	/ENTER LINC MODE
3233	0100	SAM0	/FAST SAM SET THEREFORE READ IN KNOB 1
3234	0002	PDP	/SHOULD STILL READ KNOB1
3235	3052	DCA	/ENTER PDP-8 MODE
3236	1052	TAD	/SAVE VALUE
3237	7041	CIA	/RESTORE IT
3240	1053	TAD	/2'S COMPLEMENT
3241	7640	SZA CLA	/COMPARE IT
3242	4427	JMS I	/EQUAL?
3243	4425	JMS I	/CHECK MONITOR
3244	7314	TST73M	/READING FAST SAM CONVERTED IN ERROR
3245	7402	HLT	/MESSAGE POINTER
3246	7410	SKP	/ERROR HALT
3247	3202	TST73	/TO NEXT TEST
3250	7340	CLA CLL	/ISZ LOOP1 SCOPE LOOP
3251	3045	DCA	/SET AC=7777
			/PRESET REGA FOR NEXT TEST

/TEST FAST SAMPLE WITH MODE 2=1 (CHECK THAT KNOBS 0 & 1 ARE SET PROPERLY)

3252	1116	TAD	K0500	/SET AC 03,05=1
3253	6132	CLL		/MODE 2(1),0(1)
3254	7330	CLA CLL CML RAR		/SET AC=4000
3255	6133	CLAB		/SET BUFF=4000
3256	7200	CLA		/CLEAR AC
3257	1111	TAD	K0200	/SET AC 04=1
3260	6134	CLEN		/LOAD CTN FROM BUF
3261	7200	CLA		/CLEAR AC
3262	6133	CLAB		/CLR BUF
3263	7200	CLA		/CLEAR AC
3264	6132	CLL		/CLEAR ALL MODES
3265	1116	TAD	K0500	/SET AC 03,05=1
3266	6132	CLL		/SET OVERFLOW MODE 0(1)
3267	6141	LINC		/ENTER LINC MODE
3270	0100	SAM0		/SAMPLE KNOB 0
3271	0002	PDP		/ENTER PDP=8 MODE
3272	3052	DCA	RXED	/STORE
3273	1052	TAD	RXED	/RESTORE
3274	7041	CIA	SEND	/2'S COMPLEMENT
3275	1053	TAD		/ADD FIRST SAMPLE
3276	7650	SNA CLA		/EQUAL?
3277	4427	JMS I	NERROR	/CHECK MONITOR
3300	4425	JMS I	ERROR	/CONVERSION NOT INITIATED BY OVFLOW
3301	7333	TST74M		/MESSAGE POINTER
3302	7402	HLT		/ERROR HALT
3303	7410	SKP		/TO NEXT TEST
3304	3252	TST74		/IS2 LOOP/ SCOPE LOOP
3305	7340	CLA CLL	CMA	/SET AC=7777
3306	3045	DCA	REGA	/REGA FOR NEXT TEST
3307	2046	ISE	REGB	/DONE?
3310	5202	JMP	TST73	/BACK
3311	1144	TAD	M0040	
3312	3046	DCA	REGB	

```

/ CHECK THAT MODE 0(0),1(1),2(1) DO NOT AFFECT SAMPLE
/
TST75,
3313 7200
3314 6132
3315 1113
3316 6132
3317 6141
3320 0011
3321 0024
3322 0100
3323 0002
3324 3053
3325 6141
3326 0101
3327 1020
3330 0100
3331 0004
3332 0100
3333 0002
3334 3052
3335 1052
3336 7041
3337 1053
3340 7640
3341 4427
3342 4425
3343 7355
3344 7402
3345 7410
3346 3313
3347 7340
3350 3045

/ CLEAR AC
/ ZERO ALL MODES
/ SET AC04,05=1
/ MODE 1(1),2(1),0(0)
/ ENTER LINC MODE
/ CLEAR AC
/ ZERO SPEC. IN. REG.
/ SAMPLE KNOB 0
/ TO PHODE
/ SAVE KNOB 0
/ TO LMODE
/ SAMPLE KNOB 1
/ PICK UP AC 05

/ SET FAST SAM FLOP
/ GET KNOB 1 SETTING
/ ENTER PDP MODE
/ STORE
/ RECEIVE
/ 2'S COMPLEMENT
/ COMPARE
/ EQUAL?
/ CHECK MONITOR
/ FAST SAM NOT SET
/ MESSAGE POINTER
/ ERROR HALT
/ TO NEXT TEST
/ IS2 LOOP1 SCOPE LOCK
/ SET AC=7777
/ PRESET REGA FOR NEXT

```

/NOW CHECK FOR INHIBITING OF FAST SAM

3351	6141	ENTER LINC MODE
3352	0100	/READ KNOB 0
3353	0002	/ENTER PDP MODE
3354	3052	/STORE
3355	1052	/RESTORE
3356	7041	/2'S COMPLEMENT
3357	1053	/COMPARE
3360	7650	/EQUAL?
3361	4427	/CHECK MONITOR
3362	4425	/MODE 2(1),1(1) INHIBIT FAST SAM
3363	7376	/MESSAGE POINTER
3364	7402	/ERROR HALT
3365	7410	/TO NEXT TEST
3366	3351	/ISZ LOOP1 SCOPE LOOP
3367	7340	/SET AC=777
3370	3045	/PRESET REGA FOR NEXT TEST
3371	2046	/DONE?
3372	5460	/BACK VIA PAGE 0
3373	1144	/PRESET REGB
3374	3046	

TST76.	LINC	
	SAM0	
	PDP	
	DCA	RXED
	TAD	RXED
	CIA	
	TAD	SEND
	SNA CLA	
	JMS I	NERROR
	JMS I	ERROR
	TST76M	
	HLT	
	SKP	
	TST76	
	CLA CLL	CMA
	DCA	REGA
	ISZ	REGB
	JMP I	TST75N
	TAD	M0040
	DCA	REGB

/DOES TO PRESET CLEAR OVFL0; ENABLES, RATES AND MODES
/PROGRAMED IO PRESET USED

3375	7200	CLA	/CLEAR AC
3376	6132	CLLR	/CLEAR ALL MODES
3377	6134	CLEN	/CLEAR ALL ENABLES
3400	1126	TAD	/SET AC 01.02=1
3401	6132	CLLR	/SET RATE=10KHZ
3402	7200	CLA	
3403	1135	TAD	/SET AC 00.01=1
3404	7001	IAC	/INCREMENT COUNTER
3405	7440	SZA	/DONE?
3406	5204	JMP	/WAIT LOOP 4.92 MSEC

/NOW DO IO PRESET CHECK IF RATE BITS 1,2 CLEAR

3407	4157	CLEAR	/GENERATE I=0 PRESET
3410	6137	CLCA	/GET COUNTER
3411	3053	DCA	/STORE
3412	1135	TAD	/SET UP DELAY
3413	7001	IAC	/INCREMENT COUNTER
3414	7440	SZA	/DONE?
3415	5213	JMP	/WAIT LOOP 4.92 MSEC
3416	6137	CLCA	/READ COUNTER AGAIN
3417	7041	CIA	/2'S COMPLEMENT
3420	1053	TAD	/COMPARE
3421	7650	SNA CLA	/HAS COUNTER CHANGED?
3422	4427	JMS I	/CHECK MONITOR
3423	4425	JMS I	/IO PRESET FAILED TO CLEAR RATE BITS 1 & 2
3424	7423	TST77M	/MESSAGE POINTER
3425	7402	HLT	/ERROR HALT
3426	7410	SKP	/TO NEXT TEST
3427	3375	TST77	/IS2 LOOP SCOPE LOOP
3430	7340	CLA CLL	/SET AC=7777
3431	3045	DCA	/PRESET REGA FOR NEXT TEST
3432	2046	ISZ	/LOOP BACK
3433	5461	JMP I	
3434	1144	TAD	/
3435	3046	DCA	/PRESET REGB

```

3436 7200      /NOW ENABLE RATE BIT 0
3437 6132      /TST79, CLA
3440 6134      CCLR
3441 1130      TAD K4000
3442 6132      CCLR
3443 7200      CLA
3444 7001      IAC
3445 7440      SZA
3446 5244      JMP .-2

3447 4157      /NOW 00 10 PRESET AND SEE IF BIT 0 CLEARED
3450 6137      /CLEAR
3451 3053      CLCA
3452 7001      DCA SEND
3453 7440      IAC
3454 5252      SZA .-2
3455 6137      JMP
3456 7041      CLCA
3457 1053      CIA
3460 7650      TAD SEND
3461 4427      SNA CLA
3462 4425      JMS I NERROR
3463 7457      JMS I ERROR
3464 7402      TST79M
3465 7410      HLT
3466 3436      SKP
3467 7340      TST79
3470 3045      CLA CLL CMA
3471 2046      DCA REGA
3472 5462      ISZ REGB
3473 3045      JMP I TST79N
          DCA REGA

```

```

/CLEAR AC
/CLEAR ALL MODES
/CLEAR ENABLES
/SET AC 00=1
/SET RATE=1KHZ

/INCREMENT COUNTER
/DONE?
/WAIT LOOP 16 MSEC

/GENERATE I=0 PRESET
/READ COUNTER
/STORE
/INCREMENT COUNTER
/DONE?
/WAIT 16 MSEC
/READ COUNTER AGAIN
/2'S COMPLEMENT
/COMPARE
/COUNTER STILL THE SAME
/CHECK MONITOR
/RATE BIT 0 SET AFTER 10 PRESET
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP1 SCOPE LOOP
/SET AC=7777
/PRESET REGA
/LOOP BACK
/BACK VIA PAGE 0
/CLEAR REGA IF EXECUTING NEXT TEST

```

/DOES OVERFLOW AND OVFL0 INT. FLOP
/CLEAR WITH I0 PRESET
/

3474	7200	CLA	/CLEAR AC
3475	6132	CLLR	/CLEAR ALL MODES
3476	1107	TAD	
3477	6132	CLLR	/SET MODE 2(1)
3500	6135	CLSA	/CLEAR STATUS
3501	7240	CLSA CMA	
3502	6133	CLAB	/SET BUF TO 7777
3503	7200	CLA	
3504	1111	TAD	
3505	6134	CLEN	/LOAD COUNTER
3506	4157	CLEAR	/GENERATE I=0 PRESET THIS ONE WILL SET OVERFLOW
3507	4157	CLEAR	/THIS ONE WILL CLEAR IT
3510	6135	CLSA	/GET STATUS
3511	7700	SMA CLA	
3512	4427	JMS I	/CHECK MONITOR
3513	4425	JMS I	/OVFL0 STILL SET AFTER I0 PRESET
3514	7511	TST81M	/MESSAGE POINTER
3515	7402	HLT	/ERROR HALT
3516	7410	SKP	/TO NEXT TEST
3517	3474	TST81	/IS2 LOOP) SCOPE LOOP

```

/PDP-12 KW12A CLOCK TEST; MAINDEC 12-D8CD=L      PAL10      V141      3=DEC=71      16133      PAGE 60

/
/TEST OVFL0 INT ENABLE
/
TST82,      CLA      TAD      K0100
3520 7200      CLLR
3521 1107      CLSA
3522 6132      CLA CMA
3523 6135      CLAB
3524 7240      CLA
3525 6133      TAD      K0200
3526 7200      CLEN
3527 1111      CLEAR
3530 6134      CLLR
3531 4157      TAD      K0100
3532 6132      CLSK
3533 1107      JMS I      NERROR
3534 6132      JMS I      ERROR
3535 6131      TST82M
3536 4427      HLT
3537 4425      SKP CLA
3540 7534
3541 7422      TST82
3542 7610
3543 3520

/CLEAR AC
/SET MODE 2(1)
/CLEAR STATUS
/SET BUP PRESET REG.

/LOAD CNT WITH 4000
/GENERATE I-O PRESET; THIS WILL SET OVERFLOW
/CLEAR ALL MODES
/GEN.

/CHECK MONITOR
/OVFL0 INTER. SET AFTER I/O PRESET
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP; SCOPE LOOP

```

```

/DOES IO PRESET CLEAR INPUT ENABLE FLOPS
/
TST83,
3544 7200 CLA
3545 6132 CLLR
3546 1106 TAD K0077
3547 6134 CLEN
3550 4157 CLEAR
3551 6135 CLSA
3552 7200 CLA
3553 1106 TAD K0077
3554 6132 CLLR
3555 7200 CLA
3556 6135 CLSA
3557 0127 AND K3777
3560 7650 SNA CLA
3561 4427 JMS I NERROR
3562 4425 JMS I ERROR
3563 4310 TST83M
3564 7402 HLT
3565 7610 SKP CLA
3566 3544 TST83

/CLEAR ALL MODES
/ENABLE INPUTS TO ALL CHAN
/GENERATE I-O PRESET
/CLEAR STATUS

/SIMULATE INPUTS ON ALL CHAN

/GET STATUS
/IGNORE OIFLO

/CHECK MONITOR
/STATUS NOT ZERO I/O PRESET FAILED
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP, SCOPE LOOP

```

```

/DOES IO PRESET CLEAR MODE 2
/
TST84,
6133 CLAB
3570 CLLR
3571 TAD K0100
3572 CLLR
3573 CLEAR
3574 TAD K5555
3575 CLAB
3576 CLA
3577 TAD K0200
3600 CLEN
3601 CLCA
3602 SMA CLA
3603 JMS I NERROR
3604 JMS I ERROR
3605 TST84M
3606 HLT
3607 SKP CLA
3610 TST84
3611 CLA CLL CMA
3612 DCA REGA

/SET MODE 2(1) = CLR CNT
/GENERATE I=0 PRESET
/LOAD BUF WITH 5555
/GEN LOAD CNT
/LOAD CNT TO AC
/CHECK MONITOR
/MODE 2 NOT CLEARED BY I/O PRESET
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP1 SCOPE LOOP
/SET AC = 7777
/PRESET REGA

```

/DOES IO PRESET CLEAR MODE 0

3613	7604	LAS		/IF RIGHT SW BIT 4(1)
3614	7006	RTL		/SKIP FAST SAM TEST
3615	7006	RTL		
3616	7710	SPA CLA	RESET	
3617	5300	JMP		
3620	7200	CLA		
3621	6132	CLLR		/CLEAR ALL MODES
3622	6141	LINC		/ENTER LINC MODE
3623	0100	SAM0		/READ KNOB 0
3624	0002	PDP		
3625	3053	DCA	SEND	
3626	6141	LINC		
3627	0101	SAM1		/READ KNOB 1
3630	0002	PDP		/ENTER PDP MODE
3631	7200	CLA		
3632	1115	TAD	K0400	
3633	6132	CLLR		/SET MODE 0(1)
3634	6141	LINC		/ENTER LINC MODE
3635	1020	LDAL		
3636	0020	0020		/DO IO PRESET
3637	0004	ESF		
3640	1020	LDAL		/ENABLE FAST SAM
3641	0100	0100		
3642	0004	ESF		/READ KNOB 1-FAST S. MODE
3643	0100	SAM0		/ENTER PDP MODE
3644	0002	PDP		
3645	7041	CIA		
3646	1053	TAD	SEND	
3647	7640	SZA CLA		/CHECK MONITOR
3650	4427	JMS I	NERROR	/FAST SAM NOT SET
3651	4425	JMS I	ERROR	/MESSAGE POINTER
3652	4360	TST85M		/ERROR HALT
3653	7402	HLT		/TO NEXT TAPE
3654	7410	SKP		/IS2 LOOP/ SCOPE LOOP
3655	3613	TST85		/SET AC = 7777
3656	7340	CLA CLL	CMA	/PRESET REGA
3657	3045	DCA	REGA	

```

3660 6141
3661 0100
3662 0002
3663 7041
3664 1053
3665 7650
3666 4427
3667 4425
3670 4405
3671 7402
3672 7410
3673 3660
3674 7340
3675 3045
3676 2046
3677 5213

/
/ NOW CHECK FOR MODE 0 CLEARED
/
TST86, LINC
      SAM0
      PDP
      CIA
      TAD SEND
      SNA CLA
      JMS I NERROR
      JMS I ERROR
      TST86M
      HLT
      SKP
      TST86
      CLA CLL CMA
      DCA REGA
      ISZ REG8
      JMP TST85

/ RESET ANYTHING LEFT HANGING
/
RESET, CLEAR
      TAD M0040
      DCA REGA

3700 4157
3701 1144
3702 3045

/ ENTER LINC MODE
/ READ KNOB 0
/ ENTER PDP MODE

/ CHECK MONITOR
/ MODE 0 NOT CLEARED
/ MESSAGE POINTER
/ ERROR HALT
/ TO NEXT TEST
/ ISZ LOOP1 SCOPE LOOP
/ SET AC = 7777
/ PRESET REGA
/ LOOP BACK

/ GENERATE I-0 PRESET
/ PRESET REGA PRIOR TO NEXT TEST

```

/DOES MODE 1(1) WORK CHAN 1

Address	Instruction	Comment
3703	CLA	
3704	CLLR	
3705	CLAB	
3706	JMS I	RANDOM
3707	DCA	SEND
3710	TAD	SEND
3711	CLAB	
3712	CLA	
3713	TAD	K0100
3714	CLLR	
3715	CLSA	
3716	CLA	
3717	TAD	K0200
3720	CLEN	
3721	CLLR	
3722	CLA	
3723	CLAB	
3724	TAD	K0060
3725	CLEN	
3726	ISE	REGB
3727	SKP	.03
3730	JMP	.04
3731	CLSK	
3732	JMP	
3733	CLSA	
3734	CLA	
3735	DCA	REGB
3736	CLBA	
3737	CLA	SEND
3740	TAD	SNA CLA
3741	JMS I	NERROR
3742	JMS I	ERROR
3743	TST87M	
3744	HLT	
3745	SKP	
3746	TST87	
3747	TAD	M0040
3750	DCA	REGA
3751		

```

/PDP-12 KW12A CLOCK TEST, MAINDEC 12-D8CD=L      PAL10      V141      3-DEC-71      16133      PAGE 66

/DOES MODE 1 (1) WORK CHAN 2
/
TST88.
3752 6134 CLEN
3753 6135 CLSA
3754 7200 CLA
3755 6133 CLAB
3756 1100 TAD
3757 6134 CLEN
3760 2046 ISZ
3761 7410 SKP
3762 5365 JMP
3763 6131 CLSK
3764 5360 JMP
3765 6135 CLSA
3766 7200 CLA
3767 3046 DCA
3770 6136 CLBA
3771 7041 CIA
3772 1053 TAD
3773 7650 SNA CLA
3774 4427 JMS I
3775 4425 JMS I
3776 4453 TST88M
3777 7402 HLT
4000 7410 SKP
4001 3752 TST88
4002 1144 TAD
4003 3045 DCA

K0014
REG8
.03
.04
REG8
SEND
NERROR
ERROR
M0040
REGA

/CLEAR ENABLES
/CLEAR CLOCK STATUS
/CLEAR BUFFER
/ENABLE CHAN 2 INPUT AND INT
/INCREMENT TIMER
/NOT DONE YET
/TIME OUT
/SKP ON CLOCK INT
/CLEAR STATUS
/CLEAR REG8
/GET BUFFER
/COMPARE
/CHECK MONITOR
/CHAN2 INPUT FAILED TO CAUSE CNT TO BUF TRANSFER
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP/ SCOPE LOOP

```

/DOES MODE 1 (1) WORK CHAN 3

4004	6134	CLEN	/CLEARS ENABLE
4005	6135	CLSA	/CLEAR STATUS
4006	7200	CLA	
4007	6133	CLAB	/CLEAR BUFFER
4010	1074	TAD	
4011	6134	CLEN	/ENABLES CHAN 3 INPUT AND INT
4012	2046	ISZ	/INCREMENT TIMER
4013	7410	SKP	/NOT DONE YET
4014	5217	JMP	/TIME OUT
4015	6131	CLSK	/SKIP ON CK INT
4016	5212	JMP	
4017	6135	CLSA	/CLEAR CLOCK STATUS
4020	7200	CLA	
4021	3046	DCA	/CLEAR REGB
4022	6136	CLBA	/GET BUF
4023	7041	CIA	
4024	1053	TAD	/COMPARE
4025	7650	SNA CLA	
4026	4427	JMS I	/CHECK MONITOR
4027	4425	JMS I	/CHAN 3 INPUT FAILED TO CAUSE CNT TO BUF TRANSFER
4030	4501	TST89M	/MESSAGE POINTER
4031	7402	HLT	/ERROR HALT
4032	7410	SKP	/TO NEXT TEST
4033	4004	TST89	/ISZ LOOP; SCOPE LOOP
4034	7340	CLA CLL	/SET AC=7777
4035	3045	DCA	/PRESET REGA
4036	1144	TAD	/
4037	3046	DCA	/PRESET REGB

```

/TEST MODE 1(1) AND MODE 2(1) CHAN 1
/
TST90, CLEN K0300 /CLEARS ENABLES
TAD TAD K1000
CLLR CLLR
CLA CLA
TAD TAD K0300
CLLR CLLR
CLCA CLCA
DCA DCA SEND
CLSA CLSA
CLA CLA
CLAB CLAB
TAD TAD K0060
CLEN CLEN
ISZ ISZ REGT
SKP SKP .+3
JMP JMP .+4
CLSK CLSK
JMP JMP
CLSA CLSA
CLA CLA
DCA DCA REGT
CLBA CLBA
CIA CIA
TAD TAD SEND
SNA CLA
JMS I NERROR
JMS I ERROR
TST90M
HLT
SKP
TST90
CLA CLL CMA
DCA REGA
4040 6134
4041 1113
4042 1122
4043 6132
4044 7200
4045 1113
4046 6132
4047 6137
4050 3053
4051 6135
4052 7200
4053 6133
4054 1105
4055 6134
4056 2050
4057 7410
4060 5263
4061 6131
4062 9256
4063 6135
4064 7200
4065 3050
4066 6136
4067 7041
4070 1053
4071 7650
4072 4427
4073 4425
4074 4527
4075 7402
4076 7410
4077 4040
4100 7340
4101 3045

```

```

/START CNT RATE=400KHZ = MODE 1(1) AND 2(1)
/STOP CNT - MODE 1(1) AND 2(1)
/GET CNT
/STORE
/CLEAR BUF
/ENABLE CHAN1 INPUT AND INT
/INCREMENT TIMER
/NOT DONE YET
/TIME OUT
/SKP ON CLOCK INT
/CLEAR CLOCK STATUS
/CLEAR TIMER
/GET BUF
/COMAPRE
/CHECK MONITOR
/CHAN1 FAILED TO CAUSE CNT TO BUF TRANSFER
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/IS2 LOOP/ SCOPE LOOP

```

```

4102 6134
4103 6135
4104 7200
4105 6133
4106 1100
4107 6134
4110 2050
4111 7410
4112 5315
4113 6131
4114 5310
4115 6135
4116 7200
4117 3050
4120 7000
4121 6136
4122 7041
4123 1053
4124 7650
4125 4427
4126 4423
4127 4555
4130 7402
4131 7610
4132 4102
4133 7340
4134 3045

/TEST MODE 1 (1) AND MODE 2 (1) CHAN 2
/
TST91,
CLEN
CLSA
CLA
CLAB
TAD
CLEN
ISE
SKP
JMP
CLSK
JMP
CLSA
CLA
DCA
NOP
CLBA
CIA
TAD
SNA CLA
JMS I
JMS I
TST91M
HLT
SKP CLA
TST91
CLA CLL CMA
DCA REGA

/CLEAR STATUS
/CLEAR BUF
/ENABLE CHAN 2 INPUT AND INT
/INCREMENT TIMER
/NOT DONE YET
/TIME OUT
/SKP ON CLOCK INT
/CLEAR STATUS
/CLEAR REGT
/GET BUF
/COMPARE
/CHECK MONITOR
/CHAN 2 INPUT FAILED TO CAUSE CNT TO BUF TRANSFER
/PRESET REGA

```

```

4135 6134
4136 6135
4137 7200
4140 6133
4141 1074
4142 6134
4143 2050
4144 7410
4145 5320
4146 6131
4147 5343
4150 6135
4151 7200
4152 3050
4153 7000
4154 6136
4155 7041
4156 1053
4157 7050
4160 4427
4161 4425
4162 4603
4163 7402
4164 7410
4165 4135
4166 7340
4167 3045

/TEST MODE 1 (1) AND MODE 2 (1) CHAN 3
/TEST92;
/CLEN
/CLSA
/CLA
/CLAB
TAD
/CLEN
ISZ
SKP
JMP
CLSK
JMP
/CLSA
/CLA
DCA
NOP
CLBA
CIA
TAD
SNA
JMS
JMS
TST92M
HLT
SKP
TST92
CLA
DCA
CLL
CMA
REGA

K0003
REGT
.03
.04
REGT
SEND
NERROR
ERROR

/ENABLES CHAN3 INPUT AND INT
/INCREMENT TIMER
/NOT DONE YET
/TIME OUT
/SKP ON CLOCK INT
/CLEAR CLOCK STATUS
/CLEAR REGT
/GET BUF
/COMPARE
/CHAN 3 INPUT FAILED TO CAUSE CNT TO BUF TRANSFER
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOPJ SCOPE LOOP
/SET AC = 7777
/PRESET REGA

```

```

4170 6137
4171 3052
4172 1052
4173 7650
4174 4427
4175 4425
4176 4631
4177 7402
4200 7410
4201 4170
4202 7340
4203 3045
4204 2046
4205 5463
4206 1144
4207 3045

/
/ CHECK THAT CHAN 3 CLEARED COUNTER FROM TEST 92
/
TST93,
CLCA
DCA
RXED
TAD
RXED
SNA CLA
JMS I NERROR
JMS I ERROR
TST93M
HLT
SKP
TST93
CLA CLL CMA
DCA REGA
ISZ REGB
JMP I TST90N
TAD M0040
DCA REGA
/GET CNT
/ZERO?
/CHECK MONITOR
/CHAN3 INPUT FAILED TO CLEAR CNT
/MESSAGE POINTER
/ERROR HALT
/TO NEXT TEST
/ISZ LOOP) SCOPE LOOP
/SET AC = 7777
/PRESET REGA
/DO TESTS 90-93 40 TIMES
/TO TEST 90
/PRESET REGA

```

```

4210 1135
4211 3050
4212 1214
4213 6133
4214 7300
4215 1107
4216 6132
4217 6134
4220 1125
4221 6132
4222 6131
4223 5222
4224 2050
4225 5224
4226 7200
4227 6132
4230 6134
4231 6135
4232 6137
4233 7440
4234 7710
4235 4427
4236 4425
4237 4657
4240 7402
4241 7410
4242 4210

/ CHECK THAT O'FLO ALWAYS TRANSFERS BUFFER TO COUNTER ON MODE 2(1)
/
TST94,
TAD
DCA
REGT
K7300
CLAB
CLA CLL
TAD
CLLR
CLEN
TAD
CLLR
CLSK
JMP
ISZ
JMP
CLA
CLLR
CLEN
CLSA
CLCA
SZA
SPA CLA
JMS I NERROR
JMS I ERROR
TST94M
HLT
SKP
TST94

/GET 6000
/SET UP TIMER
/GET PRESET
/PRESET BUFFER
/GET RATE
/START CLOCK
/GET ENABLES
/WAIT FOR INTERRUPT
/WAIT FOR ANOTHER OVERFLOW
/22 MSEC DELAY

/GET THE COUNTER
/0 IS OK
/COUNTER SHOULD NEVER GO POSITIVE
/ECO EM12-00034 IS EITHER NOT INSTALLED OR NOT WORKING
/
/
/
/
/

```

/
/
/TEST THAT THE CLOCK COUNTER IS INCREMENTED
/ BY 1 WITH AN I-O PRESET

4243 7300	TST95,	CLA CLL	REGA	/CLEAR REGA
4244 3045	DCA	SEND	/PRESET SEND TO 0000	
4245 3053	CLLR		/CLEAR CLOCK	
4246 6132	TAD	K0100	/GET 0100	
4247 1107	CLLR		/	
4250 6132	CLSA		/	
4251 6135	CLA CLL		/LOAD PRESET BUFFER	
4252 7300	CLAB			
4253 6133	CLA CLL	K0200	/GET 0200	
4254 7300	TAD		/ENABLE	
4255 1111	CLEN		/GENERATE I-O PRESET	
4256 6134	CLEN		/INCREMENT DATA	
4257 4157	ISZ	SEND		
4260 2053	NOP		/READ COUNTER	
4261 7000	CLCA		/SAVE VALUE	
4262 6137	DCA	RXD	/GET IT BACK	
4263 3052	TAD	RXD	/NEGATE IT	
4264 1052	CLA		/ADD EXPECTED VALUE	
4265 7041	TAD	SEND	/ARE THEY EQUAL ?	
4266 1053	SNA CLA		/YES, NO ERROR	
4267 7650	JMS I	NERROR	/NO, ECO EM12-00055 IS NOT INSTALLED	
4270 4427	JMS I	ERROR	/ OR NOT WORKING CORRECTLY	
4271 4425			/	
4272 4716	TST95M		/	
4273 7402	HLT		/	
4274 7410	SKP		/	
4275 4257	TST95N		/	

/ALERT OPERATOR OF PASS COMPLETION
/SUPPRESS PRINTOUT IF RSW 06 = 1

4276 2031	TST96,	ISZ	PASS	/INCREMENT PASS
4277 7000	NOP			/DON'T SKIP
4300 7604	LAS			/READ SWITCHES
4301 0104	AND	K0040		/PICK OUT RSW 06
4302 7640	SZA CLA			/SET?
4303 5176	JMP	176		/YES, NO PRINTOUT
4304 1043	TAD	PNTJ		/GET POINTER
4305 3425	DCA I	ERROR		/CHEAT MONITOR
4306 5430	JMP I	OUTPAS		/GO TYPE ALARM
4307 4755	TST96M			/MESSAGE POINTER

LOCJ,
/RETURN TO LOC 176 FROM ASCII TYPEOUT (MONITOR WILL HANDLE LINK)

```

5000      *5000
5001      /NON ERROR MONITOR DETERMINES IF OPERATOR WANTS TO LOOP ON NONFAILING TEST
5002      /RETURN ADDRESS
5003      /SET AC = 4
5004      /GET RETURN ADDRESS
5005      /UPDATE RETURN ADDRESS
5006      /GET SCOPE LOOP ADDRESS
5007      /STORE IT
5008      /UPDATE DATA
5009      /EXIT
5010      /READ SWITCHES
5011      /SAVE SR3
5012      /TEST AND CLEAR
5013      /LOOPING
5014      /SET AC=-1
5015      /ADD NERROS
5016      /STORE IN NERROS
5017      /JUMP INDIRECT LOOP

5020      /ERROR PROCESSOR, SCOPE LOOP, HALT, PRINT
5021      /RETURN ADDRESS STORAGE
5022      /READ SWITCHES
5023      /MOVE SR1 INTO AC00
5024      /IS IT SET
5025      /NO TYPE A MESSAGE
5026      /RING THE BELL
5027      /GET CURRENT ERROR ADDRESS
5028      /INVERT IT
5029      /STORE IN LAST ERROR
5030      /YES INDEX ESCAPE
5031      /READ SWITCHES
5032      /IS SR0 SET
5033      /NO, ERROR HALT
5034      /YES INDEX ESCAPE TO JUMP OUT
5035      /INDEX ERRORS TO SCOPE MODE
5036      /GET SCOPE ADDRESS
5037      /STORE IN TYPE
5038      /READ SWITCHES
5039      /MOVE SR02 TO AC0
5040      /IS SCOPE MODE SELECTED
5041      /YES CONTINUE IN SCOPE LOOP
5042      /NO SET AC=7777 (-1)
5043      /SUBTRACT ONE FROM ERRORS
5044      /STORE SELECTED ADDRESS
5045      /EXIT TO NEXT TEST
5046
5047      CLC IAC RTL
5048      TAD NERROS
5049      DCA NERROS
5050      TAD I NERROS
5051      DCA ERRORS
5052      ISZ REGA
5053      JMP I ERRORS
5054      LAS K0400
5055      AND K0400
5056      SZA CLA
5057      JMP I ERRORS
5058      CMA
5059      TAD NERROS
5060      DCA NERROS
5061      JMP I NERROS
5062
5063      ASCRXT, TAD
5064      CIA
5065      ISZ
5066      LAS
5067      SMA CLA
5068      HLT
5069      ISZ
5070      ISZ
5071      TAD I
5072      DCA
5073      LAS
5074      SPA CLA
5075      JMP I
5076      CMA
5077      TAD
5078      DCA
5079      JMP I
5080
5081      LAS
5082      RAL
5083      SMA CLA
5084      JMP ASCII
5085      JMS I BELL
5086      TAD
5087      CIA
5088      ISZ
5089      LAS
5090      SMA CLA
5091      HLT
5092      ISZ
5093      ISZ
5094      TAD I
5095      DCA
5096      LAS
5097      SPA CLA
5098      JMP I
5099      CMA
5100      TAD
5101      DCA
5102      JMP I
5103
5104      LAS
5105      RAL
5106      SMA CLA
5107      JMP ASCII
5108      JMS I BELL
5109      TAD
5110      CIA
5111      ISZ
5112      LAS
5113      SMA CLA
5114      HLT
5115      ISZ
5116      ISZ
5117      TAD I
5118      DCA
5119      LAS
5120      SPA CLA
5121      JMP I
5122      CMA
5123      TAD
5124      DCA
5125      JMP I
5126
5127      LAS
5128      RAL
5129      SMA CLA
5130      JMP ASCII
5131      JMS I BELL
5132      TAD
5133      CIA
5134      ISZ
5135      LAS
5136      SMA CLA
5137      HLT
5138      ISZ
5139      ISZ
5140      TAD I
5141      DCA
5142      LAS
5143      SPA CLA
5144      JMP I
5145      CMA
5146      TAD
5147      DCA
5148      JMP I
5149
5150      LAS
5151      RAL
5152      SMA CLA
5153      JMP ASCII
5154      JMS I BELL
5155      TAD
5156      CIA
5157      ISZ
5158      LAS
5159      SMA CLA
5160      HLT
5161      ISZ
5162      ISZ
5163      TAD I
5164      DCA
5165      LAS
5166      SPA CLA
5167      JMP I
5168      CMA
5169      TAD
5170      DCA
5171      JMP I
5172
5173      LAS
5174      RAL
5175      SMA CLA
5176      JMP ASCII
5177      JMS I BELL
5178      TAD
5179      CIA
5180      ISZ
5181      LAS
5182      SMA CLA
5183      HLT
5184      ISZ
5185      ISZ
5186      TAD I
5187      DCA
5188      LAS
5189      SPA CLA
5190      JMP I
5191      CMA
5192      TAD
5193      DCA
5194      JMP I
5195
5196      LAS
5197      RAL
5198      SMA CLA
5199      JMP ASCII
5200      JMS I BELL
5201      TAD
5202      CIA
5203      ISZ
5204      LAS
5205      SMA CLA
5206      HLT
5207      ISZ
5208      ISZ
5209      TAD I
5210      DCA
5211      LAS
5212      SPA CLA
5213      JMP I
5214      CMA
5215      TAD
5216      DCA
5217      JMP I
5218
5219      LAS
5220      RAL
5221      SMA CLA
5222      JMP ASCII
5223      JMS I BELL
5224      TAD
5225      CIA
5226      ISZ
5227      LAS
5228      SMA CLA
5229      HLT
5230      ISZ
5231      ISZ
5232      TAD I
5233      DCA
5234      LAS
5235      SPA CLA
5236      JMP I
5237      CMA
5238      TAD
5239      DCA
5240      JMP I
5241
5242      LAS
5243      RAL
5244      SMA CLA
5245      JMP ASCII
5246      JMS I BELL
5247      TAD
5248      CIA
5249      ISZ
5250      LAS
5251      SMA CLA
5252      HLT
5253      ISZ
5254      ISZ
5255      TAD I
5256      DCA
5257      LAS
5258      SPA CLA
5259      JMP I
5260      CMA
5261      TAD
5262      DCA
5263      JMP I
5264
5265      LAS
5266      RAL
5267      SMA CLA
5268      JMP ASCII
5269      JMS I BELL
5270      TAD
5271      CIA
5272      ISZ
5273      LAS
5274      SMA CLA
5275      HLT
5276      ISZ
5277      ISZ
5278      TAD I
5279      DCA
5280      LAS
5281      SPA CLA
5282      JMP I
5283      CMA
5284      TAD
5285      DCA
5286      JMP I
5287
5288      LAS
5289      RAL
5290      SMA CLA
5291      JMP ASCII
5292      JMS I BELL
5293      TAD
5294      CIA
5295      ISZ
5296      LAS
5297      SMA CLA
5298      HLT
5299      ISZ
5300      ISZ
5301      TAD I
5302      DCA
5303      LAS
5304      SPA CLA
5305      JMP I
5306      CMA
5307      TAD
5308      DCA
5309      JMP I
5310
5311      LAS
5312      RAL
5313      SMA CLA
5314      JMP ASCII
5315      JMS I BELL
5316      TAD
5317      CIA
5318      ISZ
5319      LAS
5320      SMA CLA
5321      HLT
5322      ISZ
5323      ISZ
5324      TAD I
5325      DCA
5326      LAS
5327      SPA CLA
5328      JMP I
5329      CMA
5330      TAD
5331      DCA
5332      JMP I
5333
5334      LAS
5335      RAL
5336      SMA CLA
5337      JMP ASCII
5338      JMS I BELL
5339      TAD
5340      CIA
5341      ISZ
5342      LAS
5343      SMA CLA
5344      HLT
5345      ISZ
5346      ISZ
5347      TAD I
5348      DCA
5349      LAS
5350      SPA CLA
5351      JMP I
5352      CMA
5353      TAD
5354      DCA
5355      JMP I
5356
5357      LAS
5358      RAL
5359      SMA CLA
5360      JMP ASCII
5361      JMS I BELL
5362      TAD
5363      CIA
5364      ISZ
5365      LAS
5366      SMA CLA
5367      HLT
5368      ISZ
5369      ISZ
5370      TAD I
5371      DCA
5372      LAS
5373      SPA CLA
5374      JMP I
5375      CMA
5376      TAD
5377      DCA
5378      JMP I
5379
5380      LAS
5381      RAL
5382      SMA CLA
5383      JMP ASCII
5384      JMS I BELL
5385      TAD
5386      CIA
5387      ISZ
5388      LAS
5389      SMA CLA
5390      HLT
5391      ISZ
5392      ISZ
5393      TAD I
5394      DCA
5395      LAS
5396      SPA CLA
5397      JMP I
5398      CMA
5399      TAD
5400      DCA
5401      JMP I
5402
5403      LAS
5404      RAL
5405      SMA CLA
5406      JMP ASCII
5407      JMS I BELL
5408      TAD
5409      CIA
5410      ISZ
5411      LAS
5412      SMA CLA
5413      HLT
5414      ISZ
5415      ISZ
5416      TAD I
5417      DCA
5418      LAS
5419      SPA CLA
5420      JMP I
5421      CMA
5422      TAD
5423      DCA
5424      JMP I
5425
5426      LAS
5427      RAL
5428      SMA CLA
5429      JMP ASCII
5430      JMS I BELL
5431      TAD
5432      CIA
5433      ISZ
5434      LAS
5435      SMA CLA
5436      HLT
5437      ISZ
5438      ISZ
5439      TAD I
5440      DCA
5441      LAS
5442      SPA CLA
5443      JMP I
5444      CMA
5445      TAD
5446      DCA
5447      JMP I
5448
5449      LAS
5450      RAL
5451      SMA CLA
5452      JMP ASCII
5453      JMS I BELL
5454      TAD
5455      CIA
5456      ISZ
5457      LAS
5458      SMA CLA
5459      HLT
5460      ISZ
5461      ISZ
5462      TAD I
5463      DCA
5464      LAS
5465      SPA CLA
5466      JMP I
5467      CMA
5468      TAD
5469      DCA
5470      JMP I
5471
5472      LAS
5473      RAL
5474      SMA CLA
5475      JMP ASCII
5476      JMS I BELL
5477      TAD
5478      CIA
5479      ISZ
5480      LAS
5481      SMA CLA
5482      HLT
5483      ISZ
5484      ISZ
5485      TAD I
5486      DCA
5487      LAS
5488      SPA CLA
5489      JMP I
5490      CMA
5491      TAD
5492      DCA
5493      JMP I
5494
5495      LAS
5496      RAL
5497      SMA CLA
5498      JMP ASCII
5499      JMS I BELL
5500      TAD
5501      CIA
5502      ISZ
5503      LAS
5504      SMA CLA
5505      HLT
5506      ISZ
5507      ISZ
5508      TAD I
5509      DCA
5510      LAS
5511      SPA CLA
5512      JMP I
5513      CMA
5514      TAD
5515      DCA
5516      JMP I
5517
5518      LAS
5519      RAL
5520      SMA CLA
5521      JMP ASCII
5522      JMS I BELL
5523      TAD
5524      CIA
5525      ISZ
5526      LAS
5527      SMA CLA
5528      HLT
5529      ISZ
5530      ISZ
5531      TAD I
5532      DCA
5533      LAS
5534      SPA CLA
5535      JMP I
5536      CMA
5537      TAD
5538      DCA
5539      JMP I
5540
5541      LAS
5542      RAL
5543      SMA CLA
5544      JMP ASCII
5545      JMS I BELL
5546      TAD
5547      CIA
5548      ISZ
5549      LAS
5550      SMA CLA
5551      HLT
5552      ISZ
5553      ISZ
5554      TAD I
5555      DCA
5556      LAS
5557      SPA CLA
5558      JMP I
5559      CMA
5560      TAD
5561      DCA
5562      JMP I
5563
5564      LAS
5565      RAL
5566      SMA CLA
5567      JMP ASCII
5568      JMS I BELL
5569      TAD
5570      CIA
5571      ISZ
5572      LAS
5573      SMA CLA
5574      HLT
5575      ISZ
5576      ISZ
5577      TAD I
5578      DCA
5579      LAS
5580      SPA CLA
5581      JMP I
5582      CMA
5583      TAD
5584      DCA
5585      JMP I
5586
5587      LAS
5588      RAL
5589      SMA CLA
5590      JMP ASCII
5591      JMS I BELL
5592      TAD
5593      CIA
5594      ISZ
5595      LAS
5596      SMA CLA
5597      HLT
5598      ISZ
5599      ISZ
5600      TAD I
5601      DCA
5602      LAS
5603      SPA CLA
5604      JMP I
5605      CMA
5606      TAD
5607      DCA
5608      JMP I
5609
5610      LAS
5611      RAL
5612      SMA CLA
5613      JMP ASCII
5614      JMS I BELL
5615      TAD
5616      CIA
5617      ISZ
5618      LAS
5619      SMA CLA
5620      HLT
5621      ISZ
5622      ISZ
5623      TAD I
5624      DCA
5625      LAS
5626      SPA CLA
5627      JMP I
5628      CMA
5629      TAD
5630      DCA
5631      JMP I
5632
5633      LAS
5634      RAL
5635      SMA CLA
5636      JMP ASCII
5637      JMS I BELL
5638      TAD
5639      CIA
5640      ISZ
5641      LAS
5642      SMA CLA
5643      HLT
5644      ISZ
5645      ISZ
5646      TAD I
5647      DCA
5648      LAS
5649      SPA CLA
5650      JMP I
5651      CMA
5652      TAD
5653      DCA
5654      JMP I
5655
5656      LAS
5657      RAL
5658      SMA CLA
5659      JMP ASCII
5660      JMS I BELL
5661      TAD
5662      CIA
5663      ISZ
5664      LAS
5665      SMA CLA
5666      HLT
5667      ISZ
5668      ISZ
5669      TAD I
5670      DCA
5671      LAS
5672      SPA CLA
5673      JMP I
5674      CMA
5675      TAD
5676      DCA
5677      JMP I
5678
5679      LAS
5680      RAL
5681      SMA CLA
5682      JMP ASCII
5683      JMS I BELL
5684      TAD
5685      CIA
5686      ISZ
5687      LAS
5688      SMA CLA
5689      HLT
5690      ISZ
5691      ISZ
5692      TAD I
5693      DCA
5694      LAS
5695      SPA CLA
5696      JMP I
5697      CMA
5698      TAD
5699      DCA
5700      JMP I
5701
5702      LAS
5703      RAL
5704      SMA CLA
5705      JMP ASCII
5706      JMS I BELL
5707      TAD
5708      CIA
5709      ISZ
5710      LAS
5711      SMA CLA
5712      HLT
5713      ISZ
5714      ISZ
5715      TAD I
5716      DCA
5717      LAS
5718      SPA CLA
5719      JMP I
5720      CMA
5721      TAD
5722      DCA
5723      JMP I
5724
5725      LAS
5726      RAL
5727      SMA CLA
5728      JMP ASCII
5729      JMS I BELL
5730      TAD
5731      CIA
5732      ISZ
5733      LAS
5734      SMA CLA
5735      HLT
5736      ISZ
5737      ISZ
5738      TAD I
5739      DCA
5740      LAS
5741      SPA CLA
5742      JMP I
5743      CMA
5744      TAD
5745      DCA
5746      JMP I
5747
5748      LAS
5749      RAL
5750      SMA CLA
5751      JMP ASCII
5752      JMS I BELL
5753      TAD
5754      CIA
5755      ISZ
5756      LAS
5757      SMA CLA
5758      HLT
5759      ISZ
5760      ISZ
5761      TAD I
5762      DCA
5763      LAS
5764      SPA CLA
5765      JMP I
5766      CMA
5767      TAD
5768      DCA
5769      JMP I
5770
5771      LAS
5772      RAL
5773      SMA CLA
5774      JMP ASCII
5775      JMS I BELL
5776      TAD
5777      CIA
5778      ISZ
5779      LAS
5780      SMA CLA
5781      HLT
5782      ISZ
5783      ISZ
5784      TAD I
5785      DCA
5786      LAS
5787      SPA CLA
5788      JMP I
5789      CMA
5790      TAD
5791      DCA
5792      JMP I
5793
5794      LAS
5795      RAL
5796      SMA CLA
5797      JMP ASCII
5798      JMS I BELL
5799      TAD
5800      CIA
5801      ISZ
5802      LAS
5803      SMA CLA
5804      HLT
5805      ISZ
5806      ISZ
5807      TAD I
5808      DCA
5809      LAS
5810      SPA CLA
5811      JMP I
5812      CMA
5813      TAD
5814      DCA
5815      JMP I
5816
5817      LAS
5818      RAL
5819      SMA CLA
5820      JMP ASCII
5821      JMS I BELL
5822      TAD
5823      CIA
5824      ISZ
5825      LAS
5826      SMA CLA
5827      HLT
5828      ISZ
5829      ISZ
5830      TAD I
5831      DCA
5832      LAS
5833      SPA CLA
5834      JMP I
5835      CMA
5836      TAD
5837      DCA
5838      JMP I
5839
5840      LAS
5841      RAL
5842      SMA CLA
5843      JMP ASCII
5844      JMS I BELL
5845      TAD
5846      CIA
5847      ISZ
5848      LAS
5849      SMA CLA
5850      HLT
5851      ISZ
5852      ISZ
5853      TAD I
5854      DCA
5855      LAS
5856      SPA CLA
5857      JMP I
5858      CMA
5859      TAD
5860      DCA
5861      JMP I
5862
5863      LAS
5864      RAL
5865      SMA CLA
5866      JMP ASCII
5867      JMS I BELL
5868      TAD
5869      CIA
5870      ISZ
5871      LAS
5872      SMA CLA
5873      HLT
5874      ISZ
5875      ISZ
5876      TAD I
5877      DCA
5878      LAS
5879      SPA CLA
5880      JMP I
5881      CMA
5882      TAD
5883      DCA
5884      JMP I
5885
5886      LAS
5887      RAL
5888      SMA CLA
5889      JMP ASCII
5890      JMS I BELL
5891      TAD
5892      CIA
5893      ISZ
5894      LAS
5895      SMA CLA
5896      HLT
5897      ISZ
5898      ISZ
5899      TAD I
5900      DCA
5901      LAS
5902      SPA CLA
5903      JMP I
5904      CMA
5905      TAD
5906      DCA
5907      JMP I
5908
5909      LAS
5910      RAL
5911      SMA CLA
5912      JMP ASCII
5913      JMS I BELL
5914      TAD
5915      CIA
5916      ISZ
5917      LAS
5918      SMA CLA
5919      HLT
5920      ISZ
5921      ISZ
5922      TAD I
5923      DCA
5924      LAS
5925      SPA CLA
5926      JMP I
5927      CMA
5928      TAD
5929      DCA
5930      JMP I
5931
5932      LAS
5933      RAL
5934      SMA CLA
5935      JMP ASCII
5936      JMS I BELL
5937      TAD
5938      CIA
5939      ISZ
5940      LAS
5941      SMA CLA
5942      HLT
5943      ISZ
5944      ISZ
5945      TAD I
5946      DCA
5947      LAS
5948      SPA CLA
5949      JMP I
5950      CMA
5951      TAD
5952      DCA
5953      JMP I
5954
5955      LAS
5956      RAL
5957      SMA CLA
5958      JMP ASCII
5959      JMS I BELL
5960      TAD
5961      CIA
5962      ISZ
5963      LAS
5964      SMA CLA
5965      HLT
5966      ISZ
5967      ISZ
5968      TAD I
5969      DCA
5970      LAS
5971      SPA CLA
5972      JMP I
5973      CMA
5974      TAD
5975      DCA
5976      JMP I
5977
5978      LAS
5979      RAL
5980      SMA CLA
5981      JMP ASCII
5982      JMS I BELL
5983      TAD
5984      CIA
5985      ISZ
5986      LAS
5987      SMA CLA
5988      HLT
5989      ISZ
5990      ISZ
5991      TAD I
5992      DCA
5993      LAS
5994      SPA CLA
5995      JMP I
5996      CMA
5997      TAD
5998      DCA
5999      JMP I
6000

```

5051	7240	CLA CMA	ASCII,		/SET C(AC)=-1
5052	1620	TAD I	ERRORS		/GET MESSAGE ADDRESS STORAGE
5053	3010	DCA	PINT		/STORE IT IN AUTO INDEX REGISTER
5054	1220	TAD	ERRORS		/GET RETURN ADDRESS
5055	1026	TAD	LSTERR		/SUBTRACT LAST ERROR ADDRESS
5056	7650	SNA CLA			/TEST
5057	5363	JMP	DATYP		/SAME GO TYPE DATA
5060	1410	TAD I	PINT		/GET FIRST CHARACTER
5061	3200	DCA	NERROS		/SAVE IT
5062	1200	TAD	NERROS		/GET IT
5063	7450	SNA			/TEST IT
5064	5226	JMP	ASCRXT		/NUMBER=EXIT,
5065	7040	CMA			/INVERT IT
5066	7450	SNA			/NUMBER=EXITA
5067	5315	JMP	DATUM		/TYPE OUT DATA ROUTINE
5070	7040	CMA			/CHANGE IT BACK
5071	7112	RTR CLL			/SWAP AC TO THE RIGHT
5072	7012	RTR			/MOVE
5073	7012	RTR			/MOVE
5074	4300	JMS	TYPECH		/TYPE IT
5075	1200	TAD	NERROS		/GET IT AGAIN
5076	4300	JMS	TYPECH		/TYPE IT
5077	5260	JMP	ASCII+7		/MUST BE MORE WORDS THAT NEED TYPING
5100	0000	TYPECH, 0			
5101	0106	AND	K0077		/SAVE SIGNIFICANT PART
5102	3055	DCA	SPACE		/STORE WORD
5103	1055	TAD	SPACE		/FETCH IT
5104	7650	SNA CLA			/TEST FOR 00 CRLF CODE
5105	4354	JMS	CRLF		/YES IT WAS
5106	1055	TAD	SPACE		/NO TYPE IT
5107	1144	TAD	M0040		/SUBTRACT 40
5110	7510	SPA			/TEST POLARITY
5111	1107	TAD	K0100		/ADD 340
5112	1112	TAD	K240		/ADD 240
5113	4464	JMS I	TYPE		/TYPE
5114	5700	JMP I	TYPECH		/EXIT

5115	DATUM,	TAD I	PINT	/GET ADDRESS OF REGISTER
1410		DCA	NERROS	/STORE IN TEMP
3200		TAD	NERROS	/GET TEMP
5116		SNA CLA	ASCRXT	/TEST FOR EXIT
5117		JMP	NERROS	/EQUALS 0000 EXIT
7650		TAD	M4444	/GET TEMP
5120		TAD		/SS?
5121		SNA CLA	176	/TEST
5122		JMP	NERROS	/SPECIAL RESTART
5123		TAD I	OCTYP	/GET DATA
5124		JMS	K240	/TYPE IT
5125		TAD	TYPE	/SPACE
5126		JMS I	DATUM	/TYPE IT
5127		JMP		/TYPE NUMERIC DATA
5128	OCTYP,	Ø	TYPECH	/RETURN ADDRESS STORAGE
5129		DCA	K7774	/STORE DATA TO BE PRINTED
5130		TAD	SPACE	/SET UP TALLY
5131		DCA	K1026	/SET IT
5132	HERE,	TAD	CRLF	/GET FLAG NUMBER
5133	REDO,	DCA	TYPECH	/STORE
5134		TAD		
5135		RAL	TYPECH	
5136		DCA	CRLF	
5137		TAD		
5138		RAL		
5139		SNL	REDO	
5140		JMP	TYPE	
5141		JMS I	SPACE	
5142		ISZ	HERE	
5143		JMP I	OCTYP	
5144		Ø	K0213	/EXIT
5145		TAD	TYPE	/RETURN ADDRESS STORAGE
5146		JMS I	K0212	/GET CR
5147		TAD	TYPE	/TYPE IT
5148		JMS I	K0177	/GET LF
5149		TAD	CRLF	/TYPE IT
5150		JMS I	PINT	/SET TO RUBOUT
5151		JMP I	ASCRXT	/EXIT
5152		SNA		/GET A TERM OFF OF TYPE LIST
5153		JMP		/END OF LIST?
5154		CMA		/YES EXIT
5155		SZA CLA		/INVERT
5156		JMP	DATYP	/BEGINNING OF DATA
5157		JMS	CRLF	/NO
5158		CLA CLL	DATUM	/YES OK RETURN THE TTY CARRIAGE AND LINE FEED
5159		JMP		/CLEAR AC AND LINK
5160		Ø215,		/GO TYPE THE DATA
5161		K0212,		
5162		Ø212,		

5200	5200	BELLS,	*5200		
5201	0000		0	LAS	
5202	7604		AND		
5203	0107		SEA	CLA	K0100
5204	7640		JMP	I	BELLS
5205	5600		TAD	K0007	
5206	1076		JMS	I	TYPE
5207	4464		JMP	I	BELLS
5208	5600		0		
5209	0000	RANDY,	TAD	RNA	
5210	1240		TAD	RNB	
5211	1241		TAD	RNC	
5212	1242		TAD	K5252	
5213	1133		DCA	RNA	
5214	3240		RAL		
5215	7004		TAD	RNA	
5216	1240		TAD	RNB	
5217	1241		TAD	RNC	
5218	1242		TAD	K5252	
5219	1133		DCA	RNB	
5220	3241		RAL		
5221	7004		TAD	RNA	
5222	1240		TAD	RNB	
5223	1241		TAD	RNC	
5224	1242		TAD	K5252	
5225	1133		DCA	RNB	
5226	3241		RAL		
5227	7004		TAD	RNA	
5228	1240		TAD	RNB	
5229	1241		TAD	RNC	
5230	1242		TAD	K5252	
5231	1133		DCA	RNB	
5232	3241		RAL		
5233	7004		TAD	RNA	
5234	1240		TAD	RNB	
5235	1241		TAD	RNC	
5236	1242		TAD	K5252	
5237	1133		DCA	RNB	
5238	3241		RAL		
5239	7004		TAD	RNA	
5240	1240		TAD	RNB	
5241	1241		TAD	RNC	
5242	1242		TAD	K5252	
5243	1133		DCA	RNB	
5244	3241		RAL		
5245	7004		TAD	RNA	
5246	1240		TAD	RNB	
5247	1241		TAD	RNC	
5248	1242		TAD	K5252	
5249	1133		DCA	RNB	
5250	3241		RAL		
5251	7004		TAD	RNA	
5252	1240		TAD	RNB	
5253	1241		TAD	RNC	
5254	1242		TAD	K5252	
5255	1133		DCA	RNB	
5256	3241		RAL		
5257	7004		TAD	RNA	
5258	1240		TAD	RNB	
5259	1241		TAD	RNC	
5260	1242		TAD	K5252	
5261	1133		DCA	RNB	
5262	3241		RAL		
5263	7004		TAD	RNA	
5264	1240		TAD	RNB	
5265	1241		TAD	RNC	
5266	1242		TAD	K5252	
5267	1133		DCA	RNB	
5268	3241		RAL		
5269	7004		TAD	RNA	
5270	1240		TAD	RNB	
5271	1241		TAD	RNC	
5272	1242		TAD	K5252	
5273	1133		DCA	RNB	
5274	3241		RAL		
5275	7004		TAD	RNA	
5276	1240		TAD	RNB	
5277	1241		TAD	RNC	
5278	1242		TAD	K5252	
5279	1133		DCA	RNB	
5280	3241		RAL		
5281	7004		TAD	RNA	
5282	1240		TAD	RNB	
5283	1241		TAD	RNC	
5284	1242		TAD	K5252	
5285	1133		DCA	RNB	
5286	3241		RAL		
5287	7004		TAD	RNA	
5288	1240		TAD	RNB	
5289	1241		TAD	RNC	
5290	1242		TAD	K5252	
5291	1133		DCA	RNB	
5292	3241		RAL		
5293	7004		TAD	RNA	
5294	1240		TAD	RNB	
5295	1241		TAD	RNC	
5296	1242		TAD	K5252	
5297	1133		DCA	RNB	
5298	3241		RAL		
5299	7004		TAD	RNA	
5300	1240		TAD	RNB	
5301	1241		TAD	RNC	
5302	1242		TAD	K5252	
5303	1133		DCA	RNB	
5304	3241		RAL		
5305	7004		TAD	RNA	
5306	1240		TAD	RNB	
5307	1241		TAD	RNC	
5308	1242		TAD	K5252	
5309	1133		DCA	RNB	
5310	3241		RAL		
5311	7004		TAD	RNA	
5312	1240		TAD	RNB	
5313	1241		TAD	RNC	
5314	1242		TAD	K5252	
5315	1133		DCA	RNB	
5316	3241		RAL		
5317	7004		TAD	RNA	
5318	1240		TAD	RNB	
5319	1241		TAD	RNC	
5320	1242		TAD	K5252	
5321	1133		DCA	RNB	
5322	3241		RAL		
5323	7004		TAD	RNA	
5324	1240		TAD	RNB	
5325	1241		TAD	RNC	
5326	1242		TAD	K5252	
5327	1133		DCA	RNB	
5328	3241		RAL		
5329	7004		TAD	RNA	
5330	1240		TAD	RNB	
5331	1241		TAD	RNC	
5332	1242		TAD	K5252	
5333	1133		DCA	RNB	
5334	3241		RAL		
5335	7004		TAD	RNA	
5336	1240		TAD	RNB	
5337	1241		TAD	RNC	
5338	1242		TAD	K5252	
5339	1133		DCA	RNB	
5340	3241		RAL		
5341	7004		TAD	RNA	
5342	1240		TAD	RNB	
5343	1241		TAD	RNC	
5344	1242		TAD	K5252	
5345	1133		DCA	RNB	
5346	3241		RAL		
5347	7004		TAD	RNA	
5348	1240		TAD	RNB	
5349	1241		TAD	RNC	
5350	1242		TAD	K5252	
5351	1133		DCA	RNB	
5352	3241		RAL		
5353	7004		TAD	RNA	
5354	1240		TAD	RNB	
5355	1241		TAD	RNC	
5356	1242		TAD	K5252	
5357	1133		DCA	RNB	
5358	3241		RAL		
5359	7004		TAD	RNA	
5360	1240		TAD	RNB	
5361	1241		TAD	RNC	
5362	1242		TAD	K5252	
5363	1133		DCA	RNB	
5364	3241		RAL		
5365	7004		TAD	RNA	
5366	1240		TAD	RNB	
5367	1241		TAD	RNC	
5368	1242		TAD	K5252	
5369	1133		DCA	RNB	
5370	3241		RAL		
5371	7004		TAD	RNA	
5372	1240		TAD	RNB	
5373	1241		TAD	RNC	
5374	1242		TAD	K5252	
5375	1133		DCA	RNB	
5376	3241		RAL		
5377	7004		TAD	RNA	
5378	1240		TAD	RNB	
5379	1241		TAD	RNC	
5380	1242		TAD	K5252	
5381	1133		DCA	RNB	
5382	3241		RAL		
5383	7004		TAD	RNA	
5384	1240		TAD	RNB	
5385	1241		TAD	RNC	
5386	1242		TAD	K5252	
5387	1133		DCA	RNB	
5388	3241		RAL		
5389	7004		TAD	RNA	
5390	1240		TAD	RNB	
5391	1241		TAD	RNC	
5392	1242		TAD	K5252	
5393	1133		DCA	RNB	
5394	3241		RAL		
5395	7004		TAD	RNA	
5396	1240		TAD	RNB	
5397	1241		TAD	RNC	
5398	1242		TAD	K5252	
5399	1133		DCA	RNB	
5400	3241		RAL		

/RING THE BELL

/RANDOM NUMBER GENERATOR

/CLEAR FLAG

/RESET PASS COUNTER

/TEXT TEST ERROR MESSAGES

/TST12M: 0024 /TST10 CLAB CHANGED AC

5261 0024
5262 2324
5263 6160
5264 4003
5265 1401
5266 0240
5267 0310
5270 0116
5271 0705
5272 0440
5273 0103
5274 4000
5275 7777
5276 0045
5277 0052
5300 0000

/TST11M: 0024 /TST11 CLBA FAILED

5301 0024
5302 2324
5303 6161
5304 4003
5305 1402
5306 0140
5307 0601
5310 1114
5311 0504
5312 4000
5313 7777
5314 0053
5315 0052
5316 0000

/TST12M: 0024 /TST12 CLAB FAILED

5317 0024
5320 2324
5321 6162
5322 4003
5323 1401
5324 0240
5325 0601
5326 1114
5327 0504
5330 4000
5331 7777
5332 0053
5333 0052
5334 0000

/TST13M: 0024 /TST13 CLAB FAILED

5335 0024
5336 2324
5337 6163
5340 4003
5341 1401

5342 0240
5343 0601
5344 1114
5345 0504
5346 4000
5347 7777
5350 0045
5351 0052
5352 0000
EXITA
REGA
RXED
EXIT

TST14M: 0024 2324 6164 4003 1401 0240 0601 1114 0504 4000
EXITA
SEND
RXED
EXIT

/TST14 CLAB FAILED

/TST15 CLBA CHANGED BUFFER

5371 0024
5372 2324
5373 6165
5374 4003
5375 1402
5376 0140
5377 0310
5400 0116
5401 0705
5402 0440
5403 0225
5404 0606
5405 0522
5406 4000
5407 7777
5410 0053
5411 0052
5412 0000
EXITA
SEND
RXED
EXIT

TST15M: 0024 2324 6165 4003 1402 0140 0310 0116 0705 0440 0225 0606 0522 4000
EXITA
SEND
RXED
EXIT

/TST16 CLAB <> CLBA FAILED

5413 0024
5414 2324
5415 6166
5416 4003
5417 1401
5420 0274
5421 7603
5422 1402
5423 0140
5424 0601
5425 1114

TST16M: 0024 2324 6166 4003 1401 0274 7603 1402 0140 0601 1114

5426 0504
5427 4000
5430 7777
5431 0045
5432 0052
5433 0000
0504
4000
EXITA
REGA
RXED
EXIT

TST17M, 0024 2324 6167 4003 1401 0274 7603 1402 0140 0601 1114 0504 4000 EXITA
/TST17 CLAB <> CLBA FAILED

5434 0024
5435 2324
5436 6167
5437 4003
5440 1401
5441 0274
5442 7603
5443 1402
5444 0140
5445 0601
5446 1114
5447 0504
5450 4000
5451 7777
5452 0053
5453 0052
5454 0000
0024
2324
6167
4003
1401
0274
7603
1402
0140
0601
1114
0504
4000
EXITA
SEND
RXED
EXIT

TST18M, 0024 2324 6170 4003 1401 0274 7603 1402 0140 0601 1114 0504 4000 EXITA
/TST18 CLAB <> CLBA FAILED

5455 0024
5456 2324
5457 6170
5460 4003
5461 1401
5462 0274
5463 7603
5464 1402
5465 0140
5466 0601
5467 1114
5470 0504
5471 4000
5472 7777
5473 0053
5474 0052
5475 0000
0024
2324
6170
4003
1401
0274
7603
1402
0140
0601
1114
0504
4000
EXITA
SEND
RXED
EXIT

TST19M, 0024 2324 6171 4003 1405 1640 0310 0116 0705 0440 0103 4000
/TST19 CLEN CHANGED AC

5476 0024
5477 2324
5500 6171
5501 4003
5502 1405
5503 1640
5504 0310
5505 0116
5506 0705
5507 0440
5510 0103
5511 4000
0024
2324
6171
4003
1405
1640
0310
0116
0705
0440
0103
4000

5512 7777
5513 0045
5514 0052
5515 0000
EXITA
REGA
RXED
EXIT

TST20M: 0024
/TST20 CLEN CHANGED BUFFER

5516 0024
5517 2324
5518 6260
5519 4003
5520 1405
5521 1640
5522 0310
5523 0116
5524 0705
5525 0440
5526 0225
5527 0606
5528 0522
5529 4000
5530 EXITA
5531 REGA
5532 RXED
5533 EXIT
5534 7777
5535 0045
5536 0052
5537 0000

TST21M: 0024
/TST21 CLCA FAILED

5540 0024
5541 2324
5542 6261
5543 4003
5544 1403
5545 0140
5546 0601
5547 1114
5548 0504
5549 4000
5550 EXITA
5551 SEND
5552 RXED
5553 EXIT
5554 7777
5555 0053
5556 0052
5557 0000

TST22M: 0024
/TST22 "CLR CNT" FAILED

5556 0024
5557 2324
5558 6262
5559 4042
5560 0314
5561 2240
5562 0316
5563 2442
5564 4006
5565 0111
5566 1405
5567 0400
5568 EXITA
5569 SEND
5570 RXED
5571 EXIT
5572 7777
5573 0053
5574 0052
5575 0000

/TST23 CLEN FAILED

TST23M, 0024
 5576 0024
 5577 2324
 5600 6263
 5601 4003
 5602 1405
 5603 1640
 5604 0601
 5605 1114
 5606 0504
 5607 4000
 5610 7777
 5611 0045
 5612 0052
 5613 0000
 EXITA
 REGA
 RXED
 EXIT

/TST24 CLEN FAILED

TST24M, 0024
 5614 0024
 5615 2324
 5616 6264
 5617 4003
 5620 1405
 5621 1640
 5622 0601
 5623 1114
 5624 0504
 5625 4000
 5626 7777
 5627 0053
 5630 0052
 5631 0000
 EXITA
 SEND
 RXED
 EXIT

/TST25 CLCA CHANGES COUNT

TST25M, 0024
 5632 0024
 5633 2324
 5634 6265
 5635 4003
 5636 1403
 5637 0140
 5640 0310
 5641 0116
 5642 0705
 5643 2340
 5644 0317
 5645 2516
 5646 2400
 5647 7777
 5650 0053
 5651 0052
 5652 0000
 EXITA
 SEND
 RXED
 EXIT

/TST26 BUFFER <> COUNTER FAILED

TST26M, 0024
 5653 0024
 5654 2324
 5655 6266
 5656 4002
 5657 2506
 5660 0605
 0024
 2324
 6266
 4002
 2506
 0605

5661 2274
 5662 7603
 5663 1725
 5664 1624
 5665 0522
 5666 4006
 5667 0111
 5670 1405
 5671 0400
 5672 7777
 5673 0053
 5674 0052
 5675 0000
 EXITA
 SEND
 RXED
 EXIT

/TST27 "LOAD CNT" FAILS TO "OR"

TST27M, 0024
 5676 0024
 5677 2324
 5700 6267
 5701 4042
 5702 1417
 5703 0104
 5704 4003
 5705 1624
 5706 4240
 5707 0601
 5710 1114
 5711 2340
 5712 2417
 5713 4042
 5714 1722
 5715 4200
 5716 7777
 5717 0053
 5720 0052
 5721 0000
 EXITA
 SEND
 RXED
 EXIT

/TST28 "LOAD CNT" LOADED IN ERROR

TST28M, 0024
 5722 0024
 5723 2324
 5724 6270
 5725 4042
 5726 1417
 5727 0104
 5730 4003
 5731 1624
 5732 4240
 5733 1417
 5734 0104
 5735 0504
 5736 4011
 5737 1640
 5740 0522
 5741 2217
 5742 2200
 5743 7777
 5744 0053
 5745 0052
 EXITA
 SEND
 RXED

```

5746 0000
5747 0024
5750 2324
5751 6271
5752 4042
5753 1417
5754 0104
5755 4003
5756 1624
5757 4240
5760 1417
5761 0104
5762 0504
5763 4011
5764 1640
5765 0522
5766 2217
5767 2200
5770 7777
5771 0053
5772 0052
5773 0000

TST29M, 0024
EXIT
2324
6271
4042
1417
0104
4003
1624
4240
1417
0104
0504
4011
1640
0522
2217
2200
EXITA
SEND
RXED
EXIT

```

/TST30 MODE REG CAUSES "LOAD CNT"

```

5774 0024
5775 2324
5776 6360
5777 4015
6000 1704
6001 0540
6002 2205
6003 0740
6004 0301
6005 2523
6006 0523
6007 4042
6010 1417
6011 0104
6012 4003
6013 1624
6014 4200
6015 7777
6016 0053
6017 0052
6020 0000

TST30M, 0024
2324
6360
4015
1704
0540
2205
0740
0301
2523
0523
4042
1417
0104
4003
1624
4200
EXITA
SEND
RXED
EXIT

```

/TST31 MODE REG CAUSES "LOAD CNT" OR "CLR BUF"

```

6021 0024
6022 2324
6023 6361
6024 4015
6025 1704
6026 0540
6027 2205
6030 0740
6031 0301
6032 2523

TST31M, 0024
2324
6361
4015
1704
0540
2205
0740
0301
2523

```

6033 0523
 6034 4042
 6035 1417
 6036 0104
 6037 4003
 6040 1624
 6041 4240
 6042 1722
 6043 4042
 6044 0314
 6045 2240
 6046 0225
 6047 0642
 6050 4000
 6051 7777
 6052 0053
 6053 0052
 6054 0046
 6055 0000

TST32M, 0024 /TST32 MODE 21 1>0 CLOCKED CNTR

6056 0024
 6057 2324
 6060 6362
 6061 4015
 6062 1704
 6063 0540
 6064 6272
 6065 4061
 6066 7660
 6067 4003
 6070 1417
 6071 0313
 6072 0504
 6073 4003
 6074 1624
 6075 2200
 6076 7777
 6077 0053
 6100 0052
 6101 0000

TST33M, 0024 /TST33 MODE 21 0>1 CLOCKED CNTR

6102 0024
 6103 2324
 6104 6363
 6105 4015
 6106 1704
 6107 0540
 6110 6272
 6111 4060
 6112 7661
 6113 4003
 6114 1417
 6115 0313
 6116 0504
 6117 4003

6120 1624
6121 2200
6122 7777
6123 0071
6124 0052
6125 0000
EXIT
RXED
K0000

/TST34 O'FLO FAILED TO SET O'FLO FLOP

TST34M, 0024
6126 0024
6127 2324
6130 6364
6131 4017
6132 4706
6133 1417
6134 4006
6135 0111
6136 1405
6137 0440
6140 2417
6141 4023
6142 0524
6143 4017
6144 4706
6145 1417
6146 4006
6147 1417
6150 2000
6151 0000
EXIT

/TST35 CLSA FAILED TO CLEAR O'FLO FLOP

TST35M, 0024
6152 0024
6153 2324
6154 6365
6155 4003
6156 1423
6157 0140
6160 0601
6161 1114
6162 0504
6163 4024
6164 1740
6165 0314
6166 0501
6167 2240
6170 4017
6171 4706
6172 1417
6173 4006
6174 1417
6175 2000
6176 0000
EXIT

/TST36 CLSK SKIPPED IN ERROR

TST36M, 0024
6177 0024
6200 2324
6201 6366
6202 4003
6203 1423

6204 1340
6205 2313
6206 1120
6207 2005
6210 0440
6211 1116
6212 4005
6213 2222
6214 1722
6215 4000
6216 0000
EXIT

TST37M, 0024
6217 0024
6220 2324
6221 6367
6222 4011
6223 1414
6224 0507
6225 0114
6226 4003
6227 1417
6230 0313
6231 4011
6232 1624
6233 0522
6234 2225
6235 2024
6236 4100
6237 0000
EXIT

/TST37 ILLEGAL CLOCK INTERRUPT!

/TST38 CLSK FAILED TO SKIP

TST38M, 0024
6240 0024
6241 2324
6242 6370
6243 4003
6244 1423
6245 1340
6246 0601
6247 1114
6250 0504
6251 4024
6252 1740
6253 2313
6254 1120
6255 4000
6256 0000
EXIT

/TST39 CLOCK INTERRUPT FAILED

TST39M, 0024
6257 0024
6260 2324
6261 6371
6262 4003
6263 1417
6264 0313
6265 4011
6266 1624
6267 0522

6270 2225
6271 2024
6272 4006
6273 0111
6274 1405
6275 0400
6276 0000
EXIT

6277 0024
6300 2324
6301 6460
6302 4017
6303 4706
6304 1417
6305 4005
6306 1601
6307 0214
6310 0540
6311 2717
6312 1647
6313 2440
6314 3205
6315 2217
6316 4000
6317 0000
EXIT

/TST40 0'FLO ENABLE MONIT ZERO

6320 0024
6321 2324
6322 6461
6323 4017
6324 4706
6325 1417
6326 4006
6327 1401
6330 0740
6331 2717
6332 1647
6333 2440
6334 0314
6335 0501
6336 2200
6337 0000
EXIT

/TST41 0'FLO FLAG MONIT CLEAR

6340 0024
6341 2324
6342 6462
6343 4003
6344 1417
6345 0313
6346 4011
6347 1624
6350 2240
6351 2717
6352 1647
6353 2440

/TST42 CLOCK INTR MONIT CLEAR

6354 0314
6355 0501
6356 2200
6357 0000
EXIT

/TST43 BIT 11 FAILED.

TST43M: 0024
6360 0024
6361 2324
6362 6463
6363 4002
6364 1124
6365 4061
6366 6140
6367 0601
6370 1114
6371 0504
6372 5600
6373 7777
6374 0053
6375 0052
6376 0000
EXITA
SEND
RXED
EXIT

/TST44 BIT 10 FAILED.

TST44M: 0024
6377 0024
6400 2324
6401 6464
6402 4002
6403 1124
6404 4061
6405 6040
6406 0601
6407 1114
6410 0504
6411 5600
6412 7777
6413 0053
6414 0052
6415 0000
EXITA
SEND
RXED
EXIT

/TST45 BIT 09 FAILED.

TST45M: 0024
6416 0024
6417 2324
6420 6465
6421 4002
6422 1124
6423 4060
6424 7140
6425 0601
6426 1114
6427 0504
6430 5600
6431 7777
6432 0053
6433 0052
6434 0000
EXITA
SEND
RXED
EXIT

/TST46 BIT 08 FAILED.

TST46M: 0024
6435 0024
6436 2324

6437 6466
6440 4002
6441 1124
6442 4060
6443 7040
6444 0601
6445 1114
6446 0504
6447 5600
6450 7777
6451 0053
6452 0052
6453 0000

/TST47 BIT 07 FAILED.

TST47M: 0024
6454 0024
6455 2324
6456 6467
6457 4002
6460 1124
6461 4060
6462 6740
6463 0601
6464 1114
6465 0504
6466 5600
6467 7777
6470 0053
6471 0052
6472 0000

/TST48 BIT 06 FAILED.

TST48M: 0024
6473 0024
6474 2324
6475 6470
6476 4002
6477 1124
6500 4060
6501 6640
6502 0601
6503 1114
6504 0504
6505 5600
6506 7777
6507 0053
6510 0052
6511 0000

/TST49 BIT 05 FAILED.

TST49M: 0024
6512 0024
6513 2324
6514 6471
6515 4002
6516 1124
6517 4060
6520 6540
6521 0601
6522 1114

6523 0504
6524 5600
6525 7777
6526 0053
6527 0052
6530 0000

6531 0024
6532 2324
6533 6560
6534 4002
6535 1124
6536 4060
6537 6440
6540 0601
6541 1114
6542 0504
6543 5600
6544 7777
6545 0053
6546 0052
6547 0000

/TST50 BIT 04 FAILED.

6550 0024
6551 2324
6552 6561
6553 4002
6554 1124
6555 4060
6556 6340
6557 0601
6560 1114
6561 0504
6562 5600
6563 7777
6564 0053
6565 0052
6566 0000

/TST51 BIT 03 FAILED.

6567 0024
6570 2324
6571 6562
6572 4002
6573 1124
6574 4060
6575 6240
6576 0601
6577 1114
6600 0504
6601 5600
6602 7777
6603 0053
6604 0052
6605 0000

/TST52 BIT 02 FAILED.

/PDP-12 KW12A CLOCK TEST, MAINDEC 12-D8CDOL PAL10 V141 3-DEC-71 16133 PAGE 77514

6606 0024 TST53M, 0024
6607 2324 2324
6610 6563 6563
6611 4002 4002
6612 1124 1124
6613 4060 4060
6614 6140 6140
6615 0601 0601
6616 1114 1114
6617 0504 0504
6620 5600 5600
6621 7777 EXITA
6622 0053 SEND
6623 0052 RXED
6624 0000 EXIT

/TST54 BIT 00 FAILED

6625 0024 TST54M, 0024
6626 2324 2324
6627 6564 6564
6630 4002 4002
6631 1124 1124
6632 4060 4060
6633 6040 6040
6634 0601 0601
6635 1114 1114
6636 0504 0504
6637 5600 5600
6640 7777 EXITA
6641 0053 SEND
6642 0052 RXED
6643 0000 EXIT

/TST55 RATE 400KC FAILS

6644 0024 TST55M, 0024
6645 2324 2324
6646 6565 6565
6647 4022 4022
6650 0124 0124
6651 0540 0540
6652 6460 6460
6653 6013 6013
6654 0340 0340
6655 0601 0601
6656 1114 1114
6657 2300 2300
6660 0000 EXIT

/TST56 RATE 100KC FAILS

6661 0024 TST56M, 0024
6662 2324 2324
6663 6566 6566
6664 4022 4022
6665 0124 0124
6666 0540 0540
6667 6160 6160
6670 6013 6013
6671 0340 0340

6672 0021 0601
 6673 1114 1114
 6674 2300 2300
 6675 0000 EXIT

/TST57 RATE 10KC FAILS

TST57M: 0024
 6676 0024 0024
 6677 2324 2324
 6700 6567 6567
 6701 4022 4022
 6702 0124 0124
 6703 0540 0540
 6704 6160 6160
 6705 1303 1303
 6706 4006 4006
 6707 0111 0111
 6710 1423 1423
 6711 4000 4000
 6712 0000 EXIT

/TST58 RATE 1KC FAILS

TST58M: 0024
 6713 0024 0024
 6714 2324 2324
 6715 6570 6570
 6716 4022 4022
 6717 0124 0124
 6720 0540 0540
 6721 6113 6113
 6722 0340 0340
 6723 0601 0601
 6724 1114 1114
 6725 2300 2300
 6726 0000 EXIT

/TST59 RATE 100CPS FAILS

TST59M: 0024
 6727 0024 0024
 6730 2324 2324
 6731 6570 6570
 6732 4022 4022
 6733 0124 0124
 6734 0540 0540
 6735 6160 6160
 6736 6003 6003
 6737 2023 2023
 6740 4006 4006
 6741 0111 0111
 6742 1423 1423
 6743 4000 4000
 6744 0000 EXIT

/TST60 CHAN 1 INPUT LOCKED OUT

TST60M: 0024
 6745 0024 0024
 6746 2324 2324
 6747 6660 6660
 6750 0003 0003
 6751 1001 1001
 6752 1640 1640
 6753 6140 6140
 6754 1116 1116

6755 2025
6756 2440
6757 1417
6760 0313
6761 0504
6762 4017
6763 2524
6764 4000
6765 0000
EXIT

TST61M; 0024 /TST61 CHAN 3 MON'IT TOGGLE

6766 0024
6767 2324
6770 6661
6771 4003
6772 1001
6773 1640
6774 6340
6775 2717
6776 1647
6777 2440
7000 2417
7001 0707
7002 1405
7003 4000
7004 7777
7005 0053
7006 0052
7007 0000
EXITA
SEND
RXED
EXIT

TST62M; 0024 /TST62 CHAN 2 MON'IT TOGGLE

7010 0024
7011 2324
7012 6662
7013 4003
7014 1001
7015 1640
7016 6240
7017 2717
7020 1647
7021 2440
7022 2417
7023 0707
7024 1405
7025 4000
7026 7777
7027 0053
7030 0052
7031 0000
EXITA
SEND
RXED
EXIT

TST63M; 0024 /TST63 CHAN 1 MON'IT TOGGLE

7032 0024
7033 2324
7034 6663
7035 4003
7036 1001
7037 1640
7040 6140

7041 2717
7042 1647
7043 2440
7044 2417
7045 0707
7046 1405
7047 4000
7050 7777
7051 0053
7052 0052
7053 0000
2717
1647
2440
2417
0707
1405
4000
EXITA
SEND
RXED
EXIT

TST64M; 0024 2324 6664 4003 1001 1640 4061 4027 1716 4724 4011 1624 2200 EXIT

/TST64 CHAN 1 WON'T INTR

/TST65 CHAN 1 INTR IN ERROR

7072 0024
7073 2324
7074 6665
7075 4003
7076 1001
7077 1640
7100 4061
7101 4011
7102 1624
7103 2240
7104 1116
7105 4005
7106 2222
7107 1722
7110 4000
7111 0000
0024
2324
6665
4003
1001
1640
4061
4011
1624
2240
1116
4005
2222
1722
4000
EXIT

TST66M; 0024 2324 6666 4003 1001 1640 6240 2717 1647 2440 1116

/TST66 CHAN 2 WON'T INTR

7125 2422
7126 5600
7127 7777
7130 0053
7131 0052
7132 0000

2422
5600
EXITA
SEND
RXED
EXIT

/TST67 CHAN 2 INTR IN ERROR

7133 0024
7134 2324
7135 6667
7136 4003
7137 1001
7140 1640
7141 6240
7142 1116
7143 2422
7144 4011
7145 1640
7146 0522
7147 2217
7150 2200
7151 0000

TST67M: 0024
2324
6667
4003
1001
1640
6240
1116
2422
4011
1640
0522
2217
2200
EXIT

/TST68 CHAN 3 WON'T INTR.

7152 0024
7153 2324
7154 6670
7155 4003
7156 1001
7157 1640
7160 6340
7161 2717
7162 1647
7163 2440
7164 1116
7165 2422
7166 5600
7167 7777
7170 0053
7171 0052
7172 0000

TST68M: 0024
2324
6670
4003
1001
1640
6340
2717
1647
2440
1116
2422
5600
EXITA
SEND
RXED
EXIT

/TST69 CHAN 3 INTR IN ERROR

7173 0024
7174 2324
7175 6671
7176 4003
7177 1001
7200 1640
7201 6340
7202 1116
7203 2422
7204 4011
7205 1640
7206 0522
7207 2217
7210 2200

TST69M: 0024
2324
6671
4003
1001
1640
6340
1116
2422
4011
1640
0522
2217
2200

7211	0000	EXIT
7212	0024	TST70M, 0024
7213	2324	2324
7214	6760	6760
7215	4003	4003
7216	1001	1001
7217	1640	1640
7220	6340	6340
7221	1116	1116
7222	2025	2025
7223	2440	2440
7224	1411	1411
7225	1605	1605
7226	4006	4006
7227	2205	2205
7230	2140	2140
7231	0601	0601
7232	1114	1114
7233	0504	0504
7234	4000	4000
7235	7777	EXITA
7236	0052	RXED
7237	0000	EXIT

/TST70 CHAN 3 INPUT LINE FREQ FAILED

/TST71 CHAN 2 INPUT LINE FREQ FAILED

7240	0024	TST71M, 0024
7241	2324	2324
7242	6761	6761
7243	4003	4003
7244	1001	1001
7245	1640	1640
7246	6240	6240
7247	1116	1116
7250	2025	2025
7251	2440	2440
7252	1411	1411
7253	1605	1605
7254	4006	4006
7255	2205	2205
7256	2140	2140
7257	0601	0601
7260	1114	1114
7261	0504	0504
7262	4000	4000
7263	7777	EXITA
7264	0052	RXED
7265	0000	EXIT

/TST72 CHAN 1 INPUT LINE FREQ FAILED

7266	0024	TST72M, 0024
7267	2324	2324
7270	6762	6762
7271	4003	4003
7272	1001	1001
7273	1640	1640
7274	6140	6140

7275	1116
7276	2025
7277	2440
7300	1411
7301	1605
7302	4006
7303	2205
7304	2140
7305	0601
7306	1114
7307	0504
7310	4000
7311	7777
7312	0052
7313	0000

/TST73 FAST SAM FAILS

7314	0024	TST73M, 0024
7315	2324	2324
7316	6763	6763
7317	4006	4006
7320	0123	0123
7321	2440	2440
7322	2301	2301
7323	1540	1540
7324	0601	0601
7325	1114	1114
7326	2300	2300
7327	7777	7777
7330	0053	0053
7331	0052	0052
7332	0000	0000

/TST74 0'FLO WON'T FAST SAM

7333	0024	TST74M, 0024
7334	2324	2324
7335	6764	6764
7336	4017	4017
7337	4706	4706
7340	1417	1417
7341	4027	4027
7342	1716	1716
7343	4724	4724
7344	4006	4006
7345	0123	0123
7346	2440	2440
7347	2301	2301
7350	1500	1500
7351	7777	7777
7352	0053	0053
7353	0052	0052
7354	0000	0000

/TST75 FAST SAM WON'T SET

7355	0024	TST75M, 0024
7356	2324	2324
7357	6765	6765
7360	4006	4006

7361 0123
7362 2440
7363 2301
7364 1540
7365 2717
7366 1647
7367 2440
7370 2305
7371 2400
7372 7777
7373 0053
7374 0052
7375 0000

7376 0024
7377 2324
7400 6766
7401 4015
7402 1704
7403 0523
7404 4062
7405 5561
7406 4011
7407 1610
7410 1102
7411 1124
7412 4006
7413 0123
7414 2440
7415 2301
7416 1500
7417 7777
7420 0053
7421 0052
7422 0000

7423 0024
7424 2324
7425 6770
7426 4011
7427 3417
7430 4020
7431 2205
7432 2305
7433 2440
7434 2717
7435 1647
7436 2440
7437 2324
7440 1720
7441 4003
7442 1417
7443 0313
7444 4000
7445 5022

/TS776 MODES 2,1 INHIBIT FAST SAM

/TS778 I/O PRESET MONIT STOP CLOCK
/(RATE BITS 1 & 2)

7446 0124
7447 0540
7450 0211
7451 2423
7452 4061
7453 4046
7454 4062
7455 5100
7456 0000
EXIT

TST79M: 0024
7457 0024
7460 2324
7461 7060
7462 4011
7463 3417
7464 4020
7465 2205
7466 2305
7467 2440
7470 2717
7471 1647
7472 2440
7473 2324
7474 1720
7475 4003
7476 1417
7477 0313
7500 4000
7501 5022
7502 0124
7503 0540
7504 0211
7505 2440
7506 6051
7507 4000
7510 0000
EXIT

TST81M: 0024
7511 0024
7512 2324
7513 7061
7514 4011
7515 3417
7516 4020
7517 2205
7520 2305
7521 2440
7522 2717
7523 1647
7524 2440
7525 0314
7526 0501
7527 2240
7530 1747
7531 0614
7532 1700

```

7533 0000          EXIT
7534 0024          TSTB2M, 0024
7535 2324          2324
7536 7062          7062
7537 4011          4011
7540 3417          3417
7541 4020          4020
7542 2205          2205
7543 2305          2305
7544 2440          2440
7545 2717          2717
7546 1647          1647
7547 2440          2440
7550 0314          0314
7551 0501          0501
7552 2240          2240
7553 1116          1116
7554 2405          2405
7555 2222          2222
7556 2520          2520
7557 2440          2440
7560 0516          0516
7561 0102          0102
7562 1405          1405
7563 4000          4000
7564 0000          EXIT
    
```

/TST82 I/O PRESET WON'T CLEAR INTERRUPT ENABLE

/FOLD TEXT BACK INTO FREE CORE AREA

/TST83 I/O PRESET WON'T CLEAR INPUTS

```

4310          *LOCJ+1
4310 0024          TSTB3M, 0024
4311 2324          2324
4312 7063          7063
4313 4011          4011
4314 3417          3417
4315 4020          4020
4316 2205          2205
4317 2305          2305
4320 2440          2440
4321 2717          2717
4322 1647          1647
4323 2440          2440
4324 0314          0314
4325 0501          0501
4326 2240          2240
4327 1116          1116
4330 2025          2025
4331 2423          2423
4332 4000          4000
4333 0000          EXIT
4334 0024          TSTB4M, 0024
4335 2324          2324
4336 7064          7064
    
```

/TST84 I/O PRESET WON'T CLEAR MODE 2

4337 4011 4011
4340 3417 3417
4341 4020 4020
4342 2205 2205
4343 2305 2305
4344 2440 2440
4345 2717 2717
4346 1647 1647
4347 2440 2440
4350 0314 0314
4351 0501 0501
4352 2240 2240
4353 1517 1517
4354 0405 0405
4355 4062 4062
4356 4000 4000
4357 0000 EXIT

/TST85 I/O PRESET WON'T CLEAR MODE 0

TST85M: 0024 0024
4360 0024 0024
4361 2324 2324
4362 7065 7065
4363 4011 4011
4364 3417 3417
4365 4020 4020
4366 2205 2205
4367 2305 2305
4370 2440 2440
4371 2717 2717
4372 1647 1647
4373 2440 2440
4374 0314 0314
4375 0501 0501
4376 2240 2240
4377 1517 1517
4400 0405 0405
4401 4060 4060
4402 4000 4000
4403 7777 EXITA
4404 0000 EXIT

/TST86 FAST SAM NOT CLEARED

TST86M: 0024 0024
4405 0024 0024
4406 2324 2324
4407 7066 7066
4410 4006 4006
4411 0123 0123
4412 2440 2440
4413 2301 2301
4414 1540 1540
4415 1617 1617
4416 2440 2440
4417 0314 0314
4420 0501 0501
4421 2205 2205
4422 0400 0400
4423 7777 EXITA

```
4424 0000 EXIT
4425 0024 TST87M, 0024
4426 2324 2324
4427 7067 7067
4430 4003 4003
4431 1001 1001
4432 1640 1640
4433 6140 6140
4434 2717 2717
4435 1647 1647
4436 2440 2440
4437 2422 2422
4440 0116 0116
4441 2340 2340
4442 0316 0316
4443 2440 2440
4444 2417 2417
4445 4002 4002
4446 2506 2506
4447 4000 4000
4450 7777 EXITA
4451 0111 K0200
4452 0000 EXIT
```

/TST87 CHAN 1 MONIT TRANS CNT TO BUF

/TST88 CHAN 2 MONIT TRANS CNT TO BUF

```
4453 0024 TST88M, 0024
4454 2324 2324
4455 7070 7070
4456 4003 4003
4457 1001 1001
4460 1640 1640
4461 6240 6240
4462 2717 2717
4463 1647 1647
4464 2440 2440
4465 2422 2422
4466 0116 0116
4467 2340 2340
4470 0316 0316
4471 2440 2440
4472 2417 2417
4473 4002 4002
4474 2506 2506
4475 4000 4000
4476 7777 EXITA
4477 0111 K0200
4500 0000 EXIT
```

/TST89 CHAN 3 MONIT TRANS CNT TO BUF

```
4501 0024 TST89M, 0024
4502 2324 2324
4503 7071 7071
4504 4003 4003
4505 1001 1001
4506 1640 1640
4507 6340 6340
```

4510 2717 2717
 4511 1647 1647
 4512 2440 2440
 4513 2422 2422
 4514 0116 0116
 4515 2340 2340
 4516 0316 0316
 4517 2440 2440
 4520 2417 2417
 4521 4002 4002
 4522 2506 2506
 4523 4000 4000
 4524 7777 EXITA
 4525 0111 K0200
 4526 0000 EXIT

TST90M: 0024 /TST90 CHAN 1 MONIT TRANS CNT TO BUF

4527 0024 0024
 4530 2324 2324
 4531 7160 7160
 4532 4003 4003
 4533 1001 1001
 4534 1640 1640
 4535 6140 6140
 4536 2717 2717
 4537 1647 1647
 4540 2440 2440
 4541 2422 2422
 4542 0116 0116
 4543 2340 2340
 4544 0316 0316
 4545 2440 2440
 4546 2417 2417
 4547 4002 4002
 4550 2506 2506
 4551 4000 4000
 4552 7777 EXITA
 4553 0113 K0300
 4554 0000 EXIT

TST91M: 0024 /TST91 CHAN 2 MONIT TRANS CNT TO BUF

4555 0024 0024
 4556 2324 2324
 4557 7161 7161
 4560 4003 4003
 4561 1001 1001
 4562 1640 1640
 4563 6240 6240
 4564 2717 2717
 4565 1647 1647
 4566 2440 2440
 4567 2422 2422
 4570 0116 0116
 4571 2340 2340
 4572 0316 0316
 4573 2440 2440
 4574 2417 2417

4575 4022 4002
4576 2506 2506
4577 4000 4000
4600 7777 EXITA
4601 0113 K0300
4602 0000 EXIT

/TST92 CHAN 3 MONIT TRANS CNT TO BUF

TST92M: 0024
4603 0024 2324
4604 2324 7162
4605 7162 4003
4606 4003 1001
4607 1001 1640
4610 1640 6340
4611 6340 2717
4612 2717 1647
4613 1647 2440
4614 2440 2422
4615 2422 0116
4616 0116 2340
4617 2340 0316
4620 0316 2440
4621 2440 2417
4622 2417 4002
4623 4002 2506
4624 2506 4000
4625 4000 EXITA
4626 7777 K0300
4627 0113 EXIT
4630 0000

/TST93 CHAN 3 INPUT FAILED TO CLR CNT

TST93M: 0024
4631 0024 2324
4632 2324 7163
4633 7163 4003
4634 4003 1001
4635 1001 1640
4636 1640 6340
4637 6340 1116
4640 1116 2025
4641 2025 2440
4642 2440 0601
4643 0601 1114
4644 1114 0504
4645 0504 4024
4646 4024 1740
4647 1740 0314
4650 0314 2240
4651 2240 0316
4652 0316 2400
4653 2400 EXITA
4654 7777 RXED
4655 0052 EXIT
4656 0000

/TST94 ECO EM12-00034 IS EITHER NOT WORKING OR NOT INSTALLED

TST94M: 0024
4657 0024 2324
4660

4661	7164	7164
4662	4005	4005
4663	0317	0317
4664	4005	4005
4665	1561	1561
4666	6255	6255
4667	6060	6060
4670	6063	6063
4671	6440	6440
4672	1123	1123
4673	4005	4005
4674	1124	1124
4675	1005	1005
4676	2240	2240
4677	1617	1617
4700	2440	2440
4701	2717	2717
4702	2213	2213
4703	1116	1116
4704	0740	0740
4705	1722	1722
4706	4016	4016
4707	1724	1724
4710	4011	4011
4711	1623	1623
4712	2401	2401
4713	1414	1414
4714	0504	0504
4715	0000	EXIT

4716	0024	TST95M, 0024
4717	2324	2324
4720	7165	7165
4721	4005	4005
4722	0317	0317
4723	4005	4005
4724	1561	1561
4725	6255	6255
4726	6060	6060
4727	6065	6065
4730	6540	6540
4731	1123	1123
4732	4005	4005
4733	1124	1124
4734	1005	1005
4735	2240	2240
4736	1617	1617
4737	2440	2440
4740	2717	2717
4741	2213	2213
4742	1116	1116
4743	0740	0740
4744	1722	1722
4745	4016	4016
4746	1724	1724

/TST95 ECO EM12-00055 IS EITHER NOT WORKING OR IS NOT INSTALLED

4747 4011
 4750 1623
 4751 2401
 4752 1414
 4753 0504
 4754 0000
 EXIT

TST96M: 0013 /KW12 PASS--(PASS)

4755 0013
 4756 2761
 4757 6240
 4760 2001
 4761 2323
 4762 5555
 4763 7777
 4764 0031
 4765 4444
 EXITA
 PASS
 EXITB
 S

/EXIT B CAUSES A RETURN TO 0176

[illegible]

[illegible]

ASCI1	5051	K0215	5174	NERROR	0027	TST18	0466
ASCRXT	5026	K0300	0113	NERRORS	5000	TST18M	5455
BELL	0021	K0377	0114	OCTYP	5133	TST19	0550
BELLS	5200	K0400	0115	OUTPAS	0030	TST19M	5476
BK43	1561	K0500	0116	PASS	0031	TST20	0566
BK47	1764	K0600	0117	PDP	0002	TST20M	5516
BK55	2362	K0700	0120	PINT	0010	TST21	0616
CLAB	6133	K0777	0121	PNTA	0032	TST21M	5540
CLAR	0157	K1000	0122	PNTB	0033	TST22	0643
CLBA	6136	K1026	0123	PNTC	0034	TST22M	5556
CLCA	6137	K1777	0124	PNTD	0035	TST23	0672
CLEAR	4157	K2000	0125	PNTE	0036	TST23M	5576
CLEN	6134	K240	0112	PNTF	0037	TST24	0721
CLLR	0011	K3000	0126	PNTG	0040	TST24M	5614
CLR	0011	K3777	0127	PNTH	0041	TST25	0753
CLSA	6135	K4000	0130	PNTJ	0042	TST25M	5632
CLSK	6131	K4100	0131	PNTJ	0043	TST26	1012
CNTR	0024	K5100	0132	PNTJ	0044	TST26M	5653
CRLF	5154	K5252	0133	RANDOM	5210	TST27	1043
DATUM	5115	K5555	0134	RANDY	5140	TST27M	5676
DATYP	5163	K6000	0135	REGA	0045	TST28	1077
DN43	0022	K7300	4214	REGB	0046	TST28M	5722
DN55	0023	K7774	0136	REGC	0047	TST29	1131
ERRORS	0025	LDAI	1020	REGT	0050	TST29M	5747
ESF	0004	LINC	6141	RESET	3700	TST30	1156
EXIT	0000	LOGA	1425	RETURN	0051	TST30M	5774
EXITA	7777	LOGB	1457	RNA	5240	TST31	1205
EXITB	4444	LOGC	1527	RNB	5241	TST31M	6021
FD43	1572	LOGD	2720	RNC	5242	TST32	1245
FD51	2201	LOGE	2742	RXED	0052	TST32M	6056
FD55	2372	LOGF	2763	SAM0	0100	TST33	1276
FD61	2617	LOGG	3005	SAM1	0101	TST33M	6102
HERE	5137	LOGH	3027	SEND	0053	TST34	1316
K0000	0071	LOGI	3051	SET	0054	TST34M	6126
K0001	0072	LOGJ	4307	SETN	5252	TST35	1344
K0002	0073	LSTER	0026	SPACE	0055	TST35M	6152
K0003	0074	M0001	0137	TST10	0201	TST35N	0056
K0004	0075	M0002	0140	TST10M	5261	TST36	1373
K0007	0076	M0004	0141	TST11	0217	TST36M	6177
K0010	0077	M0010	0142	TST11M	5301	TST37	1417
K0014	0100	M0020	0143	TST12	0235	TST37M	6217
K0017	0101	M0040	0144	TST12M	5317	TST38	1434
K0020	0102	M0042	0145	TST13	0254	TST38M	6240
K0037	0103	M0100	0146	TST13M	5335	TST39	1451
K0040	0104	M0200	0147	TST14	0274	TST39M	6257
K0060	0105	M0400	0150	TST14M	5353	TST40	1467
K0077	0106	M1000	0151	TST15	0315	TST40M	6277
K0100	0107	M1400	0152	TST15M	5371	TST41	1502
K0177	0110	M2000	0153	TST16	0340	TST41M	6320
K0200	0111	M4000	0154	TST16M	5413	TST42	1521
K0221	5175	M4444	0155	TST17	0403	TST42M	6340
		M5400	0156	TST17M	5434	TST43	1542

TST43M	6360	TST68M	7152	TST94M	4657
TST44	1602	TST69	3037	TST95	4243
TST44M	6377	TST69M	7173	TST95M	4716
TST45	1642	TST70	3064	TST95N	4257
TST45M	6416	TST70M	7212	TST96	4276
TST46	1723	TST71	3116	TST96M	4755
TST46M	6435	TST71M	7240	TYPE	0064
TST47	1744	TST72	3150	TYPECH	5100
TST47M	6454	TST72M	7266	TYPQUT	5243
TST48	2005	TST73	3202	UP43	0065
TST48M	6473	TST73M	7314	UP51	0066
TST49	2046	TST74	3252	UP55	0067
TST49M	6512	TST74M	7333	UP61	0070
TST50	2107	TST75	3313		
TST50M	6531	TST75M	7355		
TST51	2150	TST75N	0060		
TST51M	6550	TST76	3351		
TST52	2211	TST76M	7376		
TST52M	6567	TST77	3375		
TST53	2252	TST77M	7423		
TST53M	6606	TST77N	0061		
TST54	2313	TST79	3436		
TST54M	6623	TST79M	7457		
TST55	2354	TST79N	0062		
TST55M	6644	TST81	3474		
TST56	2401	TST81M	7511		
TST56M	6661	TST82	3520		
TST57	2426	TST82M	7534		
TST57M	6676	TST83	3544		
TST58	2460	TST83M	4310		
TST58M	6713	TST84	3567		
TST59	2507	TST84M	4334		
TST59M	6727	TST85	3613		
TST60	2546	TST85M	4360		
TST60M	6745	TST86	3660		
TST60N	2554	TST86M	4405		
TST61	2573	TST87	3703		
TST61M	6766	TST87M	4425		
TST62	2624	TST88	3752		
TST62M	7010	TST88M	4453		
TST63	2655	TST89	4004		
TST63M	7032	TST89M	4501		
TST64	2710	TST90	4040		
TST64M	7054	TST90M	4527		
TST65	2730	TST90N	0063		
TST65M	7072	TST91	4102		
TST66	2753	TST91M	4555		
TST66M	7112	TST92	4135		
TST66N	0057	TST92M	4603		
TST67	2773	TST93	4170		
TST67M	7133	TST93M	4631		
TST68	3016	TST94	4210		


/PDP-12 KW12A CLOCK TEST; MAINDEC 12-D8CD=L PAL10 V141 3-DEC-71 16133 PAGE 77-34

ERRORS DETECTED: 0

LINKS GENERATED: 0

RUN-TIME: 43 SECONDS

3K CORE USED



0000			*20	
0001			/	
0002			/ KW12A1	
0003			/	18 JULY 1977
0004			/	18 JULY 1977
0005			/	
0006			/	
0007			/	
0010			/ SUPPLEMENT TO THE KW12A DIAGNOSTIC PROGRAM.	
0011			/ CHECKS WHETHER, IN MODE 011, EVENT 2 ZERO'S THE	
0012			/ CLOCK COUNTER AS WELL AS TRANSFERRING ITS CON-	
0013			/ TS TO THE CLOCK BUFFER.	
0014			/	
0015			/ ASSUMES KW12A HAS RUN SUCCESSFULLY.	
0016			/	
0017			/ DISCONNECT ALL INPUT LINES, AND DESELECT	
0020			/ "LINE FREQ" FROM ALL THREE SOURCES.	
0021			/ START 8MODE, 0020.	
0022			/	
0023			/	
0024			PMODE	
0025			*0020	
0026			/	
0027			/ RATE AND MODE:	
0030			/ RATE 110 (COUNT INPUT 1 EVENTS)	
0031			/ MODE 011 (ANY EVENT TRANSFERS COUNTER TO BUFFER,	
0032			/ & EVENT 3 ZERO'S COUNTER)	
0033	0020	7200	CLA	
0034	0021	1117	TAD K0025	
0035	0022	6134	CLEN	/ENABLE ALL 3 INPUTS
0036	0023	7200	CLA	
0037	0024	1120	AGAIN, TAD K6300	
0040	0025	6132	CLLR	
0041	0026	7001	IAC	
0042	0027	6132	CLLR	/INPUT 3
0043	0030	6135	CLSA	/REENABLE INPUTS
0044	0031	7200	CLA	
0045	0032	1121	TAD K6301	
0046	0033	6132	CLLR	/AGAIN
0047	0034	6136	CLBA	/BUFFER TO AC
0050	0035	7440	SZA	/DID IT ZERO COUNTER?
0051	0036	7402	HLT	/IT SHOULD HAVE.
0052	0037	1123	TAD K6320	
0053	0040	6132	CLLR	/INPUT 1
0054	0041	6132	CLLR	/AGAIN
0055	0042	6137	CLCA	/COUNTER TO AC
0056	0043	1124	TAD KM2	
0057	0044	7440	SZA	/WAS IT 2?
0060	0045	7402	HLT	/IT SHOULD HAVE BEEN.
0061	0046	6133	CLAB	/CLEAR BUFFER PRESET REG.
0062	0047	6135	CLSA	/REENABLE INPUTS
0063	0050	7200	CLA	
0064	0051	1121	TAD K6301	
0065	0052	6132	CLLR	/INPUT 3
0066	0053	6136	CLBA	
0067	0054	1124	TAD KM2	
0070	0055	7440	SZA	/DID THE COUNTER GO TO THE
0071				/BUFFER BEFORE IT ZEROED?
0072	0056	7402	HLT	/NO; IT SHOULD HAVE.
0073	0057	6137	CLCA	
0074	0060	7440	SZA	/DIT IT THEN ZERO?
0075	0061	7402	HLT	/NO; IT SHOULD HAVE

0076	0062	1123	TAD K6320	
0077	0063	6132	CLLR	/INPUT 1
0100	0064	6132	CLLR	/AGAIN
0101	0065	6132	CLLR	/AND AGAIN
0102	0066	6137	CLCA	
0103	0067	7450	SNA	/IS THERE SOMETHING THERE?
0104	0070	7402	HLT	/NO; THERE SHOULD BE.
0105	0071	3116	DCA BUF	/YES; KEEP IT
0106	0072	1122	TAD K6304	
0107	0073	6132	CLLR	/INPUT 2
0110	0074	6136	CLBA	
0111	0075	7041	CIA	
0112	0076	1116	TAD BUF	
0113	0077	7440	SZA	/IS THE SAME THING THERE?
0114	0100	7402	HLT	/NO
0115	0101	6135	CLSA	
0116	0102	7200	CLA	
0117	0103	6133	CLAB	/CLEAR THE BUFFER
0120	0104	1122	TAD K6304	/INPUT 2
0121	0105	6132	CLLR	
0122	0106	6136	CLBA	
0123	0107	7041	CIA	
0124	0110	1116	TAD BUF	
0125	0111	7440	SZA	/STILL THERE?
0126	0112	7402	HLT	/OH-OH! INPUT 2 MUST DO
0127				/SOMETHING TO THE COUNTER!
0130	0113	6135	CLSA	
0131	0114	7200	CLA	
0132	0115	5024	JMP AGAIN	
0133		/		
0134	0116	0000	BUF, 0	
0135	0117	0025	K0025, 0025	
0136	0120	6300	K6300, 6300	
0137	0121	6301	K6301, 6301	
0140	0122	6304	K6304, 6304	
0141	0123	6320	K6320, 6320	
0142	0124	7776	KM2, -2	

NO ERRORS

AGAIN	0024
BUF	0116
KM2	0124
K0025	0117
K6300	0120
K6301	0121
K6304	0122
K6320	0123