

ADVANCE COPY

This document subject to change
without notice.

IDENTIFICATION

PRODUCT CODE: MAINDEC-8E-D0HB-D

PRODUCT NAME: RANDOM JMP TEST

DATE CREATED: DECEMBER 10, 1970

MAINTAINER: DIAGNOSTIC GROUP

AUTHOR: BRUCE HANSEN

1. ABSTRACT

THIS PROGRAM TESTS THE JMP INSTRUCTION OF THE PDP-8E. MOST OF MEMORY IS USED AS A JUMP FIELD WITH A RANDOM NUMBER GENERATOR SELECTING EACH JUMP FROM AND JUMP TO LOCATION.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-8E EQUIPPED WITH TELETYPE.

2.2 STORAGE

0000,0421. THE BINARY LOADER MUST BE STORED IN THE LAST MEMORY PAGE.

2.3 PRELIMINARY PROGRAMS

IT IS ASSUMED THAT MAINDEC-8E-D0AA, AND MAINDEC-8E-D0BA HAVE RUN SUCCESSFULLY.

3. LOADING PROCEDURE

3.1 METHOD

USE STANDARD BINARY LOADER.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

SR0(0) HALT ON ERROR.

SR2 HOLD JUMP FROM ADDRESSES CONSTANT. (1)
SELECT RANDOM JUMP FROM ADDRESSES. (0)

SR3 HOLD JUMP TO ADDRESSES CONSTANT. (1)
SELECT RANDOM JUMP TO ADDRESSES. (0)

4.2 STARTING ADDRESS

0200

RESTART ADDRESS

0214

4.3

OPERATOR ACTION -----

A. SET SR TO 0200 AND PRESS LOAD ADDRESS.

B. SET SR TO DESIRED MODE. IF A PARTICULAR MEMORY LOCATION IS DESIRED FOR EITHER A "CONSTANT FROM" OR "CONSTANT TO", THIS MEMORY ADDRESS IS ENTERED INTO ONE OF THE LOCATIONS SHOWN BELOW:

FROM 1 ADDRESS = 0120

FROM ADDRESS = 0117

TO ADDRESS = 0116

NOTE! ALWAYS MAKE (FROM 1) = (FROM) -1

IF SR2 OR SR3 IS SET AFTER THE PROGRAM HAS BEEN STARTED, THE LAST ADDRESS TAKEN FROM THE RANDOM NUMBER GENERATOR IS USED REPEATEDLY.

C. PRESS CLEAR THEN CONTINUE.

5. OPERATING PROCEDURE -----

SAME AS SECTION 4.

6. ERRORS -----

6.1 ERROR HALTS -----

ALL UNUSED MEMORY LOCATIONS ARE LOADED WITH HLT ORDERS. IF THE PROGRAM EXECUTES ONE OF THESE BACKGROUND HLTs, IT IS PROBABLE THAT THE INTERRUPT FAILED TO OCCUR FOLLOWING THE JMP INSTRUCTION.

6.2

ERROR PRINTOUTS

F WWW TO XXXX

Z = YYYY

(FROM) F WWW:WWW = THE ADDRESS OF THE JMP INSTRUCTION.
(TO) T XXX: XXX = THE ADDRESS THAT THE JMP INSTRUCTION IS JUMPING TO.
(LOC 0000) Z = YYYY; YYYY = THE ADDRESS STORED IN LOCATION 0000 DURING THE INTERRUPT.

NOTE THAT YYYY SHOULD EQUAL XXXX.

EXAMPLE: THE FOLLOWING IS A TYPICAL ERROR PRINTOUT:

F 4252 TO 7020
Z = 7000

LINE 1 OF THE PRINTOUT IS A STATEMENT OF THE PROBLEM. A JMP INSTRUCTION IS PLACED AT LOCATION 4252. THIS JMP INSTRUCTION IS TRYING TO JUMP TO LOCATION 7020. LINE 2 OF THE PRINTOUT INDICATES THE ERROR. THE TO ADDRESS (7020) WAS TO HAVE BEEN STORED IN LOCATION 0000 BUT INSTEAD A 7000 WAS STORED. THUS BIT 7 WAS DROPPED.

6.3

ERROR RECOVERY

THE PROGRAM CONTINUES TESTING FOLLOWING AN ERROR PRINTOUT. WHEN ENOUGH INFORMATION HAS BEEN GATHERED FROM THE ERROR PRINTOUTS, A FROM AND TO ADDRESS IS SELECTED FOR USE IN THE SCOPE MODE LOOP. ENTER THE CHOSEN ADDRESSES INTO PROPER LOCATIONS (SEE SECTION 4.3.B). RESTART THE PROGRAM WITH SR2 AND SR3 SET. AFTER ALLOWING IT TO RUN FOR A MOMENT PUSH HALT, ENTER (3520) INTO LOCATION 1, AND RESTART THE PROGRAM AT LOCATION 0027 WITH SR2 AND SR3 SET. THE SCOPE MODE LOOP IS

LOCATION	CODING
0000	
0001	JMP 1 FROM 1
XXXX	A, ION
XXXX	JMP 1 TO
0120	FROM 1, A

WHEN IT IS DESIRED TO DISCONTINUE THE SCOPE MODE LOOP, RESTORE THE ORIGINAL CONTENT 1116 INTO LOCATION 1, AND RESTART THE PROGRAM.

7.

RESTRICTIONS

(NONE)

8. MISCELLANEOUS

8.1 EXECUTION TIME

7200 RANDOM TEST/SECOND

9. PROGRAM DESCRIPTION

THE JMP INSTRUCTION IS CHECKED THROUGH THE USE OF THE INTERRUPT FUNCTION. A RANDOM NUMBER GENERATOR SELECTS A FROM AND A TO ADDRESS. AN ION INSTRUCTION IS THEN PLACED AT FROM-1 AND THE JMP INSTRUCTION AT FROM. THE JMP INSTRUCTION JUMPS TO THE ADDRESS SPECIFIED BY TO. AFTER EXECUTING THESE TWO ORDERS, AN INTERRUPT OCCURS STARTING THE PROGRAM COUNTER AT LOCATION 1. A CHECKING ROUTINE LOCATED HERE VERIFIES THAT THE OPERATION WAS SUCCESSFUL BEFORE STARTING THE NEXT TEST.

RANDOM ADDRESSES ARE RESTRICTED AS FOLLOWS: 0400<RANDOM ADDRESS <7600. THE AREA BETWEEN 0400 AND 7600 IS FILLED WITH HLT INSTRUCTIONS IN CASE THE INTERRUPT FAILS. A "HB" IS PRINTED AFTER EACH GROUP OF 72,000 TESTS.

/RANDOM JMP TEST
/SR0(0)=HALT ON ERROR
/SR2(1)=CONSTANT FROM ADDRESS
/SR3(1)=CONSTANT TO ADDRESS

0000	0000	0	/FOR SCOPE MODE INSERT
0001	0001	JMP 1	/JMP I FROM1 (5520) INTO LOC. 1
0002	0002	2	
0003	0003	3	
0004	0004	0	
0005	0005	0	
0006	7640	SEA CLA	
0007	5534	JMP I AER	
0010	1115	TAD HALT	
0011	3517	DCA I FROM	
0012	1115	TAD HALT	
0013	3520	DCA I FROM1	
0014	3000	DCA 0	
0015	7001	IAC	
0016	1140	TAD CT	
0017	3140	DCA CT	
0020	1140	TAD CT	
0021	7640	SEA CLA	
0022	5027	JMP LOOP	
0023	5424	JMP I .+1	
0024	0316	SUP	
0025	1142	TAD M17	
0026	3141	DCA CT1	

ADVANCE COPY
This document subject to change
without notice.

/CHECK FOR CONSTANT FROM

0027	7604	LAS
0030	7004	RAL
0031	7006	RTL
0032	7630	SEL CLA
0033	5057	JMP LOOP1

/SELECT RANDOM FROM

0034	1121	GETRAN, TAD RANUM
0035	7104	RAL CLL
0036	7430	SEL
0037	1122	TAD THREE
0040	3121	DCA RANUM
0041	7100	CLL
0042	1121	TAD RANUM
0043	1124	TAD LIMHI
0044	7630	SEL CLA
0045	9034	JMP GETRAN
0046	1121	TAD RANUM
0047	1123	TAD LIMLO
0050	7620	SNL CLA
0051	5034	JMP GETRAN

0052 1121
0053 3117
0054 7040
0055 1117
0056 3120

TAD RANUM
DCA FROM
CMA
TAD FROM
DCA FROM1

/CHECK FOR CONSTANT TO ADDRESS

0057 7004
0060 7006
0061 7006
0062 7630
0063 8104

LOOP1, LAS
RTL
RTL
SEL CLA
JMP JPLP

/SELECT RANDOM TO ADDRESS

0064 1121
0065 7104
0066 7430
0067 1122
0070 3121
0071 7100
0072 1121
0073 1124
0074 7630
0075 8064
0076 1121
0077 1123
0100 7620
0101 8064
0102 1121
0103 3116

GTRAN1, TAD RANUM
RAL CLL
SEL
TAD THREE
DCA RANUM
CLL
TAD RANUM
TAD LIMHI
SEL CLA
JMP GTRAN1
TAD RANUM
TAD LIMLO
SNL CLA
JMP GTRAN1
TAD RANUM
DCA TO

/PLACE INSTRUCTIONS

0104 1125
0105 3517
0106 1126
0107 3520

JPLP, TAD JMP1
DCA I FROM
TAD ITON
DCA I FROM1

/RAISE FLAG

0110 8041
0111 8046
0112 8041
0113 5112

TSP
TLS
TSP
JMP -1

/DO IT

0114 5520
0115 7402

HALT, HLT
JMP I FROM1
/JUMP FAILED

/CONSTANTS, VARIABLES, AND SUCH

/SPREAD HALTS THROUGH MEMORY

0200	5770	JMP I PATCH	/TAD LIMLO
0201	7041	CIA TO	
0202	3116	DCA TO	
0203	1115	TAD HALT	
0204	3516	DCA I TO	
0205	1116	TAD TO	
0206	7001	IAC	
0207	3116	DCA TO	
0210	1116	TAD TO	
0211	1124	TAD LIMHI	
0212	7640	SZA CLA	
0213	5203	JMP GON	
0214	1367	TAD M15	
0215	3141	DCA CT1	
0216	3140	DCA CT	
0217	5027	JMP LOOP	

/ERROR ROUTINES
ER,

0220	1117	TAD FROM
0221	4341	JMS SLOC
0222	3150	DCA INS1
0223	1131	TAD SAVE
0224	0130	AND MSK7
0225	1127	TAD TW6
0226	3151	DCA INS2
0227	1132	TAD SAVE+1
0230	0130	AND MSK7
0231	1127	TAD TW6
0232	3152	DCA INS3
0233	1133	TAD SAVE+2
0234	0130	AND MSK7
0235	1127	TAD TW6
0236	3153	DCA INS4
0237	1116	TAD TO
0240	4341	JMS SLOC
0241	3157	DCA INS5
0242	1131	TAD SAVE
0243	0130	AND MSK7
0244	1127	TAD TW6
0245	3160	DCA INS6
0246	1132	TAD SAVE+1
0247	0130	AND MSK7
0250	1127	TAD TW6
0251	3161	DCA INS7
0252	1133	TAD SAVE+2
0253	0130	AND MSK7
0254	1127	TAD TW6
0255	3162	DCA INS8
0256	1000	TAD 0
0257	4341	JMS SLOC
0260	3172	DCA INS9

0261 1131 TAD SAVE
0262 0130 AND MSK7
0263 1127 TAD TW6
0264 1173 DCA INS10
0265 1132 TAD SAVE+1
0266 0130 AND MSK7
0267 1127 TAD TW6
0270 1174 DCA INS11
0271 1133 TAD SAVE+2
0272 0130 AND MSK7
0273 1127 TAD TW6
0274 1175 DCA INS12

/PRINT ERROR MESSAGE

0275 1137 TAD MSGC1
0276 1135 DCA WORK
0277 1135 TAD I WORK
0278 0046 TLS
0281 0041 TSF
0282 0001 JMP -1
0283 7201 CLA IAC
0284 1135 TAD WORK
0285 1135 DCA WORK
0286 1135 TAD I WORK
0287 1136 TAD M207
0288 0000 SEA CLA
0289 0277 JMP LP
0290 7604 LAS
0291 7700 SMA CLA
0292 7402 HLT
0293 0010 JMP 10

/HALT ON ERROR

SUP.

0316 1141 TAD CT1
0317 7001 IAC
0320 1141 DCA CT1
0321 1141 TAD CT1
0322 7640 SEA CLA
0323 0027 JMP LOOP

LP1.

0324 1361 TAD MSG2
0325 1135 DCA WORK
0326 1135 TAD WORK
0327 7001 IAC
0328 1135 DCA WORK
0331 1535 TAD I WORK
0332 0046 TLS
0333 0041 TSF
0334 1333 JMP -1
0335 1366 TAD M302
0336 7640 SEA CLA
0337 1326 JMP LP1
0340 0025 JMP LOOP-2

SLOC.

0341 0000 0

PAL10 VI41

0342 0343 0344 0345 0346 0347 0350 0351 0352 0353 0354 0355 0356 0357 0360
 DCA SAVE+2
 TAD SAVE+2
 RTR
 RAR
 DCA SAVE+1
 TAD SAVE+1
 RTR
 RAR
 DCA SAVE
 TAD SAVE
 RTR
 RAR
 AND MSK7
 TAD TW6
 JMP I SLOC

0361 0362 0363 0364 0365 0366 0367 0370
 AMS02,
 215 /CR
 212 /LF
 310 /H
 302 /B
 -302
 -15
 M302,
 M15,
 PATCH,
 XPATCH

0400 0401 0402 0403 0404 0405 0406 0407 0410 0411 0412 0413 0414 0415 0416 0417 0420 0421
 XPATCH,
 DCA 0
 TAD X1
 DCA 1
 TAD X2
 DCA 2
 TAD X3
 DCA 3
 TAD X4
 DCA I X5
 CLA CLL
 DCA 4
 DCA 5
 JMP I X5
 1116
 CIA
 1000
 TAD LIMLO
 200
 /RESTORE 0.1.2.3 AND GO
 /AWAY
 /TAD TO
 /TAD 0

S

4000
4100

4200
4300

4400
4500

4600
4700

5000
5100

5200
5300

5400
5500

5600
5700

6000
6100

6200
6300

6400
6500

6600
6700

7000
7100

7200
7300

7400
7500

7600
7700

X5 0421
XPATCH 0400

/RANDOM IMP TEST

AMSG1	0134
AMSG2	0137
CT	0361
CT1	0140
ER	0141
FROM	0220
FROM1	0117
GETRAN	0120
GON	0034
GTRAN1	0203
HALT	0064
INS1	0115
INS10	0150
INS11	0173
INS12	0174
INS2	0175
INS3	0151
INS4	0152
INS5	0153
INS6	0157
INS7	0160
INS8	0161
INS9	0162
ITON	0172
JMP1	0126
JPLP	0125
LIMHI	0104
LIMLO	0124
LOOP	0123
LOOP1	0027
LP	0057
LP1	0277
M15	0326
M17	0367
M207	0142
M302	0136
MSG1	0366
MSG7	0143
PATCH	0130
RANUM	0370
SAVE	0121
SLOC	0131
SUP	0341
THREE	0316
TO	0122
TW6	0116
WORK	0127
X1	0135
X2	0415
X3	0416
X4	0417
	0420

