

PRODUCT CODE: MAINDEB-8E-D0LA-D-(D)  
PRODUCT TEST: KE-8E (EAE) INSTRUCTION TEST 1  
DATE CREATED: JULY 15, 1971  
MAINTAINER: DIAGNOSTIC GROUP  
AUTHOR: ED FORTMILLER

1. ABSTRACT

THIS PROGRAM IS A TEST OF ALL THE KE-8E ZAE INSTRUCTIONS,  
(EXCEPT MULTIPLY AND DIVIDE).

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-8/E PROCESSOR, KE-8E OPTION, AND A TELETYPE ARE REQUIRED.

2.2 STORAGE

LOCATIONS 0000 THROUGH 7600 ARE USED.

2.3 PRELIMINARY PROGRAMS

ALL PROCESSOR RELATED TEST PROGRAMS MUST HAVE BEEN RUN  
SUCCESSFULLY.

3. LOADING PROCEDURE

3.1 METHOD

THE BINARY LOADER IS USED TO LOAD THE PROGRAM INTO ANY DE-  
SIRED FIELD. REFER TO THE BINARY LOADER DOCUMENTATION IF  
UNFAMILIAR WITH ITS USE.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTING

CONTROL SWITCH SETTINGS DO NOT APPLY TO STEP COUNTER, GT, MODE,  
AND COMBINED TESTS. AN ERROR WILL BE INDICATED BY A PROGRAM HALT.

SR0=1 HALT ON ERROR

SR1=1 SCOPE MODE (REPEAT PATTERN AND/OR TEST)

SR2=1 PRINT ERROR INFORMATION

SR3=1 DO NOT EXIT CURRENT TEST.

SR10=11	SR10	SR11	
	0	0	EXECUTE TEST IN "A" AND "B" MODES.
	0	1	EXECUTE TEST IN "A" AND "B" MODES.
	1	0	SELECT "A" MODE.
	1	1	SELECT "B" MODE.

4.2 STARTING ADDRESS  
-----

THIS PROGRAM STARTS AT LOCATION 0200.

4.3 PROGRAM AND/OR OPERATOR ACTION  
-----

WITH THE PROGRAM LOADED IN CORE PROCEED AS FOLLOWS:

- A. INSURE TELETYPE IS ON-LINE.
- B. LOAD ADDRESS 0200.
- C. SET ANY DESIRED OPTIONS IN THE SR.
- D. PRESS CLEAR AND CONTINUE.

NOTE:

FOR A NORMAL PROGRAM RUN, SET SR SWITCHES TO 5000.  
PROGRAM WILL RUN CONTINUOUSLY EXECUTING THE TEST IN WAH  
AND "B" MODES UNLESS AN ERROR IS DETECTED AT WHICH TIME  
THE ERROR INFORMATION WOULD BE PRINTED OUT AND THEN  
THE PROGRAM WILL HALT.

5. ERRORS  
-----

5.1 PROGRAM AND/OR OPERATOR ACTION:  
-----

THE PURPOSE OF THIS PROGRAM IS TO DETECT OPERATION ERRORS  
IN THE KE-8 HARDWARE. UPON DETECTION OF AN ERROR, THE  
PROGRAM EITHER HALTS, OR GIVES AN ERROR PRINTOUT DE-  
PENDING ON THE SETTING OF SR 0 AND 2.

LOC 0240	MQL FAILED TO CLEAR THE AC OR THE LINK WAS CLEARED.
LOC 0447	MQL FAILED TO CLEAR THE AC OR THE LINK WAS SET.
LOC 0562	MQL FAILED TO LOAD THE MQ OR MQA FAILED TO LOAD THE AC.
LOC 0727	MQL FAILED TO LOAD THE MQ OR MQA FAILED TO LOAD THE AC.
LOC 1054	MQA FAILED TO "INCLUSIVE OR" THE MQ WITH THE AC.
LOC 1222	MQA FAILED TO "INCLUSIVE OR" THE MQ WITH THE AC.
LOC 1301	SAM INSTRUCTION FAILED.
LOC 1434	SAM INSTRUCTION FAILED.
LOC 1522	SHL INSTRUCTION FAILED.
LOC 1635	SHL INSTRUCTION FAILED.
LOC 1725	LSR INSTRUCTION FAILED.
LOC 2035	LSR INSTRUCTION FAILED.
LOC 2125	ASR INSTRUCTION FAILED.
LOC 2235	ASR INSTRUCTION FAILED.
LOC 2516	DPSZ INSTRUCTION FAILED.
LOC 2637	OPIC INSTRUCTION FAILED.

LOC 2705	DPIC IN
LOC 3034	DCM INSTRUCTION FAILED;
LOC 3147	DAD INSTRUCTION FAILED;
LOC 3300	DAD INSTRUCTION FAILED;
LOC 3434	DST INSTRUCTION FAILED;
LOC 3536	DST INSTRUCTION FAILED;
LOC 3653	NORMALIZE INSTRUCTION FAILED;
LOC 4336	NORMALIZE INSTRUCTION FAILED;
LOC 4520	NORMALIZE INSTRUCTION FAILED;
LOC 4605	EAE NOP SKIPPED;
LOC 4610	EAE NOP MODIFIED THE AC;
LOC 4614	EAE NOP MODIFIED THE MQ;
LOC 4622	EAE CLA SKIPPED;
LOC 4624	EAE CLĀ FAILED TO CLEAR THE AC;
LOC 4630	EAE CLĀ MODIFIED THE MQ;
LOC 4637	AC OR MQ NOT CLEARED BY CAM;
LOC 4650	SWP FAILED;
LOC 4655	SWP FAILED;
LOC 4666	ACL FAILED;
LOC 4704	OLD (CAM DAD) FAILED;
LOC 4711	OLD (CAM DAD) FAILED;
LOC 4732	DDE (CAM DST) FAILED;
4735	
4740	
LOC 5003	CLEAR KEY FAILED TO SET "MODE A" OR SKB FAILED;
LOC 5006	SWAB FAILED TO SET "MODE B" OR SKB FAILED;
LOC 5012	SWBA FAILED TO SET "MODE A";
LOC 5017	CAF FAILED TO SET "MODE A";

LI 025 SCL OR SCA ERROR,  
5034  
5043  
5052  
5061  
5070  
5077  
5106  
5113  
5122  
5131  
5141  
5151

LOC 5157 ACS INSTRUCTION FAILED  
5164  
5172  
5175

LOC 5207 RTP INSTRUCTION FAILED TO SET GT FLAG TO 0 OR  
GTF FAILED TO GET IT,

LOC 5217 RTP INSTRUCTION FAILED TO SET GT FLAG TO 1 OR  
GTF FAILED TO GET IT,

LOC 5225 SGT SKIPPED WITH GT FLAG NOT SET,

LOC 5232 SGT FAILED TO SKIP WITH GT FLAG SET,

LOC 5241 SHBA FAILED TO CLEAR THE GT FLAG,

5.3 ERROR PRINTOUTS

-----

5.3.1 MQL TESTS

-----

MQLT MODE A (OR B)

AC 1 000000000011

0-AC 1 000000000001

MQLI MQL INSTRUCTION TEST WITH LINK SET TO A 1,  
AC THE ORIGINAL C(AC) AND C(L),  
0-AC C(AC) AND C(L) AFTER THE MQL INSTRUCTION WAS  
EXECUTED,  
NOTE THAT BIT 11 OF AC SHOULD EQUAL 0.

MQLT1 MODE A (OR B)

AC 0 000000000001

0-AC 0 000000000001

MQLI MQL INSTRUCTION TEST WITH LINK SET TO A 0,  
AC THE ORIGINAL C(AC) AND C(L),  
0-AC C(AC) AND C(L) AFTER THE MQL INSTRUCTION  
WAS EXECUTED,  
NOTE THAT BIT 11 OF THE AC SHOULD EQUAL 0.

5.3.2 MQA TESTS

-----

MQAT MODE A (OR B)

AC 1 000000000001

MQL)1 000000000000

MQA)

MQAT MQA MQL INSTRUCTIONS TEST WITH THE LINK SET  
TO A 1,  
AC THE ORIGINAL C(AC) AND C(L),  
MQL MQA THE C(AC) AND C(L) AFTER THE EXECUTION OF  
AN MQL INSTRUCTION FOLLOWED BY AN MQA IN-  
STRUCTION, NOTE THAT BIT 11 OF THE AC SHOULD  
BE A 1.

MQAT1 MODE A (OR B)

AC 0 100000000000

MQL) 0 011111111111

MQA)

MQL, MQA INSTRUCTION TEST WITH THE LINK SET TO  
 AL THE ORIGINAL C(AC) AND C(L).  
 MQL, MQA THE C(AC) AND C(L) AFTER THE EXECUTION OF AN MQL  
 INSTRUCTION FOLLOWED BY AN MQA INSTRUCTION.  
 NOTE THAT THE C(AC) SHOULD BE 4000.

MQAT2 MODE A (OR B)

AC 1 11111111110  
 MQ 000000000001  
 MQVAC 1 000000000000

MQAT2 MQA INSTRUCTION TEST;  
 AC ORIGINAL C(AC) AND C(L).  
 MQ ORIGINAL C(MQ).  
 MQVAC THE C(AC) AND C(L) AFTER THE EXECUTION OF AN MQA  
 INSTRUCTION.  
 NOTE THAT THE C(AC) SHOULD BE 7777.

MQAT3 MODE A (OR B)

AC 0 11111111110  
 MQ 000000000001  
 MQVAC 0 000000000000

MQAT3 MQA INSTRUCTION TEST;  
 AC ORIGINAL C(L) AND C(AC).  
 MQ ORIGINAL C(MQ).  
 MQVAC THE C(AC) AND THE C(L) AFTER THE EXECUTION  
 OF AN MQA INSTRUCTION.  
 NOTE THAT THE C(AC) SHOULD BE 7777.

5.3.3 SAM TESTS

\*\*\*\*\*

SAM TEST 0 (OR 1) MODE B

	C(L)	C(AC)	C(MQ)	C(GT)	C(SC)
PROBLEM	1	000000111111	000001000000	0	000000000000
SIMULATED	0	000000000001	000001000000	1	000000000000
ACTUAL	0	000000000000	000001000000	1	000000000000

PROBLEM THE CONTENTS OF THE REGISTERS PRIOR TO ISSUING  
 A SAM INSTRUCTION;  
 SIMULATED WHAT THE RESULTS SHOULD BE;  
 ACTUAL WHAT THE RESULTS WERE FROM THE EXECUTION OF  
 A SAM INSTRUCTION;  
 NOTE THAT AC SHOULD BE 0001 IN THE "ACTUAL".

5.3.4 SHL TESTS

SHL TEST 0 (OR 1) 0003 SHIFTS MODE A (OR B)

	C(L)	C(AC)	C(MQ)	C(GT)	C(SC)
PROBLEM	1	000100100001	000100000001	0	000000000010
SIMULATED	0	100100001000	100000001000	0	000000000000
ACTUAL	0	100100000000	100000001000	0	000000000000

PROBLEM THE CONTENTS OF THE REGISTERS PRIOR TO ISSUING AN SHL INSTRUCTION, THE NUMBER CONTAINED IN C(SC) IS THE CONTENTS OF THE ADDRESS FOLLOWING THE SHL INSTRUCTION,

SIMULATED WHAT THE RESULTS SHOULD BE,  
 ACTUAL WHAT THE RESULTS WERE FROM THE EXECUTION OF AN SHL INSTRUCTION,

5.3.5 LSR TESTS

LSR TEST 1 (OR 0) 0004 SHIFTS MODE B (OR A)

	C(L)	C(AC)	C(MQ)	C(GT)	C(SC)
PROBLEM	1	000000111111	000000001111	0	000000001100
SIMULATED	0	000000000011	111100000000	1	000000011111
ACTUAL	0	000000000011	111100000000	0	000000011111

PROBLEM THE CONTENTS OF THE REGISTERS PRIOR TO ISSUING AN LSR INSTRUCTION, THE NUMBER CONTAINED IN C(SC) IS THE CONTENTS OF THE ADDRESS FOLLOWING THE LSR INSTRUCTION,

SIMULATED WHAT THE RESULTS SHOULD BE,  
 ACTUAL WHAT THE RESULTS WERE FROM THE EXECUTION OF AN LSR INSTRUCTION,  
 NOTE THAT THE C(GT) SHOULD BE 1 IN THE "ACTUAL".

5.3.6 ASR TESTS  
-----

ASR TEST 0 (OR 1) 0002 SHIFTS MODE B (OR A)

	C(L)	C(AC)	C(MQ)	C(GT)	C(SC)
PROBLEM	0	000000000110	000000100001	1	000000000010
SIMULATED	1	110000000001	100000001000	0	000000011111
ACTUAL	1	110000000001	000000001000	0	000000011111

PROBLEM THE CONTENTS OF THE REGISTERS PRIOR TO ISSUING AN ASR INSTRUCTION, THE NUMBER CONTAINED IN C(SC) IS THE CONTENTS OF THE ADDRESS FOLLOWING THE ASR INSTRUCTION.  
SIMULATED WHAT THE RESULTS SHOULD BE,  
ACTUAL WHAT THE RESULTS WERE FROM THE EXECUTION OF AN ASR INSTRUCTION.  
NOTE THAT THE C(MQ) SHOULD BE 4010 IN THE "ACTUAL".

5.3.7 DPSZ TESTS  
-----

DPSZ TEST 0 MODE B

NO SKIP OCCURRED

	C(L)	C(AC)	C(MQ)	C(GT)	C(SC)
PROBLEM	0	000000000000	000000000000	0	000000000000
SIMULATED	0	000000000000	000000000000	0	000000000000
ACTUAL	0	000000000000	000000000000	0	000000000000

PROBLEM THE CONTENTS OF THE REGISTERS PRIOR TO ISSUING A DPSZ INSTRUCTION,  
SIMULATED WHAT THE REGISTERS SHOULD BE AFTER ISSUING THE DPSZ INSTRUCTION,  
ACTUAL WHAT THE REGISTERS WERE AFTER ISSUING THE DPSZ INSTRUCTION,  
NOTE WITH AC ANC MQ BOTH ZERO A SKIP FAILED TO OCCUR.

DPSZ TEST 0 MODE B

SKIP OCCURRED

	C(L)	C(AC)	C(MQ)	C(GT)	C(SC)
PROBLEM	0	000000000000	000000000001	0	000000000000
SIMULATED	0	000000000000	000000000000	0	000000000000
ACTUAL	0	000000000000	000000000000	0	000000000000

PROBLEM THE CONTENTS OF THE REGISTER PRIOR TO ISSUING A DPSZ INSTRUCTION,  
SIMULATED WHAT THE REGISTERS SHOULD BE AFTER ISSUING THE DPSZ INSTRUCTION,  
ACTUAL WHAT THE REGISTERS WERE AFTER ISSUING THE DPSZ INSTRUCTION,  
NOTE WITH MQ NON ZERO A SKIP OCCURRED.

DPSZ TEST 0 MODE B

REG MODIFIED

	C(L)	C(AC)	C(MQ)	C(GT)	C(SC)
PROBLEM 0		000000000001	000000000000	0	000000000000
SIMULATED 0		000000000001	000000000000	0	000000000000
ACTUAL 0		000000000000	000000000000	0	000000000000

PROBLEM THE CONTENTS OF THE REGISTERS PRIOR TO ISSUING A  
 DPSZ INSTRUCTION,  
 SIMULATED WHAT THE REGISTERS SHOULD BE AFTER ISSUING THE  
 DPSZ INSTRUCTION,  
 ACTUAL WHAT THE REGISTERS WERE AFTER ISSUING THE DPSZ  
 INSTRUCTION,  
 NOTE THAT THE C(AC) SHOULD BE 0001 IN THE "ACTUAL".

5.3.8 DPIC TESTS

DPIC TEST 0 (OR 1) MODE B

	C(L)	C(AC)	C(MQ)	C(GT)	C(SC)
PROBLEM 1		000000000000	000000000000	0	000000000000
SIMULATED 0		000000000000	000000000001	0	000000000000
ACTUAL 0		000000000000	000000000000	0	000000000000

PROBLEM THE CONTENTS OF THE REGISTERS PRIOR TO ISSUING A  
 DPIC INSTRUCTION,  
 SIMULATED WHAT THE REGISTERS SHOULD BE AFTER THE ISSUING  
 OF A DPIC INSTRUCTION,  
 ACTUAL WHAT THE REGISTERS WERE AFTER ISSUING THE DPIC  
 INSTRUCTION,  
 NOTE THAT THE C(AC) SHOULD BE 0001 IN THE "ACTUAL".

5.3.9 DCM TESTS

DCM TEST 0 (OR 1) MODE B

	C(L)	C(AC)	C(MQ)	C(GT)	C(SC)
PROBLEM 1		000000000000	000000000001	0	000000000000
SIMULATED 0		111111111111	111111111111	0	000000000000
ACTUAL 0		111111111111	111111111110	0	000000000000

PROBLEM THE CONTENTS OF THE REGISTERS PRIOR TO ISSUING A  
 DCM INSTRUCTION,  
 SIMULATED WHAT THE REGISTERS SHOULD BE AFTER THE ISSUING OF  
 A DCM INSTRUCTION,  
 ACTUAL WHAT THE REGISTERS WERE AFTER ISSUING THE DCM  
 INSTRUCTION,  
 NOTE THAT THE C(MQ) SHOULD BE 7777.

5.3.10 DA STS  
-----

DAD TEST 0 (OR 1) MODE B

	C(L)	C(AC)	C(MQ)	C(GT)	C(SC)
PROBLEM 0		000000011111	000011110101	0	000000000000
TO BE ADDED		111111000000	111100001010		
SIMULATED 0		111111111111	111111111111	0	000000000000
ACTUAL 0		111111111111	111111111110	0	000000000000

PROBLEM THE CONTENTS OF THE REGISTERS PRIOR TO ISSUING A DAD INSTRUCTION,  
 TO BE ADDED THE CONTENTS OF THE TWO ADDRESS TO BE ADDED TO THE AC AND MQ,  
 SIMULATED WHAT THE REGISTERS SHOULD BE AFTER THE ISSUING THE DAD INSTRUCTION,  
 ACTUAL WHAT THE REGISTERS WERE AFTER ISSUING THE DAD INSTRUCTION,  
 NOTE THAT C(MQ) SHOULD BE 9777 IN THE ACTUAL.

5.3.11 DST TESTS  
-----

DST TEST 0 (OR 1) MODE B

REG	BEFORE DST	AFTER DST
C(L)	1	1
C(AC)	111111111111	111111111111
C(MSH)		000000000000
C(MQ)	111110111110	111101111110
C(LSH)		111101111110

BEFORE DST THE CONTENTS OF THE REGISTERS BEFORE ISSUING A DST INSTRUCTION,  
 AFTER DST WHAT THE REGISTERS WERE AFTER ISSUING THE DST INSTRUCTION,  
 MSH IS WHAT DST STORED FOR THE AC,  
 LSH IS WHAT DST STORED FOR THE MQ,  
 NOTE THAT THE C(MSH) SHOULD BE 7777.

5.3.12 NORMALIZE TESTS  
-----

NMIT	C(AC)	C(MQ)	MODE A (OR B)
	000000000000	010101010101	
NMI	010101010100	000000000000	
SCAT	000000001100		
SCA	000000001100		

NMIT NORMALIZE AND STEP COUNTER TEST, ORIGINAL C(AC) AND C(MQ).

NMI C(AC) AND C(MQ) AFTER THE NMI INSTRUCTION WAS EXECUTED,  
 SCAT THE CORRECT COUNT OF THE STEP COUNTER AFTER THE NORMALIZE INSTRUCTION WAS EXECUTED,  
 SCA THE ACTUAL COUNT IN THE STEP COUNTER AS READ INTO THE AC BY THE SCA INSTRUCTION AFTER THE NORMALIZE INSTRUCTION WAS EXECUTED.  
 NOTE THAT BIT 11 OF AC IN ERROR, C(AC) SHOULD EQUAL 2925.

5.4 TABLE OF INSTRUCTIONS  
 -----

THE FOLLOWING TABLE CONTAINS THE TEST MNEMONIC, STARTING ADDRESS, ERROR HALT ADDRESS AND INSTRUCTION TESTED.

MNEMONIC -----	INSTRUCTIONS -----	STARTING ADDRESS -----	ERROR HALT -----
MQLT	MQL	0203	0240
MQLT1	MQL	0400	0447
MQAT	MQL, MQA	0503	0502
MQAT1	MQL, MQA	0650	0727
MQAT2	MQA	1000	1054
MQAT3	MQA	1135	1222
SAMTS0	SAM	1245	1301
SAMTS1	SAM	1336	1434
SHLTS0	SHL	1450	1522
SHLTS1	SHL	1600	1635
LSRTS0	LSR	1692	1725
LSRTS1	LSR	2000	2035
ASRTS0	ASR	2052	2125
ASRTS1	ASR	2200	2235
DPSES0	DPSE	2292	2516
DPITS0	DPIC	2600	2637
DPITS1	DPIC	2653	2705
DCMTS0	DCM	2721	3034
DADTS0	DAD	3050	3147
DADTS1	DAD	3200	3300
DSTTS0	DST	3314	3434
DSTTS1	DST	3450	3536
NORMT	NMI, SCA	3600	3653
NORMT1	NMI, SCA	4200	4336
NORMT2	NMI	4400	4520
COMTST	NOP, CLA, ACL	4600	4605-4740
	DLD, DDE		
MDTST	SKB, SWAB, SWBA	0200	5003-5017
TSCL	SCL, ACS	0200	5025-5175
GTTST	GTF, RTP, SGT	0200	5207-5241

6.

DESCRIPTION  
-----

THE KEB EAE INSTRUCTION TEST 1, TESTS THE FOLLOWING EXTENDED ARITHMETIC ELEMENT INSTRUCTIONS:

MQL, MOA, SHL, LSR, ASR, DPSZ, DPIC, DCM, DAD,  
DST, NMI, SKB, SWAB, SWBA, SGT, RTF, AND GTF,

THE EXTENDED ARITHMETIC ELEMENT IS TESTED USING PATTERNS NECESSARY TO DETECT AND ISOLATE ERRORS; IF A FAILURE DOES OCCUR, THE TEST WILL PRINTOUT THE ERROR INFORMATION AND/OR HALT AT A PREDETERMINED ERROR HALT ACCORDING TO THE SR SETTING.

7.

EXECUTION TIME  
-----

ONE COMPLETE PROGRAM PASS TAKES APPROXIMATELY 6.5 MINUTES AND AT THE END OF EACH PASS "KEB 1" WILL BE PRINTED OUT ON THE TELETYPE.

7K8B EAE INSTRUCTION TEST PART 1 MAINDEC-8E-00LA  
 7COPYRIGHT 1971, DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS. 01954

## /SWITCH REGISTER OPTIONS:

/SR0=1 HALT ON ERROR  
 /SR1=1 SCOPE MODE (REPEAT PATTERN AND/OR TEST)  
 /SR2=1 PRINT ERROR INFORMATION  
 /SR3=1 DO NOT EXIT CURRENT TEST

/SR10=1	SR10	SR11	
/ 0	0	0	EXECUTE TEST IN "A" AND "B" MODES
/ 0	0	1	EXECUTE TEST IN "A" AND "B" MODES
/ 1	1	0	SELECT "A" MODE
/ 1	1	1	SELECT "B" MODE

7421	MOQ=7421	/LOAD MQ.
7501	MQA=7501	/INCLUSIVE OR MQ WITH AC.
7401	NOPM=7401	/EAE NOP.
7601	CLAM=7601	/EAE CLA.
7411	NMI=7411	/NORMALIZE
7413	SHL=7413	/SHIFT LEFT
7415	ASR=7415	/ARITHMETIC SHIFT RIGHT
7417	LSR=7417	/LOGICAL SHIFT RIGHT
7521	SWP=7521	/SWAP AC AND MQ.
7621	CAM=7621	/CLEAR AC AND MQ.
7701	ACL=CLAM MGA	/LOAD AC FROM MQ.
7441	SCA=7441	/STEP COUNTER TO AC.
7431	SWAB=7431	/SWITCH FROM MODE "A" TO "B".
7447	SWBA=7447	/SWITCH FROM MODE "B" TO "A".
7671	SKB=7671	/SKIP IF MODE "B".
7403	SCL=7403	/STEP COUNTER LOAD FROM MEMORY.
7403	ACS=7403	/ACCUMULATOR TO STEP COUNTER.
7457	SAM=7457	/SUBTRACT AC FROM MQ.
7443	DAD=7443	/DOUBLE PRECISION ADD.
7445	DST=7445	/DOUBLE PRECISION STORE.
7573	DPIC=7573	/DOUBLE PRECISION INCREMENT.
7575	DCM=7575	/DOUBLE PRECISION COMPLEMENT.
7451	DPSZ=7451	/DOUBLE PRECISION SKIP IF ZERO.
7663	DLD=DAD CAM	/DOUBLE PRECISION LOAD.
7665	DDZ=DST CAM	/DOUBLE PRECISION DEPOSIT ZERO.
6001	ION=6001	/TURN THE INTERRUPT ON.
6002	IOF=6002	/TURN THE INTERRUPT OFF.
6004	GTF=6004	/GET THE INTERRUPT FLAGS.
6005	RTF=6005	/RESTORE THE INTERRUPT FLAGS.
6006	SGT=6006	/SKIP ON GREATER THAN FLAG.
6007	CAF=6007	/CLEAR THE WORLD.
6214	RDF=6214	/READ THE DATA FIELD.
6224	RIF=6224	/READ THE INSTRUCTION FIELD.
7002	BSW=7002	/SWAP BYTES IN AC.
7400	NOP=7400	/GROUP 2 NOP.
7402	HLT=7402	/HALT.

```

0000 OPEN=0000 /PROGRAM MODIFIABLE.
0000 *0
0000 0000 0
0001 5001 JMP 1
0002 0002 2
0003 0003 3
0020 *0020

/THESE STORAGE LOCATIONS FROM "TOLINK THROUGH "ADDR" MUST
/REMAIN IN THE ORDER SHOWN.

0020 0000 TOLINK, OPEN
0021 0000 TOAC, OPEN
0022 0000 TOMQ, OPEN
0023 0000 TOSHIF, OPEN
0024 0000 TOGT, OPEN
0025 0000 TLINK, OPEN
0026 0000 TAC, OPEN
0027 0000 TMQ, OPEN
0030 0000 TSHIF, OPEN
0031 0000 TGT, OPEN
0032 0000 LKTOCK, OPEN
0033 0000 ACTOCK, OPEN
0034 0000 MQTOCK, OPEN
0035 0000 SCTOCK, OPEN
0036 0000 GTOCK, OPEN
0037 0000 TEMP A, OPEN
0040 0000 TEMP B, OPEN
0041 0000 LSH, OPEN
0042 0000 MSH, OPEN
0043 0000 LSH, OPEN
0044 0000 SCSIM, OPEN
0045 0000 GTSIM, OPEN
0046 0000 ADDR, OPEN

0047 6600 XTYPST, TYPST
0050 6670 UPSPC, PSPC
0051 6334 UCOMP, COMP
0052 6400 UMOVE, MOVE
0053 6723 U1SPC, SPACE1
0054 6727 U2SPC, SPACE2

0055 0000 BACK, 0000
0056 0000 NEXT, 0000
0057 0400 XMQLT1, MQLT1
0060 0503 XMQAT, MQAT
0061 0650 XMQAT1, MQAT1

```

0062	0000	ACP,	0	/GOOD AC
0063	0000	LXP,	0	/GOOD LINK
0064	0000	GENX,	0	
0065	0000	BLXP,	0	/BAD LINK
0066	0000	BACP,	0	/BAD AC
0067	0215	CR,	0215	/CARRIAGE RETURN
0070	0212	LF,	0212	/LINE FEED
0071	0315	M,	0315	/M
0072	0321	Q,	0321	/Q
0073	0314	LL,	0314	/L
0074	0324	TT,	0324	/T
0075	0301	A,	0301	/A
0076	0303	C,	0303	/C
0077	0261	ONE,	0261	/1
0100	0260	ZERO,	0260	/0
0101	0000	LINK,	0	
0102	0255	TO,	0255	/DASH
0103	7763	COUNTX,	7763	
0104	0000	STRCNT,	0	
0105	0000	BITSTR,	0	
0106	1000	XMGAT2,	MGAT2	
0107	1135	XMGAT3,	MGAT3	
0110	0326	INCOR,	0326	/V
0111	0263	THREE,	0263	/3
0112	0262	TWO,	0262	
0113	0000	SCOUNT,	OPEN	
0114	0000	MODE,	OPEN	
0115	0000	ANYUSE,	OPEN	/GENERAL USE,
0116	0000	COUNT,	OPEN	

0117	7740	K7740,	7740	
0120	5611	CRLF,	UCRLF	
0121	5620	CRLF2,	UCRLF2	
0122	5624	PRXLOP,	RXLOP	
0123	5632	PLINK,	UPLINK	
0124	5650	ZEROR,	UZEROR	
0125	5655	MESSG,	UMESSG	
0126	5637	ONZER,	UONZER	
0127	5644	ONEP,	UONEP	
0130	5701	?Y?ST,	UTY?ST	
0131	5263	MOSEL,	MOSEL	
0132	5306	ONLYB,	UONLYB	
0133	7000	PREGS,	UPREGS	
0134	5473	ASCOMP,	SCOMP	
0135	5350	SAVREG,	USVREG	
0136	5600	UGEN,	GEN	
0137	5314	TSTSW0,	SW0TST	
0140	5322	TSTSW1,	SW1TST	
0141	5331	TSTSW2,	SW2TST	
0142	5340	TSTSW3,	SW3TST	
0143	7070	NUMSHF,	NUMSH	
0144	6525	RANDOM,	RANGEN	
0145	5743	LOREG,	ULOREG	

0146 5724 RNDATA, RANDAT  
 0147 5753 LDGT, UL0GT  
 0150 6000 RTPX, XRTF  
 0151 5720 P1BIT, UP1BIT  
 0152 5456 LDSC, UL0SC

0010 0000 \*0010  
 0010 0000 ACIND, 0  
 0011 0000 MQIND, 0  
 0012 0000 XACNMI, 0  
 0013 0000 XMQNMI, 0  
 0200 0200 \*0200

0200 7300 CLA CLL  
 0201 3114 DCA MODE /MODE MAN INITIALLY  
 0202 4577 JMS I ETSC /TEST MODE SWITCHING, 01, AND 0C.

/TEST THAT MQL WILL CLEAR THE AC AND LEAVE THE LINK SET TO 1.

0203 5246 MQLT, JMP HSE /HOUSE KEEPING  
 0204 4536 JMS I UGEN  
 0205 7360 STL CLA CHA /SET LINK  
 0206 0064 AND GENX  
 0207 3062 DCA ACP /STORE AC PATTERN  
 0210 7240 CLA CHA  
 0211 3063 DCA LXP /STORE LINK TO A ONE  
 0212 1062 TAD ACP /LOAD AC  
 0213 7421 MQL  
 0214 3066 DCA BACP /STORE AC RESULT  
 0215 7620 CLA SNL  
 0216 5347 JMP XPACP+5 /STORE LINK RESULT 0000  
 0217 7240 CLA CHA  
 0220 3065 DCA BLXP /STORE LINK RESULT 7777  
 0221 1066 TAD BACP  
 0222 7640 SZA CLA  
 0223 5230 JMP ,+5 /AC NOT EQUAL TO 0000  
 0224 1065 TAD BLXP  
 0225 7450 SNA  
 0226 5230 JMP ,+0 /LINK NOT EQUAL TO A ONE  
 0227 5241 JMP ,+12 /CONTINUE TEST MQLT  
  
 0230 7604 CLA OSR /TEST SW2  
 0231 7106 RTL CLL  
 0232 7004 RAL  
 0233 7430 SEL  
 0234 4256 JMS PMQLT /PRINT ERROR  
 0235 7704 CLL CLA OSR /TEST SW 0  
 0236 7004 RAL  
 0237 7430 SEL  
 0240 7402 HLT /HALT MQL ERROR  
 0241 7604 CLA OSR  
 0242 7106 RTL CLL /TEST SW1  
 0243 7430 SEL

0244	5205		JMP MQLT+2	/PROGRAM LOOP
0245	5204		JMP MQLT+1	/CONTINUE PROGRAM
0246	7300	HSE,	CLA CLL	
0247	3064		DCA GENX	
0250	1346		TAD XPACP+4	
0251	3055		DCA BACK	
0252	1057		TAD XMQLT1	
0253	3056		DCA NEXT	
0254	4531		JMS I MODSEL	/PERFORM MODE SELECTION;
0255	5204		JMP MQLT+1	
0256	0000	PMQLT,	0	/PRINT ROUTINE
0257	4521		JMS I CRLF2	/CR AND LF;
0260	4304		JMS MQ	
0261	4313		JMS L	
0262	4320		JMS T	
0263	4576	CP,	JMS I CTYMOD	/TYPE THE MODE;
0264	4520		JMS I CRLF	/ CR AND LF;
0265	4454		JMS I U2SPC	/2 SPACES;
0266	4325		JMS AC	
0267	4454		JMS I U2SPC	/2 SPACES;
0270	4334		JMS PLXP	
0271	4453		JMS I U1SPC	/1 SPACE;
0272	4742		JMS I XPACP	
0273	4520		JMS I CRLF	/CR AND LF;
0274	4524		JMS I ZEROR	
0275	4743		JMS I XPACP+1	/RIGHT ARROW
0276	4325		JMS AC	
0277	4454		JMS I U2SPC	/2 SPACES;
0300	4744		JMS I XPACP+2	
0301	4453		JMS I U1SPC	/1 SPACE;
0302	4745		JMS I XPACP+3	
0303	5656		JMP I PMQLT	/RETURN TO SWITCH ROUTINE
0304	0000	MQ,	0	
0305	7240		CLA CMA	
0306	0071		AND M	/M
0307	4522		JMS I PRXLOP	/PRINT;
0310	1072		TAD 0	/"0"/;
0311	4522		JMS I PRXLOP	/PRINT;
0312	5704		JMP I MQ	
0313	0000	L,	0	
0314	7240		CLA CMA	
0315	0073		AND LL	/L
0316	4522		JMS I PRXLOP	/PRINT;
0317	5713		JMP I L	
0320	0000	T,	0	
0321	7240		CLA CMA	
0322	0074		AND TT	/T

0323	4522		JMS I PRXLOP	/PRINT,
0324	5720		JMP I ?	
0325	0000	AC,	0	
0326	7240		CLA CHA	
0327	0075		AND A	/A
0330	4522		JMS I PRXLOP	/PRINT,
0331	1076		TAD C	/"C",
0332	4522		JMS I PRXLOP	/PRINT,
0333	5725		JMP I AC	
0334	0000	PLXP,	0	
0335	7240		CLA CHA	
0336	0063		AND LXP	/GOOD LINK
0337	3101		DCA LINK	
0340	4523		JMS I PLINK	
0341	5734		JMP I PLXP	
0342	0364	XPACP,	PACP	
0343	0357		PTO	
0344	0351		PBLXP	
0345	0372		PBACP	
0346	0203		MQLT	
0347	3065		DCA BLXP	
0350	5222		JMP MQLT+17	
0351	0000	PBLXP,	0	
0352	7240		CLA CHA	
0353	0065		AND BLXP	/BAD LINK
0354	3101		DCA LINK	
0355	4523		JMS I PLINK	
0356	5751		JMP I PBLXP	
0357	0000	PTO,	0	
0360	7240		CLA CHA	
0361	0102		AND TO	/RIGHT ARROW
0362	4522		JMS I PRXLOP	/PRINT,
0363	5757		JMP I PTO	
0364	0000	PACP,	0	
0365	7240		CLA CHA	
0366	0062		AND ACP	/ACP
0367	3105		DCA BITSTR	
0370	4525		JMS I MESSG	/PRINT A MESSAGE.
0371	5764		JMP I PACP	
0372	0000	PBACP,	0	
0373	7240		CLA CHA	
0374	0066		AND BACP	/BACP
0375	3105		DCA BITSTR	

0076 4525  
0377 5772  
0400

JMS I MESSG  
JMP I PBACP  
PAGE

/PRINT MESSAGE

/TEST THAT MQL WILL CLEAR THE AC AND LEAVE THE LINK CLEARED

```

0400 5227 MQLT1, JMP HSE1
0401 4536      JMS I UGEN
0402 7340      CLL CLA CHA /CLEAR LINK
0403 0064      AND GENX
0404 3062      DCA ACP /STORE AC PATTERN
0405 3063      DCA LXP /STORE LINK TO A ZERO
0406 7040      CMA
0407 0062      AND ACP /LOAD AC
0410 7421      MQL
0411 3066      DCA BACP /STORE AC RESULT
0412 7620      CLA SNL
0413 5301      JMP XONE+6 /STORE LINK RESULT 0000
0414 7240      CLA CHA
0415 3065      DCA BLXP /STORE LINK RESULT 7777
0416 7040      CMA
0417 0066      AND BACP
0420 7440      SZA
0421 5237      JMP MQLSW /AC NOT EQUAL TO 0000
0422 7240      CLA CHA
0423 0065      AND BLXP
0424 7440      SZA
0425 5237      JMP MQLSW /LINK NOT EQUAL TO A ZERO
0426 5250      JMP MQL+4 /CONTINUE TEST MQLT1
    
```

```

0427 7300 HSE1, CLA CLL
0430 3064      DCA GENX
0431 1097      TAD XMQLT1
0432 3055      DCA BACP
0433 1060      TAD XMQAT
0434 3096      DCA NEXT
0435 4531      JMS I MODSEL /PERFORM MODE SELECTION
0436 5201      JMP MQLT1+1
    
```

```

0437 7604 MQLSW, CLA OSR /TEST SW2
0440 7106      RTL CLL
0441 7004      RAL
0442 7430      SZL
0443 5256      JMP XMQL+1 /PRINT ERROR
    
```

```

0444 7604 MQL, CLA OSR /TEST SW0
0445 7104      RAL CLL
0446 7430      SZL
0447 7402      HLT /MQL ERROR
0450 7604      CLA OSR
0451 7106      RTL CLL
0452 7430      SZL
    
```

```

0453 5202      JMP MQLT1+2    /PROGRAM LOOP
0454 5201      JMP MQLT1+1    /CONTINUE PROGRAM

0455 0444      XMQ1,  MQ1
0456 7240      CLA CMA
0457 0255      AND XMQ1
0460 3700      DCA I XONE+5
0461 4521      JMS I   CRLF2      /2 CR AND LF
0462 4670      JMS I XCP+1
0463 4671      JMS I XCP+2
0464 4672      JMS I XCP+3
0465 4273      JMS XONE
0466 5667      JMP I XCP

0467 0263      XCP,   CP
0470 0304      MQ
0471 0313      L
0472 0320      T

0473 0000      XONE,  0
0474 7240      CLA CMA
0475 0077      AND ONE      /ONE
0476 4522      JMS I   PRXLOP    /PRINT
0477 5673      JMP I XONE
0500 0256      PMQLT
0501 3065      DCA BLXP
0502 5216      JMP MQLT1+16

0503 5340      MQAT,  JMP HSE2
0504 4536      JMS I UGEN
0505 7360      STL CL1 CMA    /SET LINK
0506 0064      AND GENX
0507 3062      DCA ACP      /STORE AC PATTERN
0510 7240      CLA CMA
0511 3063      DCA LXP      /STORE LINK TO A ONE
0512 7040      CMA
0513 0062      AND ACP      /LOAD AC
0514 7421      MQL        /LOAD MQ FROM AC
0515 7501      MQA        /LOAD AC FROM MP
0516 3066      DCA BAOP      /STORE RESULT OF MQL, MQA
0517 7620      CLA SNL
0520 5777      JMP YA+5      /STORE LINK RESULT 0000
0521 7240      CLA CMA
0522 3065      DCA BLXP      /STORE LINK RESULT 7777

0523 7040      RL2,   CMA
0524 0062      AND ACP      /COMPARE ACP WITH BAOP
0525 7140      CLL CMA
0526 1066      TAD BACP
0527 7040      CMA
0530 7450      SNA
0531 7430      SZL
0532 5350      JMP HSE2+10    /MQ DID NOT EQUAL AC
    
```

```

0533 7240          CLA CMA
0534 0065          AND BLXP
0535 7450          SNA
0536 5350          JMP HSE2+10      /LINK DID NOT EQUAL 1 ONE
0537 5363          JMP HSE2A

0540 7300      HSE2,  CLA CLL
0541 3064          DCA GENX
0542 1060          TAD XMQAT
0543 3055          DCA BACK
0544 1061          TAD XMQAT+1
0545 3056          DCA      NEXT
0546 4531          JMS I   MODSEL      /PERFORM MODE SELECTION
0547 5304          JMP MQAT+1
0550 7604          CLA OSR      /TEST SW2
0551 7106          RTL CLL
0552 7004          RAL
0553 7420          SNL
0554 5357          JMP ,+3
0555 4776          JMS PMQAT      /PRINT ERROR
0556 4775          JMS MQA1
0557 7604          CLA OSR      /TEST SW0
0560 7104          RAL CLL
0561 7430          SZL
0562 7402          HLT      /MQL OR MQA ERROR
0563 7604      HSE2A,  CLA OSR      /TEST SW1
0564 7106          RTL CLL
0565 7430          SZL
0566 5305          JMP MQAT+2      /PROGRAM LOOP
0567 5304          JMP MQAT+1      /CONTINUE PROGRAM

0575 0605
0576 0600
0577 0646
           0600      PAGE

```

```

0600 0000      PMQAT,  0
0601 4521          JMS I   CRLF2      /2 CR AND LF
0602 4777          JMS      MQ      /PRINT "MQ"
0603 4232          JMS      AT
0604 5600          JMP I   PMQAT

0605 0000      MQA1,  OPEN
0606 4576          JMS I   EYMOD      /TYPE THE MODE
0607 4520          JMS I   CRLF      /CR AND LF
0610 4450          JMS I   UPSPC      /5 SPACES
0611 7773          *5
0612 4776          JMS      AC      /PRINT "AC"
0613 4454          JMS I   U2SPC      /2 SPACES
0614 4775          JMS      PLXP      /
0615 4453          JMS I   U1SPC      /1 SPACE
0616 4774          JMS      PACP      /

```

```

0617 4520 JMS I CRLF /CR AND LF'
0620 4777 JMS MQ /PRINT "MQ",
0621 4773 JMS L /PRINT "L",
0622 4453 JMS I U1SPC /1 SPACE'
0623 4777 JMS MQ /PRINT "MQ",
0624 4241 JMS YA /PRINT "A",
0625 4454 JMS I U2SPC /2 SPACES'
0626 4772 JMS PBLXP /
0627 4453 JMS I U1SPC /1 SPACE'
0630 4771 JMS PBACP /
0631 5605 JMP I MQA1 /EXIT'
    
```

```

0632 0000 AT, 0
0633 7240 CLA CMA
0634 0095 AND A /A
0635 4522 JMS I PRXLOP /PRINT'
0636 1074 TAD TT /TT'
0637 4522 JMS I PRXLOP /PRINT'
0640 5632 JMP I AT
    
```

```

0641 0000 YA, 0
0642 7240 CLA CMA
0643 0095 AND A /A
0644 4522 JMS I PRXLOP /PRINT'
0645 5641 JMP I YA
0646 3065 DCA BLXP
0647 5770 JMP RL2
    
```

/TEST OF MQL WITH THE LINK SET TO 0

```

0650 4304 MQA1, JMS HSE3
0651 4536 JMS I UGEN
0652 7340 CLL CLA CMA /CLEAR LINK
0653 0064 AND GENX
0654 3062 DCA ACP /STORE AC PATTERN
0655 3063 DCA LXP /STORE LINK TO A ZERO
0656 7040 CMA
0657 0062 AND ACP /LOAD AC
0660 7421 MQL /LOAD MQ FROM AC
0661 7501 MQA /LOAD AC FROM MQ
0662 3066 DCA BACP /STORE RESULT OF MQL, MQA
0663 7620 CLA SNL
0664 5340 JMP NOPR+14
0665 7240 CLA CMA
0666 3065 DCA BLXP /STORE LINK RESULT 7777
0667 7040 CMA
0670 0062 AND ACP /COMPARE ACP WITH BACP
0671 7140 CLL CMA
0672 1066 TAD BACP
0673 7040 CMA
0674 7430 SNA
0675 7430 SZL
    
```

6	5314		JMP MQAER1	/MQ DID NOT EQ. AC
0677	7240		CLA CHA	
0700	0065		AND BLXP	
0701	7440		SEA	
0702	5314		JMP MQAER1	/LINK DID NOT EQUAL A ZERO
0703	5330		JMP NOPR+4	
0704	7300	HSE3,	CLA CLL	
0705	3064		DCA GENX	
0706	1061		TAD XMQAT1	
0707	3055		DCA BACK	
0710	1106		TAD XMQAT2	
0711	3056		DCA NEXT	
0712	4531		JMS I MODSEL	/PERFORM MODE SELECTION.
0713	5251		JMP MQAT1+1	
0714	7604	MQAER1,	CLA OSR	/TEST SW2
0715	7106		RTL CLL	
0716	7004		RAL	
0717	7420		SNL	
0720	5324		JMP NOPR	
0721	4735		JMS I NOPR+11	/PRINT ERROR
0722	4736		JMS I NOPR+12	
0723	4737		JMS I NOPR+13	
0724	7604	NOPR,	CLA OSR	/TEST SW0
0725	7104		RAL CLL	
0726	7430		SEL	
0727	7402		HLT	/MQL OR MQA ERROR.
0730	7604		CLA OSR	/TEST SW1
0731	7106		RTL CLL	
0732	7430		SEL	
0733	5252		JMP MQAT1+2	/PROGRAM LOOP
0734	5251		JMP MQAT1+1	/CONTINUE PROGRAM
0735	0600		PMQAT	
0736	0473		XONE	
0737	0605		MQA1	
0740	3065		DCA BLXP	
0741	5267		JMP MQAT1+17	
0770	0523			
0771	0372			
0772	0351			
0773	0313			
0774	0364			
0775	0334			
0776	0325			
0777	0304			
	1000			

## /TEST OF MQA,

1000	5232	MQAT2,	JMP HSE4	
1001	4536		JMS I UGEN	
1002	7360		STL CLA CMA	/SET LINK
1003	0064		AND GENX	
1004	7040		CMA	/COMPLEMENT GENX PATTERN
1005	3062		DCA ACP	/STORE AC PATTERN
1006	7040		CMA	
1007	3063		DCA LXP	/STORE LINK TO A ONE
1010	1064		TAD GENX	
1011	7421		MOI	/LOAD MQ
1012	1062		TAD ACP	/LOAD AC WITH COMPLEMENTED GENX
1013	7501		MOA	
1014	3066		DCA BAOP	/STORE RESULT OF MQA
1015	7620		CLA SNL	
1016	5333		JMP CLRL4	/STORE LINK RESULT 0000
1017	7240		CLA CMA	
1020	3065		DCA BLXP	/STORE LINK RESULT 7777
1021	1066	RL4,	TAD BAOP	/AC SHOULD EQUAL 7777
1022	7040		CMA	
1023	7440		SEA	
1024	5242		JMP MQAER2	/MQ DID NOT INCLUSIVE OR WITH AC
1025	7040		CMA	
1026	0065		AND BLXP	
1027	7450		SNA	
1030	5242		JMP MQAER2	/LINK DID NOT EQUAL A ONE
1031	5255		JMP LNPR2+4	
1032	7300	HSE4,	CLA CLL	
1033	3064		DCA GENX	
1034	1106		TAD XMQAT2	
1035	3055		DCA BAOP	
1036	1107		TAD XMQAT3	
1037	3056		DCA NEXT	
1040	4531		JMS I MQSEL	/PERFORM MODE SELECTION
1041	5201		JMP MQAT2+1	
1042	7604	MQAER2,	CLA OSR	/TEST SW2
1043	7106		RTL CLL	
1044	7004		RAL	
1045	7420		SNL	
1046	5251		JMP LNPR2	/PRINT ERROR
1047	4662		JMS I XPMQAT	
1050	4263		JMS EMQAT2	
1051	7604	LNPR2,	CLA OSR	/TEST SW0
1052	7104		RAL CLL	
1053	7430		SZL	
1054	7402		HLT	/MQA ERROR,
1055	7604		CLA OSR	/TEST SW1

```

      6 7106          RTL CLL
    1057 7430          SZL
    1060 5202          JMP MQAT2+2      /PROGRAM LOOP
    1061 5201          JMP MQAT2+1      /CONTINUE PROGRAM

    1062 0600          XPMQAT, PMQAT

    1063 0000          EMQAT2, OPEN
    1064 4326          JMS          PTWO
    1065 4576          JMS I      CTYMOD      /TYPE THE MODE
    1066 4520          A93,      JMS I      CRLF      /CARRIAGE RETURN AND LINE FEED
    1067 4454          JMS I      U2SPC      /2 SPACES
    1070 4453          JMS I      U1SPC      /1 SPACE
    1071 4777          JMS          AC          /PRINT "AC"
    1072 4454          JMS I      U2SPC      /2 SPACES
    1073 4776          JMS          PLXP      /
    1074 4453          JMS I      U1SPC      /1 SPACE
    1075 4775          JMS          PACP      /
    1076 4520          JMS I      CRLF      /CR AND LF
    1077 4454          JMS I      U2SPC      /2 SPACES
    1100 4453          JMS I      U1SPC      /1 SPACE
    1101 4774          JMS          MQ          /PRINT "MQ"
    1102 4454          JMS I      U2SPC      /2 SPACES
    1103 4454          JMS I      U2SPC      /2 SPACES
    1104 7200          CLA          /0
    1105 1064          TAD          GENX      /
    1106 3062          DCA          ACP      /
    1107 4775          JMS          PACP      /
    1110 4520          JMS I      CRLF      /CR AND LF
    1111 4774          JMS          MQ          /PRINT "MQ"
    1112 4321          JMS          VOR      /
    1113 4777          JMS          AC          /PRINT "AC"
    1114 4454          JMS I      U2SPC      /2 SPACES
    1115 4773          JMS          PBLXP      /
    1116 4453          JMS I      U1SPC      /1 SPACE
    1117 4772          JMS          PBACP      /
    1120 5663          JMP I      EMQAT2      /EXIT

    1121 0000          VOR,      0          /PRINT INCLUSIVE OR
    1122 7240          CLA          CMA
    1123 0110          AND          INCOR
    1124 4522          JMS I      PRXL0P      /PRINT
    1125 5721          JMP I      VOR

    1126 0000          PTWO,      0          /PRINT 2
    1127 7240          CLA          CMA
    1130 0112          AND          TWO
    1131 4522          JMS I      PRXL0P      /PRINT
    1132 5726          JMP I      PTWO

    1133 3065          CLRL4,      DCA          BLXP
    1134 5221          JMP          RL4
    
```

## /TEST OF MQA,

1135	5771	MQAT3,	JMP HSE5	
1136	4536		JMS I UGEN	
1137	7340		CLL CLA CMA	/CLEAR LINK
1140	0064		AND GENX	
1141	7040		CMA	/COMPLEMENT GENX PATTERN
1142	3062		DCA ACP	/STORE AC PATTERN
1143	3063		DCA LXP	/STORE LINK TO A ZERO
1144	7040		CMA	
1145	0064		AND GENX	
1146	7421		MQL	/LOAD MQ
1147	1062		TAD ACP	/LOAD AC WITH COMPLEMENTED GENX.
1150	7501		MQA	
1151	3066		DCA BACP	/STORE RESULT OF MQA
1152	7620		CLA SNL	
1153	7410		SKP	
1154	7240		CLA CMA	
1155	3065		DCA BLXP	/STORE LINK RESULT 7777
1156	1066		TAD BACP	/AC SHOULD EQUAL 7777.
1157	7040		CMA	
1160	7440		SZA	
1161	5770		JMP MQAERS	/MQ DID NOT INCLUSIVE OR WITH AC
1162	7040		CMA	
1163	0065		AND BLXP	
1164	7440		SZA	
1165	5770		JMP MQAERS	/LINK DID NOT EQUAL A ZERO
1166	5767		JMP NOPR3+4	
1167	1223			
1170	1210			
1171	1200			
1172	0372			
1173	0351			
1174	0304			
1175	0364			
1176	0334			
1177	0325			
	1200		PAGE	
1200	7300	HSE5,	CLA CLL	
1201	3064		DCA GENX	
1202	1107		TAD XMQAT3	
1203	3055		DCA BACP	
1204	1377		TAD (SAMTS0	
1205	3056		DCA NEXT	
1206	4531		JMS I MODSEL	/PERFORM MODE SELECTION.
1207	5776		JMP MQAT3+1	
1210	7604	MQAER3,	CLA OSR	/TEST SW2
1211	7106		RTL CLL	

```

      .2 7004      RAL
1213 7420      SNL
1214 5217      JMP NOPR3      /PRINT ERROR
1215 4630      JMS I APMQAT
1216 5233      JMP AMQAT3

1217 7684      NOPR3, CLA OSR      /TEST SW0
1220 7104      RAL CLL
1221 7430      SZL
1222 7402      HLT      /MQA ERROR;
1223 7604      CLA OSR      /TEST SW1
1224 7106      RTL CLL
1225 7430      SZL
1226 5775/     JMP MQAT3+2      /PROGRAM LOOP
1227 5776/     JMP MQAT3+1      /CONTINUE PROGRAM

1230 0600      APMQAT, PMQAT
1231 1217      NOPR3
1232 1063      EMQAT2

1233 4240      AMQAT3, JMS PTHREE
1234 4576      JMS I [TYMOD      /TYPE THE MODE;
1235 1231      TAD APMQAT+1
1236 3632      DCA I APMQAT+2
1237 5774/     JMP AT3

1240 0000      PTHREE, 0
1241 7240      CLA CHA
1242 0111      AND THREE
1243 4522      JMS I PRXLOP      /PRINT;
1244 5640      JMP I PTHREE

      /TEST OF THE SAM INSTRUCTION USING FIXED NUMBERS;

1245 4315      SAMTS0, JMS SAMS0H      /GO DO HOUSEKEEPING;

1246 4263      SAM0, JMS SAMGEN      /LOAD
1247 1020      TAD TOLINK
1250 7104      CLL RAL      /LINK LOADED
1251 1022      TAD TOMQ
1252 7421      MQL      /MQ LOADED
1253 1021      TAD TOAC      /AC LOADED
1254 7457      SAM      /EAE SUBTRACT
1255 4535      JMS I SAVREG      /SAVE L, AC, MQ, SC, AND CT;
1256 4773/     JMS SAMSIM      /SIMULATE "SAM"
1257 4451      JMS I UCOMP      /COMPARE ACTUAL AGAINST SIMULATED
1260 7773      -5
1261 5276      JMP ESAM0      /ERROR
1262 5302      JMP ESAM0+4      /NO ERROR

1263 0000      SAMGEN, OPEN

```

```

1264 4452      JMS I  UMOVE      /MOVE DATA TOI  TOLINK, TOAC, TOMQ.
1265 0000      OPEN
1266 0020      TOLINK
1267 7775      -3
1270 7325      CLA CLL  CML  IAC  RAL      /AC = 3
1271 1265      TAD          ,=4
1272 3265      DCA          ,=5
1273 2113      ISZ      SCOUNT
1274 5663      JMP I   SAMGEN
1275 5772      JMP          GEN+3

```

/ROUTINE TO CHECK SR OPTIONS FOR SAM TEST 0.

```

1276 4541      ESAM0, JMS I  TS1SW2      /CHECK SR 2.
1277 4305      JMS      SM0ERR      /PRINT ERROR DATA.
1300 4537      JMS I  TS1SW0      /CHECK SR 0.
1301 7402      HLT          /SUBTRACT AC FROM HQ ERROR. (SAMS).
1302 4540      JMS I  TS1SW1      /CHECK SR 1.
1303 5247      JMP      SAM0+1      /LOOP THE ROUTINE.
1304 5246      JMP      SAM0        /CONTINUE NORMAL TEST.

```

/ROUTINE TO PRINT ERROR INFORMATION FOR SAM TEST 0.

```

1305 0000      SM0ERR, OPEN
1306 4530      JMS I  TTYST      /TYPE THE FOLLOWING:
1307 7775      -3
1310 7502      ESAM          /SAM
1311 7416      TEST          /TEST
1312 7421      ZERO          /0
1313 4533      JMS I  PREGS      /PRINT HEADING AND CONTENTS OF REGISTERS.
1314 5705      JMP I  SM0ERR      /EXIT

```

/INITIALIZATION ROUTINE FOR SAM TEST 0.

```

1315 0000      SAMS0H, OPEN      /HOUSEKEEPING FOR SAMS0.
1316 4534      JMS I  ASCOMP      /SET COMPARE ROUTINE.
1317 1371      TAD      (SAMTAB      /GET ADDRESS OF THE TABLE
1320 3265      DCA      SAMGEN+2      /AND STORE IT AT SAMGEN+2
1321 1377      TAD      (SAMS0      /
1322 3055      DCA      BACK          /BACK SET TO RETURN TO CURRENT TEST
1323 1370      TAD      (SAMTS1      /
1324 3056      DCA      NEXT          /
1325 1367      TAD      (=5          /NUMBER OF TESTS.
1326 3113      DCA      SCOUNT
1327 3023      DCA      TOSHIF      /0
1330 3024      DCA      TOGT        /0
1331 3044      DCA      SCSIM       /0
1332 4531      JMS I  MODSEL      /PERFORM MODE SELECTION.
1333 4532      JMS I  ONLYB       /EXIT TEST IF A MODE.
1334 7403      ACS          /CLEAR THE STEP COUNTER.
1335 5715      JMP I  SAMS0H      /EXIT.

```

/TEST OF THE SAM INSTRUCTION USING RANDOM NUMBERS.

6	47661	SAMTS1,	JMS	SAMSIH	/GO DO USERKEEPING
1337	47651	SAM1,	JMS	SAMRGN	/LOAD WITH RANDOM
1340	1022		TAD	TOMQ	
1341	7421		MOI		/MO LOADED
1342	4547		JMS I	LDGT	/LOAD THE GT ACCORDING TO "TOGT".
1343	1020		TAD	TOLINK	
1344	7104	CLL	RAL		/LINK LOADED.
1345	1021		TAD	TOAC	/AC LOADED
1346	7457		SAM		/EAE SUBTRACT AC FROM MO.
1347	4535		JMS I	SAVREG	/SAVE L, AC, MO, SC, AND GT.
1350	47731		JMS	SAMSIH	/SIMULATE "SAM"
1351	4451		JMS I	UCOMP	/COMPARE ACTUAL AGAINST SIMULATED
1352	7773		=5		/L, AC, MO, AND SC.
1353	57641		JMP	ESAM1	/ERROR
1354	57631		JMP	ESAM1+4	/NO ERROR OCCURRED.
1363	1435				
1364	1431				
1365	1400				
1366	1414				
1367	7773				
1370	1336				
1371	7244				
1372	5603				
1373	6013				
1374	1066				
1375	1137				
1376	1136				
1377	1245				
	1400				

PAGE

/SUBROUTINE TO GENERATE THE RANDOM DATA FOR SAM TEST 1.

1400	0000	SAMRGN,	OPEN		
1401	47771		JMS	RANGEN	/GET RANDOM DATA.
1402	3021		DCA	TOAC	/THIS WILL BE LOADED INTO THE AC.
1403	7010		RAR		/RANDOM DATA FOR GT.
1404	3024		DCA	TOGT	/
1405	47771		JMS	RANGEN	/GET RANDOM DATA.
1406	3022		DCA	TOMQ	/THIS WILL BE LOADED INTO THE MO.
1407	7010		RAR		/RANDOM DATA FOR LINK.
1410	3020		DCA	TOLINK	/
1411	2113		ISZ	SCOUNT	/DONE 4096 TIMES
1412	5600		JMP I	SAMRGN	/NO.
1413	57761		JMP	GEN+3	/YES.

/INITIALIZATION ROUTINE FOR SAM TEST 1.

1414	0000	SAMSIH,	OPEN		
1415	4534		JMS I	ASCOMP	/SET COMPARE ROUTINE.
1416	1375		TAD	(SHLTS0	/ADDRESS OF THE
1417	3056		DCA	NEXT	/NEXT TEST TO "NEXT"
1420	1374		TAD	(SAMTS1	/BACK SET TO

1421	3055	DCA	BACK	/RETURN TO CURRENT TEST.
1422	3113	DCA	SCOUNT	/0
1423	3023	DCA	TOSHIF	/0
1424	3044	DCA	SCSIM	/
1425	4531	JMS I	MODSEL	/PERFORM MODE SELECTION.
1426	4532	JMS I	ONLYB	/EXIT TEST IF MODE "A".
1427	7403	ACS		/CLEAR THE STEP COUNTER.
1430	5614	JMP I	SAMS1H	/EXIT.

## /ROUTINE TO CHECK SR OPTIONS FOR SAM TEST I

1431	4541	ESAMI,	JMS I	TS1SW2	/CHECK SR 2.
1432	4240		JMS	SMIERR	/PRINT ERROR DATA.
1433	4537		JMS I	TS1SW0	/CHECK SR 0.
1434	7402		HLT		/SUBTRACT AC FROM MQ ERROR. (SAM).
1435	4540		JMS I	TS1SW1	/CHECK SR 1.
1436	5773		JMP	SAM1+1	/LOOP THE ROUTINE.
1437	5772		JMP	SAM1	/CONTINUE NORMAL TEST.

## /ROUTINE TO PRINT ERROR INFORMATION FOR SAM TEST I.

1440	0000	SMIERR,	OPEN		
1441	4530		JMS I	TYTST	/TYPE THE FOLLOWING:
1442	7775		=3		
1443	7502		ZSAM		/SAM
1444	7416		TEST		/TEST
1445	7423		ZONE		/1
1446	4533		JMS I	PREGS	/PRINT HEADING AND CONTENTS OF REGISTERS.
1447	5640		JMP I	SMIERR	/EXIT.

/TEST OF THE SHIFT LEFT INSTRUCTION USING AN  
/INCREMENTING PATTERN IN THE MQ WITH THE AC 0  
/AND SHIFTING EACH PATTERN 0-37 OCTAL SHIFTS.

1450	4276	SHLTS0,	JMS	SLTS0H	/GO DO HOUSE KEEPING
1451	4536	SHL0,	JMS I	UGEN	/GENERATE A NUMBER AND STORE IT IN GENX.
1452	7331		CLA	CLL CML IAC RAR	/AC=4000,L=1
1453	3020		DCA	TOLINK	/SAVE LINK
1454	1064		TAD	GENX	/GET THE GENERATED NUMBER
1455	3022		DCA	TOMQ	/SAVE FOR MQ
1456	3021		DCA	TOAC	/0 FOR AC
1457	1264		TAD	NBSHL0	/GET NUMBER OF SHIFTS
1460	3023		DCA	TOSHIF	/SAVE NUMBER OF SHIFTS
1461	1064		TAD	GENX	/GET THE GENERATED NUMBER
1462	7421		MQL		/LOAD THE MQ.
1463	7413		SHL		/EAE SHIFT LEFT
1464	0000	NBSHL0,	OPEN		/SHIFT THIS AMOUNT OF TIMES.
1465	4535		JMS I	SAVREG	/SAVE L,AC,MQ,SC,GT.
1466	1023		TAD	TOSHIF	
1467	1114		TAD	MODE	
1470	7040		CMA		
1471	4771		JMS	SHLSIM	/SIMULATE SHL.
1472	4451		JMS I	UCOMP	/COMPARE SIMULATED SHL AGAINST ACTUAL SHL.

```

      3 7773      =5
1474 5317      JMP      SBERR
1475 5323      JMP      SBERR*4

```

```

/L, AC, D, B, AND S;
/SIMULATED AND ACTUAL DID NOT COMPARE;
/SIMULATED AND ACTUAL COMPARED, CONTINUE TEST;

```

## /INITIALIZATION SUBROUTINE FOR SHLTS0.

```

1476 0000      SLTS0H, OPEN      /HOUSE KEEPING
1477 4534      JMS I   ASCOMP    /SET COMPARE ROUTINE;
1500 3064      DCA     GENX      /ZERO TO NUMBER GENERATOR
1501 3264      DCA     NBSHL0    /ZERO TO LOCATION CONTAINS SHIFTS;
1502 1370      TAD     (SHL0
1503 3095      DCA     BACK
1504 1367      TAD     (S0INC
1505 3056      DCA     NEXT
1506 1175      TAD     C=37
1507 3113      DCA     SCOUNT
1510 4931      JMS I   MOOSEL    /PERFORM MODE SELECTION;
1511 5676      JMP I   SLTS0H    /EXIT, AC=0;

```

## /ROUTINE TO INCREMENT SHIFT COUNT FOR SHL TEST 0.

```

1512 2264      S0INC,  ISE     NBSHL0  /INCREMENT SHIFT COUNT;
1513 2113      ISE     SCOUNT  /DONE SHIFTING
1514 5291      JMP     SHL0
1515 5716      JMP I   .+1
1516 1600      SHLTS1

```

## /ROUTINE TO CHECK SR OPTIONS FOR SHL TEST 0.

```

1517 4541      SBERR,  JMS I   TS1SW2  /CHECK SR 2;
1520 4326      JMS     SBERR1  /PRINT ERROR DATA;
1521 4537      JMS I   TS1SW0  /CHECK SR 0;
1522 7402      HLT
1523 4540      JMS I   TS1SW1  /SHL ERROR;
1524 5292      JMP     SHL0+1    /CHECK SR 1;
1525 5291      JMP     SHL0      /LOOP THE ROUTINE;

```

/CONTINUE NORMAL TEST.

## /ROUTINE TO PRINT ERROR INFORMATION FOR SHL TEST 0.

```

1526 0000      SBERR1, OPEN
1527 4530      JMS I   T1TST    /TYPE THE FOLLOWING
1530 7775      =3
1531 7413      ZSHL          /SHL
1532 7416      TEST         /TEST
1533 7421      ZERO        /0
1534 4543      JMS I   NUMSHF   /NUMBER OF SHIFTS IN DECIMAL;
1535 4533      JMS I   PREGS    /HEADING AND REGISTERS;
1536 5726      JMP I   SBERR1  /EXIT, AC=0;

```

```

1567 1512
1570 1451
1571 6051
1572 1337

```

1573 1340  
 1574 1336  
 1575 1450  
 1576 5603  
 1577 6525  
 1600

PAGE

/TEST OF THE SHIFT LEFT INSTRUCTION USING RANDOM DATA.

1600	4221	SHLTS1,	JMS	SLTS1H	/GO DO HOUSE KEEPING.
1601	4546	SHL1,	JMS I	RNDATA	/GENERATE RANDOM DATA.
1602	4545		JMS I	LDREG	/LOAD L, MQ, AND GT.
1603	1023		TAD	TOSHIF	/NUMBER OF SHIFTS.
1604	3207		DCA	NBSHL1	/LOAD THE NUMBER OF SHIFTS TO BE DONE.
1605	1021		TAD	TOAC	/AC LOADED.
1606	7413		SHL		/EAE SHIFT LEFT.
1607	0000	NBSHL1,	OPEN		/THIS AMOUNT OF TIMES
1610	4535		JMS I	SAVREG	/SAVE L, AC, MQ, SC, GT.
1611	1023		TAD	TOSHIF	/
1612	1114		TAD	MODE	/
1613	7140		CHM CLL		/
1614	4777		JMS	SHLS1M	/SIMULATE SHL
1615	4491		JMS I	UCOMP	/COMPARE SIMULATED AGAINST THE ACTUAL.
1616	7773		-5		/L, AC, MQ, GT, AND SC.
1617	5232		JMP	SIERR	/ERROR
1620	5236		JMP	SIERR+4	/NO ERRORS ENCOUNTERED.

/INITIALIZATION SUBROUTINE FOR SHLTS1.

1621	0000	SLTS1H,	OPEN		/HOUSE KEEPING
1622	4534		JMS I	ASCMP	/SET COMPARE ROUTINE AND CLEAR TABLE.
1623	1376		TAD	(SHLTS1	
1624	3095		DCA	BACK	
1625	1375		TAD	(LSR1S0	
1626	3096		DCA	NEXT	
1627	3113		DCA	SCOUNT	
1630	4531		JMS I	MODESEL	/PERFORM MODE SELECTION.
1631	5621		JMP I	SLTS1H	/EXIT, AC=0.

/ROUTINE TO CHECK SR OPTIONS FOR SHL TEST 0.

1632	4541	SIERR,	JMS I	TS1SW2	/CHECK SR 2.
1633	4241		JMS	SIERR1	/PRINT ERROR DATA.
1634	4537		JMS I	TS1SW0	/CHECK SR 0.
1635	7402		HLT		/SHL ERROR.
1636	4540		JMS I	TS1SW1	/CHECK SR 1.
1637	5202		JMP	SHL1+1	/LOOP THE ROUTINE.
1640	5201		JMP	SHL1	/CONTINUE NORMAL TEST.

/ROUTINE TO PRINT ERROR INFORMATION FOR SHL TEST 0.

1641	0000	SIERR1,	OPEN		
1642	4530		JMS I	TYTST	/TYPE THE FOLLOWING:

3	7775	-3		
1644	7413	ESHL		/SHL
1645	7416	TEST		/TEST
1646	7423	ZONE		/1
1647	4543	JMS I	NUMSHF	/NUMBER OF SHIFTS IN DECIMAL
1650	4533	JMS I	PREGS	/HEADING AND REGISTERS
1651	5641	JMP I	SIERRI	/EXIT, AC=0

/TEST OF THE LOGICAL SHIFT RIGHT INSTRUCTION, (LSR):  
 /USING A INCREMENTING PATTERN FROM THE  
 /MOST SIGNIFICANT TO LEAST SIGNIFICANT WITH THE  
 /MQ=0 AND SHIFTING EACH PATTERN 0-37 OCTAL  
 /SHIFTS.

1652	4301	LSRTO, JMS	LSRSOH	/GO DO HOUSE KEEPING
1653	4536	LSRO, JMS I	UGEN	/GENERATE A NUMBER
1654	1004	TAD	GENX	/GET THE NUMBER
1655	4774	JMS	OBVERS	/CHANGE IT TO THE OBVERSE
1656	3001	DCA	TOAC	/FOR THE AC
1657	3022	DCA	TOHQ	/0 FOR HQ.
1660	1207	TAD	NLSRO	
1661	3023	DCA	TOSHIF	
1662	7331	CLA CLL	CML IAC RAR	/L=1, AC=4000
1663	3000	DCA	TOLINK	/TOLINK=4000
1664	7401	HQL		/MQ=0
1665	1021	TAD	TOAC	/AC LOADED
1666	7417	LSR		/EAE LOGICAL SHIFT RIGHT

1667	0000	NLSRO, OPEN		/DATA TO STEP COUNTER
1670	4535	JMS I	SAVREG	/SAVE L, AC, HQ, SC, GT
1671	1003	TAD	TOSHIF	/GET NUMBER OF SHIFTS
1672	1114	TAD	MODE	/ADD MODE TO IT
1673	7140	CMA CLL		/COMPLEMENT IT
1674	4773	JMS	LSRSIM	/SIMULATE LSR
1675	4401	JMS I	UCOMP	/COMPARE SIMULATED AGAINST ACTUAL
1676	7773	-5		/L, AC, HQ, GT, AND SC
1677	5322	JMP	LBERR	/ERROR
1700	5326	JMP	LBERR+6	/NO ERRORS ENCOUNTERED

/INITIALIZATION SUBROUTINE FOR LSRTO,

1701	0000	LSRSOH, OPEN		
1702	4534	JMS I	ASCOMP	/SET COMPARE ROUTINE
1703	3004	DCA	GENX	/ZERO TO NUMBER GENERATOR
1704	3207	DCA	NLSRO	/ZERO TO LOCATION CONTAINING SHIFTS
1705	1372	TAD	(LSRO	
1706	3005	DCA	BACK	
1707	1371	TAD	(L0INC	
1710	3056	DCA	NEXT	
1711	1175	TAD	E=37	
1712	3113	DCA	SCOUNT	
1713	4531	JMS I	MODSEL	/PERFORM MODE SELECTION
1714	5701	JMP I	LSRSOH	/EXIT, AC=0

## /ROUTINE TO INCREMENT SHIFT COUNT FOR LSR TEST 0.

1715	2267	L0INC,	ISE	NBLSR0
1716	2113		ISE	SCOUNT
1717	5253		JMP	LSR0
1720	5721		JMP	I,+1
1721	2000		LSRTS1	

## /ROUTINE TO CHECK SR OPTIONS FOR LSR TEST 0.

1722	4541	L0ERR,	JMS	I	TS1SW2	/CHECK SR 2.
1723	4331		JMS		L0ERR1	/PRINT ERROR DATA.
1724	4537		JMS	I	TS1SW0	/CHECK SR 0.
1725	7402		HLT			/LSR ERROR.
1726	4540		JMS	I	TS1SW1	/CHECK SR 1.
1727	5254		JMP		LSR0+1	/LOOP THE ROUTINE.
1730	5253		JMP		LSR0	/CONTINUE NORMAL TEST.

## /ROUTINE TO PRINT ERROR INFORMATION FOR LSR TEST 0.

1731	0000	L0ERR1,	OPEN			
1732	4530		JMS	I	TYTST	/TYPE THE FOLLOWING
1733	7775		-3			
1734	7431		ZLSR			/LSR
1735	7416		TEST			/TEST
1736	7421		ZER0			/0
1737	4543		JMS	I	NUMSHF	/NUMBER OF SHIFTS IN DECIMAL
1740	4533		JMS	I	PREGS	
1741	5731		JMP	I	L0ERR1	/EXIT

1771	1715
1772	1653
1773	6120
1774	6473
1775	1602
1776	1600
1777	6051
	2000

PAGE

## /TEST OF THE LOGICAL SHIFT RIGHT INSTRUCTION USING RANDOM DATA.

2000	4221	LSRTS1,	JMS		LSRS1H	/GO DO HOUSE KEEPING.
2001	4546	LSR1,	JMS	I	RNDATA	/GENERATE RANDOM DATA.
2002	4545		JMS	I	LDREG	/LOAD L, MQ, AND GT.
2003	1023		TAD		TOSHIF	/
2004	3207		DCA		NBLSR1	/NUMBER OF SHIFTS.
2005	1021		TAD		TOAC	/AC LOADED.
2006	7417		LSR			/LOGICAL SHIFT RIGHT.
2007	0000	NBLSR1,	OPEN			/NUMBER OF SHIFTS TO BE PERFORMED.
2010	4535		JMS	I	SAVREG	/SAVE L, AC, MQ, SC, GT.
2011	1023		TAD		TOSHIF	

2	1114	TAD	MODE	
2013	7140	CMA	CLL	
2014	4777	JMS	LSRSIM	/SIMULATE LSR
2015	4491	JMS	UCOMP	/CHECK SIMULATED AGAINST ACTUAL
2016	7773	=5		/L, AC, MQ, GT, AND SC.
2017	5232	JMP	LIERR	/ERROR
2020	5236	JMP	LIERR+4	/NO ERRORS ENCOUNTERED.

## /INITIALIZATION SUBROUTINE FOR LSRTS1

2021	0000	LSRSIM, OPEN		
2022	4534	JMS	ASCOMP	/SET COMPARE ROUTINE.
2023	1376	TAD	(LSRTS1	
2024	3095	DCA	BACK	
2025	1375	TAD	(ASRTS0	
2026	3096	DCA	NEXT	
2027	3113	DCA	SCOUNT	/4096 TESTS
2030	4931	JMS	MODESEL	/PERFORM MODE SELECTION.
2031	5621	JMP	LSRSIM	/EXIT, AC=0

## /ROUTINE TO CHECK SR OPTIONS FOR LSR TEST I.

2032	4541	LIERR, JMS	I	TSTSW2	/CHECK SR 0.
2033	4241	JMS		LIERR1	/PRINT ERROR DATA.
2034	4537	JMS	I	TSTSW0	/CHECK SR 0.
2035	7402	HLT			/LSR ERROR.
2036	4540	JMS	I	TSTSW1	/CHECK SR 1.
2037	5202	JMP		LSR1+1	/LOOP THE ROUTINE.
2040	5201	JMP		LSR1	/CONTINUE NORMAL TEST.

## /ROUTINE TO PRINT ERROR INFORMATION

2041	0000	LIERR1, OPEN			
2042	4530	JMS	I	TYST	/PRINT THE FOLLOWING:
2043	7775	=3			
2044	7431	ZLSR			/LSR
2045	7416	TEST			/TEST
2046	7423	ZONE			/1
2047	4543	JMS	I	NUMSHF	/NUMBER OF SHIFTS IN DECIMAL
2050	4533	JMS	I	PREGS	/HEADING AND REGISTERS.
2051	5641	JMP	I	LIERR1	/EXIT

## /TEST OF THE ARITHMETIC SHIFT RIGHT INSTRUCTION.

/USING AN INCREMENTING PATTERN FROM THE  
/MOST SIGNIFICANT TO LEAST SIGNIFICANT WITH THE  
/MQ ZERO AND SHIFTING EACH PATTERN 0-37 OCTAL  
/SHIFTS,

2052	4301	ASRTS0, JMS	ASRS0H	/DO INITIALIZATION	
2053	4536	ASR0, JMS	I	UGEN	/GENERATE A COUNT.
2054	1064	TAD	GENX	/GET THE NUMBER	
2055	4774	JMS	OBVERS	/CHANGE IT TO THE OBVERSE	

```

2056 3021      DCA      TOAC      /COUNT PATTERN TO TOAC
2057 3022      DCA      TOMQ      /0 TO TOMQ
2060 1267      TAO      NBASR0
2061 3023      DCA      TOSHIF
2062 7331      CLA CLL  CML IAC RAR  /L=1
2063 3020      DCA      TOLINK     /1 TO TOLINK
2064 7421      MQL
2065 1021      TAO TOAC      /0 TO MQ
2066 7415      ASR
2067 0000      NBASR0, OPEN  /EAE ARITHMETIC SHIFT RIGHT.
2070 4535      JMS I   SAVREG     /SAVE L, AC, MQ, SC, GT.
2071 1023      TAD      TOSHIF
2072 1114      TAD      MODE
2073 7140      CMA CLL
2074 4773      JMS      ASRSIM     /SIMULATE ASR
2075 4401      JMS I   UCOMP      /COMPARE ACTUAL AGAINST SIMULATED
2076 7773      -5
2077 5322      JMP      ABERR      /L, AC, MQ, GT, AND SC.
2100 5326      JMP      ABERR+4    /ERROR DETECTED.
                          /NO ERROR ENCOUNTERED
    
```

/INITIALIZATION SUBROUTINE FOR ASRTEST.

```

2101 0000      ASRS0H, OPEN
2102 4534      JMS I   ASCOMP     /SET COMPARE ROUTINE.
2103 3064      DCA      GENX      /ZERO TO NUMBER GENERATOR
2104 3267      DCA      NBASR0     /ZERO TO LOCATION CONTAINING SHIFTS.
2105 1372      TAD      (ASR0
2106 3055      DCA      BACK
2107 1371      TAD      (ABINC
2110 3056      DCA      NEXT
2111 1175      TAD      C=37      /SET UP FOR
2112 3113      DCA      SCOUNT     /37 OCTAL SHIFTS
2113 4531      JMS I   MOOSEL     /PERFORM MODE SELECTION.
2114 5701      JMP I   ASRS0H      /EXIT, AC=0.
    
```

/ROUTINE TO INCREMENT SHIFT COUNT FOR ASR TEST 0.

```

2115 2267      ABINC,  ISE      NBASR0
2116 2113      ISE SCOUNT
2117 5253      JMP      ASR0      /DONE THIS TEST YET?
2120 5721      JMP I   ,+1      /NO.
2121 2200      ASRTEST1  /GO TO NEXT TEST.
    
```

/ROUTINE TO CHECK SR OPTIONS FOR ASR TEST 0.

```

2122 4541      ABERR,  JMS I   TS1SW2  /CHECK SR 2.
2123 4331      JMS      ABERR1  /PRINT ERROR DATA.
2124 4537      JMS I   TS1SW0  /CHECK SR 0.
2125 7402      HLT
2126 4540      JMS I   TS1SW1  /ASR ERROR.
2127 5254      JMP      ASR0+1  /CHECK SR 1.
2130 5253      JMP      ASR0      /LOOP THE ROUTINE.
                          /CONTINUE NORMAL TEST.
    
```

/ROUTINE TO PRINT ERROR INFORMATION FOR ASR TEST 0.

```

2131 0000  A0ERR1, OPEN
2132 4530  JMS I  TYTST /PRINT THE FOLLOWING.
2133 7775  =3
2134 7440  ZASR /ASR
2135 7416  TEST /TEST
2136 7421  ZERO /0
2137 4543  JMS I  NUMSHF /NUMBER OF SHIFTS IN DECIMAL.
2140 4533  JMS I  PREGS /HEADING AND REGISTERS.
2141 5731  JMP I  A0ERR1 /EXIT, AC=0.

```

```

2171 2115
2172 2053
2173 6200
2174 6473
2175 2052
2176 2000
2177 6120
2200

```

PAGE

```

/TEST OF THE ARITHMETIC SHIFT RIGHT INSTRUCTION
/USING RANDOM DATA.

```

```

2200 4221  ASRTS1, JMS ASRSIH /GO DO HOUSEKEEPING
2201 4546  ASR1, JMS I RNDATA /GENERATE RANDOM DATA.
2202 4545  JMS I LDREG /LOAD L, MQ, AND GT.
2203 1023  TAD TOSHIF
2204 3207  DCA NBASR1 /NUMBER OF SHIFTS LOADED.
2205 1021  TAD TOAC /AC LOADED
2206 7415  ASR /EAE ARITHMETIC SHIFT RIGHT
2207 0000  NBASR1, OPEN /NUMBER OF SHIFTS.
2210 4535  JMS I SAVREG /SAVE L, AC, MQ, SC, GT.
2211 1023  TAD TOSHIF
2212 1114  TAD MODE
2213 7140  CMA CLL
2214 4777  JMS ASRSIH /SIMULATE ASR.
2215 4451  JMS I UCMP /COMPARE SIMULATED AGAINST ACTUAL.
2216 7773  =5
2217 5232  JMP AIERR /ERROR DETECTED.
2220 5236  JMP AIERR+4 /NO ERRORS ENCOUNTERED.

```

```

/INITIALIZATION SUBROUTINE FOR ASRTS1.

```

```

2221 0000  ASRSIH, OPEN
2222 4534  JMS I ASCOMP /SET COMPARE ROUTINE.
2223 1376  TAD (ASRTS1
2224 3055  DCA BACK
2225 1375  TAD (OPSES0
2226 3056  DCA NEXT
2227 3113  DCA SCOUNT
2230 4531  JMS I MODSEL /PERFORM MODE SELECTION.
2231 5621  JMP I ASRSIH /EXIT, AC=0.

```

```

/ROUTINE TO CHECK SR OPTIONS IN ASR TEST 1.

```

```

2232 4541 AIERR, JMS I TSTSW2 /CHECK SR 2;
2233 4241 JMS AIERR1 /PRINT ERROR DATA;
2234 4537 JMS I TSTSW0 /CHECK SR 0;
2235 7402 HLT /ASR ERROR;
2236 4540 JMS I TSTSW1 /CHECK SR 1;
2237 5202 JMP ASR1+1 /LOOP THE ROUTINE;
2240 5201 JMP ASR1 /CONTINUE NORMAL TEST;

```

/ROUTINE TO PRINT ERROR INFORMATION.

```

2241 0000 AIERR1, OPEN /PRINT THE FOLLOWING;
2242 4530 JMS I TYTST
2243 7775 =3
2244 7440 ZASR /ASR
2245 7416 TEST /TEST
2246 7423 ZONE /1
2247 4543 JMS I NUMSHF /NUMBER OF SHIFTS IN DECIMAL
2250 4533 JMS I PREGS /HEADING AND REGISTERS
2251 5641 JMP I AIERR1 /EXIT

```

/TEST OF THE DOUBLE PRECISION SKIP IF ZERO INSTRUCTION. (DPSZ).

```

2252 4774/ DPSZ0, JMS DPSZ0H /GO DO HOUSE KEEPING;
2253 7320 CLA CLL CML
2254 4773/ DPSZ0, JMS ROTGEN
2255 7300 CLA CLL
2256 1043 TAD LSH /GET DATA THAT WILL BE PLACED IN THE MQ;
2257 1042 TAD MSW /ADD THE AC DATA TO THAT;
2260 7650 SNA CLA /WOULD THE AC AND MQ BE ZERO?
2261 7430 SZL /CHECK FOR A CARRY WHEN AC AND MQ ARE ADDED;
2262 4306 JMS NOSKIP /AC AND MQ WILL BE NON ZERO;
2263 4317 JMS YSKIP /AC AND MQ WILL BE ZERO;
2264 7331 CLA CLL CML IAC RAR /AC = 4000; LINK = 1;
2265 3041 DCA LSIM /LOAD THE SIMULATED LINK;
2266 1041 TAD LSIM
2267 3020 DCA TOLINK /LOAD THE PROBLEM LINK;
2270 1043 TAD LSH
2271 7421 MQL /MQ NOW LOADED;
2272 1042 TAD MSW /AC NOW LOADED;
2273 7451 DPSZ /EAE DOUBLE PRECISION SKIP IF ZERO
2274 0000 NOSKP, OPEN
2275 0000 YESSKP, OPEN
2276 4535 CKDATA, JMS I SAVREG /SAVE L, AC, MQ, SC, GF;
2277 4451 JMS I UCOMP /COMPARE L, AC, MQ;
2300 7775 =3
2301 7610 SKP CLA /DPSZ MODIFIED A REGISTER;
2302 5772/ JMP EDPSZ0+5 /NO ERROR OCCURED;
2303 1371 TAD (DATER /SET PRINTOUT FOR DATA ERROR;
2304 3770/ DCA DPZPR1
2305 5767/ JMP EDPSZ0+1 /DPSZ MODIFIED ONE OF THE REGISTERS;

```

/ROUTINE TO SETUP FOR NO SKIP CONDITION

```

2306 0000 NOSKIP, OPEN /AC AND MQ NOT 0

```

```

107 1366 TAD (JMP CRDATA
310 3274 DCA NOSKP
2311 1364 TAD (JMP EDPSZ0
2312 3275 DCA YESSKP
2313 1363 TAD (SO
2314 3770 DCA DPZPR1
2315 2306 ISZ NOSKIP
2316 5706 JMP I NOSKIP /EXIT, AC=0
    
```

/ROUTINE TO SET UP FOR A SKIP CONDITION

```

2317 0000 YSKIP, OPEN /AC AND MQ =0
2320 1366 TAD (JMP CRDATA
2321 3275 DCA YESSKP
2322 1364 TAD (JMP EDPSZ0
2323 3274 DCA NOSKP
2324 1362 TAD (NSO
2325 3770 DCA DPZPR1
2326 5717 JMP I YSKIP /EXIT, AC = 0
    
```

```

2362 7532
2363 7523
2364 5765
2365 2512
2366 5276
2367 2513
2370 5515
2371 7543
2372 2517
2373 2476
2374 2400
2375 2292
2376 2200
2377 6200
2400
    
```

PAGE

/INITIALIZATION ROUTINE FOR DPSZ0.

```

2400 0000 DPSZ0H, OPEN
2401 4534 JMS I ASCOMP /SET COMPARE ROUTINE.
2402 1377 TAD (DPSZ0
2403 3055 DCA BACK
2404 1376 TAD (DZINC
2405 3056 DCA NEXT
2406 1775 TAD DSZJMS
2407 3774 DCA PRCHG /SET PRINTOUT ROUTINE FOR DPSZ TEST.
2410 7344 CLA CLL CMA RAL /7776
2411 3273 DCA CNTR1
2412 7344 CLA CLL CMA RAL /7776
2413 3274 DCA CNTR2
2414 7344 CLA CLL CMA RAL /7776
2415 3275 DCA CNTR3
2416 1373 TAD (+32
2417 3113 DCA SCOUNT
    
```

2420	4531	JMS	I	MODESEL	/PERFORM MODE SELECTION;
2421	1114	TAD		MODE	
2422	7700	SMA	CL	A	
2423	5264	JMP		MODA	/EXIT IF MODE A
2424	7403	ACS			/CLEAR THE STEP COUNTER;
2425	5600	JMP	I	DPSZ0H	/EXIT, AC=0;

2426	2113	DZINC,	ISE	SCOUNT	
2427	5772		JMP	DPSZ0+1	
2430	7340		CLA	CMA	CLL
2431	3113		DCA		SCOUNT
2432	7240		CLA	CMA	
2433	3042		DCA		MSH
2434	3043		DCA		LSH
2435	2273		ISE		CNTR1
2436	5772		JMP		DPSZ0+1
2437	7240		CLA	CMA	
2440	3113		DCA		SCOUNT
2441	7240		CLA	CMA	
2442	3273		DCA		CNTR1
2443	7240		CLA	CMA	
2444	3043		DCA		LSH
2445	3042		DCA		MSH
2446	2274		ISE		CNTR2
2447	5772		JMP		DPSZ0+1
2450	7240		CLA	CMA	
2451	3113		DCA		SCOUNT
2452	7040		CMA		
2453	3273		DCA		CNTR1
2454	7040		CMA		
2455	3274		DCA		CNTR2
2456	7040		CMA		
2457	3043		DCA		LSH
2460	7040		CMA		
2461	3042		DCA		MSH
2462	2275		ISE		CNTR3
2463	5772		JMP		DPSZ0+1
2464	7604	MODA,	LAS		
2465	7006		RTL		
2466	7004		RAL		
2467	7710		SPA	CL	A
2470	5777		JMP		DPSZ0
2471	5672		JMP	I	+1
2472	2000		DPITS0		
2473	0000	CNTR1,	OPEN		
2474	0000	CNTR2,	OPEN		
2475	0000	CNTR3,	OPEN		

/ROUTINE TO GENERATE A ROTATING BIT THROUGH THE MQ AND AQ;

	0000	ROTCEN, OPEN		/GENER. ROTATING PATTERN
2477	1043	TAD	LSH	
2500	7004	RAL		
2501	3043	OCA	LSH	
2502	1042	TAD	MSH	
2503	7004	RAL		
2504	3042	DCA	MSH	
2505	1042	TAD	MSH	
2506	3021	DCA	TOAC	
2507	1043	TAD	LSH	
2510	3022	DCA	TOMQ	
2511	5226	JMP	DZINC	/EXIT, AC=0.

/ROUTINE TO CHECK SR OPTIONS FOR DPSZ TEST 0.

2512	4535	EDPSZ0, JMS I	SAVREG	/SAVE L, AC, MQ, SC, GT.
2513	4541	JMS I	TS1SW2	/CHECK SR 0.
2514	4323	JMS	DZERR0	/PRINT ERROR DATA.
2515	4537	JMS I	TS1SW0	/CHECK SR 0.
2516	7402	HLT		/DPSZ ERROR.
2517	4540	JMS I	TS1SW1	/CHECK SR 1.
2520	5772	JMP	DPSZ0+1	/LOOP THE ROUTINE.
2521	7100	CLL		
2522	5771	JMP	DPSZ0	/CONTINUE NORMAL TEST.

/ROUTINE TO PRINT ERROR INFORMATION.

2523	0000	DZERR0, OPEN		
2524	4530	JMS I	TYTST	
2525	7775	-3		
2526	7443	ZDPSZ		
2527	7416	TEST		
2530	7421	ZER0		
2531	4533	JMS I	PREGS	
2532	5723	JMP I	DZERR0	/EXIT

2571 2254  
 2572 2255  
 2573 7746  
 2574 7002  
 2575 7045  
 2576 2426  
 2577 2252  
 2600

PAGE

/TEST OF THE DOUBLE PRECISION INCREMENT INSTRUCTION, (DPIC).

2600	4221	DPITS0, JMS	DPIS0H	/GO DO HOUSE KEEPING.
2601	4536	DPI0, JMS I	UGEN	/GENERATE NUMBERS.
2602	7240	CLA	CMA	/7777
2603	3021	DCA	TOAC	/SIMULATED AC = 7777.
2604	3020	DCA	TOLINK	/SIMULATED LINK = 0.
2605	1064	TAD	GENX	/GET THE NUMBER GENERATED BY "GEN".
2606	7421	MOQ		/MQ LOADED.
2607	7701	CLA	MOA	/MO TO AC.

2610	3022	DCA	TOMQ	/SIMULATED MQ = C(GENX);
2611	7240	CLA	CMÄ	/AC = 7777
2612	7573	DPIC		/DOUBLE PRECISION INCREMENT
2613	4535	JMS I	SAVREG	/SAVE L, AC, MQ, SC, GT;
2614	4777	JMS	DPISIM	/SIMULATE DPI;
2615	4451	JMS I	UCOMP	/COMPARE SIMULATED AGAINST ACTUAL;
2616	7775		=3	/L, AC, MQ;
2617	5234	JMP	EDPI0	/ERROR
2620	5240	JMP	EDPI0+4	

/INITIALIZATION ROUTINE FOR DPIC TEST 0.

2621	0000	DPIS0H,	OPEN	/HOUSE KEEPING OF DPIS0H.
2622	4534	JMS I	ASCOMP	/SET COMPARE ROUTINE.
2623	3064	DCA	GENX	
2624	1376	TAD	(DPIS0	
2625	3055	DCA	BACK	
2626	1375	TAD	(DPITS1	
2627	3056	DCA	NEXT	
2630	4531	JMS I	MODSEL	/PERFORM MODE SELECTION.
2631	4532	JMS I	ONLYB	/EXIT IF MODE "A".
2632	7403	ACS		/CLEAR THE STEP COUNTER.
2633	5621	JMP I	DPIS0H	/EXIT

/ROUTINE TO CHECK SR OPTIONS FOR DPIC TEST 0.

2634	4541	EDPI0,	JMS I	TS1SW2	/CHECK SR 2.
2635	4243		JMS	DI0ERR	/PRINT ERROR DATA.
2636	4537		JMS I	TS1SW0	/CHECK SR 0.
2637	7402		HLT		/DPIC ERROR.
2640	4540		JMS I	TS1SW1	/CHECK SR 1.
2641	5202		JMP	DPIS0+1	/LOOP THE ROUTINE.
2642	5201		JMP	DPIS0	/CONTINUE NORMAL TEST.

/ROUTINE TO PRINT ERROR INFORMATION.

2643	0000	DI0ERR,	OPEN		
2644	4530		JMS I	TY1ST	/PRINT THE FOLLOWING:
2645	7775		=3		
2646	7446		ZDPIC		/DPIC
2647	7416		TEST		/TEST
2650	7421		ZER0,		/0
2651	4533		JMS I	PREGS	/HEADING AND REGISTERS.
2652	5643		JMP I	DI0ERR	/EXIT, AC=0.

/TEST OF THE DOUBLE PRECISION INCREMENT INSTRUCTION,  
/USING RANDOM DATA.

2653	4267	DPITS1,	JMS	DPIS1H	/GO DO HOUSEKEEPING
2654	4546	DPIS1,	JMS I	RNDATA	/GENERATE RANDOM DATA.
2655	4552		JMS I	LDSC	/LOAD THE STEP COUNTER.
2656	4545		JMS I	LDREG	/LOAD L, MQ, AND GT.
2657	1021		TAD	TOAC	/AC LOADED.

2061	4535	JMS I	SAVREG	/EAE 1 2 PRECISION INCREMENT.
2662	4777	JMS	DPISIM	/SAVE L,AC,MQ,SC,GT.
2663	4451	JMS I	UCOMP	/SIMULATE DPIC.
2664	7773	=5		/COMPARE SIMULATED AGAINST ACTUAL
2665	5302	JMP	EDPI1	/L,AC,MQ,GT. AD SC.
2666	5306	JMP	EDPI1+4	/ERROR
				/NO ERRORS ENCOUNTERED

## /INITIALIZATION ROUTINE FOR DPIC TEST 1.

2667	0000	DPISIM, OPEN		/HOUSEKEEPING FOR DPISIM
2670	4534	JMS I	ASCJMP	/SET COMPARE ROUTINE.
2671	3113	DCA	SCOUNT	
2672	1374	TAD	(DPISIM)	
2673	3055	DCA	BACK	
2674	1373	TAD	(DCMISO)	
2675	3056	DCA	NEXT	
2676	4531	JMS I	MODSEL	/PERFORM MODE SELECTION.
2677	4532	JMS I	ONLYB	/EXIT IF MODE "A".
2700	7403	ACS		/CLEAR THE STEP COUNTER.
2701	5667	JMP I	DPISIM	/EXIT

## /ROUTINE TO CHECK SR OPTIONS IN DPIC TEST 1.

2702	4541	EDPI1, JMS I	TS1SW2	/CHECK SR 2.
2703	4311	JMS	DI1ERR	/PRINT ERROR DATA.
2704	4537	JMS I	TS1SW0	/CHECK SR 0.
2705	7402	HLT		/DPIC ERROR.
2706	4540	JMS I	TS1SW1	/CHECK SR 1.
2707	5255	JMP	DPISIM+1	/LOOP THE ROUTINE.
2710	5254	JMP	DPISIM	/CONTINUE NORMAL TEST.

## /ROUTINE TO PRINT ERROR INFORMATION.

2711	0000	DI1ERR, OPEN		/PRINT THE FOLLOWING:
2712	4530	JMS I	TY1ST	
2713	7775	=3		
2714	7446	EDPIC		/DPIC
2715	7416	TEST		/TEST
2716	7423	ZONE		/1
2717	4533	JMS I	PREGS	/HEADING AND REGISTERS.
2720	5711	JMP I	DI1ERR	/EXIT, AC=0.

## /TEST OF THE DOUBLE PRECISION COMPLEMENT INSTRUCTION.

2721	4772	DCMISO, JMS	DCMSOH	/GO DO HOUSEKEEPING
2722	4771	DCM0, JMS	DCMGEN	/LOAD
2723	1020	TAD	TOLINK	
2724	7104	CLL RAL		/LINK LOADED
2725	1022	TAD	TOMQ	
2726	7421	SQL		/MQ LOADED
2727	1021	TAD	TOAC	/AC LOADED
2730	7575	DCM		/EAE DOUBLE PRECISION 2'S COMPLEMENT
2731	4535	JMS I	SAVREG	/SAVE L,AC,MQ,SC,GT.

2732	4770	JMS	DCMSIM	/SIMULATE DCM
2733	4451	JMS I	UCOMP	/COMPARE ACTUAL AGAINST SIMULATED.
2734	7775	=3		/L,AC,MO ONLY
2735	5767	JMP	EDCM0	/ERROR
2736	5766	JMP	EDCM0+4	/NO ERROR

2766 3035  
 2767 3031  
 2770 6302  
 2771 3000  
 2772 3013  
 2773 2721  
 2774 2654  
 2775 2653  
 2776 2601  
 2777 6264  
 3000

## PAGE

3000	0000	DCMGEN, OPEN		
3001	4452	JMS I	UMOVE	/MOVE DATA TO TOLINK, TOAD, SOMO
3002	0000	OPEN		
3003	0020	TOLINK		
3004	7773	=5		
3005	7325	CLA CLL	CML IAG RAL	/AC=0003
3006	1202	TAD	=4	/ADD THE ADDRESS
3007	3202	DCA	=5	/PUT IT BACK WITH 3 ADDED TO IT
3010	2113	ISE	SCOUNT	/FINISHED WITH ALL STORED PATTERNS
3011	5600	JMP I	DCMGEN	/NO
3012	5777	JMP	GEN+3	/YES

## /ROUTINE TO DO INITIALIZATION FOR DCM TEST 0.

3013	0000	DCMS0H, OPEN		
3014	4534	JMS I	ASCOMP	/HOUSEKEEPING FOR DCM00
3015	1376	TAD	{COMTAB	/SET COMPARE ROUTINE
3016	3202	DCA	DCMGEN+2	/GET THE ADDRESS OF THE TABLE
3017	1375	TAD	{DCM0S0	/STORE IT IN DCMGEN+2
3020	3095	DCA	BACK	
3021	1374	TAD	{DAD0S0	
3022	3096	DCA	NEXT	
3023	1373	TAD	{=6	/SET UP
3024	3113	DCA	SCOUNT	/SCOUNT
3025	4531	JMS I	MODESEL	/PERFORM MODE SELECTION
3026	4532	JMS I	ONLYB	/EXIT IF MODE "A"
3027	7403	ACS		/CLEAR THE STEP COUNTER
3030	5613	JMP I	DCMS0H	/EXIT

## /ROUTINE TO CHECK SR OPTIONS FOR DCM TEST 0.

3031	4541	EDCM0,	JMS I	TSTSW2	/CHECK SR 2.
3032	4240		JMS	DM0ERR	/PRINT ERROR DATA.
3033	4537		JMS I	TSTSW0	/CHECK SR 0.
3034	7402		HLT		/DCM ERROR.
3035	4540		JMS I	TSTSW1	/CHECK SR 1.
3036	5772		JMP	DCM0+1	/LOOP THE ROUTINE.

7 57711 JMP DCM0 /CONTI NORMAL TEST.

/ROUTINE TO PRINT ERROR INFORMATION.

```

3040 0000 DMBERR, OPEN
3041 4530 JMS I TYTST /PRINT THE FOLLOWING:
3042 7775 =3
3043 7451 ZDCM /DCM
3044 7416 TEST /TEST
3045 7421 ZERO /0
3046 4533 JMS I PREGS /HEADING AND REGISTERS.
3047 5640 JMP I DMBERR /EXIT, AC=0.

```

/TEST OF THE DOUBLE PRECISION ADD INSTRUCTION  
/USING FIXED DATA.

```

3050 4312 DADTS0, JMS DADSO0 /GO DO HOUSEKEEPING
3051 4276 DAD0, JMS DADGEN /GET NUMBERS TO ADD.
3052 1020 TAD TOLINK
3053 7104 CLL RAL /LINK LOADED
3054 1022 TAD TOMQ
3055 7421 MQL /MQ LOADED
3056 1023 TAD TOSHIF
3057 3267 DCA ,+10 /MSH LOADED
3060 1024 TAD TOGT
3061 3266 DCA ,+5 /LSH LOADED
3062 1021 TAD TOAC /AC LOADED
3063 7443 DAD /EAE DOUBLE PRECISION ADD
3064 3066 ,+2 /ADDRESS
3065 5270 JMP ,+3 /JMP OVER
3066 0000 OPEN /LSH OPERAND
3067 0000 OPEN /MSH OPERAND
3070 4535 JMS I SAVREG /SAVE L, AC, MQ, SC, GT.
3071 4770 JMS DADSIM /SIMULATE DAD
3072 4451 JMS I UCOMP /COMPARE SIMULATED AGAINST ACTUAL
3073 7775 =3 /L, AC, MQ.
3074 5332 JMP EDAD0 /ERROR
3075 5350 JMP EDAD0+16 /NO ERRORS ENCOUNTERED

```

```

3076 0000 DADGEN, OPEN
3077 4452 JMS I UMOVE
3100 0000 OPEN
3101 0020 TOLINK
3102 7773 =5
3103 7326 CLA CLL CML RPL /AC=2
3104 7124 CLL CML RAL /AC=5
3105 1300 TAD ,+5 /ADD THE ADDRESS
3106 3300 DCA ,+6 /PUT IT BACK WITH 6 ADDED TO IT
3107 2113 ISZ SCOUNT /FINISHED WITH ALL STORED PATTERNS
3110 5676 JMP I DADGEN /NO.
3111 5777 JMP GEN+3 /YES.

```

/INITIALIZATION ROUTINE FOR DAD TEST 0.

```

3112 0000      DADS0H, OPEN
3113 4534          JMS I   ASCOMP      /SET COMPARE ROUTINE;
3114 1367          TAD      (DADTAB    /GET ADDRESS OF TABLE
3115 3300          DCA      DADGEN+2   /AND STORE IT IN DADGEN+2
3116 1374          TAD      (DADTS0
3117 3055          DCA      BACK
3120 1366          TAD      (DADTS1
3121 3056          DCA      NEXT      /
3122 1365          TAD      (=5
3123 3113          DCA      SCOUNT
3124 1764          TAD      DADJMS      /GET A JMS TO MODIFY PRINT ROUTINE;
3125 3763          DCA      WILCHG     /PUT THE JMS IN WILCHG;
3126 4531          JMS I   MODSEL     /PERFORM MODE SELECTION;
3127 4532          JMS I   ONLYB      /EXIT IF MODE "A";
3130 7403          ACS      /CLEAR THE STEP COUNTER;
3131 5712          JMP I   DADS0H      /EXIT

```

## /ROUTINE TO CHECK SR OPTIONS FOR DAD TEST 0.

```

3132 1023      EDAD0, TAD      TOSHIF
3133 3037          DCA      TEMPÄ      /MSH TO TEMPÄ
3134 1024          TAD      TOGT
3135 3040          DCA      TEMPB      /LSH TO TEMPB
3136 3023          DCA      TOSHIF     /0
3137 3024          DCA      TOGT      /0
3140 4541          JMS I   TS1SW2     /CHECK SR 2;
3141 4353          JMS      DABERR     /PRINT ERROR DATA
3142 1037          TAD      TEMPÄ
3143 3023          DCA      TOSHIF     /RESTORE MSH
3144 1040          TAD      TEMPB
3145 3024          DCA      TOGT      /RESTORE LSH
3146 4537          JMS I   TS1SW0     /CHECK SR 1;
3147 7402          HLT
3150 4540          JMS I   TS1SW1     /CHECK SR 1;
3151 5252          JMP      DAD0+1
3152 5251          JMP      DAD0

```

## /ROUTINE TO PRINT ERROR INFORMATION.

```

3153 0000      DABERR, OPEN
3154 4530          JMS I   TPTST      /PRINT THE FOLLOWING;
3155 7775          =3
3156 7454          ZDAD      /DAD
3157 7416          TEST      /TEST
3160 7421          ZER0      /0
3161 4533          JMS I   PREGS      /HEADING AND REGISTERS;
3162 5753          JMP I   DABERR     /EXIT, AC=0;

```

```

3163 7016
3164 7044
3165 7773
3166 3200

```

/ 7302  
 3170 6320  
 3171 2722  
 3172 2723  
 3173 7772  
 3174 3050  
 3175 2721  
 3176 7333  
 3177 5603  
 3200

PAGE

/RANDOM DOUBLE PRECISION ADD TEST:

3200	4226	DADTS1, JMS	DADSIH	/GO DO HOUSEKEEPING
3201	4245	DAD1, JMS	RANDAD	/GENERATE RANDOM NUMBERS
3202	1020	TAD	TOLINK	
3203	7104	CLL RAL		/LINK LOADED
3204	1022	TAD	TOMQ	
3205	7421	HQL		/MQ LOADED
3206	1023	TAD	TOSHIF	
3207	3217	DCA	,+10	
3210	1024	TAD	TOGT	
3211	3216	DCA	,+5	/LEAST SIGNIFICANT LOADED
3212	1021	TAD	TOAC	/AC LOADED
3213	7443	DAD		/EAE DOUBLE PRECISION ADD
3214	3216	,+2		/ADDRESS
3215	5220	JMP	,+3	/JMP OVER
3216	0000	OPEN		/LEAST SIGNIFICANT OPERAND
3217	0000	OPEN		/MOST SIGNIFICANT OPERAND
3220	4535	JMS I	SAVREG	/SAVE L, AC, MQ, SC, GT.
3221	4777	JMS	DADSIM	/SIMULATE DAD
3222	4451	JMS I	UCOMP	/COMPARE SIMULATED AGAINST ACTUAL
3223	7775	=3		/L, AC, MQ.
3224	5263	JMP	EDAD1	/ERROR
3225	5301	JMP	EDAD1+16	/NO ERRORS ENCOUNTERED

/INITIALIZATION ROUTINE FOR DAD TEST 1,

3226	0000	DADSIH, OPEN		
3227	4534	JMS I	ASCOMP	/SET COMPARE ROUTINE.
3230	1376	TAD	(DADTS1	
3231	3055	DCA	BACK	
3232	1375	TAD	(DSTTS0	/ADDRESS OF NEXT TEST
3233	3056	DCA	NEXT	
3234	1774	TAD	DADJMS	/GET A JMS TO MODIFY PRINT ROUTINE.
3235	3773	DCA	WILCHG	/PUT THE JMS IN WILCHG.
3236	3113	DCA	SCOUNT	
3237	3044	DCA	SCSIM	/CLEAR
3240	3045	DCA	GTSIM	/CLEAR
3241	4531	JMS I	MODSEL	/PERFORM MODE SELECTION.
3242	4532	JMS I	ONLYB	/EXIT IF MODE "A".
3243	7403	ACS		/CLEAR THE STEP COUNTER.

```

3244 5626          JMP I  DADS1H          /EXIT AC=0 L=0
3245 0000          RANDAD, OPEN
3246 4772          JMS      RANGEN
3247 3021          DCA      TOAC          /RANDOM DATA FOR "AC"
3250 4772          JMS      RANGEN
3251 3022          DCA      TOMQ          /RANDOM DATA FOR "MQ"
3252 4772          JMS      RANGEN
3253 3023          DCA      TOSHIF          /RANDOM DATA FOR "MOST SIGNIFICANT"
3254 4772          JMS      RANGEN
3255 3024          DCA      TOGT          /RANDOM DATA FOR "LEAST SIGNIFICANT"
3256 7210          CLA RAR
3257 3020          DCA      TOLINK          /RANDOM DATA FOR LINK
3260 2113          ISZ     SCOUNT          /DONE
3261 5645          JMP I  RANDAD          /NO
3262 5771          JMP     GEN+3          /YES

```

/ROUTINE TO CHECK SR OPTIONS FOR DAD TEST I:

```

3263 1023          EDADI,  TAD      TOSHIF
3264 3037          DCA      TEMPA
3265 1024          TAD      TOGT
3266 3040          DCA      TEMPB
3267 3023          DCA      TOSHIF
3270 3024          DCA      TOGT
3271 4541          JMS I  TS1SW2          /CHECK SR 2;
3272 4304          JMS      DAIERR          /PRINT ERROR DATA;
3273 1037          TAD      TEMPA
3274 3023          DCA      TOSHIF
3275 1040          TAD      TEMPB
3276 3024          DCA      TOGT
3277 4537          JMS I  TS1SW0          /CHECK SR 0;
3300 7402          HLT
3301 4540          JMS I  TS1SW1          /DAD ERROR;
3302 5202          JMP     DADI+1          /CHECK SR 1;
3303 5201          JMP     DADI

```

/ROUTINE TO PRINT ERROR INFORMATION FOR DAD TEST I:

```

3304 0000          DAIERR, OPEN
3305 4530          JMS I  TY1ST          /PRINT THE FOLLOWING
3306 7775          =3
3307 7454          ZDAD          /DAD
3310 7416          TEST          /TEST
3311 7423          ZONE          /1
3312 4533          JMS I  PREGS          /HEADING AND REGISTERS
3313 5704          JMP I  DAIERR          /EXIT, AC=0

```

/TEST OF THE DOUBLE PRECISION STORE INSTRUCTION:  
/USING FIXED DATA

4	4770	DSTTS0,	JMS	DST08H	/GO DO USERKEEPING
3315	4767	DST0,	JMS	DST0GN	/SET UP NUMBERS TO BE STORED
3316	1041		TAD	LSIM	
3317	7104		CLL RAL		/LINK LOADED
3320	1043		TAD	LSH	
3321	7421		ML		/MQ LOADED
3322	1042		TAD	MSH	/AC LOADED
3323	7445		DST		/EAE DOUBLE PRECISION STORE
3324	3326		,+2		/START WITH OPERAND DEFINED BY THE ADDRESS
3325	5330		JMP	,+3	/GO OVER
3326	0000	DST0A,	OPEN		/MQ TO BE STORED HERE
3327	0000	DST0B,	OPEN		/AC TO BE STORED HERE
3330	4535		JMS I	SAVREG	/SAVE L, AC, MQ, SC, GT.
3331	1326		TAD	,=3	
3332	3036		DCA	GT0CK	/SAVE STORED MQ
3333	1327		TAD	,=4	
3334	3035		DCA	SC0CK	/SAVE STORED AC
3335	4451		JMS I	UCOMP	/CHECK L, AC, MQ AGAINST ORIGINAL
3336	7775		=3		
3337	5766		JMP	EDST0	/ERROR, L, AC, OR MQ MODIFIED BY DST.
3340	1043		TAD	LSH	
3341	7421		ML		/LOAD MQ WITH GOOD
3342	1042		TAD	MSH	/LOAD AC WITH GOOD
3343	7575		DCM		/2'S COMPLEMENT
3344	7443		DAD		/ADD "TO BE CHECKED"
3345	3326		DST0A		/STORED AT THIS ADDRESS
3346	7451		DPSZ		/ARE THEY THE SAME?
3347	5766		JMP	EDST0	/ERROR
3350	5765		JMP	EDST0+4	/NO ERRORS ENCOUNTERED
3365	3435				
3366	3431				
3367	3400				
3370	3413				
3371	5603				
3372	6525				
3373	7016				
3374	7044				
3375	3314				
3376	3200				
3377	6320				
	3400				
			PAGE		
3400	0000	DST0GN,	OPEN		
3401	4452		JMS I	UMOVE	
3402	0000		OPEN		
3403	0041		LSIM		
3404	7775		=3		
3405	7325		CLA CLL	CML IAC RAL	/AC = 3
3406	1202		TAD	,=4	
3407	3202		DCA	,=5	/+3 TO DST0GN+2
3410	2113		ISZ	SCOUNT	
3411	5600		JMP I	DST0GN	
3412	5777		JMP	GEN+3	

## /INITIALIZATION ROUTINE FOR DST TEST 0

```

3413 0000 DSTS0H, OPEN
3414 4534     JMS I  ASCOMP      /SET COMPARE ROUTINE.
3415 1376     TAD     (DSTTAB
3416 3202     DCA     DST0GN+2
3417 1375     TAD     (DSTTS0
3420 3055     DCA     BACK
3421 1374     TAD     (DSTTS1
3422 3056     DCA     NEXT
3423 1373     TAD     (=5
3424 3113     DCA     SCOUNT
3425 4531     JMS I  MODSEL      /PERFORM MODE SELECTION.
3426 4532     JMS I  ONLYB      /EXIT IF MODE "A".
3427 7403     ACS     /CLEAR THE STEP COUNTER.
3430 5613     JMP I  DSTS0H      /EXIT AC=L=0

```

## /ROUTINE TO CHECK SR OPTIONS FOR DST TEST 0

```

3431 4541 EDST0,  JMS I  TS1SW2    /CHECK SR 2.
3432 4240     JMS     DS0ERR      /PRINT ERROR DATA.
3433 4537     JMS I  TS1SW0      /CHECK SR 0.
3434 7402     HLT     /DST ERROR.
3435 4540     JMS I  TS1SW1    /CHECK SR 1.
3436 5772     JMP     DST0+1      /LOOP THE ROUTINE.
3437 5771     JMP     DST0       /CONTINUE NORMAL TEST.

```

## /ROUTINE TO PRINT ERROR INFORMATION

```

3440 0000 DS0ERR, OPEN
3441 4530     JMS I  TY1ST      /PRINT THE FOLLOWING
3442 7775     =3
3443 7457     ZDST           /DST
3444 7416     TEST          /TEST
3445 7421     ZER0         /0
3446 4770     JMS     DS1REG    /HEADING AND REGISTERS
3447 5640     JMP I  DS0ERR      /EXIT, AC=0

```

/TEST OF THE DOUBLE PRECISION STORE INSTRUCTION.  
/USING RANDOM DATA.

```

3450 4317 DSTTS1, JMS     DSTS1H    /GO DO HOUSEKEEPING
3451 4305 DST1,  JMS     DST1RN    /SET UP RANDOM NUMBERS
3452 1041     TAD     LSIM
3453 7104     CLL RAL          /LINK LOADED
3454 1043     TAD     LSH
3455 7421     MQL           /MQ LOADED
3456 1042     TAD     MSH
3457 7445     DST           /EAE DOUBLE PRECISION STORE
3460 3462     DST1A
3461 5264     JMP     ,+3
3462 0000 DST1A, OPEN          /LEAST SIGNIFICANT
3463 0000 DST1B, OPEN          /MOST SIGNIFICANT

```

3464	4535	JMS I	SAVREG	/SAV ,AC,MQ,SC,GT,
3465	1262	TAD	DST1A	
3466	3036	DCA	GTTOCK	/SAVE LEAST SIGNIFICANT
3467	1263	TAD	DST1B	
3470	3035	DCA	SCTOCK	/SAVE MOST SIGNIFICANT
3471	4451	JMS I	UCOMP	/COMPARE L, AC, AND MQ AGAINST ORIGINAL
3472	7775	=3		/L, AC, MQ
3473	5333	JMP	EDST1	/ERROR, L, AC, OR MQ MODIFIED BY DST
3474	1043	TAD	LSH	
3475	7421	MQL		/ORIGINAL MQ
3476	1042	TAD	MSH	/ORIGINAL AC
3477	7575	DCH		/2'S COMPLEMENT
3500	7443	DAD		/ADD "TO BE CHECKED"
3501	3462	DST1A		/STORED AT THIS ADDRESS
3502	7451	DPSZ		/ARE THEY THE SAME?
3503	5333	JMP	EDST1	/ERROR
3504	5337	JMP	EDST1+4	/NO ERRORS ENCOUNTERED

## /ROUTINE TO GENERATE RANDOM DATA FOR DST TEST 1

3505	0000	DST1RN, OPEN		
3506	4767	JMS	RANGEN	
3507	3042	DCA	MSH	/RANDOM DATA TO BE PUT IN AC
3510	4767	JMS	RANGEN	
3511	3043	DCA	LSH	/RANDOM DATA TO BE PUT IN MQ
3512	7010	RAR		
3513	3041	DCA	LSIM	/RANDOM DATA TO BE PUT IN LINK
3514	2113	ISZ	SCOUNT	/DONE?
3515	5705	JMP I	DST1RN	/NO
3516	5777	JMP	GEN+3	/YES

## /INITIALIZATION ROUTINE FOR DST TEST 1

3517	0000	DSTS1H, OPEN		
3520	4534	JMS I	ASCOMP	/SET COMPARE ROUTINE
3521	1374	TAD	(DSTS1	
3522	3055	DCA	BACK	
3523	1366	TAD	(NORMT	
3524	3056	DCA	NEXT	
3525	1365	TAD	(-1000	
3526	3113	DCA	SCOUNT	
3527	4531	JMS I	MODSEL	/PERFORM MODE SELECTION
3530	4532	JMS I	ONLYB	/EXIT IF "A" MODE
3531	7403	ACS		/CLEAR THE STEP COUNTER
3532	5717	JMP I	DSTS1H	/EXIT, AC=0

## /ROUTINE TO CHECK SR OPTION FOR DST TEST 1

3533	4541	EDST1, JMS I	TSTSW2	/CHECK SR 2
3534	4342	JMS	DS1ERR	/PRINT ERROR DATA
3535	4537	JMS I	TSTSW0	/CHECK SR 0

```

3536 7402 HLT /DST ERROR;
3537 4540 JMS I TS1SW1 /CHECK SR I;
3540 5252 JMP DST1+1 /LOOP THE ROUTINE;
3541 5251 JMP DST1 /CONTINUE NORMAL TEST;

```

/ROUTINE TO PRINT ERROR INFORMATION.

```

3542 0000 DSIERR, OPEN
3543 4530 JMS I TYTST /PRINT THE FOLLOWING
3544 7775 =3
3545 7457 ZDST /DST
3546 7416 TEST /TEST
3547 7423 ZONE /1
3550 4770 JMS DSTREG /HEADING AND REGISTERS
3551 5742 JMP I DSIERR /EXIT, AC=0;

```

```

3565 7000
3566 3600
3567 6525
3570 7106
3571 3315
3572 3316
3573 7773
3574 3450
3575 3314
3576 7263
3577 5603
3600

```

PAGE

/TEST OF THE NORMALIZE INSTRUCTION.

```

3600 5257 NORMT, JMP HSENMI
3601 4312 JMS GXEN
3602 7240 CLA CMA
3603 0305 AND MGNMIX
3604 7421 MQL /LOAD MQ INDEXED PATTERN
3605 7040 CMA
3606 0304 AND ACNMIX /LOAD AC INDEXED PATTERN
3607 7411 NMI
3610 3307 DCA ACNMIN /STORE AC
3611 7501 MQA
3612 3306 DCA MGNMIN /STORE MQ
3613 7441 SCA
3614 3300 DCA SCAST /STORE SCA COUNT
3615 7040 CMA
3616 0307 AND ACNMIN
3617 7140 CLL CMA
3620 1301 TAD NMIODD /6000
3621 7040 CMA
3622 7440 SEA
3623 5250 JMP NMIERR /AC DID NOT EQUAL 6000
3624 7430 SZL
3625 5250 JMP NMIERR /AC DID NOT EQUAL 6000
3626 7240 CLA CMA

```

```

1627 0306 AND MQNMIN
3630 7440 SZA
3631 5250 JMP NMIERR /MQ DID NOT EQUAL 0000
3632 7040 CMA
3633 0300 AND SCAST
3634 7140 CLL CMA
3635 1303 TAO SCASTX /INDEXED STEP COUNT #
3636 7040 CMA
3637 7440 SZA
3640 5250 JMP NMIERR /SC IN ERROR
3641 7430 SZL
3642 5250 JMP NMIERR /SC IN ERROR
3643 7240 CLA CMA
3644 0303 AND SCASTX /TEST SCA COUNT FOR 0
3645 7440 SZA /TO EXIT
3646 5254 JMP NMIERR+4 /CONTINUE TEST
3647 5272 JMP EXINMI
3650 4541 NMIERR, JMS I TSTSW2 /CHECK SR 2,
3651 4711 JMS I SCAST+11 /JUMP TO PRINT ROUTINE,
3652 4537 JMS I TSTSW0 /CHECK SR 0,
3653 7402 HLT /NORMILIZE FAILED.
3654 4540 JMS I TSTSW1 /CHECK SR 1,
3655 5202 JMP NORMT+2 /LOOP TEST,
3656 5201 JMP NORMT+1 /CONTINUE TEST,

3657 7240 HSENMI, CLA CMA
3660 0327 AND ANCMIQ
3661 3012 DCA XACNMI /AC AUTO START ADDRESS
3662 7040 CMA
3663 0330 AND MQNMIQ
3664 3013 DCA XMQNMI /MQ AUTO START ADDRESS
3665 7040 CMA
3666 0302 AND SCC23 /SC 23
3667 3303 DCA SCASTX /STORE DECIMAL 23
3670 4531 JMS I MOOSEL /PERFORM MODE SELECTION,
3671 5201 JMP NORMT+1

3672 7604 EXINMI, CLA OSR /TEST SW3
3673 7106 RTL CLL
3674 7006 RTL
3675 7430 SZL
3676 5200 JMP NORMT /REPEAT ENTIRE TEST
3677 5710 JMP I SCAST+10 /JMP TO NEXT NMI TEST

3700 0000 SCAST, 0
3701 6000 NMIO00, 6000
3702 0027 SCC23, 0027 /23 DECIMAL
3703 0000 SCASTX, 0
3704 0000 ACNMIX, 0
3705 0000 MQNMIX, 0
3706 0000 MQNMIN, 0
3707 0000 ACNMIN, 0
3710 4200 NORMT1

```

```

3711 4000 PRNMI
3712 0000 GXEN, 0
3713 7240 CLA CMA
3714 0412 AND I XACNMI
3715 3304 DCA ACNMIX /STORE AC PATTERN
3716 7040 CMA
3717 0413 AND I XMQNM1
3720 3305 DCA MQNMIX /STORE MQ PATTERN
3721 7040 CMA
3722 0303 AND SCASTX /SUBTRACT ONE FROM SCĀ COUNT
3723 7041 CIA
3724 7040 CMA
3725 3303 DCA SCASTX /STORE DECREMENTED SCĀ COUNT
3726 5331 JMP EXEN
3727 4060 ANCMIQ, ACNMI
3730 4074 MQNMIQ, MQNMI
3731 7240 EXEN, CLA CMA
3732 0303 AND SCASTX
3733 7440 SZA
3734 5712 JMP I GXEN
3735 5272 JMP EXINMI

4000 PAGE

```

```

4000 0000 PRNMI, OPEN
4001 4521 JMS I CRLF2 /2 CR AND LF'
4002 4326 JMS NMITPR /
4003 4450 JMS I UPSPC /6 SPACES'
4004 7772 =6
4005 4777 JMS PC /
4006 4776 JMS LPAR /
4007 4775 JMS AC /PRINT "AC"
4010 4774 JMS RPAR /
4011 4450 JMS I UPSPC
4012 7765 =13
4013 4777 JMS PC /PRINT "PC"
4014 4776 JMS LPAR /
4015 4773 JMS MQ /PRINT "MQ"
4016 4774 JMS RPAR /
4017 4576 JMS I IYMOD /TYPE THE MODÉ'
4020 4520 JMS I CRLF /CR AND LF'
4021 4450 JMS I UPSPC /6 SPACES'
4022 7772 =6
4023 1772 TAD ACNMIX /
4024 4771 JMS P12BIT /PRINT 12 BITS'
4025 4450 JMS I UPSPC /3 SPACES'
4026 7775 =3
4027 1770 TAD MQNMIX /
4030 4771 JMS P12BIT /PRINT 12 BITS'
4031 4520 JMS I CRLF /CR AND LF'

```

332	4767	JMS	NMIXX	/
4033	4450	JMS I	UPSPC	/3 SPACES;
4034	7775	=3		
4035	1766	TAD	ACNMIN	/
4036	4771	JMS	P12BIT	/PRINT 12 BITS;
4037	4450	JMS I	UPSPC	/3 SPACES;
4040	7775	=3		
4041	1765	TAD	MQNMIN	/
4042	4771	JMS	P12BIT	/PRINT 12 BITS;
4043	4520	JMS I	CRLF	/CR AND LF;
4044	4764	JMS	SCATXX	/
4045	4454	JMS I	U2SPC	/2 SPACES;
4046	1763	TAD	SCASTX	/
4047	4771	JMS	P12BIT	/PRINT 12 BITS;
4050	4520	JMS I	CRLF	/CR AND LF;
4051	4762	JMS	SCAXX	/
4052	4450	JMS I	UPSPC	/3 SPACES;
4053	7775	=3		
4054	1761	TAD	SCAST	/
4055	4771	JMS	P12BIT	/PRINT 12 BITS;
4056	4520	JMS I	CRLF	/CR AND LF;
4057	5600	JMP I	PRNMI	/EXIT; AC=0.

4060	0000	ACNMI,	0	
4061	7777		7777	/SC22
4062	7777		7777	/SC21
4063	7777		7777	/SC20
4064	7777		7777	/SC19
4065	7777		7777	/SC18
4066	7777		7777	/SC17
4067	7777		7777	/SC16
4070	7777		7777	/SC15
4071	7777		7777	/SC14
4072	7777		7777	/SC13
4073	7777		7777	/SC12

4074	7777	MQNMI,	7777	/SC11
4075	7777		7777	/SC10
4076	7776		7776	/SC9
4077	7774		7774	/SC8
4100	7770		7770	/SC7
4101	7760		7760	/SC6
4102	7740		7740	/SC5
4103	7700		7700	/SC4
4104	7600		7600	/SC3
4105	7400		7400	/SC2
4106	7000		7000	/SC1
4107	6000		6000	/SC0
4110	4000		4000	
4111	0000		0000	
4112	0000		0000	

4113 0000 0000  
 4114 0000 0  
 4115 0000 0  
 4116 0000 0  
 4117 0000 0  
 4120 0000 0  
 4121 0000 0  
 4122 0000 0  
 4123 0000 0  
 4124 0000 0  
 4125 0000 0

4126 0000 NMITPR, 0  
 4127 4332 JMS PNORM  
 4130 4343 JMS XNORMT  
 4131 5726 JMP I NMITPR  
 4132 0000 PNORM, 0  
 4133 7240 CLA CMA  
 4134 0760 AND N  
 4135 4522 JMS I PRXLOP /PRINT,  
 4136 1757 TAD N+1  
 4137 4522 JMS I PRXLOP /PRINT,  
 4140 1756 TAD N+2  
 4141 4522 JMS I PRXLOP /PRINT,  
 4142 5732 JMP I PNORM  
 4143 0000 XNORMT, 0  
 4144 7240 CLA CMA  
 4145 0755 AND N+3  
 4146 4522 JMS I PRXLOP /PRINT,  
 4147 5743 JMP I XNORMT

4155 5452  
 4156 5451  
 4157 5450  
 4160 5447  
 4161 3700  
 4162 5407  
 4163 3703  
 4164 5403  
 4165 3706  
 4166 3707  
 4167 5400  
 4170 3705  
 4171 7200  
 4172 3704  
 4173 0304  
 4174 5442  
 4175 0325  
 4176 5435  
 4177 5430

PAGE

4200 5261 NORMT1, JMP HSENM

701	4273	JMS GENNMI	
.202	7240	CLA CMA	
4203	0716	AND I TST25+1	/LOAD MQ PATTERN
4204	7421	MQL	
4205	7240	CLA CMA	
4206	0717	AND I TST25+2	/LOAD AC PATTERN
4207	7411	NMI	
4210	3725	DCA I TST25+10	/STORE NORMALIZED AC
4211	7501	MQA	
4212	3726	DCA I TST25+11	/STORE NORMALIZED MQ
4213	7441	SCA	
4214	3727	DCA I TST25+12	/STORE SCA COUNT
4215	7240	CLA CMA	
4216	0725	AND I TST25+10	
4217	7140	CLL CMA	
4220	1716	TAD I TST25+1	
4221	7040	CMA	
4222	7440	SZA	
4223	5333	JMP NMERR	/AC DID NOT EQUAL 2525
4224	7430	SZL	
4225	5333	JMP NMERR	/AC DID NOT EQUAL 2525
4226	7240	CLA CMA	
4227	0726	AND I TST25+11	
4230	7440	SZA	
4231	5333	JMP NMERR	/MQ DID NOT EQUAL 0000
4232	7240	CLA CMA	
4233	0727	AND I TST25+12	
4234	7140	CLL CMA	
4235	1331	TAD DEC12	/DECIMAL 12
4236	7040	CMA	
4237	7440	SZA	
4240	5333	JMP NMERR	/SC DID NOT EQUAL I2
4241	7430	SZL	
4242	5333	JMP NMERR	/SC DID NOT EQUAL I2
4243	2315	ISZ TST25	/REPEAT CURRENT TEST PATTERN
4244	5202	JMP NORMT1+2	
4245	7604	CLA OSR	/TEST SW1
4246	7106	RTL CLL	
4247	7430	SZL	
4250	5202	JMP NORMT1+2	
4251	2322	ISZ NMFLG	
4252	5201	JMP NORMT1+1	
4253	7604	CLA OSR	/TEST SW3
4254	7106	RTL CLL	
4255	7006	RTL	
4256	7430	SZL	
4257	5200	JMP NORMT1	
4260	5724	JMP I NEXNMI	
4261	7200	HSENM, CLA	
4262	3315	DCA TST25	/CLEAR TEST COUNTER
4263	7400	NOP	
4264	7040	CMA	
4265	0323	AND NM7776	
4266	3322	DCA NMFLG	

```

4267 1331      TAD DEC12
4270 3730      DCA I TST25+13
4271 4531      JMS I  MODSEL      /PERFORM MODE SELECTION.
4272 5201      JMP NORMT1+1

4273 0000      GENNMI, 0
4274 7240      CLA CMA
4275 0322      AND NMFLG
4276 7040      CMA
4277 7440      SZA
4300 5302      JMP PA2525      /GENERATE 2525
4301 5307      JMP PA2525+5      /GENERATE 5252
4302 7240      PA2525, CLA CMA
4303 0320      AND NM2525      /MQ PATTERN 2525
4304 3716      DCA I TST25+1
4305 3717      DCA I TST25+2      /AC PATTERN 0000
4306 5673      JMP I GENNMI
4307 7240      CLA CMA
4310 0321      AND NM5252      /MQ PATTERN 5252
4311 3716      DCA I TST25+1
4312 7040      CMA
4313 3717      DCA I TST25+2      /AC PATTERN 7777
4314 5673      JMP I GENNMI

4315 0000      TST25, 0
4316 3705      MQNMIX
4317 3704      ACNMIX
4320 2525      NM2525, 2525
4321 5252      NM5252, 5252
4322 0000      NMFLG, 0
4323 7776      NM7776, 7776

4324 4400      NEXNMI, NORMT2
4325 3707      ACNMIN
4326 3706      MQNMIN
4327 3700      SCAST
4330 3703      SCASTX
4331 0014      DEC12, 0014
4332 4000      PRNMI

4333 4541      NMERR, JMS I  TSTSW2      /CHECK SR 2.
4334 4732      JMS I  DEC12+1
4335 4537      JMS I  TSTSW0      /CHECK SR 0.
4336 7402      HLT      /NORMALIZE ERROR.
4337 4540      JMS I  TSTSW1      /CHECK SR 1.
4340 7610      SKP CLA
4341 5202      JMP      NORMT1+2      /CONTINUE TEST.
4342 3315      DCA      TST25      /CLEAR CURRENT TEST COUNTER.
4343 5202      JMP      NORMT1+2      /LOOP CURRENT TEST.

```

4400

PAGE

```

100 5305 NORMT2, JMP HKE /HOUSE KEEP1.
4401 4253 JMS GEX /PATTERN GENERATOR
4402 7621 CAM
4403 7040 CMA
4404 0725 AND I PAT01
4405 7421 MQL /MQ PATTERN
4406 7140 CLL CMA /AC PATTERN
4407 0726 AND I PAT00 /AC PATTERN
4410 7411 NMI
4411 3727 DCA I SPAT00 /STORE AC NORMALIZED PATTERN
4412 7501 MGA
4413 3730 DCA I SPAT01 /STORE MQ NORMALIZED PATTERN
4414 7441 SCA
4415 3734 DCA I SCANM /STORE SCA COUNT
4416 7040 CMA
4417 0727 AND I SPAT00 /AC PATTERN
4420 7040 CMA
4421 1331 TAD CHKAC /CHECK PATTERN AC
4422 7040 CMA
4423 7440 SZA /TEST AC BITS
4424 5313 JMP MT2ER /SPAT00 NOT EQUAL TO CHKAC
4425 7430 SZL
4426 5313 JMP MT2ER /SPAT00 NOT EQUAL TO CHKAC
4427 7040 CMA
4430 0730 AND I SPAT01 /MQ PATTERN
4431 7040 CMA
4432 1332 TAD CHKM0 /CHECK PATTERN MQ
4433 7040 CMA
4434 7440 SZA /TEST MQ BITS
4435 5313 JMP MT2ER /SPAT01 NOT EQUAL TO CHKM0
4436 7430 SZL
4437 5313 JMP MT2ER /SPAT01 NOT EQUAL TO CHKM0
4440 7040 CMA
4441 0734 AND I SCANM /SCA COUNT PATTERN
4442 7041 CIA
4443 1733 TAD I CHKSCA /CHECK PATTERN SCA
4444 7420 SNL
4445 5313 JMP MT2ER /SCANM NOT EQUAL TO CHKSCA
4446 2336 ISZ AGAIN /4096 REPEATS CURRENT TEST
4447 5202 JMP NORMT2+2

4450 4540 NMTS1, JMS I TSTSW1
4451 5202 JMP NORMT2+2
4452 5345 JMP PATCH /JUMP TO SW3

4453 0000 GEX, 0
4454 7240 CLA CMA
4455 0337 AND TPFLAG
4456 7040 CMA
4457 7440 SZA
4460 5262 JMP ,+2 /GENERATE 0000 MQ PATTERN
4461 5271 JMP ,+10 /GENERATE 0001 MQ PATTERN
4462 7200 CLA
4463 3726 DCA I PAT00 /STORE AC PATTERN

```

4464	3725		DCA I PAT01	/STORE MQ PATTERN
4465	3331		DCA CHKAC	/STORE AC CHECK
4466	3332		DCA CHKM0	/STORE MQ CHECK
4467	3733		DCA I CHKSCA	/STORE SCA CHECK
4470	5653		JMP I GEX	
4471	7240		CLA CMA	
4472	0335		AND SCANM+1	/MQ PATTERN (0001)
4473	3725		DCA I PAT01	/STORE MQ PATTERN
4474	7040		CMA	
4475	0340		AND TPFLAG+1	/22 DECIMAL PLACES (0030)
4476	3733		DCA I CHKSCA	
4477	3726		DCA I PAT00	/STORE AC PATTERN
4500	3332		DCA CHKM0	/STORE MQ CHECK
4501	7040		CMA	
4502	0341		AND TPFLAG+2	/20000
4503	3331		DCA CHKAC	/STORE AC CHECK
4504	5653		JMP I GEX	
4505	7240	HKE,	CLA CMA	/HOUSE KEEPING
4506	0342		AND TPFLAG+3	/7776
4507	3337		DCA TPFLAG	/LOAD FLAG
4510	3336		DCA AGAIN	/CHECK TEST COUNTER
4511	4531		JMS I MODSEL	/PERFORM MODE SELECTION
4512	5201		JMP NORMT2+1	
4513	4541	MTZER,	JMS I TSTSW2	/CHECK SR 2
4514	4743		JMS I TPFLAG+4	/PRINT ROUTINE
4515	7604		CLA OSR	/TEST SW0
4516	7104		RAL CLL	
4517	7430		SZL	
4520	7402		HLT	/NORMALIZE ERROR
4521	5250		JMP NMTS1	
4522	4542	NMTS3,	JMS I TSTSW3	/CHECK SR 3
4523	5200		JMP NORMT2	/CONTINUE
4524	5744		JMP I TPFLAG+5	
4525	3705	PAT01,	MQNMIX	
4526	3704	PAT00,	ACNMIX	
4527	3707	SPAT00,	ACNMIN	
4530	3706	SPAT01,	MQNMIN	
4531	0000	CHKAC,	0	
4532	0000	CHKM0,	0	
4533	3703	CHKSCA,	SCASTX	
4534	3700	SCANM,	SCAST	
4535	0001		0001	
4536	0000	AGAIN,	0	
4537	0000	TPFLAG,	0	
4540	0026		0026	
4541	2000		2000	
4542	7776		7776	
4543	4000		PRNMI	
4544	4600		COMTST	
4545	2337	PATCH,	ISZ TPFLAG	

546 5201 JMP NORMT2+1  
4547 5322 JMP NMTS3

4600 PAGE

## /TEST OF EAE NOP

4600 7240 COMTST, CLA CMA /7777  
4601 7421 MQL /MQ=7777  
4602 7501 MQA /AC=7777  
4603 7401 NOPM /EAE NOP  
4604 7410 SKP  
4605 7402 HLT /NOP SKIPPED  
4606 7040 CMA /0  
4607 7640 SZA CLA /  
4610 7402 HLT /AC MODIFIED BY NOPM  
4611 7501 MQA /MQ TO AC  
4612 7040 CMA /AC SHOULD NOW BE 0  
4613 7440 SZA /WAS IT 0?  
4614 7402 HLT /NO, MQ WAS MODIFIED BY NOPM

## /TEST OF EAE CLA

4615 7240 CLA CMA /7777  
4616 7421 MQL /MQ=7777  
4617 7501 MQA /AC=7777  
4620 7601 CLAM /EAE CLA  
4621 7410 SKP  
4622 7402 HLT /CLAM SKIPPED.  
4623 7640 SZA CLA /  
4624 7402 HLT /CLAM FAILED TO CLEAR THE AC.  
4625 7501 MQA /MQ TO AC  
4626 7040 CMA /AC SHOULD NOW BE 0  
4627 7440 SZA /WAS IT 0?  
4630 7402 HLT /MQ MODIFIED BY CLAM

## /TEST OF EAE CAM

4631 7240 CLA CMA /AC=7777  
4632 7421 MQL /MQ=7777  
4633 7501 MQA /AC=7777  
4634 7621 CAM /CLEAR THE AC AND MQ.  
4635 7501 MQA /MQ OR'ED WITH AC.  
4636 7440 SZA /WERE THEY BOTH 0?  
4637 7402 HLT /AC OR MQ NOT CLEARED BY CAM.

## /TEST OF EAE SWP

4640 7200 CLA /0,  
4641 1174 TAD [5252 /5252  
4642 7421 MQL /MQ=5252  
4643 1173 TAD [2525 /AC=2525  
4644 7521 SWP /SWAP AC AND MQ; AC=5252 \* MQ=2525  
4645 1173 TAD [2525 /AC=7777  
4646 7040 CMA /AC=0000

4647	7440	SZA		
4650	7402	HLT		/SWP FAILED.
4651	7501	MQA		/AC=2525
4652	1174	TAD	[5252	/AC=7777
4653	7040	CMA		/AC SHOULD BE 0
4654	7440	SZA		
4655	7402	HLT		/SWP FAILED.
/TEST OF ACL (MQA CLAM).				
4656	7621	CAM		/AC AND MQ = 0
4657	1173	TAD	[2525	/AC=2525
4660	7421	MLL		/MQ=2525
4661	1174	TAD	[5252	/AC=5252
4662	7701	ACL		/CLA THE AC AND LOAD AC FROM MQ.
4663	1174	TAD	[5252	/AC=7777
4664	7040	CMA		/AC=0
4665	7440	SZA		
4666	7402	HLT		/ACL FAILED.
/TEST OF DLD (CAM DAD).				
4667	7431	SWAB		/B MODE.
4670	7621	CAM		/AC AND MQ = 0
4671	1173	TAD	[2525	/AC=2525
4672	7421	MLL		/MQ=2525
4673	1174	TAD	[5252	/AC=5252
4674	7663	DLD		/EAE DOUBLE PRECISION LOAD.
4675	4677	,+2		/ADDRESS OF LSH OPERAND.
4676	5301	JMP	,+3	/GO OVER.
4677	5252	5252		/LSH OPERAND
4700	2525	2525		/MSH OPERAND
4701	1174	TAD	[5252	/AC=7777
4702	7040	CMA		/AC=0
4703	7440	SZA		
4704	7402	HLT		/DLD FAILED.
4705	7501	MQA		/MQ TO AC.
4706	1173	TAD	[2525	/AC=7777
4707	7040	CMA		/AC=0
4710	7440	SZA		
4711	7402	HLT		/DLD FAILED.
/TEST OF DDZ (CAM DST).				
4712	7431	SWAB		/B MODE.
4713	7621	CAM		/AC AND MQ ARE 0
4714	1173	TAD	[2525	/AC=2525
4715	7421	MLL		/MQ=2525
4716	7501	MQA		/AC=2525
4717	3326	DCA	,+7	/LSH=2525
4720	1174	TAD	[5252	/AC=5252
4721	3327	DCA	,+6	/MSH=5252
4722	1174	TAD	[5252	/AC=5252
4723	7665	DDZ		/EAE DOUBLE PRECISION DEPOSIT ZERO.
4724	4726	,+2		/OPERAND OF LSH

```

      25 5330      JMP      ,+3      /GO
      726 0000      OPEN      /LSH
      4727 0000      OPEN      /MSH
      4730 7501      MQA      /MQ OR'ED WITH AC;
      4731 7440      SZA      /BOTH 0?
      4732 7402      HLT      /NO, AC OR MQ NOT 0.
      4733 1326      TAD      ,=5      /GET C(LSH)
      4734 7440      SZA      /0?
      4735 7402      HLT      /NO, DDZ FAIL'ED.
      4736 1327      TAD      ,=7      /GET C(MSH)
      4737 7440      SZA      /0?
      4740 7402      HLT      /DDZ FAIL'ED, AC DID NOT GET STORED AS 0.

      4741 7447      SWBA      /GO TO A MODE.
      4742 4542      JMS I    TSTSWS /REMAIN IN THIS TEST
      4743 5200      JMP      COMTST /YES, SR3=1
      4744 2116      ISZ      COUNT /DO THIS TEST 4096 TIMES BEFORE EXIT.
      4745 5200      JMP      COMTST /REPEAT THE TESTS UNTIL DONE.
      4746 5777      JMP      E3A    /GO PRINT OR SOMETHING.

```

```

      4777 5250
           5000

```

PAGE

```

      5000 0000      TSCL, OPEN      /MODE, GT, AND SC TESTS

```

/TEST OF MODE SWITCHING.

```

      5001 7671      MDTST, SKB      /SKIP IF MODE B.
      5002 7610      SKP CLA      /
      5003 7402      HLT      /CLEAR KEY FAILED TO SET TO "A" MODE OR SKB FAIL'ED.
      5004 7431      SWAB      /CHANGE TO "B" MODE.
      5005 7671      SKB      /SKIP IF MODE B.
      5006 7402      HLT      /SWAB FAILED TO SET TO MODE B OR SKB FAIL'ED.
      5007 7447      SWBA      /CHANGE TO MODE A.
      5010 7671      SKB      /WAS IT MODE "A"?
      5011 7410      SKP      /YES
      5012 7402      HLT      /SWBA FAILED TO SET TO MODE A.
      5013 7431      SWAB      /B MODE.
      5014 6007      CAF      /INITIALIZE (SET TO MODE A.)
      5015 7671      SKB      /DID MODE "A" GET SET?
      5016 7610      SKP CLA      /YES
      5017 7402      HLT      /CAF FAILED TO SET MODE A.

```

/STEP COUNTER TESTS.

```

      5020 7200      SCL1, CLA      /TEST SCL=0
      5021 7403      7403      /SCL
      5022 7737      7737      /SC=0
      5023 7441      SCA
      5024 7640      CLA SZA
      5025 7402      ESCL1, HLT      /ERROR; SC NOT=0
      5026 7403      SCL2, 7403      /TEST SCL=01
      5027 7776      7776      /SC=1

```

5030	7441		SCA	
5031	1227		TAD	,=2
5032	7040		CMA	
5033	7640		CLA	SZA
5034	7402	ESCL2,	HLT	/ERROR/ SC NOT=01
5035	7403	SCL3,	7403	/TEST SCL=02
5036	7775		7775	/SC=2
5037	7441		SCA	
5040	1236		TAD	,=2
5041	7040		CMA	
5042	7640		CLA	SZA
5043	7402	ESCL3,	HLT	/ERROR/ SC NOT=02
5044	7403	SCL4,	7403	/TEST SCL=04
5045	7773		7773	/SC=4
5046	7441		SCA	
5047	1245		TAD	,=2
5050	7040		CMA	
5051	7640		CLA	SZA
5052	7402	ESCL4,	HLT	/ERROR/ SC NOT = 04
5053	7403	SCL5,	7403	/TEST SCL=10
5054	7767		7767	/SC=10
5055	7441		SCA	
5056	1254		TAD	,=2
5057	7040		CMA	
5060	7640		CLA	SZA
5061	7402	ESCL5,	HLT	/ERROR/ SC NOT=10
5062	7403	SCL6,	7403	/TEST SCL=20
5063	7757		7757	/SC=20
5064	7441		SCA	
5065	1263		TAD	,=2
5066	7040		CMA	
5067	7640		CLA	SZA
5070	7402	ESCL6,	HLT	/ERROR/ SC NOT=20
5071	7403	SCL7,	7403	/TEST SCL=12
5072	7765		7765	/SC=12
5073	7441		SCA	
5074	1272		TAD	,=2
5075	7040		CMA	
5076	7640		CLA	SZA
5077	7402	ESCL7,	HLT	/ERROR/ SC NOT=12
5100	7403	SCL8,	7403	/TEST SCL=25
5101	7752		7752	
5102	7441		SCA	
5103	1301		TAD	,=2
5104	7040		CMA	
5105	7640		CLA	SZA
5106	7402	ESCL8,	HLT	/ERROR/ SC NOT=25
5107	7403	SCL9,	7403	/TEST SCL=0
5110	0077		0077	/SC=0
5111	7441		SCA	
5112	7640		CLA	SZA
5113	7402	ESCL9,	HLT	/ERROR/ SC NOT=0
5114	7403	SCL10,	7403	/TEST SCL=37

5115	7700		7700	
5116	7441		SCA	
5117	1117		TAD K7740	
5120	7040		CMA	
5121	7640		CLA SZA	
5122	7402	ESCL10,	HLT	/ERROR; SC NOT 39
5123	7403	SCL11,	SCL	/LOAD THE SC WITH
5124	7777		7777	/0000
5125	7240		CLA CMA	/7777
5126	7441		SCA	/SC TO AC
5127	7040		CMA	
5130	7440		SZA	
5131	7402	ESCL11,	HLT	/SC DID NOT "OR" WITH AC.
5132	7403	SCL12,	SCL	/LOAD SC WITH
5133	7752		7752	/29
5134	7200		CLA	
5135	1333		TAD	,#2
5136	7441		SCA	/SC TO AC
5137	7040		CMA	
5140	7440		SZA	
5141	7402	ESCL12,	HLT	/SC DID NOT "OR" WITH THE AC.
5142	7403	SCL13,	SCL	/LOAD THE SC
5143	7765		7765	/WITH 12.
5144	7200		CLA	
5145	1343		TAD	,#2
5146	7441		SCA	/SC TO AC
5147	7040		CMA	
5150	7440		SZA	/
5151	7402	ESCL13,	HLT	/SC DID NOT "OR" WITH THE AC.

/TEST OF THE ACS INSTRUCTION.

5152	7431	ACS1,	SWAB	/CHANGE TO MODE B
5153	7360		CLA CMA CLL CML	/AC=7777 L=1
5154	7403		ACS	/AC TO SC
5155	7430		SZL	
5156	7440		SZA	
5157	7402		HLT	/ACS CLEARED THE LINK OR ACS FAILED /TO CLEAR THE AC;
5160	7441		SCA	/SC TO AC
5161	1117		TAD K7740	
5162	7040		CMA	
5163	7440		SZA	
5164	7402		HLT	/ACS FAILED TO LOAD THE STEP COUNTER WITH 39.
5165	7320	ACS2,	CLA CML CLL	/AC=0, L=1.
5166	1117		TAD K7740	
5167	7403		ACS	/AC TO SC
5170	7430		SZL	
5171	7440		SZA	
5172	7402		HLT	/ACS CLEARED LINK OR ACS FAILED TO CLEAR AC.
5173	7441		SCA	/SC TO AC

— AC = 7777 L = 1

AC = 40 L = 0

AC = 7740 L = 1

```

5174 7440 SZA /
5175 7402 HLT /AGS FAILED TO LOAD THE STEP COUNTER WITH 0.
5176 5777 JMP GTTS1 /GO TO THE GT FLAG TEST.

5177 5200 PAGE
5200 PAGE

/TEST OF THE GT FLAG.

5200 7431 GTTS1, SWAB /B MODE.
5201 7300 CLA CLL
5202 4550 JMS I RTFX /RESTORE FLAGS, WE'RE ONLY CONCERNED WITH THE GT.
5203 6004 GTF /GET THE FLAGS.
5204 0377 AND (2000 /SAVE THE GT FLAG.
5205 7006 RTL /PUT THE GT FLAG INTO THE LINK.
5206 7430 SZL /GT A 1?
5207 7402 HLT /YES, RTF FAILED TO REESET GT OR
/GTF FAILED TO GET IT.

5210 7431 GTTS2, SWAB /B MODE.
5211 7332 CLA CLL CML RTR /2000
5212 4550 JMS I RTFX /RESTORE FLAGS, SET GT TO A 1.
5213 6004 GTF /GET THE FLAGS.
5214 0377 AND (2000 /SAVE ONLY THE GT FLAG.
5215 7006 RTL /PUT IT IN THE LINK TO CHECK.
5216 7420 SNL /LINK A ZERO INDICATING GT WAS A 0?
5217 7402 HLT /YES, RTF FAILED TO SET GT OR GTF
/FAILED TO GET IT.

5220 7431 GTTS3, SWAB /B MODE.
5221 7300 CLA CLL
5222 4550 JMS I RTFX /RESTORE THE FLAGS.
5223 6006 SGT /GT FLAG = 0?
5224 7410 SKP /YES, OK
5225 7402 HLT /SGT SKIPPED ON NO GT FLAG.

5226 7431 GTTS4, SWAB /MODE B.
5227 7332 CLA CLL CML RTR /2000
5228 4550 JMS I RTFX /RESTORE THE FLAGS.
5229 6006 SGT /GT FLAG = 1?
5230 7402 HLT /SGT DID NOT SKIP WITH GT = 1

5233 7431 GTTS5, SWAB /MODE B.
5234 7332 CLA CLL CML RTR /2000
5235 4550 JMS I RTFX /RESTORE THE FLAGS.
5236 7447 SWBA /GO TO A MODE.
5237 6006 SGT /GT FLAG SET?
5238 7610 SKP CLA /NO, OK
5239 7402 HLT /SWBA FAILED TO CLEAR THE GT FLAG.
5240 4542 JMS I TS1SW3 /REMAIN IN THIS TEST?
5241 5776 JMP MD1ST /YES, SR3=1
5242 2116 ISZ COUNT /FINISHED TEST 4096 TIMES.
5243 5776 JMP MD1ST /REPEAT INITIAL TESTS
5244 6007 CAF /CLEAR AND SET TO MODE "A".
5245 5775 JMP MQLT /EXIT INITIAL TESTS.

```

/END OF TEST PRINT=OUT ROUTINE.

```

5250 4520 E3A, JMS I CRLF /CR AND LF;
5251 1114 TAD MODE /GET THE MODE; 0="A"; 7777="B";
5252 7650 SNA CLA /WHICH MODE?
5253 5256 JMP ,+3 /A MODE SO DON'T PRINT;
5254 4447 JMS I XTYPST /TYPE A MESSAGE
5255 7510 KE8SP1 /"KEB 1"
5256 1114 TAD MODE /GET MODE
5257 7140 CMA CLL /CHANGE IT TO THE OPPOSITE MODE;
5260 3114 OCA MODE /RESET MODE;
5261 6007 CAP /INITIALIZE
5262 5774 JMP MQLT=1 /START FROM THE BEGINNING

```

/ROUTINE TO SELECT MODE;

```

5263 0000 MDSEL, OPEN
5264 7604 LAS /READ THE SWITCHES;
5265 7112 CLL RTR /SR10 TO LINK; SR11 TO ACB;
5266 7430 SZL /SR 10 SET?
5267 5300 JMP S10SET /YES;
5270 7200 CLA
5271 1114 TAD MODE /GET MODE
5272 7640 SZA CLA /WHICH MODE?
5273 5276 JMP ,+3 /"B" MODE
5274 7447 SWBA /SET TO "A" MODE
5275 5663 JMP I MDSEL /EXIT SET TO "A" MODE;
5276 7431 SWAB /SET TO "B" MODE
5277 5663 JMP I MDSEL /EXIT SET TO "B" MODE;
5300 7710 S10SET, SPA CLA /SR11=0?
5301 5304 JMP ,+3 /NO, SR11=i, SO SELECT MODE "B";
5302 3114 OCA MODE /SELECT MODE "A"
5303 5270 JMP MOSEL+5 /EXIT;
5304 7140 CLL CMA /7777 IN ORDER TO SELECT "B" MODE;
5305 5302 JMP ,+3 /EXIT;

```

/ROUTINE TO EXIT TEST IF MODE "A" IS SELECTED;

```

5306 0000 UONLYB, OPEN
5307 7200 CLA
5310 1114 TAD MODE
5311 7700 SMA CLA
5312 5773 JMP GEN+3
5313 5706 JMP I UONLYB

```

/ROUTINE TO CHECK SR0;

```

5314 0000 SW0TST, OPEN
5315 7604 LAS
5316 7710 SPA CLA
5317 5714 JMP I SW0TST
5320 2314 ISZ SW0TST
5321 5714 JMP I SW0TST

```

/ROUTINE TO CHECK SR1;

```

5322 0000 SW1TST, OPEN
5323 7604 LAS
5324 7004 RAL
5325 7710 SPA CLA
5326 5722 JMP I SW1TST
5327 2322 ISZ SW1TST
5330 5722 JMP I SW1TST

```

/ROUTINE TO CHECK SR2.

```

5331 0000 SW2TST, OPEN
5332 7604 LAS
5333 7106 RTL CLL
5334 7710 SPA CLA
5335 5731 JMP I SW2TST
5336 2331 ISZ SW2TST
5337 5731 JMP I SW2TST

```

/ROUTINE TO CHECK SR3.

```

5340 0000 SW3TST, OPEN
5341 7604 LAS
5342 7106 RTL CLL
5343 7104 RAL CLL
5344 7710 SPA CLA
5345 5740 JMP I SW3TST
5346 2340 ISZ SW3TST
5347 5740 JMP I SW3TST

```

/ROUTINE TO SAVE REGISTERS.

```

5350 0000 USVREG, OPEN
5351 3033 DCA ACTOCK /SAVE AC
5352 7701 CLA MQA
5353 3034 DCA MQTOCK /SAVE MQ
5354 7210 CLA RAR
5355 3032 DCA LKTOCK /SAVE LINK
5356 7641 CLA SCA
5357 3035 DCA SCTOCK /SAVE STEP COUNTER
5360 6004 GTF
5361 0377 AND (2000
5362 7104 CLL RAL
5363 3036 DCA GTTOCK /SAVE GTFLAG
5364 5750 JMP I USVREG /EXIT, AC=0

```

```

5373 5603
5374 0202
5375 0203
5376 5001
5377 2000
5400 PAGE

```

```

5400 0000 NMIXX, 0
5401 4777 JMS PNORM

```

402	5600		JMP I NMIXX	
5403	0000	SCATXX,	0	
5404	4212		JMS PSTEP	
5405	4223		JMS PSTEP	
5406	5603		JMP I SCATXX	
5407	0000	SCAXX,	0	
5410	4212		JMS PSTEP	
5411	5607		JMP I SCAXX	
5412	0000	PSTEP,	0	
5413	7240		CLA CMA	
5414	0253		AND N+4	
5415	4522		JMS I PRXLOP	/PRINT,
5416	1254		TAD N+5	
5417	4522		JMS I PRXLOP	/PRINT,
5420	1255		TAD N+6	
5421	4522		JMS I PRXLOP	/PRINT,
5422	5612		JMP I PSTEP	
5423	0000	PSTEPT,	0	
5424	7240		CLA CMA	
5425	0252		AND N+3	
5426	4522		JMS I PRXLOP	/PRINT,
5427	5623		JMP I PSTEPT	
5430	0000	PC,	OPEN	
5431	7200		CLA	
5432	1076		TAD C	
5433	4522		JMS I PRXLOP	
5434	5630		JMP I PC	/EXIT,
5435	0000	LPAR,	OPEN	
5436	7200		CLA	
5437	1376		TAD (0250 /	
5440	4522		JMS I PRXLOP	
5441	5635		JMP I LPAR	/EXIT,
5442	0000	RPAR,	OPEN	
5443	7200		CLA	
5444	1375		TAD (251	
5445	4522		JMS I PRXLOP	
5446	5642		JMP I RPAR	/EXIT,
5447	0316	N,	0316 /N	
5450	0315		0315 /M	
5451	0311		0311 /I	
5452	0324		0324 /T	
5453	0323		0323 /S	
5454	0303		0303 /C	
5455	0301		0301 /A	

/ROUTINE TO LOAD THE STEP COUNTER.

```

5456 0000  ULOSC, OPEN
5457 1114          TAD      MODE
5460 7640          SZA CLA
5461 5270          JMP      LDSC1
5462 1023          TAD      TOSHIF
5463 7040          CMA
5464 3266          DCA      ,+2
5465 7403          SCL
5466 0000          OPEN
5467 5656          JMP I   ULOSC
5470 1023  LDSC1, TAD      TOSHIF
5471 7403          ACS
5472 5656          JMP I   ULOSC

```

/ROUTINE TO SET COMPARE ROUTINE AND DO OTHER JOBS:

```

5473 0000  SCOMP, OPEN
5474 7300          CLA CLL
5475 4550          JMS I   RFX          /CLEAR THE GF
5476 1172          TAD      ELSIM
5477 3774          DCA      C1
5500 1171          TAD      CLKTOCK
5501 3773          DCA      C2
5502 3020          DCA      TOLINK
5503 3772          DCA      WILCHG      /MAKE "WILCHG" EFFECTIVELY AN AND 0
                                        /WHICH IS REALLY A DO NOTHING INSTRUCTION.
5504 3771          DCA      PRCHG      /MAKE "PRCHG" EFFECTIVELY AN AND 0
                                        /WHICH IS REALLY A DO NOTHING INSTRUCTION.
5505 4452          JMS I   UMOVE
5506 0020          TOLINK
5507 0021          TOAC
5510 7753          =25
5511 5673          JMP I   SCOMP      /EXIT, AC=0, L=0.

```

/ROUTINE FOR DPSZ PRINTOUT

```

5512 0000  DPSZPR, OPEN
5513 4521          JMS I   CRLF2      /2 CR AND LF.
5514 4447          JMS I   XTYPST
5515 0000  DPZPR1, OPEN
5516 5712          JMP I   DPSZPR      /EXIT,

```

```

5571 7002
5572 7016
5573 6360
5574 6357
5575 0251
5576 0250
5577 4132
5600

```

PAGE

/UP-COUNT GENERATOR

```

000 0000 GEN, 0
5601 2064 ISE GENX
5602 5600 JMP I GEN
5603 7604 CLA OSR /TEST SW 3
5604 7106 RTL CLL
5605 7006 RTL
5606 7630 SZL CLA
5607 5435 JMP I BACK
5610 5436 JMP I NEXT

/Routine TO DO A CR AND LF

5611 0000 UCRLF, OPEN
5612 7240 CLA CMA
5613 0067 AND CR /CR
5614 4322 JMS I PRXLOP /PRINT
5615 1070 TAD LF /"LINE FEED"
5616 4322 JMS I PRXLOP /PRINT
5617 5611 JMP I UCRLF /EXIT

/Routine TO DO 2 CR AND LF

5620 0000 UCRLF2, OPEN
5621 4320 JMS I CRLF
5622 4320 JMS I CRLF
5623 5620 JMP I UCRLF2 /EXIT, AC = 0

5624 0000 RXLOP, 0
5625 6046 TIS /PRINT LOOP
5626 6041 TSP
5627 5226 JMP ,=1
5630 7200 CLA
5631 5624 JMP I RXLOP

5632 0000 UPLINK, 0
5633 7240 CLA CMA
5634 0101 AND LINK /LINK
5635 4237 JMS UONZER
5636 5632 JMP I UPLINK

5637 0000 UONZER, 0
5640 7440 SZA
5641 5244 JMP UONEP /PRINT ONE
5642 4250 JMS UZEROR /PRINT ZERO
5643 5637 JMP I UONZER

5644 7240 UONEP, CLA CMA /ONE
5645 0077 AND ONE
5646 4322 JMS I PRXLOP /PRINT
5647 5637 JMP I UONZER

5650 0000 UZEROR, 0
5651 7240 CLA CMA
5652 0100 AND ZERO /ZERO

```

5653 4522 JMS I PRXLOP /PRINT'  
 5654 5650 JMP I UZEROR

5655 0000 UMESSG, OPEN  
 5656 7240 CLA CMA  
 5657 0103 AND COUNTX  
 5660 3104 DCA STRCNT  
 5661 2104 ISZ STRCNT  
 5662 7410 SKP  
 5663 5655 JMP I UMESSG /EXIT'  
 5664 7240 CLA CMA  
 5665 0105 AND BITSTR  
 5666 7100 CLL  
 5667 7004 RAL  
 5670 3105 DCA BITSTR  
 5671 7430 SZL  
 5672 5275 JMP UPRONE  
 5673 4250 JMS UZEROR  
 5674 5261 JMP ,=13

5675 7240 UPRONE, CLA CMA  
 5676 0077 AND ONE /ONE  
 5677 4522 JMS I PRXLOP /PRINT'  
 5700 5261 JMP UMESSG+4

5701 0000 UTYTST, OPEN  
 5702 4521 JMS I CR LF2 /CR AND LF'  
 5703 1701 TAD I UTYTST /OBTAIN NUMBER OF WORDS  
 5704 3115 DCA ANYUSE /SAVE FOR DURATION OF THIS ROUTINE'  
 5705 2301 ISZ UTYTST /SET UP TO GET NEXT WORD'  
 5706 1701 TAD I UTYTST /GET THE WORD'  
 5707 3311 DCA ,+2 /STASH IT AWAY'  
 5710 4447 JMS I XTYPST /NOW PRINT THE WORD JUST STASHED AWAY'  
 5711 0000 OPEN /WORD TO BE PRINTED,  
 5712 4454 JMS I U2SPC /2 SPACES,  
 5713 2115 ISZ ANYUSE /DONE ALL THE WORDS SET UP FOR?  
 5714 5305 JMP ,=9 /NO, REPEAT'  
 5715 4453 JMS I U1SPC /YES, 1 SPACE'  
 5716 2301 ISZ UTYTST /SET UP FOR EXIT'  
 5717 5701 JMP I UTYTST /EXIT THIS ROUTINE. AC EQUALS ZERO'

5720 0000 UP1BIT, OPEN  
 5721 3101 DCA LINK  
 5722 4523 JMS I PLINK  
 5723 5720 JMP I UP1BIT /EXIT'

/ROUTINE TO LOAD REGISTERS WITH RANDOM DATA'

5724 0000 RANDAT, OPEN  
 5725 4544 JMS I RANDOM /GET RANDOM DATA'  
 5726 3021 DCA TOAC /SAVE FOR THE AC  
 5727 7010 RAR /LINK TO AC0  
 5730 3020 DCA TOLINK /SAVE FOR THE LINK  
 5731 4544 JMS I RANDOM /GET RANDOM DATA

```

5732 3022      DCA      TOMQ      /SAVE FOR THE MQ
5733 7010      RAR
5734 3024      DCA      TOGT      /LINK TO AC0
5735 4544      JMS I   RANDOM     /SAVE FOR THE GT
5736 0170      AND      C37        /GET RANDOM DATA
5737 3023      DCA      TOSHIF    /KEEP AC 7-11
5740 2113      ISZ      SCOUNT   /SAVE FOR THE STEP COUNTER
5741 5724      JMP I   RANDAT
5742 5203      JMP

```

/ROUTINE TO LOAD MQ, GT, AND LINK.

```

5743 0000      ULDRG, OPEN
5744 7300      CLA CLL
5745 1022      TAD      TOMQ
5746 7421      MQL
5747 4547      JMS I   LDGT
5750 1020      TAD      TOLINK
5751 7104      CLL      RAL
5752 5743      JMP I   ULDRG

```

```

/MQ LOADED;
/LOAD THE GT
/LINK LOADED;

```

/ROUTINE TO LOAD THE GT.

```

5753 0000      ULDGT, OPEN
5754 7200      CLA
5755 1024      TAD      TOGT
5756 7110      CLL RAR
5757 4550      JMS I   RTFX
5760 5753      JMP I   ULDGT

```

```

/GET THE GT DATA
/MOVE TO AC1
/NOW LOAD
/EXIT

```

6000 PAGE

/SUBROUTINE TO LOAD GT.

```

6000 0000      XRTF, OPEN
6001 3115      DCA      ANYUSE
6002 6214      RDP
6003 7112      CLL RTR
6004 7010      RAR
6005 6224      RIF
6006 1115      TAD      ANYUSE
6007 6005      RTP
6010 6002      IOP
6011 7300      CLA CLL
6012 5600      JMP I   XRTF

```

```

/SAVE DATA TO BE PLACED IN THE GT;
/READ THE DATA FIELD;
/OP NOW IN AC 9-11
/READ THE INSTRUCTION FIELD;
/GT DATA IN AC ALONG WITH IP AND DP;
/RESTORE THE FLAGS;
/DO AWAY WITH THE YON CAUSED BY RTP;
/CLEAR FOR THE EXIT;
/EXIT; AC AND LINK ARE ZERO;

```

/ROUTINE TO SIMULATE THE SUBTRACT AC FROM MQ INSTRUCTION.

```

6013 0000      SAMSIM, OPEN
6014 7300      CLA CLL
6015 1021      TAD      TOAC
6016 7041      CMA IAC

```

```

/GET ORIGINAL AC
/NEGATE IT;

```

6017	1022	TAD	TOMQ	/ADD ORIGINAL MQ TO IT
6020	3042	DCA	MSH	/SAVE AS MQ = AC
6021	1022	TAD	TOMQ	/BRING BACK THE ORIGINAL MQ.
6022	3043	DCA	LSH	/AND SAVE IT
6023	7010	RAR		/GET LINK INTO AC0
6024	3041	DCA	LSIM	/SAVE IT
6025	1021	TAD	TOAC	/GET ORIGINAL AC
6026	0167	AND	[4000	/SAVE THE SIGN BIT ONLY
6027	1022	TAD	TOMQ	/ADD ORIGINAL MQ TO IT
6030	7710	SPA	CLĀ	/AC0 = 1?
6031	5245	JMP	B0DIFF	/YES, AC AND MQ HAD DIFFERENT SIGNS
6032	1021	TAD	TOAC	/NO, SAME SIGNS, GET ORIGINAL AC
6033	0166	AND	[3777	/KILL THE SIGN BIT
6034	7041	CIA		/NEGATE IT
6035	3037	DCA	TEMPA	/SAVE FOR A MOMENT
6036	1022	TAD	TOMQ	/ORIGINAL MQ TO AC
6037	0166	AND	[3777	/KILL THE SIGN BIT
6040	1037	TAD	TEMPA	/NOW ADD THE UNSIGNED 2'S COMPLEMENT OF THE AC TO IT
6041	7040	CMA		/COMPLEMENT = (ONLY FOR BIT 0)
6042	0167	AND	[4000	/SAVE BIT 0 =
6043	3045	DCA	GTSIM	/AS THE SIMULATED GT FLAG
6044	5613	JMP	i	/EXIT, AC = 0
6045	1021	TAD	TOAC	/GET ORIGINAL AC
6046	0167	AND	[4000	/SAVE THE SIGN BIT
6047	3045	DCA	GTSIM	/AS THE GT FLAG
6050	5613	JMP	i	/EXIT, AC = 0

ROUTINE TO SIMULATE THE SHIFT LEFT INSTRUCTION:

6051	0000	SHLSIM, OPEN		/DOUBLE PRECISION SHIFT LEFT
6052	3044	DCA	SCSIM	/SAVE THE NUMBER OF SHIFTS TO BE PERFORMED
6053	1021	TAD	TOAC	/GET ORIGINAL AC
6054	3042	DCA	MSH	/MOST SIGNIFICANT HALF
6055	1022	TAD	TOMQ	/GET ORIGINAL MQ
6056	3043	DCA	LSH	/LEAST SIGNIFICANT HALF
6057	1024	TAD	TOGT	/GET ORIGINAL GT
6060	0114	AND	MODE	/AND THE MODE
6061	3045	DCA	GTSIM	/SAVE AS THE SIMULATED GT
6062	1044	TAD	SCSIM	/GET STEP COUNTER DATA
6063	1377	TAD	132	/ADD 32
6064	7710	SPA	CLĀ	/IF MORE THAN 31 SHIFTS THE RESULTS ARE PREDICTABLE
6065	5307	JMP	SHL031	/GO TO ROUTINE FOR MORE THAN 31 SHIFTS
6066	1044	TAD	SCSIM	/GET STEP COUNTER DATA
6067	7650	SNA	CLĀ	/IF 0 SHIFTS THE RESULTS ARE PREDICTABLE
6070	5313	JMP	SHIFTO	/GO TO ROUTINE FOR 0 SHIFTS
6071	1043	TAD	LSH	/GET CONTENTS OF LSH
6072	7104	CLL	RAL	/SHIFT LEFT
6073	3043	DCA	LSH	/SAVE THE SHIFTED DATA
6074	1042	TAD	MSH	/GET CONTENTS OF MSH
6075	7004	RAL		/SHIFT LEFT
6076	3042	DCA	MSH	/SAVE THE SHIFTED DATA
6077	2044	ISZ	SCSIM	/DONE NECESSARY SHIFTS?

```

6100 5271      JMP      =7      /NO
6101 7210      CLA RAR    /MOV. LINK INTO AC0;
6102 3041      DCA      LSIM    /SAVE AS SIMULATED LINK
6103 1114      TAD      MODE    /MODE IN AC. 7777=B, 0000=A.
6104 0170      AND      [37    /"AND" WITH A 37
6105 3044      DCA      SCSIM   /SAVE AS SIMULATED SC;
6106 5651      JMP I   SHLSIM   /EXIT WITH MOST SIGNIFICANT HALF IN "MSH"
                          /AND LEAST SIGNIFICANT HALF IN "LSH";

```

```

6107 7340      SHL031, CLA CMA CLL    /7777 TO
6110 3044      DCA      SCSIM   /SCSIM SO AN IMMEDIATE EXIT TAKES PLACE
6111 3043      DCA      LSH     /0 TO LSH
6112 5276      JMP      SHLA    /CONTINUE IN MAIN BODY;

```

```

6113 1020      SHIF0, TAD      TOLINK  /GET ORIGINAL LINK
6114 3041      DCA      LSIM    /SAVE AS SIMULATED LINK
6115 1170      TAD      [37     /37
6116 3044      DCA      SCSIM   /SAVE AS SIMULATED SC;
6117 5651      JMP I   SHLSIM   /EXIT; AC=0;

```

>ROUTINE TO SIMULATE THE LOGICAL SHIFT RIGHT INSTRUCTION:

```

6120 0000      LRSIM, OPEN    /DOUBLE PRECISION LOGICAL SHIFT RIGHT
6121 3044      DCA      SCSIM   /SAVE THE NUMBER OF SHIFTS TO BE PERFORMED;
6122 1044      TAD      SCSIM   /GET SHIFT DATA;
6123 1165      TAD      [31     /ADD 31 TO IT
6124 7710      SPA CLA    /IF MORE THAN 30 SHIFTS THE RESULTS ARE PREDICTABLE;
6125 5360      JMP      LSR030  /GO TO ROUTINE FOR MORE THAN 30 SHIFTS.
6126 1021      TAD      TOAC    /GET ORIGINAL AC;
6127 3042      DCA      MSH     /STORE IN MSH
6130 1022      TAD      TOMQ    /GET ORIGINAL MQ;
6131 3043      DCA      LSH     /STORE IN LSH
6132 1044      TAD      SCSIM   /GET SHIFT DATA
6133 7650      SNA CLA    /IF 0 SHIFTS, THE RESULTS ARE PREDICTABLE;
6134 5355      JMP      LSR0SH+4 /JUST DO THE NECESSARY AND EXIT;
6135 1042      LSHIFT, TAD     MSH     /GET CONTENTS OF MSH
6136 7110      CLL      RAR     /SHIFT RIGHT
6137 3042      DCA      MSH     /SAVE THE SHIFTED DATA
6140 1043      TAD      LSH     /GET CONTENTS OF LSH
6141 7010      RAR      /SHIFT RIGHT ONE;
6142 3043      LSRA,  DCA      LSH     /SAVE SHIFTED DATA
6143 2044      ISZ      SCSIM   /DONE NECESSARY SHIFTS;
6144 5335      JMP      LSHIFT  /NO, REPEAT
6145 3041      SEXIT, DCA     LSIM    /SAVE SIMULATED LINK
6146 7210      CLA     RAR
6147 0114      AND     MODE
6150 3045      DCA     GTSIM   /SAVE SIMULATED GT
6151 1170      LSR0SH, TAD   [37    /37
6152 0114      AND     MODE    /"AND" MODE;
6153 3044      DCA     SCSIM   /SAVE AS SIMULATED SC;
6154 5720      JMP I   LRSIM   /EXIT; AC=0;
6155 1024      TAD     TOGT    /
6156 3045      DCA     GTSIM   /GT REMAINS SAME ON 0 SHIFTS;
6157 5351      JMP     LSR0SH  /CONTINUE IN MAIN BODY;

```

6160 7340  
6161 3044  
6162 3042  
6163 5342

LSR030, CLA CLL CMA  
DCA SCSIM  
DCA MSH  
JMP LSRA

6177 0032  
6200

PAGE

/ROUTINE TO SIMULATE THE ARITHMETIC SHIFT RIGHT INSTRUCTION.

6200 0000  
6201 3044  
6202 1021  
6203 3042  
6204 1022  
6205 3043  
6206 1044  
6207 7650  
6210 5242  
6211 1044  
6212 1165  
6213 7710  
6214 5250  
6215 1042  
6216 7100  
6217 7510  
6220 7020  
6221 7010  
6222 3042  
6223 1043  
6224 7010  
6225 3043  
6226 2044  
6227 5215  
6230 7210  
6231 0114  
6232 3045  
6233 1042  
6234 0167  
6235 3041  
6236 1170  
6237 0114  
6240 3044  
6241 5600  
6242 1021  
6243 0167  
6244 3041  
6245 1024  
6246 3045  
6247 5236  
  
6250 1042  
6251 0167  
6252 7104

ASRSIM, OPEN  
DCA SCSIM /SAVE THE NUMBER OF SHIFTS TO BE PERFORMED;  
TAD TOAC /GET ORIGINAL AC  
DCA MSH /MOST SIGNIFICANT HALF;  
TAD TOMQ /GET ORIGINAL MQ;  
DCA LSH /LEAST SIGNIFICANT HALF;  
TAD SCSIM /GET SHIFT DATA  
SNA CLA /IF 0 SHIFTS THE RESULTS ARE PREDICTABLE  
JMP ASR0SH /JUST DO THE NECESSARY AND EXIT,  
TAD SCSIM /GET SHIFT DATA  
TAD [31 /31  
SPA CLA /IF MORE THAN 30 SHIFTS, THE RESULTS ARE PREDICTABLE;  
JMP ASR030 /GO TO ROUTINE FOR MORE THAN 30 SHIFTS  
SASR1, TAD MSH /GET MSH  
CLL /CLEAR THE LINK  
SPA /AC0=1?  
CML /YES, SET LINK  
RAR /SHIFT RIGHT  
DCA MSH /SAVE SHIFTED DATA  
TAD LSH /GET LSH  
RAR /SHIFT RIGHT  
DCA LSH /SAVE SHIFTED DATA  
ISZ SCSIM /DONE NECESSARY SHIFTS?  
JMP SASR1 /NO, REPEAT  
SASR1A, CLA RAR /LINK TO AC0  
AND MODE  
SASR2, DCA GTSIM /SAVE AS SIMULATED GT  
TAD MSH /GET MSH  
AND [4000 /KEEP AC0  
DCA LSIM /SAVE AS SIMULATED LINK  
SASR3, TAD [37 /37  
AND MODE /"AND" MODE "A"=0, "B"=7777  
DCA SCSIM /SAVE AS SIMULATED SC  
JMP I ASRSIM /EXIT, AC=0  
ASR0SH, TAD TOAC /GET ORIGINAL AC  
AND [4000 /KEEP AC0 ONLY  
DCA LSIM /SAVE AS SIMULATED LINK  
TAD TOGT /GET ORIGINAL GT  
DCA GTSIM /SAVE AS SIMULATED GT  
JMP SASR3 /CONTINUE IN MAIN BODY  
  
ASR030, TAD MSH /GET MSH  
AND [4000 /KEEP AC0  
CLL RAL /PUT INTO LINK

253	7620	SNL	CLA	/LIN	/INDICATING AC=1
254	5262	JMP	,+6	/NO,	/J WAS A 0
6255	7040	CMA		/YES,	/SET AC=7777
6256	3043	DCA	LSH	/SAVE	/AS SIMULATED MQ
6257	7040	CMA		/7777	
6260	3042	DCA	MSH	/SAVE	/AS SIMULATED AC
6261	5230	JMP	SASR1A	/CONTINUE	/IN MAIN BODY
6262	3043	DCA	LSH	/SAVE	/AS SIMULATED MQ
6263	5260	JMP	,=3	/SET	/SIMULATED AC

/ROUTINE TO SIMULATE THE DOUBLE PRECISION INCREMENT INSTRUCTION:

6264	0000	DPISIM,	OPEN	/SIMULATE	/DPI INSTRUCTION:
6265	1022	TAD	TOMQ	/GET	/WHAT WAS LOADED INTO THE MQ
6266	7101	CLL	IAC	/INCREMENT	/IT
6267	3043	DCA	LSH	/SAVE	/IT AS "SIMULATED MQ"
6270	7004	RAL		/LINK	/TO AC11; AC0 TO LINK
6271	1021	TAD	TOAC	/ADD	/WHAT WAS LOADED INTO THE AC
6272	3042	DCA	MSH	/STORE	/IT AS "SIMULATED AC"
6273	7010	RAR		/PUT	/LINK INTO AC0
6274	3041	DCA	LSIM	/STORE	/IT AS "SIMULATED LINK"
6275	1024	TAD	TOGT	/GET	/PROBLEM GT
6276	3045	DCA	GTSIM	/STORE	/IN SIMULATED GT ALSO
6277	1023	TAD	TOSHIF	/GET	/PROBLEM STEP COUNTER
6300	3044	DCA	SCSIM	/STORE	/IN SIMULATED SC
6301	5664	JMP	I DPISIM	/EXIT,	/AC AND LINK=0

/ROUTINE TO SIMULATE THE DOUBLE PRECISION COMPLEMENT INSTRUCTION:

6302	0000	DCMSIM,	OPEN	/DOUBLE	/PRECISION 2'S COMPLEMENT SIMULATOR:
6303	7300	CLA	CLL	/CLEAR	
6304	1022	TAD	TOMQ	/GET	/WHAT WAS LOADED INTO THE MQ
6305	7041	CMA	IAC	/2'S	/COMPLEMENT IT
6306	3043	DCA	LSH	/SAVE	/AS SIM MQ
6307	1021	TAD	TOAC	/GET	/WHAT WAS LOADED INTO THE AC
6310	7040	CMA		/1'S	/COMPLEMENT IT
6311	3042	DCA	MSH	/SAVE	/IT
6312	7004	RAL		/GET	/THE CARRY FROM 2'S COMPLEMENT OF MQ
6313	1042	TAD	MSH	/ADD	/1'S COMPLEMENT OF AC
6314	3042	DCA	MSH	/STORE	/AS 2'S COMPLEMENT OF AC
6315	7010	RAR		/GET	/LINK
6316	3041	DCA	LSIM	/SAVE	/IT
6317	5702	JMP	I DCMSIM	/EXIT,	/AC=0

/ROUTINE TO SIMULATE THE DOUBLE PRECISION ADD INSTRUCTION

6320	0000	DADSIM,	OPEN	/DOUBLE	/PRECISION ADD ROUTINE:
6321	7300	CLA	CLL	/CLEAR	
6322	1022	TAD	TOMQ	/GET	/ORIGINAL MQ
6323	1024	TAD	TOGT	/ADD	/ORIGINAL DATA IN "LEAST SIGNIFICANT"
6324	3043	DCA	LSH	/SAVE	/THE DATA
6325	7204	CLA	RAL	/LINK	/TO AC 11
6326	1021	TAD	TOAC	/ADD	/ORIGINAL AC TO IT
6327	1023	TAD	TOSHIF	/ADD	/ORIGINAL DATA IN "MOST SIGNIFICANT" TO IT

6330	3042	DCA	MSH	/SAVE THE DATA;
6331	7010	RAR		/LINK TO AC 0
6332	3041	DCA	LSIM	/SAVE AS SIMULATED LINK;
6333	5720	JMP I	DAOSIM	/EXIT; AC+LINK=0.

/ROUTINE TO COMPARE THE CONTENTS OF 2 LOCATIONS;

6334	0000	COMP,	OPEN		
6335	1734		TAD I	COMP	/GET AND STORE NUMBER OF
6336	3363		DCA	CMPCYR	/WORDS TO COMPARE;
6337	2334		ISZ	COMP	
6340	1357		TAD	C1	/ADDRESS IN C1
6341	3361		DCA	C1A	/C1A;
6342	1360		TAD	C2	/ADDRESS IN C2
6343	3362		DCA	C2A	/TO C2A;
6344	1761	COMP A,	TAD I	C1A	/GET "GOOD" WORD
6345	7041		C1A		/2'S COMPLEMENT IT
6346	1762		TAD I	C2A	/ADD RESULT WORD;
6347	7640		SZA	CLA	/RESULT ZERO;
6350	5734		JMP I	COMP	/NO, EXIT AC=0
6351	2361		ISZ	C1A	/YES; SET
6352	2362		ISZ	C2A	/FOR NEXT COMPARE
6353	2363		ISZ	CMPCYR	/DONE COMPARING
6354	5344		JMP	COMP A	/NO,
6355	2334		ISZ	COMP	/YES
6356	5734		JMP I	COMP	/EXIT; AC=0
6357	0000	C1,	OPEN		/CONTAINS ADDRESS OF "GOOD"
6360	0000	C2,	OPEN		/CONTAINS ADDRESS OF DATA TO BE COMPARED
6361	0000	C1A,	OPEN		/WILL CONTAIN "GOOD" DATA
6362	0000	C2A,	OPEN		/WILL CONTAIN DATA TO BE COMPARED
6363	0000	CMPCYR,	OPEN		/COUNTER;

6400 PAGE

6400	0000	MOVE,	0		
6401	7200		CLA		
6402	1600		TAD I	MOVE	/GET "FROM ADDR" AND
6403	3223		DCA	FADDR	/STORE AT FDDR
6404	2200		ISZ	MOVE	
6405	1600		TAD I	MOVE	/GET "TO ADDR" AND
6406	3224		DCA	TADDR	/STORE AT TDDR
6407	2200		ISZ	MOVE	
6410	1600		TAD I	MOVE	/GET "MOVE COUNT" AND
6411	3225		DCA	MCTR	/STORE AT MCTR
6412	2200		ISZ	MOVE	/SET UP EXIT ADDRESS
6413	7200	MOVE A,	CLA		
6414	1623		TAD I	FADDR	/GET "FROM" WORD
6415	3624		DCA I	TADDR	/STORE AT "TO" LOCATION
6416	2223		ISZ	FADDR	/INCREMENT "FROM" ADDRESS
6417	2224		ISZ	TADDR	/INCREMENT "TO" ADDRESS
6420	2225		ISZ	MCTR	/ALL WORDS MOVED?
6421	5213		JMP	MOVE A	/NO,

```

422 5600      /      JMP I  MOVE      /YES
6423 0000    FADDR, 0
6424 0000    TADDR, 0
6425 0000    MCTR,  0
    
```

/ROUTINE TO CONVERT FROM BINARY TO DECIMAL.

```

6426 0000    BDCNV,  0
6427 1377    TAD      (=4
6430 3271    DCA      CNVCTR
6431 1262    TAD      ADDRZA
6432 3243    DCA      ARROW      /INITIALIZE ARROW
6433 1626    TAD I    BDCNV
6434 2226    ISZ     BDCNV
6435 3270    DCA      DIGIT
6436 1670    TAD I    DIGIT
6437 3267    DCA      VALUE
6440 3270    DCA      DIGIT      /CLEAR DIGIT
6441 7100    CLL
6442 1267    TAD      VALUE
6443 1263    ARROW,  TAD      TENPWR
6444 7420    SNL
6445 5251    JMP      (=4
6446 2270    ISZ     DIGIT      /DEVELOP DIGIT
6447 3267    DCA      VALUE
6450 5241    JMP      ARROW=2
6451 7200    CLA
6452 1270    TAD      DIGIT      /GET DIGIT
6453 1272    TAD      K260      /ADD 260
6454 4922    JMS I    PRXLOP      /PRINT
6455 7300    CLA      CLL
6456 2243    ISZ     ARROW      /POINT ARROW
6457 2271    ISZ     CNVCTR      /DONE?
6460 5240    JMP      ARROW=3      /NO, REPEAT
6461 5626    JMP I    BDCNV      /YES, EXIT
6462 1263    ADDRZA, TAD      TENPWR
6463 6030    TENPWR, -1750
6464 7634    -144
6465 7766    -12
6466 7777    -1
6467 0000    VALUE,  0
6470 0000    DIGIT,  0
6471 0000    CNVCTR, 0
6472 0260    K260,  260
    
```

/ROUTINE TO CHANGE A BINARY NUMBER TO IT'S OBVERSE

```

6473 0000    OBVERS, OPEN      /ENTER WITH "ABC DEF GHI JKL".
6474 7102    CLL BSW
6475 7421    MQL
6476 7501    MQA
6477 7012    RTR
6500 7010    RAR
    
```

6501	0376	AND	(707
6502	7521	SWP	
6503	7106	CLL	RTL
6504	7004	RAL	
6505	0375	AND	(7070
6506	7501	MQA	
6507	7421	MQL	
6510	7501	MQA	
6511	0374	AND	(2222
6512	3324	DCA	OBV
6513	7501	MQA	
6514	0373	AND	(4444
6515	7112	CLL	RTR
6516	7521	SWP	
6517	0372	AND	(1111
6520	7106	CLL	RTL
6521	1324	TAD	OBV
6522	7501	MQA	
6523	5673	JMP	I OBVERS

/EXIT WITH "LRU INB FEB 08A", AND LINK 0.

6524 0000 OBV, OPEN

7RANDOM NUMBER GENERATOR SUBROUTINE

6525	0000	RANGEN,	0
6526	7200	CLA	
6527	1370	TAD	RANTND
6530	1355	TAD	RANDEX
6531	7640	SZA	CLA
6532	5342	JMP	RANTAD
6533	1357	TAD	RANTBL
6534	3355	DCA	RANDEX
6535	1356	TAD	RANCON
6536	7104	CLL	RAL
6537	7430	SZL	
6540	7001	IAC	
6541	3356	DCA	RANCON
6542	1356	RANTAD,	TAD RANCON
6543	1755	TAD	I RANDEX
6544	3755	DCA	I RANDEX
6545	1371	TAD	RANSAV
6546	7010	RAR	
6547	1755	TAD	I RANDEX
6550	2355	ISZ	RANDEX
6551	7400	NOP	
6552	3371	DCA	RANSAV
6553	1371	TAD	RANSAV
6554	5725	JMP	I RANGEN
6555	6570	RANDEX,	RANTND
6556	6543	RANCON,	6543
6557	6560	RANTBL,	,+1
6560	6543		6543
6561	3210		3210

562	0765	0765
6563	5432	5432
6564	2107	2107
6565	7654	7654
6566	4321	4321
6567	0176	0176
6570	1210	RANTND, =,
6571	0000	RANSAV, OPEN

6572	1111
6573	4444
6574	2222
6575	7070
6576	0707
6577	7774
6600	6600

PAGE

/ROUTINE FOR TYPING.

6600	0000	TYPST,	OPEN	
6601	7200		CLA	
6602	1600	TAD I	TYPST	/GET INITIAL ADDRESS
6603	3263	DCA	TEMQ	/STORE INITIAL ADDRESS
6604	3265	DCA	FLAG	/CLEAR FLAG
6605	2200	ISE	TYPST	/PRESET UP EXIT
6606	1663	TSC1,	TAD I	TEMQ
6607	7012		RTR	/PICK UP DATA
6610	7012		RTR	
6611	7012		RTR	
6612	4217	JMS	TSC2	/GO TYPE FIRST CHARACTER
6613	1663	TAD I	TEMQ	/PICK-UP DATA
6614	4217	JMS	TSC2	/GO TYPE SECOND CHARACTER
6615	2263	ISE	TEMQ	/EVEN STRING ADDRESS
6616	5206	JMP	TSC1	/GO BACK FOR MORE
6617	0000	TSC2,	OPEN	
6620	0377	AND	(77	/MASK OFF SIX BITS
6621	3264	DCA	TEMR	/SAVE CHARACTER
6622	1265	TAD	FLAG	/TEST "SPECIAL" FLAG
6623	7640	SZA	CLA	
6624	5234	JMP	TYPSP	/SET: TYPE SPECIAL
6625	1264	TAD	TEMR	/NO, REGULAR CHARACTER
6626	7450	SNA		/ZERO?
6627	5232	JMP	,+3	/YES, SET FLAG
6630	4253	TYPAT,	JMS	PRINT
6631	5617		JMP I	TSC2
6632	2265		ISE	FLAG
6633	5617		JMP I	TSC2
6634	3265	TYPSP,	DCA	FLAG
6635	1264		TAD	TEMR
6636	7041		CIA	
6637	7450		SNA	
6640	5230		JMP	TYPAT
6641	7001		IAC	/TEST FOR 01
6642	7650		SNA	CLA
6643	5600		JMP I	TYPST

/YES: EXIT CODE

6644	1266	TAD	SKIPMA	/ALTER INSTRUCTION
6645	3255	DCA	SWITCH	/TO BE "SMÅ"
6646	1264	TAD	TEMR	/TYPE CHAR
6647	4253	JMS	PRINT	
6650	1267	TAD	SKIPPA	/ALTER INSTRUCTION
6651	3255	DCA	SWITCH	/TO BE "SPÅ"
6652	5617	JMP I	TSC2	/RETURN,
6653	0000	PRINT,	OPEN	
6654	1376	TAD	(=40	/COMPARE WITH 40'
6655	7510	SWITCH,	SPA	/OR SMA FOR SPECIAL CODES
6656	1375	TAD	(100	
6657	1374	TAD	(240	
6660	4522	JMS I	PRXLOP	/PRINT,
6661	5653	JMP I	PRINT	

6662	0000	TEMPO,	OPEN
6663	0000	TEMQ,	OPEN
6664	0000	TEMR,	OPEN
6665	0000	FLAG,	OPEN
6666	7500	SKIPMA,	SMA
6667	7510	SKIPPA,	SPA

6670	0000	PSPC,	OPEN	
6671	1670	TAD I	PSPC	/GET NUMBER
6672	3303	DCA	SPCTR	/OF SPACES
6673	2270	ISZ	PSPC	
6674	4447	JMS I	XTYPSI	/SPACE ONCE
6675	6701	,+4		
6676	2303	ISZ	SPCTR	/ALL SPACES DONE
6677	5274	JMP	,=3	/NO. REPEAT.
6700	5670	JMP I	PSPC	/YES, EXIT
6701	4000		4000	
6702	0100		0100	
6703	0000	SPCTR,	OPEN	

/ROUTINE TO PRINT MODE FAILURE

6704	0000	TYMOD,	OPEN	
6705	7300	CLA	CLL	
6706	1114	TAD	MODE	
6707	7040	CMÅ		
6710	1373	TAD	(4002	
6711	3321	DCA	MODEX+2	
6712	4450	JMS I	UPSPC	
6713	7774	=4		
6714	4447	JMS I	XTYPSI	
6715	6717	MODEX		
6716	5704	JMP I	TYMOD	
6717	1517	MODEX,	1517	
6720	0405		0405	
6721	0000	OPEN		
6722	0001		0001	

/ROUTINE TO PRINT 1 SPACE

6723	0000	SPACE1, OPEN	
6724	4450	JMS I	UPSPC
6725	7777	=1	
6726	5723	JMP I	SPACE1

/ROUTINE TO PRINT 2 SPACES,

6727	0000	SPACE2, OPEN	
6730	4450	JMS I	UPSPC
6731	7776	=2	
6732	5727	JMP I	SPACE2

/ROUTINE TO PRINT A HEADING IN ERROR PRINTOUTS,

6733	0000	HEADIN, OPEN		
6734	4521	JMS I	CRLF2	/2 CR AND LF,
6735	4450	JMS I	UPSPC	/#12 SPACES
6736	7764	=14		
6737	4447	JMS I	XTPST	/C(L)
6740	7365	CL		
6741	4450	JMS I	UPSPC	/5 SPACES
6742	7773	=5		
6743	4447	JMS I	XTPST	/C(AC)
6744	7355	CAC		
6745	4450	JMS I	UPSPC	/9 SPACES
6746	7767	=11		
6747	4447	JMS I	XTPST	/C(MQ)
6750	7361	CMQ		
6751	4450	JMS I	UPSPC	
6752	7774	=4		
6753	4447	JMS I	XTPST	/C(GT)
6754	7434	CGT		
6755	4450	JMS I	UPSPC	/6 SPACES
6756	7772	=6		
6757	4447	JMS I	XTPST	/C(SC)
6760	7407	CSC		
6761	5733	JMP I	HEADIN	/EXIT

6773	4002		
6774	0240		
6775	0100		
6776	7740		
6777	0077		
	7000	PAGE	

7000	0000	UPREGS, OPEN	
7001	4576	JMS I	CTYMOD
7002	0000	PRCHG, OPEN	

7003	4777	JMS	HEADIN
7004	4521	JMS I	CRLF2

/THIS LOCATION WILL CONTAIN 0000 EXCEPT  
/WHEN THE OPSZ TEST ARE BEING EXECUTED AND  
/AT THAT TIME THERE WILL BE A JMS OPSZPR  
/IN THIS LOCATION.  
/PRINT HEADING  
/2 CR AND LF.

7005	4452		JMS I	UMOVE	
7006	0020		TOLINK		
7007	0025		TLINK		
7010	7773		=5		
7011	4447		JMS I	XTYPSI	
7012	7370		PROBLM		
7013	4450		JMS I	UPSPC	
7014	7771		=7		
7015	4246		JMS	PLAMGS	/PRINT C(L),C(AC),C(MQ),C(CT),C(SC)
7016	0000	WILCHR.	OPEN		/THIS LOCATION WILL CONTAIN 0000 EXCEPT
					/WHEN THE DAD TESTS ARE BEING
					/EXECUTED, THEN THERE WILL BE A JMS FORDAD
					/IN THIS LOCATION.
7017	4521		JMS I	CRLF2	/2 CR AND LF
7020	4447		JMS I	XTYPSI	/PRINT "SIMULATED"
7021	7375		SIMULT		
7022	4450		JMS I	UPSPC	/5 SPACES
7023	7773		=5		
7024	4452		JMS I	UMOVE	
7025	0041		LSIM		
7026	0025		TLINK		
7027	7773		=5		
7030	4246		JMS	PLAMGS	
7031	4521		JMS I	CRLF2	/2 CR AND LF
7032	4447		JMS I	XTYPSI	/TYPE "ACTUAL"
7033	7403		ACTUAL		
7034	4450		JMS I	UPSPC	/7 SPACES
7035	7770		=10		
7036	4452		JMS I	UMOVE	
7037	0032		LKLOCK		
7040	0025		TLINK		
7041	7773		=5		
7042	4246		JMS	PLAMGS	
7043	5600		JMP I	UPREGS	
7044	4776	DADJMS,	JMS	FORDAD	
7045	4775	DSEJMS,	JMS	DPSZPR	
7046	0000	PLAMGS,	OPEN		
7047	1025		TAD	TLINK	
7050	4551		JMS I	P1BIT	
7051	4454		JMS I	U2SPC	/2 SPACES
7052	1026		TAD	TAC	
7053	4774		JMS	P12BIT	/PRINT CONTENTS OF AC
7054	4454		JMS I	U2SPC	/2 SPACES
7055	1027		TAD	TMQ	
7056	4774		JMS	P12BIT	/PRINT CONTENTS OF MQ
7057	4450		JMS I	UPSPC	/3 SPACES
7060	7775		=3		
7061	1031		TAD	TGT	
7062	4551		JMS I	P1BIT	

```

7063 4450      JMS I  UPSPC      /4      ES
7064 7774      =4
7065 1030      TAD      TSHIF
7066 4774      JMS      P12BIT    /PRINT CONTENTS OF THE STEP COUNTER.
7067 5646      JMP I   PLAMGS    /EXIT, AC=0

```

/ROUTINE TO PRINT THE NUMBER OF SHIFTS IN DECIMAL.

```

7070 0000      NUMSH, OPEN      /PRINT NUMBER OF SHIFTS IN DECIMAL.
7071 4450      JMS I  UPSPC
7072 7775      =3
7073 1023      TAD      TOSHIF
7074 7001      IAC
7075 1114      TAD      MODE
7076 3115      DCA      ANYUSE
7077 4773      JMS      BDCNV
7100 0115      ANYUSE
7101 4454      JMS I  U2SPC
7102 4447      JMS I  XTYPST
7103 7425      SHIFTS
7104 4454      JMS I  U2SPC
7105 5690      JMP I  NUMSH      /EXIT

```

/ROUTINE TO PRINT THE CONTENTS OF THE REGISTERS FOR THE DST INSTRUCTION.

```

7106 0000      DSTREG, OPEN
7107 4576      JMS I  ETYMOD
7110 4772      JMS      DSTHED      /PRINT THE HEADING
7111 4521      JMS I  CRLF2      /2 CR AND LF.
7112 4447      JMS I  XTYPST      /PRINT C(L)
7113 7365      CL
7114 4450      JMS I  UPSPC      /3 SPACES
7115 7773      =5
7116 1041      TAD      LSH
7117 4551      JMS I  P1BIT      /PRINT ORIGINAL LINK.
7120 4450      JMS I  UPSPC      /15 SPACES
7121 7761      =17
7122 1032      TAD      LKTOCK
7123 4551      JMS I  P1BIT      /PRINT LINK AFTER EAE INSTRUCTION.
7124 4520      JMS I  CRLF      /CR AND LF.
7125 4447      JMS I  XTYPST      /PRINT C(AC)
7126 7355      CAC
7127 4450      JMS I  UPSPC      /4 SPACES
7130 7774      =4
7131 1042      TAD      MSH
7132 4774      JMS      P12BIT    /PRINT ORIGINAL AC
7133 4450      JMS I  UPSPC      /4 SPACES
7134 7774      =4
7135 1033      TAD      ACTOCK
7136 4774      JMS      P12BIT    /PRINT AC AFTER DST
7137 4520      JMS I  CRLF      /CR AND LF.
7140 4447      JMS I  XTYPST      /PRINT C(MSH)
7141 7472      CMSH
7142 4450      JMS I  UPSPC      /19 SPACES
7143 7755      =23

```

7144	1035	TAD	SC10CK	
7145	4774	JMS	P12BIT	/PRINT THE STORED AC
7146	4520	JMS I	CRLF	/CR AND LF
7147	4447	JMS I	XTYPSI	/PRINT C(MQ)
7150	7361	CMQ		
7151	4450	JMS I	UPSPC	/4 SPACES
7152	7774	=4		
7153	1043	TAD	LSH	
7154	4774	JMS	P12BIT	/PRINT ORIGINAL MQ
7155	4450	JMS I	UPSPC	/4 SPACES
7156	7774	=4		
7157	1034	TAD	MQ10CK	
7160	4774	JMS	P12BIT	/PRINT MQ AFTER DST
7161	4520	JMS I	CRLF	/CR AND LF
7162	4447	JMS I	XTYPSI	/PRINT C(LSH)
7163	7476	CLSH		
7164	4450	JMS I	UPSPC	/19 SPACES
7165	7795	=23		
7166	1036	TAD	G10CK	
7167	4774	JMS	P12BIT	/PRINT STORED MQ
7170	5706	JMP I	DSTREG	/EXIT

7172 7204  
7173 6426  
7174 7208  
7175 5512  
7176 7230  
7177 6733  
7200

PAGE

/ROUTINE TO PRINT THE 12 BITS OF A REGISTER.

7200	0000	P12BIT, OPEN		
7201	3105	DCB	BITSIR	
7202	4525	JMS I	MESSG	/PRINT A MESSAGE
7203	5600	JMP I	P12BIT	

/ROUTINE TO PRINT THE HEADING FOR THE DST INSTRUCTION.

7204	0000	DSTHED, OPEN		
7205	4521	JMS I	CRLF2	/2 CR AND LF
7206	4453	JMS I	U1SPC	/1SPACE
7207	4447	JMS I	XTYPSI	/TYPE "REG"
7210	7505	REG		
7211	4450	JMS I	UPSPC	/6 SPACES
7212	7772	=6		
7213	4447	JMS I	XTYPSI	
7214	7462	BEFORE		
7215	4453	JMS I	U1SPC	
7216	4447	JMS I	XTYPSI	
7217	7457	ZDST		
7220	4450	JMS I	UPSPC	
7221	7772	=6		
7222	4447	JMS I	XTYPSI	
7223	7466	AFTER		

```

7224 4453      JMS I  U1SPC
7225 4447      JMS I  X1YPSY
7226 7457      ZDST
7227 5604      JMP I  DSTHED      /EXIT, AC = 0.
    
```

/ROUTINE TO TYPE THE DATA TO BE ADDED TO THE AC+HQ FOR THE DAD INSTRUCTION.

```

7230 0000      FORDAO, OPEN
7231 4521      JMS I  CRLF2      /2 CR AND LF.
7232 4447      JMS I  X1YPSY      /PRINT "TO BE ADDED".
7233 7514      TOBEAD
7234 4450      JMS I  U1SPC      /6 SPACES
7235 7772      =6
7236 1023      TAD      TOSHIP      /MSH TO BE ADDED.
7237 4200      JMS      P12BIT      /PRINT THE MSH TO BE ADDED.
7240 4454      JMS I  U2SPC      /2 SPACES.
7241 1024      TAD      TQGT      /LSH TO BE ADDED.
7242 4200      JMS      P12BIT      /PRINT THE LSH TO BE ADDED.
7243 5630      JMP I  FORDAO      /EXIT.
    
```

```

7244 0000      SAMTAB, 0
7245 0000      0000
7246 7777      7777
    
```

```

7247 4000      4000
7250 7777      7777
7251 0000      0000
    
```

```

7252 0000      0
7253 7777      7777
7254 7777      7777
    
```

```

7255 0000      0
7256 0000      0000
7257 0000      0000
    
```

```

7260 0000      0
7261 0001      0001
7262 0002      0002
    
```

```

7263 0000      DSTAB, 0
7264 7777      7777
7265 7777      7777
    
```

```

7266 4000      4000
7267 0000      0000
7270 0000      0000
    
```

```

7271 4000      4000
7272 2525      2525
7273 5252      5252
    
```

```

7274 0000      0
    
```

7275	7007		7007	
7276	0770		0770	
7277	4000		4000	
7300	0770		0770	
7301	7007		7007	
7302	0000	DADTAB, 0		
7303	0000		0000	
7304	0000		0000	
7305	0000		0000	
7306	0000		0000	
7307	4000		4000	
7310	7777		7777	
7311	7777		7777	
7312	0000		0000	
7313	0000		0000	
7314	4000		4000	
7315	0000		0000	
7316	0000		0000	
7317	7777		7777	
7320	7777		7777	
7321	0000		0	
7322	2525		2525	
7323	5252		5252	
7324	5252		5252	
7325	2525		2525	
7326	0000		0	
7327	7777		7777	
7330	7777		7777	
7331	7777		7777	
7332	7777		7777	
7333	4000	COMTAB, 4000		/1 7777 0000
7334	7777		7777	
7335	0000		0000	
7336	4000		4000	/1 0000 7777
7337	0000		0000	
7340	7777		7777	
7341	0000		0	/0 0000 0000
7342	0000		0000	
7343	0000		0000	
7344	4000		4000	/1 7777 7777
7345	7777		7777	
7346	7777		7777	
7347	4000		4000	/1 2525 5252
7350	2525		2525	

7351	5252	5252
7352	4000	4000
7353	5252	5252
7354	2525	2525

/1 5252 2525

## /MESSAGES I

7355	0350	CAC,	0350
7356	0103		0103
7357	5100		5100
7360	0100		0100
7361	0350	CMQ,	0350
7362	1521		1521
7363	5100		5100
7364	0100		0100
7365	0350	CL,	0350
7366	1451		1451
7367	0001		0001
7370	2022	PROBLM,	2022
7371	1702		1702
7372	1405		1405
7373	1500		1500
7374	0100		0100

/C(AC)

/C(MQ)

/C(L)

7375	2311	SIMULT,	2311
7376	1525		1525
7377	1401		1401
7400	2405		2405
7401	0400		0400
7402	0100		0100

/SIMULATED

7403	0103	ACTUAL,	0103
7404	2425		2425
7405	0114		0114
7406	0001		0001

/ACTUAL

7407	0350	CSC,	0350
7410	2303		2303
7411	5100		5100
7412	0100		0100
7413	2310	ZSHL,	2310
7414	1400		1400
7415	0100		0100
7416	2405	TEST,	2405
7417	2324		2324
7420	0001		0001
7421	6000	ZER0,	6000
7422	0100		0100
7423	6100	ZONE,	6100
7424	0100		0100
7425	2310	SHIFTS,	2310
7426	1106		1106
7427	2423		2423
7430	0001		0001

/C(SC)

/SHL

/TEST

/0

/"1"

/SHIFTS

## /KEB EAE INSTRUCTION TEST P.

7431	1423	ZLSR,	1423	/LSR
7432	2200		2200	
7433	0100		0100	
7434	0350	CGT,	0350	/C(GT)
7435	0724		0724	
7436	5100		5100	
7437	0100		0100	
7440	0123	ZASR,	0123	/ASR
7441	2200		2200	
7442	0100		0100	
7443	0420	ZDPSZ,	0420	/DPSZ
7444	2332		2332	
7445	0001		0001	
7446	0420	ZDPIC,	0420	/DPIC
7447	1103		1103	
7450	0001		0001	
7451	0403	ZDCM,	0403	/DCM
7452	1500		1500	
7453	0100		0100	
7454	0401	ZDAD,	0401	/DAD
7455	0400		0400	
7456	0100		0100	
7457	0423	ZDST,	0423	/DST
7460	2400		2400	
7461	0100		0100	
7462	0205	BEFORE,	0205	/BEFORE
7463	0617		0617	
7464	2205		2205	
7465	0001		0001	
7466	0106	AFTER,	0106	/AFTER
7467	2405		2405	
7470	2200		2200	
7471	0100		0100	
7472	0350	CMSH,	0350	/C(MSH)
7473	1523		1523	
7474	1051		1051	
7475	0001		0001	
7476	0350	CLSH,	0350	/C(LSH)
7477	1423		1423	
7500	1051		1051	
7501	0001		0001	
7502	2301	ZSAM,	2301	/"SAM"
7503	1500		1500	
7504	0100		0100	
7505	2205	REG,	2205	/"REG"
7506	0700		0700	
7507	0100		0100	
7510	1305	KEBSP1,	1305	/"KEB 1"
7511	7040		7040	
7512	6100		6100	
7513	0100		0100	

514 2417 TOBEAD, 2417  
 515 4002 4002  
 7516 0540 0540  
 7517 0104 0104  
 7520 0405 0405  
 7521 0400 0400  
 7522 0100 0100

/TO 10000'

7523 2313 SO, 2313  
 7524 1120 1120  
 7525 4017 4017  
 7526 0303 0303  
 7527 2522 2522  
 7530 0504 0504  
 7531 0001 0001

/SKIP OCCURED'

7532 1617 NSO, 1617  
 7533 4023 4023  
 7534 1311 1311  
 7535 2040 2040  
 7536 1703 1703  
 7537 0325 0325  
 7540 2205 2205  
 7541 0400 0400  
 7542 0100 0100

/NO SKIP OCCURED'

7543 2205 DATER, 2205  
 7544 0740 0740  
 7545 1517 1517  
 7546 0411 0411  
 7547 0611 0611  
 7550 0504 0504  
 7551 0001 0001

/REG MODIFIED'

S

0165 0031  
 0166 3777  
 0167 4000  
 0170 0037  
 0171 0032  
 0172 0041  
 0173 2525  
 0174 5252  
 0175 7741  
 0176 6704  
 0177 5000

0000	11110000	11110000	11111111	11111111	11111111	11111111	11111111	11111111
0100	11111111	11111111	11111111	11111111	11111111	11000000	00000111	11111111
0200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0300	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0500	11111111	11111111	11111111	11111111	11111111	11111111	11111111	00000111
0600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0700	11111111	11111111	11111111	11111111	11000000	00000000	00000000	11111111
1000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1100	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1300	11111111	11111111	11111111	11111111	11111111	11111000	00011111	11111111
1400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1500	11111111	11111111	11111111	11111110	00000000	00000000	00000001	11111111
1600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1700	11111111	11111111	11111111	11111111	11000000	00000000	00000000	01111111
2000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
2100	11111111	11111111	11111111	11111111	11000000	00000000	00000000	01111111
2200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
2300	11111111	11111111	11111110	00000000	00000000	00000000	00111111	11111111
2400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
2500	11111111	11111111	11111111	11000000	00000000	00000000	00000000	01111111
2600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
2700	11111111	11111111	11111111	11111110	00000000	00000000	00000011	11111111
3000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
3100	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
3200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
3300	11111111	11111111	11111111	11111111	11111111	10000000	00000111	11111111
3400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
3500	11111111	11111111	11111111	11111111	11111111	11000000	00000111	11111111
3600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
3700	11111111	11111111	11111111	11111110	00000000	00000000	00000000	00000000



A	0075	C2A	6362	DEC12	4331	ESAM1	1431
ABERR	2122	CAC	7355	DI0ERR	2643	ESCL1	5009
ABERR1	2131	CAF	6007	DI1ERR	2711	ESCL10	5122
ABINC	2115	CAM	7621	DIGIT	6470	ESCL11	5131
A1ERR	2232	CGT	7434	DL0	7663	ESCL12	5141
A1ERR1	2241	CHKAC	4531	DM0ERR	3040	ESCL13	5151
AC	0325	CHKMO	4532	DPI0	2601	ESCL2	5034
ACIND	0010	CHKSCA	4533	DPI1	2654	ESCL3	5043
ACL	7701	CKDATA	2276	DPIC	7573	ESCL4	5052
ACNMI	4040	CL	7365	DPIS0H	2621	ESCL5	5061
ACNMIN	3707	CLAM	7601	DPIS1H	2667	ESCL6	5070
ACNMIX	3704	CLRL4	1133	DPISIM	6264	ESCL7	5077
ACP	0062	CLSH	7476	DPITS0	2600	ESCL8	5106
ACS	7403	CMPCTR	6363	DPITS1	2653	ESCL9	5113
ACS1	5152	CMQ	7361	DPSZ	7451	EXEN	3731
ACS2	5165	CMSH	7472	DPSZ0	2254	EXINMI	3672
AGTOCK	0033	CNTR1	2473	DPSZ0H	2400	FADDR	6423
ACTUAL	7403	CNTR2	2474	DPSZPR	5912	FLAG	6660
ADDR	0046	CNTR3	2475	DPSZS0	2252	FORDAD	7230
ADDRZA	6462	CNVCTR	6471	DPEPR1	5515	GEN	5600
AFTER	7466	COMP	6334	DS0ERR	3440	GENNMI	4273
AGAIN	4536	COMPA	6344	DS1ERR	3542	GENX	0064
AMGAT3	1233	COMTAB	7333	DST	7445	GRX	4405
ANCMIQ	3727	COMTST	4600	DST0	3315	GTP	6004
ANYUSE	0115	COUNT	0116	DST0A	3326	GTSIM	0045
APMOAT	1230	COUNTX	0103	DST0B	3327	GTT0CK	0036
ARROW	6443	CP	0263	DST0GN	3400	GTTST1	5200
ASCOMP	0134	CR	0067	DST1	3451	GTTST2	5200
ASR	7415	CRLF	0120	DST1A	3462	GTTST3	5200
ASR0	2053	CRLF2	0121	DST1B	3463	GTTST4	5200
ASR0SH	6242	CSC	7407	DST1RN	3505	GTTST5	0200
ASR1	2201	DABERR	3153	DSTHED	7204	GXEN	3712
ASR030	6250	DA1ERR	3304	DSTREG	7106	HEADIN	6733
ASRS0H	2101	DAD	7443	DSTS0H	3413	HKE	4505
ASRS1H	2221	DAD0	3051	DSTS1H	3517	HIT	7402
ASRSIM	6200	DAD1	3201	DSTTAB	7263	HSE	0246
ASRTS0	2052	DADGEN	3076	DSTTS0	3314	HSE1	0427
ASRTS1	2200	DADJMS	7044	DSTTS1	3450	HSE2	0540
AT	0632	DADS0H	3112	DSEJMS	7045	HSE2A	0563
AT3	1066	DADS1H	3226	DZERR0	2523	HSE3	0704
B0DIFF	6045	DADSIM	6320	DZINC	2426	HSE4	1002
BACK	0055	DADTAB	7302	E3A	5250	HSE5	1200
BACP	0066	DADTS0	3050	EDAD0	3132	HSENM	4261
BDCNV	6426	DADTS1	3200	EDAD1	3263	HSENM1	3657
BEFORE	7462	DATER	7543	EDCM0	3031	INCOR	0110
BITSTR	0105	DCM	7575	EDPI0	2634	IOF	6002
BLXP	0065	DCM0	2722	EDPI1	2702	ION	6001
BSW	7002	DCMGEN	3000	EDPSZ0	2512	K260	6472
C	0076	DCMS0H	3013	EDST0	3431	K7740	0117
C1	6357	DCMSIM	6302	EDST1	3533	KE0SP1	7510
C1A	6361	DCMTS0	2721	ENQAT2	1063		0313
C2	6360	DDZ	7665	ESAM0	1276	LOERR	1722

RR1 1731  
 L0INC 1715  
 L1ERR 2032  
 L1ERR1 2041  
 LDGT 0147  
 LDREG 0145  
 LDSC 0152  
 LDSC1 5470  
 LF 0070  
 LINK 0101  
 LKTOCK 0032  
 LL 0073  
 LNPR2 1051  
 LPAR 5435  
 LSH 0043  
 LSHIFT 6135  
 LSIM 0041  
 LSR 7417  
 LSR0 1603  
 LSR0SH 6151  
 LSR1 2001  
 LSRA 6142  
 LSRO30 6160  
 LSR0SH 1701  
 LSR0SH 2021  
 LSR0SH 6120  
 LSR0SH 1652  
 LSR0SH 2000  
 LXP 0063  
 M 0071  
 MCTR 6425  
 MQSEL 5263  
 MQYST 5001  
 MESSG 0125  
 MQDA 2464  
 MQDE 0114  
 MQDEX 6717  
 MQDSEL 0131  
 MQVE 6400  
 MQVEA 6413  
 MQ 0304  
 MQ1 0444  
 MQ1SH 0437  
 MQA 7501  
 MQA1 0605  
 MQAER1 0714  
 MQAER2 1042  
 MQAER3 1210  
 MQAT 0503  
 MQAT1 0650  
 MQAT2 1000  
 MQAT3 1135

MQIND 0011  
 MQL 7421  
 MQLT 0203  
 MQLT1 0400  
 MQNMI 4074  
 MQNMIN 3706  
 MQNMIQ 3730  
 MQNMIX 3705  
 MQTOCK 0034  
 MSW 0042  
 MT2ER 4513  
 N 5447  
 NBASR0 2067  
 NBASR1 2207  
 NBLSR0 1667  
 NBLSR1 2007  
 NBSHL0 1444  
 NBSHL1 1607  
 NEXNMI 4324  
 NEXT 0056  
 NM2525 4320  
 NM5252 4321  
 NM7776 4323  
 NMERR 4333  
 NMFLG 4322  
 NMI 7411  
 NMIERR 3650  
 NMIODD 3701  
 NMITPR 4126  
 NMIXX 5400  
 NMIS1 4450  
 NMIS3 4522  
 NOP 7400  
 NOPM 7401  
 NOPR 0724  
 NOPR3 1217  
 NORMT 3600  
 NORMT1 4200  
 NORMT2 4400  
 NOSKIP 2306  
 NOSKP 2274  
 NSO 7532  
 NUMSH 7070  
 NUMSHF 0143  
 OBV 6524  
 OBVERS 6473  
 ONE 0077  
 ONEP 0127  
 ONLYB 0132  
 ONZER 0126  
 OPEN 0000  
 P12BIT 7200

P1B 0151  
 PA2525 4302  
 PACP 0364  
 PAT00 4526  
 PAT01 4525  
 PATCH 4545  
 PBACP 0372  
 PBLXP 0351  
 PC 5430  
 PLAMGS 7046  
 PLINK 0123  
 PLXP 0334  
 PMQAT 0600  
 PHQLT 0256  
 PNORM 4132  
 PRCHG 7002  
 PREGS 0133  
 PRINT 6653  
 PRNMI 4000  
 PROBLM 7370  
 PRXLOP 0122  
 PSPC 6670  
 PSTEP 5412  
 PSTEPT 5423  
 PTHREE 1240  
 PTO 0357  
 PTWO 1126  
 Q 0072  
 RANCON 6556  
 RANDAD 5245  
 RANDAT 5724  
 RANDEX 6555  
 RANDOM 0144  
 RANGEN 6525  
 RANSAV 6571  
 RANTAD 6542  
 RANTBL 6557  
 RANTND 6570  
 RDP 6214  
 REG 7505  
 RIF 6224  
 RL2 0523  
 RL4 1021  
 RNDATA 0146  
 ROTGEN 2476  
 RPAR 5442  
 RTF 6005  
 RTFX 0150  
 RXLOP 5624  
 S0ERR 1517  
 S0ERR1 1526  
 S0INC 1512

S0SET 5300  
 S1ERR 1632  
 S1ERR1 1641  
 SAM 7497  
 SAM0 1246  
 SAM1 1337  
 SAMGEN 1243  
 SAMRGN 1400  
 SAMS0H 1315  
 SAMS1H 1414  
 SAMS1M 6013  
 SAMTAB 7244  
 SAMTS0 1245  
 SAMTS1 1336  
 SASR1 6213  
 SASR1A 6230  
 SASR2 6232  
 SASR3 6236  
 SAVREG 0135  
 SCA 7441  
 SCANM 4534  
 SCASX 3700  
 SCASX 3703  
 SCASX 5403  
 SCASX 5407  
 SCASX 3702  
 SCC23 3702  
 SCL 7403  
 SCL1 5020  
 SCL10 5114  
 SCL11 5123  
 SCL12 5132  
 SCL13 5142  
 SCL2 5026  
 SCL3 5035  
 SCL4 5044  
 SCL5 5053  
 SCL6 5062  
 SCL7 5071  
 SCL8 5100  
 SCL9 5107  
 SCOMP 5073  
 SCOUNT 0113  
 SCOSIM 0044  
 SCSTOCK 0035  
 SEXIT 6145  
 SGT 6006  
 SHIFTO 6113  
 SHIFTS 7423  
 SHL 7413  
 SHL0 1451  
 SHL1 1601  
 SHLA 6076

SHL031	6107	TSHIF	0030	XTYPSY	0047
SHLSIM	6051	TST25	4315	YA	0641
SHLTS0	1450	TSTSW0	0137	YESSKP	2275
SHLTS1	1600	TSTSW1	0140	YSKIP	2317
SIMULT	7375	TSTSW2	0141	ZASR	7440
SKB	7671	TSTSW3	0142	ZDAD	7454
SKIPMA	6666	TT	0074	ZGCM	7451
SKIPPA	6667	TWO	0112	ZDPIC	7446
SLTS0H	1476	PYMOD	6704	ZDPSZ	7443
SLTS1H	1621	TYPAT	6630	ZDST	7457
SM0ERR	1305	TYPSP	6634	ZER0	7421
SM1ERR	1440	TYPSY	6600	ZERC	0100
SO	7523	TYTST	0130	ZEROR	0124
SPACE1	6723	U1SPC	0053	ZLSR	7431
SPACE2	6727	U2SPC	0054	ZONE	7423
SPAT00	4527	UCOMP	0051	ZSAM	7502
SPAT01	4530	UCRLF	5611	ZSHL	7413
SPCTR	6703	UCRLF2	5620		
STRCNT	0104	UGEN	0136		
SW0TST	5314	ULDGT	5753		
SW1TST	5322	ULDREG	5743		
SW2TST	5331	ULDSC	5456		
SW3TST	5340	UMESSG	0655		
SWAB	7431	UMOVE	0052		
SWBA	7447	UONEP	5644		
SWTCH	6655	UONLYB	5306		
SWP	7521	UONZER	5637		
Y	0320	UPIBIT	5720		
TAG	0026	UPLINK	5632		
TADDR	6424	UPREGS	7000		
TEMPA	0037	UPRONE	5675		
TEMPB	0040	UPSPC	0050		
TEMPO	6662	USVREG	5350		
TEMQ	6663	UTYTST	5701		
TEMR	6664	UZEROR	5650		
TENPWR	6463	VALUE	6467		
TEST	7416	VOR	1121		
TGT	0031	WILCHG	7016		
THREE	0111	XACNMI	0012		
TLINK	0025	XCP	0467		
TMQ	0027	XMQ1	0455		
TO	0102	XMQAT	0060		
TOAC	0021	XMQAT1	0061		
TOBEAD	7514	XMQAT2	0106		
TOGT	0024	XMQAT3	0107		
TOLINK	0020	XMQLT1	0057		
TOMQ	0022	XMQNMI	0013		
TOSHIF	0023	XNORMT	4143		
TPFLAG	4537	XONE	0473		
TSC1	6606	XPACP	0342		
TSC2	6617	XPMQAT	1062		
TACL	5000	XRTF	6000		

ERRORS DETECTED: 0

LINKS GENERATED: 156

RUN-TIME: 42 SECONDS

3K CORE USED