

IDENTIFICATION

PRODUCT CODE: MAINDEC-8E-DBAC-D

PRODUCT NAME: DK8E CLOCKS DIAGNOSTIC

DATE CREATED: OCTOBER 8, 1971

MAINTAINER: DIAGNOSTIC PROGRAMMING GROUP

AUTHOR: JOHN VROBEL

COPYRIGHT © 1971
DIGITAL EQUIPMENT
CORPORATION



1. ABSTRACT

THE DK8E CLOCKS DIAGNOSTIC IS DESIGNED TO VERIFY CORRECT OPERATION OF THE DK8-EA, DK8-EC, DK8-ES, AND DK8-EP REAL TIME CLOCK OPTIONS. THE PROGRAM UTILIZES AND TESTS IOT'S ASSOCIATED WITH THE DK8-EA LINE, DK8-EC CRYSTAL, AND THE DK8-EP/DK8-ES PROGRAMMABLE REAL TIME CLOCKS.

2. REQUIREMENTS

2.1 EQUIPMENT

A PDP-8E WITH THE DK8-EA, DK8-EC, DK8-ES, OR THE DK8-EP OPTION INSTALLED AND AN ASR-33 TELETYPE OR EQUIVALENT.

A SPECIAL TEST CABLE IS NECESSARY TO CONNECT THE CLOCK FRONT PANEL TO THE PDP8/E POWER SUPPLY FOR THE DK8-ES CLOCK OPTION.

A SPECIAL CABLE IS NECESSARY TO CONNECT THE DK8-EA CLOCK MODULE TO THE PDP8/E POWER SUPPLY FOR THE DK8-EA CLOCK OPTION.

2.2 STORAGE

THE PROGRAM OCCUPIES LOCATIONS 0000-6600.

2.3 PRELIMINARY PROGRAMS

ALL PROGRAMS FOR THE BASIC PDP-8E MUST HAVE BEEN RUN SUCCESSFULLY.

3. LOADING PROCEDURE

3.1 METHOD

THE PROGRAM IS LOADED INTO BANK 0, USING THE STANDARD BINARY LOADER TECHNIQUE.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

| | |
|--------|--|
| SWR0=1 | FOR DK8-EP/DK8-ES REGISTER TEST |
| SWR1=1 | FOR DK8-ES SCHMITT TRIGGER LOGIC TEST |
| SWR2=1 | FOR INHIBIT ERROR PRINT OUT |
| SWR3=1 | FOR INHIBIT ERROR BELL |
| SWR4=1 | FOR INHIBIT ERROR HALT |
| SWR5=1 | FOR ENTER SCOPE LOOP ON ERROR |
| SWR6=1 | FOR LOOP ON NON-FAILING TEST |
| SWR7=1 | FOR DK8-EP/DK8-ES EXTERNAL PULSE SCOPE LOOP TEST |

SWR8#1

FOR DK8-ES EXTERNAL CLOCK SCOPE LOOP TEST

4.1.1 FREQUENCY SWITCH SETTINGS FOR DK8-EA/DK8-EC TEST

| | |
|-----------|-----------------------------|
| SWR9-11=0 | TEST 1 CPS CRYSTAL CLOCK |
| SWR9-11=1 | TEST 50 CPS CRYSTAL CLOCK |
| SWR9-11=2 | TEST 50 CPS LINE CLOCK |
| SWR9-11=3 | TEST 60 CPS LINE CLOCK |
| SWR9-11=4 | TEST 500 CPS CRYSTAL CLOCK |
| SWR9-11=5 | TEST 5000 CPS CRYSTAL CLOCK |

4.2 STARTING ADDRESS

THE STARTING ADDRESS IS 0200 OCTAL.

4.3 OPERATOR ACTION

4.3.1 DK8-EA/DK8-EC TEST

WITH THE PROGRAM IN BANK 0, SET SWITCH REGISTER TO 0200.
PRESS ADDRESS LOAD.

SET THE SWITCH REGISTER TO 0000.

SET SWITCH REGISTER TO INDICATE FREQUENCY OF DK8-EA
OR DK8-EC CLOCK UNDER TEST.

PRESS CLEAR AND THEN PRESS CONTINUE.

THE PROGRAM SHOULD RUN UNTIL AN ERROR OCCURES OR UNTIL
STOPPED BY THE OPERATOR.

THE TTY WILL SIGNAL "DK8E PASS COMPLETE" AT
THE COMPLETION OF EVERY PASS.

4.3.2 DK8-EP/DK8-ES REGISTER TEST

WITH THE PROGRAM IN BANK 0, SET SWITCH REGISTER TO 0200.
PRESS ADDRESS LOAD.

SET SWITCH REGISTER TO 0000.

SET SWITCH REGISTER TO INDICATE DK8-EP/DK8-ES REGISTER TEST.

PRESS CLEAR AND THEN PRESS CONTINUE.

THE PROGRAM SHOULD RUN UNTIL AN ERROR OCCURES OR UNTIL
STOPPED BY THE OPERATOR.

THE TTY WILL SIGNAL "DK8E PASS COMPLETE" AT
THE COMPLETION OF EVERY PASS.

4.3.3 DK8-ES SCHMITT TRIGGER INPUT LOGIC TEST

WITH THE PROGRAM IN BANK 0, SET THE SWITCH REGISTER TO 0200.
PRESS ADDRESS LOAD.

SET SWITCH REGISTER TO 0000.

SET THE SWITCH REGISTER TO INDICATE DK8-ES SCHMITT TRIGGER
INPUT LOGIC TEST.

PRESS CLEAR AND THEN CONTINUE.

THE PROGRAM SHOULD RUN UNTIL AN ERROR OCCURES OR UNTIL
STOPPED BY THE OPERATOR.

THE TTY WILL SIGNAL "DK8E PASS COMPLETE" AT
THE COMPLETION OF EVERY PASS.

4.3.4 DK8-EP/DK8-ES EXTERNAL PULSE SCOPE LOOP TEST

WITH THE PROGRAM IN MEMORY, SET THE SWITCH REGISTER TO 0200.
PRESS ADDRESS LOAD.

SET SWITCH REGISTER TO 0000.

SET SWITCH REGISTER TO INDICATE EXTERNAL PULSE SCOPE LOOP TEST.

PRESS CLEAR AND THEN PRESS CONTINUE.

USE OSCILLOSCOPE TO VERIFY 40 MICRO SECOND PULSE RATE AT
FJ2, FJ1, HM1, AND HM2 ON THE DK8-EP/DK8-ES MODULES.

USE OSCILLOSCOPE TO VERIFY 40 MICRO SECOND PULSE RATE AT
OVERFLOW ON DK8-ES CLOCK FRONT PANEL. (DK8-ES ONLY)

4.3.5 DK8-ES EXTERNAL CLOCK SCOPE LOOP TEST

WITH THE PROGRAM IN MEMORY, SET THE SWITCH REGISTER TO 0200.
PRESS ADDRESS LOAD.

SET SWITCH REGISTER TO 0000.

SET SWITCH REGISTER TO INDICATE EXTERNAL CLOCK SCOPE LOOP TEST.

PRESS CLEAR AND THEN PRESS CONTINUE.

GROUND CLOCK IN ON DK8-ES CLOCK FRONT PANEL.

THE TTY BELL WILL SIGNAL, IF AN EXTERNAL CLOCK IN WAS
RECEIVED.

5. OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

NONE

5.2 SUBROUTINE ABSTRACTS

NONE

5.3 OPERATOR TEST SELECTION

5.3.1 DK8-EA OR DK8-EC CLOCK OPTION

INSTALL DK8-EA OR DK8-EC CLOCK OPTION

RUN DK8-EA/DK8-EC TEST 4.3.1.

5.3.2 DK8-EP CLOCK OPTION

INSTALL DK8-EP CLOCK OPTION.

RUN DK8-EP/DK8-ES REGISTER TEST 4.3.2.

RUN DK8-EP/DK8-ES EXTERNAL PULSE SCOPE LOOP TEST 4.3.4.

5.3.3. DK8-ES CLOCK OPTION

INSTALL DK8-ES CLOCK OPTION.

RUN DK8-EP/DK8-ES REGISTER TEST 4.3.2.

CONNECT EXTERNAL SOURCE FREQUENCY LOCATED AT J5 ON THE PDP8/E POWER SUPPLY TO THE EXTERNAL SCHMITT TRIGGER INPUT LOGIC VIA THE DK8-ES CLOCK FRONT PANEL WITH THE SPECIAL TEST CABLE.

SET THE THREE SLOPE SELECTION SWITCHES ON DK8-ES CLOCK FRONT PANEL TO THE POSITIVE POSITION.

ADJUST THE THREE INPUT THRESHOLD POTENTIOMETERS ON DK8-ES CLOCK FRONT PANEL TO THE CENTER POSITION.

RUN THE DK8-ES SCHMITT TRIGGER INPUT LOGIC TEST 4.3.3.

RUN THE DK8-EP/DK8-ES EXTERNAL PULSE SCOPE LOOP TEST 4.3.4.

RUN THE DK8-ES EXTERNAL CLOCK SCOPE LOOP TEST 4.3.5.

6. ERRORS

ALL RECOVERABLE ERRORS ENCOUNTERED IN THE PROGRAM WILL RESULT IN AN ERROR HALT OR AN ERROR TYPEOUT AND THEN AN ERROR HALT.

6.1 ERRORS AND DISCRPTION

6.1.1 ERROR HALTS

ERROR HALTS IN PROGRAM ARE AS FOLLOWS:

EHLT1: MONITOR ERROR HALT, READ ERROR TYPE-OUT.

EHLT2: SKIP TRAP, CLZE

EHLT3: SKIP TRAP, CLOE

EHLT4: SKIP TRAP, CLOE

EHLT5: SKIP TRAP, CLAB

EHLT6: SKIP TRAP, CLEN

EHLT7: SKIP TRAP, CLSA

EHLT10: SKIP TRAP, CLBA

EHLT11: SKIP TRAP, CLCA

6.1.2 ERROR TYPECUTS

ERROR TYPECUTS IN PROGRAM ARE AS FOLLOWS:

TEST XXXX FAILED, STARTING ADDRESS XXXX

THE GOOD AC = XXXX AND BAD AC = XXXX

CLOCK BUFFER REGISTER AND AC TRANSFER FAILED

CLOCK COUNTER REGISTER AND AC TRANSFER FAILED

CLOCK ENABLE REGISTER AND AC TRANSFER FAILED

THE AC WAS CHANGED BY A CLOCK IOT

PROGRAM INTERRUPT FAILED, NO INTERRUPT EXPECTED

PROGRAM INTERRUPT FAILED, INTERRUPT EXPECTED

CLOCK SKIP FAILED, NO SKIP EXPECTED

CLOCK SKIP FAILED, SKIP EXPECTED

CLOCK OUTPUT FAILED, CLOCK FREQUENCY FAST

CLOCK OUTPUT FAILED, CLOCK FREQUENCY SLOW

6.2 ERROR RECOVERY

ALL ERRORS ENCOUNTERED MUST BE CORRECTED BEFORE PROCEEDING ON IN THE PROGRAM. IN ALL CASES ACCESS THE LISTING FOR

FURTHER INFORMATION.

6.2.1 SCOPE LOOPS

A SCOPE LOOP IS AVAILABLE FOR ALL MONITOR ERROR HALTS. THE OPERATOR MAY ENTER A SCOPE LOOP AFTER A MONITOR ERROR HALT BY DOING THE FOLLOWING.

SET SWR4=1 TO INDICATE INHIBIT ERROR HALT.

SET SWR5=1 TO INDICATE ENTER SCOPE LOOP.

SET SWR6=1 TO INDICATE LOOP ON THIS TEST.

PRESS CLEAR AND THEN PRESS CONTINUE.

SET SWR2=1 TO INHIBIT ERROR TYPEOUT.

SET SWR3=1 TO INHIBIT ERROR BELL.

7. RESTRICTIONS

7.1 STARTING RESTRICTIONS

NONE

7.2 OPERATING RESTRICTIONS

THE PROGRAM MUST RESIDE IN BANK 0 .

PDP-8E WITH THE DK8-EA, DK8-EC, DK8-ES, OR THE DK8-EP CLOCK OPTION INSTALLED.

THE EXT. CPS SOURCE USED IN THE DK8-ES EXTERNAL SCHMITT TRIGGER INPUT LOGIC TEST MUST BE DISCONNECTED WHEN RUNNING THE DK8-EP/DK8-ES REGISTER TEST.

THE PDP-8E MUST BE RUNNING FAST CYCLE "1.2" MICRO. SECONDS.

ALL CLOCK OUTPUTS SHOULD BE VERIFIED WITH AN OSCILLOSCOPE TO INSURE CORRECT OPERATION.

8. MISCELLANECUS

8.1 SPECIFICATIONS

THE DK8-EA CLOCK COUNTS AT INTERVALS OF TIME AT 100 OR 120 TIMES A SECOND. THE FREQUENCY IS DETERMINED BY THE FULL WAVE RECTIFIER NETWORK WHICH OPERATES OFF THE 50 OR 60 CPS LINE WHICH EVER IT MAY BE. THIS MAKES THE CLOCK CAPABLE OF SUPPLYING PROGRAM INTERRUPT REQUESTS AT A RATE OF 100 OR 120 TIMES A SECOND.

8.2 EXECUTION TIME

DK8-EA/DK8-EC TEST, APPROXIMATELY 2.5 MINUTES PER PASS,
DK8-EP/DK8-ES REGISTER TEST, APPROXIMATELY 3.5 MINUTES
PER PASS,
DK8-ES SCHMITT TRIGGER INPUT LOGIC TEST, APPROXIMATELY
2 MINUTES PER PASS.

9. PROGRAM DISCRIPTION

9.1 DK8-EA OR DK8-EC CLOCK

THE PROGRAM EXERCISES AND TESTS THE FOLLOWING IOT'S FOR CORRECT
OPERATION AND FUNCTION.

SKIP ON A CLOCK FLAG AND CLEAR THE FLAG (CLSK)

OCTAL CODE: 6133

OPERATION: SENSES THE CLOCK FLAG, WHICH IS SET WITH
EACH CLOCK PULSE; IF IT IS SET, THE NEXT
SEQUENTIAL INSTRUCTION IS SKIPPED AND THE
FLAG IS THEN CLEARED.

ENABLE CLOCK INTERRUPT (CLEI)

OCTAL CODE: 6131

OPERATION: ENABLES THE CLOCK FLAG, WHICH IS SET WITH
EACH CLOCK PULSE, TO CAUSE A PROGRAM
INTERRUPT REQUEST. THE FLAG WILL REMAIN
SET UNTIL CLEARED WITH CLSK,

DISABLE CLOCK INTERRUPT (CLED)

OCTAL CODE: 6132

OPERATION: DISABLES THE CLOCK FLAG FROM CAUSING
AN INTERRUPT REQUEST, THE FLAG IS NOT AFFECTED.

9.2 DK8-EP/DK8-ES CLOCK

THE PROGRAM EXERCISES AND TESTS THE FOLLOWING IOT'S FOR CORRECT
OPERATION AND FUNCTION.

CLEAR THE CLOCK ENABLE REGISTER PER AC (CLZE)

OCTAL CODE: 6130

OPERATION: CLEARS THE BITS IN THE CLOCK ENABLE
REGISTER CORRESPONDING TO THOSE BITS
SET IN THE AC. THE AC IS NOT AFFECTED.

SKIP ON A CLOCK INTERRUPT (CLSK)

OCTAL CODE: 6131

OPERATION: SENSES FOR INTERRUPT CONDITIONS, IF THE
CONDITIONS ARE PRESENT THE NEXT SEQUENTIAL
INSTRUCTION IS SKIPPED. THE CONDITIONS
ARE AS FOLLOWS:
A. ENABLE EVENT INTERRUPT 1 AND INPUT 4
B. ENABLE EVENT INTERRUPT 2 AND INPUT 2
C. ENABLE EVENT INTERRUPT 3 AND INPUT 1
D. ENABLE OVERFLOW INTERRUPT AND OVERFLOW

AC TO CLOCK ENABLE REGISTER (CLOE)

OCTEL CODE:

6132

OPERATION:

CAUSES THE CONTENTS OF THE AC TO BE LOADED INTO THE CLOCK ENABLE REGISTER CORRESPONDING TO THOSE BITS SET IN THE AC, THE AC IS NOT AFFECTED. CLOCK ENABLE REGISTER FUNCTIONS ARE AS FOLLOWS.

AC BIT

FUNCTION

0

ENABLE CLOCK OVERFLOW

1 & 2

MODE CONTROL

00 COUNTER RUNS AT SELECTED RATE, OVERFLOW OCCURS EVERY 4096 COUNTS. OVERFLOW REMAINS SET UNTIL CLEARED BY (CLSA) IOT 6135.

01 COUNTER RUNS AT SELECTED RATE, OVERFLOW CAUSES THE CLOCK BUFFER REGISTER TO BE TRANSFERRED TO THE CLOCK COUNTER REGISTER WHICH WILL CONTINUE TO RUN AFTER TRANSFER. OVERFLOW WILL REMAIN SET UNTIL CLEARED BY (CLSA) IOT 6135.

10 COUNTER RUNS AT SELECTED RATE. AN EXTERNAL SCHMITT TRIGGER SIGNAL, IF ENABLED, CAUSES THE CLOCK COUNTER REGISTER TO BE TRANSFERRED TO THE CLOCK BUFFER REGISTER AND THE CLOCK COUNTER CONTINUES TO RUN.

11 COUNTER RUNS AT SELECTED RATE. AN EXTERNAL SCHMITT TRIGGER SIGNAL, IF ENABLED, CAUSES THE CLOCK COUNTER REGISTER TO BE TRANSFERRED TO THE CLOCK BUFFER REGISTER AND THE CLOCK COUNTER WILL CONTINUE TO RUN FROM 0.

3, 4 & 5

COUNT RATE

000 STOP
001 EXTERNAL CLOCK SOURCE
010 100 CPS
011 1000 CPS
100 10000 CPS
101 100000 CPS
110 1000000 CPS
111 STOP

6

WHEN SET TO A 1, OVERFLOW CAUSES AN EXTERNAL PULSE.

- 7 WHEN SET TO A 1, THE CLOCK COUNTER IS INHIBITED FROM COUNTING.
- 8 WHEN SET TO A 1, ENABLES EXTERNAL SCHMITT TRIGGER SIGNALS AND THE OVERFLOW FLOP TO CAUSE AN INTERRUPT REQUEST IF THEY ARE ENABLED.
- 9,10 & 11 ENABLE SCHMITT TRIGGER EVENTS

100 INPUT 4
 010 INPUT 2
 001 INPUT 1

AC TO CLOCK BUFFER REGISTER (CLAB)

OCTAL CODE: 6133

OPERATION: CAUSES THE CONTENTS OF THE AC TO BE TRANSFERED INTO THE CLOCK BUFFER REGISTER; THE CONTENTS OF BUFFER REGISTER IS THEN TRANSFERED TO THE CLOCK COUNTER REGISTER. THE AC IS NOT AFFECTED.

CLOCK ENABLE REGISTER TO AC (CLEN)

OCTAL CODE: 6134

OPERATION: CAUSES THE CONTENTS OF THE CLOCK ENABLE REGISTER TO BE TRANSFERRED TO THE AC. THE ENABLE REGISTER IS NOT AFFECTED.

CLOCK STATUS TO AC (CLSA)

OCTAL CODE: 6135

OPERATION: CAUSES THE CONTENTS OF THE CLOCK STATUS REGISTER TO BE TRANSFERED INTO THE AC. THE STATUS BITS ARE THEN CLEARED CORRESPONDING TO THOSE BITS THAT WERE SET IN THE AC. THE STATUS REGISTER FUNCTIONS ARE AS FOLLOWS.

| AC BIT | STATUS CONDITION |
|--------|------------------|
| ----- | ----- |
| 0 | OVERFLOW |
| 1-8 | NOT USED |
| 9 | INPUT 4 |
| 10 | INPUT 2 |
| 11 | INPUT 1 |

CLOCK BUFFER REGISTER TO AC (CLBA)

OCTAL CODE: 6136

OPERATION: CAUSES THE CONTENTS OF THE CLOCK BUFFER REGISTER TO BE TRANSFERED INTO THE AC. THE BUFFER REGISTER IS NOT AFFECTED.

CLOCK COUNTER REGISTER TO AC (CLCA)

OCTAL CODE: 6137

OPERATION:

CAUSES THE CONTENTS OF THE CLOCK
COUNTER TO BE TRANSFERED INTO THE
CLOCK BUFFER REGISTER. THE BUFFER
REGISTER IS THEN TRANSFERED INTO
THE AC. THE COUNTER REGISTER
IS NOT AFFECTED.

10. LISTING

S

/

/DK8E CLOCKS DIAGNOSTIC

/

/COPYRIGHT 1971, DIGITAL EQUIP. CORP., MAYNARD, MASS.

/

/THE STARTING ADDRESS 0200 OCTAL.

/

/PLEASE READ DOCUMENT FOR FURTHER INFORMATION.

/

| | | | |
|------|------|---------|-------|
| | 0000 | *0000 | |
| | | / | |
| 0000 | 0000 | 0000 | |
| 0001 | 5001 | 5001 | |
| 0002 | 0002 | 0002 | |
| 0003 | 0003 | 0003 | |
| 0004 | 0000 | | 0000 |
| 0005 | 0000 | | 0000 |
| 0006 | 0207 | K0207, | 0207 |
| 0007 | 0007 | K0007, | 0007 |
| 0010 | 0000 | AUTO10, | 0000 |
| 0011 | 0000 | SAVAC, | 0000 |
| 0012 | 7700 | K7700, | 7700 |
| 0013 | 0100 | K0100, | 0100 |
| 0014 | 4000 | K4000, | 4000 |
| 0015 | 0200 | K0200, | 0200 |
| 0016 | 2525 | K2525, | 2525 |
| 0017 | 5252 | K5252, | 5252 |
| 0020 | 5102 | XI0TA, | I0TA |
| 0021 | 5107 | XI0TB, | I0TB |
| 0022 | 5114 | XI0TC, | I0TC |
| 0023 | 5121 | XI0TD, | I0TD |
| 0024 | 5127 | XI0TE, | I0TE |
| 0025 | 5134 | XI0TF, | I0TF |
| 0026 | 5142 | XI0TF1, | I0TF1 |
| 0027 | 5146 | XI0TG, | I0TG |
| 0030 | 5154 | XI0TH, | I0TH |
| 0031 | 5163 | XI0TI, | I0TI |
| 0032 | 5200 | XI0TJ, | I0TJ |
| 0033 | 5207 | XI0TK, | I0TK |
| 0034 | 5350 | XI0TS, | I0TS |
| 0035 | 5360 | XI0TS1, | I0TS1 |
| 0036 | 5370 | XI0TS2, | I0TS2 |
| 0037 | 5400 | XI0TS3, | I0TS3 |
| 0040 | 0000 | REGA, | 0000 |
| 0041 | 0000 | REGB, | 0000 |
| 0042 | 0000 | REGC, | 0000 |
| 0043 | 0000 | REGD, | 0000 |
| 0044 | 0000 | REGE, | 0000 |
| 0045 | 0000 | REGF, | 0000 |
| 0046 | 5642 | SKPWAT, | XWAIT |
| 0047 | 5255 | XPIG01, | PIG01 |
| 0050 | 5270 | XPIG02, | PIG02 |
| 0051 | 5323 | XPIG03, | PIG03 |
| 0052 | 5336 | XPIG04, | PIG04 |
| 0053 | 5234 | XPIG05, | PIG05 |

| | | | |
|------|------|---------|-----------|
| 0054 | 5310 | XISZ, | ISZLOP |
| 0055 | 5224 | RANDY, | RANDOM |
| 0056 | 5216 | XSNDRV, | SNDRV |
| 0057 | 5302 | XSYNC, | SYNC |
| 0060 | 5065 | XCLREG, | CLRREG |
| 0061 | 0215 | OVER2, | BCNEAC |
| 0062 | 0217 | OVER2A, | BCNEAC +2 |
| 0063 | 0570 | XDKSEP, | TST30 |
| 0064 | 3561 | XMITT, | TST202 |
| 0065 | 3556 | XMITT1, | TST202 -3 |
| 0066 | 5660 | XLAS, | SNLAS |
| 0067 | 5746 | XGTAD, | GTAD |
| 0070 | 0000 | SEND, | 0000 |
| 0071 | 0000 | RECEV, | 0000 |
| 0072 | 5000 | NERROR, | NERROR |
| 0073 | 5020 | ERROR, | ERRO |
| 0074 | 5413 | XCLOCK, | CLOCK |
| 0075 | 0000 | CLOCKS, | 0000 |
| 0076 | 0000 | KREGC, | 0000 |
| 0077 | 0000 | LOOP, | 0000 |
| 0100 | 5402 | JMP12, | JMP I 2 |
| 0101 | 5441 | XCRLF, | CRLF |
| 0102 | 5563 | XREG, | PREG |
| 0103 | 5471 | XSORT, | SORT |
| 0104 | 5420 | XOCTEL, | OCTEL |
| 0105 | 5542 | XMESS, | MESS |
| 0106 | 5624 | XPRINT, | PRINT |
| 0107 | 5056 | XTYPE, | TYPE |
| 0110 | 5046 | XBELL, | BELL |
| 0111 | 7730 | KPRMT1, | 7730 |
| 0112 | 7400 | K7400, | 7400 |
| 0113 | 0000 | KT1CPS, | 0000 |
| 0114 | 6007 | K6007, | 6007 |
| 0115 | 0006 | K0006, | 0006 |
| 0116 | 0400 | K0400, | 0400 |
| 0117 | 6000 | K6000, | 6000 |
| 0120 | 3000 | K3000, | 3000 |
| 0121 | 5000 | K5000, | 5000 |
| 0122 | 7770 | K7770, | 7770 |
| 0123 | 0260 | K0260, | 0260 |
| 0124 | 4100 | K4100, | 4100 |
| 0125 | 3740 | K3740, | 3740 |
| 0126 | 0240 | K0240, | 0240 |
| 0127 | 0017 | K0017, | 0017 |
| 0130 | 7774 | K7774, | 7774 |
| 0131 | 7773 | K7773, | 7773 |
| 0132 | 7772 | K7772, | 7772 |
| 0133 | 0077 | K0077, | 0077 |
| 0134 | 0215 | K0215, | 0215 |
| 0135 | 0212 | K0212, | 0212 |
| 0136 | 0377 | K0377, | 0377 |
| 0137 | 0040 | K0040, | 0040 |
| 0140 | 0020 | K0020, | 0020 |
| 0141 | 7000 | K7000, | 7000 |
| 0142 | 0010 | K0010, | 0010 |

```

0143 2000 K2000, 2000
0144 1000 K1000, 1000
0145 0300 K0300, 0300
0146 0500 K0500, 0500
0147 0600 K0600, 0600
0150 0700 K0700, 0700
0151 2725 KTA, 2725
0152 2650 KTA1, 2650
0153 7425 KTB, 7425
0154 7350 KTB1, 7350
0155 7753 KTC, 7753
0156 0225 KTC1, 0225
0157 0150 KTC2, 0150
0160 1450 KTD, 1450
0161 1425 KTD1, 1425
0162 6575 KTE, 6575
0163 6525 KTE1, 6525
0164 5600 XSET0, SET0
0165 5450 XOPR, POPR
0166 0070 PATCH, 0070
0167 5771 XGETM, TIMCLK
0170 5740 XPASS, PASS
0171 1775 XCRS1, T122B
0172 2200 XCRS2, T127A
0173 2603 XCRS3, T150A
0174 2565 XCRS4, T150B
0175 4003 XCRS5, T215A

```

0200

0200

```

0200 7300 BEGIN, CLA CLL /CLEAR THE AC AND LINK
0201 6007 6007 /CAF OR CLEAR THE WORLD
0202 4501 JMS I XCRLF /CRLF
0203 4506 JMS I XPRINT /PRINT DK8E CLOCKS DIAGNOSTIC
0204 6000 DKMES /MESSAGE POINTER
0205 4501 JMS I XCRLF /CRLF
0206 4400 JMS I XCLREG /CLEAR ALL MY REGISTERS
0207 4504 JMS I XSET0 /SET UP FOR PI RETURN
0210 4466 JMS I XLAS /GET HIS SWITCHES
0211 5465 JMP I XMITT1 /TEST SCHMITT
0212 5463 JMP I XD8EP /TEST DK8EP CLOCK
0213 4474 JMS I XCLOCKS /TEST DK8EA OR DK8EC
0214 4565 JMS I XOPR /SORT AND PRINT FREQ. SELECTED
0215 4567 BGNEAC, JMS I XGETM /GET TIME LENGTH
0216 3077 DCA LOOP /SET LOOP COUNTER
0217 4400 JMS I XCLREG /CLEAR ALL REGISTERS
0220 3040 DCA REGA

```

/ DOES IOT CLEI CHANGE AC ?
/CHECK ALL COMBINATIONS

```

0221 1040 TST0, TAD REGA /GET AC NUMBER
0222 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
0223 1070 TAD SEND
0224 4420 JMS I XIOTA /IOT 6131, CLEI

```

```

0225 3071          DCA RECEV          /SAVE INPUT FOR ERROR PRINTER
0226 1071          TAD RECEV
0227 4456          JMS I XSNDRV          /CHECK SEND AND RECEV REGISTERS
0230 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER.
0231 4473          JMS I ERROR          /ERROR: CLEI CHANGED AC.
0232 3000          3000          /TST0 ERROR MESSAGE.
0233 0221          TST0          /SCOPE LOOP.
0234 3040          DCA REGA

```

```

/
/DOES IOT CLED CHANGE AC ?
/CHECK ALL COMBINATIONS
/

```

```

0235 1040          TST1,  TAD REGA          /GET AC NUMBER
0236 3070          DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
0237 1070          TAD SEND
0240 4421          JMS I XIOTB          /IOT 6132, CLED
0241 3071          DCA RECEV          /SAVE INPUT FOR ERROR PRINTER
0242 1071          TAD RECEV
0243 4456          JMS I XSNDRV          /CHECK SEND AND RECEV REGISTERS
0244 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER.
0245 4473          JMS I ERROR          /ERROR: CLED CHANGED AC.
0246 3001          3001          /TST1 ERROR MESSAGE.
0247 0235          TST1          /SCOPE LOOP.
0250 3040          DCA REGA

```

```

/
/DOES IOT CLSK CHANGE AC ?
/CHECK ALL COMBINATIONS
/

```

```

0251 1040          TST2,  TAD REGA          /GET AC NUMBER
0252 3070          DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
0253 1070          TAD SEND
0254 4422          JMS I XIOTC          /IOT 6133, CLSK
0255 7000          NOP          /WAIT JUST IN CASE !
0256 3071          DCA RECEV          /SAVE INPUT FOR ERROR PRINTER
0257 1071          TAD RECEV
0260 4456          JMS I XSNDRV          /CHECK SEND AND RECEV REGISTERS
0261 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER.
0262 4473          JMS I ERROR          /ERROR: CLSK CHANGED AC.
0263 3002          3002          /TST2 ERROR MESSAGE.
0264 0251          TST2          /SCOPE LOOP.

```

```

/
/TEST FOR NO INTERRUPT RQST.
/

```

```

0265 6007          TST3,  6007          /CAF OR CLEAR THE WORLD
0266 4447          JMS I XPIG01          /GO TO PI, NO PI EXPECTED
0267 4472          JMS I NERROR          /CHECK NON-ERROR HANDLER
0270 4473          JMS I ERROR          /ERROR:PI OR INT. RQST. FAILED
0271 1003          1003          /TST3 ERROR MESSAGE
0272 0265          TST3          /SCOPE LOOP

```

```

/
/DOES CLSK SKIP ON A CLOCK FLAG
/

```

```

0273 1113          TST4,  TAD KT10PS
0274 3045          DCA REGF          /SET UP TIMER
0275 4422          JMS I XIOTC          /IOT 6133, CLSK

```

```

0276 7020      NOP
0277 4422      JMS I XIOTC    /IOT 6133, CLSK
0300 4446      JMS I SKPWAT   /GO WAIT FOR FLAG
0301 4472      JMS I NERROR   /CHECK NON-ERROR HANDLER
0302 4473      JMS I ERROR    /ERROR: CLSK OR FLAG FAILED
0303 0404      0404      /TST4 ERROR MESSAGE
0304 0273      TST4          /SCOPE LOOP

```

/

/DOES CLSK CLEAR THE FLAG ?

/

```

0305 1113      TST5, TAD KT1CPS
0306 3045      DCA REGF      /SET UP TIMER
0307 4422      JMS I XIOTC    /IOT 6133, CLSK
0310 7020      NOP
0311 4422      JMS I XIOTC    /IOT 6133, CLSK
0312 4446      JMS I SKPWAT   /GO WAIT FOR FLAG
0313 7410      SKP          /GOT THE FLAG
0314 5704      JMP I .-10     /GO BACK TO TEST 4
0315 4422      JMS I XIOTC    /IOT 6133, CLSK
0316 4472      JMS I NERROR   /CHECK NON-ERROR HANDLER
0317 4473      JMS I ERROR    /ERROR: CLSK CLEAR THE FLAG FAILED
0320 0005      0005      /TST5 ERROR MESSAGE
0321 0305      TST5          /SCOPE LOOP

```

/

/DOES CLEI ENABLE CLOCK INTERRUPT ?

/

```

0322 4420      TST6, JMS I XIOTA    /IOT 6131, CLEI
0323 4450      JMS I XPIG02   /GO TO PI, PI EXPECTED
0324 4472      JMS I NERROR   /CHECK NON-ERROR HANDLER,
0325 4473      JMS I ERROR    /ERROR: DID CLEI ENABLE CLOCK INTERRUPT ?
0326 1406      1406      /TST6 ERROR MESSAGE
0327 0322      TST6          /SCOPE LOOP.

```

/

/DOES CLED DISABLE CLOCK INTERRUPT ?

/

```

0330 4420      TST7, JMS I XIOTA    /IOT 6131, CLEI
0331 4421      JMS I XIOTB    /IOT 6132, CLED
0332 4447      JMS I XPIG01   /GO TO PI, NO PI EXPECTED
0333 4472      JMS I NERROR   /CHECK NON-ERROR HANDLER,
0334 4473      JMS I ERROR    /ERROR: DID CLED DISABLE CLOCK INTERRUPT?
0335 1007      1007      /TST7 ERROR MESSAGE
0336 0330      TST7          /SCOPE LOOP.

```

/

/DOES CAF DISABLE CLOCK INTERRUPT ?

/

```

0337 4420      TST10, JMS I XIOTA    /IOT 6131, CLEI
0340 6007      6007      /CAF OR CLEAR THE WORLD
0341 4447      JMS I XPIG01   /GO TO PI, NO PI EXPECTED
0342 4472      JMS I NERROR   /CHECK NON-ERROR HANDLER,
0343 4473      JMS I ERROR    /ERROR: DID CAF DISABLE CLOCK INTERRUPT ?
0344 1010      1010      /TST10 ERROR MESSAGE
0345 0337      TST10     /SCOPE LOOP.

```

/

/DOES CLEI ENABLE CLOCK INTERRUPT ?

/

```

0346 4420 TST11, JMS I XIOTA /IOT 6131, CLEI
0347 4447 JMS I XPIG01 /GO TO PI, PI EXPECTED
0350 5354 JMP T11A
0351 4420 JMS I XIOTA /IOT 6131, CLEI
0352 4450 JMS I XPIG02 /GO TO PI, PI EXPECTED
0353 4472 JMS I NERROR /CHECK NON-ERROR HANDLER,
0354 4473 T11A, JMS I ERROR /ERROR: CLEI AND CLED FAST TOGGLE
0355 1411 1411 /TS11 ERROR MESSAGE
0356 0346 TST11 /SCOPE.

```

/

/DOES CLED DISABLE CLOCK INTERRUPT ?

/

```

0357 4420 TST12, JMS I XIOTA /IOT 6131, CLEI
0360 4421 JMS I XIOTB /IOT 6132, CLED
0361 4450 JMS I XPIG02 /GO TO PI, NO PI EXPECTED
0362 5366 JMP T12A
0363 4421 JMS I XIOTB /IOT 6132, CLED
0364 4447 JMS I XPIG01 /GO TO PI, NO PI EXPECTED
0365 4472 JMS I NERROR /CHECK NON-ERROR HANDLER,
0366 4473 T12A, JMS I ERROR /ERROR: CLEI AND CLED FAST TOGGLE
0367 1012 1012 /TST12 ERROR MESSAGE
0370 0357 TST12 /SCOPE LOOP.

```

/

/TEST DECODER FOR 6135, NOT CLEI

/

```

0371 4421 TST13, JMS I XIOTB /IOT 6132, CLED
0372 4431 JMS I XIOTI /IOT 6135, NOT AN IOT 6131
0373 4447 JMS I XPIG01 /GO TO PI, NO PI EXPECTED
0374 4472 JMS I NERROR /CHECK NON-ERROR HANDLER,
0375 4473 JMS I ERROR /ERROR: DID DECODER WORK
0376 1013 1013 /TST13 ERROR MESSAGE
0377 0371 TST13 /SCOPE LOOP.

```

/

/TEST DECODER FOR A 6136, NOT CLED

/

```

0400 4420 TST14, JMS I XIOTA /IOT 6131, CLEI
0401 4432 JMS I XIOTJ /IOT 6136, NOT AN IOT 6132.
0402 4450 JMS I XPIG02 /GO TO PI, PI EXPECTED
0403 4472 JMS I NERROR /CHECK NON-ERROR HANDLER,
0404 4473 JMS I ERROR /ERROR: DID DECODER WORK
0405 1414 1414 /TST14 ERROR MESSAGE
0406 0400 TST14 /SCOPE LOOP.

```

/

/TEST DECODER FOR 6137, NOT CLSK

/

```

0407 1113 TST15, TAD KT1CPS
0410 3045 DCA REGF /SET UP TIMER
0411 4422 JMS I XIOTC /IOT 6132, CLED
0412 7000 NOP
0413 4433 JMS I XIOTK /IOT 6137, NOT AN IOT 6133
0414 4446 JMS I SKPWAT /GO WAIT FOR FLAG
0415 7410 SKP /ERROR, SKIP OCCURRED
0416 4472 JMS I NERROR /CHECK NON-ERROR HANDLER,
0417 4473 JMS I ERROR /ERROR: DID DECODER WORK
0420 0015 0015 /TST15 ERROR MESSAGE

```

```

0421 0407          TST15          /SCOPE LOOP.
/
/DOES CLSK ENABLE CLOCK INTERRUPT ?
/
0422 4422          TST16, JMS I XIOTC          /IOT 6133, CLSK
0423 7000          NOP
0424 4447          JMS I XPIG01         /GO TO PI, NO PI EXPECTED
0425 4472          JMS I NERROR        /CHECK NON-ERROR HANDLER,
0426 4473          JMS I ERROR         /ERROR: DID CLSK CAUSE INTERRUPT
0427 1016          1016                /TST16 ERROR MESSAGE
0430 0422          TST16                /SCOPE LOOP.
/
/DOES CLSK DISABLE CLOCK INTERRUPT ?
/
0431 4420          TST17, JMS I XIOTA          /IOT 6131, CLEI
0432 4422          JMS I XIOTC          /IOT 6133, CLSK
0433 7000          NOP
0434 4450          JMS I XPIG02         /GO TO PI, PI EXPECTED
0435 4472          JMS I NERROR        /CHECK NON-ERROR HANDLER,
0436 4473          JMS I ERROR         /ERROR: CLSK DISABLED CLOCK INTERRUPT
0437 1417          1417                /TST17 ERROR MESSAGE
0440 0431          TST17                /SCOPE LOOP.
/
/DOES CLEI CAUSE A SKIP ON FLAG ?
/
0441 1113          TST20, TAD KT1CPS
0442 3045          DCA REGF            /SET UP TIMER
0443 4420          JMS I XIOTA          /IOT 6131, CLEI
0444 4446          JMS I SKPWAT        /GO WAIT FOR FLAG
0445 7410          SKP                 /ERROR, SKIP OCCURRED
0446 4472          JMS I NERROR        /CHECK NON-ERROR HANDLER,
0447 4473          JMS I ERROR         /ERROR: DID CLEI CAUSE A SKIP
0450 0020          0020                /TST20 ERROR MESSAGE
0451 0441          TST20                /SCOPE LOOP.
/
/DOES CLED CAUSE A SKIP ON FLAG ?
/
0452 1113          TST21, TAD KT1CPS
0453 3045          DCA REGF            /SET UP TIMER
0454 4421          JMS I XIOTB          /IOT 6132, CLED
0455 4446          JMS I SKPWAT        /GO WAIT FOR FLAG
0456 7410          SKP                 /ERROR, SKIP OCCURRED
0457 4472          JMS I NERROR        /CHECK NON-ERROR HANDLER,
0460 4473          JMS I ERROR         /ERROR: DID CLED CAUSE A SKIP ON FLAG
0461 0021          0021                /TST21 ERROR MESSAGE
0462 0452          TST21                /SCOPE LOOP.
/
/DOES INT. RQST STAY DOWN ?
/
0463 4457          TST22, JMS I XSYNC          /SYNC WITH CLOCK
0464 4420          JMS I XIOTA          /IOT 6131, CLEI
0465 4447          JMS I XPIG01         /GO TO PI, PI EXPECTED
0466 5273          JMP T22A            /ERROR, PI FAILED
0467 2041          ISZ REGB
0470 5267          JMP .-1              /WAIT 15.5 MS

```

```

0471 4452          JMS I XPIG04  /GO TO PI, PI EXPECTED
0472 4472          JMS I NERROR  /CHECK NON-ERROR HANDLER
0473 4473 T22A,    JMS I ERROR   /ERROR: DID RQST. LAST ?
0474 1422          1422        /TST21 ERROR MESSAGE
0475 0463          TST22        /SCOPE LOOP

```

/DOES CLSK CLEAR RQST. LINE ?

```

0476 4420 TST23,  JMS I XIOTA   /IOT 6131, CLEI
0477 4457          JMS I XSYNC   /SYNC WITH CLOCK FLAG
0500 4451          JMS I XPIG03  /GO TO PI, NO PI EXPECTED
0501 4472          JMS I NERROR  /CHECK NON-ERROR HANDLER
0502 4473          JMS I ERROR   /ERROR: DID CLSK CLEAR RQST. FLAG
0503 1023          1023        /TST23 ERROR MESSAGE
0504 0476          TST23        /SCOPE LOOP

```

/SYNC WITH CLOCK AND
/CHECK FOR FAST OUTPUT

```

0505 4467 TST24,  JMS I XGTAD   /GET TIME CONSTANTS
0506 0000          0000        /MODIFIED BY TEST
0507 1706          TAD I .-1
0510 3043          DCA REGD
0511 4420          JMS I XIOTA   /IOT 6131, CLEI
0512 4457          JMS I XSYNC   /SYNC WITH CLOCK
0513 4447          JMS I XPIG01  /GO TO PI, NO PI EXPECTED
0514 4472          JMS I NERROR  /CHECK NON-ERROR HANDLER,,
0515 4473          JMS I ERROR   /ERROR: CLOCK FREQUENCY FAST.
0516 2024          2024        /TST24 ERROR MESSAGE.
0517 0505          TST24        /SCOPE LOOP.

```

/SYNC WITH CLOCK AND
/CHECK FOR SLOW OUTPUT

```

0520 1115 TST25,  TAD K0006   /SETUP FOR SLOW CLOCK
0521 4467          JMS I XGTAD   /GET TIME CONSTANTS
0522 0000          0000        /MODIFIED BY TEST
0523 1722          TAD I .-1
0524 3043          DCA REGD
0525 4420          JMS I XIOTA   /IOT 6131, CLEI
0526 4457          JMS I XSYNC   /SYNC WITH CLOCK
0527 4450          JMS I XPIG02  /GO TO PI, PI EXPECTED
0530 4472          JMS I NERROR  /CHECK NON-ERROR HANDLER.
0531 4473          JMS I ERROR   /ERROR: CLOCK FREQUENCY SLOW.
0532 2425          2425        /TST25 ERROR MESSAGE.
0533 0520          TST25        /SCOPE LOOP.

```

/CHECK FOR FAST CLOCK AND
/BAD CLOCK FLAG WITH CLSK.

```

0534 4467 TST26,  JMS I XGTAD   /GET TIME CONSTANTS
0535 0000          0000        /MODIFIED BY TEST
0536 1735          TAD I .-1
0537 3043          DCA REGD
0540 4457          JMS I XSYNC   /SYNC WITH CLOCK

```

```

0541 4454 JMS I XISZ /WAIT
0542 4422 JMS I XIOTC /IOT 6133, CLSK
0543 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0544 4473 JMS I ERROR /ERROR: CLOCK FAILED
0545 2026 2026 /TST26 ERROR MESSAGE
0546 0534 TST26 /SCOPE LOOP

```

```

/
/CHECK FOR SLOW CLOCK AND
/BAD CLOCK FLAG WITH CLSK
/

```

```

0547 1115 TST27, TAD K0006 /SET UP FOR SLOW CLOCK
0550 4467 JMS I XGTAD /GET TIME CONSTANTS
0551 0000 0000 /MODIFIED BY TEST
0552 1751 TAD I .-1
0553 3043 DCA REGD
0554 4457 JMS I XSYNC /SYNC WITH CLOCK
0555 4454 JMS I XISZ /WAIT
0556 4422 JMS I XIOTC /IOT 6133, CLSK
0557 7410 SKP /ERROR, SKIP OCCURRED
0560 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0561 4473 JMS I ERROR /ERROR: CLSK OR CLOCK FLAG FAILED
0562 2427 2427 /TST27 ERROR MESSAGE
0563 0547 TST27 /SCOPE LOOP
0564 2077 ISZ LOOP
0565 5462 JMP I OVER2A /LOOP ON TEST
0566 4570 JMS I XPASS /TYPE PASS COMPLETE
0567 5461 JMP I OVER2 /RESET COUNTER AND CONTINUE TESTING

```

```

/
/DOES IOT CLZE CHANGE AC?
/CHECK ALL COMBINATIONS.
/
/

```

```

0570 1040 TST30, TAD REGA /GET AC NUMBER
0571 4423 JMS I XIOTD /IOT 6130, CLZE
0572 3071 DCA RECEV /SAVE INPUT FOR ERROR PRINTER
0573 1071 TAD RECEV
0574 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
0575 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0576 4473 JMS I ERROR /ERROR: CLZE CHANGED AC
0577 3030 3030 /TST30 ERROR MESSAGE
0600 0570 TST30 /SCOPE LOOP

```

```

/
/DOES IOT CLSK CHANGE AC?
/CHECK ALL COMBINATIONS
/

```

```

0601 1040 TST31, TAD REGA /GET AC NUMBER
0602 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
0603 1070 TAD SEND
0604 4424 JMS I XIOTE /IOT 6131, CLSK
0605 7000 NOP
0606 3071 DCA RECEV /SAVE INPUT FOR ERROR PRINTER
0607 1071 TAD RECEV
0610 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
0611 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0612 4473 JMS I ERROR /ERROR: CLSK CHANGED AC.

```

0613 3031 3031 /TST31 ERROR MESSAGE
 0614 0601 TST31 /SCOPE LOOP

/
 /DOES IOT CLOE CHANGE AC?
 /CHECK ALL COMBINATIONS
 /

0615 1040 TST32, TAD REGA /GET AC NUMBER
 0616 4425 JMS I XIOTF /IOT 6132, CLOE
 0617 3071 DCA RECEV /SAVE INPUT FOR ERROR PRINTER
 0620 1071 TAD RECEV
 0621 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 0622 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 0623 4473 JMS I ERROR /ERROR:CLDE CHANGED AC
 0624 3032 3032 /TST32 ERROR MESSAGE
 0625 0615 TST32 /SCOPE LOOP

/
 /DOES IOT CLAB CHANGE AC?
 /CHECK ALL COMBINATIONS
 /

0626 1040 TST33, TAD REGA /GET AC NUMBER
 0627 4427 JMS I XIOTG /IOT 6133, CLAB
 0630 3071 DCA RECEV /SAVE INPUT FOR ERROR PRINTER
 0631 1071 TAD RECEV
 0632 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 0633 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 0634 4473 JMS I ERROR /ERROR:CLAB CHANGED AC
 0635 3033 3033 /TST33 ERROR MESSAGE
 0636 0626 TST33 /SCOPE LOOP

/
 /DOES CAF CLEAR BUFFER REGISTER?
 /CHECK FOR JAM TO AC, CLBA.
 /

0637 6007 TST34, 6007 /CAF OR CLEAR THE WORLD
 0640 7340 CLA CLL CMA /AC TO 7777
 0641 4432 JMS I XIOTJ /IOT 6136, CLBA
 0642 7650 SNA CLA /WAS BUFFER ALL 0'S?
 0643 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 0644 4473 JMS I ERROR /ERROR:CAF OR CLBA FAILED.
 0645 3434 3434 /TST34 ERROR MESSAGE
 0646 0637 TST34 /SCOPE LOOP

/
 /DOES CAF CLEAR ENABLE REGISTER?
 /CHECK FOR JAM TO AC, CLEN.
 /

0647 6007 TST35, 6007 /CAF OR CLEAR THE WORLD
 0650 7340 CLA CLL CMA /AC TO 7777
 0651 4430 JMS I XIOTH /IOT 6134, CLEN
 0652 7650 SNA CLA /WAS ENABLE REGISTER ALL 0'S?
 0653 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 0654 4473 JMS I ERROR /ERROR:CAL OR CLEN FAILED.
 0655 4435 4435 /TST35 ERROR MESSAGE
 0656 0647 TST35 /SCOPE LOOP

/
 /DOES CAF CLEAR STATUS REGISTER ?
 /CHECK J.M TO AC CLSA

/
 TST36, 6007 /CAF OR THE CLEAR THE WORLD
 0657 6007 CLA CLL CMA /AC TO 7777
 0660 7340 JMS I XIOTI /IOT 6135, CLSA
 0661 4431 SNA CLA /WAS STATUS REGISTER ALL 0'S ?
 0662 7650 JMS I NERROR /CHECK NON-ERROR HANDLER
 0663 4472 JMS I ERROR /CAF OR CLSA FAILED
 0664 4473 5036 /TST36 ERROR MESSAGE
 0665 5036 TST36 /SCOPE LOOP
 0666 0657

/
 /DOES AC LOAD BUFFER REGISTER?
 /CHECK ALL 0'S TRANSFER
 /CHECK JAM TO AC, CLBA

/
 TST37, JMS I XIOTG /IOT 6133, CLAB
 0667 4427 CLA CLL CMA /AC TO 7777
 0670 7340 JMS I XIOTJ /IOT 6136, CLBA
 0671 4437 SNA CLA /WAS BUFFER ALL 0'S?
 0672 7650 JMS I NERROR /CHECK NON-ERROR HANDLER
 0673 4472 JMS I ERROR /ERROR:CLAB OR CLBA FAILED
 0674 4473 3437 /TST37 ERROR MESSAGE
 0675 3437 TST37 /SCOPE LOOP
 0676 0667

/
 /DOES AC LOAD BUFFER REGISTER ?
 /CHECK ALL 1'S TRANSFER
 /CHECK JAM TO AC , CLBA

/
 TST40, CLA CLL CMA /AC TO 7777
 0677 7340 JMS I XIOTG /IOT 6133, CLAB
 0700 4427 CLA CLL /CLEAR THE AC AND LINK
 0701 7300 JMS I XIOTJ /IOT 6136, CLBA
 0702 4432 CMA /COMPLEMENT THE AC
 0703 7040 SNA CLA /WAS BUFFER ALL 1'S?
 0704 7650 JMS I NERROR /CHECK NON-ERROR HANDLER
 0705 4472 JMS I ERROR /ERROR:CLAB OR CLBA FAILED
 0706 4473 3440 /TST40 ERROR MESSAGE
 0707 3440 TST40 /SCOPE LOOP
 0710 0677

/
 /DOES BUFFER SURVIVE PATTERN 2525 ?

/
 TST41, TAD K2525 /GET AC NUMBER
 0711 1016 JMS I XIOTG /IOT 6133, CLAB
 0712 4427 CMA /COMPLEMENT AC
 0713 7040 JMS I XIOTJ /IOT 6136, CLBA
 0714 4432 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 0715 4456 JMS I NERROR /CHECK NON-ERROR HANDLER
 0716 4472 JMS I ERROR /ERROR: BUFFER OR AC FAILED
 0717 4473 3441 /TST41 ERROR MESSAGE
 0720 3441 TST41 /SCOPE LOOP
 0721 0711

/
 /DOES BUFFER SURVIVE PATTERN 5252 ?

```

0722 1017 TST42, TAD K5252 /GET AC NUMBER
0723 4427 JMS I XIOTG /IOT 6133, CLXB
0724 7040 CMA /COMPLEMENT AC
0725 4432 JMS I XIOTJ /IOT 6136, CLBA
0726 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
0727 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0730 4473 JMS I ERROR /ERROR: BUFFER OR AC FAILED
0731 3442 3442 /TST42 ERROR MESSAGE
0732 0722 TST42 /SCOPE LOOP

```

/DOES CAF REALLY CLEAR BUFFER ?

```

0733 7240 TST43, CLA CLA CMA /AC TO ALL 7777
0734 4427 JMS I XIOTG /IOT 6133, CLAB
0735 6007 6007 /CAF OR CLEAR THE WORLD
0736 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
0737 7340 CLA CLL CMA
0740 4432 JMS I XIOTJ /IOT 6136, CLBA
0741 7650 SNA CLA /WAS BUFFER ALL 0'S ?
0742 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0743 4473 JMS I ERROR /ERROR: CAF OR BUFFER FAILED
0744 3443 3443 /TST43 ERROR MESSAGE
0745 0733 TST43 /SCOPE LOOP

```

/DOES CAF REALLY CLEAR BUFFER ?

/DO ALL COMBINATIONS

```

0746 1040 TST44, TAD REGA /GET AC NUMBER
0747 4427 JMS I XIOTG /IOT 6133, CLAB
0750 6007 6007 /CAF OR CLEAR THE WORLD
0751 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
0752 7340 CLA CLL CMA
0753 4432 JMS I XIOTJ /IOT 6136, CLBA
0754 7650 SNA CLA /WAS BUFFER ALL 0'S ?
0755 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
0756 4473 JMS I ERROR /ERROR: CAF OR BUFFER FAILED
0757 3444 3444 /TST44 ERROR MESSAGE
0760 0746 TST44 /SCOPE LOOP

```

/CHECK AC TO BUFFER REGISTER AND
/BUFFER REGISTER TO AC TRANSFERS.
/CHECK ALL COMBINATIONS.
/CHECK LOAD ON BUFFER REGISTER.

```

0761 7340 TST45, CLA CLL CMA
0762 3040 DCA REGA
0763 1041 T45B, TAD REGB /GET AC NUMBER
0764 4427 JMS I XIOTG /IOT 6133, CLAB
0765 7040 CMA /COMPLEMENT THE AC
0766 4432 JMS I XIOTJ /IOT 6136, CLBA
0767 4456 JMS I XSNDRV /CHECK SEND RECEV REGISTERS
0770 7610 SKP CLA
0771 5375 JMP T45A
0772 2041 ISZ REGB /UPDATE AC NUMBER

```

```

0773 5363          JMP T45B
0774 4472          JMS I NERROR /CHECK NON-ERROR HANDLER
0775 4473 T45A,    JMS I ERROR  /ERROR: AC OR BUFFER FAILED.
0776 3445          3445      /TST45 ERROR MESSAGE
0777 0761          TST45      /SCOPE LOOP

```

/
/DOES READING BUFFER CHANGE ITS CONTENTS ?
/

```

1000 7340 TST46,  CLA CLL CMA /AC TO 7777
1001 3040          DCA REGA
1002 1016          TAD K2525 /GET AC NUMBER
1003 4427          JMS I XIOTG /IOT 6133, CLAB
1004 7040          CMA      /COMPLEMENT AC
1005 4432 T46B,    JMS I XIOTJ /IOT 6136, CLBA
1006 4456          JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
1007 7610          SKP CLA
1010 5214          JMP T46A
1011 2041          ISZ REGB /UPDATE COUNTER
1012 5205          JMP T46B /DO 4096 TIMES
1013 4472          JMS I NERROR /CHECK NON-ERROR HANDLER
1014 4473 T46A,    JMS I ERROR  /ERROR: BUFFER FAILED
1015 3446          3446      /TST46 ERROR MESSAGE
1016 1000          TST46      /SCOPE LOOP

```

/
/DOES READING BUFFER CHANGE ITS CONTENTS ?
/

```

1017 7340 TST47,  CLA CLL CMA /AC TO 7777
1020 3040          DCA REGA
1021 1017          TAD K2525 /GET AC NUMBER
1022 4427          JMS I XIOTG /IOT 6133, CLAB
1023 7040          CMA      /COMPLEMENT AC
1024 4432 T47B,    JMS I XIOTJ /IOT 6136, CLBA
1025 4456          JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
1026 7610          SKP CLA
1027 5233          JMP T47A
1030 2041          ISZ REGB /UPDATE COUNTER
1031 5224          JMP T47B /DO 4096 TIMES
1032 4472          JMS I NERROR /CHECK NON-ERROR HANDLER
1033 4473 T47A,    JMS I ERROR  /ERROR: BUFFER FAILED
1034 3447          3447      /TST47 ERROR MESSAGE
1035 1017          TST47      /SCOPELOOP

```

/
/DOES BUFFER SURVIVE RANDOM PATTERNS ?
/

```

1036 7340 TST50,  CLA CLL CMA /AC TO 7777
1037 3040          DCA REGA
1040 4455 T50B,    JMS I RANDY /GET RANDOM NUMBER
1041 4427          JMS I XIOTG /IOT 6133, CLAB
1042 7040          CMA      /COMPLEMENT AC
1043 4432          JMS I XIOTJ /IOT 6136, CLBA
1044 4456          JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
1045 7610          SKP CLA
1046 5252          JMP T50A
1047 2041          ISZ REGB /UPDATE COUNTER
1050 5240          JMP T50B /DO 4096 TIMES

```

```

1051 4472      JMS I NERROR /CHECK NON-ERROR HANDLER
1052 4473 T50A, JMS I ERROR /ERROR: BUFFER FAILED
1053 3450      3450 /TST50 ERROR MESSAGE
1054 1036      TST50 /SCOPE LOOP
/
/DOES BUFFER SURVIVE FAST TOGGLE ?
/
1055 1040 TST51, TAD REGA /GET AC NUMBER
1056 3070      DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
1057 1040      TAD REGA
1060 4435      JMS I XIOTS1 /IOT'S 6133 AND 6136
1061 3071      DCA RECEV /SAVE INPUT FOR ERROR PRINTER
1062 1071      TAD RECEV
1063 4456      JMS I XSNDRV /CHECK SEND RECEV REGISTERS
1064 4472      JMS I NERROR /CHECK NON-ERROR HANDLER
1065 4473      JMS I ERROR /ERROR: BUFFER FAILED
1066 3451      3451 /TST51 ERROR MESSAGE
1067 1055      TST51 /SCOPE LOOP
/
/DOES AC SET ENABLE REGISTER?
/CHECK ALL 1'S TRANSFER.
/CHECK JAM TO AC, CLEN
/
1070 7340 TST52, CLA CLL CMA /AC TO 7777
1071 4425      JMS I XIOTF /IOT 6132, CLOE
1072 7040      CMA /COMPLEMENT AC
1073 4430      JMS I XIOTH /IOT 6134, CLEN
1074 7040      CMA /COMPLEMENT AC
1075 7650      SNA CLA /WAS ENABLE REGISTER ALL 1'S ?
1076 4472      JMS I NERROR /CHECK NON-ERROR HANDLER
1077 4473      JMS I ERROR /ERROR:CLOE OR CLEN FAILED.
1100 4452      4452 /TST52 ERROR MESSAGE
1101 1070      TST52 /SCOPE LOOP
/
/DOES AC SET ENABLE REGISTER?
/CHECK ALL 0'S TRANSFER.
/
/CHECK FOR JAM TO AC , CLEN
/
1102 7340 TST53, CLA CLL CMA /AC TO 7777
1103 4425      JMS I XIOTF /IOT 6132, CLOE
1104 7300      CLA CLL /CLEAR THE AC AND LINK
1105 4426      JMS I XIOTF1 /IOT 6132, CLOE
1106 4430      JMS I XIOTH /IOT 6134, CLEN
1107 7040      CMA /COMPLEMENT THE AC
1110 7650      SNA CLA /WAS ENABLE REGISTER ALL 1'S?
1111 4472      JMS I NERROR /CHECK NON-ERROR HANDLER
1112 4473      JMS I ERROR /ERROR:CLOE OR CLEN FAILED
1113 4453      4453 /TST53 ERROR MESSAGE
1114 1102      TST53 /SCOPE LOOP
/
/DOES CAF REALLY CLEAR ENABLE REGISTER?
/
1115 7340 TST54, CLA CLL CMA /AC TO 7777
1116 4425      JMS I XIOTF /IOT 6132, CLOE

```

| | | | |
|------|------|--------------|--------------------------------|
| 1117 | 6007 | 6007 | /CAF OR CLEAR THE WORLD |
| 1120 | 3070 | DCA SEND | /SAVE OUTPUT FOR ERROR PRINTER |
| 1121 | 7340 | CLA CLL CMA | /AC TO 7777 |
| 1122 | 4430 | JMS I XIOTH | /IOT 6134, CLEN |
| 1123 | 7650 | SNA CLA | /WAS REGISTER ALL 0'S |
| 1124 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1125 | 4473 | JMS I ERROR | /ERROR:CAF,CLOE,OR CLEN FAILED |
| 1126 | 4454 | 4454 | /TST54 ERROR MESSAGE |
| 1127 | 1115 | TST54 | /SCOPE LOOP |

/

/DOES CAF REALLY CLEAR ENABLE REGISTER ?

/DO ALL COMBINATIONS

| | | | |
|------|------|-----------------|--------------------------------|
| 1130 | 1040 | TST55, TAD REGA | /GET AC NUMBER |
| 1131 | 4426 | JMS I XIOTF1 | /IOT 6132, CLOE |
| 1132 | 6007 | 6007 | /CAF OR CLEAR THE WORLD |
| 1133 | 7340 | CLA CLL CMA | /AC TO 7777 |
| 1134 | 4430 | JMS I XIOTH | /IOT 6134, CLEN |
| 1135 | 7650 | SNA CLA | /WAS ENABLE REGISTER ALL 0'S ? |
| 1136 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1137 | 4473 | JMS I ERROR | /ERROR: ENABLE REGISTER FAILED |
| 1140 | 4455 | 4455 | /TST55 ERROR MESSAGE |
| 1141 | 1130 | TST55 | /SCOPE LOOP |

/

/DOES ENABLE REGISTER SURVIVE PATTERN 2525 ?

| | | | |
|------|------|------------------|---------------------------------|
| 1142 | 1016 | TST56, TAD K2525 | /GET AC NUMBER |
| 1143 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 1144 | 7040 | CMA | /COMPLEMENT AC |
| 1145 | 4430 | JMS I XIOTH | /IOT 6134, CLEN |
| 1146 | 4456 | JMS I XSNDRV | /CHECK SEND AND RECEV REGISTERS |
| 1147 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1150 | 4473 | JMS I ERROR | /ERROR: EBABLE REGISTER FAILED |
| 1151 | 4456 | 4456 | /TST56 ERROR MESSAGE |
| 1152 | 1142 | TST56 | /SCOPE LOOP |

/

/DOES ENABLE REGISTER SURVIVE PATTERN 5252 ?

| | | | |
|------|------|------------------|---------------------------------|
| 1153 | 1017 | TST57, TAD K5252 | /GET AC NUMBER |
| 1154 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 1155 | 7040 | CMA | /COMPLEMENT AC |
| 1156 | 4430 | JMS I XIOTH | /IOT 6134, CLEN |
| 1157 | 4456 | JMS I XSNDRV | /CHECK SEND AND RECEV REGISTERS |
| 1160 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1161 | 4473 | JMS I ERROR | /ERROR: ENABLE REGISTER FAILED |
| 1162 | 4457 | 4457 | /TST57 ERROR MESSAGE |
| 1163 | 1153 | TST57 | /SCOPE LOOP |

/

/DOES ENABLE REGISTER SURVIVE PATTERN 2525 ?

| | | | |
|------|------|------------------|------------------------|
| 1164 | 1016 | TST60, TAD K2525 | /GET AC NUMBER |
| 1165 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 1166 | 7300 | CLA CLL | /CLEAR THE AC AND LINK |
| 1167 | 4426 | JMS I XIOTF1 | /IOT 6132, CLOE |
| 1170 | 7340 | CLA CLL CMA | /AC TO 7777 |

| | | | |
|------|------|--------------|---------------------------------|
| 1171 | 4430 | JMS I XIOTH | /IOT 6134, CLEN |
| 1172 | 4456 | JMS I XSNDRV | /CHECK SEND AND RECEV REGISTERS |
| 1173 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1174 | 4473 | JMS I ERROR | /ERROR: ENABLE REGISTER FAILED |
| 1175 | 4460 | 4460 | /TST60 ERROR MESSAGE |
| 1176 | 1164 | TST60 | /SCOPE LOOP |

/

/DOES ENABLE REGISTER SURVIVE PATTERN 5252 ?

/

| | | | |
|------|------|------------------|---------------------------------|
| 1177 | 1017 | TST61, TAD K5252 | /GET AC NUMBER |
| 1200 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 1201 | 7300 | CLA CLL | /CLEAR THE AC AND LINK |
| 1202 | 4426 | JMS I XIOTF1 | /IOT 6132, CLOE |
| 1203 | 7340 | CLA CLL CMA | /AC TO 7777 |
| 1204 | 4430 | JMS I XIOTH | /IOT 6134, CLEN |
| 1205 | 4456 | JMS I XSNDRV | /CHECK SEND AND RECEV REGISTERS |
| 1206 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1207 | 4473 | JMS I ERROR | /ERROR: ENABLE REGISTER FAILED |
| 1210 | 4461 | 4461 | /TST61 ERROR MESSAGE |
| 1211 | 1177 | TST61 | /SCOPE LOOP |

/

/DOES ENABLE REGISTER SURVIVE COMPLEMENT PATTERN ?

/

| | | | |
|------|------|--------------------|--------------------------------|
| 1212 | 7340 | TST62, CLA CLL CMA | /AC TO 7777 |
| 1213 | 3070 | DCA SEND | /SAVE OUTPUT FOR ERROR PRINTER |
| 1214 | 1016 | TAD K2525 | /GET AC NUMBER |
| 1215 | 4426 | JMS I XIOTF1 | /IOT 6132, CLOE |
| 1216 | 7040 | CMA | /COMPLEMENT AC |
| 1217 | 4426 | JMS I XIOTF1 | /IOT 6132, CLOE |
| 1220 | 7300 | CLA CLL | /CLAER THE AC AND LINK |
| 1221 | 4430 | JMS I XIOTH | /IOT 6134, CLEN |
| 1222 | 4456 | JMS I XSNDRV | /CHECK SEND RECEV REGISTERS |
| 1223 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1224 | 4473 | JMS I ERROR | /ERROR: ENABLE REGISTER FAILED |
| 1225 | 4462 | 4462 | /TST62 ERROR MESSAGE |
| 1226 | 1212 | TST62 | /SCOPE LOOP |

/

/DOES ENABLE REGISTER SURVIVE COMPLEMENT PATTERN ?

/

| | | | |
|------|------|--------------------|---------------------------------|
| 1227 | 7340 | TST63, CLA CLL CMA | /AC TO 7777 |
| 1230 | 3070 | DCA SEND | /SAVE OUTPUT FOR ERROR PRINTER |
| 1231 | 1017 | TAD K5252 | /GET AC NUMBER |
| 1232 | 4426 | JMS I XIOTF1 | /IOT 6132, CLOE |
| 1233 | 7040 | CMA | /COMPLEMENT AC |
| 1234 | 4426 | JMS I XIOTF1 | /IOT 6132, CLOE |
| 1235 | 7300 | CLA CLL | |
| 1236 | 4430 | JMS I XIOTH | /IOT 6134, CLEN |
| 1237 | 4456 | JMS I XSNDRV | /CHECK SEND AND RECEV REGISTERS |
| 1240 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1241 | 4473 | JMS I ERROR | /ERROR: ENABLE REGISTERS |
| 1242 | 4463 | 4463 | /TST63 ERROR MESSAGE |
| 1243 | 1227 | TST63 | /SCOPE LOOP |

/

/DO AC TO ENABLE REGISTER AND
/ENABLE REGISTER TO AC TRANSFERS

/CHECK ALL COMBINATIONS

```

/
TST64, TAD REGA          /GET AC NUMBER
      JMS I XIOTF        /IOT 6132, CLOE
      CLA CLL CMA        /AC TO 7777
      JMS I XIOTH        /IOT 6134, CLEN
      JMS I XSNDRV       /CHECK SEND AND RECEV REGISTERS
      JMS I NERROR       /CHECK NON-ERROR HANDLER
      JMS I ERROR        /ERROR: AC OR ENABLE REGISTER FAILED.
      4464               /TST64 ERROR MESSAGE
      TST64              /SCOPE LOOP
  
```

/DOES ENABLE REGISTER SURVIVE COMPLEMENT PATTERN.
/DO ALL COMBINATIONS.

```

/
TST65, CLA CLL CMA      /AC TO 7777
      DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
      TAD REGA          /GET AC NUMBER
      JMS I XIOTF1      /IOT 6132, CLOE
      CMA               /COMPLEMENT THE AC
      JMS I XIOTF1      /IOT 6132, CLOE
      JMS I XIOTH       /IOT 6134, CLEN
      JMS I XSNDRV       /CHECK SEND AND RECEV REGISTERS
      JMS I NERROR       /CHECK NON-ERROR HANDLER
      JMS I ERROR        /ERROR: AC OR ENABLE REGISTER FAILED.
      4465               /TST65 ERROR MESSAGE
      TST65              /SCOPE LOOP
  
```

/DOES ENABLE REGISTER SURVIVE RANDOM PATTERN ?

```

/
TST66, JMS I RANDY      /GET RANDOM NUMBER
      JMS I XIOTF        /IOT 6132, CLOE
      CLA CLL           /CLEAR THE AC AND LINK
      JMS I XIOTH       /IOT 6134, CLEN
      JMS I XSNDRV       /CHECK SEND AND RECEV REGISTERS
      JMS I NERROR       /CHECK NON-ERROR HANDLER
      JMS I ERROR        /ERROR: ENABLE REGISTER FAILED
      4466               /TST66 ERROR MESSAGE
      TST66              /SCOPE LOOP
  
```

/DOES ENABLE REGISTER SURVIVE RANDOM COMPLEMENT PATTERN ?

```

/
TST67, CLA CLL CMA      /AC TO 7777
      DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
      JMS I RANDY      /GET RANDOM NUMBER
      JMS I XIOTF1      /COMPLEMENT AC
      CMA               /IOT 6132, CLOE
      JMS I XIOTH       /IOT 6134, CLEN
      JMS I XSNDRV       /CHECK SEND AND RECEV REGISTERS
      JMS I NERROR       /CHECK NON-ERROR HANDLER
      JMS I ERROR        /ERROR: ENABLE REGISTER FAILED
      4467               /TST67 ERROR MESSAGE
      TST67              /SCOPE LOOP
  
```

/DOES READING ENABLE REGISTER CHANGE ITS CONTENTS ?

```

/
1316 7340 TST70, CLA CLL CMA /AC TO 7777
1317 3040 DCA REGA
1320 1016 TAD K2525 /GET AC NUMRER
1321 4425 JMS I XIOTF /IOT 6132, CLOE
1322 7340 T70B, CLA CLL CMA /AC TO 7777
1323 4430 JMS I XIOTH /IOT 6134, CLEN
1324 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
1325 7610 SKP CLA
1326 5332 JMP T70A
1327 2041 IS2 REGB /UPDATE COUNTER
1330 5322 JMP T70B /DO 4096 TIMES
1331 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1332 4473 T70A, JMS I ERROR /ERROR: ENABLE REGISTER FAILED
1333 4470 4470 /TST70 ERROR MESSAGE
1334 1316 TST70 /SCOPE LOOP

```

/DOES READING ENABLE REGISTER CHANGE TIS CONTENTS ?

```

/
1335 7340 TST71, CLA CLL CMA /AC TO 7777
1336 3040 DCA REGA
1337 1017 TAD K5252 /GET AC NUMBER
1340 4425 JMS I XIOTF /IOT 6132, CLOE
1341 7300 T71B, CLA CLL /CLEAR THE AC AND LINK
1342 4430 JMS I XIOTH /IOT 6134, CLEN
1343 4456 JMS I XSNDRV /CHECK SEND RECEV REGISTERS
1344 7610 SKP CLA
1345 5351 JMP T71A
1346 2041 IS2 REGB /UPDATE COUNTER
1347 5341 JMP T71B /DO 4096 TIMES
1350 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1351 4473 T71A, JMS I ERROR /ERROR: ENABLE REGISTER FAILED
1352 4471 4471 /TST71 ERROR MESSAGE
1353 1335 TST71 /SCOPE LOOP

```

/DOES ENABLE REGISTER SURVIVE FAST TOGGLE ?

```

/
1354 1040 TST72, TAD REGA /GET AC NUMBER
1355 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
1356 1040 TAD REGA
1357 4434 JMS I XIOTS /IOT'S 6132 AND 6134
1360 3071 DCA RECEV /SAVE INPUT FOR ERROR PRINTER
1361 1071 TAD RECEV
1362 4456 JMS I XSNDRV /CHECK SEND RECEV REGISTERS
1363 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1364 4473 JMS I ERROR /ERROR: ENABLE REGISTER FAILED
1365 4472 4472 /TST72 ERROR MESSAGE
1366 1354 TST72 /SCOPE LOOP

```

/DOES CLZE CLEAR ENABLE REGISTER?

```

/
1367 7340 TST73, CLA CLL CMA /AC TO 7777
1370 4426 JMS I XIOTF1 /IOT 6132, CLOE
1371 7340 CLA CLL CMA

```

```

1372 4423 JMS I XIOTD /IOT 6130, CLZE
1373 7300 CLA CLL /CLEAR THE AC AND LINK
1374 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
1375 7340 CLA CLL CMA /AC TO 7777
1376 4430 JMS I XIOTH /IOT 6134, CLEN
1377 7650 SNA CLA /WAS REGISTER ALL 0'S
1400 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1401 4473 JMS I ERROR /ERROR:CLZE OR CLEN FAILED.
1402 4473 4473 /TST73 ERROR MESSAGE
1403 1367 TST73 /SCOPE LOOP

```

/ DOES CLZE CLEAR ENABLE REGISTER?

```

1404 7340 TST74, CLA CLL CMA /AC TO 7777
1405 4425 JMS I XIOTF /IOT 6132, CLOE
1406 7300 CLA CLL
1407 4423 JMS I XIOTD /IOT 6130, CLZE
1410 7340 CLA CLL CMA /AC TO 7777
1411 3070 DCA SEND /SAVE OUTPUT ERROR PRINTER
1412 4430 JMS I XIOTH /IOT 6134, CLEN
1413 7040 CMA /COMPLEMENT AC
1414 7650 SNA CLA /WAS REGISTER ALL 0'S?
1415 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1416 4473 JMS I ERROR /ERROR:CLZE OR CLEN FAILED.
1417 4474 4474 /TST74 ERROR MESSAGE
1420 1424 TST74 /SCOPE LOOP

```

/ DOES CLZE CLEAR ENABLE REGISTER?

```

1421 1016 TST75, TAD K2525
1422 4425 JMS I XIOTF /IOT 6132,CLOE
1423 7040 CMA /COMPLEMENT THE AC
1424 4423 JMS I XIOTD /IOT 6130, CLZE
1425 7040 CMA /COMPLEMENT AC
1426 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
1427 4430 JMS I XIOTH /IOT 6134, CLEN
1430 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
1431 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1432 4473 JMS I ERROR /ERROR:CLZE,CLOE, OR CLEN FAILED
1433 4475 4475 /TST75 ERROR MESSAGE
1434 1421 TST75 /SCOPE LOOP

```

/ DOES CLZE CLEAR ENABLE REGISTER ?

```

1435 1017 TST76, TAD K2525 /GET AC NUMBER
1436 4425 JMS I XIOTF /IOT 6132, CLOE
1437 7040 CMA /COMPLEMENT AC
1440 4423 JMS I XIOTD /IOT 6130, CLZE
1441 7040 CMA /COMPLEMENT AC
1442 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
1443 4430 JMS I XIOTH /IOT 6134, CLEN
1444 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
1445 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1446 4473 JMS I ERROR /ERROR: ENABLE REGISTER FAILED
1447 4476 4476 /TST76 ERROR MESSAGE

```

1450 1435 TST76 /SCOPE LOOP

/DOES CLZE CLEAR ENABLE REGISTER?
/CHECK ALL COMBINATIONS

1451 1040 TST77, TAD REGA /GET AC NUMBER
 1452 4425 JMS I XIOTF /IOT 6132, CLOE
 1453 4423 JMS I XIOTD /IOT 6130, CLZE
 1454 7300 CLA CLL /CLEAR THE AC AND LINK
 1455 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
 1456 7340 CLA CLL CMA /AC TO ALL 1'S
 1457 4430 JMS I XIOTH /IOT 6134, CLEN
 1460 7650 SNA CLA /WAS REGISTER ALL 0'S?
 1461 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 1462 4473 JMS I ERROR /ERROR:CLZE,CLOE, OR CLEN FAILED
 1463 4477 4477 /TST77 ERROR MESSAGE
 1464 1431 TST77 /SCOPE LOOP

/DOES CLZE CLEAR ENABLE REGISTER?
/DO ALL COMBINATIONS

1465 1040 TST100, TAD REGA /GET AC NUMBER
 1466 4425 JMS I XIOTF /IOT 6132, CLOE
 1467 7040 CMA /COMPLEMENT THE AC
 1470 4423 JMS I XIOTD /IOT 6130, CLZE
 1471 7040 CMA /COMPLEMENT THE AC
 1472 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
 1473 4430 JMS I XIOTH /IOT 6134, CLEN
 1474 4436 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 1475 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 1476 4473 JMS I ERROR /ERROR:CLZE, CLOE, OR CLEN FAILED
 1477 4500 4500 /TST100 ERROR MESSAGE
 1500 1465 TST100 /SCOPE LOOP

/DOES CLZE SURVIVE RANDOM PATTERN ?

1501 4435 TST101, JMS I RANDY /GET RANDOM NUMBER
 1502 4425 JMS I XIOTF /IOT 6132, CLOE
 1503 4423 JMS I XIOTD /IOT 6130, CLZE
 1504 7300 CLA CLL /CLEAR THE AC AND LINK
 1505 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
 1506 4430 JMS I XIOTH /IOT 6134, CLEN
 1507 4436 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 1510 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 1511 4473 JMS I ERROR /ERROR: ENABLE REGISTER FAILED
 1512 4501 4501 /TST101 ERROR MESSAGE
 1513 1501 TST101 /SCOPE LOOP

/DOES CLZE SURVIVE RANDOM COMPLEMENT PATTERN ?

1514 4435 TST102, JMS I RANDY /GET RANDOM NUMBER
 1515 4425 JMS I XIOTF /IOT 6132, CLOE
 1516 7040 CMA /COMPLEMENT AC

| | | | |
|------|------|--------------|---------------------------------|
| 1517 | 4423 | JMS I XIOTD | /IOT 6130, CLZE |
| 1520 | 7040 | CMA | /COMPLEMENT AC |
| 1521 | 3070 | DCA SEND | /SAVE OUTPUT FOR ERROR PRINTER |
| 1522 | 4430 | JMS I XIOTH | /IOT 6134, CLEN |
| 1523 | 4456 | JMS I XSNDRV | /CHECK SEND AND RECEV REGISTERS |
| 1524 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1525 | 4473 | JMS I ERROR | /ERROR: ENABLE REGISTER FAILED |
| 1526 | 4502 | 4502 | /TST102 ERROR MESSAGE |
| 1527 | 1514 | TST102 | /SCOPE LOOP |

/

/DOES CLZE SURVIVE FAST TOGGLE ?

/

| | | | |
|------|------|------------------|--------------------------------|
| 1530 | 1040 | TST103, TAD REGA | /GET AC NUMBER |
| 1531 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 1532 | 4437 | JMS I XIOTSG | /IOT'S 6130 AND 6134 |
| 1533 | 3071 | DCA RECEV | /SAVE INPUT FOR ERROR PRINTER |
| 1534 | 1071 | TAD RECEV | |
| 1535 | 4456 | JMS I XSNDRV | /CHECK SEND RECEV REGISTERS |
| 1536 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1537 | 4473 | JMS I ERROR | /ERROR: ENABLE REGISTER FAILED |
| 1540 | 4503 | 4503 | /TST103 ERROR MESSAGE |
| 1541 | 1530 | TST103 | /SCOPE LOOP |

/

/DOES AC TRANSFER TO BUFFER THEN TO COUNTER ?

/

| | | | |
|------|------|---------------------|-----------------------------|
| 1542 | 4427 | TST104, JMS I XIOTG | /IOT 6133, CLAH |
| 1543 | 7340 | CLA CLL CMA | /AC TO ALL 1'S |
| 1544 | 4433 | JMS I XIOTK | /IOT 6137, CLCA |
| 1545 | 7650 | SNA CLA | /WAS COUNTER ALL 0'S? |
| 1546 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1547 | 4473 | JMS I ERROR | /ERROR: CLAB OR CLCA FAILED |
| 1550 | 4104 | 4104 | /TST104 ERROR MESSAGE |
| 1551 | 1542 | TST104 | /SCOPE LOOP |

/

/DOES AC TRANSFER TO BUFFER THEN TO COUNTER?

/

| | | | |
|------|------|---------------------|-----------------------------|
| 1552 | 7340 | TST105, CLA CLL CMA | |
| 1553 | 4427 | JMS I XIOTG | /IOT 6133, CLAB |
| 1554 | 4433 | JMS I XIOTK | /IOT 6137, CLCA |
| 1555 | 7040 | CMA | /COMPLEMENT THE AC |
| 1556 | 7650 | SNA CLA | /WAS COUNTER ALL 1'S? |
| 1557 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1560 | 4473 | JMS I ERROR | /ERROR: CLAB OR CLCA FAILED |
| 1561 | 4105 | 4105 | /TST105 ERROR MESSAGE |
| 1562 | 1552 | TST105 | /SCOPE LOOP |

/

/DOES COUNTER SURVIVE PATTERN 2525 ?

/

| | | | |
|------|------|-------------------|---------------------------------|
| 1563 | 1016 | TST106, TAD K2525 | /GET AC NUMBER |
| 1564 | 4427 | JMS I XIOTG | /IOT 6133, CLAB |
| 1565 | 7300 | CLA CLL | /CLEAR THE AC AND LINK |
| 1566 | 4433 | JMS I XIOTK | /IOT 6137, CLCA |
| 1567 | 4456 | JMS I XSNDRV | /CHECK SEND AND RECEV REGISTERS |
| 1570 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |

| | | | |
|------|------|-------------|------------------------|
| 1571 | 4473 | JMS I ERROR | /ERROR: COUNTER FAILED |
| 1572 | 4126 | 4106 | /TST106 ERROR MESSAGE |
| 1573 | 1503 | TST106 | /SCOPE LOOP |

/ DOES COUNTER SURVIVE PATTERN 5252 ?

| | | | |
|------|------|-------------------|---------------------------------|
| 1574 | 1017 | TST107, TAD K5252 | /GET AC NUMBER |
| 1575 | 4427 | JMS I XIOTG | /IOT 6133, CLAB |
| 1576 | 7340 | CLA CLL CMA | /AC TO ALL 7777 |
| 1577 | 4433 | JMS I XIOTK | /IOT 6137, CLCA |
| 1600 | 4456 | JMS I XSNDRV | /CHECK SEND AND RECEV REGISTERS |
| 1601 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1602 | 4473 | JMS I ERROR | /ERROR: COUNTER FAILED |
| 1603 | 4127 | 4107 | /TST107 ERROR MESSAGE |
| 1604 | 1574 | TST107 | /SCOPE LOOP |

/ DOES AC TRANSFER TO BUFFER THEN TO COUNTER?
/CHECK ALL COMBINATIONS

| | | | |
|------|------|------------------|---------------------------------|
| 1605 | 1040 | TST110, TAD REGA | |
| 1606 | 4427 | JMS I XIOTG | /IOT 6133, CLAB |
| 1607 | 7040 | CMA | /COMPLEMENT THE AC |
| 1610 | 4433 | JMS I XIOTK | /IOT 6137, CLCA |
| 1611 | 4456 | JMS I XSNDRV | /CHECK SEND AND RECEV REGISTERS |
| 1612 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1613 | 4473 | JMS I ERROR | /ERROR: CLAB OR CLCA FAILED |
| 1614 | 4110 | 4110 | /TST110 ERROR MESSAGE |
| 1615 | 1605 | TST110 | /SCOPE LOOP |

/ DOES COUNTER SURVIVE FAST TOGGLE?

| | | | |
|------|------|------------------|---------------------------------|
| 1616 | 1040 | TST111, TAD REGA | /GET AC NUMBER |
| 1617 | 3070 | DCA SEND | /SAVE OUTPUT FOR ERROR PRINTER |
| 1620 | 1070 | TAD SEND | |
| 1621 | 4436 | JMS I XIOTS2 | /IOT 6133 AND 6137 |
| 1622 | 3071 | DCA RECEV | /SAVE INPUT FOR ERROR PRINTER |
| 1623 | 1071 | TAD RECEV | |
| 1624 | 4456 | JMS I XSNDRV | /CHECK SEND AND RECEV REGISTERS |
| 1625 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1626 | 4473 | JMS I ERROR | /ERROR:CLAB OR CLCA FAILED |
| 1627 | 4111 | 4111 | /TST111 ERROR MESSAGE |
| 1630 | 1616 | TST111 | /SCOPE LOOP |

/ DOES CAF AFFECT COUNTER ?

| | | | |
|------|------|------------------|---------------------------------|
| 1631 | 1040 | TST112, TAD REGA | /GET AC NUMBER |
| 1632 | 4427 | JMS I XIOTG | /IOT 6133, CLAB |
| 1633 | 0007 | 6007 | /CAF OR CLEAR THE WORLD |
| 1634 | 4433 | JMS I XIOTK | /IOT 6137, CLCA |
| 1635 | 4456 | JMS I XSNDRV | /CHECK SEND AND RECEV REGISTERS |
| 1636 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 1637 | 4473 | JMS I ERROR | /ERROR: CLAB OR CLCA FAILED. |
| 1640 | 4112 | 4112 | /TST112 ERROR MESSAGE |

1641 1631 TST112 /SCOPE LOOP

/
/DOES READING COUNTER CHANGE ITS CONTENTS?
/PATTERN 2525.

1642 7340 TST113, CLA CLL CMA /AC TO 7777
 1643 3040 DCA REGA
 1644 1016 TAD K2525
 1645 4427 JMS I XIOTG /IOT 6133, CLAB
 1646 4433 T113B, JMS I XIOTK /IOT 6137, CLCA
 1647 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 1650 7410 SKP
 1651 5255 JMP T113A
 1652 2041 ISZ REGB
 1653 5246 JMP T113B
 1654 4472 JMS I NERROR /CHECK NON-ERROR
 1655 4473 T113A, JMS I ERROR /ERROR: CLAB OR CLCA FAILED
 1656 4113 4113 /TST113 ERROR MESSAGE
 1657 1642 TST113 /SCOPE LOOP

/
/DOES READING COUNTER CHANGE ITS CONTENTS?
/PATTERN 5252

1660 7340 TST114, CLA CLL CMA /AC TO 7777
 1661 3040 DCA REGA
 1662 1017 TAD K5252
 1663 4427 JMS I XIOTG /IOT 6133, CLAB
 1664 4433 T114B, JMS I XIOTK /IOT 6137, CLCA
 1665 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 1666 7410 SKP
 1667 5273 JMP T114A
 1670 2041 ISZ REGB
 1671 5264 JMP T114B
 1672 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 1673 4473 T114A, JMS I ERROR /ERROR: COUNTER FAILED
 1674 4114 4114 /TST114 ERROR MESSAGE
 1675 1660 TST114 /SCOPE LOOP

/
/DOES COUNTER SURVIVE RANDOM PATTERN ?

1676 4455 TST115, JMS I RANDY /GET RANDOM NUMBER
 1677 4427 JMS I XIOTG /IOT 6133, CLAB
 1700 7340 CLA CLL CMA
 1701 4433 JMS I XIOTK /IOT 6137, CLCA
 1702 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 1703 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 1704 4473 JMS I ERROR /ERROR: COUNTER FAILED
 1705 4115 4115 /TST115 ERROR MESSAGE
 1706 1676 TST115 /SCOPE LOOP

/
/TEST FOR NO INT. RQST.

1707 7340 TST116, CLA CLL CMA /AC TO 7777

```

1710 4427 JMS I XIOTG /IOT 6133, CLAB
1711 3040 DCA REGA
1712 1142 TAD K0010
1713 1147 TAD K0600 /GET ENABLES
1714 4425 JMS I XIOTF /IOT 6132, CLOE
1715 4447 JMS I XPIG01 /GO TO PI, NO PI EXPECTED
1716 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1717 4473 JMS I ERROR /ERROR: INT. ROST. FAILED
1720 1116 1116 /TST116, ERROR MESSAGE
1721 1707 TST116 /SCOPE LOOP

/
/DOES CLSK SKIP ON CLOCK OVERFLOW?
/SKIP EXPECTED, MODE 0, RATE 6
/
1722 7340 TST117, CLA CLL CMA /AC TO 7777
1723 4427 JMS I XIOTG /IOT 6133, CLAB
1724 7300 CLA CLL /CLEAR THE AC AND LINK
1725 1147 TAD K0600 /GET RATE 6
1726 4425 JMS I XIOTF /IOT 6132, CLOE
1727 4424 JMS I XIOTE /IOT 6131, CLSK
1730 7410 SKP
1731 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1732 4473 JMS I ERROR /ERROR: CLSK OR OVERFLOW FAILED
1733 0517 0517 /TST117 ERROR MESSAGE
1734 1722 TST117 /SCOPE LOOP

/
/DOES OVERFLOW REMAIN SET ?
/
1735 7340 TST120, CLA CLL CMA
1736 4427 JMS I XIOTG /IOT 6133, CLAB
1737 3040 DCA REGA
1740 1147 TAD K0600 /GET ENABLES
1741 4425 JMS I XIOTF /IOT 6132, CLOE
1742 4424 JMS I XIOTE /IOT 6131, CLSK
1743 5351 JMP T120A
1744 2041 ISZ REGB
1745 5344 JMP .-1 /WAIT ABOUT 15 MS
1746 4424 JMS I XIOTE /IOT 6131, CLSK
1747 7410 SKP
1750 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
1751 4473 T120A, JMS I ERROR /ERROR: CLSK OR OVERFLOW FAILED
1752 0520 0520 /TST120 ERROR MESSAGE
1753 1735 TST120 /SCOPE LOOP

/
/DOES CAF CLEAR THAT FLAG ?
/
1754 7340 TST121, CLA CLL CMA
1755 4427 JMS I XIOTG /IOT 6133, CLAB
1756 3040 DCA REGA
1757 1147 TAD K0600 /GET ENABLES
1760 4425 JMS I XIOTF /IOT 6132, CLOE
1761 4424 JMS I XIOTE /IOT 6131, CLSK
1762 5361 JMP .-1
1763 6007 6007 /CAF OR CLEAR THE WORLD
1764 4424 JMS I XIOTE /IOT 6131, CLSK

```

1765 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 1766 4473 T121A, JMS I ERROR /ERROR: CAF OR OVERFLOW FAILED
 1767 0121 0121 /TST121 ERROR MESSAGE
 1770 1754 TST121 /SCOPE LOOP

/
 /DOES CLSK SKIP ON OVERFLOW ?
 /SKIP EXPECTED, RATE 2-6, MODE 0

1771 1131 TST122, TAD K7773
 1772 3041 DCA REGB
 1773 1015 TAD K0200
 1774 3044 DCA REGE
 1775 7340 T122B, CLA CLL CMA /AC TO 7777
 1776 4427 JMS I XIOTG /IOT 6133, CLAB
 1777 3040 DCA REGA
 2000 1044 TAD REGE /GET ENABLES
 2001 4425 JMS I XIOTF /IOT 6132, CLOE
 2002 2043 ISZ REGD
 2003 5202 JMP .-1 /WAIT
 2004 4424 JMS I XIOTE /IOT 6131, CLSK
 2005 5214 JMP T122A /NO OVERFLOW FOUND
 2006 1013 TAD K0100
 2007 3044 DCA REGE /UPDATE CLOCK RATE
 2010 6007 6007 /CAF OR CLEAR THE WORLD
 2011 2041 ISZ REGB
 2012 5571 JMP I XCRS1
 2013 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 2014 4473 T122A, JMS I ERROR /ERROR: CLSK OR OVERFLOW FAILED
 2015 0522 0522 /TST122 ERROR MESSAGE
 2016 1771 TST122 /SCOPE LOOP

/
 /DOES CLSK SKIP ON OVERFLOW ?
 /SKIP EXPECTED, RATE 2-6, MODE 1

2017 1131 TST123, TAD K7773
 2020 3041 DCA REGB
 2021 1144 TAD K1000
 2022 1015 TAD K0200
 2023 3044 DCA REGE
 2024 7340 T123B, CLA CLL CMA /AC TO 7777
 2025 4427 JMS I XIOTG /IOT 6133, CLAB
 2026 3040 DCA REGA
 2027 1044 TAD REGE /GET ENABLES
 2030 4425 JMS I XIOTF /IOT 6132, CLOE
 2031 2043 ISZ REGD
 2032 5231 JMP .-1 /WAIT
 2033 4424 JMS I XIOTE /IOT 6131, CLSK
 2034 5243 JMP T123A /NO OVERFLOW FOUND
 2035 1013 TAD K0100
 2036 3044 DCA REGE /UPDATE CLCOK RATE
 2037 6007 6007 /CAF OR CLEAR THE WORLD
 2040 2041 ISZ REGB
 2041 5224 JMP T123B /DO RATES 2-6
 2042 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 2043 4473 T123A, JMS I ERROR /ERROR: CLSK OR OVERFLOW FAILED

2044 0523 0523 /TST123 ERROR MESSAGE
 2045 2017 TST123 /SCOPE LOOP

/
 /DOES CLSK SKIP ON OVERFLOW ?
 /SKIP EXPECTED, MODE 2, RATE 2-6
 /

2046 1131 TST124, TAD K7773
 2047 3041 DCA REGB
 2050 1143 TAD K2000
 2051 1015 TAD K0200 /MAKE ENABLES
 2052 3044 DCA REGE
 2053 7340 T124B, CLA CLL CMA
 2054 4427 JMS I XIOTG /IOT 6133, CLAB
 2055 3040 DCA REGA
 2056 1044 TAD REGE /GET ENABLES
 2057 4425 JMS I XIOTF /IOT 6132, CLOE
 2060 2043 ISZ REGD
 2061 5260 JMP ,-1 /WAIT ABOUT 15 MS
 2062 4424 JMS I XIOTE /IOT 6131, CLSK
 2063 5272 JMP T124A
 2064 1013 TAD K0100 /UPDATE RATE
 2065 3044 DCA REGE
 2066 6007 /CAF OR CLEAR THE WORLD
 2067 2041 ISZ REGB
 2070 5253 JMP T124B /DO RATES 2-6
 2071 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 2072 4473 T124A, JMS I ERROR /ERROR! CLSK OR OVERFLOW FAILED
 2073 0524 0524 /TST124 ERROR MESSAGE
 2074 2046 TST124 /SCOPE LOOP

/
 /DOES CLSK SKIP ON OVERFLOW ?
 /SKIP EXPECTED, RATE 2-6, MODE 3
 /

2075 1131 TST125, TAD K7773
 2076 3041 DCA REGB
 2077 1120 TAD K3000
 2100 1015 TAD K0200 /MAKE ENABLES
 2101 3044 DCA REGE /SAVE ENABLES
 2102 7340 T125B, CLA CLL CMA
 2103 4427 JMS I XIOTG /IOT 6133, CLAB
 2104 3040 DCA REGA
 2105 1044 TAD REGE /GET ENABLES
 2106 4425 JMS I XIOTF /IOT 6132, CLOE
 2107 2043 ISZ REGD
 2110 5307 JMP ,-1 /WAIT ABOUT 15 MS
 2111 4424 JMS I XIOTE /IOT 6131, CLSK
 2112 5320 JMP T125A
 2113 1013 TAD K0100 /UPDATE RATE
 2114 3044 DCA REGE
 2115 2041 ISZ REGB
 2116 5302 JMP T125B /DO RATES 2-6
 2117 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 2120 4473 T125A, JMS I ERROR /ERROR! CLSK OR OVERFLOW FAILED
 2121 0525 0525 /TST125 ERROR MESSAGE
 2122 2075 TST125 /SCOPE LOOP

/
 /DOES CLSK SKIP ON OVERFLOW ?
 /NO SKIP EXPECTED, RATE 0-7, MODE 0, DISABLE BIT 7

```

2123 1122 TST126, TAD K7770
2124 3043          DCA REGD
2125 7340 T126B, CLA CLL CMA      /AC TO 7777
2126 4427          JMS I XIOTG      /IOT 6133, CLAB
2127 3040          DCA REGA
2130 1140          TAD K0020
2131 1041          TAD REGB      /GET ENABLES
2132 4425          JMS I XIOTF      /IOT 6132, CLOE
2133 2042          ISZ REGC
2134 5333          JMP ,-1          /WAIT
2135 4424          JMS I XIOTE      /IOT 6131, CLSK
2136 7410          SKP
2137 9347          JMP T126A      /OVERFLOW FOUND
2140 0150          AND K0700      /MASK BITS 3-5
2141 1013          TAD K0100
2142 3041          DCA REGB      /UPDATE RATE
2143 6007          6007          /CAF OR CLEAR THE WORLD
2144 2043          ISZ REGD
2145 9325          JMP T126B      /DO RATES 0-7
2146 4472          JMS I NERROR     /CHECK NON-ERROR HANDLER
2147 4473 T126A, JMS I ERROR      /ERROR! CLSK OR OVERFLOW FAILED
2150 0126          0126          /TST126 ERROR MESSAGE
2151 2123          TST126      /SCOPE LOOP

```

/
 /DOES CLSK SKIP ON OVERFLOW ?
 /NO SKIP EXPECTED, RATE 0,1,7 MODE 0

```

2152 7340 TST127, CLA CLL CMA
2153 4427          JMS I XIOTG      /IOT 6133, CLAB
2154 3040          DCA REGA
2155 4425          JMS I XIOTF      /IOT 6132, CLOE
2156 2041          ISZ REGB
2157 9356          JMP ,-1          /WAIT ABOUT 15 MS
2160 4424          JMS I XIOTE      /IOT 6131, CLSK
2161 7410          SKP
2162 5572          JMP I XCRS2
2163 1013          TAD K0100      /UPDATE ENABLE
2164 4426          JMS I XIOTF1     /IOT 6132, CLOE
2165 2042          ISZ REGC
2166 5365          JMP ,-1          /WAIT ABOUT 15 MS
2167 4424          JMS I XIOTE      /IOT 6131, CLSK
2170 7410          SKP
2171 5572          JMP I XCRS2
2172 1147          TAD K0600      /UPDATE ENABLE
2173 4426          JMS I XIOTF1     /IOT 6132, CLOE
2174 2043          ISZ REGD
2175 5374          JMP ,-1          /WAIT ABOUT 15 MS
2176 4424          JMS I XIOTE      /IOT 6131, CLSK
2177 4472          JMS I NERROR     /CHECK NON-ERROR HANDLER
2200 4473 T127A, JMS I ERROR      /ERROR! CLSK OR OVERFLOW FAILED
2201 0127          0127          /TST127 ERROR MESSAGE

```

2202 2152

TST127 /SCOPE LOOP

/DOES CLSA READ OVERFLOW BIT ?

2203 7340

TST130, CLA CLL CMA

2204 4427

JMS I XIOTG /IOT 6132, CLOE

2205 7330

CLA CLL CML RAR /AC TO 4000

2206 3070

DCA SEND /SAVE OUTPUT FOR ERROR PRINTER

2207 7313

CLA CLL IAC RTR /AC TO 4000

2210 1147

TAD K0600 /GET ENABLE

2211 4426

JMS I XIOTF1

2212 4424

JMS I XIOTE /IOT 6131, CLSK

2213 5212

JMP .-1

2214 7350

CLA CLL CMA RAR /AC TO 3777

2215 4431

JMS I XIOTI /IOT 6135, CLSA

2216 4456

JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS

2217 4472

JMS I NERROR /CHECK NON-ERROR HANDLER

2220 4473

T130A, JMS I ERROR /ERROR! CLSI OR OVERFLOW FAILED

2221 5130

5130 /TST130 ERROR MESSAGE

2222 2203

TST130 /SCOPE LOOP

/DOES CLSA CLEAR OVERFLOW FLOP ?

2223 7340

TST131, CLA CLL CMA /AC TO 7777

2224 4427

JMS I XIOTG /IOT 6133, CLAB

2225 7313

CLA CLL IAC RTR /AC TO 4000

2226 1147

TAD K0600 /GET ENABLE

2227 4426

JMS I XIOTF1 /IOT 6132, CLOE

2230 4424

JMS I XIOTE /IOT 6131, CLSK

2231 5230

JMP .-1

2232 7350

CLA CLL CMA RAR /AC TO 3777

2233 4431

JMS I XIOTI /IOT 6135, CLSA

2234 7300

CLA CLL /CLEAR AC AND LINK

2235 3070

DCA SEND /SAVE OUTPUT FOR ERROR PRINTER

2236 7340

CLA CLL CMA /AC TO 7777

2237 4431

JMS I XIOTI /IOT 6135, CLSA

2240 7650

SNA CLA /WAS STATUS REGISTER ALL 0'S ?

2241 4472

JMS I NERROR /CHECK NON-ERROR HANDLER

2242 4473

JMS I ERROR /ERROR! CLSA OR OVERFLOW FAILED

2243 5131

5131 /TST131 ERROR MESSAGE

2244 2223

TST131 /SCOPE LOOP

/DOES CLSA READ OVERFLOW BIT ?

2245 7340

TST132, CLA CLL CMA

2246 4427

JMS I XIOTG /IOT 6133, CLAB

2247 7300

CLA CLL

2250 3070

DCA SEND /SAVE OUTPUT FOR ERROR PRINTER

2251 1147

TAD K0600 /GET ENABLES

2252 4426

JMS I XIOTF1 /IOT 6132, CLOE

2253 4424

JMS I XIOTE /IOT 6131, CLSK

2254 5253

JMP .-1

2255 7344

CLA CLL CMA RAL /AC TO 3777

2256 4431

JMS I XIOTI /IOT 6135, CLSA

2257 7650

SNA CLA /WAS STATUS 0 ?

```

PAL10 V141 9-OCT-71 15144 PAGE 1-28
2260 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2261 4473 JMS I ERROR /ERROR: CLSA OR STATUS FAILED
2262 5132 5132 /TST132 ERROR MESSAGE
2263 2245 TST132 /SCOPE LOOP
/
/DOES BUFFER TO COUNTER ON OVERFLOW ?
/MODE 1, RATE 2
/
2264 7340 TST133, CLA CLL CMA
2265 4427 JMS I XIOTG /IOT 6133, CLAB
2266 3040 DCA REGA
2267 7313 CLA CLL IAC RTR /AC TO 4000
2270 1116 TAD K0400
2271 1144 TAD K1000 /GET ENABLES
2272 4426 JMS I XIOTF1 /IOT 6132, CLOE
2273 4424 T133B, JMS I XIOTE /IOT 6131, CLSK
2274 5273 JMP ,-1 /WAIT FOR FLAG
2275 7300 CLA CLL /CLEAR THE AC AND LINK
2276 4433 JMS I XIOTK /IOT 6137, CLCA
2277 7040 CMA /FOR TESTING
2300 7440 SZA /WAS COUNTER ALL 1'S ?
2301 5306 JMP T133A
2302 4431 JMS I XIOTI /IOT 6135, CLSA
2303 2041 ISZ REGB
2304 5273 JMP T133B /DO TEST 4096 TIMES
2305 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2306 4473 T133A, JMS I ERROR /ERROR: COUNTER FAILED
2307 4133 4133 /TST133 ERROR MESSAGE
2310 2264 TST133 /SCOPE LOOP
/
/DOES BUFFER TO COUNTER ON OVERFLOW ?
/MODE 1, RATE 4
/
2311 1017 TST134, TAD K5252 /GET AC NUMBER
2312 4427 JMS I XIOTG /IOT 6133, CLAB
2313 7340 CLA CLL CMA /AC TO 7777
2314 3040 DCA REGA
2315 1144 TAD K1000
2316 1116 TAD K0400 /GET ENABLES
2317 4426 JMS I XIOTF1 /IOT 6132, CLOE
2320 4424 JMS I XIOTE /IOT 6131, CLSK
2321 5320 JMP ,-1 /WAIT FOR FLAG
2322 7340 CLA CLL CMA /AC TO 7777
2323 4433 JMS I XIOTK /IOT 6137, CLCA
2324 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
2325 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2326 4473 JMS I ERROR /ERROR: COUNTER FAILED
2327 4134 4134 /TST134 ERROR MESSAGE
2330 2311 TST134 /SCOPE LOOP
/
/DOES BUFFER TO COUNTER ON OVERFLOW ?
/MODE 1, RATE 4
/
2331 1016 TST135, TAD K2525 /GET AC NUMBER
2332 4427 JMS I XIOTG /IOT 6133, CLAB

```

```

2333 7340 CLA CLL CMA /AC TO 7777
2334 3040 DCA REGA
2335 1144 TAD K1000
2336 1116 TAD K0400 /GET ENABLES
2337 4426 JMS I XIOTF1 /IOT 6132, CLOE
2340 4424 JMS I XIOTE /IOT 6131, CLSK
2341 5340 JMP ,-1 /WAIT FOR OVERFLOW
2342 4433 JMS I XIOTK /IOT 6137, CLCA
2343 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
2344 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2345 4473 JMS I ERROR /ERROR: COUNTER FAILED
2346 4135 /TST135 ERROR MESSAGE
2347 2331 TST135 /SCOPE LOOP

```

```

/
/DOES BUFFER TO COUNTER ON OVERFLOW ?
/RATE 4, MODE 2
/

```

```

2350 7340 TST136, CLA CLL CMA /AC TO 7777
2351 4427 JMS I XIOTG /IOT 6133, CLAB
2352 3040 DCA REGA
2353 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
2354 1116 TAD K0400
2355 1143 TAD K2000 /GET ENABLES
2356 4426 JMS I XIOTF1 /IOT 6132, CLOE
2357 4424 JMS I XIOTE /IOT 6131, CLSK
2360 5357 JMP ,-1 /WAIT FOR FLAG
2361 4433 JMS I XIOTK /IOT 6137, CLCA
2362 7650 SNA CLA /WAS COUNTER ALL 0'S ?
2363 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2364 4473 JMS I ERROR /ERROR: COUNTER FAILED
2365 4136 /TST136 ERROR MESSAGE
2366 2350 TST136 /SCOPE LOOP

```

```

/
/DOES BUFFER TO COUNTER ON OVERFLOW ?
/MODE 3, RATE 4
/

```

```

2367 7340 TST137, CLA CLL CMA
2370 4427 JMS I XIOTG /IOT 6133, CLAB
2371 3040 DCA REGA
2372 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
2373 1116 TAD K0400
2374 1120 TAD K3000 /GET ENABLES
2375 4426 JMS I XIOTF1 /IOT 6132, CLOE
2376 4424 JMS I XIOTE /IOT 6131, CLSK
2377 5376 JMP ,-1 /WAIT FOR OVERFLOW
2400 7340 CLA CLL CMA
2401 4433 JMS I XIOTK /IOT 6137, CLCA
2402 7650 SNA CLA /WAS COUNTER ALL 0'S ?
2403 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2404 4473 JMS I ERROR /ERROR: COUNTER FAILED
2405 4137 /TST137 ERROR MESSAGE
2406 2367 TST137 /SCOPE LOOP

```

```

/
/DOES INT, WITHOUT BIT 8 ?
/

```

```

2407 7340 TST140, CLA CLL CMA
2410 4427 JMS I XIOTG /IOT 6133, CLAB
2411 3040 DCA REGA
2412 7313 CLA CLL IAC RTR /AC TO 4000
2413 1007 TAD K0007
2414 1147 TAD K0600 /GET ENABLES
2415 4425 JMS I XIOTF /IOT 6132, CLOE
2416 4447 JMS I XPIG01 /GO TO PI, NO PI EXPECTED
2417 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2420 4473 JMS I ERROR /ERROR: INT. RQST. OR ENA 0 FAILED
2421 1140 1140 /TST140 ERROR MESSAGE
2422 2407 TST140 /SCOPE LOOP

```

```

/
/DOES OVERFLOW CAUSE INT. RQST. ?
/RATE 6, MODE 0
/

```

```

2423 7340 TST141, CLA CLL CMA /AC TO 7777
2424 4427 JMS I XIOTG /IOT 6133, CLAB
2425 7300 CLA CLL /CLEAR THE AC AND LINK
2426 1014 TAD K4000
2427 1142 TAD K0010
2430 1147 TAD K0600 /GET RATE + MODE
2431 4425 JMS I XIOTF /IOT 6132, CLOE
2432 4452 JMS I XPIG04 /GO TO PI, PI EXPECTED
2433 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2434 4473 JMS I ERROR /ERROR: OVERFLOW OR ENA 0 FAILED
2435 1541 1541 /TST141 ERROR MESSAGE
2436 2423 TST141 /SCOPE LOOP

```

```

/
/DOES INT. RQST. WITHOUT ENA 0 ?
/RATE 6, MODE 0
/

```

```

2437 7340 TST142, CLA CLL CMA /AC TO 7777
2440 4427 JMS I XIOTG /IOT 6133, CLAB
2441 7300 CLA CLL /CLEAR THE AC AND LINK
2442 1142 TAD K0010
2443 1147 TAD K0600 /GET RATE + MODE
2444 4425 JMS I XIOTF /IOT 6132, CLOE
2445 4451 JMS I XPIG03 /GO TO PI, NO PI EXPECTED
2446 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2447 4473 JMS I ERROR /ERROR: ENA 0 FAILED
2450 1142 1142 /TST142 ERROR MESSAGE
2451 2437 TST142 /SCOPE LOOP

```

```

/
/DOES COUNTER COUNT ?
/RATE 6, MODE 0
/

```

```

2452 7340 TST143, CLA CLL CMA /AC TO 7777
2453 3040 DCA REGA
2454 4427 JMS I XIOTG /IOT 6133, CLAB
2455 1014 TAD K4000
2456 1142 TAD K0010
2457 1147 TAD K0600 /GET RATE + MODE
2460 4425 JMS I XIOTF /IOT 6132, CLOE
2461 4450 JMS I XPIG02 /GO TO PI

```

| | | | |
|------|------|--------------|------------------------------------|
| 2462 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 2463 | 4473 | JMS I ERROR | /ERROR: OVERFLOW OR COUNTER FAILED |
| 2464 | 1543 | 1543 | /TST143 ERROR MESSAGE |
| 2465 | 2452 | TST143 | /SCOPE LOOP |

/
/DOES COUNTER COUNT ?
/RATE 6, MODE 1

| | | | |
|------|------|---------------------|------------------------------------|
| 2466 | 7340 | TST144, CLA CMA CLL | |
| 2467 | 3040 | DCA REGA | |
| 2470 | 4427 | JMS I XIOTG | /IOT 6133, CLAB |
| 2471 | 1121 | TAD K5000 | |
| 2472 | 1142 | TAD K0010 | |
| 2473 | 1147 | TAD K0600 | /GET RATE + MODE |
| 2474 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 2475 | 4450 | JMS I XPIG02 | /GO TO PI |
| 2476 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 2477 | 4473 | JMS I ERROR | /ERROR: OVERFLOW OR COUNTER FAILED |
| 2500 | 1544 | 1544 | /TST144 ERROR MESSAGE |
| 2501 | 2466 | TST144 | /SCOPE LOOP |

/
/DOES COUNTER COUNT ?
/RATE 6, MODE 2

| | | | |
|------|------|---------------------|------------------------------------|
| 2502 | 7340 | TST145, CLA CLL CMA | /AC TO 7777 |
| 2503 | 3040 | DCA REGA | |
| 2504 | 4427 | JMS I XIOTG | /IOT 6133, CLAB |
| 2505 | 1117 | TAD K6000 | |
| 2506 | 1142 | TAD K0010 | |
| 2507 | 1147 | TAD K0600 | /GET ENABLES |
| 2510 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 2511 | 4450 | JMS I XPIG02 | /GO TO PI, PI EXPECTED |
| 2512 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 2513 | 4473 | JMS I ERROR | /ERROR: OVERFLOW OR COUNTER FAILED |
| 2514 | 1545 | 1545 | /TST145 ERROR MESSAGE |
| 2515 | 2502 | TST145 | /SCOPE LOOP |

/
/DOES COUNTER COUNT ?
/RATE 6, MODE 3

| | | | |
|------|------|---------------------|----------------------------------|
| 2516 | 7340 | TST146, CLA CLL CMA | /AC TO 7777 |
| 2517 | 3040 | DCA REGA | |
| 2520 | 4427 | JMS I XIOTG | /IOT 6133, CLAB |
| 2521 | 1141 | TAD K7000 | |
| 2522 | 1142 | TAD K0010 | |
| 2523 | 1147 | TAD K0600 | /GET ENABLES |
| 2524 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 2525 | 4450 | JMS I XPIG02 | /GO TO PI, PI EXPECTED |
| 2526 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 2527 | 4473 | JMS I ERROR | /ERROR: COUNTER OR MODE 3 FAILED |
| 2530 | 1546 | 1546 | /TST146 ERROR MESSAGE |
| 2531 | 2516 | TST146 | /SCOPE LOOP |

/
/DOES OVERFLOW CAUSE ROST. ?
/RATE 2-6, MODE 0

```

/
2532 1131 TST147, TAD K7773
2533 3041          DCA REGB
2534 1014          TAD K4000
2535 1142          TAD K0010
2536 1015          TAD K0200
2537 3044 T147B,  DCA REGE          /SET UP ENABLES
2540 7340          CLA CLL CMA      /AC TO 7777
2541 4427          JMS I XIOTG      /IOT 6133, CLAB
2542 3040          DCA REGA
2543 1044          TAD REGE          /GET ENABLES
2544 4425          JMS I XIOTF      /IOT 6132, CLOE
2545 4447          JMS I XPIG01     /GO TO PI, PI EXPECTED
2546 5355          JMP T147A
2547 6007          6007            /CAF OR CLEAR THE WORLD
2550 1013          TAD K0100
2551 1044          TAD REGE
2552 2041          ISZ REGB
2553 5337          JMP T147B          /DO RATES 2-6
2554 4472          JMS I NERROR     /CHECK NON-ERROR HANDLER
2555 4473 T147A,  JMS I ERROR     /ERROR: OVERFLOW OR MODE FAILED
2556 1547          1547            /TST147 ERROR MESSAGE
2557 2532          TST147          /SCOPE LOOP

```

```

/
/DOES OVERFLOW CAUSE ROST. ?
/RATE 2-6, MODE 1
/

```

```

2560 1131 TST150, TAD K7773
2561 3041          DCA REGB
2562 1121          TAD K5000
2563 1142          TAD K0010
2564 1015          TAD K0200      /MAKE ENABLES
2565 3044 T150B,  DCA REGE
2566 7340          CLA CLL CMA      /AC TO 7777
2567 4427          JMS I XIOTG      /IOT 6133, CLAB
2570 3040          DCA REGA
2571 1044          TAD REGE          /GET ENABLES
2572 4425          JMS I XIOTF      /IOT 6132, CLOE
2573 4447          JMS I XPIG01     /GO TO PI, PI EXPECTED
2574 5573          JMP I XCRS3
2575 6007          6007            /CAF OR CLEAR THE WORLD
2576 1013          TAD K0100
2577 1044          TAD REGE
2600 2041          ISZ REGB
2601 5574          JMP I XCRS4
2602 4472          JMS I NERROR     /CHECK NON-ERROR HANDLER
2603 4473 T150A,  JMS I ERROR     /ERROR: OVERFLOW OR MODE FAILED
2604 1550          1550            /TST150 ERROR MESSAGE
2605 2560          TST150          /SCOPE LOOP

```

```

/
/DOES OVERFLOW CAUSE ROST. ?
/RATE 2-6, MODE 2
/

```

```

2606 1131 TST151, TAD K7773
2607 3041          DCA REGB

```

```

2610 1117 TAD K6000
2611 1142 TAD K0010
2612 1015 TAD K0200
2613 3044 T151B, DCA REGE /MAKE ENABLES
2614 7340 CLA CLL CMA /AC TO 7777
2615 4427 JMS I XIOTG /IOT 6133, CLAB
2616 3040 DCA REGA
2617 1044 TAD REGE /GET ENABLES
2620 4425 JMS I XIOTF /IOT 6132, CL0E
2621 4447 JMS I XPIG01 /GO TO PI, PI EXPECTED
2622 5231 JMP T151A
2623 6007 6007 /CAF OR CLEAR THE WORLD
2624 1013 TAD K0100
2625 1044 TAD REGE
2626 2041 ISZ REGB
2627 5213 JMP T151B
2630 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2631 4473 T151A, JMS I ERROR /ERROR: OVERFLOW OR MODE FAILED
2632 1551 1551 /TST151 ERROR MESSAGE
2633 2606 TST151 /SCOPE LOOP

```

/ DOES OVERFLOW CAUSE ROST, ?
/RATE 2-6, MODE 3

```

2634 1131 TST152, TAD K7773
2635 3041 DCA REGE
2636 1141 TAD K7000
2637 1142 TAD K0010
2640 1015 TAD K0200 /MAKE ENABLES
2641 3044 T152B, DCA REGE
2642 7340 CLA CLL CMA /AC TO 7777
2643 4427 JMS I XIOTG /IOT 6133, CLAB
2644 3040 DCA REGA
2645 1044 TAD REGE /GET ENABLES
2646 4425 JMS I XIOTF /IOT 6132, CL0E
2647 4447 JMS I XPIG01 /GO TO PI, PI EXPECTED
2650 5257 JMP T152A
2651 6007 6007 /CAF OR CLEAR THE WORLD
2652 1013 TAD K0100
2653 1044 TAD REGE
2654 2041 ISZ REGB
2655 5241 JMP T152B /DO RATES 2-6
2656 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2657 4473 T152A, JMS I ERROR /ERROR: OVERFLOW OR MODE FAILED
2660 1552 1552 /TST152 ERROR MESSAGE
2661 2634 TST152 /SCOPE LOOP

```

/ DOES OVERFLOW CAUSE ROST, ?
/RATE 0-7, MODE 1, DISABLE BIT 7

```

2662 1142 TST153, TAD K7770
2663 3041 DCA REGB
2664 1141 TAD K5000
2665 1142 TAD K0010
2666 1140 TAD K0020

```

```

2667 3044 T153B, DCA REGE /MAKE ENABLES
2670 7340 CLA CLL CMA /AC TO 7777
2671 4427 JMS I XIOTG /IOT 6133, CLAB
2672 3040 DCA REGA
2673 1044 TAD REGE /GET ENABLES
2674 4425 JMS I XIOTF /IOT 6132, CLOE
2675 4450 JMS I XPIG02 /GO TO PI, NO PI EXPECTED
2676 5305 JMP T153A
2677 6007 6007 /CAF OR CLEAR THE WORLD
2700 1013 TAD K0100
2701 1044 TAD REGE
2702 2041 ISZ REGB
2703 5267 JMP T153B /DO RATE 0-7
2704 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2705 4473 T153A, JMS I ERROR /ERROR: OVERFLOW OR CLK ENA FAILED
2706 1153 1153 /TST153 ERROR MESSAGE
2707 2662 TST153 /SCOPE LOOP

```

```

/
/DOES OVERFLOW CAUSE RQST. ?
/RATE 0-7, MODE 2, DISABLE INT. RQST. BIT
/

```

```

2710 1142 TST154, TAD K7770
2711 3041 DCA REGB
2712 1117 TAD K6000
2713 1142 TAD K0010
2714 1140 TAD K0020
2715 3044 T154B, DCA REGE /MAKE ENABLES
2716 7340 CLA CLL CMA /AC TO 7777
2717 4427 JMS I XIOTG /IOT 6133, CLAB
2720 3040 DCA REGA
2721 1044 TAD REGE /GET ENABLES
2722 4425 JMS I XIOTF /IOT 6132, CLOE
2723 4450 JMS I XPIG02 /GO TO PI, NO PI EXPECTED
2724 5333 JMP T154A
2725 6007 6007 /CAF OR CLEAR THE WORLD
2726 1013 TAD K0100
2727 1044 TAD REGE
2730 2041 ISZ REGB
2731 5315 JMP T154B /DO RATE 0-7
2732 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
2733 4473 T154A, JMS I ERROR /ERROR: OVERFLOW OR CLK ENA FAILED
2734 1154 1154 /TST154 ERROR MESSAGE
2735 2710 TST154 /SCOPE LOOP

```

```

/
/DOES OVERFLOW CAUSE INT. RQST. ?
/MODE 0, RATE 6
/

```

```

2736 7340 TST155, CLA CLL CMA /AC TO 7777
2737 4427 JMS I XIOTG /IOT 6133, CLAB
2740 7330 CLA CLL CML RAR /AC TO 4000
2741 1147 TAD K0600
2742 1142 TAD K0010 /GET ENABLES
2743 4425 JMS I XIOTF /IOT 6132, CLOE
2744 4452 JMS I XPIG04 /GO TO PI, PI EXPECTED
2745 4472 JMS I NERROR /CHECK NON-ERROR HANDLER

```

| | | | |
|------|------|-------------|------------------------------------|
| 2746 | 4473 | JMS I ERROR | /ERROR: OVERFLOW OR COUNTER FAILED |
| 2747 | 1555 | 1555 | /TST155 ERROR MESSAGE |
| 2750 | 2736 | TST155 | /SCOPE LOOP |

/
/DOES CLSK SKIP THEN INTERRUPT ?
/RATE 6, MODE 0
/

| | | | |
|------|------|---------------------|---------------------------|
| 2751 | 7340 | TST156, CLA CLL CMA | /AC TO 7777 |
| 2752 | 4427 | JMS I XIOTG | /IOT 6133, CLAR |
| 2753 | 7330 | CLA CLL CML RAR | |
| 2754 | 1142 | TAD K0010 | |
| 2755 | 1147 | TAD K0600 | /MAKE ENABLES |
| 2756 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 2757 | 4424 | JMS I XIOTE | /IOT 6131, CLSK |
| 2760 | 5357 | JMP .-1 | /WAIT FOR OVERFLOW |
| 2761 | 4452 | JMS I XPIG04 | /GO TO PI, PI EXPECTED |
| 2762 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 2763 | 4473 | JMS I ERROR | /ERROR: CLSK OR PI FAILED |
| 2764 | 1556 | 1556 | /TST156 ERROR MESSAGE |
| 2765 | 2751 | TST156 | /SCOPE LOOP |

/CHECK FOR NO INT. RQST.
/MODE 0, RATE 6, DISABLE WITH CLSA
/

| | | | |
|------|------|---------------------|---------------------------|
| 2766 | 7340 | TST157, CLA CLL CMA | /AC TO 7777 |
| 2767 | 4427 | JMS I XIOTG | /IOT 6133, CLAR |
| 2770 | 7330 | CLA CLL CML RAR | /AC TO 4000 |
| 2771 | 1147 | TAD K0600 | |
| 2772 | 1142 | TAD K0010 | |
| 2773 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 2774 | 4424 | JMS I XIOTE | /IOT 6131, CLSK |
| 2775 | 5374 | JMP .-1 | /WAIT FOR OVERFLOW |
| 2776 | 4431 | JMS I XIOTI | /IOT 6135, CLSA |
| 2777 | 4451 | JMS I XPIG03 | /GO TO PI, NO PI EXPECTED |
| 3000 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 3001 | 4473 | JMS I ERROR | /ERROR: INT. RQST. FAILED |
| 3002 | 1157 | 1157 | /TST157 ERROR MESSAGE |
| 3003 | 2766 | TST157 | /SCOPE LOOP |

/DOES CLOCK FREQUENCY TIME OUT ?
/RATE 2, MODE 0
/

| | | | |
|------|------|---------------------|------------------------------|
| 3004 | 7340 | TST160, CLA CLL CMA | /AC TO 7777 |
| 3005 | 3040 | DCA REGA | |
| 3006 | 1151 | TAD KTA | |
| 3007 | 3076 | DCA KREGC | |
| 3010 | 4427 | JMS I XIOTG | /IOT 6133, CLAR |
| 3011 | 1014 | TAD K4000 | |
| 3012 | 1142 | TAD K0010 | |
| 3013 | 1015 | TAD K0200 | /MAKE ENABLES |
| 3014 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 3015 | 4453 | JMS I XPIG05 | |
| 3016 | 7610 | SKP CLA | |
| 3017 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 3020 | 4473 | JMS I ERROR | /ERROR: CLOCK FREQUENCY FAST |

3021 2160 2160 /TST160 ERROR MESSAGE
 3022 3004 TST160 /SCOPE LOOP

/DOES CLOCK FREQUENCY TIME OUT ?
 /RATE 2, MODE 0

3023 7340 TST161, CLA CLL CMA /AC TO 7777
 3024 3040 DCA REGA
 3025 1152 TAD KTA1
 3026 3076 DCA KREGC
 3027 4427 JMS I XIOTG /IOT 6133, CLAB
 3030 1014 TAD K4000
 3031 1142 TAD K0010
 3032 1015 TAD K0200 /MAKE ENABLES
 3033 4425 JMS I XIOTF /IOT 6132, CLOE
 3034 4453 JMS I XPIG05
 3035 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 3036 4473 JMS I ERROR /ERROR: CLOCK FREQUENCY SLOW
 3037 2561 2161 /TST161 ERROR MESSAGE
 3040 3023 TST161 /SCOPE LOOP

/DOES CLOCK FREQUENCY TIME OUT ?
 /RATE 3, MODE 0

3041 7340 TST162, CLA CLL CMA /AC TO 7777
 3042 3040 DCA REGA
 3043 1153 TAD KTB
 3044 3076 DCA KREGC
 3045 4427 JMS I XIOTG /IOT 6133, CLAB
 3046 1014 TAD K4000
 3047 1142 TAD K0010
 3050 1145 TAD K0300 /MAKE ENABLES
 3051 4425 JMS I XIOTF /IOT 6132, CLOE
 3052 4453 JMS I XPIG05
 3053 7610 SKP CLA
 3054 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 3055 4473 JMS I ERROR /ERROR: CLOCK FREQUENCY FAST
 3056 2162 2162 /TST162 ERROR MESSAGE
 3057 3041 TST162 /SCOPE LOOP

/DOES CLOCK FREQUENCY TIME OUT ?
 /RATE 3, MODE 0

3060 7340 TST163, CLA CLL CMA /AC TO 7777
 3061 3040 DCA REGA
 3062 1154 TAD KTB1
 3063 3076 DCA KREGC
 3064 4427 JMS I XIOTG /IOT 6133, CLAB
 3065 1014 TAD K4000
 3066 1142 TAD K0010
 3067 1145 TAD K0300 /MAKE ENABLES
 3070 4425 JMS I XIOTF /IOT 6132, CLOE
 3071 4453 JMS I XPIG05
 3072 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 3073 4473 JMS I ERROR /ERROR: CLOCK FREQUENCY SLOW

3074 2563 2563 /TST163 ERROR MESSAGE
3075 3060 TST163 /SCOPE LOOP

/
/DOES CLOCK FREQUENCY TIME OUT ?
/RATE 4, MODE 0

/
TST164, CLA CLL CMA /AC TO 7777
DCA REGA
TAD KTC
DCA KREGC
TAD KTC1
DCA REGD /SET TIMER FOR 10000 CPS CLOCK
JMS I XIOTG /IOT 6133, CLAB
TAD K4000
TAD K0010
TAD K0400 /MAKE ENABLES
JMS I XIOTF /IOT 6132, CLOE
JMS I XPIG05
SKP CLA
JMS I NERROR /CHECK NON-ERROR HANDLER
JMS I ERROR /ERROR: CLOCK FREQUENCY FAST
2164 /TST164 ERROR MESSAGE
TST164 /SCOPE LOOP

/
/DOES CLOCK FREQUENCY TIME OUT ?
/RATE 4, MODE 0

/
TST165, CLA CLL CMA /AC TO 7777
DCA REGA
TAD KTC
DCA KREGC
TAD KTC2
DCA REGD /SET TIMER FOR 10000 CLOCK
JMS I XIOTG /IOT 6133, CLAB
TAD K4000
TAD K0010
TAD K0400 /MAKE ENABLES
JMS I XIOTF /IOT 6132, CLOE
JMS I XPIG05
JMS I NERROR /CHECK NON-ERROR HANDLER
JMS I ERROR /ERROR: CLOCK FREQUENCY SLOW
2565 /TST165 ERROR MESSAGE
TST165 /SCOPE LOOP

/
/DOES CLOCK FREQUENCY TIME OUT ?
/RATE 5, MODE 0

/
TST166, CLA CLL CMA /AC TO 7777
DCA REGA
CLA CLL CMA RAR
JMS I XIOTG /IOT 6133, CLAB
CLA CLL /CLEAR THE AC AND LINK
TAD KTD
DCA REGD /SET TIMER FOR 10000 CPS CLOCK
TAD K4000

```

3147 1142 TAD K0010
3150 1146 TAD K0500 /MAKE ENABLES
3151 4425 JMS I XIOTF /IOT 6132, CLOE
3152 4447 JMS I XPIG01
3153 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3154 4473 JMS I ERROR /ERROR: CLOCK FREQUENCY FAST
3155 2166 2166 /TST166 ERROR MESSAGE
3156 3137 TST166 /SCOPE LOOP

```

/

/DOES CLOCK FREQUENCY TIME OUT ?

/RATE 5, MODE 0

/

```

3157 7340 TST167, CLA CLL CMA /AC TO 7777
3160 3040 DCA REGA
3161 7350 CLA CLL CMA RAR
3162 4427 JMS I XIOTG /IOT 6133, CLAB
3163 7300 CLA CLL /CLEAR THE AC AND LINK
3164 1161 TAD KTD1
3165 3043 DCA REGD /SET TIMER FOR 100000 CPS CLOCK
3166 1014 TAD K4000
3167 1142 TAD K0010
3170 1146 TAD K0500 /MAKE ENABLES
3171 4425 JMS I XIOTF /IOT 6132, CLOE
3172 4450 JMS I XPIG02
3173 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3174 4473 JMS I ERROR /ERROR: CLOCK FREQUENCY SLOW
3175 2567 2567 /TST167 ERROR MESSAGE
3176 3157 TST167 /SCOPE LOOP

```

/

/DOES CLOCK FREQUENCY TIME OUT ?

/RATE 6, MODE 0

/

```

3177 7340 TST170, CLA CLL CMA /AC TO 7777
3200 3040 DCA REGA
3201 1162 TAD KTE
3202 3043 DCA REGD /SET TIMER FOR 1000000 CPS CLOCK
3203 4427 JMS I XIOTG /IOT 6133, CLAB
3204 1014 TAD K4000
3205 1142 TAD K0010
3206 1147 TAD K0600 /MAKE ENABLES
3207 4425 JMS I XIOTF /IOT 6132, CLOE
3210 4447 JMS I XPIG01
3211 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3212 4473 JMS I ERROR /ERROR: CLOCK FREQUENCY FAST
3213 2170 2170 /TST170 ERROR MESSAGE
3214 3177 TST170 /SCOPE LOOP

```

/

/DOES CLOCK FREQUENCY TIME OUT ?

/RATE 6, MODE 0

/

```

3215 7340 TST171, CLA CLL CMA /AC TO 7777
3216 3040 DCA REGA
3217 1163 TAD KTE1
3220 3043 DCA REGD /SET TIMER FOR 1000000 CPS CLOCK
3221 4427 JMS I XIOTG /IOT 6133, CLAB

```

```

3222 1014 TAD K4000
3223 1142 TAD K0010
3224 1147 TAD K0600 /MAKE ENABLES
3225 4425 JMS I XIOTF /IOT 6132, CLOE
3226 4450 JMS I XPIG02
3227 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3230 4473 JMS I ERROR /ERROR: CLOCK FREQUENCY SLOW
3231 2571 2571 /TST171 ERROR MESSAGE
3232 3215 TST171 /SCOPE LOOP

```

/
/DOES COUNTER REALLY COUNT ?
/RATE 2, MODE 0
/

```

3233 7340 TST172, CLA CLL CMA /AC TO 7777
3234 4427 JMS I XIOTG /IOT 6133, CLAB
3235 3040 DCA REGA
3236 1015 TAD K0200 /GET RATE + MODE
3237 4426 JMS I XIOTF1 /IOT 6132, CLOE
3240 7300 T172B1, CLA CLL /CLEAR THE AC AND LINK
3241 3042 DCA REGC
3242 1041 TAD REGB
3243 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
3244 4433 T172B, JMS I XIOTK /IOT 6137, CLCA
3245 7041 CIA
3246 1041 TAD REGB /COMPARE TO THIS REGISTER
3247 7650 SNA CLA /ARE THEY THE SAME YET ?
3250 5254 JMP T172A /YES, TEST NEXT NUMBER
3251 2042 ISZ REGC
3252 5244 JMP T172B /WAIT ABOUT 15 MS FOR REGISTER
3253 5257 JMP T172A1 /NUMBER NOT FOUND
3254 2041 T172A, ISZ REGB /UPDATE COMPARE REGISTER
3255 5240 JMP T172B1 /TEST FOR NEXT COUNTER PULSE
3256 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3257 4473 T172A1, JMS I ERROR /ERROR: COUNTER FAILED
3260 4172 4172 /TST172 ERROR MESSAGE
3261 3233 TST172 /SCOPE LOOP

```

/
/DOES COUNTER REALLY COUNT ?
/RATE 3, MODE 0
/

```

3262 7340 TST173, CLA CLL CMA /AC TO 7777
3263 4427 JMS I XIOTG /IOT 6133, CLAB
3264 3040 DCA REGA
3265 1145 TAD K0300 /GET RATE + MODE
3266 4426 JMS I XIOTF1 /IOT 6132, CLOE
3267 7300 T173B1, CLA CLL /CLEAR THE AC AND LINK
3270 3042 DCA REGC
3271 1041 TAD REGB
3272 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
3273 4433 T173B, JMS I XIOTK /IOT 6137, CLCA
3274 7041 CIA
3275 1041 TAD REGB /COMPARE TO THIS REGISTER
3276 7650 SNA CLA /ARE THEY THE SAME YET ?
3277 5303 JMP T173A /YES, TEST NEXT NUMBER
3300 2042 ISZ REGC

```

```

3301 5273          JMP T173B      /WAIT ABOUT 15 MS FOR REGISTER
3302 5306          JMP T173A1     /NUMBER NOT FOUND
3303 2041    T173A, ISZ REGB  /UPDATE COMPARE REGISTER
3304 5267          JMP T173B1     /TEST FOR NEXT COUNTER PULSE
3305 4472          JMS I NERROR /CHECK NON-ERROR HANDLER
3306 4473    T173A1, JMS I ERROR /ERROR: COUNTER FAILED
3307 4173          4173      /TST173 ERROR MESSAGE
3310 3262          TST173     /SCOPE LOOP

```

/

/DOES COUNTER REALLY COUNT ?

/RATE 2, MODE 1

/

```

3311 7340    TST174, CLA CLL CMA      /AC TO 7777
3312 4427          JMS I XIOTG     /IOT 6133, CLAB
3313 3040          DCA REGA
3314 1015          TAD K0200
3315 1144          TAD K1000      /GET RATE + MODE
3316 4426          JMS I XIOTF1    /IOT 6132, CLOE
3317 4424          JMS I XIOTE     /IOT 6131, CLSK
3320 5317          JMP .-1
3321 7300          CLA CLL        /CLEAR THE AC AND LINK
3322 4427          JMS I XIOTG     /IOT 6133, CLAB
3323 3042    T174B1, DCA REGC
3324 1041          TAD REGB
3325 3070          DCA SEND      /SAVE OUTPUT FOR ERROR PRINTER
3326 4433    T174B, JMS I XIOTK    /IOT 6137, CLCA
3327 7041          CIA
3330 1041          TAD REGB      /COMPARE TO THIS REGISTER
3331 7650          SNA CLA        /ARE THEY THE SAME YET ?
3332 5336          JMP T174A      /YES, TEST NEXT NUMBER
3333 2042          ISZ REGC
3334 5326          JMP T174B      /WAIT ABOUT 15 MS FOR REGISTER
3335 5341          JMP T174A1     /NUMBER NOT FOUND
3336 2041    T174A, ISZ REGB  /UPDATE COMPARE REGISTER
3337 5323          JMP T174B1     /TEST FOR NEXT COUNTER PULSE
3340 4472          JMS I NERROR /CHECK NON-ERROR HANDLER
3341 4473    T174A1, JMS I ERROR /ERROR: COUNTER FAILED
3342 4174          4174      /TST174 ERROR MESSAGE
3343 3311          TST174     /SCOPE LOOP

```

/

/DOES COUNTER REALLY COUNT ?

/RATE 4, MODE 1

/

```

3344 7340    TST175, CLA CLL CMA      /AC TO 7777
3345 4427          JMS I XIOTG     /IOT 6133, CLAB
3346 3040          DCA REGA
3347 1116          TAD K0400
3350 1144          TAD K1000      /GET RATE + MODE
3351 4426          JMS I XIOTF1    /IOT 6132, CLOE
3352 4424          JMS I XIOTE     /IOT 6131, CLSK
3353 5352          JMP .-1
3354 7300          CLA CLL        /CLEAR THE AC AND LINK
3355 4427          JMS I XIOTG     /IOT 6133, CLAB
3356 3042    T175B1, DCA REGC
3357 1041          TAD REGB

```

```

3360 3070          DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
3361 4433 T175B,  JMS I XIOTK        /IOT 6137, CLCA
3362 7041          CIA
3363 1041          TAD REGB          /COMPARE TO THIS REGISTER
3364 7650          SNA CLA          /ARE THEY THE SAME YET ?
3365 5371          JMP T175A        /YES, TEST NEXT NUMBER
3366 2042          ISZ REGC
3367 5361          JMP T175B        /WAIT ABOUT 15 MS FOR REGISTER
3370 5374          JMP T175A1       /NUMBER NOT FOUND
3371 2041 T175A,  ISZ REGB          /UPDATE COMPARE REGISTER
3372 5356          JMP T175B1       /TEST FOR NEXT COUNTER PULSE
3373 4472          JMS I NERROR      /CHECK NON-ERROR HANDLER
3374 4473 T175A1, JMS I ERROR      /ERROR: COUNTER FAILED
3375 4175          4175             /TST175 ERROR MESSAGE
3376 3344          TST175          /SCOPE LOOP

```

/
/DOES COUNTER REALLY COUNT ?
/RATE 2, MODE 2
/

```

3377 7340 TST176, CLA CLL CMA          /AC TO 7777
3400 4427          JMS I XIOTG        /IOT 6133, CLAB
3401 3040          DCA REGA
3402 1015          TAD K0200
3403 1143          TAD K2000        /GET RATE + MODE
3404 4426          JMS I XIOTF1      /IOT 6132, CLOE
3405 7300 T176B1, CLA CLL          /CLEAR THE AC AND LINK
3406 3042          DCA REGC
3407 1041          TAD REGB
3410 3070          DCA SEND          /SAVE OUTPUT FOR ERROR PRINTER
3411 4433 T176B,  JMS I XIOTK        /IOT 6137, CLCA
3412 7041          CIA
3413 1041          TAD REGB          /COMPARE TO THIS REGISTER
3414 7650          SNA CLA          /ARE THEY THE SAME YET ?
3415 5221          JMP T176A        /YES, TEST NEXT NUMBER
3416 2042          ISZ REGC
3417 5211          JMP T176B        /WAIT ABOUT 15 MS FOR REGISTER
3420 5224          JMP T176A1       /NUMBER NOT FOUND
3421 2041 T176A,  ISZ REGB          /UPDATE COMPARE REGISTER
3422 5205          JMP T176B1       /TEST FOR NEXT COUNTER PULSE
3423 4472          JMS I NERROR      /CHECK NON-ERROR HANDLER
3424 4473 T176A1, JMS I ERROR      /ERROR: COUNTER FAILED
3425 4176          4176             /TST176 ERROR MESSAGE
3426 3377          TST176          /SCOPE LOOP

```

/
/DOES COUNTER REALLY COUNT ?
/RATE 4, MODE 2
/

```

3427 7340 TST177, CLA CLL CMA          /AC TO 7777
3430 4427          JMS I XIOTG        /IOT 6133, CLAB
3431 3040          DCA REGA
3432 1116          TAD K0400
3433 1143          TAD K2000        /GET RATE + MODE
3434 4426          JMS I XIOTF1      /IOT 6132, CLOE
3435 7300 T177B1, CLA CLL          /CLEAR THE AC AND LINK
3436 3042          DCA REGC

```

```

3437 1041      TAD REGB
3440 3070      DCA SEND      /SAVE OUTPUT FOR ERROR PRINTER
3441 4433      T177B, JMS I XIOTK /IOT 6137, CLCA
3442 7041      CIA
3443 1041      TAD REGB      /COMPARE TO THIS REGISTER
3444 7650      SNA CLA      /ARE THEY THE SAME YET ?
3445 5251      JMP T177A     /YES, TEST NEXT NUMBER
3446 2042      ISZ REGC
3447 5241      JMP T177B     /WAIT ABOUT 15 MS FOR REGISTER
3450 5254      JMP T177A1    /NUMBER NOT FOUND
3451 2041      T177A, ISZ REGB /UPDATE COMPARE REGISTER
3452 5255      JMP T177B1    /TEST FOR NEXT COUNTER PULSE
3453 4472      JMS I NERROR  /CHECK NON-ERROR HANDLER
3454 4473      T177A1, JMS I ERROR /ERROR: COUNTER FAILED
3455 4177      4177      /TST177 ERROR MESSAGE
3456 3427      TST177      /SCOPE LOOP

```

```

/
/DOES COUNTER REALLY COUNT ?
/RATE 4, MODE 3
/

```

```

3457 7340      TST200, CLA CLL CMA /AC TO 7777
3460 4427      JMS I XIOTG    /IOT 6133, CLAB
3461 3040      DCA REGA
3462 1116      TAD K0420
3463 1120      TAD K3000    /GET RATE + MODE
3464 4426      JMS I XIOTF1  /IOT 6132, CLOE
3465 7300      T200B1, CLA CLL /CLEAR THE AC AND LINK
3466 3042      DCA REGC
3467 1041      TAD REGB
3470 3070      DCA SEND    /SAVE OUTPUT FOR ERROR PRINTER
3471 4433      T200B, JMS I XIOTK /IOT 6137, CLCA
3472 7041      CIA
3473 1041      TAD REGB    /COMPARE TO THIS REGISTER
3474 7650      SNA CLA    /ARE THEY THE SAME YET ?
3475 5301      JMP T200A    /YES, TEST NEXT NUMBER
3476 2042      ISZ REGC
3477 5271      JMP T200B    /WAIT ABOUT 15 MS FOR REGISTER
3500 5304      JMP T200A1   /NUMBER NOT FOUND
3501 2041      T200A, ISZ REGB /UPDATE COMPARE REGISTER
3502 5265      JMP T200B1   /TEST FOR NEXT COUNTER PULSE
3503 4472      JMS I NERROR /CHECK NON-ERROR HANDLER
3504 4473      T200A1, JMS I ERROR /ERROR: MODE 3, COUNTER FAILED
3505 4200      4200    /TST200 ERROR MESSAGE
3506 3457      TST200    /SCOPE LOOP

```

```

/
/DO IOT'S AFFECT AC ?
/

```

```

3507 7340      TST201, CLA CLL CMA /AC TO 7777
3510 4427      JMS I XIOTG    /IOT 6133, CLAB
3511 3040      DCA REGA    /PASS COUNT 1
3512 6007      6007    /CAF OR CLEAR THE WORLD
3513 1144      TAD K1000
3514 1015      TAD K0200    /GET ENABLES
3515 4426      JMS I XIOTF1  /IOT 6132, CLOE
3516 4424      JMS I XIOTE  /IOT 6131, CLSK

```

```

3517 5316      JMP .-1          /WAIT FOR COUNTER TO GET CLEARED
3520 7340      CLA CLL CMA
3521 4423      JMS I XIOTD      /IOT 6130, CLZE
3522 7320      T201B, CLA CLL          /CLEAR AC AND LINK
3523 3070      DCA SEND      /SAVE OUTPUT FOR ERROR PRINTER
3524 1041      TAD REGB      /GET AC NUMBER
3525 4432      JMS I XIOTJ      /IOT 6136, CLBA
3526 7640      SZA CLA          /WAS AC ALL 0'S ?
3527 5351      JMP T201A
3530 1041      TAD REGB      /GET AC NUMBER
3531 4433      JMS I XIOTK      /IOT 6137, CLCA
3532 7640      SZA CLA          /WAS AC ALL 0'S ?
3533 5351      JMP T201A
3534 1041      TAD REGB      /GET AC NUMBER
3535 4430      JMS I XIOTH      /IOT 6134, CLEN
3536 7640      SZA CLA          /WAS AC ALL 0'S ?
3537 5351      JMP T201A
3540 1041      TAD REGB      /GET AC NUMBER
3541 4431      JMS I XIOTI      /IOT 6135, CLSA
3542 7640      SZA CLA          /WAS AC ALL 0'S ?
3543 5351      JMP T201A
3544 4424      JMS I XIOTE      /IOT 6131, CLSK
3545 5344      JMP .-1          /WAS FLAG STILL SET ?
3546 2041      ISZ REGB      /UPDATE PASS COUNTER
3547 5322      JMP T201R      /TEST IOT'S AGAIN
3550 4472      JMS I NERROR      /CHECK NON-ERROR HANDLER
3551 4473      T201A, JMS I ERROR      /ERROR: IOT FAILED
3552 3201      3201          /TST201 ERROR MESSAGE
3553 3527      TST201          /SCOPE LOOP

3554 4570      JMS I XPASS      /TYPE PASS COMPLETE
3555 5463      JMP I XDK8EP      /CONTINUE TESTING

```

/ DOES INPUT 4 CAUSE INT. RQST.

```

3556 7320      CLA CLL
3557 1112      TAD K7400
3560 3077      DCA LOOP      /LOAD LOOP COUNTER
3561 7340      TST202, CLA CLL CMA      /AC TO 7777
3562 3040      DCA REGA
3563 7327      CLA CLL IAC RTL      /AC TO 0004
3564 1142      TAD K0010      /GET ENABLES
3565 4425      JMS I XIOTF      /IOT 6132, CLOE
3566 4450      JMS I XPIG02      /GO TO PI, PI EXPECTED
3567 4472      JMS I NERROR      /CHECK NON-ERROR HANDLER
3570 4473      JMS I ERROR      /ERROR: INPUT 4 FAILED
3571 1602      1602          /TST202 ERROR MESSAGE
3572 3561      TST202          /SCOPE LOOP

```

/ DOES INPUT 2 CAUSE INT. RQST.

```

3573 7340      TST203, CLA CLL CMA      /AC TO 7777
3574 3040      DCA REGA
3575 7326      CLA CLL CML RTL      /AC TO 0002
3576 1142      TAD K0010      /GET ENABLES

```

| | | | |
|------|------|--------------|--------------------------|
| 3577 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 3600 | 4450 | JMS I XPIG02 | /GO TO PI, PI EXPECTED |
| 3601 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 3602 | 4473 | JMS I ERROR | /ERROR: INPUT 2 FAILED |
| 3603 | 1603 | 1603 | /TST203 ERROR MESSAGE |
| 3604 | 3573 | TST203 | /SCOPE LOOP |

/DOES INPUT 1 CAUSE INT. RQST.

| | | | |
|------|------|---------------------|--------------------------|
| 3605 | 7340 | TST204, CLA CLL CMA | /AC TO 7777 |
| 3606 | 3040 | DCA REGA | |
| 3607 | 7324 | CLA CLL CML RAL | /AC TO 0001 |
| 3610 | 1142 | TAD K0010 | /GET ENARLES |
| 3611 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 3612 | 4450 | JMS I XPIG02 | /GO TO PI, PI EXPECTED |
| 3613 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 3614 | 4473 | JMS I ERROR | /ERROR: INPUT 1 FAILED |
| 3615 | 1604 | 1604 | /TST204 ERROR MESSAGE |
| 3616 | 3605 | TST204 | /SCOPE LOOP |

/DOES INPUT 4 RQST. LAST ?

| | | | |
|------|------|---------------------|--------------------------|
| 3617 | 7340 | TST205, CLA CLL CMA | /AC TO 7777 |
| 3620 | 3040 | DCA REGA | |
| 3621 | 7307 | CLA CLL IAC RTL | /AC TO 0004 |
| 3622 | 1142 | TAD K0010 | /GET ENARLES |
| 3623 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 3624 | 4447 | JMS I XPIG01 | /GO TO PI, PI EXPECTED |
| 3625 | 5252 | JMP T205A | /NO RQST, FOUND |
| 3626 | 2041 | ISZ REGB | /UPDATE COUNTER |
| 3627 | 5226 | JMP .-1 | /WAIT 15 MS |
| 3630 | 4450 | JMS I XPIG02 | /GO TO PI, PI EXPECTED |
| 3631 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 3632 | 4473 | T205A, JMS I ERROR | /ERROR: INPUT 4 FAILED |
| 3633 | 1605 | 1605 | /TST205 ERROR MESSAGE |
| 3634 | 3617 | TST205 | /SCOPE LOOP |

/DOES INPUT 2 RQST. LAST ?

| | | | |
|------|------|---------------------|--------------------------|
| 3635 | 7340 | TST206, CLA CLL CMA | /AC TO 7777 |
| 3636 | 3040 | DCA REGA | |
| 3637 | 7305 | CLA CLL IAC RAL | /AC TO 0002 |
| 3640 | 1142 | TAD K0010 | /GET ENARLES |
| 3641 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 3642 | 4447 | JMS I XPIG01 | /GO TO PI, PI EXPECTED |
| 3643 | 5250 | JMP T206A | /NO RQST, FOUND |
| 3644 | 2041 | ISZ REGB | /UPDATE COUNTER |
| 3645 | 5244 | JMP .-1 | /WAIT 15 MS |
| 3646 | 4450 | JMS I XPIG02 | /GO TO PI, PI EXPECTED |
| 3647 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 3650 | 4473 | T206A, JMS I ERROR | /ERROR: INPUT 2 FAILED |
| 3651 | 1606 | 1606 | /TST206 ERROR MESSAGE |
| 3652 | 3635 | TST206 | /SCOPE LOOP |

/DOES INPUT 1 RQST. LAST ?

```

/
3653 7340 TST207, CLA CLL CMA /AC TO 7777
3654 3040 DCA REGA
3655 7324 CLA CLL CML RAL /AC TO 0001
3656 1142 TAD K0010 /GET ENABLES
3657 4425 JMS I XIOTF /IOT 6132, CLOE
3660 4447 JMS I XPIG01 /GO TO PI, PI EXPECTED
3661 5266 JMP T207A /NO RQST. FOUND
3662 2041 ISZ REGB /UPDATE COUNTER
3663 5262 JMP .-1 /WAIT 15 MS
3664 4450 JMS I XPIG02 /GO TO PI, PI EXPECTED
3665 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3666 4473 T207A, JMS I ERROR /ERROR: INPUT 1 FAILED
3667 1607 1607 /TST207 ERROR MESSAGE
3670 3653 TST207 /SCOPE LOOP

```

/DOES INPUTS 4,2,1 WITHOUT BIT 8 ?

```

/
3671 7340 TST210, CLA CLL CMA /AC TO 7777
3672 3040 DCA REGA
3673 7313 CLA CLL IAC RTR /AC TO 4000
3674 1007 TAD K0007
3675 1147 TAD K0600
3676 4425 JMS I XIOTF /IOT 6132, CLOE
3677 4447 JMS I XPIG01 /GO TO PI, NO PI EXPECTED
3700 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3701 4473 JMS I ERROR /ERROR:ENABLE BIT 8 FAILED
3702 1210 1210 /TST210 ERROR MESSAGE
3703 3671 TST210 /SCOPE LOOP

```

/DOES INPUT 4 CAUSE SKIP ?

```

/
3704 7340 TST211, CLA CLL CMA /AC TO 7777
3705 3040 DCA REGA
3706 1113 TAD KT1CPS
3707 3045 DCA REGF
3710 7307 CLA CLL IAC RTL /AC TO 0004
3711 4425 JMS I XIOTF /IOT 6132, CLOE
3712 4424 JMS I XIOTE /IOT 6131, CLSK
3713 4446 JMS I SKPWAT /LET'S WAIT FOR A FLAG
3714 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3715 4473 JMS I ERROR /ERROR: INPUT 4 OR SKIP FAILED
3716 0611 0611 /TST211 ERROR MESSAGE
3717 3704 TST211 /SCOPE LOOP

```

/DOES INPUT 2 CAUSE SKIP ?

```

/
3720 7340 TST212, CLA CLL CMA /AC TO 7777
3721 3040 DCA REGA
3722 1113 TAD KT1CPS
3723 3045 DCA REGF
3724 7526 CLA CLL CML RTL /AC TO 0002
3725 4425 JMS I XIOTF /IOT 6132, CLOE
3726 4424 JMS I XIOTE /IOT 6131, CLSK
3727 4446 JMS I SKPWAT /LET'S WAIT FOR A FLAG

```

```

3730 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3731 4473 JMS I ERROR /ERROR: INPUT 2 OR SKIP FAILED
3732 0612 0612 /TST212 ERROR MESSAGE
3733 3720 TST212 /SCOPE LOOP

```

/ DOES INPUT 1 CAUSE SKIP ?

```

3734 7340 TST213, CLA CLL CMA /AC TO 7777
3735 3040 DCA REGA
3736 1113 TAD KT1CPS
3737 3045 DCA REGF
3740 7301 CLA CLL IAC /AC TO 0001
3741 4425 JMS I XIOTF /IOT 6132, CLOE
3742 4424 JMS I XIOTE /IOT 6131, CLSK
3743 4446 JMS I SKPWAT /LET'S WAIT FOR FLAG
3744 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3745 4473 JMS I ERROR /ERROR: INPUT 1 OR SKIP FAILED
3746 0613 0613 /TST213 ERROR MESSAGE
3747 3734 TST213 /SCOPE LOOP

```

/ DOES INPUT 4 RQST. THEN SKIP AND VICE-VERSA ?

```

3750 7340 TST214, CLA CLL CMA /AC TO 7777
3751 3040 DCA REGA
3752 7307 CLA CLL IAC RTL /AC TO 0004
3753 1142 TAD K0010 /GET ENABLES
3754 4425 JMS I XIOTF /IOT 6132, CLOE
3755 4424 JMS I XIOTE /IOT 6131, CLSK
3756 5355 JMP .-1
3757 4447 JMS I XPIG01 /GO TO PI, PI EXPECTED
3760 5364 JMP T214A /NO RQST, FOUND
3761 4424 JMS I XIOTE /IOT 6131, CLSK
3762 5361 JMP .-1
3763 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
3764 4473 T214A, JMS I ERROR /ERROR: INPUT 4 SKIP OR INT, RQST. FAILED
3765 1614 1614 /TST214 ERROR FAILED
3766 3750 TST214 /SCOPE LOOP

```

/ DOES INPUT 2 SKIP THEN INT, RQST. AND VICE-VERSA ?

```

3767 7340 TST215, CLA CLL CMA /AC TO 7777
3770 3040 DCA REGA
3771 7305 CLA CLL IAC RAL /AC TO 0002
3772 1142 TAD K0010 /GET ENABLES
3773 4425 JMS I XIOTF /IOT 6132, CLOE
3774 4424 JMS I XIOTE /IOT 6131, CLSK
3775 5374 JMP .-1
3776 4447 JMS I XPIG01 /GO TO PI, PI EXPECTED
3777 5575 JMP I XCRS5
4000 4424 JMS I XIOTE /IOT 6131, CLSK
4001 5200 JMP .-1
4002 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4003 4473 T215A, JMS I ERROR /ERROR: INPUT 2 SKIP OR RQST, FAILED
4004 1615 1615 /TST215 ERROR MESSAGE
4005 3767 TST215 /SCOPE LOOP

```

```

/
/DOES INPUT 1 SKIP THEN INT, RQST. AND VICE-VERSA ?
/
4006 7340 TST216, CLA CLL CMA /AC TO 7777
4007 3040 DCA REGA
4010 7307 CLA CLL IAC /AC TO 0001
4011 1142 TAD K0010 /GET ENABLES
4012 4425 JMS I XIOTF /IOT 6132, CLOE
4013 4424 JMS I XIOTE /IOT 6131, CLSK
4014 5213 JMP .-1
4015 4447 JMS I XPIG01 /GO TO PI, PI EXPECTED
4016 5222 JMP T216A
4017 4424 JMS I XIOTE /IOT 6131, CLSK
4020 5217 JMP .-1
4021 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4022 4473 T216A, JMS I ERROR /ERROR: INPUT 1 SKIP OR INT, RQST. FAILED
4023 1616 1616 /TST216 ERROR MESSAGE
4024 4006 TST216 /SCOPE LOOP

/
/DOES CAF CLEAR INPUT 4 INT, RQST. ?
/
4025 7340 TST217, CLA CLL CMA /AC TO 7777
4026 3040 DCA REGA
4027 7307 CLA CLL IAC RTL /AC TO 0004
4030 4425 JMS I XIOTF /IOT 6132, CLOE
4031 4424 JMS I XIOTE /IOT 6131, CLSK
4032 5251 JMP .-1 /WAIT FOR FIRST FLAG
4033 6007 6007 /CAF OR CLEAR THE WORLD
4034 7307 CLA CLL IAC RTL /AC TO 0004
4035 4425 JMS I XIOTF /IOT 6132, CLOE
4036 4424 JMS I XIOTE /IOT 6131, CLSK
4037 5256 JMP .-1 /WAIT FOR SECOND FLAG
4040 6007 6007 /CAF OR CLEAR THE WORLD
4041 7307 CLA CLL IAC RTL
4042 4425 JMS I XIOTF /IOT 6132, CLOE
4043 4424 JMS I XIOTE /IOT 6131, CLSK
4044 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4045 4473 JMS I ERROR /ERROR: INPUT 4 SKIP OR RQST. FAILED
4046 0217 0217 /TST217 ERROR MESSAGE
4047 4025 TST217 /SCOPE LOOP

/
/DOES CAF CLEAR INPUT 2 RQST. ?
/
4050 7340 TST220, CLA CLL CMA /AC TO 7777
4051 3040 DCA REGA
4052 7305 CLA CLL IAC RAL /AC TO 0002
4053 4425 JMS I XIOTF /IOT 6132, CLOE
4054 4424 JMS I XIOTE /IOT 6131, CLSK
4055 5254 JMP .-1 /WAIT FOR FIRST FLAG
4056 6007 6007 /CAF OR CLEAR THE WORLD
4057 7305 CLA CLL IAC RAL /AC TO 0002
4060 4425 JMS I XIOTF /IOT 6132, CLOE
4061 4424 JMS I XIOTE /IOT 6131, CLSK
4062 5261 JMP .-1 /WAIT FOR SECOND FLAG
4063 6007 6007 /CAF OR CLEAR THE WORLD
```

```

4064 7305 CLA CLL IAC RAL /AC TO 0002
4065 4425 JMS I XIOTF /IOT 6132, CLOE
4066 4424 JMS I XIOTE /IOT 6131, CLSK
4067 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4070 4473 JMS I ERROR /ERROR: INPUT 2 SKIP OR RQST, FAILED
4071 0220 0220 /TST220 ERROR MESSAGE
4072 4050 TST220 /SCOPE LOOP

```

/

/DOES CAF CLEAR INTPUT 3 RQST. ?

/

```

4073 7340 TST221, CLA CLL CMA /AC TO 7777
4074 3040 DCA REGA
4075 7301 CLA CLL IAC /AC TO 0001
4076 4425 JMS I XIOTF /IOT 6132, CLOE
4077 4424 JMS I XIOTE /IOT 6131, CLSK
4100 5277 JMP .-1 /WAIT FOR FIRST FLAG
4101 6007 6007 /CAF OR CLEAR THE WORLD
4102 7301 CLA CLL IAC /AC TO 0001
4103 4425 JMS I XIOTF /IOT 6132, CLOE
4104 4424 JMS I XIOTE /IOT 6131, CLSK
4105 5304 JMP .-1 /WAIT FOR SECONED FLAG
4106 6007 6007 /CAF OR CLEAR THE WORLD
4107 7301 CLA CLL IAC
4110 4425 JMS I XIOTF /IOT 6132, CLOE
4111 4424 JMS I XIOTE /IOT 6131, CLSK
4112 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4113 4473 JMS I ERROR /ERROR: INPUT 1 SKIP OR RQST, FAILED
4114 0221 0221 /TST221 ERROR MESSAGE
4115 4073 TST221 /SCOPE LOOP

```

/

/DOES CLSA READ RQST. INPUT 4 ?

/

```

4116 7340 TST222, CLA CLL CMA /AC TO 7777
4117 3040 DCA REGA
4120 7307 CLA CLL IAC RTL /AC TO 0004
4121 4425 JMS I XIOTF /IOT 6132, CLOE
4122 4424 JMS I XIOTE /IOT 6131, CLSK
4123 5322 JMP .-1 /WAIT FOR FLAG
4124 7040 CMA /AC TO 7773
4125 4431 JMS I XIOTI /IOT 6135, CLSA
4126 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4127 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4130 4473 JMS I ERROR /ERROR: CLSA OR INPUT 4 FAILED
4131 5222 5222 /TST222 ERROR MESSAGE
4132 4116 TST222 /SCOPE LOOP

```

/

/DOES CLSA READ RQST. INPUT 2 ?

/

```

4133 7340 TST223, CLA CLL CMA /AC TO 7777
4134 3040 DCA REGA
4135 7305 CLA CLL IAC RAL /AC TO 0002
4136 4425 JMS I XIOTF /IOT 6132, CLOE
4137 4424 JMS I XIOTE /IOT 6131, CLSK
4140 5337 JMP .-1 /WAIT FOR FLAG
4141 7040 CMA /AC TO 7775

```

```

4142 4431 JMS I XIOTI /IOT 6135, CLSA
4143 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4144 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4145 4473 JMS I ERROR /ERROR: CLSA OR INPUT 2 FAILED
4146 5223 5223 /TST223 ERROR MESSAGE
4147 4133 TST223 /SCOPE LOOP

```

/

/DOES CLSA READ RQST. INPUT 1 ?

```

4150 7340 TST224, CLA CLL CMA /AC TO 7777
4151 3040 DCA REGA
4152 7301 CLA CLL IAC /AC TO 0001
4153 4425 JMS I XIOTF /IOT 6132, CLOE
4154 4424 JMS I XIOTE /IOT 6131, CLSK
4155 5354 JMP ,-1 /WAIT FOR FLAG
4156 7040 CMA /AC TO 7776
4157 4431 JMS I XIOTI /IOT 6135, CLSA
4160 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4161 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4162 4473 JMS I ERROR /ERROR: CLSA OR INPUT 1 FAILED
4163 5224 5224 /TST224 ERROR MESSAGE
4164 4150 TST224 /SCOPE LOOP

```

/

/DOES CLSA CLEAR INPUT 4 RQST. ?

```

4165 7340 TST225, CLA CLL CMA /AC TO 7777
4166 3040 DCA REGA
4167 7307 CLA CLL IAC RTL /AC TO 0004
4170 4426 JMS I XIOTF1 /IOT 6132, CLOE
4171 4424 JMS I XIOTE /IOT 6131, CLSK
4172 5371 JMP ,-1 /WAIT FOR FIRST FLAG
4173 4431 JMS I XIOTI /IOT 6135, CLSA
4174 4424 JMS I XIOTE /IOT 6131, CLSK
4175 5374 JMP ,-1 /WAIT FOR SECOND FLAG
4176 4431 JMS I XIOTI /IOT 6135, CLSA
4177 4424 JMS I XIOTE /IOT 6131, CLSK
4200 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4201 4473 JMS I ERROR /ERROR: CLSA OR INPUT 1 FAILED
4202 0225 0225 /TST225 ERROR MESSAGE
4203 4165 TST225 /SCOPE LOOP

```

/

/DOES CLSA CLEAR INPUT 2 RQST. ?

```

4204 7340 TST226, CLA CLL CMA /AC TO 7777
4205 3040 DCA REGA
4206 7305 CLA CLL IAC RAL /AC TO 0002
4207 4425 JMS I XIOTF /IOT 6132, CLOE
4210 4424 JMS I XIOTE /IOT 6131, CLSK
4211 5210 JMP ,-1 /WAIT FOR FIRST FLAG
4212 4431 JMS I XIOTI /IOT 6135, CLSA
4213 4424 JMS I XIOTE /IOT 6131, CLSK
4214 5213 JMP ,-1 /WAIT FOR SECOND FLAG
4215 4431 JMS I XIOTI /IOT 6135, CLSA
4216 4424 JMS I XIOTE /IOT 6131, CLSK
4217 4472 JMS I NERROR /CHECK NON-ERROR HANDLER

```

4220 4473 JMS I ERROR /ERROR: CLSA OR INPUT 2 FAILED
 4221 0226 0226 /TST226 ERROR MESSAGE
 4222 4204 TST226 /SCOPE LOOP

/
 /DOES CLSA CLEAR INPUT 4 RQST. ?
 /

4223 7340 TST227, CLA CLL CMA /AC TO 7777
 4224 3040 DCA REGA
 4225 7301 CLA CLL IAC /AC TO 0001
 4226 4425 JMS I XIOTF /IOT 6132, CLOE
 4227 4424 JMS I XIOTE /IOT 6131, CLSK
 4230 5227 JMP ,-1 /WAIT FOR FIRST FLAG
 4231 4431 JMS I XIOTI /IOT 6135, CLSA
 4232 4424 JMS I XIOTE /IOT 6131, CLSK
 4233 5232 JMP ,-1 /WAIT FOR SECOND FLAG
 4234 4431 JMS I XIOTI /IOT 6135, CLSA
 4235 4424 JMS I XIOTE /IOT 6131, CLSK
 4236 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 4237 4473 JMS I ERROR /ERROR: CLSA OR INPUT 1 FAILED
 4240 0227 0227 /TST227 ERROR MESSAGE
 4241 4223 TST227 /SCOPE LOOP

/
 /DOES CLSA READ INPUT 4,2,1 ?
 /

4242 7340 TST230, CLA CLL CMA /AC TO 7777
 4243 3040 DCA REGA
 4244 1007 TAD K0007 /GET ENABLES
 4245 4425 JMS I XIOTF /IOT 6132, CLOE
 4246 7000 NOP
 4247 2041 ISZ REGB
 4250 5246 JMP ,-2 /WAIT FOR ALL
 4251 4424 JMS I XIOTE /IOT 6131, CLOE
 4252 5251 JMP ,-1 /WAIT FOR FLAGS
 4253 7340 CLA CLL CMA /AC TO 7777
 4254 4431 JMS I XIOTI /IOT 6135, CLSA
 4255 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 4256 7610 SKP CLA
 4257 5265 JMP T230A /ERROR, STATUS REGISTER
 4260 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
 4261 7340 CLA CLL CMA /AC TO 7777
 4262 4431 JMS I XIOTI /IOT 6135, CLSA
 4263 7650 SNA CLA /WAS STATUS ALL 0'S ?
 4264 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 4265 4473 T230A, JMS I ERROR /ERROR: CLSA OR INPUTS 1,2,3 FAILED
 4266 5230 5230 /TST230 ERROR MESSAGE
 4267 4242 TST230 /SCOPE LOOP

/
 /DOES INPUT 4 CLEAR BIT 7 ?
 /

4270 7340 TST231, CLA CLL CMA
 4271 3040 DCA REGA
 4272 7307 CLA CLL IAC RTL /AC TO 0004
 4273 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
 4274 1070 TAD SEND
 4275 1140 TAD K0020 /GET ENABLES

```

4276 4426 JMS I XIOTF1 /IOT 6132, CLOE
4277 4424 JMS I XIOTE /IOT 6131, CLSK
4300 5277 JMP .-1 /WAIT FOR FLAG
4301 7340 CLA CLL CMA /AC TO 7777
4302 4430 JMS I XIOTH /IOT 6134, CLEN
4303 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4304 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4305 4473 JMS I ERROR /ERROR: BIT 7 OR INPUT 4 FAILED
4306 4631 4631 /TST231 ERROR MESSAGE
4307 4270 TST231 /SCOPE LOOP

```

/ DOES INPUT 2 CLEAR BIT 7 ?

```

4310 7340 TST232, CLA CLL CMA
4311 3040 DCA REGA
4312 7305 CLA CLL IAC RAL /AC TO 0002
4313 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
4314 1070 TAD SEND
4315 1140 TAD K0020
4316 4426 JMS I XIOTF1 /IOT 6132, CLOE
4317 4424 JMS I XIOTE /IOT 6131, CLSK
4320 5317 JMP .-1 /WAIT FOR FLAG
4321 7340 CLA CLL CMA
4322 4430 JMS I XIOTH /IOT 6134, CLEN
4323 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4324 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4325 4473 JMS I ERROR /ERROR: BIT 7 OR INPUT 2 FAILED
4326 4632 4632 /TST232 ERROR MESSAGE
4327 4310 TST232 /SCOPE LOOP

```

/ DOES INPUT 1 CLEAR BIT 7 ?

```

4330 7340 TST233, CLA CLL CMA /AC TO 7777
4331 3040 DCA REGA
4332 7301 CLA CLL IAC /AC TO 0001
4333 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
4334 1070 TAD SEND
4335 1140 TAD K0020
4336 4426 JMS I XIOTF1 /IOT 6132, CLOE
4337 4424 JMS I XIOTE /IOT 6131, CLSK
4340 5337 JMP .-1 /WAIT FOR FLAG
4341 7340 CLA CLL CMA /AC TO 7777
4342 4430 JMS I XIOTH /IOT 6134, CLEN
4343 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4344 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4345 4473 JMS I ERROR /ERROR: BIT 7 OR INPUT 1 FAILED
4346 4633 4633 /TST233 ERROR MESSAGE
4347 4330 TST233 /SCOPE LOOP

```

/ DOES INPUT 4,2,1 GENERATE CLR CNT ?
/MODE 3, RATE 0

```

4350 7340 TST234, CLA CLL CMA /AC TO 7777
4351 3040 DCA REGA
4352 1016 TAD K2525 /GET AC NUMBER

```

```

4353 4427 JMS I XIOTG /IOT 6133, CLAB
4354 7307 CLA CLL IAC RTL /AC TO 0004
4355 1120 TAD K3000 /GET ENABLES
4356 4426 JMS I XIOTF1 /IOT 6132, CLOE
4357 4424 JMS I XIOTE /IOT 6131, CLSK
4360 5357 JMP .-1 /WAIT FOR FLAG
4361 7300 CLA CLL
4362 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
4363 7340 CLA CLL CMA /AC TO 7777
4364 4433 JMS I XIOTK /IOT 6137, CLCA
4365 7650 SNA CLA /WAS COUNTER ALL 0'S ?
4366 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4367 4473 JMS I ERROR /ERROR: CLR CNT FAILED
4370 4234 4234 /TST234 ERROR MESSAGE
4371 4350 TST234 /SCOPE LOOP

```

/

```

/DOES INPUT 4,2,1 CAUSE CLR CNT ?
/MODE 3, RATE 0

```

```

4372 7340 TST235, CLA CLL CMA /AC TO 7777
4373 3040 DCA REGA
4374 1017 TAD K5252 /GET AC NUMBER
4375 4427 JMS I XIOTG /IOT 6133, CLAB
4376 7305 CLA CLL IAC RAL /AC TO 0002
4377 1120 TAD K3000 /GET ENABLES
4400 4426 JMS I XIOTF1 /IOT 6132, CLOE
4401 4424 JMS I XIOTE /IOT 6131, CLSK
4402 5201 JMP .-1 /WAIT FOR FLAG
4403 7300 CLA CLL
4404 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
4405 7340 CLA CLL CMA /AC TO 7777
4406 4433 JMS I XIOTK /IOT 6137, CLCA
4407 7650 SNA CLA /WAS COUNTER ALL 0'S ?
4410 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4411 4473 JMS I ERROR /ERROR: CLR CNT FAILED ?
4412 4235 4235 /TST235 ERROR MESSAGE
4413 4372 TST235 /SCOPE LOOP

```

/

```

/DOES INPUT 4,2,1 TRANSFER COUNTER TO BUFFER ?

```

```

4414 7340 TST236, CLA CLL CMA /AC TO 7777
4415 3040 DCA REGA
4416 1016 TAD K2525 /GET AC NUMBER
4417 4427 JMS I XIOTG /IOT 6133, CLAB
4420 6007 6007 /CAF OR CLEAR THE WORLD
4421 7301 CLA CLL IAC /AC TO 0001
4422 1120 TAD K3000 /GET ENABLES
4423 4426 JMS I XIOTF1 /IOT 6132, CLOE
4424 4424 JMS I XIOTE /IOT 6131, CLSK
4425 5224 JMP .-1 /WAIT FOR FLAG
4426 7340 CLA CLL CMA /AC TO 7777
4427 4432 JMS I XIOTJ /IOT 6136, CLBA
4430 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4431 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4432 4473 JMS I ERROR /ERROR: COUNTER TO BUFFER FAILED

```

4433 3636 3636 /TST236 ERROR MESSAGE
 4434 4414 TST236 /SCOPE LOOP

/
 /DOES INPUT 4,2,1 TRANSFER COUNTER TO BUFFER ?
 /

4435 7340 TST237, CLA CLL CMA /AC TO 7777
 4436 3040 DCA REGA
 4437 1017 TAD K5252 /GET AC NUMBER
 4440 4427 JMS I XIOTG /IOT 6133, CLAB
 4441 6007 6007 /CAF OR CLEAR THE WORLD
 4442 7301 CLA CLL IAC /AC TO 0001
 4443 1140 TAD K3000 /GET ENABLES
 4444 4426 JMS I XIOTF1 /IOT 6132, CLOE
 4445 4424 JMS I XIOTE /IOT 6131, CLSK
 4446 5245 JMP .-1 /WAIT FOR FLAG
 4447 7340 CLA CLL CMA /AC TO 7777
 4450 4432 JMS I XIOTJ /IOT 6136, CLBA
 4451 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 4452 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
 4453 4473 JMS I ERROR /ERROR: COUNTER TO BUFFER FAILED
 4454 3637 3637 /TST237 ERROR MESSAGE
 4455 4435 TST237 /SCOPE LOOP

/
 /DOES INPUT 4,2,1 GENERATE CLR CNT ?
 /MODE 2, RATE 0
 /

4456 7340 TST240, CLA CLL CMA /AC TO 7777
 4457 3040 DCA REGA
 4460 1016 TAD K2525 /GET AC NUMBER
 4461 4427 JMS I XIOTG /IOT 6133, CLAB
 4462 6007 6007 /CAF OR CLEAR THE WORLD
 4463 7307 CLA CLL IAC RTL /AC TO 0004
 4464 1143 TAD K2000 /GET ENABLES
 4465 4426 JMS I XIOTF1 /IOT 6132, CLOE
 4466 4424 JMS I XIOTE /IOT 6131, CLSK
 4467 5266 JMP .-1 /WAIT FOR FLAG
 4470 7340 CLA CLL CMA /AC TO 7777
 4471 4433 JMS I XIOTK /IOT 6137, CLCA
 4472 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
 4473 4472 JMS I NERROR /CHECK NON-ERROR MESSAGE
 4474 4473 JMS I ERROR /ERROR: CLR CNT FAILED, MODE 2
 4475 4240 4240 /TST240 ERROR MESSAGE
 4476 4456 TST240 /SCOPE LOOP

/
 /DOES INPUT 4,2,1 CAUSE CLR CNT ?
 /MODE 2, RATE 0
 /

4477 7340 TST241, CLA CLL CMA
 4500 3040 DCA REGA
 4501 1017 TAD K5252 /GET AC NUMBER
 4502 4427 JMS I XIOTG /IOT 6133, CLAB
 4503 6007 6007 /CAF OR CLEAR THE WORLD
 4504 7305 CLA CLL IAC RAL /AC TO 0002
 4505 1143 TAD K2000 /GET ENABLES

```

4506 4426 JMS I XIOTF1 /IOT 6132, CLOE
4507 4424 JMS I XIOTE /IOT 6131, CLSK
4510 5307 JMP .-1 /WAIT FOR FLAG
4511 7340 CLA CLL CMA /AC TO 7777
4512 4433 JMS I XIOTK /IOT 6137, CLCA
4513 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4514 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4515 4473 JMS I ERROR /ERROR: CLR CNT FAILED, MODE 2
4516 4241 4241 /TST241 ERROR MESSAGE
4517 4477 TST241 /SCOPE LOOP

```

```

/
/DOES COUNTER TRANSFER TO BUFFER ?
/MODE 2, RATE 0
/

```

```

4520 7340 TST242, CLA CLL CMA /AC TO 7777
4521 3040 DCA REGA
4522 1016 TAD K2525 /GET AC NUMBER
4523 4427 JMS I XIOTG /IOT 6133, CLAH
4524 6007 6007 /CAF OR CLEAR THE WORLD
4525 7307 CLA CLL IAC RTL
4526 1143 TAD K2000 /GET ENABLES
4527 4426 JMS I XIOTF1 /IOT 6132, CLOE
4530 4424 JMS I XIOTE /IOT 6131, CLSK
4531 5330 JMP .-1 /WAIT FOR FLAG
4532 7340 CLA CLL CMA /AC TO 7777
4533 4432 JMS I XIOTJ /IOT 6136, CLBA
4534 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4535 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4536 4473 JMS I ERROR /ERROR: COUNTER TO BUFFER FAILED
4537 3642 3642 /TST242 ERROR MESSAGE
4540 4520 TST242 /SCOPE LOOP

```

```

/
/DOES COUNTER TRANSFER TO BUFFER ?
/MODE 2, RATE 0
/

```

```

4541 7340 TST243, CLA CLL CMA /AC TO 7777
4542 3040 DCA REGA
4543 1017 TAD K2525 /GET AC NUMBER
4544 4427 JMS I XIOTG /IOT 6133, CLAH
4545 6007 6007 /CAF OR CLEAR THE WORLD
4546 7305 CLA CLL IAC RAL /AC TO 0002
4547 1143 TAD K2000 /GET ENABLES
4550 4426 JMS I XIOTF1 /IOT 6132, CLOE
4551 4424 JMS I XIOTE /IOT 6131, CLSK
4552 5351 JMP .-1 /WAIT FOR FLAG
4553 7340 CLA CLL CMA
4554 4432 JMS I XIOTJ /IOT 6136, CLBA
4555 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4556 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4557 4473 JMS I ERROR /ERROR: COUNTER TO BUFFER FAILED
4560 3643 3643 /TST243 ERROR MESSAGE
4561 4541 TST243 /SCOPE LOOP

```

```

/
/DOES INPUT 4,2,1 AFFECT MODE 0 ?
/

```

```

4562 7340 TST244, CLA CLL CMA
4563 3040 DCA REGA
4564 1016 TAD K2525 /GET AC NUMBER
4565 4427 JMS I XIOTG /IOT 6133, CLAB
4566 6007 6007 /CAF OR CLEAR THE WORLD
4567 7327 CLA CLL IAC RTL /AC TO 0004
4570 4426 JMS I XIOTF1 /IOT 6132, CLOE
4571 4424 JMS I XIOTE /IOT 6131, CLSK
4572 5371 JMP ,-1 /WAIT FOR FLAG
4573 7340 CLA CLL CMA /AC TO 7777
4574 4433 JMS I XIOTK /IOT 6137, CLCA
4575 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4576 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4577 4473 JMS I ERROR /ERROR: MODE 0 FAILED
4600 4244 4244 /TST 244 ERROR MESSAGE
4601 4562 TST244 /SCOPE LOOP

```

/ DOES INPUT 4,2,1 AFFECT MODE 0 ?

```

4602 7340 TST245, CLA CLL CMA /AC TO 7777
4603 3040 DCA REGA
4604 1017 TAD K2525 /GET AC NUMBER
4605 4427 JMS I XIOTG /IOT 6133, CLAB
4606 7301 CLA CLL IAC /AC TO 0001
4607 4426 JMS I XIOTF1 /IOT 6132, CLOE
4610 4424 JMS I XIOTE /IOT 6131, CLSK
4611 5210 JMP ,-1 /WAIT FOR FLAG
4612 7340 CLA CLL CMA /AC TO 7777
4613 4432 JMS I XIOTJ /IOT 6136, CLBA
4614 4456 JMS I XSNDRV /CHECK SEND RECEV REGISTERS
4615 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4616 4473 JMS I ERROR /ERROR: MODE 0 FAILED
4617 3645 3645 /TST245 ERROR MESSAGE
4620 4602 TST245 /SCOPE LOOP

```

/ DOES INPUT 4,2,1 AFFECT MODE 1 ?

```

4621 7340 TST246, CLA CLL CMA /AC TO 7777
4622 3040 DCA REGA
4623 1016 TAD K2525 /GET AC NUMBER
4624 4427 JMS I XIOTG /IOT 6133, CLAB
4625 6007 6007 /CAF OR CLEAR THE WORLD
4626 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
4627 7301 CLA CLL IAC /AC TO 0001
4630 1144 TAD K1000 /GET ENABLES
4631 4426 JMS I XIOTF1 /IOT 6132, CLOE
4632 4424 JMS I XIOTE /IOT 6131, CLOE
4633 5252 JMP ,-1 /WAIT FOR FLAG
4634 7340 CLA CLL CMA /AC TO 7777
4635 4432 JMS I XIOTJ /IOT 6136, CLBA
4636 7650 SNA CLA /WAS BUFFER STILL ALL 0'S ?
4637 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4640 4473 JMS I ERROR /ERROR: MODE 1 FAILED
4641 4246 4246 /TST246 ERROR MESSAGE
4642 4621 TST246 /SCOPE LOOP

```

/

/DOES INPUT 4,2,1 AFFECT MODE 1 ?

/

| | | | |
|------|------|---------------------|---------------------------------|
| 4643 | 7340 | TST247, CLA CLL CMA | /AC TO 7777 |
| 4644 | 3040 | DCA REGA | |
| 4645 | 1017 | TAD K0252 | /GET AC NUMBER |
| 4646 | 4427 | JMS I XIOTG | /IOT 6133, CLAB |
| 4647 | 7307 | CLA CLL IAC RTL | /AC TO 0004 |
| 4650 | 1144 | TAD K1000 | |
| 4651 | 4426 | JMS I XIOTF1 | /IOT 6132, CLOE |
| 4652 | 4424 | JMS I XIOTE | /IOT 6131, CLSK |
| 4653 | 5252 | JMP .-1 | /WAIT FOR FLAG |
| 4654 | 7340 | CLA CLL CMA | /AC TO 7777 |
| 4655 | 4432 | JMS I XIOTJ | /IOT 6136, CLBA |
| 4656 | 4426 | JMS I XSNDRV | /CHECK SEND AND RECEV REGISTERS |
| 4657 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 4660 | 4473 | JMS I ERROR | /ERROR: MODE 1 FAILED |
| 4661 | 3647 | 3647 | /TST247 ERROR MESSAGE |
| 4662 | 4643 | TST247 | /SCOPE LOOP |

/

/DOES CLSA READ INPUTS 4,2,1 ?

/

| | | | |
|------|------|---------------------|--------------------------------------|
| 4663 | 7340 | TST250, CLA CLL CMA | /AC TO 7777 |
| 4664 | 3040 | DCA REGA | |
| 4665 | 1007 | TAD K0007 | /GET ENABLES |
| 4666 | 4426 | JMS I XIOTF1 | /IOT 6132, CLOE |
| 4667 | 7000 | NOP | |
| 4670 | 2041 | ISZ REGB | |
| 4671 | 5267 | JMP .-2 | /WAIT FOR ALL |
| 4672 | 4424 | JMS I XIOTE | /IOT 6131, CLSK |
| 4673 | 5272 | JMP .-1 | |
| 4674 | 4423 | JMS I XIOTD | /IOT 6130, CLZE |
| 4675 | 7300 | CLA CLL | /CLEAR THE AC AND LINK |
| 4676 | 3070 | DCA SEND | /SAVE OUTPUT FOR ERROR PRINTER |
| 4677 | 7340 | CLA CLL CMA | /AC TO 7777 |
| 4700 | 4431 | JMS I XIOTI | /IOT 6135, CLSA |
| 4701 | 7650 | SNA CLA | /WAS STATUS ALL 0'S ? |
| 4702 | 4472 | JMS I NERROR | /CHECK NON-ERROR HANDLER |
| 4703 | 4473 | JMS I ERROR | /ERROR: INPUT 4,2,1 OR STATUS FAILED |
| 4704 | 5250 | 5250 | /TEST250 ERROR MESSAGE |
| 4705 | 4663 | TST250 | /SCOPE LOOP |

/

/DOES CLSA READ STATUS REGISTER ?

/

| | | | |
|------|------|---------------------|-----------------|
| 4706 | 7340 | TST251, CLA CLL CMA | /AC TO 7777 |
| 4707 | 3040 | DCA REGA | |
| 4710 | 1007 | TAD K0007 | /GET ENABLES |
| 4711 | 4425 | JMS I XIOTF | /IOT 6132, CLOE |
| 4712 | 7000 | NOP | |
| 4713 | 2041 | ISZ REGB | |
| 4714 | 5312 | JMP .-2 | /WAIT FOR FLAGS |
| 4715 | 4424 | JMS I XIOTE | /IOT 6131, CLSK |
| 4716 | 5315 | JMP .-1 | |
| 4717 | 7340 | CLA CLL CMA | /AC TO 7777 |
| 4720 | 4431 | JMS I XIOTI | /IOT 6135, CLSA |

```

4721 4456 JMS I XSNDRV /CHECK SEND AND RECEV REGISTERS
4722 4472 JMS I NERROR /CHECK NON-ERROR HANDLER
4723 4473 JMS I ERROR /ERROR: CLSA OR STATUS REGISTER
4724 5251 5251 /TST251 ERROR MESSAGE
4725 4706 TST251 /SCOPE LOOP

```

```

4726 7300 /
4727 2077 ISZ LOOP
4730 5464 JMP I XMITT /DO TEST 4096 TIMES
4731 4570 JMS I XPASS /TYPE PASS COMPLETE
4732 5465 JMP I XMITT1 /CONTINUE TESTING

```

/NON-ERROR HANDLER FOR PROGRAM

```

5000 *5000
5000 0000 NERRO, 0000
5001 6007 6007 /CAF OR CLEAR THE WORLD
5002 2200 ISZ NERRO
5003 2200 ISZ NERRO
5004 2040 ISZ REGA
5005 5215 JMP OUT
5006 4460 JMS I XCLREG /CLEAR ALL REGISTERS
5007 7604 LAS
5010 0137 AND K0040 /IS IT LOOP ON NON-
5011 7640 SZA CLA /FAILING TEST.
5012 5215 JMP OUT
5013 2200 ISZ NERRO
5014 5600 JMP I NERRO /TO NEXT TEST

5015 1600 OUT, TAD I NERRO
5016 3220 DCA ERRO
5017 5620 JMP I ERRO

```

/ERROR HANDLER FOR PROGRAM

```

5020 0000 ERRO, 0000
5021 6007 6007 /CAF OR CLEAR THE WORLD
5022 7604 LAS
5023 7006 RTL
5024 7700 SMA CLA /CHECK SWR2 FOR INH. PRINT
5025 4503 JMS I XSORT /GET ERROR MESSAGE
5026 4510 JMS I XBELL /RING BELL
5027 4460 JMS I XCLREG
5030 2220 ISZ ERRO
5031 7604 LAS
5032 0015 AND K0200
5033 7650 SNA CLA /CHECK SWR4 FOR INH. HLT
5034 7402 EH11, HLT /MONITOR ERROR HALT, READ TYPEOUT
/AND REFERENCE LISTING.

5035 7604 LAS
5036 0013 AND K0100
5037 7640 SZA CLA /CHECK SWR5 FOR SCOPE LOOP
5040 5243 JMP IN
5041 2220 ISZ ERRO

```

```

5042 5620      /      JMP I ERRO      /ENTER SCOPE LOOP
5043 1620      / IN,      TAD I ERRO
5044 3200      DCA NERRO
5045 5620      JMP I NERRO
5046 0000      / BELL,     0000
5047 7624      LAS
5050 0116      AND K0400
5051 7640      SZA CLA
5052 5646      JMP I BELL
5053 1026      TAD K0207
5054 4527      JMS I XTYPE
5055 5646      JMP I BELL
5056 0000      / TYPE,     0000
5057 6046      TLS
5060 6041      TSF
5061 5260      JMP .-1
5062 7200      CLA
5063 6042      TCF
5064 5656      JMP I TYPE
5065 0000      / CLRREG,   0000
5066 7300      CLA CLL      /CLEAR THE AC AND LINK
5067 3041      DCA REGB
5070 3042      DCA REGC
5071 3043      DCA REGD
5072 3070      DCA SEND
5073 3071      DCA RECEV
5074 7624      LAS
5075 0117      AND K6000
5076 7650      SNA CLA
5077 7340      CLA CLL CMA
5100 3040      DCA REGA
5101 5665      JMP I CLRREG
5102 0000      / IOTA,     0000
5103 6131      6131      /FIELD SERVICE CHANGE
5104 5702      JMP I IOTA
5105 2302      ISZ IOTA
5106 5702      JMP I IOTA
5107 0000      / IOTB,     0000
5110 6132      6132      /FIELD SERVICE CHANGE
5111 5707      JMP I IOTB
5112 2307      ISZ IOTB
5113 5707      JMP I IOTB
5114 0000      / IOTC,     0000
5115 6133      6133      /FIELD SERVICE CHANGE
5116 5714      JMP I IOTC
5117 2314      ISZ IOTC
5120 5714      JMP I IOTC

```

```

5121 0000 IOTD, 0000
5122 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
5123 1070 TAD SEND
5124 6130 6130 /FIELD SERVICE CHANGE
5125 5721 JMP I IOTD
5126 7402 EHLT2, HLT /SKIP TRAP, CLZE
/
5127 0000 IOTE, 0000
5130 6131 6131 /FIELD SERVICE CHANGE
5131 5727 JMP I IOTE
5132 2327 ISZ IOTE
5133 5727 JMP I IOTE
/
5134 0000 IOTF, 0000
5135 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
5136 1070 TAD SEND
5137 6132 6132 /FIELD SERVICE CHANGE
5140 5734 JMP I IOTF
5141 7402 EHLT3, HLT /SKIP TRAP, CL0E
/
5142 0000 IOTF1, 0000
5143 6132 6132 /FIELD SERVICE CHANGE
5144 5742 JMP I IOTF1
5145 7402 EHLT4, HLT /SKIP TRAP, CL0E
/
5146 0000 IOTG, 0000
5147 3070 DCA SEND /SAVE OUTPUT FOR ERROR PRINTER
5150 1070 TAD SEND
5151 6133 6133 /FIELD SERVICE CHANGE
5152 5746 JMP I IOTG
5153 7402 EHLT5, HLT /SKIP TRAP, CLAB
/
5154 0000 IOTH, 0000
5155 6134 6134 /FIELD SERVICE CHANGE
5156 7410 SKP
5157 7402 EHLT6, HLT /SKIP TRAP, CLEN
5160 3071 DCA RECEV /SAVE OUTPUT FOR ERROR PRINTER
5161 1071 TAD RECEV
5162 5754 JMP I IOTH
/
5163 0000 IOTI, 0000
5164 6135 6135 /FIELD SERVICE CHANGE
5165 7410 SKP
5166 7402 EHLT7, HLT /SKIP TRAP, CLSA
5167 3071 DCA RECEV /SAVE OUTPUT FOR ERROR PRINTER
5170 1071 TAD RECEV
5171 5763 JMP I IOTI
/
5200 *5200
/
5200 0000 IOTJ, 0000
5201 6136 6136 /FIELD SERVICE CHANGE
5202 7410 SKP
5203 7402 EHLT10, HLT /SKIP TRAP, CLBA
5204 3071 DCA RECEV /SAVE OUTPUT FOR ERROR PRINTER

```

```

5205 1071      TAD RECEV
5206 5600      JMP I IOTJ
/
5207 0000      IOTK,  0000
5210 6137      6137      /FIELD SERVICE CHANGE
5211 7410      SKP
5212 7402      EHLT11, HLT      /SKIP TRAP, CLCA
5213 3071      DCA RECEV      /SAVE OUTPUT FOR ERROR PRINTER
5214 1071      TAD RECEV
5215 5607      JMP I IOTK
/
5216 0000      SNDRV,  0000
5217 7041      CIA
5220 1070      TAD SEND
5221 7640      SZA CLA      /WAS SEND AND RECEV THE SAME ?
5222 2216      ISZ SNDRV
5223 5616      JMP I SNDRV
/
5224 0000      RANDOM, 0000
5225 1044      TAD REGE
5226 7004      RAL
5227 7430      SEL
5230 1410      TAD I 10
5231 3044      DCA REGE
5232 1044      TAD REGE
5233 5624      JMP I RANDOM
5234 0000      PIG05,  0000
5235 7300      CLA CLL      /CLEAR THE AC AND LINK
5236 1254      TAD PRET5
5237 3002      DCA 2      /SET FOR PI RETURN
5240 6001      ION
5241 7300      CLA CLL      /CLEAR THE AC AND LINK
5242 1076      TAD KREGC
5243 3042      DCA REGC
5244 4433      JMS I XIOTK      /READ THE COUNTER
5245 2042      ISZ REGC
5246 5245      JMP .-1
5247 2043      ISZ REGD
5250 5241      JMP .-7
5251 2254      ISZ PIG05
5252 6002      PIRET5, IOF      /DISABLE PROGRAM INTERRUPT
5253 5634      JMP I PIG05
/
5254 5252      PRET5,  PIRET5
/
5255 0000      PIG01,  0000
5256 7300      CLA CLL      /CLEAR THE AC AND LINK
5257 1267      TAD PRET1
5260 3002      DCA 2      /SET FOR PI RETURN
5261 6001      ION      /ENABLE PROGRAM INTERRUPT
5262 4454      JMS I XISZ
5263 7410      SKP
5264 2255      PIRET1, ISZ PIG01
5265 6002      IOF      /DISABLE PROGRAM INTERRUPT
5266 5655      JMP I PIG01

```

```

/
5267 5264 /
PRET1, PIRET1
/
5270 0000 PIG02, 0000
5271 7300 CLA CLL /CLEAR THE AC AND LINK
5272 1301 TAD PRET2
5273 3002 DCA 2 /SET FOR PI RETURN
5274 6001 ION
5275 4454 JMS I XISZ /WAIT
5276 2270 ISZ PIG02
5277 6002 PIRET2, IOF
5300 5670 JMP I PIG02
/
5301 5277 PRET2, PIRET2
/
5302 0000 SYNC, 0000
5303 4422 JMS I XIOTC
5304 5303 JMP .-1
5305 4422 JMS I XIOTC
5306 5305 JMP .-1
5307 5702 JMP I SYNC
/
5310 0000 ISZLOP, 0000
5311 7300 CLA CLL
5312 1113 TAD KT1CPS
5313 3049 DCA REGF
5314 7001 IAC
5315 7000 NOP
5316 2043 ISZ REGD
5317 5314 JMP .-3
5320 2045 ISZ REGF
5321 5314 JMP .-5
5322 5710 JMP I ISZLOP
/
5323 0000 PIG03, 0000
5324 7300 CLA CLL /CLEAR THE AC AND LINK
5325 1335 TAD PRETC
5326 3002 DCA 2
5327 6001 ION
5330 7000 NOP
5331 7410 SKP
5332 2523 RETC, ISZ PIG03
5333 6002 IOF
5334 5723 JMP I PIG03
/
5335 5332 PRETC, RETC
/
5336 0000 PIG04, 0000
5337 7300 CLA CLL /CLEAR THE AC AND LINK
5340 1347 TAD PRETD
5341 3002 DCA 2
5342 6001 ION
5343 7000 NOP
5344 2336 ISZ PIG04
5345 6002 RETD, IOF

```

```

5346 5736          JMP I PIG04
/
5347 5345  PRETD, RETD
/
5350 0000  IOTS,  0000
5351 6132          6132
5352 6134          6134
5353 6132          6132
5354 6134          6134
5355 6132          6132
5356 6134          6134
5357 5750          JMP I IOTS
/
5360 0000  IOTS1, 0000
5361 6133          6133
5362 6136          6136
5363 6133          6133
5364 6136          6136
5365 6133          6133
5366 6136          6136
5367 5760          JMP I IOTS1
/
5370 0000  IOTS2, 0000
5371 6133          6133
5372 6137          6137
5373 6133          6133
5374 6137          6137
5375 6133          6133
5376 6137          6137
5377 5770          JMP I IOTS2
/
          5400  *5400
/
5400 0000  IOTS3, 0000
5401 6134          6134
5402 7040          CMA          /COMPLEMENT THE AC
5403 6130          6130
5404 7040          CMA          /COMPLEMENT THE AC
5405 6134          6134
5406 7040          CMA          /COMPLEMENT THE AC
5407 6130          6130
5410 7040          CMA          /COMPLEMENT THE AC
5411 6134          6134
5412 5600          JMP I IOTS3
/
5413 0000  CLOCK, 0000
5414 7604          LAS
5415 0007          AND K0007
5416 3075          DCA CLOCKS
5417 5613          JMP I CLOCK
/
/Routine to type octal numbers
/ENTER WITH NUMBER IN AC AND LINK 0
/
5420 0000  OCTEL, 0000

```

```

5421 7006      RTL
5422 7006      RTL
5423 3041      DCA REGB      /SAVE NUMBER
5424 1130      TAD K7774
5425 3042      DCA REGC      /SET UP COUNTER
5426 1041      TAD REGB      /GET NUMBER
5427 0007      AND K0007
5430 1123      TAD K0260
5431 4507      JMS I XTYPE
5432 1041      TAD REGB      /GET NUMBER
5433 7006      RTL
5434 7004      RAL
5435 3041      DCA REGB      /SAVE THE REST
5436 2042      ISZ REGC
5437 5226      JMP .-11
5440 5620      JMP I OCTEL

```

/
/ROUTINE FOR CRLF

```

5441 0000      CRLF, 0000
5442 7300      CLA CLL          /CLEAR THE AC AND LINK
5443 1134      TAD K0215
5444 4507      JMS I XTYPE
5445 1135      TAD K0212
5446 4507      JMS I XTYPE
5447 5641      JMP I CRLF

```

/ROUTINE TO TYPE CLOCK

```

5450 0000      POPR, 0000
5451 7300      CLA CLL          /CLEAR THE AC AND LINK
5452 1262      TAD KTADCK      /GET CLOCK TAD
5453 1075      TAD CLOCKS      /MAKE IT
5454 3255      DCA .+1
5455 1262      TAD KTADCK      /MODIFIED BY TEST
5456 4504      JMS I XOCTEL      /PRINT NUMBER
5457 4506      JMS I XPRINT      /PRINT CLOCKS
5460 6026      FMES
5461 5650      JMP I POPR

```

5462 1263 / KTADCK, TAD CLKNO

```

5463 0001      / CLKNO, 0001
5464 0050      0050
5465 0100      0100
5466 0120      0120
5467 0500      0500
5470 5000      5000

```

/
/ROUTINE TO SORT ERROR MESSAGES

```

5471 0000      / SORT, 0000
5472 7300      CLA CLL          /CLEAR THE AC AND LINK
5473 4501      JMS I XCRLF      /CRLF
5474 1473      TAD IERROR      /GET MESSAGE POINT
5475 3044      DCA REGE

```

```

5476 4505 JMS I XMESS /GO PRINT TEST + ADDRESS
5477 1444 TAD I REGE
5500 7012 RTR
5501 7012 RTR
5502 7012 RTR
5503 7012 RTR /MOVE IT TO BITS 8-11
5504 0127 AND K0017 /MASK 8-11
5505 3044 DCA REGE /SAVE POINTER
5506 7300 CLA CLL /CLEAR THE AC AND LINK
5507 1044 TAD REGE /GET POINTER
5510 1326 TAD KTADM
5511 3312 DCA .+1
5512 1326 TAD KTADM /MODIFIED BY TEST
5513 3316 DCA .+3 /STORE MESSAGE POINTER
5514 4501 JMS I XCRLF /CRLF
5515 4506 JMS I XPRINT /PRINT MESSAGE
5516 0000 0000 /MODIFIED MESSAGE POINTER
5517 7300 CLA CLL
5520 1044 TAD REGE /GET MESSAGE POINTER
5521 1132 TAD K7772 /IS IT GREATER THAN
5522 7620 SNL CLA
5523 5671 JMP I SORT
5524 4502 JMS I XREG
5525 5671 JMP I SORT

```

```

/
5526 1327 KTADM, TAD KTMX
/

```

```

5527 6107 KTMX, MES1
5530 6131 MES2
5531 6132 MES3
5532 6202 MES4
5533 6231 MES5
5534 6256 MES6
5535 6303 MES7
5536 6324 MES8
5537 6353 MES9
5540 6402 MES10
5541 6431 MES11

```

```

/ROUTINE TO PRINT TEST + ADDRESS
/

```

```

5542 0000 MESS, 0000
5543 7300 CLA CLL /CLEAR THE AC AND LINK
5544 4501 JMS I XCRLF /CRLF
5545 4506 JMS I XPRINT /GO PRINT TEST
5546 6046 TMES
5547 1473 TAD I ERROR /GET ERROR MESSAGE
5550 3043 DCA REGD /STORE MESSAGE POINTER
5551 1443 TAD I REGD
5552 0136 AND K0377 /MASK 4-11
5553 4504 JMS I XOCTEL /GO PRINT NUMBER
5554 2043 ISZ REGD /UPDATE POINTER
5555 4506 JMS I XPRINT /GO PRINT STARTING ADDRESS
5556 6051 AMES
5557 1443 TAD I REGD

```

| | | | |
|------|------|--------------|------------------------|
| 5560 | 4524 | JMS I XOCTEL | /GO PRINT NUMBER |
| 5561 | 7300 | CLA CLL | /CLEAR THE AC AND LINK |
| 5562 | 5742 | JMP I MESS | |

/ROUTINE TO PRINT AC

| | | | |
|------|------|--------------|------------------------|
| 5563 | 0000 | PREG, 0000 | |
| 5564 | 4521 | JMS I XCRLF | /CRLF |
| 5565 | 4526 | JMS I XPRINT | /GO PRINT MESSAGE |
| 5566 | 6067 | GMES | |
| 5567 | 1070 | TAD SEND | /GET GOOD AC |
| 5570 | 4524 | JMS I XOCTEL | /PRINT IT |
| 5571 | 4526 | JMS I XPRINT | /PRINT BAD AC |
| 5572 | 6077 | BMES | |
| 5573 | 1071 | TAD RECEV | /GET BAD AC |
| 5574 | 4524 | JMS I XOCTEL | /PRINT IT |
| 5575 | 7300 | CLA CLL | /CLEAR THE AC AND LINK |
| 5576 | 5763 | JMP I PREG | |

5600 +5600

| | | | |
|------|------|------------|--------------------|
| 5600 | 0000 | SETO, 0000 | |
| 5601 | 1120 | TAD JMP12 | /GET JMP I 2 |
| 5602 | 3021 | DCA 1 | /SET FOR PI RETURN |
| 5603 | 5600 | JMP I SETO | |

/ROUTINE TO TYPE LISTING
/ENTER WITH JMS +1 EQUAL TO START OF LIST

| | | | |
|------|------|-------------|------------------------|
| 5604 | 0000 | PRINT, 0000 | |
| 5605 | 7300 | CLA CLL | /CLEAR THE AC AND LINK |
| 5606 | 1604 | TAD I PRINT | |
| 5607 | 2204 | ISZ PRINT | /SET FOR RETURN +1 |
| 5610 | 3041 | DCA REGB | /SAVE THE POINTER |
| 5611 | 1441 | TAD I REGB | /GET THE CHARACTER |
| 5612 | 0012 | AND K7700 | /MASK BITS 0-5 |
| 5613 | 7400 | SNA | /END OF MESSAGE |
| 5614 | 5240 | JMP EXIT | /YES, EXIT |
| 5615 | 7520 | SMA | /IS AC MINUS |
| 5616 | 7020 | CML | /NO, SET THE LINK |
| 5617 | 7001 | IAC | |
| 5620 | 7012 | RTR | |
| 5621 | 7012 | RTR | |
| 5622 | 7012 | RTR | |
| 5623 | 4507 | JMS I XTYPE | /PRINT THE CHARACTER |
| 5624 | 1441 | TAD I REGB | /GET THE WORD |
| 5625 | 0133 | AND K0077 | /MASK BITS 6-11 |
| 5626 | 7400 | SNA | /END OF MESSAGE |
| 5627 | 5240 | JMP EXIT | /YES EXIT |
| 5630 | 1125 | TAD K3740 | /NO, ADD A CONSTANT |
| 5631 | 7520 | SMA | |
| 5632 | 1124 | TAD K4100 | |
| 5633 | 1126 | TAD K0240 | |
| 5634 | 4527 | JMS I XTYPE | /TYPE THE CHARACTER |
| 5635 | 2041 | ISZ REGB | /UPDATE WORD LIST |

```

5636 7300          CLA CLL          /CLEAR THE AC AND LINK
5637 5211          JMP PRINT+5

```

```

/
5640 7300          EXIT,  CLA CLL          /CLEAR THE AC AND LINK
5641 5604          JMP I PRINT        /YES EXIT

```

/ROUTINE TO WAIT FOR OVERFLOWS

```

/
5642 0000          XWAIT, 0000
5643 3011          DCA SAVAC          /SAVE THE AC
5644 7344          CLA CLL CMA RAL
5645 1242          TAD XWAIT
5646 3242          DCA XWAIT          /SET FOR RETURN ADDRESS
5647 2041          ISZ REGB
5650 5256          JMP RETURN
5651 2045          ISZ REGF
5652 5256          JMP RETURN
5653 7325          CLA CLL CML IAC RAL
5654 1242          TAD XWAIT
5655 3242          DCA XWAIT          /UPDATE FOR ERROR RETURN
5656 1011          RETURN, TAD SAVAC
5657 5642          JMP I XWAIT

```

```

/
5660 0000          SWLAS, 0000
5661 7604          LAS
5662 0142          AND K0010
5663 7640          SZA CLA          /CHECK FOR EXTERNAL CLOCK SCOPE LOOP
5664 5325          JMP CLKIN        /ENTER SCOPE LOOP
5665 7604          LAS
5666 0140          AND K0020          /CHECK FOR EXTERNAL PULSE SCOPE LOOP
5667 7640          SZA CLA
5670 5313          JMP EXTER        /ENTER SCOPE LOOP
5671 7340          CLA CLL CMA          /AC TO 7777
5672 3113          DCA KT1CPS
5673 7604          LAS
5674 0114          AND K6007
5675 7640          SZA CLA
5676 5321          JMP .+3
5677 1111          TAD KPRMTI
5700 3113          DCA KT1CPS
5701 7604          LAS          /GET HIS SWITCHES
5702 7004          RAL          /GET BIT 1
5703 7710          SPA CLA
5704 5660          JMP I SWLAS        /TEST SCHMITT
5705 2260          ISZ SWLAS
5706 7604          LAS          /GET HIS SWITCHES
5707 7710          SPA CLA
5710 5660          JMP I SWLAS        /TEST DK8-EP
5711 2260          ISZ SWLAS
5712 5660          JMP I SWLAS        /TEST DK8-EA OR DK8-EC

```

```

/
5713 7340          EXTER, CLA CLL CMA
5714 4427          JMS I XIOTG        /IOT 6133, CLAS
5715 7300          CLA CLL
5716 1137          TAD K0040

```

```

5717 1147 TAD K0600 /GET ENABLES
5720 4425 JMS I XIOTF /IOT 6132, CLOE
5721 4424 JMS I XIOTE /IOT 6131, CLSK
5722 5321 JMP ,-1 /WAIT FOR OVERFLOW
5723 6007 6007 /CAF OR CLEAR THE WORLD
5724 5313 JMP EXTER /CONTINUE WITH SCOPE LOOP

```

```

/
5725 7340 CLKIN, CLA CLL CMA /AC TO 7777
5726 4427 JMS I XIOTG /IOT 6133, CLAB
5727 7300 CLA CLL
5730 1013 TAD K0100 /GET ENABLES
5731 4426 JMS I XIOTF1 /IOT 6132, CLOE
5732 4424 JMS I XIOTE /IOT 6131, CLSK
5733 5332 JMP ,-1 /WAIT FOR OPERATOR
5734 6007 6007 /CAF OR CLEAR THE WORLD
5735 1006 TAD K0207
5736 4507 JMS I XTYPE /TTY SIGNAL
5737 5325 JMP CLKIN /LOOP

```

```

/
5740 0000 PASS, 0000
5741 4501 JMS I XCRLF /CRLF
5742 4506 JMS I XPRINT /PRINT MESSAGE
5743 6014 PMES
5744 6007 6007
5745 5740 JMP I PASS

```

```

/
5746 0000 GTAD, 0000
5747 1075 TAD CLOCKS /GET SELECTED CLOCK
5750 1354 TAD CLTAD
5751 3746 DCA I GTAD
5752 2346 ISZ GTAD
5753 5746 JMP I GTAD

```

```

/
5754 5755 CLTAD, CLTAD +1
5755 6000 6000
5756 1612 1612
5757 4776 4776
5760 5367 5367
5761 7306 7306
5762 7747 7747
5763 4000 4000
5764 1527 1527
5765 4552 4552
5766 5217 5217
5767 7276 7276
5770 7741 7741

```

```

/
5771 0000 TIMCLK, 0000
5772 7604 LAS
5773 0114 AND K6007
5774 7650 SNA CLA
5775 1166 TAD PATCH
5776 1012 TAD K7700
5777 5771 JMP I TIMCLK

```

| | | |
|------|------|--|
| 6000 | 0413 | DKMES, TEXT ?DK8E CLOCKS DIAGNOSTIC? |
| 6001 | 7025 | |
| 6002 | 4023 | |
| 6003 | 1417 | |
| 6004 | 0313 | |
| 6005 | 2340 | |
| 6006 | 0411 | |
| 6007 | 0107 | |
| 6010 | 1617 | |
| 6011 | 2324 | |
| 6012 | 1103 | |
| 6013 | 0000 | |
| 6014 | 0413 | PMES, TEXT ?DK8E PASS COMPLETE? |
| 6015 | 7025 | |
| 6016 | 4020 | |
| 6017 | 0143 | |
| 6020 | 2340 | |
| 6021 | 0317 | |
| 6022 | 1520 | |
| 6023 | 1405 | |
| 6024 | 2405 | |
| 6025 | 0000 | |
| 6026 | 4023 | FMES, TEXT ? CPS CLOCK SELECTED BY OPERATOR? |
| 6027 | 2023 | |
| 6030 | 4023 | |
| 6031 | 1417 | |
| 6032 | 0313 | |
| 6033 | 4023 | |
| 6034 | 0514 | |
| 6035 | 0523 | |
| 6036 | 2405 | |
| 6037 | 0440 | |
| 6040 | 0231 | |
| 6041 | 4017 | |
| 6042 | 2025 | |
| 6043 | 2201 | |
| 6044 | 2417 | |
| 6045 | 2200 | |
| 6046 | 2405 | TMES, TEXT ?TEST ? |
| 6047 | 2324 | |
| 6050 | 4020 | |
| 6051 | 4026 | AMES, TEXT ? FAILED, STARTING ADDRESS ? |
| 6052 | 0111 | |
| 6053 | 1405 | |
| 6054 | 0434 | |
| 6055 | 4023 | |
| 6056 | 2401 | |
| 6057 | 2224 | |
| 6060 | 1116 | |
| 6061 | 0740 | |
| 6062 | 0104 | |
| 6063 | 0422 | |
| 6064 | 0523 | |
| 6065 | 2340 | |
| 6066 | 0000 | |

6067 2410
6070 0540
6071 0717
6072 1704
6073 4001
6074 0340
6075 7540
6076 0000
6077 4001
6100 1604
6101 4002
6102 0104
6103 4001
6104 0340
6105 7540
6106 0000
6107 0314
6110 1703
6111 1340
6112 2313
6113 1120
6114 4006
6115 0111
6116 1405
6117 0404
6120 4016
6121 1740
6122 2313
6123 1120
6124 4005
6125 3020
6126 0503
6127 2405
6130 0400
6131 0314
6132 1703
6133 1340
6134 2313
6135 1120
6136 4006
6137 0111
6140 1405
6141 0404
6142 4023
6143 1311
6144 2040
6145 0530
6146 2005
6147 0324
6150 0504
6151 0000
6152 2022
6153 1707
6154 2201
6155 1540

GMES, TEXT ?THE GOOD AC = ?

BMES, TEXT ? AND BAD AC = ?

MES1, TEXT ?CLOCK SKIP FAILED, NO SKIP EXPECTED?

MES2, TEXT ?CLOCK SKIP FAILED, SKIP EXPECTED?

MES3, TEXT ?PROGRAM INTERRUPT FAILED, NO INTERRUPT EXPECTED?

6156 1116
6157 2405
6160 2222
6161 2520
6162 2440
6163 0601
6164 1114
6165 0504
6166 5440
6167 1617
6170 4011
6171 1624
6172 0522
6173 2225
6174 2024
6175 4005
6176 3020
6177 0503
6200 2405
6201 0400
6202 2022
6203 1707
6204 2201
6205 1540
6206 1116
6207 2405
6210 2222
6211 2520
6212 2440
6213 0601
6214 1114
6215 0504
6216 5440
6217 1116
6220 2405
6221 2222
6222 2520
6223 2440
6224 0530
6225 2005
6226 0524
6227 0504
6230 0000
6231 0314
6232 1703
6233 1340
6234 1725
6235 2420
6236 2524
6237 4006
6240 0111
6241 1405
6242 0454
6243 4003
6244 1417

MES4, TEXT ?PROGRAM INTERRUPT FAILED, INTERRUPT EXPECTED?

MES5, TEXT ?CLOCK OUTPUT FAILED, CLOCK FREQUENCY FAST?

6245 0313
6246 4006
6247 2225
6250 2125
6251 0516
6252 0331
6253 4006
6254 0123
6255 2420
6256 0314
6257 1703
6260 1340
6261 1725
6262 2420
6263 2524
6264 4006
6265 0111
6266 1405
6267 0424
6270 4003
6271 1417
6272 0313
6273 4006
6274 2225
6275 2125
6276 0516
6277 0331
6300 4023
6301 1417
6302 2700
6303 2410
6304 0540
6305 0123
6306 4027
6307 0123
6310 4003
6311 1001
6312 1607
6313 0504
6314 4002
6315 3140
6316 0140
6317 0314
6320 1703
6321 1340
6322 1117
6323 2420
6324 0314
6325 1703
6326 1340
6327 0225
6330 0606
6331 0522
6332 4022
6333 0507

MES6, TEXT ?CLOCK OUTPUT FAILED, CLOCK FREQUENCY SLOW?

MES7, TEXT ?THE AC WAS CHANGED BY A CLOCK IOT?

MES8, TEXT ?CLOCK BUFFER REGISTER AND AC TRANSFER FAILED?

6334 1123
6335 2405
6336 2240
6337 0116
6340 0440
6341 0103
6342 4024
6343 2201
6344 1623
6345 0605
6346 2240
6347 0601
6350 1114
6351 0504
6352 0000
6353 0314
6354 1703
6355 1340
6356 0317
6357 2516
6360 2405
6361 2240
6362 2205
6363 0711
6364 2324
6365 0522
6366 4001
6367 1604
6370 4001
6371 0340
6372 2422
6373 0116
6374 2306
6375 0522
6376 4006
6377 0111
6400 1405
6401 0400
6402 0314
6403 1703
6404 1340
6405 0516
6406 0102
6407 1405
6410 4022
6411 0507
6412 1123
6413 2405
6414 2240
6415 0116
6416 0440
6417 0103
6420 4024
6421 2201
6422 1623

MES9, TEXT ?CLOCK COUNTER REGISTER AND AC TRANSFER FAILED?

MES10, TEXT ?CLOCK ENABLE REGISTER AND AC TRANSFER FAILED?

6423 0605
6424 2240
6425 0601
6426 1114
6427 0504
6430 0000
6431 0314
6432 1703
6433 1340
6434 2324
6435 0124
6436 2523
6437 4022
6440 0507
6441 1123
6442 2405
6443 2240
6444 0116
6445 0440
6446 0103
6447 4024
6450 2201
6451 1623
6452 0605
6453 2240
6454 0601
6455 1114
6456 0504
6457 0000

MES11, TEXT ?CLOCK STATUS REGISTER AND AC TRANSFER FAILED?

| | | | | | | | |
|--------|------|--------|------|--------|------|--------|------|
| AMES | 6051 | K0017 | 0127 | LOOP | 0077 | SETO | 5600 |
| AUTO10 | 0010 | K0020 | 0140 | MES1 | 6107 | SKPWAT | 0046 |
| BEGIN | 0220 | K0040 | 0137 | MES10 | 6402 | SNDRV | 5216 |
| BELL | 5046 | K0077 | 0133 | MES11 | 6431 | SORT | 5471 |
| BGNEAC | 0215 | K0100 | 0013 | MES2 | 6131 | SWLAS | 5660 |
| BMES | 6077 | K0200 | 0015 | MES3 | 6152 | SYNC | 5302 |
| CLKIN | 5725 | K0207 | 0006 | MES4 | 6202 | T113A | 1655 |
| CLKNO | 5463 | K0212 | 0135 | MES5 | 6231 | T113B | 1646 |
| CLOCK | 5413 | K0215 | 0134 | MES6 | 6256 | T114A | 1673 |
| CLOCKS | 0075 | K0240 | 0126 | MES7 | 6303 | T114F | 1664 |
| CLRREG | 5065 | K0260 | 0123 | MES8 | 6324 | T11A | 0354 |
| CLTAD | 5754 | K0300 | 0145 | MES9 | 6353 | T120A | 1751 |
| CRLF | 5441 | K0377 | 0136 | MESS | 5542 | T121A | 1766 |
| DKMES | 6000 | K0400 | 0116 | NERR0 | 5000 | T122A | 2014 |
| EHLT1 | 5034 | K0500 | 0146 | NERROR | 0072 | T122H | 1775 |
| EHLT10 | 5203 | K0600 | 0147 | OCTEL | 5420 | T123A | 2043 |
| EHLT11 | 5212 | K0700 | 0150 | OUT | 5015 | T123B | 2024 |
| EHLT2 | 5126 | K1000 | 0144 | OVER2 | 0061 | T124A | 2072 |
| EHLT3 | 5141 | K2000 | 0143 | OVER2A | 0062 | T124P | 2053 |
| EHLT4 | 5145 | K2525 | 0016 | PASS | 5740 | T125A | 2120 |
| EHLT5 | 5153 | K3000 | 0120 | PATCH | 0166 | T125B | 2102 |
| EHLT6 | 5157 | K3740 | 0125 | PIG01 | 5255 | T126A | 2147 |
| EHLT7 | 5166 | K4000 | 0014 | PIG02 | 5270 | T126P | 2125 |
| ERRO | 5020 | K4100 | 0124 | PIG03 | 5323 | T127A | 2200 |
| ERROR | 0073 | K5000 | 0121 | PIG04 | 5336 | T12A | 0366 |
| EXIT | 5640 | K5252 | 0017 | PIG05 | 5234 | T130A | 2220 |
| EXTER | 5713 | K6000 | 0117 | PIRET1 | 5264 | T133A | 2306 |
| FMES | 6026 | K6007 | 0114 | PIRET2 | 5277 | T133E | 2273 |
| GMES | 6067 | K7000 | 0141 | PIRET5 | 5252 | T147A | 2555 |
| GTAD | 5746 | K7400 | 0112 | PMES | 6014 | T147B | 2537 |
| IN | 5043 | K7700 | 0012 | POPR | 5450 | T150A | 2603 |
| IOTA | 5102 | K7770 | 0122 | PREG | 5563 | T150P | 2565 |
| IOTB | 5107 | K7772 | 0132 | PRET1 | 5267 | T151A | 2631 |
| IOTC | 5114 | K7773 | 0131 | PRET2 | 5301 | T151P | 2613 |
| IOTD | 5121 | K7774 | 0130 | PRET5 | 5254 | T152A | 2657 |
| IOTE | 5127 | KPRMTI | 0111 | PRETC | 5335 | T152P | 2641 |
| IOTF | 5134 | KREGC | 0076 | PRETD | 5347 | T153A | 2705 |
| IOTF1 | 5142 | KT1CPS | 0113 | PRINT | 5604 | T153E | 2667 |
| IOTG | 5146 | KTA | 0151 | RANDOM | 5224 | T154A | 2733 |
| IOTH | 5154 | KTA1 | 0152 | RANDY | 0055 | T154B | 2715 |
| IOTI | 5163 | KTADCK | 5462 | RECEV | 0071 | T172A | 3254 |
| IOTJ | 5200 | KTADM | 5526 | REGA | 0040 | T172A1 | 3257 |
| IOTK | 5207 | KTB | 0153 | REGB | 0041 | T172B | 3244 |
| IOTS | 5350 | KTB1 | 0154 | REGC | 0042 | T172P1 | 3240 |
| IOTS1 | 5360 | KTC | 0155 | REGD | 0043 | T173A | 3303 |
| IOTS2 | 5370 | KTC1 | 0156 | REGE | 0044 | T173A1 | 3306 |
| IOTS3 | 5400 | KTC2 | 0157 | REGF | 0045 | T173B | 3273 |
| ISZLOP | 5310 | KTD | 0160 | RETC | 5332 | T173B1 | 3267 |
| JMP12 | 0100 | KTD1 | 0161 | RETO | 5345 | T174A | 3336 |
| K0006 | 0115 | KTE | 0162 | RETURN | 5656 | T174A1 | 3341 |
| K0007 | 0007 | KTE1 | 0163 | SAVAC | 0011 | T174B | 3326 |
| K0010 | 0142 | KTMX | 5527 | SEND | 0070 | T174B1 | 3323 |

| | | | | | | | |
|--------|------|--------|------|--------|------|--------|------|
| T175A | 3371 | TST110 | 1605 | TST167 | 3157 | TST244 | 4562 |
| T175A1 | 3374 | TST111 | 1616 | TST17 | 0431 | TST245 | 4602 |
| T175B | 3361 | TST112 | 1631 | TST170 | 3177 | TST246 | 4621 |
| T175B1 | 3356 | TST113 | 1642 | TST171 | 3215 | TST247 | 4643 |
| T176A | 3421 | TST114 | 1660 | TST172 | 3233 | TST25 | 0520 |
| T176A1 | 3424 | TST115 | 1676 | TST173 | 3262 | TST250 | 4663 |
| T176B | 3411 | TST116 | 1707 | TST174 | 3311 | TST251 | 4706 |
| T176B1 | 3405 | TST117 | 1722 | TST175 | 3344 | TST26 | 0534 |
| T177A | 3451 | TST12 | 0357 | TST176 | 3377 | TST27 | 0547 |
| T177A1 | 3454 | TST120 | 1735 | TST177 | 3427 | TST3 | 0265 |
| T177B | 3441 | TST121 | 1754 | TST2 | 0251 | TST30 | 0570 |
| T177B1 | 3435 | TST122 | 1771 | TST20 | 0441 | TST31 | 0601 |
| T200A | 3521 | TST123 | 2017 | TST200 | 3457 | TST32 | 0615 |
| T200A1 | 3504 | TST124 | 2046 | TST201 | 3507 | TST33 | 0626 |
| T200B | 3471 | TST125 | 2075 | TST202 | 3561 | TST34 | 0637 |
| T200B1 | 3465 | TST126 | 2123 | TST203 | 3573 | TST35 | 0647 |
| T201A | 3551 | TST127 | 2152 | TST204 | 3605 | TST36 | 0657 |
| T201B | 3522 | TST13 | 0371 | TST205 | 3617 | TST37 | 0667 |
| T205A | 3632 | TST130 | 2203 | TST206 | 3635 | TST4 | 0273 |
| T206A | 3650 | TST131 | 2223 | TST207 | 3653 | TST40 | 0677 |
| T207A | 3666 | TST132 | 2245 | TST21 | 0452 | TST41 | 0711 |
| T214A | 3764 | TST133 | 2264 | TST210 | 3671 | TST42 | 0722 |
| T215A | 4003 | TST134 | 2311 | TST211 | 3704 | TST43 | 0733 |
| T216A | 4022 | TST135 | 2331 | TST212 | 3720 | TST44 | 0746 |
| T22A | 0473 | TST136 | 2350 | TST213 | 3734 | TST45 | 0761 |
| T230A | 4265 | TST137 | 2367 | TST214 | 3750 | TST46 | 1000 |
| T45A | 0775 | TST14 | 0400 | TST215 | 3767 | TST47 | 1017 |
| T45B | 0763 | TST140 | 2407 | TST216 | 4006 | TST5 | 0305 |
| T46A | 1014 | TST141 | 2423 | TST217 | 4025 | TST50 | 1036 |
| T46B | 1005 | TST142 | 2437 | TST22 | 0463 | TST51 | 1055 |
| T47A | 1033 | TST143 | 2452 | TST220 | 4050 | TST52 | 1070 |
| T47B | 1024 | TST144 | 2466 | TST221 | 4073 | TST53 | 1102 |
| T50A | 1052 | TST145 | 2502 | TST222 | 4116 | TST54 | 1115 |
| T50B | 1040 | TST146 | 2516 | TST223 | 4133 | TST55 | 1130 |
| T70A | 1332 | TST147 | 2532 | TST224 | 4150 | TST56 | 1142 |
| T70B | 1322 | TST15 | 0407 | TST225 | 4165 | TST57 | 1153 |
| T71A | 1351 | TST150 | 2560 | TST226 | 4204 | TST6 | 0322 |
| T71B | 1341 | TST151 | 2606 | TST227 | 4223 | TST60 | 1164 |
| TIMCLK | 5771 | TST152 | 2634 | TST23 | 0476 | TST61 | 1177 |
| TMES | 6046 | TST153 | 2662 | TST230 | 4242 | TST62 | 1212 |
| TST0 | 0221 | TST154 | 2710 | TST231 | 4270 | TST63 | 1227 |
| TST1 | 0235 | TST155 | 2736 | TST232 | 4310 | TST64 | 1244 |
| TST10 | 0337 | TST156 | 2751 | TST233 | 4330 | TST65 | 1255 |
| TST100 | 1465 | TST157 | 2766 | TST234 | 4350 | TST66 | 1271 |
| TST101 | 1501 | TST16 | 0422 | TST235 | 4372 | TST67 | 1302 |
| TST102 | 1514 | TST160 | 3004 | TST236 | 4414 | TST7 | 0330 |
| TST103 | 1530 | TST161 | 3023 | TST237 | 4435 | TST70 | 1316 |
| TST104 | 1542 | TST162 | 3041 | TST24 | 0505 | TST71 | 1335 |
| TST105 | 1552 | TST163 | 3060 | TST240 | 4456 | TST72 | 1354 |
| TST106 | 1563 | TST164 | 3076 | TST241 | 4477 | TST73 | 1367 |
| TST107 | 1574 | TST165 | 3117 | TST242 | 4520 | TST74 | 1404 |
| TST11 | 0346 | TST166 | 3137 | TST243 | 4541 | TST75 | 1421 |

| | |
|--------|------|
| TST76 | 1435 |
| TST77 | 1451 |
| TYPE | 5056 |
| XBELL | 0110 |
| XCLOCK | 0074 |
| XCLREG | 0060 |
| XCRLF | 0101 |
| XCRS1 | 0171 |
| XCRS2 | 0172 |
| XCRS3 | 0173 |
| XCRS4 | 0174 |
| XCRS5 | 0175 |
| XDK8EP | 0063 |
| XGETM | 0167 |
| XGTAD | 0067 |
| XIOTA | 0020 |
| XIOTB | 0021 |
| XIOTC | 0022 |
| XIOTD | 0023 |
| XIOTE | 0024 |
| XIOTF | 0025 |
| XIOTF1 | 0026 |
| XIOTG | 0027 |
| XIOTH | 0030 |
| XIOTI | 0031 |
| XIOTJ | 0032 |
| XIOTK | 0033 |
| XIOTS | 0034 |
| XIOTS1 | 0035 |
| XIOTS2 | 0036 |
| XIOTS3 | 0037 |
| XISZ | 0054 |
| XLAS | 0066 |
| XMESS | 0105 |
| XMITT | 0064 |
| XMITT1 | 0065 |
| XOCTEL | 0104 |
| XOPR | 0165 |
| XPASS | 0170 |
| XPIG01 | 0047 |
| XPIG02 | 0050 |
| XPIG03 | 0051 |
| XPIG04 | 0052 |
| XPIG05 | 0053 |
| XPRINT | 0106 |
| XREG | 0102 |
| XSETO | 0164 |
| XSNORV | 0056 |
| XSORT | 0103 |
| XSYNC | 0057 |
| XTYPE | 0107 |
| XWAIT | 5642 |

ERRORS DETECTED: 0

LINKS GENERATED: 0

RUN-TIME: 39 SECCNDS

3K CORE USED