


IDENTIFICATION  
-----

PRODUCT CODE: MAINDEC-8E-DØHC-D  
PRODUCT NAME: RANDOM JMP TEST  
DATE CREATED: JUNE 11, 1971  
MAINTAINER: DIAGNOSTIC GROUP  
AUTHOR: BRUCE HANSEN



1. ABSTRACT  
-----

THIS PROGRAM TESTS THE JMP INSTRUCTION OF THE PDP-8E. MOST OF MEMORY IS USED AS A JUMP FIELD WITH A RANDOM NUMBER GENERATOR SELECTING EACH JUMP FROM AND JUMP TO LOCATION.

2. REQUIREMENTS  
-----

2.1 EQUIPMENT  
-----

PDP-8E EQUIPPED WITH TELETYPE,

2.2 STORAGE  
-----

0000,0421, THE BINARY LOADER MUST BE STORED IN THE LAST MEMORY PAGE,

2.3 PRELIMINARY PROGRAMS  
-----

IT IS ASSUMED THAT MAINDEC=8E-D0A(N), AND MAINDEC=8E-D0B(N) HAVE RUN SUCCESSFULLY,

3. LOADING PROCEDURE  
-----

3.1 METHOD  
-----

USE STANDARD BINARY LOADER,

4. STARTING PROCEDURE  
-----

4.1 CONTROL SWITCH SETTINGS  
-----

SR0(0) HALT ON ERROR,

SR2 HOLD JUMP FROM ADDRESSES CONSTANT, (1)  
SELECT RANDOM JUMP FROM ADDRESSES, (0)

SR3 HOLD JUMP TO ADDRESSES CONSTANT, (1)  
SELECT RANDOM JUMP TO ADDRESSES, (0)

4.2 STARTING ADDRESS  
-----

0200

RESTART ADDRESS  
-----

0214

4.5

OPERATOR ACTION  
-----

- A. SET SR TO 0200 AND PRESS LOAD ADDRESS.
- B. SET SR TO DESIRED MODE; IF A PARTICULAR MEMORY LOCATION IS DESIRED FOR EITHER A "CONSTANT FROM" OR "CONSTANT TO", THIS MEMORY ADDRESS IS ENTERED INTO ONE OF THE LOCATIONS SHOWN BELOW:  
  
FROM 1 ADDRESS = 0120  
FROM ADDRESS = 0117  
TO ADDRESS = 0116  
  
NOTE! ALWAYS MAKE (FROM 1) = (FROM) #1  
  
IF SR2 OR SR3 IS SET AFTER THE PROGRAM HAS BEEN STARTED, THE LAST ADDRESS TAKEN FROM THE RANDOM NUMBER GENERATOR IS USED REPEATEDLY.

C. PRESS CLEAR THEN CONTINUE.

5. OPERATING PROCEDURE  
-----

SAME AS SECTION 4.

6. ERRORS  
-----

6.1 ERROR HALTS  
-----

ALL UNUSED MEMORY LOCATIONS ARE LOADED WITH HLT ORDERS, IF THE PROGRAM EXECUTES ONE OF THESE BACKGROUND HLTS, IT IS PROBABLE THAT THE INTERRUPT FAILED TO OCCUR FOLLOWING THE JMP INSTRUCTION.

6.2

ERROR PRINTOUTS  
-----

F WWWW TO XXXX

Z = YYYY

(FROM) F WWWWIWWW = THE ADDRESS OF THE JMP INSTRUCTION.  
(TO) T XXXX: XXXX = THE ADDRESS THAT THE JMP INSTRUCTION IS JUMPING TO;  
(LOC 0000) Z = YYYY: YYYY = THE ADDRESS STORED IN LOCATION  
0000 DURING THE INTERRUPT.

NOTE THAT YYYY SHOULD EQUAL XXXX.

EXAMPLE! THE FOLLOWING IS A TYPICAL ERROR PRINTOUT:

F 4252 TO 7020  
Z = 7000

LINE 1 OF THE PRINTOUT IS A STATEMENT OF THE PROBLEM, A JMP  
INSTRUCTION IS PLACED AT LOCATION 4252, THIS JMP INSTRUCTION IS  
TRYING TO JUMP TO LOCATION 7020, LINE 2 OF THE PRINTOUT INDICATES  
THE ERROR, THE TO ADDRESS (7020) WAS TO HAVE BEEN STORED IN  
LOCATION 0000 BUT INSTEAD A 7000 WAS STORED, THUS BIT 7 WAS  
DROPPED.

6.3

ERROR RECOVERY  
-----

THE PROGRAM CONTINUES TESTING FOLLOWING AN ERROR PRINTOUT, WHEN  
ENOUGH INFORMATION HAS BEEN GATHERED FROM THE ERROR PRINTOUTS,  
A FROM AND TO ADDRESS IS SELECTED FOR USE IN THE SCOPE MODE LOOP,  
ENTER THE CHOSEN ADDRESSES INTO PROPER LOCATIONS (SEE SECTION  
4.3.8). RESTART THE PROGRAM WITH SR2 AND SR3 SET, AFTER  
ALLOWING IT TO RUN FOR A MOMENT PUSH HALT, ENTER (3520) INTO  
LOCATION 1, AND RESTART THE PROGRAM AT LOCATION 0027 WITH SR2  
AND SR3 SET, THE SCOPE MODE LOOP IS

LOCATION	CODING
0000	
0001	JMP I FROM 1
XXXX	A, ION
XXXX	JMP I TO
0120	FROM 1, A

WHEN IT IS DESIRED TO DISCONTINUE THE SCOPE MODE LOOP, RESTORE  
THE ORIGINAL CONTENT 1116 INTO LOCATION 1, AND RESTART THE PROGRAM.

7.

RESTRICTIONS  
-----

(NONE)