

DH11

DH11 AUTO ECHO LOG
CZDHHCO

AH-FG27C-MC

1 OF 1 OCT 1985

COPYRIGHT© 1972-85

digital
MADE IN USA



.REM !

IDENTIFICATION

PRODUCT CODE: AC-8472C-MC
PRODUCT NAME: CZDMMCO DH11 AUTO-ECHO TEST
DATE: JUNE 1985
MAINTAINER: NAC SOFTWARE ENGINEERING
AUTHOR: G. BAISLEY

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES

COPYRIGHT (C) 1985 BY DIGITAL EQUIPMENT CORPORATION

1.0 ABSTRACT

VERIFIES THAT THE AUTO ECHO FEATURE OF THE DH11 WORKS.

2.0 REQUIREMENTS

2.1 EQUIPMENT

PDP-11 FAMILY STANDARD COMPUTER WITH 4KW OF MEMORY
ASR-33 TELETYPE OR EQUIVALENT
DH11 ASYNCHRONOUS MULTIPLEXER
DH11 MAINTENANCE CARD INSTALLED

2.2 STORAGE

THE PROGRAM LOADS INTO 4KW OF MEMORY

3.0 LOADING PROCEDURE

THE STANDARD PROCEDURE FOR LOADING ABSOLUTE BINARY TAPES IS TO BE USED

4.0 STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

4.1.1 AFTER PROGRAM LOAD (INITIAL PROGRAM START)

ALL CONSOLE SWITCHES DOWN

PAGE 3

1
2
3
4 4.1.2 TO MODIFY DEVICE VECTOR AND CONTROL REGISTER ADDRESSES AFTER
5 PROGRAM RESTART
6

7 SW00=1
8
9

10
11 4.1.3 TO START PROGRAM AT SELECTED TEST AFTER PROGRAM RESTART
12

13 SW01=1
14
15

16
17 4.2 STARTING ADDRESS
18

19 THE STARTING ADDRESS FOR ALL TESTS IS 000200
20 THE RESTART ADDRESS FOR ALL TESTS IS 000200
21 THE STARTING ADDRESS TO ENTER A SELECTED TEST IS 000200
22
23

24
25 4.3 PROGRAM AND/OR OPERATOR ACTION
26
27

28
29 4.3.1 INITIAL PROGRAM START
30
31

32
33 4.3.1.1 LOAD PROGRAM INTO MEMORY
34
35

36
37 4.3.1.2 LOAD ADDRESS 000200
38
39

40
41 4.3.1.3 CLEAR CONSOLE SWITCHES
42
43

44
45 4.3.1.4 PRESS START
46
47

48
49 4.3.1.5 THE PROGRAM WILL TYPE "DH11 AUTO-ECHO TEST" AND WILL
50 THEN TYPE "VECTOR ADDRESS-" AND WAIT FOR AN INPUT FROM THE TELETYPE
51 KEYBOARD.

PAGE 4

1
2
3
4 4.3.1.6 TYPE IN THE ADDRESS OF THE RECEIVER INTERRUPT VECTOR FOR THE
5 DH11 TO BE TESTED FOLLOWED BY <CARRIAGE RETURN>
6
7

NOTE

8
9 WORDS IN ANGLE BRACKETS, I.E. <CARRIAGE
10 RETURN> MEAN THAT THE TELETYPE KEY WITH
11 THE NAMED FUNCTION SHOULD BE STRUCK
12
13

14
15 IF AN INCORRECT ADDRESS IS ENTERED, THE PROGRAM WILL TYPE "?" AND WILL
16 REPEAT THE SECOND MESSAGE OF 4.3.1.5
17
18

19
20 4.3.1.7 THE PROGRAM WILL TYPE "CONTROL REGISTER ADDRESS-" AND WAIT
21 FOR AN INPUT FROM THE TELETYPE KEYBOARD
22
23

24
25 4.3.1.8 TYPE IN THE ADDRESS OF THE SYSTEM CONTROL REGISTER OF THE
26 DH11 TO BE TESTED FOLLOWED BY <CARRIAGE RETURN>
27

28 IF AN INCORRECT ADDRESS IS TYPED, THE PROGRAM WILL TYPE "?" AND WILL
29 THEN REPEAT THE OF 4.3.1.7
30
31

32
33 4.3.1.9 THE PROGRAM WILL TYPE "R" TO INDICATE THAT IT IS ABOUT TO
34 START TESTING, AND THEN TESTING WILL BEGIN
35
36

37
38 4.3.2 PROGRAM RESTART WITH ALL SWITCHES DOWN
39
40

41
42 4.3.2.1 PERFORM 4.3.1.2 TO 4.3.1.5
43
44

45
46 4.3.2.2 THE PROGRAM WILL TYPE "DH11 AUTO-ECHO TEST" AND WILL
47 THEN CONTINUE AS DESCRIBED IN 4.3.1.9
48
49

50
51 4.3.3 PROGRAM RESTART WITH SW00=1

PAGE 5

1
2
3
4 4.3.3.1 LOAD ADDRESS 000200
5
6
7

8 4.3.3.2 SET SW01=1
9

10
11
12 4.3.3.3 PRESS START
13
14

15
16 4.3.3.4 THE PROGRAM WILL PERFORM AS DESCRIBED IN 4.3.1.5 TO 4.3.1.9
17
18

19
20 4.3.4 PROGRAM RESTART WITH SW01=1
21
22

23
24 4.3.4.1 LOAD ADDRESS 000200
25
26

27
28 4.3.4.2 SET SW01=1
29
30

31
32 4.3.4.3 PRESS START
33
34

35
36 4.3.4.4 THE PROGRAM WILL TYPE "DH11 AUTO-ECHO TEST" AND WILL
37 THEN TYPE "TEST PC-" AND WILL WAIT FOR AN INPUT FROM THE TELETYPE
38 KEYBOARD
39

40
41 4.3.4.5 TYPE IN THE ADDRESS OF THE TEST AT WHICH THE PROGRAM IS TO BE
42 STARTED FOLLOWED BY <CARRIAGE RETURN>
43
44

45
46 4.3.4.6 THE PROGRAM WILL TYPE R TO INDICATE THAT IT HAS STARTED AND
47 WILL START TESTING AT THE SELECTED TEST.
48
49

50
51 NOTE

52 CARE MUST BE TAKEN WHEN THIS FEATURE IS
53 USED, SINCE THERE IS NO PROTECTION
54 AGAINST SELECTING AN ADDRESS THAT IS IN
55 THE MIDDLE OF A TEST
56

PAGE 6

NOTE

IF IT IS DESIRED TO LOOP ON THE TEST
THAT IS SELECTED SET SW14=1 BEFORE
ENTERING THE TEST ADDRESS

5.0 OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

SW15=1, HALT ON ERROR
SW14=1, LOOP ON CURRENT TEST
SW13=1, SUPPRESS ERROR TYPEOUT
SW11=1, INHIBIT ITERATIONS
SW10=1, ESCAPE TO NEXT TEST ON ERROR
SW09=1, FREEZE VARIABLE PARAMETER IN CURRENT TEST
SW01=1, START PROGRAM AT SELECTED TEST
SW00=1, CHANGE PARAMETERS AT PROGRAM RESTART

5.2 SUBROUTINE ABSTRACTS

5.2.1 TRAPCATCHER (LOCATIONS 000000-000776)

THIS ROUTINE IS USED TO INTERCEPT UNEXPECTED INTERRUPTS AND TRAPS.
THE AREA FROM 000000-000776 IS LOADED WITH THE FOLLOWING SEQUENCE

2
0
4
0
...
772
0
776
0

IF AN UNEXPECTED INTERRUPT OR TRAP OCCURS, THE PROGRAM WILL HALT WITH
THE PC 2 GREATER THAN THE ADDRESS TO WHICH THE PROGRAM TRAPPED. THE
PROCESSOR STACK MAY BE EXAMINED TO DETERMINE WHERE THE PROGRAM WAS
WHEN THE TRAP OR INTERRUPT OCCURED.

PAGE 7

5.2.2 START (PROGRAM INITIALIZATION)

THIS ROUTINE INITIALIZES ALL PROGRAM FLAGS AND COUNTERS, TYPES THE PROGRAM TITLE MESSAGE, AND INPUTS THE VECTOR AND CONTROL REGISTER ADDRESSES OF THE DH11 TO BE TESTED.

5.2.3 BEGIN (PROGRAM START AND RESTART)

THIS ROUTINE IS ENTERED IMMEDIATELY AFTER "START" AND EACH TIME A PROGRAM PASS HAS BEEN COMPLETED. THE ROUTINE SETS UP THE PROCESSOR STACK AND STATUS WORD AND THEN TRANSFERS CONTROL TO THE TEST AT WHICH TESTING WILL BEGIN. IF SW01=0 WHEN THIS ROUTINE IS ENTERED TESTING WILL START AT T1 (TEST 1). IF SW01=1 WHEN THIS ROUTINE IS ENTERED, TESTING WILL START AT THE PC ENTERED FROM THE TELETYPE KEYBOARD.

5.2.4 EOP (END OF PASS)

THIS ROUTINE IS ENTERED ONCE PER PASS AFTER ALL TESTS HAVE BEEN COMPLETED. THIS ROUTINE TYPES THE MAINDEC IDENTIFICATION CODE OF THE PROGRAM, CLEARS ERROR FLAGS AND UPDATES THE PASS COUNT. IF THE PROGRAM WAS LOADED UNDER ACT11 OR DDP, THE ROUTINE CHECKS FOR RETURN TO THE ACT11 OR DDP MONITOR. IF THE PROGRAM IS NOT UNDER MONITOR CONTROL, THE ROUTINE TRANSFERS TO BEGIN.

5.2.5 SCOPER (SCOPE LOOP AND ITERATION HANDLER)

THIS ROUTINE IS ENTERED EACH TIME A TEST IS COMPLETED. THE ROUTINE CHECKS FOR THE FOLLOWING UPON ENTRY

1. IF SW10=1, THE ROUTINE WILL TRANSFER TO THE NEXT TEST IN SEQUENCE, AFTER CLEARING ERROR FLAGS.
2. IF SW11=1, THE ROUTINE WILL TRANSFER TO THE NEXT TEST SEQUENCE, AFTER CLEARING ERROR FLAGS.
3. IF SW14=1, THE ROUTINE WILL LOOP ON THE CURRENT TEST REGARDLESS OF THE ITERATION COUNT.

IF NONE OF THE ABOVE IS TRUE, THE ROUTINE WILL ADD 1 TO THE COUNT OF TEST ITERATIONS, AND COMPARE THIS VALUE TO THE NUMBER OF ITERATIONS THAT SHOULD BE PERFORMED. IF THESE NUMBERS ARE EQUAL, THE ROUTINE WILL TRANSFER TO THE NEXT TEST IN SEQUENCE. IF THE NUMBERS ARE NOT EQUAL, THE TEST CURRENTLY IN PROGRESS WILL BE REPEATED.

5.2.6 SCOP1R (FREEZE ON CURRENT DATA)

THE CALL TO THIS ROUTINE FOLLOWS IMMEDIATELY AFTER THE CALL TO THE ERROR HANDLER IN THOSE TESTS THAT HAVE VARIABLE PARAMETERS. THIS ROUTINE IS ALWAYS ENTERED IN THOSE TESTS, WHETHER OR NOT AN ERROR OCCURS. IF SW09=1, THE ROUTINE WILL TRANSFER CONTROL BACK TO THE TEST AT A POINT WHICH WILL ALLOW REPEATING THE FUNCTION UNDER TEST CONTINUOUSLY WITH THE SAME DATA. IF THIS OPTION IS SELECTED, THE ROUTINE "SCOPER" IS NEVER ENTERED AND ITERATION COUNTS WILL NOT BE UPDATED.

5.2.7 ERRORS (ERROR HANDLER)

THIS ROUTINE IS ENTERED UPON ERROR DETECTION ONLY. WITH ALL CONSOLE SWITCHES DOWN, THE ROUTINE PROCEEDS AS FOLLOWS:

1. THE PC OF THE INSTRUCTION THAT CALLED THE ERROR HANDLER IS ACCESSED THRU THE STACK, AND THEN THE EMT INSTRUCTION ITSELF IS FETCHED. THE 8 LSB OF THE EMT INSTRUCTION ARE THE ERROR CODE. THIS CODE IS USED TO ACCESS A TABLE OF ERROR MESSAGES AND ERROR DATA STORAGE LOCATIONS.
2. IF THE TEST THAT FAILED DID NOT FAIL PREVIOUSLY DURING THIS PASS, A COMPLETE ERROR REPORT IS MADE IF THE TEST THAT FAILED FAILED MORE THAN ONCE DURING THE CURRENT PASS, ONLY THE DATA RELATING TO THE FAILURE IS TYPED. IF SW13=1, NO ERROR TYPEOUT IS MADE.
3. THE ROUTINE NOW CHECKS FOR HALT ON ERROR. IF SW15=1 THE PROGRAM WILL HALT WITH THE PC OF THE CALL TO THE ERROR ROUTINE IN R0. IF SW15=0, THE PROGRAM WILL NOT HALT, BUT WILL CHECK FOR ESCAPE TO NEXT TEST.
4. IF SW10=0, THE ROUTINE WILL RETURN TO THE TEST IN PROGRESS. IF SW10=1, THE ROUTINE WILL ABORT THE CURRENT TEST, AND TRANSFER TO THE NEXT TEST IN SEQUENCE, THRU THE ROUTINE "SCOPER".

5.2.8 TRPSRV (TRAP DECODE AND DISPATCH)

THIS ROUTINE DECODES THE 8 LSB OF THE TRAP INSTRUCTION THAT CAUSED THE PROGRAM INTERRUPT, AND TRANSFERS CONTROL TO THE ROUTINE THRU THE TABLE "TRPTAB" USING THE 8 LSB OF THE TRAP INSTRUCTION AS AN OFFSET TO THE POINTER TO THE ROUTINE TO BE ENTERED.

1
2
3
4 5.3 PROGRAM AND OR OPERATOR ACTION
5
6
7

8 5.3.1 PROGRAM START WITH ALL SWITCHES DOWN
9

10
11
12 5.3.1.1 REFER TO SECTIONS 4.3.1 AND 4.3.2 FOR INITIAL PROGRAM
13 BEHAVIOR.
14

15
16
17 5.3.1.2 AFTER "R" HAS BEEN TYPED BY THE PROGRAM, TEST EXECUTION WILL
18 BEGIN. EACH TEST WILL BE REPEATED A SELECTED NUMBER OF ITERATIONS
19 (SEE LISTING FOR EXACT NUMBER FOR EACH TEST) AND THEN THE PROGRAM WILL
20 PROCEED TO THE NEXT TEST.
21

22
23
24 5.3.1.3 WHEN ALL ITERATIONS HAVE BEEN COMPLETED, THE PROGRAM WILL
25 TYPE "CZDHH-C" AND THEN RESTART TESTING AT TEST 1 (LOCATION T1 IN THE
26 PROGRAM).
27

28
29
30 5.3.1.4 IF AN ERROR OCCURS, THE PROGRAM WILL TYPE AN APPROPRIATE
31 ERROR MESSAGE, AND THEN CONTINUE THE TEST IN PROGRESS.
32

33
34
35 5.3.2 PROGRAM START WITH SW00=1
36

37 THE PROGRAM WILL PERFORM AS DESCRIBED IN 4.3.1 AND 5.3.1
38

39
40
41 5.3.3 PROGRAM START WITH SW01=1
42

43
44
45 5.3.3.1 REFER TO SECTION 4.3.4 FOR INITIAL PROGRAM BEHAVIOR
46

47
48
49 5.3.3.2 TEST EXECUTION WILL START AT THE ADDRESS SPECIFIED AND WILL
50 CONTINUE AS DESCRIBED IN 5.3.1.2

1
2
3
4 5.3.3.3 AFTER "CZDHH-C" HAS BEEN TYPED, THE PROGRAM WILL RESUME TESTING
5 AT TEST 1
6
7
8

9 5.3.4 PROGRAM OPERATION WITH SW15=1

10
11 SAME AS 5.3.1, EXCEPT THAT IN THE CASE OF AN ERROR, THE PROGRAM WILL
12 HALT AFTER THE ERROR TYPEOUT, AND THE PC+2 OF THE CALL TO THE ERROR
13 ROUTINE WILL BE DISPLAYED IN RO.
14
15

16
17 5.3.5 PROGRAM OPERATION WITH SW13=1

18
19 SAME AS 5.3.1 EXCEPT THAT NO ERROR TYPEOUTS WILL OCCUR
20
21

22
23 5.3.6 PROGRAM OPERATION WITH SW11=1

24
25 SAME AS 5.3.1 EXCEPT THAT EACH TEST WILL BE REPEATED ONCE ONLY
26
27

28
29 5.3.7 PROGRAM OPERATION WITH SW10=1

30
31 SAME AS 5.3.1, EXCEPT THAT IN THE CASE OF AN ERROR THE CURRENT TEST
32 WILL BE ABORTED, AND THE PROGRAM WILL PROCEED TO THE NEXT TEST IN
33 SEQUENCE.
34
35

36
37 5.3.8 PROGRAM OPERATION WITH SW14=1, OR SW09=1

38
39 THESE FUNCTIONS ARE NORMALLY USED FOR TROUBLE SHOOTING. SEE SECTION
40 6.3 FOR THEIR USE.
41
42
43

44
45
46
47
48
49
50
51
52
53
54
55
56
57
58

6.0 ERRORS

6.1 ERROR HALTS

THE ERROR MESSAGE FORMAT FOR ALL ERROR TYPEOUTS IS AS FOLLOWS

PC+2 MESSAGE
 HEADER (IF APPLICABLE)
 DATA (IF APPLICABLE)

WHERE

PC+2 IS THE ADDRESS OF THE CALL TO THE ERROR HANDLER + 2;
MESSAGE IS AN ASCII MESSAGE DESCRIBING (BRIEFLY) THE FAILURE;
HEADER IS A DESCRIPTION OF THE DATA TO FOLLOW;
DATA IS OCTAL INFORMATION RELATING TO THE CAUSE OF THE FAILURE. IF

PAGE 11

THE SAME ERROR OCCURS IN A GIVEN TEST ON THE SAME PASS, AND IF DATA IS ASSOCIATED WITH THAT ERROR, ONLY DATA IS TYPE ON SUCCEEDING ERROR TYPEOUTS.

IF NO DATA IS ASSOCIATED WITH THE ERROR THE COMPLETE ERROR MESSAGE IS TYPED.

6.1.1 ERROR DESCRIPTIONS

SEE LISTING FOR DETAILS OF ERRORS

6.2 ERROR RECOVERY

6.2.1 SW15=0

IF THE PROGRAM IS RUN WITH SW15=0, NO OPERATOR ACTION IS REQUIRED TO CONTINUE TESTING

6.2.2 SW15=1

IF THE PROGRAM IS RUN WITH SW15=1, TO CONTINUE TESTING AFTER THE PROGRAM HAS HALTED, PRESS THE PROCESSOR CONSOLE CONTINUE SWITCH

6.2.3 ILLEGAL INTERRUPTS

IF AN INTERRUPT OCCURS TO A VECTOR ADDRESS NOT SELECTED DURING PROGRAM INITIALIZATION, THE PROGRAM WILL HALT IN THE TRAPCATCHER. THE ADDRESS AT WHICH THE PROGRAM HALTS IS 2 GREATER THAN THE ADDRESS TO WHICH THE INTERRUPT OCCURED. THE PROGRAM MUST BE RESTARTED AT 200 TO RECOVER FROM THIS ERROR.

6.3 SCOPE LOOPING

PAGE 12

6.3.1 TO SCOPE ON A SPECIFIC TEST, SET SW14=1 AND SW13=1. THIS WILL CAUSE THE PROGRAM TO CONTINUOUSLY LOOP ON THE SAME TEST, AND WILL CAUSE ALL ERROR TYPEOUTS TO BE INHIBITED

6.3.2 TO SCOPE ON A SPECIFIC VALUE OF A PARAMETER WITHIN A TEST, SET SW09=1 TO FREEZE THE DATA. (SEE LISTING FOR THOSE TESTS THAT INCORPORATE THIS FEATURE)

6.3.3 PROGRAM START TO SCOPE LOOP ON SELECTED TEST
PERFORM SECTION 4.3.4 WITH SW14=1

7.0 RESTRICTIONS

7.1 STARTING

THE DH11 TEST CARD MUST BE INSTALLED

7.2 RUNNING

NONE

38 8.0 MISCELLANEOUS
3940
41
42 8.1 EXECUTION TIME
43

44 THE TIME FOR ONE PASS OF THE PROGRAM (END OF TYPEOUT OF CZDHH-C TO END
45 OF TYPEOUT OF CZDHH-C) IS GIVEN FOR VARIOUS PROCESSORS IN THE TABLE
46 BELOW
47

48 TIME
4950 PROCESSOR
5152 PDP-11/05.10
5354 PDP-11/20
5556 PDP-11/40
57

58 PDP-11/45

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20

9.0 PROGRAM DESCRIPTION

FIRST, VERIFY THAT AUTO-ECHO WORKS ON ALL LINES BY TRANSMITTING ONE CHARACTER WITH AUTO ECHO ENABLED.

THEN A BINARY PATTERN IS TRANSMITTED ON ALL LINES EXCEPT THE ON WITH AUTO-ECHO ENABLED. A SINGLE CHARACTER IS TRANSMITTED ON THAT LINE. ALL DATA IS VERIFIED TO BE CORRECT.

10.0 LISTING

!

1 ; DHMAC-A - DH11 MACRO LIBRARY
2 ; COPYRIGHT 1985, DIGITAL EQUIPMENT CORP., MAYNARD, MASS. 01754
3
4

5 .LIST ME
6 .NLIST MC,MD,CND
7

; 3

; CMS REPLACEMENT HISTORY

104
119
131
148
158
167
303
339
373
520
563
595
607
652
664
691
712
743
744
745
746 ; *9 SKONETSKI 26-APR-1985 16:23:08 "FIXED TYPO CAUSING ASSEMBLY ERRORS"
747 ; *8 SKONETSKI 22-APR-1985 16:48:03 "TYPO ERROR IN VECTOR CHANGE CODE SOURCE FIXED"
748 ; *7 SKONETSKI 22-APR-1985 16:26:04 "ADDED CODE TO SET VECTORS FOR PMR FAIL, ERRORS, AND EMT
TRAPS." ; *6 SKONETSKI 22-APR-1985 14:22:35 "FIXED BRANCH ERROR IN END OF PASS ROUTINE"
749 ; *5 SKONETSKI 22-APR-1985 08:28:54 "FIXED BUG (AN OCTASC MACRO CALL WAS WRONG) AND ADDED A
750
CLEAN END OF PASS
MESSAGE.
751 ; *4 SKONETSKI 18-APR-1985 14:20:15 "ADDED SOFTWARE SWITCH REG SUPPORT, BUT UNTESTED"
752 ; *3 SKONETSKI 12-APR-1985 10:34:52 "FIXED PROBLEMS WITH SPURIOUS CR/LFS"
753 ; *2 SKONETSKI 11-APR-1985 16:00:24 "ADDED MACRO FROM SYSMAC.SML THAT SIZES FOR SOFTWARE SWI
TCH REGISTER"
754 ; *1 SKONETSKI 11-APR-1985 15:49:05 "LIBRARY FOR DH11 DIAGNOSTICS"

2
3
5 000000

.LIST ME
.NLIST MC,MD,CND
.HEADER +/1972,1985/,+/DH11 AUTO-ECHO TEST/,+/CZDHH-CO/

;STARTING PROCEDURE
;LOAD PROGRAM
;LOAD ADDRESS 000200
;PRESS START
;PROGRAM WILL TYPE DH11 AUTO-ECHO TEST
;PROGRAM WILL TYPE "VECTOR ADDRESS-"
;TYPE IN THE ADDRESS OF THE RECEIVER INTERRUPT VECTOR
;FOR THE DH11 TO BE TESTED, FOLLOWED BY <CARRIAGE RETURN>
;PROGRAM WILL TYPE "CONTROL REGISTER ADDRESS-"
;TYPE IN THE ADDRESS OF THE SYSTEM CONTROL REGISTER
;FOR THE DH11 TO BE TESTED, FOLLOWED BY <CARRIAGE RETURN>
;PROGRAM WILL TYPE "R" TO INDICATE THAT TESTING HAS STARTED
;AT THE END OF A PASS, PROGRAM WILL TYPE " CZDHH-CO "
;AND THEN RESUM TESTING

; 3

000000

.TITLE CZDHH-CO
.ENABLE ABS
.NLIST MC,MD,CND
.LIST ME
.SYMBOLS

6 000000

;SWITCH REGISTER OPTIONS

100000
040000
020000
010000
004000
002000
001000
000400
000100
000040
000020
000010
000004
000002
000001

SW15=100000 ;=1,HALT ON ERROR
SW14=40000 ;=1,LOOP ON CURRENT TEST
SW13=20000 ;=1,INHIBIT ERROR TYPEDOUT
SW12=10000
SW11=4000 ;=1,INHIBIT ITERATIONS
SW10=2000 ;=1,ESCAPE TO NEXT TEST ON ERROR
SW09=1000 ;=1,LOOP WITH CURRENT DATA
SW08=400
SW06=100
SW05=40
SW04=20
SW03=10
SW02=4
SW01=2
SW00=1

; 3

;RESTART PROGRAM AT SELECTED TEST
;RESELECT VECTOR AND CONTROL REGISTER
;ADDRESS AFTER PROGRAM RESTART

0

;REGISTER DEFINITIONS

000000	R0=#0	;GENERAL REGISTER
000001	R1=#1	;GENERAL REGISTER
000002	R2=#2	;GENERAL REGISTER
000003	R3=#3	;GENERAL REGISTER
000004	R4=#4	;GENERAL REGISTER
000005	R5=#5	;GENERAL REGISTER
000006	SP=#6	;PROCESSOR STACK POINTER
000007	PC=#7	;PROGRAM COUNTER

;LOCATION EQUIVALENCIES

	;SWR=177570	;CONSOLE SWITCH REGISTER	; 3
	;LIGHTS=177570	;PDP-11/45 DISPLAY REGISTER	; 4
177776	PS=177776	;PROCESSOR STATUS WORD	; 4
015644	STACK=ENDC00+200	;START OF PROCESSOR STACK	; 3

;INSTRUCTION DEFINITIONS

005746	PUSH1SP=5746	;DECREMENT PROCESSOR STACK 1 WORD
005726	POP1SP=5726	;INCREMENT PROCESSOR STACK 1 WORD
010046	PUSHRO=10046	;SAVE R0 ON STACK
012600	POPPO=12600	;RESTORE R0 FROM STACK
024646	PUSH2SP=24646	;DECREMENT STACK TWICE
022626	POP2SP=22626	;INCREMENT STACK TWICE

```

;
.MACRO HLT      $A
          EMT    $A
.ENDM HLT
;

```

100000	BIT15=100000
040000	BIT14=40000
020000	BIT13=20000
010000	BIT12=10000
004000	BIT11=4000
002000	BIT10=2000
001000	BIT09=1000
000400	BIT08=400
000200	BIT07=200
000100	BIT06=100
000040	BIT05=40
000020	BIT04=20
000010	BIT03=10
000004	BIT02=4
000002	BIT01=2
000001	BIT00=1

1 000000 .CA1CH

; 3

```

0                                ;TRAPCATCAER FOR ILLEGAL INTERRUPTS
                                .=0
                                000000
                                000200
                                .REPT 200
                                .+2
                                HALT
                                .ENDR
                                ;UNEXPECTED TRAP TO THIS LOCATION
                                ;EXAMINE STACK TO FIND CAUSE

000000 000002                  .+2
000002 000000                  HALT
000004 000006                  .+2
000006 000000                  HALT
000010 000012                  .+2
000012 000000                  HALT
000014 000016                  .+2
000016 000000                  HALT
000020 000022                  .+2
000022 000000                  HALT
000024 000026                  .+2
000026 000000                  HALT
000030 000032                  .+2
000032 000000                  HALT
000034 000036                  .+2
000036 000000                  HALT
000040 000042                  .+2
000042 000000                  HALT
000044 000046                  .+2
000046 000000                  HALT
000050 000052                  .+2
000052 000000                  HALT
000054 000056                  .+2
000056 000000                  HALT
000060 000062                  .+2
000062 000000                  HALT
000064 000066                  .+2
000066 000000                  HALT
000070 000072                  .+2
000072 000000                  HALT
000074 000076                  .+2
000076 000000                  HALT
000100 000102                  .+2
000102 000000                  HALT
000104 000106                  .+2
000106 000000                  HALT
000110 000112                  .+2
000112 000000                  HALT
000114 000116                  .+2
000116 000000                  HALT
000120 000122                  .+2
000122 000000                  HALT
000124 000126                  .+2
000126 000000                  HALT
000130 000132                  .+2
000132 000000                  HALT
000134 000136                  .+2
000136 000000                  HALT
000140 000142                  .+2
000142 000000                  HALT
000144 000146                  .+2

```


000146	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000150	000152	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000152	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000154	000156	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000156	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000160	000162	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000162	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000164	000166	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000166	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000170	000172	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000172	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000174	000176	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000176	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000200	000202	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000202	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000204	000206	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000206	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000210	000212	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000212	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000214	000216	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000216	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000220	000222	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000222	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000224	000226	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000226	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000230	000232	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000232	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000234	000236	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000236	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000240	000242	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000242	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000244	000246	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000246	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000250	000252	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000252	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000254	000256	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000256	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000260	000262	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000262	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000264	000266	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000266	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000270	000272	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000272	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000274	000276	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000276	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000300	000302	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000302	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000304	000306	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000306	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000310	000312	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000312	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000314	000316	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000316	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000320	000322	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000322	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000324	000326	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000326	000000	HALT	;EXAMINE STACK TO FIND CAUSE

000330	000332	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000332	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000334	000336	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000336	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000340	000342	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000342	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000344	000346	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000346	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000350	000352	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000352	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000354	000356	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000356	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000360	000362	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000362	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000364	000366	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000366	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000370	000372	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000372	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000374	000376	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000376	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000400	000402	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000402	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000404	000406	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000406	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000410	000412	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000412	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000414	000416	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000416	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000420	000422	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000422	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000424	000426	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000426	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000430	000432	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000432	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000434	000436	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000436	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000440	000442	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000442	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000444	000446	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000446	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000450	000452	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000452	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000454	000456	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000456	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000460	000462	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000462	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000464	000466	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000466	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000470	000472	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000472	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000474	000476	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000476	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000500	000502	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000502	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000504	000506	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000506	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000510	000512	.+2	;UNEXPECTED TRAP TO THIS LOCATION

000512	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000514	000516	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000516	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000520	000522	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000522	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000524	000526	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000526	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000530	000532	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000532	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000534	000536	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000536	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000540	000542	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000542	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000544	000546	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000546	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000550	000552	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000552	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000554	000556	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000556	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000560	000562	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000562	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000564	000566	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000566	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000570	000572	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000572	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000574	000576	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000576	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000600	000602	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000602	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000604	000606	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000606	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000610	000612	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000612	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000614	000616	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000616	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000620	000622	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000622	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000624	000626	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000626	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000630	000632	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000632	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000634	000636	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000636	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000640	000642	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000642	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000644	000646	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000646	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000650	000652	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000652	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000654	000656	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000656	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000660	000662	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000662	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000664	000666	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000666	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000670	000672	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000672	000000	HALT	;EXAMINE STACK TO FIND CAUSE

000674	000676	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000676	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000700	000702	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000702	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000704	000706	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000706	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000710	000712	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000712	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000714	000716	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000716	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000720	000722	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000722	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000724	000726	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000726	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000730	000732	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000732	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000734	000736	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000736	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000740	000742	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000742	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000744	000746	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000746	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000750	000752	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000752	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000754	000756	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000756	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000760	000762	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000762	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000764	000766	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000766	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000770	000772	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000772	000000	HALT	;EXAMINE STACK TO FIND CAUSE
000774	000776	.+2	;UNEXPECTED TRAP TO THIS LOCATION
000776	000000	HALT	;EXAMINE STACK TO FIND CAUSE
1 001000		.SETVEC	


```

0          000200 000167 000600      .-200      ;STANDARD INTERRUPT VECTORS
          000200      JMP      START      ;GO TO START OF PROGRAM

1 000204      .TRPDEF

          ;DEFINITIONS FOR TRAP SUBROUTINE CALLS
          ;POINTERS TO SUBROUTINES CAN BE FOUND STARTING
          ;AT LOCATION "TRPTAB"

000204      TRPDEF SCOPE,+/SCOPE LOOP AND ITERATION HANDLER/
          104400      SCOPE=TRAP+Y      ;SCOPE LOOP AND ITERATION HANDLER
          000001      Y=Y+1

000204      TRPDEF TYPE,+/TELETYPE OUTPUT ROUTINE/
          104401      TYPE=TRAP+Y      ;TELETYPE OUTPUT ROUTINE
          000002      Y=Y+1

000204      TRPDEF OCTASC,+/OCTAL TO ASCII CONVERSION/
          104402      OCTASC=TRAP+Y      ;OCTAL TO ASCII CONVERSION
          000003      Y=Y+1

000204      TRPDEF INSTR,+/INPUT ASCII STRING/
          104403      INSTR=TRAP+Y      ;INPUT ASCII STRING
          000004      Y=Y+1

000204      TRPDEF INSTER,+/STRING INPUT ERROR/
          104404      INSTER=TRAP+Y      ;STRING INPUT ERROR
          000005      Y=Y+1

000204      TRPDEF PARAM,+/CONVERT STRING TO OCTAL, CHECK LIMITS/
          104405      PARAM=TRAP+Y      ;CONVERT STRING TO OCTAL, CHECK LIMITS
          000006      Y=Y+1

000204      TRPDEF SAVOSP,+/SAVE R0-R5, PC/
          104406      SAVOSP=TRAP+Y      ;SAVE R0-R5, PC
          000007      Y=Y+1

000204      TRPDEF RESO5,+/RESTORE R0-R5/
          104407      RESO5=TRAP+Y      ;RESTORE R0-R5
          000010      Y=Y+1

000204      TRPDEF SCOPE1,+/CHECK FOR FREEZE ON CURRENT DATA/
          104410      SCOPE1=TRAP+Y      ;CHECK FOR FREEZE ON CURRENT DATA
          000011      Y=Y+1

2          .MACRO CODEM1
3          MOV      DHSSR,DHSLR      ;SET UP ADDRESS OF SILO
4          INC      DHSLR      ;STATUS REGISTER HIGH BYTE
5          .ENDM CODEM1
6 000204      .START DHRVEC,3,4,DHSCR,0,177776,7,10,...,1

```

0 001000 .-1000

```

;PROGRAM INITIALIZATION
;LOCK OUT INTERRUPTS
;SET UP PROCESSOR STACK
;SET UP POWER FAIL VECTOR
;CLEAR PROGRAM FLAGS AND COUNTS
;TYPE TITLE MESSAGE
.IIF NB <>, ;DETERMINE MEMORY SIZE
.IIF NB <>, ;SET UP TRACE TRAP RETURN

001000 177570 SWR: .WORD 177570 ; SWITCH DHSCR ADDRESS ; 4
001002 177570 LIGHTS: .WORD 177570 ; LIGHTS ; 4
; 4

001004 012767 000340 176764 START: MOV #340,PS ;LOCK OUT INTERRUPTS
001012 012706 015644 MOV #STACK,SP ;SET UP PROCESSOR STACK
001016 012702 000024 MOV #24,R2 ; POINT TO VECTOR AREA ; 7
001022 012722 014510 MOV #PFAIL,(R2)+ ;SET UP POWER FAIL TRAP ; 7
001026 012722 000340 MOV #340,(R2)+ ;SERVICE AT LEVEL 7 ; 7
001032 012722 012350 MOV #ERRORS,(R2)+ ;ERROR HANDLER ; 7
001036 012722 000340 MOV #340,(R2)+ ;SERVICE AT LEVEL 7 ; 7
001042 012722 012562 MOV #TRPSRV,(R2)+ ;GENERAL HANDLER DISPATCH SERVICE ; 7
001046 012712 000340 MOV #340,(R2) ;SERVICE AT LEVEL 7 ; 8
001052 005067 012556 CLR STFLG ;CLEAR TEST START FLAG
001056 005067 012512 CLR PASCNT ;CLEAR PASS COUNT
001062 005067 012510 CLR ERRCNT ;CLEAR ERROR COUNT
001066 005067 012500 CLR ERRFLG ;CLEAR ERROR FLAG
001072 005067 012474 CLR ERRFLG ;CLEAR LAST ERROR PC
001076 016746 176702 MOV 4,-(SP) ; PUSH TRAP VECTOR ; 4
001102 016746 176700 MOV 6,-(SP) ; 4
001106 012767 001122 176670 MOV #14,4 ; SET UP TRAP VECTOR ; 4
001114 005777 177660 TST @SWR ; TEST SWITCH REGISTER ADDRESS ; 4
001120 000405 BR 24 ; IF SUCCESSFUL, LEAVE IT ALONE ; 4
001122 14: ; 4
001122 012767 000176 177650 MOV #176,SWR ; POINT TO SOFT SWITCH DHSCR ; 4
001130 005067 177646 CLR LIGHTS ; 0 MEANS WE ARE NOT GOING TO USE LIGHTS ; 4
001134 24: ; 5
001134 005726 TST (SP)+ ; CLEAN UP STACK ; 4
001136 005726 TST (SP)+ ; 4
001140 012667 176642 MOV (SP)+,6 ; 4
001144 012667 176634 MOV (SP)+,4 ; 4
001150 104401 014660 TYPE ,MTITLE ;TYPE TITLE MESSAGE
001154 005767 012452 TST INIFLG ;CHECK INITIALIZATION FLAG
;IF NB <DHRVEC>
BNE VEC1 ;IF NOT 0, CHECK SWITCHES
;FOR REINITIALIZATION
.IFF
BNE BEGIN ;IF NOT 0, START TEST
.ENDC
.IF NB <>
SIZE: CLR R0
MOV #24,004 ;SET UP TIME OUT RETURN
14: TST (R0)+ ;WILL TRAP WHEN NO MEMORY ; 9
BR 14 ;LOCATION RESPONDED, CONTINUE
24: MOV R0,HCORE ;R0 CONTAINS ADDRESS OF
SUB #2,HCORE ;NON EXISTANT MEMORY ; 9
MOV #6,004 ;RESTORE TRAPCATCHER

```

```

      .ENDC
      .IF NB
      TRACER: MOV    #18,0#10
              SXT    R0
              MOV    #RTT,TRTRET
              BR     2#
      1#:     MOV    #RTI,TRTRET
              MOV    #12,0#10
              MOV    #TRTRET,0#16
      .ENDC
      .IF NB
      .IF B
      001162 000404
      .IFF
      TST     INIFLG
      BEQ     VEC2
      .ENDC
      VEC1:   BIT     #SW00,0SWR
      BEQ     BEGIN
      VEC2:   MOV     #300,R1
              MOV     #302,R2
              MOV     #4,R3
      1#:     MOV     R2,(R1)
              CLR     (R2)
              ADD     R3,R1
              ADD     R3,R2
              CMP     R1,#1000
              BNE     1#
              INSTR
              MVECTOR
              PARAM
              300
              770
              DHRVEC
      .BYTE   3
      .BYTE   4
      INSTR
      MREGAD
      PARAM
      0
      177776
      DHSCR
      .BYTE   7
      .BYTE   10
      .ENDC
      .IF NB
      001262
      001262 016767 012270 012270
      001270 005267 012264
      .ENDC
      TST     INIFLG
      BNE     BEGIN
      COM     INIFLG
      .PROGRAM START
      .CHECK FOR PROGRAM START AT SELECTED ADDRESS

;SET UP ILLEGAL INSTRUCTION TRAP RETURN
;DO 11/40, 11/45 INSTRUCTION
;11/40,45 RTT RETURN FROM TRACE TRAP
;1105,10,20 RTI RETURN FROM TRACE TRAP
;RESTORE TRAPCATCHER
;SET UP TRACE TRAP VECTOR

; 3

;IF INITIALIZE FLAG=0
;GET VECTOR AND CSR ADDRESS
;IF SW00=1, GET NEW VECTOR
;AND CSR
; 4
; 4
; 4
;RESTORE TRAPCATCHER
;IN FLOATING VECTOR AREA
;INPUT ADDRESS OF DEVICE VECTOR
;MESSAGE "VECTOR ADDRESS-"
;CONVERT STRING TO OCTAL
;LOW LIMIT
;HIGH LIMIT
;LOCATIONS TO BE FILLED
;NUMBER OF LOCATIONS
;LSB MASK
;INPUT ADDRESS OF DEVICE CSR
;MESSAGE "CONTROL REGISTER ADDRESS-"
;CONVERT STRING TO OCTAL
;LOW LIMIT
;HIGH LIMIT
;LOCATIONS TO BE FILLED
;NUMBER OF LOCATIONS
;LSB MASK
; 3
; 3
; 3

```

001306	012767	000340	176462	BEGIN:	MOV	#340,PS	;LOCK OUT INTERRUPTS	
001314	012706	015644			MOV	#STACK,SP	;SET UP PROCESSOR STACK	
001320	032777	000002	177452		BIT	#SW01,BSWR	;IF SW01=1	; 4
001326	001410				BEQ	1#	;GET PC FOR PROGRAM START	
001330	104403				INSTR		;GET PC	
001332	015123				MTSTPC		;MESSAGE "TEST PC"	
001334	104405				PARAM		;CONVERT STRING TO OCTAL	
001336	000000				0			
001340	017500				17500			
001342	013600				RETRN			
001344	001			.BYTE	1			
001345	001			.BYTE	1			
001346	000410				BR	2#		
001350	012767	001400	012222	1#:	MOV	#T1,RETRN	;NORMAL START, TEST 1	
001356	005767	012252			TST	STFLG	;IF LOOPING, BYPASS TYPEOUT	
001362	001004				BNE	3#		
001364	005167	012244			COM	STFLG		
001370	104401	015117		2#:	TYPE	,MR	;TYPE "R" TO INDICATE START	
001374	000177	012200		3#:	JMP	@RETRN	;START TESTING	; 3

```

1      .MACRO  AUTO1  XLINE,XBIT,K
2
3      ;ENABLE AUTO ECHO ON LINE 'XLINE'
4      ;TRANSMIT ONE CHARACTER ON LINE 'XLINE'
5      ;AT 9600 BAUD, 8 BITS.
6      ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
7      ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
8      ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.
9
10     TS \XN,100,4:
11         MOV     @BIT11,@DHSCR      ;MASTER CLEAR INTERFACE
12     1$:      JSR     PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
13             ;BUS ADDRESS REGISTERS
14             MOV     #'XLINE',@DHSCR ;SELECT LINE 'XLINE'
15             MOV     #-1,@DHBC      ;SET BYTE COUNT TO 1
16             MOV     @TWRD'K',@DHBA ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
17             MOV     @100,R0        ;SET UP TO RECEIVE 64 CHARACTERS
18             CLR     R1              ;COUNT OF CHARACTERS RECEIVED
19             MOV     @133503,@DHLPR ;SET UP SPEED FOR 9600 BAUD
20             ;8 BITS PER CHARACTER,
21             ;AUTO ECHO ENABLED ON LINE 'XLINE'
22             MOV     #'XBIT',@DHBAR ;SET BAR BIT FOR LINE 'K'
23     2$:      TSTB    @DHSCR         ;WAIT FOR CHARACTER TO
24             BPL     2$              ;BE RECEIVED
25             INC     R1              ;UPDATE RECEIVED CHARACTER COUNT
26             MOV     @DHNR,R4       ;READ CHARACTER
27             CMP     R4,TWRD'K'     ;IS CHARACTER CORRECT
28             BEQ     3$              ;
29             MOV     TWRD'K',R5     ;(R5)=EXPECTED CHARACTER
30             CLR     @DHLPR         ;SHUT OFF AUTO ECHO
31             HLT     0              ;CHARACTER ECHOED INCORRECTLY
32             BR      4$              ;RESTART TEST
33     3$:      DEC     R0              ;IF 64 CHARACTERS HAVE NOT
34             BGT     2$              ;BEEN RECEIVED, CONTINUE
35             BMI     4$              ;
36             BIC     @100000,@DHLPR ;SHLT OFF AUTO-ECHO
37             BR      2$              ;GET 1 MORE CHARACTER
38     4$:      SCOPE   AUTO1          ;CHECK FOR ITERATIONS, LOOP
39     .ENDM

```

```

1      .MACRO  AUTO2  XLINE,XBIT,K
2
3      ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 'K'
4      ;TRANSMIT 1 CHARACTER ON LINE 'K' WITH AUTO ECHO ENABLED
5      ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
6      ;CHARACTER LENGTH IS 8 BITS
7      ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES
8
9      TS \XN,10,5:
10     MOV     @BIT11,@DHSCR      ;MASTER CLEAR INTERFACE
11     JSR     PC,SETALL          ;SET UP ALL LINES TO TRANSMIT
12                                     ;400 (OCTAL) CHARACTERS
13     MOV     #'K',@DHSCR        ;SELECT LINE XLINE FOR TESTING
14     MOV     @TWRD'K',@DHBA     ;CHARACTER TO BE TRANSMITTED
15                                     ;ON LINE XLINE IN AUTO ECHO MODE
16     MOV     @-1,@DHBC          ;TRANSMIT ONLY 1 CHARACTER ON LINE XLINE
17     MOV     @133503,@DHLPR     ;SET AUTO ECHO FOR LINE XLINE
18     BIC     #'XBIT',LINACT     ;CLEAR LINE ACTIVE BIT
19     MOV     @-1,@DHBA          ;SET BAR BITS FOR ALL LINES
20     CLR     R0                 ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
21     1:      MOV     @DHNR,R4     ;GET A CHARACTER FROM SILO
22     BPL     1:                 ;IF NOT VALID DATA, TRY AGAIN
23     MOV     R4,R3              ;EXTRACT LINE NUMBER FORM CHARACTER
24     SWAB    R3
25     BIC     @177760,R3         ;CLEAR STATUS BITS
26     MOV     R3,R2
27     ASL     R2
28     CMP     R3, #'K'          ;IF LINE NUMBER IS XLINE
29     BEQ     4:                 ;CHECK FOR CORRECT ECHOED CHARACTER
30     CMP     RBUF(R2),R4        ;IF NOT LINE XLINE, CHECK DATA
31     BEQ     2:                 ;
32     MOV     RBUF(R2),R5        ;:(R5)=EXPECTED NON ECHOED DATA
33     HLT     1                 ;NON ECHOED DATA ERROR
34     BR      4:
35     2:      INCB    RBUF(R2)     ;UPDATE EXPECTED RECEIVED DATA
36     BNE     1:                 ;CONTINUE IF NOT DONE
37     BIC     LINBIT(R2),LINACT   ;CLEAR ACTIVE BIT
38     3:      TST     LINACT       ;IF ALL LINES ARE DONE
39     BNE     1:                 ;EXIT
40     MOV     #'K',@DHSCR        ;SELECT LINE XLINE
41     BIC     @100000,@DHLPR     ;CLEAR AUTO ECHO FOR LINE XLINE
42     TSTB    @DHSLR             ;GET REST OF CHARACTERS
43     BNE     1:                 ;AND CHECK
44     BR      5:
45     4:      INC     R0           ;UPDATE ECHOED CHARACTER COUNT
46     CMP     R4,TWRD'K'         ;CHECK ECHOED DATA
47     BEQ     3:
48     MOV     TWRD'K',R5         ;:(R5)=EXPECTED ECHOED DATA
49     HLT     2                 ;ECHOED DATA ERROR
50     5:      SCOPE    AUTO2      ;CHECK FOR ITERATIONS. LOOP
51     .ENDM

```

```

1      .MACRO SSETALL
2
3          ;SET BYTE COUNT FOR ALL LINES TO 400
4          ;SET BUS ADDRESS FOR ALL LINES TO TBUF
5          ;CLEAR EXPECTED CHARACTER BUFFERS
6          ;SET LINE ACTIVE BITS FOR ALL LINES
7
8      SETALL: MOV     #20,R0          ;SET UP TO LOAD 16
9                                     ;BYTE COUNT AND BUS ADDRESS
10                                    ;MEMORY LOCATIONS
11                                     ;SET UP TO GENERATE EXPECTED
12                                     ;RECEIVED CHARACTER BUFFER
13                                     ;WILL BE HIGH BYTE
14                                     ;OF EXPECTED RECEIVED CHARACTER
15                                     ;OFFSET FOR HIGH BYTE
16      1$: MOV     #TBUF, @DHBA      ;LOAD BUS ADDRESS
17      MOV     #-400, @DHBC          ;LOAD BYTE COUNT
18      MOV     #31403, @HLP          ;SET LINE SPEED TO 4800 BAUD
19      CLRB     RBUF(R1)
20
21      MOV      R2, RBUF(R3)          ;RECEIVED CHARACTER
22      INC      @DHSCR               ;LOAD HIGH BYTE
23      INC      R2                   ;ADVANCE LINE NUMBER TO NEXT LINE
24      ADD      #2, R1               ;UPDATE POINTERS
25      ADD      #2, R3
26      DEC      R0
27      BNE      1$
28      MOV      #-1, LINACT          ;CONTINUE IF NOT DONE
29      RTS      PC                  ;SET ACTIVE FLAGS FOR ALL LINES
30                                     ;RETURN TO CALLING ROUTINE
31      .ENDM SSETALL
32
33      .MACRO CCLRALL
34
35          ;CLEAR ALL BYTE COUNT AND BUS ADDRESS REGISTERS
36
37      CLRALL: MOV     #20,R0          ;SET UP TO CLEAR 16
38      1$: CLR      @DHBA            ;CLEAR BUS ADDRESS
39      CLR      @DHBC              ;CLEAR BYTE COUNT
40      INC      @HSCR              ;ADVANCE LINE NUMBER
41      DEC      R0                 ;CONTINUE IF NOT DONE
42      BNE      1$
43      RTS      PC                  ;RETURN TO CALLING ROUTINE

```



```

2      000020      XLINE=LINE
3      000000      XBIT=BITX
4      000020      K=KX
5      000000      LINE=0
6      000001      BITX=1
7      000000      KX=0
9      000020      .REPT 20
10     AUTO1 \LINE,\BITX,\KX
11     .NLIST
12     LINE=LINE+1
13     BITX=BITX+BITX
14     KX=KX+1
15     .LIST
16     .ENDR
      001400      AUTO1 \LINE,\BITX,\KX

```

```

;ENABLE AUTO ECHO ON LINE 0
;TRANSMIT ONE CHARACTER ON LINE 0
;AT 9600 BAUD, 8 BITS.
;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

```

```

001400      TS \XN,100,4;
001400      012767      000340      176370      T1:      MOV      #340,PS      ;DISABLE ALL INTERRUPTS
001406      012767      000100      012172      MOV      #100,ICOUNT      ;SET UP FOR 100 ITERATIONS
001414      012767      001554      012160      MOV      #44,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB      <>
      MOV      #.FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
001422      012777      004000      012110      14:      MOV      #BIT11,BDHSCR      ;MASTER CLEAR INTERFACE
001430      004767      011744      JSR      PC,CLRALL      ;CLEAR ALL BYTE COUNT AND
      ;BUS ADDRESS REGISTERS
001434      012777      000000      012076      MOV      #0,BDHSCR      ;SELECT LINE 0
001442      012777      177777      012100      MOV      #-1,BDHBC      ;SET BYTE COUNT TO 1
001450      012777      014310      012070      MOV      #THRDO,BDHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
001456      012700      000100      MOV      #100,R0      ;SET UP TO RECEIVE 64 CHARACTERS
001462      005001      CLR      R1      ;COUNT OF CHARACTERS RECEIVED
001464      012777      133503      012052      MOV      #133503,BDHLPR      ;SET UP SPEED FOR 9600 BAUD
      ;8 BITS PER CHARACTER.
      ;AUTO ECHO ENABLED ON LINE 0
001472      012777      000001      012052      24:      MOV      #1,BDHBAR      ;SET BAR BIT FOR LINE 0
001500      105777      012034      TSTB      BDHSCR      ;WAIT FOR CHARACTER TO
001504      100375      BPL      24      ;BE RECEIVED
001506      005201      INC      R1      ;UPDATE RECEIVED CHARACTER COUNT
001510      017704      012026      MOV      BDHNR,R4      ;READ CHARACTER
001514      020467      012570      CMP      R4,THRDO      ;IS CHARACTER CORRECT
001520      001406      BEQ      34      ;(R5)=EXPECTED CHARACTER
001522      016705      012562      MOV      THRDO,R5      ;SHUT OFF AUTO ECHO
001526      005077      012012      CLR      BDHLPR      ;CHARACTER ECHOED INCORRECTLY
001532      HLT      0
001532      104000      EMT      0
001534      000407      BR      44      ;RESTART TEST
001536      005300      34:      DEC      R0      ;IF 64 CHARACTERS HAVE NOT
001540      003357      BGT      24      ;BEEN RECEIVED, CONTINUE
001542      100404      BMI      44

```

```

001544 042777 100000 011772      BIC      #100000,8DHLPR      ;SHUT OFF AUTO-ECHO
001552 000752                      BR        2#              ;GET 1 MORE CHARACTER
001554 104400                      4#:    SCOPE              ;CHECK FOR ITERATIONS, LOOP
      000001                      LINE=LINE+1
      000002                      BITX=BITX+BITX
      000001                      KX=KX+1
001556                      AUTO1    \LINE,\BITX,\KX

      ;ENABLE AUTO ECHO ON LINE 1
      ;TRANSMIT ONE CHARACTER ON LINE 1
      ;AT 9600 BAUD, 8 BITS.
      ;RECEIVE AND VERIFY CHAPACTERS UNTIL 64 HAVE BEEN RECEIVED.
      ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
      ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

001556                      TS \XN,100,4#
001556 012767 000340 176212      T2:    MOV      #340,PS              ;DISABLE ALL INTERRUPTS
001564 012767 000100 012014      MOV      #100,ICOUNT          ;SET UP FOR 100 ITERATIONS
001572 012767 001732 012002      MOV      #4#,ESCAPE          ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB <>
      MOV      #,FREEZ1              ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
001600 012777 004000 011732      MOV      #BIT11,8DHSCR          ;MASTER CLEAR INTERFACE
001606 004767 011566              1#:    JSR      PC,CLRALL        ;CLEAR ALL BYTE COUNT AN
      ;BUS ADDRESS REGISTERS
001612 012777 000001 011720      MOV      #1,8DHSCR          ;SELECT LINE 1
001620 012777 177777 011722      MOV      #-1,8DHBC          ;SET BYTE COUNT TO 1
001626 012777 014312 011712      MOV      #TWRD1,8DHBA        ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
001634 012700 000100              MOV      #100,R0              ;SET UP TO RECEIVE 64 CHARACTERS
001640 005001                      CLR      R1                  ;COUNT OF CHARACTERS RECEIVED
001642 012777 133503 011674      MOV      #133503,8DHLPR        ;SET UP SPEED FOR 9600 BAUD
      ;8 BITS PER CHARACTER.
      ;AUTO ECHO ENABLED ON LINE 1
      ;SET BAR BIT FOR LINE 1
      ;WAIT FOR CHARACTER TO
      ;BE RECEIVED
      ;UPDATE RECEIVED CHARACTER COUNT
      ;READ CHARACTER
      ;IS CHARACTER CORRECT

001650 012777 000002 011674      MOV      #2,8DHBAR          ;(R5)=EXPECTED CHARACTER
001656 105777 011656      2#:    TSTB      8DHSCR              ;SHUT OFF AUTO ECHO
001662 100375                      BPL        2#              ;CHARACTER ECHOED INCORRECTLY
001664 005201                      INC      R1                  ;RESTART TEST
001666 017704 011650              MOV      8DHRC,R4              ;IF 64 CHARACTERS HAVE NOT
001672 020467 012414              CMP      R4,TWRD1            ;BEEN RECEIVED, CONTINUE
001676 001406                      BEQ      3#
001700 016705 012406              MOV      TWRD1,R5
001704 005077 011634              CLR      8DHLPR
001710                      HLT      0
001710                      EMT      0
001712 000407                      BR        4#
001714 005300      3#:    DEC      R0
001716 003357                      BGT      2#
001720 100404                      BHI      4#
001722 042777 100000 011614      BIC      #100000,8DHLPR        ;SHUT OFF AUTO-ECHO
001730 000752                      BR        2#              ;GET 1 MORE CHARACTER
001732 104400                      4#:    SCOPE              ;CHECK FOR ITERATIONS, LOOP
      000002                      LINE=LINE+1
      000004                      BITX=BITX+BITX
      000002                      KX=KX+1
001734                      AUTO1    \LINE,\BITX,\KX

```

```

;ENABLE AUTO ECHO ON LINE 2
;TRANSMIT ONE CHARACTER ON LINE 2
;AT 9600 BAUD, 8 BITS.
;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

```

```

001734      000004      TS \XN,100,4#
001734 012767 000340 176034 T3:  MOV  #340,PS      ;DISABLE ALL INTERRUPTS
001742 012767 000100 011636      MOV  #100,ICOUNT  ;SET UP FOR 100 ITERATIONS
001750 012767 002110 011624      MOV  #4#,ESCAPE  ;SET UP TO ESCAPE TO NEXT TEST
                                .IF NB  <>
                                MOV    #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
                                .ENDC
                                XN=XN+1
001756 012777 004000 011554      MOV  #BIT11,BDHSCR  ;MASTER CLEAR INTERFACE
001764 004767 011410      1#:  JSR    PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
                                ;BUS ADDRESS REGISTERS
001770 012777 000002 011542      MOV  #2,BDHSCR      ;SELECT LINE 2
001776 012777 177777 011544      MOV  #-1,BDHBC      ;SET BYTE COUNT TO 1
002004 012777 014314 011534      MOV  #TWRD2,BDHBA    ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
002012 012700 000100      MOV  #100,R0      ;SET UP TO RECEIVE 64 CHARACTERS
002016 005001      CLR    R1      ;COUNT OF CHARACTERS RECEIVED
002020 012777 133503 011516      MOV  #133503,BDHLPR    ;SET UP SPEED FOR 9600 BAUD
                                ;8 BITS PER CHARACTER,
                                ;AUTO ECHO ENABLED ON LINE 2
                                ;SET BAR BIT FOR LINE 2
                                ;WAIT FOR CHARACTER TO
                                ;BE RECEIVED
002026 012777 000004 011516      MOV  #4,BDHBAR      ;UPDATE RECEIVED CHARACTER COUNT
002034 105777 011500      2#:  TSTB  BDHSCR      ;READ CHARACTER
002040 100375      BPL    2#      ;IS CHARACTER CORRECT
002042 005201      INC    R1
002044 017704 011472      MOV  #BDHNR,R4
002050 020467 012240      CMP    R4,TWRD2
002054 001406      BEQ    3#
002056 016705 012232      MOV  TWRD2,R5      ;(R5)=EXPECTED CHARACTER
002062 005077 011456      CLR    BDHLPR      ;SHUT OFF AUTO ECHO
002066      HLT    0      ;CHARACTER ECHOED INCORRECTLY
002066 104000      EMT    0
002070 000407      BR     4#
002072 005300      3#:  DEC    R0      ;RESTART TEST
002074 003357      BGT    2#      ;IF 64 CHARACTERS HAVE NOT
002076 100404      BMI    4#      ;BEEN RECEIVED, CONTINUE
002100 042777 100000 011436      BIC  #100000,BDHLPR
002106 000752      BR     2#
002110 104400      4#:  SCOPE
                                LINE=LINE+1
                                BITX=BITX+BITX
                                KX=KX+1
                                AUTO1  \LINE,\BITX,\KX
002112      0060C3
                                000010
                                000003
                                ;ENABLE AUTO ECHO ON LINE 3
                                ;TRANSMIT ONE CHARACTER ON LINE 3
                                ;AT 9600 BAUD, 8 BITS.
                                ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
                                ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
                                ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

002112      TS \XN,100,4#

```

```

002112 012767 000340 175656 T4:  MOV  #340,PS      ;DISABLE ALL INTERRUPTS
002120 012767 000100 011460      MOV  #100,ICOUNT  ;SET UP FOR 100 ITERATIONS
002126 012767 002266 011446      MOV  #44,ESCAPE    ;SET UP TO ESCAPE TO NEXT TEST
                                <>
                                MOV  #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
                                .ENDC
                                XN=XN+1

002134 012777 004000 011376      MOV  #BIT11,0DHSCR  ;MASTER CLEAR INTERFACE
002142 004767 011232 14:  JSR  PC,CLRALL  ;CLEAR ALL BYTE COUNT AN
                                ;BUS ADDRESS REGISTERS
                                MOV  #3,0DHSCR      ;SELECT LINE 3
                                MOV  #-1,0DHBC      ;SET BYTE COUNT TO 1
                                MOV  #TWRD3,0DHBA    ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
                                MOV  #100,R0        ;SET UP TO RECEIVE 64 CHARACTERS
                                CLR  R1             ;COUNT OF CHARACTERS RECEIVED
                                MOV  #133503,0DHLPR  ;SET UP SPEED FOR 9600 BAUD
                                ;8 BITS PER CHARACTER,
                                ;AUTO ECHO ENABLED ON LINE 3
                                ;SET BAR BIT FOR LINE 3
                                ;WAIT FOR CHARACTER TO
                                ;BE RECEIVED
                                ;UPDATE RECEIVED CHARACTER COUNT
                                ;READ CHARACTER
                                ;IS CHARACTER CORRECT

002204 012777 000010 011340      MOV  #10,0DHBAR    ;(R5)=EXPECTED CHARACTER
002212 105777 011322 24:  TSTB  0DHSCR      ;SHUT OFF AUTO ECHO
002216 100375      BPL  24:      ;CHARACTER ECHOED INCORRECTLY
002220 005201      INC  R1
002222 017704 011314      MOV  0DHNR, R4
002226 020467 012064      CMP  R4, TWRD3
002232 001406      BEQ  34:
002234 016705 012056      MOV  TWRD3, R5
002240 005077 011300      CLR  0DHLPR
002244      HLT  0
002244 104009      EMT  0
002246 000407      BR  44
002250 005300      34:  DEC  R0
002252 003357      BGT  24
002254 100404      BMI  44
002256 042777 100000 011260      BIC  #100000,0DHLPR
002264 000752      BR  24
002266 104400      44:  SCOPE
                                LINE=LINE+1
                                BITX=BITX+BITX
                                KX=KX+1
                                AUTO1  \LINE, \BITX, \KX

002270      ;ENABLE AUTO ECHO ON LINE 4
                                ;TRANSMIT ONE CHARACTER ON LINE 4
                                ;AT 9600 BAUD, 8 BITS,
                                ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
                                ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
                                ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

002270 TS \XN,100,44
002270 012767 000340 175500 T5:  MOV  #340,PS      ;DISABLE ALL INTERRUPTS
002276 012767 000100 011302      MOV  #100,ICOUNT  ;SET UP FOR 100 ITERATIONS
002304 012767 002444 011270      MOV  #44,ESCAPE    ;SET UP TO ESCAPE TO NEXT TEST
                                <>
                                MOV  #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
                                .ENDC
                                XN=XN+1

002312 000006 004000 011220      MOV  #BIT11,0DHSCR  ;MASTER CLEAR INTERFACE

```

```

002320 004767 011054      14:  JSR      PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
                                ;BUS ADDRESS REGISTERS
002324 012777 000004 011206      MOV      #4,0DHSCR      ;SELECT LINE 4
002332 012777 177777 011210      MOV      #-1,0DHBC      ;SET BYTE COUNT TO 1
002340 012777 014320 011206      MOV      #TWRD4,0DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
002346 012700 000100      MOV      #100,R0      ;SET UP TO RECEIVE 64 CHARACTERS
002352 005001      CLR      R1      ;COUNT OF CHARACTERS RECEIVED
002354 012777 133503 011162      MOV      #133503,0DHLPR      ;SET UP SPEED FOR 9600 BAUD
                                ;8 BITS PER CHARACTER,
                                ;AUTO ECHO ENABLED ON LINE 4
                                ;SET BAR BIT FOR LINE 4
002362 012777 000020 011162      MOV      #20,0DHBAR      ;WAIT FOR CHARACTER TO
002370 105777 011144      24:  TSTB      0DHSCR      ;BE RECEIVED
002374 100375      BPL      24      ;UPDATE RECEIVED CHARACTER COUNT
002376 005201      INC      R1      ;READ CHARACTER
002400 017704 011136      MOV      0DHNR,R4      ;IS CHARACTER CORRECT
002404 020467 011710      CMP      R4,TWRD4
002410 001406      BEQ      34      ;(R5)=EXPECTED CHARACTER
002412 016705 011702      MOV      TWRD4,R5      ;SHUT OFF AUTO ECHO
002416 005077 011122      CLR      0DHLPR      ;CHARACTER ECHOED INCORRECTLY
002422      HLT      0
002422 104000      EMT      0
002424 000407      BR      44      ;RESTART TEST
002426 005300      34:  DEC      R0      ;IF 64 CHARACTERS HAVE NOT
002430 003357      BGT      24      ;BEEN RECEIVED, CONTINUE
002432 100404      BMI      44
002434 042777 100000 011102      BIC      #100000,0DHLPR      ;SHUT OFF AUTO-ECHO
002442 000752      BR      24      ;GET 1 MORE CHARACTER
002444 104400      44:  SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000005      LINE=LINE+1
      000040      BITX=BITX+BITX
      000005      KX=KX+1
002446      AUTO1      \LINE,\BITX,\KX

      ;ENABLE AUTO ECHO ON LINE 5
      ;TRANSMIT ONE CHARACTER ON LINE 5
      ;AT 9600 BAUD, 8 BITS.
      ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
      ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
      ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

002446      TS      \XN,100,44
002446 012767 000340 175322      T6:  MOV      #340,PS      ;DISABLE ALL INTERRUPTS
002454 012767 000100 011124      MOV      #100,ICOUNT      ;SET UP FOR 100 ITERATIONS
002462 012767 002622 011112      MOV      #41,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
                                ;IF NB      <>
                                MOV      #.FREEZ1      ;SET UP TO LOOP WITH DATA
                                .ENDC
                                XN=XN+1
002470 012777 004000 011042      MOV      #BIT11,0DHSCR      ;MASTER CLEAR INTERFACE
002476 004767 010676      14:  JSR      PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
                                ;BUS ADDRESS REGISTERS
002502 012777 000005 011030      MOV      #5,0DHSCR      ;SELECT LINE 5
002510 012777 177777 011032      MOV      #-1,0DHBC      ;SET BYTE COUNT TO 1
002516 012777 014322 011022      MOV      #TWRD5,0DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
002524 012700 000100      MOV      #100,R0      ;SET UP TO RECEIVE 64 CHARACTERS
002530 005001      CLR      R1      ;COUNT OF CHARACTERS RECEIVED
002532 012777 133503 011004      MOV      #133503,0DHLPR      ;SET UP SPEED FOR 9600 BAUD

```

```

002540 012777 000040 011004      MOV    #40,8DH5AR
002546 105777 010766      2$:  TSTB   8DH5CR
002552 100375              BPL     2$
002554 005201              INC     R1
002556 017704 010760      MOV    8DH5RC,R4
002562 020467 011534      CMP     R4,TWRD5
002566 001406              BEQ     3$
002570 016705 011526      MOV    TWRD5,R5
002574 005077 010744      CLR     8DH5LPR
002600              HLT     0
002600 104000              EMT     0
002602 000407              BR      4$
002604 005300      3$:  DEC     R0
002606 003357              BGT     2$
002610 100404              BMI     4$
002612 042777 100000 010724      BIC     #100000,8DH5LPR
002620 000752              BR      2$
002622 104400      4$:  SCOPE
000006      LINE=LINE+1
000100      BITX=BITX+BITX
000006      KX=KX+1
002624      AUTO1  \LINE,\BITX,\KX

;ENABLE AUTO ECHO ON LINE 6
;TRANSMIT ONE CHARACTER ON LINE 6
;AT 9600 BAUD, 8 BITS.
;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

002624      TS \XN,100,4$
002624 012767 000340 175144      T7:  MOV    #340,PS
002632 012767 000100 010746      MOV    #100,ICOUNT
002640 012767 003000 010734      MOV    #4$,C$CAPE
;IF NB <>
;MOV    #,FREEZ1
;ENDC
;XN=XN+1
002646 012777 004000 010664      MOV    #BIT11,8DH5CR
002654 004767 010520      1$:  JSR     PC,CLRALL
;MASTER CLEAR INTERFACE
;CLEAR ALL BYTE COUNT AN
;BUS ADDRESS REGISTERS
002660 012777 000006 010652      MOV    #6,8DH5CR
002666 012777 177777 010654      MOV    #-1,8DH5C
002674 012777 014324 010644      MOV    #TWRD6,8DH5A
002702 012700 000100      MOV    #100,R0
002706 005001      CLR     R1
002710 012777 133503 010626      MOV    #133503,8DH5LPR
;SET UP SPEED FOR 9600 BAUD
;8 BITS PER CHARACTER,
;AUTO ECHO ENABLED ON LINE 6
;SET BAR BIT FOR LINE 6
;WAIT FOR CHARACTER TO
;BE RECEIVED
;UPDATE RECEIVED CHARACTER COUNT
;READ CHARACTER
;IS CHARACTER CORRECT

002716 012777 000100 010626      MOV    #100,8DH5AR
002724 105777 010610      2$:  TSTB   8DH5CR
002730 100375              BPL     2$
002732 005201              INC     R1
002734 017704 010602      MOV    8DH5RC,R4
002740 020467 011360      CMP     R4,TWRD6

```

```

002744 001406      BEQ      3#
002746 016705 011352  MOV     TWRD6,R5      ;(R5)=EXPECTED CHARACTER
002752 005077 010566  CLR     @DHLPR      ;SHUT OFF AUTO ECHO
002756      104000      HLT     0      ;CHARACTER ECHOED INCORRECTLY
002756      000407      EMT     0
002760      005300      BR      4#      ;RESTART TEST
002762      003357      3#: DEC     R0      ;IF 64 CHARACTERS HAVE NOT
002764      100404      BGT     2#      ;BEEN RECEIVED, CONTINUE
002766      042777 100000 010546  BMI     4#
002770      000752      BIC     @100000,@DHLPR      ;SHUT OFF AUTO-ECHO
002776      104400      BR      2#      ;GET 1 MORE CHARACTER
003000      000007      4#: SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000200      LINE=LINE+1
      000007      BITX=BITX+BITX
003002      000007      KX=KX+1
      AUTO1      \LINE,\BITX,\KX

      ;ENABLE AUTO ECHO ON LINE 7
      ;TRANSMIT ONE CHARACTER ON LINE 7
      ;AT 9600 BAUD, 8 BITS.
      ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
      ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
      ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

003002      TS \XN,100,4#
003002 012767 000340 174766 T10:  MOV     @340,PS      ;DISABLE ALL INTERRUPTS
003010 012767 000100 010570      MOV     @100,ICOUNT      ;SET UP FOR 100 ITERATIONS
003016 012767 003156 010556      MOV     @41,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB      <>
      MOV     @,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
003024 012777 004000 010506      MOV     @BIT11,@DHSCR      ;MASTER CLEAR INTERFACE
003032 004767 010342      1#: JSR     PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
      ;BUS ADDRESS REGISTERS
003036 012777 000007 010474      MOV     @7,@DHSCR      ;SELECT LINE 7
003044 012777 177777 010476      MOV     @-1,@DHBC      ;SET BYTE COUNT TO 1
003052 012777 014326 010466      MOV     @TWRD7,@DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
003060 012700 000100      MOV     @100,R0      ;SET UP TO RECEIVE 64 CHARACTERS
003064 005001      CLR     R1      ;COUNT OF CHARACTERS RECEIVED
003066 012777 133503 010450      MOV     @133503,@DHLPR      ;SET UP SPEED FOR 9600 BAUD
      ;8 BITS PER CHARACTER,
      ;AUTO ECHO ENABLED ON LINE 7
003074 012777 000200 010450      MOV     @200,@DHBAR      ;SET BAR BIT FOR LINE 7
003102 105777 010432      2#: TSTB   @DHSCR      ;WAIT FOR CHARACTER TO
003106 100375      BPL     2#      ;BE RECEIVED
003110 005201      INC     R1      ;UPDATE RECEIVED CHARACTER COUNT
003112 017704 010424      MOV     @DHNR,R4      ;READ CHARACTER
003116 020467 011204      CMP     R4,TWRD7      ;IS CHARACTER CORRECT
003122 001406      BEQ     3#
003124 016705 011176      MOV     TWRD7,R5      ;(R5)=EXPECTED CHARACTER
003130 005077 010410      CLR     @DHLPR      ;SHUT OFF AUTO ECHO
003134      HLT     0      ;CHARACTER ECHOED INCORRECTLY
003134      104000      EMT     0
003136      000407      BR      4#      ;RESTART TEST
003140      005300      3#: DEC     R0      ;IF 64 CHARACTERS HAVE NOT
003142      003357      BGT     2#      ;BEEN RECEIVED, CONTINUE

```

```

003144 100404      BMI      4#
003146 042777 100000 010370      BIC      @100000, @DHLPR      ;SHUT OFF AUTO-ECHO
003154 000752      BR      2#      ;GET 1 MORE CHARACTER
003156 104400      4#: SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000010      LINE=LINE+1
      000400      BITX=BITX+BITX
      000010      KX=KX+1
003160      AUTO1  \LINE, \BITX, \KX

      ;ENABLE AUTO ECHO ON LINE 10
      ;TRANSMIT ONE CHARACTER ON LINE 10
      ;AT 9600 BAUD, 8 BITS.
      ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
      ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
      ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

003160      TS \XN, 100, 4#
003160 012767 000340 174610      T11: MOV      @340, PS      ;DISABLE ALL INTERRUPTS
003166 012767 000100 010412      MOV      @100, ICOUNT      ;SET UP FOR 100 ITERATIONS
003174 012767 003334 010400      MOV      @4#, ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB      <>
      MOV      @, FREEZ1      ;SET UP TO LOOP WITH DATA      , 3
      .ENDC
      XN=XN+1
003202 012777 004000 010330      MOV      @BIT11, @DHSCR      ;MASTER CLEAR INTERFACE
003210 004767 010164      1#: JSR      PC, CLRALL      ;CLEAR ALL BYTE COUNT AND
      ;BUS ADDRESS REGISTERS
003214 012777 000010 010316      MOV      @10, @DHSCR      ;SELECT LINE 10
003222 012777 177777 010320      MOV      @-1, @DHBC      ;SET BYTE COUNT TO 1
003230 012777 014330 010310      MOV      @THRD10, @DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
003236 012700 000100      MOV      @100, R0      ;SET UP TO RECEIVE 64 CHARACTERS
003242 005001      CLR      R1      ;COUNT OF CHARACTERS RECEIVED
003244 012777 133503 010272      MOV      @133503, @DHLPR      ;SET UP SPEED FOR 9600 BAUD
      ;8 BITS PER CHARACTER.
      ;AUTO ECHO ENABLED ON LINE 10
      ;SET @AR BIT FOR LINE 10
      ;WAIT FOR CHARACTER TO
      ;BE RECEIVED
      ;UPDATE RECEIVED CHARACTER COUNT
      ;READ CHARACTER
      ;IS CHARACTER CORRECT
003252 012777 000400 010272      MOV      @400, @DHBA      ;(R5)=EXPECTED CHARACTER
003260 105777 010254      2#: TSTB      @DHSCR      ;SHUT OFF AUTO ECHO
003264 100375      BPL      2#      ;CHARACTER ECHOED INCORRECTLY
003266 005201      INC      R1
003270 017704 010246      MOV      @DHNR, R4
003274 020467 011030      CMP      R4, THRD10
003300 001406      BEQ      3#
003302 016705 011022      MOV      THRD10, R5
003306 005077 010232      CLR      @DHLPR
003312      HLT      0
003312 104000      EMT      0
003314 000407      BR      4#
003316 005300      3#: DEC      R0
003320 003357      BGT      2#
003322 100404      BMI      4#
003324 042777 100000 010212      BIC      @100000, @DHLPR
003332 000752      BR      2#
003334 104400      4#: SCOPE
      000011      LINE=LINE+1
      001000      BITX=BITX+BITX
      000011      KX=KX+1
003336      AUTO1  \LINE, \BITX, \KX

```



```

;ENABLE AUTO ECHO ON LINE 11
;TRANSMIT ONE CHARACTER ON LINE 11
;AT 9600 BAUD, 8 BITS.
;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

```

003336				TS \XN,100,4#		
003336	012767	000340	174432	T12:	MOV	#340,PS
003344	012767	000100	010234		MOV	#100,ICOUNT
003352	012767	003512	010222		MOV	#44,ESCAPE
				.IF NB	<>	
					MOV	#,FREEZ1
				.ENDC		
	000013			XN=XN+1		
003360	012777	004000	010152		MOV	#BIT11,8DHSCR
003366	004767	010006		1#:	JSR	PC,CLRALL
003372	012777	000011	010140		MOV	#11,8DHSCR
003400	012777	177777	010142		MOV	#-1,8DHBC
003406	012777	014332	010132		MOV	#TWRD11,8DHBA
003414	012700	000100			MOV	#100,R0
003420	005001				CLR	R1
003422	012777	133503	010114		MOV	#133503,8DHLPR
003430	012777	001000	010114		MOV	#1000,8DHBAR
003436	105777	010076		2#:	TSTB	8DHSCR
003442	100375				BPL	2#
003444	005201				INC	R1
003446	017704	010070			MOV	8DHNR, R4
003452	020467	010654			CMF	R4, TWRD11
003456	001406				BEQ	3#
003460	016705	010646			MOV	TWRD11, R5
003464	005077	010054			CLR	8DHLPR
003470					HLT	0
003470	104000				ENT	0
003472	000407				BR	4#
003474	005300			3#:	DEC	R0
003476	003357				BGT	2#
003500	100404				BMI	4#
003502	042777	100000	010034		BIC	#100000,8DHLPR
003510	000752				BR	2#
003512	104400			4#:	SCOPE	
	000012			LINE=LINE+1		
	002000			BITX=BITX+BITX		
	000012			KX=KX+1		
003514				AUTO1	\LINE, \BITX, \KX	

```

;DISABLE ALL INTERRUPTS
;SET UP FOR 100 ITERATIONS
;SET UP TO ESCAPE TO NEXT TEST
;SET UP TO LOOP WITH DATA ; 3

```

```

;MASTER CLEAR INTERFACE
;CLEAR ALL BYTE COUNT AN
;BUS ADDRESS REGISTERS
;SELECT LINE 11
;SET BYTE COUNT TO 1
;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
;SET UP TO RECEIVE 64 CHARACTERS
;COUNT OF CHARACTERS RECEIVED
;SET UP SPEED FOR 9600 BAUD
;8 BITS PER CHARACTER
;AUTO ECHO ENABLED ON LINE 11
;SET BAR BIT FOR LINE 11
;WAIT FOR CHARACTER TO
;BE RECEIVED
;UPDATE RECEIVED CHARACTER COUNT
;READ CHARACTER
;IS CHARACTER CORRECT
;(R5)=EXPECTED CHARACTER
;SHUT OFF AUTO ECHO
;CHARACTER ECHOED INCORRECTLY
;RESTART TEST
;IF 64 CHARACTERS HAVE NOT
;BEEN RECEIVED, CONTINUE
;SHUT OFF AUTO-ECHO
;GET 1 MORE CHARACTER
;CHECK FOR ITERATIONS, LOOP

```

```

;ENABLE AUTO ECHO ON LINE 12
;TRANSMIT ONE CHARACTER ON LINE 12
;AT 9600 BAUD, 8 BITS.
;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

```

```

003514      TS \XN,100,4#
003514 012767 000340 174254 T13:  MOV  #340,PS          ;DISABLE ALL INTERRUPTS
003522 012767 000100 010056      MOV  #100,ICOUNT      ;SET UP FOR 100 ITERATIONS
003530 012767 003670 010044      MOV  #4#,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
                        .IF NB  <>
                        MOV  #,FREEZ1          ;SET UP TO LOOP WITH DATA          ; 3
                        .ENDC
                        XN=XN+1
003536 012777 004000 007774      MOV  #BIT11,@DHSCR      ;MASTER CLEAR INTERFACE
003544 004767 007630 1# :      JSR  PC,CLRALL          ;CLEAR ALL BYTE COUNT AN
                        ;BUS ADDRESS REGISTERS
003550 012777 000012 007762      MOV  #12,@DHSCR      ;SELECT LINE 12
003556 012777 177777 007764      MOV  #-1,@DHBC      ;SET BYTE COUNT TO 1
003564 012777 014334 007754      MOV  #TWRD12,@DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
003572 012700 000100      MOV  #100,R0          ;SET UP TO RECEIVE 64 CHARACTERS
003576 005001      CLR  R1          ;COUNT OF CHARACTERS RECEIVED
003600 012777 133503 007736      MOV  #133503,@DHLPR      ;SET UP SPEED FOR 9600 BAUD
                        ;8 BITS PER CHARACTER,
                        ;AUTO ECHO ENABLED ON LINE 12
003606 012777 002000 007736      MOV  #2000,@DHBAR      ;SET BAR BIT FOR LINE 12
003614 105777 007720 2# :      TSTB  @DHSCR          ;WAIT FOR CHARACTER TO
003620 100375      BPL  2#          ;BE RECEIVED
003622 005201      INC  R1          ;UPDATE RECEIVED CHARACTER COUNT
003624 017704 007712      MOV  @DHNR,R4          ;READ CHARACTER
003630 020467 010500      CMP  R4,TWRD12          ;IS CHARACTER CORRECT
003634 001406      BEQ  3#          ;
003636 016705 010472      MOV  TWRD12,R5          ;(R5)=EXPECTED CHARACTER
003642 005077 007676      CLR  @DHLPR          ;SHUT OFF AUTO ECHO
003646      HLT  0          ;CHARACTER ECHOED INCORRECTLY
003646 104000      EMT  0
003650 000407      BR  4#          ;RESTART TEST
003652 005300 3# :      DEC  R0          ;IF 64 CHARACTERS HAVE NOT
003654 003357      BGT  2#          ;BEEN RECEIVED, CONTINUE
003656 100404      BMI  4#          ;
003660 042777 100000 007656      BIC  #100000,@DHLPR      ;SHUT OFF AUTO-ECHO
003666 000752      BR  2#          ;GET 1 MORE CHARACTER
003670 104400 4# :      SCOPE          ;CHECK FOR ITERATIONS, LOOP
000013      LINE=LINE+1
004000      BITX=BITX+BITX
000013      KX=KX+1
003672      AUTO1  \LINE,\BITX,\KX

                        ;ENABLE AUTO ECHO ON LINE 13
                        ;TRANSMIT ONE CHARACTER ON LINE 13
                        ;AT 9600 BAUD, 8 BITS.
                        ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
                        ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
                        ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

003672      TS \XN,100,4#
003672 012767 000340 174076 T14:  MOV  #340,PS          ;DISABLE ALL INTERRUPTS
003700 012767 000100 007700      MOV  #100,ICOUNT      ;SET UP FOR 100 ITERATIONS
003706 012767 004046 007666      MOV  #4#,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
                        .IF NB  <>
                        MOV  #,FREEZ1          ;SET UP TO LOOP WITH DATA          ; 3
                        .ENDC
000015      XN=XN+1

```

```

003714 012777 004000 007616      MOV    #BIT11, @DHSCR      ;MASTER CLEAR INTERFACE
003722 004767 007452      JSR      PC, CLRALL      ;CLEAR ALL BYTE COUNT AN
                                           ;BUS ADDRESS REGISTERS
003726 012777 000013 007604      MOV    #13, @DHSCR      ;SELECT LINE 13
003734 012777 177777 007606      MOV    #-1, @DHBC      ;SET BYTE COUNT TO 1
003742 012777 014336 007576      MOV    @TWRD13, @DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
003750 012700 000100      MOV    #100, R0      ;SET UP TO RECEIVE 64 CHARACTERS
003754 005001      CLR      R1      ;COUNT OF CHARACTERS RECEIVED
003756 012777 133503 007560      MOV    #133503, @DHLP      ;SET UP SPEED FOR 9600 BAUD
                                           ;8 BITS PER CHARACTER,
                                           ;AUTO ECHO ENABLED ON LINE 13
003764 012777 004000 007560      MOV    #4000, @DHBAR      ;SET BAR BIT FOR LINE 13
003772 105777 007542      2$:    TSTB    @DHSCR      ;WAIT FOR CHARACTER TO
003776 100375      BPL      2$      ;BE RECEIVED
004000 005201      INC      R1      ;UPDATE RECEIVED CHARACTER COUNT
004002 017704 007534      MOV    @CHNRC, R4      ;READ CHARACTER
004006 020467 010324      CMP      R4, TWRD13      ;IS CHARACTER CORRECT
004012 001406      BEQ      3$
004014 016705 010316      MOV    TWRD13, R5      ;(R5)=EXPECTED CHARACTER
004020 005077 007520      CLR      @DHLP      ;SHUT OFF AUTO ECHO
004024      HLT      0      ;CHARACTER ECHOED INCORRECTLY
004024 104000      EMT      0
004026 000407      BR      4$
004030 005300      3$:    DEC      R0      ;RESTART TEST
004032 003357      BGT      2$      ;IF 64 CHARACTERS HAVE NOT
004034 100404      BMI      4$      ;BEEN RECEIVED, CONTINUE
004036 042777 100000 007500      BIC    #100000, @DHLP      ;SHUT OFF AUTO-ECHO
004044 000752      BR      2$      ;GET 1 MORE CHARACTER
004046 104400      4$:    SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000014      LINE=LINE+1
      010000      BITX=BITX+BITX
      000014      KX=KX+1
004050      AUTO1    \LINE, \BITX, \KX

      ;ENABLE AUTO ECHO ON LINE 14
      ;TRANSMIT ONE CHARACTER ON LINE 14
      ;AT 9600 BAUD, 8 BITS.
      ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
      ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
      ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

004050      TS \XN, 100, 4$
004050 012767 000340 173720      T15:    MOV    #340, PS      ;DISABLE ALL INTERRUPTS
004056 012767 000100 007522      MOV    #100, ICOUNT      ;SET UP FOR 100 ITERATIONS
004064 012767 004224 007510      MOV    #4$, ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB      <>
      MOV    #, FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
004072 012777 004000 007440      MOV    #BIT11, @DHSCR      ;MASTER CLEAR INTERFACE
004100 004767 007274      1$:    JSR      PC, CLRALL      ;CLEAR ALL BYTE COUNT AN
                                           ;BUS ADDRESS REGISTERS
004104 012777 000014 007426      MOV    #14, @DHSCR      ;SELECT LINE 14
004112 012777 177777 007430      MOV    #-1, @DHBC      ;SET BYTE COUNT TO 1
004120 012777 014340 007420      MOV    @TWRD14, @DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
004126 012700 000100      MOV    #100, R0      ;SET UP TO RECEIVE 64 CHARACTERS
004132 005001      CLR      R1      ;COUNT OF CHARACTERS RECEIVED

```

```

004134 012777 133503 007402      MOV      #133503, @DHLPR      ;SET UP SPEED FOR 9600 BAUD
                                           ;8 BITS PER CHARACTER,
                                           ;AUTO ECHO ENABLED ON LINE 14
004142 012777 010000 007402      MOV      #10000, @DHBAR      ;SET BAR BIT FOR LINE 14
001150 105777 007364              2$:  TSTB      @DHSCR      ;WAIT FOR CHARACTER TO
004154 100375                      BPL        2$           ;BE RECEIVED
004156 005201                      INC        R1           ;UPDATE RECEIVED CHARACTER COUNT
004160 017704 007356              MOV      @DHNR, R4        ;READ CHARACTER
004164 020467 010150              CMP      R4, TWRD14       ;IS CHARACTER CORRECT
004170 001406                      BEQ        3$           ;
004172 016705 010142              MOV      TWRD14, R5       ;(R5)=EXPECTED CHARACTER
004176 005077 007342              CLR      @DHLPR        ;SHUT OFF AUTO ECHO
004202                      HLT        0                 ;CHARACTER ECHOED INCORRECTLY
004202 104000                      EMT        0
004204 000407                      BR        4$           ;RESTART TEST
004206 005300              3$:  DEC        R0           ;IF 64 CHARACTERS HAVE NOT
004210 003357                      BGT        2$           ;BEEN RECEIVED, CONTINUE
004212 100404                      BMI        4$           ;
004214 042777 100000 007322      BIC      #100000, @DHLPR    ;SHUT OFF AUTO-ECHO
004222 000752                      BR        2$           ;GET 1 MORE CHARACTER
004224 104400              4$:  SCOPE                     ;CHECK FOR ITERATIONS, LOOP
      000015      LINE=LINE+1
      020000      BITX=BITX+BITX
      000015      KX=KX+1
004226      AUTO1  \LINE, \BITX, \KX

      ;ENABLE AUTO ECHO ON LINE 15
      ;TRANSMIT ONE CHARACTER ON LINE 15
      ;AT 9600 BAUD, 8 BITS.
      ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
      ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
      ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

004226      TS \XP, 100, 4$
004226 012767 000340 173542      T16:  MOV      #340, PS      ;DISABLE ALL INTERRUPTS
004234 012767 000100 007344      MOV      #100, ICOUNT    ;SET UP FOR 100 ITERATIONS
004242 012767 004402 007332      MOV      #4$, ESCAPE    ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB <>
      MOV      #, FREEZ1
      .ENDC
      XN=XN+1
      ;SET UP TO LOOP WITH DATA      ; 3

004250 012777 004000 007262      MOV      @BIT11, @DHSCR    ;MASTER CLEAR INTERFACE
004256 004767 007116              1$:  JSR      PC, CLRALL    ;CLEAR ALL BYTE COUNT AN
                                           ;BUS ADDRESS REGISTERS
004262 012777 000015 007250      MOV      #15, @DHSCR    ;SELECT LINE 15
004270 012777 177777 007252      MOV      #-1, @DHBC     ;SET BYTE COUNT TO 1
004276 012777 014342 007242      MOV      @TWRD15, @DHBA    ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
004304 012700 000100              MOV      #100, R0        ;SET UP TO RECEIVE 64 CHARACTERS
004310 005001                      CLR      R1           ;COUNT OF CHARACTERS RECEIVED
004312 012777 133503 007224      MOV      #133503, @DHLPR    ;SET UP SPEED FOR 9600 BAUD
                                           ;8 BITS PER CHARACTER,
                                           ;AUTO ECHO ENABLED ON LINE 15
004320 012777 020000 007224      MOV      #20000, @DHBAR    ;SET BAR BIT FOR LINE 15
004326 105777 007206              2$:  TSTB      @DHSCR      ;WAIT FOR CHARACTER TO
004332 100375                      BPL        2$           ;BE RECEIVED
004334 005201                      INC        R1           ;UPDATE RECEIVED CHARACTER COUNT
004336 017704 007200              MOV      @DHNR, R4        ;READ CHARACTER

```

```

004342 020467 007774      CMP      R4,TWRD15      ;IS CHARACTER CORRECT
004346 001406              BEQ      3$
004350 016705 007766      MOV      TWRD15,R5      ;(R5)=EXPECTED CHARACTER
004354 005077 007164      CLR      @DHLPR      ;SHUT OFF AUTO ECHO
004360              HLT      0      ;CHARACTER ECHOED INCORRECTLY
004360 104000              EMT      0
004362 000407              BR      4$
004364 005300      3$:      DEC      R0      ;RESTART TEST
004366 003357              BGT      2$      ;IF 64 CHARACTERS HAVE NOT
004370 100404              BMI      4$      ;BEEN RECEIVED, CONTINUE
004372 042777 100000 007144      BIC      @100000,@DHLPR      ;SHUT OFF AUTO-ECHO
004400 003752              BR      2$      ;GET 1 MORE CHARACTER
004402 104400      4$:      SCOPE      ;CHECK FOR ITERATIONS, LOOP
              LINE=LINE+1
              BITX=BITX+BITX
              KX=KX+1
004404      AUTO1      \LINE,\BITX,\KX

              ;ENABLE AUTO ECHO ON LINE 16
              ;TRANSMIT ONE CHARACTER ON LINE 16
              ;AT 9600 BAUD, 8 BITS.
              ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
              ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
              ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

004404      TS      \XN,100,4$
004404 012767 000340 173364      T17:      MOV      @340,PS      ;DISABLE ALL INTERRUPTS
004412 012767 000100 007166      MOV      @100,ICOUNT      ;SET UP FOR 100 ITERATIONS
004420 012767 004560 007154      MOV      @4$,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
              .IF NB      <>
              MOV      @,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
              .ENDC
              XN=XN+1
004426 012777 004000 007104      MOV      @BIT11,@DHSCR      ;MASTER CLEAR INTERFACE
004434 004767 006740      1$:      JSR      PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
              ;BUS ADDRESS REGISTERS
004440 012777 000016 007072      MOV      @16,@DHSCR      ;SELECT LINE 16
004446 012777 177777 007074      MOV      @-1,@DHBC      ;SET BYTE COUNT TO 1
004454 012777 014344 007064      MOV      @TWRD16,@DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
004462 012700 000100      MOV      @100,R0      ;SET UP TO RECEIVE 64 CHARACTERS
004466 005001      CLR      R1      ;COUNT OF CHARACTERS RECEIVED
004470 012777 133503 007046      MOV      @133503,@DHLPR      ;SET UP SPEED FOR 9600 BAUD
              ;8 BITS PER CHARACTER,
              ;AUTO ECHO ENABLED ON LINE 16
004476 012777 040000 007046      MOV      @40000,@DHBAR      ;SET BAR BIT FOR LINE 16
004504 105777 007030      2$:      TSTB      @DHSCR      ;WAIT FOR CHARACTER TO
004510 100375              BPL      2$      ;BE RECEIVED
004512 005201              INC      R1      ;UPDATE RECEIVED CHARACTER COUNT
004514 017704 007022      MOV      @DHNR,R4      ;READ CHARACTER
004520 020467 007620      CMP      R4,TWRD16      ;IS CHARACTER CORRECT
004524 001406              BEQ      3$
004526 016705 007612      MOV      TWRD16,R5      ;(R5)=EXPECTED CHARACTER
004532 005077 007006      CLR      @DHLPR      ;SHUT OFF AUTO ECHO
004536              HLT      0      ;CHARACTER ECHOED INCORRECTLY
004536 104000              EMT      0
004540 000407              BR      4$
004542 005300      3$:      DEC      R0      ;RESTART TEST
              ;IF 64 CHARACTERS HAVE NOT

```

```

004544 003357          BGT      2#          ;BEEN RECEIVED, CONTINUE
004546 100404          BMI      4#
004550 042777 100000 006766      BIC      @100000,@DHLPR      ;SHUT OFF AUTO-ECHO
004556 000752          BR       2#          ;GET 1 MORE CHARACTER
004560 104400          4#:      SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000017          LINE=LINE+1
      100000          BITX=BITX+BITX
      000017          KX=KX+1
004562          AUTO1      \LINE,\BITX,\KX

      ;ENABLE AUTO ECHO ON LINE 17
      ;TRANSMIT ONE CHARACTER ON LINE 17
      ;AT 9600 BAUD, 8 BITS.
      ;RECEIVE AND VERIFY CHARACTERS UNTIL 64 HAVE BEEN RECEIVED.
      ;AFTER 64 CHARACTERS HAVE BEEN RECEIVED, DISABLE AUTO ECHO.
      ;EXACTLY ONE MORE CHARACTER SHOULD BE RECEIVED.

004562          TS \XN,100,4#
004562 012767 000340 173206      T20:      MOV      @340,PS          ;DISABLE ALL INTERRUPTS
004570 012767 000100 007010          MOV      @100,ICOUNT      ;SET UP FOR 100 ITERATIONS
004576 012767 004736 006776          MOV      @4#,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB      <>
      MOV      @,FREEZ1          ;SET UP TO LOOP WITH DATA          ; 3
      .ENDC
      XN=XN+1
004604 012777 004000 006726          MOV      @BIT11,@DHSCR      ;MASTER CLEAR INTERFACE
004612 004767 006562          1#:      JSR      PC,CLRALL      ;CLEAR ALL BYTE COUNT AN
      ;BUS ADDRESS REGISTERS
004616 012777 000017 006714          MOV      @17,@DHSCR      ;SELECT LINE 17
004624 012777 177777 006716          MOV      @-1,@DHBC      ;SET BYTE COUNT TO 1
004632 012777 014346 006706          MOV      @TWRD17,@DHBA      ;SET UP ADDRESS OF CHARACTER TO BE TRANSMITTED
004640 012700 000100          MOV      @100,R0      ;SET UP TO RECEIVE 64 CHARACTERS
004644 005001          CLR      R1      ;COUNT OF CHARACTERS RECEIVED
004646 012777 133503 006670          MOV      @133503,@DHLPR      ;SET UP SPEED FOR 9600 BAUD
      ;8 BITS PER CHARACTER,
      ;AUTO ECHO ENABLED ON LINE 17
004654 012777 100000 006670          MOV      @100000,@DHBAR      ;SET BAR BIT FOR LINE 17
004662 105777 006652          2#:      TSTB      @DHSCR      ;WAIT FOR CHARACTER TO
004666 100375          BPL      2#          ;BE RECEIVED
004670 005201          INC      R1      ;UPDATE RECEIVED CHARACTER COUNT
004672 017704 006644          MOV      @DHNR,R4      ;READ CHARACTER
004676 020467 007444          CMP      R4,TWRD17      ;IS CHARACTER CORRECT
004702 001406          BEQ      3#
004704 016705 007436          MOV      TWRD17,R5      ;(R5)=EXPECTED CHARACTER
004710 005077 006630          CLR      @DHLPR      ;SHUT OFF AUTO ECHO
004714          HLT      0      ;CHARACTER ECHOED INCORRECTLY
004714 104000          EMT      0
004716 000407          BR       4#
004720 005300          3#:      DEC      R0      ;RESTART TEST
004722 003357          BGT      2#          ;IF 64 CHARACTERS HAVE NOT
004724 100404          BMI      4#          ;BEEN RECEIVED, CONTINUE
004726 042777 100000 006610      BIC      @100000,@DHLPR      ;SHUT OFF AUTO-ECHO
004734 000752          BR       2#          ;GET 1 MORE CHARACTER
004736 104400          4#:      SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000020          LINE=LINE+1
      000000          BITX=BITX+BITX
      000020          KX=KX+1

```

```

18      000020      XLINE=LINE
19      000000      XBIT=BITX
20      000020      K=KX
21      000000      LINE=0
22      000001      BITX=1
23      000000      KX=0
25      000020      .REPT 20
26      AUTO2      \LINE,\BITX,\KX
27      .NLIST
28      LINE=LINE+1
29      BITX=BITX+BITX
30      KX=KX+1
31      .LIST
32      .ENDR
      004740      AUTO2      \LINE,\BITX,\KX

```

```

;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 0
;TRANSMIT 1 CHARACTER ON LINE 0 WITH AUTO ECHO ENABLED
;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
;CHARACTER LENGTH IS 8 BITS
;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

```

```

004740      000022      TS \XN,10,5
004740      012767      000340      173030      T21:      MOV      #340,PS      ;DISABLE ALL INTERRUPTS
004746      012767      000010      006632      MOV      #10,ICOUNT      ;SET UP FOR 10 ITERATIONS
004754      012767      005174      006620      MOV      #5,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB      <>
      MOV      #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
004762      012777      004000      006550      MOV      #BIT11,0DHSCR      ;MASTER CLEAR INTERFACE
004770      004767      006432      JSR      PC,SETALL      ;SET UP ALL LINES TO TRANSMIT
      ;400 (OCTAL) CHARACTERS
004774      012777      000000      006536      MOV      #0,0DHSCR      ;SELECT LINE 0 FOR TESTING
005002      012777      014310      006536      MOV      #TWRD0,0DHBA      ;CHARACTER TO BE TRANSMITTED
      ;ON LINE 0 IN AUTO ECHO MODE
005010      012777      177777      006532      MOV      #-1,0DHBC      ;TRANSMIT ONLY 1 CHARACTER ON LINE 0
005016      012777      133503      006520      MOV      #133503,0DHLPR      ;SET AUTO ECHO FOR LINE 0
005024      042767      000001      006610      BIC      #1,LINACT      ;CLEAR LINE ACTIVE BIT
005032      012777      177777      006512      MOV      #-1,0DHBA      ;SET BAR BITS FOR ALL LINES
005040      005000      CLR      R0      ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
005042      017704      006474      1$:      MOV      0DHNR,R4      ;GET A CHARACTER FROM SILO
005046      100375      BPL      1$      ;IF NOT VALID DATA, TRY AGAIN
005050      010403      MOV      R4,R3      ;EXTRACT LINE NUMBER FORM CHARACTER
005052      000303      SWAB      R3
005054      042703      177760      BIC      #177760,R3      ;CLEAR STATUS BITS
005060      010302      MOV      R3,R2
005062      006302      ASL      R2
005064      020327      000000      CMP      R3,#0      ;IF LINE NUMBER IS 0
005070      001432      BEQ      4$      ;CHECK FOR CORRECT ECHOED CHARACTER
005072      026204      014246      CMP      RBUF(R2),R4      ;IF NOT LINE 0, CHECK DATA
005076      001404      BEQ      2$
005100      016205      014246      MOV      RBUF(R2),R5      ;(R5)=EXPECTED NON ECHOED DATA
005104      104001      HLT      1      ;NON ECHOED DATA ERROR
005106      000423      EMT      1
005110      105262      014246      2$:      BR      4$
      INCB      RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA

```

```

005114 001352      BNE      1#      ;CONTINUE IF NOT DONE
005116 046267 014450 006516      BIC      LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
005124 005767 006512      TST      LINACT      ;IF ALL LINES ARE DONE
005130 001344      BNE      1#      ;EXIT
005132 012777 000000 006400      MOV      #0,0DHSCR      ;SELECT LINE 0
005140 042777 100000 006376      BIC      #100000,0DHLPR      ;CLEAR AUTO ECHO FOR LINE 0
005146 105777 006406      TSTB     0DHSLR      ;GET REST OF CHARACTERS
005152 001333      BNE      1#      ;AND CHECK
005154 000407      BR       5#
005156 005200      4# :      INC      R0      ;UPDATE ECHOED CHARACTER COUNT
005160 020467 007124      CMP      R4,TWRD0      ;CHECK ECHOED DATA
005164 001757      BEQ      3#
005166 016705 007116      MOV      TWRD0,R5      ;(R5)=EXPECTED ECHOED DATA
005172      HLT      2      ;ECHOED DATA ERROR
005172 104002      EMT      2
005174 104400      5# :      SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000001      LINE=LINE+1
      000002      BITX=BITX+BITX
      000001      KX=KX+1
005176      AUT02     \LINE,\BITX,\KX

      ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 1
      ;TRANSMIT 1 CHARACTER ON LINE 1 WITH AUTO ECHO ENABLED
      ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
      ;CHARACTER LENGTH IS 8 BITS
      ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

005176      TS \XN,10,5#
005176 012767 000340 172572 T22:  MOV      #340,PS      ;DISABLE ALL INTERRUPTS
005204 012767 000010 006374      MOV      #10,ICOUNT      ;SET UP FOR 10 ITERATIONS
005212 012767 005432 006362      MOV      #5#,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB      <>
      MOV      #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
005220 012777 004000 006312      MOV      #BIT11,0DHSCR      ;MASTER CLEAR INTERFACE
005226 004767 006174      JSR      PC,SETALL      ;SET UP ALL LINES TO TRANSMIT
      ;400 (OCTAL) CHARACTERS
005232 012777 000001 006300      MOV      #1,0DHSCR      ;SELECT LINE 1 FOR TESTING
005240 012777 014312 006300      MOV      #TWRD1,0DHBA      ;CHARACTER TO BE TRANSMITTED
      ;ON LINE 1 IN AUTO ECHO MODE
005246 012777 177777 006274      MOV      #-1,0DHBC      ;TRANSMIT ONLY 1 CHARACTER ON LINE 1
005254 012777 133503 006262      MOV      #133503,0DHLPR      ;SET AUTO ECHO FOR LINE 1
005262 042767 000002 006352      BIC      #2,LINACT      ;CLEAR LINE ACTIVE BIT
005270 012777 177777 006254      MOV      #-1,0DHBAR      ;SET BAR BITS FOR ALL LINES
005276 005000      CLR      R0      ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
005300 017704 006236      1# :      MOV      0DHNR,R4      ;GET A CHARACTER FROM SILO
005304 106375      BPL      1#      ;IF NOT VALID DATA, TRY AGAIN
005306 010403      MOV      R4,R3      ;EXTRACT LINE NUMBER FORM CHARACTER
005310 000303      SWAB     R3
005312 042703 177760      BIC      #177760,R3      ;CLEAR STATUS BITS
005316 010302      MOV      R3,R2
005320 006302      ASL      R2
005322 020327 000001      CMP      R3,#1      ;IF LINE NUMBER IS 1
005326 001432      BEQ      4#      ;CHECK FOR CORRECT ECHOED CHARACTER
005330 026204 014246      CMP      RBUF(R2),R4      ;IF NOT LINE 1, CHECK DATA
005334 001404      BEQ      2#

```



```

005336 016205 014246      MOV      RBUF(R2),R5      ;(R5)=EXPECTED NON ECHOED DATA
005342      HLT      1      ;NON ECHOED DATA ERROR
005342 104001      EMT      1
005344 000423      BR      4$
005346 105262 014246      2$: INCB     RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
005352 001352      BNE     1$      ;CONTINUE IF NOT DONE
005354 046267 014450 006260 3$: BIC     LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
005362 005767 006254      TST     LINACT      ;IF ALL LINES ARE DONE
005366 001344      BNE     1$      ;EXIT
005370 012777 000001 006142  MOV     #1,BDHSCR      ;SELECT LINE 1
005376 042777 100000 006140  BIC     #100000,BDHLPR    ;CLEAR AUTO ECHO FOR LINE 1
005404 105777 006150      TSTB     BDHSLR      ;GET REST OF CHARACTERS
005410 001333      BNE     1$      ;AND CHECK
005412 000407      BR      5$
005414 005200      4$: INC      R0      ;UPDATE ECHOED CHARACTER COUNT
005416 020467 006670      CMP     R4,TWRD1    ;CHECK ECHOED DATA
005422 001757      BEQ     3$
005424 016705 006662      MOV     TWRD1,R5      ;(R5)=EXPECTED ECHOED DATA
005430      HLT      2      ;ECHOED DATA ERROR
005430 104002      EMT      2
005432 104400      5$: SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000002      LINE=LINE+1
      000004      BITX=BITX+BITX
      000002      KX=KX+1
005434      AUTO2   \LINE,\BITX,\KX

      ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 2
      ;TRANSMIT 1 CHARACTER ON LINE 2 WITH AUTO ECHO ENABLED
      ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
      ;CHARACTER LENGTH IS 8 BITS
      ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

005434      TS \XN,10,5$
005434 012767 000340 172334 T23: MOV     #340,PS      ;DISABLE ALL INTERRUPTS
005442 012767 000010 006136  MOV     #10,ICOUNT    ;SET UP FOR 10 ITERATIONS
005450 012767 005670 006124  MOV     #5$,ESCAPE    ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB <>
      MOV     #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
005456 012777 004000 006054  MOV     #BIT11,BDHSCR    ;MASTER CLEAR INTERFACE
005464 004767 005736      JSR     PC,SETALL    ;SET UP ALL LINES TO TRANSMIT
      ;400 (OCTAL) CHARACTERS
005470 012777 000002 006042  MOV     #2,BDHSCR      ;SELECT LINE 2 FOR TESTING
005476 012777 014314 006042  MOV     #TWRD2,BDHBA    ;CHARACTER TO BE TRANSMITTED
      ;ON LINE 2 IN AUTO ECHO MODE
005504 012777 177777 006036  MOV     #-1,BDHBC      ;TRANSMIT ONLY 1 CHARACTER ON LINE 2
005512 012777 133503 006024  MOV     #133503,BDHLPR  ;SET AUTO ECHO FOR LINE 2
005520 042767 000004 006114  BIC     #4,LINACT      ;CLEAR LINE ACTIVE BIT
005526 012777 177777 006016  MOV     #-1,BDHBA      ;SET BAR BITS FOR ALL LINES
005534 005000      CLR     R0      ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
005536 017704 006000      1$: MOV     #DHNR, R4    ;GET A CHARACTER FROM SILO
005542 100375      BPL     1$      ;IF NOT VALID DATA, TRY AGAIN
005544 010403      MOV     R4,R3      ;EXTRACT LINE NUMBER FORM CHARACTER
005546 000303      SHAB    R3
005550 042703 177760      BIC     #177760,R3    ;CLEAR STATUS BITS
005554 010302      MOV     R3,R2

```

```

005556 006302      ASL      R2
005560 020327 000002    CMP      R3,#2      ;IF LINE NUMBER IS 2
005564 001432      BEQ      4$      ;CHECK FOR CORRECT ECHOED CHARACTER
005566 026204 014246    CMP      RBUF(R2),R4    ;IF NOT LINE 2, CHECK DATA
005572 001404      BEQ      2$
005574 016205 014246    MOV      RBUF(R2),R5    ;(R5)=EXPECTED NON ECHOED DATA
005600      HLT      1      ;NON ECHOED DATA ERROR
005600 104001      EMT      1
005602 000423      BR      4$
005604 105262 011246    2$: INCB     RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
005610 001352      BNE      1$      ;CONTINUE IF NOT DONE
005612 046267 014450 006022 BIC      LINBIT(R2),LINACT    ;CLEAR ACTIVE BIT
005620 005767 006016    3$: TST      LINACT      ;IF ALL LINES ARE DONE
005624 001344      BNE      1$      ;EXIT
005626 012777 000002 005704 MOV      #2,0DHSCR      ;SELECT LINE 2
005634 042777 100000 005702 BIC      #100000,0DHLPR    ;CLEAR AUTO ECHO FOR LINE 2
005642 105777 005712    TSTB     0DHSLR      ;GET REST OF CHARACTERS
005646 001333      BNE      1$      ;AND CHECK
005650 000407      BR      5$
005652 005200    4$: INC      R0      ;UPD/TE ECHOED CHARACTER COUNT
005654 020467 006434    CMP      R4,TWRD2    ;CHECK ECHOED DATA
005660 001757      BEQ      3$
005662 016705 006426    MOV      TWRD2,R5    ;(R5)=EXPECTED ECHOED DATA
005666      HLT      2      ;ECHOED DATA ERROR
005666 104002      EMT      2
005670 104400    5$: SCOPE      ;CHECK FOR ITERATIONS, LOOP
      000003      LINE=LINE+1
      000010      BITX=BITX+BITX
      000003      KX=KX+1
005672      AUTO2     \LINE,\BITX,\KX

      ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 3
      ;TRANSMIT 1 CHARACTER ON LINE 3 WITH AUTO ECHO ENABLED
      ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
      ;CHARACTER LENGTH IS 8 BITS
      ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

005672      TS \XN,10,5$
005672 012767 000340 172076 T24: MOV      #340,PS      ;DISABLE ALL INTERRUPTS
005700 012767 000010 005700 MOV      #10,ICOUNT    ;SET UP FOR 10 ITERATIONS
005706 012767 006126 005666 MOV      #5$,ESCAPE    ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB <>
      MOV      #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
005714 012777 004000 005616 MOV      #BIT11,0DHSCR    ;MASTER CLEAR INTERFACE
005722 004767 005500      JSR      PC,SETALL    ;SET UP ALL LINES TO TRANSMIT
      ;400 (OCTAL) CHARACTERS
      ;SELECT LINE 3 FOR TESTING
005726 012777 000003 005604 MOV      #3,0DHSCR      ;CHARACTER TO BE TRANSMITTED
005734 012777 014316 005604 MOV      #TWRD3,0DHBA    ;ON LINE 3 IN AUTO ECHO MODE
      ;TRANSMIT ONLY 1 CHARACTER ON LINE 3
      ;SET AUTO ECHO FOR LINE 3
005742 012777 177777 005600 MOV      #-1,0DHBC      ;CLEAR LINE ACTIVE BIT
005750 012777 133503 005566 MOV      #133503,0DHLPR    ;SET BAR BITS FOR ALL LINES
005756 042767 000010 005656 BIC      #10,LINACT      ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
005764 012777 177777 005560 MOV      #-1,0DHBA      ;GET A CHARACTER FROM SILO
005772 005000      CLR      R0
005774 017704 005542    1$: MOV      0DHNRC,R4

```

```

006000 100375      BPL      1#                ;IF NOT VALID DATA, TRY AGAIN
006002 010403      MOV      R4,R3            ;EXTRACT LINE NUMBER FORM CHARACTER
006004 000303      SWAB     R3                ;CLEAR STATUS BITS
006006 042703 177760 BIC      #177760,R3
006012 010302      MOV      R3,R2
006014 006302      ASL      R2
006016 020327 000003 CMP      R3,#3          ;IF LINE NUMBER IS 3
006022 001432      BEQ      4#                ;CHECK FOR CORRECT ECHOED CHARACTER
006024 026204 014246 CMP      RBUF(R2),R4      ;IF NOT LINE 3, CHECK DATA
006030 001404      BEQ      2#
006032 016205 014246 MOV      RBUF(R2),R5      ;(R5)=EXPECTED NON ECHOED DATA
006036          HLT      1                    ;NON ECHOED DATA ERROR
006036 104001      EMT      1
006040 000423      ER      4#
006042 105262 014246 2# : INCB     RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
006046 001352      BNE      1#                ;CONTINUE IF NOT DONE
006050 046267 014450 005564 BIC      LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
006056 005767 005560 3# : TST      LINACT        ;IF ALL LINES ARE DONE
006062 001344      BNE      1#                ;EXIT
006064 012777 000003 005446 MOV      #3,BDHSCR      ;SELECT LINE 3
006072 042777 100000 005444 BIC      #100000,BDHLPB      ;CLEAR AUTO ECHO FOR LINE 3
006100 105777 005454      TSTB     BDHSLR      ;GET REST OF CHARACTERS
006104 001333      BNE      1#                ;AND CHECK
006106 000407      BR      5#
006110 005200      4# : INC      R0                ;UPDATE ECHOED CHARACTER COUNT
006112 020467 006200      CMP      R4,TWRD3      ;CHECK ECHOED DATA
006116 001757      BEQ      3#
006120 016705 006172      MOV      TWRD3,R5      ;(R5)=EXPECTED ECHOED DATA
006124          HLT      2                    ;ECHOED DATA ERROR
006124 104002      EMT      2
006126 104400      5# : SCOPE
          LINE=LINE+1
          BITX=BITX+BITX
          KX=KX+1
          AUT02 \LINE,\BITX,\KX
          ;CHECK FOR ITERATIONS. LOOP

          ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 4
          ;TRANSMIT 1 CHARACTER ON LINE 4 WITH AUTO ECHO ENABLED
          ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
          ;CHARACTER LENGTH IS 8 BITS
          ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

006130          TS \XN,10,5#
006130 012767 000340 171640 T25: MOV      #340,PS      ;DISABLE ALL INTERRUPTS
006136 012767 000010 005442      MOV      #10,ICOUNT    ;SET UP FOR 10 ITERATIONS
006144 012767 006364 005430      MOV      #5#,ESCAPE    ;SET UP TO ESCAPE TO NEXT TEST
          .IF NB <>
          MOV      #,FREEZ1      ;SET UP TO LOOP WITH DATA      : 3
          .ENDC
          XN=XN+1
006152 012777 004000 005360      MOV      #BIT11,BDHSCR  ;MASTER CLEAR INTERFACE
006160 004767 005242      JSR      PC,SETALL      ;SET UP ALL LINES TO TRANSMIT
          ;400 (OCTAL) CHARACTERS
006164 012777 000004 005346      MOV      #4,BDHSCR      ;SELECT LINE 4 FOR TESTING
006172 012777 014320 005346      MOV      #TWRD4,BDHBA    ;CHARACTER TO BE TRANSMITTED
          ;ON LINE 4 IN AUTO ECHO MODE
006200 012777 177777 005342      MOV      #-1,BDHBC      ;TRANSMIT ONLY 1 CHARACTER ON LINE 4

```

```

006206 012777 133503 005330      MOV      #133503,8DHLPR      ;SET AUTO ECHO FOR LINE 4
006214 042767 000020 005420      BIC      #20,LINACT      ;CLEAR LINE ACTIVE BIT
006222 012777 177777 005322      MOV      #-1,8DHBAR      ;SET BAR BITS FOR ALL LINES
006230 005000                      CLR      R0      ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
006232 017704 005304      1#:  MOV      8DHNRC,R4      ;GET A CHARACTER FROM SILO
006236 100375                      BPL      1#      ;IF NOT VALID DATA, TRY AGAIN
006240 010403                      MOV      R4,R3      ;EXTRACT LINE NUMBER FORM CHARACTER
006242 000303                      SWAB     R3
006244 042703 177760      BIC      #177760,R3      ;CLEAR STATUS BITS
006250 010302                      MOV      R3,R2
006252 006302                      ASL      R2
006254 020327 000004      CMP      R3,#4      ;IF LINE NUMBER IS 4
006260 001432                      BEQ      4#      ;CHECK FOR CORRECT ECHOED CHARACTER
006262 026204 014246      CMP      RBUF(R2),R4      ;IF NOT LINE 4, CHECK DATA
006266 001404                      BEQ      2#
006270 016205 014246      MOV      RBUF(R2),R5      ;(R5)=EXPECTED NON ECHOED DATA
006274                      HLT      1      ;NON ECHOED DATA ERROR
006274 104001                      EMT      1
006276 000423                      BR      4#
006300 105262 014246      2#:  INCB     RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
006304 001352                      BNE      1#      ;CONTINUE IF NOT DONE
006306 046267 014450 005326      BIC      LINBIT(R2),LINACT      ;CLEAR ACTIVE BIT
006314 005767 005322      3#:  TST      LINACT      ;IF ALL LINES ARE DONE
006320 001344                      BNE      1#      ;EXIT
006322 012777 000004 005210      MOV      #4,8DHSCR      ;SELECT LINE 4
006330 042777 100000 005206      BIC      #100000,8DHLPR      ;CLEAR AUTO ECHO FOR LINE 4
006336 105777 005216      TSTB     8DHSLR      ;GET REST OF CHARACTERS
006342 001333                      BNE      1#      ;AND CHECK
006344 000407                      BR      5#
006346 005200      4#:  INC      R0      ;UPDATE ECHOED CHARACTER COUNT
006350 020467 005744      CMP      R4,TWRD4      ;CHECK ECHOED DATA
006354 001757                      BEQ      3#
006356 016705 005736      MOV      TWRD4,R5      ;(R5)=EXPECTED ECHOED DATA
006362                      HLT      2      ;ECHOED DATA ERROR
006362 104002                      EMT      2
006364 104400      5#:  SCOPE      ;CHECK FOR ITERATIONS, LOOP
000005      LINE=LINE+1
000040      BITX=BITX+BITX
000005      KX=KX+1
006366      AUTO2  \LINE,\BITX,\KX

;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 5
;TRANSMIT 1 CHARACTER ON LINE 5 WITH AUTO ECHO ENABLED
;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
;CHARACTER LENGTH IS 8 BITS
;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

006366      TS \XN,10,5#
006366 012767 000340 171402      T26:  MOV      #340,PS      ;DISABLE ALL INTERRUPTS
006374 012767 000010 005204      MOV      #10,ICOUNT      ;SET UP FOR 10 ITERATIONS
006402 012767 006622 005172      MOV      #5#,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB <>
      MOV      #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
006410 000027
006416 012777 004000 005122      MOV      #BIT11,8DHSCR      ;MASTER CLEAR INTERFACE
006416 004767 005004      JSR      PC,SETALL      ;SET UP ALL LINES TO TRANSMIT

```

```

006422 012777 000005 005110      MOV    #5, @DHSCR
006430 012777 014322 005110      MOV    @TWRD5, @DHBA      ; CHARACTER TO BE TRANSMITTED
                                ; 400 (OCTAL) CHARACTERS
                                ; SELECT LINE 5 FOR TESTING
                                ; ON LINE 5 IN AUTO ECHO MODE
                                ; TRANSMIT ONLY 1 CHARACTER ON LINE 5
                                ; SET AUTO ECHO FOR LINE 5
006436 012777 177777 005104      MOV    #-1, @DHBC
006444 012777 133503 005072      MOV    #133503, @DHLPR
006452 042767 000040 005162      BIC    #40, LINACT      ; CLEAR LINE ACTIVE BIT
006460 012777 177777 005064      MOV    #-1, @DHBAR
006466 005000                    CLR    R0      ; SET BAR BITS FOR ALL LINES
006470 017704 005046      1$:      MOV    @DHNR, R4      ; KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
006474 100375                    BPL     1$      ; GET A CHARACTER FROM SILO
006476 010403                    MOV    R4, R3      ; IF NOT VALID DATA, TRY AGAIN
006500 000303                    SWAB   R3      ; EXTRACT LINE NUMBER FORM CHARACTER
006502 042703 177760      BIC    #177760, R3      ; CLEAR STATUS BITS
006506 010302                    MOV    R3, R2
006510 006302                    ASL    R2
006512 020327 000005      CMP     R3, #5      ; IF LINE NUMBER IS 5
006516 001432                    BEQ    4$      ; CHECK FOR CORRECT ECHOED CHARACTER
006520 026204 014246      CMP     RBUF(R2), R4      ; IF NOT LINE 5, CHECK DATA
006524 001404                    BEQ    2$
006526 016205 014246      MOV     RBUF(R2), R5      ; (R5)=EXPECTED NON ECHOED DATA
006532                    HLT     1      ; NON ECHOED DATA ERROR
006532 104001                    EMT     1
006534 000423                    BR     4$
006536 105262 014246      2$:      INCB   RBUF(R2)      ; UPDATE EXPECTED RECEIVED DATA
006542 001352                    BNE     1$      ; CONTINUE IF NOT DONE
006544 046267 014450 005070      BIC    LINBIT(R2), LINACT      ; CLEAR ACTIVE BIT
006552 005767 005064      3$:      TST    LINACT      ; IF ALL LINES ARE DONE
006556 001344                    BNE     1$      ; EXIT
006560 012777 000005 004752      MOV    #5, @DHSCR      ; SELECT LINE 5
006566 042777 100000 004750      BIC    #100000, @DHLPR      ; CLEAR AUTO ECHO FOR LINE 5
006574 105777 004760      TSTB   @DHSLR      ; GET REST OF CHARACTERS
006600 001333                    BNE     1$      ; AND CHECK
006602 000407                    BR     5$
006604 005200      4$:      INC     R0      ; UPDATE ECHOED CHARACTER COUNT
006606 020467 005510      CMP     R4, TWRD5      ; CHECK ECHOED DATA
006612 001757                    BEQ    3$
006614 016705 005502      MOV     TWRD5, R5      ; (R5)=EXPECTED ECHOED DATA
006620                    HLT     2      ; ECHOED DATA ERROR
006620 104002                    EMT     2
006622 104400      5$:      SCOPE
                                LINE=LINE+1
                                BITX=BITX+BITX
                                KX=KX+1
                                AUT02  \LINE, \BITX, \KX
                                ; CHECK FOR ITERATIONS, LOOP
006624                    ; TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 6
                                ; TRANSMIT 1 CHARACTER ON LINE 6 WITH AUTO ECHO ENABLED
                                ; TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
                                ; CHARACTER LENGTH IS 8 BITS
                                ; VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

006624 TS \XN, 10, 5$
006624 012767 000340 171144 T27:  MOV    #340, PS      ; DISABLE ALL INTERRUPTS
006632 012767 000010 004746      MOV    #10, ICOUNT      ; SET UP FOR 10 ITERATIONS
006640 012767 007060 004734      MOV    #5, ESCAPE      ; SET UP TO ESCAPE TO NEXT TEST
                                .IF NB <>

```

```

                                MOV     #,FREEZ1                ;SET UP TO LOOP WITH DATA      ; 3
                                .ENDC
                                XN=XN+1
006646 000030                   MOV     #BIT11, @DHSCR          ;MASTER CLEAR INTERFACE
006654 004767 004000 004664     JSR     PC,SETALL              ;SET UP ALL LINES TO TRANSMIT
                                                ;400 (OCTAL) CHARACTERS
006660 012777 000006 004652     MOV     #6, @DHSCR            ;SELECT LINE 6 FOR TESTING
006666 012777 014324 004652     MOV     @THRD6, @DHBA          ;CHARACTER TO BE TRANSMITTED
                                                ;ON LINE 6 IN AUTO ECHO MODE
006674 012777 177777 004646     MOV     #-1, @DHBC           ;TRANSMIT ONLY 1 CHARACTER ON LINE 6
006702 012777 133503 004634     MOV     #133503, @DHLPR          ;SET AUTO ECHO FOR LINE 6
006710 042767 000100 004724     BIC     #100, LINACT          ;CLEAR LINE ACTIVE BIT
006716 012777 177777 004626     MOV     #-1, @DHBA          ;SET BAR BITS FOR ALL LINES
006724 005000                   CLR     R0                    ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
006726 017704 004610 11:       MOV     @DHNR, R4              ;GET A CHARACTER FROM SILO
006732 100375                   BPL     11                     ;IF NOT VALID DATA, TRY AGAIN
006734 010403                   MOV     R4, R3                    ;EXTRACT LINE NUMBER FORM CHARACTER
006736 000303                   SWAB    R3
006740 042703 177760           BIC     #177760, R3
006744 010302                   MOV     R3, R2
006746 006302                   ASL     R2
006750 020327 000006           CMP     R3, #6                  ;IF LINE NUMBER IS 6
006754 001432                   BEQ     41                     ;CHECK FOR CORRECT ECHOED CHARACTER
006756 026204 014246           CMP     RBUF(R2), R4            ;IF NOT LINE 6, CHECK DATA
006762 001404                   BEQ     21
006764 016205 014246           MOV     RBUF(R2), R5              ; (R5)=EXPECTED NON ECHOED DATA
006770                   HLT     1                               ;NON ECHOED DATA ERROR
006770 104001                   EMT     1
006772 000423                   BR      41
006774 105262 014246 21:       INCB    RBUF(R2)                ;UPDATE EXPECTED RECEIVED DATA
007000 001352                   BNE     11                     ;CONTINUE IF NOT DONE
007002 046267 014450 004632     BIC     LINBIT(R2), LINACT      ;CLEAR ACTIVE BIT
007010 005767 004626 31:       TST     LINACT                    ;IF ALL LINES ARE DONE
007014 001344                   BNE     11                     ;EXIT
007016 012777 000006 004514     MOV     #6, @DHSCR            ;SELECT LINE 6
007024 042777 100000 004512     BIC     #100000, @DHLPR          ;CLEAR AUTO ECHO FOR LINE 6
007032 105777 004522           TSTB    @DHSLR
007036 001333                   BNE     11
007040 000407                   BR      51
007042 005200 41:       INC     R0                               ;UPDATE ECHOED CHARACTER COUNT
007044 020467 005254           CMP     R4, THRD6              ;CHECK ECHOED DATA
007050 001757                   BEQ     31
007052 016705 005246           MOV     THRD6, R5
007056                   HLT     2                               ; (R5)=EXPECTED ECHOED DATA
007056 104002                   EMT     2                               ;ECHOED DATA ERROR
007060 104400 51:       SCOPE                                     ;CHECK FOR ITERATIONS, LOOP
000007 LINE=LINE+1
000200 BITX=BITX+BITX
000007 KX=KX+1
007062 AUTO2 \LINE, \BITX, \KX

```

```

;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 7
;TRANSMIT 1 CHARACTER ON LINE 7 WITH AUTO ECHO ENABLED
;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
;CHARACTER LENGTH IS 8 BITS
;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

```

```

007062      000031      TS \XN,10
007062 012767 000340 170706 T30: MOV #340,PS ;DISABLE ALL INTERRUPTS
007070 012767 000010 004510 MOV #10,ICOUNT ;SET UP FOR 10 ITERATIONS
007076 012767 007316 004476 MOV #5,ESCAPE ;SET UP TO ESCAPE TO NEXT TEST
                .IF NB <>
                MOV #,FREEZ1 ;SET UP TO LOOP WITH DATA ; 3
                .ENDC
                XN=XN+1
007104 012777 004000 004426 MOV #BIT11,0DHSCR ;MASTER CLEAR INTERFACE
007112 004767 004310 JSR PC,SETALL ;SET UP ALL LINES TO TRANSMIT
                                ;400 (OCTAL) CHARACTERS
                                ;SELECT LINE 7 FOR TESTING
007116 012777 000007 004414 MOV #7,0DHSCR ;ON LINE 7 IN AUTO ECHO MODE
007124 012777 014326 004414 MOV #TWRD7,0DHBA ;CHARACTER TO BE TRANSMITTED
                                ;TRANSMIT ONLY 1 CHARACTER ON LINE 7
                                ;SET AUTO ECHO FOR LINE 7
007132 012777 177777 004410 MOV #-1,0DHBC ;CLEAR LINE ACTIVE BIT
007140 012777 133503 004376 MOV #133503,0DHLPR ;SET BAR BITS FOR ALL LINES
007146 042767 000200 004466 BIC #200,LINACT ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
007154 012777 177777 004370 MOV #-1,0DHBA ;GET A CHARACTER FROM SILO
007162 005000 CLR R0 ;IF NOT VALID DATA, TRY AGAIN
007164 017704 004352 11: MOV #0DHNR,R4 ;EXTRACT LINE NUMBER FORM CHARACTER
007170 100375 BPL 11
007172 010403 MOV R4,R3
007174 000303 SWAB R3
007176 042703 177760 BIC #177760,R3 ;CLEAR STATUS BITS
007202 010302 MOV R3,R2
007204 006302 ASL R2
007206 020327 000007 CMP R3,#7 ;IF LINE NUMBER IS 7
007212 001432 BEQ 41 ;CHECK FOR CORRECT ECHOED CHARACTER
007214 026204 014246 CMP RBUF(R2),R4 ;IF NOT LINE 7, CHECK DATA
007220 001404 BEQ 21
007222 016205 014246 MOV RBUF(R2),R5 ;(R5)=EXPECTED NON ECHOED DATA
007226 HLT 1 ;NON ECHOED DATA ERROR
007226 104001 EMT 1
007230 000423 BR 41
007232 105262 014246 21: INCB RBUF(R2) ;UPDATE EXPECTED RECEIVED DATA
007236 001352 BNE 11 ;CONTINUE IF NOT DONE
007240 046267 014450 004374 BIC LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
007246 005767 004370 31: TST LINACT ;IF ALL LINES ARE DONE
007252 001344 BNE 11 ;EXIT
007254 012777 000007 004256 MOV #7,0DHSCR ;SELECT LINE 7
007262 042777 100000 004254 BIC #100000,0DHLPR ;CLEAR AUTO ECHO FOR LINE 7
007270 105777 004264 TSTB #0DHSLR ;GET REST OF CHARACTERS
007274 001333 BNE 11 ;AND CHECK
007276 000407 BR 51
007300 005200 41: INC R0 ;UPDATE ECHOED CHARACTER COUNT
007302 020467 005020 CMP R4,TWRD7 ;CHECK ECHOED DATA
007306 001757 BEQ 31
007310 016705 005012 MOV TWRD7,R5 ;(R5)=EXPECTED ECHOED DATA
007314 HLT 2 ;ECHOED DATA ERROR
007314 104002 EMT 2
007316 104400 51: SCOPE ;CHECK FOR ITERATIONS, LOOP
                LINE=LINE+1
                BITX=BITX+BITX
                KX=KX+1
007320 AUTO2 \LINE,\BITX,\KX
                                ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 10

```

;TRANSMIT 1 CHARACTER ON LINE 10 WITH AUTO ECHO ENABLED
 ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
 ;CHARACTER LENGTH IS 8 BITS
 ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

007320				TS \XN,10,50		
007320	012767	000340	170450	T31: MOV	#340,PS	;DISABLE ALL INTERRUPTS
007326	012767	000010	004252	MOV	#10,ICOUNT	;SET UP FOR 10 ITERATIONS
007334	012767	007554	004240	MOV	#54,ESCAPE	;SET UP TO ESCAPE TO NEXT TEST
				.IF NB	<>	
				MOV	#,FREEZ1	;SET UP TO LOOP WITH DATA ; 3
				.ENDC		
	000032			XN=XN+1		
007342	012777	004000	004170	MOV	#BIT11,0DHSCR	;MASTER CLEAR INTERFACE
007350	004767	004052		JSR	PC,SETALL	;SET UP ALL LINES TO TRANSMIT
						;400 (OCTAL) CHARACTERS
007354	012777	000010	004156	MOV	#10,0DHSCR	;SELECT LINE 10 FOR TESTING
007362	012777	014330	004156	MOV	#TWRD10,0DHBA	;CHARACTER TO BE TRANSMITTED
						;ON LINE 10 IN AUTO ECHO MODE
007370	012777	177777	004152	MOV	#-1,0DHBC	;TRANSMIT ONLY 1 CHARACTER ON LINE 10
007376	012777	133503	004140	MOV	#133503,0DHLP	;SET AUTO ECHO FOR LINE 10
007404	042767	000400	004230	BIC	#400,LINACT	;CLEAR LINE ACTIVE BIT
007412	012777	177777	004132	MOV	#-1,0DHBA	;SET BAR BITS FOR ALL LINES
007420	005000			CLR	R0	;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
007422	017704	004114		10: MOV	0DHNR,R4	;GET A CHARACTER FROM SILO
007426	100375			BPL	10	;IF NOT VALID DATA, TRY AGAIN
007430	010403			MOV	R4,R3	;EXTRACT LINE NUMBER FORM CHARACTER
007432	000303			SWAB	R3	
007434	042703	177760		BIC	#177760,R3	;CLEAR STATUS BITS
007440	010302			MOV	R3,R2	
007442	006302			ASL	R2	
007444	020327	000010		CMP	R3,#10	;IF LINE NUMBER IS 10
007450	001432			BEQ	40	;CHECK FOR CORRECT ECHOED CHARACTER
007452	026204	014246		CMP	RBUF(R2),R4	;IF NOT LINE 10, CHECK DATA
007456	001404			BEQ	20	
007460	016205	014246		MOV	RBUF(R2),R5	; (R5)=EXPECTED NON ECHOED DATA
007464				HLT	1	;NON ECHOED DATA ERROR
007464	104001			EMT	1	
007466	000423			BR	40	
007470	105262	014246		20: INCB	RBUF(R2)	;UPDATE EXPECTED RECEIVED DATA
007474	001352			BNE	10	;CONTINUE IF NOT DONE
007476	046267	014450	004136	BIC	LINBIT(R2),LINACT	;CLEAR ACTIVE BIT
007504	005767	004132		30: TST	LINACT	;IF ALL LINES ARE DONE
007510	001344			BNE	10	;EXIT
007512	012777	000010	004020	MOV	#10,0DHSCR	;SELECT LINE 10
007520	042777	100000	004016	BIC	#100000,0DHLP	;CLEAR AUTO ECHO FOR LINE 10
007526	105777	004026		TSTB	0DHSLR	;GET REST OF CHARACTERS
007532	001333			BNE	10	;AND CHECK
007534	000407			BR	50	
007536	005200			40: INC	R0	;UPDATE ECHOED CHARACTER COUNT
007540	020467	004564		CMP	R4,TWRD10	;CHECK ECHOED DATA
007544	001757			BEQ	30	
007546	016705	004556		MOV	TWRD10,R5	; (R5)=EXPECTED ECHOED DATA
007552				HLT	2	;ECHOED DATA ERROR
007552	104002			EMT	2	
007554	104400			50: SCOPE		;CHECK FOR ITERATIONS, LOOP
	000011			LINE=LINE+1		


```

001000      BITX=BITX+BITX
000011      KX=KX+1
007556      AUTO2  \LINE,\BITX,\KX

;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 11
;TRANSMIT 1 CHARACTER ON LINE 11 WITH AUTO ECHO ENABLED
;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
;CHARACTER LENGTH IS 8 BITS
;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

007556      TS \XN,10,5
007556      T32:  MOV     #340,PS          ;DISABLE ALL INTERRUPTS
007564      012767 000340 170212      MOV     #10,ICOUNT      ;SET UP FOR 10 ITERATIONS
007572      012767 010012 004002      MOV     #5,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
;IF NB      <>
;MOV        #,FREEZ1          ;SET UP TO LOOP WITH DATA          ; 3
.ENDC
XN=XN+1
007600      000033      004000 003732      MOV     #BIT11,BDHSCR      ;MASTER CLEAR INTERFACE
007606      004767 003614      JSR     PC.SETALL      ;SET UP ALL LINES TO TRANSMIT
;400 (OCTAL) CHARACTERS
007612      012777 000011 003720      MOV     #11,BDHSCR      ;SELECT LINE 11 FOR TESTING
007620      012777 014332 003720      MOV     #THRD11,BDHBA      ;CHARACTER TO BE TRANSMITTED
;ON LINE 11 IN AUTO ECHO MODE
007626      012777 177777 003714      MOV     #-1,BDHBC      ;TRANSMIT ONLY 1 CHARACTER ON LINE 11
007634      012777 133503 003702      MOV     #133503,BDHLPR      ;SET AUTO ECHO FOR LINE 11
007642      042767 001000 003772      BIC     #1000,LINACT      ;CLEAR LINE ACTIVE BIT
007650      012777 177777 003674      MOV     #-1,BDHBA      ;SET BAR BITS FOR ALL LINES
007656      005000      CLR     R0          ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
007660      017704 003656      1$:      MOV     BDHNR,R4      ;GET A CHARACTER FROM SILO
007664      100375      BPL     1$          ;IF NOT VALID DATA, TRY AGAIN
007666      010403      MOV     R4,R3      ;EXTRACT LINE NUMBER FORM CHARACTER
007670      000303      SWAB    R3
007672      042703 177760      BIC     #177760,R3      ;CLEAR STATUS BITS
007676      010302      MOV     R3,R2
007700      006302      ASL     R2
007702      020327 000011      CMP     R3,#11      ;IF LINE NUMBER IS 11
007706      001432      BEQ     4$          ;CHECK FOR CORRECT ECHOED CHARACTER
007710      026204 014246      CMP     RBUF(R2),R4      ;IF NOT LINE 11, CHECK DATA
007714      001404      BEQ     2$
007716      016205 014246      MOV     RBUF(R2),R5      ;(R5)=EXPECTED NON ECHOED DATA
007722      HLT     1          ;NON ECHOED DATA ERROR
007722      104001      EMT     1
007724      000423      BR     4$
007726      105262 014246      2$:      INCB    RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
007732      001352      BNE     1$          ;CONTINUE IF NOT DONE
007734      046267 014450 003700      BIC     LINBIT(R2),LINACT      ;CLEAR ACTIVE BIT
007742      005767 003674      3$:      TST     LINACT      ;IF ALL LINES ARE DONE
007746      001344      BNE     1$          ;EXIT
007750      012777 000011 003562      MOV     #11,BDHSCR      ;SELECT LINE 11
007756      042777 100000 003560      BIC     #100000,BDHLPR      ;CLEAR AUTO ECHO FOR LINE 11
007764      105777 003570      TSTB    BDHSLR      ;GET REST OF CHARACTERS
007770      001333      BNE     1$          ;AND CHECK
007772      000407      BR     5$
007774      005200      4$:      INC     R0          ;UPDATE ECHOED CHARACTER COUNT
007776      020467 004330      CMP     R4,THRD11      ;CHECK ECHOED DATA
010002      001757      BEQ     3$

```

```

010004 016705 004322      MOV      TWRD11,R5      ;(R5)=EXPECTED ECHOED DATA
010010                      HLT      2              ;ECHOED DATA ERROR
010010 104002              EMT      2
010012 104400              5$: SCOPE              ;CHECK FOR ITERATIONS, LOOP
      000012              LINE=LINE+1
      002000              BITX=BITX+BITX
      000012              KX=KX+1
010014                      AUTO2   \LINE,\BITX,\KX

      ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 12
      ;TRANSMIT 1 CHARACTER ON LINE 12 WITH AUTO ECHO ENABLED
      ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
      ;CHARACTER LENGTH IS 8 BITS
      ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

010014                      TS \XN,10,5$
010014 012767 000340 167754 T33:  MOV      #340,PS      ;DISABLE ALL INTERRUPTS
010022 012757 000010 003556      MOV      #10,ICOUNT    ;SET UP FOR 10 ITERATIONS
010030 012767 010250 003544      MOV      #5$,ESCAPE    ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB <>
      MOV      #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
010036 012777 004000 003474      MOV      #BIT11,BDHSCR    ;MASTER CLEAR INTERFACE
010044 004767 003356              JSR      PC,SETALL      ;SET UP ALL LINES TO TRANSMIT
      ;400 (OCTAL) CHARACTERS
010050 012777 000012 003462      MOV      #12,BDHSCR    ;SELECT LINE 12 FOR TESTING
010056 012777 014334 003462      MOV      #TWRD12,BDHB A ;CHARACTER TO BE TRANSMITTED
      ;ON LINE 12 IN AUTO ECHO MODE
010064 012777 177777 003456      MOV      #-1,BDHBC      ;TRANSMIT ONLY 1 CHARACTER ON LINE 12
010072 012777 133503 003444      MOV      #133503,BDHLP R ;SET AUTO ECHO FOR LINE 12
010100 042767 002000 003534      BIC      #2000,LINACT    ;CLEAR LINE ACTIVE BIT
010106 012777 177777 003436      MOV      #-1,BDHBAR    ;SET BAR BITS FOR ALL LINES
010114 005000              CLR      R0              ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
010116 017704 003420      1$: MOV      #DHNR C,R4      ;GET A CHARACTER FROM SILO
010122 100375              BPL      1$              ;IF NOT VALID DATA, TRY AGAIN
010124 010403              MOV      R4,R3              ;EXTRACT LINE NUMBER FORM CHARACTER
010126 000303              SWAB      R3
010130 042703 177760      BIC      #177760,R3      ;CLEAR STATUS BITS
010134 010302              MOV      R3,R2
010136 006302              ASL      R2
010140 020327 000012      CMP      R3,#12      ;IF LINE NUMBER IS 12
010144 001432              BEQ      4$              ;CHECK FOR CORRECT ECHOED CHARACTER
010146 026204 014246      CMP      RBUF(R2),R4      ;IF NOT LINE 12, CHECK DATA
010152 001404              BEQ      2$
010154 016205 014246      MOV      RBUF(R2),R5      ;(R5)=EXPECTED NON ECHOED DATA
010160                      HLT      1              ;NON ECHOED DATA ERROR
010160 104001              EMT      1
010162 000423              BR      4$
010164 105262 014246      2$: INCB      RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
010170 001352              BNE      1$              ;CONTINUE IF NOT DONE
010172 046267 014450 003442      BIC      LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
010200 005767 003436      3$: TST      LINACT      ;IF ALL LINES ARE DONE
010204 001344              BNE      1$              ;EXIT
010206 012777 000012 003324      MOV      #12,BDHSCR    ;SELECT LINE 12
010214 042777 100000 003322      BIC      #100000,BDHLP R ;CLEAR AUTO ECHO FOR LINE 12
010222 105777 003332      TSTB      BDHSLR      ;GET REST OF CHARACTERS

```

```

010226 001333          BNE      1$          ;AND CHECK
010230 000407          BR       5$
010232 005200          4$: INC      R0          ;UPDATE ECHOED CHARACTER COUNT
010234 020467 004074   CMP      R4,TWRD12    ;CHECK ECHOED DATA
010240 001757          BEQ      3$
010242 016705 004066   MOV      TWRD12,R5          ;(R5)=EXPECTED ECHOED DATA
010246          HLT      2          ;ECHOED DATA ERROR
010246 104002          EMT      2
010250 104400          5$: SCOPE          ;CHECK FOR ITERATIONS, LOOP
      000013          LINE=LINE+1
      004000          BITX=BITX+BITX
      000013          KX=KX+1
010252          AUTC2  \LINE,\BITX,\KX

      ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 13
      ;TRANSMIT 1 CHARACTER ON LINE 13 WITH AUTO ECHO ENABLED
      ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
      ;CHARACTER LENGTH IS 8 BITS
      ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

010252          TS  \XN,10,5$
010252 012767 000340 167516 T34: MOV     #340,PS          ;DISABLE ALL INTERRUPTS
010260 012767 000010 003320      MOV     #10,ICOUNT        ;SET UP FOR 10 ITERATIONS
010266 012767 010506 003306      MOV     #5$,ESCAPE        ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB <>
      MOV     #,FREEZ1          ;SET UP TO LOOP WITH DATA          ; 3
      .ENDC
      XN=XN+1
010274 012777 004000 003236      MOV     #BIT11,SDHSCR        ;MASTER CLEAR INTERFACE
010302 004767 003120          JSR     PC,SETALL          ;SET UP ALL LINES TO TRANSMIT
      ;400 (OCTAL) CHARACTERS
      ;SELECT LINE 13 FOR TESTING
010306 012777 000013 003224      MOV     #13,SDHSCR        ;CHARACTER TO BE TRANSMITTED
010314 012777 014336 003224      MOV     #TWRD13,SDHBA      ;ON LINE 13 IN AUTO ECHO MODE
      ;TRANSMIT ONLY 1 CHARACTER ON LINE 13
      ;SET AUTO ECHO FOR LINE 13
010322 012777 177777 003220      MOV     #-1,SDHSC        ;CLEAR LINE ACTIVE BIT
010330 012777 133503 003206      MOV     #133503,SDHLPR      ;SET BAR BITS FOR ALL LINES
010336 042767 004000 003276      BIC     #4000,LINACT      ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
010344 012777 177777 003200      MOV     #-1,SDHBA        ;GET A CHARACTER FROM SILO
010352 005000          CLR      R0          ;IF NOT VALID DATA, TRY AGAIN
010354 017704 003162          1$: MOV     SDHARC,R4        ;EXTRACT LINE NUMBER FORM CHARACTER
010360 100375          BPL      1$
010362 010403          MOV     R4,R3
010364 000303          SWAB     R3
010366 042703 177760      BIC     #177760,R3          ;CLEAR STATUS BITS
010372 010302          MOV     R3,R2
010374 006302          ASL      R2
010376 020327 000013      CMP     R3,#13          ;IF LINE NUMBER IS 13
010402 001432          BEQ      4$          ;CHECK FOR CORRECT ECHOED CHARACTER
010404 026204 014246      CMP     RBUF(R2),R4        ;IF NOT LINE 13, CHECK DATA
010410 001404          BEQ      2$
010412 016205 014246      MOV     RBUF(R2),R5        ;(R5)=EXPECTED NON ECHOED DATA
010416          HLT      1          ;NON ECHOED DATA ERROR
010416 104001          EMT      1
010420 000423          BR       4$
010422 105262 014246      2$: INCB     RBUF(R2)        ;UPDATE EXPECTED RECEIVED DATA
010426 001352          BNE      1$          ;CONTINUE IF NOT DONE
010430 046267 014450 003204      BIC     LINBIT(R2),LINACT ;CLEAR ACTIVE BIT

```

```

010436 005767 003200      3$:  TST      LINACT      ;IF ALL LINES ARE DONE
010442 001344              BNE      1$          ;EXIT
010444 012777 000013 003066  MOV      #13,8DHSCR  ;SELECT LINE 13
010452 042777 100000 003064  BIC      #100000,8DHLPR ;CLEAR AUTO ECHO FOR LINE 13
010460 105777 003074      TSTB     8DHSLR      ;GET REST OF CHARACTERS
010464 001333              BNE      1$          ;AND CHECK
010466 000407              BR       5$          ;
010470 005200      4$:  INC      R0          ;UPDATE ECHOED CHARACTER COUNT
010472 020467 003640      CMP      R4,TWRD13    ;CHECK ECHOED DATA
010476 001757              BEQ      3$          ;
010500 016705 003632      MOV      TWRD13,R5    ;(R5)=EXPECTED ECHOED DATA
010504              HLT      2                ;ECHOED DATA ERROR
010506 104002              EMT      2          ;
104400      5$:  SCOPE                      ;CHECK FOR ITERATIONS, LOOP
000014      LINE=LINE+1
010000      BITX=BITX+BITX
000014      KX=KX+1
010510      AUTO2  \LINE,\BITX,\KX

;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 14
;TRANSMIT 1 CHARACTER ON LINE 14 WITH AUTO ECHO ENABLED
;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
;CHARACTER LENGTH IS 8 BITS
;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

010510      TS  \XN,10,5$
010510 012767 000340 167260 T35:  MOV      #340,PS      ;DISABLE ALL INTERRUPTS
010516 012767 000010 003062      MOV      #10,ICOUNT    ;SET UP FOR 10 ITERATIONS
010524 012767 010744 003050      MOV      #5$,ESCAPE    ;SET UP TO ESCAPE TO NEXT TEST
;IF NB  <>
;MOV      #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
.ENDC
XN=XN+1
010532 012777 004000 003000      MOV      #BIT11,8DHSCR   ;MASTER CLEAR INTERFACE
010540 004767 002662      JSR      PC,SETALL      ;SET UP ALL LINES TO TRANSMIT
;400 (OCTAL) CHARACTERS
;SELECT LINE 14 FOR TESTING
010544 012777 000014 002766      MOV      #14,8DHSCR     ;CHARACTER TO BE TRANSMITTED
010552 012777 014340 002766      MOV      #TWRD14,8DHBA  ;ON LINE 14 IN AUTO ECHO MODE
;TRANSMIT ONLY 1 CHARACTER ON LINE 14
;SET AUTO ECHO FOR LINE 14
010560 012777 177777 002762      MOV      #-1,8DHBC      ;CLEAR LINE ACTIVE BIT
010566 012777 133503 002750      MOV      #133503,8DHLPR  ;SET BAR BITS FOR ALL LINES
010574 042767 010000 003040      BIC      #10000,LINACT  ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
010602 012777 177777 002742      MOV      #-1,8DHBA      ;GET A CHARACTER FROM SILO
010610 005000      CLR      R0          ;IF NOT VALID DATA, TRY AGAIN
010612 017704 002724      1$:  MOV      8DHNR, R4      ;EXTRACT LINE NUMBER FORM CHARACTER
010616 100375      BPL      1$          ;
010620 010403      MOV      R4,R3          ;
010622 000303      SWAB     R3          ;
010624 042703 177760      BIC      #177760,R3        ;CLEAR STATUS BITS
010630 010302      MOV      R3,R2          ;
010632 006302      ASL      R2          ;
010634 020327 000014      CMP      R3,#14      ;IF LINE NUMBER IS 14
010640 001432      BEQ      4$          ;CHECK FOR CORRECT ECHOED CHARACTER
010642 026204 014246      CMP      RBUF(R2),R4      ;IF NOT LINE 14, CHECK DATA
010646 001404      BEQ      2$          ;
010650 016205 014246      MOV      RBUF(R2),R5    ;(R5)=EXPECTED NON ECHOED DATA
010654              HLT      1                ;NON ECHOED DATA ERROR

```

```

010654 104001      EMT      1
010656 000423      BR      4#
010660 105262 014246 2# : INCB    RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
010664 001352      BNE      1#      ;CONTINUE IF NOT DONE
010666 046267 014450 002746 3# : BIC    LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
010674 005767 002742      TST    LINACT      ;IF ALL LINES ARE DONE
010700 001344      BNE      1#      ;EXIT
010702 012777 000014 002630      MOV    #14,SDHSCR ;SELECT LINE 14
010710 042777 100000 002626      BIC    #100000,SDHLPR ;CLEAR AUTO ECHO FOR LINE 14
010716 105777 002636      TSTB   SDHSLR      ;GET REST OF CHARACTERS
010722 001333      BNE      1#      ;AND CHECK
010724 000407      BR      5#
010726 005200      INC      R0      ;UPDATE ECHOED CHARACTER COUNT
010730 020467 003404      CMP     R4,TWRD14 ;CHECK ECHOED DATA
010734 001757      BEQ      3#
010736 016705 003376      MOV     TWRD14,R5      ;(R5)=EXPECTED ECHOED DATA
010742      HLT      2      ;ECHOED DATA ERROR
010742 104002      EMT      2
010744 104400      5# : SCOPE      ;CHECK FOR ITERATIONS LOOP
      000015      LINE=LINE+1
      020000      BITX=BITX+BITX
      000015      KX=KX+1
010746      AUTO2   \LINE,\BITX,\KX

      ;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 15
      ;TRANSMIT 1 CHARACTER ON LINE 15 WITH AUTO ECHO ENABLED
      ;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
      ;CHARACTER LENGTH IS 8 BITS
      ;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

010746      TS \XN,10,5#
010746 012767 000340 167022 T36: MOV    #340,PS      ;DISABLE ALL INTERRUPTS
010754 012767 000010 002624      MOV    #10,ICOUNT ;SET UP FOR 10 ITERATIONS
010762 012767 011202 002612      MOV    #5#,ESCAPE ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB    <>
      MOV      #,FREEZ1      ;SET UP TO LOOP WITH DATA      ; 3
      .ENDC
      XN=XN+1
010770 000037      MOV    #BIT11,SDHSCR      ;MASTER CLEAR INTERFACE
010776 004767 002424      JSR     PC,SETALL ;SET UP ALL LINES TO TRANSMIT
      ;400 (OCTAL) CHARACTERS
011002 012777 000015 002530      MOV    #15,SDHSCR ;SELECT LINE 15 FOR TESTING
011010 012777 014342 002530      MOV    #TWRD15,SDHBA ;CHARACTER TO BE TRANSMITTED
      ;ON LINE 15 IN AUTO ECHO MODE
011016 012777 177777 002524      MOV    #-1,SDHBC ;TRANSMIT ONLY 1 CHARACTER ON LINE 15
011024 012777 133503 002512      MOV    #133503,SDHLPR ;SET AUTO ECHO FOR LINE 15
011032 042767 020000 002602      BIC    #20000,LINACT ;CLEAR LINE ACTIVE BIT
011040 012777 177777 002504      MOV    #-1,SDHBA ;SET BAR BITS FOR ALL LINES
011046 005000      CLR      R0      ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
011050 017704 002466 1# : MOV     SDHNR, R4 ;GET A CHARACTER FROM SILO
011054 100375      BPL      1#      ;IF NOT VALID DATA, TRY AGAIN
011056 010403      MOV     R4,R3      ;EXTRACT LINE NUMBER FORM CHARACTER
011060 000303      SWAB     R3
011062 042703 177760      BIC     #177760,R3 ;CLEAR STATUS BITS
011066 010302      MOV     R3,R2
011070 006302      ASL      R2
011072 020327 000015      CMP     R3,#15      ;IF LINE NUMBER IS 15

```

```

011076 001432      BEQ      4#      ;CHECK FOR CORRECT ECHOED CHARACTER
011100 026204 014246 CMP      RBUF(R2),R4 ;IF NOT LINE 15, CHECK DATA
011104 001404      BEQ      2#
011106 016205 014246 MOV      RBUF(R2),R5 ;(R5)=EXPECTED NON ECHOED DATA
011112      HLT      1      ;NON ECHOED DATA ERROR
011112 104001      EMT      1
011114 000423      BR      4#
011116 105262 014246 2# : INCB     RBUF(R2) ;UPDATE EXPECTED RECEIVED DATA
011122 001352      BNE     1#      ;CONTINUE IF NOT DONE
011124 046267 014450 002510 JIC     LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
011132 005767 002504 3# : TST     LINACT ;IF ALL LINES ARE DONE
011136 001344      BNE     1#      ;EXIT
011140 012777 000015 002372 MOV     #15,SDHSCR ;SELECT LINE 15
011146 042777 100000 002370 BIC     #100000,SDHLPR ;CLEAR AUTO ECHO FOR LINE 15
011154 105777 002400      TSTB    SDHSLR ;GET REST OF CHARACTERS
011160 001333      BNE     1#      ;AND CHECK
011162 000407      BR      5#
011164 005200      INC      R0      ;UPDATE ECHOED CHARACTER COUNT
011166 020467 003150      CMP     R4,TWRD15 ;CHECK ECHOED DATA
011172 001757      BEQ      3#
011174 016705 003142      MOV     TWRD15,R5 ;(R5)=EXPECTED ECHOED DATA
011200      HLT      2      ;ECHOED DATA ERROR
011200 104002      EMT      2
011202 104400      5# : SCOPE ;CHECK FOR ITERATIONS, LOOP
      000016      LINE=LINE+1
      040000      BITX=BITX+BITX
      000016      KX=KX+1
011204      AUTO2   \LINE,\BITX,\KX

;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 16
;TRANSMIT 1 CHARACTER ON LINE 16 WITH AUTO ECHO ENABLED
;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
;CHARACTER LENGTH IS 8 BITS
;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

011204      TS \YN,10,5#
011204 012767 000340 166564 T37: MOV     #340,PS ;DISABLE ALL INTERRUPTS
011212 012767 000010 002366 MOV     #10,ICOUNT ;SET UP FOR 10 ITERATIONS
011220 012767 011440 002354 MOV     #5#,ESCAPE ;SET UP TO ESCAPE TO NEXT TEST

      .IF NB <>
      MOV     #,FREEZ1 ;SET UP TO LOOP WITH DATA ; 3
      .ENDC
      XN=XN+1

011226 000040      MOV     #BIT11,SDHSCR ;MASTER CLEAR INTERFACE
011234 004767 002166      JSR     PC,SETALL ;SET UP ALL LINES TO TRANSMIT
;400 (OCTAL) CHARACTERS
011240 012777 000016 002272 MOV     #16,SDHSCR ;SELECT LINE 16 FOR TESTING
011246 012777 014344 002272 MOV     #TWRD16,SDHBA ;CHARACTER TO BE TRANSMITTED
;ON LINE 16 IN AUTO ECHO MODE
011254 012777 177777 002266 MOV     #-1,SDHBC ;TRANSMIT ONLY 1 CHARACTER ON LINE 16
011262 012777 133503 002254 MOV     #133503,SDHLPR ;SET AUTO ECHO FOR LINE 16
011270 042767 040000 002344 BIC     #40000,LINACT ;CLEAR LINE ACTIVE BIT
011276 012777 177777 002246 MOV     #-1,SDHBA ;SET BAR BITS FOR ALL LINES
011304 005000      CLR      R0      ;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
011306 017704 002230 1# : MOV     SDHNR, R4 ;GET A CHARACTER FROM SILO
011312 100375      BPL      1#      ;IF NOT VALID DATA, TRY AGAIN
011314 010403      MOV     R4,R3 ;EXTRACT LINE NUMBER FORM CHARACTER

```

```

011316 000303          SWAB      R3
011320 042703 177760    BIC      #177760,R3          ;CLEAR STATUS BITS
011324 010302          MOV      R3,R2
011326 006302          ASL      R2
011330 020327 000016    CMP      R3,#16          ;IF LINE NUMBER IS 16
011334 001432          BEQ      4$          ;CHECK FOR CORRECT ECHOED CHARACTER
011336 026204 014246    CMP      RBUF(R2),R4      ;IF NOT LINE 16, CHECK DATA
011342 001404          BEQ      2$
011344 016205 014246    MOV      RBUF(R2),R5      ;(R5)=EXPECTED NON ECHOED DATA
011350          HLT      1          ;NON ECHOED DATA ERROR
011350 104001          EMT      1
011352 000423          BR      4$
011354 105262 014246    2$:      INCB     RBUF(R2)      ;UPDATE EXPECTED RECEIVED DATA
011360 001352          BNE      1$          ;CONTINUE IF NOT DONE
011362 046267 014450 002252    BIC      LINBIT(R2),LINACT ;CLEAR ACTIVE BIT
011370 005767 002246    3$:      TST      LINACT      ;IF ALL LINES ARE DONE
011374 001344          BNE      1$          ;EXIT
011376 012777 000016 002134    MOV      #16,8DHSCR      ;SELECT LINE 16
011404 042777 100000 002132    BIC      #100000,8DHLP      ;CLEAR AUTO ECHO FOR LINE 16
011412 105777 002142          TSTB     8DHSLR      ;GET REST OF CHARACTERS
011416 001333          BNE      1$          ;AND CHECK
011420 000407          BR      5$
011422 005200          4$:      INC      R0          ;UPDATE ECHOED CHARACTER COUNT
011424 020467 002714    CMP      R4,TWRD16      ;CHECK ECHOED DATA
011430 001757          BEQ      3$
011432 016705 002706    MOV      TWRD16,R5      ;(R5)=EXPECTED ECHOED DATA
011436          HLT      2          ;ECHOED DATA ERROR
011436 104002          EMT      2
011440 104400          5$:      SCOPE
011440 000017          LINE=LINE+1
011440 100000          BITX=BITX+BITX
011440 000017          KX=KX+1
011442          AUTO2   \LINE,\BITX,\KX

;TRANSMIT A BINARY COUNT PATTERN ON ALL LINES EXCEPT LINE 17
;TRANSMIT 1 CHARACTER ON LINE 17 WITH AUTO ECHO ENABLED
;TRANSMISSION SPEED FOR ALL LINES IS 9600 BAUD
;CHARACTER LENGTH IS 8 BITS
;VERIFY THAT CORRECT DATA IS RECEIVED ON ALL LINES

011442          TS \XN,10,5$
011442 012767 000340 166326    T40:      MOV      #340,PS          ;DISABLE ALL INTERRUPTS
011450 012767 000010 002130    MOV      #10,ICOUNT      ;SET UP FOR 10 ITERATIONS
011456 012767 011676 002116    MOV      #51,ESCAPE      ;SET UP TO ESCAPE TO NEXT TEST
                                .IF NB
                                <>
                                MOV      #,FREEZ1          ;SET UP TO LOOP WITH DATA      ; 3
                                .ENDC
                                XN=XN+1
011464 012777 004000 002046    MOV      #BIT11,8DHSCR      ;MASTER CLEAR INTERFACE
011472 004767 001730          JSR      PC,SETALL      ;SET UP ALL LINES TO TRANSMIT
                                ;400 (OCTAL) CHARACTERS
011476 012777 000017 002034    MOV      #17,8DHSCR      ;SELECT LINE 17 FOR TESTING
011504 012777 014346 002034    MOV      #TWRD17,8DHBA      ;CHARACTER TO BE TRANSMITTED
                                ;ON LINE 17 IN AUTO ECHO MODE
011512 012777 177777 002030    MOV      #-1,8DHBC      ;TRANSMIT ONLY 1 CHARACTER ON LINE 17
011520 012777 133503 002016    MOV      #133503,8DHLP      ;SET AUTO ECHO FOR LINE 17
011526 042767 100000 002106    BIC      #100000,LINACT ;CLEAR LINE ACTIVE BIT

```

011534	012777	177777	002010	MOV	#-1, 8DHBAR	;SET BAR BITS FOR ALL LINES
011542	005000			CLR	R0	;KEEP COUNT OF NUMBER OF RECEIVED CHARACTERS
011544	017704	001772		1#: MOV	8DHNR, R4	;GET A CHARACTER FROM SILO
011550	100375			BPL	1#	;IF NOT VALID DATA, TRY AGAIN
011552	010403			MOV	R4, R3	;EXTRACT LINE NUMBER FORM CHARACTER
011554	000303			SWAB	R3	
011556	042703	177760		BIC	#177760, R3	;CLEAR STATUS BITS
011562	010302			MOV	R3, R2	
011564	006302			ASL	R2	
011566	020327	000017		CMP	R3, #17	;IF LINE NUMBER IS 17
011572	001432			BEQ	4#	;CHECK FOR CORRECT ECHOED CHARACTER
011574	026204	014246		CMP	RBUF(R2), R4	;IF NOT LINE 17, CHECK DATA
011600	001404			BEQ	2#	
011602	016205	014246		MOV	RBUF(R2), R5	; (R5)=EXPECTED NON ECHOED DATA
011606				HLT	1	;NON ECHOED DATA ERROR
011606	104001			EMT	1	
011610	000423			BR	4#	
011612	105262	014246		2#: INCB	RBUF(R2)	;UPDATE EXPECTED RECEIVED DATA
011616	001352			BNE	1#	;CONTINUE IF NOT DONE
011620	046267	014450	002014	BIC	LINBIT(R2), LINACT	;CLEAR ACTIVE BIT
011626	005767	002010		3#: TST	LINACT	;IF ALL LINES ARE DONE
011632	001344			BNE	1#	;EXIT
011634	012777	000017	001676	MVI	#17, 8DHSCR	;SELECT LINE 17
011642	042777	100000	001674	LD	000000, 8DHLP	;CLEAR AUTO ECHO FOR LINE 17
011650	105777	001704		STB	8DHSLR	;GET REST OF CHARACTERS
011654	001333			BNE	1#	;AND CHECK
011656	000407			BR	5#	
011660	005200			4#: INC	R0	;UPDATE ECHOED CHARACTER COUNT
011662	020467	002460		CMP	R4, TWRD17	;CHECK ECHOED DATA
011666	001757			BEQ	3#	
011670	016705	002452		MOV	TWRD17, R5	; (R5)=EXPECTED ECHOED DATA
011674				HLT	2	;ECHOED DATA ERROR
011674	104002			EMT	2	
011676	104400			5#: SCOPE		;CHECK FOR ITERATIONS, LOOP
	000020			LINE=LINE+1		
	000000			BITX=BITX+BITX		
	000020			KX=KX+1		


```

1
2
3
4
5 011700 TS \XN,100,5#
   011700 012767 000340 166070 T41: MOV #340,PS ;DISABLE ALL INTERRUPTS
   011706 012767 000100 001672 MOV #100,ICOUNT ;SET UP FOR 100 ITERATIONS
   011714 012767 012130 001660 MOV #5#,ESCAPE ;SET UP TO ESCAPE TO NEXT TEST
      .IF NB <>
      MOV #,FREEZ1 ;SET UP TO LOOP WITH DATA ; 3
      .ENDC
      XN=XN+1
6 011722 000042
7 011730 012777 004000 001610 MOV #BIT11,BDHSCR ;MASTER CLEAR INTERFACE
8 011734 012701 014310 MOV #20,R0 ;SET UP PARAMETERS FOR 16 LINES
9 011740 012702 014350 MOV #TWRD0,R1 ;CHARACTER TO BE TRANSMITTED
10 011744 012703 014410 MOV #RCNT0,R2 ;RECEIVED CHARACTER COUNT
11 011750 010177 00152 1# : MOV #RDCT0,R3 ;EXPECTED NUMBER OF CHARACTERS
12 011754 012777 177777 001566 MOV R1,BDHBA ;LOAD BUS ADDRESS
13 011762 012777 131403 001554 MOV #1,BDHBC ;LOAD BYTE COUNT
14 011770 005022 CLR #131403,BDHLPR ;SET AUTO ECHO
15 011772 012723 000100 MOV (R2), ;CLEAR RECEIVED CHARACTER COUNT
16 011776 062701 000002 ADD #100,(R3), ;NUMBER OF CHARACTERS TO BE RECEIVED
17 012002 005300 DEC #2,R1 ;ADVANCE POINTER
18 012004 001361 BNE R0 ;CONTINUE IF NOT DONE
19 012006 012767 177777 001630 MOV #1,AEACT ;INDICATE AUTO ECHO ACTIVE
20
21 012014 012777 177777 001530 MOV #1,BDHBAR ;FOR ALL LINES
22 012022 105777 001512 2# : TSTB BDHSCR ;SET BAR BITS FOR ALL LINES
23 012026 100375 BPL 2# ;WAIT FOR A CHARACTER
24 012030 017704 001506 MOV #BDHNR,R4 ;GET CHARACTER
25 012034 010403 MOV R4,R3
26 012036 000303 SWAB R3
27 012040 042703 177760 BIC #177760,R3 ;EXTRACT LINE NUMBER
28 012044 010302 MOV R3,R2
29 012046 006302 ASL R2
30 012050 005262 014350 INC RCNT0(R2) ;UPDATE RECEIVED COUNT FOR LINE
31 012054 020462 014310 CMP R4,TWRD0(R2) ;CHECK EXPECTED AND RECEIVED DATA
32 012060 001404 BEQ 3#
33 012062 016205 014310 MOV TWRD0(R2),R5 ;(R5)=EXPECTED ECHOED DATA
34 012066 HLT 2 ;AUTO ECHO ERROR
   012066 104002 EMT 2
35 012070 000417 BR 5#
36 012072 005362 014410 3# : DEC RDCT0(R2) ;UPDATE RECEIVED EXPECTED COUNT
37 012076 003351 BGT 2# ;CONTINUE IF NOT 0
38 012100 100413 BMI 5# ;EXIT IOF NEGATIVE
39 012102 010377 001432 MOV R3,BDHSCR ;SELECT LINE THAT FINISHED
40 012106 042777 100000 001430 BIC #100000,BDHLPR ;CLEAR AUTO ECHO
41 012114 046267 014450 001522 BIC LINBIT(R2),AEACT ;CLEAR AUTO ECHO ACTIVE
42 012122 005767 001516 TST AEACTION ;ALL LINES DONE
43 012126 001335 BNE 2# ;IF NOT, CONTINUE
44 012130 104400 5# : SCOPE ;CHECK FOR ITERATIONS, LOOP

```

```

1
2 012132      .EOP      +/BEGIN/

                        ;END OF PASS
                        ;TYPE NAME OF TEST
                        ;UPDATE PASS COUNT
                        ;CHECK FOR EXIT TO ACT-11
                        ;RESTART TEST

012132 104401      EOP:    TYPE
012134 015064      MEPASS
012136 005067 001474  CLR      LAST
012142 005067 001424  CLR      ERRFLG
012146 005267 001422  INC      PASCNT
012152 005767 166624  TST      LIGHTS
012156 001005      BNE      2+
012160 104401      TYPE
012162 015077      PASTXT
012164 104402      OCTASC
012166 012224      PASARG
012170 000403      BR      3+
012172
012172 016767 001376 166602 2+:    MOV      PASCNT,LIGHTS
012200
012200 013701 000042 3+:    MOV      @+42,R1
012204 001405      BEQ      RESTRT
012206 000005      RESET
012210 004711      LOGICAL:  JSR      PC,(R1)
012212 000240      NOP
012214 000240      NOP
012216 000240      NOP
012220 000167 167062  RESTRT:  JMP      BEGIN
012224 000001      PASARG:  .WORD    1
012226 006      002      .BYTE    6,2
012230 013574      .WORD    PASCNT
3 012232      .SCOPE

                        ;CHECK FOR LOOP ON CURRENT TEST
                        ;CHECK FOR ITERATION SUPPRESSION

012232 032777 002000 166540 SCOPER: BIT      @SW10,@SWR
012240 001030      BNE      4+
012242 032777 040000 166530 1+:    BIT      @SW14,@SWR
012250 001021      BNE      3+
012252 032777 004000 166520      BIT      @SW11,@SWR
012260 001006      BNE      2+
012262 005267 001322      INC      LPCNT
012266 026767 001316 001312  CMP      LPCNT,ICOUNT
012274 001007      BNE      3+
012276 005067 001306      CLR      LPCNT
012302 005067 001264      CLR      ERRFLG
012306 011667 001266      MOV      (SP),RETRN
012312 000002      RTI
012314 016716 001260      3+:    MOV      RETRN,(SP)
012320 000002      RTI
012322 005767 001244      4+:    TST      ERRFLG
012326 001745      BEQ      1+

```

012330 000762
4 012332

BR 24
.SCOP1

;CHECK FOR FREEZE ON CURRENT DATA

012332 032777 001000 166440 SCOP1R: BIT 4SW09,BSWR
012340 001402 BEQ 14
012342 016716 001236 MOV FREEZ1,(SP)
012346 000002 14: RTI

; 4

1 012350

.ERROR

;ERROR HANDLER

```

012350 032777 020000 166422 ERRORS: BIT    #SW13, @SWR          ; 4
012356 001055          BNE    HALTS
012360 021667 001252    CMP    (SP), LAST
012364 001404          BEQ    11
012366 011667 001244    MOV    (SP), LAST
012372 005067 001174    CLR    ERRFLG
012376 104406          11:    SAV05P
012400 011605          MOV    (SP), R5
012402 162705 000002    SUB    #2, R5
012406 011504          MOV    (R5), R4
012410 006304          ASL    R4
012412 006304          ASL    R4
012414 042704 177001    BIC    #177001, R4
012420 062704 015216    ADD    @ERRTAB, R4
012424 012467 000040    MOV    (R4), ERRMSG
012430 011467 000052    MOV    (R4), DATABP
012434 005767 001132    TST    ERRFLG
012440 001403          BEQ    TYPMSG
012442 005767 000040    TST    DATABP
012446 001011          BNE    TYPDAT
012450 104401          TYPMSG: TYPE
012452 014774          MCRLF
012454 104402          OCTASC
012456 012554          ERTAB0
012460 012767 000001 001104    MOV    #1, ERRFLG
012466 104401          TYPE
012470 000000          ERRMSG: 0
012472 005767 000010    TYPDAT: TST    DATABP
012476 001404          BEQ    RESREG
012500 104401          TYPE
012502 014774          MCRLF
012504 104402          OCTASC
012506 000000          DATABP: 0
012510 104407          RESREG: RES05
012512 005777 166262    HALTS: TST    @SWR
012516 100005          BPL    EXITER
012520 010046          PUSHRO
012522 016600 000002    MOV    2(SP), R0
012526 000000          HALT
012530 012600          POPRO
012532 005267 001040    EXITER: INC    ERRCNT
012536 032777 002000 166234    BIT    #SW10, @SWR
012544 001402          BEQ    11
012546 016716 001030    MOV    ESCAPE, (SP)
012552 000002          11:    RTI
012554 000001          ERTAB0: 1
012556 006      002      .BYTE 6, 2
012560 013630          SAVPC

```

012562

.TRPSRV

;TRAP DISPATCH SERVICE
;ARGUMENT OF TRAP IS EXTRACTED
;AND USED AS OFFSET TO OBTAIN POINTER
;TO SELECTED SUBROUTINE

; 3

012562 011646
012564 162716 000002
012570 017616 000000
012574 006316
012576 042716 177001
012602 062716 015136
012606 017616 000000
012612 000136
2 012614

TRPSRV: MOV (SP),-(SP) ;GET PC OF RETURN
SUB #2,(SP) ;PC OF TRAP
MOV #0(SP),(SP) ;GET TRP
TRPOK: ASL (SP) ;MULTIPLY TRAP ARG BY 2
BIC #177001,(SP) ;CLEAR UNWANTED BITS
ADD #TRPTAB,(SP) ;POINTER TO SUBROUTINE ADDRESS
MOV #0(SP),(SP) ;SUBROUTINE ADDRESS
JMP #0(SP)+ ;GO TO SUBROUTINE

.SAVREG

;SAVE PC OF TEST THAT FAILED AND R0-R5

012614 016667 000004 001006 SV05P: MOV 4(SP),SAVPC

;SAVE R0-R5

; 3

012622 010567 000776
012626 010467 000770
012632 010367 000762
012636 010267 000754
012642 010167 000746
012646 010067 000740
012652 000002
3 012654

SV05: MOV R5,SAVR5
MOV R4,SAVR4
MOV R3,SAVR3
MOV R2,SAVR2
MOV R1,SAVR1
MOV R0,SAVR0
RTI

.RESREG

;RESTORE R0-R5

012654 016700 000732
012660 016701 000730
012664 016702 000726
012670 016703 000724
012674 016704 000722
012700 016705 000720
012704 000002

RS05: MOV SAVR0,R0
MOV SAVR1,R1
MOV SAVR2,R2
MOV SAVR3,R3
MOV SAVR4,R4
MOV SAVR5,R5
RTI

1 012706

.TYPER

;TELETYPE OUTPUT ROUTINE

; 3

012706 017605 000000
 012712 062716 000002
 012716 105777 000612
 012722 100375
 012724 105715
 012726 001001
 012730 000002
 012732 112577 000600
 012736 000767
 2 012740

TYPER: MOV @ (SP), R5
 ADD #2, (SP)
 1: TSTB @TPCSR
 BPL 1:
 TSTB (R5)
 BNE 2:
 RTI
 2: MOVB (R5), @TPDBR
 BR 1:
 .INSTRG

;ASCII STRING INPUT ROUTINE

012740 017667 000000 000006
 012746 062716 000002
 012752 104401
 012754 000000
 012756 012764 015160
 012762 012703 000007
 012766 105777 000536
 012772 100375
 012774 117714 000532
 013000 142714 000200
 013004 122427 000015
 013010 001413
 013012 117777 000514 000516
 013020 105777 000510
 013024 100375
 013026 005303
 013030 001356
 013032 104401
 013034 014770
 013036 000745
 013040 000002

INSTRG: MOV @ (SP), MSG
 ADD #2, (SP)
 INSTR1: TYPE
 MSG: 0
 MOV @INBUF, R4
 MOV #7, R3
 1: TSTB @TKCSR
 BPL 1:
 MOVB @TKDBR, (R4)
 BICB #200, (R4)
 CMPB (R4), #15
 BEQ INSTR2
 MOVB @TKVBR, @TPDBR
 2: TSTB @TPCSR
 BPL 2:
 DEC R3
 BNE 1:
 INSTR2: TYPE
 MOVM
 BR INSTR1
 INSTR2: RTI

1 013042

.PARAMS

;CONVERT ASCII STRING TO OCTAL

; 3

013042 011605
 013044 012567 000146
 013050 012567 000144
 013054 012567 000142
 013060 112567 000140
 013064 112567 000135
 013070 010516
 013072 005005
 013074 012704 015160
 013100 122714 000015
 013104 001420
 013106 121427 000060
 013112 002415
 013114 121427 000067
 013120 003012
 013122 142714 000060
 013126 152405
 013130 122714 000015
 013134 001406
 013136 006305
 013140 006305
 013142 006305
 013144 000760
 013146 104404
 013150 000750

PARAMS: MOV (SP),R5
 MOV (R5)+,LOLIM
 MOV (R5)+,HILIM
 MOV (R5)+,DEVADR
 MOV (R5)+,LOBITS
 MOV (R5)+,ADRCNT
 MOV R5,(SP)
 PARAM1: CLR R5
 MOV #INBUF,R4
 CMPB #15,(R4)
 BEQ PARERR
 1\$: CMPB (R4),#60
 BLT PARERR
 CMPB (R4),#67
 BGT PARERR
 BICB #60,(R4)
 BISB (R4)+,R5
 CMPB #15,(R4)
 BEQ LIMITS
 ASL R5
 ASL R5
 ASL R5
 BR 1\$
 PARERR: INSTER
 BR PARAM1

;TEST TO SEE IF NUMBER IS WITHIN LIMITS

013152 020567 000042
 013156 101373
 013160 020567 000032
 013164 103770
 013166 136705 000032
 013172 001365

LIMITS: CMP R5,HILIM
 BHI PARERR
 CMP R5,LOLIM
 BLO PARERR
 BITB LOBITS,R5
 BNE PARERR

; 3

;STORE NUMBER AT SPECIFIED ADDRESS

013174 016704 000022
 013200 010524
 013202 062705 000002
 013206 105367 000013
 013212 001372
 013214 000002
 013216 000000
 013220 000000
 013222 000000
 013224 000000
 013225

1\$: MOV DEVADR,R4
 MOV R5,(R4)+
 ADD #2,R5
 DECB ADRCNT
 BNE 1\$
 RTI
 LOLIM: 0
 HILIM: 0
 DEVADR: 0
 LOBITS: 0
 ADRCNT=LOBITS+1

013226

.OCTASC

;CONVERT OCTAL NUMBER TO ASCII AND OUTPUT TO TELEPRINTER

013226 017601 000000
 013232 062716 000002
 013236 012167 000130
 013242 112167 000126
 013246 112167 000123
 013252 013167 000120
 013256 016704 000114
 013262 116705 000106
 013266 012700 015172
 013272 010403
 013274 042703 177770
 013300 062703 000260
 013304 110320
 013306 006204
 013310 006204
 013312 006204
 013314 005305
 013316 001365
 013320 012703 015204
 013324 114023
 013326 105367 000042
 013332 001374
 013334 105767 000035
 013340 001405
 013342 112723 000240
 013346 105367 000023
 013352 001373
 013354 105013
 013356 104401
 013360 015204
 013362 005367 000004
 013366 001325
 013370 000002
 013372 000000
 013374 000000
 013375 013375
 013376 000000

OCTASN: MOV @ (SP), R1
 ADD @2, (SP)
 MOV (R1)+, WRDCNT
 1\$: MOV (R1)+, CHRCNT
 MOV (R1)+, SPACNT
 MOV @ (R1)+, BINWRD
 2\$: MOV BINWRD, R4
 MOV CHRCNT, R5
 MOV @TEMP, R0
 3\$: MOV R4, R3
 BIC @177770, R3
 ADD @260, R3
 MOV R3, (R0)+
 ASR R4
 ASR R4
 ASR R4
 DEC R5
 BNE 3\$
 MOV @MDATA, R3
 4\$: MOV -(R0), (R3)+
 DECB CHRCNT
 BNE 4\$
 TSTB SPACNT
 BEQ 6\$
 5\$: MOV @240, (R3)+
 DECB SPACNT
 BNE 5\$
 6\$: CLRB (R3)
 TYPE
 MDATA
 DEC WRDCNT
 BNE 1\$
 RTI
 WRDCNT: 0
 CHRCNT: 0
 SPACNT=CHRCNT+1
 BINWRD: 0

; 5

; 3

013400

CCLRALL

;CLEAR ALL BYTE COUNT AND BUS ADDRESS REGISTERS

013400	012700	000020		CLRALL: MOV	#20,R0		;SET UP TO CLEAR 16
013404	005077	000136		1+: CLR	@DH3A		;CLEAR BUS ADDRESS
013410	005077	000134		CLR	@DHBC		;CLEAR BYTE COUNT
013414	005277	000120		INC	@DHSCR		;ADVANCE LINE NUMBER
013420	005300			DEC	R0		;CONTINUE IF NOT DONE
013422	001370			BNE	1+		
013424	000207			RTS	PC		;RETURN TO CALLING ROUTINE
2 013426				SSETALL			

				;SET BYTE COUNT FOR ALL LINES TO 400			
				;SET BUS ADDRESS FOR ALL LINES TO TBUF			
				;CLEAR EXPECTED CHARACTER BUFFERS			
				;SET LINE ACTIVE BITS FOR ALL LINES			

013426	012700	000020		SETALL: MOV	#20,R0		;SET UP TO LOAD 16
							;BYTE COUNT AND BUS ADDRESS
							;MEMORY LOCATIONS
013432	005001			CLR	R1		;SET UP TO GENERATE EXPECTED
							;RECEIVED CHARACTER BUFFER
013434	012702	000200		MOV	#200,R2		;WILL BE HIGH BYTE
							;OF EXPECTED RECEIVED CHARACTER
013440	012703	000001		MOV	#1,R3		;OFFSET FOR HIGH BYTE
013444	012777	013646	000074	1+: MOV	@TBUF,@DH3A		;LOAD BUS ADDRESS
013452	012777	177400	000070	MOV	#-400,@DHBC		;LOAD BYTE COUNT
013460	012777	031403	000056	MOV	#31403,@DHLPR		;SET LINE SPEED TO 4800 BAUD
013466	105061	014246		CLRB	RBUF(R1)		
							;RECEIVED CHARACTER
013472	110263	014246		MOVB	R2,RBUF(R3)		;LOAD HIGH BYTE
013476	005277	000036		INC	@DHSCR		;ADVANCE LINE NUMBER TO NEXT LINE
013502	005202			INC	R2		;UPDATE POINTERS
013504	062701	000002		ADD	#2,R1		
013510	062703	000002		ADD	#2,R3		
013514	005300			DEC	R0		;CONTINUE IF NOT DONE
013516	001352			BNE	1+		
013520	012767	177777	000114	MOV	#-1,LINACT		;SET ACTIVE FLAGS FOR ALL LINES
013526	000207			RTS	PC		;RETURN TO CALLING ROUTINE

```
1 013530      .POINT  +/DHSCR,DHNRC,DHLPR,DHBA,DHBC,DHBAR,DHBCR,DHSSR,DHSLR,DHRVEC,DHRLVL,DHTVEC,DHTLVL/
                  ;INDIRECT POINTERS
                  ; 3

013530 177560   TKCSR: 177560
013532 177562   TKDBR: 177562
013534 177564   TPCSR: 177564
013536 177566   TPDBR: 177566
TLVL> .IRP      A      <DHSCR,DHNRC,DHLPR,DHBA,DHBC,DHBAR,DHBCR,DHSSR,DHSLR,DHRVEC,DHRLVL,DHTVEC,DH
                  A:      0
                  .ENDM
013540 000000   DHSCR: 0
013542 000000   DHNRC: 0
013544 000000   DHLPR: 0
013546 000000   DHBA: 0
013550 000000   DHBC: 0
013552 000000   DHBAR: 0
013554 000000   DHBCR: 0
013556 000000   DHSSR: 0
013560 000000   DHSLR: 0
013562 000000   DHRVEC: 0
013564 000000   DHRLVL: 0
013566 000000   DHTVEC: 0
013570 000000   DHTLVL: 0
2 013572      .VARIA  +/ENDFLG,LINACT,AEACT/
                  ;PROGRAM VARIABLES

013572 000000   ERRFLG: 0      ;ERROR FLAG
013574 000000   PASCNT: 0      ;PASS COUNT
013576 000000   ERRCNT: 0      ;ERROR COUNT
013600 000000   RETRN: 0       ;SCOPE RETURN ADDRESS FOR TEST LOOPING
013602 000000   ESCAPE: 0      ;ADDRESS FOR ERROR ESCAPE
013604 000000   FREEZ1: 0      ;DATA LOOPING RETURN ADDRESS
013606 000000   ICOUNT: 0      ;ITERATION COUNT FOR TEST IN PROGRESS
013610 000000   LPCNT: 0       ;NUMBER OF ITERATIONS THIS TEST
013612 000000   SAVR0: 0       ;R0 SAVE AREA
013614 000000   SAVR1: 0       ;R1 SAVE AREA
013616 000000   SAVR2: 0       ;R2 SAVE AREA
013620 000000   SAVR3: 0       ;R3 SAVE ARE
013622 000000   SAVR4: 0       ;R4 SAVE AREA
013624 000000   SAVR5: 0       ;R5 SAVE AREA
013626 000000   SAVSP: 0       ;STACK POINTER SAVE AREA
013630 000000   SAVPC: 0       ;CALLING ROUTINE SAVE AREA
013632 000000   INIFLG: 0      ;PROGRAM INITIALIZATION FLAG
013634 000000   STFLG: 0       ;PROGRAM START FLAG
013636 000000   LAST: 0        ;LAST ERROR PC
                  .IRP      A      <ENDFLG,LINACT,AEACT>
                  A:      0
                  .ENDM
013640 000000   ENDFLG: 0
013642 000000   LINACT: 0
013644 000000   AEACT: 0
```

	000001	TDAT=1
4 013646	000	TBUF: .BYTE 0
5	000377	.REPT 377
6		.BYTE TDAT
7		.NLIST
8		TDAT=TDAT+1
9		.LIST
10		.ENDR
013647	001	.BYTE TDAT
	000002	TDAT=TDAT+1
013650	002	.BYTE TDAT
	000003	TDAT=TDAT+1
013651	003	.BYTE TDAT
	000004	TDAT=TDAT+1
013652	004	.BYTE TDAT
	000005	TDAT=TDAT+1
013653	005	.BYTE TDAT
	000006	TDAT=TDAT+1
013654	006	.BYTE TDAT
	000007	TDAT=TDAT+1
013655	007	.BYTE TDAT
	000010	TDAT=TDAT+1
013656	010	.BYTE TDAT
	000011	TDAT=TDAT+1
013657	011	.BYTE TDAT
	000012	TDAT=TDAT+1
013660	012	.BYTE TDAT
	000013	TDAT=TDAT+1
013661	013	.BYTE TDAT
	000014	TDAT=TDAT+1
013662	014	.BYTE TDAT
	000015	TDAT=TDAT+1
013663	015	.BYTE TDAT
	000016	TDAT=TDAT+1
013664	016	.BYTE TDAT
	000017	TDAT=TDAT+1
013665	017	.BYTE TDAT
	000020	TDAT=TDAT+1
013666	020	.BYTE TDAT
	000021	TDAT=TDAT+1
013667	021	.BYTE TDAT
	000022	TDAT=TDAT+1
013670	022	.BYTE TDAT
	000023	TDAT=TDAT+1
013671	023	.BYTE TDAT
	000024	TDAT=TDAT+1
013672	024	.BYTE TDAT
	000025	TDAT=TDAT+1
013673	025	.BYTE TDAT
	000026	TDAT=TDAT+1
013674	026	.BYTE TDAT
	000027	TDAT=TDAT+1
013675	027	.BYTE TDAT
	000030	TDAT=TDAT+1
013676	030	.BYTE TDAT
	000031	TDAT=TDAT+1
013677	031	.BYTE TDAT

	000032	TDAT=TDAT+1
013700	032	.BYTE TDAT
	000033	TDAT=TDAT+1
013701	033	.BYTE TDAT
	000034	TDAT=TDAT+1
013702	034	.BYTE TDAT
	000035	TDAT=TDAT+1
013703	035	.BYTE TDAT
	000036	TDAT=TDAT+1
013704	036	.BYTE TDAT
	000037	TDAT=TDAT+1
013705	037	.BYTE TDAT
	000040	TDAT=TDAT+1
013706	040	.BYTE TDAT
	000041	TDAT=TDAT+1
013707	041	.BYTE TDAT
	000042	TDAT=TDAT+1
013710	042	.BYTE TDAT
	000043	TDAT=TDAT+1
013711	043	.BYTE TDAT
	000044	TDAT=TDAT+1
013712	044	.BYTE TDAT
	000045	TDAT=TDAT+1
013713	045	.BYTE TDAT
	000046	TDAT=TDAT+1
013714	046	.BYTE TDAT
	000047	TDAT=TDAT+1
013715	047	.BYTE TDAT
	000050	TDAT=TDAT+1
013716	050	.BYTE TDAT
	000051	TDAT=TDAT+1
013717	051	.BYTE TDAT
	000052	TDAT=TDAT+1
013720	052	.BYTE TDAT
	000053	TDAT=TDAT+1
013721	053	.BYTE TDAT
	000054	TDAT=TDAT+1
013722	054	.BYTE TDAT
	000055	TDAT=TDAT+1
013723	055	.BYTE TDAT
	000056	TDAT=TDAT+1
013724	056	.BYTE TDAT
	000057	TDAT=TDAT+1
013725	057	.BYTE TDAT
	000060	TDAT=TDAT+1
013726	060	.BYTE TDAT
	000061	TDAT=TDAT+1
013727	061	.BYTE TDAT
	000062	TDAT=TDAT+1
013730	062	.BYTE TDAT
	000063	TDAT=TDAT+1
013731	063	.BYTE TDAT
	000064	TDAT=TDAT+1
013732	064	.BYTE TDAT
	000065	TDAT=TDAT+1
013733	065	.BYTE TDAT
	000066	TDAT=TDAT+1

013734	066	.BYTE TDAT
	000067	TDAT=TDAT+1
013735	067	.BYTE TDAT
	000070	TDAT=TDAT+1
013736	070	.BYTE TDAT
	000071	TDAT=TDAT+1
013737	071	.BYTE TDAT
	000072	TDAT=TDAT+1
013740	072	.BYTE TDAT
	000073	TDAT=TDAT+1
013741	073	.BYTE TDAT
	000074	TDAT=TDAT+1
013742	074	.BYTE TDAT
	000075	TDAT=TDAT+1
013743	075	.BYTE TDAT
	000076	TDAT=TDAT+1
013744	076	.BYTE TDAT
	000077	TDAT=TDAT+1
013745	077	.BYTE TDAT
	000100	TDAT=TDAT+1
013746	100	.BYTE TDAT
	000101	TDAT=TDAT+1
013747	101	.BYTE TDAT
	000102	TDAT=TDAT+1
013750	102	.BYTE TDAT
	000103	TDAT=TDAT+1
013751	103	.BYTE TDAT
	000104	TDAT=TDAT+1
013752	104	.BYTE TDAT
	000105	TDAT=TDAT+1
013753	105	.BYTE TDAT
	000106	TDAT=TDAT+1
013754	106	.BYTE TDAT
	000107	TDAT=TDAT+1
013755	107	.BYTE TDAT
	000110	TDAT=TDAT+1
013756	110	.BYTE TDAT
	000111	TDAT=TDAT+1
013757	111	.BYTE TDAT
	000112	TDAT=TDAT+1
013760	112	.BYTE TDAT
	000113	TDAT=TDAT+1
013761	113	.BYTE TDAT
	000114	TDAT=TDAT+1
013762	114	.BYTE TDAT
	000115	TDAT=TDAT+1
013763	115	.BYTE TDAT
	000116	TDAT=TDAT+1
013764	116	.BYTE TDAT
	000117	TDAT=TDAT+1
013765	117	.BYTE TDAT
	000120	TDAT=TDAT+1
013766	120	.BYTE TDAT
	000121	TDAT=TDAT+1
013767	121	.BYTE TDAT
	000122	TDAT=TDAT+1
013770	122	.BYTE TDAT

013771	000123	TDAT=TDAT+1
	123	.BYTE TDAT
013772	000124	TDAT=TDAT+1
	124	.BYTE TDAT
013773	000125	TDAT=TDAT+1
	125	.BYTE TDAT
013774	000126	TDAT=TDAT+1
	126	.BYTE TDAT
013775	000127	TDAT=TDAT+1
	127	.BYTE TDAT
013776	000130	TDAT=TDAT+1
	130	.BYTE TDAT
013777	000131	TDAT=TDAT+1
	131	.BYTE TDAT
014000	000132	TDAT=TDAT+1
	132	.BYTE TDAT
014001	000133	TDAT=TDAT+1
	133	.BYTE TDAT
014002	000134	TDAT=TDAT+1
	134	.BYTE TDAT
014003	000135	TDAT=TDAT+1
	135	.BYTE TDAT
014004	000136	TDAT=TDAT+1
	136	.BYTE TDAT
014005	000137	TDAT=TDAT+1
	137	.BYTE TDAT
014006	000140	TDAT=TDAT+1
	140	.BYTE TDAT
014007	000141	TDAT=TDAT+1
	141	.BYTE TDAT
014010	000142	TDAT=TDAT+1
	142	.BYTE TDAT
014011	000143	TDAT=TDAT+1
	143	.BYTE TDAT
014012	000144	TDAT=TDAT+1
	144	.BYTE TDAT
014013	000145	TDAT=TDAT+1
	145	.BYTE TDAT
014014	000146	TDAT=TDAT+1
	146	.BYTE TDAT
014015	000147	TDAT=TDAT+1
	147	.BYTE TDAT
014016	000150	TDAT=TDAT+1
	150	.BYTE TDAT
014017	000151	TDAT=TDAT+1
	151	.BYTE TDAT
014020	000152	TDAT=TDAT+1
	152	.BYTE TDAT
014021	000153	TDAT=TDAT+1
	153	.BYTE TDAT
014022	000154	TDAT=TDAT+1
	154	.BYTE TDAT
014023	000155	TDAT=TDAT+1
	155	.BYTE TDAT
014024	000156	TDAT=TDAT+1
	156	.BYTE TDAT
	000157	TDAT=TDAT+1

014025	157	.BYTE TDAT
	000160	TDAT=TDAT+1
014026	160	.BYTE TDAT
	000161	TDAT=TDAT+1
014027	161	.BYTE TDAT
	000162	TDAT=TDAT+1
014030	162	.BYTE TDAT
	000163	TDAT=TDAT+1
014031	163	.BYTE TDAT
	000164	TDAT=TDAT+1
014032	164	.BYTE TDAT
	000165	TDAT=TDAT+1
014033	165	.BYTE TDAT
	000166	TDAT=TDAT+1
014034	166	.BYTE TDAT
	000167	TDAT=TDAT+1
014035	167	.BYTE TDAT
	000170	TDAT=TDAT+1
014036	170	.BYTE TDAT
	000171	TDAT=TDAT+1
014037	171	.BYTE TDAT
	000172	TDAT=TDAT+1
014040	172	.BYTE TDAT
	000173	TDAT=TDAT+1
014041	173	.BYTE TDAT
	000174	TDAT=TDAT+1
014042	174	.BYTE TDAT
	000175	TDAT=TDAT+1
014043	175	.BYTE TDAT
	000176	TDAT=TDAT+1
014044	176	.BYTE TDAT
	000177	TDAT=TDAT+1
014045	177	.BYTE TDAT
	000200	TDAT=TDAT+1
014046	200	.BYTE TDAT
	000201	TDAT=TDAT+1
014047	201	.BYTE TDAT
	000202	TDAT=TDAT+1
014050	202	.BYTE TDAT
	000203	TDAT=TDAT+1
014051	203	.BYTE TDAT
	000204	TDAT=TDAT+1
014052	204	.BYTE TDAT
	000205	TDAT=TDAT+1
014053	205	.BYTE TDAT
	000206	TDAT=TDAT+1
014054	206	.BYTE TDAT
	000207	TDAT=TDAT+1
014055	207	.BYTE TDAT
	000210	TDAT=TDAT+1
014056	210	.BYTE TDAT
	000211	TDAT=TDAT+1
014057	211	.BYTE TDAT
	000212	TDAT=TDAT+1
014060	212	.BYTE TDAT
	000213	TDAT=TDAT+1
014061	213	.BYTE TDAT

	000214	TDAT=TDAT+1
014062	214	.BYTE TDAT
	000215	TDAT=TDAT+1
014063	215	.BYTE TDAT
	000216	TDAT=TDAT+1
014064	216	.BYTE TDAT
	000217	TDAT=TDAT+1
014065	217	.BYTE TDAT
	000220	TDAT=TDAT+1
014066	220	.BYTE TDAT
	000221	TDAT=TDAT+1
014067	221	.BYTE TDAT
	000222	TDAT=TDAT+1
014070	222	.BYTE TDAT
	000223	TDAT=TDAT+1
014071	223	.BYTE TDAT
	000224	TDAT=TDAT+1
014072	224	.BYTE TDAT
	000225	TDAT=TDAT+1
014073	225	.BYTE TDAT
	000226	TDAT=TDAT+1
014074	226	.BYTE TDAT
	000227	TDAT=TDAT+1
014075	227	.BYTE TDAT
	000230	TDAT=TDAT+1
014076	230	.BYTE TDAT
	000231	TDAT=TDAT+1
014077	231	.BYTE TDAT
	000232	TDAT=TDAT+1
014100	232	.BYTE TDAT
	000233	TDAT=TDAT+1
014101	233	.BYTE TDAT
	000234	TDAT=TDAT+1
014102	234	.BYTE TDAT
	000235	TDAT=TDAT+1
014103	235	.BYTE TDAT
	000236	TDAT=TDAT+1
014104	236	.BYTE TDAT
	000237	TDAT=TDAT+1
014105	237	.BYTE TDAT
	000240	TDAT=TDAT+1
014106	240	.BYTE TDAT
	000241	TDAT=TDAT+1
014107	241	.BYTE TDAT
	000242	TDAT=TDAT+1
014110	242	.BYTE TDAT
	000243	TDAT=TDAT+1
014111	243	.BYTE TDAT
	000244	TDAT=TDAT+1
014112	244	.BYTE TDAT
	000245	TDAT=TDAT+1
014113	245	.BYTE TDAT
	000246	TDAT=TDAT+1
014114	246	.BYTE TDAT
	000247	TDAT=TDAT+1
014115	247	.BYTE TDAT
	000250	TDAT=TDAT+1

014116	250	.BYTE TDAT
	000251	TDAT=TDAT+1
014117	251	.BYTE TDAT
	000252	TDAT=TDAT+1
014120	252	.BYTE TDAT
	000253	TDAT=TDAT+1
014121	253	.BYTE TDAT
	000254	TDAT=TDAT+1
014122	254	.BYTE TDAT
	000255	TDAT=TDAT+1
014123	255	.BYTE TDAT
	000256	TDAT=TDAT+1
014124	256	.BYTE TDAT
	000257	TDAT=TDAT+1
014125	257	.BYTE TDAT
	000260	TDAT=TDAT+1
014126	260	.BYTE TDAT
	000261	TDAT=TDAT+1
014127	261	.BYTE TDAT
	000262	TDAT=TDAT+1
014130	262	.BYTE TDAT
	000263	TDAT=TDAT+1
014131	263	.BYTE TDAT
	000264	TDAT=TDAT+1
014132	264	.BYTE TDAT
	000265	TDAT=TDAT+1
014133	265	.BYTE TDAT
	000266	TDAT=TDAT+1
014134	266	.BYTE TDAT
	000267	TDAT=TDAT+1
014135	267	.BYTE TDAT
	000270	TDAT=TDAT+1
014136	270	.BYTE TDAT
	000271	TDAT=TDAT+1
014137	271	.BYTE TDAT
	000272	TDAT=TDAT+1
014140	272	.BYTE TDAT
	000273	TDAT=TDAT+1
014141	273	.BYTE TDAT
	000274	TDAT=TDAT+1
014142	274	.BYTE TDAT
	000275	TDAT=TDAT+1
014143	275	.BYTE TDAT
	000276	TDAT=TDAT+1
014144	276	.BYTE TDAT
	000277	TDAT=TDAT+1
014145	277	.BYTE TDAT
	000300	TDAT=TDAT+1
014146	300	.BYTE TDAT
	000301	TDAT=TDAT+1
014147	301	.BYTE TDAT
	000302	TDAT=TDAT+1
014150	302	.BYTE TDAT
	000303	TDAT=TDAT+1
014151	303	.BYTE TDAT
	000304	TDAT=TDAT+1
014152	304	.BYTE TDAT

014153	000305	TDAT=TDAT.1
	305	.BYTE TDAT
014154	000306	TDAT=TDAT.1
	306	.BYTE TDAT
014155	000307	TDAT=TDAT.1
	307	.BYTE TDAT
014156	000310	TDAT=TDAT.1
	310	.BYTE TDAT
014157	000311	TDAT=TDAT.1
	311	.BYTE TDAT
014160	000312	TDAT=TDAT.1
	312	.BYTE TDAT
014161	000313	TDAT=TDAT.1
	313	.BYTE TDAT
014162	000314	TDAT=TDAT.1
	314	.BYTE TDAT
014163	000315	TDAT=TDAT.1
	315	.BYTE TDAT
014164	000316	TDAT=TDAT.1
	316	.BYTE TDAT
014165	000317	TDAT=TDAT.1
	317	.BYTE TDAT
014166	000320	TDAT=TDAT.1
	320	.BYTE TDAT
014167	000321	TDAT=TDAT.1
	321	.BYTE TDAT
014170	000322	TDAT=TDAT.1
	322	.BYTE TDAT
014171	000323	TDAT=TDAT.1
	323	.BYTE TDAT
014172	000324	TDAT=TDAT.1
	324	.BYTE TDAT
014173	000325	TDAT=TDAT.1
	325	.BYTE TDAT
014174	000326	TDAT=TDAT.1
	326	.BYTE TDAT
014175	000327	TDAT=TDAT.1
	327	.BYTE TDAT
014176	000330	TDAT=TDAT.1
	330	.BYTE TDAT
014177	000331	TDAT=TDAT.1
	331	.BYTE TDAT
014200	000332	TDAT=TDAT.1
	332	.BYTE TDAT
014201	000333	TDAT=TDAT.1
	333	.BYTE TDAT
014202	000334	TDAT=TDAT.1
	334	.BYTE TDAT
014203	000335	TDAT=TDAT.1
	335	.BYTE TDAT
014204	000336	TDAT=TDAT.1
	336	.BYTE TDAT
014205	000337	TDAT=TDAT.1
	337	.BYTE TDAT
014206	000340	TDAT=TDAT.1
	340	.BYTE TDAT
	000341	TDAT=TDAT.1

014207	341	.BYTE TDAT
	000342	TDAT=TDAT+1
014210	342	.BYTE TDAT
	000343	TDAT=TDAT+1
014211	343	.BYTE TDAT
	000344	TDAT=TDAT+1
014212	344	.BYTE TDAT
	000345	TDAT=TDAT+1
014213	345	.BYTE TDAT
	000346	TDAT=TDAT+1
014214	346	.BYTE TDAT
	000347	TDAT=TDAT+1
014215	347	.BYTE TDAT
	000350	TDAT=TDAT+1
014216	350	.BYTE TDAT
	000351	TDAT=TDAT+1
014217	351	.BYTE TDAT
	000352	TDAT=TDAT+1
014220	352	.BYTE TDAT
	000353	TDAT=TDAT+1
014221	353	.BYTE TDAT
	000354	TDAT=TDAT+1
014222	354	.BYTE TDAT
	000355	TDAT=TDAT+1
014223	355	.BYTE TDAT
	000356	TDAT=TDAT+1
014224	356	.BYTE TDAT
	000357	TDAT=TDAT+1
014225	357	.BYTE TDAT
	000360	TDAT=TDAT+1
014226	360	.BYTE TDAT
	000361	TDAT=TDAT+1
014227	361	.BYTE TDAT
	000362	TDAT=TDAT+1
014230	362	.BYTE TDAT
	000363	TDAT=TDAT+1
014231	363	.BYTE TDAT
	000364	TDAT=TDAT+1
014232	364	.BYTE TDAT
	000365	TDAT=TDAT+1
014233	365	.BYTE TDAT
	000366	TDAT=TDAT+1
014234	366	.BYTE TDAT
	000367	TDAT=TDAT+1
014235	367	.BYTE TDAT
	000370	TDAT=TDAT+1
014236	370	.BYTE TDAT
	000371	TDAT=TDAT+1
014237	371	.BYTE TDAT
	000372	TDAT=TDAT+1
014240	372	.BYTE TDAT
	000373	TDAT=TDAT+1
014241	373	.BYTE TDAT
	000374	TDAT=TDAT+1
014242	374	.BYTE TDAT
	000375	TDAT=TDAT+1
014243	375	.BYTE TDAT

	014244	000376	TDAT=TDAT+1
		376	.BYTE TDAT
		000377	TDAT=TDAT+1
	014245	377	.BYTE TDAT
		000400	TDAT=TDAT+1
11			.EVEN
12	014246	000000	RBUF: 0
13		014310	. = .+40

```
1      .MACRO WORDS WNAME,K,DATA
2      'WNAME'K': DATA
3      .ENDM WORDS
5      000020 K=KX
6      000000 DATA=DATA
7      000000 KX=0
9      000020 .REPT 20
10     .NLIST
11     DATA=KX*400+100377
12     .LIST
13     WORDS +/TWRD/,\KX,\DATA
14     .NLIST
15     KX=KX+1
16     .LIST
17     .ENDR
      DATA=KX*400+100377
014310 WORDS +/TWRD/,\KX,\DATA
014310 100377 TWRD0: 100377
      000001 KX=KX+1
      100777 DATA=KX*400+100377
014312 WORDS +/TWRD/,\KX,\DATA
^14312 100777 TWRD1: 100777
      000002 KX=KX+1
      101377 DATA=KX*400+100377
014314 WORDS +/TWRD/,\KX,\DATA
014314 101377 TWRD2: 101377
      000003 KX=KX+1
      101777 DATA=KX*400+100377
014316 WORDS +/TWRD/,\KX,\DATA
014316 101777 TWRD3: 101777
      000004 KX=KX+1
      102377 DATA=KX*400+100377
014320 WORDS +/TWRD/,\KX,\DATA
014320 102377 TWRD4: 102377
      000005 KX=KX+1
      102777 DATA=KX*400+100377
014322 WORDS +/TWRD/,\KX,\DATA
014322 102777 TWRD5: 102777
      000006 KX=KX+1
      103377 DATA=KX*400+100377
014324 WORDS +/TWRD/,\KX,\DATA
014324 103377 TWRD6: 103377
      000007 KX=KX+1
      103777 DATA=KX*400+100377
014326 WORDS +/TWRD/,\KX,\DATA
014326 103777 TWRD7: 103777
      000010 KX=KX+1
      104377 DATA=KX*400+100377
014330 WORDS +/TWRD/,\KX,\DATA
014330 104377 TWRD10: 104377
      000011 KX=KX+1
      104777 DATA=KX*400+100377
014332 WORDS +/TWRD/,\KX,\DATA
014332 104777 TWRD11: 104777
      000012 KX=KX+1
      105377 DATA=KX*400+100377
014334 WORDS +/TWRD/,\KX,\DATA
```

014334	105377	TWRD12: 105377
	000013	KX=KX+1
	105777	DATAX=KX*400+100377
014336		WORDS +/TWRD/, \KX, \DATAX
014336	105777	TWRD13: 105777
	000014	KX=KX+1
	106377	DATAX=KX*400+100377
014340		WORDS +/TWRD/, \KX, \DATAX
014340	106377	TWRD14: 106377
	000015	KX=KX+1
	106777	DATAX=KX*400+100377
014342		WORDS +/TWRD/, \KX, \DATAX
014342	106777	TWRD15: 106777
	000016	KX=KX+1
	107377	DATAX=KX*400+100377
014344		WORDS +/TWRD/, \KX, \DATAX
014344	107377	TWRD16: 107377
	000017	KX=KX+1
	107777	DATAX=KX*400+100377
014346		WORDS +/TWRD/, \KX, \DATAX
014346	107777	TWRD17: 107777
	000020	KX=KX+1
19	107777	DATA=DATAX
20	000020	K=KX
21	000000	DATAX=0
22	000000	KX=0
24	000020	.REPT 20
25		WORDS +/RCNT/, \KX, \DATAX
26		.NLIST
27		KX=KX+1
28		.LIST
29		.ENDR
014350		WORDS +/RCNT/, \KX, \DATAX
014350	000000	RCNT0: 0
	000001	KX=KX+1
014352		WORDS +/RCNT/, \KX, \DATAX
014352	000000	RCNT1: 0
	000002	KX=KX+1
014354		WORDS +/RCNT/, \KX, \DATAX
014354	000000	RCNT2: 0
	000003	KX=KX+1
014356		WORDS +/RCNT/, \KX, \DATAX
014356	000000	RCNT3: 0
	000004	KX=KX+1
014360		WORDS +/RCNT/, \KX, \DATAX
014360	000000	RCNT4: 0
	000005	KX=KX+1
014362		WORDS +/RCNT/, \KX, \DATAX
014362	000000	RCNT5: 0
	000006	KX=KX+1
014364		WORDS +/RCNT/, \KX, \DATAX
014364	000000	RCNT6: 0
	000007	KX=KX+1
014366		WORDS +/RCNT/, \KX, \DATAX
014366	000000	RCNT7: 0
	000010	KX=KX+1
014370		WORDS +/RCNT/, \KX, \DATAX

014370	000000	RCNT10: 0
	000011	KX=KX+1
014372		WORDS +/RCNT/, \KX, \DATA
014372	000000	RCNT11: 0
	000012	KX=KX+1
014374		WORDS +/RCNT/, \KX, \DATA
014374	000000	RCNT12: 0
	000013	KX=KX+1
014376		WORDS +/RCNT/, \KX, \DATA
014376	000000	RCNT13: 0
	000014	KX=KX+1
014400		WORDS +/RCNT/, \KX, \DATA
014400	000000	RCNT14: 0
	000015	KX=KX+1
014402		WORDS +/RCNT/, \KX, \DATA
014402	000000	RCNT15: 0
	000016	KX=KX+1
014404		WORDS +/RCNT/, \KX, \DATA
014404	000000	RCNT16: 0
	000017	KX=KX+1
014406		WORDS +/RCNT/, \KX, \DATA
014406	000000	RCNT17: 0
	000020	KX=KX+1
31	000000	DATA=DATA
32	000020	K=KX
33	0000C0	DATA=0
34	000000	KX=0
36	000020	.REPT 20
37		WORDS +/RDCT/, \KX, \DATA
38		.NLIST
39		KX=KX+1
40		.LIST
41		.ENDR
014410		WORDS +/RDCT/, \KX, \DATA
014410	000000	RDCT0: 0
	000001	KX=KX+1
014412		WORDS +/RDCT/, \KX, \DATA
014412	000000	RDCT1: 0
	000002	KX=KX+1
014414		WORDS +/RDCT/, \KX, \DATA
014414	000000	RDCT2: 0
	000003	KX=KX+1
014416		WORDS +/RDCT/, \KX, \DATA
014416	000000	RDCT3: 0
	000004	KX=KX+1
014420		WORDS +/RDCT/, \KX, \DATA
014420	000000	RDCT4: 0
	000005	KX=KX+1
014422		WORDS +/RDCT/, \KX, \DATA
014422	000000	RDCT5: 0
	000006	KX=KX+1
014424		WORDS +/RDCT/, \KX, \DATA
014424	000000	RDCT6: 0
	000007	KX=KX+1
014426		WORDS +/RDCT/, \KX, \DATA
014426	000000	RDCT7: 0
	000010	KX=KX+1

014430		WORDS	↑/RDCT/,\KX,\DATA
014430	000000	RDCT10:	0
	000011	KX=KX+1	
014432		WORDS	↑/RDCT/,\KX,\DATA
014432	000000	RDCT11:	0
	000012	KX=KX+1	
014434		WORDS	↑/RDCT/,\KX,\DATA
014434	000000	RDCT12:	0
	000013	KX=KX+1	
014436		WORDS	↑/RDCT/,\KX,\DATA
014436	000000	RDCT13:	0
	000014	KX=KX+1	
014440		WORDS	↑/RDCT/,\KX,\DATA
014440	000000	RDCT14:	0
	000015	KX=KX+1	
014442		WORDS	↑/RDCT/,\KX,\DATA
014442	000000	RDCT15:	0
	000016	KX=KX+1	
014444		WORDS	↑/RDCT/,\KX,\DATA
014444	000000	RDCT16:	0
	000017	KX=KX+1	
014446		WORDS	↑/RDCT/,\KX,\DATA
014446	000000	RDCT17:	0
	000020	KX=KX+1	
42 014450	000001	LINBIT:	1
43 014452	000002		2
44 014454	000004		4
45 014456	000010		10
46 014460	000020		20
47 014462	000040		40
48 014464	000100		100
49 014466	000200		200
50 014470	000400		400
51 014472	001000		1000
52 014474	002000		2000
53 014476	004000		4000
54 014500	010000		10000
55 014502	020000		20000
56 014504	040000		40000
57 014506	100000		100000

1 014510

.PFAIL

;ENTER HERE ON POWER FAILURE

```

014510 010046      PFAIL:  MOV    R0,-(SP)          ;SAVE R0-R5 ON PROCESSOR STACK
014512 010146      MOV    R1,-(SP)
014514 010246      MOV    R2,-(SP)
014516 010346      MOV    R3,-(SP)
014520 010446      MOV    R4,-(SP)
014522 010546      MOV    R5,-(SP)
014524 016746 163274 MOV    24,-(SP)
014530 010667 177072 MOV    SP,SAVSP          ;SAVE STACK POINTER
014534 012767 014546 163262 MOV    @RESTART,24      ;SET UP FOR POWER UP TRAP
014542 000000      HALT                                ;HALT ON POWER DOWN NORMAL
014544 000777      BR      .

```

;PROCESSOR WILL TRAP HERE WHEN POWER IS RESTORED

```

014546 016706 177054  RESTAR: MOV    SAVSP,SP          ;RESTORE STACK POINTER
014552 012605      MOV    (SP)+,R5          ;RESTORE R0-R5
014554 012604      MOV    (SP)+,R4
014556 012603      MOV    (SP)+,R3
014560 012602      MOV    (SP)+,R2
014562 012601      MOV    (SP)+,R1
014564 012600      MOV    (SP)+,R0
014566 012767 014510 163230 MOV    @PFAIL,24      ;SET UP FOR POWER FAILURE
014574 012767 000340 163174 MOV    @340,PS
014602 012706 015644      MOV    @STACK,SP
014606 005067 000360      CLR    TEMP
014612 005267 000354      INC    TEMP
014616 001375      BNE     .-4
014620 104401      TYPE
014622 014774      MCRLF                      ; 5
014624 104402      OCTASC                      ; 5
014626 014650      PFTAB
014630 104401      TYPE
014632 014777      MPFAIL
014634 005067 176732      CLR    ERRFLG
014640 005067 176772      CLR    LAST
014644 000177 176730      JMP    @RETRN
014650 000001      PFTAB: 1
014652 000006 000002      6,2
014656 013600      RETRN

```

014660				.MSG	↑/DH11 AUTO ECHO TEST/./↑/CZDHH-CO/
014660	015	012	012	MTITLE:	.ASCIZ <15><12><12>/DH11 AUTO ECHO TEST /<15><12>
014663	104	110	061		
014666	061	040	101		
014671	125	124	117		
014674	040	105	103		
014677	110	117	040		
014702	124	105	123		
014705	124	040	015		
014710	012	000			
014712	015	012	126	MVECTO:	.ASCIZ <15><12>/VECTOR ADDRESS-/
014715	105	103	124		
014720	117	122	040		
014723	101	104	104		
014726	122	105	123		
014731	123	055	000		
014734	015	012	103	MREGAD:	.ASCIZ <15><12>/CONTROL REGISTER ADDRESS-/
014737	117	116	124		
014742	122	117	114		
014745	040	122	105		
014750	107	111	123		
014753	124	105	122		
014756	040	101	104		
014761	104	122	105		
014764	123	123	055		
014767	000				
014770	040	040	077	MQM:	.ASCIZ / ?/
014773	000				
014774	015	012	000	MCRLF:	.ASCIZ <15><12>
014777	040	040	120	MPFAIL:	.ASCIZ / POWER FAILURE, PROGRAM RESTART AT TEST IN PROGRESS/
015002	117	127	105		
015005	122	040	106		
015010	101	111	114		
015013	125	122	105		
015016	054	040	120		
015021	122	117	107		
015024	122	101	115		
015027	040	122	105		
015032	123	124	101		
015035	122	124	040		
015040	101	124	040		
015043	124	105	123		
015046	124	040	111		
015051	116	040	120		
015054	122	117	107		
015057	122	105	123		
015062	123	000			
015064	015	012	103	MEPASS:	.ASCIZ <15><12>/CZDHH-CO/
015067	132	104	110		
015072	110	055	103		
015075	060	000			
015077	015	012	120	PASTXT:	.ASCIZ <15><12>/PASS COUNT = /
015102	101	123	123		
015105	040	103	117		
015110	125	116	124		
015113	040	075	040		

```

015116      000
015117      015      012      122 MR:      .ASCIZ  <15><12>/R/
015122      000
015123      015      012      124 MTSTPC: .ASCIZ  <15><12>/TEST PC-/
015126      105      123      124
015131      040      120      103
015134      055      000

      .EVEN
      .EVEN
      .TRPTAB

3 015136

      ;TABLE OF POINTERS FOR TRAP DECODING

015136 012232      TRPTAB: SCOPER
015140 012706      TYPER
015142 013226      OCTASN
015144 012740      INSTRG
015146 013032      INSTRE
015150 013042      PARAMS
015152 012614      SV05P
015154 012654      RS05
015156 012332      SCOP1R
4 015160      .BUFFER

      ;BUFFERS FOR INPUT-OUTPUT

015160 000000      INBUF:  0
015172 000000      .*.+10
015172 000000      TEMP:   0
015204 000000      .*.+10
015204 000000      MDATA:  0
5 015216 015216      .*.+10
      .ERRTAB

      ;TABLE OF POINTERS TO ERROR MESSAGES AND DATA

015216      ERRTAB:
6 015216 015232      EM1
7 015220 015414      DT1
8 015222 015267      EM2
9 015224 015426      DT2
10 015226 015343      EM3
11 015230 015426      DT2
12 015232      101      125      124 EM1:      .ASCIZ  /AUTO ECHO ERROR/<15><12>/EXP      REC/
015235      117      040      105
015240      103      110      117
015243      040      105      122
015246      122      117      122
015251      015      012      105
015254      130      120      040
015257      040      040      040
015262      040      122      105
015265      103      000
13 015267      116      117      116 EM2:      .ASCIZ  /NON ECHOED DATA ERROR/<15><12>/EXP      REC      LINE/
015272      040      105      103
015275      110      117      105

```

	015300	104	040	104		
	015303	101	124	101		
	015306	040	105	122		
	015311	122	117	122		
	015314	015	012	105		
	015317	130	120	040		
	015322	040	040	040		
	015325	040	122	105		
	015330	103	040	040		
	015333	040	040	040		
	015336	114	111	116		
	015341	105	000			
14	015343	105	103	110	EM3: .ASCIZ /ECHOED DATA ERROR/<15><12>/EXP	REC LINE/
	015346	117	105	104		
	015351	040	104	101		
	015354	124	101	040		
	015357	105	122	122		
	015362	117	122	015		
	015365	012	105	130		
	015370	120	040	040		
	015373	040	040	040		
	015376	122	105	103		
	015401	040	040	040		
	015404	040	040	114		
	015407	111	116	105		
	015412	000				
15					.EVEN	
16	015414	000002			DT1: 2	
17	015416	006	002		.BYTE 6.2	
18	015420	013624			SAVR5	
19	015422	006	000		.BYTE 6.0	
20	015424	013622			SAVR4	
21	015426	000003			DT2: 3	
22	015430	006	002		.BYTE 6.2	
23	015432	013624			SAVR5	
24	015434	006	002		.BYTE 6.2	
25	015436	013622			SAVR4	
26	015440	002	002		.BYTE 2.2	
27	015442	013620			SAVR3	
28	015444				.ENDCOD	
	015444	000000			ENDCOD: 0	
29		000001			.END	

ADRCN1 - 013225	ERRTAB 015216	POPRO = 012600	SAVR4 013622	TWRD2 014314
AEACT 013644	ERTAB0 012554	POP1SP= 005726	SAVR5 013624	TWRD3 014316
BEGIN 001306	ESCAPE 013602	POP2SP= 022626	SAVSP 013626	TWRD4 014320
BINWRD 013376	EXITER 012532	PS = 177776	SAV0SP= 104406	TWRD5 014322
BITX = 000000	FREEZ1 013604	PUSHRO= 010046	SCOPE = 104400	TWRD6 014324
BIT00 = 000001	HALTS 012512	PUSH1S= 005746	SCOPE1= 104410	TWRD7 014326
BIT01 = 000002	HILIM 013220	PUSH2S= 024646	SCOPE1R 012332	TYPDAT 012472
BIT02 = 000004	ICOUNT 013606	RBUF 014246	SCOP1R 012332	TYPE = 104401
BIT03 = 000010	INBUF 015160	RCNT0 014350	SETALL 013426	TYPER 012706
BIT04 = 000020	INIFLG 013632	RCNT1 014352	SPACNT= 013375	TYPMSG 012450
BIT05 = 000040	INSTER= 104404	RCNT10 014370	STACK = 015644	T1 001400
BIT06 = 000100	INSTR = 104403	RCNT11 014372	START 001004	T10 003002
BIT07 = 000200	INSTRE 013032	RCNT12 014374	STFLG 013634	T11 003160
BIT08 = 000400	INSTRG 012740	RCNT13 014376	SV05 012622	T12 003336
BIT09 = 001000	INSTR1 012752	RCNT14 014400	SV05P 012614	T13 003514
BIT10 = 002000	INSTR2 013040	RCNT15 014402	SWR 001000	T14 003672
BIT11 = 004000	K = 000020	RCNT16 014404	SW00 = 000001	T15 004050
BIT12 = 010000	KX = 000020	RCNT17 014406	SW01 = 000002	T16 004226
BIT13 = 020000	LAST 013636	RCNT2 014354	SW02 = 000004	T17 004404
BIT14 = 040000	LIGHTS 001002	RCNT3 014356	SW03 = 000010	T2 001556
BIT15 = 100000	LIMITS 013152	RCNT4 014360	SW04 = 000020	T20 004562
CHRCNT 013374	LINACT 013642	RCNT5 014362	SW05 = 000040	T21 004740
CLRALL 013400	LINBIT 014450	RCNT6 014364	SW06 = 000100	T22 005176
DATA = 000000	LINE = 000020	RCNT7 014366	SW08 = 000400	T23 005434
DATABP 012506	LOBITS 013224	RDCT0 014410	SW09 = 001000	T24 005672
DATAX = 000000	LOGICA 012210	RDCT1 014412	SW10 = 002000	T25 006130
DEVADR 013222	LOLIM 013216	RDCT10 014430	SW11 = 004000	T26 006366
DHBA 013546	LPCNT 013610	RDCT11 014432	SW12 = 010000	T27 006624
DHBA 013552	MCRLF 014774	RDCT12 014434	SW13 = 020000	T3 001734
DHBC 013550	MDATA 015204	RDCT13 014436	SW14 = 040000	T30 007062
DHBCR 013554	MEPASS 015064	RDCT14 014440	SW15 = 100000	T31 007320
DHLPR 013544	MPFAIL 014777	RDCT15 014442	TBUF 013646	T32 007556
DHNR 013542	MQM 014770	RDCT16 014444	TDAT = 000400	T33 010014
DHRLVL 013564	MR 015117	RDCT17 014446	TEMP 015172	T34 010252
DHRVEC 013562	MREGAD 014734	RDCT2 014414	TKCSR 013530	T35 010510
DHSCR 013540	MSG 012754	RDCT3 014416	TKDBR 013532	T36 010746
DHSLR 013560	MTITLE 014660	RDCT4 014420	TPCSR 013534	T37 011204
DHSSR 013556	MTSTPC 015123	RDCT5 014422	TPDBR 013536	T4 002112
DHTLVL 013570	MVECTO 014712	RDCT6 014424	TRPOK 012574	T40 011442
DHTVEC 013566	N = 000001	RDCT7 014426	TRPSRV 012562	T41 011700
DT1 015414	OCTASC= 104402	RESREG 012510	TRPTAB 015136	T5 002270
DT2 015426	OCTASN 013226	RESTAR 014546	TWRD0 014310	T6 002446
EM1 015232	PARAM = 104405	RESTR 012220	TWRD1 014312	T7 002624
EM2 015267	PARAMS 013042	RES05 = 104407	TWRD10 014330	VEC1 001164
EM3 015343	PARAM1 013072	RETRN 013600	TWRD11 014332	VEC2 001174
ENDCOD 015444	PARERR 013146	RS05 012654	TWRD12 014334	WRDCNT 013372
ENDFLG 013640	PASARG 012224	SAVPC 013630	TWRD13 014336	X = 000000
EOP 012132	PASCNT 013574	SAVR0 013612	TWRD14 014340	XBIT = 000000
EPRCNT 013576	PASTXT 015077	SAVR1 013614	TWRD15 014342	XLINE = 000020
ERRFLG 013572	PFAIL 014510	SAVR2 013616	TWRD16 014344	XN = 000042
ERRMSG 012470	PFTAB 014650	SAVR3 013620	TWRD17 014346	Y = 000011

ABS. 015446 000
000000 001
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 19200 WORDS (75 PAGES)

