

DH11

OVERLAY FOR ITEP
CZDHLC0

AH-8489C-MC

COPYRIGHT © 75-78

FICHE 1 OF 1

JUN 1978

digital

MADE IN USA



B01

EOF1CVKUAASEQ
PDP8040001
CZDHLCP11

00010000 780519
CZDHLCO DH11 ITEP OVERLAY
23-MAR-78 12:56

PDP10 411
MACY11 30A(1052) 23-MAR-78 13:03 PAGE 2

00010000

780519

SEQ 0001

IDENTIFICATION

PRODUCT CODE: AC-8488C-MC
PRODUCT NAME: CZDHLCO DH11 OVRLY FOR ITEP
PROGRAM DATE: MARCH 1978
MAINTAINER: DIAGNOSTICS
AUTHORS: R A JONES
JOHN EGOLF
FAY BASHAW

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR IT'S AFFILIATED COMPANIES.

COOPYRIGHT (C)1975, 1978 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL
DEC

PDP
DECUS

UNIBUS
DECTAPE

MASSBUSS

1.0 ABSTRACT.

THIS PROGRAM IS DESIGNED AS A MAINTENANCE AID FOR FIELD SERVICE PERSONEL. IT WILL VERIFY THE PROPER OPERATION OF A COMPLETE COMMUNICATION LINK FROM ONE PDP-11 SYSTEM TO ANOTHER OR TO A COMMUNICATION TEST CENTER.

THIS PROGRAM MUST BE USED IN CONJUNCTION WITH THE INTERPROCESSOR TEST PROGRAM(DZITP) ON A PDP-11 SYSTEM WITH A DL-11 INTERFACE.

2.0 REQUIREMENTS.

2.1 EQUIPMENT

- A. PDP-11 SYSTEM WITH 4K OF CORE.
- B. A CZDHLCO DH11 COMMUNICATION INTERFACE.

2.2 STORAGE.

4K OF CORE

3.0 LOADING PROCEDURE

THIS PROGRAM IS IN ABSOLUTE FORMAT.
THE ABS LOADER MUST BE USED TO LOAD THE PROGRAM.

4.0 OPERATING PROCEDURES.

- A. TWO METHODS OF ENTERING PARAMETERS ARE PROVIDED
 - 1. LOAD ADDRESS 200 AND START TO ENTER PARAMS FROM CONSOLE TTY, PROCEED TO SECTION B.
 - 2. LOAD ADDRESS 200 AND SET SWITCH REGISTER BIT 15 BEFORE STARTING TO ENTER PARAMS FROM CONSOLE SWITCHES, PROCEED TO SECTION C.

*THE PROGRAM MAY BE RESTARTED AT LOC 204 (ONCE PARAMETERS HAVE ALREADY BEEN SELECTED)

- B. CONSOLE DIALOGUE PARAMETER INPUT (CURRENT VALUES FOR PARAMETERS ARE FOUND IN OVERLAY)

- 1. THE PROGRAM WILL TYPEOUT THE NAME OF THE VARIABLE OVERLAY.
 - A. IF YOU WISH TO SETUP JUST THE INDICATED OVERLAY, TYPE A CARAGE RETURN
 - B. IF YOU WISH TO SETUP A DN11, TYPE IN DN.
 - C. IF YOU WISH TO SETUP A DM11BB, TYPE IN DMB.

IF DN OR DMB WAS TYPED IN STEP 1 ABOVE THEN THE BUS ADDRESS VECTOR ETC. REFERED TO IN STEPS 2 THRU 7, PERTAIN TO THE DN11 OR DM11BB.

- 2. THE PROGRAM WILL TYPE THE DEFAULT BUS ADDRESS OF THE INTERFACE UNDER TEST.
 - A. TYPE A CAR. RETURN TO USE DEFAULT BUS ADDRESS
 - B. TYPEIN ACTUAL BUS ADDRESS

- 3. THE PROGRAM WILL TYPE OUT THE DEFAULT VECTOR ADDRESS
 - A. TYPE A CAR. RETURN TO USE DEFAULT ADDRESS
 - B. TYPEIN ACTUAL VECTOR ADDRESS

- 4. THE PROGRAM WILL TYPE OUT THE DEFAULT INTERFACE PRIORITY
NOTE: 200=PRIO 4, 240=PRIO 5, 300=PRIO 6, ETC.

- A. TYPE A CAR. RETURN TO USE DEFAULT VALUE
- B. TYPEIN ACTUAL VALUE
- 5. THE PROGRAM WILL TYPEOUT THE DEFAULT VALUE OF PARAM#1
IF REQUIRED BY THE ISR. (SEE SECT. 10.0 IN OVERLAY LISTING FOR PARAMETER DESCRIPTION)
 - A. TYPE A CAR. RETURN TO USE DEFAULT VALUE
 - B. TYPEIN ACTUAL VALUE
- 6. THE PROGRAM WILL TYPEOUT THE DEFAULT VALUE OF PARAM#2
IF REQUIRED BY THE ISR.
 - A. TYPE A CAR. RETURN TO USE DEFAULT VALUE
 - B. ENTER ACTUAL VALUE
- 7. THE PROGRAM WILL TYPEOUT THE DEFAULT VALUE OF PARAM#3
IF REQUIRED BY THE OVERLAY.
 - A. TYPE A CAR. RETURN TO USE DEFAULT VALUE
THE DN-11 WILL USE PARAM #3 AS THE # TO DIAL.
IF USING A MODEM WITHOUT AUTOMATIC HANDSHAKING,
THE NUMBER MUST TERMINATE WITH A
"END-OF-NUMBER" CHARACTER (:).
 - B. ENTER ACTUAL VALUE.
- 8. THE PROGRAM WILL RETURN TO STEP B1 IF THIS SETUP
WAS FOR DN11 OR DM11BB.
- 9. THE PROGRAM WILL REQUEST THAT SWITCH REGISTER BE SET.
 - A. SETUP SWITCH REGISTER AS SPECIFIED IN STEP D.
AND TYPE A CAR. RETURN.

NOTE: IF ANY OF THE ABOVE ITEMS 2 THRU 7 WERE CHANGED BY ENTERING
NEW VALUES, THE NEW VALUE BECOMES THE DEFAULT VALUE FOR SUBSEQUENT
RESTARTS OF THE PROGRAM.

- C. MANUAL PARAMETER INPUT FROM SWITCH REGISTER
1. THE PROGRAM HALTS FOR ISR(INTERFACE SERVICE ROUTINE) SPECIFICATION
SWR14=SETUP DN-11B ISR
SWR13=SETUP DN-11 ISR
SWR=000000=SETUP VARIABLE ISR
 2. THE FOLLOWING HALTS ARE REPEATED FOR EACH ISR SPECIFIED.
SETUP SEQUENCE IS: DN11, DN11-BB THEN VARIABLE OVERLAY. (EACH ENTRY SET SWITCHES THEN HIT CONTINUE.)
 - A. HALT FOR BUS ADDRESS OF INTERFACE
 - B. HALT FOR VECTOR ADDRESS OF INTERFACE
 - C. HALT FOR PRIORITY OF INTERFACE
 - D. HALT FOR INTERFACE PARAM #1 (SEE SECT. 10.0 IN OVERLAY LISTING FOR PARAMETER DESCRIPTION)
 - E. HALT FOR INTERFACE PARAM #2 (DN11 AND DMBB PARAMETERS ARE DISCUSSED IN SECT. 10.0 OF THE MONITOR.
 - F. GO BACK TO STEP A IF THIS SETUP WAS FOR DN OR DMB.
 3. HALT FOR OPERATIONAL SWITCH SETTINGS. (SEE STEP D.)
 - A. PRESS CONTINUE TO START TESTING

BEFORE ATTEMPTING TO RUN THIS PROGRAM, THE OPERATOR MUST ACCERTAIN THE COMPLETE COMMUNICATION LOOP AND PROCEDURES TO BE USED, INCLUDING THE TYPE OF MODEMS, THE TYPE OF INTERFACE BEING USED AT THE OTHER CPU AND THE MODES OF OPERATION, DATA AND PARAMETERS TO BE USED AT EACH CPU.

THIS WILL REQUIRED VOCAL COMMUNICATION WITH THE OPERATOR AT THE OTHER CPU UNLESS ITS CONFIGURATION AND OPERATION ARE FIXED AS A TEST CENTER.

AFTER DETERMINING THAT THE EQUIPMENTS ARE COMPATIBLE AND AGREEING ON THE MODE AND VARIABLE PARAMETERS TO BE USED, THE SYSTEM WHICH IS TO RECEIVE DATA FIRST SHOULD BE LOADED AND STARTED. IF THE MODEM BEING USED ON THIS SYSTEM HAS AN AUTOMATIC ANSWER FEATURE, IT SHOULD BE ENABLED.

THE SYSTEM WHICH IS TO TRANSMIT FIRST SHOULD THEN BE LOADED AND STARTED AND THE CONNECTION ESTABLISHED EITHER MANUALLY OR AUTOMATICALLY (VIA DN-11).

D. OPERATIONAL SWITCH SETTINGS.

SW15=1 HALT ON ERROR
SW14=1 SINGLE PASS
SW14 HAS NO EFFECT IF SW04=0
SW13=1 INHIBIT ERROR TYPEOUTS
SW12=1 INHIBIT ALL TYPEOUTS EXCEPT ERRORS
IF SW12=0 AND SW04=1 END PASS IS TYPED
AND TRANSMITTED/RECEIVED DATA IS TYPED.
SW11=1 USE PREVIOUSLY SPECIFIED DATA
SW10=1 DATA SELECT (WITH SW09)
SW09=1 DATA SELECT (WITH SW10)
00=1 GET DATA FROM OPERATOR
01=1 TEST MESSAGE #1 (SA QUICK BROWN FOX)
10=1 TEST MESSAGE #2 (SB NUMERICS)
11=1 TEST MESSAGE #3 (SC COMTEST/QUICK BROWN FOX/NUMERICS)
SW08=1 TRANSMIT RECEIVED DATA (INTERNAL LOOPBACK MODE)
SW07=1 DO NOT TEST RECEIVED DATA
SW06=1 MONITOR TRANSMITTED DATA ON CONSOLE TTY.*
SW05=1 MONITOR RECEIVED DATA ON CONSOLE TTY.*
* IN MANY CASES, NOT ALL DATA WILL APPEAR ON THE CONSOLE
TTY. THIS IS ESPECIALLY TRUE WHEN THE COMM INTERFACE IS
RUNNING AT A FASTER BAUD THAN THE CONSOLE, BUT EVEN AT EQUAL
OR SLOWER BAUDS, ALL CHARACTERS MAY NOT APPEAR ON THE CONSOLE.
SW04=1 RETURN TO MONITOR FOR END PASS
WHEN SW04=0 PROGRAM LOOPS IN THE OVERLAY NEVER RETURNING TO THE MONITOR.
SW03=1 INTERNAL LOOPBACK MODE
SW02=1 EXTERNAL LOOPBACK MODE
SW01=1 ONE-WAY-IN MODE
SW00=1 ONE-WAY-OUT MODE

THIS PROGRAM HAS BEEN MODIFIED TO RUN ON A PROCESSOR WITH OR WITHOUT A HARDWARE SWITCH REGISTER. WHEN FIRST EXECUTED THE PROGRAM TESTS THE EXISTENCE OF A HARDWARE SWITCH REGISTER. IF NOT FOUND A SOFTWARE SWITCH REGISTER LOCATION (SWREG=LOC. 176) IS DEFAULTED TO. IF THIS IS THE CASE, UPON EXECUTION THE CONTENTS OF THE SWREG ARE DUMPED IN OCTAL ON THE CONSOLE TTY AND ANY CHANGES ARE REQUESTED

(IE) SWR=XXXXXX NEW=

POSSIBLE RESPONSES ARE:

1. <CR> IF NO CHANGES ARE TO BE MADE
2. 6 DIGITS 0-7 TO REPRESENT IN OCTAL THE NEW SWITCH REGISTER VALUE .LAST DIGIT FOLLOWED BY <CR>.
3. ↑U TO ALLOW REENTERING VALUE IF ERROR IS COMMITTED KEYING IN SWREG VALUE.

BUILT INTO THE PROGRAM IS THE ABILITY TO DYNAMICALLY CHANGE THE CONTENTS OF SWREG DURING PROGRAM EXECUTION. BY STRIKING ↑G (CNTRL G) ON CONSOLE TTY THE OPERATOR SETS A REQUEST FLAG TO CHANGE THE CONTENTS OF SWREG, WHICH IS PROCESSED IN KEY AREAS OF THE PROGRAM CODE (IE) ERROR ROUTINES, AFTER HALTS END OF PASS, AND OTHER APPLICABLE AREAS.

IF OPERATOR SPECIFIED DATA WAS INDICATED, THE PROGRAM WILL TYPE A REQUEST FOR THE DATA. DATA MAY BE ENTERED AS ASCII CHARACTERS OR OCTAL CODE. TYPE IN THE DATA TERMINATED WITH A CR. OCTAL CODE MAY BE ENTERED BY TYPING AN ↑(UP ARROW) FOLLOWED BY THE OCTAL CODE (IN THE RANGE 000 TO 377) SEPERATED BY SPACES AND TERMINATED BY ↑(UP ARROW).
I.E. ABCD↑ 000 123 377↑ EFG (CAR.RETURN)

A TYPICAL SWITCH SETTING FOR HALF-DUPLEX=003150 THIS SETTING USES INTERNAL LOOPBACK MODE, LOOPS IN OVERLAY, MONITORS TRANSMITTED AND RECEIVED DATA ON THE CONSOLE TTY, AND TESTS RECEIVED DATA USING TEST MESSAGE #3.

A TYPICAL SWITCH SETTING FOR FULL-DUPLEX=003144 THIS SETTING IS THE SAME AS ABOVE EXCEPT IT USES THE EXTERNAL LOOPBACK MODE.

ALL STANDARD MESSAGES(TEST MESSAGES 1-3) ARE PRECEDED BY 2 FILL CHARACTERS(177), AND ARE FOLLOWED BY A CR(015), LF(012), RECEIVE TERMINATING CHARACTER(001), 4 FILLS(177), AND A TRANSMIT TERMINATING CHARACTER(000). DURING TRANSMISSION, WHEN A 000 CHARACTER IS SEEN THE TRANSMISSION IS STOPPED. DURING RECEPTION, WHEN A 001 CHARACTER IS RECEIVED, THE RECEIVER IS SHUT OFF. IF THE MESSAGE WAS INPUTED BY THE OPERATER, THE TERMINATING CHARACTERS ARE ADDED.

TEST MODES

INTERNAL LOOPBACK MODE

1. THE OVERLAY WAITS TO RECEIVE A MESSAGE (TERMINATED BY <001>)
2. VERIFIES THE DATA AGAINST THE DATA SELECTED BY SW09 AND SW10 (SW7=0)
3. TRANSMIT THE DATA SELECTED BY SW09 AND SW10 (SW8=0) OR
TRANSMIT THE RECEIVED DATA (SW8=1)
4. RETURNS TO MONITOR FOR "END PASS" (SW4=1) OR
GO TO STEP 1. (SW4=0)

EXTERNAL LOOPBACK MODE

1. THE OVERLAY SETS REQUEST TO SEND
2. WAIT FOR CLEAR TO SEND
3. TRANSMITS THE SELECTED DATA
4. RESETS REQUEST TO SEND
5. WAIT FOR MESSAGE TO BE RECEIVED
6. VERIFIES THE DATA (SW07=0)
7. RETURNS TO MONITOR FOR "END PASS". (SW04=1) OR
GO TO STEP 1 (SW04=0)

ONE-WAY-IN MODE

1. THE OVERLAY WAITS FOR MESSAGE TO BE RECEIVED.
2. VERIFIES THE DATA (SW07=0)
3. RETURNS TO MONITOR FOR "END PASS" (SW04=1) OR
GO TO STEP 1 (SW04=0)

ONE-WAY-OUT MODE

1. THE OVERLAY SETS REQUEST TO SEND
2. WAITS FOR CLEAR TO SEND
3. TRANSMITS SELECTED DATA
4. RETURNS TO MONITOR FOR "END PASS". (SW04=1) OR
GO TO STEP 1 (SW04=0)

- E. THE OVERLAY IS THEN ENTERED AND A CONNECTION ESTABLISHED EITHER
MANUALLY OR AUTOMATICALLY.

IF ONE-WAY-IN OR INTERNAL LOOPBACK MODES ARE SELECTED.
THE OVERLAY WILL SET DATA TERMINAL READY AND WAIT FOR DATA.

IF ONE-WAY-OUT OR EXTERNAL LOOPBACK MODES WERE SELECTED.
THE OVERLAY WILL SET DATA TERMINAL READY AND REQUEST TO SEND.
THE OVERLAY WILL THEN WAIT FOR CLEAR TO SEND BEFORE ATTEMPTING TO
TRANSMIT DATA.

THE PROGRAM WILL PRINTOUT A "WAITING FOR CLEAR TO SEND"
MESSAGE AND THE CONTENTS OF THE XMIT CSR EVERY 60 SECS.
UNTIL CLEAR TO SEND IS ASSERTED.

F. IF SW04=0 THE OVERLAY WILL CONTINUE TO TRANSMIT/RECEIVE DATA.

IF SW04=1 THE OVERLAY WILL RETURN TO THE MONITOR AND TYPE "END PASS".

IF BOTH SW04=1 AND SW14=1, THE PROGRAM WILL REQUEST NEW INTERFACE PARAMS AFTER ONE PASS OF THE SELECTED TEST MODE.

TEST EXECUTION MAY BE INTERRUPTED BY TYPING THE FOLLOWING CHARACTERS ON THE CONSOLE TTY.

LINE FEED = RESTART PROGRAM AT LOCATION 200.

QUESTION MARK = PRINTOUT FIRST 8 WORDS OF INPUT BUFFER.(ASCII)

THEN TYPE EITHER:

*WXXXXXX

TO PRINTOUT THE 8 WORDS
AT LOC XXXXXX.

*BXXXXXX

TO PRINTOUT THE 16 BYTES
AFTER LOC XXXXXX.

*C

TO CONTINUE

PROGRAM MUST BE RESTARTED AT 200 AFTER PRINTING.

CARRIAGE RETURN = RESTART AT REQUEST FOR NEW OPERATIONAL SWITCHES.

5.0 PROGRAM AND/OR OPERATOR ACTION

IF THE OPERATOR WISHES TO MANUALLY EXAMINE THE TRANSMIT OR RECEIVE BUFFERS, DO THE FOLLOWING: TO FIND THE STARTING ADDRESS OF THE RECEIVE BUFFER, LOAD ADDRESS 11020 AND EXAMINE. TO FIND THE STARTING ADDRESS OF THE TRANSMIT BUFFER, LOAD ADDRESS 11022 AND EXAMINE.

5.1 NORMAL HALTS SEE SECTION 4.

6.0 ERRORS

6.1 ERROR REPORTING

THE ONLY ERROR REPORT FROM THE CONTROL PROGRAM OCCURS IF THE INTERFACE SPECIFIED IS NOT LOADED.

IF DATA IS RECEIVED AND SWITCH 7 (NO DATA COMPARE) IS RESET, THE DATA WILL BE COMPARED AGAINST THE PRESELECTED DATA AFTER A LINE FEED CHARACTER IS RECEIVED. IF THERE IS A MISMATCH, THE FOLLOWING ERROR REPORT IS PRINTED:

RECEIVED DATA=RRRRRR
DATA SHOULD BE TTTTTT
DATA COMPARE ERROR; BAD DATA=BBB GOOD DATA=GGG

WHERE RRRRRR IS THE RECEIVE BUFFER (UP TO 512 CHARACTERS)
TTTTTT IS THE TRANSMIT BUFFER (UP TO 512 CHARACTERS)
BBB IS THE BAD DATA CHARACTER
GGG IS THE GOOD DATA CHARACTER

IF THE INTERFACE DETECTS A DATA ERROR, THE FOLLOWING
WILL BE PRINTED BEFORE THE DATA IS COMPARED:

THERE WAS A RECEIVER ERROR. RECEIVER DATA REGISTER =XXXXXX

WHERE XXXXXX IS THE CONTENTS OF THE RECEIVER DATA REGISTER
THE LOW BYTE IS THE DATA, AND THE HIGH BYTE IS THE ERROR BITS.

IF A RECEIVE TERMINATING CHARACTER<001> IS NOT DETECTED
WITHIN 512 CHARACTERS A "BUFFER FULL" PRINTOUT WILL OCCUR.

7.0 RESTRICTIONS

THE OPERATION OF THIS PROGRAM REQUIRES COORDINATION BETWEEN
THE OPERATOR AND THE OPERATOR OF ANOTHER PDP-11 SYSTEM
UNLESS ONE OF THE SYSTEMS IS ALWAYS OPERATING IN A FIXED
MODE. THE FOLLOWING TABLE LISTS THE VALID COMBINATIONS:

CPU #1	CPU #2
ONE-WAY-OUT	ONE-WAY-IN
ONE-WAY-IN	ONE-WAY-OUT
EXTERNAL-LOOPBACK	INTERNAL-LOOPBACK
INTERNAL-LOOPBACK	EXTERNAL-LOOPBACK
EXTERNAL-LOOPBACK	EXTERNAL-LOOPBACK (FULL DUPLEX)

WHEN THE COMMUNICATION LINK INVOLVES MODEMS THE FOLLOWING
RESTRICTION APPLY:

IF RUNNING IN FULL DUPLEX MODE BOTH SYSTEMS
MUST BE IN EXTERNAL LOOP BACK MODE.

BOTH SYSTEMS SHOULD BE RUNNING IDENTICAL ROUTINES.

EXAMPLE:

SWITCHES 14,13,7,4 SHOULD BE THE SAME
ON BOTH CPU S

IF PROGRAM IS WAITING IN A SCAN ROUTINE AND TYPES OUT
A "WAITING MESSAGE", IF AN INCOMING MESSAGE STARTS DURING
THE TYPE OUT, IT WILL BE LOST BECAUSE THE TYPEOUT PRIORITY
IS AT LEVEL 7. THIS WILL RESULT IN OVERRUN OR SILO OVER-
RUN ERRORS, DEPENDING ON THE DEVICE. TO AVOID THIS SITUATION
RUN WITH SWITCH 13 UP. IF OVERRUN DOES OCCURE DURING A
TYPEOUT THE PROGRAM SHOULD BE RESTARTED.

IF USING AN ASYNCHRONOUS DEVICE, MODEMS AND THE
MAYNARD TEST STATION AND INITIALIZE DOES NOT CLEAR THE
CONNECTION (EXAMPLE THE DJ11) IF THE PROGRAM IS RESTARTED
IN THE MIDDLE OF A MESSAGE AT LOC 204 OR BY HITTING CR
AN IMMEDIATE ERROR MESSAGE FROM MAYNARD WILL BE RE-

CEIVED. THIS IS BECAUSE THE TEST STATION IS STILL LOOKING
FOR THE REST OF THE INTERRUPTED MESSAGE. TO AVOID THIS
ERROR, RESTART PROGRAM ONLY AT THE END OF THE MESSAGE
CURRENTLY BEING TRANSMITTED.

8.0 MISCELLANEOUS

ITEP WAS CHECKED OUT USING THE FOLLOWING BELL TELEPHONE MODEMS.
201A (HALF-DUPLEX SYNCHRONOUS 2000 BAUD)
202C (HALF-DUPLEX ASYNCHRONOUS 1200 BAUD)
103A (FULL-DUPLEX ASYNCHRONOUS 110 BAUD)

9.0 PROGRAM DESCRIPTION

9.1 THE CZDHLCO DH11 INTERFACE SERVICE PARAMS ARE SETUP, AS SPECIFIED BY THE OPERATOR,
BY THE ITEP CONTROL PROGRAM.

TIME: PROVIDES A MEANS OF MEASURING ELAPSED TIME. IT IS INCREMENTED
EVERY SECOND BY A CLOCK INTERRUPT ROUTINE IN ITEP.

9.2 WHEN THE OVERLAY IS FIRST ENTERED BY ITEP AT LOCATION START:,
THE CONTENTS OF THE SWITCH REGISTER ARE STORED IN REGISTER 0.
THE MODE AND DATA SELECTIONS ARE FIXED AT THIS TIME AND CANNOT
BE ALTERED WITHOUT RETURNING TO THE CONTROL PROGRAM.
THE INTERRUPT VECTORS AND VARIABLES ARE THEN SETUP.
THE SELECTED ROUTINE DETERMINED BY THE MODE IS THEN ENTERED

9.3 THE OVERLAY THEN LOOPS IN ROUTINES: SOWI, IF "ONE WAY IN" MODE
WAS SELECTED. SOWO, IF "ONE WAY OUT" MODE WAS SELECTED.
\$ILB, IF "INTERNAL LOOP BACK" MODE WAS SELECTED.
\$XLB, IF "EXTERNAL LOOP BACK" WAS SELECTED.

9.31 SOWI: IN THIS ROUTINE THE RECEIVER IS INITIALIZED AND PROGRAM
LOOPS WAITING FOR THE RECEIVER TO FINISH. IF NOTHING IS RECEIVED
FOR 60 SECS A "WAITING" MESSAGE IS TYPED. WHEN THE RECEIVER IS
DONE, THE PROGRAM CHECKS DATA IF SWITCHES PERMIT, AND TYPES END
PASS DEPENDING ON SWITCH SETTINGS.

9.32 SOWO: THE TRANSMITTER IS INITIALIZED AND PROGRAM LOOPS
WAITING FOR TRANSMITTER TO FINISH. A "WAITING" MESSAGE IS TYPED
EVERY 60 SECS IF THERE IS NO ACTION. WHEN THE TRANSMITTER IS
DONE, THE PROGRAM EITHER LOOPS BACK TO SOWO OR TYPES END PASS
DEPENDING ON SWITCH SETTINGS.

9.33 \$ILB: THE RECEIVER IS INITIALIZED AND PROGRAM LOOPS WAITING FOR
RECEIVER TO FINISH. A "WAITING" MESSAGE IS TYPED EVERY 60 SEC
IF NO ACTION. WHEN RECEIVER IS DONE PROGRAM CHECKS DATA IF SWITCH
SETTINGS PERMIT, AND END PASS IS TYPED IF SWITCH SETTINGS PERMIT.
THEN THE TRANSMITTER IS INITIALIZED. A "WAITING" MESSAGE IS TYPED
EVERY 60 SEC IF NO ACTION. WHEN TRANSMITTER IS DONE PROGRAM RETURNS
TO START OF ROUTINE. (\$ILB)

9.34 \$XLB: IF IN HALF DUPLEX THE TRANSMITTER IS INITIALIZED,
A "WAITING MESSAGE IS TYPED EVERY 60 SEC IF THERE IS NO ACTION

WHEN THE TRANSMITTER IS DONE THE RECEIVER IS INITIALIZED
A "WAITING" MESSAGE IS TYPED EVERY 60 SEC IF THERE IS NO ACTION.
WHEN THE RECEIVER IS DONE DATA IS CHECKED IF SWITCH SETTINGS
PERMIT AND END PASS IS TYPED IF SWITCHES ALLOW. THE PROGRAM NOW
REPEATS CYCLE STARTING AT \$XLB.
IF IN FULL DUPLEX THE RECEIVER AND TRANSMITTER ARE INITIALIZED
A "WAITING" MESSAGE IS TYPED EVERY 60 SEC IF THERE IS NO
ACTION. WHEN BOTH THE RECEIVER AND TRANSMITTER ARE DONE DATA IS
CHECKED, END PASS IS TYPED AND PROGRAM LOOPS TO \$XLB DEPENDING
ON THE SWITCH SETTINGS.

- 9.4 THE RETURN TO MONITOR ROUTINE FOR END PASS AT EOP:
LOCKS OUT INTERRUPTS AND SAVES THE TRANSMITTER INTERRUPT ENABLE
BIT AND ALL GENERAL REGISTERS. IT THEN RETURNS TO THE MONITOR
TO TYPE "END PASS". THE MONITOR CHECKS SW14 IF UP IT RETURNS
TO ENTER:, OTHERWISE IT RESTARTS THE PROGRAM.
- 9.5 ENTER: IS ENTERED FROM THE MONITOR AFTER TYPEING "END PASS",
IT RESTORES THE GENERAL REGISTERS AND THE TRANSMITTER CSR
AS SAVED IN EOP. THE DELAY FLAG IS SET AND PROGRAM RETURNS TO
THE SCAN ROUTINE(OWO,OWI,ILB,XLB) WHERE IT CAME FROM.
- 9.6 THE INITIALIZE TRANSMIT SUBROUTINE AT STARTX:
SETS UP THE INTERFACE AND POINTERS NECESSARY TO
INITIATE A TRANSMIT OPERATION.
AFTER SETTING "DATA TERMINAL READY" AND "REQUEST TO SEND" A CHECK
IS MADE ON PARAM2 TO DETERMINE IF HALF DUPLEX OPERATION
WAS SELECTED BY THE OPERATOR. IF IT WAS, THE
SUBROUTINE WAITS FOR CLEAR TO SEND.
A 'WAITING FOR CLEAR TO SEND' PRINTOUT OCCURS
EVERY 30 SECONDS UNTIL CLEAR TO SEND IS ASSERTED.
- 9.7 THE INITIALIZE RECEIVED SUBROUTINE AT STARTR:
SETS UP THE INTERFACE AND POINTERS NECESSARY TO
RECEIVE A MESSAGE.
- 9.8 THE TRANSMIT INTERRUPT SERVICE ROUTINE
AT XISR:, IS ENTERED VIA TRANSMIT INTERRUPTS
FROM THE INTERFACE.
A TEST IS MADE TO SEE IF THE LAST CHARACTER
TRANSMITTED WAS A NULL (ALL ZEROS) CHARACTER.
IF IT WAS, THE TRANSMIT LOGIC IN THE INTERFACE
IS RESET AND THE TRANSMIT COMPLETE FLAG IS SET.
AT XISR1: THE NEXT CHARACTER IS TRANSMITTED
AND PRINTED ON THE TTY IF THE MONITOR TRANSMIT
SWITCH IS SET.
- 9.9 THE RECEIVE INTERRUPT SERVICE ROUTINE
AT RISR: IS ENTERED VIA RECEIVER INTERRUPTS
FROM THE INTERFACE.
THE RECEIVED CHARACTER IS STORED IN
THE INPUT BUFFER AND PRINTED ON THE TTY IF
THE MONITOR RECEIVER SWITCH IS SET.
IF THE INPUT BUFFER IS FULL, A 'BUFFER FULL'
PRINTOUT WILL OCCUR. THIS INDICATES THAT A
LINE FEED CHARACTER WAS NOT RECOGNIZED

IN THE RECEIVED DATA (WITHIN 1000 CHARACTERS).
IF THE RECEIVED CHARACTER IS A LINE FEED,
THE RECEIVED LOGIC IS RESET AND THE
RECEIVE COMPLETE FLAG IS SET.
IF A 'RECEIVE ERROR' IS DETECTED AT RISR:, THE
CSR AND DBR WILL BE SAVED AND PRINTED OUT
AFTER THE COMPLETE MESSAGE HAS BEEN RECEIVED.

- 9.10 THE DATA TEST SUBROUTINE AT TESTD: IS
ENTERED AFTER A COMPLETE MESSAGE HAS BEEN
RECEIVED.
IF A 'RECEIVE ERROR' HAD BEEN DETECTED,
THE CONTENTS OF THE 'RECEIVE BUFFER' AT THE
TIME THE ERROR OCCURRED WILL BE PRINTED.
THE DATA IS COMPARED UNTIL A 'ALL ZEROS'
CHARACTER IS RECOGNIZED. 'FILL' (ALL ONES)
CHARACTERS ARE IGNORED. IF A MISMATCH
IS DETECTED, THE COMPLETE CONTENTS OF THE
INPUT BUFFER AND GOOD DATA IS PRINTED.

DH11 RESTRICTIONS

IF A DM11BB EXISTS IN THE SYSTEM WITH THE DH11 BEING
TESTED, BUT MODEM CONTROL IS NOT DESIRED AND THE DM11BB
WAS NOT INITIALIZED BY ITEP THE PROGRAM WILL HANG IN THE
DH11 TRANSMITTER INITIALIZATION ROUTINE. TO CORRECT THIS
LOAD LOCATION "DMBB" WITH AN ADDRESS THAT WILL TIME OUT (NO
SLAVE SYNC RESPONSE). THE ADDRESS OF DMBB CAN BE FOUND
IN THE CROSS REFERENCE TABLE IN THE BACK OF THIS LISTING.

576

10.0 PARAMETERS FOR THE DH11

PARAM#1 IS LOADED INTO THE SYSTEM CONTROL REGISTER.(SCR)
BITS 0-3 LINE SELECTION, DEFAULT= LINE 0 (0000)

PARAM#2 IS LOADED INTO THE LINE PARAMETER REGISTER.(LPR)

BITS 0,1	CHARACTER LENGTH, DEFAULT= 8 BITS (11)
BIT 2	STOP BITS, DEFAULT= 2 STOP BITS (1)
BIT 4	PARITY ENABLED (1), DEFAULT= (0)
BIT 5	ODD PARITY (1), DEFAULT= (0)
BITS 6-9	RECEIVER SPEED, DEFAULT= 110 BAUD (0011)
BITS 10-13	TRANSMIT SPEED, DEFAULT= 110 BAUD (0011)
BIT 14	HALF DUPLEX (1), DEFAULT= FULL DUPLEX (0)

PARAM#3 IS NOT USED (177777)


```

596
597
598
599
600
601 011000 011000 000040
602 011004 044104
603 011006 160020
604 011010 000300
605 011012 000240
606 011014 000000
607 011016 006307
608 011020 177777
609 011022 000000
610 011024 000000
611 011026 000000
612 011030 000000
613 011032 000000
614 011034 000000
615 011036 011102
616 011040
617 011040 000
618 011041
619 011041 001
620 011042 000000
621 011044 177570
622 011046 177570
623
624
625
626
627
628
629
630
631
632
633 011050 000000
634 011052 000000
635 011054 000000
636 011056 000000
637 011060 000000
638
639 011062 000000
640 011064 000000
641 011066 000000
642 011070 000000
643
644 011072 177560
645 011074 177562
646 011076 177564
647 011100 177566
648
649 000001

```

```

;*****
; DH11 INTERFACE SERVICE PARAMS
;*****
DH11:  .=11000
BA:    .ASCIZ /DH /
RIV:   300
PRIO:  240
PARAM1: 0
PARAM2: 006307
PARAM3: 177777
IRDA:  .WORD 0
IXDA:  .WORD 0
SETTLE: .WORD 0
B2016: .WORD 0
TIME:  .WORD 0
TX. TERM: .WORD START
RX. TERM: .WORD 000
FLAG:    .BYTE 001
SWR:     .WORD 0
DISPLAY: 177570

;*****
; CONSTANTS + WORKING STORAGE
;*****
STAT=00
XFLG=100000
RFLG=40000
DSFLG=20000
BIT13=20000

SXCSR: 0
SRCR: 0
ERCSR: 0
ERDBR: 0
DSSTAT: 0

XCC: 0
RCC: 0
RD4: 0
XDA: 0

TKS: 177560
TKB: 177562
TPS: 177564
TPB: 177566

FULL.DUPLEX=000001

;ISR NAME
;BUS ADDRESS
;VECTOR ADDRESS
;PRIORITY
;PARAM #1
;PARAM #2
;PARAM #3
;INITIAL READ DATA ADDRESS
;INITIAL XMIT DATA ADDRESS
;LINE SETTLE DELAY FLAG
;ADDR OF BIN TO OCT TYPE ROUTINE
;TIMER
;ADDR OF START OF PROGRAM
;TRANSMITTER TERMINATING CHAR.
;RECEIVER TERMINATING CHAR.
;XMIT COMPLETE FLAG
;RCV COMPLETE FLAG
;DATA SET STATUS CHANGE FLAG
;INHIBIT PRINTOUTS
;SAVED XMIT CSR
;SAVED RCV CSR
;RCV CSR SAVED ON ERROR
;RCV DATA REG SAVED ON ERROR
;RCV CSR SAVED ON DS CHANGE
;XMIT CHAR COUNT
;RCV CHAR COUNT
;RCV DATA ADDR.
;XMIT DATA ADDR.

```

650
651
652
653 011102 000240
654 011104 017700 177734
655 011110 042700 177400
656 011114 013702 011006
657 011120 012722 014040
658 011124 013722 011010
659 011130 012722 013470
660 011134 013722 011010
661 011140 013704 011004
662 011144 012714 004000
663 011150 053714 011012
664 011154 053764 011014 000004
665 011162 123727 011012 000017
666 011170 101402
667 011172 000000
668 011174 000776
669 011176 010046
670 011200 012700 000001
671 011204 013701 011012
672 011210 005701
673 011212 001403
674 011214 006300
675 011216 005301
676 011220 000773
677 011222 010037 013714
678 011226 012600
679
680
681
682
683
684
685
686 011230 005037 011032
687 011234 005037 013120
688 011240 005037 013124
689 011244 032700 000001
690 011250 001402
691 011252 000137 011426
692 011256 032700 000002
693 011262 001402
694 011264 000137 011320
695 011270 032700 000010
696 011274 001402
697 011276 000137 011524
698 011302 032700 000004
699 011306 001402
700 011310 000137 011754
701 011314 000000
702 011316 000776
703
704
705

```
*****
: DH11-X INTERFACE SERVICE ROUTINE
*****
START: NOP
      MOV     JSWR, R0      ;SETUP MODE IN R0
      BIC     #177400, R0   ;STRIP JUNK
      MOV     RIV, R2      ;SETUP
      MOV     #RISR, (R2)+ ;INTERRUPT
      MOV     PRIOR, (R2)+ ;VECTORS
      MOV     #XISR, (R2)+
      MOV     PRIOR, (R2)+
      MOV     BA, R4        ;SETUP BUS ADDR INDEX
      MOV     #MC, JRCSR
      BIS     PARAM1, JRCSR
      BIS     PARAM2, LPR(R4)
      CMPB    PARAM1, #17
      BLOS    1$
      HALT
      BR      .-2
1$:   MOV     R0, -(SP)
      MOV     #1, R0
      MOV     PARAM1, R1
2$:   TST     R1
      BEQ     3$           ;CALCULATE BAR BIT
      ASL     R0
      DEC     R1
      BR      2$
3$:   MOV     R0, BARTMP
      MOV     (SP)+, R0
*****
: ROUTINE USED TO GOT()
: SUBROUTINE DEPENDENT
: ON MODE SELECTED.
*****
GO:   CLR     TIME
      CLR     DELAY
      CLR     STOP
      BIT     #OWO, MODE
      BEQ     1$
      JMP     SOWO
1$:   BIT     #OWI, MODE
      BEQ     2$
      JMP     SOWI
2$:   BIT     #ILB, MODE
      BEQ     3$
      JMP     SILB
3$:   BIT     #XLB, MODE
      BEQ     4$
      JMP     SXLB
4$:   HALT
      BR      .-2
```


706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761

011320	104416		
011322	004737	013726	
011326	032700	040000	
011332	001013		
011334	023727	011032	000100
011342	103771		
011344	011402		
011346	016403	000000	
011352	104001		
011354	005037	011032	
011360	000762		
011362	032777	000200	177454
011370	001002		
011372	004737	012344	
011376	042700	040000	
011402	032777	000020	177434
011410	001405		
011412	012737	011424	013122
011420	000137	012204	
011424	000735		

SOWI:	KBDIN	
1S:	JSR	PC, STARTR
	BIT	#RFLG, STAT
	BNE	2S
	CMP	TIME, #100
	BLO	1S
	MOV	3RCSR, R2
	MOV	XCSR(R4), R3
	HLT	1
	CLR	TIME
	BR	1S
2S:	BIT	#NODAT, 2SWR
	BNE	3S
3S:	JSR	PC, TESTD
	BIC	#RFLG, STAT
	BIT	#LOOP, 2SWR
	BEQ	4S
	MOV	#4S, BACK
4S:	JMP	EOP
	BR	SOWI

ROUTINE USED IF "ONE WAY OUT" WAS SELECTED.
NOTE THAT WHEN IN THIS MODE HALF DUPLEX IS THE ONLY
MODE AVAILABLE.
"ONE WAY OUT" MEANS THAT ONLY THE TRANSMITTER IS
ENABLED. THE RECEIVER IS NEVER "TURNED ON".

011426	104416		
011430	004737	013126	
011434	005037	011032	
011440	032700	100000	
011444	001013		
011446	023727	011032	000100
011454	103771		
011456	011402		
011460	016403	000000	
011464	104001		
011466	005037	011032	
011472	000762		
011474	042700	100000	
011500	032777	000020	177336

SOWO:	KBDIN	
1S:	JSR	PC, STARTX
	CLR	TIME
	BIT	#XFLG, STAT
	BNE	2S
	CMP	TIME, #100
	BLO	1S
	MOV	3RCSR, R2
	MOV	XCSR(R4), R3
	HLT	1
	CLR	TIME
	BR	1S
2S:	BIC	#XFLG, STAT
	BIT	#LOOP, 2SWR

CZDHLCO DH11 ITEP OVERLAY
CZDHLCO.P11 23-MAR-78 12:56

MACY11 30A(1052) 23-MAR-78 13:03 PAGE 17

SEQ 0016
SEQ 0016

762	011506	001405			BEO	3\$
763	011510	012737	011522	013122	MOV	#3\$, BACK
764	011516	000137	012204		JMP	EOP
765	011522	000741		3\$:	BR	\$OWO
766						
767						
768						

769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823

011524	104416		
011526	004737	013726	
011532	005037	011032	
011536	032700	040000	
011542	001013		
011544	023727	011032	000100
011552	103771		
011554	011402		
011556	016403	000000	
011562	104001		
011564	005037	011032	
011570	000762		
011572	032777	000200	177244
011600	001002		
011602	004737	012344	
011606	042700	040000	
011612	032777	000020	177224
011620	001405		
011622	012737	011634	013122
011630	000137	012204	
011634	032777	000400	177202
011642	001416		
011644	013702	011020	
011650	013703	011022	
011654	010337	011070	
011660	112223		
011662	001376		
011664	112743	000177	
011670	005203		
011672	112723	000177	
011676	105023		
011700	005037	011032	
011704	004737	013126	
011710	032700	100000	
011714	001013		
011716	023727	011032	000100
011724	103771		
011726	011402		
011730	016403	000000	
011734	104001		
011736	005037	011032	
011742	000762		
011744	042700	100000	
011750	000137	011524	

```
*****
ROUTINE USED IF INTERNAL LOOP BACK" WAS SELECTED.
NOTE THAT WHEN IN THIS MODE; HALF DUPLEX IS THE
ONLY MODE AVAILABLE.
"INTERNAL LOOP BACK" MEANS THAT THE RECEIVER IS "TURNED ON"
AND A COMPLETE MESSAGE IS RECEIVED. IF DATA IS TO BE CHECKED
IT IS; IF "END PASS" IS DESIRED; IT IS GIVEN.
THEN THE TRANSMITTER IS ENABLED. AFTER THE WHOLE MESSAGE
IS TRANSMITTED; THE CYCLE IS REPETED AS ABOVE.
*****

SILB:  KBDIN
      JSR  PC,STARTR
      CLR  TIME
1$:    BIT  #RFLG,STAT
      BNE  2$
      CMP  TIME,#100
      BLO  1$
      MOV  @RCSR,R2
      MOV  XCSR(R4),R3
      HLT  1
      CLR  TIME
      BR   1$
2$:    BIT  #NODAT,@SWR
      BNE  3$
      JSR  PC,TESTD
      BIC  #RFLG,STAT
      BIT  #LOOP,@SWR
      BEQ  4$
      MOV  #4$ BACK
      JMP  EOP
4$:    BIT  #400,@SWR
      BEQ  7$
      MOV  IRDA,R2
      MOV  IXDA,R3
      MOV  R3,XDA
      MOVB (R2)+,(R3)+
      BNE  -2
      MOVB #177,-(R3)
      INC  R3
      MOVB #177,(R3)+
      CLRB (R3)+
      CLR  TIME
7$:    JSR  PC,STARTX
      BIT  #XFLG,STAT
      BNE  6$
      CMP  TIME,#100
      BLO  5$
      MOV  @RCSR,R2
      MOV  XCSR(R4),R3
      HLT  1
      C_R  TIME
      BR   5$
6$:    BIC  #XFLG,STAT
      JMP  SILB

;USE EXTERNAL DATA?
;BR IF NO
;SET POINTER
;SET POINTER
;SETUP XMIT DATA ADDR
;MOVE INPUT TO OUTPUT
;LOOP IF NOT ZERO CHAR
;INSERT A FILL CHAR
;BUMP ADDRESS
;INSERT ANOTHER FILL
;INSERT ZERO CHAR
```

824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879

011754	104416		
011756	032737	040000	011014
011764	001002		
011766	004737	013726	
011772	004737	013126	
011776	005037	011032	
012002	032700	100000	
012006	001016		
012010	032700	040000	
012014	001024		
012016	023727	011032	000100
012024	103766		
012026	011402		
012030	016403	000000	
012034	104001		
012036	005037	011032	
012042	000757		
012044	032737	040000	011014
012052	001756		
012054	042700	100000	
012060	004737	013726	
012064	000746		
012066	032737	040000	011014
012074	001020		
012076	032700	100000	
012102	001013		
012104	023727	011032	000100
012112	103765		
012114	011402		
012116	016403	000000	
012122	104001		
012124	005037	011032	
012130	000756		
012132	042700	100000	
012136	042700	040000	
012142	005037	011032	
012146	032777	000200	176670
012154	001002		
012156	004737	012344	
012162	032777	000020	176654
012170	001671		
012172	012737	011754	013122
012200	000137	012204	

```
*****
ROUTINE USED IF "EXTERNAL LOOP BACK" WAS SELECTED.
EITHER HALF OR FULL DUPLEX MAY BE SELECTED IN THIS MODE.
"EXTERNAL LOOP BACK" MEANS THAT THE TRANSMITTER IS FIRST
TURNED ON (IF HALF DUPLEX) AND THE WHOLE MESSAGE IS TRANSMITTED;
THEN THE RECEIVER IS ENABLED. AFTER THE WHOLE MESSAGE IS RECEIVED
DATA WILL THEN BE CHECKED IF DESIRED AND END PASS WILL
BE GIVEN IF DESIRED. THEN THE CYCLE IS REPEATED
AS ABOVE. IF RUNNING IN FULL DUPLEX THE PROGRAM
WAITS FOR BOTH THE RECEIVER AND TRANSMITTER TO
FINISH THEN RESTARTS THE RECEIVER AND TRANSMITTER.
*****

$XLB:  KBDIN
      BIT      #HALF.DUPLEX,PARAM2
      BNE      1$
      JSR      PC,STARTR
1$:    JSR      PC,STARTX
      CLR      TIME
2$:    BIT      #XFLG,STAT
      BNE      3$
      BIT      #RFLG,STAT
7$:    BNE      4$
      CMP      TIME,#100
      BLO      2$
      MOV      @RCSR,R2
      MOV      XCSR(R4),R3
      HLT      1
      CLR      TIME
      BR       2$
3$:    BIT      #HALF.DUPLEX,PARAM2
      BEQ      7$
      BIC      #XFLG,STAT
      JSR      PC,STARTR
      BR       2$
4$:    BIT      #HALF.DUPLEX,PARAM2
      BNE      8$
      BIT      #XFLG,STAT
      BNE      6$
      CMP      TIME,#100
      BLO      4$
      MOV      @RCSR,R2
      MOV      XCSR(R4),R3
      HLT      1
      CLR      TIME
      BR       4$
6$:    BIC      #XFLG,STAT
8$:    BIC      #RFLG,STAT
      CLR      TIME
      BIT      #NODAT,JSWR
      BNE      5$
      JSR      PC,TESTD
      BIT      #LOOP,JSWR
      BEQ      $XLB
      MOV      #$XLB,BACK
      JMP      EOP
```


880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935

012204		
012204	104414	000340
012210	016437	000000
012216	042737	157777
012224	042764	020000
012232	012766	012272
012240	010037	013104
012244	010137	013106
012250	010237	013110
012254	010337	013112
012260	010437	013114
012264	010537	013116
012270	000207	
012272		
012272	013700	013104
012276	013701	013106
012302	013702	013110
012306	013703	013112
012312	013704	013114
012316	013705	013116
012322	012737	177777
012330	053764	012342
012336	000177	000560
012342	000000	
012344	013746	011056
012350	001413	
012352	032777	020000
012360	001007	
012362	104400	012544
012366	004077	176436
012372	005746	
012374	104400	012625
012400	013701	011022
012404	013702	011020
012410	122122	
012412	001776	
012414	123741	011040
012420	001447	
012422	122742	000002
012426	001005	
012430	010237	012436
012434	104400	

ROUTINE TO RETURN
TO MONITOR FOR
END PASS.

EOP:

STPS, PRTY7

MOV	XCSR(R4), QTPIE
BIC	#1C<TIE>, QTPIE
BIC	#TIE, XCSR(R4)
MOV	#ENTER, 2(SP)
MOV	R0, SAVR0
MOV	R1, SAVR1
MOV	R2, SAVR2
MOV	R3, SAVR3
MOV	R4, SAVR4
MOV	R5, SAVR5
RTS	PC

:SET PS PRIORITY TO 7

:SAVE TX CSR
:CLEAR ALL BUT TX IE.
:CLEAR TX IE (EVEN IF IT WASN'T SET)
:SET FOR RETURN IF SW 14=1
:SAVE REGISTER 0
:SAVE REGISTER 1
:SAVE REGISTER 2
:SAVE REGISTER 3
:SAVE REGISTER 4
:SAVE REGISTER 5
:RETURN TO CONTROL PROGRAM

ENTER:

MOV	SAVR0, R0
MOV	SAVR1, R1
MOV	SAVR2, R2
MOV	SAVR3, R3
MOV	SAVR4, R4
MOV	SAVR5, R5
MOV	#-1, DELAY
BIS	QTPIE, XCSR(R4)
JMP	BACK

:RESTORE R0
:RESTORE R1
:RESTORE R2
:RESTORE R3
:RESTORE R4
:RESTORE R5

:IF ORIGINALLY SET; SET TX IE

QTPIE: 000000

SUBROUTINE TO CHECK
RECEIVER DATA.

TESTD:	MOV	ERDRA, -(SP)
	BEQ	TSTDAT
	BIT	#BIT13, JSWR
	BNE	TSTDAT
	TYPE	MSG0
	JSR	R0, 002016
	TST	-(SP)
	TYPE	MSG1
TSTDAT:	MOV	IXDA, R1
	MOV	IRDA, R2
SCAN4:	CMPB	(R1)+, (R2)+
	BEQ	SCAN4
	CMPB	TX TERM, -(R1)
	BEQ	TESTOX
	CMPB	#002, -(R2)
	BNE	ZS
	MOV	R2, 15
	TYPE	

:WAS THERE A RECEIVE ERROR?

:BR IF NO

:INHIBIT PRINTOUTS?

:BR IF YES

:<15><12>THERE WAS A RECEIVE ERROR. RBUF=

:PRINT CONTENTS OF RBUF

:<15><12>

:SETUP XMIT DATA ADDR

:SETUP RCY DATA ADDR

:DATA OK ?

:BR IF OK

:IS IT END OF DATA

:BR IF YES

LINE	ADDRESS	DATA	OPERATION	REGISTER	COMMENT
936	012436	000000	1S:	WORD	
937	012440	000437	BR	TESTDX	
938	012442		2S:		
939	012442	105712	TSTB	(R2)	
940	012444	001435	BEQ	TESTDX	
941	012446	122721	CMPB	#177, (R1)+	BR IF YES
942	012452	001756	BEQ	SCAN4	IS IT FILL CHAR?
943	012454	005301	DEC	R1	BR IF YES
944	012456	122722	CMPB	#177, (R2)+	BACKUP
945	012462	001752	BEQ	SCAN4	IS IT FILL?
946	012464	000240	NOP		BR IF YES
947	012466	032777	BIT	#BIT13, 2SWR	DATA ERROR
948	012474	001016	BNE	DERR	INHIBIT PRINTOUTS
949	012476	104400	TYPE	MSG2	BR IF YES
950	012502	013737	MOV	IRDA, RDAX	<15><12>RECEIVED DATA = <15><12>
951	012510	104400	TYPE		SETUP DATA ADDRESS
952	012512	000000	RDAX:	0	PRINT RECEIVED DATA
953	012514	104400	TYPE	MSG3	RECEIVED DATA ADDR.
954	012520	013737	MOV	IXDA, .+10	<15><12>DATA SHOULD BE<15><12>
955	012526	104400	TYPE		SETUP ADDR.
956	012530	011022	IXDA		PRINT GOOD DATA
957	012532	111103	DERR:	MOV B (R1), R3 ;SETUP XMIT DATA	
958	012534	114202	MOV B	-(R2), R2	SETUP RCV DATA
959	012536	104007	HLT+7		DATA ERROR HALT
960	012540	005726	TESTDX:	TST (SP)+	POP STACK
961	012542	000207	RTS	PC	RETURN FROM SUB/ROUT
962					
963	012544	005015	MSG0:	.ASCIZ	<15><12>/THERE WAS A RECEIVER ERROR. REGISTER (SEL 2) =/
(1)	012625	015	MSG1:	.ASCIZ	<15><12>
(1)	012630	005015	MSG2:	.ASCIZ	<15><12>/RECEIVED DATA = /<15><12>
(1)	012655	015	MSG3:	.ASCIZ	<15><12>/DATA SHOULD BE/<15><12>
(1)	012700	005015	MSG4:	.ASCII	<15><12>/PLEASE MAKE CONNECTION (DIAL NUMBER)./
(1)	012747	015		.ASCIZ	<15><12>/WHEN CONNECTION COMPLETE; HIT CONTINUE SWITCH./<15><12>
(1)	013032	005015	MSG5:	.ASCIZ	<15><12>/PLEASE MAKE CONNECTION (DIAL NUMBER)./<15><12>
(1)					
(1)	013104	000000	.EVEN		
964	013106	000000	SAVR0:	0	
965	013110	000000	SAVR1:	0	
966	013112	000000	SAVR2:	0	
967	013114	000000	SAVR3:	0	
968	013116	000000	SAVR4:	0	
969	013120	000000	SAVR5:	0	
970	013122	000000	DELAY:	0	
971	013124	000000	BACK:	0	
972			STOP:	0	


```
973  
974  
975  
976  
977 013126 005737 011024  
978 013132 001004  
979 013134 005737 013120  
980 013140 001015  
981 013142 000434  
982 013144 005037 013710  
983 013150 012737 000007 013712  
984 013156 062737 000001 013710  
985 013164 001374  
986 013166 005337 013712  
987 013172 001371  
988 013174 005037 013710  
989 013200 012737 000007 013712  
990 013206 062737 000001 013710  
991 013214 001374  
992 013216 005337 013712  
993 013222 001371  
994 013224 005037 013120  
995 013230 005037 011024  
996 013234 032737 040000 011014  
997 013242 001440  
998 013244 013746 000004  
999 013250 013746 000006  
1000 013254 012737 013332 000004  
1001 013262 005037 000006  
1002 013266 005737 013124  
1003 013272 001407  
1004 013274 012737 177777 013124  
1005 013302 032777 000100 000406  
1006 013310 001374  
1007 013312 052777 000004 000376  
1008 013320 032777 000040 000370  
1009 013326 001774  
1010 013330 024646  
1011 013332 022626  
1012 013334 012637 000006  
1013 013340 012637 000004  
1014 013344 013737 011022 011070  
1015 013352 042700 100000  
1016 013356 013764 011070 000006  
1017 013364 032737 040000 011014  
1018 013372 001022  
1019 013374 032700 000004  
1020 013400 001417  
1021 013402 012737 177777 013722  
1022 013410 012764 177777 000010  
1023 013416 052714 020000  
1024 013422 013764 013714 000012  
1025 013430 000001  
1026 013432 005737 013720  
1027 013436 001375  
1028 013440 013764 011070 000006
```

```
*****  
; TRANSMITTER INITIALIZATION SUBROUTINE  
*****  
STARTX: TST      SETTLE  
        BNE      6$  
        TST      DELAY  
        BNE      5$  
        BR       1$  
6$:     CLR      TEMP1      ;PREPARE FOR DELAY  
        MOV      #7,TEMP2  
        ADD      #1,TEMP1   ;INC DELAY  
        BNE      -6  
        DEC      TEMP2  
        BNE      -14  
5$:     CLR      TEMP1      ;PREPARE FOR DELAY  
        MOV      #7,TEMP2  
        ADD      #1,TEMP1   ;INC DELAY  
        BNE      -6  
        DEC      TEMP2  
        BNE      -14  
1$:     CLR      DELAY  
        CLR      SETTLE  
        BIT      #HALF.DUPLEX,PARAM2 ;HALF DUPLEX?  
        BEQ      4$  
        MOV      #4,-(SP)   ;SAVE LOC 4  
        MOV      #6,-(SP)   ;SAVE LOC 6  
        MOV      #35,#4     ;SET UP TRAP CATCHER  
        CLR      #6        ;CLEAR VECT+2  
        TST      STOP      ;FIRST TIME HERE?  
        BEQ      8$  
        MOV      #-1,STOP   ;BR IF YES  
        BIT      #100,DMBB   ;CARRIER UP?  
        BNE      -6        ;BR IF YES  
        BIS      #BIT2,DMBB  ;SET RQTS IN DMBB  
        BIT      #BIT5,DMBB  ;SPIN ON CTS  
        BEQ      2$  
        CMP      -(SP),-(SP) ;ADJUST STACK  
        CMP      (SP)+,(SP)+ ;POP STACK  
        MOV      (SP)+,#6    ;RESTORE LOC 6  
        MOV      (SP)+,#4    ;RESTORE LOC 4  
        MOV      IXDA,XDA    ;SET UP XMIT DATA ADD  
        BIC      #XFLG,STAT  ;CLEAR XFLG  
        MOV      XDA,CAR(R4) ;LOAD CURRENT ADDRESS REG  
        BIT      #HALF.DUPLEX,PARAM2 ;HALF DUPLEX?  
        BNE      7$  
        BIT      #XLB,MODE   ;XLB MODE?  
        BEQ      7$  
        MOV      #-1,TRNFLG  ;BR IF YES  
        MOV      #-1,BCR(R4) ;BR IF NO  
        BIS      #TIE,ARCSR  ;SET SOFTWARE FLAG  
        MOV      BARTMP,BAR(R4)  
        WAIT  
        TST      SNCFGL      ;HAS RECEIVER GOT FIRST CHAR?  
        BNE      -4         ;NO WAIT FOR IT  
        MOV      XDA,CAR(R4) ;LOAD CURRENT ADDRESS REG
```

1029	013446	012764	177777	000010		MOV	#-1,BCR(R4)	:LOAD BYTE COUNT REG
1030	013454	052714	020000			BIS	#TIE,ARCSR	:SET INTERRUPT ENABLE
1031	013460	013764	013714	000012		MOV	BARTMP,BAR(R4)	:LOAD BAR REG
1032	013466	000207				RTS	PC	
1033								
1034	013470	042714	100000		XISR:	BIC	#TI,ARCSR	:CLEAR XMIT DONE
1035	013474	032714	002000			BIT	#NEM,ARCSR	:NON-EXISTENT MEM ERROR?
1036	013500	001407				BEQ	15	:BR IF NO
1037	013502	011402				MOV	ARCSR,R2	:SAVE CSR FOR TYPE OUT
1038	013504	005003				CLR	R3	
1039	013506	104010				HLT	10	:ERROR HLT
1040	013510	104400	014317			TYPE	,NONEX	:TYPE ERROR MESS
1041	013514	000000				HALT		
1042	013516	000776				BR	-2	:BR HALT
1043	013520	127737	175344	011040	15:	CMPB	AXDA,TX.TERM	:IS CHAR TERMINATION CHAR?
1044	013526	001033				BNE	XISR1	:BR IF NO
1045	013530	052700	100000			BIS	#XFLG,STAT	:SET XMIT DONE FLAG
1046	013534	042714	020000			BIC	#TIE,ARCSR	:CLEAR INTERRUPT ENABLE
1047	013540	032737	040000	011014		BIT	#HALF.DUPLEX,PARAM2	:HALF DUPLEX?
1048	013546	001422				BEQ	35	:BR IF NO
1049	013550	013746	000004			MOV	#4,-(SP)	:SAVE LOC 4
1050	013554	013746	000006			MOV	#6,-(SP)	:SAVE LOC 6
1051	013560	012737	013602	000004		MOV	#25,#4	:SET UP TRAP CATCHER
1052	013566	005037	000006			CLR	#6	:CLEAR VECT+2
1053	013572	042777	000004	000116		BIC	#BIT2,ADMBB	:CLEAR RQTS
1054	013600	024646				CMP	-(SP),-(SP)	:ADJUST STACK
1055	013602	022626			25:	CMP	(SP)+,(SP)+	:POP STACK
1056	013604	012637	000006			MOV	(SP)+,#6	:RESTORE LOC 6
1057	013610	012637	000004			MOV	(SP)+,#4	:RESTORE LOC 4
1058	013614	000430			35:	BR	XISR2	
1059	013616	032777	000100	175220	XISR1:	BIT	#100,ASWR	:MONITOR XMIT DATA?
1060	013624	001406				BEQ	NOXMON	:BR IF NO
1061	013626	105777	175244			TSTB	ATPS	:TTY READY?
1062	013632	100003				BPL	NOXMON	:BR IF NO
1063	013634	117777	175230	175236		MOVB	AXDA,ATPB	:TYPE CHAR
1064	013642	005237	011070		NOXMON:	INC	XDA	:INC TXBUF POINTER
1065	013646	013764	011070	000006		MOV	XDA,CAR(R4)	:LOAD CURRENT ADDRESS REG
1066	013654	005737	013722			TST	TRNFLG	:IS THIS FIRST TIME?
1067	013660	001006				BNE	XISR2	:BR IF YES
1068	013662	012764	177777	000010		MOV	#-1,BCR(R4)	:LOAD BYTE COUNT REG
1069	013670	013764	013714	000012		MOV	BARTMP,BAR(R4)	:SET BAR BIT
1070	013676	005037	011032		XISR2:	CLR	TIME	
1071	013702	005037	013722			CLR	TRNFLG	
1072	013706	000002				RTI		
1073	013710	000000			TEMP1:0			
1074	013712	000000			TEMP2:0			
1075	013714	000000			BARTMP:0			
1076	013716	170502			DMBB:170502			:LINE STATUS REG IN DMBB
1077	013720	000000			SNCFLG:0			
1078	013722	000000			TRNFLG:0			
1079	013724	177			FILL:177			
1080		013726			.EVEN			


```
1081
1082
1083
1084
1085 013726 032737 040000 011014 STARTR: BIT #HALF.DUPLEX,PARAM2 :HALF DUPLEX?
1086 013734 001010 BNE 2$ :BR IF YES
1087 013736 032700 000004 BIT #XLB,MODE :XLB MODE?
1088 013742 001405 BEQ 2$ :BR IF NO
1089 013744 005037 013710 CLR TEMP1 :START DELAY
1090 013750 005237 013710 1$: INC TEMP1
1091 013754 001375 BNE 1$
1092 013756 042700 040000 2$: BIC #RFLG,STAT :CLEAR RFLG
1093 013762 013737 011020 011066 MOV IRDA,RDA :SET UP RECEIVER DATA ADD
1094 013770 012737 001000 011064 MOV #1000,RCC :SET UP BUFFER LIMIT
1095 013776 012737 177777 013720 MOV #-1,SNCFLG :SET SOFTWARE FLAG
1096 014004 005037 011054 CLR ERCSR :CLEAR ERROR RECORDS
1097 014010 005037 011056 CLR ERDBR
1098 014014 052714 004000 BIS #BIT11,ERCSR :MASTER CLEAR
1099 014020 053714 011012 BIS PARAM1,ERCSR :SET LINE NUMBER
1100 014024 053764 011014 BIS PARAM2,LPR(R4) :LINE PARAMETERS
1101 014032 052714 010100 BIS #RIE+SIE,ERCSR :SET INTERRUPT ENABLES
1102 014036 000207 RTS PC
1103
1104 014040 032714 040000 RISR: BIT #SI,ERCSR :SILO OVERFLOW?
1105 014044 001407 BNE 1$ :BR IF NO
1106 014046 011402 MOV ERCSR,R2 :SAVE CSR FOR TYPEOUT
1107 014050 005003 CLR R3
1108 014052 104010 HLT 10 :ERROR HLT
1109 014054 104400 014270 TYPE ,SILO :TYPE ERROR MESS
1110 014060 000000 HALT
1111 014062 000776 BR -2 :BR HALT
1112 014064 016401 000002 1$: MOV NCR(R4),R1 :PUT CHAR IN R1
1113 014070 042701 000200 BIC #200,R1 :STRIP A BIT
1114 014074 005701 TST R1 :VALID DATA?
1115 014076 100403 BMI 4$ :BR IF YES
1116 014100 011402 MOV ERCSR,R2 :SAVE CSR FOR TYPEOUT
1117 014102 005003 CLR R3
1118 014104 104010 HLT 10 :ERROR HLT
1119 014106 032701 070000 4$: BIT #DO+FE+PE,R1 :OVERRUN, FRAMING OR PARITY ERROR?
1120 014112 001404 BNE 3$ :BR IF NO
1121 014114 011437 011054 MOV ERCSR,ERCSR :SAVE CSR
1122 014120 010137 011056 MOV R1,ERDBR :SAVE CHAR
1123 014124 110177 174736 3$: MOV R1,IRDA :STORE CHAR IN BUFFER
1124 014130 032777 000040 174706 BIT #BITS,SWR :MONITOR RECEIVE DATA?
1125 014136 001405 BEQ NORMON :BR IF NO
1126 014140 105777 174732 TSTB JTPS :TTY READY?
1127 014144 100002 BPL NORMON :BR IF NO
1128 014146 110177 174726 MOV R1,JTPB :TYPE CHAR
1129 014152 005237 011066 NORMON: INC RDA :INC RECEIVER BUFFER POINTER
1130 014156 105077 174704 CLRB JRDA :CLEAR NEXT LOCATION
1131 014162 005337 011064 DEC RCC :DEC CHAR COUNT
1132 014166 001005 BNE 1$ :BR IF BUFFER NOT FULL
1133 014170 000005 RESET
1134 014172 104000 HLT 0 :STOP THE SHOW,BUFFER OVERFLOWED!
1135 014174 104006 HLT+6 :RECEIVER BUFFER FULL
1136 014176 000000 HALT
```

1137	014200	000776			BR	-2		:BR HALT
1138	014202	123701	011041	1\$:	CMPB	RX.TERM,R1		:IS CHAR RCV TERMINATION CHAR
1139	014206	001004			BNE	RISR1		:BR IF NOT
1140	014210	042714	010100		BIC	#RIE+SIE,DRCSR		:CLEAR INTERRUPT ENABLES
1141	014214	052700	040000		BIS	#RFLG,STAT		:SET RCV DONE FLAG
1142	014220	005037	011032	RISR1:	CLR	TIME		
1143	014224	005037	013720		CLR	SMOFLG		:CLEAR FLAG
1144	014230	000002			RTI			
1145	014232	005015	051105	047522	MFULL:	.ASCIZ<15><12>/ERROR! RECEIVER BUFFER FULL/		
	014270	005015	051105	047522	SILO:	.ASCIZ<15><12>/ERROR! SILO OVERFLOW/		
	014317	015	047012	047117	NONEX:	.ASCIZ<15><12>/NON EXISTENT MEMORY ERROR/		
	014353	015	050012	042514	LINES:	.ASCIZ<15><12>/PLEASE SELECT ONLY ONE LINE AT A TIME(PARAM3)/		
		014434			.EVEN			
		000001			.END			

CZDHLCO DH11 ITP OVERLAY
CZDHLCO.P11 23-MAR-78 12:56

MACY11 30A(1052) 23-MAR-78 13:03 PAGE 27
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0025
SEQ 0025

BA	011004	602#	661						
BACK	013122	735#	763*	798*	878*	909	970#		
BAR	= 000012	596#	1024*	1031*	1069*				
BARTMP	013714	677*	1024	1031	1069	1075#			
BCR	= 000010	596#	1022*	1029*	1068*				
BITO	= 000001	596#							
BIT1	= 000002	596#							
BIT10	= 002000	596#							
BIT11	= 004000	596#	1098						
BIT12	= 010000	596#							
BIT13	= 020000	596#	631#	920	947				
BIT14	= 040000	596#							
BIT15	= 100000	596#							
BIT2	= 000004	596#	1007	1053					
BIT3	= 000010	596#							
BIT4	= 000020	596#							
BIT5	= 000040	596#	1008	1124					
BIT6	= 000100	596#							
BIT7	= 000200	596#							
BIT8	= 000400	596#							
BIT9	= 001000	596#							
B2016	011030	612#	923						
CAR	= 000006	596#	1016*	1028*	1065*				
DELAY	013120	687*	907*	969#	979	994*			
DEAR	012532	948	957#						
DH11	011000	601#							
DISPLA	011046	622#							
DMBB	013716	1005	1007*	1008	1053*	1076#			
DO	= 040000	596#	1119						
DSFLG	= 020000	596#	630#						
DSSTAT	011060	637#							
ENTER	012272	841	900#						
EOP	012204	736	764	799	879	886#			
ERCSR	011054	635#	1096*	1121*					
ERDBR	011056	636#	918	1097*	1122*				
FE	= 020000	596#	1119						
FILL	013724	1079#							
FLAG	011042	620#							
FULL.D	= 000001	649#							
GO	011230	686#							
HALF.D	= 040000	596#	838	854	859	996	1017	1047	1085
ILB	= 000010	596#	695						
IRDA	011020	608#	802	927	950	1093			
IXDA	011022	609#	803	926	954	956	1014		
KBDIN	= 104416	596#	717	748	780	837			
LINES	014353	1145#							
LOOP	= 000020	596#	733	761	796	876			
LPR	= 000004	596#	664*	1100*					
MC	= 004000	596#	662						
MFULL	014232	1145#							
MSG0	012544	922	963#						
MSG1	012625	925	963#						
MSG2	012630	949	963#						
MSG3	012655	953	963#						
MSG4	012700	963#							
MSG5	013032	963#							

[illegible]

DOCUMENT PAGES: 27

C03