

# MS11-K

0-124K MEMORY EXERCISER  
CZQMCE0

AH-9047E-MC

COPYRIGHT © 75-78

FICHE 1 OF 1

MAR 1978

**digital**

MADE IN USA



EDF102070880411

00010000 780223  
=====

IDENTIFIED

.PHDR:0ZQMCESEQ

00010000

780223  
SEQ 0001

PRODUCT CODE: AC-9045E-MC  
PRODUCT NAME: CZQMCEQ D-124K MEM EXER 16K  
PRODUCT DATE: FEB 1978  
MAINTAINER: DIAGNOSTIC ENGINEERING

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital or its affiliated companies

Copyright (c) 1975, 1978 by Digital Equipment Corporation

The following are trademarks of Digital Equipment Corporation:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	



REVISION HISTORY  
=====

Revision A:	May 1975
Revision B:	October 1975
Revision C:	October 1976
Revision D:	June 1977
Revision E:	December 1977



TABLE OF CONTENTS

1.0	GENERAL PROGRAM INFORMATION.
1.1	Program Purpose (Abstract)
1.2	System Requirements
1.3	Related Documents and Standards
1.4	Diagnostic Hierarchy Prerequisites
1.5	Assumptions
2.0	OPERATING INSTRUCTIONS
2.1	Loading and Starting Procedure
2.2	Special Environments
2.3	Program Options
2.4	Execution Times
3.0	ERROR INFORMATION
3.1	Error Reporting
3.2	Error Halts
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
5.1	CORE PARITY REGISTER
5.2	MOS PARITY REGISTER
5.3	MSII-K CSR
6.0	SUB-TEST SUMMARIES
6.1	Section 1: Address Tests
6.2	Section 2: Worst Case Noise Tests
6.3	Section 3: Instruction Execution Tests
6.4	Section 4: MOS Tests
6.5	Special Toggle in Tests
7.0	PROGRAM FUNCTIONAL FLOW CHARTS
8.0	PROGRAM LISTING



## 1.0 GENERAL PROGRAM INFORMATION.

## 1.1 Program Purpose (Abstract)

This program has the ability to test memory from address 000000 to address 757777. It does so using:

- A. Unique addressing techniques
- B. Worse case noise patterns, and
- C. Instruction execution thruout memory.

There is also a special routine to type out all unibus address ranges which do not timeout, as well as two(2) toggle in address tests provided in section 6.1 of this document.

The intent of this program is to test as comprehensively as possible all memory systems manufactured by DEC without concentrating on any one system. Although the tests relate to general designs they may be complete for certain systems. E.G. Any core memory from the 8K M11-L on up need not have any other addressing or worst case patterns run but in order to completely test the M11-K MOS memory another diagnostic is required. This test is also not intended to be a 100% test of the memory. Other tests that do I/O may find memory problems that this test is unable to.

## 1.2 System Requirements

## A. Hardware Requirements

PDP11 family processor with a minimum of 16K of memory.  
optional...  
Any parity memory control module.  
KT11 memory management.

## B. Software Requirements

The smallest unit of memory this program will recognize is 4K. If any address in a 4K bank causes a time out trap, that entire bank of memory is ignored by the program.

The program is designed to exercise the vector portion of memory (locations 0-776) in exactly the same manner as the rest of memory. To make this possible, without requiring memory management, no software traps are used in the program. This means that if memory management is not available or is disabled (SW12=1), if the program is relocated out of bank 0, if location 0-776 are selected for test, and if an unexpected hardware trap occurs, the results will be unpredictable.



The program has the proper interface code to allow running under the automated manufacturing test line system - ACT11 and APT.

### 1.3 Related Documents and Standards

- A. Programming practices - Document No. 175-003-009-01
- B. PDP-11 MAINDEC SYSMAC Package - MAINDEC-11-DZQAC-C2-D
- C. MF11-U/UP Core Memory System Maintenance Manual  
Document No. DEC-11-HMFMA-B-D
- D. Applicable Circuit Schematics:
  - G235 - 16K X-Y DRIVE
  - G114 - 16K SENSE/INHIBIT
  - M8293 - 16K UNIBUS TIMING
  - M7259 - PARITY CONTROL

### 1.4 Diagnostic Hierarchy Prerequisites

Before running this program, a CPU diagnostic should be run to verify the functionality of the processor and PDP-11 instruction set.

If memory management is to be used, then the KT11 diagnostic should also be run before this program.

PDP-11/05 - MAINDEC-11-DZQKC  
 PDP-11/20 - MAINDEC-11-DZQKC  
 PDP-11/34 - MAINDEC-11-DFKTH  
 PDP-11/40 - MAINDEC-11-DBQEA  
           OR MAINDEC-11-DCQKC  
 PDP-11/45 - MAINDEC-11-DCQKC  
 PDP-11/60 - MAINDEC-11-DQKDA  
 KT11-C - MAINDEC-11-DCKTA THRU DCKTF  
 KT11-D - MAINDEC-11-DBKTA THRU DBKTF

### 1.5 Assumptions

This program assumes the correct operation of the CPU and, if used, the memory management option.

## 2.0 OPERATING INSTRUCTIONS

### 2.1 Loading and Starting Procedures

2.1.1 Load the program using any standard absolute loader.

2.1.2 Starting address 200:

Normal program execution.

2.1.3 Starting address 204:

Allows the operator to input, via teletype conversation,



first and last addresses to be exercised, and a data pattern to be used in tests 6 and 7.

#### 2.1.4 Starting Address 210:

Restart program using previously selected parameters.

#### 2.1.5 Starting Address 214:

Restore loaders and halt. This routine is capable of relocating the program back to banks 0 and 1 if the program was halted while running the top two banks of memory. There are special procedures required for this situation.

- A. If memory addresses 0-1000 have not been exercised, either through parameter selection (SA=204) or by running with SW05=1, then:

Load Address 214,  
Press START.

- B. If running without memory management, then:

Load Address <214+relocation factor>  
(Relocation factor is typed when the program is relocated),  
Press START.

- C. If running with memory management and the unibus has not been initialized (via reset instruction, start switch, etc.), then:

Load Address 777707 (PC)  
Deposit 214  
Press CONTINUE

- D. If running with memory management and the unibus has been initialized:

Load Address 772340 (KIPAR0)  
Deposit <(relocation factor)/100>  
(Example: Relocation factor=540000, then  
deposit 005400)  
Load Address 777572 (SR0)  
Deposit 000001  
Load Address 777707 (PC)  
Deposit 214  
Press Continue

#### 2.1.6 Starting address 220:

Byte address memory map typeout routine. This routine performs DATI, DATIP, DATO, and DATOB on all possible



addresses, and types the ranges of addresses which do not cause a timeout trap.

## 2.2 Special Environments

If the program is run in quick verify mode under ACT11 or APT11 the program is done after the first pass. Also, the program does not relocate to test the lower 8K of memory.

## 2.3 Program Options

SW15 = 1 OR UP....	HALT ON ERROR
SW14 = 1 OR UP....	LOOP ON TEST
SW13 = 1 OR UP....	INHIBIT ERROR TYPEOUT
SW12 = 1 OR UP....	INHIBIT MEMORY MANAGEMENT (INITIAL START ONLY)
SW11 = 1 OR UP....	INHIBIT SUBTEST ITERATION
SW10 = 1 OR UP....	RING BELL ON ERROR
SW9 = 1 OR UP....	LOOP ON ERROR
SW8 = 1 OR UP....	LOOP ON TEST IN SWR<4:0>
SW7 = 1 OR UP....	INHIBIT PROGRAM RELOCATION
SW6 = 1 OR UP....	INHIBIT PARITY ERROR DETECTION

NOTE: With parity error detection enabled, a memory failure while running the worse case noise tests (non-parity) can cause a parity error. The error printout on a parity error does not type the good data. Thus a bit drop or pickup will not be typed as such. It is best to run the program for 1 pass with parity disabled, then, restart the program with parity enabled.

SW5 = 1 OR UP.	INHIBIT EXERCISING VECTOR AREA (LOCATIONS 0-1000).
----------------	--

## 2.4 EXECUTION TIMES

Execution time is dependent on type of memory, and amount of memory. Worse case run times with 900ns memorys are:

- a. For Non-Parity Memory
  - First Pass: 65 seconds for first 16k + 15 seconds for each additional 16k.
  - Full Pass: 3 minutes 40 seconds for first 16k + 3 minutes for each additional 16k.



Iteration Inhibited: same as first pass

- b. For Parity Memory  
First Pass: 1 minute 40 seconds per 16k.  
Full Pass: 8 minutes per 16K  
Iteration Inhibited: same as first pass

### 3.0 ERROR INFORMATION

#### 3.1 Error Reporting

There are a total of 31(8) types of error reports generated by the program. Some of the key column heading mnemonics are described below for clarity:

PC = Program Counter of error detection code.  
(V/PC=P, PC)

V/PC = Virtual Program Counter. This is where the error detection code can be found in the program listing.

P/PC = Physical Program Counter. This is where the error detection code is actually located in memory.

TRP/PC = Physical Program Counter of the code which caused a trap.

MA = Memory Address

REG = Parity REGISTER address.

PS = Processor Status word.

IUT = Instruction Under Test.

S/B = What contents Should Be.

WAS = What contents WAS.

#### 3.2 Error Halts

With the 'HALT ON ERROR' switch (SW15) not set there are several programmed 'HALTS' in the program:

- A. In the error trap service routine for unexpected traps to vector 4. This one will occur if a 2nd trap to 4 occurs before the error report for the first has had a chance to be printed out.



- B. In the relocation routine if the program is being relocated back to the first BK of memory and the program code was not able to be transferred properly.
- C. In the case of error reporting and there is no terminal to allow the information transfer.
- D. In the power fail routine if the power up sequence was started before the power down sequence had a chance to complete itself.
- E. In the Memory mapping routine or any of the address control routines, failures to find a meaningful map.

## 4.0 PERFORMANCE AND PROGRESS REPORTS

Not applicable

## 5.0 DEVICE INFORMATION TABLES

The following is a picture view of a parity control status registers, which will show bit assignments and definitions, to provide a handy reference:

## 5.1 CORE PARITY REGISTER

```

-----
| I | I | I | I | I | I | I | I | I | I | I | I | I | I | I | I |
| PE |   |   |   |   |   | ADDRESS |   |   |   |   | WP |   | AE |
| I | I | I | I | I | I | I | I | I | I | I | I | I | I | I | I |
-----
15 14 13 12 11 10 09 08 07 06 05 04 03 02 01 00

```

Bit assignments are defined as follows:

BIT15	PARITY ERROR	
BITS 11-5	ERROR ADDRESS	HIGH ORDER ADDRESS BITS OF ADDRESS OF PARITY ERROR (BITS 17-11 OF ADDRESS)
BIT02	WRITE WRONG PARITY	NORMAL PARITY (ODD) WHEN CLEAR; OTHER PARITY (EVEN) WHEN SET
BIT00	ACTION ENABLE	NO ACTION WHEN CLEAR TRAP TO VECTOR 114 WHEN SET

## 5.2 MCS PARITY REGISTER



BIT15	PARITY ERROR	
BIT02	WRITE WRONG PARITY	NORMAL PARITY (ODD) WHEN CLEAR; OTHER PARITY (EVEN) WHEN SET
BIT00	ACTION ENABLE	NO ACTION WHEN CLEAR TRAP TO VECTOR 114 WHEN SET

I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
DE		SI				ADDRESS				SE	IP	DC	EC	EE		
I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00	

BIT15	DOUBLE ERROR	
BIT 13	SET INHIBIT MODE	WHEN THIS BIT IS SET TO A 1, IT ENABLES THE INH MODE POINTER TO INHIBIT EITHER THE FIRST OR SECOND 16K FROM EVER GOING INTO THE DIAG. CHECK OR ECC DISABLE MODE.
BITS 11-5	ERROR ADDRESS	WHEN BIT02 CLEARED, CONTAINS HIGH ORDER BITS OF ADDRESS OF PARITY ERROR (BITS 17-11). WHEN BIT02 SET, CONTAINS CHECK BITS FOR ECC.
BIT04	SINGLE ERROR	SET WHENEVER SINGLE ERROR OCCURS
BIT03	INHIBIT MODE POINTER	THE INHIBIT MODE POINTER WORKS IN



CONJUNCTION WITH THE  
SET INHIBIT MODE BIT.  
WHEN BIT 13 IS SET TO  
A 1, A 16K PORTION OF  
MEMORY IS INHIBITED  
FROM OPERATING IN THE  
ECC DISABLE MODE OR  
DIAGNOSTIC CHECK MODE.  
THE INHIBIT MODE  
POINTER INDICATES  
WHICH 16K IS BEING  
INHIBITED,,,BIT 3 =1

THE SECOND 16K OF  
MEMORY IS INHIBITED.  
WHEN BIT 13 IS SET TO  
A 0, BIT 3 BECOMES  
INOPERATIVE.

BIT02	DIAGNOSTIC CHECK A	WHEN SET ENABLES READ-WRITE OF CHECK BITS(SEE BITS 11-5)
BIT01	DISABLE ERROR CORRECTION	WHEN SET NO ERROR CORRECTION TAKES PLACE
BIT00	DOUBLE ERROR ENABLE	WHEN SET ENABLES TRAP TO VECTOR 114 ON DOUBLE ERROR.

## 6.0 SUB-TEST SUMMARIES

### 6.1 Section 1: Address Tests.

These tests verify the uniqueness of every memory address.

TEST 1 Writes and reads the value of each memory Word Address into that Memory location. After all memory has been written, all locations are checked again.

TEST 2 Writes the byte value of each address into that byte location and checks it.

TEST 3 Writes the complement of each word address into that location and checks it.

TEST 4 Writes the 4K bank number into each byte of that bank and checks it.

TEST 5 Writes the complement of the bank number into each byte of that bank and checks it.



## E.2 Section 2: Worst Case Noise Tests.

These are intended to apply maximum stress to the various types of PDP-11 core memories.

TEST 6 and TEST 7 Are supplied to allow the operator to select a single word data pattern (SA=204) and SCOPE on either the writing (DATO) in TEST 6 or the reading (DATI) in TEST 7 of that data.

TEST 10 Writes and then checks a series of single word patterns which are designed to stress parity memory.

TEST 11 Writes all memory with 1's in every bit and then "Ripples" a "0" through it.

TEST 12 Writes all memory with 0's in every bit and then "Ripples" a "1" through it.

TEST 13,14,15, AND 16 Write a pattern which complements when address BIT 3 XOR BIT 9 complements.

TEST 17 Writes wrong parity in each byte of memory and checks that the parity detection logic works. This test is skipped for non-parity memory.

TEST 20 Write "random" program code through memory and checks it.

## E.3 Section 3: Instruction Execution Tests.

This group of tests place instructions in the memory under test, then executes the instructions, and finally, checks that they executed correctly.

TEST 21 Executes an instruction which does a DATI and a DATO on the memory under test.

TEST 22 Executes an instruction which does a DATI and a DATOB on the low byte of memory under test.

TEST 23 Executes an instruction which does a DATI and a DATOB on the high byte.

TEST 24 Executes an instruction which does a DATIP and a DATO.

TEST 25 Executes an instruction which does a DATIP and a DATOB on the low byte.

TEST 26 EXECUTES AN INSTRUCTION WHICH DOES A DATIP and a DATOB on the high byte.



## e 4 Section 4: Mos Tests

TEST 27 -Writes a pattern of 000577 through memory, then compliments it addressing downward, compliments the new pattern addressing upward, compliments the third pattern addressing upward and finally compliments this new AB patterns addressing downward.

TEST 30-31 Write a checkerboard through memory then stalls for 2 seconds and then verifies no data has changed.

## e 5 Special Toggle In Tests

## e 5.1 Toggle-in-program #1

The following is a toggle in memory address test. This test is useful when an address selection failure is suspected involving the first 8K of memory. This program writes the value of each address into itself starting with the lower limit and continuing to the upper limit. After all addresses have been written each address is checked for the correct contents starting with the upper limit and continuing to the lower limit.

LOCAT	CONTENTS	MNEMONIC	COMMENT
10	012700	MOV #50,R0	GET FIRST ADDRESS
* 12	000050		TO TEST
			(EXAMPLE START ADDRESS)
14	C10001	MOV R0,R1	SAVE IN R1
16	C20037	15: CMP R0,#SWR	CHECK UPPER LIMIT
20	177570		(IN SWITCH REGISTER)
22	001403	BEQ 25	BRANCH IF AT UPPER LIMIT
24	010010	MOV R0,(R0)	LOAD VALUE INTO ADDRESS
26	005720	TST (R0)+	STEP TO NEXT ADDRESS
30	000772	B 15	LOOP UNTIL DONE
32	010004	25: MOV R0,R4	SAVE UPPER LIMIT
34	020001	35: CMP R0,R1	CHECK IF AT LOWER LIMIT
* 36	001767	BEQ 15	BRANCH IF DONE
40	024000	CMP -(R0),R0	CHECK DATA WRITTEN
42	001774	BEQ 35	BRANCH IF OK
44	000000	HALT	ERROR
46	000772	BR 35	LOOP BACK

After toggling the program LA=10\*set upper limit\*\*, start

NOTES: The upper limit address obtained from the switch register may be changed during program operation. However occasionally the program may halt because of 'SWITCH BOUNCE'. (The best procedure when changing limits is to stop the program make the change and continue.) The lower limit address (12) may be patched to any desired address.



## 6.5.2 Toggle-in-Program #2

The following is also a toggle in program to be used with toggle-in-program #1 for more complete address testing. This program writes the complement value of each address into itself starting with the upper limit and continuing to the lower limit. After all addresses have been written each address is checked for the correct contents starting with the lower limit address and continuing to the upper limit. Toggle in the following patches to the program above.

These are the patches to toggle-in-program #1:

LOCATION	CONTENTS	MNEMONIC	COMMENT
12	100		:CHANGE LOWER LIMIT
36	001404	BEQ 4\$	:BRANCH TO PROGRAM #2

These are the additions to toggle-in-program #1:

LOCATION	CONTENTS	MNEMONIC	COMMENT
50	010402	4\$: MOV R4,R2	:GET UPPER LIMIT
52	005142	5\$: COM -(R2)	:COMPLEMENT ADDRESS
54	020201	CMP R2,R1	:CHECK IF AT LOWER LIMIT
56	001375	BNE 5\$	:LOOP UNTIL DONE
60	020204	6\$: CMP R2,R4	:CHECK IF AT UPPER LIMIT
62	001755	BEQ 1\$	:GO TO PROGRAM 1 IF DONE
64	010203	MOV R2,R3	:GET VALUE OF ADDRESS
66	005103	COM R3	:COMPLEMENT VALUE
70	020322	CMP R3,(R2)+	:CHECK ADDRESS
72	001772	BEQ 6\$	:BRANCH IF OK
74	000000	HALT	:ERROR
76	000770	BR 6\$	:GO CHECK NEXT ADDRESS

7.0 PROGRAM FUNCTIONAL FLOW CHARTS  
Attached

8.0 PROGRAM LISTING  
Attached



C02

CZQMCE0 0-124K MEM EXER 16K

DECFL0 VER 00.07 10-JAN-78 13:19 PAGE A

SEQ 0015

FLOW CHART  
\*\*\*\*\*

CZQMCE0 0-124K MEM EXER 16K

\*\*\*\*\*

COPYRIGHT 1978  
DIGITAL EQUIPMENT CORPORATION  
MAYNARD, MASS. 01754



TABLE OF CONTENTS  
\*\*\*\*\*

PAGE 01	DEFINITIONS, TRAP CATCHER, STARTING ADDRESSES.
PAGE 02	RESTART AND RESTORE ROUTINES
PAGE 04	POWER FAIL ROUTINES
PAGE 05	COMMON TAGS
PAGE 06	SETUP
PAGE 08	MAP MEMORY
PAGE 09	MEMORY BYTE MAP ROUTINE
PAGE 12	MAP PARITY REGISTERS
PAGE 13	MAP PARITY MEMORY
PAGE 14	TEST PARITY REGISTERS
PAGE 15	USER PARAMETER SELECTION SECTION
PAGE 16	START1: START OF PASS
PAGE 17	SECTION 1: ADDRESS TESTS. TEST 1
PAGE 18	TEST 2
PAGE 19	TEST 3
PAGE 20	TEST 4
PAGE 21	TEST 5
PAGE 22	SECTION 2: WORSE CASE NOISE TESTS. TEST 6
PAGE 23	TEST 7
PAGE 24	TEST 10
PAGE 25	TEST 11
PAGE 26	TEST 12
PAGE 27	TEST 13: 3 XOR 9
PAGE 29	TEST 14: 3 XOR 9
PAGE 31	TEST 15: 3 XOR 9 (FOR PARITY)



TABLE OF CONTENTS  
\*\*\*\*\*

PAGE 33	TEST 16: 3 XOR 9 (FOR PARITY)
PAGE 35	TEST 17: PARITY BYTE TEST
PAGE 39	TEST 20
PAGE 40	TEST 21: EXICUTE DATI, DATO
PAGE 41	TEST 22: EXICUTE DATI, DATOB (LO BYTE)
PAGE 42	TEST 23: EXICUTE DATI, DATOB (HI BYTE)
PAGE 43	TEST 24: EXICUTE DATIP, DATO
PAGE 44	TEST 25: EXICUTE DATIP, DATOB (LO BYTE)
PAGE 45	TEST 26: EXICUTE DATIP, DATOB (HI BYTE)
PAGE 46	TEST 27: MARCHING 1'S AND 0'S
PAGE 49	TEST 30: MOS REFRESH TEST
PAGE 51	TEST 31: MOS REFRESH TEST
PAGE 53	DONE
PAGE 54	END OF PASS
PAGE 55	MEMORY MANAGEMENT AND ADDRESSING SUBROUTINES
PAGE 57	SUBROUTINES FOR ADDRESS AND WORSE CASE NOISE TESTS
PAGE 58	RELOCATION SUBROUTINES
PAGE 60	PARITY ROUTINES
PAGE 62	SPECIAL PRINTOUT ROUTINES
PAGE 63	SYSMAC AND STANDARD UTILITY ROUTINES



F02

CZQMCEO 0-124K MEM EXER 16K  
DEFINITIONS. TRAP CATCHER, STARTING ADDRESSES.

DECFL0 VER 00.07 10-JAN-78 13:19 PAGE 01

SEQ 0018

```
*****  
* SWITCH SETTINGS AND *  
* BASIC DEFINITIONS *  
* *  
*****
```

```
*****  
* TRAP CATCHER AND *  
* STARTING ADDRESSES *  
* *  
*****  
.=0
```




CZQMCE0 0-124K MEM EXER 16K  
RESTART AND RESTORE ROUTINES

SEQ 0019

SA=210 . =300

SA=214





CZQMCE0 0-124K MEM EXER 16K  
RESTART AND RESTORE ROUTINES

```

-----
/ PROGRAM MAP \ YES
/ POINTING TO BANKS 0 & 1? \
-----
I NO
V RELO(59)
*****
** RELOCATE PROGRAM TO **
** BANKS 0 & 1 **
**
*****
I<-----
V
-----
/ RESTART FLAG \ YES
/ (RS=0)? \ -----> *****
*****
I NO
V RESLDR(59)
*****
** RESTORE LOADERS **
**
*****
I
V
*****
**HALT **
*****

```

. =572



```
*****  
**$PWRDN **  
*****  
  I  
  V  
*****  
* $ILLUP -> VECTOR *  
*   SAVE REGISTERS   *  
* $PWRDN -> VECTOR *  
*****  
  I  
  V  
*****  
**HALT **  
*****
```

```
*****  
**$PWRUP **  
*****  
  I  
  V  
*****  
* WAIT LOOP FOR TTY *  
* RESTORE REGISTERS *  
* $PWRDN -> VECTOR *  
*****  
  I  
  V  
***** SPRINT(63)  
***  
  I  
  V  
*****  
  I  
  V  
*****  
**RETURN **  
*****
```

```
*****  
**$ILLUP **  
*****  
  I  
  V  
*****  
**HALT **  
*****
```



CZQMCED 0-124K MEM EXER 16K  
COMMON TAGS

J02

DECFL0 VER 00.07 10-JAN-78 13:19 PAGE 05

SEQ 0022

.=1100

```
*****
* STANDARD 'SYSMAC' *
* COMMON TAGS *
* *****
```

```
*****
* APT MAILBOX AND *
* ETABLE *
* *****
```

```
*****
* COMMON TAGS FOR THIS *
* PROGRAM *
* *****
```

```
*****
* RELATIVE ADDRESSING *
* TABLE, ERROR DATA *
* POINTER *
* *****
```

```
*****
* MEMORY PARITY WORSE *
* CASE PATTERNS TABLE *
* *****
```

```
*****
* MEMORY PARITY *
* REGISTER ADDRESS AND *
* MAP TABLE *
* *****
```

```
*****
* ERROR MESSAGE POINTER *
* TABLE *
* *****
```




SA=204

```
*****
**SELECT **
*****
I
*****
* SET FLAG FOR *
* SELECTING *
* PARAMETERS *
*****
I
```

SA=200

```
*****
**START **
*****
I
*****
* CLEAR FLAG FOR *
* SELECTING *
* PARAMETERS *
*****
I
```






```


      / CLEAR 'MMAVA' \ YES
     / MEMORY MGMTMENT \ -----
    / EXITS AND DESIRED? \
-----
          I NO
          |
          | I
          | I
          | I
          | I
          | I
          | I <-----
          V
*****
*
*TURN OFF CACHE *
*
*****
          I
          I
          V

```














020MCEC 0-124 MEM EXER 16K  
MEMORY BYTE MAP ROUTINE















[illegible]











H03

DECFL0 VER 00.07 10-JAN-78 13:19 PAGE 16

SEQ 0033

CZQMCEO 0-124K MEM EXER 16K  
START1: START OF PASS

```
MANUL2
*****
*   MAKE NECESSARY   *
*ADJUSTMENTS TO FIRST*
* AND LAST ADDRESSES *
*****
      I
      V
*****
**START1**
*****
      I
      I
      I
      V
START1
*****
*INITIALIZE EVERYTING*
*  FOR A NEW PASS    *
*****
      I
      I
      I
      I
      V
```



```

TST1 INITMM(55)
*****
** INITIALIZE ADDRESS **
** POINTERS **
*****
----->I
V
*****
* WRITE PHYSICAL *
* ADDRESS VALUE IN EACH *
* WORD LOCATION *
*****
I
V MMUP(56)
*****
** UPDATE ADDRESS **
** POINTERS **
**
*****
IDONE
V INITDN(55)
*****
** INITIALIZE ADDRESS **
** POINTERS **
**
*****
----->I
V
*****
/ DOES EACH \ NO
/ LOCATION HAVE \
/ ADDRESS VALUE? \
-----
I YES
I<-----I
V MMDOWN(56)
*****
** UPDATE ADDRESS **
** POINTERS **
**
*****
IDONE
I
I
I

```

MORE MEMORY

\*\*\*\*\*  
\*\* ERROR: ADDRESS VALUE \*\*  
\*\* NOT IN LOCATION \*\*  
\*\*\*\*\*

ERROR(63)



```

TST2          INITMM(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
----->I
      V
*****
** WRITE PHYSICAL **
** ADDRESS VALUE IN EACH **
**   BYTE LOCATION **
*****
      I
      V          MMUP(56)
*****
** UPDATE ADDRESS **
**   POINTERS     **
**                   **
*****
      IDONE
      V          INITDN(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
----->I
      V
-----
/ DOES EACH BYTE \ NO
/ LOCATION HAVE  \
/ ADDRESS VALUE? \
-----
      I YES
      I<-----I
      V          MMDOWN(56)
*****
** UPDATE ADDRESS **
**   POINTERS     **
**                   **
*****
      IDONE
      I
      I
      I
      V

```



```

TST3          INITDN(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
----->I
      V
*****
*   WRITE ONE'S      *
* COMPLEMENT OF ADR  *
* INTO WORD LOCATION *
*****
      I
      V          MMDOWN(56)
*****
MORE MEMORY ** UPDATE ADDRESS **
----- **   POINTERS         **
**                   **
*****
      IDONE
      V          INITMM(55)
*****
** INITIALIZE ADDRESS **
**   PC'NTERS         **
**                   **
*****
----->I
      V
      /-----\
      / DOES EACH WORD \ NO
      / HAVE COMPLEMENT OF \----->
      / ADR. VALUE?       \
      \-----/
      I YES
      I <-----I
      V          MMUP(56)
*****
MORE MEMORY ** UPDATE ADDRESS **
----- **   POINTERS         **
**                   **
*****
      IDONE
      I
      I
      I
      V

```



```

TST4                                INITMM(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
-----> I
      V
*****
** WRITE BANK # VALUE **
** INTO EACH BYTE    **
**   LOCATION        **
*****
      I
      V
      MMUP(56)
*****
** UPDATE ADDRESS     **
**   POINTERS         **
**                   **
**~*****
      IDONE
      V
      INITMM(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
-----> I
      V
      / DOES EACH BYTE \ NO
      / HAVE ITS BANK # \
      / VALUE?          \
      /                   \
      I YES
      I<-----
      V
      MMUP(56)
*****
** UPDATE ADDRESS     **
**   POINTERS         **
**                   **
**~*****
      IDONE
      I
      I
      V
*****
** ERROR: BANK # VALUE **
** NOT IN LOCATION    **
*****
      ERROR(63)

```



```

TSTS          INITDN(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
----->I
      V
*****
**WRITE 1'S COMPLEMENT **
** OF BANK NUMBER INTO **
**   BYTE LOCATION     **
*****
      I
      V          MMDOWN(56)
MORE MEMORY ** UPDATE ADDRESS **
----- **   POINTERS         **
*****
          IDONE
          V          INITDN(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
----->I
      V
          / DOES EACH BYTE \ NO
          / HAVE COMPLEMENT OF \
          /   BANK VALUE?   \
          -----
          I YES
          I<-----
          V          MMDOWN(56)
MORE MEMORY ** UPDATE ADDRESS **
----- **   POINTERS         **
*****
          IDONE
          I
          I
          V

```

\*\*\*\*\*  
\*\*ERROR: COMPLEMENT OF \*\*  
\*\* BANK # NOT IN BYTE \*\*  
\*\* LOC. \*\*  
\*\*\*\*\*

\*\*\*\*\*  
\*\*ERROR(63)  
\*\*\*\*\*




```


      I
      I
      I<-----
TST6      V      INITMM(55)
*****
** INITIALIZE ADDRESS **
**      POINTERS      **
**                     **
*****
----->I
      I
      V
*****
*WRITE A CONSTANT INTO*
*ALL LOCATIONS. (USER *
*      SELECTABLE)    *
*****
      I
      V      MMUP(56)
*****
MORE MEMORY ** UPDATE ADDRESS **
----- **      POINTER      **
*****
IDONE
      I
      I
      I
      V

```











```

-----
TST11      I
          V      SETCON(57)
*****
**PUT ALL ONE'S IN ALL **
**      MEMORY      **
**      **
*****
          I
          V      INITMM(55)
*****
** INITIALIZE ADDRESS **
**      POINTERS      **
**      **
*****
          I
          V      ROTATE(57)
*****
** CLEAR C-BIT AND **
**ROTATE IT THROUGH TWO**
**      BYTES      **
*****
          I
          V
          / C-BIT CLEAR AND \ NO
          -1 IN MEMORY      /
          / LOCATION?      \
          /-----\
          I YES
          I<-----I
          V      MMUP(56)
*****
** UPDATE ADDRESS **
**      POINTERS      **
**      **
*****
          IDONE
          I
          V

```

```

*****
** ERROR(63)
** ERROR: ROTATING 0 **
**      FAILED.      **
**      **
*****

```

MORE MEMORY








```

TST13          INITMM(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
----->I
I             V      W3X9(57)
I             *****
I             ** WRITE 256. WORD **
I             **   BLOCKS WITH   **
I             ** 0,0,0,0,-1,-1,-1,-1 **
I             *****
I             I
I             V      MMUP(56)
I             *****
I MORE MEMORY ** UPDATE ADDRESS **
I             **   POINTERS     **
I             *****
I             IDONE
I             V      INITMM(55)
I             *****
I             ** INITIALIZE ADDRESS **
I             **   POINTERS         **
I             *****
----->I
I             V
I             /256. WORD BLOCKS \NO
I             / WRITTEN WITH   \-----> ***** $ERROR(63)
I             / 0,0,0,0,-1,-1,-1,-1 \ ** ERROR: 3 XOR 9 **
I             -----> ** PATTERN FAILURE **
I             *****
I             I YES
I             I<-----I
I             V      MMUP(56)
I             *****
I MORE MEMORY ** UPDATE ADDRESS **
I             **   POINTERS     **
I             *****
I             IDONE
I             I
I             I
I             I
I             V

```








```

TST14          INITMM(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
----->I
      V      W3X9(57)
*****
**   WRITE 256. WORD   **
**   BLOCKS WITH      **
** -1,-1,-1,-1,0,0,0 **
*****
      I
      V      MMUP(56)
*****
MORE MEMORY **   UPDATE ADDRESS   **
----- **   POINTERS             **
**                   **
*****
      IDONE
      V      INITMM(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
----->I
      V
      /256. WORD BLOCKS \NO
      / WRITTEN WITH   \----->
      / -1,-1,-1,-1,0,0,0 \
      /-----
      I YES
      I<-----
      V      MMUP(56)
*****
MORE MEMORY **   UPDATE ADDRESS   **
----- **   POINTERS             **
**                   **
*****
      IDONE
      I
      I
      I
      I
      V

```

\*\*\*\*\*\$ERROR(63)\*\*\*\*\*  
 \*\* ERROR: 3 XOR 9 \*\*  
 \*\* PATTERN FAILURE \*\*  
 \*\*\*\*\*








```

TST15 INITMM(55)
*****
** INITIALIZE ADDRESS **
** POINTERS **
** *****
----->I
V W3X9(57)
*****
** WRITE 256. WORD **
** BLOCKS WITH 401 AND **
** -1 **
*****
I
V MMUP(56)
*****
MORE MEMORY ** UPDATE ADDRESS **
** POINTERS **
*****
IDONE
V INITMM(55)
*****
** INITIALIZE ADDRESS **
** POINTERS **
** *****
----->I
V
/256. WORD BLOCKS \NO
/ WRITTEN WITH 401 \----->
AND -1?
*****
I YES I
I<-----I
V MMUP(56)
*****
MORE MEMORY ** UPDATE ADDRESS **
** POINTERS **
*****
IDONE
I
I
I
I
V

```








```

TST16          INITMM(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
----->I
V          W3X9(57)
*****
**   WRITE 256. WORD   **
** BLOCKS WITH -1 AND **
**         401         **
*****
I
V          MMUP(56)
*****
MORE MEMORY **   UPDATE ADDRESS   **
----- **   POINTERS             **
**                   **
*****
IDONE
V          INITMM(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
----->I
V
-----
/256. WORD BLOCKS \NO
/WRITTEN WITH -1 AND\----->
401?
-----
I YES
I<-----I
V          MMUP(56)
*****
MORE MEMORY **   UPDATE ADDRESS   **
----- **   POINTERS             **
**                   **
*****
IDONE
I
I
I
V


```

\*\*\*\*\*  
SERROR(63)  
\*\*\*\*\*  
\*\* ERROR: 3 XOR 9 \*\*  
\*\* PATTERN FAILURE \*\*  
\*\*\*\*\*





















```

                                     MMUP(56)
*****
***** MORE MEMORY *****
** UPDATE ADDRESS **
** POINTERS **
**
*****
IDONE
V MAMF(60)
*****
** RESET ALL PARITY **
** REGISTERS **
**
*****
I
I
I
V
```



```

*****
**TST20 **
*****
TST20      I      INITMM(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
-----> I
      V
*****
* COPY 2K BLOCK OF *
* PROGRAM CODE INTO *
* MEMORY UNDER TEST *
*****
      I
      V
-----> I
      V
      / DID "RANDOM" DATA \ NO
      / COPY OK?          \
      \                   /
      \                   /
      I YES
      I <----- I
      V      MMUP(56)
*****
** UPDATE ADDRESS **
**   POINTERS     **
**                   **
*****
-----> I
      V
      I DONE
      I
      I
      I
      V

```


MORE MEMORY

\*\*\*\*\*  
 \*\* ERROR: PROGRAM CODE \*\*  
 \*\* COPIED CHANGE. \*\*  
 \*\*\*\*\*

\*\*\*\*\*  
 \*\* ERROR(63) \*\*  
 \*\*\*\*\*



CZQMCEO 0-124K MEM EXER 16K  
TEST 21: EXICUTE DATI, DATO






```


TST22          INITMM(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
----->I
      V
*****
*   PUT INSTRUCTION   *
* 'MOVB R4,(R2)'      *
* AND RTS INTO MEMORY *
*****
      I
      V
*****
**JSR TO ADDRESS UNDER **
**   TEST              **
*****
----->I
      V
*****
* EXICUTE INSTRUCTION *
* IN MEMORY ADDRESS  *
* UNDER TEST (MAUT)  *
*****
      I
      V
-----<<<--**RETURN **
*****
      I
      I
      V
-----
/ DID THE \ NO
/ INSTRUCTION EXICUTE \
/ PROPERLY? \ ----->
-----
      I YES
      I<-----
      V          MMUP(56)
*****
** UPDATE ADDRESS    **
**   POINTERS        **
**                   **
*****
-----
MORE MEMORY
-----
      IDONE
      I
      I
      V

```












```


TST25          INITMM(55)
*****
** INITIALIZE ADDRESS **
**   POINTERS         **
**                   **
*****
----->I
      V
*****
*   PUT INSTRUCTION   *
* 'BICB (R2)+, -(R2)' *
* AND RTS INTO MEMORY *
*****
      I
      V
*****
**JSR TO ADDRESS UNDER **
**   TEST              **
*****
----->I
      V
*****
* EXICUTE INSTRUCTION *
* IN MEMORY ADDRESS  *
* UNDER TEST (MAUT)  *
*****
      I
      V
-----<<<--**RETURN **
*****
      I
      V
----->I
      V
*****
/ DID THE \ NO
/ INSTRUCTION EXICUTE \
/ PROPERLY? \----->I
*****
      I YES
      I<-----I
      V          MMUP(56)
*****
** UPDATE ADDRESS **
**   POINTERS     **
*****
----->I
      V
*****
IDONE
      I
      V

```











































































```

*****  

**SETAE **      **MAMF **  

*****          *****  

I  

I MAMF I  

I V  

-----  

/ PARITY REGISTER \ NO  

/ EXIST AND NOT \ -----  

/ INHIBITED? \  

-----  

I YES  

V  

*****  

*SET UP PARITY VECTOR.*  

---> * SET 'ACTION ENABLE' *  

* IN ALL REGISTERS *  

*****  

I <-----  

V  

*****  

**RETURN **  

*****  

*****  

**CLRPAR **  

*****  

I  

CLRPAR V  

*****  

*CLEAR OUT ALL MEMORY *  

* PARITY REGISTERS *  

* *  

*****  

I  

V  

*****  

**RETURN **  

*****

```







```

*****
**SPRNT **--->I
*****

*****
**SPRNTQ **--->I
*****

*****
**SPRNTNTR **--->I
*****

*****
**SPRNTD **--->I
*****

*****
**SPRNT1 **--->I
*****

*****
**SPRNT3 **--->I
*****

*****
**SPRNT2 **--->I
*****

*****
* ROUTINES TO SET UP *
* DATA FOR ERROR *
* TYPEOUTS. *
*****

I
V
*****
**RETURN **
*****

```

```

*****
**TYPMAP **
*****
I
TYPMAP V
-----
MAP CONTAIN \NO
FLAGS? ----->
-----
I YES
V
*****
/TYPE FIRST + LAST /
/ADDRESS OF BANKS /
/FOUND /
*****
I<-----
V
*****
**RETURN **
*****

```



```

$SCOPE
*****
***** * CONTROLS LOOPING, * *****
**$SCOPE **--> * INTERACTIONS, ETC. *--> **RETURN **
***** * BETWEEN SUBTESTS * *****
*****

$ERROR
*****
***** * COUNTS ERRORS, LOOPS. * *****
**$ERROR **--> * PASS DATA TO $ERRTYP *--> **RETURN **
***** * *****
*****

ERRTYP
*****
***** * TYPEOUT ERROR * *****
**ERRTYP **--> * MESSAGE, HEADER, AND *--> **RETURN **
***** * DATA * *****
*****

$RDCHR
*****
***** * INPUTS CHARACTER FROM * *****
**$RDCHR **--> * TTY *--> **RETURN **
***** * *****
*****

$ROLIN
*****
***** * INPUTS STRING OF * *****
**$ROLIN **--> * CHARACTERS FROM TTY *--> **RETURN **
***** * *****
*****

$RDOCT
*****
***** * CONVERTS ASCII OCTAL * *****
**$RDOCT **--> * NUMBER TO MACHINE *--> **RETURN **
***** * NARY * *****
*****

$PRINT
*****
***** * RELOCATES MESSAGE * *****
**$PRINT **--> * ADDRESS FOR $TYPE *--> **RETURN **
***** * *****
*****

```

```

$TYPE
*****
***** * TYPES OUT A MESSAGE * *****
**$TYPE **--> * ON TTY. *--> **RETURN **
***** * *****
*****

$TYPDS
*****
***** * TYPE A DECIMAL NUMBER *--> **RETURN **
**$TYPDS **--> * *****
*****

$TYPOC
*****
***** * TYPE AN OCTAL NUMBER *--> **RETURN **
**$TYPOC **--> * *****
*****

ERRTRP
*****
***** * UNEXPECTED TIMEOUT * *****
**ERRTRP **--> * TRAP (TO 4) ROUTINE *--> **HALT **
***** * *****
*****

$TYPAD
*****
***** * TYPE AN 18-BIT * *****
**$TYPAD **--> * ADDRESS (OCTAL) *--> **RETURN **
***** * *****
*****

*****
* ASCII MESSAGES *
*****

*****
* ERROR DATA FORMAT *
* TABLE *
*****

```

```

*****
**END **
*****

```



[illegible]



SPRNT2	62#																		
SPRNT3	62#																		
SPRNTQ	62#																		
SPRNTR	62#																		
START	06#																		
START1	03	16#	16	53	54														
STARTA	02	06																	
TIMOUT	09#																		
TMAP	13																		
TST1	17																		
TST11	25																		
TST12	28																		
TST13	27																		
TST14	29																		
TST15	31																		
TST16	33																		
TST17	35																		
TST2	18																		
TST20	35	39#	39																
TST21	40																		
TST22	41																		
TST23	42																		
TST24	43																		
TST25	44																		
TST26	45																		
TST27	46																		
TST3	19																		
TST4	20																		
TST5	21																		
TST6	22																		
TST7	23																		
TYPMAP	13	62#	62																
W3X9	27	29	31	33	57#	57													
WWPB1	35	35#	37																
WWPB2	36	36#	37																
WWPB3	37																		
WWPB4	36	36	37	37#															
WWPB5	35	35	37	37#															
WWPBT	35	35#	38																
\$EOP	54																		
\$ERROR	14	14	14	17	18	19	20	21	23	24	25	26	27	28	28	28	29	30	
	30	30	31	32	32	32	33	34	34	34	36	36	36	36	36	37	37	37	
	39	40	41	42	43	44	45	46	46	48	50	52	58	60	61	61	61	61	
	63	63#																	
\$ILLUP	04#																		
\$MMUP	47																		
\$PRINT	04	09	10	10	15	63	63#												
\$PWRDN	04#																		
\$PWRUP	04#																		
\$RDCHR	63	63#																	
\$RDOCT	15	15	63	63#															
\$ROLIN	63																		



CZQMCEO 0-124K MEM EXER 16K  
FLOW CHART CROSS REFERENCE LIST

F07

DECFL0 VER 00.07 10-JAN-78 13:19 PAGE 66

SEQ 0083

\$SCOPE	63#			
\$TYPAD	63	63#		
\$TYPDS	10	10	63	63#
\$TYPE	63	63#		
\$TYPOC	63	63#		
.END	63			



GO7

```

TITLE CZQMCEO 0-124K MEMORY EXERCISER, 16K VER
*COPYRIGHT (C) 1975,1977
*DIGITAL EQUIPMENT CORP.
*MAYNARD, MASS. 01754
*
*PROGRAM BY BRUCE BURGESS/KEN CHAPMAN
*
*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
*

```

```

13      .SBTTL OPERATIONAL SWITCH SETTINGS
14      *
15      *      SWITCH      USE
16      *      -----
17      *      15      HALT ON ERROR
18      *      14      LOOP ON TEST
19      *      13      INHIBIT ERROR TYPEOUTS
20      *      12      INHIBIT KT11 (AT START TIME ONLY)
21      *      11      INHIBIT ITERATIONS
22      *      10      BELL ON ERROR
23      *      9       LOOP ON ERROR
24      *      8       LOOP ON TEST IN SWR<4:0>
25      *      7       INHIBIT PROGRAM RELOCATION
26      *      6       INHIBIT PARITY ERROR DETECTION
27      *      5       INHIBIT EXERCISING VECTOR AREA.
28      .SBTTL BASIC DEFINITIONS
29
30      *INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
31      001100      STACK= 1100
32      .EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
33      .EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL
34
35      *MISCELLANEOUS DEFINITIONS
36      000011      HT= 11      ;;CODE FOR HORIZONTAL TAB
37      000012      LF= 12      ;;CODE FOR LINE FEED
38      000015      CR= 15      ;;CODE FOR CARRIAGE RETURN
39      000200      CRLF= 200    ;;CODE FOR CARRIAGE RETURN-LINE FEED
40      177776      PS= 177776   ;;PROCESSOR STATUS WORD
41      .EQUIV PS,PSW
42      177774      STKLM1= 177774 ;;STACK LIMIT REGISTER
43      177772      PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
44      177570      DSWR= 177570 ;;HARDWARE SWITCH REGISTER
45      177570      DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
46
47      *GENERAL PURPOSE REGISTER DEFINITIONS
48      000000      R0= %0      ;;GENERAL REGISTER
49      000001      R1= %1      ;;GENERAL REGISTER
50      000002      R2= %2      ;;GENERAL REGISTER
51      000003      R3= %3      ;;GENERAL REGISTER
52      000004      R4= %4      ;;GENERAL REGISTER
53      000005      R5= %5      ;;GENERAL REGISTER
54      000006      R6= %6      ;;GENERAL REGISTER
55      000007      R7= %7      ;;GENERAL REGISTER
56      000006      SP= %6      ;;STACK POINTER

```



H07

SEQ 0085

```

57      000007      PC=      7      ;;PROGRAM COUNTER
58
59      ;*PRIORITY LEVEL DEFINITIONS
60      000000      PR0=      0      ;;PRIORITY LEVEL 0
61      000040      PR1=      40     ;;PRIORITY LEVEL 1
62      000100      PR2=     100     ;;PRIORITY LEVEL 2
63      000140      PR3=     140     ;;PRIORITY LEVEL 3
64      000200      PR4=     200     ;;PRIORITY LEVEL 4
65      000240      PR5=     240     ;;PRIORITY LEVEL 5
66      000300      PR6=     300     ;;PRIORITY LEVEL 6
67      000340      PR7=     340     ;;PRIORITY LEVEL 7
68
69      ;*"SWITCH REGISTER" SWITCH DEFINITIONS
70      100000      SW15= 100000
71      040000      SW14= 40000
72      020000      SW13= 20000
73      010000      SW12= 10000
74      004000      SW11= 4000
75      002000      SW10= 2000
76      001000      SW09= 1000
77      000400      SW08= 400
78      000200      SW07= 200
79      000100      SW06= 100
80      000040      SW05= 40
81      000020      SW04= 20
82      000010      SW03= 10
83      000004      SW02= 4
84      000002      SW01= 2
85      000001      SW00= 1
86      .EQUIV      SW09,SW9
87      .EQUIV      SW08,SW8
88      .EQUIV      SW07,SW7
89      .EQUIV      SW06,SW6
90      .EQUIV      SW05,SW5
91      .EQUIV      SW04,SW4
92      .EQUIV      SW03,SW3
93      .EQUIV      SW02,SW2
94      .EQUIV      SW01,SW1
95      .EQUIV      SW00,SW0
96
97      ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
98      100000      BIT15= 100000
99      040000      BIT14= 40000
100     020000      BIT13= 20000
101     010000      BIT12= 10000
102     004000      BIT11= 4000
103     002000      BIT10= 2000
104     001000      BIT09= 1000
105     000400      BIT08= 400
106     000200      BIT07= 200
107     000100      BIT06= 100
108     000040      BIT05= 40
109     000020      BIT04= 20
110     000010      BIT03= 10
111     000004      BIT02= 4
112     000002      BIT01= 2

```



```

113      .000001      BIT00= 1
114                      .EQUIV BIT09,BIT9
115                      .EQUIV BIT08,BIT8
116                      .EQUIV BIT07,BIT7
117                      .EQUIV BIT06,BIT6
118                      .EQUIV BIT05,BIT5
119                      .EQUIV BIT04,BIT4
120                      .EQUIV BIT03,BIT3
121                      .EQUIV BIT02,BIT2
122                      .EQUIV BIT01,BIT1
123                      .EQUIV BIT00,BIT0
124
125      ;*BASIC "CPU" TRAP VECTOR ADDRESSES
126      000004      ERRVEC= 4      ;: TIME OUT AND OTHER ERRORS
127      000010      RESVEC= 10      ;: RESERVED AND ILLEGAL INSTRUCTIONS
128      000014      TBITVEC=14      ;: "T" BIT
129      000014      TRTVEC= 14      ;: TRACE TRAP
130      000014      BPTVEC= 14      ;: BREAKPOINT TRAP (BPT)
131      000020      IOTVEC= 20      ;: INPUT/OUTPUT TRAP (IOT) **SCOPE**
132      000024      PWRVEC= 24      ;: POWER FAIL
133      000030      EMTVEC= 30      ;: EMULATOR TRAP (EMT) **ERROR**
134      000034      TRAPVEC=34      ;: "TRAP" TRAP
135      000060      TKVEC= 60      ;: TTY KEYBOARD VECTOR
136      000064      TPVEC= 64      ;: TTY PRINTER VECTOR
137      000240      PIRQVEC=240    ;: PROGRAM INTERRUPT REQUEST VECTOR
138
139      .SBTTL MEMORY MANAGEMENT DEFINITIONS
140
141      ;*KT11 VECTOR ADDRESS
142
143      000250      MMVEC= 250
144
145      ;*KT11 STATUS REGISTER ADDRESSES
146
147      177572      SR0= 177572
148      177574      SR1= 177574
149      177576      SR2= 177576
150      172516      SR3= 172516
151
152      ;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
153
154      172300      KIPDR0= 172300
155      172302      KIPDR1= 172302
156      172304      KIPDR2= 172304
157      172306      KIPDR3= 172306
158      172310      KIPDR4= 172310
159      172312      KIPDR5= 172312
160      172314      KIPDR6= 172314
161      172316      KIPDR7= 172316
162
163      ;*KERNEL "I" PAGE ADDRESS REGISTERS
164
165      172340      KIPAR0= 172340
166      172342      KIPAR1= 172342
167      172344      KIPAR2= 172344
168

```



```

169      172346      KIPAR3= 172346
170      172350      KIPAR4= 172350
171      172352      KIPAR5= 172352
172      172354      KIPAR6= 172354
173      172356      KIPAR7= 172356
174
175      000000      UP = 0 ;CODE FOR UPWARDS MAP IN MEM MGMT PDR'S
176      000006      RW = 6 ;CODE FOR READ/WRITE IN MEM MGMT PDR'S
177
178      ;* PARITY MEMORY DEFINITIONS.
179      000001      AE=1 ;PARITY ACTION ENABLE
180      000114      PARVEC=114 ;PARITY TRAP VECTOR
181
182      ;* MISCELLANEOUS ASSIGNMENTS
183      017777      MASK4K= 17777 ;MASK FOR 4K ADDRESS BANK BOUNDARY.
184
185      ;* CACHE REGISTER DEFINITIONS.
186      177746      IMPCHE= 177746
187
188      .SBTTL TRAP CATCHER
189
190      000000      .=0
191      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
192      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
193      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
194      .=174
195      000174      000000      DISPREG: .WORD 0 ;;SOFTWARE DISPLAY REGISTER
196      000176      000000      SWREG: .WORD 0 ;;SOFTWARE SWITCH REGISTER
197      .SBTTL STARTING ADDRESS(ES)
198      000200      000137      002640      JMP 2*START ;;JUMP TO STARTING ADDRESS OF PROGRAM
199      000204      000167      002436      JMP SELECT ;;STARTING ADDRESS TO ALLOW THE OPERATOR TO
200      ;;SELECT VARIOUS PARAMETERS.
201      000210      000167      000064      JMP RESTAR ;;RESTART ADDRESS, USING PREVIOUS PARAMETERS.
202      000214      000167      000064      JMP RESTOR ;;RESTORE LOADERS TO END OF MEMORY AND HALT.
203      000220      000167      003352      JMP TIMOUT ;;TYPE OUT MEMORY MAP, BYTE BY BYTE.
204
205      .=ERRVEC
206      000004      025060      .WORD ERRTRP
207      000006      000000      .WORD 0
208
209      .SBTTL ACT11 HOOKS
210
211      ;*****
212      ;HOOKS REQUIRED BY ACT11
213      000010      $SVPC=. ;SAVE PC
214      000046      .=46
215      000046      014174      $ENDAD ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .SEOP
216      000052      000052      .=52
217      000052      040000      .WORD BIT14 ;;2)SET LOC.52 TO BIT14
218      000010      .=$SVPC ;; RESTORE PC

```



```

219      000300      . = 300
220      /
221      ;*****
222      ; THE FOLLOWING ROUTINES ARE LOCATED IN THE VECTOR AREA (0-1000) SO THAT
223      ; THEY CAN BE PROTECTED BY SELECTING SW05 (SEE DOCUMENT FOR USE OF SW05).
224      ; THE CODE CAN ALSO BE RUN FROM ANY BANK OF MEMORY, ASSUMING MEMORY
225      ; MANAGEMENT IS DISABLED BY "CONSOLE START".
226      ;*****
226 000300 005005 RESTAR: CLR R5 ;CLEAR FLAG TO INDICATE RESTART.
227 000302 000401 BR REST1 ;GO RESTORE PROGRAM BEFORE RESTARTING.
228 000304 010705 RESTOR: MOV PC R5 ;PUT DATA INTO FLAG FOR RESTORE.
229 000306 012706 001100 REST1: MOV #STACK, SP ;SET UP THE STACK POINTER.
230 000312 005767 001206 TST MEMMAP ;CHECK IF THE MEMORY HAS BEEN MAPPED.
231 000316 001002 BNE REST2 ;BR IF MEMORY MAPPED.
232 000320 000167 002330 JMP STARTA ;GO START
233 000324 005767 000256 REST2: TST MMAPA ;CHECK IF MEM MGMT AVAILABLE.
234 000330 001470 BEQ 10$ ;BR IF NO MEM MGMT.
235 000332 032737 000001 177572 BIT #BIT0, @#SRO ;CHECK IF MEM MGMT ACTIVE.
236 000340 001034 BNE 2$ ;BR IF MEM MGMT ALREADY SET UP.
237 000342 012700 172300 MOV #KIPORO, RO ;POINT TO FIRST MEM MGMT DDATA REG.
238 000346 012701 000010 MOV #8, R1 ;SET UP COUNTER.
239 000352 012720 077406 1$: MOV #077406, (RO)+ ;MAP FIRST 28K 1-FOR-1.
240 000356 005301 DEC R1 ;COUNT REGESTERS.
241 000360 001374 BNE 1$ ;BR IF MORE REG.
242 000362 012700 172340 MOV #KIPARO, RO ;POINT TO FIRST MEM MGMT ADDRESS REG.
243 000366 005020 CLR (RO)+ ;PAR0 MAPPED INTO BANK0.
244 000370 012720 000200 MOV #200, (RO)+ ;PAR1 MAPPED INTO BANK1.
245 000374 012720 000400 MOV #400, (RO)+ ;PAR2 MAPPED INTO BANK2.
246 000400 012720 000600 MOV #600, (RO)+ ;PAR3 MAPPED INTO BANK3.
247 000404 012720 001000 MOV #1000, (RO)+ ;PAR4 MAPPED INTO BANK4.
248 000410 012720 001200 MOV #1200, (RO)+ ;PAR5 MAPPED INTO BANK5.
249 000414 012720 001400 MOV #1400, (RO)+ ;PAR6 MAPPED INTO BANK6.
250 000420 012720 007600 MOV #7600, (RO)+ ;PAR7 MAPPED INTO BANK37.
251 000424 012737 000001 177572 MOV #BIT0, @#SRO ;ENABLE MEM MGMT.
252 000432 005000 2$: CLR RO ;INIT TEMP PAR REG.
253 000434 016701 000142 MOV PRGMAP, R1 ;GET THE PROGRAM MAP...LO 64K.
254 000440 016702 000140 MOV PRGMAP+2, R2 ;HI 64K.
255 000444 006202 3$: ASR R2 ;SHIFT THE MAP POINTER...HI
256 000446 006001 ROR R1 ;...LO.
257 000450 103404 BCS 4$ ;BR WHEN FIRST BANK FOUND.
258 000452 062700 000200 ADD #200, RO ;UPDATE TMP PAR TO NEXT BANK.
259 000456 100372 BPL 3$ ;BR IF MORE.
260 000460 000000 HALT ;FATAL ERROR!!! MAP EMPTY?
261 000462 010037 172340 4$: MOV RO, @#KIPARO ;PUT TEMP PAR INTO FIRST PAR.
262 000466 000137 000472 JMP @#5$ ;JUMP INTO PROGRAM IF NOT THERE ALREADY.
263 000472 062700 000200 5$: ADD #200, RO ;KEEP UPDATING TEMP PAR REG.
264 000476 006202 ASR R2 ;SHIFT POINTER...HI
265 000500 006001 ROR R1 ;...LO
266 000502 103373 BCC 5$ ;BR IF TOP BANK NOT YET FOUND.
267 000504 010037 172342 MOV RO, @#KIPAR1 ;SET UP SECOND PROGRAM ANK POINTER.
268 000510 000410 BR 20$ ;BR TO RELOCATE SECTION.
269 000512 016700 000062 10$: MOV RELOCF, RO ;GET RELOCATION FACTOR.
270 000516 062700 001100 ADD #STACK, RO ;SET UP STACK POINTER.
271 000522 010006 MOV RO, SP ;SET STACK TO RELOCATE PROGRAM.
272 000524 062700 177432 ADD #20$-STACK, RO ;ADJUST RO TO RELOCATED "20$" ADDRESS.
273 000530 000110 JMP (RO) ;GO TO "20$" (RELOCATED).
274 000532 022767 000003 000042 20$: CMP #3, PRGMAP ;CHECK IF PROGRAM IS IN BANKS 0 AND 1.

```



275	000540	001402		BEQ	21\$		;BR IF IN BANKS 0 AND 1.
276	000542	004767	016260	JSR	PC,	RELO	;RELOCATE THE PROGRAM BACK TO BANKS 0 AND 1.
277	000546	005705		21\$: TST	R5		;CHECK RESTART/RESTORE FLAG.
278	000550	001006		BNE	22\$		;BR IF RESTORE.
279	000552	005067	000412	CLR	\$TIMES		;CLEAN UP BEFORE STARTING.
280	000556	105067	000320	CLRB	\$STNM		
281	000562	000167	005272	JMP	START1		
282	000566	004767	016442	22\$: JSR	PC,	RESLDR	;RESTART WITH PREVIOUSLY SELECTED PARAMETERS. ;RESTORE THE LOADERS TO THE "TOP" OF MEMORY.
283	000572	000000		HALT			;HALT AFTER RESTORING THE LOADERS.
284	000574	000167	002054	JMP	STARTA		;CONTINUE WILL RESTART THE PROGRAM.
285				;* THE FOLLOWING LOCATIONS ARE USED BY THE ABOVE ROUTINE AND MUST BE LOCATED			
286				;* BELOW 1000 TO INSURE CORRECT OPERATION UNDER THE WIDEST VARIETY OF			
287				;* CIRCUMSTANCES.			
288	000600	000000		RELOCF:	.WORD	0	;CONTAINS RELOCATION FACTOR (NO MEM MGMT)
289	000602	000000	000000	PRGMAP:	.WORD	0,0	;PROGRAM MAP - WHERE THE PROGRAM IS LOCATED
290	000606	000000		MMAVA:	.WORD	0	;MEMORY MANAGEMENT AVAILABLE FLAG.



## .SBTTL POWER DOWN AND UP ROUTINES

```

*****
: POWER DOWN ROUTINE

```

```

$PWRDN: MOV    $SILLUP, @PWRVEC    ; SET FOR FAST UP
        MOV    #340, @PWRVEC+2    ; Prio: 7
        MOV    R0, -(SP)           ; PUSH R0 ON STACK
        MOV    R1, -(SP)           ; PUSH R1 ON STACK
        MOV    R2, -(SP)           ; PUSH R2 ON STACK
        MOV    R3, -(SP)           ; PUSH R3 ON STACK
        MOV    R4, -(SP)           ; PUSH R4 ON STACK
        MOV    R5, -(SP)           ; PUSH R5 ON STACK
        MOV    @SWR, -(SP)         ; PUSH @SWR ON STACK
        MOV    SP, $SAVR6          ; SAVE SP
        MOV    $PWRUP, @PWRVEC    ; SET UP VECTOR
        HALT
        BR      .-2                ; HANG UP

```

```

*****
: POWER UP ROUTINE

```

```

$PWRUP: MOV    $SILLUP, @PWRVEC    ; SET FOR FAST DOWN
        MOV    $SAVR6, SP          ; GET SP
        CLR    $SAVR6              ; WAIT LOOP FOR THE TTY
        1$: INC    $SAVR6          ; WAIT FOR THE INC
        BNE    1$                  ; OF WORD
        MOV    (SP)+, @SWR         ; POP STACK INTO @SWR
        MOV    (SP)+, R5           ; POP STACK INTO R5
        MOV    (SP)+, R4           ; POP STACK INTO R4
        MOV    (SP)+, R3           ; POP STACK INTO R3
        MOV    (SP)+, R2           ; POP STACK INTO R2
        MOV    (SP)+, R1           ; POP STACK INTO R1
        MOV    (SP)+, R0           ; POP STACK INTO R0
        MOV    $PWRDN, @PWRVEC    ; SET UP THE POWER DOWN VECTOR
        MOV    #340, @PWRVEC+2    ; Prio: 7
        JSR    R5, $PRINT          ; GO PRINT OUT THE FOLLOWING MESSAGE.
        $PWRMG: .WORD    PWRMSG    ; POWER FAIL MESSAGE POINTER
        $PWRAD: .WORD    (PC)+, (SP) ; RESTART AT RESTART
        RTI                        ; RESTART ADDRESS
        $SILLUP: HALT
        BR      .-2                ; THE POWER UP SEQUENCE WAS STARTED
        $SAVR6: 0                  ; BEFORE THE POWER DOWN WAS COMPLETE
        ; PUT THE SP HERE

```



```

333 .SBTTL COMMON TAGS
334
335 ;*****
336 ;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
337 ;*USED IN THE PROGRAM.
338
339 001100
340 001100 001100 $CMTAG: . =1100 ; ; START OF COMMON TAGS
341 001100 000000 $TSTNM: .BYTE 0 ; ; CONTAINS THE TEST NUMBER
342 001102 000 $SERFLG: .BYTE 0 ; ; CONTAINS ERROR FLAG
343 001103 000 $ICNT: .WORD 0 ; ; CONTAINS SUBTEST ITERATION COUNT
344 001104 000000 $LPADR: .WORD 0 ; ; CONTAINS SCOPE LOOP ADDRESS
345 001106 000000 $LPERR: .WORD 0 ; ; CONTAINS SCOPE RETURN FOR ERRORS
346 001110 000000 $ERTTL: .WORD 0 ; ; CONTAINS TOTAL ERRORS DETECTED
347 001112 000000 $ITEMB: .BYTE 0 ; ; CONTAINS ITEM CONTROL BYTE
348 001114 000 $SERMAX: .BYTE 1 ; ; CONTAINS MAX. ERRORS PER TEST
349 001115 001 $ERRPC: .WORD 0 ; ; CONTAINS PC OF LAST ERROR INSTRUCTION
350 001116 000000 $GDADR: .WORD 0 ; ; CONTAINS ADDRESS OF 'GOOD' DATA
351 001120 000000 $BDADR: .WORD 0 ; ; CONTAINS ADDRESS OF 'BAD' DATA
352 001122 000000 $GDDAT: .WORD 0 ; ; CONTAINS 'GOOD' DATA
353 001124 000000 $BDDAT: .WORD 0 ; ; CONTAINS 'BAD' DATA
354 001126 000000 ; ; RESERVED--NOT TO BE USED
355 001130 000000
356 001132 000000
357 001134 000 $AUTOB: .BYTE 0 ; ; AUTOMATIC MODE INDICATOR
358 001135 000 $INTAG: .BYTE 0 ; ; INTERRUPT MODE INDICATOR
359 001136 000000
360 001140 177570 $SWR: .WORD DSWR ; ; ADDRESS OF SWITCH REGISTER
361 001142 177570 $DISPLAY: .WORD DDISP ; ; ADDRESS OF DISPLAY REGISTER
362 001144 177560 $TKS: 177560 ; ; TTY KBD STATUS
363 001146 177562 $TKB: 177562 ; ; TTY KBD BUFFER
364 001150 177564 $TPS: 177564 ; ; TTY PRINTER STATUS REG. ADDRESS
365 001152 177566 $TPB: 177566 ; ; TTY PRINTER BUFFER REG. ADDRESS
366 001154 000 $NULL: .BYTE 0 ; ; CONTAINS NULL CHARACTER FOR FILLS
367 001155 002 $FILLS: .BYTE 2 ; ; CONTAINS # OF FILLER CHARACTERS REQUIRED
368 001156 012 $FILLC: .BYTE 12 ; ; INSERT FILL CHARS. AFTER A "LINE FEED"
369 001157 000 $TPFLG: .BYTE 0 ; ; "TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
370 001160 000000 $TMP0: .WORD 0 ; ; USER DEFINED
371 001162 000000 $TMP1: .WORD 0 ; ; USER DEFINED
372 001164 000000 $TMP2: .WORD 0 ; ; USER DEFINED
373 001166 000000 $TMP3: .WORD 0 ; ; USER DEFINED
374 001170 000000 $TIMES: 0 ; ; MAX. NUMBER OF ITERATIONS
375 001172 000000 $ESCAPE: 0 ; ; ESCAPE ON ERROR ADDRESS
376 001174 177607 000377 $BELL: .ASCIZ <207><377><377> ; ; CODE FOR BELL
377 001200 077 $QUES: .ASCII /?/ ; ; QUESTION MARK
378 001201 015 $CRLF: .ASCII <15> ; ; CARRIAGE RETURN
379 001202 000012 $LF: .ASCIZ <12> ; ; LINE FEED
380 ;*****
381 .SBTTL APT MAILBOX-ETABLE
382
383 ;*****
384 .EVEN
385 001204 $MAIL: ; ; APT MAILBOX
386 001204 000000 $MSGTY: .WORD AMSGTY ; ; MESSAGE TYPE CODE
387 001206 000000 $FATAL: .WORD AFATAL ; ; FATAL ERROR NUMBER
388 001210 000000 $TESTN: .WORD ATESTN ; ; TEST NUMBER

```



389	001212	000000	\$PASS:	.WORD	APASS	::PASS COUNT
390	001214	000000	\$DEVCT:	.WORD	ADEVCT	::DEVICE COUNT
391	001216	000000	\$UNIT:	.WORD	AUNIT	::I/O UNIT NUMBER
392	001220	000000	\$MSGAD:	.WORD	AMSGAD	::MESSAGE ADDRESS
393	001222	000000	\$MSGLG:	.WORD	AMSLG	::MESSAGE LENGTH
394	001224		\$ETABLE:			::APT ENVIRONMENT TABLE
395	001224	000	\$ENV:	.BYTE	AENV	::ENVIRONMENT BYTE
396	001225	000	\$ENVM:	.BYTE	AENVM	::ENVIRONMENT MODE BITS
397	001226	000000	\$SWREG:	.WORD	ASWREG	::APT SWITCH REGISTER
398	001230	000000	\$USWR:	.WORD	AUSWR	::USER SWITCHES
399	001232	000000	\$CPUOP:	.WORD	ACPUOP	::CPU TYPE, OPTIONS
400			::*			BITS 15-11=CPU TYPE
401			::*			11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05
402			::*			11/70=06, PDQ=07, Q=10
403			::*			BIT 10=REAL TIME CLOCK
404			::*			BIT 9=FLOATING POINT PROCESSOR
405			::*			BIT 8=MEMORY MANAGEMENT
406	001234	000	\$MAMS1:	.BYTE	AMAMS1	::HIGH ADDRESS, M.S. BYTE
407	001235	000	\$MTYP1:	.BYTE	AMTYP1	::MEM. TYPE, BLK#1
408			::*			MEM. TYPE BYTE -- (HIGH BYTE)
409			::*			900 NSEC CORE=001
410			::*			300 NSEC BIPOLAR=002
411			::*			500 NSEC MOS=003
412	001236	000000	\$MADR1:	.WORD	AMADR1	::HIGH ADDRESS, BLK#1
413			::*			MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE
414	001240	000	\$MAMS2:	.BYTE	AMAMS2	::HIGH ADDRESS, M.S. BYTE
415	001241	000	\$MTYP2:	.BYTE	AMTYP2	::MEM. TYPE, BLK#2
416	001242	000000	\$MADR2:	.WORD	AMADR2	::MEM. LAST ADDRESS, BLK#2
417	001244	000	\$MAMS3:	.BYTE	AMAMS3	::HIGH ADDRESS, M.S. BYTE
418	001245	000	\$MTYP3:	.BYTE	AMTYP3	::MEM. TYPE, BLK#3
419	001246	000000	\$MADR3:	.WORD	AMADR3	::MEM. LAST ADDRESS, BLK#3
420	001250	000	\$MAMS4:	.BYTE	AMAMS4	::HIGH ADDRESS, M.S. BYTE
421	001251	000	\$MTYP4:	.BYTE	AMTYP4	::MEM. TYPE, BLK#4
422	001252	000000	\$MADR4:	.WORD	AMADR4	::MEM. LAST ADDRESS, BLK#4
423	001254	000000	\$VECT1:	.WORD	AVECT1	::INTERRUPT VECTOR#1, BUS PRIORITY#1
424	001256	000000	\$VECT2:	.WORD	AVECT2	::INTERRUPT VECTOR#2, BUS PRIORITY#2
425	001260	000000	\$BASE:	.WORD	ABASE	::BASE ADDRESS OF EQUIPMENT UNDER TEST
426	001262	000000	\$DEVN:	.WORD	ADEVN	::DEVICE MAP
427	001264	000000	\$CDW1:	.WORD	ACDW1	::CONTROLLER DESCRIPTION WORD#1
428	001266	000000	\$CDW2:	.WORD	ACDW2	::CONTROLLER DESCRIPTION WORD#2
429	001270	000000	\$DDW0:	.WORD	ADDW0	::DEVICE DESCRIPTOR WORD#0
430	001272	000000	\$DDW1:	.WORD	ADDW1	::DEVICE DESCRIPTOR WORD#1
431	001274	000000	\$DDW2:	.WORD	ADDW2	::DEVICE DESCRIPTOR WORD#2
432	001276	000000	\$DDW3:	.WORD	ADDW3	::DEVICE DESCRIPTOR WORD#3
433	001300	000000	\$DDW4:	.WORD	ADDW4	::DEVICE DESCRIPTOR WORD#4
434	001302	000000	\$DDW5:	.WORD	ADDW5	::DEVICE DESCRIPTOR WORD#5
435	001304	000000	\$DDW6:	.WORD	ADDW6	::DEVICE DESCRIPTOR WORD#6
436	001306	000000	\$DDW7:	.WORD	ADDW7	::DEVICE DESCRIPTOR WORD#7
437	001310	000000	\$DDW8:	.WORD	ADDW8	::DEVICE DESCRIPTOR WORD#8
438	001312	000000	\$DDW9:	.WORD	ADDW9	::DEVICE DESCRIPTOR WORD#9
439	001314	000000	\$DDW10:	.WORD	ADDW10	::DEVICE DESCRIPTOR WORD#10
440	001316	000000	\$DDW11:	.WORD	ADDW11	::DEVICE DESCRIPTOR WORD#11
441	001320	000000	\$DDW12:	.WORD	ADDW12	::DEVICE DESCRIPTOR WORD#12
442	001322	000000	\$DDW13:	.WORD	ADDW13	::DEVICE DESCRIPTOR WORD#13
443	001324	000000	\$DDW14:	.WORD	ADDW14	::DEVICE DESCRIPTOR WORD#14
444	001326	000000	\$DDW15:	.WORD	ADDW15	::DEVICE DESCRIPTOR WORD#15



```

445 001330      SETEND:
446             .MEXIT
447             .SBTTL  APT PARAMETER BLOCK
448
449             ;*****
450             ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
451             ;*****
452             .SX=.      ;SAVE CURRENT LOCATION
453             .=24      ;SET POWER FAIL TO POINT TO START OF PROGRAM
454 000024      200      ;FOR APT START UP
455             .=44      ;POINT TO APT INDIRECT ADDRESS PNTR.
456 000044      $APTHDR  ;POINT TO APT HEADER BLOCK
457             .=$X      ;RESET LOCATION COUNTER
458             ;*****
459             ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
460             ;INTERFACE SPEC.
461
462 001330      $APTHD:
463 001330      $HIBTS: .WORD 0      ;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
464 001332      $MBADR: .WORD $MAIL  ;ADDRESS OF APT MAILBOX (BITS 0-15)
465 001334      $STMT:  .WORD 2400.  ;RUN TIM OF LONGEST TEST
466 001336      $PASTM: .WORD 120.   ;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
467 001340      $UNITM: .WORD 240.   ;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
468 001342      .WORD $SETEND-$MAIL/2 ;LENGTH MAILBOX-ETABLE(WORDS)
469             SBTTL  APT STATISTICS TABLE
470
471             ;*****
472 001344      $ASTAT:
473 001344      177777 000000      .WORD -1,0
474 001350      177777 000000      .WORD -1,0
475 001354      177777 000000      .WORD -1,0
476 001360      177777 000000      .WORD -1,0
477 001364      177777 000000      .WORD -1,0
478 001370      177777 000000      .WORD -1,0
479 001374      177777 000000      .WORD -1,0
480 001400      177777 000000      .WORD -1,0
481 001404      177777 000000      .WORD -1,0
482 001410      177777 000000      .WORD -1,0
483 001414      177777 000000      .WORD -1,0
484 001420      177777 000000      .WORD -1,0
485 001424      177777 000000      .WORD -1,0
486 001430      177777 000000      .WORD -1,0
487 001434      177777 000000      .WORD -1,0
488 001440      177777 000000      .WORD -1,0
489 001444      177777 000000      .WORD -1,0
490 001450      177777 000000      .WORD -1,0
491 001454      177777 000000      .WORD -1,0
492 001460      177777 000000      .WORD -1,0
493 001464      177777 000000      .WORD -1,0
494 001470      177777 000000      .WORD -1,0
495 001474      177777 000000      .WORD -1,0
496 001500      177777 000000      .WORD -1,0
497 001504      177777 000000      .WORD -1,0
498 001510      177777
499 001512      001344
500
$ASTEND:
$APTR: $ASTAT

```



```

501 *****
502 *THE FOLLOWING TAGS ARE USER DEFINED
503 *****
504 001514 000000 $VERPC: .WORD 0 :VIRTUAL PC LOCATION FOR ERROR TYPEOUT ROUTINE ($ERTYP).
505 001516 070032 RESRVD: .WORD 070032 :CORE PARITY REG BITS RESERVED FOR FUTURE USE.
506 :NOTE: FOR MS11 MEMORY WITH PARITY, CHANGE TO 077772.
507 001520 000000 LMAD: .WORD 0 :LAST CONTIGUOUS MEMORY ADDRESS (+2)
508 001522 000000 LDDISP: .WORD 0 :CONTAINS DISPLAY REGISTER IMAGE
509 001524 000000 MEMMAP: .WORD 0 :MEMORY MAP - EACH BIT CORRESPONDS TO 4K
510 001524 000000 :FIRST WORD CONTAINS LOW (0-64K) MAP
511 001526 000000 :SECOND WORD CONTAINS HIGH (64-128K) MAP
512 001530 000000 TSTMAP: .WORD 0 :TEST MAP - WHICH BANKS ARE SELECTED FOR TEST.
513 001530 000000 :FIRST WORD CONTAINS LOW (0-64K) MAP
514 001532 000000 :SECOND WORD CONTAINS HIGH (64-128K) MAP
515 001534 000000 SAVTST: .WORD 0 :SAVED TEST MAP - USED DURING FIRST PASS TO ONLY
516 :TEST EACH BANK ONCE.
517 001534 000000 :FIRST WORD CONTAINS LOW (0-64K) MAP
518 001536 000000 :SECOND WORD CONTAINS HIGH (64-128K) MAP
519 001540 000000 PMEMAP: .WORD 0 :PARITY MAP - WHICH BANKS HAVE MEMORY PARITY
520 001540 000000 :FIRST WORD CONTAINS LOW (0-64K) MAP
521 001542 000000 :SECOND WORD CONTAINS HIGH (64-128K) MAP
522 001544 000000 BITPT: .WORD 0 :POINTER TO CURRENT 4K BANK OF MEMORY
523 001544 000000 :FIRST WORD CONTAINS LOW (0-64K) MAP
524 001546 000000 :SECOND WORD CONTAINS HIGH (64-128K) MAP
525 001550 000000 TMPPT: .WORD 0 :TEMPORARY POINTER FOR 2ND 4K BANK OF MEMORY
526 001550 000000 :FIRST WORD CONTAINS LOW (0-64K) MAP
527 001552 000000 :SECOND WORD CONTAINS HIGH (64-128K) MAP
528 001554 000000 MMORE: .WORD 0 :LOOP ADDRESS FOR MULTIPLE BLOCK TESTING.
529 :SET UP BY "INITMM" AND "INITON" ROUTINES.
530 :USED BY "MMUP" AND "MMDOWN" ROUTINES.
531 001556 000 SELFGL: .BYTE 0 :OPERATOR SELECTED PARAMETERS FLAG. (SA=204)
532 001557 000 FLAGBK: .BYTE 0 :BK BLOCK INDICATOR. USED IN "INITMM" AND "MMUP".
533 001560 000 OEFLG: .BYTE 0 :ODD/EVEN FLAG USED IN PARITY MEMORY BYTE TEST.
534 001562 001562 :EVEN
535 001562 000000 FSTADR: .WORD 0 :FIRST VIRTUAL ADDRESS TO BE TESTED.
536 :FIRST ADDRESS IS USER SELECTABLE.
537 001564 000000 TMPFAD: .WORD 0 :ADJUSTED FIRST ADDRESS.
538 001566 000000 FADMSK: .WORD 0 :BIT MASK TO ALLOW DOWNWARD ADDRESSING TESTS
539 :TO BREAK TO "MMDOWN" TO FIND FIRST ADDRESS.
540 001570 000000 000000 FADMAP: .WORD 0,0 :MAP OF BANK IN WHICH FIRST ADDRESS IS LOCATED.
541 001574 000000 LSTADR: .WORD 0 :LAST VIRTUAL ADDRESS (+2) TO BE TESTED.
542 :LAST ADDRESS IS USER SELECTABLE.
543 001576 000000 TMPLAD: .WORD 0 :ADJUSTED LAST ADDRESS.
544 001600 000000 LADMSK: .WORD 0 :BIT MASK TO ALLOW UPWARD ADDRESSING TESTS
545 :TO BREAK TO "MMUP" TO FIND LAST ADDRESS.
546 001602 000000 000000 LADMAP: .WORD 0,0 :MAP OF BANK IN WHICH LAST ADDRESS IS LOCATED.
547 001606 000000 BLKMSK: .WORD 0 :BLOCK MASK, DETERMINES THE BLOCK SIZE.
548 001610 000000 .CONST: .WORD 0 :USER SELECTABLE CONSTANT DATA.
549 001612 000004 WWP: .WORD 4 :WRITE WRONG PARITY COMMAND
550 001614 000000 TEMP: .WORD 0 :TEMPORARY STORAGE
551 001616 000000 CASFLG: .WORD 0 :CACHE PRESENT FLAG
552 001620 177746 CASREG: .WORD 177746 :CACHE CONTROL REGISTER
553 *****
554 * RELATIVE ADDRESSING TABLE.
555 * THE FOLLOWING LOCATIONS ARE MODIFIED AT RELOCATION TIME TO ALLOW
556

```



```

557      ;* RELATIVE ADDRESSING TO GET THE RELOCATED VALUE OF THE ARGUEMENT TAGS.
558      ;*****
559      RADTAB:
560      .STACK: STACK          ;STACK POINTER INITIAL ADDRESS.
561      .RESRV: RESRVD         ;PARITY REGISTER RESERVED BIT MASK ADDRESS.
562      .MPRO: MPRO           ;MEMORY PARITY REGISTER TABLE ADDRESS.
563      .MPRX: MPRX          ;MEMORY PARITY REGISTER EXIST TABLE ADDRESS.
564      .PBTRP: PBTRP        ;PARITY BYTE TEST TRAP ROUTINE ADDRESS.
565      .MPPAT: MPPATS       ;MEMORY PARITY PATTERN TABLE ADDRESS.
566      .PESRV: PESRV        ;MEMORY PARITY ERROR TRAP ROUTINE ADDRESS.
567      .ERRTB: $ERRTB       ;ERROR TYPEOUT TABLE PONTER.
568      .EIGHT: 8            ;DECIMAL TYPE ROUTINE COUNT DESIGNATOR.
569      .TST32: TST32        ;SCOPE ABORT ADR FOR WHEN NO MEM AVA FOR TEST.
570      ;*****
571      ;* DATA CONTAINERS FOR ERROR PRINTOUT.
572      ;*****
573      DT1:  $ERRPC,$GDADR,$GDDAT,$BDDAT,0
574      DT2:  $VERPC,$ERRPC,$GDADR,$GDDAT,$BDDAT,0
575      DT12: $VERPC,$ERRPC,$GDADR,$GDDAT,0
576      DT14: $VERPC,$ERRPC,$TMP0,$GDADR,0
577      DT15: $VERPC,$ERRPC,$GDADR,$TMP0,$GDDAT,$BDDAT,0
578      DT21: $VERPC,$ERRPC,$TMP0,$GDADR,$GDDAT,$BDDAT,0
579      DT23: $VERPC,$ERRPC,$GDADR,$BDADR,$GDDAT,$BDDAT,0
580      DT24: $VERPC,$ERRPC,$BDADR,0
581      DT25: $VERPC,$ERRPC,$BDADR,$TMP0,$TMP1,0
582      DT26: $VERPC,$ERRPC,$TMP0,$TMP1,0
583      DT30: $TMP0,$TMP1,$GDADR,$BDDAT,0
584      DT31: $TMP3,0
585      .WORD -1 ;TABLE TERMINATOR.
586
587      .SBTTL MEMORY PARITY PATTERNS TABLE
588      ;*****
589      ;THE FOLLOWING ARE THE PARITY PATTERNS EXERCISED THRUOUT MEMORY
590      ;*****
591      MPPATS: 125325 ;EVEN,ODD
592              152652 ;ODD,EVEN
593              052452 ;EVEN,ODD
594              025125 ;ODD,EVEN
595              102070 ;EVEN,EVEN
596              072527 ;ODD,ODD
597              177777 ;EVEN,EVEN
598
599
600
601
602
603
604
605
606      002050 125325
607      002052 152652
608      002054 052452
609      002056 025125
610      002060 102070
611      002062 072527
612      002064 177777

```



613	002066	107030	107030	: ODD, ORO
614	002070	152525	152525	: ODD, EVEN
615	002072	000000	0	: EXTRA PATTERN HOLDER FOR
616				: FUTURE USE
617	002074	000000	MPEND: 0	: TABLE TERMINATOR

## .SBTTL MEMORY PARITY REGISTER ADDRESS TABLE

\*\*\*\*\*  
 \* THE FOLLOWING REPRESENTS THE MEMORY PARITY REGISTER ADDRESS TABLE  
 \* FROM WHICH PARITY MEMORY IS ADDRESSED & CONTROLLED:  
 \*\*\*\*\*

\* THE LEAST SIGNIFICANT BIT IN THE DEVICE ADDRESS IS SET TO A ONE (1)  
 \* IF THE CONTROL IS FOUND NOT TO BE PRESENT. THE MEMORY PRESENT UNDER  
 \* THE CONTROL OF EACH CONTROLLER IS REPRESENTED BY TWO (2) WORDS FOLLOWING  
 \* THE DEVICE ADDRESS. EACH BIT REPRESENTING A 4K BLOCK. I.E.  
 \* FIRST WORD BIT0 = 0 - 4K, BIT1 = 4 - 8K, BIT15 = 60 - 64K  
 \* SECOND WORD BIT0 = 64 - 68K, ... BIT14 = 120 - 124K.  
 \*\*\*\*\*

632	002076	172101	MPRO:	172100 +1	: PARITY STATUS REGISTER
633	002100	000000		0	: CONTROL MAP (LOW 64K)
634	002102	000000		0	: CONTROL MAP (HIGH 64K)
635	002104	000000		0	: MASK FOR MOS CORE MS11-K
636	002106	172103	MPR1:	172102 +1	: PARITY STATUS REGISTER
637	002110	000000		0	: CONTROL MAP (LOW 64K)
638	002112	000000		0	: CONTROL MAP (HIGH 64K)
639	002114	000000		0	: MASK FOR MOS CORE MS11-K
640	002116	172105	MPR2:	172104 +1	: PARITY STATUS REGISTER
641	002120	000000		0	: CONTROL MAP (LOW 64K)
642	002122	000000		0	: CONTROL MAP (HIGH 64K)
643	002124	000000		0	: MASK FOR MOS CORE MS11-K
644	002126	172107	MPR3:	172106 +1	: PARITY STATUS REGISTER
645	002130	000000		0	: CONTROL MAP (LOW 64K)
646	002132	000000		0	: CONTROL MAP (HIGH 64K)
647	002134	000000		0	: MASK FOR MOS CORE MS11-K
648	002136	172111	MPR4:	172110 +1	: PARITY STATUS REGISTER
649	002140	000000		0	: CONTROL MAP (LOW 64K)
650	002142	000000		0	: CONTROL MAP (HIGH 64K)
651	002144	000000		0	: MASK FOR MOS CORE MS11-K
652	002146	172113	MPR5:	172112 +1	: PARITY STATUS REGISTER
653	002150	000000		0	: CONTROL MAP (LOW 64K)
654	002152	000000		0	: CONTROL MAP (HIGH 64K)
655	002154	000000		0	: MASK FOR MOS CORE MS11-K
656	002156	172115	MPR6:	172114 +1	: PARITY STATUS REGISTER
657	002160	000000		0	: CONTROL MAP (LOW 64K)
658	002162	000000		0	: CONTROL MAP (HIGH 64K)
659	002164	000000		0	: MASK FOR MOS CORE MS11-K
660	002166	172117	MPR7:	172116 +1	: PARITY STATUS REGISTER
661	002170	000000		0	: CONTROL MAP (LOW 64K)
662	002172	000000		0	: CONTROL MAP (HIGH 64K)
663	002174	000000		0	: MASK FOR MOS CORE MS11-K
664	002176	172121	MPR8:	172120 +1	: PARITY STATUS REGISTER
665	002200	000000		0	: CONTROL MAP (LOW 64K)
666	002202	000000		0	: CONTROL MAP (HIGH 64K)
667	002204	000000		0	: MASK FOR MOS CORE MS11-K
668	002206	172123	MPR9:	172122 +1	: PARITY STATUS REGISTER



669	002210	000000	0	: CONTROL MAP (LOW 64K)
670	002212	000000	0	: CONTROL MAP (HIGH 64K)
671	002214	000000	0	: MASK FOR MOS CORE, MS11-K
672	002216	172125	MPR10: 172124 +1	: PARITY STATUS REGISTER
673	002220	000000	0	: CONTROL MAP (LOW 64K)
674	002222	000000	0	: CONTROL MAP (HIGH 64K)
675	002224	000000	0	: MASK FOR MOS CORE, MS11-K
676	002226	172127	MPR11: 172126 +1	: PARITY STATUS REGISTER
677	002230	000000	0	: CONTROL MAP (LOW 64K)
678	002232	000000	0	: CONTROL MAP (HIGH 64K)
679	002234	000000	0	: MASK FOR MOS CORE, MS11-K
680	002236	172131	MPR12: 172130 +1	: PARITY STATUS REGISTER
681	002240	000000	0	: CONTROL MAP (LOW 64K)
682	002242	000000	0	: CONTROL MAP (HIGH 64K)
683	002244	000000	0	: MASK FOR MOS CORE, MS11-K
684	002246	172133	MPR13: 172132 +1	: PARITY STATUS REGISTER
685	002250	000000	0	: CONTROL MAP (LOW 64K)
686	002252	000000	0	: CONTROL MAP (HIGH 64K)
687	002254	000000	0	: MASK FOR MOS CORE, MS11-K
688	002256	172135	MPR14: 172134 +1	: PARITY STATUS REGISTER
689	002260	000000	0	: CONTROL MAP (LOW 64K)
690	002262	000000	0	: CONTROL MAP (HIGH 64K)
691	002264	000000	0	: MASK FOR MOS CORE, MS11-K
692	002266	172137	MPR15: 172136 +1	: PARITY STATUS REGISTER
693	002270	000000	0	: CONTROL MAP (LOW 64K)
694	002272	000000	0	: CONTROL MAP (HIGH 64K)
695	002274	000000	0	: MASK FOR MOS CORE, MS11-K
696				
697	002276	000021	: THIS IS THE END OF THE TABLE !	
698			MPRX: .BLKW 17.	: TABLE TO HOLD JUST PARITY STATUS REGISTERS THAT EXIST.
699				: (THE EXTRA WORD IS FOR A TERMINATOR.)



```

700 .SBTTL ERROR POINTER TABLE
701
702 ;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
703 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
704 ;*LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
705 ;*NOTE1: IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
706 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
707
708 ;*      EM      ;: POINTS TO THE ERROR MESSAGE
709 ;*      DH      ;: POINTS TO THE DATA HEADER
710 ;*      DT      ;: POINTS TO THE DATA
711 ;*      DF      ;: POINTS TO THE DATA FORMAT
712
713
714 002340 $ERRTB:
715 ;* ITEM 1
716 002340 026754 DM1 ;: PARITY REGISTER DATA ERROR.
717 002342 030333 DH1 ;: PC, REG, S/B, WAS
718 002344 001646 DT1 ;: $ERRPC, $GDADR, $GDDAT, $BDDAT
719 002346 030700 DF1 ;: 16, 18, 16, 16
720 ;* ITEM 2
721 002350 027010 DM2 ;: ADDRESS TEST ERROR(TST1-5).
722 002352 030352 DH2 ;: V/PC, P/PC, MA, S/B, WAS
723 002354 001660 DT2 ;: $VERPC, $ERRPC, $GDADR, $GDDAT, $BDDAT
724 002356 030704 DF2 ;: 16, 18, 18, 16, 16
725 ;* ITEM 3
726 002360 027010 DM2 ;: ADDRESS TEST ERROR(TST1-5).
727 002362 030352 DH2 ;: V/PC, P/PC, MA, S/B, WAS
728 002364 001660 DT2 ;: $VERPC, $ERRPC, $GDADR, $GDDAT, $BDDAT
729 002366 030711 DF3 ;: 16, 18, 18, 8, 8
730 ;* ITEM 4
731 002370 027044 DM4 ;: CONSTANT DATA ERROR(TST6-10).
732 002372 030352 DH2 ;: V/PC, P/PC, MA, S/B, WAS
733 002374 001660 DT2 ;: $VERPC, $ERRPC, $GDADR, $GDDAT, $BDDAT
734 002376 030704 DF2 ;: 16, 18, 18, 16, 16
735 ;* ITEM 5
736 002400 027102 DM5 ;: ROTATING BIT ERROR(TST11-12).
737 002402 030352 DH2 ;: V/PC, P/PC, MA, S/B, WAS
738 002404 001660 DT2 ;: $VERPC, $ERRPC, $GDADR, $GDDAT, $BDDAT
739 002406 030704 DF2 ;: 16, 18, 18, 16, 16
740 ;* ITEM 6
741 002410 027140 DM6 ;: MOS REFRESH TEST ERROR (TST30-31).
742 002412 030352 DH2 ;: V/PC, P/PC, MA, S/B, WAS
743 002414 001660 DT2 ;: $VERPC, $ERRPC, $GDADR, $GDDAT, $BDDAT
744 002416 030704 DF2 ;: 16, 18, 18, 16, 16
745 ;* ITEM 7
746 002420 027204 DM7 ;: 3 XOR 9 PATTERN ERROR(TST13-16).
747 002422 030352 DH2 ;: V/PC, P/PC, MA, S/B, WAS
748 002424 001660 DT2 ;: $VERPC, $ERRPC, $GDADR, $GDDAT, $BDDAT
749 002426 030704 DF2 ;: 16, 18, 18, 16, 16
750 ;* ITEM 10
751 002430 027245 DM10 ;: MARCHING 1'S AND 0'S ERROR(TST27).
752 002432 030352 DH2 ;: V/PC, P/PC, MA, S/B, WAS
753 002434 001660 DT2 ;: $VERPC, $ERRPC, $GDADR, $GDDAT, $BDDAT
754 002436 030704 DF2 ;: 16, 18, 18, 16, 16
755 ;* ITEM 11

```



756	002440	027311	DM11	: PARITY MEMORY ADDRESS ERROR(TST17).
757	002442	030352	DH2	: V/PC P/PC MA S/B WAS
758	002444	001660	DT2	: \$VERPC, \$ERRPC, \$GDADR, \$GDDAT, \$BDDAT
759	002446	030711	DF3	: 16, 18, 18, 8, 8
760			; * ITEM 12	
761	002450	027355	DM12	: DATIP WITH WRONG PARITY DIDN'T TRAP(TST17).
762	002452	030377	DH12	: V/PC P/PC MA S/B
763	002454	001674	DT12	: \$VERPC, \$ERRPC, \$GDADR, \$GDDAT
764	002456	030711	DF3	: 16, 18, 18, 8
765			; * ITEM 13	
766	002460	027431	DM13	: WRONG PARITY TRAPED, BUT NO REGISTER SHOWS ERROR FLAG.
767	002462	030377	DH12	: V/PC P/PC MA S/B
768	002464	001674	DT12	: \$VERPC, \$ERRPC, \$GDADR, \$GDDAT
769	002466	030711	DF3	: 16, 18, 18, 8
770			; * ITEM 14	
771	002470	027521	DM14	: PARITY REGISTER NOT MAPPED AS CONTROLLING THIS ADDRESS(TST17).
772	002472	030420	DH14	: V/PC P/PC REG, MA
773	002474	001706	DT14	: \$VERPC, \$ERRPC, \$TMPD, \$GDADR
774	002476	030716	DF14	: 16, 18, 18, 18
775			; * ITEM 15	
776	002500	026754	DM1	: PARITY REGISTER DATA ERROR.
777	002502	030441	DH15	: V/PC P/PC MAUT, REG, S/B WAS
778	002504	001720	DT15	: \$VERPC, \$ERRPC, \$GDADR, \$TMPD, \$GDDAT, \$BDDAT
779	002506	030716	DF14	: 16, 18, 18, 18, 16, 16
780			; * ITEM 16	
781	002510	027620	DM16	: MORE THAN ONE REGISTER INDICATED PARITY ERROR.
782	002512	030420	DH14	: V/PC P/PC REG, MA
783	002514	001706	DT14	: \$VERPC, \$ERRPC, \$TMPD, \$GDADR
784	002516	030716	DF14	: 16, 18, 18, 18
785			; * ITEM 17	
786	002520	027677	DM17	: DATA SHOULDN'T HAVE CHANGED WHEN PARITY ERROR
787				: TRAPPED(TST21).
788	002522	030352	DH2	: V/PC P/PC MA S/B WAS
789	002524	001660	DT2	: \$VERPC, \$ERRPC, \$GDADR, \$GDDAT, \$BDDAT
790	002526	030711	DF3	: 16, 18, 18, 8, 8
791			; * ITEM 20	
792	002530	027775	DM20	: RANDOM DATA ERROR(TST20).
793	002532	030352	DH2	: V/PC P/PC MA S/B WAS
794	002534	001660	DT2	: \$VERPC, \$ERRPC, \$GDADR, \$GDDAT, \$BDDAT
795	002536	030704	DF2	: 16, 18, 18, 16, 16
796			; * ITEM 21	
797	002540	030027	DM21	: INSTRUCTION EXECUTION ERROR(TST21-26).
798	002542	030474	DH21	: V/PC P/PC IUT, MA S B WAS
799	002544	001736	DT21	: \$VERPC, \$ERRPC, \$TMPD, \$GDADR, \$GDDAT, \$BDDAT
800	002546	030724	DF21	: 16, 18, 16, 18, 16, 16
801			; * ITEM 22	: NOT USED
802			; * ITEM 23	
803	002550	030076	DM23	: PROGRAM CODE CHANGED WHEN RELOCATED.
804	002552	030525	DH23	: V/PC P/PC SRC MA, DST MA, S/B WAS
805	002554	001754	DT23	: \$VERPC, \$ERRPC, \$GDADR, \$BDADR, \$GDDAT, \$BDDAT
806	002556	030716	DF14	: 16, 18, 18, 18, 16, 16
807			; * ITEM 24	
808	002560	030143	DM24	: TRAPPED, BUT NO REGISTER HAD ERROR BIT SET.
809	002562	030565	DH24	: V/PC P/PC TRP/PC
810	002564	001772	DT24	: \$VERPC, \$ERRPC, \$BDADR
811	002566	030716	DF14	: 16, 18, 18



J08

CZQMCE0 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-79 13:12 PAGE 18  
CZQMCE.P11 10-JAN-78 12:56 ERROR POINTER TABLE

SEQ 0100

812			;* ITEM 25	
813	002570	030217	DM25	: TRAPPED TO 114.
814	002572	030606	DH25	: V/PC, P/PC, TRP/PC, REG, WAS
815	002574	002002	DT25	: \$VERPC, \$EARRPC, \$B0ADR, \$TMP0, \$TMP1
816	002576	030716	DF14	: 16, 18, 18, 18, 16
817			;* ITEM 26	
818	002600	030237	DM26	: FAILED TO TRAP.
819	002602	030637	DH26	: V/PC, P/PC, REG, WAS
820	002604	002016	DT26	: \$VERPC, \$EARRPC, \$TMP0, \$TMP1
821	002606	030704	DF2	: 16, 18, 18, 16
822			;* ITEM 27	
823	002610	030257	DM27	: (ACTION ENABLE WASN'T SET).
824	002612	030637	DH26	: V/PC, P/PC, REG, WAS
825	002614	002016	DT26	: \$VERPC, \$EARRPC, \$TMP0, \$BDDAT
826	002616	030704	DF2	: 16, 18, 18, 16
827			;* ITEM 30	
828	002620	000000	0	: NO MESSAGE.
829	002622	030661	DH30	: REG, WAS, MA, WAS
830	002624	002030	DT30	: \$TMP0, \$TMP1, \$GDADR, \$BDR, IT
831	002626	030732	DF30	: 18, 16, 18, 8
832			;* ITEM 31	
833	002630	030313	DM31	: TRAPPED TO 4
834	002632	000000	0	: NO HEADER
835	002634	002042	DT31	: \$TMP3
836	002636	030732	DF30	: 18



837

.SBTTL START: SETUP AND MAP MEMORY

```

; /*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:
; * THIS IS THE NORMAL (SA = 200) BEGINNING OF THE PROGRAM.
; * NOTE: THIS CODE IS NOT POSITION INDEPENDENT.
; /*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:

```

```

844 002640 105067 176712 START: CLRB SELF LG ; CLEAR SELECT PARAMETER FLAG.
845 002644 000403 BR STARTA ; GO DO SETUP AND MEMORY MAP.
846 002646 112767 177777 176702 SELECT: MOVB #-1, SELF LG ; SET THE SELECT PARAMETERS FLAG.
847 002654 STARTA:
848 .SBTTL INITIALIZE THE COMMON TAGS
849 ;; CLEAR THE COMMON TAGS ($CMTAG) AREA
850 002654 012706 001100 MOV $CMTAG, R6 ; FIRST LOCATION TO BE CLEARED
851 002660 005026 CLR (R6)+ ; CLEAR MEMORY LOCATION
852 002662 022706 001140 CMP #SWR, R6 ;; DONE?
853 002666 001374 BNE -6 ;; LOOP BACK IF NO
854 002670 012706 001100 MOV #STACK, SP ;; SETUP THE STACK POINTER
855 ;; INITIALIZE A FEW VECTORS
856 002674 012737 000610 000024 MOV #SPWRON, $PWRVEC ;; POWER FAILURE VECTOR
857 002702 012737 000340 000026 MOV #340, $PWRVEC+2 ;; LEVEL 7
858 002710 016767 011214 011204 MOV $ENDCT, $EOPCT ;; SETUP END-OF-PROGRAM COUNTER
859 ;; SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
860 ;; EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
861 002716 013746 000004 MOV $ERRVEC, -(SP) ;; SAVE ERROR VECTOR
862 002722 012737 002756 000004 MOV #64$, $ERRVEC ;; SET UP ERROR VECTOR
863 002730 012767 177570 176202 MOV #DSWR, SWR ;; SETUP FOR A HARDWARE SWICH REGISTER
864 002736 012767 177570 176176 MOV #DDISP, DISPLAY ;; AND A HARDWARE DISPLAY REGISTER
865 002744 022777 177777 176166 CMP #-1, $SWR ;; TRY TO REFERENCE HARDWARE SWR
866 002752 001012 BNE 66$ ;; BRANCH IF NO TIMEOUT TRAP OCCURRED
867 ;; AND THE HARDWARE SWR IS NOT = -1
868 002754 000403 BR 65$ ;; BRANCH IF NO TIMEOUT
869 002756 012716 002764 64$: MOV #65$, (SP) ;; SET UP FOR TRAP RETURN
870 002762 000002 RTI
871 002764 012767 000176 176146 65$: MOV #SWREG, SWR ;; POINT TO SOFTWARE SWR
872 002772 012767 000174 176142 MOV #DISPREG, DISPLAY
873 003000 012637 000004 66$: MOV (SP)+, $ERRVEC ;; RESTORE ERROR VECTOR
874
875 003004 005067 176202 CLR $PASS ;; CLEAR PASS COUNT
876 003010 132767 000200 176207 BITB #APTSIZE, $ENVM ;; TEST USER SIZE UNDER APT
877 003016 001403 BEQ 67$ ;; YES, USE NON-APT SWITCH
878 003020 012767 001226 176112 MOV #SSWREG, SWR ;; NO, USE APT SWITCH REGISTER
879 003026 67$:
880 003026 005067 176470 CLR LDDISP ;; CLEAR DISPLAY REGISTER STORAGE LOCN
881 003032 005077 176104 CLR $DISPLAY ;; CLEAR DISPLAY REGISTER
882 .SBTTL TYPE PROGRAM NAME
883 ;; TYPE THE NAME OF THE PROGRAM IF FIRST PASS
884 003036 005227 177777 INC #-1 ;; FIRST TIME?
885 003042 001040 BNE 68$ ;; BRANCH IF NO
886 003044 022737 014174 000042 CMP #SENDAD, $#42 ;; ACT-11?
887 003052 001434 BEQ 68$ ;; BRANCH IF YES
888 003054 004567 020376 JSR R5, $PRINT ;; GO PRINT OUT THE FOLLOWING MESSAGE.
889 003060 003132 .WORD 69$ ;; ADDRESS OF MESSAGE TO BE TYPED
890 .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
891 003062 005737 000042 TST $#42 ;; ARE WE RUNNING UNDER XXDP/ACT?
892 003066 001015 BNE 70$ ;; BRANCH IF YES

```



```

893 003070 126727 176130 000001      CMPB   $ENV,#1          ;;ARE WE RUNNING UNDER APT?
894 003076 001411                BEQ     70$          ;;BRANCH IF YES
895 003100 026727 176034 000176      CMP     SWR,#SWREG      ;;SOFTWARE SWITCH REG SELECTED?
896 003106 001010                BNE     71$          ;;BRANCH IF NO
897                                ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $GTSWR ROUTINE
898                                ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
899 003110 013746 177776                MOV     @PSW, -(SP)      ;PUT THE PROCESSOR STATUS ON THE STACK
900 003114 004767 017262                JSR     PC,$GTSWR      ;GO TO THE SUBROUTINE
901 003120 000403                BR      71$
902 003122 112767 000001 176004 70$:   MOVB    #1,$AUTOB      ;;SET AUTO-MODE INDICATOR
903 003130 000405                71$:
904                                BR      68$          ;;GET OVER THE ASCIZ
905                                ;:69$: .ASCIZ  <CRLF>'CZQMCE0'<CRLF>
906                                68$:
907 003144 010700                MOV     PC,      R0          ;GET CURRENT PROGRAM COUNTER.
908 003146 022700 003146                CMP     #,      R0          ;CHECK IF THE PROGRAM IS RELOCATED.
909 003152 001402                BEQ     10$          ;BR IF PROGRAM NOT RELOCATED.
910 003154 000167 175120                JMP     RESTAR      ;GO TRY TO RELOCTED BEFORE CONTINUING.
911 003160 012767 000003 175414 10$:   MOV     #3,      PRGMAP      ;INITIALIZE PROGRAM MAP...LO 64K.
912 003166 005067 175412                CLR     PRGMAP+2      ;...HI 64K.
913 003172 005067 175402                CLR     RELOCF      ;INIT THE RELOCATION FACTOR.
914 003176 004767 014112                JSR     PC,SAVLDR      ;GO SAVE LOADERS
915
916                                ;* CHECK IF MEMORY MANAGEMENT IS AVAILABLE, AND SET IT UP IF IT IS.
917 003202 005067 175400                CLR     MMAVA      ;CLEAR MEM MGMT AVAILABLE FLAG
918 003206 032777 010000 175724        BIT     #SW12, @SWR      ;CHECK FOR INHIBIT KT11 SWITCH
919 003214 001014                BNE     IMPCK      ;BRANCH IF SET
920 003216 012737 003246 000004        MOV     @IMPCK,@ERRVEC      ;SET UP TIMEOUT TRAP VECTOR
921 003224 005037 177572                CLR     @MSRO      ;CLEAR MEM MGMT STATUS REG
922 003230 004767 011010                JSR     PC,MMINIT      ;MEM MGMT INITIALIZATION ROUTINE.
923 003234 005267 175346                INC     MMAVA      ;SET MEM MGMT AVAILABLE FLAG
924 003240 004567 020212                JSR     R5,$SPRINT      ;GO PRINT OUT THE FOLLOWING MESSAGE.
925 003244 025320                .WORD    MMAMES      ;ADDRESS OF MESSAGE TO BE TYPED
926                                ;"KT11 AVAILABLE"
927
928                                ;* CHECK IF CACHE PRESENT, IF SO TURN IT OFF!!!
929 003246 012706 001100 000004  IMPCK:  MOV     @STACK, SP      ;CLEAR CACHE PRESENT FLAG
930 003252 005067 176340                CLR     CASFLG
931 003256 012737 003300 000004        MOV     @MAPMEM,@ERRVEC
932 003264 052767 000014 174454        BIS     #14, IMPCHE
933 003272 012767 000001 176316        MOV     #1, CASFLG      ;SET CACHE PRESENT FLAG
934
935                                ;*****
936                                ;* ROUTINE TO MAP ALL OF MEMORY.
937                                ;* ONLY FULL 4K BANKS WILL BE RECOGNIZED.
938                                ;* R0 = MEMMAP POINTER...LO 64K.
939                                ;* R1 = MEMMAP POINTER...HI 64K.
940                                ;* R2 = ADDRESS POINTER
941                                ;* R3 = BANK POINTER...LO 64K.
942                                ;* R4 = BANK POINTER...HI 64K.
943                                ;* R5 = SCRATCH REGISTER.
944                                ;*****
945 003300 012706 001100 001524  MAPMEM: MOV     @STACK, SP      ;RESET THE STACK
946 003304 012700 001524                MOV     @MEMMAP,R0      ;SET UP MEMORY MAP POINTER...LO 64K.
947 003310 012701 001526                MOV     @MEMMAP+2,R1      ;...HI 64K.
948 003314 005010                CLR     (R0)          ;CLR MEMORY MAP...LO 64K.

```



949	003316	005011			CLR	(R1)		...HI 64K.
950	003320	005002			CLR	R2		SET ADDRESS POINTER TO 0
951	003322	012703	000001		MOV	#1, R3		SETUP 4K BANK POINTER...LO 64K.
952	003326	005004			CLR	R4		...HI 64K.
953	003330	005067	175632		CLR	\$TMP3		INIT TEMPORARY HIGH ADDRESS BITS.
954	003334	004567	020116		JSR	R5 \$PRINT		GO PRINT OUT THE FOLLOWING MESSAGE.
955	003340	025365			.WORD	MEMNES		ADDRESS OF MESSAGE TO BE TYPED
956								"MEMORY MAP:"
957	003342	012737	003456	000004	MOV	#2\$, @ERRVEC		SET UP TIMEOUT VECTOR
958	003350	011222		1\$:	MOV	(R2), (R2)+		READ+WRITE ALL MEMORY
959	003352	032702	017777		BIT	#MASK4K, R2		CHECK FOR 4K BOUNDARY
960	003356	001374			BNE	1\$		BRANCH IF MORE IN BANK
961	003360	050310			BIS	R3, (R0)		SET FLAG FOR BANK...LO 64K.
962	003362	050411			BIS	R4, (R1)		...HI 64K.
963	003364	010267	175574		MOV	R2, \$TMP2		SAVE ADDRESS POINTER.
964	003370	005367	175570		DEC	\$TMP2		ADJUST TO LAST ADR, LAST BANK.
965	003374	005767	175206		TST	MMAVA		CHECK FOR MEM MGMT.
966	003400	001432			BEQ	3\$		BR IF NO MEM MGMT.
967	003402	042767	160000	175554	BIC	#160000, \$TMP2		CLEAR BANK BITS ON RELATIVE ADDRESS.
968	003410	013705	172344		MOV	@KIPAR2, R5		SAVE KIPAR2.
969	003414	005067	175546		CLR	\$TMP3		MAKE SURE HI BITS ARE INIT.
970	003420	006305			ASL	R5		SHIFT IT 6 PLACES.
971	003422	006305			ASL	R5		
972	003424	006305			ASL	R5		
973	003426	006305			ASL	R5		
974	003430	006305			ASL	R5		
975	003432	006167	175530		ROL	\$TMP3		
976	003436	006305			ASL	R5		
977	003440	006167	175522		ROL	\$TMP3		
978	003444	060567	175514		ADD	R5, \$TMP2		;MAKE LAST ADR PHYSICAL.
979	003450	005567	175512		ADC	\$TMP3		
980	003454	000404			BR	3\$		;GO TO UPDATE POINTERS.
981								
982								
983	003456	022626			2\$:	CMP	(SP)+, (SP)+	;RESTORE THE STACK POINTER
984	003460	052702	017777		BIS	#MASK4K, R2		LAST ADDRESS OF 4K BANK
985	003464	005202			INC	R2		FIRST ADDRESS OF NEXT BANK.
986	003466	005767	175114		3\$:	TST	MMAVA	CHECK FOR MEM MGMT
987	003472	001411			BEQ	4\$		BRANCH IF NO MEM MGMT
988	003474	062737	000200	172344	ADD	#200, @KIPAR2		UPDATE THIRD PAR
989	003502	012702	040000		MOV	#40000, R2		POINT TO START OF THIRD PAR
990	003506	006303			ASL	R3		UPDATE LO BANK POINTER.
991	003510	006104			ROL	R4		UPDATE HI BANK POINTER
992	003512	100316			BPL	1\$		BRANCH IF MORE MEMORY TO MAP.
993	003514	000402			BR	5\$		EXIT WHEN DONE.
994								
995	003516	106303			4\$:	ASLB	R3	UPDATE MAP POINTER
996	003520	100313			BPL	1\$		BRANCH IF NOT YET DONE
997	003522	012737	025060	000004	5\$:	MOV	#ERRTRP, @ERRVEC	RESET TIMEOUT VECTOR
998	003530	004767	014622		JSR	PC, TYPMAP		GO TYPE THE MAP.
999	003534	004567	017716		JSR	R5, \$PRINT		GO PRINT OUT THE FOLLOWING MESSAGE.
1000	003540	001201			.WORD	\$CALF		ADDRESS OF MESSAGE TO BE TYPED
1001	003542	011067	175766		MOV	(R0), SAVTST		SET UP TEST MAP...LO 64K.
1002	003546	011167	175764		MOV	(R1), SAVTST+2		...HI 64K.
1003	003552	011000			MOV	(R0), R0		GET LOW MEM MAP
1004	003554	042700	177760		BIC	#177760, R0		MASK ALL BUT BOTTOM 4 BANKS



```

1005 003560 020027 000017      CMP      R0,      #17      ;CHECK THAT BOTTOM 16K IS ALL THERE!
1006 003564 001530      BEQ      GMPR      ;BRANCH IF BOTTOM 16K EXISTS
1007 003566 004567 017664      JSR      R5,      $PRINT    ;GO PRINT OUT THE FOLLOWING MESSAGE.
1008 003572 025470      .WORD     INSUFF    ;ADDRESS OF MESSAGE TO BE TYPED
1009                                     ;"FIRST 16K OF MEMORY NOT ALL THERE!"
1010 003574 000000      6$:      HALT      ;FATAL ERROR HALT.
1011                                     ;MEMORY IS NOT CONFIGURED TO RUN THIS PROGRAM.
1012                                     ;*****
1013                                     ;* SPECIAL ROUTINE TO TYPE OUT ALL UNIBUS ADDRESSES WHICH RESPOND TO
1014                                     ;* DATI, DATIP, DATO, AND DATOB.
1015                                     ;*****
1016 003576 012706 001100      TIMEOUT: MOV    #STACK, SP      ;SET UP THE STACK POINTER.
1017 003602 005067 175000      CLR      MMAVA      ;CLEAR MEM MGMT AVAILABLE FLAG.
1018 003606 032777 010000 175324      BIT      #SW12, 2$SWR      ;CHECK IF MEM MGMT TO BE INHIBITED.
1019 003614 001011      BNE      1$,      ;BR IF NO MEM MGMT.
1020 003616 012737 003640 000004      MOV      #1$,      2$ERRVEC    ;SET TIMEOUT FOR MEM MGMT CHECK.
1021 003624 005037 177572      CLR      2$SRD      ;CHECK FOR MEM MGMT...TIMES OUT IF NONE.
1022 003630 004767 010410      JSR      PC,      MMINIT    ;INIT ALL MEM MGMT REGISTERS.
1023 003634 005267 174746      INC      MMAVA      ;SET MEM MGMT AVAILABLE FLAG.
1024 003640      1$:
1025 003640 004567 017612      JSR      R5,      $PRINT    ;GO PRINT OUT THE FOLLOWING MESSAGE.
1026 003644 025403      .WORD     BYTIMES    ;ADDRESS OF MESSAGE TO BE TYPED
1027                                     ;"BYTE MEMORY MAP:"
1028 003646 005000      CLR      R0      ;SET UP TYPE OUT FLAG.
1029 003650 005002      CLR      R2      ;SET ADDRESS POINTER TO ZERO.
1030 003652 012737 003716 000004      MOV      #20$,      2$ERRVEC    ;SET TIME OUT VEC TO SERVICE NON-EX MEM.
1031 003660 105712      TSTB      (R2)      ;DO DATI ONLY.
1032 003662 032702 000001      BIT      #BIT0,      R2      ;CHECK FOR WORD ADDRESS.
1033 003666 001001      BNE      11$,      ;BR IF ODD BYTE ADDRESS.
1034 003670 011212      MOV      (R2),      (R2)      ;DO DATI, DATO...NOP FOR READ ONLY MAP.
1035 003672 151212      BISB      (R2),      (R2)      ;DO DATI, DATIP, DATOB... NOP FOR READ ONLY MAP.
1036 003674 005700      TST      R0      ;CHECK FOR PREVIOUS TYPED.
1037 003676 001023      BNE      30$,      ;BR IF ALREADY TYPED "FROM".
1038 003700 004567 017552      JSR      R5,      $PRINT    ;GO PRINT OUT THE FOLLOWING MESSAGE.
1039 003704 025453      .WORD     FROM      ;ADDRESS OF MESSAGE TO BE TYPED
1040                                     ;"FROM"
1041 003706 010246      MOV      R2,      -(SP)      ;PUT THE DATA ON THE STACK.
1042 003710 004767 021202      JSR      PC,      $TYPAD    ;DETERMINE THE PHYSICAL ADDRESS AND TYPE IT.
1043 003714 000413      BR      29$      ;GO TO ADDRESS POINTER UPDATE.
1044                                     ;* TIME OUTS COME HERE.
1045 003716 022626      20$:      CMP      (SP)+,      (SP)+    ;POP TWO OFF STACK.
1046 003720 005700      TST      R0      ;CHECK FOR PREVIOUS TYPED.
1047 003722 001411      BEQ      30$,      ;BR IF ALREADY TYPED "TO".
1048 003724 004567 017526      JSR      R5,      $PRINT    ;GO PRINT OUT THE FOLLOWING MESSAGE.
1049 003730 025463      .WORD     TO      ;ADDRESS OF MESSAGE TO BE TYPED
1050                                     ;"TO"
1051 003732 005302      DEC      R2      ;BACK UP ONE BYTE.
1052 003734 010246      MOV      R2,      -(SP)      ;PUT THE DATA ON THE STACK.
1053 003736 004767 021154      JSR      PC,      $TYPAD    ;DETERMINE THE PHYSICAL ADDRESS AND TYPE IT.
1054 003742 005202      INC      R2      ;RESET ADDRESS POINTER.
1055 003744 005100      COM      R0      ;RESET PREVIOUS TYPED FLAG.
1056 003746 005202      INC      R2      ;UPDATE ADDRESS POINTER TO NEXT BYTE.
1057 003750 001423      BEQ      31$,      ;EXIT IF ZERO REACHED.
1058 003752 032702 017777      BIT      #MASK4K,R2    ;CHECK FOR 4K BANK BOUNDARY.
1059 003756 001340      BNE      10$,      ;BR IF MORE THIS 4K BANK.
1060 003760 005767 174622      TST      MMAVA      ;CHECK IF MEM MGMT IS AVAILABLE.

```



```

1061 003764 001735      BEQ      10$      ;BR IF NO MEM MGMT.
1062 003766 022737 007600 172346  CMP      07600, 2*KIPAR3 ;CHECK FOR END OF LAST 4K BANK.
1063 003774 001411      BEQ      31$      ;EXIT WHEN ALL DONE.
1064 003776 012702 060000      MOV      060000, R2 ;RESET VIRTUAL ADDRESS POINTER.
1065 004002 013737 172346 172344  MOV      2*KIPAR3, 2*KIPAR2 ;SAVE MEM MGMT REG FOR TYPEOUT.
1066 004010 062737 000200 172346  ADD      0200, 2*KIPAR3 ;UPDATE MEM MGMT REG 2 TO NEXT 4K BANK.
1067 004016 000720      BR      10$      ;BR BACK TO DO NEXT BANK.
1068 004020 005700 31$: TST      R0      ;CHECK PREVIOUS TYPE FLAG BEFORE EXIT.
1069 004022 001407      BEQ      32$      ;BR TO EXIT IF TYPING ALL DONE.
1070 004024 004567 017426      JSR      R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
1071 004030 025463      .WORD      TO      ;ADDRESS OF MESSAGE TO BE TYPED
1072                                "TO"
1073                                ;BACK ADDRESS POINTER UP ONE BYTE.
1074 004032 005302      DEC      R2      ;PUT THE DATA ON THE STACK.
1075 004034 010246      MOV      R2, -(SP) ;DETERMINE THE PHYSICAL ADDRESS AND TYPE IT.
1076 004036 004767 021054      JSR      PC, STYPAD ;* THIS ROUTINE IS FOR DEBUG USE ONLY.
1077 004042 000000 32$: HALT      ;* TO RUN THE MAIN PROGRAM RESTART AT 200 OR 204.
1078 004044 000654      BR      TIMEOUT ;LOOP BACK AND DO AGAIN UPON CONTINUE.
1079
1080 .SBTTL MAP PARITY REGISTERS
1081 ;*****
1082 ;* SEARCH FOR PARITY REGISTERS PRESENT AND TYPE ADDRESSES OF THOSE FOUND
1083 ;* THAT ARE FUNCTIONAL AND HAVE CORRESPONDING PARITY MEMORY
1084 ;*****
1085
1086 004046 012704 002276      GMPR: MOV      0MPRX, R4      ;SET UP POINTER TO PARITY REG EXIST TABLE.
1087 004052 032777 000100 175060  BIT      0SW06, 2$WR ;CHECK FOR INHIBIT PARITY SWITCH.
1088 004060 001036      BNE      GMPRO ;BR IF INHIBIT PARITY.
1089 004062 012703 002076      MOV      0MPRO, R3      ;SET UP TABLE POINTER
1090 004066 012737 004110 000004  MOV      0GMPRB, 2$ERRVEC ;SET UP TIMEOUT TRAP SERVICE
1091 004074 042713 000001      GMPRA: BIC      01, (R3) ;CLEAR FLAG BIT IN TABLE
1092 004100 005773 000000      TST      2(R3) ;DOES THIS MEMORY PARITY REGISTER EXIST.
1093 ;* IF IT DOESN'T EXIST, A TIMEOUT TRAP WILL GO TO "GMPRB".
1094 004104 012324      MOV      (R3)+, (R4)+ ;SAVE IT IN THE PARITY REG EXIST TABLE.
1095 004106 000403      BR      GMPRC ;SKIP TIMEOUT SERVICE CODE
1096 ;* TIMEOUT COMES HERE
1097 004110 022626      GMPRB: CMP      (SP)+, (SP)+ ;RESTORE STACK POINTER
1098 004112 052723 000001      BIS      01, (R3)+ ;SET FLAG TO INDICATE REGISTER NOT PRESENT
1099 004116 005023      GMPRC: CLR      (R3)+ ;CLEAR THE MAP...LO 64K.
1100 004120 005023      CLR      (R3)+ ;...HI 64K.
1101 004122 005023      CLR      (R3)+ ;...AND THE MASK.
1102 004124 020327 002276      CMP      R3, 0MPRX ;HAVE WE CHECKED ALL REGISTERS?
1103 004130 103761      BLO      GMPRA ;NO - GO BACK TO CHECK NEXT ONE
1104 004132 005014      CLR      (R4) ;SET TERMINATOR IN PARITY REG EXIST TABLE.
1105 004134 012737 025060 000004  MOV      0ERRTRP, 2$ERRVEC ;RESTORE TRAPCATCHER
1106 004142 005767 176130      TST      MPX ;ANY PARITY REGISTERS PRESENT?
1107 004146 001006      BNE      MPAMEM ;YES - GO TEST CONTROLS PRESENT
1108 004150 004567 017302      JSR      R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
1109 004154 025551      .WORD      MTR ;ADDRESS OF MESSAGE TO BE TYPED
1110                                ;"NO MEMORY PARITY REGISTERS FOUND"
1111 004156 005014      GMPRD: CLR      (R4) ;MAKE SURE TABLE IS CLEAR.
1112 004160 000167 001156      JMP      MANUAL ;AND SKIP ALL CONTROLS TESTING
1113

```



```

1114 .SBTTL MAP PARITY MEMORY
1115 ;*****
1116 ;MAP CORRESPONDENCE BETWEEN PARITY REGISTERS AND MEMORY, AND TYPE RESULTS
1117 ;NOTE THAT IF PARITY MEMORY IS NOT LOCATED CORRECTLY THAT IT IS IN ALL
1118 ;PROBABILITY DUE TO ONE OF THE FOLLOWING FAILURES:
1119 ; - SETTING WRITE WRONG PARITY DIDN'T CAUSE BAD PARITY TO BE WRITTEN
1120 ; - PARITY GENERATE OR DETECT LOGIC FAILED
1121 ; - PARITY ERROR BIT FAILED TO SET
1122 ; - PARITY BITS IN MEMORY LOCATION FAILED
1123 ; - I.E. BIT STUCK AT GOOD PARITY VALUE
1124 ;*****
1125
1126 004164 004767 014044 MPAMEM: JSR PC, CLPAR ;INITIALIZE ALL PARITY REGISTERS
1127 004170 012767 000001 175346 MOV #1, BITPT ;INITIALIZE 4K POINTER
1128 004176 005067 175344 CLR BITPT+2 ;CLEAR HI 64K POINTER
1129 004202 012702 014000 MOV #14000, R2 ;SET ADR POINTER TO 14000.
1130 004206 005767 174374 TST MMAPA ;CHECK FOR MEM MGMT
1131 004212 001404 BEQ MAPRB ;BRANCH IF NO MEM MGMT
1132 004214 012702 054000 MOV #54000, R2 ;SET ADR POINTER TO PAR2
1133 004220 004767 010020 JSR PC, MMINIT ;SET UP ALL MEMORY MGMT REGISTERS.
1134
1135 ;*****
1136 ;SET WRITE WRONG PARITY IN ALL REGISTERS PRESENT
1137 ;* THEN WRITE TEST LOCATION VIA DAT0 & READ TEST LOCATION VIA DAT1
1138 ;* THEN CLEAR WRITE WRONG PARITY IN ALL REGISTERS.
1139 ;*****
1140
1141 004224 005067 175310 MAPRB: CLR PMAP ;CLEAR THE PARITY MEMORY MAP
1142 004230 005067 175306 CLR PMAP+2
1143 004234 012703 002076 1$: MOV #MPRO, R3 ;INITIALIZE TABLE ADDRESS
1144 004240 032713 000001 2$: BIT #1, (R3) ;IS THIS REGISTER PRESENT?
1145 004244 001052 BNE 3$ ;NO - GET THE NEXT ONE
1146 004246 013773 001612 000000 MOV @WWP, @R3 ;YES - SET WRITE WRONG PARITY
1147 ;AND CLEAR REST OF REGISTER
1148 004254 011212 MOV (R2), (R2) ;WRITE WRONG PARITY
1149 004256 005712 TST (R2) ;READ WRONG PARITY
1150 004260 043773 001612 000000 BIC @WWP, @R3 ;CLEAR WRITE WRONG PARITY
1151 004266 005773 000000 TST @R3 ;OTHERWISE, CHECK TO SEE IF THIS
1152 ;CONTROL REGISTER GOT A PARITY
1153 ;ERROR
1154 004272 100014 BPL 6$ ;BRANCH IF IT DIDN'T AND CHECK
1155 004274 032773 007740 000000 BIT #7740, @R3 ;IS IT A CORE PAR. REG.
1156 004302 001404 BEQ 5$ ;BRANCH IF NOT.
1157 004304 012763 070032 000006 MOV #70032, @R3 ;IF IT IS SET UP MASK
1158 004312 000413 BR 7$ ;AND BRANCH TO SET BITS.
1159 004314 012763 077772 000006 5$: MOV #77772, @R3 ;IF MOS SET UP MASK
1160 004322 000407 BR 7$ ;AND BRANCH TO SET BIT.
1161 004324 032773 007740 000000 6$: BIT #7740, @R3 ;IF ANY BITS ARE SET
1162 004332 001417 BEQ 3$ ;THEN CSR IS MS11-K.
1163 004334 012763 070000 000006 MOV #70000, @R3 ;IF MS11-K SET MASK.
1164 004342 056763 175176 000002 7$: BIS BITPT, @R3 ;SET FLAG IN MAP FOR THIS PARITY REGISTER
1165 004350 056763 175172 000004 BIS BITPT+2, @R3
1166 004356 056767 175162 175154 BIS BITPT, PMAP ;SET FLAG IN PARITY MAP
1167 004364 056767 175156 175150 BIS BITPT+2, PMAP+2
1168 004372 062703 000010 3$: ADD #10, R3 ;STEP UP TO NEXT REGISTER
1169 004376 020327 002276 CMP R3, #MPRX ;ARE WE DONE WITH TABLE?

```



```

1170 004402 103716 BLO 2$ ;GO BACK TO CHECK FOR ANY MORE!
1171 004404 011212 MOV (R2), (R2) ;CLEAR BAD PARITY
1172 004406 005767 174174 TST MMVA ;CHECK FOR MEM MGMT
1173 004412 001444 BEQ 10$ ;BR IF NO MEM MGMT
1174 004414 062737 000200 172344 4$: ADD #200, 2#KIPAR2 ;UPDATE PAR TO NEXT 4K BANK.
1175 004422 006367 175116 ASL BITPT ;UPDATE BANK POINTER...LO 64K.
1176 004426 006167 175114 ROL BITPT+2 ;...HI 64K.
1177 004432 100441 BMI TMAP ;BR IF ALL DONE.
1178 004434 023727 172344 001000 CMP 2#KIPAR2, #1000 ;THIS CODE TESTS IF MS11-K IS
1179 004442 001013 BNE 12$ ;PRESENT AND IF IT IS I SET
1180 004444 032737 000003 002260 BIT #3, 2#MPR14+2 ;THE BIT TO DISABLE ECC IN
1181 004452 001004 BNE 13$ ;THE LOCATION WWP THAT IS
1182 004454 032737 000003 002270 BIT #3, 2#MPR15+2 ;USED AS THE COMMAND TO
1183 004462 001400 BEQ 13$ ;WRITE WRONG PARITY.
1184 004464 012737 020004 001612 13$: MOV #20004, 2#WWP
1185 004472 036767 175046 175024 12$: BIT BITPT, MEMMAP ;CHECK IF BANK EXISTS...LO 64K.
1186 004500 001255 BNE 1$ ;BR IF BANK EXISTS.
1187 004502 036767 175040 175016 BIT BITPT+2, MEMMAP+2 ;...HI 64K.
1188 004510 001251 BNE 1$ ;BR IF BANK EXISTS.
1189 004512 000740 BR 4$ ;BR IF BANK DOESN'T EXIST.
1190 004514 036767 175024 175002 11$: BIT BITPT, MEMMAP ;CHECK IF BANK EXISTS.
1191 004522 001244 BNE 1$ ;BR IF BANK EXISTS.
1192 004524 062702 020000 10$: ADD #20000, R2 ;UPDATE ADDRESS POINTER TO NEXT BANK.
1193 004530 106367 175010 ASLB BITPT ;MOVE POINTER TO NEXT BANK.
1194 004534 100367 BPL 11$ ;BR IF MORE TO LOOK FOR.
1195
1196 ;*****
1197 ;* ROUTINE TO TYPE MAP OF WHERE PARITY MEMORY IS PRESENT
1198 ;* AND WHICH CONTROL REGISTERS CONTROL WHICH MEMORY
1199 ;*****
1200
1201 004536 004767 013472 TMAP: JSR PC, CLRPAR ;INITIALIZE ALL PARITY REGISTERS PRESENT
1202 004542 004567 016710 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
1203 004546 025426 .WORD MTMAP ;ADDRESS OF MESSAGE TO BE TYPED
1204 ;"PARITY MEMORY MAP:"
1205 004550 012703 002076 MOV #MPRO, R3 ;INITIALIZE TABLE POINTER
1206 004554 032713 000001 1$: BIT #BIT0, (R3) ;CHECK IF THIS REGISTER IS PRESENT.
1207 004560 001046 BNE 2$ ;BR IF NOT PRESENT.
1208 004562 022763 070032 000006 CMP #70032, 6(R3)
1209 004570 001004 BNE 3$
1210 004572 004567 016660 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
1211 004576 026067 .WORD MX3 ;ADDRESS OF MESSAGE TO BE TYPED
1212 ;"CORE PARITY"
1213 004600 000417 BR 5$
1214 004602 022763 077772 000006 3$: CMP #77772, 6(R3)
1215 004610 001004 BNE 4$
1216 004612 004567 016640 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
1217 004616 026106 .WORD MX4 ;ADDRESS OF MESSAGE TO BE TYPED
1218 ;"MOS PARITY"
1219 004620 000407 BR 5$
1220 004622 022763 070000 000006 4$: CMP #70000, 6(R3)
1221 004630 001003 BNE 5$
1222 004632 004567 016620 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
1223 004636 026124 .WORD MX5 ;ADDRESS OF MESSAGE TO BE TYPED
1224 ;"MS11-K CSR"
1225 004640 5$:

```



```

1226 004640 004567 016612 JSR R5 $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
1227 004644 026035 .WORD MX1 ;ADDRESS OF MESSAGE TO BE TYPED
1228 ;"REGISTER AT"
1229 004646 011346 MOV (R3), -(SP) ;SAVE (R3) FOR TYPEOUT
1230 ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOC ROUTINE
1231 ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
1232 004650 013746 177776 MOV @PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
1233 004654 004767 017774 JSR PC, $TYPOC ;GO TO THE SUBROUTINE
1234 004660 004567 016572 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
1235 004664 026054 .WORD MX2 ;ADDRESS OF MESSAGE TO BE TYPED
1236 ;"CONTROLS"
1237 004666 010300 MOV R3, R0 ;SET UP R0 FOR TYPMAP ROUTINE.
1238 004670 005720 TST (R0)+ ;UPDATE POINTER TO MAP.
1239 004672 004767 013460 JSR PC, TYPMAP ;GO TYPE THE MEMORY COVERED BY THIS REGISTER.
1240 004676 062703 000010 2$: ADD #10, R3 ;UPDATE TO NEXT REGISTER IN TABLE.
1241 004702 020327 002276 CMP R3, #MPRX ;ARE WE ALL DONE WITH TABLE?
1242 004706 103722 BLO 1$ ;BRANCH IF MORE REGISTERS
1243 004710 004567 016542 JSR R5, $PRINT ;THE REASON I'M OUTPUTTING THIS CRLF
1244 004714 001201 $CRLF ;IS TO GIVE THE PRINTER ENOUGH TIME TO
1245 ;FINISH PRINTING THE MEMORY MAP BEFORE THE RESET OCCURS.
1246 004716 022737 070000 002264 CMP #70000, @MPR14+6 ;DO WE HAVE MS11-K AT THIS ADDRESS
1247 004724 001006 BNE 7$ ;IF NO BRANCH
1248 004726 043727 002260 001540 BIC @MPR14+2, #PMEMAP ;IF YES THEN CLEAR THE BITS IN
1249 004734 043737 002262 001540 BIC @MPR14+4, @PMEMAP ;THE PARITY MEMORY MAP.
1250 004742 022737 070000 002274 7$: CMP #70000, @MPR15+6 ;DO WE HAVE A MS11-K
1251 004750 001031 BNE 9$ ;IF NO GO TO TESTS NOW.
1252 004752 043737 002270 001540 BIC @MPR15+2, @PMEMAP ;IF YES I AM GOING TO
1253 004760 043737 002272 001542 BIC @MPR15+4, @PMEMAP+2 ;CLEAR THE PARITY INDICATORS
1254 004766 012705 002276 MOV #MPRX, R5 ;FOR THAT PORTION OF MEMORY.
1255 004772 021537 002256 6$: CMP (R5), @MPR14 ;SEARCH FOR THIS MS11-K CSR IN
1256 004776 001004 BNE 8$ ;AND IF ITS THERE DELETE IT
1257 005000 005015 CLR (R5)
1258 005002 052737 000001 002256 8$: BIS #1, @MPR14
1259 005010 022537 002266 CMP (R5)+, @MPR15 ;SEARCH FOR MS11-K CSR IN
1260 005014 001366 BNE 6$ ;THE AVAILABILITY TABLE.
1261 005016 005045 CLR -(R5) ;AND CLEAR ITS ADDRESS FROM THE TABLE
1262 005020 052737 000001 002266 BIS #1, @MPR15 ;SET BIT0 IN ADDRESS IN CSR TABLE
1263 005026 004567 016424 JSR R5, $PRINT ;OUTPUT MESSAGE TO RUN MS11-K TEST.
1264 005032 026142 .WORD MX6
1265 005034 005737 002276 9$: TST @MPRX ;ARE THERE ANY PARITY REGISTERS TO TEST?
1266 005040 001002 BNE CTRLS ;IF SO TEST THE BITS IN THE REGISTERS,
1267 005042 000167 000274 JMP MANUAL ;IF NO JUMP OVER REGISTER TESTS.
1268
1269 .SBTTL TEST PARITY REGISTERS
1270 ;*****
1271 ;* SHOW THAT BITS 0, 2, 5 - 11, AND 15 OF EACH PARITY REGISTER PRESENT
1272 ;* CAN BE SET AND CLEARED.
1273 ;* THIS IS A ONCE ONLY TEST.
1274 ;*****
1275
1276 005046 012703 002076 CTRLS: MOV #MPRO, R3 ;LOAD INITIAL TABLE ADDRESS FOR A POINTER
1277 005052 011302 1$: MOV (R3), R2 ;LOAD R2 WITH ADDRESS OF THIS PARITY REGISTER
1278 005054 062703 000010 ADD #10, R3 ;UPDATE POINTER TO NEXT PAR. REG. ADD.
1279 005060 032702 000001 BIT #1, R2 ;IS THIS REGISTER BEING USED?
1280 005064 001372 BNE 1$ ;GO TO NEXT IF NOT
1281 005066 020327 002276 CMP R3, #MPRX ;ARE WE AT END OF TABLE

```



```

1282 005072 003055      BGT  RESCHK      ;GO TO NEXT TEST IF YES
1283 005074 005763 177776 TST  -2(R3)      ;TEST MASK FOR PARITY REGISTER
1284 005100 001764      BEQ  1$          ;IF = 0 THEN DO NOT TEST
1285 005102 016367 177776 174406 MOV -2(R3), RESRVD ;GET MASK FOR REGISTER WE ARE WORKING ON
1286 005110 012700 000001 MCV  #1, R0      ;LOAD R0 WITH VALUE OF 1ST BIT TESTED
1287 005114 005012      CLR  (R2)      ;INITIALIZE THE PARITY REGISTER
1288 005116 011201      MOV  (R2), R1      ;READ THE CONTENTS OF THE PARITY REGISTER
1289 005120 046701 174372 BIC  RESRVD, R1   ;CLEAR BITS WHICH ARE RESERVED
1290 005124 001405      BEQ  2$          ;CHECK OTHER BITS - BRANCH IF OK
1291 005126 004767 013124 64$: JSR  PC, SPRNT    ;SET UP VALUES FOR ERROR PRINTING.
1292 005132 004767 014446 JSR  PC, $ERROR   ;*** ERROR *** (GO TYPE A MESSAGE)
1293 005136 000001      .WORD 1          ;ERROR TYPE CODE.
1294 005140 030067 174352 2$: BIT  R0, RESRVD   ;IS THIS BIT RESERVED?
1295 005144 001025      BNE  3$          ;YES - DON'T TEST IT
1296 005146 010012      MOV  R0, (R2)      ;NO - SET THIS BIT IN THE PARITY REGISTER
1297 005150 011201      MOV  (R2), R1      ;READ & SAVE CONTENTS OF THE PARITY REGISTER
1298 005152 005012      CLR  (R2)      ;CLEAR THE PARITY REGISTER
1299 005154 046701 174336 BIC  RESRVD, R1   ;CLEAR BIT LOCATIONS THAT ARE RESERVED
1300 005160 020001      CMP  R0, R1      ;COMPARE THE CHECK W C D WITH THE DATA READ.
1301 005162 001405      BEQ  66$        ;BRANCH OVER ERROR CALL IF GOOD DATA.
1302 005164 004767 013116 65$: JSR  PC, SPRNT    ;SET UP VALUES FOR ERROR PRINTING.
1303 005170 004767 014410 JSR  PC, $ERROR   ;*** ERROR *** (GO TYPE A MESSAGE)
1304 005174 000001      .WORD 1          ;ERROR TYPE CODE.
1305 005176 005176 66$:      MOV  (R2), R1      ;READ THE CONTENTS OF THE PARITY REGISTER
1306 005176 011201      BIC  RESRVD, R1   ;CLEAR BITS WHICH ARE RESERVED
1307 005200 046701 174312 BEQ  3$          ;CHECK OTHER BITS - BRANCH IF OK
1308 005204 001405      JSR  PC, SPRNT    ;SET UP VALUES FOR ERROR PRINTING.
1309 005206 004767 013044 67$: JSR  PC, $ERROR   ;*** ERROR *** (GO TYPE A MESSAGE)
1310 005212 004767 014366 JSR  PC, $ERROR   ;*** ERROR *** (GO TYPE A MESSAGE)
1311 005216 000001      .WORD 1          ;ERROR TYPE CODE.
1312 005220 006300 3$:  ASL  R0          ;ROTATE TO GET NEXT BIT TO BE TESTED
1313 005222 103346      BCC  2$          ;BRANCH IF NOT DONE WITH ALL BITS
1314 005224 000712      BR   1$          ;AFTER TESTING FOR BIT 15 GO GET NEXT REGISTER.
1315
1316 ;*****
1317 ;* SHOW THAT RESET CLEARS BITS 0,2, AND 15 OF EACH PARITY REGISTER PRESENT.
1318 ;* THIS IS A ONCE ONLY TEST.
1319 ;*****
1320
1321 005226 012704 002076 RESCHK: MOV  #MPRO, R4      ;LOAD INITIAL TABLE ADDRESS FOR A POINTER
1322 005232 010403 1$:  MOV  R4, R3
1323 005234 062704 000010 ADD  #10, R4
1324 005240 032713 000001 BIT  #1, (R3)      ;IS THIS REGISTER BEING USED
1325 005244 001372      BNE  1$          ;BRANCH IF NO
1326 005246 012773 177777 000000 MOV  #-1, 2(R3)   ;SET ALL BITS TO A 1
1327 005254 022704 002276 CMP  #MPRX, R4      ;ARE WE AT THE END OF THE TABLE
1328 005260 002764      BLT  1$          ;IF YES THEN WE ARE READY TO TEST
1329 005262 000005      RESET          ;RESET THE WORLD
1330 005264 012703 002076 MOV  #MPRO, R3      ;LOAD INITIAL ADDRESS FOR POINTER
1331 005270 011302 2$:  MOV  (R3), R2      ;STORE PARITY REGISTER ADDRESS
1332 005272 062703 000010 ADD  #10, R3
1333 005276 032702 000001 BIT  #1, R2
1334 005302 001372      BNE  2$          ;
1335 005304 022703 002276 CMP  #MPRX, R3
1336 005310 002014      BGE  MANUAL
1337 005312 011201      MOV  (R2), R1      ;GET CONTENTS OF REGISTER

```



1338	005314	005012		CLR	(R2)		
1339	005316	042701	077772	BIC	#77772, R1		; CLEAR BITS NOT EFFECTED BY RESET
1340	005322	005701		TST	R1		; CHECK IF REST WERE CLEARED BY RESET
1341	005324	001405		BEG	65\$		; BRANCH OVER ERROR CALL IF GOOD DATA.
1342	005326	004767	012724	JSR	PC,	SPRNT	; SET UP VALUES FOR ERROR PRINTING.
1343	005332	004767	014246	JSR	PC,	\$ERROR	; *** ERROR *** (GO TYPE A MESSAGE)
1344	005336	000001		.WORD	1		; ERROR TYPE CODE.
1345	005340						
1346	005340	000753		BR	2\$		; BRANCH BACK TO CHECK NEXT REGISTER
1347							
1348							
1349	005342	012700	000014	MANUAL: MOV	#12, R0		; SET COUNTER TO CLEAR 12 WORDS.
1350	005346	012701	001562	MOV	#FSTADR, R1		; STARTING AT FSTADR.
1351	005352	005021		1\$: CLR	(R1)+		; CLEAR THE LOCATIONS.
1352	005354	005300		DEC	R0		; COUNT.
1353	005356	001375		BNE	1\$		; BR IF MORE.
1354	005360	105767	174172	TSTB	SELFLG		; CHECK FOR SELECT PARAMETERS STARTUP.
1355	005364	001005		BNE	MANUL1		; BR IF PARAMETERS TO BE SELECTED.
1356	005366	016767	173572	MOV	\$TMP2, LSTADR		; SET UP VIRTUAL LAS ADDRESS.
1357	005374	000167	000402	JMP	MANUL2		; SKIP PARAMETER SELECTION SECTION.



```

1358 .SBTTL USER PARAMETER SELECTION SECTION
1359 ;*****
1360 ;* USER PARAMETER SELECTION SECTION IS ENTERED BY STARTING AT 204.
1361 ;*****
1362 005400 012700 000001 MANUL1: MOV #BIT0, R0 ;SET UP BANK POINTER.
1363 005404 005001 CLR R1 ;HI 64K.
1364 005406 005002 CLR R2 ;CLEAR ADDRESS POINTER.
1365 005410 005003 CLR R3 ;HI ADDRESS BITS.
1366 005412 004567 016040 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
1367 005416 026255 .WORD FAOMES ;ADDRESS OF MESSAGE TO BE TYPED
1368 ;"FIRST ADDRESS:"
1369 ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $RDOCT ROUTINE
1370 ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
1371 005420 013746 177776 MOV #PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
1372 005424 004767 015654 JSR PC, $RDOCT ;GO TO THE SUBROUTINE
1373 005430 042716 000001 BIC #BIT0, (SP) ;MAKE SURE ADDRESS IS ON A WORD BOUNDARY.
1374 005434 005067 174074 CLR SAVTST ;INIT TEST MAP...LO 64K.
1375 005440 005067 174072 CLR SAVTST+2 ;HI 64K.
1376 005444 062702 020000 1$: ADD #20000, R2 ;UPDATE ADDRESS POINTER TO NEXT BANK.
1377 005450 005503 ADC R3
1378 005452 020367 015776 CMP R3, $HIOCT ;CHECK HI ADDRESS BITS.
1379 005456 103403 BLO 2$ ;BR IF NOT HI ENOUGH YET.
1380 005460 101006 BHI 3$ ;BR IF PAST SELECTED ADDRESS.
1381 005462 020216 CMP R2, (SP) ;CHECK THE LO ADDRESS BITS.
1382 005464 101004 BHI 3$ ;BR IF PAST SELECTED ADDRESS.
1383 005466 006300 2$: ASL R0 ;UPDATE POINTER...LO 64K.
1384 005470 006101 ROL R1 ;HI 64K.
1385 005472 100364 BPL 1$ ;BR BACK TO CHECK NEXT BANK.
1386 005474 000507 BR 17$ ;BR IF OVERFLOW.
1387 005476 030067 174022 3$: BIT R0, MEMMAP ;CHECK IF BANK EXISTS.
1388 005502 001003 BNE 4$ ;BR IF BANK EXISTS.
1389 005504 030167 174016 BIT R1, MEMMAP+2 ;CHECK HI 64K.
1390 005510 001501 BEQ 17$ ;BR IF ADDRESS IN UN-MAPPED BANK.
1391 005512 016704 015736 4$: MOV $HIOCT, R4 ;SAVE FIRST ADR HI BITS.
1392 005516 10$: JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
1393 005516 004567 015734 .WORD LADMES ;ADDRESS OF MESSAGE TO BE TYPED
1394 005522 026342 ;"LAST ADDRESS:"
1395 ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $RDOCT ROUTINE
1396 ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
1397 005524 013746 177776 MOV #PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
1398 005530 004767 015550 JSR PC, $RDOCT ;GO TO THE SUBROUTINE
1399 005534 005716 TST (SP) ;CHECK IF ADR 0 SELECTED (DEFAULT).
1400 005536 001010 BNE 11$ ;BR IF NOT 0 (DEFAULT)
1401 005540 005767 015710 TST $HIOCT ;CHECK HI BITS.
1402 005544 001005 BNE 11$ ;BR IF NOT 0 (DEFAULT).
1403 005546 016716 173412 MOV $TMP2, (SP) ;SET UP DEFAULT LAST ADR.
1404 005552 016767 173410 MOV $TMP3, $HIOCT
1405 005560 012667 174010 11$: MOV (SP)+, LSTADR ;GET THE DATA.
1406 005564 020467 015664 CMP R4, $HIOCT ;CHECK FOR LAST ADR BELOW FIRST ADR.
1407 005570 101352 BHI 10$ ;BR IF LAST BELOW FIRST.
1408 005572 103403 BLO 12$ ;BR IF LAST ABOVE FIRST.
1409 005574 021667 173774 CMP (SP), LSTADR ;CHECK FOR LAST BELOW FIRST.
1410 005600 101346 BHI 10$ ;BR IF LAST BELOW FIRST.
1411 005602 032716 017777 12$: BIT #MASK4K, (SP) ;CHECK IF FIRST ADR ON BANK BOUNDARY.
1412 005606 001404 BEQ 13$ ;BR IF ON BOUNDARY.

```



1414	005610	010067	173754		MOV	R0,	FADMAP	;SET UP FIRST ADDRESS MAP.
1415	005614	010167	173752		MOV	R1,	FADMAP+2	
1416	005620	050067	173710	13\$:	BIS	R0,	SAVTST	;SFT FLAG IN TEST MAP...LO 64K.
1417	005624	050167	173706		BIS	R1,	SAVTST+2	;HI 64K.
1418	005630	020367	015620	14\$:	CMP	R3,	\$HIOCT	;CHECK FOR PAST LAST ADR.
1419	005634	103404			BLO	15\$		;BR IF BELOW LAST ADR.
1420	005636	101020			BHI	16\$		;BR IF GONE PAST LAST ADR.
1421	005640	020267	173730		CMP	R2,	LSTADR	;CHECK FOR PAST LAST ADR.
1422	005644	101015			BHI	16\$		;BR IF GONE PAST LAST ADR.
1423	005646	062702	020000	15\$:	ADD	#20000,	R2	;UPDATE ADDRESS POINTER.
1424	005652	005503			ADC	R3		;...HI BITS.
1425	005654	006300			ASL	R0		;UPDATE BANK POINTER...LO 64K.
1426	005656	006101			ROL	R1		;...HI 64K.
1427	005660	100415			BMI	17\$		;BR IF OVERFLOW.
1428	005662	030067	173636		BIT	R0	MEMMAP	;CHECK IF THIS BANK EXISTS.
1429	005666	001354			BNE	13\$		;BR IF BANK EXISTS.
1430	005670	030167	173632		BIT	R1	MEMMAP+2	;CHECK IF THIS BANK EXISTS.
1431	005674	001351			BNE	13\$		;BR IF BANK EXISTS.
1432	005676	000754			BR	14\$		;BR IF BANK DOESN'T EXIST.
1433	005700	030067	173620	16\$:	BIT	R0	MEMMAP	;CHECK IF THIS BANK EXISTS.
1434	005704	001010			BNE	20\$		;BR IF IT EXISTS.
1435	005706	030167	173614		BIT	R1	MEMMAP+2	;CHECK IF THIS BANK EXISTS.
1436	005712	001005			BNE	20\$		;BR IF IT EXISTS.
1437	005714	005726		17\$:	TST	(SP)+		;ADJUST THE STACK.
1438	005716	004567	015534		JSR	R5	\$PRINT	;GO PRINT OUT THE FOLLOWING MESSAGE.
1439	005722	026365			.WORD	BADADR		;ADDRESS OF MESSAGE TO BE TYPED
1440								"?ADDRESS IN UNMAPPED BANK?"
1441	005724	000606			BR	MANUAL		;LOOP BACK TO THE BEGINNING.
1442	005726	010067	173650	20\$:	MOV	R0,	LADMAP	;SET UP MAP FOR LAST ADDRESS.
1443	005732	010167	173646		MOV	R1,	LADMAP+2	
1444	005736	005767	172644	21\$:	TST	MMAVA		;CHECK FOR MEMORY MANAGEMENT.
1445	005742	001404			BEQ	22\$		;BR IF NO MEM MGMT.
1446	005744	042716	160000		BIC	#160000,(SP)		;ADJUST FSTADR TO VITRUAL BANK 0.
1447	005750	062716	040000		ADD	#40C00,(SP)		;...TO VIRTUAL BANK 2.
1448	005754	012667	173602	22\$:	MOV	(SP)+,	FSTADR	;SAVE FISRT ADDRESS OFF THE STACK.
1449	005760			30\$:				
1450	005760	004567	015472		JSR	R5	\$PRINT	;GO PRINT OUT THE FOLLOWING MESSAGE.
1451	005764	026422			.WORD	CONST		;ADDRESS OF MESSAGE TO BE TYPED
1452								"SELECT CONSTANT:"
1453					;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE \$RDOCT ROUTINE			
1454					;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.			
1455	005766	013746	177776		MOV	#PSW,	-(SP)	;PUT THE PROCESSOR STATUS ON THE STACK
1456	005772	004767	015306		JSR	PC	\$RDOCT	;GO TO THE SUBROUTINE
1457	005776	012667	173606		MOV	(SP)+,	.CONST	;SAVE THE CONSTANT
1458	006002	005767	172600	MANUL2:	TST	MMAVA		;CHECK IF MEM MGMT IS AVAILABLE.
1459	006006	001406			BEQ	31\$		;BR IF NO MEM MGMT.
1460	006010	042767	160000		BIC	#160000,LSTADR		;ADJUST LSTADR TO VIRTUAL BANK 0.
1461	006016	062767	040000		ADD	#40000,LSTADR		;...VIRTUAL BANK 2.
1462	006024	062767	000002	31\$:	ADD	#2,LSTADR		;ADJUST LAST ADDRESS UP ONE WORD.
1463	006032	042767	000001		BIC	#B10,LSTADR		;MAKE SURE IT IS A WORD ADDRESS.
1464	006040	032767	017777		BIT	#MASK4K,LSTADR		;CHECK IF LAST ADR IS ON BANK BOUNDRY.
1465	006046	001004			BNE	START1		;BR IF NOT ON BOUNDARY.
1466	006050	005067						



```

:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:
: * THE REST OF THE PROGRAM IS POSITION INDEPENDENT CODE, SO THAT IT CAN EXECUTE PROPERLY WHEN THE PROGRAM HAS BEEN RELO
: * THIS IS DONE SO THAT THE FIRST TWO BANKS OF MEMORY CAN BE EXERCISED IN EXACTLY THE SAME MANNER AS THE REST OF MEMORY
:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:/*:

```

1475	006060	016706	173536		START1:	MOV	.STACK, SP		;SET STACK POINTER
1476	006064	005767	173526			TST	CASFLG		;CHECK CACHE PRESENT FLAG
1477	006070	001403				BEQ	IS		;BRANCH IF NO CACHE
1478	006072	052777	000014	173520		BIS	#14, @CASREG		;TURN OFF CACHE
1479	006100	012767	006060	173000	IS:	MOV	#START1, \$LPADR		;INIT LOOP ADDRESS.
1480	006106	066767	172466	172772		ADD	RELOCF, \$LPADR		
1481	006114	004767	011362			JSR	PC, MAMF		;SET UP MEMORY PARITY ERROR VECTOR
1482	006120	005767	172462			TST	MMAVA		;CHECK FOR MEMORY MANAGEMENT AVAILABLE.
1483	006124	001406				BEQ	TST1		;BRANCH IF NO MEM MGMT.
1484	006126	032737	000001	177572		BIT	#BIT0, @MSRO		;CHECK IF MEM MGMT ENABLED.
1485	006134	001002				BNE	TST1		;BR IF MEM MGMT ENABLED.
1486	006136	004767	006102			JSR	PC, MMINIT		;SET UP MEM MGMT REGISTERS.



```

1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497 006142
1498 006142 004567 012426
1499 006146 000001
1500
1501 006150 000167 005604
1502
1503
1504 006154 004467 006212
1505 006160 004767 007634
1506 006164 010012
1507 006166 012201
1508 006170 020001
1509 006172 001405
1510 006174 004767 012132
1511 006200 004767 013400
1512 006204 000002
1513 006206
1514 006206 062700 000002
1515 006212 030502
1516 006214 001363
1517 006216 004767 006726
1518
1519
1520
1521 006222 004467 006602
1522 006226 004767 007566
1523 006232 162700 000002
1524 006236 014201
1525 006240 020001
1526 006242 001405
1527 006244 004767 012036
1528 006250 004767 013330
1529 006254 000002
1530 006256
1531 006256 030502
1532 006260 001364
1533 006262 004767 007352

```

```

.SBTTL SECTION 1: MEMORY ADDRESS TESTS
*****
;TEST 1 WRITE VALUE OF MEMORY ADDRESS INTO MEMORY
; R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
; R1 = DATA READ FROM MEMORY (WAS)
; R2 = VIRTUAL ADDRESS
; R3 = NOT USED
; R4 = NOT USED
; R5 = BLOCK BOUNDARY BIT MASK.
*****
TST1:
      JSR      R5,      $SCOPE ;GO TO SCOPE ROUTINE.
      .WORD    1          ;MINIMUM BLOCK SIZE OF 1 WORDS
                          ;REQUIRED FOR THIS TEST.
      JMP      TST32      ;SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
                          ;AVAILABLE FOR TEST.

; * UPWARDS WORD ADDRESSING.
      JSR      R4,      INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$:    JSR      PC,      PHYADR ;GET PHYSICAL ADDRESS INTO R0
2$:    MOV      R0,      (R2)   ;WRITE VALUE OF ADDRESS INTO ADDRESS
      MOV      (R2)+,    R1     ;GET THE DATA FROM MEMORY UNDER TEST.
      CMP      R0,      R1     ;COMPARE THE CHECK WORD WITH THE DATA READ.
      BEQ      65$         ;BRANCH OVER ERROR CALL IF GOOD DATA.
64$:   JSR      PC,      SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
      JSR      PC,      $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
      .WORD    2          ;ERROR TYPE CODE.
65$:   ADD      #2,      R0     ;ADD #2 TO PHYSICAL ADDRESS
      BIT      R5,      R2     ;CHECK FOR END OF A BLOCK.
      BNE      2$,      ;BRANCH IF MORE IN CURRENT BLOCK.
      JSR      PC,      MMUP   ;FIND NEXT BLOCK AND LOOP TO 1$.

; * CHECK THAT VALUE OF MEMORY ADDRESS WAS WRITTEN CORRECTLY
; * DOWNWARDS WORD ADDRESSING.
      JSR      R4,      INITDN ;INITIALIZE THE MEMORY ADDRESS POINTERS.
3$:    JSR      PC,      PHYADR ;GET PHYSICAL ADDRESS INTO R0
4$:    SUB      #2,      R0     ;DEC DATA BY 2
      MOV      -(R2),    R1     ;GET THE DATA FROM MEMORY
      CMP      R0,      R1     ;COMPARE THE CHECK WORD WITH THE DATA READ.
      BEQ      67$         ;BRANCH OVER ERROR CALL IF GOOD DATA.
66$:   JSR      PC,      SPRNTQ ;SET UP VALUES FOR ERROR PRINTING.
      JSR      PC,      $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
      .WORD    2          ;ERROR TYPE CODE.
67$:   BIT      R5,      R2     ;CHECK FOR END OF A BLOCK.
      BNE      4$,      ;BRANCH IF MORE IN CURRENT BLOCK.
      JSR      PC,      MMDOWN ;FIND NEXT BLOCK AND LOOP TO $TAG1.

```



L09

```

1534
1535
1536
1537
1538
1539
1540
1541
1542
1543 006266
1544 006266 004567 012302
1545 006272 000000
1546
1547 006274 004467 006072
1548 006300 004767 007514
1549 006304 110022
1550 006306 005200
1551 006310 030502
1552 006312 001374
1553 006314 004767 006630
1554
1555
1556
1557 006320 004467 006504
1558 006324 004767 007470
1559 006330 005300
1560 006332 114201
1561 006334 120001
1562 006336 001405
1563 006340 004767 011742
1564 006344 004767 013234
1565 006350 000003
1566 006352 030502
1567 006354 001365
1568 006356 004767 007256
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580 006362
1581 006362 004567 012206
1582 006366 000000
1583
1584 006370 004467 006434
1585 006374 004767 007420
1586 006400 005100
1587 006402 062700 000002
1588 006406 010042
1589 006410 030502

```

```

*****
*TEST 2 WRITE VALUE OF MEMORY ADDRESS INTO MEMORY
*
* R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
* R1 = DATA READ FROM MEMORY (WAS)
* R2 = VIRTUAL ADDRESS
* R3 = NOT USED
* R4 = NOT USED
* R5 = BLOCK BOUNDARY BIT MASK.
*****
*ST2:
      JSR      R5,      $SCOPE ;GO TO SCOPE ROUTINE.
      .WORD    0           ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
; * UPWARDS BYTE ADDRESSING.
      JSR      R4,      INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$:   JSR      PC,      PHYADR ;GET PHYSICAL ADDRESS INTO R0
2$:   MOV      R0,      (R2)+  ;WRITE VALUE OF ADDRESS INTO ADDRESS
      INC      R0          ;ADD ONE TO PHYSICAL ADDRESS
      BIT      R5,      R2    ;CHECK FOR END OF A BLOCK.
      BNE      2$,      PC    ;BRANCH IF MORE IN CURRENT BLOCK.
      JSR      PC,      MMUP  ;FIND NEXT BLOCK AND LOOP TO 1$.
; * CHECK THAT VALUE OF MEMORY ADDRESS WAS WRITTEN CORRECTLY
; * DOWNWARDS BYTE ADDRESSING.
      JSR      R4,      INITDN ;INITIALIZE THE MEMORY ADDRESS POINTERS.
3$:   JSR      PC,      PHYADR ;GET PHYSICAL ADDRESS INTO R0
4$:   DEC      R0          ;DEC DATA BY 1
      MOV      -(R2), R1    ;GET THE DATA FROM MEMORY
      CMP      R0,      R1   ;CHECK THE DATA...LO BYTE ONLY VALID.
      BEQ      65$,      PC  ;BRANCH OVER ERROR CALL IF GOOD DATA.
64$:  JSR      PC,      SPRNT0 ;SET UP VALUES FOR ERROR PRINTING.
      JSR      PC,      $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
      .WORD    3           ;ERROR TYPE CODE.
65$:  BIT      R5,      R2    ;CHECK FOR END OF A BLOCK.
      BNE      4$,      PC    ;BRANCH IF MORE IN CURRENT BLOCK.
      JSR      PC,      MMDOWN ;FIND NEXT BLOCK AND LOOP TO $TAG1.
*****
*TEST 3 WRITE 1'S COMPLEMENT VALUE OF ADDRESS INTO ADDRESS.
*
* R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
* R1 = DATA READ FROM MEMORY (WAS)
* R2 = VIRTUAL ADDRESS
* R3 = NOT USED
* R4 = NOT USED
* R5 = BLOCK BOUNDARY BIT MASK.
*****
*ST3:
      JSR      R5,      $SCOPE ;GO TO SCOPE ROUTINE.
      .WORD    0           ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
; * DOWNWARDS WORD ADDRESSING.
      JSR      R4,      INITDN ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$:   JSR      PC,      PHYADR ;GET PHYSICAL ADDRESS INTO R0
      COM      R0          ;COMPLEMENT THE ADR
2$:   ADD      #2,      R0    ;+2 TO DATA--ADR GOES DOWN SO COM GOES UP
      MOV      R0,      -(R2) ;PUT DATA INTO MEMORY
      BIT      R5,      R2    ;CHECK FOR END OF A BLOCK.

```



1590 006412 001373  
1591 006414 004767 007220  
1592  
1593  
1594  
1595 006420 004467 005746  
1596 006434 004767 007370  
1597 006430 005100  
1598 006432  
1599 006432 012201  
1600 006434 020001  
1601 006436 001405  
1602 006440 004767 011665  
1603 006444 004767 013134  
1604 006450 000002  
1605 006452  
1606 006452 162700 000002  
1607 006456 J30502  
1608 006460 001364  
1609 006462 004767 006462  
1610  
1611  
1612  
1613  
1614  
1615  
1616  
1617  
1618  
1619  
1620 006466  
1621 006466 004567 012102  
1622 006472 000000  
1623  
1624 006474 004467 005672  
1625 006500 004767 007370  
1626 006504 110022  
1627 006506 030502  
1628 006510 001375  
1629 006512 004767 006432  
1630  
1631  
1632  
1633 006516 004467 005650  
1634 006522 004767 007346  
1635 006526 112201  
1636 006530 020001  
1637 006532 001405  
1638 006534 004767 011554  
1639 006540 004767 013040  
1640 006544 000003  
1641 006546  
1642 006546 030502  
1643 006550 001366  
1644 006552 004767 006372  
1645

```

BNE 2$ ;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMDOWN ;FIND NEXT BLOCK AND LOOP TO 1$.

;* CHECK COMPLEMENT DATA WRITTEN DOWN
;* UPWARDS WORD ADDRESSING.
3$: JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
    JSR PC, PHYADR ;GET PHYSICAL ADDRESS INTO R0
    COM R0 ;COMPLEMENT IT
4$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
    CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    BEQ 65$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
64$: JSR PC, SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
     JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
     .WORD 2 ;ERROR TYPE CODE.
65$: SUB #2, R0 ;COUNT DOWN WITH ADDRESS
     BIT R5, R2 ;CHECK FOR END OF A BLOCK.
     BNE 4$ ;BRANCH IF MORE IN CURRENT BLOCK.
     JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 3$.

;*****
;TEST 4 WRITE BANK # INTO ALL ADDRESSES IN A 4K BANK
; R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
; R1 = DATA READ FROM MEMORY (WAS)
; R2 = VIRTUAL ADDRESS
; R3 = NOT USED
; R4 = NOT USED
; R5 = BLOCK BOUNDARY BIT MASK.
;*****
1ST4: JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
      .WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
;* UPWARDS BYTE ADDRESSING.
3$: JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
    JSR PC, BANKNO ;GET THE BANK NUMBER INTO R0
2$: MOV R0, (R2)+ ;WRITE BANK # INTO ALL ADDRESSES
    BIT R5, R2 ;CHECK FOR END OF A BLOCK.
    BNE 2$ ;BRANCH IF MORE IN CURRENT BLOCK.
    JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

;* CHECK THAT DATA WRITTEN ABOVE CAN BE READ
;* UPWARDS BYTE ADDRESSING.
3$: JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
    JSR PC, BANKNO ;GET THE BANK NUMBER INTO R0
4$: MOV (R2)+, R1 ;READ THE DATA OUT OF MEMORY
    CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    BEQ 65$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
64$: JSR PC, SPRT1 ;SET UP VALUES FOR ERROR PRINTING.
     JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
     .WORD 3 ;ERROR TYPE CODE.
65$: BIT R5, R2 ;CHECK FOR END OF A BLOCK.
     BNE 4$ ;BRANCH IF MORE IN CURRENT BLOCK.
     JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 3$.

```



```

1646
1647
1648
1649
1650
1651
1652
1653
1654
1655 006556
1656 006556 004567 012012
1657 006562 000000
1658
1659 006564 004467 006240
1660 006570 004767 007300
1661 006574 005100
1662 006576 110042
1663 006600 030502
1664 006602 001375
1665 006604 004767 007030
1666
1667
1668
1669 006610 004467 006214
1670 006614 004767 007254
1671 006620 005100
1672 006622 114201
1673 006624 020001
1674 006626 001405
1675 006630 004767 011452
1676 006634 004767 012744
1677 006640 000003
1678 006642
1679 006642 030502
1680 006644 001366
1681 006646 004767 006766

```

```

*****
;TEST 5      WRITE 1'S COMPLEMENT OF BANK #.
;R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
;R1 = DATA READ FROM MEMORY (WAS)
;R2 = VIRTUAL ADDRESS
;R3 = NOT USED
;R4 = NOT USED
;R5 = BLOCK BOUNDARY BIT MASK.
*****
+STS:      JSR      R5,      $SCOPE      ;GO TO SCOPE ROUTINE.
           .WORD    0              ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
; * DOWNWARDS BYTE ADDRESSING.
           JSR      R4,      INITDN      ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$:      JSR      PC,      BANKNO      ;GET THE BANK NUMBER INTO R0
           COM      R0              ;1'S COMPLEMENT OF BANK #
2$:      MOV      R0,      -(R2)      ;PUT 1'S COM OF BANK # INTO MEMORY
           BIT      R5,      R2      ;CHECK FOR END OF A BLOCK.
           BNE     2$      ;BRANCH IF MORE IN CURRENT BLOCK.
           JSR      PC,      MMDOWN     ;FIND NEXT BLOCK AND LOOP TO 1$.
; * CHECK THAT DATA WRITTEN CAN BE READ.
; * DOWNWARDS BYTE ADDRESSING.
           JSR      R4,      INITDN      ;INITIALIZE THE MEMORY ADDRESS POINTERS.
3$:      JSR      PC,      BANKNO      ;GET THE BANK # INTO R0
           COM      R0              ;SET 1'S COMPLEMENT OF BANK #
4$:      MOV      -(R2), R1      ;READ DATA OUT OF MEMORY
           CMP      R0,      R1      ;COMPARE THE CHECK WORD WITH THE DATA READ.
           BEQ     65$      ;BRANCH OVER ERROR CALL IF GOOD DATA.
64$:      JSR      PC,      SPRNT0      ;SET UP VALUES FOR ERROR PRINTING.
           JSR      PC,      $ERROR     ;*** ERROR *** (GO TYPE A MESSAGE)
           .WORD    3              ;ERROR TYPE CODE.
65$:      BIT      R5,      R2      ;CHECK FOR END OF A BLOCK.
           BNE     4$      ;BRANCH IF MORE IN CURRENT BLOCK.
           JSR      PC,      MMDOWN     ;FIND NEXT BLOCK AND LOOP TO $TAG1.

```



```

1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697 006652
1698 006652 004567 011716
1699 006656 000000
1700 006660 016700 172724
1701 006664 004467 005502
1702 006670 010022
1703 006672 030502
1704 006674 001375
1705 006676 004767 006246
1706
1707
1708
1709
1710
1711 006702
1712 006702 004567 011666
1713 006706 000000
1714 006710 016700 172674
1715 006714 004467 005452
1716 006720
1717 006720 012201
1718 006722 020001
1719 006724 001405
1720 006726 004767 011400
1721 006732 004767 012646
1722 006736 000004
1723 006740
1724 006740 030502
1725 006742 001366
1726 006744 004767 006200
1727
1728
1729
1730 006750 032777 000400 172162
1731 006756 001416
1732 006760 017746 172154
1733 006764 042716 177740
1734 006770 022726 000006
1735 006774 001007
1736 006776 162767 000001 172076
1737 007004 162767 000030 172074

```

```

.SBTTL SECTION 2:      WORST CASE NOISE TESTS
*****
* THESE TESTS WRITE MEMORY WORST CASE NOISE TEST PATTERNS THROUGHOUT
* MEMORY AND CHECK THAT THEY CAN BE WRITTEN AND READ.
*****
* TEST 6      WRITE A CONSTANT INTO MEMORY.
* THE CONSTANT IS USER SELECTABLE (DEFAULT = 0).
* R0 = DATA WRITTEN INTO MEMORY (SHOULD BE)
* R1 = DATA READ FROM MEMORY (WAS)
* R2 = VIRTUAL ADDRESS
* R3 = NOT USED
* R4 = NOT USED
* R5 = BLOCK BOUNDARY BIT MASK.
*****
TST6:      JSR      R5,      $SCOPE      ;GO TO SCOPE ROUTINE.
           .WORD      0              ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
TST6A:     MOV      .CONST, R0          ;GET USER CONSTANT
           JSR      R4,      INITMM     ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$:        MOV      R0,      (R2)+      ;WRITE CONSTANT INTO MEMORY.
           BIT      R5,      R2          ;CHECK FOR END OF A BLOCK.
           BNE      1$,      1$          ;BRANCH IF MORE IN CURRENT BLOCK.
           JSR      PC,      MMUP       ;FIND NEXT BLOCK AND LOOP TO 1$.
*****
* TEST 7      READ MEMORY AND COMPARE TO CONSTANT.
* IMPORTANT: THIS TEST SHOULD NOT BE RUN WITHOUT FIRST RUNNING TEST 6.
*****
TST7:      JSR      R5,      $SCOPE      ;GO TO SCOPE ROUTINE.
           .WORD      0              ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
           MOV      .CONST, R0          ;GET USER CONSTANT
           JSR      R4,      INITMM     ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$:        MOV      (R2)+, R1          ;GET THE DATA FROM MEMORY UNDER TEST.
           CMP      R0,      R1          ;COMPARE THE CHECK WORD WITH THE DATA READ.
           BEQ      65$,      65$       ;BRANCH OVER ERROR CALL IF GOOD DATA.
64$:       JSR      PC,      $SPRINT2    ;SET UP VALUES FOR ERROR PRINTING.
           JSR      PC,      $ERROR      ;*** ERROR *** (GO TYPE A MESSAGE)
           .WORD      4              ;ERROR TYPE CODE.
65$:       BIT      R5,      R2          ;CHECK FOR END OF A BLOCK.
           BNE      1$,      1$          ;BRANCH IF MORE IN CURRENT BLOCK.
           JSR      PC,      MMUP       ;FIND NEXT BLOCK AND LOOP TO 1$.
* SPECIAL CHECK TO SEE IF TEST 6 IS SELECTED THRU THE SWR.
* ALLOWS THE OPERATOR TO SWITCH BACK AND FORTH BETWEEN TESTS 6 AND 7
* BY SIMPLY "TOGGLING" SW00 WHEN SW01, SW02, AND SW03 ARE SET.
*
           BIT      #SW08, 2SWR        ;CHECK THAT LOOP ON TEST BIT SET
           BEQ      TST10, 2SWR        ;BRANCH IF NOT LOOP ON TEST
           MOV      2SWR, -(SP)         ;GET SWITCH REGISTER DATA.
           BIC      #177740, (SP)      ;CLEAR NON-TEST-NUMBER SWITCHES.
           CMP      #6, (SP)+          ;CHECK IF TEST 6 IN SWITCHES.
           BNE      TST10              ;BRANCH IF NOT TEST 6
           SUB      #1, $TSTNM         ;RESET TEST NUM
           SUB      #TST7-TST6, $LPADR ;RESET LOOP ADR

```



## C10

CZQMCEO 0-124K MEMORY EXERCISER, 16K VER  
CZQMCE.P11 10-JAN-78 12:56 T7

MACY11 30A(1052) 10-JAN-78 13:12 PAGE 37  
READ MEMORY AND COMPARE TO CONSTANT.

SEQ 0119

```

1738 007012 000722          BR      TST6A          ;GO TO TEST 6
1739
1740          ;*****
1741          ;*TEST 10      WORSE CASE NOISE (PARITY) WORD TESTING
1742          ;* CHECK MEMORY WITH A SERIES OF PATTERNS
1743          ;*****
1744          †ST10:
1745 007014 004567 011554      JSR      R5,      $SCOPE      ;GO TO SCOPE ROUTINE.
1746 007020 000000              .WORD      0              ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
1747 007022 016704 172606      MOV      .MPPAT, R4          ;INITIALIZE PATTERN TABLE POINTER
1748 007026 004767 010550      JSR      PC,      CKPMER      ;CHECK FOR NON-TRAP PARITY MEMORY ERRORS.
1749 007032 012400              MOV      (R4)+, R0          ;GET THE DATA PATTERN.
1750 007034 001420              BEQ      TST11, R0          ;BR IF END OF TABLE.
1751 007036 004467 005330      JSR      R4,      INITMM      ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1752 007042 010012              MOV      R0,      (R2)        ;PUT DATA PATTERN INTO MEMORY.
1753 007044 012201              MOV      (R2)+, R1          ;GET THE DATA FROM MEMORY UNDER TEST.
1754 007046 020001              CMP      R0,      R1          ;COMPARE THE CHECK WORD WITH THE DATA READ.
1755 007050 001405              BEQ      65$, R1            ;BRANCH OVER ERROR CALL IF GOOD DATA.
1756 007052 004767 011254      JSR      PC,      SPRINT2     ;SET UP VALUES FOR ERROR PRINTING.
1757 007056 004767 012522      JSR      PC,      $ERROR      ;*** ERROR *** (GO TYPE A MESSAGE)
1758 007062 000004              .WORD      4              ;ERROR TYPE CODE.
1759 007064
1760 007064 030502              BIT      R5,      R2          ;CHECK FOR END OF A BLOCK.
1761 007066 001365              BNE      2$, R5            ;BRANCH IF MORE IN CURRENT BLOCK.
1762 007070 004767 006054      JSR      PC,      MMUP        ;FIND NEXT BLOCK AND LOOP TO 2$.
1763 007074 000754              BR      1$, R5            ;BR BACK TO DO NEXT PATTERN

```



```

1764
1765
1766
1767 007076
1768 007076 004567 011472
1769 007102 000000
1770 007104 012700 177777
1771 007110 004767 007020
1772 007114 004467 005252
1773 007120 000241
1774 007122 004767 007026
1775 007126 016201 177776
1776 007132 103402
1777 007134 020001
1778 007136 001405
1779 007140 004767 011166
1780 007144 004767 012434
1781 007150 000005
1782 007152
1783 007152 030502
1784 007154 001361
1785 007156 004767 005766
1786
1787
1788
1789
1790 007162
1791 007162 004567 011406
1792 007166 000000
1793 007170 005000
1794 007172 004767 006736
1795 007176 004467 005170
1796 007202 000261
1797 007204 004767 006744
1798 007210 016201 177776
1799 007214 103002
1800 007216 020001
1801 007220 001405
1802 007222 004767 011104
1803 007226 004767 012352
1804 007232 000005
1805 007234
1806 007234 030502
1807 007236 001361
1808 007240 004767 005704

```

```

*****
;TEST 11 ROTATE A "0" BIT THROUGH A FIELD OF ONES.
*****
;ST11:
JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
;WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
MOV #-1, R0 ;SET CHECK WORD
JSR PC, SETCON ;PUT THE CONTENTS OF R0 IN ALL MEMORY.
JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$: CLC ;CLEAR CARRY BIT IN PSW
JSR PC, ROTATE
MOV -2(R2), R1 ;GET RESULT
BCS 63$ ;BRANCH IF 'C' BIT WAS SET
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 64$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
63$: JSR PC, SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
;WORD 5 ;ERROR TYPE CODE.
64$: BIT R5, R2 ;CHECK FOR END OF A BLOCK.
BNE 1$ ;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

*****
;TEST 12 ROTATE A "1" BIT THROUGH A FIELD OF ZEROS
*****
;ST12:
JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
;WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
CLR R0 ;SET CHECK WORD
JSR PC, SETCON ;PUT THE CONTENTS OF R0 IN ALL MEMORY.
JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$: SEC ;SET 'C' BIT IN PSW
JSR PC, ROTATE ;GO ROTATE '1' BIT
MOV -2(R2), R1 ;GET RESULT
BCC 63$ ;BRANCH IF 'C' IS CLEAR
CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ 64$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
63$: JSR PC, SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
;WORD 5 ;ERROR TYPE CODE.
64$: BIT R5, R2 ;CHECK FOR END OF A BLOCK.
BNE 1$ ;BRANCH IF MORE IN CURRENT BLOCK.
JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

```



```

1809      ;*****
1810      ;*TEST 13      3 XOR 9 TEST PATTERN.
1811      ;*****
1812      ;T13:
1813      JSR      R5,      $SCOPE      ;GO TO SCOPE ROUTINE.
1814      .WORD    777      ;MINIMUM BLOCK SIZE OF 256. WORDS
1815      ;          ;REQUIRED FOR THIS TEST.
1816      JMP      TST14      ;SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
1817      ;          ;AVAILABLE FOR TEST.
1818      .3X9:    CLR      R0      ;SET UP TEST DATA
1819      MOV      R0-1,      R3      ;SET COM DATA REG
1820      JSR      R4,      INITMM      ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1821      JSR      PC,      W3X9      ;WRITE 256. WORD BLOCK WITH 3 XOR 9 PAT.
1822      BIT      R5,      R2      ;CHECK FOR END OF A BLOCK.
1823      BNE      1$,      ;BRANCH IF MORE IN CURRENT BLOCK.
1824      JSR      PC,      MMUP      ;FIND NEXT BLOCK AND LOOP TO 1$.
1825
1826      ;*****
1827      ;* CHECK 3 XOR 9 TEST PATTERN WRITTEN ABOVE
1828      ;*****
1829      CLR      R0      ;SET CHECK WORD
1830      JSR      R4,      INITMM      ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1831      MOV      R4,      R4      ;SET 256. WORD COUNTER
1832
1833      11$:     MOV      (R2)+,      R1      ;GET THE DATA FROM MEMORY UNDER TEST.
1834      CMP      R0,      R1      ;COMPARE THE CHECK WORD WITH THE DATA READ.
1835      BEQ      65$,      ;BRANCH OVER ERROR CALL IF GOOD DATA.
1836      JSR      PC,      SPRT2      ;SET UP VALUES FOR ERROR PRINTING.
1837      JSR      PC,      $ERROR      ;*** ERROR *** (GO TYPE A MESSAGE)
1838      .WORD    7      ;ERROR TYPE CODE.
1839
1840      65$:     MOV      (R2)+,      R1      ;GET THE DATA FROM MEMORY UNDER TEST.
1841      CMP      R0,      R1      ;COMPARE THE CHECK WORD WITH THE DATA READ.
1842      BEQ      67$,      ;BRANCH OVER ERROR CALL IF GOOD DATA.
1843      JSR      PC,      SPRT2      ;SET UP VALUES FOR ERROR PRINTING.
1844      JSR      PC,      $ERROR      ;*** ERROR *** (GO TYPE A MESSAGE)
1845      .WORD    7      ;ERROR TYPE CODE.
1846
1847      67$:     MOV      (R2)+,      R1      ;GET THE DATA FROM MEMORY UNDER TEST.
1848      CMP      R0,      R1      ;COMPARE THE CHECK WORD WITH THE DATA READ.
1849      BEQ      69$,      ;BRANCH OVER ERROR CALL IF GOOD DATA.
1850      JSR      PC,      SPRT2      ;SET UP VALUES FOR ERROR PRINTING.
1851      JSR      PC,      $ERROR      ;*** ERROR *** (GO TYPE A MESSAGE)
1852      .WORD    7      ;ERROR TYPE CODE.
1853
1854      69$:     MOV      (R2)+,      R1      ;GET THE DATA FROM MEMORY UNDER TEST.
1855      CMP      R0,      R1      ;COMPARE THE CHECK WORD WITH THE DATA READ.
1856      BEQ      71$,      ;BRANCH OVER ERROR CALL IF GOOD DATA.
1857      JSR      PC,      SPRT2      ;SET UP VALUES FOR ERROR PRINTING.
1858      JSR      PC,      $ERROR      ;*** ERROR *** (GO TYPE A MESSAGE)
1859      .WORD    7      ;ERROR TYPE CODE.
1860
1861      71$:     MOV      (R2)+,      R1      ;GET THE DATA FROM MEMORY UNDER TEST.
1862      CMP      R0,      R1      ;COMPARE THE CHECK WORD WITH THE DATA READ.
1863      BEQ      71$,      ;BRANCH OVER ERROR CALL IF GOOD DATA.
1864      JSR      PC,      SPRT2      ;SET UP VALUES FOR ERROR PRINTING.
1865      JSR      PC,      $ERROR      ;*** ERROR *** (GO TYPE A MESSAGE)
1866      .WORD    7      ;ERROR TYPE CODE.
1867
1868      71$:     COM      R0      ;COMPLEMENT CHECK WORD
1869      DEC      R4      ;DECREMENT 256. WORD COUNTER
1870      BNE      12$,      ;
1871      COM      R0      ;COMPLEMENT CHECK WORD

```



## F10

CZQMCE0 0-124K MEMORY EXERCISER, 16K VER  
CZQMCE.P11 10-JAN-78 12:56 T13

MACY11 30A(1052) 10-JAN-78 13:12 PAGE 40  
3 XOR 9 TEST PATTERN.

SEQ 0122

```

1865 007426 030502          BIT    R5      R2      ;CHECK FOR END OF A BLOCK.
1866 007430 001330          BNE    11$      ;BRANCH IF MORE IN CURRENT BLOCK.
1867 007432 004767 005512    JSR     PC,      MMUP    ;FIND NEXT BLOCK AND LOOP TO 11$.
1868
1869
1870
1871
1872 007436 005000          ;*****
1873 007440 004467 004726    ;* CHECK, COM, CHECK, COM, CHECK 3 XOR 9 PATTERN WRITTEN ABOVE.
1874 007444 012704 000100    ;*****
1875 007450 012703 000004    ;*****
1876 007454          CLR     R0
1877 007454 012201          JSR     R4,      INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1878 007456 020001          MOV     #64.,    R4      ;SET 256. WORD COUNTER
1879 007460 001405          MOV     #4,      R3      ;SET 4 WORD COUNTER
1880 007462 004767 010644    21$:    MOV     (R2)+,    R1      ;GET THE DATA FROM MEMORY UNDER TEST.
1881 007466 004767 012112    22$:    CMP     R0,      R1      ;COMPARE THE CHECK WORD WITH THE DATA READ.
1882 007472 000007          BEQ     73$      ;BRANCH OVER ERROR CALL IF GOOD DATA.
1883 007474          72$:    JSR     PC,      SPRT2    ;SET UP VALUES FOR ERROR PRINTING.
1884 007474 005100          JSR     PC,      $ERROR  ;*** ERROR *** (GO TYPE A MESSAGE)
1885 007476 005142          .WORD    7          ;ERROR TYPE CODE.
1886 007500 012201          COM     R0
1887 007502 020001          COM     -(R2)
1888 007504 001405          MOV     (R2)+,    R1      ;COMPLEMENT CHECK WORD
1889 007506 004767 010620    73$:    CMP     R0,      R1      ;COMPLEMENT TEST DATA
1890 007512 004767 012066    74$:    BEQ     75$      ;GET THE DATA FROM MEMORY UNDER TEST.
1891 007516 000007          JSR     PC,      SPRT2    ;COMPARE THE CHECK WORD WITH THE DATA READ.
1892 007520          JSR     PC,      $ERROR  ;BRANCH OVER ERROR CALL IF GOOD DATA.
1893 007520 005100          .WORD    7          ;SET UP VALUES FOR ERROR PRINTING.
1894 007522 005142          COM     R0          ;*** ERROR *** (GO TYPE A MESSAGE)
1895 007524 012201          COM     -(R2)        ;ERROR TYPE CODE.
1896 007526 020001          MOV     (R2)+,    R1      ;COMPLEMENT CHECK WORD
1897 007530 001405          CMP     R0,      R1      ;COMPLEMENT TEST DATA
1898 007532 004767 010574    75$:    BEQ     76$      ;GET THE DATA FROM MEMORY UNDER TEST.
1899 007536 004767 012042    76$:    JSR     PC,      SPRT2    ;COMPARE THE CHECK WORD WITH THE DATA READ.
1900 007542 000007          JSR     PC,      $ERROR  ;BRANCH OVER ERROR CALL IF GOOD DATA.
1901 007544          .WORD    7          ;SET UP VALUES FOR ERROR PRINTING.
1902 007544 005303          COM     R0          ;*** ERROR *** (GO TYPE A MESSAGE)
1903 007546 001342          COM     -(R2)        ;ERROR TYPE CODE.
1904 007550 005100          MOV     (R2)+,    R1      ;COMPLEMENT CHECK WORD
1905 007552 005304          CMP     R0,      R1      ;COMPLEMENT TEST DATA
1906 007554 001335          BEQ     77$      ;GET THE DATA FROM MEMORY UNDER TEST.
1907 007556 005100          JSR     PC,      SPRT2    ;COMPARE THE CHECK WORD WITH THE DATA READ.
1908 007560 030502          JSR     PC,      $ERROR  ;BRANCH OVER ERROR CALL IF GOOD DATA.
1909 007562 001330          .WORD    7          ;SET UP VALUES FOR ERROR PRINTING.
1910 007564 004767 005360    77$:    JSR     PC,      $ERROR  ;*** ERROR *** (GO TYPE A MESSAGE)
          .WORD    7          ;ERROR TYPE CODE.
          DEC     R3          ;DECREMENT 4 WORD COUNTER
          BNE    23$          ;BR IF NOT DONE.
          COM     R0          ;COMPLEMENT CHECK WORD
          DEC     R4          ;DECREMENT 256. WORD COUNTER
          BNE    22$          ;BR IF NOT DONE.
          COM     R0          ;COMPLEMENT CHECK WORD
          BIT     R5,      R2    ;CHECK FOR END OF A BLOCK.
          BNE    21$          ;BRANCH IF MORE IN CURRENT BLOCK.
          JSR     PC,      MMUP    ;FIND NEXT BLOCK AND LOOP TO 21$.

```



# G10

```

1911
1912
1913
1914 007570
1915 007570 004567 011000
1916 007574 000777
1917
1918 007576 000167 000316
1919
1920 007602 012700 177777
1921 007606 005003
1922 007610 004467 004556
1923 007614 004767 006402
1924 007620 030502
1925 007622 001374
1926 007624 004767 005320
1927
1928
1929
1930
1931
1932 007630 012700 177777
1933 007634 004467 004532
1934 007640 012704 000100
1935 007644
1936 007644 012201
1937 007646 020001
1938 007650 001405
1939 007652 004767 010454
1940 007656 004767 011722
1941 007662 000007
1942 007664
1943 007664 012201
1944 007666 020001
1945 007670 001405
1946 007672 004767 010434
1947 007676 004767 011702
1948 007702 000007
1949 007704
1950 007704 012201
1951 007706 020001
1952 007710 001405
1953 007712 004767 010414
1954 007716 004767 011662
1955 007722 000007
1956 007724
1957 007724 012201
1958 007726 020001
1959 007730 001405
1960 007732 004767 010374
1961 007736 004767 011642
1962 007742 000007
1963 007744
1964 007744 005100
1965 007746 005304
1966 007750 001335

;*****
;TEST 14 COMPLEMENT 3 XOR 9 TEST PATTERN
;*****
TST14: JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
        .WORD 777 ;MINIMUM BLOCK SIZE OF 256. WORDS
        ;REQUIRED FOR THIS TEST.
        JMP TST15 ;SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
        ;AVAILABLE FOR TEST.
        MOV #-1, R0 ;SET UP TEST DATA
        CLR R3 ;SET COM DATA REG
        JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$: JSR PC, W3X9 ;WRITE 256. WORD BLOCK WITH 3 XOR 9 PAT.
    BIT R5, R2 ;CHECK FOR END OF A BLOCK.
    BNE 1$ ;BRANCH IF MORE IN CURRENT BLOCK.
    JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

;*****
;CHECK COMPLEMENTED 3 XOR 9 TEST PATTERN WRITTEN ABOVE.
;*****
MOV #-1, R0 ;SET CHECK WORD
JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
11$: MOV #64., R4 ;SET 256. WORD COUNTER
12$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
    CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    BEQ 65$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
64$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
    JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
    .WORD 7 ;ERROR TYPE CODE.
65$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
    CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    BEQ 67$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
66$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
    JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
    .WORD 7 ;ERROR TYPE CODE.
67$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
    CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    BEQ 69$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
68$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
    JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
    .WORD 7 ;ERROR TYPE CODE.
69$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
    CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    BEQ 71$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
70$: JSR PC, SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.
    JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
    .WORD 7 ;ERROR TYPE CODE.
71$: COM R0 ;COMPLEMENT CHECK WORD
    DEC R4 ;DECREMENT 256. WORD COUNTER
    BNE 12$

```



## H10

CZQMCEO 0-124K MEMORY EXERCISER, 16K VER  
CZQMCE.P11 10-JAN-78 12:56 T14

MACY11 30A 1052) 10-JAN-78 13:12 PAGE 42  
COMPLEMENT 3 XOR 9 TEST PATTERN

SEQ 0124

1967	007752	005100		COM	R0		; COMPLEMENT CHECK WORD
1968	007754	030502		BIT	R5	R2	; CHECK FOR END OF A BLOCK.
1969	007756	001330		BNE	11\$		; BRANCH IF MORE IN CURRENT BLOCK.
1970	007760	004767	005164	JSR	PC,	MMUP	; FIND NEXT BLOCK AND LOOP TO 11\$.
1971							
1972							
1973							
1974							
1375	007764	012700	177777				
1976	007770	004467	004376				
1977	007774	012704	000100				
1978	010000	012703	000004	21\$:	MOV	#64.,	R4
1979	010004			22\$:	MOV	#4,	R3
1980	010004	012201		23\$:			
1981	010006	020001			MOV	(R2)+,	R1
1982	010010	001405			CMP	R0,	R1
1983	010012	004767	010314		BEQ	73\$	
1984	010016	004767	011562	72\$:	JSR	PC,	SPRNT2
1985	010022	000007			JSR	PC,	\$ERROR
1986	010024				.WORD	7	
1987	010024	005100		73\$:			
1988	010026	005142			COM	R0	; COMPLEMENT CHECK WORD
1989	010030	012201			COM	-(R2)	; COMPLEMENT TEST DATA
1990	010032	020001			MOV	(R2)+,	R1
1991	010034	001405			CMP	R0,	R1
1992	010036	004767	010270		BEQ	75\$	
1993	010042	004767	011536	74\$:	JSR	PC,	SPRNT2
1994	010046	000007			JSR	PC,	\$ERROR
1995	010050				.WORD	7	
1996	010050	005100		75\$:			
1997	010052	005142			COM	R0	; COMPLEMENT CHECK WORD
1998	010054	012201			COM	-(R2)	; COMPLEMENT TEST DATA
1999	010056	020001			MOV	(R2)+,	R1
2000	010060	001405			CMP	R0,	R1
2001	010062	004767	010244		BEQ	77\$	
2002	010066	004767	011512	76\$:	JSR	PC,	SPRNT2
2003	010072	000007			JSR	PC,	\$ERROR
2004	010074				.WORD	7	
2005	010074	005303		77\$:			
2006	010076	001342			DEC	R3	; DECREMENT 4 WORD COUNTER
2007	010100	005100			BNE	23\$	; BR IF NOT DONE.
2008	010102	005304			COM	R0	; COMPLEMENT CHECK WORD
2009	010104	001335			DEC	R4	; DECREMENT 256. WORD COUNTER
2010	010106	005100			BNE	22\$	; BR IF NOT DONE.
2011	010110	030502			COM	R0	; COMPLEMENT CHECK WORD
2012	010112	001330			BIT	R5,	R2
2013	010114	004767	005030		BNE	21\$	; CHECK FOR END OF A BLOCK.
					JSR	PC,	MMUP
							; FIND NEXT BLOCK AND LOOP TO 21\$.



```

2014
2015
2016
2017 010120
2018 010120 004567 010450
2019 010124 000777
2020
2021 010126 000167 000610
2022
2023 010132 012700 000401
2024 010136 012703 177777
2025 010142 004467 004224
2026 010146 004767 006050
2027 010152 030502
2028 010154 001374
2029 010156 004767 004766
2030
2031
2032
2033
2034 010162 012700 000401
2035 010166 012703 177777
2036 010172 004467 004174
2037 010176 012704 000100
2038 010202
2039 010202 012201
2040 010204 020001
2041 010206 001405
2042 010210 004767 010116
2043 010214 004767 011364
2044 010220 000007
2045 010222
2046 010222 012201
2047 010224 020001
2048 010226 001405
2049 010230 004767 010076
2050 010234 004767 011344
2051 010240 000007
2052 010242
2053 010242 012201
2054 010244 020001
2055 010246 001405
2056 010250 004767 010056
2057 010254 004767 011324
2058 010260 000007
2059 010262
2060 010262 012201
2061 010264 020001
2062 010266 001405
2063 010270 004767 010036
2064 010274 004767 011304
2065 010300 000007
2066 010302
2067 010302 010046
2068 010304 010300
2069 010306 012603

;*****
;TEST 15 MODIFIED 3 XOR 9 PATTERN FOR PARITY MEMORY
;*****
TST15: JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
        .WORD 777 ;MINIMUM BLOCK SIZE OF 256. WORDS
        ;REQUIRED FOR THIS TEST.
        JMP TST16 ;SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
        ;AVAILABLE FOR TEST.
        MOV #401, R0 ;SET UP PARITY "ALL ZEROS" PATTERN
        MOV #-1, R3 ;SET COM DATA REG
        JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$: JSR PC, W3X9 ;WRITE 256. WORD BLOCK WITH 3 XOR 9 PAT.
    BIT R5, R2 ;CHECK FOR END OF A BLOCK.
    BNE 1$ ;BRANCH IF MORE IN CURRENT BLOCK.
    JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

;*****
;CHECK PARITY 3 XOR 9 PATTERN WRITTEN ABOVE.
;*****
        MOV #401, R0 ;RESET PARITY "ALL ZEROS" PATTERN.
        MOV #-1, R3 ;RESET PARITY ALL ONES PATTERN.
        JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
11$: MOV #64., R4 ;SET 256. WORD COUNTER
12$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
    CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    BEQ 65$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
64$: JSR PC, SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
    JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
    .WORD 7 ;ERROR TYPE CODE.
65$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
    CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    BEQ 67$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
66$: JSR PC, SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
    JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
    .WORD 7 ;ERROR TYPE CODE.
67$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
    CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    BEQ 69$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
68$: JSR PC, SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
    JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
    .WORD 7 ;ERROR TYPE CODE.
69$: MOV (R2)+, R1 ;GET THE DATA FROM MEMORY UNDER TEST.
    CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
    BEQ 71$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
70$: JSR PC, SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
    JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
    .WORD 7 ;ERROR TYPE CODE.
71$: MOV R0, -(SP) ;SAVE R0
    MOV R3, R0 ;PUT R3 INTO R0
    MOV (SP)+, R3 ;PUT SAVED R0 INTO R3

```



2070 010310 005304  
2071 010312 001333  
2072 010314 010046  
2073 010316 010300  
2074 010320 012603  
2075 010322 030502  
2076 010324 001324  
2077 010326 004767 004616  
2078  
2079  
2080  
2081  
2082 010332 012700 000401  
2083 010336 012703 177777  
2084 010342 004467 004024  
2085 010346 012704 000100  
2086 010352  
2087 010352 012201  
2088 010354 020001  
2089 010356 001405  
2090 010360 004767 007746  
2091 010364 004767 011214  
2092 010370 000007  
2093 010372  
2094 010372 005100  
2095 010374 005142  
2096 010376 012201  
2097 0 00 020001  
2098 01 02 001405  
2099 01 14 004767 007722  
2100 010410 004767 011170  
2101 010414 000007  
2102 010416  
2103 010416 005100  
2104 010420 005142  
2105 010422 012201  
2106 010424 020001  
2107 010426 001405  
2108 010430 004767 007676  
2109 010434 004767 011144  
2110 010440 000007  
2111 010442  
2112 010442 012201  
2113 010444 020001  
2114 010446 001405  
2115 010450 004767 007656  
2116 010454 004767 011124  
2117 010460 000007  
2118 010462  
2119 010462 005100  
2120 010464 005142  
2121 010466 012201  
2122 010470 020001  
2123 010472 001405  
2124 010474 004767 007632  
2125 010500 004767 011100

```

DEC      R4      ;COUNT 256. WORDS
BNE      12$     ;BRANCH IF MORE
MOV      R0,     -(SP) ;SAVE R0
MOV      R3,     R0   ;PUT R3 INTO R0
MOV      (SP)+,  R3   ;PUT SAVED R0 INTO R3
BIT      R5,     R2   ;CHECK FOR END OF A BLOCK.
BNE      11$     ;BRANCH IF MORE IN CURRENT BLOCK.
JSR      PC,     MMUP ;FIND NEXT BLOCK AND LOOP TO 11$.

;*****
; * CHECK, COM, CHECK, COM, CHECK PARITY 3 XOR 9 PATTERN.
;*****
MOV      #401,   R0   ;SET UP PARITY "ALL ZEROS" PATTERN.
MOV      #-1,    R3   ;SET UP ALL ONES PATTERN.
JSR      R4,     INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
21$:     MOV      #64.,R4 ;SET 256. WORD COUNTER
22$:
MOV      (R2)+,  R1   ;GET THE DATA FROM MEMORY UNDER TEST.
CMP      R0,     R1   ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ      73$      ;BRANCH OVER ERROR CALL IF GOOD DATA.
72$:     JSR      PC,   SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR      PC,   $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
        .WORD    7      ;ERROR TYPE CODE.
73$:
COM      R0      ;COMPLEMENT CHECK WORD
COM      -(R2)   ;COMPLEMENT TEST DATA
MOV      (R2)+,  R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP      R0,     R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ      75$     ;BRANCH OVER ERROR CALL IF GOOD DATA.
74$:     JSR      PC,   SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR      PC,   $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
        .WORD    7      ;ERROR TYPE CODE.
75$:
COM      R0      ;COMPLEMENT CHECK WORD
COM      -(R2)   ;RESTORE DATA
MOV      (R2)+,  R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP      R0,     R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ      77$     ;BRANCH OVER ERROR CALL IF GOOD DATA.
76$:     JSR      PC,   SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR      PC,   $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
        .WORD    7      ;ERROR TYPE CODE.
77$:
MOV      (R2)+,  R1   ;GET THE DATA FROM MEMORY UNDER TEST.
CMP      R0,     R1   ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ      79$      ;BRANCH OVER ERROR CALL IF GOOD DATA.
78$:     JSR      PC,   SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR      PC,   $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
        .WORD    7      ;ERROR TYPE CODE.
79$:
COM      R0      ;COMPLEMENT CHECK WORD
COM      -(R2)   ;COMPLEMENT TEST DATA
MOV      (R2)+,  R1 ;GET THE DATA FROM MEMORY UNDER TEST.
CMP      R0,     R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
BEQ      81$     ;BRANCH OVER ERROR CALL IF GOOD DATA.
80$:     JSR      PC,   SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
JSR      PC,   $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)

```



2126	010504	000007			.WORD 7		; ERROR TYPE CODE.
2127	010506		81\$:		COM RO		; COMPLEMENT CHECK WORD
2128	010506	005100			COM -(R2)		; RESTORE DATA
2129	010510	005142			MOV (R2)+, R1		; GET THE DATA FROM MEMORY UNDER TEST.
2130	010512	012201			CMP RO, R1		; COMPARE THE CHECK WORD WITH THE DATA READ.
2131	010514	020001			BEQ 83\$		; BRANCH OVER ERROR CALL IF GOOD DATA.
2132	010516	001405			JSR PC, SPRT2		; SET UP VALUES FOR ERROR PRINTING.
2133	010520	004767	007606	82\$:	JSR PC, \$ERROR		; *** ERROR *** (GO TYPE A MESSAGE)
2134	010524	004767	011054		.WORD 7		; ERROR TYPE CODE.
2135	010530	000007		83\$:	MOV (R2)+, R1		; GET THE DATA FROM MEMORY UNDER TEST.
2136	010532				CMP RO, R1		; COMPARE THE CHECK WORD WITH THE DATA READ.
2137	010532	012201			BEQ 85\$		; BRANCH OVER ERROR CALL IF GOOD DATA.
2138	010534	020001			JSR PC, SPRT2		; SET UP VALUES FOR ERROR PRINTING.
2139	010536	001405		84\$:	JSR PC, \$ERROR		; *** ERROR *** (GO TYPE A MESSAGE)
2140	010540	004767	007566		.WORD 7		; ERROR TYPE CODE.
2141	010544	004767	011034		COM RO		; COMPLEMENT CHECK WORD
2142	010550	000007		85\$:	COM -(R2)		; COMPLEMENT TEST DATA
2143	010552				MOV (R2)+, R1		; GET THE DATA FROM MEMORY UNDER TEST.
2144	010552	005100			CMP RO, R1		; COMPARE THE CHECK WORD WITH THE DATA READ.
2145	010554	005142			BEQ 87\$		; BRANCH OVER ERROR CALL IF GOOD DATA.
2146	010556	012201			JSR PC, SPRT2		; SET UP VALUES FOR ERROR PRINTING.
2147	010560	020001		86\$:	JSR PC, \$ERROR		; *** ERROR *** (GO TYPE A MESSAGE)
2148	010562	001405			.WORD 7		; ERROR TYPE CODE.
2149	010564	004767	007542		COM RO		; COMPLEMENT CHECK WORD
2150	010570	004767	011010	87\$:	COM -(R2)		; RESTORE DATA
2151	010574	000007			MOV (R2)+, R1		; GET THE DATA FROM MEMORY UNDER TEST.
2152	010576				CMP RO, R1		; COMPARE THE CHECK WORD WITH THE DATA READ.
2153	010576	005100			BEQ 89\$		; BRANCH OVER ERROR CALL IF GOOD DATA.
2154	010600	005142			JSR PC, SPRT2		; SET UP VALUES FOR ERROR PRINTING.
2155	010602	012201		88\$:	JSR PC, \$ERROR		; *** ERROR *** (GO TYPE A MESSAGE)
2156	010604	020001			.WORD 7		; ERROR TYPE CODE.
2157	010606	001405		89\$:	MOV (R2)+, R1		; GET THE DATA FROM MEMORY UNDER TEST.
2158	010610	004767	007516		CMP RO, R1		; COMPARE THE CHECK WORD WITH THE DATA READ.
2159	010614	004767	010764		BEQ 91\$		; BRANCH OVER ERROR CALL IF GOOD DATA.
2160	010620	000007		90\$:	JSR PC, SPRT2		; SET UP VALUES FOR ERROR PRINTING.
2161	010622				JSR PC, \$ERROR		; *** ERROR *** (GO TYPE A MESSAGE)
2162	010622	012201			.WORD 7		; ERROR TYPE CODE.
2163	010624	020001		91\$:	COM RO		; COMPLEMENT CHECK WORD
2164	010626	001405			COM -(R2)		; COMPLEMENT TEST DATA
2165	010630	004767	007476		MOV (R2)+, R1		; GET THE DATA FROM MEMORY UNDER TEST.
2166	010634	004767	010744		CMP RO, R1		; COMPARE THE CHECK WORD WITH THE DATA READ.
2167	010640	000007			BEQ 93\$		; BRANCH OVER ERROR CALL IF GOOD DATA.
2168	010642			92\$:	JSR PC, SPRT2		; SET UP VALUES FOR ERROR PRINTING.
2169	010642	005100			JSR PC, \$ERROR		; *** ERROR *** (GO TYPE A MESSAGE)
2170	010644	005142			.WORD 7		; ERROR TYPE CODE.
2171	010646	012201		93\$:	COM RO		; COMPLEMENT CHECK WORD
2172	010650	020001			COM -(R2)		; RESTORE DATA
2173	010652	001405			MOV (R2)+, R1		; GET THE DATA FROM MEMORY UNDER TEST.
2174	010654	004767	007452		CMP RO, R1		; COMPARE THE CHECK WORD WITH THE DATA READ.
2175	010660	004767	010720				
2176	010664	000007					
2177	010666						
2178	010666	005100					
2179	010670	005142					
2180	010672	012201					
2181	010674	020001					



2182 010676 001405  
2183 010700 004767 007426  
2184 010704 004767 010674  
2185 010710 000007  
2186 010712  
2187 010712 010046  
2188 010714 010300  
2189 010716 012603  
2190 010720 005304  
2191 010722 001213  
2192 010724 010046  
2193 010726 010300  
2194 010730 012603  
2195 010732 030502  
2196 010734 001204  
2197 010736 004767 004206  
2198  
2199  
2200  
2201  
2202 010742  
2203 010742 004567 007626  
2204 010746 000777  
2205  
2206 010750 000167 000610  
2207  
2208 010754 012700 177777  
2209 010760 012703 000401  
2210 010764 004467 003402  
2211 010770 004767 005226  
2212 010774 030502  
2213 010776 001374  
2214 011000 004767 004144  
2215  
2216  
2217  
2218  
2219 011004 012700 177777  
2220 011010 012703 000401  
2221 011014 004467 003352  
2222 011020 012704 000100  
2223 011024  
2224 011024 012201  
2225 011026 020001  
2226 011030 001405  
2227 011032 004767 007274  
2228 011036 004767 010542  
2229 011042 000007  
2230 011044  
2231 011044 012201  
2232 011046 020001  
2233 011050 001405  
2234 011052 004767 007254  
2235 011056 004767 010522  
2236 011062 000007  
2237 011064

```

94$: BEQ 95$ ; BRANCH OVER ERROR CALL IF GOOD DATA.
      JSR PC, SPRNT2 ; SET UP VALUES FOR ERROR PRINTING.
      JSR PC, $ERROR ; *** ERROR *** (GO TYPE A MESSAGE)
      .WORD 7 ; ERROR TYPE CODE.

95$: MOV R0, -(SP) ; SAVE R0
      MOV R3, R0 ; PUT R3 INTO R0
      MOV (SP)+, R3 ; PUT SAVED R0 INTO R3
      DEC R4 ; DECREMENT 256. WORD COUNTER
      BNE 22$ ; BRANCH IF MORE.
      MOV R0, -(SP) ; SAVE R0
      MOV R3, R0 ; PUT R3 INTO R0
      MOV (SP)+, R3 ; PUT SAVED R0 INTO R3
      BIT R5, R2 ; CHECK FOR END OF A BLOCK.
      BNE 21$ ; BRANCH IF MORE IN CURRENT BLOCK.
      JSR PC, MMUP ; FIND NEXT BLOCK AND LOOP TO 21$.

;*****
; *TEST 16 COMPLEMENT PARITY 3 XOR 9 TEST PATTERN.
;*****
TST16: JSR R5, $SCOPE ; GO TO SCOPE ROUTINE.
        .WORD 777 ; MINIMUM BLOCK SIZE OF 256. WORDS
                        REQUIRED FOR THIS TEST.
        JMP TST17 ; SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
                        AVAILABLE FOR TEST.
        MOV #-1, R0 ; SET UP ALL ONES PATTERN
        MOV #401, R3 ; SET UP PARITY "ALL ZEROS" PATTERN
        JSR R4, INITMM ; INITIALIZE THE MEMORY ADDRESS POINTERS.
1$: JSR PC, W3X9 ; WRITE 256. WORD BLOCK WITH 3 XOR 9 PAT.
    BIT R5, R2 ; CHECK FOR END OF A BLOCK.
    BNE 1$ ; BRANCH IF MORE IN CURRENT BLOCK.
    JSR PC, MMUP ; FIND NEXT BLOCK AND LOOP TO 1$.

;*****
; * CHECK COMPLEMENT PARITY 3 XOR 9 PATTERN' WRITTEN ABOVE.
;*****
        MOV #-1, R0 ; SET UP ALL ONES PATTERN
        MOV #401, R3 ; SET UP PARITY "ALL ZEROS" PATTERN
        JSR R4, INITMM ; INITIALIZE THE MEMORY ADDRESS POINTERS.
11$: MOV #64, R4 ; SET 256. WORD COUNTER
12$: MOV (R2)+, R1 ; GET THE DATA FROM MEMORY UNDER TEST.
      CMP R0, R1 ; COMPARE THE CHECK WORD WITH THE DATA READ.
      BEQ 65$ ; BRANCH OVER ERROR CALL IF GOOD DATA.
64$: JSR PC, SPRNT2 ; SET UP VALUES FOR ERROR PRINTING.
      JSR PC, $ERROR ; *** ERROR *** (GO TYPE A MESSAGE)
      .WORD 7 ; ERROR TYPE CODE.

65$: MOV (R2)+, R1 ; GET THE DATA FROM MEMORY UNDER TEST.
      CMP R0, R1 ; COMPARE THE CHECK WORD WITH THE DATA READ.
      BEQ 67$ ; BRANCH OVER ERROR CALL IF GOOD DATA.
66$: JSR PC, SPRNT2 ; SET UP VALUES FOR ERROR PRINTING.
      JSR PC, $ERROR ; *** ERROR *** (GO TYPE A MESSAGE)
      .WORD 7 ; ERROR TYPE CODE.

67$:

```



## M10

CZQMCEO 0-124K MEMORY EXERCISER, 16K VER  
CZQMCE.P11 10-JAN-78 12:56 T16

MACY11 30A(1052) 10-JAN-78 13:12 PAGE 47  
COMPLEMENT PARITY 3 XOR 9 TEST PATTERN.

SEQ 0129

2238	011064	012201		MOV	(R2)+,	R1	;GET THE DATA FROM MEMORY UNDER TEST.
2239	011066	020001		CMP	RO,	R1	;COMPARE THE CHECK WORD WITH THE DATA READ.
2240	011070	001405		BEQ	69\$,		;BRANCH OVER ERROR CALL IF GOOD DATA.
2241	011072	004767	007234	JSR	PC,	SPRNT2	;SET UP VALUES FOR ERROR PRINTING.
2242	011076	004767	010502	JSR	PC,	\$ERROR	;*** ERROR *** (GO TYPE A MESSAGE)
2243	011102	000007		.WORD	7		;ERROR TYPE CODE.
2244	011104						
2245	011104	012201		MOV	(R2)+,	R1	;GET THE DATA FROM MEMORY UNDER TEST.
2246	011106	020001		CMP	RO,	R1	;COMPARE THE CHECK WORD WITH THE DATA READ.
2247	011110	001405		BEQ	71\$,		;BRANCH OVER ERROR CALL IF GOOD DATA.
2248	011112	004767	007214	JSR	PC,	SPRNT2	;SET UP VALUES FOR ERROR PRINTING.
2249	011116	004767	010462	JSR	PC,	\$ERROR	;*** ERROR *** (GO TYPE A MESSAGE)
2250	011122	000007		.WORD	7		;ERROR TYPE CODE.
2251	011124						
2252	011124	010046		MOV	RO,	-(SP)	;SAVE RO
2253	011126	010300		MOV	R3,	RO	;PUT R3 INTO RO
2254	011130	012603		MOV	(SP)+,	R3	;PUT SAVED RO INTO R3
2255	011132	005304		DEC	R4		;COUNT 256. WORDS
2256	011134	001333		BNE	12\$,		;BRANCH IF MORE
2257	011136	010046		MOV	RO,	-(SP)	;SAVE RO
2258	011140	010300		MOV	R3,	RO	;PUT R3 INTO RO
2259	011142	012603		MOV	(SP)+,	R3	;PUT SAVED RO INTO R3
2260	011144	030502		BIT	R5,	R2	;CHECK FOR END OF A BLOCK.
2261	011146	001324		BNE	11\$,		;BRANCH IF MORE IN CURRENT BLOCK.
2262	011150	004767	003774	JSR	PC,	MMLIP	;FIND NEXT BLOCK AND LOOP TO 11\$.
2263							
2264							
2265							
2266							
2267	011154	012700	177777	MOV	#-1,	RO	;SET UP ALL ONES PATTERN
2268	011160	012703	000401	MOV	#401,	R3	;SET UP PARITY "ALL ZEROS" PATTERN
2269	011164	004467	003202	JSR	R4	INITMM	;INITIALIZE THE MEMORY ADDRESS POINTERS.
2270	011170	012704	000100	MOV	#64.,	R4	;SET 256. WORD COUNTER
2271	011174						
2272	011174	012201		MOV	(R2)+,	R1	;GET THE DATA FROM MEMORY UNDER TEST.
2273	011176	020001		CMP	RO,	R1	;COMPARE THE CHECK WORD WITH THE DATA READ.
2274	011200	001405		BEQ	73\$,		;BRANCH OVER ERROR CALL IF GOOD DATA.
2275	011202	004767	007124	JSR	PC,	SPRNT2	;SET UP VALUES FOR ERROR PRINTING.
2276	011206	004767	010372	JSR	PC,	\$ERROR	;*** ERROR *** (GO TYPE A MESSAGE)
2277	011212	000007		.WORD	7		;ERROR TYPE CODE.
2278	011214						
2279	011214	005100		COM	RO		;COMPLEMENT CHECK WORD
2280	011216	005142		COM	-(R2)		;COMPLEMENT TEST DATA
2281	011220	012201		MOV	(R2)+,	R1	;GET THE DATA FROM MEMORY UNDER TEST.
2282	011222	020001		CMP	RO,	R1	;COMPARE THE CHECK WORD WITH THE DATA READ.
2283	011224	001405		BEQ	75\$,		;BRANCH OVER ERROR CALL IF GOOD DATA.
2284	011226	004767	007100	JSR	PC,	SPRNT2	;SET UP VALUES FOR ERROR PRINTING.
2285	011232	004767	010346	JSR	PC,	\$ERROR	;*** ERROR *** (GO TYPE A MESSAGE)
2286	011236	000007		.WORD	7		;ERROR TYPE CODE.
2287	011240						
2288	011240	005100		COM	RO		;COMPLEMENT CHECK WORD
2289	011242	005142		COM	-(R2)		;RESTORE DATA
2290	011244	012201		MOV	(R2)+,	R1	;GET THE DATA FROM MEMORY UNDER TEST.
2291	011246	020001		CMP	RO,	R1	;COMPARE THE CHECK WORD WITH THE DATA READ.
2292	011250	001405		BEQ	77\$,		;BRANCH OVER ERROR CALL IF GOOD DATA.
2293	011252	004767	007054	JSR	PC,	SPRNT2	;SET UP VALUES FOR ERROR PRINTING.

\*\*\*\*\*  
\* CHECK, COM, CHECK, COM CHECK COMPLEMENTED PARITY 3 XOR 9 PATTERN.  
\*\*\*\*\*



2294	011256	004767	010322	JSR	PC,	\$ERROR	*** ERROR *** (GO TYPE A MESSAGE)
2295	011262	000007		.WORD	7		;ERROR TYPE CODE.
2296	011264		77\$:				
2297	011264	012201		MOV	(R2)+,	R1	;GET THE DATA FROM MEMORY UNDER TEST.
2298	011266	020001		CMP	RO	R1	;COMPARE THE CHECK WORD WITH THE DATA READ.
2299	011270	001405		BEQ	79\$		;BRANCH OVER ERROR CALL IF GOOD DATA.
2300	011272	004767	007034	JSR	PC,	SPRNT2	;SET UP VALUES FOR ERROR PRINTING.
2301	011276	004767	010302	JSR	PC,	\$ERROR	*** ERROR *** (GO TYPE A MESSAGE)
2302	011302	000007		.WORD	7		;ERROR TYPE CODE.
2303	011304		79\$:				
2304	011304	005100		COM	RO		;COMPLEMENT CHECK WORD
2305	011306	005142		COM	-(R2)		;COMPLEMENT TEST DATA
2306	011310	012201		MOV	(R2)+,	R1	;GET THE DATA FROM MEMORY UNDER TEST.
2307	011312	020001		CMP	RO	R1	;COMPARE THE CHECK WORD WITH THE DATA READ.
2308	011314	001405		BEQ	81\$		;BRANCH OVER ERROR CALL IF GOOD DATA.
2309	011316	004767	007010	JSR	PC,	SPRNT2	;SET UP VALUES FOR ERROR PRINTING.
2310	011322	004767	010256	JSR	PC,	\$ERROR	*** ERROR *** (GO TYPE A MESSAGE)
2311	011326	000007		.WORD	7		;ERROR TYPE CODE.
2312	011330		81\$:				
2313	011330	005100		COM	RO		;COMPLEMENT CHECK WORD
2314	011332	005142		COM	-(R2)		;RESTORE DATA
2315	011334	012201		MOV	(R2)+,	R1	;GET THE DATA FROM MEMORY UNDER TEST.
2316	011336	020001		CMP	RO	R1	;COMPARE THE CHECK WORD WITH THE DATA READ.
2317	011340	001405		BEQ	83\$		;BRANCH OVER ERROR CALL IF GOOD DATA.
2318	011342	004767	006764	JSR	PC,	SPRNT2	;SET UP VALUES FOR ERROR PRINTING.
2319	011346	004767	010232	JSR	PC,	\$ERROR	*** ERROR *** (GO TYPE A MESSAGE)
2320	011352	000007		.WORD	7		;ERROR TYPE CODE.
2321	011354		83\$:				
2322	011354	012201		MOV	(R2)+,	R1	;GET THE DATA FROM MEMORY UNDER TEST.
2323	011356	020001		CMP	RO	R1	;COMPARE THE CHECK WORD WITH THE DATA READ.
2324	011360	001405		BEQ	85\$		;BRANCH OVER ERROR CALL IF GOOD DATA.
2325	011362	004767	006744	JSR	PC,	SPRNT2	;SET UP VALUES FOR ERROR PRINTING.
2326	011366	004767	010212	JSR	PC,	\$ERROR	*** ERROR *** (GO TYPE A MESSAGE)
2327	011372	000007		.WORD	7		;ERROR TYPE CODE.
2328	011374		85\$:				
2329	011374	005100		COM	RO		;COMPLEMENT CHECK WORD
2330	011376	005142		COM	-(R2)		;COMPLEMENT TEST DATA
2331	011400	012201		MOV	(R2)+,	R1	;GET THE DATA FROM MEMORY UNDER TEST.
2332	011402	020001		CMP	RO	R1	;COMPARE THE CHECK WORD WITH THE DATA READ.
2333	011404	001405		BEQ	87\$		;BRANCH OVER ERROR CALL IF GOOD DATA.
2334	011406	004767	006720	JSR	PC,	SPRNT2	;SET UP VALUES FOR ERROR PRINTING.
2335	011412	004767	010166	JSR	PC,	\$ERROR	*** ERROR *** (GO TYPE A MESSAGE)
2336	011416	000007		.WORD	7		;ERROR TYPE CODE.
2337	011420		87\$:				
2338	011420	005100		COM	RO		;COMPLEMENT CHECK WORD
2339	011422	005142		COM	-(R2)		;RESTORE DATA
2340	011424	012201		MOV	(R2)+,	R1	;GET THE DATA FROM MEMORY UNDER TEST.
2341	011426	020001		CMP	RO	R1	;COMPARE THE CHECK WORD WITH THE DATA READ.
2342	011430	001405		BEQ	89\$		;BRANCH OVER ERROR CALL IF GOOD DATA.
2343	011432	004767	006674	JSR	PC,	SPRNT2	;SET UP VALUES FOR ERROR PRINTING.
2344	011436	004767	010142	JSR	PC,	\$ERROR	*** ERROR *** (GO TYPE A MESSAGE)
2345	011442	000007		.WORD	7		;ERROR TYPE CODE.
2346	011444		89\$:				
2347	011444	012201		MOV	(R2)+,	R1	;GET THE DATA FROM MEMORY UNDER TEST.
2348	011446	020001		CMP	RO	R1	;COMPARE THE CHECK WORD WITH THE DATA READ.
2349	011450	001405		BEQ	91\$		;BRANCH OVER ERROR CALL IF GOOD DATA.



C20MCE0 0-124K MEMORY EXERCISER. 16K VER  
C20MCE P11 10-JAN-78 12:56 T16

MACY11 30A(1052) 10 JAN 78 13:12 PAGE 49  
COMPLEMENT PARITY 3 XOR 9 TEST PATTERN.

SEQ 0131

2350	011452	004767	006654	90\$:	JSR	PC,	SPRNT2	:SET UP VALUES FOR ERROR PRINTING.
2351	011456	004767	010122		JSR	PC,	\$ERROR	:*** ERROR *** (GO TYPE A MESSAGE)
2352	011462	000007			.WORD	7		:ERROR TYPE CODE.
2353	011464			91\$:				
2354	011464	005100			COM	RO		:COMPLEMENT CHECK WORD
2355	011466	005142			COM	-(R2)		:COMPLEMENT TEST DATA
2356	011470	012201			MOV	(R2)+,	R1	:GET THE DATA FROM MEMORY UNDER TEST.
2357	011472	020001			CMP	RO	R1	:COMPARE THE CHECK WORD WITH THE DATA READ.
2358	011474	001405			BEQ	93\$		:BRANCH OVER ERROR CALL IF GOOD DATA.
2359	011476	004767	006630	92\$:	JSR	PC,	SPRNT2	:SET UP VALUES FOR ERROR PRINTING.
2360	011502	004767	010076		JSR	PC,	\$ERROR	:*** ERROR *** (GO TYPE A MESSAGE)
2361	011506	000007			.WORD	7		:ERROR TYPE CODE.
2362	011510			93\$:				
2363	011510	005100			COM	RO		:COMPLEMENT CHECK WORD
2364	011512	005142			COM	-(R2)		:RESTORE DATA
2365	011514	012201			MOV	(R2)+,	R1	:GET THE DATA FROM MEMORY UNDER TEST.
2366	011516	020001			CMP	RO	R1	:COMPARE THE CHECK WORD WITH THE DATA READ.
2367	011522	001405			BEQ	95\$		:BRANCH OVER ERROR CALL IF GOOD DATA.
2368	011522	004767	006604	94\$:	JSR	PC,	SPRNT2	:SET UP VALUES FOR ERROR PRINTING.
2369	011526	004767	010052		JSR	PC,	\$ERROR	:*** ERROR *** (GO TYPE A MESSAGE)
2370	011532	000007			.WORD	7		:ERROR TYPE CODE.
2371	011534			95\$:				
2372	011534	010046			MOV	RO,	-(SP)	:SAVE RO
2373	011536	010300			MOV	R3,	RO	:PUT R3 INTO RO
2374	011540	012603			MOV	(SP)+,	R3	:PUT SAVED RO INTO R3
2375	011542	005304			DEC	R4		:DECREMENT 256. WORD COUNTER
2376	011544	001213			BNE	22\$		:BRANCH IF MORE.
2377	011546	010046			MOV	RO,	-(SP)	:SAVE RO
2378	011550	010300			MOV	R3,	RO	:PUT R3 INTO RO
2379	011552	012603			MOV	(SP)+,	R3	:PUT SAVED RO INTO R3
2380	011554	030502			BIT	R5,	R2	:CHECK FOR END OF A BLOCK.
2381	011556	001204			BNE	21\$		:BRANCH IF MORE IN CURRENT BLOCK.
2382	011560	004767	003364		JSR	PC,	MMUP	:FIND NEXT BLOCK AND LOOP TO 21\$.



```

2383 *****
2384 *TEST 17 WORSE CASE NOISE PARITY BYTE TESTING
2385 * CHECK PARITY MEMORY WITH A SERIES OF BYTE PATTERNS
2386 * 1) FORCE WRONG PARITY IN EACH BYTE OF PARITY MEMORY
2387 * 2) READ IT BACK WITH ACTION ENABLE SET, MAKING SURE THAT A TRAP OCCURS
2388 * 3) WRITE GOOD PARITY AND MAKE SURE NO TRAP OCCURS WHEN IT IS READ
2389 * 4) MAKE SURE THE ERROR ADDRESS BITS (CSR BITS <11-5>) ARE CORRECT
2390 *****
2391 *ST17:
2392 JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
2393 .WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
2394 WWPB0: TST MPRX ;CHECK FOR ANY PARITY MEMORY.
2395 BEQ 1$ ;BR IF NO PARITY MEMORY.
2396 011564 004567 007004 167332 BIT #SW06, 2SWR ;CHECK FOR INHIBIT PARITY SWITCH.
2397 BEQ 2$ ;BR IF NOT SET.
2398 011570 000000 170500 1$: JMP TST20 ;SKIP THIS TEST IF NO PARITY MEMORY PRESENT.
2399 011572 005767 000100 2$: CLR R0 ;ZERO TO BE PUT IN ALL MEMORY.
2400 011576 001404 000622 JSR PC, SETCON ;ROUTINE TO LOAD ALL MEMORY.
2401 011600 032777 004312 JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2402 011606 001402 002544 WWPBYT: BIT PT, PMEMAP ;CHECK IF CURRENT BANK HAS PARITY MEMORY.
2403 011610 000167 167704 BNE 2$ ;BR IF PARITY MEM.
2404 011614 005000 167676 BIT BITPT+2, PMEMAP+2 ;...HI 64K.
2405 011616 004767 004312 BNE 2$ ;BR IF PARITY MEM.
2406 011622 004467 005664 BIS R5, R2 ;POINT TO END OF BLOCK.
2407 011626 036767 005714 INC R2 ;FIRST ADR OF NEXT BLOCK.
2408 011634 001010 000540 JMP WWPB5 ;GO TO FIND NEXT BLOCK.
2409 011636 036767 005664 2$: JSR PC, SETAE ;SET ACTION ENABLE (EVEN IF BANK0.)
2410 011644 001004 005714 JSR PC, CKPMER ;CHECK FOR ANY NON TRAP PARITY ERRORS.
2411 011646 050502 000114 WWPB1: CMP R2, #114 ;CHECK IF POINTING TO PARITY ERROR VECTOR.
2412 011650 005202 000004 BNE 3$ ;BR IF NOT AT VECTOR.
2413 011652 000167 000512 ADD #4, R2 ;SKIP PARITY VECTOR.
2414 011656 004767 000512 JMP WWPB5 ;CHECK FOR BLOCK END.
2415 011662 004767 006342 3$: MOV8 (R2), R1 ;CHECK IF BYTE STILL CLEARED.
2416 011666 020227 007664 BEQ 65$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
2417 011672 001004 000011 64$: JSR PC, SPANT ;SET UP VALUES FOR ERROR PRINTING.
2418 011674 062702 000011 JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
2419 011700 000167 000011 .WORD 11 ;ERROR TYPE CODE.
2420 011722 105067 167632 CLRB OEFLG ;CLEAR ODD/EVEN FLAG.
2421 011726 112700 000252 MOV8 #252, R0 ;SET UP DATA...EVEN, SETS PARITY BIT.
2422 011732 110012 167670 WWPB2: MOV8 R0, (R2) ;MOV DATA INTO TEST LOCATION.
2423 011734 016703 167646 MOV MPRX, R3 ;GET PARITY REGISTER TABLE POINTER.
2424 011740 056773 000000 10$: BIS WWP, 2(R3) ;SET WRITE WRONG PARITY.
2425 011746 052733 000001 BIS #AE, 2(R3)+
2426 011752 005713 TST (R3) ;CHECK FOR TABLE TERMINATOR.
2427 011754 001371 BNE 10$ ;BR IF MORE REGS IN TABLE.
2428 * SET WRONG PARITY IN LOCATION UNDER TEST.
2429 MOV8 R0, (R2) ;WRITE SAME DATA (EXCEPT PARITY) VIA DATOB.
2430 011756 110012 167644 MOV MPRX, R3 ;GET PARITY REG TABLE POINTER.
2431 011760 016703 167622 11$: BIC WWP, 2(R3)+ ;CLEAR WRITE WRONG PARITY.
2432 011764 046733 005713 TST (R3) ;CHECK FOR TABLE TERMINATOR.
2433 011770 005713 167632 000114 BNE 11$ ;BR IF MORE PARITY REGISTERS.
2434 011772 001374 MOV PBTRP, 2#PARVEC ;SET UP VECTOR FOR EXPECTED TRAP.
2435 011774 016737 * DETECT WRONG PARITY VIA DATIP; DATOB SHOULDN'T EXECUTE.
2436 012002 105412 NEGB (R2) ;DATIP (DATOB AND COM PARITY BIT.)
2437 * SHOULD HAVE TRAPPED TO PBTRP.
2438

```



```

2439 012004 016737 167626 000114      MOV    .PESRV, 2*PARVEC ;RESET VECTOR FOR UNEXPECTED TRAPS.
2440 012012 004767 006270 64$:      JSR    PC,    SPRTD ;SET UP VALUES FOR ERROR PRINTING.
2441 012016 004767 007562      JSR    PC,    $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
2442 012022 000012      .WORD 12 ;ERROR TYPE CODE.
2443 012024 000562      BR     WWPB4 ;SKIP TRAP SERVICE.
2444
2445 ;* EXPECTED PARITY MEMORY TRAPS COME HERE.
2446 012026 016737 167604 000114 PBTRP: MOV    .PESRV, 2*PARVEC ;RESET PARITY VECTOR FOR UNEXPECTED TRAPS.
2447 012034 022626      CMP    (SP)+, (SP)+ ;RESET THE STACK POINTER AFTER TRAP.
2448 012036 016703 167564      MOV    .MPRO, R3 ;GET PARITY REG AND MAP TABLE POINTER.
2449 012042 032713 000001 21$:      BIT    #BIT0, (R3) ;CHECK IF THIS REGISTER EXISTS.
2450 012046 001003      BNE     22$ ;BR IF IT DOESN'T EXIST.
2451 012050 017301 000000      MOV    2(R3), R1 ;GET THE CONTENTS.
2452 012054 100413      BMI     23$ ;BR IF ERROR FLAG SET.
2453 012056 062703 000010 22$:      ADD    #10, R3 ;MOVE POINTER TO NEXT REG.
2454 012062 020367 167542      CMP    R3, .MPRX ;CHECK FOR END OF TABLE.
2455 012066 103765      BLO     21$ ;BR IF MORE REGISTERS.
2456 012070 004767 006212 64$:      JSR    PC,    SPRTD ;SET UP VALUES FOR ERROR PRINTING.
2457 012074 004767 007504      JSR    PC,    $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
2458 012100 000013      .WORD 13 ;ERROR TYPE CODE.
2459 012102 000533      BR     WWPB4 ;EXIT AFTER ERROR.
2460 012104 036763 167434 000002 23$:      BIT    BITPT, 2(R3) ;CHECK THE MAP FOR THIS REGISTER.
2461 012112 001011      BNE     24$ ;BR IF THIS REGISTER CONTROLS THIS BANK.
2462 012114 036763 167426 000004      BIT    BITPT+2, 4(R3) ;CHECK THE HI 64K.
2463 012122 001005      BNE     24$ ;BR IF THIS REGISTER CONTROLS THIS BANK.
2464 012124 004767 006152 65$:      JSR    PC,    SPRTD ;SET UP VALUES FOR ERROR PRINTING.
2465 012130 004767 007450      JSR    PC,    $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
2466 012134 000014      .WORD 14 ;ERROR TYPE CODE.
2467 012136
2468 012136 010046      MOV    R0, -(SP) ;PUSH R0 ON STACK
2469 012140 010200      MOV    R2, R0 ;GET THE ADDRESS POINTER.
2470 012142 042700 003777      BIC    #3777, R0 ;CLEAR LOW ADDRESS BITS.
2471 012146 000300      SWAB  R0 ;SHIFT 6 PLACES RIGHT.
2472 012150 006300      ASL    R0
2473 012152 006300      ASL    R0
2474 012154 005767 166426      TST    MMAVA ;CHECK FOR MEM MGMT.
2475 012160 001404      BEQ     25$ ;BR IF NO MEM MGMT.
2476 012162 042700 177600      BIC    #177600, R0 ;CLEAR BANK BITS
2477 012166 063700 172344      ADD    2*SKIPAR2, R0 ;ADD MEM MGMT OFFSET.
2478 012172 052700 100001 25$:      BIS    #BIT15+BIT0, R0 ;SET ERROR AND AE BIT IN CHECK WORD.
2479 012176 016367 000006      MOV    6(R3), RESAVD ;GET APPROPRIATE MASK.
2480 012204 046700 167306      BIC    RESAVD, R0 ;CLEAR PARITY REG BITS RESERVED FOR FUTURE.
2481 012210 046701 167302      BIC    RESAVD, R1 ;CLEAR PARITY REG BITS RESERVED FOR FUTURE.
2482 ;NOTE: THE ABOVE INSTRUCTION (2 WORDS) CAN BE NOP'ED FOR UNMIXED MEMORY TYPES.
2483 012214 020001      CMP    R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
2484 012216 001405      BEQ     67$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
2485 012220 004767 006056 66$:      JSR    PC,    SPRTD ;SET UP VALUES FOR ERROR PRINTING.
2486 012224 004767 007354      JSR    PC,    $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
2487 012230 000015      .WORD 15 ;ERROR TYPE CODE.
2488 012232
2489 012232 005073 000000 67$:      CLR    2(R3) ;CLEAR REG INCLUDING ACTION ENABLE.
2490 012236 010346      MOV    R3, -(SP) ;PUSH R3 ON STACK
2491 012240 062703 000010 26$:      ADD    #10, R3 ;UPDATE POINTER TO NEXT PARITY REG + MAP.
2492 012244 020367 167360      CMP    R3, .MPRX ;CHECK FOR END OF TABLE.
2493 012250 101014      BHI     WWPB3 ;BR IF END OF TABLE REACHED.
2494 012252 032713 000001      BIT    #BIT0, (R3) ;CHECK IF NEXT REG EXISTS.

```



2495	012256	001370		BNE	26\$		;BR IF THIS PARITY REG DOESN'T EXIST.
2496	012260	017301	000000	MOV	2(R3), R1		;SAVE AND CHECK FOR ERROR FLAG.
2497	012264	100365		BPL	26\$		;BR IF NO ERROR FLAG.
2498	012266	004767	006010	68\$: JSR	PC,	SPRNT	;SET UP VALUES FOR ERROR PRINTING.
2499	012272	004767	007306	JSR	PC,	\$ERROR	;*** ERROR *** (GO TYPE A MESSAGE)
2500	012276	000016		.WORD	16		;ERROR TYPE CODE.
2501	012300	000757		BR	26\$		;BR AFTER ERROR.
2502	012302	111204		WWPB3: MOV	(R2), R4		;GET THE DATA FOR CHECKING.
2503				;* READING THE DATA VIA DATI TO CHECK IT SHOULD CAUSE PARITY ERROR, BUT			
2504				;* ACTION ENABLE IS NOT SET IN CONTROLLING REG, SO NO TRAP SHOULD OCCURE.			
2505	012304	111212		MOV	(R2), (R2)		;RESTORE RIGHT PARITY
2506				;NOTE: THE ABOVE INSTRUCTION CAN BE NOP'ED FOR PROCESSORS			
2507				; WHICH DO ONLY DATOB TO DESTINATION OF MOV B INSTRUCTIONS.			
2508	012306	012603		MOV	(SP)+, R3		;POP STACK INTO R3
2509	012310	017301	000000	MOV	2(R3), R1		;READ THE PARITY REGISTER TO CHECK IT AGAIN.
2510	012314	046701	167176	BIC	RESRVD, R1		;CLEAR PARITY REG BITS RESERVED FOR FUTURE.
2511				;NOTE: THE ABOVE INSTRUCTION (2 WORDS) CAN BE NOP'ED FOR UNMIXED MEMORY TYPES.			
2512	012320	042700	000001	BIC	*AE, R0		;CLEAR THE ACTION ENABLE BIT IN TEST DATA.
2513	012324	020001		CMP	R0, R1		;COMPARE THE CHECK WORD WITH THE DATA READ.
2514	012326	001405		BEQ	65\$		;BRANCH OVER ERROR CALL IF GOOD DATA.
2515	012330	004767	005746	64\$: JSR	PC,	SPRNT	;SET UP VALUES FOR ERROR PRINTING.
2516	012334	004767	007244	JSR	PC,	\$ERROR	;*** ERROR *** (GO TYPE A MESSAGE)
2517	012340	000015		.WORD	15		;ERROR TYPE CODE.
2518	012342			65\$: MOV	*1, 2(R3)		;CLEAR ALL BUT ACTION ENABLE.
2519	012342	012773	000001 000000	MOV	R4, R1		;GET DATA READ FROM MEMORY FOR TESTING.
2520	012350	010401		MOV	(SP)+, R0		;POP STACK INTO R0
2521	012352	012600		CMPB	R0, R1		;CHECK THE DATA.
2522	012354	120001		BEQ	67\$		;BRANCH OVER ERROR CALL IF GOOD DATA.
2523	012356	001405		66\$: JSR	PC,	SPRNT	;SET UP VALUES FOR ERROR PRINTING.
2524	012360	004767	005722	JSR	PC,	\$ERROR	;*** ERROR *** (GO TYPE A MESSAGE)
2525	012364	004767	007214	.WORD	17		;ERROR TYPE CODE.
2526	012370	000017		67\$: MOV	R0, (R2)		;RESTORE DATA.
2527	012372			WWPB4: TSTB	(R2)		;DO A DATI TO BE SURE RIGHT PARITY.
2528	012372	110012		MOV	*253, R0		;SET ODD PARITY DATA.
2529	012374	105712		COMB	OEFLG		;CHECK IF DONE BOTH ODD AND EVEN PARITY.
2530	012376	012700	000253	BPL	27\$		;BR IF DONE BOTH EVEN AND ODD.
2531	012402	105167	167152	JMP	WWPB2		;LOOP BACK AND DO ODD(PARITY BIT CLR).
2532	012406	100002		27\$: INC	R2		;MOVE POINTER TO NEXT MEMORY BYTE.
2533	012410	000167	177316	WWPB5: BIT	R5, R2		;CHECK FOR END OF BLOCK.
2534	012414	005202		BEQ	30\$		;BR IF END OF BLOCK FOUND.
2535	012416	030502		JMP	WWPB1		;LOOP BACK TO TEST NEXT BYTE.
2536	012420	001402		30\$: JSR	PC,	MMUP	;FIND NEXT BLOCK AND LOOP TO WWPBYT
2537	012422	000167	177240	JSR	PC,	MAMF	;GO RESET PARITY REGISTERS.
2538	012426	004767	002516				
2539	012432	004767	005044				



```

2540      ;*****
2541      ;*TEST 20      RANDOM DATA TESTING THRU PROGRAM CODE RELOCATION.
2542      ;*****
2543      TST20:
2544      JSR      R5,      $SCOPE      ;GO TO SCOPE ROUTINE.
2545      .WORD    0              ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
2546      RANTST: MOV      PC,      R3      ;GET CURRENT PROGRAM COUNTER.
2547      BIC      #7777, R3      ;POINT TO BEGINNING OF CURRENT 2K BLOCK.
2548      JSR      R4,      INITMM      ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2549      1$:      MOV      R2,      -(SP)      ;SAVE MEMORY POINTER.
2550      MOV      R3,      -(SP)      ;SAVE "DATA" POINTER.
2551      2$:      MOV      (R3)+, (R2)+      ;MOV CODE INTO TEST MEMORY.
2552      BIT      #7777, R3      ;CHECK FOR END OF "DATA TABLE"
2553      BNE      3$              ;BRANCH IF MORE
2554      SUB      #10000, R3      ;RESET POINTER TO START OF "RANDOM DATA"
2555      3$:      BIT      R5,      R2      ;CHECK FOR END OF BLOCK
2556      BNE      2$              ;BRANCH IF MORE
2557      MOV      (SP)+, R3      ;RESET "DATA" POINTER.
2558      MOV      (SP)+, R2      ;RESET MEMORY POINTER.
2559      4$:      MOV      (R3)+, R0      ;GET S/B DATA.
2560      MOV      (R2)+, R1      ;GET THE DATA FROM MEMORY UNDER TEST.
2561      CMP      R0,      R1      ;COMPARE THE CHECK WORD WITH THE DATA READ.
2562      BEQ      65$              ;BRANCH OVER ERROR CALL IF GOOD DATA.
2563      64$:      JSR      PC,      SPRT2      ;SET UP VALUES FOR ERROR PRINTING.
2564      JSR      PC,      $ERROR      ;*** ERROR *** (GO TYPE A MESSAGE)
2565      .WORD    20              ;ERROR TYPE CODE.
2566      65$:      BIT      #7777, R3      ;CHECK FOR END OF "DATA TABLE"
2567      BNE      5$              ;BR IF MORE.
2568      SUB      #10000, R3      ;RESET POINTER TO TOP OF "DATA TABLE".
2569      5$:      BIT      R5,      R2      ;CHECK FOR END OF A BLOCK.
2570      BNE      4$              ;BRANCH IF MORE IN CURRENT BLOCK.
2571      JSR      PC,      MMUP      ;FIND NEXT BLOCK AND LOOP TO 1$.
2572
2573

```



```

2574 .SBTTL SECTION 3: INSTRUCTION EXECUTION TESTS.
2575 *****
2576 *TEST 21 EXECUTE DATA, DATA THRU MEMORY.
2577 * EXECUTE THE INSTRUCTION 'MOV R4,(R2)' THROUGHOUT MEMORY.
2578 * AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'MOV' INSTRUCTION TO RETURN
2579 * CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
2580 * THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:
2581 *
2582 *          MEMORY LOCATION      INSTRUCTION      CONTENTS OF MEMORY LOCATION
2583 *          LOCATION            PLACED THERE      AFTER INSTRUCTION EXECUTION
2584 *
2585 * 1ST PASS / 40000             010412             000205
2586 * THRU TEST / 40002           000205             000205
2587 *
2588 * 2ND PASS / 40002             010412             000205
2589 * THRU TEST / 40004           000205             000205
2590 *
2591 * ETC., ETC., ETC.
2592 *
2593 * R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
2594 * R1 = DATA READ FROM MEMORY (WAS).
2595 * R2 = ADDRESS OF IUT/DATA.
2596 * R3 = INSTRUCTION UNDER TEST (IUT).
2597 * R4 = RTS R5 (CODE 205).
2598 * R5 = BLOCK BOUNDARY BIT MASK.
2599 *****
2600 ST21: JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
2601 .WORD 3 ;MINIMUM BLOCK SIZE OF 2 WORDS
2602 ;REQUIRED FOR THIS TEST.
2603 JMP TST22 ;SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
2604 ;AVAILABLE FOR TEST.
2605 D1D0: MOV #010412,R3 ;GET 'MOV R4,(R2)' INSTRUCTION (IUT).
2606 MOV #205,R4 ;GET 'RTS R5'
2607 MOV R4,R0 ;SET UP S/B DATA AFTER EXECUTION.
2608 JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2609 1$: MOV R3,(R2)+ ;PUT IUT INTO FIRST LOC OF BLOCK.
2610 2$: MOV R4,(R2) ;PUT 'RTS R5' FOLLOWING IUT.
2611 JSR R5,-(R2) ;GO EXECUTE THE IUT.
2612 MOV (R2)+,R1 ;GET THE DATA FROM THE MEM ADR UNDER TEST.
2613 CMP R0,R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
2614 BEQ 65$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
2615 64$: JSR PC, SPANT3 ;SET UP VALUES FOR ERROR PRINTING.
2616 JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
2617 .WORD 21 ;ERROR TYPE CODE.
2618 65$: MOV R3,(R2)+ ;PUT THE IUT INTO THE NEXT LOCATION.
2619 BIT R5,R2 ;CHECK FOR END OF A BLOCK.
2620 BNE 2$ ;BRANCH IF MORE IN CURRENT BLOCK.
2621 JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.
2622
2623

```



## H11

CZQMCEO 0-124K MEMORY EXERCISER, 16K VER  
CZQMCE.P11 10-JAN-78 12:56 T22

MACY11 30A(1052) 10-JAN-78 13:12 PAGE 55  
EXECUTE DATI, DATOB (LOW BYTE) THRU MEMORY.

SEQ 0137

2624  
2625  
2626  
2627  
2628  
2629  
2630  
2631  
2632  
2633  
2634  
2635  
2636  
2637  
2638  
2639  
2640  
2641  
2642  
2643  
2644  
2645  
2646  
2647  
2648  
2649 012642  
2650 012642 004567 005726  
2651 012646 000003  
2652  
2653 012650 000167 000060  
2654  
2655 012654 012703 110412  
2656 012660 012704 000205  
2657 012664 012700 110605  
2658 012670 004467 001476  
2659 012674 010322  
2660 012676 010412  
2661 012700 004542  
2662 012702 012201  
2663 012704 020001  
2664 012706 001405  
2665 012710 004767 005412  
2666 012714 004767 006664  
2667 012720 000021  
2668 012722  
2669 012722 010322  
2670 012724 030502  
2671 012726 001363  
2672 012730 004767 002214

```

*****
*TEST 22 EXECUTE DATI, DATOB (LOW BYTE) THRU MEMORY.
* EXECUTES THE INSTRUCTION 'MOVB R4 (R2)' THROUGHOUT MEMORY.
* AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'MOVB' INSTRUCTION TO RETURN
* CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
* THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:
*
*          MEMORY          INSTRUCTION          CONTENTS OF MEMOFY LOCATION
*          LOCATION        PLACED THERE        AFTER INSTRUCTION EXECUTION
*
* 1ST PASS / 40000        110412              110605
* THRU TEST / 40002        000205              000205
*
* 2ND PASS / 40002        110412              110605
* THRU TEST / 40004        000205              000205
*
*      ETC., ETC., ETC.
*
* R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
* R1 = DATA READ FROM MEMORY (WAS).
* R2 = ADDRESS OF IUT/DATA.
* R3 = INSTRUCTION UNDER TEST (IUT).
* R4 = RTS R5 (CODE 205).
* R5 = BLOCK BOUNDARY BIT MASK.
*****
TST22: JSR      R5,      $SCOPE ;GO TO SCOPE ROUTINE.
        .WORD      3          ;MINIMUM BLOCK SIZE OF 2 WORDS
                                ;REQUIRED FOR THIS TEST.
        JMP      TST23        ;SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
                                ;AVAILABLE FOR TEST.
DIDBL: MOV      #110412,R3     ;GET 'MOVB R4,(R2)' INSTRUCTION (IUT).
        MOV      #205,R4      ;GET 'RTS R5'.
        MOV      #110605,R0    ;SET UP S/B DATA AFTER EXECUTION.
        JSR      R4,          ;INITIALIZE THE MEMORY ADDRESS POINTERS.
                                ;PUT IUT INTO FIRST LOC OF BLOCK.
1$: MOV      R3,          (R2)+ ;PUT 'RTS R5' FOLLOWING IUT.
2$: MOV      R4,          (R2)  ;GO EXECUTE THE IUT.
        JSR      R5,          -(R2) ;GET THE DATA FROM THE MEM ADR UNDER TEST.
        MOV      (R2)+, R1      ;COMPARE THE CHECK WORD WITH THE DATA READ.
        CMP      R0, R1        ;BRANCH OVER ERROR CALL IF GOOD DATA.
        BEQ      65$          ;SET UP VALUES FOR ERROR PRINTING.
64$: JSR      PC,          SPRT3 ;*** ERROR *** (GO TYPE A MESSAGE)
        JSR      PC,          $ERROR ;ERROR TYPE CODE.
        .WORD      21
65$: MOV      R3,          (R2)+ ;PUT THE IUT INTO THE NEXT LOCATION.
        BIT      R5, R2        ;CHECK FOR END OF A BLOCK.
        BNE      2$,          ;BRANCH IF MORE IN CURRENT BLOCK.
        JSR      PC,          MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

```



2673  
2674  
2675  
2676  
2677  
2678  
2679  
2680  
2681  
2682  
2683  
2684  
2685  
2686  
2687  
2688  
2689  
2690  
2691  
2692  
2693  
2694  
2695  
2696  
2697  
2698 012734  
2699 012734 004567 005634  
2700 012740 000003  
2701  
2702 012742 000167 000064  
2703  
2704 012746 012703 110342  
2705 012752 012704 000205  
2706 012756 012700 161342  
2707 012762 004467 001404  
2708 012766 010322  
2709 012770 010412  
2710 012772 001562 177776  
2711 012776 005302  
2712 013000 012201  
2713 013002 020001  
2714 013004 001405  
2715 013006 004767 005314  
2716 013012 004767 006566  
2717 013016 000021  
2718 013020  
2719 013020 010322  
2720 013022 030502  
2721 013024 001361  
2722 013026 004767 002116

```

*****
TEST 23 EXECUTE DATI, DATOB (HIGH BYTE) THRU MEMORY.
EXECUTES THE INSTRUCTION 'MOVB R3, -(R2)' THROUGHOUT MEMORY.
AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'MOVB' INSTRUCTION TO RETURN
CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:

      MEMORY      INSTRUCTION      CONTENTS OF MEMORY LOCATION
      LOCATION    PLACED THERE    AFTER INSTRUCTION EXECUTION

1ST PASS / 40000      110342      161342
THRU TEST / 40002      000205      000205

2ND PASS / 40002      110342      161342
THRU TEST / 40004      000205      000205

      ETC., ETC., ETC.

R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
R1 = DATA READ FROM MEMORY (WAS).
R2 = ADDRESS OF IUT/DATA.
R3 = INSTRUCTION UNDER TEST (IUT).
R4 = RTS R5 (CODE 205).
R5 = BLOCK BOUNDARY BIT MASK.
*****
TST23: JSR      R5,      $SCOPE ; GO TO SCOPE ROUTINE.
        .WORD      3          ; MINIMUM BLOCK SIZE OF 2 WORDS
                                ; REQUIRED FOR THIS TEST.
        JMP      TST24        ; SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
                                ; AVAILABLE FOR TEST.
DIDBH: MOV      #110342, R3    ; GET 'MOVB R3, -(R2)' INSTRUCTION (IUT).
        MOV      #205, R4      ; GET 'RTS R5'
        MOV      #161342, R0    ; SET UP S/B DATA AFTER EXECUTION.
        JSR      R4,      INITMM ; INITIALIZE THE MEMORY ADDRESS POINTERS.
1$:     MOV      R3,      (R2)+ ; PUT IUT INTO FIRST LOC OF BLOCK.
2$:     MOV      R4,      (R2)   ; PUT 'RTS R5' FOLLOWING IUT.
        JSR      R5,      -2(R2) ; GO EXECUTE THE IUT.
        DEC      R2            ; ADJUST R2 TO POINT TO MAUT.
        MOV      (R2)+, R1      ; GET THE DATA FROM THE MEM ADR UNDER TEST.
        CMP      R0, R1        ; COMPARE THE CHECK WORD WITH THE DATA READ.
        BEQ      65$          ; BRANCH OVER ERROR CALL IF GOOD DATA.
64$:    JSR      PC,      SPRT3  ; SET UP VALUES FOR ERROR PRINTING.
        JSR      PC,      $ERROR ; *** ERROR *** (GO TYPE A MESSAGE)
        .WORD      21          ; ERROR TYPE CODE.
65$:    MOV      R3,      (R2)+ ; PUT THE IUT INTO THE NEXT LOCATION.
        BIT      R5,      R2    ; CHECK FOR END OF A BLOCK.
        BNE      2$          ; BRANCH IF MORE IN CURRENT BLOCK.
        JSR      PC,      MMUP  ; FIND NEXT BLOCK AND LOOP TO 1$.

```



# J11

CZQMCEO 0-124K MEMORY EXERCISER, 16K VER  
CZQMCE.P11 10-JAN-78 12:56 T24

MACY11 30A(1052) 10-JAN-78 13:12 PAGE 57  
EXECUTE DATI, DATIP, DATO THRU MEMORY.

SEQ 0139

2723  
2724  
2725  
2726  
2727  
2728  
2729  
2730  
2731  
2732  
2733  
2734  
2735  
2736  
2737  
2738  
2739  
2740  
2741  
2742  
2743  
2744  
2745  
2746  
2747  
2748 013032  
2749 013032 004567 005536  
2750 013036 000003  
2751  
2752 013040 000167 000060  
2753  
2754 013044 012703 005412  
2755 013050 012704 000205  
2756 013054 012700 172366  
2757 013060 004467 001306  
2758 013064 010322  
2759 013066 010412  
2760 013070 004542  
2761 013072 12201  
2762 013074 020001  
2763 013076 001405  
2764 013100 004767 005222  
2765 013104 004767 006474  
2766 013110 000021  
2767 013112  
2768 013112 010322  
2769 013114 030502  
2770 013116 001363  
2771 013120 004767 002024

```

*****
TEST 24 EXECUTE DATI, DATIP, DATO THRU MEMORY.
EXECUTES THE INSTRUCTION 'NEG (R2)' THROUGHOUT MEMORY.
AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'NEG' INSTRUCTION TO RETURN
CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:

      MEMORY      INSTRUCTION      CONTENTS OF MEMORY LOCATION
      LOCATION    PLACED THERE      AFTER INSTRUCTION EXECUTION

1ST PASS / 40000      005412      172366
THRU TEST / 40002      000205      000205

2ND PASS / 40002      005412      172366
THRU TEST / 40004      000205      000205

      ETC., ETC., ETC.

R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
R1 = DATA READ FROM MEMORY (WAS).
R2 = ADDRESS OF IUT/DATA.
R3 = INSTRUCTION UNDER TEST (IUT).
R4 = RTS R5 (CODE 205).
R5 = BLOCK BOUNDARY BIT MASK.
*****
TST24: JSR      R5,      $SCOPE ;GO TO SCOPE ROUTINE.
        .WORD    3          ;MINIMUM BLOCK SIZE OF 2 WORDS
        ;REQUIRED FOR THIS TEST.
        JMP      TST25      ;SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
        ;AVAILABLE FOR TEST.
DIP00: MOV      #005412,R3    ;GET 'NEG (R2)' INSTRUCTION (IUT).
        MOV      #205, R4    ;GET 'RTS R5'
        MOV      #172366,R0  ;SET UP S/B DATA AFTER EXECUTION.
        JSR      R4,      INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$: MOV      R3,      (R2)+ ;PUT IUT INTO FIRST LOC OF BLOCK.
2$: MOV      R4,      (R2)  ;PUT 'RTS R5' FOLLOWING IUT.
        JSR      R5,      -(R2) ;GO EXECUTE THE IUT.
        MOV      (R2)+, R1    ;GET THE DATA FROM THE MEM ADR UNDER TEST.
        CMP      R0,      R1    ;COMPARE THE CHECK WORD WITH THE DATA READ.
        BEQ      65$          ;BRANCH OVER ERROR CALL IF GOOD DATA.
64$: JSR      PC,      SPRNT3 ;SET UP VALUES FOR ERROR PRINTING.
        JSR      PC,      $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
        .WORD    21          ;ERROR TYPE CODE.
65$: MOV      R3,      (R2)+ ;PUT THE IUT INTO THE NEXT LOCATION.
        BIT      R5,      R2    ;CHECK FOR END OF A BLOCK.
        BNE      2$          ;BRANCH IF MORE IN CURRENT BLOCK.
        JSR      PC,      MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

```



2772  
2773  
2774  
2775  
2776  
2777  
2778  
2779  
2780  
2781  
2782  
2783  
2784  
2785  
2786  
2787  
2788  
2789  
2790  
2791  
2792  
2793  
2794  
2795  
2796  
2797 013124  
2798 013124 004567 005444  
2799 013130 000003  
2800  
2801 013132 000167 000060  
2802  
2803 013136 012703 142242  
2804 013142 012704 000205  
2805 013146 012700 142000  
2806 013152 004467 001214  
2807 013156 010322  
2808 013160 010412  
2809 013162 004542  
2810 013164 012201  
2811 013166 020001  
2812 013170 001405  
2813 013172 004767 005130  
2814 013176 004767 006402  
2815 013202 000021  
2816 013204  
2817 013204 010322  
2818 013206 030502  
2819 013210 001363  
2820 013212 004767 001732

```

*****
TEST 25      EXECUTE DATI, DATI, DATIP, DATOB (LOW BYTE) THRU MEMORY.
* EXECUTES THE INSTRUCTION BICB (R2)+, -(R2)' THROUGHOUT MEMORY.
* AN 'RTS R5' (CODE 205) IS PLACED AFTER THE BICB' INSTRUCTION TO RETURN
* CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
* THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:
*
*          MEMORY LOCATION      INSTRUCTION      CONTENTS OF MEMORY LOCATION
*          PLACED THERE          AFTER INSTRUCTION EXECUTION
*
* 1ST PASS / 40000              142242              142000
* THRU TEST / 40002              000205              000205
*
* 2ND PASS / 40002              142242              142000
* THRU TEST / 40004              000205              000205
*
*      ETC., ETC., ETC.
*
* R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
* R1 = DATA READ FROM MEMORY (WAS).
* R2 = ADDRESS OF IUT/DATA.
* R3 = INSTRUCTION UNDER TEST (IUT).
* R4 = RTS R5 (CODE 205).
* R5 = BLOCK BOUNDARY BIT MASK.
*****
TST25:      JSR      R5,      $SCOPE      ;GO TO SCOPE ROUTINE.
              .WORD      3              ;MINIMUM BLOCK SIZE OF 2 WORDS
              ;REQUIRED FOR THIS TEST.
              JMP      TST26              ;SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
              ;AVAILABLE FOR TEST.
DPDBL:      MOV      #142242, R3          ;GET BICB (R2)+, -(R2)' INSTRUCTION (IUT).
              MOV      #205, R4           ;GET 'RTS R5'
              MOV      #142000, R0        ;SET UP S/B DATA AFTER EXECUTION.
              JSR      R4,      INITMM    ;INITIALIZE THE MEMORY ADDRESS POINTERS.
              1$:     MOV      R3,      (R2)+ ;PUT IUT INTO FIRST LOC OF BLOCK.
              2$:     MOV      R4,      (R2) ;PUT 'RTS R5' FOLLOWING IUT.
              JSR      R5,      -(R2)     ;GO EXECUTE THE IUT.
              MOV      (R2)+, R1          ;GET THE DATA FROM THE MEM ADR UNDER TEST.
              CMP      R0, R1             ;COMPARE THE CHECK WORD WITH THE DATA READ.
              BEQ      65$               ;BRANCH OVER ERROR CALL IF GOOD DATA.
              64$:     JSR      PC,      SPRNT3 ;SET UP VALUES FOR ERROR PRINTING.
              JSR      PC,      $ERROR    ;*** ERROR *** (GO TYPE A MESSAGE)
              .WORD      21              ;ERROR TYPE CODE.
              65$:     MOV      R3,      (R2)+ ;PUT THE IUT INTO THE NEXT LOCATION.
              BIT      R5, R2             ;CHECK FOR END OF A BLOCK.
              BNE      2$                ;BRANCH IF MORE IN CURRENT BLOCK.
              JSR      PC,      MMUP      ;FIND NEXT BLOCK AND LOOP TO 1$.

```



```

2821
2822
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834
2835
2836
2837
2838
2839
2840
2841
2842
2843
2844
2845
2846 013216
2847 013216 004567 005352
2848 013222 000003
2849
2850 013224 000167 000062
2851
2852 013230 012703 152212
2853 013234 012704 000205
2854 013240 012700 157212
2855 013244 004467 001122
2856 013250 010322
2857 013252 010412
2858 013254 004542
2859 013256 005302
2860 013260 012201
2861 013262 020001
2862 013264 001405
2863 013266 004767 005034
2864 013272 004767 006306
2865 013276 000021
2866 013300
2867 013300 010322
2868 013302 030502
2869 013304 001362
2870 013306 004767 001636

```

```

*****
TEST 26 EXECUTE DATI, DATI, DATIP, DATOB (HIGH BYTE) THRU MEMORY.
EXECUTES THE INSTRUCTION 'BISB (R2)+, (R2)' THROUGHOUT MEMORY.
AN 'RTS R5' (CODE 205) IS PLACED AFTER THE 'BISB' INSTRUCTION TO RETURN
CONTROL TO THE MAIN PROGRAM FOR INSTRUCTION EXECUTION CHECKOUT.
THIS IS AN EXAMPLE OF WHAT THIS TEST DOES IN RELATION TO MEMORY:

      MEMORY LOCATION      INSTRUCTION      CONTENTS OF MEMORY LOCATION
      PLACED THERE      AFTER INSTRUCTION EXECUTION

1ST PASS / 40000      152212      157212
THRU TEST / 40002      000205      000205

2ND PASS / 40002      152212      157212
THRU TEST / 40004      000205      000205

ETC., ETC., ETC.

R0 = DATA WRITTEN ON TOP OF IUT BY THE IUT (SHOULD BE).
R1 = DATA READ FROM MEMORY (WAS).
R2 = ADDRESS OF IUT/DATA.
R3 = INSTRUCTION UNDER TEST (IUT).
R4 = RTS R5 (CODE 205).
R5 = BLOCK BOUNDARY BIT MASK.
*****
TST26: JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
        .WORD 3 ;MINIMUM BLOCK SIZE OF 2 WORDS
        ;REQUIRED FOR THIS TEST.
        JMP TST27 ;SKIP TO NEXT TEST WHEN LESS THAN ONE BLOCK
        ;AVAILABLE FOR TEST.
DPDBH: MOV #152212, R3 ;GET 'BISB (R2)+, (R2)' INSTRUCTION (IUT).
        MOV #205, R4 ;GET 'RTS R5'
        MOV #157212, R0 ;SET UP S/B DATA AFTER EXECUTION.
        JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
1$: MOV R3, (R2)+ ;PUT IUT INTO FIRST LOC OF BLOCK.
2$: MOV R4, (R2) ;PUT 'RTS R5' FOLLOWING IUT.
        JSR R5, -(R2) ;GO EXECUTE THE IUT.
        DEC R2 ;RESET R2 TO POINT TO IUT.
        MOV (R2)+, R1 ;GET THE DATA FROM THE MEM ADR UNDER TEST.
        CMP R0, R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
        BEQ 65$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
64$: JSR PC, SPRT3 ;SET UP VALUES FOR ERROR PRINTING.
        JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
        .WORD 21 ;ERROR TYPE CODE.
65$: MOV R3, (R2)+ ;PUT THE IUT INTO THE NEXT LOCATION.
        BIT R5, R2 ;CHECK FOR END OF A BLOCK.
        BNE 2$ ;BRANCH IF MORE IN CURRENT BLOCK.
        JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.

```



```

2871 .SBTTL SECTION 4:MOS TESTS
2872 *****
2873 *TEST 27 MARCHING 1'S AND 0'S.
2874 * THIS TEST IS DESIGNED TO STRESS MOS MEMORIES.
2875 * STARTING AT THE BOTTOM ADDRESS AND ADDRESSING UPWARDS A 4K BANK IS
2876 * WRITTEN WITH 000377 THEN STARTING AT THE TOP ADDRESS OF THE BANK THE
2877 * 000377 IS READ THE BYTES ARE SWAPPED TO 177400 AND THE LOCATION
2878 * REREAD TO CONFIRM THE WRITE. THIS IS REPEATED FOR EVERY LOCATION
2879 * ADDRESSED DOWNWARD UNTIL THE BOTTOM IS REACHED. STARTING AT THE
2880 * BOTTOM EACH LOCATION IS READ FOR 177400 THE BYTES ARE SWAPPED TO
2881 * 000377 AND REREAD TO CONFIRM THE WRITE UNTIL THE TOP ADDRESS OF THE
2882 * BANK IS REACHED. AGAIN STARTING AT THE BOTTOM EACH LOCATION IS READ
2883 * FOR 000377 THE BYTES SWAPPED TO 177400 AND THE LOCATION REREAD TO
2884 * CONFIRM THE WRITE. LASTLY STARTING FROM THE TOP AND ADDRESSING DOWN-
2885 * WARD EACH LOCATION IS READ THE BYTES SWAPPED TO 000377 AND THE
2886 * LOCATION IS REREAD TO CONFIRM THE WRITE. THIS IS REPEATED FOR EVERY
2887 * 4K BANK UNDER TEST.
2888 *
2889 * R0=DATA WRITTEN INTO MEMORY(SHOULD BE)
2890 * R1=DATA READ FROM MEMORY(WAS)
2891 * R2=VIRTUAL ADDRESS
2892 * R3=TIMES THROUGH COUNTER
2893 * R4=NOT USED
2894 * R5=BLOCK BOUNDARY BIT MASK.
2895 *****
2896 TST27:
2897 JSR R5, $SCOPE ;GO TO SCOPE ROUTINE.
2898 .WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
2899 JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
2900 MOV R2,TEMP ;SAVE BANK STARTING ADDRESS
2901 CLR R3 ;CLEAR PASS COUNTER
2902 MOV #000377,R0 ;SETUP TO WRITE PATTERN
2903 MOV R0,(R2)+ ;WRITE PATTERN
2904 BIT R5,R2 ;END OF 4K?
2905 BNE 2$ ;CONTINUE WRITING IF NO.
2906 MOV -(R2),R1 ;GET DATA WRITTEN
2907 CMP R0,R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
2908 BEQ 65$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
2909 JSR PC, SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
2910 JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
2911 .WORD 10 ;ERROR TYPE CODE.
2912 65$:
2913 SWAB R0 ;SWAP BYTES OF DATA
2914 MOV R0,(R2) ;WRITE SWAPPED WORD
2915 MOV (R2),R1 ;GET DATA WRITTEN
2916 CMP R0,R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.
2917 BEQ 67$ ;BRANCH OVER ERROR CALL IF GOOD DATA.
2918 JSR PC, SPRT2 ;SET UP VALUES FOR ERROR PRINTING.
2919 JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
2920 .WORD 10 ;ERROR TYPE CODE.
2921 67$:
2922 SWAB R0 ;PUT DATA BACK TO ORIGINAL
2923 TST R3 ;IF ON PASS 0 OR PASS 3
2924 BEQ 5$ ;WE ARE ADDRESSING DOWN
2925 CMP R3,#3 ;IF ON PASS 1 OR 2 GO TO
2926 BNE 6$ ;UPWARD

```



2927 013424 030502  
2928 013426 001346  
2929 013430 005203  
2930 013432 022703 000004  
2931 013436 001427  
2932 013440 000300  
2933 013442 000404  
2934 013444 062702 000002  
2935 013450 030502  
2936 013452 001411  
2937 013454 011201  
2938 013456 020001  
2939 013460 001405  
2940 013462 004767 004644  
2941 013466 004767 006112  
2942 013472 000010  
2943 013474  
2944 013474 000733  
2945 013476 005203  
2946 013500 000300  
2947 013502 020327 000002  
2948 013506 001316  
2949 013510 016702 166100  
2950 013514 000757  
2951 013516 004467 000650  
2952 013522 004767 001422  
2953  
2954  
2955  
2956  
2957  
2958  
2959  
2960  
2961  
2962  
2963  
2964  
2965  
2966  
2967 013526  
2968 013526 004567 005042  
2969 013532 000000  
2970 013534 004467 000632  
2971 013540 012700 125252  
2972 013544 010022  
2973 013546 005100  
2974 013550 030502  
2975 013552 001374  
2976 013554 004767 C 1370  
2977 013560 005003  
2978 013562 012704 000046  
2979 013566 005303  
2980 013570 001376  
2981 013572 005304  
2982 013574 001374

5\$: BIT R5,R2 ;DONE A PASS?  
BNE 3\$ ;IF NO CONTINUE  
INC R3 ;IF YES INCREMENT PASS COUNTER  
CMP #4,R3 ;ARE WE DONE ALL PASSES FOR THIS 4K?  
BEQ 9\$ ;IF YES BRANCH  
SWAB R0 ;ELSE SET UP NEW READ WORD  
BR 7\$ ;GO TO START OF ADDRESS UP  
6\$: ADD #2,R2 ;UPDATE TO NEXT ADDRESS  
BIT R5,R2 ;DONE A PASS  
BEQ 8\$ ;IF YES BRANCH  
7\$: MOV (R2),R1 ;GET DATA WRITTEN  
CMP R0,R1 ;COMPARE THE CHECK WORD WITH THE DATA READ.  
BEQ 69\$ ;BRANCH OVER ERROR CALL IF GOOD DATA.  
68\$: JSR PC,SPRNT2 ;SET UP VALUES FOR ERROR PRINTING.  
JSR PC,\$ERROR ;\*\*\* ERROR \*\*\* (GO TYPE A MESSAGE)  
.WORD 10 ;ERROR TYPE CODE.  
69\$: BR 4\$  
8\$: INC R3 ;INCREMENT PASS COUNTER  
SWAB R0 ;SET UP NEW READ WORD  
CMP R3,#2 ;ADDRESSING UP?  
BNE 3\$ ;IF NO GO TO DOWN SEQUENCE  
MOV TEMP,R2 ;IF YES RESET ADDRESS TO START  
BR 7\$ ;GO TO UP SEQUENCE  
9\$: JSR R4,INITMM ;INITIALIZE MEMORY ADDRESS POINTERS  
JSR PC,MMUP ;UPDATE TO NEW BANK IF EXISTS  
\*\*\*\*\*  
;TEST 30 WRITE CHECKERBOARD STARTING WITH '125252' DATA.  
; THESE TESTS WRITE A CHECKERBOARD THROUGHOUT MEMORY STALL  
; FOR 2 SECONDS THEN CHECK PATTERN TO VERIFY DATA DID NOT  
; DETERIORATE BETWEEN REFRESH CYCLES.  
; R0=DATA WRITTEN INTO MEMORY(SHOULD BE)  
; R1=DATA READ FROM MEMORY(WAS)  
; R2=VIRTUAL ADDRESS  
; R3=SMALL LOOP COUNTER FOR STALL  
; R4=NUMBER OF TIMES SMALL LOOP DONE  
; R5=BLOCK BOUNDARY BIT MASK.  
\*\*\*\*\*  
;ST30:  
JSR R5,\$SCOPE ;GO TO SCOPE ROUTINE.  
.WORD 0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.  
JSR R4,INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS  
MOV #125252,R0 ;SETUP DATA PATTERN  
1\$: MOV R0,(R2)+ ;WRITE A WORD  
COM R0 ;COMPLEMENT DATA  
BIT R5,R2 ;CHECK FOR END OF A BLOCK.  
BNE 1\$ ;BRANCH IF MORE IN CURRENT BLOCK.  
JSR PC,MMUP ;FIND NEXT BLOCK AND LOOP TO 1\$.  
CLR R3 ;SET UP COUNTER FOR STALL  
2\$: MOV #46,R4 ;DO LOOP 46 TIMES OR 2 SEC. TOTAL.  
DEC R3  
BNE 2\$  
DEC R4  
BNE 2\$



020MCEO 0-124K MEMORY EXERCISER, 16K VER  
020MCE P11 10-JAN-78 12:56 30

MAGY11 30A 1052, 10-JAN-78 13:12 PAGE 62  
WRITE CHECKERBOARD STARTING WITH '125252' DATA.

SEQ 0144

2983	013576	004467	000570	JSR	R4	INITMM	: INITIALIZE THE MEMORY ADDRESS POINTERS.
2984	013602	012700	125252	MOV	#125252, R0		: INIT DATA FOR CHECKING
2985	013606			3\$:			
2986	013606	012201		MOV	(R2)+, R1		: GET THE DATA FROM MEMORY UNDER TEST.
2987	013610	020001		CMP	R0, R1		: COMPARE THE CHECK WORD WITH THE DATA READ.
2988	013612	001405		BEQ	65\$,		: BRANCH OVER ERROR CALL IF GOOD DATA.
2989	013614	004767	004512	64\$:	JSR	PC, SPRNT2	: SET UP VALUES FOR ERROR PRINTING.
2990	013620	004767	005760	JSR	PC, \$ERROR		: *** ERROR *** (GO TYPE A MESSAGE)
2991	013624	000006		.WORD	6		: ERROR TYPE CODE.
2992	013626			65\$:			
2993	013626	005100		COM	R0		
2994	013630	030502		BIT	R5, R2		: CHECK FOR END OF A BLOCK.
2995	013632	001365		BNE	3\$,		: BRANCH IF MORE IN CURRENT BLOCK.
2996	013634	004767	001310	JSR	PC, MMUP		: FIND NEXT BLOCK AND LOOP TO 1\$.
2997				: *****			
2998				: TEST 31 WRITE CHECKERBOARD STARTING WITH 052525 DATA			
2999				: *****			
3000	013640			1\$:			
3001	013640	004567	004730	JSR	R5, \$SCOPE		: GO TO SCOPE ROUTINE.
3002	013644	000000		.WORD	0		: NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
3003	013646	004467	000520	JSR	R4	INITMM	: INITIALIZE THE MEMORY ADDRESS POINTERS.
3004	013652	012700	052525	MOV	#052525, R0		: SETUP DATA PATTERN
3005	013656	010022		MOV	R0, (R2)+		: WRITE A WORD
3006	013660	005100		COM	R0		
3007	013662	030502		BIT	R5, R2		: CHECK FOR END OF A BLOCK.
3008	013664	001374		BNE	1\$,		: BRANCH IF MORE IN CURRENT BLOCK.
3009	013666	004767	001256	JSR	PC, MMUP		: FIND NEXT BLOCK AND LOOP TO 1\$.
3010	013672	005003		CLR	R3		: SET COUNTER FOR LOOP
3011	013674	012704	000046	MOV	#46, R4		: DO LOOP 46 TIMES OR 2 SEC. TOTAL
3012	013700	005303		2\$:	DEC	R3	
3013	013702	001376		BNE	2\$,		
3014	013704	005304		DEC	R4		
3015	013706	001374		BNE	2\$,		
3016	013710	004467	000456	JSR	R4	INITMM	: INITIALIZE THE MEMORY ADDRESS POINTERS.
3017	013714	012700	052525	MOV	#052525, R0		: INIT PATTERN FOR CHECKING
3018	013720			3\$:			
3019	013720	012201		MOV	(R2)+, R1		: GET THE DATA FROM MEMORY UNDER TEST.
3020	013722	020001		CMP	R0, R1		: COMPARE THE CHECK WORD WITH THE DATA READ.
3021	013724	001405		BEQ	65\$,		: BRANCH OVER ERROR CALL IF GOOD DATA.
3022	013726	004767	004400	64\$:	JSR	PC, SPRNT2	: SET UP VALUES FOR ERROR PRINTING.
3023	013732	004767	005646	JSR	PC, \$ERROR		: *** ERROR *** (GO TYPE A MESSAGE)
3024	013736	000006		.WORD	6		: ERROR TYPE CODE.
3025	013740			65\$:			
3026	013740	005100		COM	R0		
3027	013742	030502		BIT	R5, R2		: CHECK FOR END OF A BLOCK.
3028	013744	001365		BNE	3\$,		: BRANCH IF MORE IN CURRENT BLOCK.
3029	013746	004767	001176	JSR	PC, MMUP		: FIND NEXT BLOCK AND LOOP TO 1\$.



3030						.SBTTL	DONE:	RELOCATE PROGRAM AND REPEAT ALL TESTS.
3031	013752					DONE:		
3032	013752	004567	004616				JSR	RS, \$SCOPE ;GO TO SCOPE ROUTINE.
3033	013756	000000					.WORD	0 ;NO MINIMUM BLOCK SIZE REQUIRED THIS TEST.
3034	013760	005067	165204			TST32:	CLR	\$TIMES ;RESET ITERATION COUNTER FOR RESTARTING TEST.
3035	013764	105067	165112				CLBB	\$ISTNM ;RESET TEST NUMBER.
3036	013770	036767	164606	165536	1S:		PRGMAP, SAVTST	;CHECK IF PROGRAM IS IN TEST AREA.
3037	013776	001004					BNE	2S ;BR IF IT PROG IN MEM TO BE TESTED.
3038	014000	036767	164600	165530			BIT	PRGMAP+2, SAVTST+2 ;CHECK HI 64K
3039	014006	001434					BEQ	\$L OP ;BR IF PROG NOT IN MEM TO BE TESTED.
3040	014010	032777	000200	165122	2S:		BIT	\$SW07, @SWR ;CHECK FOR INHIBIT RELOCATION SWITCH.
3041	014016	001030					BNE	\$EOP ;SKIP RELOCATION IF SWITCH SET.
3042	014020	022767	000003	164554			CMP	#3, PRGMAP ;CHECK IF PROGRAM IN FIRST 8K.
3043	014026	001012					BNE	4S ;BR IF NOT IN FIRST 8K.
3044	014030	005737	000042				TST	@#42 ;CHECK FOR A ACT11.
3045	014034	001014					BNE	5S ;BR IF A ACT11.
3046	014036	105737	001224				TSTB	@\$ENV ;CHECK FOR APT
3047	014042	001011					BNE	5S ;IF APT DO NOT RELOCATE
3048	014044	004767	002354				JSR	PC RELTOP ;RELOCATE PROGRAM TO TOP OF MEMORY.
3049	014050	000167	172004		3S:		JMP	START1 ;LOOP BACK AND RUN ALL TESTS AGAIN.
3050								
3051	014054	004767	002746		4S:		JSR	PC RELO ;RELOCATE PROGRAM BACK TO FIRST 8K.
3052	014060	005737	000042				TST	@#42 ;TEST FOR XXDP
3053	014064	001402					BEQ	6S ;IF NOT RUNNING UNDER MON. DONT
3054	014066	004767	003142		5S:		JSR	PC, RESLDR ;RESTORE LOADERS.
3055	014072				6S:			
3056	014072	004567	007360				JSR	RS, \$PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
3057	014076	001201					.WORD	\$CRLF ;ADDRESS OF MESSAGE TO BE TYPED



CZQMCEO 0-124K MEMORY EXERCISER, 15K VER  
CZQMCE.P11 10-JAN-78 12:56

MACY11 30A(1052) 10-JAN-78 13:12 PAGE 64  
DONE: RELOCATE PROGRAM AND REPEAT ALL TESTS.

SEQ 0146

```

3058                                     ;*****
3059                                     ;
3060 .SBTTL  END OF PASS ROUTINE
3061
3062 ;*INCREMENT THE PASS NUMBER ($PASS)
3063 ;*TYPE "END PASS XXXXX" (WHERE XXXXX IS A DECIMAL NUMBER)
3064 ;*IF THERES A MONITOR GO TO IT
3065 ;*IF THERE ISN'T JUMP TO START1
3066
3067 $EOP:
3068     NOP
3069     CLR     $TIMES           ;; ZERO THE NUMBER OF ITERATIONS
3070     INC     $PASS           ;; INCREMENT THE PASS NUMBER
3071     BIC     $100000,$PASS   ;; DON'T ALLOW A NEG. NUMBER
3072     DEC     (PC)+           ;; LOOP?
3073 $EOPCT: .WORD 1
3074     BGT     $DOAGN          ;; YES
3075     MOV     (PC)+,$(PC)+    ;; RESTORE COUNTER
3076 $ENDCT: .WORD 1
3077     $EOPCT
3078     JSR     R5,$SPRINT      ;GO PRINT OUT THE FOLLOWING MESSAGE.
3079     .WORD   $ENDMG          ;ADDRESS OF MESSAGE TO BE TYPED
3080     MOV     $PASS,-(SP)     ;SAVE $PASS FOR TYPEOUT
3081 ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPDS ROUTINE
3082 ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
3083     MOV     $PSW,-(SP)      ;PUT THE PROCESSOR STATUS ON THE STACK
3084     JSR     PC,$TYPDS       ;GO TO THE SUBROUTINE
3085     JSR     R5,$SPRINT      ;GO PRINT OUT THE FOLLOWING MESSAGE.
3086     .WORD   $ENULL         ;ADDRESS OF MESSAGE TO BE TYPED
3087 $GET42:
3088
3089     MOV     42,R0           ;GET MONITOR ADDRESS
3090     BEQ     $DOAGN          ;BRANCH IF NO MONITOR
3091     RESET
3092     JSR     PC,(R0)         ;CLEAR THE WORLD
3093     NOP
3094     NOP
3095     NOP
3096     CMP     $42,$46         ;GO TO MONITOR
3097     BEQ     $DOAGN          ;SAVE ROOM
3098     JSR     PC,$AVLDR       ;FOR
3099     $DOAGN: JMP     START1   ;ACT11
3100                                     ;ARE WE UNDER ACT11 OR XXDP
3101     $ENDMG: .ASCIZ  <15><12>/END PASS #/
3102                                     ;IF ACT11 THEN RESTART
3103                                     ;IF XXDP FIRST SAVE MONITOR
3104     $ENULL: .BYTE  -1,-1,0   ;RETURN*****
3105                                     ;
3106 .SBTTL  SUBROUTINE AND TRAP ROUTINE SECTION.
3107 .SBTTL  MEMORY MANAGEMENT AND ADDRESSING SUBROUTINES.
3108 ;*****
3109 ;* SET UP ALL THE MEM MGMT REGISTERS FOR NORMAL OPERATION.
3110 ;* THE PROGRAM IS POINTED TO BY PARS 0 AND 1.
3111 ;* THE MEMORY UNDER TEST IS POINTED TO BY PARS 2 AND 3.
3112 ;* THE DEVICE ADDRESS AREA IS POINTED TO BY PAR 7.
3113 ;* PARS 4, 5, AND 6 ARE UNUSED.
3114 ;*****

```



```

3114 014244 MMINIT:
3115 014244 012737 077406 172300 MOV #200-1*400+UP+RW, @#KIPDR0 ;SET KIPDR0 = RW UP 200 BLOCKS
3116 014252 012737 077406 172302 MOV #200-1*400+UP+RW, @#KIPDR1 ;SET KIPDR1 = RW UP 200 BLOCKS
3117 014260 012737 077406 172304 MOV #200-1*400+UP+RW, @#KIPDR2 ;SET KIPDR2 = RW UP 200 BLOCKS
3118 014266 012737 077406 172306 MOV #200-1*400+UP+RW, @#KIPDR3 ;SET KIPDR3 = RW UP 200 BLOCKS
3119 014274 005037 172310 CLR @#KIPDR4
3120 014300 005037 172312 CLR @#KIPDR5
3121 014304 005037 172314 CLR @#KIPDR6
3122 014310 012737 077406 172316 MOV #200-1*400+UP+RW, @#KIPDR7 ;SET KIPDR7 = RW UP 200 BLOCKS
3123 014316 005037 172340 @#KIPAR0 ;MAP PAR0 INTO BANK0
3124 014322 012737 000200 172342 MOV #200, @#KIPAR1 ;MAP PAR1 INTO BANK1
3125 014330 005037 172344 CLR @#KIPAR2 ;MAP PAR2 INTO BANK0
3126 014334 005037 172346 CLR @#KIPAR3
3127 014340 005037 172350 CLR @#KIPAR4
3128 014344 005037 172352 CLR @#KIPAR5
3129 014350 005037 172354 CLR @#KIPAR6
3130 014354 012737 007600 172356 MOV #7600, @#KIPAR7 ;MAP PAR7 INTO I/O BANK
3131 014362 012737 000001 177572 MOV #1, @#SRO ;ENABLE MEMORY MANAGEMENT
3132 014370 000207 RTS PC ;RETURN
3133
3134
3135 *****
3136 * MEMORY ADDRESS POINTER INITIALIZATION ROUTINES.
3137 *****
3138 014372 012767 000001 165144 INITMM: MOV #BIT0, BITPT ;SET POINTER TO BANK0
3139 014400 005067 165142 CLR BITPT+2 ;CLEAR HI 64K BANK POINTERS
3140 014404 005002 R2 ;SET ADDRESS POINTER TO 0
3141 014406 016705 165174 MOV BLKMSK, R5 ;RESET R5 TO BLOCK MASK.
3142 014412 005767 164170 TST MMVA ;CHECK FOR MEM MGMT AVAILABLE
3143 014416 001514 BEQ 10$ ;BRANCH IF NO MEM MGMT
3144 014420 005037 172344 CLR @#KIPAR2 ;SET UP 3RD PAR TO BANK0
3145 014424 012702 040000 MOV #40000, R2 ;RESET VIRTUAL ADR POINTER
3146 014430 036767 165110 165072 1$: BIT BITPT, TSTMAP ;CHECK IF THIS BANK TO BE TESTED
3147 014436 001015 BNE 2$ ;BRANCH IF MATCH
3148 014440 036767 165102 165064 BIT BITPT+2, TSTMAP+2 ;CHECK IN HI MAP
3149 014446 001011 BNE 2$ ;BRANCH IF MATCH
3150 014450 062737 000200 172344 ADD #200, @#KIPAR2 ;UPDATE MEM MGMT, THIRD PAR.
3151 014456 006367 165062 BITPT ;UPDATE LO POINTER TO NEXT BANK.
3152 014462 006167 165060 ROL BITPT+2 ;...HI POINTER.
3153 014466 100360 BPL 1$ ;BR IF MORE.
3154 014470 000000 HALT ;FATAL ERROR!!! NO 4K BANK FOUND?
3155 014472 036767 165046 165102 2$: BIT BITPT, LADMAP ;CHECK IF LAST BANK.
3156 014500 001004 BNE 3$ ;BR IF LAST BANK.
3157 014502 036767 165040 165074 BIT BITPT+2, LADMAP+2 ;CHECK IF LAST BANK.
3158 014510 001405 BEQ 4$ ;BR IF NOT LAST BANK.
3159 014512 016705 165062 3$: MOV LADMSK, R5 ;SET MASK TO FIND LAST ADR.
3160 014516 042767 020000 165052 BIC #20000, TMPLAD ;MAKE SURE VIRTUAL LAST ADR IN BANK 2.
3161 014524 013737 172344 172346 4$: MOV @#KIPAR2, @#KIPAR3 ;COPY CURRENT PAR INTO FORTH PAR.
3162 014532 016767 165006 165010 MOV BITPT, TMPPT ;COPY BITPT...LO 64K.
3163 014540 016767 165002 165004 MOV BITPT+2, TMPPT+2 ;...HI 64K.
3164 014546 032705 020000 BIT #BIT13, R5 ;CHECK FOR A BLOCK SIZE OF 8K.
3165 014552 001505 BEQ 21$ ;BRANCH IF NOT 8K.
3166 014554 062737 000200 172346 5$: ADD #200, @#KIPAR3 ;UP DATE FORTH PAR.
3167 014562 006367 164762 TMPPT ;UPDATE LO POINTER TO NEXT 4K BANK.
3168 014566 006167 164760 ROL TMPPT+2 ;...HI POINTER.
3169 014572 100473 BMI 20$ ;BR IF NO MORE.

```



3170	014574	036767	164750	164726		BIT	TMPPT, TSTMAP	;CHECK IF BANK TO BE TESTED.
3171	014602	001004				BNE	6\$	;BRANCH IF A MATCH.
3172	014604	036767	164742	164720		BIT	TMPPT+2, TSTMAP+2	;CHECK FOR HI 64K BANKS.
3173	014612	001760				BEQ	5\$	;BRANCH IF NO MEMORY
3174	014614	036767	164730	164760	6\$:	BIT	TMPPT, LADMAP	;CHECK IF LAST BANK.
3175	014622	001004				BNE	7\$	;BRANCH IF A MATCH
3176	014624	036767	164722	164752		BIT	TMPPT+2, LADMAP+2	;CHECK HI 64K
3177	014632	001455				BEQ	21\$	;BR IF NOT LAST BANK.
3178	014634	016705	164740		7\$:	MOV	LADMSK, R5	;RESET MASK TO FIND LAST ADR.
3179	014640	052767	020000	164730		BIS	#20000, TMPLAD	;MAKE SURE LAST ADDRESS IS IN BANK 3.
3180	014646	000447				BR	21\$	;BR TO FINISH UP.
3181								
3182	014650	036767	164670	164652	10\$:	BIT	BITPT, TSTMAP	;CHECK IF THIS BANK TO BE TESTED.
3183	014656	001006				BNE	11\$	;BR IF MATCH.
3184	014660	062702	020000			ADD	#20000, R2	;UPDATE PHYSICAL ADR PNTR TO NEXT BANK.
3185	014664	106367	164654			ASLB	BITPT	;UPDATE BANK POINTER TO NEXT BANK.
3186	014670	100367				BPL	10\$	;BR IF MORE BANKS.
3187	014672	000000				HALT		;FATAL ERROR!!! NO 4K BANK FOUND?
3188	014674	016767	164644	164646	11\$:	MOV	BITPT, TMPPT	;COPY BANK POINTER.
3189	014702	036767	164636	164672		BIT	BITPT, LADMAP	;CHECK IF LAST BANK.
3190	014710	001021				BNE	12\$	;BR IF LAST BANK.
3191	014712	032705	020000			BIT	#BIT13, R5	;CHECK FOR 8K BLOCK SIZE.
3192	014716	001423				BEQ	21\$	;BRANCH IF SMALLER BLOCK SIZE.
3193	014720	106367	164624			ASLB	TMPPT	;POINT TO NEXT BANK.
3194	014724	100416				BMI	20\$	;BRANCH IF OVERFLOW.
3195	014726	036767	164616	164574		BIT	TMPPT, TSTMAP	;CHECK IF BANK TO BE TESTED.
3196	014734	001412				BEQ	20\$	;BRANCH IF NOT TO BE TESTED.
3197	014736	112767	000011	164613		MOVB	#11, FLAG8K	;SET 8K BLOCK SIZE FLAG.
3198	014744	036767	164600	164630		BIT	TMPPT, LADMAP	;CHECK FOR LAST BANK.
3199	014752	0C1403				BEQ	20\$	;BR IF NOT LAST BANK.
3200	014754	0 6705	164620		12\$:	MOV	LADMSK, R5	;RESET MASK TO FIND LAST ADR.
3201	014760	0 J0402				BR	21\$	;SKIP MASK RESET.
3202	014762	012705	017777		20\$:	MOV	#MASK4K, R5	;RESET MASK TO 4K BLOCK SIZE.
3203	014766	056767	164552	164554	21\$:	BITPT	TMPPT	;SET TMPPT FOR FLAGING LAST BANK.
3204	014774	056767	164546	164550		BIS	BITPT+2, TMPPT+2	
3205	015002	036767	164536	164560		BIT	BITPT, FADMAP	;CHECK IF FIRST ADDRESS NEEDS TO BE SET.
3206	015010	001004				BNE	22\$	;BR IF FIRST BANK.
3207	015012	036767	164530	164552		BIT	BITPT+2, FADMAP+2	;CHECK HI 64K.
3208	015020	001450				BEQ	INITEX	;BR IF NOT FIRST BANK.
3209	015022	016702	164536		22\$:	MOV	TMPLAD, R2	;RESET ADDRESS POINTER TO FIRST ADR.
3210	015026	000445				BR	INITEX	
3211								
3212	015030	016705	164552		INITDN:	MOV	BLKMSK, R5	;RESET R5 TO CURRENT BLOCK MASK.
3213	015034	005002				CLR	R2	;INIT ADDRESS POINTER.
3214	015036	005767	163544			TST	MMAVA	;CHECK FOR MEM MGMT
3215	015042	001411				BEQ	31\$	;BRANCH IF NO MEM MGMT
3216	015044	012767	100000	164474		MOV	#BIT15, BITPT+2	;SET POINTER TO TOP BIT
3217	015052	005067	164466			CLR	BITPT	
3218	015056	012737	007600	172344		MOV	#7600, #KIPAR2	;SET PAR TO TOP OF MEM
3219	015064	000403				BR	32\$	;BRANCH TO COMMON AREA
3220								
3221	015066	012767	000400	164450	31\$:	MOV	#BIT8, BITPT	;SET UP BANK POINTER
3222	015074	012767	015116	164452	32\$:	MOV	#33\$, MMORE	;SET "MMDOWN" EXIT ADDRESS.
3223	015102	066767	163472	164444		ADD	RELOC, MMORE	;ADD OFFSET
3224	015110	004767	000524			JSR	PC, MMDOWN	;ROUTINE TO SEARCH DOWNWARD FOR TOP MEM BANK
3225	015114	000000				HALT		;FATAL ERROR!!! NO MEM INDICATED IN MEM MAP ABOVE 8K!



```

3226 015116 036767 164422 164456 33$: BIT BITPT, LADMAP ;CHECK FOR NON BOUNDARY LAST ADDR.
3227 015124 001004 BNE 34$ ;BR IF LAST BANK FLAG FOUND.
3228 015126 036767 164414 164450 BIT BITPT+2,LADMAP+2 ;CHECK FOR NON BOUNDARY LAST ADDR.
3229 015134 001402 BEQ INTEX ;BR IF NO LAD FLG FOUND.
3230 015136 016702 164432 34$: MOV LSTADR, R2 ;SET UP R2.
3231 015142 010467 164406 INITEX: MOV R4, MMORE ;PUT RETURN PC INTO "MMORE"
3232 015146 000204 RTS R4 ;RETURN
3233
3234 ;*****
3235 ;* COMMON UPWARDS ADDRESSING ROUTINE
3236 ;* FINDS NEXT EXISTING 4K BANK AND UPDATES POINTERS.
3237 ;* GOES TO ADDRESS IN "MMORE" IF MORE BANKS.
3238 ;* DOES STRAIGHT EXIT WHEN ALL MEMORY HAS BEEN DONE.
3239 ;*****
3240 015150 036767 164374 164424 MMUP: BIT TMPPT, LADMAP ;CHECK FOR LAST BANK FLAG.
3241 015156 001122 BNE 10$ ;BR IF LAST BANK.
3242 015160 036767 164366 164416 BIT TMPPT+2,LADMAP+2 ;CHECK FOR LAST BANK FLAG.
3243 015166 001116 BNE 10$ ;BR IF LAST BANK.
3244 015170 016705 164412 MOV BLKMSK, R5 ;RESET R5 TO BLOCK MASK.
3245 015174 005767 163406 TST MMVA ;CHECK FOR MEM MGMT AVAILABLE
3246 015200 001515 BEQ 20$ ;BRANCH IF NO MEM MGMT
3247 015202 012702 040000 MOV #40000, R2 ;RESET VIRTUAL ADR POINTER
3248 015206 062737 000200 172344 1$: ADD #200, 2*MMIPAR2 ;UPDATE MEM MGMT, THIRD PAR.
3249 015214 006367 164324 ASL BITPT ;UPDATE LO POINTER TO NEXT BANK.
3250 015220 006167 164322 ROL BITPT+2 ;...HI POINTER.
3251 015224 100577 BMI 32$ ;BR IF ALL DONE.
3252 015226 036767 164312 164274 BIT BITPT, TSTMAP ;CHECK IF THIS BANK EXISTS
3253 015234 001004 BNE 2$ ;BRANCH IF MATCH
3254 015236 036767 164304 164266 BIT BITPT+2,TSTMAP+2 ;CHECK IN HI MAP
3255 015244 001760 BEQ 1$ ;BRANCH IF NO MATCH
3256 015246 036767 164272 164326 2$: BIT BITPT, LADMAP ;CHECK FOR LAST BANK FLAG.
3257 015254 001004 BNE 3$ ;BRANCH IF LAST BANK FLAG.
3258 015256 036767 164264 164320 BIT BITPT+2,LADMAP+2 ;CHECK IF LAST BANK FLAG.
3259 015264 001405 BEQ 4$ ;BR IF NOT LAST BANK.
3260 015266 016705 164306 3$: MOV LADMSK, R5 ;RESET MASK.
3261 015272 042767 020000 164276 BIC #20000, TMPLAD ;MAKE SURE VIRTUAL LAST ADR IN BANK 2
3262 015300 016767 164240 164242 4$: MOV BITPT, TMPPT ;COPY BITPT...LO 64K.
3263 015306 016767 164234 164236 MOV BITPT+2,TMPPT+2 ;...HI 64K.
3264 015314 032705 020000 BIT #BIT13, R5 ;CHECK FOR A BLOCK SIZE OF 8K.
3265 015320 001530 BEQ 31$ ;BRANCH IF NOT.
3266 015322 013737 172344 172346 MOV 2*MMIPAR2, 2*MMIPAR3 ;COPY CURRENT PAR INTO FORTH PAR.
3267 015330 062737 000200 172346 5$: ADD #200, 2*MMIPAR3 ;UP DATE FORTH PAR.
3268 015336 006367 164206 TMPPT ;UPDATE LO POINTER TO NEXT 4K BANK.
3269 015342 006167 164204 ROL TMPPT+2 ;...HI POINTER.
3270 015346 100513 BMI 30$ ;BR IF NO MORE.
3271 015350 036767 164174 164152 6$: BIT TMPPT, TSTMAP ;CHECK IF BANK TO BE TESTED.
3272 015356 001004 BNE 7$ ;BRANCH IF A MATCH.
3273 015360 036767 164166 164144 BIT TMPPT+2,TSTMAP+2 ;CHECK FOR HI 64K BANKS.
3274 015366 001760 BEQ 5$ ;BRANCH IF NO MEMORY
3275 015370 036767 164154 164204 7$: BIT TMPPT,LADMAP ;CHECK FOR LAST BANK FLAG.
3276 015376 001004 BNE 8$ ;BRANCH IF A MATCH
3277 015400 036767 164146 164176 BIT TMPPT+2,LADMAP+2 ;CHECK HI 64K
3278 015406 001475 BEQ 31$ ;BR IF NO LAST BANK FLAG.
3279 015410 016705 164164 8$: MOV LADMSK, R5 ;RESET MASK TO FIND LAST ADDRESS.
3280 015414 052767 020000 164154 BIS #20000, TMPLAD ;SET VIRTUAL ADR TO BANK 3.
3281 015422 000467 BR 31$

```



```

3282
3283 015424 026702 164146      10$:  CMP      TEMPLAD, R2      ;CHECK IF LAST ADR REACHED.
3284 015430 001064              BNE      31$              ;BR IF MORE.
3285 015432 000474              BR       32$              ;BR IF ALL DONE.
3286
3287 015434 106267 164117      20$:  ASRB      FLAG8K              ;SHIFT 8K FLAG
3288 015440 001407              BEQ      22$              ;BR IF NOT 8K BLOCK.
3289 015442 103455              BCS      30$              ;BR IF ANOTHER 4K.
3290 015444 105067 164107      CLRB      FLAG8K              ;CLEAR OUT ALL FLAGS.
3291 015450 162702 040000      SUB      #40000, R2      ;BACK UP 8K.
3292 015454 062702 020000      21$:  ADD      #20000, R2      ;UPDATE PHYSICAL ADR PNTR TO NEXT BANK.
3293 015460 106367 164060      22$:  ASLB      BITPT              ;UPDATE POINTER.
3294 015464 100457              BMI      32$              ;BRANCH WHEN END IS REACHED.
3295 015466 036767 164052 164034  BIT      BITPT, TSTMAP      ;CHECK IF THIS BANK EXISTS.
3296 015474 001767              BEQ      21$              ;BRANCH IF NO MATCH.
3297 015476 036767 164042 164076  BIT      BITPT, LADMAP      ;CHECK FOR LAST BANK FLAG.
3298 015504 001402              BEQ      23$              ;BR IF NO MATCH.
3299 015506 016705 164066      MOV      LADMSK, R5      ;RESET MASK TO FIND LAST ADR.
3300 015512 016767 164026 164030  23$:  MOV      BITPT, TMPPT      ;SET UP TMP POINTER.
3301 015520 032705 020000      BIT      #BIT13, R5      ;CHECK FOR 8K BLOCK SIZE.
3302 015524 001426              BEQ      31$              ;BRANCH IF SMALLER BLOCK SIZE.
3303 015526 106367 164016      ASLB      TMPPT              ;POINT TO NEXT BANK.
3304 015532 100421              BMI      30$              ;BRANCH IF OVERFLOW.
3305 015534 036767 164010 163766  BIT      TMPPT, TSTMAP      ;CHECK IF BANK TO BE TESTED.
3306 015542 001415              BEQ      30$              ;BRANCH IF NOT TO BE TESTED.
3307 015544 036767 163774 164030  BIT      BITPT, LADMAP      ;CHECK FOR LAST BANK FLAG.
3308 015552 112767 000011 163777  MOVB     #11, FLAG8K      ;SET 8K BLOCK FLAG.
3309 015560 036767 163760 164014  BIT      BITPT, LADMAP      ;CHECK FOR LAST BANK FLAG.
3310 015566 001403              BEQ      30$              ;BR IF NO FLAG.
3311 015570 016705 164004      MOV      LADMSK, R5      ;RESET MASK TO FIND LAST ADR.
3312 015574 000402              BR       31$
3313 015576 012705 017777      30$:  MOV      #MASK4K, R5      ;SET MASK TO 4K.
3314 015602 056767 163736 163740  31$:  BIS      BITPT, TMPPT      ;SET TMPPT FOR FINDING LAST ADR.
3315 015610 056767 163732 163734  BIS      BITPT+2, TMPPT+2
3316 015616 016716 163732      MOV      MMORE, (SP)      ;FUDGE RETURN ADDRESS TO LOOP.
3317 015622 000207              RTS      PC              ;RETURN
3318
3319 015624 005767 164446      ;* BEFORE FINAL EXIT, CHECK FOR ANY NON-TRAP PARITY ERRORS.
3320 015630 001402      32$:  TST      MPRX              ;CHECK FOR ANY PARITY REGISTERS PRESENT.
3321 015632 004767 001744      BEQ      33$              ;BR IF NONE.
3322 015636 000207      JSR      PC, CKPMER      ;CHECK FOR PARITY MEMORY ERRORS.
3323      RTS      PC              ;STRAIGHT RETURN.
3324
3325      ;*****
3326      ;* MEMORY DOWNWARDS ADDRESSING SUBROUTINE.
3327      ;* FINDS NEXT LOWER 4K BANK AND UPDATES POINTERS.
3328      ;* GOES TO ADDRESS IN "MMORE" IF MORE BANKS.
3329      ;* DOES STRAIGHT EXIT WHEN ALL MEMORY HAS BEEN DONE.
3330      ;*****
3330 015640 036767 163700 163722  MMDOWN: BIT      BITPT, FADMAP      ;CHECK FOR FIRST ADR FLAG.
3331 015646 001004              BNE      1$              ;BR IF FIRST ADR IN THIS BANK.
3332 015650 036767 163672 163714  BIT      BITPT+2, FADMAP+2 ;CHECK FOR FIRST ADR FLAG.
3333 015656 001404              BEQ      2$              ;BR IF NO FLAG
3334 015660 026702 163700      1$:  CMP      TMPFAD, R2      ;CHECK IF FIRST ADDRESS REACHED.
3335 015664 001052              BNE      9$              ;BR IF MORE.
3336 015666 000453              BR       10$             ;BR IF ALL DONE.
3337 015670 005767 162712      2$:  TST      MMAVA              ;CHECK IF MEM MGMT IS AVAILABLE

```



3338	015674	001425			BEQ	6\$		; BRANCH IF NOT
3339	015676	162737	000200	172344	SUB	#200, 2#KIPAR2		; LOWER MEM MGMT PAR BY 4K
3340	015704	006067	163636		ROR	BITPT+2		; MOV POINTER TO NEXT LOWER BANK...HI MAP.
3341	015710	006067	163630		ROR	BITPT		; ...LO MAP.
3342	015714	103440			BCS	10\$		; BR IF NO MORE.
3343	015716	036767	163622	163604	BIT	BITPT, TSTMAP		; CHECK FOR BANK EXISTING
3344	015724	001004			BNE	4\$		; BR IF BANK TO BE TESTED.
3345	015726	036767	163614	163576	BIT	BITPT+2, TSTMAP+2		; CHECK FOR BANK IN HI MAP.
3346	015734	001760			BEQ	3\$		; BR IF NOT THERE.
3347	015736	012702	060000		MOV	#60000, R2		; SET ADR POINTER TO TOP OF BANK
3348	015742	000411			BR	7\$		; GO TO COMMON EXIT
3349	015744	162702	020000		SUB	#20000, R2		; BACK POINTER DOWN ONE BANK
3350	015750	006267	163570		ASR	BITPT		; MOVE POINTER TO NEXT LOWER BANK
3351	015754	103420			BCS	10\$		; BRANCH TO EXIT IF NO MORE MEM
3352	015756	036767	163562	163544	BIT	BITPT, TSTMAP		; CHECK IF BANK EXISTS
3353	015764	001767			BEQ	5\$		; BRANCH IF BANK DOESN'T EXIST
3354	015766	036767	163552	163574	BIT	BITPT, FADMAP		; CHECK IF FIRST BANK FLAG.
3355	015774	001004			BNE	8\$		; BR IF FIRST BANK.
3356	015776	036767	163544	163566	BIT	BITPT+2, FADMAP+2		; CHECK IF FIRST BANK FLAG.
3357	016004	001402			BEQ	9\$		; BR IF NO FLAG FOUND.
3358	016006	016705	163554		MOV	FADMSK, R5		; SET UP R5 TO FIND FIRST ADDRESS.
3359	016012	016716	163536		MOV	MMORE, (SP)		; RESET RETURN ADDRESS
3360	016016	000207			RTS	PC		; RETURN



```

3361 .SBTTL SUBROUTINES FOR ADDRESS AND WORSE CASE NOISE TESTS.
3362 ;*****
3363 ;* SUBROUTINE TO CALCULATE PHYSICAL ADDRESS AND PUT IT IN R0 (BOTTOM 16 BITS).
3364 ;* BITS 16 AND 17 ARE IN $TMP0.
3365 ;*****
3366 016020 010200 PHYADR: MOV R2, R0 ;VIRTUAL INTO R0
3367 016022 005067 163132 CLR $TMP0 ;CLEAR TEMP SAVE OF HIGH BITS
3368 016026 005767 162554 TST MMAPA ;CHECK FOR MEM MGMT AVAILABLE
3369 016032 001417 BEQ 1$ ;BRANCH IF NO MEM MGMT
3370 016034 010146 MOV R1, -(SP) ;PUSH R1 ON STACK
3371 016036 013701 172344 MOV 2*PAR2, R1 ;GET PAR TO BE ADDED TO VIRTUAL
3372 016042 006301 ASL R1 ;SHIFT IT 6 TIMES
3373 016044 006301 ASL R1
3374 016046 006301 ASL R1
3375 016050 006301 ASL R1
3376 016052 006301 ASL R1
3377 016054 006167 163100 ROL $TMP0 ;SAVE EXTRA BITS
3378 016060 006301 ASL R1
3379 016062 006167 163072 ROL $TMP0
3380 016066 060100 ADD R1, R0 ;ADD SHIFTED PAR TO VIRTUAL
3381 016070 012601 MOV (SP)+, R1 ;POP STACK INTO R1
3382 016072 000207 1$: RTS PC ;RETURN
3383
3384 ;*****
3385 ;* SUBROUTINE TO PUT BANK NUMBER INTO R0.
3386 ;*****
3387 016074 005000 BANKNO: CLR R0 ;INIT R0
3388 016076 010146 MOV R1, -(SP) ;PUSH R1 ON STACK
3389 016100 010246 MOV R2, -(SP) ;PUSH R2 ON STACK
3390 016102 016701 163436 MOV BITPT, R1 ;GET BANK MAP POINTER...LO 64K.
3391 016106 016702 163434 MOV BITPT+2, R2 ;HI 64K.
3392 016112 006202 1$: ASR R2 ;SHIFT POINTER...HI
3393 016114 006001 ROR R1 ;LO
3394 016116 103403 BCS 2$ ;BR WHEN POINTER FOUND.
3395 016120 105200 INCB R0 ;COUNT BANKS.
3396 016122 100373 BPL 1$ ;BR IF NOT OVERFLOW.
3397 016124 000000 HALT ;FATAL ERROR!!! NO POINTER FOUND.
3398 016126
3399 016126 012602 2$: MOV (SP)+, R2 ;POP STACK INTO R2
3400 016130 012601 MOV (SP)+, R1 ;POP STACK INTO R1
3401 016132 000207 RTS PC ;RETURN
3402
3403 ;*****
3404 ;* SUBROUTINE TO WRITE THE CONSTANT IN R0 INTO ALL OF MEMORY.
3405 ;*****
3406 016134 004467 176232 SETCON: JSR R4, INITMM ;INITIALIZE THE MEMORY ADDRESS POINTERS.
3407 016134 010022 2$: MOV R0, (R2)+ ;MOV CONSTANT INTO MEMORY
3408 016140 030502 BIT R5, R2 ;CHECK FOR END OF A BLOCK.
3409 016142 001375 BNE 2$ ;BRANCH IF MORE IN CURRENT BLOCK.
3410 016144 004767 JSR PC, MMUP ;FIND NEXT BLOCK AND LOOP TO 1$.
3411 016146 000207 RTS PC ;RETURN
3412 016152

```



```

3413
3414
3415
3416 016154 106112
3417 016156 106112
3418 016160 106112
3419 016162 106112
3420 016164 106112
3421 016166 106112
3422 016170 106112
3423 016172 106112
3424 016174 106122
3425 016176 106112
3426 016200 106112
3427 016202 106112
3428 016204 106112
3429 016206 106112
3430 016210 106112
3431 016212 106112
3432 016214 106112
3433 016216 106122
3434 016220 000207
3435
3436
3437
3438
3439 016222 012704 000020
3440
3441 016226 010022
3442 016230 010022
3443 016232 010022
3444 016234 010022
3445
3446 016236 010322
3447 016240 010322
3448 016242 010322
3449 016244 010322
3450
3451 016246 010022
3452 016250 010022
3453 016252 010022
3454 016254 010022
3455
3456 016256 010322
3457 016260 010322
3458 016262 010322
3459 016264 010322
3460
3461 016266 005304
3462 016270 001356
3463 016272 010046
3464 016274 010300
3465 016276 012603
3466 016300 000207

```

```

*****
ROUTINE TO ROTATE 'C' BIT THROUGH A MEMORY LOCATION.
*****
ROTATE: ROLB (R2) ; (R2)=177776 OR 000001
        ROLB (R2) ; (R2)=177775 OR 000002
        ROLB (R2) ; (R2)=177773 OR 000004
        ROLB (R2) ; (R2)=17776 OR 000010
        ROLB (R2) ; (R2)=177757 OR 000020
        ROLB (R2) ; (R2)=177737 OR 000040
        ROLB (R2) ; (R2)=177677 OR 000100
        ROLB (R2) ; (R2)=177777 OR 000000
        ROLB (R2)+ ; (R2)=177577 OR 000200
        ROLB (R2) ; (R2)=177377 OR 000400
        ROLB (R2) ; (R2)=176777 OR 001000
        ROLB (R2) ; (R2)=175777 OR 002000
        ROLB (R2) ; (R2)=173777 OR 004000
        ROLB (R2) ; (R2)=167777 OR 010000
        ROLB (R2) ; (R2)=157777 OR 020000
        ROLB (R2) ; (R2)=137777 OR 040000
        ROLB (R2) ; (R2)=077777 OR 100000
        ROLB (R2)+ ; (R2)=177777 OR 000000
        RTS PC ; RETURN
*****
SUBROUTINE TO WRITE 3 XOR 9 PATTERN INTO 256. WORD BLOCK.
*****
W3X9: MOV #16.,R4 ; EACH LOOP WRITES 256. WORDS
25: MOV R0,(R2)+
    MOV R0,(R2)+
    MOV R0,(R2)+
    MOV R0,(R2)+
    MOV R3,(R2)+
    MOV R3,(R2)+
    MOV R3,(R2)+
    MOV R3,(R2)+
    MOV R0,(R2)+
    MOV R0,(R2)+
    MOV R0,(R2)+
    MOV R0,(R2)+
    MOV R3,(R2)+
    MOV R3,(R2)+
    MOV R3,(R2)+
    MOV R3,(R2)+
    DEC R4
    BNE 25
    MOV R0,-(SP) ; SAVE R0
    MOV R3,R0 ; PUT R3 INTO R0
    MOV (SP)+,R3 ; PUT SAVED R0 INTO R3
    RTS PC ; RETURN

```



```

3467 .SBTTL RELOCATION SUBROUTINES.
3468 ;*****
3469 ;* ROUTINE TO RELOCATE PROGRAM CODE
3470 ;*****
3471 RELOC:
3472     MOV     R2,-(SP)      ;; PUSH R2 ON STACK
3473     MOV     R3,-(SP)      ;; PUSH R3 ON STACK
3474     MOV     R4,-(SP)      ;; PUSH R4 ON STACK
3475     4$:     MOV     (R5)+, R2      ;; GET FIRST LOCATION.
3476     MOV     (R5)+, R3      ;; GET FIRST LOCATION OF DESTINATION.
3477     MOV     #20000, R4      ;; SET UP BK COUNTER.
3478     1$:     MOV     (R2)+, (R3)+  ;; MOV THE DATA.
3479     DEC     R4            ;; COUNT THE WORDS.
3480     BNE     1$           ;; BR IF MORE.
3481     MOV     #20000, R4      ;; RESET THE COUNTER.
3482     2$:     CMP     -(R2), -(R3)  ;; CHECK THE DATA JUST MOVED.
3483     BEQ     3$           ;; BR IF DATA OK.
3484     MOV     (R2), $GDDAT    ;; GET SOURCE DATA.
3485     MOV     (R3), $BDDAT    ;; GET DESTINATION DATA.
3486     MOV     R2, $GDADR     ;; GET SOURCE ADDRESS.
3487     MOV     R3, $BDADR     ;; GET DESTINATION ADDRESS.
3488     JSR     PC, $ERRR      ;; *** ERROR *** (GO TYPE A MESSAGE)
3489     .WORD   23            ;; ERROR TYPE CODE.
3490     HALT                    ;; FATAL ERROR!!! RELOCATION FAILED.
3491     SUB     #4, R5         ;; ADJUST RETURN POINTER.
3492     BR      4$           ;; GO BACK AND TRY AGAIN.
3493     3$:     DEC     R4            ;; COUNT WORDS.
3494     BNE     2$           ;; BR IF MORE.
3495     JSR     R5, $PRINT     ;; GO PRINT OUT THE FOLLOWING MESSAGE.
3496     .WORD   PRELOC        ;; ADDRESS OF MESSAGE TO BE TYPED
3497     "PROGRAM RELOCATED TO "
3498     MOV     R3, -(SP)      ;; PUT THE DATA ON THE STACK.
3499     JSR     PC, $TYPAD     ;; DETERMINE THE PHYSICAL ADDRESS AND TYPE IT.
3500     MOV     (SP)+, R4      ;; POP STACK INTO R4
3501     MOV     (SP)+, R3      ;; POP STACK INTO R3
3502     MOV     (SP)+, R2      ;; POP STACK INTO R2
3503     RTS     R5            ;; RETURN
3504 ;*****
3505 ;* SUBROUTINE TO MOVE PROGRAM FROM BOTTOM TO TOP OF MEMORY.
3506 ;*****
3507     RELTOP: CMP     #3, PRGMAP    ;; CHECK THAT THE PROGRAM IS NOW IN BANKS 0 AND 1.
3508     BEQ     1$           ;; BR IF OK
3509     HALT                    ;; FATAL ERROR!!! PROG SHOULD BE IN BANKS 0 AND 1
3510     1$:     MOV     R0,-(SP)      ;; PUSH R0 ON STACK
3511     MOV     R1,-(SP)      ;; PUSH R1 ON STACK
3512     TST     MMABA
3513     BEQ     10$          ;; SET PAR TO TOP OF MEM
3514     MOV     #7600, @#KIPAR3      ;; INIT BANK POINTER...LO 64k
3515     CLR     R0            ;; ...HI 64k.
3516     MOV     #BIT15, R1      ;; BACK DOWN ONE BANK.
3517     SUB     #200, @#KIPAR3      ;; MOVE POINTER...HI 64k.
3518     ROR     R1            ;; ...LO 64k.
3519     ROR     R0
3520     BCS     90$
3521     BIT     R1, MEMMAP+2      ;; CHECK FOR BANK EXISTS.
3522
3507 016424 022767 000003 162150
3508 016432 001401
3509 016434 000000
3510 016436
3511 016436 010046
3512 016440 010146
3513 016442 005767 162140
3514 016446 001465
3515 016450 012737 007600 172346
3516 016456 005000
3517 016460 012701 100000
3518 016464 162737 000200 172346
3519 016472 006001
3520 016474 006000
3521 016476 103500
3522 016500 030167 163022

```



```

3523 016504 001003      BNE      3$      ;BR IF AVAILABLE
3524 016506 030067 163012  BIT      RO,      MEMMAP ;CHECK FOR BANK EXISTS.
3525 016512 001764      BEQ      2$      ;BR IF NO BANK FOUND.
3526 016514 013737 172346 172344 3$:  MOV      2*#KIPAR3,2*#KIPAR2 ;COPY PAR
3527 016522 010046      MOV      RO,-(SP) ;PUSH RO ON STACK
3528 016524 010146      MOV      R1,-(SP) ;PUSH R1 ON STACK
3529 016526 162737 000200 172344 4$:  SUB      #200, 2*#KIPAR2 ;BACK DOWN WITH LOW PAR.
3530 016534 006001      ROR      R1      ;SHIFT POINTER.
3531 016536 006000      ROR      RO      ;...LO 64K.
3532 016540 103457      BCS      90$     ;BR IF OVERFLOW.
3533 016542 030167 162760      5$:  BIT      R1,      MEMMAP+2 ;CHECK IF BANK EXISTS...HI 64K.
3534 016546 001003      BNE      6$      ;BR IF BANK EXISTS.
3535 016550 030067 162750      BIT      RO,      MEMMAP ;CHECK IF BANK EXISTS...LO 64K.
3536 016554 001764      BEQ      4$      ;BR IF BANK DOESN'T EXIST.
3537 016556 052601      6$:  BIS      (SP)+, R1      ;GET SECOND BANK POINTER.
3538 016560 052600      BIS      (SP)+, RO      ;...LO 64K.
3539 016562 030067 162014      BIT      RO,      PRGMAP ;CHECK FOR CONFLICT.
3540 016566 001044      BNE      90$     ;ABORT IF DESTINATION OVERLAYS SOURCE.
3541 016570 004567 177506      JSR      R5,      RELOC ;GO RELOCATE PROGRAM.
3542 016574 000000      .WORD    0      ;SOURCE FIRST ADDRESS.
3543 016576 040000      .WORD    40000 ;DESTINATION FIRST ADDRESS.
3544 016600 013737 172344 172340  MOV      2*#KIPAR2,2*#KIPAR0 ;RELOCATE LO BANK
3545 016606 013737 172346 172342  MOV      2*#KIPAR3,2*#KIPAR1 ;RELOCATE HI BANK.
3546      ;* PROGRAM SHOULD NOW BE EXECUTING OUT OF LAST TWO BANKS OF MEMORY.
3547 016614 010167 161764      MOV      R1,      PRGMAP+2 ;RESET PROGRAM MAP.
3548 016620 000473      BR       30$     ;BR TO COMMON EXIT.
3549
3550 016622 012700 000400      10$:  MOV      #BIT8, RO ;SET BANK POINTER TO TOP OF MEM.
3551 016626 005001      CLR      R1      ;SET ADDRESS POINTER TO TOP.
3552 016630 162701 020000      11$:  SUB      #20000, R1 ;BACK DOWN ONE BANK.
3553 016634 006200      ASR      RO      ;MOVE POINTER DOWN ONE BANK.
3554 016636 103420      BCS      90$     ;BR IF OVERFLOW.
3555 016640 030067 162660      BIT      RO,      MEMMAP ;CHECK IF THIS BANK EXISTS.
3556 016644 001771      BEQ      11$     ;BR IF NON-EXISTANT BANK.
3557 016646 162701 020000      SUB      #20000, R1 ;BACK DOWN TO NEXT BANK.
3558 016652 006200      ASR      RO      ;MOV POINTER DOWN ONE BANK.
3559 016654 103411      BCS      90$     ;BR IF OVERFLOW.
3560 016656 030067 162642      BIT      RO,      MEMMAP ;CHECK IF THIS BANK EXISTS.
3561 016662 001762      BEQ      11$     ;BR TO START OVER IF NO LOWER BANK.
3562 016664 010046      MOV      RO,      -(SP) ;SAVE THE POINTER.
3563 016666 006300      ASL      RO      ;RESET POINTER TO HI BANK.
3564 016670 052600      BIS      (SP)+, RO ;SET BIT FOR LO BANK.
3565 016672 030067 161704      BIT      RO,      PRGMAP ;CHECK FOR A PROGRAM CONFLICT.
3566 016676 001401      BEQ      12$     ;BR IF NO CONFLICT.
3567 016700      90$:
3568 016700 000000      HALT      ;FATAL ERROR!!! NOT ENOUGH MEMORY??
3569 016702 010167 000006      12$:  MOV      R1,      13$     ;SET DATA FOR RELOCATION SUBROUTINE.
3570 016706 004567 177370      JSR      R5,      RELOC ;GO RELOCATE THE PROGRAM TO TOP OF MEM.
3571 016712 000000      .WORD    0      ;SOURCE STARTING ADDRESS.
3572 016714 000000      .WORD    0      ;DESTINATION STARTING ADDRESS.
3573 016716 010167 161656      13$:  MOV      R1,      RELOCF ;SET RELOCATION FACTOR IN UNRELOCATED CODE.
3574 016722 060107      ADD      R1,      PC      ;JUMP TO RELOCATED PROGRAM
3575      ;* PROGRAM NOW EXECUTING OUT OF TOP OF MEMORY.
3576 016724 060106      ADD      R1,      SP ;ADJUST THE STACK POINTER TO TOP OF MEMORY.
3577 016726 010167 161646      MOV      R1,      RELOCF ;SET THE RELOCATION FACTOR.
3578 016732 060137 000004      ADD      R1,      2*#ERRVEC ;ADJUST ERROR VECTOR.

```



```

3579 016736 060137 000024      ADD    R1,    2#PWRVEC ;ADJUST POWER FAIL VECTOR.
3580 016742 060137 000114      ADD    R1,    2#PARVEC ;ADJUST PARITY ERROR VECTOR.
3581 016746 026727 162166 177570  CMP    SWR,    #177570 ;CHECK FOR HARDWARE SWITCH REGISTER.
3582 016754 001404          BEQ     14$      ;BR IF HARDWARE SWITCH REGISTER.
3583 016756 060167 162156      ADD    R1,    SWR      ;ADJUST SOFTWARE SWITCH REGISTER.
3584 016762 060167 162154      ADD    R1,    DISPLAY ;ADJUST SOFTWARE DISPLAY REGISTER.
3585 016766 062701 001622      14$:  ADD    #RACDAB,R1 ;POINT TO THE RELATIVE RELOCATION TABLE.
3586 016772 066721 161602      15$:  ADD    RELOC, (R1)+ ;ADD RELOCATION FACTOR TO ADDRESSES IN TABLE.
3587 016776 005721          16$:  TST    (R1)+ ;CHECK FOR INTERUM TERMINATOR.
3588 017000 001776          BEQ     16$      ;BR SO AS TO NOT MODIFY ZERO.
3589 017002 024127 177777      CMP     -(R1), #-1 ;CHECK FOR END OF TABLE.
3590 017006 001371          BNE     15$      ;BR IF MORE IN TABLE.
3591 017010 010067 161566      30$:  MOV     R0,    PRGMAP ;SET NEW PROGRAM MAP...LO 64K.
3592 017014 012601          MOV     (SP)+,R1 ;POP STACK INTO R1
3593 017016 012600          MOV     (SP)+,R0 ;POP STACK INTO R0
3594 017020 066716 161554      ADD     RELOC, (SP) ;ADJUST RETURN ADDRESS.
3595 017024 000207          RTS     PC      ;RETURN
3596
3597 ;*****
3598 ;* SUBROUTINE TO RELOCATE PROGRAM BACK TO BANKS 0 AND 1.
3599 ;*****
3600 017026 032767 000003 161546 RELO:  BIT     #3,    PRGMAP ;CHECK FOR PROGRAM ALREADY IN BANKS 0 OR 1.
3601 017034 001401          BEQ     1$      ;BR IF NO CONFLICT.
3602 017036 000000          HALT          ;FATAL ERROR!!! PROGRAM ALREADY IN BANKS 0 OR 1!!!!
3603 017040 005767 161542      1$:  TST     MMAVA ;CHECK FOR MEM MGMT.
3604 017044 001417          BEQ     10$     ;BR IF NO MEMMGMT.
3605 017046 005037 172344      CLR     2#KIPAR2 ;SET PAR 2 TO BANK 0.
3606 017052 012737 000200 172346      MOV     #200, 2#KIPAR3 ;SET PAR 3 TO BANK 1.
3607 017060 004567 177216      JSR     R5,    RELOC ;GO MOVE BK INTO BANKS 0 AND 1.
3608 017064 000000          .WORD    0 ;SOURCE STARTING ADDRESS.
3609 017066 040000          .WORD    40000 ;DESTINATION STARTING ADDRESS.
3610 017070 005037 172340      CLR     2#KIPAR0 ;RESTORE PAR 0 TO BANK0.
3611 017074 012737 000200 172342      MOV     #200, 2#KIPAR1 ;RESTORE PAR 1 TO BANK 1.
3612 ;* PROGRAM IS NOW EXICUTING OUT OF BANKS 0 AND 1.
3613 017102 000444          BR      30$      ;BR TO COMMON EXIT.
3614
3615 017104 016746 161470      10$:  MOV     RELOC, -(SP) ;PUT RELOCATION FACTOR ONTO THE STACK.
3616 017110 011667 000004      MOV     (SP), 20$ ;SET DATA FOR RELOC SUBROUTINE.
3617 017114 004567 177162      JSR     R5,    RELOC ;GO MOVE THE PROGRAM BACK TO BANKS 0 AND 1.
3618 017120 000000          20$:  .WORD    0 ;SOURCE STARTING ADDRESS.
3619 017122 000000          .WORD    0 ;DESTINATION STARTING ADDRESS.
3620 017124 161607          SUB     (SP), PC ;JUMP TO RELOCATED PROGRAM.
3621 ;* THE PROGRAM IS NOW EXICUTING OUT OF BANKS 0 AND 1.
3622 017126 161606          SUB     (SP), SP ;RESET THE STACK POINTER.
3623 017130 010046          MOV     R0, -(SP) ;PUSH R0 ON STACK
3624 017132 012700 001622      MOV     #RACDAB,R0 ;SET UP POINTER TO RELATIVE ADDRESS TABLE.
3625 017136 166620 000002      21$:  SJB     2(SP), (R0)+ ;RESET ADDRESSES TO UNRELOCATED VALUES.
3626 017142 005720          22$:  TST     (R0)+ ;CHECK FOR TERMINATORS.
3627 017144 001776          BEQ     22$      ;BR OVER TERMINATORS.
3628 017146 024027 177777      CMP     -(R0), #-1 ;CHECK FOR END OF TABLE INDICATOR.
3629 017152 001371          BNE     21$      ;BR IF MORE ADDRESSES IN TABLE.
3630 017154 012600          M       (SP)+,R0 ;POP STACK INTO R0
3631 017156 161637 000004          SUB     (SP), 2#ERRVEC ;ADJUST ERROR VECTOR.
3632 017162 161637 000024          SUB     (SP), 2#PWRVEC ;ADJUST POWER FAIL VECTOR.
3633 017166 161637 000114          SUB     (SP), 2#PARVEC ;ADJUST PARITY ERROR VECTOR.
3634 017172 026727 161742 177570  CMP    SWR,    #177570 ;CHECK FOR HARDWARE SWITCH REGISTER.

```



```

3635 017200 001404 BEQ 23$ ;BR IF HARDWARE SWITCH REGISTER.
3636 017202 161667 161732 SUB (SP), SWR ;ADJUST SOFTWARE SWITCH REGISTER.
3637 017206 161667 161730 SUB (SP), DISPLAY ;ADJUST SOFTWARE DISPLAY REGISTER.
3638 017212 162616 30$: SUB (SP), SP ;ADJUST RETURN ADDRESS.
3639 017214 005067 161360 30$: CLR RELOC ;RESET RELOCATION FACTOR.
3640 017220 012767 000003 161354 MOV B3 PRGMAP ;SET PROGRAM MAP TO POINT TO BANKS 0 AND 1.
3641 017226 005067 161352 CLR PRGMAP+2 ;HI 64K.
3642 017232 000207 RTS PC ;RETURN.
3643
3644
3645 *****
3646 * THIS SUBROUTINE MOVES THE LOADER AREA BACK TO THE "TOP" OF MEMORY FROM
3647 * WHENCE IT CAME. THE LOADER AREA IS SAVED AT THE END OF THE BK OF
3648 * PROGRAM CODE WHEN THE PROGRAM IS INITIALLY RUN.
3649 *****
3649 017234 016700 162260 RESLDR: MOV LMAD, R0 ;CHECK IF THE LOADERS WERE SAVED.
3650 017240 001001 BNE 1$ ;BR IF LOADER AREA WAS SAVED.
3651 017242 000000 HALT ;FATAL ERROR!!! CAN'T RESTORE LOADER AREA IF IT WASN'T SAVED.
3652 017244 005767 161336 1$: TST MMAVA ;CHECK FOR MEM MGMT.
3653 017250 001402 BEQ 2$ ;SKIP IF NO MEM MGMT.
3654 017252 005037 177572 CLR 2$SR0 ;DISABLE MEM MGMT.
3655 017256 012701 040000 2$: MOV 2$0000, R1 ;GET END OF BK, ASSUME PROG NOT RELOCATED.
3656 017262 012702 002734 MOV 2$1500, R2 ;GET COUNTER.
3657 017266 014140 3$: MOV -(R1), -(R0) ;MOVE THE LOADER AREA.
3658 017270 005302 DEC R2 ;COUNT HOW LONG THE AREA IS.
3659 017272 001375 BNE 3$ ;BR IF NOT MORE TO MOVE.
3660 017274 005067 162220 CLR LMAD ;CLEAR MONITOR SAVED FLAG.
3661 017300 005767 161302 TST MMAVA ;CHECK FOR MEM MGMT.
3662 017304 001402 BEQ 4$ ;BR IF NO MEM MGMT.
3663 017306 005237 177572 INC 2$SR0 ;ENABLE MEM MGMT.
3664 017312 000207 4$: RTS PC ;RETURN.
3665
3666 * ROUTINE TO SAVE THE LOADERS AT THE END OF BK.
3667 017314 005767 162200 SAVLDR: TST LMAD ;CHECK IF LOADERS HAVE BEEN SAVED ALREADY.
3668 017320 001024 BNE 4$ ;BRANCH IF ALREADY SAVED
3669 017322 012700 040000 MOV 2$0000, R0 ;GET END OF BK
3670 017326 010001 MOV R0, R1 ;GET END OF BK
3671 017330 012737 017342 000004 MOV 2$2$ERRVEC ;SET UP TIMEOUT VECTOR
3672 017336 011020 1$: MOV (R0), (R0)+ ;SEARCH FOR END OF MEMORY
3673 017340 000776 BR 1$ ;KEEP SEARCHING
3674 017342 022626 2$: CMP (SP)+, (SP)+ ;RESTORE STACK POINTER
3675 017344 012737 025060 000004 MOV 2$ERRATP, 2$ERRVEC ;RESET TIMEOUT VECTOR.
3676 017352 010046 MOV R0, -(SP) ;SAVE LAST MEMORY ADDRESS (CONTIGUOUS)
3677 017354 012702 002734 MOV 2$1500, R2 ;SET UP WORD COUNTER
3678 017360 014041 3$: MOV -(R0), -(R1) ;SAVE THE LOADERS
3679 017362 005302 DEC R2 ;COUNT THE WORDS
3680 017364 001375 BNE 3$ ;BRANCH IF MORE WORDS
3681 017366 012667 162126 MOV (SP)+, LMAD ;SAVE LAST MEMORY ADDRESS
3682 017372 000207 4$: RTS PC ;RETURN

```



```

3683 .SBTTL PARITY MEMORY TRAP SERVICE AND SUBROUTINES.
3684 ;*****
3685 ;* PARITY MEMORY UNEXPECTED ERROR TRAP SERVICE ROUTINE.
3686 ;* FIND OUT WHICH REGISTER DETECTED THE ERROR.
3687 ;* THEN SCAN MEMORY TO SEE IF PARITY ERROR STILL SET AND REPORT LOCATION.
3688 ;*****
3689 PESRV: MOV (SP), SBDADR ;GET PC OF INSTRUCTION WHICH CAUSED ERROR.
3690 JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
3691 .WORD UNEXPT ;ADDRESS OF MESSAGE TO BE TYPED
3692 ;"UNEXPECTED MEMORY PARITY TRAP."
3693 MOV R1, -(SP) ;PUSH R1 ON STACK
3694 MOV R3, -(SP) ;PUSH R3 ON STACK
3695 MOV MPRX, R3 ;SET POINTER TO PARITY REGISTERS.
3696 1$: TST 2(R3)+ ;CHECK THE PARITY REG FOR AN ERROR FLAG.
3697 BMI 3$ ;BR IF THIS REGISTER SHOWS THE ERROR.
3698 TST (R3) ;CHECK FOR TABLE TERMINATOR.
3699 BNE 1$ ;BR IF MORE REGISTERS.
3700 JSR PC, SERROR ;*** ERROR *** (GO TYPE A MESSAGE)
3701 ;***ERROR*** NO REGISTER INDICATED ERROR
3702 .WORD 24 ;ERROR TYPE CODE.
3703 BR 4$ ;EXIT
3704 2$: TST (R3) ;CHECK FOR TABLE TERMINATOR.
3705 BEQ 4$ ;BR IF NO MORE PARITY REGISTERS.
3706 TST 2(R3)+ ;CHECK THE PARITY REG FOR AN ERROR FLAG.
3707 BPL 2$ ;BR IF NO ERROR FLAG.
3708 JSR R5, SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
3709 .WORD MTOE ;ADDRESS OF MESSAGE TO BE TYPED
3710 ;"MORE THAN ONE ERROR FOUND."
3711 3$: JSR PC, SPRNTQ ;SET UP VALUES FOR ERROR PRINTING.
3712 64$: JSR PC, SERROR ;*** ERROR *** (GO TYPE A MESSAGE)
3713 .WORD 25 ;ERROR TYPE CODE.
3714 JSR PC, PSCAN ;GO SCAN MEMORY FOR BAD PARITY.
3715 BR 2$ ;GO LOOK FOR MORE ERRORS.
3716 4$: MOV (SP)+, R3 ;POP STACK INTO R3
3717 MOV (SP)+, R1 ;POP STACK INTO R1
3718 RTI ;RETURN.
3719
3720 ;*****
3721 ;ROUTINE TO ENABLE PARITY ERROR ACTION ON MA/MF PARITY MEMORIES
3722 ;THIS ROUTINE IS MEANT TO CATCH UNEXPECTEDS
3723 ;*****
3724 MAMF: TST MPRX ;CHECK IF ANY PARITY REGISTERS EXIST.
3725 BEQ MAMF2 ;EXIT IF NO PARITY REGISTERS.
3726 BIT #SW6, 2SWR ;CHECK FOR INHIBIT PARITY ERROR DETECTION.
3727 BNE MAMF2 ;EXIT IF NO PARITY ERROR DETECTION.
3728 TST RELOCF ;CHECK IF PROGRAM RELOCATED OUT OF BANK 0.
3729 BEQ SETAE ;BR IF PROG IN BANK 0.
3730 BIT #SW5, 2SWR ;CHECK IF VECTORS PROTECTED.
3731 BNE SETAE ;BR IF VECTOR AREA PROTECTED.
3732 CMP FSTADR, #1000 ;CHECK FOR STARTING ADDRESS ABOVE THE VECTORS.
3733 BLO MAMF2 ;EXIT IF VECTORS EXPOSED TO TESTING.
3734
3735 017374 011667 161522
017400 004567 004052
017404 026445
017406 010146
017410 010346
017412 016703 162212
017416 005733
017420 100415
017422 005713
017424 001374
017426 004767 002152
017432 000024
017434 000417
017436 005713
017440 001415
017442 005733
017444 100374
017446 004567 004004
017452 026536
017454
017454 004767 000610
017460 004767 002120
017464 000025
017466 004767 000216
017472 000761
017474
017474 012603
017476 012601
017500 000002
017502 005767 162570
017506 001434
017510 032777 000100 161422
017516 001030
017520 005767 161054
017524 001410
017526 032777 000040 161404
017534 001004
017536 026727 162020 001000
017544 103415

```



```

3736 017546 016737 162064 000114 SETAE: MOV .PESRV, 2*PARVEC ;SET PARITY ERROR TRAP VECTOR
3737 017554 005037 000116 CLR 2*PARVEC+2 ;PRIORITY LEVEL 0 ON TRAP
3738 017560 010346 MOV R3, -(SP) ;PUSH R3 ON STACK
3739 017562 016703 162042 MOV .MPRX, R3 ;GET PARITY REGISTER TABLE POINTER.
3740 017566 052733 000001 MAMF1: BIS #AE, 2(R3)+ ;SET ACTION ENABLE BIT IN PARITY REG
3741 017572 005713 TST (R3) ;CHECK FOR END OF TABLE.
3742 017574 001374 BNE MAMF1 ;BR IF MORE PARITY REGISTERS.
3743 017576 012603 MOV (SP)+, R3 ;POP STACK INTO R3
3744 017600 000207 MAMF2: RTS PC ;RETURN.
3745
3746 ;*****
3747 ;* SUBROUTINE TO CHECK PARITY REGISTERS FOR ERRORS THAT DIDN'T TRAP.
3748 ;*****
3749 017602 005767 162470 CKPMER: TST MPRX ;CHECK IF ANY PARITY REGISTERS EXIST.
3750 017606 001437 BEQ 4$ ;BR IF NO PARITY REGISTERS.
3751 017610 032777 000100 161322 BIT #SW6, 2SWR ;CHECK FOR INHIBIT PARITY ERROR CHECKING.
3752 017616 001033 BNE 4$ ;BR IF PARITY ERROR CHECKING INHIBITED.
3753 017620 010346 MOV R3, -(SP) ;PUSH R3 ON STACK
3754 017622 016703 162002 MOV .MPRX, R3 ;GET PARITY REG TABLE POINTER.
3755 017626 005733 1$: TST 2(R3)+ ;CHECK THE PARITY REG FOR AN ERROR FLAG.
3756 017630 100023 BPL 3$ ;BR IF NO ERROR
3757 017632 032773 000001 177776 BIT #BIT0, 2-2(R3) ;CHECK IF A TRAP SHOULD HAVE OCCURRED.
3758 017640 001010 BNE 2$ ;BR IF NO ACTION ENABLE.
3759 017642 004767 000422 64$: JSR PC, SPRTQ ;SET UP VALUES FOR ERROR PRINTING.
3760 017646 004767 001732 JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
3761 017652 000026 .WORD 26 ;ERROR TYPE CODE.
3762 017654 000411 BR 3$
3763 017656 004767 000026 JSR PC, PSCAN ;GO SCAN ALL MEMORY FOR PARITY ERRORS.
3764 017662 2$:
3765 017662 004767 000402 65$: JSR PC, SPRTQ ;SET UP VALUES FOR ERROR PRINTING.
3766 017666 004767 001712 JSR PC, $ERROR ;*** ERROR *** (GO TYPE A MESSAGE)
3767 017672 000027 .WORD 27 ;ERROR TYPE CODE.
3768 017674 004767 000010 JSR PC, PSCAN ;GO SCAN ALL MEMORY FOR PARITY ERRORS.
3769 017700 005713 3$: TST (R3) ;CHECK FOR TABLE TERMINATOR.
3770 017702 001351 BNE 1$ ;BR IF MORE.
3771 017704 012603 MOV (SP)+, R3 ;POP STACK INTO R3
3772 017706 000207 4$: RTS PC ;RETURN.
3773
3774 ;*****
3775 ;* THIS SUBROUTINE WILL SCAN ALL OF MEMORY LOOKING FOR BAD PARITY,
3776 ;* TYPE OUT ALL LOCATIONS FOUND TO BE BAD, AND WRITE BACK INTO THE
3777 ;* LOCATIONS IN ORDER TO RESTORE GOOD PARITY.
3778 ;*****

```



3779	017710			PSCAN:	MOV	R0,-(SP)	;; PUSH R0 ON STACK
3780	017710	010046			MOV	R1,-(SP)	;; PUSH R1 ON STACK
3781	017712	010146			MOV	R2,-(SP)	;; PUSH R2 ON STACK
3782	017714	010246			MOV	R3,-(SP)	;; PUSH R3 ON STACK
3783	017716	010346			MOV	R4,-(SP)	;; PUSH R4 ON STACK
3784	017720	010446			MOV	2#114,-(SP)	;; PUSH 2#114 ON STACK
3785	017722	013746	000114		MOV	2#116,-(SP)	;; PUSH 2#116 ON STACK
3786	017726	013746	000116		JSR	R5 \$PRINT	GO PRINT OUT THE FOLLOWING MESSAGE.
3787	017732	004567	003520		.WORD	SCANM	ADDRESS OF MESSAGE TO BE TYPED
3788	017736	026602					"SCANNING MEMORY FOR BAD PARITY."
3789							SET BIT POINTER TO FIRST BANK.
3790	017740	012700	000001		MOV	#BIT0, R0	CLR HI 64K POINTER.
3791	017744	005001			CLR	R1	INIT ADDRESS POINTER.
3792	017746	005002			CLR	R2	INIT ERROR DETECTED FLAG.
3793	017750	005004			CLR	R4	CLEAR THE PARITY REGISTERS.
3794	017752	004767	000256		JSR	PC CLRPAR	HALT IF ANOTHER PARITY TRAP.
3795	017756	012737	000116	000114	MOV	2#116, 2#114	
3796	017764	005037	000116		CLR	2#116	
3797	017770	005767	160612		TST	MMAVA	;; CHECK FOR MEMORY MANAGEMENT.
3798	017774	001406			BEQ	1\$	BR IF NO MEM MGMT.
3799	017776	013746	172344		MOV	2#KIPAR2,-(SP)	;; PUSH 2#KIPAR2 ON STACK
3800	020002	005037	172344		CLR	2#KIPAR2	INIT MEM MGMT TO POINT TO BANK 0.
3801	020006	012702	040000		MOV	#40000, R2	SET ADR POINTER TO PAR2.
3802	020012	030067	161506	1\$:	BIT	R0, MEMMAP	;; CHECK IF THIS BANK OF MEM EXISTS.
3803	020016	001003			BNE	2\$	BR IF THIS BANK EXISTS.
3804	020020	030167	161502		BIT	R1, MEMMAP+2	;; CHECK HI 64K MAP.
3805	020024	001442			BEQ	10\$	BR IF THIS BANK DOESN'T EXIST.
3806	020026			2\$:			
3807	020026	010146			MOV	R1,-(SP)	;; PUSH R1 ON STACK
3808	020030	111201			MOV	(R2), R1	READ THE LOCATION TO SEE IF IT HAS A PARITY ERROR.
3809	020032	016703	161572		MOV	.MPRX, R3	SET UP POINTER TO PARITY REGISTERS.
3810	020036	005733		4\$:	TST	2(R3)+	;; CHECK FOR THE ERROR FLAG.
3811	020040	100024			BPL	6\$	BR IF NO ERROR FLAG.
3812	020042	005704			TST	R4	;; CHECK IF FIRST ERROR, THIS SCAN.
3813	020044	001003			BNE	5\$	BR IF MORE THAN ONE ERROR FOUND.
3814	020046	005367	161040		DEC	\$ERTTL	ADJUST ERROR COUNT.
3815	020052	005204			INC	R4	SET FLAG TO INDICATE ERROR FOUND.
3816	020054			5\$:			
3817	020054	004767	000210	64\$:	JSR	PC, SPRTQ	SET UP VALUES FOR ERROR PRINTING.
3818	020060	004767	001520		JSR	PC, \$ERROR	*** ERROR *** (GO TYPE A MESSAGE)
3819	020064	000030			.WORD	30	ERROR TYPE CODE.
3820	020066	111212			MOV	(R2), (R2)	REWRITE THE LOCATION TO CLEAR BAD PARITY.
3821	020070	005053			CLR	2-(R3)	CLEAR THE ERROR FLAG.
3822	020072	105712			TST	(R2)	;; CHECK IF THE PARITY ERROR WAS CLEARED.
3823	020074	005733			TST	2(R3)+	;; CHECK FOR THE ERROR FLAG.
3824	020076	100005			BPL	6\$	BR IF IT IS OK.
3825	020100	004567	003352		JSR	R5 \$PRINT	GO PRINT OUT THE FOLLOWING MESSAGE.
3826	020104	026644			.WORD	PEWNC	ADDRESS OF MESSAGE TO BE TYPED
3827							"PARITY ERROR WILL NOT CLEAR."
3828	020106	005073	177776		CLR	2-2(R3)	CLEAR OUT THE PARITY ERROR FLAG.
3829	020112	005713		6\$:	TST	(R3)	;; CHECK FOR THE END OF REG ADR TABLE.
3830	020114	001350			BNE	4\$	BR IF MORE PARITY REGISTERS.
3831	020116	005202			INC	R2	GO TO NEXT MEMORY ADDRESS.
3832	020120	032702	017777		BIT	#MASK4K, R2	;; CHECK FOR END OF 4K BANK.
3833	020124	001341			BNE	3\$	BR IF MORE MEMORY THIS BANK.
3834	020126	012601			MOV	(SP)+, R1	;; POP STACK INTO R1



```

3835 020130 000402 BR 11$ ;BR TO CHECK FOR NEXT BANK.
3836 020132 062702 020000 10$: ADD #20000, R2 ;SKIP BANKS THAT AREN'T THERE.
3837 020136 005767 160444 11$: TST MMABA ;CHECK FOR MEM MGMT.
3838 020142 001413 BEQ 12$ ;BR IF NO MEM MGMT.
3839 020144 062737 000200 172344 ADD #200, 2#KIPAR2 ;UPDATE MEM MGMT REG TO NEXT 4K.
3840 020152 012702 040000 MOV #40000, R2 ;RESET ADDRESS POINTER TO BEGINNING OF BANK.
3841 020156 006300 ASL R0 ;UPDATE BANK POINTER.
3842 020160 006101 ROL R1 ;HI 64K.
3843 020162 100313 BPL 1$ ;BR IF MORE BANKS.
3844 020164 012637 172344 MOV (SP)+, 2#KIPAR2 ;POP STACK INTO 2#KIPAR2
3845 020170 000402 BR 20$ ;GO CHECK IF ANY ERRORS FOUND.
3846 020172 106300 12$: ASLB R0 ;UPDATE POINTER TO NEXT BANK.
3847 020174 100306 BPL 1$ ;BR IF MORE BANKS.
3848 020176 005704 20$: TST R4 ;CHECK IF ANY PARITY ERRORS DETECTED.
3849 020200 001003 BNE 21$ ;BR IF ERRORS DETECTED.
3850 020202 004567 003250 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
3851 020206 025652 .WORD NOPE$ ;ADDRESS OF MESSAGE TO BE TYPED
3852 020210 21$: MOV (SP)+, 2#116 ;POP STACK INTO 2#116
3853 020210 012637 000116 MOV (SP)+, 2#114 ;POP STACK INTO 2#114
3854 020214 012637 000114 MOV (SP)+, R4 ;POP STACK INTO R4
3855 020220 012604 MOV (SP)+, R3 ;POP STACK INTO R3
3856 020222 012603 MOV (SP)+, R2 ;POP STACK INTO R2
3857 020224 012602 MOV (SP)+, R1 ;POP STACK INTO R1
3858 020226 012601 MOV (SP)+, R0 ;POP STACK INTO R0
3859 020230 012600 RTS PC ;RETURN.
3860 020232 000207
3861
3862 ;*****
3863 ;ROUTINE TO CLEAR ALL PARITY REGISTERS PRESENT
3864 ;*****
3865 020234 CLRPAR:
3866 020234 010346 MOV R3, -(SP) ;PUSH R3 ON STACK
3867 020236 016703 161366 MOV .MPRX, R3 ;GET PARITY REGISTER TABLE POINTER.
3868 020242 005713 1$: TST (R3) ;CHECK FOR THE TABLE TERMINATOR.
3869 020244 001402 BEQ 2$ ;BR IF DONE ALL PARITY REGISTERS.
3870 020246 005033 CLR 2(R3)+ ;CLEAR THE PARITY REGISTER.
3871 020250 000774 BR 1$ ;BR FOR MORE
3872 020252 2$: MOV (SP)+, R3 ;POP STACK INTO R3
3873 020252 012603 RTS PC ;RETURN.
3874 020254 000207
3875
3876 .SBTTL SUBROUTINES TO SET UP DATA FOR ERROR PRINTOUT ROUTINE.
3877 ;*****
3878 ;* THESE ROUTINES ARE USED TO TRANSFER DATA TO COMMON TAG AREA (.SCMT)
3879 ;* FOR ERROR PRINTOUT BY .$ERROR & .$ERRTYP ROUTINES FROM **SYSMAC**.
3880 ;*****
3881 020256 010267 160636 SPRNT: MOV R2, $GDADR ;SAVE THE ADDRESS UNDER TEST.
3882 020262 005067 160636 CLR $GDDAT ;SHOULD BE DATA IS "0".
3883 020266 000430 BR SPRNTB
3884
3885 020270 014367 160664 SPRNTQ: MOV -(R3), $TMP0 ;GET THE PARITY REGISTER ADDRESS.
3886 020274 013367 160662 MOV 2(R3)+, $TMP1 ;GET THE CONTENTS OF THE PARITY REG.
3887 020300 000402 BR SPRNTQ
3888
3889 020302 011367 160652 SPRNTP: MOV (R3), $TMP0 ;GET THE PARITY REGISTER ADDRESS.
3890 020306 010267 160606 SPRNTQ: MOV R2, $GDADR ;GET THE MEMORY ADDRESS BEING TESTED

```



```

3891 020312 000414 BR SPRNTA ;BR TO COMMON SECTION.
3892
3893 020314 010267 160600 SPRNT1: MOV R2, $GDADR ;GET THE MEMORY ADDRESS BEING TESTED
3894 020320 005367 160574 DEC $GDADR ;ADJUST IT FOR PRINTOUT.
3895 020324 000407 BR SPRNTA ;BR TO COMMON SECTION.
3896
3897 020326 010367 160626 SPRNT3: MOV R3, $TMPD ;GET THE DATA IN R3.
3898 020332 010267 160562 SPRNT2: MOV R2, $GDADR ;GET THE MEMORY ADDRESS BEING TESTED
3899 020336 162767 000002 160554 SUB #2, $GDADR ;ADJUST IT FOR PRINTOUT.
3900 020344 010067 160554 SPRNTA: MOV R0, $GDDAT ;GET WHAT THE DATA SHOULD BE
3901 020350 010167 160552 SPRNTB: MOV R1, $BDDAT ;GET WHAT THE DATA WAS
3902 020354 000207 RTS PC ;RETURN TO ENTER ERROR ROUTINES
3903
3904 ;*****
3905 ;* SUBROUTINE TO TYPE OUT A MAP OF 4K BANK.
3906 ;* R0 POINTS TO THE MAP UPON ENTERING THIS ROUTINE.
3907 ;*****
3908 020356 005710 TYPMAP: TST (R0) ;CHECK IF ANY MEMORY IN MAP...LO 64K.
3909 020360 001007 BNE 1$ ;BR IF MEMORY IN MAP.
3910 020362 005760 000002 TST 2(R0) ;...HI 64K.
3911 020366 001004 BNE 1$ ;BR IF MEMORY IN MAP.
3912 020370 004567 003062 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
3913 020374 026232 .WORD NOMEM ;ADDRESS OF MESSAGE TO BE TYPED
3914 ;"NO MEMORY FOUND."
3915 020376 000475 BR 6$ ;EXIT
3916 020400 1$: MOV R1, -(SP) ;PUSH R1 ON STACK
3917 020400 010146 MOV R2, -(SP) ;PUSH R2 ON STACK
3918 020402 010246 MOV R3, -(SP) ;PUSH R3 ON STACK
3919 020404 010346 MOV R4, -(SP) ;PUSH R4 ON STACK
3920 020406 010446 MOV #BIT0, R1 ;SET UP BANK POINTER...LO 64K.
3921 020410 012701 000001 MOV R2, #1, R3 ;...HI 64K.
3922 020414 005002 CLR R2 ;SET UP ADDRESS POINTER TO -1.
3923 020416 012703 177777 MOV R3, R4 ;HI BITS OF ADDRESS AS WILL.
3924 020422 010304 2$: BIT R1, (R0) ;CHECK THE MAP FOR THIS BANK.
3925 020424 030110 BNE 3$ ;BR IF THIS BANK PRESENT.
3926 020426 001014 BIT R2, 2(R0) ;CHECK HI 64K MAP.
3927 020430 030260 000002 BNE 3$ ;BR IF THIS BANK PRESENT.
3928 020434 001011 TSTB R3 ;CHECK FOR PREVIOUS PRINTOUT.
3929 020436 105703 BNE 5$ ;BR IF ALREADY TYPED "TO"
3930 020440 001042 SUB #1, R3 ;BACK UP TO LAST ADR OF PREVIOUS BANK.
3931 020442 162703 000001 SBC R4, R3 ;...HI ADDRESS BITS.
3932 020446 005604 SBC R4, R4 ;GO PRINT OUT THE FOLLOWING MESSAGE.
3933 020450 004567 003002 JSR R5, $PRINT ;ADDRESS OF MESSAGE TO BE TYPED
3934 020454 025463 .WORD TO ;GO TO TYPE THE ADDRESS.
3935 020456 000410 BR 4$ ;CHECK FOR PREVIOUS TYPEOUT.
3936 020460 105703 3$: TSTB R3 ;BR IF ALREADY TYPE "FROM".
3937 020462 001431 BEQ 5$ ;POINT TO FIRST ADDRESS OF THIS BANK.
3938 020464 062703 000001 ADD #1, R3 ;...HI BITS OF ADDRESS.
3939 020470 005504 ADC R4, R4 ;GO PRINT OUT THE FOLLOWING MESSAGE.
3940 020472 004567 002760 JSR R5, $PRINT ;ADDRESS OF MESSAGE TO BE TYPED
3941 020476 025453 .WORD FROM
3942 020500 4$: MOV R3, -(SP) ;PUSH R3 ON STACK
3943 020500 010346 MOV R4, -(SP) ;PUSH R4 ON STACK
3944 020502 010446 ASL R3 ;BIT 15 INTO C-BIT
3945 020504 006303 ROL R4 ;BIT 15 INTO R4.
3946 020506 006104

```



## H13

CZQMCEO 0-124K MEMORY EXERCISER, 16K VER  
CZQMCE.P11 10-JAN-78 12:56

MACY11 30A(1052) 10-JAN-78 13:12 PAGE 81  
SUBROUTINES TO SET UP DATA FOR ERROR PRINTOUT ROUTINE.

SEQ 0163

```

3947 020510 006003          ROR    R3          ;RESTORE BITS 14-0.
3948 020512 010446          MOV    R4,-(SP)      ;SAVE R4 FOR TYPEOUT
3949                                     ;TYPE ADDRESS BITS 21-15
3950                                     ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
3951                                     ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
3952 020514 013746 177776    MOV    $PSW, -(SP)  ;PUT THE PROCESSOR STATUS ON THE STACK
3953 020520 004767 004104    JSR    PC, $TYPOS  ;GO TO THE SUBROUTINE
3954 020524      003          .BYTE 3          ;TYPE 3 DIGIT(S)
3955 020525      000          .BYTE 0          ;SUPPRESS LEADING ZEROS
3956 020526 010346          MOV    R3,-(SP)      ;SAVE R3 FOR TYPEOUT
3957                                     ;TYPE ADDRESS BITS 14-0
3958                                     ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
3959                                     ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
3960 020530 013746 177776    MOV    $PSW, -(SP)  ;PUT THE PROCESSOR STATUS ON THE STACK
3961 020534 004767 004070    JSR    PC, $TYPOS  ;GO TO THE SUBROUTINE
3962 020540      005          .BYTE 5          ;TYPE 5 DIGIT(S)
3963 020541      001          .BYTE 1          ;TYPE LEADING ZEROS
3964 020542 012604          MOV    (SP)+,R4      ;POP STACK INTO R4
3965 020544 012603          MOV    (SP)+,R3      ;POP STACK INTO R3
3966 020546 062703 020000    $S:  ADD    $20000, R3 ;UPDATE TO NEXT BANK.
3967 020552 005504          ADC    R4          ;HI ADDRESS BITS.
3968 020554 006301          ASL    R1          ;SHIFT POINTER...LO 64K.
3969 020556 006102          ROL    R2          ;HI 64K.
3970 020560 103321          BCC    $S          ;BR IF MORE BANKS.
3971 020562 012604          MOV    (SP)+,R4      ;POP STACK INTO R4
3972 020564 012603          MOV    (SP)+,R3      ;POP STACK INTO R3
3973 020566 012602          MOV    (SP)+,R2      ;POP STACK INTO R2
3974 020570 012601          MOV    (SP)+,R1      ;POP STACK INTO R1
3975 020572 000207          $S:  RTS    PC      ;RETURN.
3976
3977 .SBTTL  SCOPE HANDLER ROUTINE
3978
3979 ;*****
3980 ;THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
3981 ;AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
3982 ;AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
3983 ;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
3984 ;*SW14=1      LOOP ON TEST
3985 ;*SW11=1      INHIBIT ITERATIONS
3986 ;*SW09=1      LOOP ON ERROR
3987 ;*SW08=1      LOOP ON TEST IN SWR<4:0>
3988 ;*CALL
3989 ;*      SCOPE          ;;SCOPE=IOT
3990
3991 020574
3992 $SCOPE:
3993 ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $CKSWR ROUTINE
3994 ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
3995 020574 013746 177776    MOV    $PSW, -(SP)  ;PUT THE PROCESSOR STATUS ON THE STACK
3996 020600 004767 001524    JSR    PC, $CKSWR  ;GO TO THE SUBROUTINE
3997 020604 012504          MOV    (R5)+, R4      ;SAVE MINIMUM BLOCK MASK NEXT TEST.
3998 020606 010516          MOV    R5, (SP)      ;PUT RETURN PC ONTO STACK, SIMULATE JSR PC.
3999 020610 032777 040000 160322 1$:  BIT    $BIT14,$SWR ;LOOP ON PRESENT TEST?
4000          BNE    $OVER          ;YES IF SW14=1
4001          ;*****START OF CODE FOR THE XOR TESTER*****
4002 $XTSTR: BR    $S          ;IF RUNNING ON THE "XOR" TESTER CHANGE
                           ;THIS INSTRUCTION TO A "NOP" (NOP=240)

```



4003	020622	013746	000004		MOV	2#ERRVEC, -(SP)	;; SAVE THE CONTENTS OF THE ERROR VECTOR
4004	020626	012737	020646	000004	MOV	55, 2#ERRVEC	;; SET FOR TIMEOUT
4005	020634	005737	177060		TST	2#177060	;; TIME OUT ON XOR?
4006	020640	012637	000004		MOV	(SP)+, 2#ERRVEC	;; RESTORE THE ERROR VECTOR
4007	020644	000466			BR	55VLAD	;; GO TO THE NEXT TEST
4008	020646	022626			5\$: CMP	(SP)+, (SP)+	;; CLEAR THE STACK AFTER A TIME OUT
4009	020650	012637	000004		MOV	(SP)+, 2#ERRVEC	;; RESTORE THE ERROR VECTOR
4010	020654	000426			BR	75	;; LOOP ON THE PRESENT TEST
4011	020656				6\$: ; #####	END OF CODE FOR THE XOR	TESTER#####
4012	020656	032777	000400	160254	BIT	2#BIT08, 2SWR	;; LOOP ON SPEC. TEST?
4013	020664	001407			BEQ	25	;; BR IF NO
4014	020666	017746	160246		MOV	2SWR, -(SP)	;; SET DESIRED TEST NUM. FROM SWR
4015	020672	042716	000340		BIC	55SWRMK, (SP)	;; STRIP AWAY UNDESIRED BITS
4016	020676	122667	160200		CMPB	(SP)+, 5TSTNM	;; ON THE RIGHT TEST?
4017	020702	001465			BEQ	5OVER	;; BR IF YES
4018	020704	105767	160173		2\$: TSTB	5ERFLG	;; HAS AN ERROR OCCURRED?
4019	020710	001421			BEQ	35	;; BR IF NO
4020	020712	126767	160177	160163	CMPB	5ERMAX, 5ERFLG	;; MAX. ERRORS FOR THIS TEST OCCURRED?
4021	020720	101015			BHI	35	;; BR IF NO
4022	020722	032777	001000	160210	BIT	2#BIT09, 2SWR	;; LOOP ON ERROR?
4023	020730	001404			BEQ	45	;; BR IF NO
4024	020732	016767	160152	160146	7\$: MOV	5LPERR, 5LPADR	;; SET LOOP ADDRESS TO LAST SCOPE
4025	020740	000446			BR	5OVER	
4026	0207 3	105067	160135		4\$: CLRB	5ERFLG	;; ZERO THE ERROR FLAG
4027	020746	005067	160216		CLR	5TIMES	;; CLEAR THE NUMBER OF ITERATIONS TO MAKE
4028	020752	000415			BR	15	;; ESCAPE TO THE NEXT TEST
4029	020754	032777	004000	160156	3\$: BIT	2#BIT11, 2SWR	;; INHIBIT ITERATIONS?
4030	020762	001011			BNE	15	;; BR IF YES
4031	020764	005767	160222		TST	5PASS	;; IF FIRST PASS OF PROGRAM
4032	020770	001406			BEQ	15	;; INHIBIT ITERATIONS
4033	020772	005267	160106		INC	5ICNT	;; INCREMENT ITERATION COUNT
4034	020776	026767	160166	160100	CMP	5TIMES, 5ICNT	;; CHECK THE NUMBER OF ITERATIONS MADE
4035	021004	002024			BGE	5OVER	;; BR IF MORE ITERATION REQUIRED
4036	021006	012767	000001	160070	1\$: MOV	21, 5ICNT	;; REINITIALIZE THE ITERATION COUNTER
4037	021014	016767	000552	160146	MOV	5MXCNT, 5TIMES	;; SET NUMBER OF ITERATIONS TO DO
4038	021022	105267	160054		55VLAD: INCB	5TSTNM	;; COUNT TEST NUMBERS
4039	021026	116767	160050	160154	MOVB	5TSTNM, 5TESTN	;; SET TEST NUMBER IN APT MAILBOX
4040	021034	011667	160046		MOV	(SP), 5LPADR	;; SAVE SCOPE LOOP ADDRESS
4041	021040	011667	160044		MOV	(SP), 5LPERR	;; SAVE ERROR LOOP ADDRESS
4042	021044	005067	160122		CLR	5ESCAPE	;; CLEAR THE ESCAPE FROM ERROR ADDRESS
4043	021050	112767	000001	160037	MOVB	21, 5ERMAX	;; ONLY ALLOW ONE(1) ERROR ON NEXT TEST
4044	021056	016777	160020	160056	5OVER: MOV	5TSTNM, 2DISPLAY	;; DISPLAY TEST NUMBER
4045	021064	016716	160016		MOV	5LPADR, (SP)	;; FUDGE RETURN ADDRESS
4046	021070	020516			INSERT: CMP	55, (SP)	;; CHECK FOR LOOP ON TEST.
4047	021072	001402			BEQ	15	;; BR IF START NEXT TEST.
4048	021074	000167	000470		JMP	5ENDINS	;; JMP IF LOOP ON LAST TEST.
4049	021100	012767	037777	160500	1\$: MOV	237777, 5BLKMSK	;; SET 8K BOUNDARY MASK.
4050	021106	005767	160100		TST	5PASS	;; CHECK FOR PASS 0.
4051	021112	001404			BEQ	25	;; BR IF PASS 0
4052	021114	126727	157762	000021	CMPB	5TSTNM, 221	;; CHECK IF IN SECTION 3.
4053	021122	103002			BHIS	35	;; BR IF IN SECTION 3.
4054	021124	006267	160456		2\$: ASR	5BLKMSK	;; RESET BOUNDARY TO 4K.
4055	021130	016767	160426	160426	3\$: MOV	5FSTADR, 5TMPFAD	;; GET FIRST ADDRESS.
4056	021136	005767	157436		TST	5RELOC	;; CHECK IF PRG RELOCATED.
4057	021142	001430			BEQ	45	;; BR IF NOT RELOCATED.
4058	021144	032777	000040	157766	BIT	2#SW05, 2SWR	;; CHECK IF LOC 0-776 TO BE PROTECTED.



4059	021152	001424			BEQ	4\$		;BR IF SW NOT SET.
4060	021154	026727	160404	001000	CMP	TMPFAD, #1000		;CHECK IF NOT BEING TESTED.
4061	021162	103020			BHIS	4\$		;BR IF ALREADY PROTECTED.
4062	021164	012767	001000	160372	MOV	#1000, TMPFAD		;RESET FIRST ADDRESS.
4063	021172	052767	000001	160370	BIS	#BIT0, FADMAP		;SET FLAG IN FIRST BANK.
4064	021200	026727	160370	001000	CMP	LSTADR, #1000		;CHECK IF GONE PAST LAST ADR.
4065	021206	101006			BHI	4\$		;BR IF ENOUGH MEMORY.
4066	021210	004567	002242		JSR	R5, \$PRINT		;GO PRINT OUT THE FOLLOWING MESSAGE.
4067	021214	026703			.WORD	NOMIST		;ADDRESS OF MESSAGE TO BE TYPED
4068								; "NO MEMORY TESTED"
4069	021216	016716	160422		MOV	.TST32, (SP)		;ADJUST RETURN ADR FOR ABORT.
4070	021222	000207			RTS	PC		;ABORT.
4071	021224	016767	160344	160344	4\$: MOV	LSTADR, TMPLAD		;GET LAST ADDRESS.
4072	021232	016767	160276	160270	MOV	SAVTST, TSTMAP		;GET TEST MAP, LO 64K.
4073	021240	016767	160272	160264	MOV	SAVTST+2, TSTMAP+2		;HI 64K.
4074	021246	046767	157330	160254	BIC	PRGMAP, TSTMAP		;DON'T TEST OVER THE PROGRAM.
4075	021254	046767	157324	160250	BIC	PRGMAP+2, TSTMAP+2		
4076	021262	005767	157724		TST	\$PASS		;CHECK FOR FIRST PASS
4077	021266	001011			BNE	10\$		;BR IF NOT FIRST PASS.
4078	021270	032767	000003	160232	BIT	#3, TSTMAP		;CHECK IF FIRST TWO BANKS AVAILABLE.
4079	021276	001405			BEQ	10\$		;NOT TESTING FIRST 2 BANKS.
4080	021300	042767	177774	160222	BIC	#177774, TSTMAP		;CLR ALL BUT FIRST 2 BANKS.
4081	021306	005067	160220		CLR	TSTMAP+2		
4082	021312	005704			10\$: TST	R4		;CHECK FOR A MINIMUM BLOCK SIZE.
4083	021314	001503			BEQ	20\$		;BR IF NO MIN BLOCK SIZE.
4084	021316	030467	160242		BIT	R4, TMPFAD		;CHECK IF FIRST ADR ON BLOCK BOUNDARY.
4085	021322	001416			BEQ	11\$		;BR IF FIRST ADR ON BLOCK BOUNDARY.
4086	021324	050467	160234		BIS	R4, TMPFAD		;ADJUST FIRST ADR TO END OF BLOCK.
4087	021330	005267	160230		INC	TMPFAD		;FIRST ADR TO FIRST ADR OF NEXT BLOCK.
4088	021334	032767	017777	160222	BIT	#MASK4K, TMPFAD		;CHECK IF FIRST ADR REACHED 4K BOUNDARY.
4089	021342	001006			BNE	11\$		;BR IF NOT ON 4K BOUNDARY.
4090	021344	046767	160220	160156	BIC	FADMAP, TSTMAP		;DON'T TEST FIRST BANK.
4091	021352	046767	160214	160152	BIC	FADMAP+2, TSTMAP+2		
4092	021360	030467	160212		11\$: BIT	R4, TMPLAD		;CHECK IF LAST ADR ON BLOCK BOUNDARY.
4093	021364	001414			BEQ	12\$		;BR IF ON BLOCK BOUNDARY.
4094	021366	040467	160204		BIC	R4, TMPLAD		;ADJUST LAST ADR DOWN TO NEXT BLOCK BOUNDARY.
4095	021372	032767	017777	160176	BIT	#MASK4K, TMPLAD		;CHECK IF ADJUSTED TO 4K BOUNDARY.
4096	021400	001006			BNE	12\$		;BR IF NOT ON 4K BOUNDARY.
4097	021402	046767	160174	160120	BIC	LADMAP, TSTMAP		;SKIP TESTING LAST BANK.
4098	021410	046767	160170	160114	BIC	LADMAP+2, TSTMAP+2		
4099	021416	036767	160146	160156	12\$: BIT	FADMAP, LADMAP		;CHECK IF FIRST AND LAST IN SAME BANK.
4100	021424	001004			BNE	13\$		;BR IF IN SAME BANK.
4101	021426	036767	160140	160150	BIT	FADMAP+2, LADMAP+2		;...UPPER 64K.
4102	021434	001404			BEQ	14\$		;BR IF FIRST AND LAST NOT SAME BANK.
4103	021436	026767	160134	160120	13\$: CMP	TMPLAD, TMPFAD		;CHECK IF ANY MEMORY LEFT.
4104	021444	101406			BLOS	15\$		;BR IF NO MEMORY TO TEST.
4105	021446	005767	160056		14\$: TST	TSTMAP		;CHECK IF ANY BANKS LEFT TO TEST!!
4106	021452	001017			BNE	16\$		;BR IF TEST MAP NOT EMPTY.
4107	021454	005767	160052		TST	TSTMAP+2		;CHECK FOR ANY BANKS.
4108	021460	001014			BNE	16\$		;BR IF TEST MAP NOT EMPTY.
4109	021462				15\$: JSR	R5, \$PRINT		;GO PRINT OUT THE FOLLOWING MESSAGE.
4110	021462	004567	001770		.WORD	SKPMES		;ADDRESS OF MESSAGE TO BE TYPED
4111	021466	026727						; "SKIPPING TEST #"
4112								;CLEAR THE WORD ON THE STACK.
4113	021470	005046			CLR	-(SP)		
4114	021472	116716	157404		MOVB	\$TSTNM, (SP)		;PUT THE DATA ON THE STACK.



```

4115      ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
4116      ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
4117      MOV    @#PSW, -(SP)      ;PUT THE PROCESSOR STATUS ON THE STACK
4118      JSR    PC, $TYPOS        ;GO TO THE SUBROUTINE
4119      .BYTE   3                ;TYPE 3 DIGITS.
4120      .BYTE   1                ;TYPE LEADING ZEROS.
4121      BR      ENDINS           ;RETURN TO SKIP TEST.
4122      16$: ADD    #4, (SP)      ;SKIP THE SKIP ON RETURN.
4123      ADD    #4, $LPADR        ;ADJUST THE LOOP ADR PAST THE SKIP.
4124      20$: MOV    #MASK4K, FADMSK ;GET 4K MASK.
4125      MOV    TMPFAD, R5        ;GET FIRST ADR.
4126      21$: BIC    R5, FADMSK   ;CLR MASK ABOVE LOWEST BIT OF FIRST ADR.
4127      ASL    R5               ;MOVE LOWEST BIT UP ONE.
4128      BNE    21$              ;LOOP UNTIL OVERFLOW.
4129      MOV    #MASK4K, LADMSK   ;SET MASK BITS
4130      MOV    TMPLAD, R5        ;GET LAST ADR.
4131      22$: BIC    R5, LADMSK   ;CLR ALL MASK BITS ABOVE LOWEST BIT IN LAST ADR.
4132      ASL    R5               ;MOVE LOWEST BIT OF LAST ADR UP ONE.
4133      BNE    22$              ;LOOP UNTIL OVERFLOW.
4134      ENDINS: RTS    PC        ;EXIT SCOPE ROUTINE BACK TO TEST.
4135      $MXCNT: 4                ;MAX. NUMBER OF ITERATIONS
4136      ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $CKSWR ROUTINE
4137      ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
4138      MOV    @#PSW, -(SP)      ;PUT THE PROCESSOR STATUS ON THE STACK
4139      JSR    PC, $CKSWR        ;GO TO THE SUBROUTINE
4140      .SBTTL  ERROR HANDLER ROUTINE
4141
4142      ;*****
4143      ;THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
4144      ;SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
4145      ;AND GO TO $ERRTYP ON ERROR
4146      ;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
4147      ;$SW15=1      HALT ON ERROR
4148      ;$SW13=1      INHIBIT ERROR TYPEOUTS
4149      ;$SW10=1      BELL ON ERROR
4150      ;$SW09=1      LOOP ON ERROR
4151      ;CALL
4152      ;*      ERROR    N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
4153
4154      $ERROR:
4155      ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $CKSWR ROUTINE
4156      ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
4157      MOV    @#PSW, -(SP)      ;PUT THE PROCESSOR STATUS ON THE STACK
4158      JSR    PC, $CKSWR        ;GO TO THE SUBROUTINE
4159      ADD    #2, (SP)          ;ADJUST POINTER PAST CODE WORD.
4160      7$: INCB    $ERFLG        ;SET THE ERROR FLAG
4161      BEQ    7$                ;DON'T LET THE FLAG GO TO ZERO
4162      MOV    $STNM, @DISPLAY    ;DISPLAY TEST NUMBER AND ERROR FLAG
4163      BIT    #BIT10, @SWR      ;BELL ON ERROR?
4164      BEQ    1$                ;NO - SKIP
4165      JSR    R5, $PRINT        ;GO PRINT OUT THE FOLLOWING MESSAGE.
4166      .WORD   $BELL           ;ADDRESS OF MESSAGE TO BE TYPED
4167      1$: INC     $ERTTL        ;COUNT THE NUMBER OF ERRORS
4168      MOV    (SP), $ERRPC      ;GET ADDRESS OF ERROR INSTRUCTION
4169      SUB    #2, $ERRPC
4170      MOVB   @$ERRPC, $ITEMB   ;;STRIP AND SAVE THE ERROR ITEM CODE

```



```

4171 021676 032777 020000 157234      BIT      #BIT13,2SWR      ;;SKIP TYPEOUT IF SET
4172 021704 001005                      BNE      20$          ;;SKIP TYPEOUTS
4173 021706 004767 000116              JSR      PC,$ERRTYP    ;;GO TO USER ERROR ROUTINE
4174 021712 004567 001540              JSR      RS,$PRINT    ;;GO PRINT OUT THE FOLLOWING MESSAGE.
4175 021716 001201                      .WORD    $CRLF        ;;ADDRESS OF MESSAGE TO BE TYPED
4176 021720                      20$:      CMPB      #APTENV,$ENV      ;;RUNNING IN APT MODE
4177 021720 122767 000001 157276      BNE      2$          ;;NO SKIP APT ERROR REPORT
4178 021726 001007                      MOV      $ITEMB,21$      ;;SET ITEM NUMBER AS ERROR NUMBER
4179 021730 116767 157160 000004      JSR      PC,$ATY4      ;;REPORT FATAL ERROR TO APT
4180 021736 004767 002044                      .BYTE    0
4181 021742 000                      21$:      .BYTE    0
4182 021743 000                      22$:      BR      22$          ;;APT ERROR LOOP
4183 021744 000777                      2$:      TST      2SWR      ;;HALT ON ERROR
4184 021746 005777 157166              BPL      3$          ;;SKIP IF CONTINUE
4185 021752 100005                      HALT      ;;HALT ON ERROR!
4186 021754 000000                      ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $CKSWR ROUTINE
4187                      ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
4188                      MOV      2#PSW, -(SP)      ;;PUT THE PROCESSOR STATUS ON THE STACK
4189 021756 013746 177776              JSR      PC,$CKSWR      ;;GO TO THE SUBROUTINE
4190 021762 004767 000342              BIT      #BIT09,2SWR      ;;JOP ON ERROR SWITCH SET?
4191 021766 032777 001000 157144      BEQ      4$          ;;BR IF NO
4192 021774 001402                      MOV      $LPERR,(SP)      ;;FUDGE RETURN FOR LOOPING
4193 021776 016716 157106              TST      $ESCAPE      ;;CHECK FOR AN ESCAPE ADDRESS
4194 022002 005767 157164              BEQ      5$          ;;BR IF NONE
4195 022006 001402                      MOV      $ESCAPE,(SP)      ;;FUDGE RETURN ADDRESS FOR ESCAPE
4196 022010 016716 157156              5$:      CMP      #SENDAD,2#42      ;;ACT-11 AUTO-ACCEPT?
4197 022014                      BNE      6$          ;;BRANCH IF NO
4198 022014 022737 014174 000042      HALT      ;;YES
4199 022022 001001                      6$:      RTS      PC
4200 022024 00000C                      ;*****
4201 022026                      .SBTTL  ERROR MESSAGE TYPEOUT ROUTINE
4202 022026 000207                      ;*THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
4203                      ;*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
4204                      ;*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
4205                      $ERRTYP:
4206                      JSR      RS,$PRINT    ;;GO PRINT OUT THE FOLLOWING MESSAGE.
4207                      .WORD    $CRLF        ;;ADDRESS OF MESSAGE TO BE TYPED
4208                      MOV      RO,-(SP)      ;;SAVE RO
4209                      CLR      RO          ;;PICKUP THE ITEM INDEX
4210                      BISB     $ITEMB,RO
4211                      BNE      1$          ;;IF ITEM NUMBER IS ZERO, JUST
4212                      ;TYPE THE PC OF THE ERROR
4213                      MOV      $ERRPC,-(SP)  ;;SAVE $ERRPC FOR TYPEOUT
4214                      ;ERROR ADDRESS
4215                      ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOC ROUTINE
4216                      ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**
4217                      MOV      2#PSW, -(SP)  ;;PUT THE PROCESSOR STATUS ON THE STACK
4218                      JSR      PC,$TYPOC      ;;GO TO THE SUBROUTINE
4219                      BR      10$          ;;GET OUT
4220                      1$:      MOV      $ERRPC,$VERPC  ;;SET UP VIRTUAL PC FOR TYPEOUT.
4221 022030 004567 001422
4222 022034 001201
4223 022036 010046
4224 022040 005000
4225 022042 156700 157046
4226 022046 001007
4227 022050 016746 157042
4228 022054 013746 177776
4229 022060 004767 002570
4230 022064 000513
4231 022066 016767 157024 157420

```



```

4227 022074 166767 156500 157412 SUB RELOCF, $VERPC ;MAKE VIRTUAL IF NOT ALREADY.
4228 022102 005300 DEC RO ;ADJUST THE INDEX SO THAT IT WILL
4229 022104 006300 ASL RO ; WORK FOR THE ERROR TABLE
4230 022106 006300 ASL RO
4231 022110 006300 ASL RO
4232 022112 066700 157522 ADD .ERRTB, RO ;FORM TABLE POINTER
4233 022116 012067 000006 MOV (RO)+, 2$ ;PICKUP "ERROR MESSAGE" POINTER
4234 022122 001406 BEQ 3$ ;SKIP TYPEOUT IF NO POINTER
4235 022124 004567 001326 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
4236 022130 000000 2$: .WORD 0 ;"ERROR MESSAGE" POINTER GOES HERE
4237 022132 004567 001320 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
4238 022136 001201 .WORD $CALF ;ADDRESS OF MESSAGE TO BE TYPED
4239 022140 012067 000006 MOV (RO)+, 4$ ;PICKUP "DATA HEADER" POINTER
4240 022144 001406 BEQ 5$ ;SKIP TYPEOUT IF 0
4241 022146 004567 001304 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
4242 022152 000000 4$: .WORD 0 ;"DATA HEADER" POINTER GOES HERE
4243 022154 004567 001276 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
4244 022160 001201 .WORD $CALF ;ADDRESS OF MESSAGE TO BE TYPED
4245 022162 010146 5$: MOV R1, -(SP) ;SAVE R1
4246 022164 012001 MOV (RO)+, R1 ;PICKUP "DATA TABLE" POINTER
4247 022166 001451 BEQ 9$ ;BR IF NO DATA TO BE TYPED
4248 022170 066701 156404 ADD RELOCF, R1 ;ADJUST POINTER
4249 022174 012000 MOV (RO)+, RO ;PICKUP "DATA FORMAT" POINTER
4250 022176 066700 156376 ADD RELOCF, RO ;ADJUST POINTER.
4251 022202 105720 6$: TSTB (RO)+ ;CHECK THE FORMAT
4252 022204 001006 BNE 7$ ;BR IF NOT 16-BIT OCTAL
4253 022206 013146 MOV 2(R1)+, -(SP) ;SAVE 2(R1)+ FOR TYPEOUT
4254 ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOC ROUTINE
4255 ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
4256 022210 013746 177776 MOV 2$PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
4257 022214 004767 002434 JSR PC, $TYPOC ;GO TO THE SUBROUTINE
4258 022220 000426 BR 8$
4259 022222 100406 7$: BMI 17$ ;BRANCH IF NOT DECIMAL
4260 022224 013146 MOV 2(R1)+, -(SP) ;SAVE 2(R1)+ FOR TYPEOUT
4261 ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPDS ROUTINE
4262 ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
4263 022226 013746 177776 MOV 2$PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
4264 022232 004767 002140 JSR PC, $TYPDS ;GO TO THE SUBROUTINE
4265 022236 000417 BR 8$ ;SKIP
4266 022240 122760 177777 177777 17$: CMPB #-1, -1(RO) ;CHECK FOR 18-BIT ADDRESS FORMAT.
4267 022246 001004 BNE 18$ ;BR IF NOT 18-BIT ADDRESS FORMAT.
4268 022250 013146 MOV 2(R1)+, -(SP) ;PUT THE DATA ON THE STACK.
4269 022252 004767 002640 JSR PC, $TYPAD ;DETERMINE THE PHYSICAL ADDRESS AND TYPE IT.
4270 022256 000407 BR 8$ ;SKIP
4271 022260 18$: CLR -(SP) ;CLEAR THE WORD ON THE STACK.
4272 022260 005046 MOVB 2(R1)+, (SP) ;PUT THE DATA ON THE STACK.
4273 022262 113116 ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOS ROUTINE
4274 ;* WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
4275 022264 013746 177776 MOV 2$PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
4276 022270 004767 002334 JSR PC, $TYPOS ;GO TO THE SUBROUTINE
4277 022274 003 .BYTE 3 ;TYPE 3 DIGITS.
4278 022275 001 .BYTE 1 ;TYPE LEADING ZEROS.
4279 022276 005711 8$: TST (R1) ;IS THERE ANOTHER NUMBER?
4280 022276 001404 BEQ 9$ ;BR IF NO
4281 022300 004567 001150 JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.

```



N13

CZQMCE0 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 87  
 CZQMCE.P11 10-JAN-78 12:56 ERROR MESSAGE TYPEOUT ROUTINE

SEQ 0169

```

4283 022306 022326          .WORD 11$          ;ADDRESS OF MESSAGE TO BE TYPED
4284 022310 000734          BR 6$              ;LOOP
4285
4286 022312 012601          9$: MOV (SP)+,R1      ;RESTORE R1
4287 022314 012600          10$: MOV (SP)+,R0     ;RESTORE R0
4288 022316 004567 001134    JSR R5 $SPRINT      ;GO PRINT OUT THE FOLLOWING MESSAGE.
4289 022322 001201          .WORD $CRLF         ;ADDRESS OF MESSAGE TO BE TYPED
4290 022324 000207          RTS PC              ;RETURN
4291 022326 000011          11$: .ASCIIZ / /      ;TAB CHARACTER.
4292
4293          .EVEN
4294          .SBTTL TTY INPUT ROUTINE
4295
4296          ;*****
4297          .ENABL LSB
4298
4299          ;*****
4300          ;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
4301          ;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
4302          ;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
4303          ;*WHEN OPERATING IN TTY FLAG MODE.
4304 022330 022767 000176 156602 $CKSWR: CMP $SWREG,SWR ;IS THE SOFT-SWR SELECTED?
4305 022336 001104          BNE 15$              ;BRANCH IF NO
4306 022340 105777 156600    TSTB $S'KS         ;CHAR THERE?
4307 022344 100101          BPL 15$              ;IF NO, DON'T WAIT AROUND
4308 022346 117746 156574    MOV $STKB,-(SP)      ;SAVE THE CHAR
4309 022352 042716 177600    BIC $C177,(SP)      ;STRIP-OFF THE ASCII
4310 022356 022726 000007    CMP $7,(SP)+        ;IS IT A CONTROL G?
4311 022364 001072          BNE 15$              ;NO, RETURN TO USER
4312 022372 126727 156544 000001    CMPB $AUTOB,#1 ;ARE WE RUNNING IN AUTO-MODE?
4313 022372 001466          BEQ 15$              ;BRANCH IF YES
4314 022374 004567 001056    JSR R5 $SPRINT      ;GO PRINT OUT THE FOLLOWING MESSAGE.
4315 022400 023255          .WORD $CNTLG         ;ADDRESS OF MESSAGE TO BE TYPED
4316 022402
4317 022402 004567 001050    $GTSWR: JSR R5 $SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
4318 022406 023262          .WORD $MSWR         ;ADDRESS OF MESSAGE TO BE TYPED
4319 022410 016746 155562    MOV $SWREG,-(SP)    ;SAVE SWREG FOR TYPEOUT
4320
4321          ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPOC ROUTINE
4322          ;* WITHOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
4323 022414 013746 177776    MOV $PSW,-(SP)      ;PUT THE PROCESSOR STATUS ON THE STACK
4324 022420 004767 002230    JSR PC, $TYPOC      ;GO TO THE SUBROUTINE
4325 022424 004567 001026    JSR R5 $SPRINT      ;GO PRINT OUT THE FOLLOWING MESSAGE.
4326 022430 023273          .WORD $MNEW         ;ADDRESS OF MESSAGE TO BE TYPED
4327 022432 005046          19$: CLR -(SP)        ;CLEAR COUNTER
4328 022434 005046          CLR -(SP)            ;THE NEW SWR
4329 022436 105777 156502    7$: TSTB $STKS     ;CHAR THERE?
4330 022442 100375          BPL 7$                ;IF NOT TRY AGAIN
4331
4332 022444 117746 156476    MOV $STKB,-(SP)      ;PICK UP CHAR
4333 022450 042716 177600    BIC $C177,(SP)      ;MAKE IT 7-BIT ASCII
4334
4335
4336 022454 021627 000025    9$: CMP (SP),#25    ;IS IT A CONTROL-U?
4337 022460 001006          BNE 10$              ;BRANCH IF NOT
4338 022462 004567 000770    JSR R5 $SPRINT      ;GO PRINT OUT THE FOLLOWING MESSAGE.

```



4339	022466	023250	000006	205:	WORD	SCNTL	ADDRESS OF MESSAGE TO BE TYPED
4340	022470	062706	000006	205:	AOC	06 SP	IGNORE PREVIOUS INPUT
4341	022474	000756	000006	205:	BR	195	LET'S TRY IT AGAIN
4342							
4343							
4344	022476	021627	000015	105:	CMP	(SP), 015	IS IT A CR?
4345	022502	001023			BNE	165	BRANCH IF NO
4346	022504	005766	000004		TST	4 SP	YES, IS IT THE FIRST CHAR
4347	022510	001403			BEQ	115	BRANCH IF YES
4348	022512	016677	000002	156420	MOV	2(SP), 25MR	SAVE NEW SWR
4349	022520	062706	000006	115:	AOC	06 SP	CLEAR UP STACK
4350	022524			145:			
4351	022524	004567	000726		JSR	RS SPRINT	GO PRINT OUT THE FOLLOWING MESSAGE
4352	022530	001201			WORD	SCALF	ADDRESS OF MESSAGE TO BE TYPED
4353	022532	126727	156377	000001	CMPB	\$INTAG, 01	RE-ENABLE TTY KBD INTERRUPTS
4354	022540	001003			BNE	155	BRANCH IF NOT
4355	022542	012777	000100	156374	MOV	0100, 25TKS	RE-ENABLE TTY KBD INTERRUPTS
4356	022550	000002		155:	RTI		RETURN
4357	022552	004767	001142	165:	JSR	PC STYPEC	ECHO CHAR
4358	022556	021627	000060		CMP	(SP), 060	CHAR < 0?
4359	022562	002420			BLT	185	BRANCH IF YES
4360	022564	021627	000067		CMP	(SP), 067	CHAR > 7?
4361	022570	003015			BGT	185	BRANCH IF YES
4362	022572	042726	000060		BIC	060 (SP)+	STRIP-OFF ASCII
4363	022576	005766	000002		TST	2(SP)	IS THIS THE FIRST CHAR
4364	022602	001403			BEQ	175	BRANCH IF YES
4365	022604	006316			ASL	(SP)	NO, SHIFT PRESENT
4366	022606	006316			ASL	(SP)	CHAR OVER TO MAKE
4367	022610	006316			ASL	(SP)	ROOM FOR NEW ONE.
4368	022612	005266	000002	175:	INC	2(SP)	KEEP COUNT OF CHAR
4369	022616	056616	177776		BIS	-2(SP), (SP)	SET IN NEW CHAR
4370	022622	000705			BR	75	GET THE NEXT ONE
4371	022624			185:			
4372	022624	004567	000626		JSR	RS SPRINT	GO PRINT OUT THE FOLLOWING MESSAGE.
4373	022630	001200			WORD	\$QUES	ADDRESS OF MESSAGE TO BE TYPED
4374	022632	000716			BR	205	SIMULATE CONTROL-U
4375				.DSABL	LSB		
4376							
4377							
4378							
4379							
4380							
4381							
4382							
4383							
4384							
4385							
4386	022634	011646		\$RDCHR:	MOV	(SP), -(SP)	PUSH DOWN THE PC
4387	022636	016666	000004		MOV	4(SP), 2(SP)	SAVE THE PS
4388	022644	105777	156274	15:	TSTB	25TKS	WAIT FOR
4389	022650	100375			BPL	15	A CHARACTER
4390	022652	117766	156270	000004	MOVB	25TKB, 4(SP)	READ THE TTY
4391	022660	042766	177600	000004	BIC	01C(177), 4(SP)	GET RID OF JUNK IF ANY
4392	022666	026627	000004	000023	CMP	4(SP), 023	IS IT A CONTROL-S?
4393	022674	001013			BNE	35	BRANCH IF NO
4394	022676	105777	156242	25:	TSTB	25TKS	WAIT FOR A CHARACTER

\*\*\*\*\*  
 THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY

\*CALL:

\* RDCHR  
 \* RETURN HERE

INPUT A SINGLE CHARACTER FROM THE TTY  
 CHARACTER IS ON THE STACK  
 WITH PARITY BIT STRIPPED OFF



```

4395 022702 100375 BPL 2$ ; LOOP UNTIL ITS THERE
4396 022704 112746 156236 MOVB 2$KB, -(SP) ; GET CHARACTER
4397 022710 042716 177600 BIC 2$C177, (SP) ; MAKE IT 7-BIT ASCII
4398 022714 022627 000021 CMP (SP)+, 21 ; IS IT A CONTROL-Q?
4399 022720 001366 BNE 2$ ; IF NOT DISCARD IT
4400 022722 000750 BR 1$ ; YES, RESUME
4401 022724 026627 000004 000140 3$: CMP 4$(SF), 140 ; IS IT UPPER CASE?
4402 022732 002407 BLT 4$ ; BRANCH IF YES
4403 022734 026627 000004 060175 CMP 4$(SP), 175 ; IS IT A SPECIAL CHAR?
4404 022742 003003 BGT 4$ ; BRANCH IF YES
4405 022744 042766 000040 000004 BIC 4$40, 4$(SP) ; MAKE IT UPPER CASE
4406 022752 000002 4$: RTI ; GO BACK TO USER
4407 *****
4408 ; THIS ROUTINE WILL INPUT A STRING FROM THE TTY
4409 ; CALL:
4410 ; ROLIN ; INPUT A STRING FROM THE TTY
4411 ; RETURN HERE ; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
4412 ; ; TERMINATOR WILL BE A BYTE OF ALL 0'S
4413
4414 022754 010346 $ROLIN: MOV R3, -(SP) ; SAVE R3
4415 022756 005046 CLR -(SP) ; CLEAR THE RUBOUT KEY
4416 022760 012703 023240 1$: MOV 2$TTYIN, R3 ; GET ADDRESS
4417 022764 022703 023250 2$: CMP 2$TTYIN+8, R3 ; BUFFER FULL?
4418 022770 101467 BLOS 4$ ; BR IF YES
4419 ; * THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $RDCHR ROUTINE
4420 ; * WITHOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
4421 022772 013746 177776 MOV 2$PSW, -(SP) ; PUT THE PROCESSOR STATUS ON THE STACK
4422 022776 004767 177632 JSR PC, $RDCHR ; GO TO THE SUBROUTINE
4423 023002 112613 MOVB 2$(SP)+, (R3) ; GET CHARACTER
4424 023004 122713 000177 10$: CMPB 2$177, (R3) ; IS IT A RUBOUT
4425 023010 001024 BNE 5$ ; BR IF NO
4426 023012 005716 TST (SP) ; IS THIS THE FIRST RUBOUT?
4427 023014 001010 BNE 6$ ; BR IF NO
4428 023016 112767 000134 000212 MOVB 2$'\, 9$ ; TYPE A BACK SLASH
4429 023024 004567 000426 JSR R5, $PRINT ; GO PRINT OUT THE FOLLOWING MESSAGE.
4430 023030 023236 .WORD 9$ ; ADDRESS OF MESSAGE TO BE TYPED
4431 023032 012716 177777 MOV 2$-1, (SP) ; SET THE RUBOUT KEY
4432 023036 005303 6$: DEC R3 ; BACKUP BY ONE
4433 023040 020327 023240 CMP R3, 2$TTYIN ; STACK EMPTY?
4434 023044 103441 BLO 4$ ; BR IF YES
4435 023046 111367 000164 MOVB (R3), 9$ ; SETUP TO TYPEOUT THE DELETED CHAR.
4436 023052 004567 000400 JSR R5, $PRINT ; GO PRINT OUT THE FOLLOWING MESSAGE.
4437 023056 023236 .WORD 9$ ; ADDRESS OF MESSAGE TO BE TYPED
4438 023060 000741 BR 2$ ; GO READ ANOTHER CHAR.
4439 023062 005716 5$: TST (SP) ; RUBOUT KEY SET?
4440 023064 001407 BEQ 7$ ; BR IF NO
4441 023066 112767 000134 000142 MOVB 2$'\, 9$ ; TYPE A BACK SLASH
4442 023074 004567 000356 JSR R5, $PRINT ; GO PRINT OUT THE FOLLOWING MESSAGE.
4443 023100 023236 .WORD 9$ ; ADDRESS OF MESSAGE TO BE TYPED
4444 023102 005016 CLR (SP) ; CLEAR THE RUBOUT KEY
4445 023104 122713 000025 7$: CMPB 2$25, (R3) ; IS CHARACTER A CTRL U?
4446 023110 001004 BNE 8$ ; BR IF NO
4447 023112 004567 000340 JSR R5, $PRINT ; GO PRINT OUT THE FOLLOWING MESSAGE.
4448 023116 023250 .WORD 9$ ; ADDRESS OF MESSAGE TO BE TYPED
4449 023120 000717 BR 1$ ; GO START OVER
4450 023122 122713 000022 8$: CMPB 2$22, (R3) ; IS CHARACTER A "↑R"?

```



```

4451 023126 001014 BNE 3$ ;: BRANCH IF NO
4452 023130 105013 CLRB (R3) ;: CLEAR THE CHARACTER
4453 023132 004567 000320 JSR R5, $PRINT ;: GO PRINT OUT THE FOLLOWING MESSAGE.
4454 023136 001201 .WORD $CRLF ;: ADDRESS OF MESSAGE TO BE TYPED
4455 023140 004567 000312 JSR R5, $PRINT ;: GO PRINT OUT THE FOLLOWING MESSAGE.
4456 023144 023240 .WORD $TTYIN ;: ADDRESS OF MESSAGE TO BE TYPED
4457 023146 000706 BR 2$ ;: GO PICKUP ANOTHER CHARACTER
4458 023150
4459 023150 004567 000302 JSR R5, $PRINT ;: GO PRINT OUT THE FOLLOWING MESSAGE.
4460 023154 001200 .WORD $QUES ;: ADDRESS OF MESSAGE TO BE TYPED
4461 023156 000700 BR 1$ ;: CLEAR THE BUFFER AND LOOP
4462 023160 111367 000052 3$: MOV (R3), 9$ ;: ECHO THE CHARACTER
4463 023164 004567 000266 JSR R5, $PRINT ;: GO PRINT OUT THE FOLLOWING MESSAGE.
4464 023170 023236 .WORD 9$ ;: ADDRESS OF MESSAGE TO BE TYPED
4465 023172 122723 000015 CMPB #15, (R3)+ ;: CHECK FOR RETURN
4466 023176 001272 BNE 2$ ;: LOOP IF NOT RETURN
4467 023200 105063 177777 CLRB -1(R3) ;: CLEAR RETURN (THE 15)
4468 023204 004567 000246 JSR R5, $PRINT ;: GO PRINT OUT THE FOLLOWING MESSAGE.
4469 023210 001202 .WORD $LF ;: ADDRESS OF MESSAGE TO BE TYPED
4470 023212 005726 TST (SP)+ ;: CLEAR RUBOUT KEY FROM THE STACK
4471 023214 012603 MOV (SP)+, R3 ;: RESTORE R3
4472 023216 011646 MOV (SP), -(SP) ;: ADJUST THE STACK AND PUT ADDRESS OF THE
4473 023220 016666 000004 000002 MOV 4(SP), 2(SP) ;: FIRST ASCII CHARACTER ON IT
4474 023226 012766 023240 000004 MOV #TTYIN, 4(SP)
4475 023234 000002 RTI ;: RETURN
4476 023236 000 9$: .BYTE 0 ;: STORAGE FOR ASCII CHAR. TO TYPE
4477 023237 000 .BYTE 0 ;: TERMINATOR
4478 023240 000010 .BLKB 8 ;: RESERVE 8 BYTES FOR TTY INPUT
4479 023250 052536 005015 000 $CNTLU: .ASCIIZ /U/<15><12> ;: CONTROL "U"
4480 023255 136 006507 000012 $CNTLG: .ASCIIZ /G/<15><12> ;: CONTROL "G"
4481 023262 005015 053523 020122 $MSWR: .ASCIIZ <15><12>/SWR = /
4482 023270 020075 000
4483 023273 040 047040 053505 $MNEW: .ASCIIZ / NEW = /
4484 023300 036440 000040
4485 .SBTTL READ AN OCTAL NUMBER FROM THE TTY
4486
4487 ;: *****
4488 ;: *THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
4489 ;: *CHANGE IT TO BINARY.
4490 ;: *THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL
4491 ;: *OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A "?" WILL BE TYPED
4492 ;: *FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
4493 ;: *THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
4494 ;: *CALL:
4495 ;: * RDOCT ;: READ AN OCTAL NUMBER
4496 ;: * RETURN HERE ;: LOW ORDER BITS ARE ON TOP OF THE STACK
4497 ;: * ;: HIGH ORDER BITS ARE IN $HIOCT
4498
4499 023304 011646 000004 000002 $RDOCT: MOV (SP), -(SP) ;: PROVIDE SPACE FOR THE
4500 023306 016666 MOV 4(SP), 2(SP) ;: INPUT NUMBER
4501 023314 010046 MOV R0, -(SP) ;: PUSH R0 ON STACK
4502 023316 010146 MOV R1, -(SP) ;: PUSH R1 ON STACK
4503 023320 010246 MOV R2, -(SP) ;: PUSH R2 ON STACK
4504 023322
4505 1$: ;: THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $RDLIN ROUTINE
4506 ;: * WIHTOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.

```



```

4507 023322 013746 177776      MOV      2#PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
4508 023326 004767 177422      JSR      PC, $RDLIN ;GO TO THE SUBROUTINE
4509 023332 012600              MOV      (SP)+, R0 ;GET ADDRESS OF 1ST CHARACTER
4510 023334 010067 000102      MOV      R0, 5$ ;AND SAVE IT
4511 023340 005001              CLR      R1 ;CLEAR DATA WORD
4512 023342 005002              CLR      R2
4513 023344 112046 2$:         MOV      (R0)+, -(SP) ;PICKUP THIS CHARACTER
4514 023346 001420              BEQ      3$ ;IF ZERO GET OUT
4515 023350 122716 000060      CMP      #'0, (SP) ;MAKE SURE THIS CHARACTER
4516 023354 003026              BGT      4$ ;IS AN OCTAL DIGIT
4517 023356 122716 000067      CMP      #'7, (SP)
4518 023362 002423              BLT      4$
4519 023364 006301              ASL      R1 ;;*2
4520 023366 006102              ROL      R2
4521 023370 006301              ASL      R1 ;;*4
4522 023372 006102              ROL      R2
4523 023374 006301              ASL      R1 ;;*8
4524 023376 006102              ROL      R2
4525 023400 042716 177770      BIC      #'C7, (SP) ;STRIP THE ASCII JUNK
4526 023404 062601              ADD      (SP)+, R1 ;ADD IN THIS DIGIT
4527 023406 000756              BR       2$ ;LOOP
4528 023410 005726 3$:         TST      (SP)+ ;CLEAN TERMINATOR FROM STACK
4529 023412 010166 000012      MOV      R1, 12(SP) ;SAVE THE RESULT
4530 023416 010267 000032      MOV      R2, $SHIOCT
4531 023422 012602              MOV      (SP)+, R2 ;POP STACK INTO R2
4532 023424 012601              MOV      (SP)+, R1 ;POP STACK INTO R1
4533 023426 012600              MOV      (SP)+, R0 ;POP STACK INTO R0
4534 023430 000002              RTI      ;RETURN
4535 023432 005726 4$:         TST      (SP)+ ;CLEAN PARTIAL FROM STACK
4536 023434 105010              CLRB     (R0) ;SET A TERMINATOR
4537 023436 004567 000014      JSR      R5, $SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
4538 023442 000000 5$:         .WORD    0
4539 023444 004567 000006      JSR      R5, $SPRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
4540 023450 001200              .WORD    $QUES ;ADDRESS OF MESSAGE TO BE TYPED
4541 023452 000723              BR       1$ ;TRY AGAIN
4542 023454 000000 $SHIOCT: .WORD 0 ;HIGH ORDER BITS GO HERE
4543
4544 ;*****
4545 ;* SUBROUTINE TO PASS RELOCATED MESSAGE ADDRESSES TO THE $TYPE ROUTINE.
4546 ;* CALL: JSR R5, $SPRINT
4547 ;* <MESSAGE VIRTUAL ADDRESS>
4548 ;*****
4549 023456 012567 000016 $SPRINT: MOV (R5)+, 1$ ;GET THE MESSAGE VIRTUAL ADDRESS.
4550 023462 066767 155112 000010 ADD RELOC, 1$ ;MAKE IT PHYSICAL.
4551 ;* THE NEXT TWO INSTRUCTIONS PROVIDE AN INTERFACE TO THE $TYPE ROUTINE
4552 ;* WITHOUT USING A "TRAP" INSTRUCTION AS CALLED FOR BY **SYSMAC**.
4553 023470 013746 177776 MOV 2#PSW, -(SP) ;PUT THE PROCESSOR STATUS ON THE STACK
4554 023474 004767 000004 JSR PC, $TYPE ;GO TO THE SUBROUTINE
4555 023500 000000 1$:         .WORD    0 ;CONTAINS THE PHYSICAL MESSAGE ADDRESS.
4556 023502 000205 RTS R5 ;RETURN.
4557
4558 .SBTTL TYPE ROUTINE
4559
4560 ;*****
4561 ;*ROUTINE TO TYPE ASCII MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
4562 ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.

```



```

4563      ;*NOTE1:          $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
4564      ;*NOTE2:          $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
4565      ;*NOTE3:          $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
4566      ;*
4567      ;*CALL:
4568      ;*1) USING A TRAP INSTRUCTION
4569      ;*      TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
4570      ;*OR
4571      ;*      TYPE
4572      ;*      MESADR
4573      ;*
4574
4575 023504 105767 155447 $TYPE: TSTB $TFPLG      ;; IS THERE A TERMINAL?
4576 023510 100002      BPL 1$      ;; BR IF YES
4577 023512 000000      HALT      ;; HALT HERE IF NO TERMINAL
4578 023514 000430      BR 3$      ;; LEAVE
4579 023516 010046      1$: MOV RO, -(SP)      ;; SAVE RO
4580 023520 017600      MOV 02(SP), RO      ;; GET ADDRESS OF ASCIZ STRING
4581 023524 122767 000001 155472 CMPB #APTENV, $ENV      ;; RUNNING IN APT MODE
4582 023532 001011      BNE 62$      ;; NO GO CHECK FOR APT CONSOLE
4583 023534 132767 000100 155463 BITB #APTSPool, $ENVM      ;; SPOOL MESSAGE TO APT
4584 023542 001405      BEQ 62$      ;; NO GO CHECK FOR CONSOLE
4585 023544 010067 000004      MOV RO, 61$      ;; SETUP MESSAGE ADDRESS FOR APT
4586 023550 004767 000222      JSR PC, $ATY3      ;; SPOOL MESSAGE TO APT
4587 023554 000000      61$: .WORD 0      ;; MESSAGE ADDRESS
4588 023556 132767 000040 155441 62$: BITB #APTCSP, $ENVM      ;; APT CONSOLE SUPPRESSED
4589 023564 001003      BNE 60$      ;; YES, SKIP TYPE OUT
4590 023566 112046      2$: MOVB (RO)+, -(SP)      ;; PUSH CHARACTER TO BE TYPED ONTO STACK
4591 023570 001005      BNE 4$      ;; BR IF IT ISN'T THE TERMINATOR
4592 023572 005726      TST (SP)+      ;; IF TERMINATOR POP IT OFF THE STACK
4593 023574 012600      60$: MOV (SP)+, RO      ;; RESTORE RO
4594 023576 062716 000002      3$: ADD #2, (SP)      ;; ADJUST RETURN PC
4595 023602 000002      RTI      ;; RETURN
4596 023604 122716 000011      4$: CMPB #HT, (SP)      ;; BRANCH IF <HT>
4597 023610 001431      BEQ 8$      ;;
4598 023612 122716 000200      CMPB #CRLF, (SP)      ;; BRANCH IF NOT <CRLF>
4599 023616 001007      BNE 5$      ;;
4600 023620 005726      TST (SP)+      ;; POP <CR><LF> EQUIV
4601 023622 00567 177630      JSR R5, $PRINT      ;; GO PRINT OUT THE FOLLOWING MESSAGE.
4602 023626 001201      $CRLF
4603 023630 105067 000130      CLRB $CHARCNT      ;; CLEAR CHARACTER COUNT
4604 023634 000754      BR 2$      ;; GET NEXT CHARACTER
4605 023636 004767 000056      5$: JSR PC, $TYPEC      ;; GO TYPE THIS CHARACTER
4606 023642 126726 155310      6$: CMPB $FILLC, (SP)+      ;; IS IT TIME FOR FILLER CHARS.?
4607 023646 001347      BNE 2$      ;; IF NO GO GET NEXT CHAR.
4608 023650 016746 155300      MOV $NULL, -(SP)      ;; GET # OF FILLER CHARS. NEEDED
4609      ;; AND THE NULL CHAR.
4610 023654 105366 000001      7$: DECB 1(SP)      ;; DOES A NULL NEED TO BE TYPED?
4611 023660 002770      BLT 6$      ;; BR IF NO--GO POP THE NULL OFF OF STACK
4612 023662 004767 000032      JSR PC, $TYPEC      ;; GO TYPE A NULL
4613 023666 105367 000072      DECB $CHARCNT      ;; DO NOT COUNT AS A COUNT
4614 023672 000770      BR 7$      ;; LOOP
4615
4616      ;HORIZONTAL TAB PROCESSOR
4617
4618 023674 112716 000040      8$: MOVB #' , (SP)      ;; REPLACE TAB WITH SPACE

```



```

4619 023700 004767 000014 9$: JSR PC,$TYPEC ;;TYPE A SPACE
4620 023704 132767 000007 000052 BITB #7,$CHARCNT ;;BRANCH IF NOT AT
4621 023712 001372 BNE 9$ ;;TAB STOP
4622 023714 005726 TST (SP)+ ;;POP SPACE OFF STACK
4623 023716 000723 BR 2$ ;;GET NEXT CHARACTER
4624 023720 105777 155224 $TYPEC: TSTB 2$TPS ;;WAIT UNTIL PRINTER IS READY
4625 023724 100375 BPL $TYPEC
4626 023726 116677 000002 155216 MOVB 2(SP),2$TPB ;;LOAD CHAR TO BE TYPED INTO DATA REG.
4627 023734 122766 000015 000002 CMPB #CR,2(SP) ;;IS CHARACTER A CARRIAGE RETURN?
4628 023742 001003 BNE 1$ ;;BRANCH IF NO
4629 023744 105067 000014 CLRB $CHARCNT ;;YES--CLEAR CHARACTER COUNT
4630 023750 000406 BR $TYPEX ;;EXIT
4631 023752 122766 000012 000002 1$: CMPB #LF,2(SP) ;;IS CHARACTER A LINE FEED?
4632 023760 001402 BEQ $TYPEX ;;BRANCH IF YES
4633 023762 105227 INCB (PC)+ ;;COUNT THE CHARACTER
4634 023764 000000 $CHARCNT: .WORD 0 ;;CHARACTER COUNT STORAGE
4635 023766 000207 $TYPEX: RTS PC
4636
4637 .SBTTL APT COMMUNICATIONS ROUTINE
4638
4639 *****
4640 023770 112767 000001 000376 $ATY1: MOVB #1,$FFLG ;;TO REPORT FATAL ERROR
4641 023776 112767 000001 000366 $ATY3: MOVB #1,$MFLG ;;TO TYPE A MESSAGE
4642 024004 000403 BR $ATYC
4643 024006 112767 000001 000360 $ATY4: MOVB #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
4644 024014 $ATYC:
4645 024014 010046 MOV RO,-(SP) ;;PUSH RO ON STACK
4646 024016 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
4647 024020 105767 000346 TSTB $MFLG ;;SHOULD TYPE A MESSAGE?
4648 024024 001450 BEQ 5$ ;;IF NOT: JR
4649 024026 122767 000001 155170 CMPB #APTENV,$ENV ;;OPERATING UNDER APT?
4650 024034 001031 BNE 3$ ;;IF NOT: BR
4651 024036 132767 000100 155161 BITB #APTSPool,$ENVM ;;SHOULD SPOOL MESSAGES?
4652 024044 001425 BEQ 3$ ;;IF NOT: BR
4653 024046 017600 000004 MOV 24(SP),RO ;;GET MESSAGE ADDR.
4654 024052 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
4655 024060 005767 155120 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
4656 024064 001375 BNE 1$ ;;IF NOT: WAIT
4657 024066 010067 155126 MOV RO,$MSGAD ;;PUT ADDR IN MAILBOX
4658 024072 105720 2$: TSTB (RO)+ ;;FIND END OF MESSAGE
4659 024074 001376 BNE 2$
4660 024076 166700 155116 SUB $MSGAD,RO ;;SUB START OF MESSAGE
4661 024102 006200 ASR RO ;;GET MESSAGE LENGTH IN WORDS
4662 024104 010067 155112 MOV RO,$MSGGLT ;;PUT LENGTH IN MAILBOX
4663 024110 012767 000004 155066 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
4664 024116 000413 BR 5$
4665 024120 017667 000004 000016 3$: MOV 24(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
4666 024126 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
4667 024134 016746 153636 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
4668 024140 004767 177340 JSR PC,$TYPE ;;CALL TYPE MACRO
4669 024144 000000 4$: .WORD 0
4670 024146 5$:
4671 024146 105767 000221 TSTB $LFLG ;;SHOULD LOG AN ERROR?
4672 024152 001422 BEQ 10$ ;;IF NOT: BR
4673 024154 017600 000004 MOV 24(SP),RO ;;GET ERROR #
4674 024160 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.

```



```

4675 024166 012701 001344      6$: MOV    #SASTAT,R1      ;; POINT TO TABLE START
4676 024172 005711      TST    (R1)      ;; END OF TABLE?
4677 024174 100404      BMI    8$      ;; IF SO: BR
4678 024176 020021      CMP    R0,(R1)+      ;; PROPER ENTRY?
4679 024200 001406      BEQ    9$      ;; IF SO: BR
4680 024202 005721      TST    (P1)+      ;; MOVE PAST COUNTER WORD
4681 024204 000772      BR     6$      ;; KEEP LOOKING
4682 024206 026701 155300      8$: CMP    $APTR,R1      ;; TABLE FULL?
4683 024212 001402      BEQ    10$      ;; IF SO: BR -- NO MORE ROOM
4684 024214 010021      MOV    R0,(R1)+      ;; SET UP NEW ENTRY
4685 024216 005211      INC     (R1)      ;; BUMP ERROR COUNT
4686 024220 105767 000150      9$: TSTB   $FFLG      ;; SHOULD REPORT FATAL ERROR?
4687 024224 001416      BEQ    12$      ;; IF NOT: BR
4688 024226 005767 154772      TST    $ENV      ;; RUNNING UNDER APT?
4689 024232 001413      BEQ    12$      ;; IF NOT: BR
4690 024234 005767 154744      11$: TST    $MSGTYPE      ;; FINISHED LAST MESSAGE?
4691 024240 001375      BNE     11$      ;; IF NOT: WAIT
4692 024242 017667 000004 154736      MOV    24(SP), $FATAL      ;; GET ERROR #
4693 024250 062766 000002 000004      ADD    #2,4(SP)      ;; BUMP RETURN ADDR.
4694 024256 005267 154722      INC     $MSGTYPE      ;; TELL APT TO TAKE ERROR
4695 024262 105067 000106      12$: CLRB   $FFLG      ;; CLEAR FATAL FLAG
4696 024266 105067 000101      CLRB   $LFLG      ;; CLEAR LOG FLAG
4697 024272 105067 000074      CLRB   $MFLG      ;; CLEAR MESSAGE FLAG
4698 024276 012601      MOV     (SP)+,R1      ;; POP STACK INTO R1
4699 024300 012600      MOV     (SP)+,R0      ;; POP STACK INTO R0
4700 024302 000207      RTS     PC      ;; RETURN
4701 024304      $ATY6:      MOV     R0,-(SP)      ;; PUSH R0 ON STACK
4702 024304      MOV     $APTR,R0
4703 024306 016700 155200      SUB     #SASTAT,R0
4704 024312 162700 001344      TST     $MSGTY
4705 024316 005767 154662      1$: BNE     1$      ;; GET SIZE OF STAT TABLE
4706 024322 001375      MOV     R0,$MSGGLG      ;; SEE IF DONE LAST COMMUNICATION
4707 024324 010067 154672      MOV     #SASTAT,$MSGAD      ;; IF NOT: WAIT
4708 024330 012767 001344 154662      MOV     #2,$MSGTY      ;; SET MESSAGE LENGTH
4709 024336 012767 000002 154640      MOV     (SP)+,R0      ;; SET MESSAGE ADDR.
4710 024344 012600      RTS     PC      ;; TELL APT TO TAKE STATS.
4711 024346 000207      2$: MOV     (SP)+,R0      ;; POP STACK INTO R0
4712 024350      $ATY7:      MOV     R0,-(SP)      ;; PUSH R0 ON STACK
4713 024350      MOV     #SASTAT,R1      ;; GET START OF TABLE
4714 024352 012701 001344      TST     (R1)+      ;; END OF TABLE?
4715 024356 005721      BMI     2$      ;; IF SO: BR
4716 024360 100402      CLR     (R1)+      ;; CLEAR ERROR COUNT
4717 024362 005021      BR     1$      ;; KEEP CLEARING
4718 024364 000774      2$: MOV     (SP)+,R0      ;; POP STACK INTO R0
4719 024366      RTS     PC      ;; RETURN
4720 024366 012600      $MFLG: .BYTE 0      ;; MESSG. FLAG
4721 024370 000207      $LFLG: .BYTE 0      ;; LOG FLAG
4722 024372 000      $FFLG: .BYTE 0      ;; FATAL FLAG
4723 024373 000      .EVEN
4724 024374 000
4725 024376 024376
4726 000200
4727 000001
4728 000100
4729 000040
4730

```

APTSIZE=200  
APTENV=001  
APTSPool=100  
APTCsup=040  
;:\*\*\*\*\*



```

4731
4732
4733
4734
4735
4736
4737
4738
4739
4740
4741
4742
4743 024376
4744 024376 010046
4745 024400 010146
4746 024402 010246
4747 024404 010346
4748 024406 010546
4749 024410 012746 020200
4750 024414 016605 000020
4751 024420 100004
4752 024422 005405
4753 024424 112766 000055 000001
4754 024432 016700 154142
4755 024436 012703 024620
4756 024442 060003
4757 024444 112723 000040
4758 024450 005002
4759 024452 016001 024610
4760 024456 160105
4761 024460 002402
4762 024462 005202
4763 024464 000774
4764 024466 060105
4765 024470 005702
4766 024472 001002
4767 024474 105716
4768 024476 100407
4769 024500 106316
4770 024502 103003
4771 024504 116663 000001 177777
4772 024512 052702 000060
4773 024516 052702 000040
4774 024522 110223
4775 024524 005720
4776 024526 020067 155110
4777 024532 103746
4778 024534 101002
4779 024536 010502
4780 024540 000764
4781 024542 105726
4782 024544 100003
4783 024546 116663 177777 177776
4784 024554 105013
4785 024556 012605
4786 024560 012603

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

; *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
; *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
; *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
; *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
; *REPLACED WITH SPACES.
; *CALL:
; *      MOV      NUM,-(SP)      ; PUT THE BINARY NUMBER ON THE STACK
; *      TYPDS      ; GO TO THE ROUTINE

$TYPDS:
      MOV      R0,-(SP)      ; PUSH R0 ON STACK
      MOV      R1,-(SP)      ; PUSH R1 ON STACK
      MOV      R2,-(SP)      ; PUSH R2 ON STACK
      MOV      R3,-(SP)      ; PUSH R3 ON STACK
      MOV      R5,-(SP)      ; PUSH R5 ON STACK
      MOV      #20200,-(SP)  ; SET BLANK SWITCH AND SIGN
      MOV      20(SP),R5     ; GET THE INPUT NUMBER
      BPL      1$           ; BR IF INPUT IS POS.
      NEG      R5           ; MAKE THE BINARY NUMBER POS.
      MOV      #'-(SP)      ; MAKE THE ASCII NUMBER NEG.
      MOV      RELOC, R0     ; GET RELOCATION FACTOR.
      MOV      #50BLK,R3     ; SETUP THE OUTPUT POINTER
      ADD      R0,R3         ; ADD IN RELOCATION FACTOR.
      MOV      #' , (R3)+    ; SET THE FIRST CHARACTER TO A BLANK
      CLR      R2           ; CLEAR THE BCD NUMBER
      MOV      $DTBL(R0),R1  ; GET THE CONSTANT
      SUB      R1,R5        ; FORM THIS BCD DIGIT
      BLT      4$           ; BR IF DONE
      INC      R2           ; INCREASE THE BCD DIGIT BY 1
      BR      3$           ;
      ADD      R1,R5        ; ADD BACK THE CONSTANT
      TST      R2           ; CHECK IF BCD DIGIT=0
      BNE      5$          ; FALL THROUGH IF 0
      TSTB     (SP)         ; STILL DOING LEADING 0'S?
      BMI      7$          ; BR IF YES
      ASLB     (SP)         ; MSD?
      BCC      6$          ; BR IF NO
      MOV      1(SP),-1(R3)  ; YES--SET THE SIGN
      BIS      #'0,R2       ; MAKE THE BCD DIGIT ASCII
      BIS      #' , R2      ; MAKE IT A SPACE IF NOT ALREADY A DIGIT
      MOV      R2,(R3)+     ; PUT THIS CHARACTER IN THE OUTPUT BUFFER
      TST      (R0)+        ; JUST INCREMENTING
      CMP      R0, .EIGHT   ; CHECK THE TABLE INDEX
      BLO      2$          ; GO DO THE NEXT DIGIT
      BHI      8$          ; GO TO EXIT
      MOV      R5,R2        ; GET THE LSD
      BR      6$          ; GO CHANGE TO ASCII
      TSTB     (SP)+        ; WAS THE LSD THE FIRST NON-ZERO?
      BPL      9$          ; BR IF NO
      MOV      -1(SP),-2(R3) ; YES--SET THE SIGN FOR TYPING
      CLRB     (R3)         ; SET THE TERMINATOR
      MOV      (SP)+,R5     ; POP STACK INTO R5
      MOV      (SP)+,R3     ; POP STACK INTO R3

```



J14

CZQMCEO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 96  
 CZQMCE.P11 10-JAN-78 12:56 CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

SEQ 0178

```

4787 024562 012602      MOV      (SP)+,R2      ;;POP STACK INTO R2
4788 024564 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
4789 024566 012600      MOV      (SP)+,R0      ;;POP STACK INTO R0
4790 024570 004567      JSR      R5,$SPRINT    ;;GO PRINT OUT THE FOLLOWING MESSAGE.
4791 024574 024620      .WORD    $DBLK        ;;ADDRESS OF MESSAGE TO BE TYPED
4792 024576 016666      MOV      2(SP),4(SP)  ;;ADJUST THE STACK
4793 024604 012616      MOV      (SP)+,(SP)
4794 024606 000002      RTI                      ;;RETURN TO USER
4795 024610 023420      $DTBL: 10000.
4796 024612 001750      1000.
4797 024614 000144      100.
4798 024616 000012      10.
4799 024620 000004      $DBLK: .BLKW 4
4800                                     .SBTTL  BINARY TO OCTAL (ASCII) AND TYPE
4801
4802                                     ;*****
4803                                     ;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
4804                                     ;OCTAL (ASCII) NUMBER AND TYPE IT.
4805                                     ;$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
4806                                     ;CALL:
4807                                     ;      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
4808                                     ;      TYPOS      ;;CALL FOR TYPEOUT
4809                                     ;      .BYTE    N          ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
4810                                     ;      .BYTE    M          ;;M=1 OR 0
4811                                     ;                                     ;;1=TYPE LEADING ZEROS
4812                                     ;                                     ;;0=SUPPRESS LEADING ZEROS
4813                                     ;
4814                                     ;$STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
4815                                     ;$TYPOS OR $TYPOC
4816                                     ;CALL:
4817                                     ;      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
4818                                     ;      TYPON      ;;CALL FOR TYPEOUT
4819                                     ;
4820                                     ;$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
4821                                     ;CALL:
4822                                     ;      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
4823                                     ;      TYPOC      ;;CALL FOR TYPEOUT
4824                                     ;
4825 024630 017646 000000      $TYPOS: MOV      2(SP),-(SP)      ;;PICKUP THE MODE
4826 024634 116667 000001      MOV      1(SP),$OFILL      ;;LOAD ZERO FILL SWITCH
4827 024642 112667 000211      MOV      (SP)+,$OMODE+1    ;;NUMBER OF DIGITS TO TYPE
4828 024646 062716 000002      ADD      #2,(SP)          ;;ADJUST RETURN ADDRESS
4829 024652 000406      BR      $TYPON
4830 024654 112767 000001      $TYPOC: MOV      #1,$OFILL      ;;SET THE ZERO FILL SWITCH
4831 024662 112767 000006      MOV      #6,$OMODE+1      ;;SET FOR SIX(6) DIGITS
4832 024670 112767 000005      $STYPON: MOV      #5,$OCNT      ;;SET THE ITERATION COUNT
4833 024676 010346      MOV      R3,-(SP)          ;;SAVE R3
4834 024700 010446      MOV      R4,-(SP)          ;;SAVE R4
4835 024702 010546      MOV      R5,-(SP)          ;;SAVE R5
4836 024704 116704 000147      MOV      $OMODE+1,R4      ;;GET THE NUMBER OF DIGITS TO TYPE
4837 024710 005404      NEG      R4
4838 024712 062704 000006      ADD      #6,R4          ;;SUBTRACT IT FOR MAX. ALLOWED
4839 024716 110467 000134      MOV      R4,$OMODE      ;;SAVE IT FOR USE
4840 024722 116704 000127      MOV      $OFILL,R4      ;;GET THE ZERO FILL SWITCH
4841 024726 016605 000012      MOV      12(SP),R5      ;;PICKUP THE INPUT NUMBER
4842 024732 005003      CLR      R3          ;;CLEAR THE OUTPUT WORD

```



```

4843 024734 006105      1$: ROL R5      ;; ROTATE MSB INTO "C"
4844 024736 000404      BR 3$      ;; GO DO MSB
4845 024740 006105      2$: ROL R5      ;; FORM THIS DIGIT
4846 024742 006105      ROL R5
4847 024744 006105      ROL R5
4848 024746 010503      MOV R5,R3
4849 024750 006103      3$: ROL R3      ;; GET LSB OF THIS DIGIT
4850 024752 105367 000100 DECB $OMODE ;; TYPE THIS DIGIT?
4851 024756 100017      BPL 7$      BR IF NO
4852 024760 042703 177770 BIC #177770,R3 ;; GET RID OF JUNK
4853 024764 001002      BNE 4$      TEST FOR 0
4854 024766 005704      TST R4      SUPPRESS THIS 0?
4855 024770 001403      BEQ 5$      BR IF YES
4856 024772 005204      4$: INC R4      DON'T SUPPRESS ANYMORE 0'S
4857 024774 052703 000060 BIS #0,R3      MAKE THIS DIGIT ASCII
4858 025000 052703 000040 5$: BIS #1,R3      MAKE ASCII IF NOT ALREADY
4859 025004 110367 000042 MOV R3,8$      SAVE FOR TYPING
4860 025010 004567 176442 JSR R5, $PRINT ;; GO PRINT OUT THE FOLLOWING MESSAGE.
4861 025014 025052      8$: .WORD 8$      ADDRESS OF MESSAGE TO BE TYPED
4862 025016 105367 000032 7$: DECB $OCNT      COUNT BY 1
4863 025022 003346      BGT 2$      BR IF MORE TO DO
4864 025024 002402      BLT 6$      BR IF DONE
4865 025026 005204      INC R4      INSURE LAST DIGIT ISN'T A BLANK
4866 025030 000743      BR 2$      GO DO THE LAST DIGIT
4867 025032 012605      6$: MOV (SP)+,R5      RESTORE R5
4868 025034 012604      MOV (SP)+,R4      RESTORE R4
4869 025036 012603      MOV (SP)+,R3      RESTORE R3
4870 025040 016666 000002 000004 MOV 2(SP),4(SP) ;; SET THE STACK FOR RETURNING
4871 025046 012616      MOV (SP)+,(SP)
4872 025050 000002      RTI      RETURN
4873 025052 000      8$: .BYTE 0      STORAGE FOR ASCII DIGIT
4874 025053 000      .BYTE 0      TERMINATOR FOR TYPE ROUTINE
4875 025054 000      $OCNT: .BYTE 0      OCTAL DIGIT COUNTER
4876 025055 000      $OFILL: .BYTE 0      ZERO FILL SWITCH
4877 025056 000000      $OMODE: .WORD 0      NUMBER OF DIGITS TO TYPE
4878      .ERROR TRAP SERVICE ROUTINE
4879 025060 005727      ERRTRP: TST (PC)+      CHECK IF PREV TRAP TO 4 REPORTED
4880 025062 000000      1$: .WORD 0      CONTAINS ERROR REPORTED FLAG
4881 025064 001010      BNE 2$      BRANCH IF NOT REPORTED
4882 025066 005267 177770 INC 1$      SET DOUBLE TRAP FLAG.
4883 025072 011667 154070 MOV (SP), $TMP3 ;; SAVE THE BAD PC FOR TYPING.
4884 025076 004767 174502 JSR PC, $ERROR ;; *** ERROR *** (GO TYPE A MESSAGE)
4885 025102 000031      .WORD 31      ERROR TYPE CODE.
4886 025104 000401      BR 3$      SKIP HALT
4887 025106 000000      2$: HALT      ERROR! SECOND TRAP TO 4 OCCURRED
4888      BEFORE FIRST WAS PRINTED
4889 025110 005067 177746      3$: CLR 1$      RETURN TO PROGRAM AND TRY TO RECOVER
4890 025114 000002      RTI
4891
4892      .SBTTL PHYSICAL ADDRESS TYPE ROUTINE
4893      ;* ROUTINE TO TYPE A PHYSICAL ADDRESS (18 BITS).
4894      $TYPAD:
4895 025116 010046      MOV R0,-(SP)      ;; PUSH R0 ON STACK
4896 025120 010146      MOV R1,-(SP)      ;; PUSH R1 ON STACK
4897 025122 010246      MOV R2,-(SP)      ;; PUSH R2 ON STACK
4898 025124 010346      MOV R3,-(SP)      ;; PUSH R3 ON STACK

```



L14

- SZQMCE0 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 98  
 CZQMCE.P11 10-JAN-78 12:56 PHYSICAL ADDRESS TYPE ROUTINE

SEQ 0180

```

4899 025126 016602 000012 --MOV 12(SP), R2 ;GET BASE ADDRESS
4900 025132 005003 --CLR R3 ;WORKING & INDEX REGISTER
4901 025134 005767 153446 --TST MMAPVA ;CHECK FOR MEM MGMT AVAILABLE
4902 025140 001430 --BEQ 1$ ;BRANCH IF NO MEM MGMT
4903 025142 032737 000001 177572 --BIT #1, 2$SR0 ;CHECK IF MEM MGMT ENABLED
4904 025150 001424 --BEQ 1$ ;BRANCH IF MEM MGMT NOT ENABLED
4905 025152 010201 --MOV R2, R1 ;COPY VIRTUAL ADR
4906 025154 006101 --ROL R1 ;SHUFFLE BITS 13,14,15 INTO 1,2,3
4907 025156 006101 --ROL R1
4908 025160 006101 --ROL R1
4909 025162 006101 --ROL R1
4910 025164 006101 --ROL R1
4911 025166 042701 177761 --BIC #177761, R1 ;CLR ALL EXCEPT BITS 1,2,3
4912 025172 062701 172340 --ADD #KIPARO, R1 ;SET TO APPROPRIATE PAR
4913 025176 011101 --MOV (R1), R1 ;GET CONTENTS OF PAR
4914 025200 012700 000006 --MOV #6, R0 ;SET UP COUNTER
4915 025204 006301 4$: --ASL R1 ;SHIFT PAR
4916 025206 006103 --ROL R3 ;SAVE OVERFLOW BITS
4917 025210 077003 --SOB R0, 4$ ;COUNT SIX SHIFTS
4918 025212 042702 160000 --BIC #160000, R2 ;SAVE BANK BITS
4919 025216 060102 --ADD R1, R2 ;COMPUTE PHYSICAL ADDRESS
4920 025220 005503 --ADC R3 ;MAKE SURE CARRY ISN'T LOST!
4921 025222 006302 1$: --ASL R2 ;FIRST DIGIT TO R3
4922 025224 006103 --ROL R3
4923 025226 012700 000006 --MOV #6, R0 ;DIGIT COUNT
4924 025232 000404 --BR 3$ ;PRINT FIRST DIGIT
4925 025234 006302 2$: --ASL R2
4926 025236 006103 --ROL R3
4927 025240 005301 --DEC R1
4928 025242 001374 --BNE 2$
4929 025244 012701 000003 3$: --MOV #3, R1 ;DIGIT SHIFT COUNT
4930 025250 062703 000060 --ADD #60, R3 ;MAKE IT AN ASCII DIGIT
4931 025254 110367 000036 --MOVB R3, 8$ ;LOAD DIGIT INTO MESSAGE
4932 025260 004567 176172 --JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
4933 025264 025316 --.WORD 8$ ;ADDRESS OF MESSAGE TO BE TYPED
4934 025266 005003 --CLR R3 ;CLEAR INDEX
4935 025270 005300 --DEC R0 ;DEC DIGIT COUNT
4936 025272 001360 --BNE 2$
4937 025274 012603 --MOV (SP)+, R3 ;POP STACK INTO R3
4938 025276 012602 --MOV (SP)+, R2 ;POP STACK INTO R2
4939 025300 012601 --MOV (SP)+, R1 ;POP STACK INTO R1
4940 025302 012600 --MOV (SP)+, R0 ;POP STACK INTO R0
4941 025304 012616 --MOV (SP)+, (SP) ;ADJUST THE STACK TO CLEAR DATA
4942 025306 004567 176144 --JSR R5, $PRINT ;GO PRINT OUT THE FOLLOWING MESSAGE.
4943 025312 026751 --.WORD FILL2 ;ADDRESS OF MESSAGE TO BE TYPED
4944 025314 000207 --RTS PC ;RETURN
4945 025316 000 8$: --.BYTE 0 ;ONE DIGIT MESSAGE BUFFER
4946 025317 000 --.BYTE 0 ;MESSAGE TERMINATOR
4947
4948 .SBTTL STANDARD PROGRAM MESSAGES
4949 ;*****
4950 ;VARIOUS MESSAGE PRINTOUTS USED THRUOUT
4951 ;THE PROGRAM
4952 ;*****
4953 025320 005015 052113 030461 MMAMES: .ASCIZ <15><12>'KT11 (MEMORY MANAGEMENT) AVAILABLE'
4954 025326 024040 042515 047515

```



M14

CZQMCEO 0- 4K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 99  
 CZQMCE.P11 10-JAN-78 12:56 STANDARD PROGRAM MESSAGES

SEQ 0181

4955	025334	054522	046440	047101	
4956	025342	043501	046505	047105	
4957	025350	024524	040440	040526	
4958	025356	046111	041101	042514	
4959	025364	000			
4960	025365	015	046412	046505	MEMMES: .ASCIZ <15><12>'MEMORY MAP:'
4961	025372	051117	020131	040515	
4962	025400	035120	000		
4963	025403	015	041012	052131	BYTMES: .ASCIZ <15><12>'BYTE MEMORY MAP:'
4964	025410	020105	042515	047515	
4965	025416	054522	046440	050101	
4966	025424	000072			
4967	025426	005015	040520	044522	MTMAP: .ASCIZ <15><12>'PARITY MEMORY MAP:'
4968	025434	054524	046440	046505	
4969	025442	051117	020131	040515	
4970	025450	035120	000		
4971	025453	015	043012	047522	FROM: .ASCIZ <15><12>'FROM '
4972	025460	020115	000		
4973	025463	040	047524	000040	TO: .ASCIZ ' TO '
4974	025470	005015	047111	052523	INSUFF: .ASCIZ <15><12>'INSUFFICIENT MEMORY...FIRST 16K NOT ALL THERE!'
4975	025476	043106	041511	042511	
4976	025504	052116	046440	046505	
4977	025512	051117	027131	027056	
4978	025520	044506	051522	020124	
4979	025526	033061	020113	047516	
4980	025534	020124	046101	020114	
4981	025542	044124	051105	020505	
4982	025550	000			
4983	025551	015	047012	020117	MTR: .ASCIZ <15><12>'NO PARITY REGISTERS FOUND'
4984	025556	040520	044522	054524	
4985	025564	051040	043505	051511	
4986	025572	042524	051522	043040	
4987	025600	052517	042116	000	
4988	025605	015	051012	051505	PWRMSG: .ASCIZ <15><12>'RESTARTING AFTER A POWER FAILURE'<15><12>
4989	025612	040524	052122	047111	
4990	025620	020107	043101	042524	
4991	025626	020122	020101	047520	
4992	025634	042527	020122	040506	
4993	025642	046111	051125	006505	
4994	025650	000012			
4995	025652	005015	047516	050040	NOPEs: .ASCIZ <15><12>'NO PARITY ERRORS FOUND ON MEMORY SCAN'<15><12>
4996	025660	051101	052111	020131	
4997	025666	051105	047522	051522	
4998	025674	043040	052517	042116	
4999	025702	047440	020116	042515	
5000	025710	047515	054522	051440	
5001	025716	040503	006516	000012	
5002	025724	005015	051120	043517	PROREL: .ASCII <15><12>'PROGRAM NOW RESIDES BACK AT 0 TO 8K'
5003	025732	040522	020115	047516	
5004	025740	020127	042522	044523	
5005	025746	042504	020123	040502	
5006	025754	045503	040440	020124	
5007	025762	020060	047524	034040	
5008	025770	113			
5009	025771	015	044012	052111	.ASCIZ <15><12>'HIT CONTINUE FOR NORMAL RUNNING'<15><12>
5010	025776	041440	047117	044524	



N14

CZQMCEO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 100  
 CZQMCE.P1! 10-JAN-78 12:56 STANDARD PROGRAM MESSAGES

SEQ 0192

5011	026004	052516	020105	047506	
5012	026012	020122	047516	046522	
5013	026020	046101	051040	047125	
5014	026026	044516	043516	005015	
5015	026034	000			
5016	026035	015	051012	043505	MX1: .ASCIZ <15><12>'REGISTER AT '
5017	026042	051511	042524	020122	
5018	026050	052101	000040		
5019	026054	041440	047117	051124	MX2: .ASCIZ ' CONTROLS '
5020	026062	046117	020123	000	
5021	026067	015	041412	051117	MX3: .ASCIZ <15><12>'CORE PARITY '
5022	026074	020105	040520	044522	
5023	026102	054524	000040		
5024	026106	005015	047515	020123	MX4: .ASCIZ <15><12>'MOS PARITY '
5025	026114	040520	044522	054524	
5026	026122	000040			
5027	026124	005015	051515	030461	MX5: .ASCIZ <15><12>'MS11-K CSR '
5028	026132	045455	041440	051123	
5029	026140	000040			
5030	026142	051515	030461	045455	MX6: .ASCIZ 'MS11-K MEMORY PRESENT!! TO COMPLETELY TEST RUN DZMML...'
5031	026150	046440	046505	051117	
5032	026156	020131	051120	051505	
5033	026164	047105	020524	020041	
5034	026172	047524	041440	046517	
5035	026200	046120	052105	046105	
5036	026206	020131	042524	052123	
5037	026214	051040	047125	042040	
5038	026222	046532	046115	027056	
5039	026230	000056			
5040	026232	005015	047516	046440	NOMEM: .ASCIZ <15><12>'NO MEMORY FOUND.'
5041	026240	046505	051117	020131	
5042	026246	047506	047125	027104	
5043	026254	000			
5044	026255	015	005012	044412	FADMES: .ASCII <15><12><12><12>'INPUT ALL PARAMETERS IN OCTAL.'
5045	026262	050116	052125	040440	
5046	026270	046114	050040	051101	
5047	026276	046501	052105	051105	
5048	026304	020123	047111	047440	
5049	026312	052103	046101	056	
5050	026317	015	043012	051111	.ASCIZ <15><12>'FIRST ADDRESS: '
5051	026324	052123	046440	042104	
5052	026332	042522	051523	020072	
5053	026340	000040			
5054	026342	005015	040514	052123	LADMES: .ASCIZ <15><12>'LAST ADDRESS: '
5055	026350	040440	042104	042522	
5056	026356	051523	020072	020040	
5057	026364	000			
5058	026365	015	037412	042101	BADADR: .ASCIZ <15><12>'?ADDRESS IN UNMAPPED BANK?'
5059	026372	051104	051505	020123	
5060	026400	047111	052440	046516	
5061	026406	050101	042520	020104	
5062	026414	040502	045516	000077	
5063	026422	005015	042523	042514	CONST: .ASCIZ <15><12>'SELECT CONSTANT: '
5064	026430	052103	041440	047117	
5065	026436	052123	047101	035124	
5066	026444	000			



5067	026445	015	052412	042516	JNEXP: .ASCIZ (15)(12)'UNEXPECTED MEMORY PARITY ERROR'
5068	026450	050120	041505	042524	
5069	026460	020104	042515	047515	
5070	026466	054522	050040	051105	
5071	026474	052111	020131	051105	
5072	026502	047522	000122		
5073	026508	005015	051120	043517	PRELOC: .ASCIZ (15)(12)'PROGRAM RELOCATED TO '
5074	026514	040522	020115	042522	
5075	026522	047514	040503	042524	
5076	026530	020104	047524	000740	
5077	026536	005015	047515	042522	MTOE: .ASCIZ (15)(12)'MORE THAN ONE PARITY ERROR FOUND.'
5078	026544	052040	040510	020116	
5079	026552	047117	020105	040520	
5080	026560	044522	054524	042440	
5081	026566	051122	051117	043040	
5082	026574	052517	042116	000056	SCANN: .ASCIZ (15)(12)'SCANNING MEMORY FOR BAD PARITY.'
5083	026602	005015	041523	047101	
5084	026610	044516	043516	046440	
5085	026616	046505	051117	020131	
5086	026624	047506	020122	040502	
5087	026632	020104	040520	044522	
5088	026640	054524	000056		
5089	026644	005015	040520	044522	PEWNC: .ASCIZ (15)(12)'PARITY ERROR WILL NOT CLEAR.'
5090	026652	054524	042440	051122	
5091	026660	051117	053440	046111	
5092	026666	020114	047516	020124	
5093	026674	046103	040505	027122	
5094	026702	000			
5095	026703	015	047012	020117	NOMTST: .ASCIZ (15)(12)'NO MEMORY TESTED.'
5096	026710	042515	047515	054522	
5097	026716	052040	051505	042524	
5098	026724	027104	000		
5099	026727	015	051412	044513	SKPMES: .ASCIZ (15)(12)'SKIPPING TEST #'
5100	026734	050120	047111	020107	
5101	026742	042524	052123	021440	
5102	026750	000			
5103	026751	377	000377		FILL2: .ASCIZ (377)(377)
5104					
5105					.SBTTL ERROR REPORTING MESSAGES AND TABLES.
5106					*****
5107					*** MESSAGE BLOCK FOR ERROR TABLE TYPEOUTS
5108					*****
5109	026754	040520	044522	054524	DM1: .ASCIZ 'PARITY REGISTER DATA ERROR.'
5110	026762	051040	043505	051511	
5111	026770	042524	020122	040504	
5112	026776	040524	042440	051122	
5113	027004	051117	000056		
5114	027010	042101	051104	051505	DM2: .ASCIZ 'ADDRESS TEST ERROR(TST1-5).'
5115	027016	020123	042524	052123	
5116	027024	042440	051122	051117	
5117	027032	052050	052123	026461	
5118	027040	024465	000056		
5119	027044	047503	051516	040524	DM4: .ASCIZ 'CONSTANT DATA ERROR(TST6-10).'
5120	027052	052116	042040	052101	
5121	027060	020101	051105	047522	
5122	027066	024122	051524	033124	



5123	027074	030455	024460	000056		
5124	027102	047522	040524	044524	DM5:	.ASCIZ 'ROTATING BIT ERROR(TST11-12).'
5125	027110	043516	041040	052111		
5126	027116	042440	041122	051117		
5127	027124	052050	052123	030461		
5128	027132	030455	024462	000056		
5129	027140	047515	020123	042522	DM6:	.ASCIZ 'MOS REFRESH TEST ERROR (TST 30-31).'
5130	027146	051106	051505	020110		
5131	027154	042524	052123	042440		
5132	027162	051122	051117	024040		
5133	027170	051524	020124	030063		
5134	027176	031455	024461	000056		
5135	027204	020063	047530	020122	DM7:	.ASCIZ '3 XOR 9 PATTERN ERROR(TST13-16).'
5136	027212	020071	040520	052124		
5137	027220	051105	020116	051105		
5138	027226	047522	024122	051524		
5139	027234	030524	026463	033061		
5140	027242	027051	000			
5141	027245	115	051101	044103	DM10:	.ASCIZ "MARCHING 1'S AND 0'S ERROR(TST 27)."
5142	027252	047111	020107	023461		
5143	027260	020123	047101	020104		
5144	027266	023460	020123	051105		
5145	027274	047522	024122	051524		
5146	027302	020124	033462	027051		
5147	027310	000				
5148	027311	120	051101	052111	DM11:	.ASCIZ 'PARITY MEMORY ADDRESS ERROR(TST17).'
5149	027316	020131	042515	047515		
5150	027324	054522	040440	042104		
5151	027332	042522	051523	042440		
5152	027340	051122	051117	052050		
5153	027346	052123	033461	027051		
5154	027354	000				
5155	027355	104	052101	050111	DM12:	.ASCIZ "DATIP WITH WRONG PARITY DIDN'T TRAP(TST17)."
5156	027362	053440	052111	020110		
5157	027370	051127	047117	020107		
5158	027376	040520	044522	054524		
5159	027404	042040	042111	023516		
5160	027412	020124	051124	050101		
5161	027420	052050	052123	033461		
5162	027426	027051	000			
5163	027431	127	047522	043516	DM13:	.ASCIZ 'WRONG PARITY TRAPPED, BUT NO REGISTER SHOWS ERROR FLAG.'
5164	027436	050040	051101	052111		
5165	027444	020131	051124	050101		
5166	027452	042520	026104	041040		
5167	027460	052123	047040	020117		
5168	027466	042522	044507	052123		
5169	027474	051105	051440	047510		
5170	027502	051527	042440	051122		
5171	027510	051117	043040	040514		
5172	027516	027107	000			
5173	027521	120	051101	052111	DM14:	.ASCIZ 'PARITY REGISTER NOT MAPPED AS CONTROLLING THIS ADDRESS(TST17).'
5174	027526	020131	042522	044507		
5175	027534	052123	051105	047040		
5176	027542	052117	046440	050101		
5177	027550	042520	020104	051501		
5178	027556	041440	047117	051124		



5179	027564	046117	044514	043516	
5180	027572	052040	044510	020123	
5181	027600	042101	051104	051505	
5182	027606	024123	051524	030524	
5183	027614	024467	000056		
5184	027620	047515	042522	052040	DM16: .ASCIZ 'MORE THAN ONE REGISTER INDICATED PARITY ERROR.'
5185	027626	020116	020116	047117	
5186	027634	020105	042522	044507	
5187	027642	052123	051105	044440	
5188	027650	042116	041511	052101	
5189	027656	042105	050040	051101	
5190	027664	052111	020131	051105	
5191	027672	047522	027122	000	
5192	027677	104	052101	020101	DM17: .ASCIZ "DATA SHOULDN'T HAVE CHANGED WHEN PARITY ERROR TRAPPED(TST17)."
5193	027704	044123	052517	042114	
5194	027712	023516	020124	040510	
5195	027720	042526	041440	040510	
5196	027726	043516	042105	053440	
5197	027734	042510	020116	040520	
5198	027742	044522	054524	042440	
5199	027750	051122	051117	052040	
5200	027756	040522	050120	042105	
5201	027764	052050	052123	033461	
5202	027772	027051	000		
5203	027775	122	047101	047504	DM20: .ASCIZ 'RANDOM DATA ERROR(TST20).'
5204	030002	020115	040504	040524	
5205	030010	042440	051122	051117	
5206	030016	052050	052123	030062	
5207	030024	027051	000		
5208	030027	111	051516	051124	DM21: .ASCIZ 'INSTRUCTION EXECUTION ERROR(TST21-26).'
5209	030034	041525	044524	047117	
5210	030042	042440	042530	052503	
5211	030050	044524	047117	042440	
5212	030056	051122	051117	052050	
5213	030064	052123	030462	031055	
5214	030072	024466	000056		
5215	030076	051120	043517	040522	DM23: .ASCIZ 'PROGRAM CODE CHANGED WHEN RELOCATED.'
5216	030104	020115	047503	042504	
5217	030112	041440	040510	043516	
5218	030120	042105	053440	042510	
5219	030126	020116	042522	047514	
5220	030134	040503	042524	027104	
5221	030142	000			
5222	030143	124	040522	050120	DM24: .ASCIZ 'TRAPPED, BUT NO REGISTER HAD ERROR BIT SET.'
5223	030150	042105	020054	052502	
5224	030156	020124	047516	051040	
5225	030164	043505	051511	042524	
5226	030172	020122	040510	020104	
5227	030200	051105	047522	020122	
5228	030206	044502	020124	042523	
5229	030214	027124	000		
5230	030217	124	040522	050120	DM25: .ASCIZ 'TRAPPED TO 114.'
5231	030224	042105	052040	020117	
5232	030232	030461	027064	000	
5233	030237	106	044501	042514	DM26: .ASCIZ 'FAILED TO TRAP.'
5234	030244	020104	047524	052040	



```

5235 030252 040522 027120 000
5236 030257 050 041501 044524 DM27: .ASCIZ "(ACTION ENABLE WASN'T SET)."
```

5237	030264	047117	042440	040516	
5238	030272	046102	020105	040527	
5239	030300	047123	052047	051440	
5240	030306	052105	027051	000	
5241	030313	015	052012	040522	DM31: .ASCIZ '<15,<12>'TRAPPED TO 4 '
5242	030320	050120	042105	052040	
5243	030326	020117	020064	000	
5244					
5245					*****
5246					DATA COLUMN HEADINGS
5247					*****
5248					
5249	030333	120	004503	042522	DH1: .ASCIZ 'PC REG S/B WAS'
5250	030340	004507	027523	004502	
5251	030346	040527	000123		
5252	030352	027526	041520	050011	DH2: .ASCIZ 'V/PC P/PC MA S/B WAS'
5253	030360	050057	004503	040515	
5254	030366	051411	041057	053411	
5255	030374	051501	000		
5256	030377	126	050057	004503	DH12: .ASCIZ 'V/PC P/PC MA S/B'
5257	030404	027520	041520	046411	
5258	030412	004501	027523	000102	
5259	030420	027526	041520	050011	DH14: .ASCIZ 'V/PC P/PC REG MA'
5260	030426	050057	004503	042522	
5261	030434	004507	040515	000	
5262	030441	126	050057	004503	DH15: .ASCIZ 'V/PC P/PC MAUT REG S/B WAS'
5263	030446	027520	041520	046411	
5264	030454	052501	004524	042522	
5265	030462	004507	027523	004502	
5266	030470	040527	000123		
5267	030474	027526	041520	050011	DH21: .ASCIZ 'V/PC P/PC IUT MA S/B WAS'
5268	030502	050057	004503	052511	
5269	030510	004524	040515	051411	
5270	030516	041057	053411	051501	
5271	030524	000			
5272	030525	126	050057	004503	DH23: .ASCIZ 'V/PC P/PC SRC MA DST MA S/B WAS'
5273	030532	027520	041520	051411	
5274	030540	041522	046440	004501	
5275	030546	051504	020124	040515	
5276	030554	051411	041057	053411	
5277	030562	051501	000		
5278	030565	126	050057	004503	DH24: .ASCIZ 'V/PC P/PC TRP/PC'
5279	030572	027520	041520	052011	
5280	030600	050122	050057	000103	
5281	030606	027526	041520	050011	DH25: .ASCIZ 'V/PC P/PC TRP/PC REG WAS'
5282	030614	050057	004503	051124	
5283	030622	027520	041520	051011	
5284	030630	043505	053411	051501	
5285	030636	000			
5286	030637	126	050057	004503	DH26: .ASCIZ 'V/PC P/PC REG WAS'
5287	030644	027520	041520	051011	
5288	030652	043505	053411	051501	
5289	030660	000			
5290	030661	122	043505	053411	DH30: .ASCIZ 'REG WAS MA WAS'



5291 030666 051501 046411 004501  
 5292 030674 040527 000123  
 5293  
 5294  
 5295  
 5296

\*\*\*\*\*  
 ; DATA FORMAT TABLE FOR ERROR PRINTOUT.  
 \*\*\*\*\*

5297 030700 000 377 000 DF1: .BYTE 0,-1,0,0  
 5298 030703 000  
 5299 030704 000 377 377 DF2: .BYTE 0,-1,-1,0,0  
 5300 030707 000 000  
 5301 030711 000 377 377 DF3: .BYTE 0,-1,-1,-2,-2  
 5302 030714 376 376  
 5303 030716 000 377 377 DF14: .BYTE 0,-1,-1,-1,0,0  
 5304 030721 377 000 000  
 5305 030724 000 377 000 DF21: .BYTE 0,-1,0,-1,0,0  
 5306 030727 377 000 000  
 5307 030732 377 000 377 DF30: .BYTE -1,0,-1,-2  
 5308 030735 376

.EVEN

5309  
 5310  
 5311 032110 . = 32110

;THE LOADERS ARE SAVE HERE TO END OF 8K

5312  
 5313 000001 .END















CZQMCEO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 110  
CZQMCE.P11 10-JAN-78 12:56 CROSS REFERENCE TABLE -- USER SYMBOLS

FADMSK	001566	538#	3358	4124*	4126*														
FILL2	026751	4943	5103#																
FLAG8K	001557	532#	3197*	3287*	3290*	3308*													
FROM	025453	1039	3941	4971#															
FSTADR	001562	535#	1350	1448*	3734	4055													
GMPR	004046	1006	1086#																
GMPRA	004074	1091#	1103																
GMPRB	004110	1090	1097#																
GMPRC	004116	1095	1099#																
GMPRD	004156	1088	1111#																
GNS	= ***** U	194	905																
HT	= 000011	36#	4596	4637															
IMPCHE=	177746	186#	932*																
IMPCK	003246	919	920	929#															
INITON	015030	1521	1557	1584	1659	1669	3212#												
INITEX	015142	3208	3210	3229	3231#														
INITMM	014372	1504	1547	1595	1624	1633	1701	1715	1751	1772	1795	1820	1830	1873					
		1922	1933	1976	2025	2036	2084	2210	2221	2269	2401	2548	2609	2658					
		2707	2757	2806	2855	2899	2951	2970	2983	3003	3016	3138#	3407						
INSERT	021070	4046#																	
INSUFF	025470	1008	4974#																
IOTVEC=	000020	131#																	
KIPAR0=	172340	166#	242	261*	3123*	3544*	3610*	4912											
KIPAR1=	172342	167#	267*	3124*	3545*	3611*													
KIPAR2=	172344	168#	968	988*	1065*	1174*	1178	2477	3125*	3144*	3150*	3161	3218*	3248*					
		3266	3339*	3371	3526*	3529*	3544	3605*	3799	3800*	3839*	3844*							
KIPAR3=	172346	169#	1062	1065	1066*	3126*	3161*	3166*	3266*	3267*	3515*	3518*	3526	3545					
		3606*																	
KIPAR4=	172350	170#	3127*																
KIPAR5=	172352	171#	3128*																
KIPAR6=	172354	172#	3129*																
KIPAR7=	172356	173#	3130*																
KIPDR0=	172300	155#	237	3115*															
KIPDR1=	172302	156#	3116*																
KIPDR2=	172304	157#	3117*																
KIPDR3=	172306	158#	3118*																



CZQMCEO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 111  
CZQMCE.P11 10-JAN-78 12:56 CROSS REFERENCE TABLE -- USER SYMBOLS

[illegible]



L15

CZQMCEO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 112  
 CZQMCE.P11 10-JAN-78 12:56 CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0193

PHEMAP	001540	519#	1141*	1142*	1166*	1167*	1248*	1249*	1252*	1253*	2402	2404		
PRELOC	026506	3496	5073#											
PRGMAP	000602	253	254	274	289#	911*	912*	3036	3038	3042	3507	3539	3547*	3565
		3591*	3600	3640*	3641*	4374	4075							
PROREL	025724	5002#												
PRO	= 000000	60#												
PR1	= 000040	61#												
PR2	= 000100	62#												
PR3	= 000140	63#												
PR4	= 000200	64#												
PR5	= 000240	65#												
PR6	= 000300	66#												
PR7	= 000340	67#												
PS	= 177776	40#	41											
PSCAN	017710	3715	3763	3768	3779#									
PSW	= 177776	41#	899	1232	1371	1398	1455	3083	3952	3960	3994	4117	4138	4157
		4189	4223	4256	4263	4276	4322	4421	4507	4553				
PWRMSG	025605	326	4988#											
PWRVEC	= 000024	132#	295*	296*	305*	311*	323*	324*	856*	857*	3579*	3632*		
RADTAB	001622	559#	3585	3624										
RANTST	012444	2546#												
RELOC	016302	3471#	3541	3570	3607	3617								
RELOC	000600	269	288#	913*	1480	3223	3573*	3577*	3586	3594	3615	3639*	3730	4056
		4227	4248	4250	4550	4754								
RELTOP	016424	3048	3507#											
RELO	017026	276	3051	3600#										
RESCHK	005226	1282	1321#											
RESLDR	017234	282	3054	3649#										
RESRVD	001516	505#	561	1285*	1289	1294	1299	1307	2479*	2480	2481	2510		
RESTAR	000300	201	226#	328	910									
RESTOR	000304	202	228#											
REST1	000306	227	229#											
REST2	000324	231	233#											
RESVEC	= 000010	127#												
ROTATE	016154	1774	1797	3416#										
RW	= 000006	176#	3115	3116	3117	3118	3122							
SAVLDR	017314	914	3098	3667#										
SAVTST	001534	515#	1001*	1002*	1374*	1375*	1416*	1417*	3036	3038	4072	4073		
SCANM	026602	3788	5083#											
SELECT	002646	199	846#											
SELFLG	001556	531#	844*	846*	1354									
SETAE	017546	2409	3731	3733	3736#									
SETCON	016134	1771	1794	2400	3406#									
SKPMES	026727	4111	5099#											
SPRNT	020256	1291	1309	1342	2417	3881#								
SPRNTA	020344	3891	3895	3900#										
SPRNTB	020350	3883	3901#											
SPRNTC	020302	2464	2485	2498	2515	3889#								
SPRNTD	020270	3712	3759	3765	3817	3885#								
SPRNT0	020306	1302	1527	1563	1675	2440	2456	2524	3887	3890#				
SPRNT1	020314	1638	3893#											
SPRNT2	020332	1510	1602	1720	1756	1779	1802	1836	1843	1850	1857	1880	1889	1898
		1939	1946	1953	1960	1983	1992	2001	2042	2049	2056	2063	2090	2099
		2108	2115	2124	2133	2140	2149	2158	2165	2174	2183	2227	2234	2241
		2248	2275	2284	2293	2300	2309	2318	2325	2334	2343	2350	2359	2368
		2563	2909	2918	2940	2989	3022	3898#						



## M15

CZQMCEO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 113  
 CZQMCE.P11 10-JAN-78 12:56 CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0194

SPRNT3	020326	2616	2665	2715	2764	2813	2863	3897*	3654*	3663*	4903						
SRO =	177572	148*	235	251*	921*	1021*	1484	3131*									
SR1 =	177574	149*															
SR2 =	177576	150*															
SR3 =	172516	151*															
STACK =	001100	31*	229	270	272	560	854	929	945	1016							
START	002640	198	844*														
STARTA	002654	232	284	845	847*												
START1	006060	281	1465	1475*	1479	3049	3100										
STKLMT =	177774	42*															
SWR	001140	303	316*	360*	852	863*	865	871*	878*	895	918	1018	1087	1730			
		1732	2396	3040	3581	3583*	3634	3636*	3728	3732	3751	3998	4012	4014			
		4022	4029	4058	4163	4171	4184	4191	4303	4348*							
SWREG	000176	196*	871	895	4303	4319											
SW0 =	000001	95*															
SW00 =	000001	85*	95														
SW01 =	000002	84*	94														
SW02 =	000004	83*	93														
SW03 =	000010	82*	92														
SW04 =	000020	81*	91														
SW05 =	000040	80*	90	4058													
SW06 =	000100	79*	89	1087	2396												
SW07 =	000200	78*	88	3040													
SW08 =	000400	77*	87	1730													
SW09 =	001000	76*	86														
SW1 =	000002	94*															
SW10 =	002000	75*															
SW11 =	004000	74*															
SW12 =	010000	73*	918	1018													
SW13 =	020000	72*															
SW14 =	040000	71*															
SW15 =	100000	70*															
SW2 =	000004	93*															
SW3 =	000010	92*															
SW4 =	000020	91*															
SW5 =	000040	90*	3732														
SW6 =	000100	89*	3728	3751													
SW7 =	000200	88*															
SW8 =	000400	87*															
SW9 =	001000	86*															
TBITVE =	000014	128*															
TEMP	001614	550*	2900*	2949													
TIMOUT	003576	203	1016*	1078													
TKVEC =	000060	135*															
TMAP	004536	1177	1201*														
TMPFAD	001564	537*	3209	3334	4055*	4060	4062*	4084	4086*	4087*	4088	4103	4125				
TMPLAD	001576	543*	3160*	3179*	3261*	3280*	3283	4071*	4092	4094*	4095	4103	4130				
TMPPT	001550	525*	3162*	3163*	3167*	3168*	3170	3172	3174	3176	3188*	3193*	3195				
		3203*	3204*	3240	3242	3262*	3263*	3268*	3269*	3271	3273	3275	3277	3198			
		3303*	3305	3314*	3315*									3300*			
		1049	1071	3934	4973*												
TO	025463	136*															
TPVEC =	000064	134*															
TRAPVE =	000034	129*															
TRTVEC =	000014	512*															
TSTMAP	001530	3343	3146	3148	3170	3172	3182	3195	3252	3254	3271	3273	3295	3305			
			3345	3352	4072*	4073*	4074*	4075*	4078	4080*	4081*	4090*	4091*	4097*			



N15

CZQMCEO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 114  
 CZQMCE.P11 10-JAN-78 12:56 CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0195

TST1	006142	4098*	4105	4107					
TST10	007014	1483	1485	1497*					
TST11	007076	1731	1735	1744*					
TST12	007162	1750	1767*						
TST13	007244	1790*							
TST14	007570	1812*							
TST15	010120	1816	1914*						
TST16	010742	1918	2017*						
TST17	011564	2021	2202*						
TST2	006266	2206	2391*						
TST20	012436	1543*							
TST21	012552	2398	2543*						
TST22	012642	2600*							
TST23	012734	2604	2649*						
TST24	013032	2653	2698*						
TST25	013124	2702	2748*						
TST26	013216	2752	2797*						
TST27	013312	2801	2846*						
TST3	006362	2850	2896*						
TST30	013526	1580*							
TST31	013640	2967*							
TST32	013760	3000*							
TST4	006466	569	1501	3034*					
TST5	006556	1620*							
TST6	006652	1655*							
TST6A	006660	1697*	1737						
TST7	006702	1700*	1738						
TYPMAP	020356	1711*	1737						
UNEXPT	026445	998	1239	3908*					
UP	= 000000	3691	5067*						
WWP	001612	175*	3115	3116	3117	3118	3122		
WWPBYT	011626	549*	1146	1150	1184*	2425	2432		
WWP80	011572	2402*							
WWP81	011666	2394*							
WWP82	011732	2411*	2537						
WWP83	012302	2423*	2533						
WWP84	012372	2493	2502*						
WWP85	012416	2443	2459	2528*					
W3X9	016222	2408	2414	2535*					
\$APTHD	001330	1821	1923	2026	2211	3439*			
\$APTR	001512	456	462*						
\$ASTAT	001344	499*	4682	4703	4675	4701	4704	4708	4714
\$ASTEN	001510	472*	499	4671					
\$ATYC	024014	498*							
\$ATY1	023770	4642	4644*						
\$ATY3	023776	4640*							
\$ATY4	024006	4586	4641*						
\$ATY6	024304	4180	4643*						
\$ATY7	024350	4701*							
\$AUTOB	001134	4712*							
\$BASE	001260	357*	902*	4311	4485				
\$BDADR	001122	425*							
\$BDDAT	001126	352*	587	590	592	3487*	3689*		
\$BELL	001174	354*	573	575	581	584	587	596	3485*
\$CDW1	001264	376*	4166	4203				3901*	
		427*							







\$ETEND	001330	445#	468											
\$FATAL	001206	387#	4692#											
\$FFLG	024374	4640#	4643#	4686	4695#	4724#								
\$FILLC	001156	368#	4606	4637										
\$FILLS	001155	367#	4637											
\$GDADR	001120	351#	573	575	577	579	581	584	587	596	3486#	3881#	3890#	3893#
		3894#	3898#	3899#										
		353#	573	575	577	581	584	587	3484#	3882#	3900#			
\$GDDAT	001124	3087#												
\$GET42	014164	900	4316#											
\$GTSMA	022402	12												
\$MO	= 000000	463#												
\$MIBTS	001330	1378	1391	1402	1405#	1407	1418	4530#	4542#					
\$MIOCT	023454	344#	4033#	4034	4036#	4135								
\$ICNT	001104	295	311	330#										
\$ILLUP	000756	358#	4353	4485										
\$INTAG	001135	348#	4170#	4179	4203	4216								
\$ITEMB	001114	379#	4203	4469	4479	4543	4637							
\$LF	001202	4671	4696#	4723#										
\$LFLG	024373	345#	1479#	1480#	1737#	4024#	4040#	4045	4123#	4135				
\$LPAOR	001106	346#	4024	4041#	4135	4193								
\$LPERR	001110	412#												
\$MAOR1	001236	416#												
\$MAOR2	001242	419#												
\$MAOR3	001246	422#												
\$MAOR4	001252	385#	464	468	875	893	4039	4177	4581					
\$MAIL	001204	406#												
\$MAMS1	001234	414#												
\$MAMS2	001240	417#												
\$MAMS3	001244	420#												
\$MAMS4	001250	464#												
\$MBAOR	001332	4641#	4647	4697#	4722#									
\$MFLG	024372	4325	4483#											
\$MNEW	023273	392#	4657#	4660	4708#									
\$MSGAO	001220	393#	4662#	4707#										
\$MSGLG	001222	386#	4655	4663#	4690	4694#	4705	4709#						
\$MSGTY	001204	4318	4481#											
\$MSR	023262	407#												
\$MTYP1	001235	415#												
\$MTYP2	001241	418#												
\$MTYP3	001245	421#												
\$MTYP4	001251	4037	4135#											
\$MXCNT	021572	366#	4608	4637										
\$NULL	001154	1488#	1490	1534#	1536	1571#	1573	1611#	1613	1646#	1648	1687#	1689	1690
\$NWTST=	000001	1707#	1709	1740#	1742	1764#	1787#	1809#	1911#	2014#	2199#	2383#	2395	2540#
		2575#	2577	2624#	2626	2673#	2675	2723#	2725	2772#	2774	2821#	2823	2872#
		2874	2954#	2956	2997#									
\$OCNT	025054	4832#	4862#	4875#										
\$OMODE	025056	4827#	4831#	4836	4839#	4850#	4877#							
\$OVER	021056	3999	4017	4025	4035	4044#								
\$PASS	001212	389#	875#	3070#	3071#	3080	3101	4031	4050	4076	4136			
\$PASTM	001336	325	888	924	954	999	1007	1025	1038	1048	1070	1108	1202	1210
\$PRINT	023456	1216	1222	1226	1234	1243	1263	1366	1393	1438	1450	3056	3078	3085
		3495	3690	3708	3787	3825	3850	3912	3933	3940	4066	4110	4165	4174
		4212	4235	4237	4241	4243	4282	4288	4314	4317	4324	4338	4351	4372



		4429	4436	4442	4447	4453	4455	4459	4463	4468	4537	4539	4549	4601
		4790	4860	4932	4942									
SPWRAD	000752	328#												
SPWRDN	000610	295#	323	856										
SPWRMG	000746	326#												
SPWRUP	000662	305	311#											
SQUES	001200	377#	4203	4373	4460	4479	4540	4543	4637					
SRDCHR	022634	4386#	4422											
SRDLIN	022754	4414#	4508											
SRDOCT	023304	1372	1399	1456	4499#									
SRDSZ =	000010	4407#												
SSAVR6	000762	304#	312	313#	314#	332#								
SSCOPE	020574	1498	1544	1581	1621	1656	1698	1712	1745	1768	1791	1813	1915	2018
		2203	2392	2544	2601	2650	2699	2749	2798	2847	2897	2968	3001	3032
		3991#												
SSSETUP=	000130	188#	855	856	858	859	886	890	3069	3992	4155	4187	4198	4298
		4485												
SSSTUP =	177777	188#												
SSVLAD	021022	4007	4038#											
SSVPC =	000010	213#	218											
SSWR =	167400	1#	12	17	18	19	20	21	22	23	24	329	374	375
		376	859	1503	1546	1583	1623	1658	1700	1714	1747	1770	1793	1818
		1920	2023	2208	2394	2546	2606	2655	2704	2754	2803	2852	2899	2970
		3003	3064	3069	3083	3100	3101	3983	3984	3985	3986	3997	3998	4010
		4012	4013	4018	4019	4020	4027	4028	4029	4041	4044	4135	4146	4147
		4148	4149	4150	4163	4171	4184	4191	4203					
SSWREG	001226	397#	878											
SSWRMK=	000340	1#	24	25	3987	3988	4014	4015						
STESTN	001210	388#	4039#											
STIMES	001170	279#	374#	3034#	3069#	4027#	4034	4037#	4135					
STKB	001146	363#	4296	4307	4331	4390	4396							
STKS	001144	362#	4296	4305	4328	4355#	4388	4394						
STMP0	001160	370#	579	581	584	592	594	596	3367#	3377#	3379#	3885#	3889#	3897#
STMP1	001162	371#	592	594	596	3886#								
STMP2	001164	372#	963#	964#	967#	978#	1356	1404						
STMP3	001166	373#	598	953#	969#	975#	977#	979#	1405	4883#				
STN -	000032	1#	12	1488	1503#	1534	1546#	1571	1583#	1611	1623#	1646	1658#	1687
		1700#	1707	1709	1714#	1727	1740	1747#	1750	1764	1770#	1787	1793#	1809
		1812	1818#	1911	1914	1920#	2014	2017	2023#	2199	2202	2		



[illegible]



F16

CZQMCEO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 120  
CZQMCE.P11 10-JAN-78 12:56 CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0200

ABORT	1#	260	3154	3187	3225	3397	3490	3509	3567	3602	3651				
CKSWR	1#	3992	4136	4155	4187										
CKWD	1#	1300	1508	1525	1600	1636	1673	1718	1754	1777	1800	1834	1841	1848	1855
	1878	1887	1896	1937	1944	1951	1958	1981	1990	1999	2040	2047	2054	2061	2088
	2097	2106	2113	2122	2131	2138	2147	2156	2163	2172	2181	2225	2232	2239	2246
	2273	2282	2291	2298	2307	2316	2323	2332	2341	2348	2357	2366	2483	2513	2561
	2614	2663	2713	2762	2811	2861	2907	2916	2938	2987	3020				
CKWD2	1#	1507	1598	1716	1753	1832	1840	1847	1854	1876	1886	1895	1935	1943	1950
	1957	1979	1989	1998	2038	2046	2053	2060	2086	2096	2105	2112	2121	2130	2137
	2146	2155	2162	2171	2180	2223	2231	2238	2245	2271	2281	2290	2297	2306	2315
	2322	2331	2340	2347	2356	2365	2560	2985	3018						
COMMEN	1#	138#	838	1469											
ENDCOM	1#	12	138#	842	1473										
ERROR	32#														
ESCAPE	1#	138#													
GETPRI	1#	138#													
GETSWR	1#	138#	890#												
GTSWR	1#	897													
LDPDR	1#	3114	3116	3117	3118	3122									
MORETA	333#	447													
MULT	1#	138#													
NEWTST	1#	138#	1488	1534	1571	1611	1646	1687	1707	1740	1764	1787	1809	1911	2014
	2199	2383	2540	2575	2624	2673	2723	2772	2821	2872	2954	2997			
POP	1#	138#	316	317	2508	2521	3381	3398	3500	3592	3630	3717	3743	3771	3834
	3844	3852	3872	3964	3971	4531	4698	4699	4710	4719	4785	4937			
PRINT	1#	924	954	999	1007	1024	1038	1048	1070	1108	1202	1210	1216	1222	1225
	1234	1366	1392	1438	1449	3055	3495	3690	3708	3787	3825	3850	3912	4066	4109
	4932	4942													
PUSH	1#	138#	297	303	2467	2490	3370	3388	3471	3510	3527	3623	3693	3738	3753
	3779	3799	3806	3865	3916	3942	4501	4644	4646	4667	4701	4712	4743	4894	
ROCHR	1#	4419													
RODEC	1#														
RDLIN	1#	4504													
RDOCT	1#	1369	1396	1453											
REPORT	1#	138#													
RESREG	1#														
SAVREG	1#														
SCOPE	33#														
SCOPEX	3977#	4046													
SCOPIN	3977#	3996													
SETPRI	1#	138#													
SETUP	1#	138#	847												
SIMTRP	1#	897	1230	1369	1396	1453	3081	3950	3958	3992	4115	4136	4155	4187	4221
	4254	4261	4274	4320	4419	4505	4551								
SKIP	1#	138#	1750												
SLASH	1#	138#	621	631											
SPACE	138#														
STARS	1#	138#	211	220	225	293	309	335	380	383	449	451	458	471	501
	503	554	558	570	572	602	604	935	944	1012	1015	1081	1084	1115	1124
	1135	1139	1196	1199	1270	1274	1316	1319	1359	1361	1488	1496	1534	1542	1571
	1579	1611	1619	1646	1654	1683	1686	1687	1696	1707	1710	1740	1743	1764	1766
	1787	1789	1809	1811	1826	1828	1869	1871	1911	1913	1929	1931	1972	1974	2014
	2016	2031	2033	2079	2081	2199	2201	2216	2218	2264	2266	2383	2390	2540	2542
	2575	2599	2624	2648	2673	2697	2723	2747	2772	2796	2821	2845	2872	2895	2954
	2966	2997	2999	3058	3107	3113	3135	3137	3234	3239	3324	3329	3362	3365	3384
	3386	3403	3405	3413	3415	3436	3438	3468	3470	3504	3506	3597	3599	3644	3648



CZQMCEO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 121  
CZQMCE.P11 10-JAN-78 12:56 CROSS REFERENCE TABLE -- MACRO NAMES

	3684	3688	3722	3725	3746	3748	3774	3778	3862	3864	3877	3880	3904	3907	3979
	4142	4203	4295	4298	4378	4407	4487	4544	4548	4560	4639	4730	4802	4949	4952
	5106	5108	5245	5247	5294	5296									
SWRSU	1#	138#	859#												
SWROR3	1#	2067	2072	2187	2192	2252	2257	2372	2377	3463					
SIREGS	1488#	1490	1536	1573	1613	1648	1690								
TYPADR	1#	1041	1052	1074	3498	4268									
TYPBIN	1#	138#													
TYPBN	1#														
TYPBYT	1#	4113	4271												
TYPDEC	1#	138#	3080	4260											
TYPDS	1#	3081	4261												
TYPE	1#	325	888	924	954	999	1007	1025	1038	1048	1070	1108	1202	1210	1216
	1222	1226	1234	1366	1393	1438	1450	3056	3078	3085	3495	3690	3708	3787	3825
	3850	3912	3933	3940	4066	4110	4165	4174	4212	4235	4237	4241	4243	4282	4288
	4314	4316	4324	4338	4350	4371	4429	4436	4442	4447	4453	4455	4458	4463	4468
	4537	4539	4601	4790	4860	4932	4942								
TYPNAM	1#	138#	882												
TYPNUM	1#	138#													
TYPOC	1#	1230	4221	4254	4320										
TYPOCS	1#	138#	3948	3956											
TYPOCT	1#	138#	1229	4219	4253	4319									
TYPON	1#														
TYPOS	1#	3950	3958	4115	4274										
TYPTXT	1#	138#													
\$CKWD	1#	1301	1341	1509	1526	1562	1601	1637	1674	1719	1755	1778	1801	1835	1842
	1849	1856	1879	1888	1897	1938	1945	1952	1959	1982	1991	2000	2041	2048	2055
	2062	2089	2098	2107	2114	2123	2132	2139	2148	2157	2164	2173	2182	2226	2233
	2240	2247	2274	2283	2292	2299	2308	2317	2324	2333	2342	2349	2358	2367	2416
	2484	2514	2523	2562	2615	2664	2714	2763	2812	2862	2908	2917	2939	2988	3021
\$INDN	1#	1521	1557	1584	1659	1669									
\$INMM	1#	1504	1547	1595	1624	1633	1701	1715	1751	1772	1795	1820	1830	1873	1922
	1933	1976	2025	2036	2084	2210	2221	2269	2401	2548	2609	2658	2707	2757	2806
	2855	2899	2970	2983	3003	3016	3406								
\$MMDN	1#	1531	1567	1589	1663	1679									
\$MMUP	1#	1515	1551	1607	1627	1642	1703	1724	1760	1783	1806	1822	1865	1908	1924
	1968	2011	2027	2075	2195	2212	2260	23							



CZQMCEO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 122  
CZQMCE.P11 10-JAN-78 12:56 CROSS REFERENCE TABLE -- MACRO NAMES

[illegible]

. ABS. 032110 000



I16  
CZQMCEO 0-124K MEMORY EXERCISER, 16K VER MACY11 30A(1052) 10-JAN-78 13:12 PAGE 123  
CZQMCE.P11 10-JAN-78 12:56 CROSS REFERENCE TABLE -- MACRO NAMES


SEQ 0203

ERRORS DETECTED: 0

CZQMCE.BIN,CZQMCE.LST/CRF/SOL/NL:TOC=CZQMCE.SML,CZQMCE.P11  
RUN-TIME: 22 29 2 SECONDS  
RUN-TIME RATIO: 325/54=5.9  
CORE USED: 39K (77 PAGES)



J16



1

1

1