

RM02/03/05

RM05/3/2 FORMATTER
CZRMLB0

AH-F919B-MC
FICHE 1 OF 1

AUG 1981
COPYRIGHT © 80-81
MADE IN USA



.REM %

IDENTIFICATION

PRODUCT CODE: AC-F918B-MC
 PRODUCT NAME: CZRMLB0 RM05/3/2 FORMATTER
 PRODUCT DATE: APRIL 1981
 MAINTAINER: CX DIAGNOSTIC GROUP
 AUTHOR: MIKE LEAVITT

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1980,1981 DIGITAL EQUIPMENT CORPORATION

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45

CONTENTS

1. ABSTRACT
2. REQUIREMENTS
 - 2.1 EQUIPMENT
 - 2.2 PRELIMINARY PROGRAMS
3. LOADING PROCEDURES
 - 3.1 PAPER TAPE AND XXDP
 - 3.2 APT
 - 3.3 APT ETABLE DEFINITIONS
4. STARTING PROCEDURES
 - 4.1 STARTING ADDRESSES
 - 4.2 OPERATOR ACTION
 - 4.3 RH11 - RH70 UNIBUS ADDRESS
5. SWITCH REGISTER SETTINGS
6. ERROR MESSAGES
7. MISCELLANEOUS
 - 7.1 FORMAT TIMES
 - 7.2 HALTING THE PROGRAM
 - 7.3 SURFACE VERIFICATION
8. PROGRAM DESCRIPTION
 - 8.1 FORMAT OPERATION
 - 8.2 POSITIONER VERIFICATION
 - 8.3 HEADER VERIFICATION
9. BAD SECTOR FILE
 - 9.1 BAD SECTOR FILE UTILITY
10. RH/RM SOFTWARE DRIVER DOCUMENT

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43

1. ABSTRACT

THE RM05/3/2 FORMATTER PROGRAM PROVIDES THE FACILITIES TO FORMAT, TO CHECK THE HEADER AND DATA FIELDS OR VERIFY THE HEADER FIELD OF EACH DATA BLOCK ON THE PACK. EACH HEADER FIELD SPECIFIES THE ADDRESS OF ITS ASSOCIATED DATA BLOCK ON THE DISK PACK.

IN THE FORMAT OPERATION, THE PROGRAM WRITES THE HEADER OF EACH DATA BLOCK WITH A CYLINDER NUMBER, TRACK NUMBER AND SECTOR NUMBER. ALSO, WRITES THE DATA FIELD WITH SELECTED DATA PATTERN. THE PROGRAM THEN VERIFIES THE WRITTEN DATA BLOCKS VIA EXECUTING THE 'WRITE CHECK HEADER AND DATA' COMMAND. THE PROGRAM THEN PERFORMS A VERIFY OF SECTOR ZERO, ON EACH OF THE TRACKS SELECTED FOR FORMATTING. THE VERIFY IS ACCOMPLISHED BY EXECUTING A 'READ HEADER AND DATA' COMMAND AND COMPARING THE TWO HEADER WORDS TO AN EXPECTED VALUE.

IN THE VERIFY OPERATION, THE PROGRAM READS THE HEADER OF SECTOR 0 THRU 29. (18 BIT MODE) OR 31. (16 BIT MODE) ON EACH CYLINDER AND TRACK TO BE VERIFIED, THEN COMPARES THE TWO HEADER WORDS TO MAKE SURE THEY ARE CORRECT.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-11 PROCESSOR
12K MEMORY
KW11-L OR KW11-P CLOCK
PROGRAM LOADING DEVICE
TERMINAL
RH11 OR RH70 CONTROLLER
1 TO 8 DISK DRIVES (ANY COMBINATION OF RM05'S, RM03'S OR RM02'S)

2.2 PRELIMINARY PROGRAMS

THERE ARE NO PREREQUISITE PROGRAMS, PROVIDING THE RM SUBSYSTEM IS KNOWN TO BE OPERATIONAL. IF THE STATE OF THE RM SUBSYSTEM IS UNKNOWN, THE FOLLOWING PROGRAMS SHOULD BE RUN PRIOR TO USING THE FORMATTER PROGRAM.

RM05/3/2 DISKLESS TEST, PART 1 & 2

RM05/3/2 FUNCTIONAL TEST, PART 1

3. LOADING PROCEDURES

3.1 PAPER TAPE AND XXDP

THE PROGRAM MAY BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER OR IT MAY BE LOADED FROM 'XXDP' MEDIA USING THE APPROPRIATE

58 LOADER.

59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114

3.2 APT

THIS PROGRAM IS APT COMPATIBLE TO THE EXTENT THAT APT HOOKS WILL BE IN THE PROGRAM AND WILL WORK THRU THE 'OPTION INTERFACE'.

FOR OTHER INTERFACES, APT MAY ONLY LOAD AND START THE PROGRAM. I.E. LOAD AND DUMP MODE.

AUTOMATIC MODE (MONITOR)

1. THE INPUT DIALOGUE IS BYPASSED.
2. THE BUSS ADDRESS AND CONTROLLER INTERRUPT VECTOR IS DEFAULTED.

DUMP MODE

INPUT DIALOGUE AFTER PROGRAM STARTS

3.3 APT ETABLE DEFINITIONS

THE FOLLOWING DEFINITIONS ARE VALID FOR SPECIFYING APT ENVIRONMENTAL TABLE (ETABLE) ENTRIES, VIA RUNNING THE APT UTILITY PROGRAM 'TSP':

1. SOFTWARE ENVIRONMENT:

- 1 IF APT SCRIPT MODE
- 0 IF STANDLONE MODE

2. ENVIRONMENT MODE:

- BIT 7 = 1 ETABLE DOES SIZING
- = 0 PROGRAM DOES SIZING

- BIT 6 = 1 SPOOL MESSAGES TO APT IF SCRIPT MODE
- 0 DON'T SPOOL TO APT

- BIT 5 = 1 SUPPRESS CONSOLE OUTPUT
- 0 ALLOW CONSOLE OUTPUT

BIT 4 TO BIT 0 ARE NOT USED

3. SWITCH 1 (SOFTWARE SWITCH REGISTER)
IF ENVIRONMENT MODE BIT 7 (SIZING BIT) IS SET TO 1, THE SOFTWARE SWITCH REGISTER WILL BE USED, INSTEAD OF THE HARDWARE CONSOLE SWITCH REGISTER.

4. SWITCH 2 (USER SWITCH REGISTER)
NOT USED

5. CPU OPTIONS
NOT USED

6. MEMORY TYPES 1-4 AND MAX MEMORY ADDRESSES

NOT USED

7. INTERRUPT VECTOR 1:
USED WHEN ENVIRONMENT MODE BIT 7 = 1; DEFAULT = 254

8. BUS PRIORITY 1:
NOT USED.

9. INTERRUPT VECTOR 2:
NOT USED

10. BUS PRIORITY 2:
NOT USED

11. BASE ADDRESS:
USED WHEN ENVIRONMENT MODE BIT 7 = 1; DEFAULT = 176700

12. DEVICE MAP:
USED WHEN ENVIRONMENT MODE BIT 7 = 1. EACH BIT SET TO
1 IN BITS 0 TO 7 WILL SELECT THE CORRESPONDING DRIVE
TO BE TESTED. BITS 8-15 ARE NOT USED.

13. CONTROLLER DESCRIPTOR WORDS:
USED WHEN ENVIRONMENT MODE BIT 7 = 1. ANY NONE ZERO
NUMBER SPECIFIES THAT PROGRAM RUNS IN CHECK MODE.

14. CONTROLLER DESCRIPTOR WORDS:
USED WHEN ENVIRONMENT MODE BIT 7 = 1. ANY NONE ZERO
NUMBER SPECIFIES THAT PROGRAM SELECTS 30. (18 BIT MODE)
SECTORS FOR A TRACK IN ALL OPERATIONS.

4. STARTING PROCEDURES

4.1 STARTING ADDRESSES

200 - START ADDRESS IS DEFAULT, ALL SWITCHES CLEAR (SEE SECTION 5)

204 - RESTART ADDRESS. THE RESTART ADDRESS PROVIDES THE OPERATOR WITH
THE ABILITY TO CHANGE THE DEFAULT RM/RH ADDRESSES AND TO USE
THE BAD SECTOR FILE UTILITY ROUTINES (SEE SECTION 9.1).

4.2 OPERATION ACTION

1. LOAD THE PROGRAM INTO MEMORY (SEE SECTION 3).
2. LOAD THE STARTING ADDRESS - 200 OR 204
3. SET THE SWITCHES AS REQUIRED AND PRESS 'START'.

IF THIS IS THE PROGRAM'S FIRST START, THE STATUS OF THE DRIVES
ON THE SELECTED MASSBUS SUBSYSTEM WILL BE TYPED OUT. THIS TYPEOUT
MAY BE INHIBITED ON SUBSEQUENT STARTS BY SETTING SW<02>.

NOTE: THAT THE CYLINDER AND TRACK VALUES ARE DECIMAL NUMBERS. THE ADDRESS SPECIFIED BY THE BEGINNING TRACK MUST BE LESS THAN THE ENDING TRACK ADDRESS IF THESE TWO ADDRESSES ARE ON THE SAME CYLINDER. ON THE OTHER HAND, THE ENDING CYLINDER ADDRESS MAY

BE LESS THAN THE STARTING CYLINDER ADDRESS. IN THIS CASE, THE PROGRAM WILL FORMAT OR VERIFY THE DISK PACK FROM THE STARTING CYLINDER TO CYLINDER 822 AND THEN FROM CYLINDER 0 TO THE ENDING CYLINDER.

9. THE PROGRAM WILL THEN TYPE:

'STARTING FORMAT'

OR

'STARTING HEADER VERIFY'

NOTE: IF A NEW PACK IS UNFORMATTED, THE PROGRAM ALSO ASKS YOU TO ENTER TWO SERIAL NUMBERS. (EXCEPT IF OPERATING IN VERIFY ONLY MODE) THESE TWO SERIAL NUMBER MUST BE NON-ZERO DECIMAL NUMBERS.

10. THE OPERATOR CAN DETERMINE WHERE THE DRIVE IS DURING THE OPERATION BY TYPING A 'CONTROL O'. THE PROGRAM WILL TYPE THE FOLLOWING MESSAGE:

'PRESENT ADDRESS IS: CXXX TXX'

11. TO CHANGE EITHER THE ADDRESSING MODE OR THE OPERATION MODE, THE PROGRAM MUST BE STARTED FROM LOCATION 200 OR 204 AGAIN.

4.3 RH11 - RH70 UNIBUS ADDRESS

THE PROGRAM ASSUMES THAT THE RH11 OR RH70 ADDRESSES START AT 176700 AND THAT THE VECTOR ADDRESS IS 254. THESE ADDRESSES MAY BE CHANGED WHEN THE PROGRAM IS STARTED FROM LOCATION 204. ENTER THE RH11/RH70 ADDRESS IN RESPONSE TO THE REQUEST FROM THE PROGRAM.

5. SWITCH REGISTER SETTINGS

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176. THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' AT ANY TIME EXCEPT WHEN THE PROGRAM IS IN KEYBOARD ENTRY MODE, OR IS AT A HIGHER PRIORITY PROCESSING AN DRIVE INTERRUPT. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTINGS ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED. 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.


```
SW<15>=1      HALT ON ERROR
SW<13>=1      INHIBIT ERROR TYPEOUTS
SW<10>=1      BELL ON ERROR
SW<09>=1      LOOP ON ERROR
SW<02>=-1     DON'T DISPLAY SYSTEM STATUS AFTER INITIAL START
SW<01>=1      LOOP ON THE CURRENT TRACK
SW<00>=-1     LOOP THE PROGRAM ON THE SELECTED DRIVE
```

ERROR MESSAGES

1. 'RH INTERRUPT OCCURRED (RMAS=0)' - AN INTERRUPT OCCURRED, BUT NOTHING ON THE MASSBUS IS INDICATING AN ATTENTION.
2. 'UNEXPECTED ATTENTION OCCURRED' - THE INDICATED DRIVE INTERRUPTED, BUT NO INTERRUPT WAS EXPECTED FROM THE INDICATED DRIVE.
3. 'MASSBUS PARITY ERROR (MCPE=1)' - A CONTROL BUS PARITY ERROR WAS DETECTED BY THE RH WHEN THE INDICATED REGISTER WAS READ.
4. 'MASSBUS PARITY ERROR (PAR=1)' - A CONTROL BUS PARITY ERROR OCCURRED WHEN THE INDICATED REGISTER WAS WRITTEN.
5. 'ADDRESS PLUG CHANGE BIT SET' - THE PROGRAM FOUND THE 'OPE' BIT SET FOR THE INDICATED DRIVE.
6. 'RH DIDN'T RESPOND TO ADDRESSING' - THE PROGRAM ACCESSED THE RH AT THE INDICATED ADDRESS AND RECEIVED NO RESPONSE.
7. 'DRIVE OFFLINE' - THE INDICATED DRIVE HAS GONE OFFLINE
8. 'PERSISTENT DRIVE UNSAFE ERROR' - THE INDICATED DRIVE HAS BECOME UNSAFE AND THE CONDITION CANNOT BE CLEARED BY ISSUING 'DRIVE CLEAR' INSTRUCTIONS.
9. 'UNCORRECTABLE MASSBUS PARITY ERROR' - THE PROGRAM ATTEMPTED TO PERFORM AN OPERATION AND DETECTED 3 SUCESSIVE MASSBUS PARITY ERRORS OR THE PROGRAM ATTEMPTED TO CLEAR A 'PAR' ERROR IN THE DRIVE AND A PARITY ERROR OCCURRED.
10. 'SOFTWARE TIMEOUT' - THE OPERATION FAILED TO COMPLETE WITHIN 1 SECOND.
11. 'DRIVE UNSAFF ERROR' - A NON-PERSISTENT UNSAFE ERROR OCCURRED DURING THE OPERATION.
12. 'CONTROLLER/DRIVE ERROR DURING WRITE' - THE INDICATED NON-DATA ERROR WAS DETECTED DURING A FORMAT OPERATION.

- 343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
13. 'CONTROLLER/DRIVE ERROR DURING WRITE CHECK' - A NON-DATA ERROR OCCURRED DURING THE WRITE CHECK.
 14. 'DATA ERROR DURING WRITE CHECK' - A DATA RELATED ERROR OCCURRED DURING A WRITE CHECK OPERATION. A DATA ERROR IS CONSIDERED TO BE ONE OF THE FOLLOWING ERRORS: 'DCK', 'OPI', 'DTE', 'MCI', 'HCE', OR 'FER'.
 15. 'RETRIES NOT SUCCESSFUL - SECTOR NOT ACCEPTABLE' - THE INDICATED SECTOR FAILED DURING RETRY FOLLOWING A DATA ERROR.
 16. 'CONTROLLER/DRIVE ERROR VERIFYING HEADERS' - AN ERROR OCCURRED DURING THE VERIFICATION PASS AFTER FORMATTING.
 17. ''HCE' ERROR VERIFYING HEADERS' - A HEADER ERROR OCCURRED DURING THE VERIFICATION PASS AFTER FORMATTING.
 18. 'CYLINDER FIELD IN HEADER IS NOT CORRECT' - THE CYLINDER FIELD FROM A HEADER READ DURING THE VERIFICATION PASS IS NOT CORRECT.
 19. 'TRACK/SECTOR FIELD IN HEADER IS NOT CORRECT' - THE TRACK AND SECTOR FIELD FROM A HEADER READ DURING THE VERIFICATION IS NOT CORRECT.
 20. 'WRITE CHECK ERROR' - THE RH REPORTED A WRITE CHECK ERROR AND NO DRIVE ERRORS WERE SET.

7. MISCELLANEOUS

7.1 FORMAT TIME

THE 'FORMAT' MODE WILL TAKE APPROX. 10 MINUTES FOR AN ENTIRE RM03/2 AND APPROX. 30 MINUTES FOR AN ENTIRE RM05.

THE 'VERIFY' ONLY MODE TAKES APPROX. 7 MINUTES FOR AN RM03/2 AND APPROX. 20 MINUTES FOR RM05.

7.2 HALTING THE PROGRAM

THE OPERATOR SHOULD NOT HALT THE PROGRAM VIA THE CONSOLE DURING A FORMAT OPERATION. HALTING THE PROGRAM MAY LEAVE A SECTOR INCORRECTLY FORMATTED. TO TERMINATE THE FORMAT, TYPE A 'CONTROL C'.

7.3 SURFACE VERIFICATION

THE FORMATTER PROGRAM IS NOT INTENDED TO BE USED TO PERFORM DISK PACK VERIFICATION. IF THE PROGRAM REPORTS A SECTOR AS BEING 'NOT ACCEPTABLE', THIS MAY IN FACT INDICATE A BAD SURFACE; HOWEVER, SECTORS WHICH 'PASSED' MAY OR MAY NOT BE GOOD.

8. PROGRAM DESCRIPTION

8.1 FORMAT OPERATION

THE PROGRAM FORMATS THE PACK ONE TRACK AT A TIME BETWEEN THE LIMITS SPECIFIED BY THE OPERATOR.

THE PACK IS WRITTEN WITH A 'WORST CASE' DATA PATTERN, WHICH IS A OCTAL NUMBER 155555, FOLLOWED BY AN OCTAL NUMBER OF 133333.

THE FORMAT OPERATION CONSISTS OF A WRITE HEADER AND DATA COMMAND FOR THE ENTIRE TRACK FOLLOWED BY A WRITE CHECK HEADER AND DATA COMMAND. IF AN ERROR OCCURS DURING THE WRITE, THE PROGRAM WILL RETRY THE WRITE BEFORE CONTINUING. IF A DATA RELATED ERROR IS DETECTED DURING THE WRITE CHECK (A DATA ERROR IS DEFINED AS ONE OF THE FOLLOWING ERRORS: 'DCK', 'OPI', 'DTE', 'HCRC', 'HCE', OR 'FER'), THE SECTOR IN ERROR WILL BE REWRITTEN. THE PROGRAM WILL CHECK THE SECTOR TWICE; IF A DATA ERROR IS DETECTED IN THE SECTOR DURING EITHER OF THE WRITE CHECKS, THE PROGRAM WILL DECLARE THE SECTOR AS BEING 'NONRECOVERABLE'. FOLLOWING THIS SEQUENCE, THE REMAINDER OF THE TRACK IS CHECKED. IF DATA ERRORS ARE ENCOUNTERED IN ANY OF THE REMAINING SECTORS, EACH SECTOR WILL BE HANDLED AS DESCRIBED ABOVE.

IF A NON-DATA RELATED ERROR OCCURS DURING THE WRITE CHECK, THE PROGRAM WILL RETRY THE COMMAND FOR THE ENTIRE TRACK BEFORE PROCEEDING TO THE NEXT TRACK.

IT SHOULD BE NOTED THAT THE FORMATTER PROGRAM FORMATS THE PACK ONLY AND IS NOT DIRECTLY VERIFYING THE SURFACE OF THE PACK. ERRORS THAT ARE ENCOUNTERED MAY BE THE RESULT OF BAD AREAS ON THE PACK BUT, AS THE PROGRAM IS NOT DESIGNED TO PERFORM AN EXHAUSTIVE CHECK OF THE DISK PACK SURFACE, THE PROGRAM CANNOT MAKE THIS CONCLUSION. IN GENERAL, HOWEVER, THE OPERATOR CAN ASSUME THAT SECTORS WHICH THE PROGRAM CALLS 'UNACCEPTABLE' INDICATE BAD AREAS OF THE PACK; UNFORTUNATELY, SECTORS WHICH 'PASS' CANNOT BE ASSUMED TO BE GOOD.

DURING THE FORMAT OPERATION, THE PROGRAM FILLS THE DATA FIELD WITH THE PATTERN SELECTED BY THE OPERATOR.

8.2 POSITIONER VERIFICATION (QUICK VERIFY)

AFTER THE PROGRAM COMPLETES THE FORMAT OPERATION, THE POSITIONER IS RETURNED TO THE STARTING CYLINDER AND THE HEADER FROM SECTOR 0 ON THE STARTING TRACK IS READ. THE CYLINDER ADDRESS FIELD FROM THE HEADER IS COMPARED TO THE REQUESTED CYLINDER; IF THE CYLINDER ADDRESSES DO NOT COMPARE, AN ERROR MESSAGE IS TYPED. THE PROGRAM CHECKS THE CYLINDER ADDRESS FIELD FROM THE HEADER OF SECTOR 0 ON THE BEGINNING TRACK OF EACH CYLINDER FORMATTED. THIS CHECK IS PERFORMED TO CONFIRM THAT THE DISK'S POSITIONER ADVANCED PROPERLY DURING THE FORMAT OPERATION.

8.3 HEADER VERIFICATION (VERIFY ONLY)

THE HEADER VERIFICATION OPERATION PERFORMS A READ HEADER AND DATA

457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513

TO AN ENTIRE TRACK AT A TIME, THEN COMPARES THE EXPECTED HEADER WORDS WITH RECEIVED HEADER WORDS. THE CYLINDER ADDRESS FIELD FROM THE HEADER IS COMPARED TO THE EXPECTED CYLINDER, IF THE CYLINDER ADDRESSES DO NOT COMPARE, AN ERROR MESSAGE IS REPORTED. NEXT, THE TRACK/SECTOR FIELD FROM THE HEADER IS COMPARED TO THE EXPECTED TRACK/SECTOR, IF THE TRACK/SECTOR ADDRESSES DO NOT COMPARE, AN ERROR IS REPORTED. VERIFICATION OF THE HEADERS STARTS FROM SECTOR 0 ON THE BEGINNING CYLINDER AND TRACK, AND CONTINUES UNTIL COMPARING SECTOR 29. (18 BIT MODE) OR 31. (16 BIT MODE) ON ENDING CYLINDER AND TRACK. THIS CHECK IS PERFORMED TO CONFIRM THAT A DISK HAS PREVIOUSLY BEEN FORMATTED AND ALL THE HEADERS ARE IN GOOD CONDITION.

9. BAD SECTOR FILE DESCRIPTION

SECTORS 0 THRU 31, ON CYLINDER 822, LAST TRACK ARE ALWAYS FORMATTED IN 16 BIT MODE. THEY CONTAIN THE BAD SECTOR FILE ON THE PACK FOR BOTH 30. SECTOR (18 BIT MODE) AND 32. SECTOR (16 BIT MODE) OPERATIONS.

THE DATA FIELD OF EACH SECTOR OF THE BAD SECTOR FILE IS DESCRIBED BELOW:

THE FIRST TWO WORDS IN THE DATA FIELD SPECIFY THE SERIAL NUMBER OF THE PACK. THE SERIAL NUMBER MUST BE A NON-ZERO NUMBER AND CONSISTS OF MAXIMUM 10 OCTAL DIGITS. THE FIRST WORD OF THE SERIAL NUMBER CONTAINS THE 5 LEAST SIGNIFICANT OCTAL DIGITS, WHILE THE SECOND WORD CONTAINS THE 5 MOST SIGNIFICANT DIGITS.

THE THIRD WORD IS ALWAYS ALL 0'S.

THE FORTH WORD IS USUALLY ALL 0'S, UNLESS THE PACK IS AN ALIGNMENT PACK, IN WHICH CASE THE WORD WILL BE 177777.

THE FOLLOWING 252. WORDS DEFINE THE BAD SECTOR ADDRESS INFORMATION. TWO WORDS ARE USED TO DEFINE A SINGLE BAD SECTOR, THE FIRST WORD OF THE PAIR, SPECIFIES THE CYLINDER ADDRESS. THE SECOND WORD OF THE PAIR, SPECIFIES THE TRACK (HIGH BYTE) AND SECTOR (LOW BYTE) ADDRESSES. ALL UNUSED LOCATIONS ARE RECORDED WITH ONES (177777).

THE SECTORS ON THE LAST TRACK (BSF) ARE DIVIDED INTO FOUR GROUPS AS FOLLOWS:

- (1) SECTORS 0, 2, 4, 6 AND 8. CONTAIN THE MANUFACTURES (MFG) DEFINED BAD SECTORS FOR 16 BIT MODE.
- (2) SECTORS 1, 3, 5, 7 AND 9. CONTAIN THE MANUFACTURES (MFG) DEFINED BAD SECTORS FOR 18 BIT MODE.
- (3) SECTORS 10, 12 THRU 30. CONTAIN THE USER (USR) DEFINED BAD SECTORS FOR 16 BIT MODE.
- (4) SECTORS 11, 13 THRU 31. CONTAIN THE USER (USR) DEFINED BAD SECTORS FOR 18 BIT MODE.

THE SECTORS IN EACH GROUP ARE IDENTICAL AND SECTORS 0, 1, 10. AND 11. ARE USED AS REFERENCE SECTORS BY THE PROGRAM.

9.1 BAD SECTOR UTILITY

THE PROGRAM PROVIDES A FEW UTILITY ROUTINES TO HANDLE THE BAD SECTOR FILE. TO ACCESS THESE ROUTINES START THE PROGRAM AT 204.

BEFORE THE PROGRAM FORMATS THE PACK, THE PROGRAM TYPES THE FOLLOWING MESSAGE TO ALLOW THE OPERATOR TO ACCESS THE UTILITIES BY ENTERING THE SELECTED FUNCTION NUMBER.

```

UPDATE 'USR' BAD SECTORS.....0
PRINT 'MFG' BAD SECTORS.....1
PRINT 'USR' BAD SECTORS.....2
INITIALIZE 'USR' BAD SECTOR FILE.....3
PRINT A SECTOR OF THE LAST TRACK.....4
PRINT THIS MESSAGE.....5
CONTINUE.....<CR>

```

ENTER UTILITY FUNCTION (HELP=5):

THE FIRST UTILITY (0) ALLOWS USER DEFINED BAD SECTORS TO BE ENTERED MANUALLY INTO THE 'USR' BAD SECTOR FILE TABLE. THIS IS ACCOMPLISHED BY SPECIFYING THE CYLINDER ADDRESS, TRACK ADDRESS AND SECTOR ADDRESS IN DECIMAL, TO THE FOLLOWING PROMPT.

```

EXAMPLE: CYL,TRK,SEC= C,T,S<CR> ;ENTERS BAD CYL,TRK,SFC IN FILE
          CYL,TRK,SEC= <CR>      ;EXIT

```

TO TERMINATE THE BAD SECTOR ADDRESS ENTRY, TYPE A 'CARRIAGE RETURN' IN RESPONSE TO THE ENTRY REQUEST.

THE SECOND (1) AND THIRD (2) UTILITIES WILL TYPE THE CONTENTS OF THE 'MFG' AND 'USR' BAD SECTOR FILES ON THE CONSOLE IN DECIMAL NUMBER. THE FORMAT OF THE TYPEOUT WILL BE AS FOLLOWS:

PACK S/N: XXXXXX

CONTENTS OF 16 BIT 'MFG OR USR' BAD SECTOR FILE (DECIMAL)
C,T,S

CONTENTS OF 18 BIT 'MFG OR USR' BAD SECTOR FILE (DECIMAL)
C,T,S

WHERE 'XXXXXX' IS THE OCTAL SERIAL NUMBER OF THE PACK. WHERE 'C' IS THE DECIMAL CYLINDER ADDRESS, 'T' IS THE DECIMAL TRACK ADDRESS, AND 'S' IS DECIMAL SECTOR OF THE BAD SECTOR. IF THERE ARE NO ENTRIES CURRENTLY IN THE BAD SECTOR FILES, THE FOLLOWING TYPEOUT WILL APPEAR:

PACK S/N: XXXXXX

CONTENTS OF 16 BIT 'MFG OR USR' BAD SECTOR FILE (DECIMAL)
* NO ENTRIES *

571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627

CONTENTS OF 18 BIT 'MFG OR USR' BAD SECTOR FILE (DECIMAL)
* NO ENTRIES *

THE FOURTH (3) UTILITY WILL RESET ALL BAD SECTOR ENTRIES IN THE 'USR' BAD SECTOR FILE TO -1. THE SERIAL NUMBER WILL NOT BE INITIALIZED BY THIS UTILITY.

THE FIFTH (4) UTILITY WILL ALLOW THE OPERATOR TO LOOK AT A SECTOR OF DATA FROM THE LAST TRACK ON THE LAST CYLINDER (BAD SECTOR FILE). THIS WILL ALLOW THE OPERATOR TO PHYSICALLY SEE WHAT IS IN THE BAD SECTOR FILE. THE DATA IS TYPED OUT IN BLOCK FORM IN OCTAL.

TYPING A '5' WILL ALLOW THE OPERATOR TO DISPLAY THE UTILITY MESSAGE AGAIN ON THE CONSOLE. TO CONTINUE THE PROGRAM OPERATION, JUST TYPE A 'CARRIAGE RETURN' <CR>.

10.1 RH/RM DRIVER

THIS DOCUMENT IS THE USER'S GUIDE FOR THE RH/RM DRIVER.

10.2 TO INITIALIZE THE DRIVER:

```
JSR    PC,RMINIT
RETURN
```

UPON RETURN YOU MUST EXAMINE THE 'DRVSTA' TABLE TO DETERMINE THE DRIVES THAT ARE ONLINE FOR TESTING. THE 'DRVSTA' TABLE IS EIGHT BYTES; ONE BYTE PER DRIVE. THE STATE OF EACH DRIVE WILL BE INDICATED AS FOLLOWS:

DRVSTA	DRIVE STATE
>0	ONLINE
0	OFFLINE, DRIVE IS NOT AN RM05/3/2, OR NONEXISTENT DRIVE
<0	UNSAFE

THE DRIVE TYPE IS DEFINED IN AN 8 BYTE LONG TABLE TAGGED 'DRVTYP'. THE TABLE CONTAINS ONE BYTE FOR EACH DRIVE AND IS INDEXED BY THE DRIVE NUMBER. ENTRIES ARE ENCODED AS FOLLOWS:

DRVTYP	CONDITION
0	NONEXISTENT DRIVE
4	RM03
5	RM02
7	RM05

-1

NOT AN RM05/3/2

THE 'RMINIT' ROUTINE WILL DO A READIN PRESET AND WILL SET FMT16.

10.3 AFTER THE DRIVER HAS BEEN INITIALIZED, IT IS CALLED USING THE FOLLOWING SEQUENCE.

CALL:

```
JSR    RO,RM03
PN-DPB
RETURN1
RETURN2
```

```
;MAKE THE CALL
;ADDRESS OF DPB*
;RETURN IF QUEUE IS FULL
;RETURN IF REQUEST IS IN
;QUEUE OR THERE IS AN
;ERROR CONDITION
```

*DPB (DATA PARAMETER BLOCK)

```
PNTDPB: .BYTE 0      ;(0) DRIVE NUMBER
        .BYTE 0      ;(1) OFFSET VALUE OR FMT16, ECT, AND HCI
        .BYTE 0      ;(2) COMMAND
        .BYTE 0      ;(3) PSEL AND A17 AND A16
        .WORD 0      ;(4) WORD COUNT (MUST BE NEG.)
        .WORD 0      ;(6) BUFFER ADDRESS OR
        .BYTE 0      ;REGISTER TABLE POINTER
        .BYTE 0      ;(10) SECTOR ADDRESS OR
        .WORD 0      ;FIRST REG. INDEX
        .WORD 0      ;(11) TRACK ADDRESS OR
        .WORD 0      ;LAST REG. INDEX
        .WORD 0      ;(12) CYLINDER ADDRESS
        .WORD 0      ;(14) ERROR TABLE POINTER
        .WORD 0      ;POINTS TO THE FIRST OF TWENTY
        .WORD 0      ;LOCATIONS OF WHERE THE DRIVER
        .WORD 0      ;IS TO STORE THE RH/RM
        .WORD 0      ;REGISTERS ON AN ERROR. IF LEFT
        .WORD 0      ;ZERO REGISTERS ARE NOT SAVED.
        .WORD 0      ;(16) STATUS/ERROR INDICATOR
        .WORD 0      ;BIT15=1->ERROR OCCURRED
        .WORD 0      ;BIT07=1->DONE
        .WORD 0      ;BIT14-BIT09 AND BIT06-BIT03
        .WORD 0      ;INDICATE TYPE OF ERROR
```

10.4 THE DRIVER PROVIDES A SOFTWARE TIMEOUT CAPABILITY. TO UTILIZE THIS CAPABILITY YOU MUST SUPPLY THE 'RM TIMER' ROUTINE WITH THE ELAPSED TIME IN THE FOLLOWING MANNER:

```
MOV     #16.,-(SP)    ;16 MILLISECONDS BETWEEN
                     ;CLOCK TICKS
JSR     PC,RMTMR      ;CALL THE TIMER ROUTINE
```

IT SHOULD BE NOTED THAT YOU MUST PROVIDE THE CODE TO DRIVE THE CLOCK. AND THE ELAPSED TIME MUST BE IN MILLISECONDS. THE DRIVER WILL SET THE TIMEOUT TO 1 SECOND FOR ALL POSITIONING AND DATA TRANSFER OPERATIONS AND WILL SET THE TIMEOUT TO 30 SECONDS FOR ERROR RECOVERY OPERATIONS.

10.4.1 EXAMPLE - WRITE 1000. WORDS

685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741

```
1$: JSR    R0,RM03      ;CALL THE DRIVER
    FMTDPB      ;DPB ADDRESS
    BR      1$          ;WAIT FOR QUEUE IF FULL
2$: TST    FMTDPB+16     ;WAIT FOR COMMAND TO COMPLETE
    BEQ     2$          ;
    BMI     ERROR1      ;ERROR OCCURRED
    .
    .
    .
```

```
FMTDPB: .BYTE 5          ;DRIVE #5
        .BYTE 0
        .BYTE 161       ;WRITE COMMAND
        .BYTE 0
        .WORD -1000.     ;WORD COUNT
        .WORD WRTBUF     ;BUFFER ADDRESS
        .BYTE 3          ;SECTOR
        .BYTE 5          ;TRACK
        .WORD 400        ;CYLINDER
        .WORD ERRTB5     ;ERROR TABLE
        .WORD 0          ;STATUS/ERROR INDICATOR
```

ALTERNATE DPB SETUP

```
FMTDPB: .WORD 5          ;THIS SETUP ACHIEVED
        .WORD WRITE      ;EVERYTHING THE
        .WORD -1000.     ;ABOVE TABLE DID, BUT
        .WORD WRTBUF     ;IN A CLEANER FORMAT
        .BYTE 3,5
        .WORD 400,ERRTB5,0
```

10.5 RH/RM REGISTERS

MNEMONIC	INDEX
-----	-----
RMCS1	0
RMWC	2
RMBA	4
RMDA	6
RMCS2	10
RMD5	12
RMER1	14
RMA5	16
RMLA	20
RMDB	22
RMMR1	24
RMD7	26
RMSN	30
RMOF	32
RMDC	34
RMHR	36
RMMR2	40
RMER2	42
RMEC1	44
RMEC2	46

10.6 COMMANDS PERFORMED BY THE DRIVER

COMMAND	CODE	COMMAND TYPE
SEEK	105	P
RECALIBRATE	107	P
DRIVE CLEAR	111	N
RELEASE	113	N
OFFSET	115	P
RETURN TO CENTER	117	P
READIN PRESET	121	N
PACK ACKNOWLEDGE	123	N
SEARCH	131	P
GET REGISTER(S)	141	S
SET FORMAT	143	S
SELECT DRIVE	145	S
WRITE CHECK DATA	151	D
WRT CHK HDR & DATA	153	D
WRITE DATA	161	D
WRITE HEADER & DATA	163	D
READ DATA	171	D
READ HEADER & DATA	173	D

N = HOUSEKEEPING
P = POSITIONING
D = DATA TRANSFER
S = SPECIAL PROVIDED BY THE DRIVER

10.7 DPB STATUS/ERROR INDICATOR WORD

THIS INDICATOR WILL INFORM THE USER OF THE RESULTS OF THE REQUEST. THIS IS ACCOMPLISHED BY SETTING VARIOUS BITS OF THE INDICATOR TO A ONE.

BIT NO.	MEANING IF ON A '1'
15	ERROR OCCURRED DONE (BIT07=0); BITS 14-9 SPECIFIES TYPE DONE (BIT07=1); BITS 6-3 SPECIFIES TYPE
14(1)	USER MADE A REQUEST FOR A FUNCTION TO BE PERFORMED ON AN OFFLINE OR UNSAFE DRIVE
13(1)	USER MADE A REQUEST FOR A FUNCTION TO BE PERFORMED ON A DRIVE THAT HAS AN UNLOAD REQUEST IN QUEUE.
12(2)	PERSISTENT UNSAFE CONDITION EXIST.
11(2)	UNCORRECTABLE PARITY ERROR OCCURRED
10(2)(4)	FATAL PARITY ERROR. A MASSBUS CLEAR WAS PERFORMED, ALL QUEUES WERE EMPTIED, AND ALL DRVACT'S SET TO THE IDLE STATE

799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855

9(3)(4) SOFTWARE TIMEOUT OCCURRED ON THIS DRIVE
8(4) SOFTWARE TIMEOUT OCCURRED ON ANOTHER DRIVE
7 DONE
6(2) ERROR OCCURRED DURING AN I/O OPERATION
5(2) ERROR OCCURRED DURING AN OPERATION OTHER THAN I/O.
4(2) CORRECTABLE UNSAFE CONDITION OCCURRED
3(?) DRIVE ERROR OCCURRED THAT CAUSED AN AUTOMATIC 'RECALIBRATE' SEQUENCE
2 PORT REQUEST TIMEOUT. THE DRIVER REQUESTED THE DRIVE BUT THE OPPOSITE PORT DID NOT RELEASE THE DRIVE WITHIN 15. SECONDS.
1 NON-EXISTENT DRIVE REQUESTED. USER MADE A REQUEST FOR A NON-EXISTENT DRIVE.

NOTES FOR ABOVE

(1) = REQUEST WASN'T PUT IN QUEUE. (RH/RM REGISTERS WERE NOT SAVED)
(2) - REQUEST QUEUE HAS BEEN EMPTIED. THE DRIVER ISSUED A 'DRIVE CLEAR' TO THE DRIVE. NOTE: ALL RH/RM REGISTERS ARE SAVED AS PER DPB+14 BEFORE THE 'DRIVE CLEAR'.
(3) - REQUEST QUEUE HAS BEEN EMPTIED. THE DRIVER ISSUED A MASSBUS INIT. ALL RH/RM REGISTER FOR THE DRIVE WERE SAVED AS PER DPB+14 BEFORE THE INIT.
(4) A 'RECALIBRATE' SHOULD BE ISSUED BEFORE ANY OTHER COMMAND.

10.8 ERROR CALLS MADE BY THE DRIVER.

THERE ARE A FEW ERRORS THAT CAN OCCUR THAT CAN NOT BE INDICATED IN A DPB. WHEN THIS TYPE OF ERROR IS DETECTED BY THE DRIVER IT WILL MAKE AN ERROR CALL OF THE FORM 'ERROR N', WHERE 'N' IS THE ERROR NUMBER AND THE ERROR WILL BE AN EMT INSTRUCTION.

N	TYPE	DATA AVAILABLE
---	----	-----
1	RH70 INTERRUPT	*R4= RMCS1'S ADDRESS

856 OCCURRED (RMAS=0)
857
858 2 UNEXPECTED ATTENTION R1= DRIVE NUMBER
859 OCCURRED R3= ATA BIT
860 *R4= RMCS1'S ADDRESS
861 R5= (RMAS)
862 RMERRS =RMDS
863 RMERRS+2=RMER1
864 RMERRS+4=RMER2
865 RMERRS+6=RMER2
866
867 3 MASSBUS PARITY RD.ADR= ADDRESS OF REG. READ
868 ERROR (MCPE-1) RD.WRD= WORD READ
869
870 4 MASSBUS PARITY WRT.AD= ADDRESS OF REG. WRITTEN
871 ERROR (PAR-1) WRT.WD= WORD WRITTEN
872 RD.WRD= WORD READ BACK
873
874 5 ADDRESS PLUG CHANGE R1= DRIVE NUMBER
875 BIT SET ('OPE' ERROR) R3= ATA BIT
876 *R4= RMCS1'S ADDRESS
877 R5= (RMAS)
878 RMERRS =RMDS
879 RMERRS+2=RMER1
880 RMERRS+4=RMER2
881 RMERRS+6=RMER2
882
883 * THIS IS THE ACTUAL UNIBUS ADDRESS (176700)
884
885 %

.*LAST REVISION 04-APR-81

.TITLE C2RMLB0 RM05/3/2 FORMATTER

.*COPYRIGHT (C) 1981

.*DIGITAL EQUIPMENT CORPORATION

.*COLORADO SPGS., CO. 80919

.*

.*PROGRAM BY MIKE LEAVITT

.*

.*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC

.*PACKAGE (MAINDEC-11-DZOAC-C5), 18-MAR-81

.*

.SBTTL OPERATIONAL SWITCH SETTINGS

.*

SWITCH	USE
15	HALT ON ERROR
13	INHIBIT ERROR TYPEOUTS
10	BELL ON ERROR
9	LOOP ON ERROR
2	DON'T DISPLAY SYSTEM STATUS AFTER INITIAL START
1	LOOP ON THE CURRENT TRACK
0	LOOP THE PROGRAM ON THE SELECTED DRIVE

.SBTTL BASIC DEFINITIONS

.*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***

001100

STACK = 1100

104000

ERROR = EMT

::BASIC DEFINITION OF ERROR CALL

000004

SCOPE = IOT

::BASIC DEFINITION OF SCOPE CALL

.*MISCELLANEOUS DEFINITIONS

000011

HT = 11

::CODE FOR HORIZONTAL TAB

000012

LF = 12

::CODE FOR LINE FEED

000015

CR = 15

::CODE FOR CARRIAGE RETURN

000200

CRLF = 200

::CODE FOR CARRIAGE RETURN-LINE FEED

177776

PS = 177776

::PROCESSOR STATUS WORD

177776

PSW=PS

177774

STKLMT = 177774

::STACK LIMIT REGISTER

177772

PIRQ = 177772

::PROGRAM INTERRUPT REQUEST REGISTER

177570

DSWR = 177570

::HARDWARE SWITCH REGISTER

177570

DDISP = 177570

::HARDWARE DISPLAY REGISTER

.*GENERAL PURPOSE REGISTER DEFINITIONS

000000

R0 = %0

::GENERAL REGISTER

000001

R1 = %1

::GENERAL REGISTER

000002

R2 = %2

::GENERAL REGISTER

000003

R3 = %3

::GENERAL REGISTER

000004

R4 = %4

::GENERAL REGISTER

000005

R5 = %5

::GENERAL REGISTER

000006

R6 = %6

::GENERAL REGISTER

000007

R7 = %7

::GENERAL REGISTER

000006

SP = %6

::STACK POINTER

000007

PC = %7

::PROGRAM COUNTER

.*PRIORITY LEVEL DEFINITIONS

000000

PRO = 0

::PRIORITY LEVEL 0

```

000040      PR1      40      ::PRIORITY LEVEL 1
000100      PR2      100     ::PRIORITY LEVEL 2
000140      PR3      = 140   ::PRIORITY LEVEL 3
000200      PR4      = 200   ::PRIORITY LEVEL 4
000240      PR5      = 240   ::PRIORITY LEVEL 5
000300      PR6      = 300   ::PRIORITY LEVEL 6
000340      PR7      = 340   ::PRIORITY LEVEL 7

```

```

;*'SWITCH REGISTER' SWITCH DEFINITIONS
100000      SW15     = 100000
040000      SW14     = 40000
020000      SW13     = 20000
010000      SW12     = 10000
004000      SW11     = 4000
002000      SW10     = 2000
001000      SW09     = 1000
000400      SW08     = 400
000200      SW07     = 200
000100      SW06     = 100
000040      SW05     = 40
000020      SW04     = 20
000010      SW03     = 10
000004      SW02     = 4
000002      SW01     = 2
000001      SW00     = 1
001000      SW9-SW09
000400      SW8-SW08
000200      SW7-SW07
000100      SW6-SW06
000040      SW5-SW05
000020      SW4-SW04
000010      SW3-SW03
000004      SW2-SW02
000002      SW1-SW01
000001      SW0-SW00

```

```

;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
100000      BIT15    = 100000
040000      BIT14    = 40000
020000      BIT13    = 20000
010000      BIT12    = 10000
004000      BIT11    = 4000
002000      BIT10    = 2000
001000      BIT09    = 1000
000400      BIT08    = 400
000200      BIT07    = 200
000100      BIT06    = 100
000040      BIT05    = 40
000020      BIT04    = 20
000010      BIT03    = 10
000004      BIT02    = 4
000002      BIT01    = 2
000001      BIT00    = 1
001000      BIT9-BIT09
000400      BIT8-BIT08
000200      BIT7-BIT07
000100      BIT6-BIT06

```

000040
 000020
 000010
 000004
 000002
 000001

BIT5=BIT05
 BIT4=BIT04
 BIT3=BIT03
 BIT2=BIT02
 BIT1=BIT01
 BIT0=BIT00

000004
 000010
 000014
 000014
 000014
 000020
 000024
 000030
 000034
 000060
 000064
 000240

;;*BASIC "CPU" TRAP VECTOR ADDRESSES
 ERRVEC = 4 ;;TIME OUT AND OTHER ERRORS
 RESVEC = 10 ;;RESERVED AND ILLEGAL INSTRUCTIONS
 TBITVEC = 14 ;;T BIT
 TRIVEC = 14 ;;TRACE TRAP
 BPTVEC = 14 ;;BREAKPOINT TRAP (BPT)
 IOTVEC = 20 ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
 PWRVEC = 24 ;;POWER FAIL
 EMTVEC = 30 ;;EMULATOR TRAP (EMT) **ERROR**
 TRAPVEC = 34 ;;"TRAP" TRAP
 TKVEC = 60 ;;TTY KEYBOARD VECTOR
 TPVEC = 64 ;;TTY PRINTER VECTOR
 PIQVEC = 240 ;;PROGRAM INTERRUPT REQUEST VECTOR

.SBITL RM REGISTERS

;CONTROL AND STATUS REGISTER 1 (RMCS1)

000100
 000200
 000400
 001000
 002000
 020000
 040000

IE = 100 ;;INTERRUPT ENABLE (BIT #6)
 RDY = 200 ;;READY (BIT #7)
 A16 = 400 ;;HIGH ORDER BUS ADDRESS BIT (BIT #8)
 A17 = 1000 ;;HIGH ORDER BUS ADDRESS BIT (BIT #9)
 PSEL = 2000 ;;PORT SELECT (BIT #10)
 MCPE = 20000 ;;MASSBUS PARITY ERROR (BIT #13)
 TRE = 40000 ;;TRANSFER ERROR (BIT #14)
 SC = 100000 ;;SPECIAL CONDITION (BIT #15)

;WORD COUNT REGISTER (RMWC)
 ;(EACH BIT IS CALLED BY BIT NUMBER)

;BUS ADDRESS REGISTER (RMBA)
 ;(EACH BIT IS CALLED BY BIT NUMBER)

;CONTROL AND STATUS REGISTER 2 (RMCS2)

000001
 000002
 000004
 000010
 000020
 000040
 000100
 000200
 000400
 001000
 002000
 004000
 010000
 020000
 040000

US1 = 1 ;;UNIT SELECT (BIT #0)
 US2 = 2 ;;UNIT SELECT (BIT #1)
 US4 = 4 ;;UNIT SELECT (BIT #2)
 BAI = 10 ;;BUS ADDRESS INCREMENT INHIBIT (BIT #3)
 PAT = 20 ;;MASSBUS PARITY TEST (BIT #4)
 CLR = 40 ;;CLEAR (BIT #5)
 IR = 100 ;;INPUT READY (BIT #6)
 OR = 200 ;;OUTPUT READY (BIT #7)
 MPE = 400 ;;MASS BUS PARITY ERROR (BIT #8)
 MXF = 1000 ;;MISSED TRANSFER ERROR (BIT #9)
 PGE = 2000 ;;PROGRAM ERROR (BIT #10)
 NEM = 4000 ;;NON EXISTENT MEMORY (BIT #11)
 NED = 10000 ;;NON EXISTENT DRIVE (BIT #12)
 UPE = 20000 ;;UNIBUS PARITY ERROR (BIT #13)
 WCE = 40000 ;;WRITE CHECK ERROR (BIT #14)

DLT = 100000 ;DATA LATE (BIT #15)

;DATA BUFFER REGISTER (RMD8)
;(EACH BIT IS CALLED BY BIT NUMBER)

.SBITL RM REGISTERS

;CONTROL AND STATUS 1 REGISTER. (#00)

000001	GO	= 1	;GO BIT (BIT #0)
000002	F1	= 2	;FUNCTION CODE BIT #1
000004	F2	= 4	;FUNCTION CODE BIT #2
000010	F3	= 10	;FUNCTION CODE BIT #3
000020	F4	= 20	;FUNCTION CODE BIT #4
000040	F5	= 40	;FUNCTION CODE BIT #5
004000	DVA	= 4000	;DEVICE AVAILABLE (BIT #11)

;DRIVE STATUS REGISTER (RMDS1) (#01)

000100	VV	= 100	;VOLUME VALID (BIT #6)
000200	DRY	= 200	;DRIVE READY (BIT #7)
000400	DPR	= 400	;DRIVE PRESENT (BIT #8)
001000	PGM	= 1000	;PROGRAMABLE (BIT #9)
002000	LST	= 2000	;LAST SECTOR TRANSFERRED (BIT #10)
004000	WRL	= 4000	;WRITE LOCK (BIT #11)
010000	MOL	= 10000	;MEDIUM ON-LINE (BIT #12)
020000	PIP	= 20000	;POSITIONING OPERATION IN PROGRESS (BIT #13)
040000	ERR	= 40000	;COMPOSITE ERROR (BIT #14)
100000	ATA	= 100000	;ATTENTION ACTIVE (BIT #15)

;ERROR REGISTER #01 (RMER1) (#02)

000001	ILF	= 1	;ILLEGAL FUNCTION (BIT #0)
000002	ILR	= 2	;ILLEGAL REGISTER (BIT #1)
000004	RMR	= 4	;REGISTER MODIFICATION REFUSED (BIT #2)
000010	PAR	= 10	;PARITY ERROR (BIT #3)
000020	FER	= 20	;FORMAT ERROR (BIT #4)
000040	WCF	= 40	;WRITE CLOCK FAIL (BIT #5)
000100	ECH	= 100	;ECC HARD ERROR (BIT #6)
000200	HCE	= 200	;HEADER COMPARE ERROR (BIT #7)
000400	HCR	= 400	;HEADER CRC ERROR (BIT #8)
001000	AOE	= 1000	;ADDRESS OVERFLOW ERROR (BIT #9)
002000	IAE	= 2000	;INVALID ADDRESS ERROR (BIT #10)
004000	WLE	= 4000	;WRITE LOCK ERROR (BIT #11)
010000	DTE	= 10000	;DRIVE TIMING ERROR (BIT #12)
020000	OPI	= 20000	;OPERATION INCOMPLETE (BIT #13)
040000	UNS	= 40000	;DRIVE UNSAFE (BIT #14)
100000	DCK	= 100000	;DATA CHECK ERROR (BIT 15)

;MAINTAINABILITY REGISTER (RMMR1) (#03)

000001	DMD	= 1	;DIAGNOSTIC MODE (BIT #0)
000002	MCLK	= 2	;MAINTAINABILITY CLOCK (BIT #1)
000004	MINX	= 4	;MAINTAINABILITY INDEX (BIT #2)
000010	MSTCK	= 10	;MAINTAINABILITY SECTOR CLOCK (BIT #3)
000020	MRD	= 20	;MAINTAINABILITY READ (BIT #4)
000040	MWR	= 40	;MAINTAINABILITY WRITE (BIT #5)


```

163      000200      DTSY      = 200      ;MAINTAINABILITY SYNC DETECTED (BIT #7)
164
165      ;ATTENTION SUMMARY PSEUDO-REGISTER (RMAS) (#04)
166
167      000001      AT0       = 1      ;DEVICE 0 (BIT #0)
168      000002      AT1       = 2      ;DEVICE 1 (BIT #1)
169      000004      AT2       = 4      ;DEVICE 2 (BIT #2)
170      000010      AT3       = 10     ;DEVICE 3 (BIT #3)
171      000020      AT4       = 20     ;DEVICE 4 (BIT #4)
172      000040      AT5       = 40     ;DEVICE 5 (BIT #5)
173      000100      AT6       = 100    ;DEVICE 6 (BIT #6)
174      000200      AT7       = 200    ;DEVICE 7 (BIT #7)
175
176      ;DESIRED SECTOR/TRACK ADDRESS REGISTER (RMDA) (#05)
177      ;(EACH BIT IS CALLED BY BIT NUMBER)
178
179      ;DRIVE TYPE REGISTER (RMDT) (#06)
180
181      000001      DT00      = 1      ;DRIVE TYPE NUMBER BIT 1
182      000002      DT01      = 2      ;DRIVE TYPE NUMBER BIT 2
183      000004      DT02      = 4      ;DRIVE TYPE NUMBER BIT 3
184      000010      DT03      = 10     ;DRIVE TYPE NUMBER BIT 4
185      000020      DT04      = 20     ;DRIVE TYPE NUMBER BIT 5
186      000040      DT05      = 40     ;DRIVE TYPE NUMBER BIT 6
187      000100      DT06      = 100    ;DRIVE TYPE NUMBER BIT 7
188      000200      DT07      = 200    ;DRIVE TYPE NUMBER BIT 8
189      000400      DT08      = 400    ;DRIVE TYPE NUMBER BIT 9
190      004000      DRQ       = 4000   ;DRIVE REQUEST REQUIRED (BIT #11)
191      020000      MOH       = 20000  ;MOVING HEAD (BIT #13)
192      040000      TAP       = 40000  ;TAPE DRIVE (BIT #14)
193      100000      N8A       = 100000 ;NOT BLOCK ADDRESSED (BIT #15)
194
195      ;LOOK-AHEAD REGISTER (RMLA) (#07)
196
197      000100      SC01      = 100     ;SECTOR COUNT FIELD 0 (BIT #6)
198      000200      SC02      = 200     ;SECTOR COUNT FIELD 1 (BIT #7)
199      000400      SC04      = 400     ;SECTOR COUNT FIELD 2 (BIT #8)
200      001000      SC10      = 1000    ;SECTOR COUNT FIELD 3 (BIT #9)
201      002000      SC20      = 2000    ;SECTOR COUNT FIELD 4 (BIT #10)
202
203      004000      TRK1      = 4000    ;TRACK FIELD 1 (BIT #11)
204      010000      TRK2      = 10000   ;TRACK FIELD 2 (BIT #12)
205      020000      TRK4      = 20000   ;TRACK FIELD 3 (BIT #13)
206      040000      TRK10     = 40000   ;TRACK FIELD 4 (BIT #14)
207      100000      TRK20     = 100000  ;TRACK FIELD 5 (BIT #15)
208
209      ;OFFSET REGISTER (RMOF) (#11)
210
211      000001      OFDIR     = 1      ;OFFSET DIRECTION
212      002000      HCI       = 2000   ;HEADER COMPARE INHIBIT (BIT #10)
213      004000      ECI       = 4000   ;ERROR CORRECTION CODE INHIBIT (BIT #11)
214      010000      FMT16     = 10000  ;FORMAT BIT (BIT #12)
215
216      ;DESIRED CYLINDER ADDRESS (RMDC) (#12)
217      ;(EACH BIT IS CALLED BY BIT NUMBER)
218
219      ;SERIAL NUMBER REGISTER (RMSN) (#14)

```

220				; (EACH IS CALLED BY BIT NUMBER)
221				
222				; RM MAINTENANCE REGISTER #02 (RMMR2) (#15)
223				
224	040000	SKI	= 40000	; SEEK INCOMPLETE (BIT #14)
225				
226				; ERROR REGISTER #02 (RMER2)
227				
228	100000	BSE	= 100000	; BAD SECTOR ERROR (BIT #15)
229				
230				; ECC POSITION REGISTER (RMEC1) (#16)
231				; (EACH BIT IS CALLED BY BIT NUMBER)
232				
233				; ECC PATTERN REGISTER (RMEC2) (#17)
234				; (EACH BIT IS CALLED BY BIT NUMBER)
235				
236				; SOME 1ST HEADER WORD DEFINITIONS
237				
238	100000	MF	100000	; MANUFACTURES BAD SECTOR FLAG (BIT #5)
239	040000	UF	= 40000	; USERS BAD SECTOR FLAG (BIT #14)
240	010000	FMT	= 10000	; FORMAT 16 BIT MODE (BIT #12)
241				
242				.SBTTL RM DRIVER COMMANDS
243				
244	000105	SEEK	= 105	; SEEK
245	000107	RECAL	= 107	; RECALIBRATE
246	000111	DRVCLR	= 111	; DRIVE CLEAR
247	000113	RELSE	= 113	; RELEASE
248	000115	OFFSET	= 115	; OFFSET
249	000117	RTC	= 117	; RETURN TO CENTER LINE
250	000121	READIN	= 121	; READ IN PRESET
251	000123	ACK	= 123	; PACK ACKNOWLEDGE
252	000131	SEARCH	= 131	; SEARCH
253	000141	GETREG	= 141	; GET REGISTERS
254	000143	SETFMT	= 143	; SET FORMAT (& ECI OR HCI)
255	000145	SELDRV	= 145	; SELECT DRIVE
256	000151	WCKD	= 151	; WRITE CHECK DATA
257	000153	WCKHD	= 153	; WRITE CHECK HEADER & DATA
258	000161	WRDAT	= 161	; WRITE DATA
259	000163	WRTHD	= 163	; WRITE HEADER & DATA
260	000171	RDDAT	= 171	; READ DATA
261	000173	RDHD	= 173	; READ HEADER & DATA
262				
263	176700	ABASE	= 176700	
264	000254	AVECT1	= 254	
265				

.SBTTL TRAP CATCHER

000000
000174 000174
000176 000000
000176 000000

.-0
:*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A '.*2,HAL*'
:*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
:*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
.=174
DISPREG: .WORD 0 ;;SOFTWARE DISPLAY REGISTER
SWREG: .WORD 0 ;;SOFTWARE SWITCH REGISTER

.SBTTL STARTING ADDRESS(ES)

2 000200 000137 007012
3 000204 000137 007020
4
5

JMP @#START ;;JUMP TO STARTING ADDRESS OF PROGRAM
JMP @#START1 ;CHANGE THE RH/RM ADDRESS

.SBTTL ACT11 HOOKS

000210
000046 000046
016352
000052
000052 020000
000210
6
7 001100
8

:HOOK REQUIRED BY ACT11
\$SVPC=.;SAVE PC
46
\$ENDAD ;;1)SET LOC.46 TO ADDRESS OF \$ENDAD IN .\$EOP
52
;WORD 20000 ;;2)SET LOC.52 TO 20000
;-\$SVPC ;;RESTORE PC

. 1100
.SBTTL APT PARAMETER BLOCK

001100
000024
000024 000200
000044
000044 001100
001100

:SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT

.\$X=.;SAVE CURRENT LOCATION
24 ;;SET POWER FAIL TO POINT TO START OF PROGRAM
200 ;;FOR APT START UP
=44 ;;POINT TO APT INDIRECT ADDRESS PNTR.
\$APTHDR ;;POINT TO APT HEADER BLOCK
=.\$X ;;RESET LOCATION COUNTER

:SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
:INTERFACE SPEC.

001100
001100 000000
001102 001210
001104 002734
001106 002734
001110 002734
001112 000032
9 001114
10

\$APTHD:
\$HIBTS: .WORD 0 ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
\$MBADR: .WORD \$MAIL ;;ADDRESS OF APT MAILBOX (BITS 0-15)
\$TSTM: .WORD 1500. ;;RUN TIM OF LONGEST TEST
\$PASTM: .WORD 1500. ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
\$UNITM: .WORD 1500. ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDED UNIT
;WORD \$ETEND-\$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)
TAB.XY-.;CMTAGSTARTING ADDRESS

0

.SBTTL COMMON TAGS

```
*****
*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
*USED IN THE PROGRAM.
```

	001114			.=TAB.XY	
001114	000000			\$CMTAG:	::START OF COMMON TAGS
001116	000			.WORD 0	
001117	000			\$TSTNM: .BYTE 0	::CONTAINS THE TEST NUMBER
001120	000000			\$ERFLG: .BYTE 0	::CONTAINS ERROR FLAG
001122	000000			\$ICNT: .WORD 0	::CONTAINS SUBTEST ITERATION COUNT
001124	000000			\$LPADR: .WORD 0	::CONTAINS SCOPE LOOP ADDRESS
001126	000000			\$LPERR: .WORD 0	::CONTAINS SCOPE RETURN FOR ERRORS
001130	000			\$ERTTL: .WORD 0	::CONTAINS TOTAL ERRORS DETECTED
001131	001			\$ITEMB: .BYTE 0	::CONTAINS ITEM CONTROL BYTE
001132	000000			\$ERMAX: .BYTE 1	::CONTAINS MAX. ERRORS PER TEST
001134	000000			\$ERRPC: .WORD 0	::CONTAINS PC OF LAST ERROR INSTRUCTION
001136	000000			\$GDADR: .WORD 0	::CONTAINS ADDRESS OF 'GOOD' DATA
001140	000000			\$BDADR: .WORD 0	::CONTAINS ADDRESS OF 'BAD' DATA
001142	000000			\$GDDAT: .WORD 0	::CONTAINS 'GOOD' DATA
001144	000000			\$BDDAT: .WORD 0	::CONTAINS 'BAD' DATA
001146	000000			.WORD 0	::RESERVED--NOT TO BE USED
001150	000			.WORD 0	
001151	000			\$AUTOB: .BYTE 0	::AUTOMATIC MODE INDICATOR
001152	000000			\$INTAG: .BYTE 0	::INTERRUPT MODE INDICATOR
001154	177570			.WORD 0	
001156	177570			SWR: .WORD DSWR	::ADDRESS OF SWITCH REGISTER
001160	177560			DISPLAY: .WORD DDISP	::ADDRESS OF DISPLAY REGISTER
001162	177562			\$TKS: 177560	::TTY KBD STATUS
001164	177564			\$TKB: 177562	::TTY KBD BUFFER
001166	177566			\$TPS: 177564	::TTY PRINTER STATUS REG. ADDRESS
001170	000			\$TPB: 177566	::TTY PRINTER BUFFER REG. ADDRESS
001171	002			\$NULL: .BYTE 0	::CONTAINS NULL CHARACTER FOR FILLS
001172	012			\$FILLS: .BYTE 2	::CONTAINS # OF FILLER CHARACTERS REQUIRED
001173	000			\$FILLC: .BYTE 12	::INSERT FILL CHARS. AFTER A 'LINE FEED'
001174	000000			\$TPFLG: .BYTE 0	::'TERMINAL AVAILABLE' FLAG (BIT<07> 0=YES)
001176	000000			\$TMP0: .WORD 0	::USER DEFINED
001200	207	377	377	\$ESCAPE: 0	::ESCAPE ON ERROR ADDRESS
001204	077			\$BELL: .ASCIZ <207><377><377>	::CODE FOR BELL
001205	015			\$QUES: .ASCII /?/	::QUESTION MARK
001206	012	000		\$CRLF: .ASCII <15>	::CARRIAGE RETURN
				\$LF: .ASCIZ <12>	::LINE FEED

.SBTTL APT MAILBOX-ETABLE

```
*****
.EVEN
$MAIL: ::APT MAILBOX
$MSGTY: .WORD AMSGTY ::MESSAGE TYPE CODE
$FATAL: .WORD AFATAL ::FATAL ERROR NUMBER
$TESTN: .WORD ATESTN ::TEST NUMBER
$PASS: .WORD APASS ::PASS COUNT
$DEVCT: .WORD ADEVCT ::DEVICE COUNT
$UNIT: .WORD AUNIT ::I/O UNIT NUMBER
$MSGAD: .WORD AMSGAD ::MESSAGE ADDRESS
$MSGLG: .WORD AMSGLG ::MESSAGE LENGTH
```

001230		SETABLE:		::APT ENVIRONMENT TABLE
001230	000	\$ENV: .BYTE	AENV	::ENVIRONMENT BYTE
001231	000	\$ENVM: .BYTE	AENVM	::ENVIRONMENT MODE BITS
001232	000000	\$SWREG: .WORD	ASWREG	::APT SWITCH REGISTER
001234	000000	\$USWR: .WORD	AUSWR	::USER SWITCHES
001236	000000	\$CPUOP: .WORD	ACPUOP	::CPU TYPE, OPTIONS
		::		BITS 15-11=CPU TYPE
		::		11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05
		::		11/70=06, PDQ=07, Q=10
		::		BIT 10=REAL TIME CLOCK
		::		BIT 9=FLOATING POINT PROCESSOR
		::		BIT 8 MEMORY MANAGEMENT
001240	000	\$MAMS1: .BYTE	AMAMS1	::HIGH ADDRESS, M.S. BYTE
001241	000	\$MTYP1: .BYTE	AMTYP1	::MEM. TYPE, BLK#1
		::		MEM. TYPE BYTE -- (HIGH BYTE)
		::		900 NSEC CORE=001
		::		300 NSEC BIPOLAR=002
		::		500 NSEC MOS=003
001242	000000	\$MADR1: .WORD	AMADR1	::HIGH ADDRESS, BLK#1
		::		MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE
001244	000	\$MAMS2: .BYTE	MAMS2	::HIGH ADDRESS, M.S. BYTE
001245	000	\$MTYP2: .BYTE	AMTYP2	::MEM. TYPE, BLK#2
001246	000000	\$MADR2: .WORD	AMADR2	::MEM. LAST ADDRESS, BLK#2
001250	000	\$MAMS3: .BYTE	AMAMS3	::HIGH ADDRESS, M.S. BYTE
001251	000	\$MTYP3: .BYTE	AMTYP3	::MEM. TYPE, BLK#3
001252	000000	\$MADR3: .WORD	AMADR3	::MEM. LAST ADDRESS, BLK#3
001254	000	\$MAMS4: .BYTE	AMAMS4	::HIGH ADDRESS, M.S. BYTE
001255	000	\$MTYP4: .BYTE	AMTYP4	::MEM. TYPE, BLK#4
001256	000000	\$MADR4: .WORD	AMADR4	::MEM. LAST ADDRESS, BLK#4
001260	000254	\$VECT1: .WORD	AVECT1	::INTERRUPT VECTOR#1, BUS PRIORITY#1
001262	000000	\$VECT2: .WORD	AVECT2	::INTERRUPT VECTOR#2, BUS PRIORITY#2
001264	176700	\$BASE: .WORD	ABASE	::BASE ADDRESS OF EQUIPMENT UNDER TEST
001266	000000	\$DEVN: .WORD	ADEVN	::DEVICE MAP
001270	000000	\$CDW1: .WORD	ACDW1	::CONTROLLER DESCRIPTION WORD#1
001272	000000	\$CDW2: .WORD	ACDW2	::CONTROLLER DESCRIPTION WORD#2
001274		\$ETEND:		
		.MEXIT		

.SBTTL USER DEFINED TAGS

001274	176700		\$RMADR: .WORD	176700	:RH/RM UNIBUS ADDRESS
001276	000254		\$RMVEC: .WORD	254	:RH/RM INTERRUPT VECTOR
001300	172540		\$LKCSR: .WORD	172540	:ADDRESS OF KW11-P CSR
001302	172542		\$LKCSB: .WORD	172542	:ADDRESS OF KW11-P COUNTER BUFFER
001304	000104	000106	\$LPVEC: .WORD	104,106	:ADDRESS OF KW11-P VECTOR
001310	177546		\$LKS: .WORD	177546	:ADDRESS OF KW11-L CONTROL REGISTER
001312	000100	000102	\$LLVEC: .WORD	100,102	:ADDRESS OF KW11-L VECTOR
	001222		DRIVE	-\$UNIT	:CONTAINS DRIVE NUMBER SELECTED
					:SAME PARAMETER USED IN APT
001316	000000		SOF SW: .WORD	0	:CONTENTS ARE FOR SOFTWARE DECISIONS
001320	000000		MODE: .WORD	0	:FORMAT= 0, VERIFY HEADERS= 1
001322	000000		SNGSEC: .WORD	0	:READ MULTI-SECTOR= 0, READ SINGLE SECTOR= 1
001324	000000		LSTRK: .WORD	0	:CONTAINS THE LAST TRACK OF THE UNIT UNDER
					:TEST. RM02/3= 4., RM05= 18.
001326	000000		MAXCYL: .WORD	0	:ENDING CYLINDER
001330	000000		MINCYL: .WORD	0	:STARTING CYLINDER
001332	000000		MAXTRK: .WORD	0	:ENDING TRACK
001334	000000		MINTRK: .WORD	0	:STARTING TRACK
001336	155555		PATA: .WORD	155555	:1ST WORD OF PATTERN (WCP)
001340	133333		PATB: .WORD	133333	:2ND WORD OF PATTERN (WCP)
001342	000000		RETRY: .WORD	0	:MAINTAINS # OF WRITE RETRIES MADE
001344	000000		BADSEC: .WORD	0	:CONTAINS LAST BAD SECTOR ON FORMAT
001346	000000		SAVWC: .WORD	0	:CONTAINS WC FOR REMAINING SECTORS ON ERROR
001350	000000		WC: .WORD	0	:30 OR 32 SECTOR TRACK SIZE (IN WORDS)
001352	000000		MWC: .WORD	0	:2'S COMPLEMENT OF 'WC'
001354	000000		HEDERR: .WORD	0	:POSITIONING ERROR DURING FORMAT INDICATOR
001356	000000		SEC30: .WORD	0	:30 OR 32 SECTOR MODE INDICATOR
					: 0= 30. SECTOR MODE (18 BIT MODE)
					: -1= 32. SECTOR MODE (16 BIT MODE)
001360	000000		MAXSEC: .WORD	0	:MAXIMUM SECTOR ADDRESS, 29. FOR 18. BIT MODE OR
					:31. FOR 16 BIT MODE
001362	000000		DS.CYL: .WORD	0	:ADDRESS OF CURRENT CYLINDER
001364	000000		DS.TRK: .WORD	0	:ADDRESS OF CURRENT TRACK
001366	000000		DDRIVE: .WORD	0	:DRIVE NUMBER OF 'DRIVER' ERROR MESSAGES
001370	000000		ATTN: .WORD	0	:ATTENTION REGISTER IMAGE FOR 'DRIVER'
					:ERROR MESSAGES
001372	000000		CNTLC: .WORD	0	:ADDRESS OF '^C' RETURN
001374	000001		CHGADR: .WORD	1	: 'CHANGE RH/RM ADDRESS' FLAG 1
001376	000000		WRAP: .WORD	0	:WRAP AROUND FLAG,FORMAT FROM HIGH TO LOW
					:CYLINDER NUMBER
001400	000000	000000	DEVMP: .WORD	0,0	:DEVICE MAP FOR APT, DEVMP+2 IS STORAGE FOR DEVICE MAP
001404	000000		BSFAVL: .WORD	0	:IF > 0, BAD SECTOR FILE AVAILABLE FROM PACK
001406	000000		UPDBSF: .WORD	0	:IF > 0, UPDATE BAD SECTOR FILE AT 'EOP'
001410	000000		HDRBIT: .WORD	0	:HEADER BIT INDICATOR FOR FIRST HEADER WORD:
					:BIT15=1 AND BIT14=1, GOOD SECTOR
					:BIT15=0 AND BIT14=1, MFG BAD SECTOR
					:BIT15=1 AND BIT14=0, USR BAD SECTOR
001412	000000		XXDP: .WORD	0	:THE LOW BYTE CONTAINS THE DRIVE NUMBER FROM WHICH
					:THE PROGRAM WAS LOADED. THE HIGH BYTE CONTAINS THE
					: 'XXDP' DEVICE CODE THE RM05/3/2.

:THIS TABLE WILL CONTAIN A COPY OF THE 16 BIT 'MFG' FILE

001414

MFG16: .BLKW 256. :MFG 16 BIT BAD SECTOR TABLE

002414 177777
002416 177777

.WORD -1
.WORD -1

; THIS TABLE WILL CONTAIN A COPY OF THE 18 BIT 'MFG' FILE

002420
003420 177777
003422 177777

MFG18: .BLKW 256. ; MFG 18 BIT BAD SECTOR TABLE
.WORD -1
.WORD -1

; THIS TABLE WILL CONTAIN THE 16 BIT 'USR' FILE IF PACK IS BEING FORMATTED
; IN 16 BIT MODE; ELSE THIS TABLE WILL CONTAIN THE 18 BIT 'USR' FILE IF THE
; PACK IS BEING FORMATTED IN 18 BIT MODE

003424
004424 177777
004426 177777

USTAB: .BLKW 256. ; USER BAD SECTOR TABLE
.WORD -1
.WORD -1

; THIS TABLE WILL SAVE THE 18 BIT 'USR' FILE IF PACK IS BEING FORMATTED
; IN 16 BIT MODE; ELSE THIS TABLE WILL SAVE THE 16 BIT 'USR' FILE IF THE
; PACK IS BEING FORMATTED IN 18 BIT MODE

004430
005430 177777
005432 177777

USSAV: .BLKW 256. ; USER BAD SECTOR SAVED TABLE
.WORD -1
.WORD -1

; CONTAINS A LIST OF CURRENT BAD SECTORS ON THE TRACK BEING FORMATTED

005434
005534 177777
005536 000000

SECCU: .BLKW 32. ; MAXIMUM OF 32. BAD SECTORS
.WORD -1
NEXT: .WORD 0 ; FLAG, IF NEXT=-1, ALL GOOD SPOT ON
; THE CURRENT TRACK ARE FORMATTED

; DATA/PARAMETER BLOCK - USED FOR ALL DRIVE OPERATION

005540 000
005541 000
005542 000
005543 000
005544 000000
005546 000000
005550 000
005551 000
005552 000000
005554 005560
005556 000000

FMTDPB: .BYTE 0 ; DRIVE NUMBER
.BYTE 0 ; OFFSET VALUE OR FMT16, ECI, AND HCI
.BYTE 0 ; COMMAND
.BYTE 0 ; PSEL AND A17 AND A16
.WORD 0 ; WORD COUNT (NEG)
.WORD 0 ; BUFFER ADDRESS
.BYTE 0 ; SECTOR ADDRESS
.BYTE 0 ; TRACK ADDRESS
.WORD 0 ; CYLINDER ADDRESS
.WORD RM.REG ; ERROR TABLE POINTER
.WORD 0 ; STATUS-ERROR INDICATOR
; BIT 15 = 1: ERROR OCCURRED
; BIT 07 = 1: DONE
; BIT 14-10 AND BIT 06-03
; INDICATE TYPE OF ERROR

; RH/RM REGISTERS STORED HERE AFTER AN OPERATION

005560 000000
005562 000000
005564 000000
005566 000000
005570 000000

RM.REG: .WORD 0 ; RMCS1
.WORD 0 ; RMWC
.WORD 0 ; RMBA
.WORD 0 ; RMDA
.WORD 0 ; RMCS2

005572	000000	.WORD	0	:RMD5
005574	000000	.WORD	0	:RMR1
005576	000000	.WORD	0	:RMA5
005600	000000	.WORD	0	:RMLA
005602	000000	.WORD	0	:RMD8
005604	000000	.WORD	0	:RMR1
005606	000000	.WORD	0	:RMDT
005610	000000	.WORD	0	:RMSN
005612	000000	.WORD	0	:RMOF
005614	000000	.WORD	0	:RMCA
005616	000000	.WORD	0	:RMDC
005620	000000	.WORD	0	:RMR2
005622	000000	.WORD	0	:RMR2
005624	000000	.WORD	0	:RMEC1
005626	000000	.WORD	0	:RMEC2

005630	000	FMWRT: .BYTE 0 ;SPECIAL DPB TO WRITE HEADER OF BAD SECTOR		
005631	000	.BYTE	0	
005632	000	.BYTE	0	
005633	000	.BYTE	0	
005634	177776	.WORD	-2	:ONLY TWO WORDS FOR HEADER
005636	046224	.WORD	RBUF	:BUFFER ADDRESS
005640	000	.BYTE	0	:SECTOR
005641	000	.BYTE	0	:TRACK
005642	000000	.WORD	0	:CYLINDER ADDRESS
005644	000000	.WORD	0	:ERROR TABLE
				:DONT'SAVE ANYTHING
005646	000000	.WORD	0	:STATUS WORD

:PARAMETER LIMIT POINTER TABLE

005650	005754	001466	001330	TABLE: PAR1,822.,MINCYL
005656	005764	001466	001326	PAR2,822.,MAXCYL
005664	005774	000004	001334	PAR3,4.,MINTRK
005672	006004	000004	001332	PAR4,4.,MAXTRK,0
005702	006014			TABLE2: PAR5 ;ASCII MESSAGE FOR INPUT
005704	001466	001362		822.,DS.CYL
005710	000004	001364		4.,DS.TRK
005714	000037	001344		31.,BADSEC
005720	006014			TABLE3: PAR5 ;ASCII MESSAGE FOR INPUT
005722	001466	001362		822.,DS.CYL
005726	000004	001364		4.,DS.TRK
005732	000035	001344		29.,BADSEC
005736	006032			TABLE4: PAR6 ;ASCII MESSAGE FOR INPUT
005740	001466	001362		822.,DS.CYL
005744	000004	001364		4.,DS.TRK
005750	047300	001344		20160.,BADSEC

:ASCII MESSAGES FOR ADDRESS PARAMETERS

005754	115	111	116	PAR1: .ASCII /MINCYL /
005764	115	101	130	PAR2: .ASCII /MAXCYL /
005774	115	111	116	PAR3: .ASCII /MINTRK /
006004	115	101	130	PAR4: .ASCII /MAXTRK /

006014 103 131 114 PAR5: .ASCIZ /CYL,TRK,SEC= /
006032 103 131 114 PAR6: .ASCIZ /CYL,TRK,BYTE= /
.EVEN

006052 021414 021624 021676 TABCAL: .WORD FUNCT2,FUNCT3,FUNCT4,FUNCT6,FUNCT7

:SECTOR BUFFER ADDRESS TABLE

006064	046234	ADRTBL: .WORD	BU'P	:ADDRESS OF SECTOR 0
006066	047240	.WORD	BUFP+<516.*1.>	:ADDRESS OF SECTOR 1.
006070	050244	.WORD	BUFP+<516.*2.>	:ADDRESS OF SECTOR 2.
006072	051250	.WORD	BUFP+<516.*3.>	:ADDRESS OF SECTOR 3.
006074	052254	.WORD	BUFP+<516.*4.>	:ADDRESS OF SECTOR 4.
006076	053260	.WORD	BUFP+<516.*5.>	:ADDRESS OF SECTOR 5.
006100	054264	.WORD	BUFP+<516.*6.>	:ADDRESS OF SECTOR 6.
006102	055270	.WORD	BUFP+<516.*7.>	:ADDRESS OF SECTOR 7.
006104	056274	.WORD	BUFP+<516.*8.>	:ADDRESS OF SECTOR 8.
006106	057300	.WORD	BUFP+<516.*9.>	:ADDRESS OF SECTOR 9.
006110	060304	.WORD	BUFP+<516.*10.>	:ADDRESS OF SECTOR 10.
006112	061310	.WORD	BUFP+<516.*11.>	:ADDRESS OF SECTOR 11.
006114	062314	.WORD	BUFP+<516.*12.>	:ADDRESS OF SECTOR 12.
006116	063320	.WORD	BUFP+<516.*13.>	:ADDRESS OF SECTOR 13.
006120	064324	.WORD	BUFP+<516.*14.>	:ADDRESS OF SECTOR 14.
006122	065330	.WORD	BUFP+<516.*15.>	:ADDRESS OF SECTOR 15.
006124	066334	.WORD	BUFP+<516.*16.>	:ADDRESS OF SECTOR 16.
006126	067340	.WORD	BUFP+<516.*17.>	:ADDRESS OF SECTOR 17.
006130	070344	.WORD	BUFP+<516.*18.>	:ADDRESS OF SECTOR 18.
006132	071350	.WORD	BUFP+<516.*19.>	:ADDRESS OF SECTOR 19.
006134	072354	.WORD	BUFP+<516.*20.>	:ADDRESS OF SECTOR 20.
006136	073360	.WORD	BUFP+<516.*21.>	:ADDRESS OF SECTOR 21.
006140	074364	.WORD	BUFP+<516.*22.>	:ADDRESS OF SECTOR 22.
006142	075370	.WORD	BUFP+<516.*23.>	:ADDRESS OF SECTOR 23.
006144	076374	.WORD	BUFP+<516.*24.>	:ADDRESS OF SECTOR 24.
006146	077400	.WORD	BUFP+<516.*25.>	:ADDRESS OF SECTOR 25.
006150	100404	.WORD	BUFP+<516.*26.>	:ADDRESS OF SECTOR 26.
006152	101410	.WORD	BUFP+<516.*27.>	:ADDRESS OF SECTOR 27.
006154	102414	.WORD	BUFP+<516.*28.>	:ADDRESS OF SECTOR 28.
006156	103420	.WORD	BUFP+<516.*29.>	:ADDRESS OF SECTOR 29.
006160	104424	.WORD	BUFP+<516.*30.>	:ADDRESS OF SECTOR 30.
006162	105430	.WORD	BUFP+<516.*31.>	:ADDRESS OF SECTOR 31.

:REMAINING WORD COUNT TABLE

006164	000402	WCTBL: .WORD	258.	:REMAINING WORD COUNT AFTER SECTOR 0
006166	001004	.WORD	258.+<258.*1.>	:REMAINING WORD COUNT AFTER SECTOR 1.
006170	001406	.WORD	258.+<258.*2.>	:REMAINING WORD COUNT AFTER SECTOR 2.
006172	002010	.WORD	258.+<258.*3.>	:REMAINING WORD COUNT AFTER SECTOR 3.
006174	002412	.WORD	258.+<258.*4.>	:REMAINING WORD COUNT AFTER SECTOR 4.
006176	003014	.WORD	258.+<258.*5.>	:REMAINING WORD COUNT AFTER SECTOR 5.
006200	003416	.WORD	258.+<258.*6.>	:REMAINING WORD COUNT AFTER SECTOR 6.
006202	004020	.WORD	258.+<258.*7.>	:REMAINING WORD COUNT AFTER SECTOR 7.
006204	004422	.WORD	258.+<258.*8.>	:REMAINING WORD COUNT AFTER SECTOR 8.
006206	005024	.WORD	258.+<258.*9.>	:REMAINING WORD COUNT AFTER SECTOR 9.
006210	005426	.WORD	258.+<258.*10.>	:REMAINING WORD COUNT AFTER SECTOR 10.
006212	006030	.WORD	258.+<258.*11.>	:REMAINING WORD COUNT AFTER SECTOR 11.
006214	006432	.WORD	258.+<258.*12.>	:REMAINING WORD COUNT AFTER SECTOR 12.

006216	007034	.WORD	258.*<258.*13.>	;REMAINING WORD COUNT AFTER SECTOR 13.
006220	007436	.WORD	258.*<258.*14.>	;REMAINING WORD COUNT AFTER SECTOR 14.
006222	010040	.WORD	258.*<258.*15.>	;REMAINING WORD COUNT AFTER SECTOR 15.
006224	010442	.WORD	258.*<258.*16.>	;REMAINING WORD COUNT AFTER SECTOR 16.
006226	011044	.WORD	258.*<258.*17.>	;REMAINING WORD COUNT AFTER SECTOR 17.
006230	011446	.WORD	258.*<258.*18.>	;REMAINING WORD COUNT AFTER SECTOR 18.
006232	012050	.WORD	258.*<258.*19.>	;REMAINING WORD COUNT AFTER SECTOR 19.
006234	012452	.WORD	258.*<258.*20.>	;REMAINING WORD COUNT AFTER SECTOR 20.
006236	013054	.WORD	258.*<258.*21.>	;REMAINING WORD COUNT AFTER SECTOR 21.
006240	013456	.WORD	258.*<258.*22.>	;REMAINING WORD COUNT AFTER SECTOR 22.
006242	014060	.WORD	258.*<258.*23.>	;REMAINING WORD COUNT AFTER SECTOR 23.
006244	014462	.WORD	258.*<258.*24.>	;REMAINING WORD COUNT AFTER SECTOR 24.
006246	015064	.WORD	258.*<258.*25.>	;REMAINING WORD COUNT AFTER SECTOR 25.
006250	015466	.WORD	258.*<258.*26.>	;REMAINING WORD COUNT AFTER SECTOR 26.
006252	016070	.WORD	258.*<258.*27.>	;REMAINING WORD COUNT AFTER SECTOR 27.
006254	016472	.WORD	258.*<258.*28.>	;REMAINING WORD COUNT AFTER SECTOR 28.
006256	017074	.WORD	258.*<258.*29.>	;REMAINING WORD COUNT AFTER SECTOR 29.
006260	017476	.WORD	258.*<258.*30.>	;REMAINING WORD COUNT AFTER SECTOR 30.
006262	020100	.WORD	258.*<258.*31.>	;REMAINING WORD COUNT AFTER SECTOR 31.

006264	001166	BYTE 16: .WORD	630.	
006266	002354	.WORD	630.*<630.*1.>	
006270	003542	.WORD	630.*<630.*2.>	
006272	004730	.WORD	630.*<630.*3.>	
006274	006116	.WORD	630.*<630.*4.>	
006276	007304	.WORD	630.*<630.*5.>	
006300	010472	.WORD	630.*<630.*6.>	
006302	011660	.WORD	630.*<630.*7.>	
006304	013046	.WORD	630.*<630.*8.>	
006306	014234	.WORD	630.*<630.*9.>	
006310	015422	.WORD	630.*<630.*10.>	
006312	016610	.WORD	630.*<630.*11.>	
006314	017776	.WORD	630.*<630.*12.>	
006316	021164	.WORD	630.*<630.*13.>	
006320	022352	.WORD	630.*<630.*14.>	
006322	023540	.WORD	630.*<630.*15.>	
006324	024726	.WORD	630.*<630.*16.>	
006326	026114	.WORD	630.*<630.*17.>	
006330	027302	.WORD	630.*<630.*18.>	
006332	030470	.WORD	630.*<630.*19.>	
006334	031656	.WORD	630.*<630.*20.>	
006336	033044	.WORD	630.*<630.*21.>	
006340	034232	.WORD	630.*<630.*22.>	
006342	035420	.WORD	630.*<630.*23.>	
006344	036606	.WORD	630.*<630.*24.>	
006346	037774	.WORD	630.*<630.*25.>	
006350	041162	.WORD	630.*<630.*26.>	
006352	042350	.WORD	630.*<630.*27.>	
006354	043536	.WORD	630.*<630.*28.>	
006356	044724	.WORD	630.*<630.*29.>	
006360	046112	.WORD	630.*<630.*30.>	
006362	047300	.WORD	630.*<630.*31.>	

006364	001240	BYTE 18: .WORD	672.	
006366	002500	.WORD	672.*<672.*1.>	
006370	003740	.WORD	672.*<672.*2.>	
006372	005200	.WORD	672.*<672.*3.>	

006374	006440	.WORD	672.*<672.*4.>
006376	007700	.WORD	672.*<672.*5.>
006400	011140	.WORD	672.*<672.*6.>
006402	012400	.WORD	672.*<672.*7.>
006404	013640	.WORD	672.*<672.*8.>
006406	015100	.WORD	672.*<672.*9.>
006410	016340	.WORD	672.*<672.*10.>
006412	017600	.WORD	672.*<672.*11.>
006414	021040	.WORD	672.*<672.*12.>
006416	022300	.WORD	672.*<672.*13.>
006420	023540	.WORD	672.*<672.*14.>
006422	025000	.WORD	672.*<672.*15.>
006424	026240	.WORD	672.*<672.*16.>
006426	027500	.WORD	672.*<672.*17.>
006430	030740	.WORD	672.*<672.*18.>
006432	032200	.WORD	672.*<672.*19.>
006434	033440	.WORD	672.*<672.*20.>
006436	034700	.WORD	672.*<672.*21.>
006440	036140	.WORD	672.*<672.*22.>
006442	037400	.WORD	672.*<672.*23.>
006444	040640	.WORD	672.*<672.*24.>
006446	042100	.WORD	672.*<672.*25.>
006450	043340	.WORD	672.*<672.*26.>
006452	044600	.WORD	672.*<672.*27.>
006454	046040	.WORD	672.*<672.*28.>
006456	047300	.WORD	672.*<672.*29.>

.EVEN

.SBTTL ERROR POINTER TABLE

;;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRP).
;;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;;* EM ::POINTS TO THE ERROR MESSAGE
;;* DH ::POINTS TO THE DATA HEADER
;;* DT ::POINTS TO THE DATA
;;* DF ::POINTS TO THE DATA FORMAT

1	006460				
2					
3					
4	006460	042446	EM1		;RH CONTROLLER INTERRUPT OCCURRED (RMAS=0)
5	006462	043734	DH1		
6	006464	045270	DT1		
7	006466	045642	DF1		
8					
9					
10					
11	006470	042520	EM2		;UNEXPECTED ATTENTION OCCURRED
12	006472	044002	DH2		
13	006474	045306	DT2		
14	006476	045646	DF2		
15					
16					
17					
18	006500	042556	EM3		;MASSBUS PARITY ERROR (MCPE-1)
19	006502	044054	DH3		
20	006504	045322	DT3		
21	006506	045652	DF3		
22					
23					
24					
25	006510	042614	EM4		;MASSBUS PARITY ERROR (PAR-1)
26	006512	044125	DH4		
27	006514	045336	DT4		
28	006516	045656	DF4		
29					
30					
31					
32	006520	000000	0		;UNUSED
33	006522	000000	0		
34	006524	000000	0		
35	006526	000000	0		
36					
37					
38					
39	006530	042705	EM6		;RH CONTROLLER DIDN'T RESPOND TO ADDRESSING
40	006532	044210	DH6		
41	006534	045354	DT6		
42	006536	045662	DF6		

43			
44			
45			:ERROR 7
46	006540	042760	EM7
47	006542	045015	DH23
48	006544	045356	DT7
49	006546	045752	DF25
50			
51			:ERROR 10
52			
53	006550	043034	EM10
54	006552	044223	DH10
55	006554	045366	DT10
56	006556	045666	DF10
57			
58			:ERROR 11
59			
60	006560	043052	EM11
61	006562	044223	DH10
62	006564	045366	DT10
63	006566	045666	DF10
64			
65			:ERROR 12
66			
67	006570	043110	EM12
68	006572	044223	DH10
69	006574	045366	DT10
70	006576	045666	DF10
71			
72			:ERROR 13
73			
74	006600	043153	EM13
75	006602	044223	DH10
76	006604	045366	DT10
77	006606	045666	DF10
78			
79			:ERROR 14
80			
81	006610	043174	EM14
82	006612	044223	DH10
83	006614	045366	DT10
84	006616	045666	DF10
85			
86			:ERROR 15
87			
88	006620	043217	EM15
89	006622	044223	DH10
90	006624	045366	DT10
91	006626	045666	DF10
92			
93			:ERROR 16
94			
95	006630	043263	EM16
96	006632	044223	DH10
97	006634	045366	DT10
98	006636	045666	DF10
99			

;TRACK/SECTOR FIELD IN HEADER IS NOT CORRECT

;DRIVE OFFLINE

;PERSISTENT DRIVE UNSAFE ERROR

;UNCORRECTABLE MASSBUS PARITY ERROR

;SOFTWARE TIMEOUT

;DRIVE UNSAFE ERROR

;CONTROLLER/DRIVE ERROR DURING WRITE

;CONTROLLER/DRIVE ERROR DURING WRITE CHECK

100			;ERROR 17	
101				
102	006640	043335	EM17	;RETRIES NOT SUCCESSFUL - SECTOR NOT ACCEPTABLE
103	006642	044452	DH17	
104	006644	045440	DT17	
105	006646	045702	DF17	
106				
107			;ERROR 20	
108				
109	006650	043413	EM20	;DATA ERROR DURING WRITE CHECK
110	006652	044521	DH20	
111	006654	045452	DT20	
112	006656	045706	DF20	
113				
114			;ERROR 21	
115				
116	006660	043451	EM21	;CONTROLLER/DRIVE ERROR VERIFYING HEADERS
117	006662	044223	DH10	
118	006664	045366	DT10	
119	006666	045666	DF10	
120				
121			;ERROR 22	
122				
123	006670	043522	EM22	; 'HCE' OR 'HCRC' ERROR VERIFYING HEADERS
124	006672	044223	DH10	
125	006674	045366	DT10	
126	006676	045666	DF10	
127				
128			;ERROR 23	
129				
130	006700	043572	EM23	;CYLINDER FIELD IN HEADER IS NOT CORRECT
131	006702	045015	DH23	
132	006704	045534	DT23	
133	006706	045752	DF25	
134				
135			;ERROR 24	
136				
137	006710	043642	EM24	;WRITE CHECK ERROR
138	006712	045054	DH24	
139	006714	045544	DT24	
140	006716	045732	DF24	
141				
142			;ERROR 25	
143				
144	006720	043664	EM25	;ILLEGAL BAD SECTOR
145	006722	045227	DH25	
146	006724	045632	DT25	
147	006726	045752	DF25	

```

1
2
3 006730 011600
4 006732 005740
5 006734 022626
6 006736 104401 006744
  006742 000417

  007002
7 007002 010046
8 007004 104402
9 007006 000240
10
11 007010 000411
12
13
14
15 007012 005037 001270
16 007016 000406
17
18 007020 012737 000001 001374
19 007026 012737 177777 001270
20
21
  007034 000240
  007036 012737 000001 001214
22 007044 005227 000000
23 007050 001375
24 007052 000005
25
26

  007054 012706 001114
  007060 005026
  007062 022706 001154
  007066 001374
  007070 012706 001100

  007074 012737 023330 000030
  007102 012737 000340 000032
  007110 012737 030046 000034
  007116 012737 000340 000036
  007124 012737 030132 000024
  007132 012737 000340 000026
  007140 005037 001176
  007144 112737 000001 001131

  007152 013746 000004
  007156 012737 007212 000004
  007164 012737 177570 001154
  007172 012737 177570 001156
  007200 022777 177777 171746
  007206 001012

  007210 000403
  007212 012716 007220

```

```

; THIS ROUTINE HANDLES UNEXPECTED TIMEOUTS
BADTMO: MOV (SP),R0 ;SAVE PC WHERE THE TIME OUT OCCURED
        TST -(R0) ;ADJUST PC -2
        CMP (SP)+,(SP)+ ;RESTORE STACK POINTER
        TYPE ,65$ ;TYPE ASCII STRING
        BR 64$ ;GET OVER THE ASCII
        ;:65$: .ASCIIZ <CRLF>/UNEXPECTED BUS TIMEOUT, PC=/
        64$:
        MOV R0,-(SP) ;SETUP FOR TYPING OUT PC
        TYPOC
        NOP ;PUT 'HALT(0)' INSTRUCTION HERE IF YOU WISH
        ;TO STOP ON UNEXPECTED TIMEOUT.
        BR TST1 ;BRANCH TO START

.SBTTL START OF PROGRAM

START: CLR $CDW1 ;DISABLE USE OF UTILITY ROUTINES
       BR TST1

START1: MOV #1,CHGADR ;ENABLE CHANGE OF 'RH/RM BUS ADDRESS'
        MOV #-1,$CDW1 ;ENABLE USE OF UTILITY ROUTINES

;*****
TST1: NOP
      MOV #1,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX
      INC #0 ;:TTY LOOP, WAIT FOR INCREMENT
      BNE .-4 ;:OF WORD
      RESET ;:CLEAR THE WORLD

.SBTTL INITIALIZE THE COMMON TAGS
;:CLEAR THE COMMON TAGS ($CMTAG) AREA
      MOV #$CMTAG,R6 ;:FIRST LOCATION TO BE CLEARED
      CLR (R6)+ ;:CLEAR MEMORY LOCATION
      CMP #SWR,R6 ;:DONE?
      BNE .-6 ;:LOOP BACK IF NO
      MOV #STACK,SP ;:SETUP THE STACK POINTER

;:INITIALIZE A FEW VECTORS
      MOV #ERROR,@#EMTVEC ;:EMT VECTOR FOR ERROR ROUTINE
      MOV #340,@#EMTVEC+2 ;:LEVEL 7
      MOV #STRAP,@#TRAPVEC ;:TRAP VECTOR FOR TRAP CALLS
      MOV #340,@#TRAPVEC+2 ;:LEVEL 7
      MOV #SPWRDN,@#PWRVEC ;:POWER FAILURE VECTOR
      MOV #340,@#PWRVEC+2 ;:LEVEL 7
      CLR $ESCAPE ;:CLEAR THE ESCAPE ON ERROR ADDRESS
      MOVB #1,$ERMAX ;:ALLOW ONE ERROR PER TEST
;:SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
;:EQUAL TO A '-1', SETUP FOR A SOFTWARE SWITCH REGISTER.
      MOV @#ERRVEC,-(SP) ;:SAVE ERROR VECTOR
      MOV #64$,@#ERRVEC ;:SET UP ERROR VECTOR
      MOV #DSWR,SWR ;:SETUP FOR A HARDWARE SWICH REGISTER
      MOV #DDISP,DISPLAY ;:AND A HARDWARE DISPLAY REGISTER
      CMP #-1,@SWR ;:TRY TO REFERENCE HARDWARE SWR
      BNE 66$ ;:BRANCH IF NO TIMEOUT TRAP OCCURRED
      ;:AND THE HARDWARE SWR IS NOT -1
      BR 65$ ;:BRANCH IF NO TIMEOUT
      64$: MOV #65$,(SP) ;:SET UP FOR TRAP RETURN

```

```

007216 000002
007220 012737 000176 001154 65$: MOV #SWREG,SWR ::POINT TO SOFTWARE SWR
007226 012737 000174 001156 MOV #DISPREG,DISPLAY
007234 012637 000004 66$: MOV (SP)+,@ERRVEC ::RESTORE ERROR VECTOR

007240 005037 001216 CLR $PASS ::CLEAR PASS COUNT
007244 132737 000200 001231 BITB #APTSIZE,$ENVM ::TEST USER SIZE UNDER APT
007252 001403 BEQ 67$ ::YES,USE NON-APT SWITCH
007254 012737 001232 001154 MOV #SWREG,SWR ::NO,USE APT SWITCH REGISTER
007262 67$:
27 ;SETUP 'TIMEOUT' TRAP VECTOR FOR UNEXPECTED BUS TIMEOUTS
28 007262 012737 006730 000004 MOV #BAD*MO,ERRVEC ::SETUP FOR UNEXPECTED TIMEOUT
29 007270 012737 000300 000006 MOV #PR6,ERRVEC+2 ::LEVEL 6
30
31 .SBTTL TYPE PROGRAM NAME
::TYPE THE NAME OF THE PROGRAM IF FIRST PASS
007276 005227 177777 INC #-1 ::FIRST TIME?
007302 001023 BNE 68$ ::BRANCH IF NO
007304 104401 007312 TYPE ,69$ ::TYPE ASCIZ STRING
007310 000420 BR 68$ ::GET OVER THE ASCIZ
::69$: .ASCIZ <CRLF>@CZRMLB0 - RM05/3/2 FORMATTER@<CRLF>
68$:
.SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
007352 005757 000042 TST @#42 ::ARE WE RUNNING UNDER XXDP/ACT?
007356 001012 BNE 70$ ::BRANCH IF YES
007360 123727 001230 000001 CMPB $ENV,#1 ::ARE WE RUNNING UNDER APT?
007366 001406 BEQ 70$ ::BRANCH IF YES
007370 023727 001154 000176 CMP SWR,#SWREG ::SOFTWARE SWITCH REG SELECTED?
007376 001005 BNE 71$ ::BRANCH IF NO
007400 104406 GTSWR ::GET SOFT-SWR SETTINGS
007402 000403 BR 71$
007404 112737 000001 001150 70$: MOVB #1,$AUTOB ::SET AUTO-MODE INDICATOR
007412 71$:

32
33 ;THE FOLLOWING FINDS OUT THE PROGRAM CONTROL MODE:
34 ;PAPER TAPE (MANUAL), ACT11, XXDP CHAIN OR DUMP
35
36 007412 005037 001412 CLR XXDP ;CLEAR 'XXDP' LOAD DEVICE STORAGE
37 007416 122737 000016 000041 CMPB #16,@#41 ;LOADED FROM AN RM05/3/2 ?
38 007424 001160 BNE 4$ ;BR IF NOT
39 007426 013737 000040 001412 MOV @#40,XXDP ;GET DEVICE INDICATOR AND NUMBER
40 007434 122737 000007 001412 CMPB #7,XXDP ;IS IT A VALID NUMBER ?
41 007442 103002 BHIS 2$ ;YES
42 007444 105037 001412 CLRB XXDP ;NO, DEFAULT TO DRIVE 0
43 007450 005737 000042 2$: TST @#42 ;CHAIN MODE OR ACT11 AUTO ACCEPT ?
44 007454 001425 BEQ 3$ ;BR IF NEITHER
45 007456 104401 007464 TYPE ,73$ ::TYPE ASCIZ STRING
007462 000412 BR 72$ ::GET OVER THE ASCIZ
::73$: .ASCIZ <CRLF>/NOT TESTING DRIVE /
72$:
46 007510 005046 CLR -(SP) ;CLEAR WORD ON STACK
47 007512 113716 001412 MOVB XXDP,(SP) ;GET DRIVE ADDRESS
48 007516 104403 TYPOS ;TYPE THE ADDRESS
49 007520 001 .BYTE 1 ;ONLY 1 CHARACTER
50 007521 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
51 007522 104401 001205 TYPE ,SCRLF ;CR-LF
52 007526 000517 BR 4$ ;GET NUMBER OF DRIVES

```


53					
54	007530	005227	177777	3\$:	INC # -1 ; FIRST TIME THRU HERE ?
55	007534	001114			BNE 4\$; NO
56	007536	104401	007544		TYPE ,75\$; TYPE ASCIZ STRING
	007542	000410			BR 74\$; GET OVER THE ASCIZ
	007564			::75\$:	.ASCIZ <CRLF>/TO TEST DRIVE /
				74\$:	
57	007564	005046			CLR -(SP) ; CLEAR WORD ON STACK
58	007566	113716	001412		MOVB XXDP,(SP) ; GET DRIVE ADDRESS
59	007572	104403			TYPOS ; TYPE DRIVE ADDRESS
60	007574	001			.BYTE 1 ; ONLY 1 CHARACTER
61	007575	000			.BYTE 0 ; SUPPRESS LEADING ZEROS
62	007576	104401	007604		TYPE ,77\$; TYPE ASCIZ STRING
	007602	000431			BR 76\$; GET OVER THE ASCIZ
				::77\$:	.ASCIZ /, HALT PROGRAM, REMOVE RRD P ACK AND REPLACE IT/<CRLF>
				76\$:	
63	007666	104401	007674		TYPE ,78\$; TYPE ASCIZ STRING
	007672	000435			BR 4\$; GET OVER THE ASCIZ
				::78\$:	.ASCIZ /WITH A WORK PACK, CLEAR LOCATION 40 AND RESTART PROGRAM./<CRLF>
				4\$:	
67	007766	012737	007012	001372	MOV #START,CN1LC ; 'CONTROL C' ADDRESS
68	007774	004737	024414		JSR PC,\$TKINT ; TURN ON THE KEYBOARD INTERRUPT
69					
70	010000	105737	001150		TSTB \$AUTOB ; RUNNING AUTO MODE ?
71	010004	001010			BNE 5\$; BR IF YES
72	010006	004737	045756		JSR PC,BUSADR ; CHECK THE RH/RM ADDRESS
73	010012	013737	001274	030456	MOV \$RMADR,RMADR ; RH/RM ADDRESS
74	010020	013737	001276	030460	MOV \$RMVEC,RMVEC ; RH/RM VECTOR ADDRESS
75	010026				
76	010026	105737	001230	5\$:	TSTB \$ENV ; RUN UNDER APT MODE?
77	010032	001422			BEQ SETVEC ; NO, DO NOT LOAD FROM E-TABLE
78	010034	105737	001260		TSTB \$VECT1 ; UUT INTERRUPT VECTOR
79	010040	001406			BEQ 6\$; DO NOT CHANGE IF 0
80	010042	113737	001260	001276	MOVB \$VECT1,\$RMVEC ; NEW VALUE
81	010050	013737	001276	030460	MOV \$RMVEC,RMVEC ; RH/RM VECTOR
82	010056	005737	001264	6\$:	TST \$BASE ; UUT BASE REGISTER ADDRESS
83	010062	001406			BEQ SETVEC ; DO NOT CHANGE IF - 0
84	010064	013737	001264	001274	MOV \$BASE,\$RMADR ; NEW BASE ADDRESS
85	010072	013737	001274	030456	MOV \$RMADR,RMADR ; RH/RM ADDRESS
86					
87					; DISPLAY DRIVE STATUS AND SET UP THE OTHER UNITS THE
88					; PROGRAM WILL USE
89					
90	010100	004737	017360		SETVEC: JSR PC,ST.CLK ; START THE CLOCK
91	010104	004737	030466		JSR PC,RMINIT ; INITIALIZE THE RM DRIVER
92	010110	013700	030456		MOV RMADR,R0 ; GET BASE ADDRESS
93	010114	012760	000040	000010	MOV #CLR,RMCS2(R0) ; CLEAR MASSBUS
94	010122	012737	177777	030416	MOV # -1,SAVEFG ; SET THE SAVE REGISTERS FLAG
95	010130	005227	177777		INC # -1 ; FIRST TIME THRU HERE ?
96	010134	001404			BEQ 1\$; BR IF NO
97	010136	032777	000004	171010	BIT #SW02,@SWR ; TYPEOUT THE DRIVE STATUS TABLE ?
98	010144	001113			BNE 12\$; BR IF NO
99	010146	005037	001400	1\$:	CLR DEVMP ; CLEAR DEVICE MAP
100	010152	005004			CLR R4 ; DRIVE TABLE POINTER
101	010154	104401	036555		TYPE ,UNSTAT ; TYPE 'UNIT STATUS'
102	010160	104401	001205	2\$:	TYPE ,CRLF ; CR-LF
103	010164	010446			MOV R4,-(SP) ; SAVE R4 FOR TYPEOUT

010166	104403			TYPOS		:: TYPE DRIVE NUMBER
010170	002			.BYTE	2	:: GO TYPE--OCTAL ASCII
010171	000			.BYTE	0	:: TYPE 2 DIGIT(S)
104 010172	104401	036617		TYPE	.BLNK54	:: SUPPRESS LEADING ZEROS
105 010176	105764	030340		TSTB	DRVSTA(R4)	:: TYPE 4 SPACES
106 010202	100416			BMI	5\$:: CHECK DRIVE'S STATUS
107 010204	001020			BNE	6\$:: BR IF UNSAFE
108						:: BR IF ONLINE
109 010206	105764	030350		TSTB	DRVSTYP(R4)	:: SEE IF OFFLINE OR NONEXISTENT
110 010212	001404			BEQ	3\$:: BR IF NONEXISTENT
111 010214	100006			BPL	4\$:: BR IF OFFLINE
112 010216	104401	036453		TYPE	.NOTRM	:: DRIVE NOT AN RM05/3/2
113 010222	000460			BR	11\$:: CHECK NEXT DRIVE
114						
115 010224	104401	036474	3\$:	TYPE	.NOTPRS	:: DRIVE NOT PRESENT
116 010230	000455			BR	11\$:: CHECK NEXT DRIVE
117						
118 010232	104401	036432	4\$:	TYPE	.UNTOFF	:: DRIVE OFFLINE
119 010236	000424			BR	8\$:: PRINT DRIVE TYPE
120						
121 010240	104401	036511	5\$:	TYPE	.NOTSAF	:: DRIVE UNSAFE
122 010244	000421			BR	8\$:: PRINT DRIVE TYPE
123						
124 010246	005737	001412	6\$:	TST	XXDP	:: LOADED FROM THIS DEVICE ?
125 010252	001406			BEQ	7\$:: BR IF NO
126 010254	123704	001412		CMPB	XXDP,R4	:: LOADED FROM THIS DRIVE ?
127 010260	001003			BNE	7\$:: BR IF NO
128 010262	104401	036521		TYPE	.LODEV	:: DRIVE IS LOAD DEVICE
129 010266	000436			BR	11\$	
130						
131 010270	104401	036443	7\$:	TYPE	.UNTON	:: DRIVE ONLINE
132 010274	156437	030444	001400	BISB	ATABIT(R4),DEVMP	:: SET DEVICE MAP
133 010302	013737	001400	001402	MOV	DEVMP,DEVMP+2	:: SAVE DEVICE MAP
134 010310	104401	036621	8\$:	TYPE	.BLNK52	:: TYPE 2 SPACES
135 010314	005000			CLR	R0	
136 010316	116400	030350		MOVB	DRVSTYP(R4),R0	:: GET DRIVE TYPE
137 010322	012737	036543	010362	MOV	#\$RM03,10\$:: ASSUME ADDRESS OF RM03 MESSAGE
138 010330	122700	000004		CMPB	#4,R0	:: IS DEVICE AN RM03 ?
139 010334	001411			BEQ	9\$:: BR IF YES
140 010336	012737	036536	010362	MOV	#\$RM02,10\$:: ADDRESS OF RM02 MESSAGE
141 010344	122700	000005		CMPB	#5,R0	:: IS DEVICE AN RM02 ?
142 010350	001403			BEQ	9\$:: BR IF YES
143 010352	012737	036550	010362	MOV	#\$RM05,10\$:: ADDRESS OF RM05 MESSAGE
144						
145 010360	104401		9\$:	TYPE		:: TYPE THE DRIVE TYPE MESSAGE
146 010362	000000		10\$:	.WORD	0	:: MESSAGE ADDRESS HERE
147						
148 010364	005204		11\$:	INC	R4	:: INCREMENT DRIVE NUMBER/TABLE POINTER
149 010366	020427	000010		CMP	R4,#8.	:: FINISHED ?
150 010372	001272			BNE	2\$:: BR IF NOT
151 010374	013737	001402	001400	MOV	DEVMP+2,DEVMP	:: GET DEVICES TO TEST
152 010402	104401	001205		TYPE	,\$CRLF	:: CR-LF

```

1
2
3
4
5 010406 105737 001150
6 010412 001540
7 010414 132737 000200 001231
8 010422 001134
9
10 010424 005737 001266
11 010430 001406
12 010432 013737 001266 001400
13 010440 042737 177400 001400
14 010446
15
16
17
18 010446 005737 001400
19 010452 001002
20 010454 000137 016342
21
22 010460 012737 000000 001334
23 010466 012737 000000 001330
24 010474 012737 001466 001326
25 010502 005037 001376
26 010506 005037 001320
27 010512 012737 177777 001356
28 010520 005737 001272
29 010524 001012
30 010526 012737 020100 001350
31 010534 012737 157700 001352
32 010542 012737 000037 001360
33 010550 000413
34
35 010552 012737 017074 001350
36 010560 012737 160704 001352
37 010566 005037 001356
38 010572 012737 000035 001360
39 010600 005001
40 010602 136137 030444 001400
41 010610 001005
42 010612 005201
43 010614 020127 000007
44 010620 003770
45 010622 000711
46
47 010624 010137 001222
48 010630 146137 030444 001400
49 010636 105761 030340
50 010642 003757
51 010644 005737 001412
52 010650 001403
53 010652 123701 001412
54 010656 001751
55
56 010660 012702 000004
57 010664 122761 000007 030350

```

.SBTTL SIZE FOR AUTO MODE

;IF RUNNING IN AUTO MODE, THEN AUTO SIZE DRIVES TO BE FORMATTED

```

XSIZE: TSTB $AUTOB ;RUNNING UNDER AUTO MODE ?
BEC ASKO ;BR IF NO
BITB #BIT7,$ENVMP ;APT AUTO SIZING ALLOWED ?
BNE ASKO ;BR IF NO

TST $DEVMP ;DEVICE MAP AVAILABLE FROM APT MAIL BOX
BEQ 1$ ;BR IF NONE
MOV $DEVMP,DEVMP ;LOAD IT FROM MAIL BOX
BIC #177400,DEVMP ;ALLOW MAX 8 DRIVES
1$:

;RETURN HERE IF RUNNING IN CHAIN MODE AND MORE DRIVES TO TEST

ST1: TST DEVMP ;CHECK DEVICE MAP
BNE 1$ ;BR IF DRIVES ASSIGNED
JMP $GET42 ;GET MONITOR

1$: MOV #0,MINTRK ;ALWAYS STARTS FROM 0 TRACK
MOV #0,MINCYL ;ALWAYS STARTS FROM 0 CYLINDER
MOV #822.,MAXCYL ;LAST CYLINDER
CLR WRAP ;SFEK FROM LO TO HI CYLINDER ADDRESS
CLR MODE ;SET TO 'FORMAT' MODE
2$: MOV #-1,SEC30 ;SET 32 SECTOR
TST $CDW2 ;APT PARAMETER 0
BNE 3$ ;NO,30 SECTOR
MOV #<258.*32.>,WC ;COUNT OF WORDS
MOV #-<258.*32.>,MWC ;WORD COUNT
MOV #31.,MAXSEC ;MAX 32 SECTOR
BR 4$

3$: MOV #<258.*30.>,WC ;COUNT OF WORDS
MOV #-<258.*30.>,MWC ;WORD COUNT
CLR SEC30 ;30 SECTOR
MOV #29.,MAXSEC ;MAX 30 SECTOR
4$: CLR R1 ;START WITH DRIVE NUMBER 0
5$: BITB ATABIT(R1),DEVMP ;IS THIS DRIVE IN DEVICE MAP ?
BNE 6$ ;BR IF YES
INC R1 ;INCREMENT DRIVE #
CMP R1,#7 ;ALL DONE WITH MAP ?
BLE 5$ ;BR IF NO
BR ST1 ;DONE !!

6$: MOV R1,DRIVE ;LOAD R1 INTO DRIVE
BICB ATABIT(R1),DEVMP ;CLEAR THE BIT FROM DEVICE MAP
TSTB DRVSTA(R1) ;IS DRIVE ON LINE ?
BLE 5$ ;BR IF NO
TST XXDP ;LOADED FROM THIS DEVICE ?
BEQ 7$ ;BR IF NO
CMPB XXDP,R1 ;LOADED FROM THIS DRIVE ?
BEQ 5$ ;BR IF YES

7$: MOV #4,R2 ;SETUP TRACK PARAMETER FOR AN RM03/2
CMPB #7,DRVSTYP(R1) ;IS DEVICE AN RM05 ?

```

```

58 010672 001002
59 010674 012702 000022
60 010700 010237 001324
61 010704 010237 001332
62 010710 000137 011566
63
64
65
66
67 010714 005037 177776
68 010720 005037 001320
69 010724 104401 001205
70 010730 104401 041732
71 010734 104411
72 010736 012600
73 010740 105710
74 010742 001416
75 010744 105760 000001
76 010750 001006
77 010752 122710 000131
78 010756 001410
79 010760 122710 000116
80 010764 001403
81 010766 104401 037174
82 010772 000756
83
84 010774 005237 001320
85 011000
86
87
88
89 011000 104401 041771
90 011004 104411
91 011006 012600
92 011010 105710
93 011012 001414
94 011014 105760 000001
95 011020 001006
96 011022 122710 000131
97 011026 001406
98 011030 122710 000116
99 011034 001420
100 011036 104401 037174
101 011042 000756
102
103 011044 012737 177777 001356
104 011052 012737 020100 001350
105 011060 012737 157700 001352
106 011066 012737 000037 001360
107 011074 000413
108
109 011076 005037 001356
110 011102 012737 017074 001350
111 011110 012737 160704 001352
112 011116 012737 000035 001360
113 011124
114

```

```

BNE 8$ ;BR IF NO
MOV #18.,R2 ;SETUP TRACK PARAMETER FOR AN RMOS
8$: MOV R2,LSTRK ;SETUP LAST TRACK AND
MOV R2,MAXTRK ;END TRACK FOR AUTO MODE.
JMP ST2 ;START TO FORMAT OR CHECK

;SEE WHICH MODE THE PROGRAM IS TO BE RUN IN.
;MODES ARE: 'FORMAT & VERIFY' OR 'VERIFY HEADER FORMAT'

ASK0: CLR PS ;ASSUME 'FORMAT' MODE
CLR MODE ;CR-LF
TYPE ,SCRLF ;TYPE 'DO YOU WANT TO FORMAT (L) Y ?'
1$: TYPE ,MMODE ;READ THE KEYBOARD
RDLIN ;SAVE ADDRESS OF RESPONSE
MOV (SP)+,R0 ;WAS RESPONSE A CARRIAGE RETURN (DEFAULT 'Y')?
TSTB (R0) ;BR IF YES
BEQ 4$ ;WAS IT TERMINATED WITH CARRIAGE RETURN ?
TSTB 1(R0) ;BR IF NO
BNE 2$ ;WAS IT A 'Y' RESPONSE ?
CMPB #'Y',(R0) ;BR IF YES
BEQ 4$ ;WAS IT A 'N' RESPONSE ?
CMPB #'N',(R0) ;BR IF YES
BEQ 3$ ;TYPE BAD ENTRY MESSAGE
2$: TYPE ,BADENT ;TRY AGAIN
BR 1$

3$: INC MODE ;SET 'VERIFY HEADERS ONLY' MODE
4$:

;FIND OUT IF FORMAT IS TO BE IN 16. OR 18. BIT MODE

ASK1: TYPE ,MSIZE ;TYPE 'DO YOU WANT 16 BIT FORMAT MODE (L) Y ?'
RDLIN ;READ THE ENTRY
MOV (SP)+,R0 ;SAVE ADDRESS OF RESPONSE
TSTB (R0) ;WAS RESPONSE A CARRIAGE RETURN (DEFAULT 'Y')?
BEQ 2$ ;BR IF YES
TSTB 1(R0) ;WAS IT TERMINATED WITH CARRIAGE RETURN ?
BNE 1$ ;BR IF NO
CMPB #'Y',(R0) ;WAS IT A 'Y' RESPONSE ?
BEQ 2$ ;BR IF YES
CMPB #'N',(R0) ;WAS IT A 'N' RESPONSE ?
BEQ 3$ ;BR IF YES
1$: TYPE ,BADENT ;TYPE BAD ENTRY MESSAGE
BR ASK1 ;TRY AGAIN

2$: MOV #-1,SEC30 ;32 SECTOR INDICATOR
MOV #<258.*32.>,WC ;TRACK SIZE IN 32 SECTOR MODE
MOV #-<258.*32.>,MWC ;2'S COMPLEMENT WORD COUNT
MOV #31.,MAXSEC ;MAX SECTOR ADDRESS IN 32 SECTOR MODE
BR 4$ ;CONTINUE

3$: CLR SEC30 ;30 SECTOR INDICATOR
MOV #<258.*30.>,WC ;TRACK SIZE IN 30 SECTOR MODE
MOV #-<258.*30.>,MWC ;2'S COMPLEMENT WORD COUNT
MOV #29.,MAXSEC ;MAX SECTOR ADDRESS IN 30 SECTOR MODE
4$:

```

```

115 ;GO FIND OUT WHAT DRIVE
116
117 011124 012737 017630 001372 ASK2: MOV #C.ENTR,CNTLC ;CONTROL C ABORT ENTRANCE
118 011132 004737 024414 JSR PC,STKINT ;INITIALIZE THE TTY KEYBOARD
119 011136 005037 001126 CLR $ERRTL ;CLEAR THE ERROR ACCUMULATOR
120 011142 104401 036573 TYPE ,MUNIT ;TYPE 'DRIVE'
121 011146 104401 036604 TYPE ,COLON ;TYPE ':'
122 011152 104411 RDLIN ;READ THE ENTRY
123 011154 012601 MOV (SP)+,R1 ;SAVE ADDRESS OF RESPONSE
124 011156 004537 023120 JSR R5,CK.CHR ;CHECK ONE CHARACTER
111162 011176 1$ ;ILLEGAL CHARACTER
111164 011176 1$ ;CARRIAGE RETURN
111166 011176 1$ ;...
111170 011176 1$ ;...
111172 011204 2$ ;DIGIT 0-7
111174 011176 1$ ;DIGIT 8-9

125
126 011176 104401 037174 1$: TYPE ,BADENT ;TYPE BAD ENTRY MESSAGE
127 011202 000750 BR ASK2 ;ASK FOR DRIVE NUMBER AGAIN
128
129 011204 010237 001222 2$: MOV R2,DRIVE ;SAVE DRIVE NUMBER
130 011210 005737 001412 TST XXDP ;LOADED FROM THIS DEVICE ?
131 011214 001406 BEQ 3$ ;BR IF NO
132 011216 123702 001412 CMPB XXDP,R2 ;WAS THIS THE DRIVE ?
133 011222 001003 BNE 3$ ;BR IF NO
134 011224 104401 036771 TYPE ,MLODEV ;DRIVE IS LOAD DEVICE
135 011230 000735 BR ASK2
136
137 011232 004737 017360 3$: JSR PC,ST.CLK ;START THE CLOCK
138 011236 004737 030466 JSR PC,RMINIT ;GO SEE WHAT DRIVES ARE AVAILABLE
139 011242 013700 030456 MOV RMADR,R0 ;GET BASE ADDRESS
140 011246 012760 000040 000010 MOV #CLR,RMCS2(R0) ;CLEAR MASSBUS
141 011254 012737 177777 030416 MOV #-1,SAVEFG ;SAVE THE REGISTERS
142 011262 012737 177777 030420 MOV #-1,SEEKFG ;SET 'NO OPTIMIZATION' FLAG
143 011270 005037 177776 CLR PS ;PRIORITY 0
144 011274 105762 030340 TSTB DRVSTA(R2) ;LOOK AT DRIVE STATUS
145 011300 003015 BGT 6$ ;BR IF ONLINE
146 011302 001403 BEQ 4$ ;BR IF DRIVE NOT AVAILABLE
147 011304 104401 036751 TYPE ,MUSDR ;'DRIVE UNSAFE'
148 011310 000705 BR ASK2 ;GO GET DRIVE NUMBER AGAIN
149
150 011312 105762 030350 4$: TSTB DRVTP(R2) ;A DRIVE PRESENT?
151 011316 001003 BNE 5$ ;BR IF SO
152 011320 104401 036675 TYPE ,MDRNP ;TYPE 'DRIVE NOT PRESENT'
153 011324 000677 BR ASK2 ;GO GET DRIVE NUMBER AGAIN
154
155 011326 104401 036722 5$: TYPE ,MER11 ;'DRIVE NOT AVAILABLE'
156 011332 000674 BR ASK2 ;GO GET DRIVE NUMBER AGAIN
157
158 011334 113737 001222 005540 6$: MOVB DRIVE,FMTDPB ;SETUP DRIVE ADDRESS
159 011342 012737 000000 001330 MOV #0,MINCYL ;CLEAR STARTING CYLINDER ADDRESS
160 011350 012737 001466 001326 MOV #822,MAXCYL ;SETUP END CYLINDER
161 011356 012737 000000 001334 MOV #0,MINTRK ;CLEAR STARTING TRACK ADDRESS
162 011364 012700 000004 MOV #4,R0 ;GET LAST TRACK FOR AN RM03/2
163 011370 122762 000007 030350 CMPB #7,DRVTP(R2) ;IS DEVICE AN RM05 ?
164 011376 001002 BNE 7$ ;BR IF NO
165 011400 012700 000022 MOV #18,R0 ;GET LAST TRACK FOR AN RM05

```

166	011404	010037	001324	7\$:	MOV	R0,LSTRK	:SETUP LAST TRACK AND
167	011410	010037	001332		MOV	R0,MAXTRK	:END TRACK PARAMETERS
170	011414	010037	005666		MOV	R0,TABLE+16	:SETUP TRACK PARAMETER LIMITS IN 'TABLE'
	011420	010037	005674		MOV	R0,TABLE+24	:SETUP TRACK PARAMETER LIMITS IN 'TABLE'
173	011424	010037	005710		MOV	R0,TABLE2+6	:SETUP TRACK PARAMETER LIMITS IN 'TABLE2'
	011430	010037	005726		MOV	R0,TABLE3+6	:SETUP TRACK PARAMETER LIMITS IN 'TABLE3'
	011434	010037	005744		MOV	R0,TABLE4+6	:SETUP TRACK PARAMETER LIMITS IN 'TABLE4'
174	011440	104401	001205		TYPE	,SCRLF	:CR-LF
175							
176							
177							
178	011444	005037	001376				
179	011450	104401	042362	ASK3:	CLR	WRAP	:ASSUME SEEK FROM LO TO HI CYLINDERS
180	011454	104411			TYPE	,MSPRM	:TYPE 'CHANGE DRIVE PARAMETERS ?'
181	011456	012600			RDLIN		:READ THE ENTRY
182	011460	105710			MOV	(SP)+,R0	:SAVE ADDRESS OF RESPONSE
183	011462	001441			TSTB	(R0)	:WAS RESPONSE A CARRIAGE RETURN (DEFAULT 'N')
184	011464	105760	000001		BEQ	ST2	:BR IF YES
185	011470	001006			TSTB	1(R0)	:WAS IT TERMINATED WITH CARRIAGE RETURN ?
186	011472	122710	000131		BNE	1\$:BR IF NO
187	011476	001406			CMPB	#'Y,(R0)	:WAS IT A 'Y' RESPONSE ?
188	011500	122710	000116		BEQ	2\$:BR IF YES
189	011504	001430			CMPB	#'N,(R0)	:WAS IT A 'N' RESPONSE ?
190	011506	104401	037174		BEQ	ST2	:BR IF YES
191	011512	000754		1\$:	TYPE	,BADENT	:TYPE BAD ENTRY MESSAGE
192	011514				BR	ASK3	:TRY AGAIN
193				2\$:			
194	011514	104401	036624	ASK3A:	TYPE	,ENTADR	:TYPE 'ENTER ADDRESS LIMITS:'
195	011520	004437	020032		JSR	R4,PARENT	:ENTER THE ADDRESS LIMITS
196	011524	005650			TABLE		:TABLE PARAMETERS
197	011526	023737	001326 001330		CMP	MAXCYL,MINCYL	:SEE IF ENDING CYL EQ TO GT THAN STARTING
198	011534	001402			BEQ	1\$:BR IF ON THE SAME CYLINDER
199	011536	103410			BLO	3\$:BR IF LESS
200	011540	000412			BR	4\$:TO CHECK DRIVE
201							
202	011542	023737	001332 001334	1\$:	CMP	MAXTRK,MINTRK	:SEE IF ENDING TRACK EQ OR GT THAN STARTING
203	011550	103006			BHIS	4\$:BR IF YES
204	011552	104401	037215	2\$:	TYPE	,MADRER	:INVALID ADDRESS ENTERED
205	011556	000756			BR	ASK3A	:TRY AGAIN
206							
207	011560	012737	177777 001376	3\$:	MOV	#-1,WRAP	:ALLOW SEEK FROM HI TO LO CYLINDER ADDRESS
208	011566			4\$:			

```

        .SBTTL TYPE THE DRIVE NUMBER
        ;TYPE THE DRIVE TO BE FORMATTED AND START
2
4
5 011566 012737 017642 000060 ST2: MOV #0,ENTR,@TKVEC ;VECTOR FOR CONTROL-C
6 011574 005037 177776 CLR PS ;PRIORITY = 0
7 011600 104401 001205 TYPE ,SCRLF ;CR-LF
8 011604 005737 001320 TST MODE ;IS IT 'FORMAT' MODE ?
9 011610 001403 BEQ 1$ ;BR IF YES
10 011612 104401 037062 TYPE ,MVERFY ;TYPE 'VERIFY HEADERS'
11 011616 000402 BR 2$
12 011620 104401 037033 1$: TYPE ,MFORMAT ;TYPE 'FORMAT & VERIFY'
13 011624 005737 001356 2$: TST SEC30 ;IS IT 16 BIT MODE ?
14 011630 100403 BMI 3$ ;BR IF YES
15 011632 104401 037141 TYPE ,M18BIT ;TYPE 'OPERATE IN 18 BIT MODE'
16 011636 000402 BR 4$
17 011640 104401 037106 3$: TYPE ,M16BIT ;TYPE 'OPERATE IN 16 BIT MODE'
18 011644 4$:
19
20 ;THIS CODE RETRIEVES THE BAD SECTOR FILE FROM THE PACK (IF FORMATTED PACK)
21 ;SET UP DPB BLOCK READ CYL 822., LAST TRACK.
22
23 011644 005037 001342 RETBAD: CLR RETRY ;CLEAR THE RETRY FLAG
24 011650 012737 177777 001404 MOV #-1,BSFAVL ;INDICATE BAD SECTOR FILE IS NOT AVAILABLE
25 011656 013737 001222 005540 MOV DRIVE,FMTDPB ;LOAD DRIVE #
26 011664 012737 001466 005552 MOV #822.,FMTDPB+12 ;CYLINDER 822.
27 011672 113737 001324 005551 MOV LSTRK,FMTDPB+11 ;LAST TRACK
28 011700 105037 005550 CLRB FMTDPB+10 ;SECTOR 0
29 011704 012737 046234 005546 MOV #BUFF,FMTDPB+6 ;BUFFER ADDRESS
30 011712 012737 157700 005544 MOV #-<32.*258.>,FMTDPB+4 ;WORD COUNT FULL TRACK INCLUDING HEAD
31 011720 112737 000020 005541 MOV #20,FMTDPB+1 ;FMT SET
32 011726 112737 000143 005542 MOV #SETFMT,FMTDPB+2 ;SET 16 BIT MODE
33 011734 004037 031214 1$: JSR R0,RM05 ;SET THE FORMAT BIT
34 011740 005540 FMTDPB
35 011742 000774 BR 1$
36 011744 005737 005556 2$: TST FMTDPB+16 ;THE COMMAND IS DONE ?
37 011750 001775 BEQ 2$ ;BR IF NOT
38
39 011752 012737 011752 001124 MOV #.,$LPERR ;LOOP ON ERROR ADDRESS
40 011760 012706 001100 MOV #STACK,SP ;RESET STACK POINT
41 011764 112737 000173 005542 MOV #RDHD,FMTDPB+2 ;RELOAD THE READ HEAD AND DATA COMMAND
42 011772 004037 031214 3$: JSR R0,RM05 ;READ THE LAST TRACK
43 011776 005540 FMTDPB
44 012000 000774 BR 3$ ;BR IF QUEUE FAIL
45 012002 005737 005556 4$: TST FMTDPB+16 ;ALL DONE
46 012006 001775 BEQ 4$ ;BR IF NOT
47 012010 100007 BPL 6$ ;BR IF NO ERROR
60 012012 022737 000003 001342 CMP #3,RETRY ;EXCEEDED RETRY LIMIT ?
61 012020 103452 BLO 9$ ;BR IF YES
62 012022 005237 001342 INC RETRY ;INCREMENT RETRY COUNT
63 012026 000761 BR 3$ ;TRY AGAIN
64
65 012030 005037 001176 6$: CLR $ESCAPE
66 012034 005037 001342 CLR RETRY
67 012040 005737 005556 TST FMTDPB+16 ;ANY ERROR ?
68 012044 100440 BMI 9$ ;BR IF YES
69 012046 022737 151466 046234 CMP #151466,BUFF ;ON THE LAST CYLINDER

```

```

70 012054 001034      BNE      9$      ;BR IF NOT
71 012056 013700      MOV      LSTRK,R0 ;GET LAST TRACK
72 012062 000300      SWAB      R0      ;MOVE TRACK TO HI BYTE AND SECTOR TO LO BYTE
73 012064 020037 046236 CMP      R0,BUFP+2 ;ON LAST TRACK AND SECTOR 0
74 012070 001026      BNE      9$      ;BR IF NOT
75 012072 005737 046240 TST      BUFP+4 ;SERIAL NUMBER SHOULD NOT 0
76 012076 001003      BNE      7$      ;BR IF NOT 0
77 012100 005737 046242 TST      BUFP+6 ;SECOND WORD OF SERIAL NUMBER
78 012104 001420      BEQ      9$      ;BR IF ZERO (CORRUPT)
79 012106 005737 046244 7$: TST      BUFP+10 ;THE THIRD WORD MUST BE 0
80 012112 001015      BNE      9$      ;BR IF NOT (CORRUPT)
81 012114 022737 177777 046246 CMP      #-1,BUFP+12 ;AN ALIGNMENT PACK ?
82 012122 001002      BNE      8$      ;BR IF NOT
83 012124 000137 016430 JMP      REJECT1 ;REJECT FOR BEING AN ALIGNMENT PACK
84 012130 005737 046246 8$: TST      BUFP+12 ;IS DISK A DATA PACK ?
85 012134 001004      BNE      9$      ;BR IF NO (CORRUPT)
86 012136 012737 000400 001404 MOV      #400,BSFAVL ;INDICATOR BAD SECTOR FILE IS AVAILABLE
87 012144 000400      BR       10$     ;FILE OK..
88 012146
89 012146
90
91
92 ;THIS CODE INITIALIZES THE MFG16, MFG18, USTAB AND USSAV TABLES
93 012146 012706 001100 TABINT: MOV      #STACK,SP ;INITIAL STACK POINT
94 012152 005046      CLR      -(SP) ;TERMINATOR
95 012154 012746 004430 MOV      #USSAV,-(SP) ;USSAV TABLE ADDRESS
96 012160 012746 002420 MOV      #MFG18,-(SP) ;MFG 18 BIT FILE ADDRESS
97 012164 012746 001414 MOV      #MFG16,-(SP) ;MFG 16 BIT FILE ADDRESS
98 012170 012703 003424 MOV      #USTAB,R3 ;USER BAD SECTOR FILE ADDRESS
99 012174 012704 000004 1$: MOV      #4,R4 ;SET 2 SERIAL NUMBER WORDS AND NEXT 2 WORDS
100 012200 005023 2$: (LR      (R3)+ ;TO ALL 0'S
101 012202 005304      DEC      R4 ;DONE YET ?
102 012204 001375      BNE      2$      ;BR IF NO
103
104 012206 012704 000374 3$: MOV      #252,R4 ;GET NUMBER OF ENTRIES LEFT TO FILL
105 012212 012723 177777 MOV      #-1,(R3)+ ;SET REST OF LOCATIONS TO -1
106 012216 005304      DEC      R4 ;DONE YET ?
107 012220 001374      BNE      3$      ;BR IF NO
108 012222 012603      MOV      (SP)+,R3 ;GET NEXT TABLE ON STACK
109 012224 001363      BNE      1$      ;BR IF NOT TERMINATOR
110
111 ;THIS CODE LOADS TABLE MFG16, MFG18, USSAV FROM PACK BAD SECTOR FILE
112 ;INFORMATION (IF BAD SECTOR FILE IS AVAILABLE)
113
114 012226 005737 001404 TABLD: TST      BSFAVL ;IS BAD SECTOR FILE AVAILABLE ?
115 012232 003451      BLE      6$      ;BR IF NO
116
117 ;POINT TO FIRST SERIAL NUMBER OF 1ST
118 012234 012702 046240 MOV      #BUFP+4,R2 ;16 BIT 'MFG' BLOCK OF BAD SECTOR FILE
119 012240 012703 001414 MOV      #MFG16,R3 ;GET ADDRESS OF MFG16 TABLE
120 012244 012704 000400 MOV      #256,R4 ;WORD COUNT
121 012250 012223 1$: MOV      (R2)+,(R3)+ ;LOAD THE MFG16 TABLE
122 012252 005304      DEC      R4 ;DONE YET ?
123 012254 001375      BNE      1$      ;BR IF NO
124
125 ;POINT TO FIRST SERIAL NUMBER OF 1ST
126 012256 012702 047244 MOV      #BUFP+4+516,R2 ;18 BIT 'MFG' BLOCK OF BAD SECTOR FILE

```


127	012262	012703	002420		MOV	#MFG18,R3	:GET ADDRESS OF MFG18 TABLE
128	012266	012704	000400		MOV	#256,R4	:WORD COUNT
129	012272	012223		2\$:	MOV	(R2)+,(R3)+	:LOAD THE MFG18 TABLE
130	012274	005304			DEC	R4	:DONE YET ?
131	012276	001375			BNE	2\$:BR IF NO
132							
133							:POINT TO FIRST SERIAL NUMBER OF 1ST
134							:16 BIT 'USR' BLOCK OF BAD SECTOR FILE IN
135	012300	012702	061314		MOV	#BUFP+4+<11.*516>,R2	:SECTOR 11.
136	012304	005737	001356		TST	SEC30	:FORMAT IN 16 BIT MODE
137	012310	100402			BMI	3\$:BR IF IT IS
138							
139							:POINT TO FIRST SERIAL NUMBER OF 1ST
140							:16 BIT 'USR' BLOCK OF BAD SECTOR FILE IN
141	012312	012702	060310		MOV	#BUFP+4+<10.*516>,R2	:SECTOR 10.
142	012316	012703	004430	3\$:	MOV	#USSAV,R3	:GET ADDRESS OF USSAV TABLE
143	012322	012704	000400		MOV	#256,R4	:WORD COUNT
144	012326	012223		4\$:	MOV	(R2)+,(R3)+	:LOAD THE USSAV TABLE
145	012330	005304			DEC	R4	:DONE YET ?
146	012332	001375			BNE	4\$:BR IF NO
147							
148	012334	062702	000004		ADD	#4,R2	:ACCESSES THE USTAB BUFFER ADD
149	012340	012703	003424		MOV	#USTAB,R3	:GET ADDRESS OF USTAB TABLE
150	012344	012704	000400		MOV	#256,R4	:WORD COUNT
151	012350	012223		5\$:	MOV	(R2)+,(R3)+	:LOAD THE USTAB TABLE
152	012352	005304			DEC	R4	:DONE YET ?
153	012354	001375			BNE	5\$:BR IF NO
154	012356			6\$:			

.SBTTL ENTER OCTAL SERIAL NUMBER

:THIS CODE ASK OPERATOR TO ENTER A SERIAL NUMBER FOR UNFORMATTED OR
:INITIALIZED PACK

6	012356	005737	001404	SERNL:	TST	BSFAVL	:IS BAD SECTOR FILE AVAILABLE ?
7	012362	003123			BGT	5\$:BR IF YES
8	012364	105737	001150		TSTB	\$AUTOB	:RUNNING UNDER AUTO MODE ?
9	012370	001116			BNE	4\$:BR IF YES
10							
11	012372	004737	024414		JSR	PC,\$TKINT	:INITIALIZE THE KEYBOARD
12	012376	104401	037533	1\$:	TYPE	,MESG1	:TYPE 'ENTER SERIAL NUMBER (OCTAL): '
13	012402	012702	000012		MOV	#10.,R2	:MAXMUM 10 OCTAL DIGITS ALLOWED
14	012406	005037	001414		CLR	MFG16	:CLEAR THE LSW OF THE SERIAL NUMBER
15	012412	005037	001416		CLR	MFG16+2	:CLEAR THE MSW OF THE SERIAL NUMBER
16	012416	104411			RDLIN		:READ IN THE STRING
17	012420	012601			MOV	(SP)+,R1	:ADDRESS OF THE READ IN STRING
18	012422	105711		2\$:	TSTB	(R1)	:TERMINATOR OF THE INPUT STRING
19	012424	001471			BEQ	3\$:BR IF IT IS
20	012426	121127	000060		CMPB	(R1),#0	:LESS THAN ASCII 0 ?
21	012432	103522			BLO	6\$:ENTER AGAIN IF IT IS
22	012434	121127	000067		CMPB	(R1),#7	:HIGH THAN ASCII 7 ?
23	012440	101117			BHI	6\$:ENTER AGAIN IF SO
24	012442	013746	001414		MOV	MFG16,-(SP)	:SAVE THE LSW
25	012446	042737	100000	001414	BIC	#BIT15,MFG16	:CLEAR THE SIGN BIT OF LSW
26	012454	006137	001414		ROL	MFG16	:ROTATE THE LSW FIVE TIMES
27	012460	006137	001414		ROL	MFG16	:TO MOVE THE MOST SIGN DIGIT
28	012464	006137	001414		ROL	MFG16	:TO BIT 0 TO BIT 2
29	012470	006137	001414		ROL	MFG16	
30	012474	006137	001414		ROL	MFG16	
31	012500	042737	177770	001414	BIC	#177770,MFG16	:LEFT ON THE MS DIGIT OF THE LSW
32	012506	006337	001416		ASL	MFG16+2	:SHIFT THE MSW LEFT ONE OCTAL DIGIT
33	012512	100472			BMI	6\$:ENTER AGAIN IF SIGN BIT SET
34	012514	006337	001416		ASL	MFG16+2	
35	012520	100467			BMI	6\$	
36	012522	006337	001416		ASL	MFG16+2	
37	012526	100464			BMI	6\$	
38	012530	063737	001414	001416	ADD	MFG16,MFG16+2	:APPENDING THE DIGITS INTO MSW
39	012536	012637	001414		MOV	(SP)+,MFG16	:RESTORE THE LSW
40	012542	006337	001414		ASL	MFG16	:SHIFT THE LSW LEFT ONE OCTAL DIGIT
41	012546	006337	001414		ASL	MFG16	
42	012552	006337	001414		ASL	MFG16	
43	012556	042737	100000	001414	BIC	#BIT15,MFG16	:CLEAR THE SIGN BIT
44	012564	111103			MOVB	(R1),R3	:LOAD THE CURRENT READ IN DIGITS
45	012566	042703	177770		BIC	#177770,R3	:LEFT ONLY ONE OCTAL DIGIT
46	012572	060337	001414		ADD	R3,MFG16	:APPEND THE READ IN CHARACTER TO LSW
47	012576	005201			INC	R1	:ADJUST THE READ IN STRING ADDRESS
48	012600	005302			DEC	R2	:DECREMENT ONE DIGIT COUNT
49	012602	001307			BNE	2\$:BR IF NOT DONE
50	012604	105711			TSTB	(R1)	:IF 10 DIGITS HAVE BEEN ENTERED
51	012606	001034			BNE	6\$:BR IF NOT <CR> TERMINATOR
52	012610	005737	001414	3\$:	TST	MFG16	:FIRST SERIAL NUMBER ZERO ?
53	012614	001006			BNE	5\$:BR IF NO
54	012616	005737	001416		TST	MFG16+2	:SECOND SERIAL NUMBER ZERO ?
55	012622	001426			BEQ	6\$:BR IF YES
56	012624	000402			BR	5\$	
57	012626	005237	001414	4\$:	INC	MFG16	:ASSUME S/N 1, IF THE SERIAL NUMBER NEEDS TO

Address	Op Code	Op 1	Op 2	Op 3	Op 4	Op 5	Op 6	Op 7	Op 8	Op 9	Op 10	Op 11	Op 12	Op 13	Op 14	Op 15	Op 16	Op 17	Op 18	Op 19	Op 20	Op 21	Op 22	Op 23	Op 24	Op 25	Op 26	Op 27	Op 28	Op 29	Op 30	Op 31	Op 32	Op 33	Op 34	Op 35	Op 36	Op 37	Op 38	Op 39	Op 40	Op 41	Op 42	Op 43	Op 44	Op 45	Op 46	Op 47	Op 48	Op 49	Op 50	Op 51	Op 52	Op 53	Op 54	Op 55	Op 56	Op 57	Op 58	Op 59	Op 60	Op 61	Op 62	Op 63	Op 64	Op 65	Op 66	Op 67	Op 68	Op 69	Op 70	Op 71	Op 72	Op 73	Op 74	Op 75	Op 76	Op 77	Op 78	Op 79	Op 80	Op 81	Op 82	Op 83	Op 84	Op 85	Op 86	Op 87	Op 88	Op 89	Op 90	Op 91	Op 92	Op 93	Op 94	Op 95	Op 96	Op 97	Op 98	Op 99	Op 100	Op 101	Op 102	Op 103	Op 104	Op 105	Op 106	Op 107	Op 108	Op 109	Op 110	Op 111	Op 112	Op 113	Op 114	Op 115	Op 116	Op 117	Op 118	Op 119	Op 120	Op 121	Op 122	Op 123	Op 124	Op 125	Op 126	Op 127	Op 128	Op 129	Op 130	Op 131	Op 132	Op 133	Op 134	Op 135	Op 136	Op 137	Op 138	Op 139	Op 140	Op 141	Op 142	Op 143	Op 144	Op 145	Op 146	Op 147	Op 148	Op 149	Op 150	Op 151	Op 152	Op 153	Op 154	Op 155	Op 156	Op 157	Op 158	Op 159	Op 160	Op 161	Op 162	Op 163	Op 164	Op 165	Op 166	Op 167	Op 168	Op 169	Op 170	Op 171	Op 172	Op 173	Op 174	Op 175	Op 176	Op 177	Op 178	Op 179	Op 180	Op 181	Op 182	Op 183	Op 184	Op 185	Op 186	Op 187	Op 188	Op 189	Op 190	Op 191	Op 192	Op 193	Op 194	Op 195	Op 196	Op 197	Op 198	Op 199	Op 200	Op 201	Op 202	Op 203	Op 204	Op 205	Op 206	Op 207	Op 208	Op 209	Op 210	Op 211	Op 212	Op 213	Op 214	Op 215	Op 216	Op 217	Op 218	Op 219	Op 220	Op 221	Op 222	Op 223	Op 224	Op 225	Op 226	Op 227	Op 228	Op 229	Op 230	Op 231	Op 232	Op 233	Op 234	Op 235	Op 236	Op 237	Op 238	Op 239	Op 240	Op 241	Op 242	Op 243	Op 244	Op 245	Op 246	Op 247	Op 248	Op 249	Op 250	Op 251	Op 252	Op 253	Op 254	Op 255	Op 256	Op 257	Op 258	Op 259	Op 260	Op 261	Op 262	Op 263	Op 264	Op 265	Op 266	Op 267	Op 268	Op 269	Op 270	Op 271	Op 272	Op 273	Op 274	Op 275	Op 276	Op 277	Op 278	Op 279	Op 280	Op 281	Op 282	Op 283	Op 284	Op 285	Op 286	Op 287	Op 288	Op 289	Op 290	Op 291	Op 292	Op 293	Op 294	Op 295	Op 296	Op 297	Op 298	Op 299	Op 300	Op 301	Op 302	Op 303	Op 304	Op 305	Op 306	Op 307	Op 308	Op 309	Op 310	Op 311	Op 312	Op 313	Op 314	Op 315	Op 316	Op 317	Op 318	Op 319	Op 320	Op 321	Op 322	Op 323	Op 324	Op 325	Op 326	Op 327	Op 328	Op 329	Op 330	Op 331	Op 332	Op 333	Op 334	Op 335	Op 336	Op 337	Op 338	Op 339	Op 340	Op 341	Op 342	Op 343	Op 344	Op 345	Op 346	Op 347	Op 348	Op 349	Op 350	Op 351	Op 352	Op 353	Op 354	Op 355	Op 356	Op 357	Op 358	Op 359	Op 360	Op 361	Op 362	Op 363	Op 364	Op 365	Op 366	Op 367	Op 368	Op 369	Op 370	Op 371	Op 372	Op 373	Op 374	Op 375	Op 376	Op 377	Op 378	Op 379	Op 380</
---------	---------	------	------	------	------	------	------	------	------	------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	--------	----------

.SBTTL UTILITY ROUTINE

;THIS CODING TO PROVIDE UTILITY ROUTINE ENTRIES

5	012706	004737	024414		CALIN:	JSR	PC,\$TKINT	;INITIALIZE THE KEYBOARD
6	012712	105737	001150			TSTB	\$AUTOB	;AUTO BYTE SET ?
7	012716	001057				BNE	\$S	;IF SO, BRANCH
8	012720	005737	001270			TST	\$CDW1	;ALLOW ANY UTILITY ROUTINE ?
9	012724	001454				BEQ	\$S	;BR IF NOT
10								
11	012726	005227	177777		1\$:	INC	#-1	;FIRST TIME THRU ?
12	012732	001002				BNE	\$S	;BR IF NO
13	012734	104401	037740		2\$:	TYPE	,MSGBLK	;ENTER MESSAGE BLOCK
14	012740	104401	040521		3\$:	TYPE	,MUTLTY	;TYPE UTILITY MESSAGE
15	012744	104410				RDCHR		;READ IN THE ROUTINE NUMBER
16	012746	012637	001174			MOV	(SP)+,\$TMP0	;ADDRESS OF INPUT BUFFER
17	012752	022737	000060	001174		CMP	#'0,\$TMP0	;INPUT NUMBER LESS THAN 0 ?
18	012760	10*022				BHI	\$S	;BR IF SO
19	012762	122737	000064	001174		CMPE	#'4,\$TMP0	;INPUT NUMBER LARGER THAN 4 ?
20	012770	103416				BLO	\$S	;BR IF SO
21	012772	104401	001174			TYPE	, \$TMP0	;TYPE CHARACTER
22	012776	104401	001205			TYPE	, \$CRLF	;CR-LF
23	013002	013701	001174			MOV	\$TMP0,R1	;GET NUMBER
24	013006	042701	177760			BIC	#177760,R1	;LEFT OF THREE BITS
25	013012	006301				ASL	R1	;WORD INDEX
26	013014	004771	006052			JSR	PC,@TABCAL(R1)	;CALL THE DESIRED UTILITY ROUTINE
27	013020	104401	001205			TYPE	, \$CRLF	;CR-LF
28	013024	000745				BR	\$S	;LOOP BACK TO THE SAME POINT
29								
30	013026	104401	001205		4\$:	TYPE	, \$CRLF	;CR-LF
31	013032	022737	000065	001174		CMP	#'5,\$TMP0	;TYPE WHOLE MESSAGE AGAIN ?
32	013040	001735				BEQ	\$S	;BR IF YES
33	013042	005037	001362			CLR	DS.CYL	;CLEAR ALL PARAMETERS
34	013046	005037	001364			CLR	DS.TRK	
35	013052	005037	001344			CLR	BADSEC	
36	013056				5\$:			

.SBTTL SETUP WRITE BUFFER

:THIS CODE SETS UP THE SELECTED DATA PATTERN TO BE WRITTEN ON EACH
 :SECTOR IMAGE. ALSO, RETURN HERE WHEN LOOPING ON DRIVE BEING TESTED
 :WITH SWO=1 (SET).

7	013056	104401	036573		ST3:	TYPE	.MUNIT	:TYPE 'DRIVE'
8	013062	013746	001222			MOV	DRIVE,-(SP)	::SAVE DRIVE FOR TYPEOUT
	013066	104403				TYPOS		::TYPE DRIVE NUMBER
	013070	002				.BYTE	2	::GO TYPE--OCTAL ASCII
	013071	000				.BYTE	0	::TYPE 2 DIGIT(S)
9	013072	104401	036602			TYPE	,\$COMMA	::SUPPRESS LEADING ZEROS
10	013076	104401	036622			TYPE	,BLNKS1	:TYPE ' '
11	013102	004737	022622			JSR	PC,TYPEPACK	:TYPE 1 BLANK
12	013106	104401	001205			TYPE	,\$CRLF	:TYPE PACK S/N IN OCTAL
13	013112	012737	017642	000060		MOV	#0,ENTR,@#1KVEC	:CR-LF
14	013120	012706	001100			MOV	#STACK,SP	:VECTOR FOR CONTROL-0
15	013124	005037	177776			CLR	PS	:RESET STACK POINTER
16	013130	005037	001406			CLR	UPDBSF	:PRIORITY = 0
17	013134	005737	001320			TST	MODE	:DON'T ALLOW UPDATE OF 'BSF' AT END OF PASS
18	013140	001006				BNE	1\$: 'FORMAT' OR 'VERIFY HEADER' MODE ?
19	013142	012737	177777	001406		MOV	#-1,UPDBSF	:BR IF 'VERIFY HEADER ONLY' MODE
20	013150	104401	037315			TYPE	,MSFOR	:ALLOW UPDATE OF 'BSF' AT END OF PASS
21	013154	000402				BR	2\$:TYPE 'STARTING FORMAT'
22	013156	000137	015110		1\$:	JMP	VFYHDR	:BEGIN FORMATTING
23								:BEGIN VERIFYING HEADERS ONLY
24	013162	013703	001350		2\$:	MOV	WC,R3	:SET JP COUNTER
25	013166	012700	046234			MOV	#BUFP,R0	:SET UP MEMORY POINTER
26	013172	013701	001336		3\$:	MOV	PATA,R1	:SET UP PATTERN IN R1
27	013176	013702	001340			MOV	PATB,R2	:SET UP PATTERN IN R2
28	013202	010120			4\$:	MOV	R1,(R0)+	:MOV 1ST PAT INTO MEM
29	013204	010220				MOV	R2,(R0)+	:MOV 2ND PAT INTO MEM
30	013206	005303				DEC	R3	:KEEP COUNT
31	013210	005303				DEC	R3	:KEEP COUNT
32	013212	001373				BNE	4\$:DO IT AGAIN IF R3 NOT 0

```

1
2
3
4
5 013214 004737 016714
6 013220 004737 017120
7
8 013224 112737 000020 005541
9 013232 005737 001356
10 013236 001002
11 013240 105037 005541
12 013244 112737 000143 005542
13 013252 004037 031214
14 013256 005540
15 013260 000774
16 013262 005737 005556
17 013266 001775
18
19
20
21 013270 023727 005552 001466
22 013276 103406
23 013300 123737 005551 001324
24 013306 103402
25 013310 000137 015076
26
27 013314 012703 005434
28 013320 012704 000040
29 013324 012723 177777
30 013330 005304
31 013332 001374
32
33
34
35
36 013334 005737 001404
37 013340 003454
38 013342 005046
39 013344 012746 003434
40 013350 012702 001424
41 013354 005737 001356
42 013360 100402
43 013362 012702 002430
44 013366 010201
45 013370 012703 005434
46 013374 012704 005534
47 013400 062701 000770
48 013404 023712 005552
49 013410 001007
50 013412 123762 005551 000003
51 013420 001003
52 013422 116205 000002
53 013426 010523
54 013430 062702 000004
55 013434 020201
56 013436 002012
57 013440 020304

.SBTTL WRITE HEADERS
;SET UP TO WRITE HEADERS AND DATA FOR FORMATTING
WRTRK: JSR PC,SETDPB ;SET DRIVE PARAMETER TABLE
        JSR PC,SETHDP ;GO INITIALIZE HEADERS IN THE SECTOR BUFFER IN CORE
        MOV #20,FMTDPB+1 ;LOAD FMT16 BIT
        TST SEC30 ;18 BIT MODE ?
        BNE 1$ ;BR IF NOT
        CLRB FMTDPB+1 ;CLEAR THE FMT16 BIT
        MOV #SETFMT,FMTDPB+2 ;'LOAD FORMAT' COMMAND
        JSR R0,RM05 ;START THE COMMAND
        FMTDPB ;DPB ADDRESS
        BR 2$ ;QUEUE FULL RETURN
        TST FMTDPB+16 ;LOOK FOR DONE
        BEQ 3$ ;LOOP UNTIL FINISHED

;SET UP 'SECCU' TABLE WITH BAD SECTORS ON CURRENT TRACK
WRTRKX: CMP FMTDPB+12,#822. ;LAST CYLINDER ?
        BLO 1$ ;BR IF NO
        CMPB FMTDPB+11,LSTRK ;LAST TRACK OF LAST CYLINDER ?
        BLO 1$ ;BR IF NO
        JMP WRTRKZ ;DON'T DESTROY LAST TRACK ON CYL 822.

1$: MOV #SECCU,R3 ;INITILIZE THE 'SECCU' TABLE
    MOV #32.,R4 ;TOTAL OF 32. ENTRIES
2$: MOV #-1,(R3)+ ;LOAD ALL LOCATIONS TO -1
    DEC R4 ;DONE YET ?
    BNE 2$ ;BR IF NO

;LOAD 'HE 'MFG' AND 'USR' BAD SECTOR FILES INTO THE 'SECCU' TABLE FOR
;THE CURRENT TRACK TO BE FORMATTED
        TST BSFAVL ;IS BAD SECTOR FILE AVAILABLF ?
        BLE 9$ ;BR IF NO
        CLR -(SP) ;CLEAR UP THE DUMMY RETURN ADDRESS
        MOV #USTAB+8.,-(SP) ;ADDRESS OF 'USR' BAD SECTOR TABLE
        MOV #MFG16+8.,R2 ;SETUP ADDRESS OF 'MFG16' BAD SECTOR TABLE
        TST SEC30 ;IS IT 16. BIT MODE ?
        BMI 3$ ;BR IF YES
        MOV #MFG18+8.,R2 ;SETUP ADDRESS OF 'MFG18' BAD SECTOR TABLE
        MOV R2,R1 ;STARTING ADDRESS OF BAD SECTOR TABLE
        MOV #SECCU,R3 ;STARTING ADDRESS OF 'SECCU' TABLE
        MOV #SECCU+64.,R4 ;ENDING ADDRESS OF TABLE (32. ENTRIES)
        ADD #252.*2,R1 ;INDEX ADDRESS TO END OF TABLE (126. ENTRIES)
        CMP FMTDPB+12,(R2) ;BAD SECTOR ON THIS CYLINDER ?
        BNE 6$ ;BR IF NO
        CMPB FMTDPB+11,3(R2) ;BAD SECTOR ON THE SAME TRACK ?
        BNE 6$ ;BR IF NO
        MOVB 2(R2),R5 ;YES--SAME CYL & TRK SO SAVE BAD SECTOR ADRS
        MOV R5,(R3)+ ;PUT BAD SECTOR IN 'SECCU' TABLE
        ADD #4,R2 ;ADVANCE TO NEXT SET OF BAD SECTORS ENTRIES
        CMP R2,R1 ;AT END OF BAD SECTOR TABLE ?
        BGE 8$ ;BR IF YES
        CMP R3,R4 ;AT END OF 'SECCU' TABLE ?

```

```

58 013442 002001      BGE      7$      :YES--SHOULD NOT BE THAT MANY ENTRIES FOR
59                      :ONE TRACK
60 013444 000757      BR        5$      :GET NEXT ENTRY
61
62 013446 004737 017522 7$:      JSR      PC,RESTRT :IMPROPER MFG INFORMATION
63 013452 012737 177777 001404 :MOV      #-1,BSFAVL :INDICATE BAD SECTOR FILE IS NOT AVAILABLE
64 013460 000137 012146 :JMP      TABINT    :AND START AGAIN
65
66 013464 011601      8$:      MOV      (SP),R1    :GET 'USR' BAD SECTOR TABLE
67 013466 012602      :MOV      (S2)+,R2 :STARTING ADDRESS OF 'USR' BAD SECTOR TABLE
68 013470 001343      :BNE      4$      :BR IF NOT DUMMY (TERMINATOR)
69 013472 000240      9$:      NOP              :DONE
70
71                      :THIS CODE SORTS THE BAD SECTOR TABLE 'SECCU' IN ASCENDING ORDER
72                      :AND DELETES THE DUPLICATED ONES
73
74 013474 012702 005434 SORT1: MOV      #SECCU,R2    :TOP OF THE TABLE
75 013500 012703 005532 :MOV      #SECCU+62.,R3 :BOTTOM OF THE TABLE
76 013504 012704 000037 :MOV      #31.,R4       :TOTAL 32 ELEMENT,SORT 31 TIMES
77 013510 022712 177777 :CMP      #-1,(R2)      :IS THE TABLE EMPTY ?
78 013514 001451      :BEQ      6$           :BR IF IT IS, QUICK EXIT
79 013516 021262 000002 1$:      CMP      (R2),2(R2) :N TH ELEMENT : N+1 TH ELEMENT
80 013522 103430      :BLO      4$           :BR IF SMALLER
81 013524 001406      :BEQ      2$           :DELET N+1 TH ELEMENT, IF SAME
82                      :OTHERWISE, N > N+1
83 013526 011246      :MOV      (R2),-(SP)    :STORE N ELEMENT
84 013530 016212 000002 :MOV      2(R2),(R2)     :SWITCH N+1 ELEMENT TO N ELEMENT
85 013534 012662 000002 :MOV      (SP)+,2(R2)    :SWITCH N ELEMENT TO N+1 ELEMENT
86 013540 000421      :BR        4$           :ADJUST TOP POINTER
87 013542 022712 177777 2$:      CMP      #-1,(R2)    :TERMINATOR ?
88 013546 001416      :BEQ      4$           :BR IF IT IS
89 013550 010246      :MOV      R2,-(SP)     :SAVE TOP POINTER
90 013552 062702 000002 :ADD      #2,R2         :DELET 2(R2)
91 013556 016222 000002 3$:      MOV      2(R2),(R2)+ :
92 013562 022702 005532 :CMP      #SECCU+62.,R2 :BOTTOM OF THE TABLE ?
93 013566 101373      :BHI      3$           :BR IF NOT
94 013570 012737 177777 005532 :MOV      #-1,SECCU+62. :LOAD -1 TO TABLE BOTTOM
95 013576 012602      :MOV      (SP)+,R2     :RESTORE THE TOP POINTER
96 013600 005304      :DEC      R4          :DECREMENT ONE ELEMENT COUNT
97 013602 001416      :BEQ      6$           :BR IF ALL DONE
98 013604 062702 000002 4$:      ADD      #2,R2       :INCREMENT THE TOP POINTER
99 013610 020302      :CMP      R3,R2       :REACH THE BOTTOM ?
100 013612 001341      :BNE      1$          :BR IF NOT
101 013614 005304      5$:      DEC      R4          :DECREMENT ONE SORT COUNT
102 013616 001410      :BEQ      6$           :BR IF ALL DONE
103 013620 012702 005434 :MOV      #SECCU,R2     :RESET TOP POINTER
104 013624 162703 000002 :SUB      #2,R3         :UPDATE BOTTOM POINTER
105 013630 022703 005434 :CMP      #SECCU,R3     :EXIT IF TOP BOTTOM
106 013634 001401      :BEQ      6$           :
107 013636 000727      :BR        1$          :
108 013640 000240      6$:      NOP              :SORT THE REST ELEMENTS
109 013642 005037 005536 :CLR      NEXT          :DONE
110                      :FLAG,START OF A NEW TRACK
111 013646 005037 001316 WRTRK1: CLR      SOFSW     :CLEAR ERROR COUNTER
112 013652 005037 001342 :CLR      RETRY         :ZERO THE RETRY COUNTER
113 013656 105037 005550 :CLRB     FMTDPB+10     :RESTORE SECTOR
114 013662 013737 001352 005544 :MOV      #WC,FMTDPB+4 :RESTORE WC

```

```

115 013670 012737 046234 005546      MOV      #BUFF,FMTDPB+6 ;RESTORE BA
116
117      ;THIS CODE TO SET UP WORD COUNT AND BUFFER ADDRESS
118
119 013676 113737 005536 005550  WRTRKA:  MOVB     NEXT,FMTDPB+10 ;STARTING SECTOR
120 013704 012701 005434          MOV      #SECCU,R1 ;R1 POINTS TO THE BAD SECTOR TABLE
121 013710 022711 177777          1$:      CMP      #-1,(R1) ;END OF 'SECCU' TABLE ?
122 013714 001512          BEQ      WRTRKD ;BR IF YES
123 013716 032711 100000          BIT      #BIT15,(R1) ;THE BAD SECTOR HAS ALREADY ACCESSED ?
124 013722 001403          BEQ      2$ ;BR IF NOT
125 013724 062701 000002          ADD      #2,R1 ;ADJUST THE POINTER
126 013730 000767          BR       1$ ;LOOPING BACK
127 013732 123711 005550          2$:      CMPB     FMTDPB+10,(R1) ;BAD SECTOR = STARTING SECTOR ?
128 013736 001416          BEQ      WRTRKB ;BR IF IT IS
129 013740 103402          BLO      3$ ;BR IF START SEC < BAD SECTOR
130 013742 000137 013270          JMP      WRTRKX ;SOMETHING IS WRONG, TRY SORTING AGAIN ON
131                                     ;THE SAME TRACK
132 013746 111102          3$:      MOVB     (R1),R2 ;UPDATE NEXT STARTING ADDRESS
133 013750 023702 001360          CMP      MAXSEC,R2 ;NEXT BAD SECTOR IS THE LAST SECTOR?
134 013754 001463          BEQ      WRTRKF ;BR IF LAST SECTOR
135 013756 103471          BLO      WRTRKD ;BR IF LESS
136 013760 005202          INC      R2 ;NEXT - BAD + 1
137 013762 010237 005536          MOV      R2,NEXT ;NEXT STARTING ADDRESS
138 013766 052721 100000          BIS      #BIT15,(R1)+ ;MARK THE ACCESSED SECTOR
139 013772 000432          BR       WRTRKC ;TO SET UP WORD COUNT
140
141 013774 105237 005550          WRTRKB:  INCB     FMTDPB+10 ;INCREMENT THE STARTING SECTOR
142 014000 052721 100000          BIS      #BIT15,(R1)+ ;MARK THE ACCESSED SECTOR
143 014004 123711 005550          CMPB     FMTDPB+10,(R1) ;STILL ON ANOTHER BAD SECTOR ?
144 014010 001771          BEQ      WRTRKB ;LOOP AGAIN
145 014012 123737 005550 001360          CMPB     FMTDPB+10,MAXSEC ;IF START SECTOR > MAXSEC
146 014020 101402          BLOS     1$ ;IMPROPER MFG INFORMATION
147 014022 000137 015010          JMP      HDRSET ;EXIT
148
149 014026 022711 177777          1$:      CMP      #-1,(R1) ;TO SEE IF NEXT BAD SECTOR IN TABLE
150 014032 001443          BEQ      WRTRKD ;BR IF NONE
151 014034 111102          MOVB     (R1),R2 ;UPDATE THE NEXT
152 014036 023702 001360          CMP      MAXSEC,R2 ;BAD SECTOR IS THE LAST SECTOR ?
153 014042 001430          BEQ      WRTRKF ;BR IF LESS
154 014044 103436          BLO      WRTRKD ;BAD SEC +1
155 014046 005202          INC      R2 ;NEXT STARTING ADDRESS
156 014050 010237 005536          MOV      R2,NEXT ;NEXT STARTING ADDRESS
157 014054 052711 100000          BIS      #BIT15,(R1) ;MARK THE ACCESSED SECTOR
158
159 014060 013702 005536          WRTRKL:  MOV      NEXT,R2 ;CALCULATE THE WORD COUNT
160 014064 162702 000002          SUB      #2,R2 ;ENDSECTOR = NEXT - 2
161 014070 006302          ASL      R2 ;WORD INDEX
162 014072 016203 006164          MOV      WCTBL(R2),R3 ;WORD CTR FOR SECTOR 0 TO ENDING SECTOR
163 014076 113702 005550          MOVB     FMTDPB+10,R2 ;STARTING SECTOR
164 014102 006302          ASL      R2 ;WORD INDEX
165 014104 166203 006164          SUB      WCTBL(R2),R3 ;WORD COUNT FOR SECTOR 0 TO STARTING SECTOR
166 014110 062703 000402          ADD      #258.,R3 ;ADJUST ONE SECTOR
167 014114 005403          NEG      R3 ;GET THE NEAGTIVE WORD COUNT
168 014116 010337 005544          MOV      R3,FMTDPB+4 ;LOAD THE WORD CTR INTO DPB
169 014122 000432          BR       WRTRKE ;LOAD THE STARTING ADDRESS
170
171 014124 012737 177777 005536  WRTRKF:  MOV      #-1,NEXT ;ALL DONE

```



```

172 014132 052711 100000      BIS      #BIT15,(R1)      ;MASK THE SECTOR
173 014136 005302      DEC      R2              ;PATCH FOR THE LAST SECTOR
174 014140 000405      BR       WTRKH          ;PATCH
175
176 014142 012737 177777 005536 WTRKD: MOV      #-1,NEXT      ;NO MORE BAD SECTOR
177 014150 013702 001360      MOV      MAXSEC,R2          ;LAST SECTOR
178
179 014154 006302      WTRKH: ASL      R2              ;WORD INDEX
180 014156 016203 006164      MOV      WCTBL(R2),R3        ;WORD CTR FOR THE ENDING SECTOR
181 014162 113702 005550      MOV      FMTDPB+10,R2        ;STARTING ADDRESS
182 014166 006302      ASL      R2              ;WORD INDEX
183 014170 166203 006164      SUB      WCTBL(R2),R3        ;WORD CTR FOR THE STARTING SECTOR
184 014174 062703 000402      ADD      #258.,R3            ;ADJUST ONE SECTOR
185 014200 005403      NEG      R3              ;NEGATIVE WORD COUNT
186 014202 010337 005544      MOV      R3,FMTDPB+4          ;LOAD THE WORD COUNT INTO DPB
187 014206 000240      NOP                      ;DONE
188
189 014210 113702 005550      WTRKE: MOV      FMTDPB+10,R2    ;STARTING ADDRESS
190 014214 006302      ASL      R2              ;LOCATE THE BUFFER ADDRESS
191 014216 016237 006064 005546      MOV      ADRTBL(R2),FMTDPB+6 ;BUFFER ADDRESS
192
193 014224 112737 000163 005542 WTRK2: MOV      #WTRHD,FMTDPB+2 ;SET WRITE HEADER & DATA COMMAND IN TBL
194 014232 012737 014232 001124      MOV      #.,$LPERR      ;SET UP LOOP ON ERROR ADDRESS
195 014240 012706 001100      MOV      #STACK,SP        ;LOAD STACK POINT
196 014244 004037 031214      1$:   JSR      R0,RM05        ;GO FORMAT A TRACK
197 014250 005540      FMTDPB      ;ADRS OF PARAMETERS - TBL
198 014252 000774      BR       1$              ;WAIT FOR QUEUE IF FULL
199 014254 005737 005556      2$:   TST      FMTDPB+16      ;WAIT FOR COMMAND TO COMPLETE
200 014260 001775      BEQ      2$              ;BR IF NOT DONE
201 014262 100024      BPL      4$              ;BR IF NO ERROR
202 014264 012737 014312 001176      MOV      #3$, $ESCAPE    ;ESCAPE TO 3$ ON ERROR
203 014272 004737 016550      JSR      PC,ERINDX        ;SEE WHICH ERROR
204 014276 104010      EMT      10              ;DRIVE OFFLINE
205 014300 104011      EMT      11              ;PERSISTENT DRIVE UNSAFE ERROR
206 014302 104012      EMT      12              ;UNCORRECTABLE MASSBUS PARITY ERROR
207 014304 104013      EMT      13              ;SOFTWARE TIMEOUT
208 014306 104014      EMT      14              ;DRIVE UNSAFE ERROR
209 014310 104015      EMT      15              ;DRIVE/CONTROLLER ERROR DURING WRITE
210
211 014312 004737 016646      3$:   JSR      PC,LOP.CK      ;LOOP ON THE ERROR ?
212 014316 022737 000003 001342      CMP      #3,RETRY      ;ERROR RETRY LIMIT ?
213 014324 001403      BEQ      4$              ;BR IF REACHED
214 014326 005237 001342      INC      RETRY          ;COUNT THE ERROR
215 014332 000744      BR       1$              ;TRY AGAIN
216 014334 005037 001176      4$:   CLR      $ESCAPE      ;CLEAR ERROR ESCAPE ADDRESS
217 014340 005037 001342      CLR      RETRY          ;CLEAR THE RETRY COUNTER
218

```

.SBTTL CHECK TRACK JUST WRITTEN

;SET UP TO CHECK THE TRACK JUST WRITTEN, WITH A WRITE CHECK HEADER
;AND DATA COMMAND

6	014344	112737	000153	005542	CKTRK: MOV	#WCKHD,FMTDPB+2	;SET WRITE CHECK HEADER & DATA COMMAND IN TBL
7	014352	012737	014352	001124	MOV	#,SLPERR	;SETUP LOOP ON ERROR ADDRESS
8	014360	012706	001100		MOV	#STACK,SP	;LOAD STACK POINTER
9	014364	004037	031214		1\$: JSR	R0,RM05	;GO CHECK THE TRACK JUST FORMATTED
10	014370	005540			FMTDPB		;ADRS OF PARAMETERS - TBL
11	014372	000774			BR	1\$;WAIT FOR QUEUE IF FULL
12	014374	005737	005556		2\$: TST	FMTDPB+16	;WAIT FOR COMMAND TO COMPLETE
13	014400	001775			BEG	2\$;BR IF NOT DONE
14	014402	100132			BPL	9\$;BR IF NO ERROR
15							
16	014404	113737	005566	001344	MOVB	RM.REG+RMDA,BADSEC	;GET THE SECTOR ADDRESS
17	014412	001005			BNE	3\$;BR IF NOT SECTOR 0
18	014414	013737	001360	001344	MOV	MAXSEC,BADSEC	;RESTORE TO LAST SECTOR +1
19	014422	005237	001344		INC	BADSEC	;INCREMENT TO LAST SECTOR +1
20	014426	005337	001344		3\$: DEC	BADSEC	;ADJUST TO BAD SECTOR
21	014432	012737	014736	001176	MOV	#11\$, \$ESCAPE	;ESCAPE TO 11\$ ON ERROR
22	014440	004737	016550		JSR	PC,ERINDX	;SEE WHICH ERROR
23	014444	104010			EMT	10	;DRIVE OFFLINE
24	014446	104011			EMT	11	;PERSISTENT DRIVE UNSAFE ERROR
25	014450	104012			EMT	12	;UNCORRECTABLE MASSBUS PARITY ERROR
26	014452	104013			EMT	13	;SOFTWARE TIMEOUT
27	014454	104014			EMT	14	;DRIVE UNSAFE ERROR
28	014456	000240			NOP		;FILLER FOR 'ERINDX' ROUTINE
29							
30	014460	032737	040000	005570	BIT	#WCE RM.REG+RMCS2	;WRITE CHECK ERROR ?
31	014466	001005			BNE	4\$;BR IF YES
32	014470	033727	005574		BIT	RM.REG+RMER1,(PC)+	;CHECK FOR DATA ERRORS
33	014474	130620			.WORD	DCK.OPI'DTE.HCRC!HCE!FER	
34	014476	001001			BNE	4\$;BR IF YES
35	014500	104016			EMT	16	;CONTROLLER/DRIVE ERROR DURING WRITE CHECK
36							
37	014502	005737	001316		4\$: TST	SOFSW	;RETRYING THE SECTOR ?
38	014506	001413			BEG	5\$;BR IF NO
39	014510	012737	014762	001176	MOV	#12\$, \$ESCAPE	;ESCAPE TO 12\$ ON ERROR
40	014516	004737	020146		JSR	PC,RECORD	;RECORD THE BAD SECTOR IN USR TABLE
41	014522	012737	100000	001410	MOV	#MF,HDRBIT	;INDICATE 'USR' BAD SECTOR
42	014530	004737	020754		JSR	PC,RESET	;RESET THE HEADER BITS AND WRITE HEADER
43	014534	104017			EMT	17	;RETRIES NOT SUCCESSFUL-SECTOR NOT ACCEPTABLE
44							
45	014536	005037	001176		5\$: CLR	\$ESCAPE	;RESET ESCAPE ADDRESS
46	014542	032737	040000	005572	BIT	#ERR,RM.REG+RMD5	;DATA ERROR ?
47	014550	001002			BNE	6\$;BR IF YES
48	014552	104024			EMT	24	;WRITE CHECK ERROR
49	014554	000401			BR	7\$;CONTINUE
50	014556				6\$: EMT	20	;DATA ERROR DURING WRITE CHECK
51							
52	014560	013701	001344		7\$: MOV	BADSEC,R1	;FAILING SECTOR ADDRESS
53	014564	113737	001344	005550	MOVB	BADSEC,FMTDPB+10	;SECTOR ADDRESS
54	014572	006301			ASL	R1	;SETUP INDEX TO ADDRESS WORDS
55	014574	016137	006064	005546	MOV	ADRTBL(R1),FMTDPB+6	;BUFFER ADDRESS FOR FAILING SECTOR

56	014602	013701	001360		MOV	MAXSEC,R1	:R1 ENDING SECTOR #
57	014606	005737	005536		TST	NEXT	:WHOLE TRACK DONE ?
58	014612	100404			BMI	8\$:BR IF IT IS
59	014614	013701	005536		MOV	NEXT,R1	:LOAD CURRENT ENDING SECTOR
60	014620	162701	000002		SUB	#2,R1	:ADJUST TWO SECTORS
61	014624	006301		8\$:	ASL	R1	:WORD INDEX
62	014626	016102	006164		MOV	WCTBL(R1),R2	:WORDCTR FOR ENDING SECTOR
63	014632	113701	005550		MOVB	FMTDPB+10,-1	:STARTING ADDRESS
64	014636	006301			ASL	R1	:WORD COUNT
65	014640	166102	006164		SUB	WCTBL(R1),R2	:WORD CTR FOR STARTING SECTOR
66	014644	005402			NEG	R2	
67	014646	010237	001346		MOV	R2,SAVWC	:SAVE THE WORD COUNT
68	014652	012737	177376	005544	MOV	#-258.,FMTDPB+4	:WORD COUNT FOR 1 SECTOR
69	014660	005237	001316		INC	SOF SW	:INDICATE THAT A RETRY IS IN PROGRESS
70	014664	000137	014224		JMP	WRTRK2	:REFORMAT ERROR SECTOR
71							
72	014670	005737	001316		TST	SOF SW	:RETRY IN PROGRESS ?
73	014674	001432		9\$:	BEQ	12\$:BR IF NOT
74	014676	022737	000002	001316	CMP	#2,SOF SW	:SEE IF LAST RETRY
75	014704	001403			BEQ	10\$:BR IF IT IS
76	014706	005237	001316		INC	SOF SW	:INCREMENT RETRY COUNT
77	014712	000624			BR	1\$:READ AGAIN
78							
79	014714	123737	001360	005550	10\$:	CMPB	MAXSEC,FMTDPB+10
80	014722	001417			BEQ	12\$:SEE IF LAST SECTOR ON THE TRACK
81	014724	004737	017072				:BR IF IT IS
82	014730	005037	001316		JSR	PC,SCAWC	:SETUP TO CHECK REMAINING SECTORS ON THE TRACK
83	014734	000613			CLR	SOF SW	:CLEAR RETRY COUNTER
84					BR	1\$:FINISH CHECKING THE TRACK
85	014736	004737	016646				
86	014742	022737	000003	001342	11\$:	JSR	PC,LOP.CK
87	014750	001404			CMP	#3,RETRY	:CHECK FOR LOOP ON ERROR
88	014752	005237	001342		BEQ	12\$:ERROR RETRY REACHED ?
89	014756	000137	014364		INC	RETRY	:BR IF IT IS
90					JMP	1\$:COUNT THE RETRY
91	014762	005037	001176				:DO THE WRITE CHECK AGAIN
92	014766	005037	001342		12\$:	CLR	\$ESCAPE
93	014772	005037	001316		CLR	RETRY	:CLEAR THE ERROR RETURN ESCAPE ADDRESS
94	014776	005737	005536		CLR	SOF SW	:CLEAR THE RETRY COUNTER
95	015002	100402			TST	NEXT	:CLEAR THE SOFTWARE RETRY COUNT
96	015004	000137	013676		BMI	13\$:WHOLE TRACK DONE ?
97	015010				JMP	WRTRKA	:BR IF IT IS
				13\$:			

.SBTTL ROUTINE TO SET HEADER BIT

3	015010	032777	000002	164'36	HDRSET: BIT	#BIT11, @SWR	: LOOP ON C RRENT TRACK ?
4	015016	001402			BEQ	1\$: BR IF NOT
5	015020	000137	013270		JMP	WRTKX	: START AGAIN ON THE SAME TRACK
6							
7	015024	012737	040000	001410	1\$: MOV	#UF, HDRBIT	: INDICATE 'MFG' BAD SECTOR
8	015032	012704	005434		MOV	#SELCU, R4	: TABLE FOR BAD SECTOR ON CURRENT TRACK
9	015036	022714	177777		2\$: CMP	#-1, (R4)	: END OF TABLE ?
10	015042	001414			BEQ	4\$: BR IF SO
11	015044	032714	040000		BIT	#BIT14, (R4)	: HAS THE SECTOR BE ASSCESSED ?
12	015050	001006			BNE	3\$: BR IF SO
13	015052	052714	040000		BIS	#BIT14, (R4)	: MASK THE SECTOR TABLE
14	015056	111437	001344		MOVB	(R4), BADSEC	: SECTOR ADDRESS
15	015062	004737	020754		JSR	PC, RESET	: RESET THE HEADER
16	015066	062704	000002		3\$: ADD	#2, R4	: INCREMENT THE TABLE POINTER
17	015072	000761			BR	2\$: LOOPING BACK
18	015074	000240			4\$: NOP		: ALL DONE
19							
20	015076	004737	016770		WRTKZ: JSR	PC, TRKIST	: GET UPDATED TRACK AND CYLINDER ADDRESSES
21	015102	000402			BR	VFYHDR	: RETURN HERE IF DONE
22							: AND DO QUICK CHECK OF DISK
23	015104	000137	013270		JMP	WRTKX	: CONTINUE WITH THE FORMAT

.SBTTL VERIFY HEADER ROUTINE

:THIS CODE MAKES SURE EACH CYLINDER FORMATTED CONTAINS THE
:PROPER CYLINDER ADDRESS. THE PROGRAM IS LOOKING FOR
:POSSIBLE POSITIONER ERRORS THAT MAY HAVE OCCURRED DURING THE FORMAT.

7	015110	005037	001342		VFYHDR: CLR	RETRY	:CLEAR RETRY COUNTER
8	015114	005737	001320		TST	MODE	:IS IT 'VERIFY HEADER ONLY' MODE ?
9	015120	001003			BNE	1\$:BR IF YES, ELSE
10	015122	104401	037337		TYPE	,MSQVER	:TYPE 'STARTING QUICK HEADER VERIFY'
11	015126	000402			BR	2\$	
12	015130	104401	037376		1\$: TYPE	,MSVER	:TYPE 'STARTING HEADER VERIFY'
13	015134	004737	016714		2\$: JSR	PC,SETDPB	:SET DRIVE PARAMETER TABLE
14	015140	004737	017120		JSR	PC,SETHDR	:SET HEADERS IN CORE
15	015144	012700	046234		3\$: MOV	#BUFV,R0	:GET STARTING ADDRESS OF EXPECTED HEADERS
16	015150	012701	106434		MOV	#BUFV,R1	:GET STARTING ADDRESS OF RECIEVED HEADERS
17	015154	010137	005546		MOV	R1,FMTDPB+6	:SET UP BUFFER ADDRESS
18	015160	013737	001352	005544	MOV	MWC,FMTDPB+4	:SETUP WORD FOR VERIFY ONLY MODE
19	015166	005037	001322		CLR	SNGSEC	:SETUP MULTI-SECTOR READ FLAG
20	015172	005737	001320		TST	MODE	:IS IT 'VERIFY HEADER ONLY' MODE ?
21	015176	001005			BNE	5\$:BR IF YES
22	015200	012737	177776	005544	4\$: MOV	#-2,FMTDPB+4	:SETUP WORD COUNT FOR QUICK VERIFY
23	015206	005237	001322		INC	SNGSEC	:SETUP SINGLE SECTOR READ
24							
25	015212	012737	015212	001124	5\$: MOV	#,\$LPERR	:SETUP LOOP ON ERROR ADDRESS
26	015220	112737	000020	005541	6\$: MOV	#20,FMTDPB+1	:LOAD 'FMT' BIT FOR 16 BIT FORMAT
27	015226	023727	005552	001466	CMP	FMTDPB+12,#822.	:IS IT LAST CYLINDER ?
28	015234	103404			BLO	7\$:BR IF NO
29	015236	123737	005551	001324	CMP	FMTDPB+11,LSTRK	:LAST TRACK OF LAST CYLINDER (BSF) ?
30	015244	001405			BEQ	8\$:BR IF YES
31	015246	005737	001356		7\$: TST	SEC30	:IS IT 16 BIT MODE ?
32	015252	001002			BNE	8\$:BR IF YES
33	015254	105037	005541		CLRB	FMTDPB+1	:LOAD 'FMT' BIT FOR 18 BIT FORMAT
34	015260	112737	000143	005542	8\$: MOV	#SETFMT,FMTDPB+2	:LOAD 'FORMAT' COMMAND
35	015266	004037	031214		9\$: JSR	R0,RM05	:START THE COMMAND
36	015272	005540			FMTDPB		:DPB ADDRESS
37	015274	000774			BR	9\$:QUEUE FULL RETURN
38	015276	005737	005556		10\$: TST	FMTDPB+16	:LOOK FOR DONE
39	015302	001775			BEQ	10\$:LOOP UNTIL FINISHED
40							
41	015304	112737	000173	005542	MOV	#RDHD,FMTDPB+2	:SET UP READ HEADER & DATA COMMAND
42	015312	004037	031214		JSR	R0,RM05	:GO READ HEADER
43	015316	005540			FMTDPB		:ADRS OF PARAMETER TBL
44	015320	000737			11\$: BR	6\$:WAIT IF QUEUE IS FULL
45	015322	005737	005556		12\$: TST	FMTDPB+16	:WAIT FOR COMMAND TO COMPLETE
46	015326	001775			BEQ	12\$:BR IF NOT DONE
47	015330	100046			BPL	15\$:BR IF NOT ERROR
48							
49	015332	012737	015562	001176	MOV	#18\$, \$ESCAPE	:ESCAPE TO 18\$ ON ERROR
50	015340	004737	016550		JSR	PC,ERINDX	:SEE WHICH ERROR
51	015344	104010			EMT	10	:DRIVE OFFLINE
52	015346	104011			EMT	11	:PERSISTENT DRIVE UNSAFE ERROR
53	015350	104012			EMT	12	:UNCORRECTABLE MASSBUS PARITY ERROR
54	015352	104013			EMT	13	:SOFTWARE TIMEOUT
55	015354	104014			EMT	14	:DRIVE UNSAFE ERROR
56	015356	000240			NOP		:FILLER FOR 'ERINDX' ROUTINE

15360	032737	040000	005574	BIT	#ERR,RM.REG+12	:ANY DRIVE ERRORS ?
15366	001427			BEQ	15\$:BR IF NO
15370	005737	001322		TST	SNGSEC	:ALREADY READING SINGLE SECTORS
15374	001701			BEQ	4\$:BR IF NO
15376	005237	001342		INC	RETRY	:INCREMENT RETRY COUNT
15402	022737	000003	001342	CMP	#3,RETRY	:TRIED 3 TIMES ?
15410	101273			BHI	4\$:BR IF NO
15412	022737	000200	005574	CMP	#HCE,RM.RFG+14	:IS IT A HEADER COMPARE ERROR ?
15420	001404			BEQ	13\$:BR IF YES
15422	032737	000400	005574	BIT	#HCRC,RM.REG+14	:IS IT A HEADER CRC ERROR ?
15430	001401			BEQ	14\$:BR IF NO
15432						
15432	104022			13\$: EMT	22	: 'HCE' OR 'HCRC' ERROR VERIFYING HEADERS
15434	022737	100000	005622	14\$: CMP	#RSE,RM.REG+42	:BAD SECTOR ERROR ?
15442	001453			BEQ	19\$:BR IF YES
15444	104021			EMT	21	:CONTROLLER/DRIVE ERROR VERIFYING HEADERS
15446	005037	001342		15\$: CLR	RETRY	:CLEAR RETRY COUNT
15452	012737	015562	001176	MOV	#18\$, \$ESCAPE	:ESCAPE TO 18\$ ON ERROR
15460	011037	046230		MOV	(R0),RBUF+4	:GET EXPECTED CYLINDER HEADER
15464	023727	005552	001466	CMP	FMTDPB+12,#822.	:IS IT LAST CYLINDER ?
15472	103407			BLO	16\$:BR IF NO
15474	123737	005551	001324	CMPB	FMTDPB+11,LSTRK	:LAST TRACK OF LAST CYLINDER (BSF) ?
15502	001003			BNE	16\$:BR IF NO
15504	052737	010000	046230	BIS	#FMT,RBUF+4	:BAD SECTOR FILE IS ALWAYS 16 BIT MODE
15512	052711	140000		16\$: BIS	#MF,UF,(R1)	:SET MFG AND USR GOOD SECTOR BITS
15516	011137	046224		MOV	(R1),RBUF	:GET RECIEVED CYLINDER HEADER
15522	023737	046224	046230	CMP	RBUF,RBUF+4	:SEE IF CYL READ EQUALS CYL EXPECTED
15530	001401			BEQ	17\$:BR IF CYL CORRECT
15532	104023			EMT	23	:CYLINDER FIELD IN HEADER IS NOT CORRECT
15534	016037	000002	046232	17\$: MOV	2(R0),RBUF+6	:GET EXPECTED TRACK/SECTOR EADER
15542	016137	000002	046226	MOV	2(R1),RBUF+2	:GET RECIEVED TRACK/SECTOR HEADER
15550	023737	046226	046232	CMP	RBUF+2,RBUF+6	:IS TRACK AND SECTOR CORRECT ?
15556	001405			BEQ	19\$:BR IF YES
15560	104007			EMT	7	:TRACK/SECTOR FIELD IN HEADER IS NOT CORRECT
15562	004737	016646		18\$: JSR	PC,LOP.CK	:CHECK FOR LOOP ON ERROR
15566	000137	016510		JMP	REJCTS	:FAILED DURING HEADER CHECK, REJECTED
15572	005737	001320		19\$: TST	MODE	:IS IT 'FORMAT' MODE ?
15576	001416			BEQ	20\$:BR IF YES
15600	123737	005550	001360	CMPB	FMTDPB+10,MAXSEC	:DONE WITH ALL SECTORS ?
15606	001412			BEQ	20\$:BR IF YES
15610	105237	005550		INCB	FMTDPB+10	:UPDATE SECTOR ADDRESS
15614	062700	001004		ADD	#516.,R0	:ADJUST POINTER TO NEXT EXPECTED HEADER
15620	005737	001322		TST	SNGSEC	:READING ONE SECTOR AT A TIME ?
15624	001235			BNE	11\$:BR IF YES
15626	062701	001004		ADD	#516.,R1	:ADJUST POINTER TO NEXT RECIEVED HEADER
15632	000705			BR	15\$:GO COMPARE NEXT SECTOR
15634	105037	005550		20\$: CLR	FMTDPB+10	:START AT SECTOR 0
15640	105237	005551		INCB	FMTDPB+11	:INCREMENT TRACK NUMBER
15644	123737	005551	001332	CMPB	FMTDPB+11,MAXTRK	:WAS IT LAST TRACK ?
15652	101003			BHI	21\$:BR IF YES
15654	004737	017320		JSR	PC,UPDTRK	:UPDATE TRACK ADDRESS IN BUFFER

114	015660	000425		BR	24\$:GO READ NEXT TRACK
115						
116	015662	113737	001334	MOVB	MINTRK,FMIDPB+11	:GET STARTING TRACK ADDRESS
117	015670	005737	001376	TST	WRAP	:SEEKING FROM HI TO LO CYLINDERS ?
118	015674	001407		BEQ	22\$:BR IF NO
119	015676	005337	005552	DEC	FMIDPB+12	:DECREMENT CYLINDER ADDRESS
120	015702	023737	005552	CMP	FMIDPB+12,MAXCYL	:DONE WITH VERIFY ?
121	015710	002413		BLT	25\$:BR IF YES
122	015712	000406		BR	23\$	
123	015714	005237	005552	INC	FMIDPB+12	:INCREMENT CYLINDER ADDRESS BEING CHECKED
124	015720	023737	005552	CMP	FMIDPB+12,MAXCYL	:DONE WITH VERIFY ?
125	015726	101004		BHI	25\$:BR IF YES
126	015730	004737	017206	JSR	PC,UPDCYL	:UPDATE CYLINDER ADDRESS IN BUFFER
127	015734	000137	015144	JMP	3\$:GO READ NEXT CYLINDER
128	015740					

.SBTTL END OF PASS ROUTINE

*INCREMENT THE PASS NUMBER (\$PASS)
*IF THERES A MONITOR GO TO IT
*IF THERE ISN'T JUMP TO DONE

015740				\$EOP:		
015740	005737	001406		1\$:	TST	UPDBSF ;UPDATE LAST TRACK ?
015744	001535				BEQ	8\$;BR IF NO
015746	005037	001342			CLR	RETRY ;CLEAR RETRY COUNT
015752	004537	020250			JSR	R5, SORT2 ;SORT THE USTAB IN ASCENDING FORM
015756	003434				USTAB+8.	;TABLE ENTRY POINT
015760	004737	020410			JSR	PC, SETBSF ;SETUP THE BUFFER FOR THE BAD SECTOR FILE
015764	112737	000020	005541		MOVB	#20, FMTDPB+1 ;16 BIT MODE
015772	112737	000143	005542		MOVB	#SETFMT, FMTDPB+2 ;SET FORMAT COMMAND
016000	004037	031214		2\$:	JSR	R0, RM05 ;CALL THE DRIVER
016004	005540				FMTDPB	
016006	000774				BR	2\$;LOOP IF QUEQU FAILS
016010	005737	005556		3\$:	TST	FMTDPB+16 ;ALL DONE ?
016014	001775				BEQ	3\$;BR IF NOT
016016	012737	001466	005552		MOV	#822., FMTDPB+12 ;CYLINDER ADDRESS
016024	113737	001324	005551		MOVB	LSTRK, FMTDPB+11 ;TRACK NUMBER
016032	105037	005550			CLRB	FMTDPB+10 ;SECTOR 0
016036	012737	157700	005544		MOV	#-<258.*32.>, FMTDPB+4 ;WORD COUNT
016044	012737	046234	005546		MOV	#BUFP, FMTDPB+6 ;BUFFER ADDRESS
016052	112737	000163	005542		MOVB	#WRTHD, FMTDPB+2 ;WRITE HEAD AND DATA COMMAND
016060	004037	031214		4\$:	JSR	R0, RM05 ;CALL THE DRIVER
016064	005540				FMTDPB	
016066	000774				BR	4\$;LOOP IF QUEUE FAILS
016070	005737	005556		5\$:	TST	FMTDPB+16 ;ALL DONE ?
016074	001775				BEQ	5\$;BR IF NOT
016076	100060				BPL	8\$;EXIT IF NO ERROR
016100	012737	016126	001176		MOV	#6\$, \$ESCAPE ;ERROR ESCAPE ADDRESS
016106	004737	016550			JSR	PC, ERINDX ;ERROR INDICATOR RT.
016112	104010				EMT	10 ;DRIVE OFFLINE
016114	104011				EMT	11 ;PERSISTENT DRIVE UNSAFE ERROR
016116	104012				EMT	12 ;UNCORRECTABLE MASSBUS PARITY ERROR
016120	104013				EMT	13 ;SOFTWARE TIMEOUT
016122	104014				EMT	14 ;DRIVE UNSAFE ERROR
016124	104015				EMT	15 ;DRIVE/CONTROLLER ERROR DURING WRITE
016126	005237	001342		6\$:	INC	RETRY ;INCREMENT RETRY COUNT
016132	022737	000003	001342		CMP	#3, RETRY ;OVER 3 TIMES ?
016140	101347				BHI	4\$;BR IF IT IS
016142	000137	016464			JMP	REJCT3 ;UNABLE TO WRITE THE BAD SECTOR TRACK
016146	122737	000037	005550		CMPB	#31., FMTDPB+10 ;LAST SECTOR ?
016154	003431				BLE	8\$;BR IF ALL SET
016156	113737	005566	001344		MOVB	RM.REG+RMDA, BADSEC ;FOUND THE BAD SECTOR
016164	001003				BNE	7\$;BR IF NOT 0
016166	012737	000037	001344		MOV	#31., BADSEC ;THE LAST SECTOR IS A BAD SECTOR
016174	113737	001344	005550	7\$:	MOVB	BADSEC, FMTDPB+10 ;LOAD THE NEW STARTING SECTOR

016202	113701	001344		MOVB	BADSEC,R1	:LOAD THE WORD CTR AND BUFFER
016206	006301			ASL	R1	:WORD INDEX
016210	016137	006064	005544	MOV	ADRTBL(R1),FMTDPB+6	:BUFFER ADDRESS
016216	012737	157700	005544	MOV	#-<258.*32.>,FMTDPB+4	:WORD COUNT
016224	066137	006164	005544	ADD	WCTBL(R1),FMTDPB+4	:WORD COUNT
016232	005037	001342		CLR	RETRY	:RESET THE RETRY FLAG
016236	000710			BR	4\$:BR BACK
016240	104401	037427		8\$: TYPE	,MSCMPT	:TYPE 'COMPLETED'
016244	005737	001126		TST	\$ERTTL	:ANY ERRORS DETECTED ?
016250	001405			BEQ	9\$:BR IF NO
016252	104401	037442		TYPE	,NUMERR	:TOTAL ERRORS
016256	013746	001126		MOV	\$ERTTL,-(SP)	:SAVE \$ERTTL FOR TYPEOUT
016262	104405			TYPDS		:GO TYPE--DECIMAL ASCII WITH SIGN
016264	005037	001126		9\$: CLR	\$ERTTL	:CLEAR THE ERROR ACCUMULATOR
016270	005037	001406		CLR	UPDBSF	:DON'T ALLOW UPDATE OF 'BSF' AT END OF PASS
016274	104401	042423		TYPE	,STARS	:TYPE '*****'
016300	005737	001400		TS,	DEVMP	:ALL ASSIGNED DEVICE DONE ?
016304	001030			BNE	DONE	:TO FORMAT NEXT DRIVE
016306	013737	001402	001400	MOV	DEVMP+2,DEVMP	:RESTORE DEVICE MAP FOR AUTO MODE
016314	005237	001216		INC	\$PASS	:INCREMENT THE PASS NUMBER
016320	042737	100000	001216	BIC	#100000,\$PASS	:DON'T ALLOW A NEG. NUMBER
016326	005327			DEC	(PC)+	:LOOP?
016330	000001			\$EOPCT:	.WORD 1	
016332	003013			BGT	\$DOAGN	:YES
016334	012737			MOV	(PC)+,@(PC)+	:RESTORE COUNTER
016336	000001			\$ENDCT:	.WORD 1	
016340	016330			\$EOPCT		
016342	013700	000042		\$GET42:	MOV @#42,R0	:GET MONITOR ADDRESS
016346	001405			BEQ	\$DOAGN	:BRANCH IF NO MONITOR
016350	000005			RESET		:CLEAR THE WORLD
016352	004710			\$ENDAD:	JSR PC,(R0)	:GO TO MONITOR
016354	000240			NOP		:SAVE ROOM
016356	000240			NOP		:FOR
016360	000240			NOP		:ACT11
016362				\$DOAGN:		
016362	000137			JMP	@(PC)+	:RETURN
016364	016366			\$RTNAD:	.WORD DONE	
2						
3	016366	105737	001150	DONE:	TSTB \$AUTOB	:RUNNING IN AUTO MODE ?
4	016372	001406		BEQ	1\$:BR IF NO
5	016374	004737	017360	JSR	PC,ST,CLK	:START THE CLOCK
6	016400	004737	024414	JSR	PC,\$TKINT	:INITIALIZE THE KEYBOARD
7	016404	000137	010446	JMP	ST1	:RETURN TO AUTO MODE START
8						
9	016410	032777	000001	1\$: BIT	#SW0,@SWR	:IS SW00=1 (SET) ?
10	016416	001002		BNE	2\$:BR IF YES
11	016420	000137	011124	JMP	ASK2	:ASK FOR NEXT DRIVE
12	016424	000137	013056	2\$: JMP	ST3	:GO--LOOP ON SELECTED DRIVE

.SBTTL REJECT MESSAGE TABLE

3	016430	104401	001205	REJECT1: TYPE	,\$CRLF	:CR-LF
4	016434	104401	037704	TYPE	,\$MSG4	:TYPE 'DISK IS AN ALIGNMENT PACK'
5	016440	000435		BR	REJEND	
6						
7	016442	104401	001205	REJECT2: TYPE	,\$CRLF	:CR-LF
8	016446	012737	016534 001176	MOV	#REJEND,\$ESCAPE	::ESCAPE TO REJEND ON ERROR
9	016454	113737	005551 001364	MOV	FMTDPB+11,DS.TRK	:TRACK NUMBER FOR ERROR LOG
10	016462	104025		EMT	25	:REPORT ILLEGAL BAD SECTOR
11						
12	016464	104401	001205	REJECT3: TYPE	,\$CRLF	:CR-LF
13	016470	104401	041563	TYPE	,\$MSG17	:TYPE 'UNABLE TO WRITE BAD SECTOR FILE TRACK'
14	016474	000417		BR	REJEND	
15						
16	016476	104401	001205	REJECT4: TYPE	,\$CRLF	:CR-LF
17	016502	104401	041630	TYPE	,\$MSG18	:TYPE 'FATAL ERROR DETECTED'
18	016506	000412		BR	REJEND	
19						
20	016510	104401	001205	REJECT5: TYPE	,\$CRLF	:CR-LF
21	016514	104401	041665	TYPE	,\$MSG19	:TYPE 'FAILURE DURING HEADER VERIFY'
22	016520	000405		BR	REJEND	
23						
24	016522	104401	001205	REJECT6: TYPE	,\$CRLF	:CR-LF
25	016526	104401	037643	TYPE	,\$MSG3	:TYPE 'OVER 126. BAD SECTORS DETECTED'
26	016532	000400		BR	REJEND	
27						
28	016534	005037	001406	REJEND: CLR	UPDBSF	:DON'T ALLOW BSF UPDATE AT END OF PASS
29	016540	104401	042226	TYPE	,\$ABORT	:TYPE 'OPERATION ABORTED'
30	016544	000137	015740	JMP	,\$EOP	:EXIT
31						

```

1      .SBTTL  SUPPORT SUBROUTINES
2
3      ;THIS ROUTINE DETERMINES THE ERROR TYPE
4
5      016550 010046      ERINDX: MOV    R0,-(SP)      ;SAVE R0
6      016552 010146      MOV    R1,-(SP)      ;SAVE R1
7      016554 005001      CLR     R1            ;CLEAR R1
8      016556 012700 005556 MOV    #FMTDPB+16,R0    ;GET DRIVER STATUS WORD
9      016562 032710      BIT     (PC)+,(R0)      ;CHECK ERROR TYPE
10     016564 060006      .WORD   BIT14:BIT13:BIT2:BIT1 ;DRIVE OFFLINE
11     016566 001021      BNE     5$            ;BR IF OFFLINE
12     016570 032710      BIT     (PC)+,(R0)      ;CHECK ERROR TYPE
13     016572 010000      .WORD   BIT12          ;DRIVE PERSISTENTLY UNSAFE
14     016574 001015      BNE     4$            ;BR IF UNSAFE
15     016576 032710      BIT     (PC)+,(R0)      ;CHECK ERROR TYPE
16     016600 006000      .WORD   BIT11:BIT10      ;UNCORRECTABLE MASSBUS PARITY ERROR ?
17     016602 001011      BNE     3$            ;BR IF PARITY ERROR
18     016604 032710      BIT     (PC)+,(R0)      ;CHECK ERROR TYPE
19     016606 001400      .WORD   BIT09:BIT08      ;SOFTWARE TIMEOUT ?
20     016610 001005      BNE     2$            ;BR IF YES
21     016612 032710      BIT     (PC)+,(R0)      ;CHECK ERROR TYPE
22     016614 000020      .WORD   BIT04          ;DRIVE UNSAFE ERROR ?
23     016616 001001      BNE     1$            ;BR IF YES
24     016620 005201      INC     R1            ;INDEX=12, ERROR='USER DEFINED'
25     016622 005201      1$: INC     R1            ;INDEX=10, ERROR=14
26     016624 005201      2$: INC     R1            ;INDEX= 6, ERROR=13
27     016626 005201      3$: INC     R1            ;INDEX= 4, ERROR=12
28     016630 005201      4$: INC     R1            ;INDEX= 2, ERROR=11
29     016632 006301      5$: ASL     R1            ;INDEX= 0, ERROR=10
30     016634 060166 000004 ADD     R1,4(SP)      ;DEVELOP THE RETURN ADDRESS
31     016640 012601      MOV     (SP)+,R1      ;RESTORE R1
32     016642 012600      MOV     (SP)+,R0      ;RESTORE R0
33     016644 000207      RTS      PC            ;RETURN
34
35     ;ROUTINE TO CHECK FOR LOOP ON ERROR
36
37     016646 032777 001000 162300 LOP.CK: BIT     #SW09,@SWR      ;LOOP ON ERROR ?
38     016654 001402      BEQ     1$            ;BR IF NOT
39     016656 000177 162242      JMP     @SLPERR      ;GO TO THE LOOP ON ERROR ADDRESS
40
41     016662 005037 001176      1$: CLR     $ESCAPE      ;CLEAR THE ERROR FSCAPE ADDRESS
42     016666 033727 005556      BIT     FMTDPB+16,(PC)+ ;CHECK FOR 'FATA' ERROR
43     016672 072002      .WORD   BIT14:BIT13:BIT12:BIT10:BIT01 ;'FATAL' ERROR BITS
44     016674 001004      BNE     2$            ;BR IF YES
45     016676 032737 004000 005574 BIT     #WLE,RM.REG+RMER1 ;WRITE LOCK ERROR ?
46     016704 001402      BEQ     3$            ;BR IF NOT
47     016706 000137 016476      2$: JMP     REJCT4      ;TERMINATE THE FORMAT
48
49     016712 000207      3$: RTS      PC            ;RETURN
50
51     ;THIS ROUTINE SETS UP THE INPUT TABLE FOR THE DRIVER ROUTINE
52
53     016714 113737 001222 005540 SETDPB: MOVB    DRIVE,FMTDPB      ;SET UP DRIVE #
54     016722 105037 005543      CLRB    FMTDPB+3      ;CLEAR HIGH ORDER ADRS BITS
55     016726 013737 001352 005544      MOV     MWC,FMTDPB+4      ;LOAD UP WORD COUNT
56     016734 012737 046234 005546      MOV     #BUFP,FMTDPB+6      ;LOAD UP CURRENT ADRS
57     016742 105037 005550      CLRB    FMTDPB+10      ;SET SECTOR TO ZERO

```

```
58 016746 113737 001334 005551      MOVB   MINTRK,FMTDPB+11  ;SET UP STARTING TRK ADRS
59 016754 013737 001330 005552      MOV     MINCYL,FMTDPB+12  ;SET UP STARTING CYL
60 016762 005037 005556      CLR      FMTDPB+16      ;CLEAR RM STATUS
61 016766 000207      RTS       PC          ;RETURN FROM SETUP
62
63      ;THIS ROUTINE CONTROLS THE DISK ADDRESSING AND TOTAL TRK COUNT
64      ;IT IS ENTERED AFTER EVERY TRK OPERATION
65
66 016770      TRKTST:
67 016770 105237 005551      INCB     FMTDPB+11      ;INCREMENT TRACK NUMBER
68 016774 123737 005551 001332      CMPB     FMTDPB+11,MAXTRK  ;LAST TRACK TO BE FORMATTED ON THIS CYLINDER ?
69 017002 101003      BHI         1$              ;BR IF YES
70 017004 04737 017320      JSR      PC,UPDTRK      ;UPDATE TRACK ADDRESS IN BUFFER
71 017110 000125      BR         4$              ;EXIT
72
73 017012 113737 001334 005551 1$:    MOVB   MINTRK,FMTDPB+11      ;GET STARTING TRACK ADDRESS
74 017020 005737 001376      TST      WRAP              ;SEEKING FROM HI TO LO CYLINDER ?
75 017024 001407      BEQ         2$              ;BR IF NO
76 017026 005337 005552      DEC      FMTDPB+12      ;DECREMENT CYLINDER ADDRESS
77 017032 023737 005552 001326      CMP      FMTDPB+12,MAXCYL  ;DONE WITH FORMATTING ?
78 017040 002413      BLT         5$              ;BR IF YES
79 017042 000406      BR         3$              ;
80 017044 005237 005552      INC      FMTDPB+12      ;INCREMENT CYLINDER ADDRESS
81 017050 023737 005552 001326      CMP      FMTDPB+12,MAXCYL  ;DONE WITH FORMATTING ?
82 017056 101004      BHI         5$              ;BR IF YES
83 017060 004737 017206      JSR      PC,UPDCYL      ;UPDATE CYLINDER ADDRESS IN BUFFER
84
85 017064 062716 000002      4$:    ADD      #2,(SP)      ;ADD TWO TO RETURN ADRS (NOT DONE)
86 017070 000207      5$:    RTS       PC          ;RETURN, DONE FORMAT !!
87
88      ;THIS ROUTINE SETS UP WC & BA FOR REMAINING SECTORS
89      ;AFTER A WRITE CHECK ERROR
90
91 017072 013737 001346 005544      SCAWC:  MOV     SAVWC,FMTDPB+4  ;SET UP WC FOR REMAINING SECTORS
92 017100 062737 001004 005546      ADD      #516,FMTDPB+6  ;SET UP BA FOR REMAINING SECTORS
93 017106 005237 005550      INC      FMTDPB+10      ;ADVANCE TO NEXT SECTOR IN TBL
94 017112 005037 001316      CLR      SOFSW          ;RESET RETRY COUNTER
95 017116 000207      RTS       PC          ;RETURN TO COMPLETE TRK FORMAT
96
97
98      ;THIS ROUTINE SETS UP THE CYLINDER ADRS, FORMAT BIT, TRACK AND
99      ;SECTOR ADRS IN MEMORY WITH THE STARTING CYL - TRK INFORMATION
100
101 017120 013701 001360      SETHDR:  MOV     MAXSEC,R1      ;SET UP SECTOR COUNT
102 017124 012737 000001 001214      MOV     #1,$TESTN      ;GARBAGE CODE FOR APT
103 017132 012700 046234      MOV     #BUFP,R0      ;SET UP HEADER POINTER IN R0
104 017136 013702 001330      MOV     MINCYL,R2      ;PUT STARTING CYL # IN R2
105 017142 052702 140000      BIS      #MFG!USR,R2      ;SET MFG AND USR GOOD BITS (DEC STANDARD 144)
106 017146 013703 001334      MOV     MINTRK,R3      ;PUT STARTING TRK # IN R3
107 017152 000303      SWAB      R3              ;JUSTIFY TRACK ADRS
108 017154 005737 001356      TST      SEC30          ;SEE IF 30 OR 32 SECTOR MODE
109 017160 001402      BEQ         1$              ;BR IF 30 SECTOR MODE
110 017162 052702 010000      BIS      #FMT,R2      ;SET THE 32 SECTOR FORMAT BIT
111 017166 010220      1$:    MOV     R2,(R0)+      ;WRITE IN HEADER AREA OF CORE THE CYL ADRS
112 017170 010320      MOV     R3,(R0)+      ;WRITE IN HEADER AREA OF CORE THE TRK ADRS
113 017172 062700 001000      ADD      #512,R0      ;SET UP FOR NEXT HEADER
114 017176 005203      INC      R3              ;UPDATE SECTOR ADRS FOR NEXT HEADER
```

```

115 017200 005301          DEC      R1          ;MAINTAIN COUNT OF SECTORS
116 017202 002371          BGE      1$          ;BR IF NOT LAST SECTOR
117 017204 000207          RTS      PC          ;EXIT - HEADERS ARE LOADED INTO CORE
118
119          ;THIS ROUTINE UPDATES THE CYLINDER ADRS OF THE HEADER WORDS
120          ;AND FILLS DATA BUFFER FIELD IN CORE
121
122 017206          UPDCYL:
123 017206 010046          MOV      R0,-(SP)      ;;PUSH R0 ON STACK
124 017210 010146          MOV      R1,-(SP)      ;;PUSH R1 ON STACK
125 017212 010246          MOV      R2,-(SP)      ;;PUSH R2 ON STACK
126 017214 010346          MOV      R3,-(SP)      ;;PUSH R3 ON STACK
127 017216 013701 001360    MOV      MAXSEC,R1    ;SET UP SECTOR COUNT
128 017222 012700 046234    MOV      #BUFP,R0    ;SET UP HEADER POINTER IN R0
129 017226 013703 001334    MOV      MINTRK,R3    ;GET STARTING TRACK
130 017232 000303          SWAB      R3          ;STARTING SECTOR - 0
131 017234 005737 001376    1$:      TST      WRAP    ;SEEKING FROM HI TO LO CYLINDERS ?
132 017240 001402          BEQ      2$          ;BR IF NO
133 017242 162710 000002    SUB      #2,(R0)      ;DECREMENT CYLINDER NUMBER
134 017246 005220          2$:      INC      (R0)+    ;INCREMENT FOR NEXT CYLINDER
135 017250 010320          MOV      R3,(R0)+      ;WRITE TRACK AND SECTOR HEADER
136 017252 012702 001000    MOV      #512,R2      ;DATA FIELD LENGTH
137 017256 013720 001336    3$:      MOV      PATA,(R0)+    ;FILL BUFFER
138 017262 013720 001340    MOV      PATB,(R0)+    ;FILL BUFFER
139 017266 162702 000004    SUB      #4,R2        ;END OF DATA FIELD ?
140 017272 001371          BNE      3$          ;NO
141 017274 005203          INC      R3          ;INCREMENT TO NEXT SECTOR
142 017276 005301          DEC      R1          ;COUNT SECTORS
143 017300 002355          BGE      1$          ;BR IF NOT LAST SECTOR
144 017302 012603          MOV      (SP)+,R3      ;;POP STACK INTO R3
145 017304 012602          MOV      (SP)+,R2      ;;POP STACK INTO R2
146 017306 012600          MOV      (SP)+,R1      ;;POP STACK INTO R1
147 017310 012600          MOV      (SP)+,R0      ;;POP STACK INTO R0
148 017312 005237 001214    INC      $TESTN      ;INCREMENT TST NUMBER FOR EACH CYLINDER CHANGE
149
150 017316 000207          RTS      PC          ;GARBAGE CODE FOR APT
151
152          ;THIS ROUTINE UPDATES THE TRACK ADRS OF THE HEADER WORDS IN CORE
153
154 017320          UPDTRK:
155 017320 010046          MOV      R0,-(SP)      ;;PLSH R0 ON STACK
156 017322 010146          MOV      R1,-(SP)      ;;PUSH R1 ON STACK
157 017324 013701 001360    MOV      MAXSEC,R1    ;SET UP SECTOR COUNT
158 017330 012700 046234    MOV      #BUFP,R0    ;SET UP HEADER POINTER IN R0
159 017334 005720          TST      (R0)+          ;POINT HEADER POINTER TO TRK - SEC ADRS
160 017336 062710 000400    1$:      ADD      #400,(R0)    ;INDEX TRK ADRS
161 017342 062700 001004    ADD      #516,R0      ;SET UP FOR NEXT HEADER
162 017346 005301          DEC      R1          ;COUNT SECTORS
163 017350 002372          BGE      1$          ;BR IF NOT LAST SECTOR
164 017352 012601          MOV      (SP)+,R1      ;;POP STACK INTO R1
165 017354 012600          MOV      (SP)+,R0      ;;POP STACK INTO R0
166 017356 000207          RTS      PC          ;EXIT
167
168          ;ROUTINE TO CHECK FOR KW11-L OR KW11-P CLOCKS
169
170 017360 012737 017436 000004 ST.CLK: MOV      #STCLK1,@#ERRVEC ;SET UP VECTOR FOR P CLK
171 017366 005037 000006    CLR      @#ERRVEC+2 ;NEW PSW

```

```

162 017372 005777 161702      TST      @CLKCSR      ;CHECK FOR KW11-P
163 017376 013746 001304      MOV      $LPVEC,-(SP) ;VECTOR ADDRESS
164 017402 012776 017616 000000 MOV      #CLOCK,@(SP) ;SET UP KW11-P VECTOR
165 017410 062716 000002      ADD      #2,(SP) ;POINT TO PSW
166 017414 012736 000300      MOV      #PR6,@(SP)+ ;PSW - PRI 6
167 017420 012777 177777 161654 MOV      #-1,@CLKCSB ;LOAD COUNTER BUFFER
168 017426 012777 000135 161644 MOV      #135,@CLKCSR ;SET CLK - CNT UP
169 017434 000426          BR      STCLK3
170 017436 062706 000004      STCLK1: ADD     #4,SP ;RESTORE THE STACK POINTER
171 017442 012737 017506 000004 MOV      #STCLK2,@#ERRVEC ;CHANGE ERROR VECTOR
172 017450 005777 161634      TST      @CLKS ;LOOK FOR KW11-L
173 017454 013746 001312      MOV      $LLVEC,-(SP) ;KW11-L VECTOR ADDRESS
174 017460 012776 017616 000000 MOV      #CLOCK,@(SP) ;SET UP KW11-L VECTOR
175 017466 062716 000002      ADD      #2,(SP) ;INCREMENT VECTOR ADDRESS
176 017472 012736 000300      MOV      #PR6,@(SP)+ ;PSW - PRI 6
177 017476 012777 000100 161604 MOV      #100,@CLKS ;SET KW11-L INTERRUPT ENABLE
178 017504 000402          BR      STCLK3
179 017506 062706 000004      STCLK2: ADD     #4,SP ;RESTORE THE STACK POINTER
180 017512 012737 000006 000004 STCLK3: MOV      #6,@#ERRVEC ;RESTORE THE ERROR VECTOR
181 017520 000207          RTS      PC
182
183          ;THIS CODE PRINT THE ABORT MESSAGE AND LET O.P. RESTART
184
185 017522 104401 037572      RESTRT: TYPE     ,MSG2 ;TYPE 'IMPROPER MFG INFORMATION'
186 017526 105737 001150      TSTB     $AUTOB ;RUN UNDER APT ?
187 017532 001000          BNE      1$ ;BR IF SO
188 017534 004737 024414      1$: JSR      PC,$TKINT ;ENABLE TO READ
189 017540 104401 042033      TYPE     ,MSINIT ;TYPE 'INITIALIZE BAD SECTOR FILE (L) N ?'
190 017544 104411          RDLIN ;READ THE ENTRY
191 017546 012600          MOV      (SP)+,R0 ;SAVE ADDRESS OF RESPONSE
192 017550 105710          TSTB     (R0) ;WAS RESPONSE A CARRIAGE RETURN (DEFAULT 'N')
193 017552 001414          BEQ      3$ ;BR IF YES
194 017554 105760 000001      TSTB     1(R0) ;WAS IT TERMINATED WITH CARRIAGE RETURN ?
195 017560 001006          BNE      2$ ;BR IF NO
196 017562 122710 000131      CMPB     #'Y',(R0) ;WAS IT A 'Y' RESPONSE ?
197 017566 001412          BEQ      4$ ;BR IF YES
198 017570 122710 000116      CMPB     #'N',(R0) ;WAS IT A 'N' RESPONSE ?
199 017574 001403          BEQ      3$ ;BR IF YES
200 017576 104401 037174      2$: TYPE     ,BADENT ;TYPE BAD ENTRY MESSAGE
201 017602 000754          BR      1$ ;TRY AGAIN
202 017604 104401 001205      3$: TYPE     ,$CRLF ;CR-LF
203 017610 000137 016534      JMP      REJEND ;JUMP TO REJECT END
204 017614 000207          4$: RTS      PC ;EXIT
205
206          ;THIS CODE SERVICES A CLOCK INTERRUPT EVERY 16MS
207
208 017616 012746 000020      CLOCK: MOV      #16,-(SP) ;PUT MILLISECONDS ON THE STACK
209 017622 004737 034476      JSR      PC,RMTMR ;GO REPORT TIME
210 017626 000002          RTI ;RETURN AND CONTINUE
211
212          ;ROUTINE TO INTERCEPT 'CONTROL C'
213
214 017630 005737 030400      C.ENTR: TST      TRNSWT ;ALL ACTIVITY STOPPED ?
215 017634 001375          BNE      C.ENTR ;BR IF NOT
216 017636 000137 007034      JMP      TST1 ;START PROGRAM AT BEGINNING
217
218          ;ROUTINE TO INTERCEPT 'CONTROL O' TYPED WHILE PROGRAM IS FORMATTING

```

```

210
221
222
223
224
225 017642 117746 161314
226 017646 042716 177600
227 017652 021627 000003
228 017656 001014
229 017660 104401 025621
230 017664 005726
231 017666 105737 001150
232 017672 001404
233 017674 005037 001400
234 017700 005037 001402
235 017704 000137 016534
236
237 017710 022627 000017
238 017714 001406
239 017716 005777 161240
240 017722 012777 000100 161230
241 017730 000002
242 017732
243
244 017732 005037 177776
245 017736 012737 017630 001372
246 017744 104401 037506
247 017750 104401 036613
248 017754 013746 005552
249 017760 004737 027100
250 017764 004737 026670
251 017770 104401 036621
252 017774 104401 036615
253 020000 005046
254 020002 113716 005551
255 020006 004737 027100
256 020012 004737 026670
257 020016 104401 001205
258 020022 012737 017642 000060
259 020030 000002
260
261
262
263
264
265
266
267 020032 010346
268 020034 011403
269 020036 012337 020046
270 020042 001435
271 020044 104401
272 020046 000000
273 020050 012302
274 020052 012305
275 020054 011546

;THE DISK PACK. THE CURRENT DISK ADDRESS IS TYPED TO THE TERMINAL
;DURING THIS ROUTINE IN THE FOLLOWING FORMAT.
;PRESENT ADDRESS IS: CXXX TXXX ;WHERE 'C' IS THE CYLINDER ADDRESS
;AND 'T' IS THE TRACK ADDRESS.(IN DECIMAL)

O.ENTR: MOVB @STKB,-(SP) ;READ FROM TTY BUFFER
        BIC #^C177,(SP) ;STRIP PARITY
        CMP (SP),#3 ;CONTROL-C ?
        BNE 2$ ;BR IF NO
        TYPE ,SCNTLC ;TYPE A CONTROL-C (^C)
        TST (SP)+ ;RESTORE STACK
        TSTB $AUTOB ;RUNNING IN AUTO MODE ?
        BEQ 1$ ;BR IF NO
        CLR DEVMP ;CLEAR DEVICE MAPS
        CLR DEVMP+2
        JMP REJEND ;JUMP TO CONTROL C REJECT

1$:
2$: CMP (SP)+,#17 ;CONTROL-O ?
        BEQ 3$ ;YES
        TST @STKB ;CLEAR DONE BIT
        MOV #100,@STKS ;ENABLE TTY INTERRUPT
        RTI
3$:

TYPADR: CLR PS ;SET PROCESSOR TO PRIORITY 0
        MOV #C.ENTR,CNTLC ;CHANGE 'CONTROL C' RETURN ADDRESS
        TYPE ,ADDRIS ;'PRESENT ADDRESS IS: '
        TYPE ,C ;'C'
        MOV FMTDPB+12,-(SP) ;PUT THE CYLINDER ADDRESS ON THE STACK
        JSR PC,$SB2D ;CONVERT IT TO DECIMAL
        JSR PC,$SUPRL ;TYPE DECIMAL NUMBER, LEFT JUSTIFY
        TYPE ,BLNKS2 ;TYPE 2 SPACES
        TYPE ,T ;'T'
        CLR -(SP) ;CLEAR THE STACK
        MOV FMTDPB+11,(SP) ;PUT THE TRACK ADDRESS ON THE STACK
        JSR PC,$SB2D ;CONVERT IT TO DECIMAL
        JSR PC,$SUPRL ;TYPE DECIMAL NUMBER, LEFT JUSTIFY
        TYPE ,SCRLF ;CR-LF
        MOV #O.ENTR,@TKVEC ;RESTORE ENTRANCE FOR CONTROL-O
        RTI ;RETURN

;PARAMETER ENTRY ROUTINE
;CALL
;JSR R4,PARENT ;THE CALLING SEQ
;TABLE ;PARAMETERS TABLE
;

PARENT: MOV R3,-(SP) ;SAVE R3
        MOV (R4),R3 ;PARAMETER TABLE ADDRESS
1$: MOV (R3)+,2$ ;ADDRESS OF PARAMETER NAME
        BEQ 7$ ;BR IF AT END OF TABLE
        TYPE ;TYPE THE PARAMETER NAME
2$: .WORD 0 ;ADDRESS OF PARAMETER NAME TEXT
        MOV (R3)+,R2 ;MAXIMUM PARAMETER VALUE
        MOV (R3)+,R5 ;ADDRESS OF PARAMETER
        MOV (R5),-(SP) ;CURRENT VALUE OF PARAMETER

```

```

276 020056 104405          TYPDS          :TYPE THE CURRENT VALUE OF THE PARAMETER
277 020060 104401 036607  TYPE          : /
278 020064 104411          RDLIN          :READ THE KEYBOARD
279 020066 012601          MOV           (SP)+,R1 :INPUT ASCII STRING ADDRESS
280 020070 004537 023172  JSR           R5,CK.DIG :CHECK THE DIGIT(S)
      020074 020036          1$           :CARRIAGE RETURN ONLY ENTERED
      020076 020136          7$           :PERIOD ONLY ENTERED
      020100 020114          4$           :ILLEGAL INPUT
      020102 020110          3$           :TERMINATED WITH A CARRIAGE RETURN
      020104 020114          4$           :TERMINATED WITH A '...'
      020106 020126          5$           :TERMINATED WITH A '...'
281 020110 010215          3$: MOV       R2,(R5) :MOVE NEW VALUE TO PARAMETER LOCATION
282 020112 000751          BR           1$       :GET MORE PARAMETERS
283 020114 104401 037174  4$: TYPE       ,BADENT :'BAD ENTRY'
284 020120 162703 000006  SUB           #6,R3    :DECREMENT THE TABLE POINTER
285 020124 000744          BR           1$       :TRY AGAIN
286 020126 010215          5$: MOV       R2,(R5) :NEW VALUE
287 020130 000402          BR           7$       :EXIT
288          6$: MOV       #TABLE,R3           :RELOAD THE PARAMETER TABLE ADDRESS
289 020132 011403          6$: MOV       (R4),R3 :RELOAD THE PARAMETER TABLE ADDRESS
290 020134 000740          BR           1$       :TRY AGAIN
291 020136 012603          7$: MOV       (SP)+,R3 :RESTORE R3
292 020140 062704 000002  ADD           #2,R4    ;ADJUST THE RETURN ADDRESS
293 020144 000204          RTS           R4      :RETURN FROM THE R4
294
295          :THIS ROUTINE LOADS THE BAD SECTOR INTO 'USTAB' TABLE
296          :CALL
297          :      JSR PC,RECORD
298          :
299          :ALL REGISTER USED ARE DESTORIED
300
301 020146 012701 003434  RECCRD: MOV       #USTAB+8.,R1 :TABLE ENTRY IN R1
302 020152 022711 177777  1$: CMP       #-1,(R1) :AN OPENING IN THE TABLE
303 020156 001421          BEQ           3$       :BR IF IT IS
304 020160 023711 005552  CMP       FMTDPB+12,(R1) :CYLINDER NUMBER MATCHES ?
305 020164 001010          BNE           2$       :BR IF NOT
306 020166 123761 005551 000003  CMPB    FMTDPB+11,3(R1) :TRK NUMBER MATCHES ?
307 020174 001004          BNE           2$       :BR IF NOT
308 020176 123761 005550 000002  CMPB    FMTDPB+10,2(R1) :SECTOR NUMBER MATCHES ?
309 020204 001416          BEQ           4$       :BR TO EXIT, IF THE SPOT HAS RECORDED
310 020206 062701 000004          2$: ADD       #4,R1 :INCREMENT 4 BYTES
311 020212 022701 004424          CMP       #USTAB+512.,R1 :END OF TABLE ?
312 020216 101355          BHI           1$       :BR IF NOT
313 020220 000411          BR           5$       :THROW AWAY THE PACK
314 020222 013711 005552          3$: MOV       FMTDPB+12,(R1) :LOAD THE CYLINDER #
315 020226 113761 005551 000003  MOVB    FMTDPB+11,3(R1) :LOAD THE TRK NUMBER
316 020234 113761 001344 000002  MOVB    BADSEC,2(R1) :LOAD THE SECTOR NUMBER
317 020242 000207          4$: RTS           PC   :EXIT
318 020244 000137 016522          5$: JMP       REJECT6 :JUMP TO REJECT TOO MANY BAD SECTORS
319
320          :THIS ROUTINE WILL SORT A BAD SECTOR TABLE IN ASCENDING ORDER
321          :CALL
322          :      JSR       R5,SORT2
323          :      TABLE+8. :ADDRESS OF TABLE TO BE SORTED
324
325 020250 011501          SORT2: MOV       (R5),R1 :TOP POINTER
326 020252 012702 000175          MOV       #125.,R2 :TOTAL 126 ELEMENTS

```


327	020256	010103			MOV	R1,R3	:LOCATE THE BOTTOM POINTER
328	020260	062703	C0C764		ADD	#500,R3	:254-4) X 2
329	020264	022711	177777		CMP	#-1,(R1)	:THE TABLE IS EMPTY ?
330	020270	001444			BEQ	4\$:QUICK EXIT
331	020272	021161	000004	1\$:	CMP	(R1),4(R1)	:COMPARE THE CYLINDER NUMBER
332	020276	101013			BHI	2\$:SWITCH ELEMENTS
333	020300	103426			BLO	3\$:INCREMENT POINTER
334	020302	126161	000003 000007		CMPB	3(R1),7(R1)	:COMPARE THE TRACK NUMBER
335	020310	101006			BHI	2\$:SWITCH ELEMENTS
336	020312	103421			BLO	3\$:INCREMENT POINTER
337	020314	126161	000002 000006		CMPB	2(R1),6(R1)	:COMPARE THE SECTOR NUMBER
338	020322	101001			BHI	2\$:SWITCH ELEMENTS
339	020324	000414			BR	3\$:INCREMENT POINTER
340	020326	011146		2\$:	MOV	(R1),-(SP)	:SAVE THE CYLINDER NUMBER
341	020330	016146	000002		MOV	2(R1),-(SP)	:SAVE THE TRK/SEC NUMBERS
342	020334	016111	000004		MOV	4(R1),(R1)	:SWITCH THE N+4 BLOCK TO N BLOCK
343	020340	016161	000006 000002		MOV	6(R1),2(R1)	:SWITCH THE N+6 BLOCK TO N+2 BLOCK
344	020346	012661	000006		MOV	(SP)+,6(R1)	:LOAD THE N+6 BLOCK
345	020352	012661	000004		MOV	(SP)+,4(R1)	:LOAD THE N+4 BLOCK
346	020356	062701	000004	7\$:	ADD	#4,R1	:UPDATE THE TOP POINTER
347	020362	020103			CMP	R1,R3	:REACH THE BOTTOM ?
348	020364	001342			BNE	1\$:BR IF NO
349	020366	005302			DEC	R2	:DONE ENTIRE SORT ?
350	020370	001404			BEQ	4\$:BR IF YES
351	020372	162703	000004		SUB	#4,R3	:ADJUST THE BOTTOM POINTER
352	020376	011501			MOV	(R5),R1	:RESET THE TOP POINTER
353	020400	000734			BR	1\$:DO NEXT SORT
354							
355	020402	062705	000002	4\$:	ADD	#2,R5	:ADJUST RETURN ADDRESS
356	020406	000205			RTS	R5	:EXIT
357							

.SBTTL SETUP BAD SECTOR BUFFER

: THIS ROUTINE SETS UP THE BUFFER TO RE-WRITE THE LAST TRACK OF
: CYLINDER 822. (BAD SECTOR FILE)

: SECTORS 0, 2, 4, 6, 8. 16 BIT MFG
: SECTORS 1, 3, 5, 7, 9. 18 BIT MFG
: SECTORS 10, 12, 14, 16,...30. 16 BIT USER
: SECTORS 11, 13, 15, 17,...31. 18 BIT USER

12	020410	012700	046234		SFTBSF: MOV	#BUFP,R0	: BUFFER ADDRESS
13	020414	012701	020100		MOV	#<258.*32.>,R1	: TOTAL WORD COUNT
14	020420	012720	177777		1\$: MOV	#-1,(R0)+	: SET ALL LOCATIONS TO -1
15	020424	005301			DEC	R1	: DONE YET ?
16	020426	001374			BNE	1\$: BR IF NO
17	020430	013746	001214		MOV	\$TESTN,-(SP)	: PUSH \$TESTN ON STACK
	020434	013746	001330		MOV	MINCYL,-(SP)	: PUSH MINCYL ON STACK
	020440	013746	001334		MOV	MINTRK,-(SP)	: PUSH MINTRK ON STACK
	020444	013746	001360		MOV	MAXSEC,-(SP)	: PUSH MAXSEC ON STACK
	020450	013746	001356		MOV	SEC30,-(SP)	: PUSH SEC30 ON STACK
18	020454	012737	000037	001360	MOV	#31,MAXSEC	: SET MAX 31 SECTORS
19	020462	012737	177777	001356	MOV	#-1,SEC30	: ALWAYS IN 16 BIT MODE
20	020470	012737	001466	001330	MOV	#822,MINCYL	: LOAD LAST CYLINDER
21	020476	013737	001324	001334	MOV	LSTRK,MINTRK	: LAST TRACK
22	020504	004737	017120		JSR	PC,SETHDR	: SET HEADER FIELD IN THE BUFFER
23	020510	012637	001356		MOV	(SP)+,SEC30	: POP STACK INTO SEC30
	020514	012637	001360		MOV	(SP)+,MAXSEC	: POP STACK INTO MAXSEC
	020520	012637	001334		MOV	(SP)+,MINTRK	: POP STACK INTO MINTRK
	020524	012637	001330		MOV	(SP)+,MINCYL	: POP STACK INTO MINCYL
	020530	012637	001214		MOV	(SP)+,\$TESTN	: POP STACK INTO \$TESTN
24							
25	020534	012701	001414		MOV	#MFG16,R1	: LOAD FIRST 4 WORDS TO EVERY SECTOR
26	020540	012702	046240		MOV	#BUFP+4,R2	: BUFFER LOCATION + 4
27	020544	012703	000040		MOV	#32,R3	: TOTAL 32 SECTORS
28	020550	011112			2\$: MOV	(R1),(R2)	: STORE 1ST OCTAL WORD (MSB OF S/N)
29	020552	016162	000002	000002	MOV	2(R1),2(R2)	: STORE 2ND OCTAL WORD (LSB OF S/N)
30	020560	005062	000004		CLR	4(R2)	: STORE 3RD WORD ALL 0'S
31	020564	005062	000006		CLR	6(R2)	: STORE 4TH WORD ALL 0'S
32	020570	062702	001004		ADD	#516.,R2	: ADVANCE TO NEXT SECTOR
33	020574	005303			DEC	R3	: DECREMENT ONE SECTOR COUNT
34	020576	001364			BNE	2\$: BR IF NO
35							
36	020600	005046			CLR	-(SP)	: LOAD TABLES INTO APPROPRIATE SECTORS
37	020602	005046			CLR	-(SP)	: DUMMY PAIRS FOR TERMINATORS
38	020604	005046			CLR	-(SP)	
39	020606	012746	001414		MOV	#MFG16,-(SP)	: TABLE ADDRESS
40	020612	012746	046240		MOV	#BUFP+4,-(SP)	: BUFFER ADDRESS
41	020616	012746	000005		MOV	#5,-(SP)	: NUMBER OF SECTORS TO LOAD
42	020622	012746	002420		MOV	#MFG18,-(SP)	: TABLE ADDRESS
43	020626	012746	047244		MOV	#BUFP+4+516.,-(SP)	: BUFFER ADDRESS
44	020632	012746	000005		MOV	#5,-(SP)	: NUMBER OF SECTORS TO LOAD
45	020636	012746	003424		MOV	#USTAB,-(SP)	: TABLE ADDRESS
46	020642	012746	060310		MOV	#BUFP+4+<516.*10.>,-(SP)	: BUFFER ADDRESS
47	020646	005737	001356		TST	SEC30	: IS IT 16 BIT FORMAT MODE ?
48	020652	100402			BM:	3\$: BR IF YES
49	020654	012716	061314		MOV	#BUFP+4+<516.*11.>,(SP)	: MFG 18 BIT BUFFER ADDRESS

```

51 020660 012746 000013 3$: MOV #1, -(SP) ;NUMBER OF SECTORS TO LOAD
52 020664 012701 004430 MOV #USSAV, R1 ;TABLE ADDRESS IN R1
53 020670 012702 061314 MOV #BUF+4+<516.*11>, R2 ;BUFFER ADDRESS IN R2
54 020674 005737 001356 TST SEC30 ;IS IT 16 BIT FORMAT MODE ?
55 020700 100402 4$ BMI 4$ ;BR IF YES
56 020702 012702 060310 MOV #BUF+4+<516.*10>, R2 ;BUFFER ADDRESS FOR 18 BIT MODE
57 020706 012703 000013 4$: MOV #11, R3 ;SECTOR COUNT IN R3
58 020712 010105 MOV R1, R5 ;TEMPORARY STORAGE
59 020714 012704 000400 5$: MOV #256, R4 ;WORD COUNT = DATA FIELD OF ONE SECTOR
60 020720 012122 6$: MOV (R1)+, (R2)+ ;LOAD TABLE INTO SECTOR DATA FIELD
61 020722 005304 DEC R4 ;ALL DONE ?
62 020724 001375 BNE 6$ ;BR IF NOT
63 020726 010501 MOV R5, R1 ;RELOAD THE TABLE ADDRESS
64 020730 062702 001010 ADD #516.+4, R2 ;SKIP ONE SECTOR
65 020734 005303 DEC R3 ;DECREMENT ONE SECTOR COUNT
66 020736 001366 BNE 5$ ;BR IF NOT DONE
67 020740 012603 MOV (SP)+, R3 ;NEXT NUMBER OF SECTORS TO LOAD
68 020742 012602 MOV (SP)+, R2 ;NEXT BUFFER ADDRESS
69 020744 012601 MOV (SP)+, R1 ;NEXT TABLE ADDRESS
70 020746 010105 MOV R1, R5 ;IS IT DUMMY TERMINATOR ?
71 020750 001361 BNE 5$ ;BR IF NO
72 020752 000207 RTS PC ;EXIT
73
74 ;THIS ROUTINE WILL SET OR RESET BIT15 AND BIT14 OF THE FIRST HEADER
75 ;WORD. IF THE HEADER IS FLAGGED AS A 'MFG' BAD SECTOR, BIT15(MF BIT)
76 ;WILL BE RESET(0) AND BIT14(UF BIT) WILL BE SET(1). IF THE HEADER IS
77 ;BEING FLAGGED AS A 'USR' BAD SECTOR, BIT15(MF BIT) WILL BE SET(1)
78 ;AND BIT14(UF BIT) WILL BE RESET(0).
79 ;CALL
80 ; JSR PC, RESET
81
82 020754 013737 005552 046224 RESET: MOV FMTDPB+12, RBUF ;GET CYLINDER ADDRESS.
83 020762 001006 BNE 1$ ;BR IF CYL 0
84 020764 122737 000001 005551 CMPB #1, FMTDPB+11 ;IS THIS CYL 0, TRK 0 OR 1 ?
85 020772 103402 BLO 1$ ;BR IF NO
86 020774 000137 016442 JMP REJCT2 ;OTHERWISE, ILLEGAL BAD SECTORS
87
88 021000 113737 005551 046227 1$: MOVB FMTDPB+11, RBUF+3 ;TRACK ADDRESS
89 021006 113737 001344 046226 MOVB BADSEC, RBUF+2 ;SECTOR ADDRESS
90 021014 053737 001410 046224 BIS HDRBIT, RBUF ;SET MFG BIT, RESET USR BIT
91 021022 113737 001222 005630 MOVB DRIVE, FMTWRT ;SETUP THE DPB FOR OPERATION
92 021030 012737 177776 005634 MOV #2, FMTWRT+4 ;WORD COUNT =2
93 021036 112737 000163 005632 MOVB #WRTHD, FMTWRT+2 ;WRITE HEAD AND DATA COMMAND
94 021044 012737 046224 005636 MOV #RBUF, FMTWRT+6 ;BUFFER ADDRESS
95 021052 113737 001344 005640 MOVB BADSEC, FMTWRT+10 ;SECTOR ADDRESS
96 021060 113737 005551 005641 MOVB FMTDPB+11, FMTWRT+11 ;TRACK ADDRESS
97 021066 013737 005552 005642 MOV FMTDPB+12, FMTWRT+12 ;CYLINDER ADDRESS
98 021074 052737 010000 046224 BIS #FMT, RBUF ;ASSUME 16 BIT MODE
99 021102 023727 005552 001466 CMP FMTDPB+12, #822. ;IS IT LAST CYLINDER ?
100 021110 001004 BNE 2$ ;BR IF NO
101 021112 123737 005551 001324 CMPB FMTDPB+11, LSTRK ;IS IT LAST TRACK (BSF) ?
102 021120 001406 BEQ 3$ ;BR IF YES
103 021122 005737 001356 2$: TST SEC30 ;IN 16 BIT MODE ?
104 021126 100403 BMI 3$ ;BR IF IT IS
105 021130 042737 010000 046224 BIC #FMT, RBUF ;RESET THE FMT BIT

```

107 021136 004037 031214
108 021142 005630
109 021144 000774
110 021146 005737 005646
111 021152 001775
112 021154 000240
113 021156 000207

3\$:

JSR RO,RM05

:CALL THE DRIVER

FMTWRT

:DPB ADDRESS

BR

3\$

:BR IF QUEUE FAILS

4\$:

TST

FMTWRT+16

:DONE ?

BEQ

4\$

:BR IF NOT

NOP

:IGNORE ANY ERRORS

RTS

PC

:EXIT

```

:THE ROUTINE INSERT:
:INSERT A BAD SECTOR ADDRESS INTO ONE OF THE MFG16, MFG18, USTAB AND
:USSAV TABLES
:CALL
:      JSR      R5,INSERT
:      TABLE+8.

8 021160 010446
9 021162 012746 000176
10 021166 011504
11 021170 022714 177777
12 021174 001420
13 021176 023714 001362
14 021202 001010
15 021204 123764 001364 000003
16 021212 001004
17 021214 123764 001344 000002
18 021222 001415
19 021224 005316
20 021226 001413
21 021230 062704 000004
22 021234 000755
23 021236 013714 001362
24 021242 113764 001364 000003
25 021250 113764 001344 000002
26 021256 062706 000002
27 021262 012604
28 021264 062705 000002
29 021270 000205

INSERT: MOV      R4,-(SP)      ;SAVE THE R4
        MOV      #126,-(SP)   ;ENTRIES OF THE TABLE
        MOV      (R5),R4      ;TABLE ADDRESS + 8 BYTES
1$:      CMP      #-1,(R4)     ;AN OPEN ENTRY ?
        BEQ      3$           ;BR IF SO
        CMP      DS.CYL,(R4)  ;CHECK IF THE BAD SECTOR HAS RECORDED
        BNE      2$           ;BR IF NOT
        CMPB     DS.TRK,3(R4) ;CYL AND TRK MATCH ?
        BNE      2$           ;BR IF NOT
        CMPB     BADSEC,2(R4) ;CYL ,TRK AND SEC MATCH ?
        BEQ      4$           ;BR IF SO
2$:      DEC      (SP)         ;DECREMENT THE ENTRY COUNT
        BEQ      4$           ;BR IF EXHAUST
        ADD      #4,R4        ;LOCATE THE NEXT ENTRY
        BR       1$          ;BR BACK
3$:      MOV      DS.CYL,(R4)  ;LOAD INTO TABLE
        MOVB     DS.TRK,3(R4) ;LOAD THE TRACK NUMBER
        MOVB     BADSEC,2(R4) ;LOAD THE SECTOR NUMBER
4$:      ADD      #2,SP        ;CLEAR UP THE STACK
        MOV      (SP)+,R4     ;RESTORE R4
        ADD      #2,R5        ;ASJUST THE RETURN ADDRESS
        RTS      R5          ;EXIT

```

.SBTTL UTILITY FUNCTION ROUTINES

;ROUTINE TO ENTER 'MFG' DEFINED BAD SECTORS IN THE 16 BIT TABLE AND
;THE 18 BIT TABLE

6	021272	005737	001320	FUNCT1:	TST	MODE		;IS IT 'FORMAT' MODE ?
7	021276	001403			BEQ	1\$;BR IF YES
8	021300	104401	042255		TYPE	,NOUPDT		;TYPE 'NO UPDATE OF FILE IN VERIFY MODE'
9	021304	000207			RTS	PC		
10								
11	021306	104401	040564	1\$:	TYPE	,MSG5		;TYPE 'ENTER MFG 16 BIT BAD SECTOR ADDRESS'
12	021312	104401	001205		TYPE	,\$CRLF		;CR-LF
13	021316	004577	022702	2\$:	JSR	R5,MANTER		;ENTER THE VALUE FROM THE KEYBOARD
14	021322	005702			TABLE2			
15								
16	021324	005737	001362		TST	DS.CYL		;WAS A VALUE ENTERED ?
17	021330	100404			BMI	3\$;BR IF NO
18	021332	004537	021160		JSR	R5,INSERT		;INSERT BAD SECTOR INTO THE 'MFG16' TABLE
19	021336	001424			MFG16+8.			
20	021340	000766			BR	2\$;NEXT ENTRY
21	021342	004537	020250	3\$:	JSR	R5, SORT2		;SORT THE TABLE WHEN DONE WITH INPUTS
22	021346	001424			MFG16+8.			
23								
24	021350	104401	040642		TYPE	,MSG6		;TYPE 'ENTER MFG 18 BIT BAD SECTOR ADDRESS'
25	021354	104401	001205		TYPE	,\$CRLF		;CR-LF
26	021360	004537	022702	4\$:	JSR	R5,MANTER		;INPUT VALUES FROM THE KEYBOARD
27	021364	005720			TABLE3			
28								
29	021366	005737	001362		TST	DS.CYL		;UPDATED VALUES ?
30	021372	100404			BMI	5\$;BR IF NOT
31	021374	004537	021160		JSR	R5,INSERT		;INSERT BAD SECTOR INTO THE 'MFG18' TABLE
32	021400	002430			MFG18+8.			
33	021402	000766			BR	4\$;NEXT ENTRY
34	021404	004537	020250	5\$:	JSR	R5, SORT2		;SORT THE TABLE WHEN DONE WITH INPUTS
35	021410	002430			MFG18+8.			
36	021412	000207			RTS	PC		;EXIT
37								
38								
39								
40								
41	021414	005737	001320	FUNCT2:	TST	MODE		;IS IT 'FORMAT' MODE ?
42	021420	001403			BEQ	1\$;BR IF YES
43	021422	104401	042255		TYPE	,NOUPDT		;TYPE 'NO UPDATE OF FILE IN VERIFY MODE'
44	021426	000207			RTS	PC		
45								
46	021430	012737	003434	1\$:	MOV	#USTAB+8.,4\$;SET UP 'USR' TABLES FOR 16 BIT MODE
47	021436	012737	003434		MOV	#USTAB+8.,6\$		
48	021444	012737	004440		MOV	#USSAV+8.,8\$		
49	021452	012737	004440		MOV	#USSAV+8.,10\$		
50	021460	005737	001356		TST	SEC30		;IS IT 18 BIT MODE ?
51	021464	100414			BMI	2\$;BR IS NO
52	021466	012737	003434		MOV	#USTAB+8.,8\$;SET UP 'USR' TABLES FOR 18 BIT MODE
53	021474	012737	003434		MOV	#USTAB+8.,10\$		
54	021502	012737	004440		MOV	#USSAV+8.,4\$		
55	021510	012737	004440		MOV	#USSAV+8.,6\$		
56								
57	021516	104401	040720	2\$:	TYPE	,MSG7		;TYPE 'ENTER USR 16 BIT BAD SECTOR ADDRESS'

```

58 021522 104401 001205
59 021526 004537 022702
60 021532 005702
61
62 021534 005737 001362
63 021540 100404
64 021542 004537 021160
65 021546 000000
66 021550 000766
67 021552 004537 020250
68 021556 000000
69
70 021560 104401 040776
71 021564 104401 001205
72 021570 004537 022702
73 021574 005720
74
75 021576 005737 001362
76 021602 100404
77 021604 004537 021160
78 021610 000000
79 021612 000766
80 021614 004537 020250
81 021620 000000
82 021622 000207
83
84
85
86
87 021624 104401 001205
88 021630 004737 022622
89 021634 104401 001205
90 021640 010146
91 021642 012701 001424
92 021646 104401 041054
93 021652 004737 022512
94
95 021656 104401 041140
96 021662 012701 002430
97 021666 004737 022512
98 021672 012601
99 021674 000207
100
101
102
103
104 021676 104401 001205
105 021702 004737 022622
106 021706 104401 001205
107 021712 010146
108 021714 010246
109 021716 012701 003434
110 021722 012702 004440
111 021726 005737 001356
112 021732 100404
113 021734 012702 003434
114 021740 012701 004440

3$: TYPE ,SCLF ;CR-LF
JSR R5,MANTER ;ENTER BAD SECTOR FROM THE KEYBOARD
TABLE2

TST DS,CYL ;UPDATED INPUT VALUE ?
BMI 5$ ;BR IF NO
JSR R5,INSERT ;INSERT THE BAD SECTOR INTO TABLE
4$: .WORD 0 ;TABLE ADDRESS
BR 3$ ;NEXT ENTRY
5$: JSR R5,SORT2 ;SORT THE 'USR' 16 BIT TABLE
6$: .WORD 0 ;TABLE ADDRESS

TYPE ,MSG8 ;TYPE 'ENTER USR 18 BIT BAD SECTOR ADDRESS'
TYPE ,SCLF ;CR-LF
7$: JSR R5,MANTER ;ENTER BAD SECTOR FORM KEYBOARD
TABLE3

TST DS,CYL ;UPDATED INPUT VALUE ?
BMI 9$ ;BR IF NOT
JSR R5,INSERT ;INSERT THE BAD SECTOR INTO TABLE
8$: .WORD 0 ;
BR 7$ ;BR TO ENTER NEXT SECTOR
9$: JSR R5,SORT2 ;SORT THE TABLE
10$: .WORD 0 ;TABLE ADDRESS
RTS PC ;EXIT FORM THE TABCAL CALLING

;THIS ROUTINE WILL TYPE THE CONTENTS OF THE 'MFG' BAD SECTOR FILES
;FOR 16 BIT MODE AND 18 BIT MODE

FUNCT3: TYPE ,SCLF ;CR-LF
JSR PC,TYPACK ;TYPE PACK SERIAL NUMBER
TYPE ,SCLF ;CR-LF
MOV R1,-(SP) ;SAVE R1
MOV #MFG16+8.,R1 ;ADDRESS OF FIRST BAD SECTOR ENTRY IN TABLE
TYPE ,MSG9 ;TYPE 'CONTENTS OF 16 BIT MFG BAD SECTOR FILE'
JSR PC,TYLIST ;TYPE BAD SECTOR LIST IN DECIMAL

TYPE ,MSG10 ;TYPE 'CONTENTS OF 18 BIT MFG BAD SECTOR FILE'
MOV #MFG18+8.,R1 ;ADDRESS OF FIRST BAD SECTOR ENTRY IN TABLE
JSR PC,TYLIST ;TYPE BAD SECTOR LIST IN DECIMAL
MOV (SP)+,R1 ;RESTORE THE R1
RTS PC ;EXIT FROM THE CALLING OF TABCAL

;THIS ROUTINE WILL TYPE THE CONTENTS OF THE 'USR' BAD SECTOR FILES
;FOR 16 BIT MODE AND 18 BIT MODE

FUNCT4: TYPE ,SCLF ;CR-LF
JSR PC,TYPACK ;TYPE PACK SERIAL NUMBER
TYPE ,SCLF ;CR-LF
MOV R1,-(SP) ;SAVE R1
MOV R2,-(SP) ;SAVE R2
MOV #USTAB+8.,R1 ;SET UP 'USR' TABLES FOR 16 BIT MODE
MOV #USSAV+8.,R2
TST SEC30 ;IS IT 16 BIT MODE ?
BMI 1$ ;BR IF YES
MOV #USTAB+8.,R2 ;SET UP 'USR' TABLES FOR 18 BIT MODE
MOV #USSAV+8.,R1 ;

```

```
115 021744 104401 041224      1$:      TYPE      ,MSG11      ;TYPE 'CONTENTS OF 16 BIT USR BAD SECTOR FILE'
116 021750 004737 022512      JSR      PC,TYLIST      ;TYPE BAD SECTOR LIST IN DECIMAL
117
118 021754 104401 041310      TYPE      ,MSG12      ;TYPE 'CONTENTS OF 18 BIT USR BAD SECTOR FILE'
119 021760 010201      MOV      R2,R1      ;GET ADDRESS TO R1
120 021762 004737 022512      JSR      PC,TYLIST      ;TYPE BAD SECTOR LIST IN DECIMAL
121 021766 012602      MOV      (SP)+,R2      ;RESTORE R2
122 021770 012601      MOV      (SP)+,R1      ;RESTORE R1
123 021772 000207      RTS      PC      ;EXIT FROM THE CALLING OF TABCAL
124
125      ;THIS ROUTINE IS USED TO INITIALIZE THE 'MFG' BAD SECTOR FILE (16 AND 18 BIT)
126
127 021774 005737 001320      FUNCT5: TST      MODE      ;IS IT 'FORMAT' MODE ?
128 022000 001403      BEQ      1$      ;BR IF YES
129 022002 104401 042314      TYPE      ,NOINIT      ;TYPE 'NO INITIALIZATION IN VERIFY MODE'
130 022006 000207      RTS      PC
131
132 022010 104401 042143      1$:      TYPE      ,INITMF      ;TYPE 'INITIALIZING MFG BAD SECTOR FILES'
133 022014 010146      MOV      R1,-(SP)      ;SAVE R1
134 022016 010246      MOV      R2,-(SP)      ;SAVE R2
135 022020 005037 001420      CLR      MFG16+4.      ;CLEAR 3RD WORD (ALL 0'S)
136 022024 005037 001422      CLR      MFG16+6.      ;CLEAR 4TH WORD (ALL 0'S)
137 022030 012701 001424      MOV      #MFG16+8.,R1      ;ADDRESS OF FIRST BAD SECTOR ENTRY
138 022034 012702 000374      MOV      #252.,R2      ;NUMBER OF WORDS LEFT
139 022040 012721 177777      2$:      MOV      #-1,(R1)+      ;RESET REST OF FILE TO -1
140 022044 005302      DEC      R2      ;DONE YET ?
141 022046 001374      BNE      2$      ;BR IF NO
142
143 022050 005037 002424      CLR      MFG18+4.      ;CLEAR 3RD WORD (ALL 0'S)
144 022054 005037 002426      CLR      MFG18+6.      ;CLEAR 4TH WORD (ALL 0'S)
145 022060 012701 002430      MOV      #MFG18+8.,R1      ;ADDRESS OF FIRST BAD SECTOR ENTRY
146 022064 012702 000374      MOV      #252.,R2      ;NUMBER OF WORDS LEFT
147 022070 012721 177777      3$:      MOV      #-1,(R1)+      ;RESET REST OF FILE TO -1
148 022074 005302      DEC      R2      ;DONE YET ?
149 022076 001374      BNE      3$      ;BR IF NO
150 022100 012602      MOV      (SP)+,R2      ;RESTORE R2
151 022102 012601      MOV      (SP)+,R1      ;RESTORE R1
152 022104 104401 041502      TYPE      ,MSG14      ;TYPE 'DONE !'
153 022110 000207      RTS      PC      ;EXIT FROM THE TABCAL CALLING
154
155      ;THIS ROUTINE IS USED TO INITIALIZE THE 'USR' BAD SECTOR FILE (16 AND 18 BIT)
156
157 022112 005737 001320      FUNCT6: TST      MODE      ;IS IT 'FORMAT' MODE ?
158 022116 001403      BEQ      1$      ;BR IF YES
159 022120 104401 042314      TYPE      ,NOINIT      ;TYPE 'NO INITIALIZATION IN VERIFY MODE'
160 022124 000207      RTS      PC
161
162 022126 104401 042100      1$:      TYPE      ,INITUS      ;TYPE 'INITIALIZING USR BAD SECTOR FILES'
163 022132 010146      MOV      R1,-(SP)      ;SAVE R1
164 022134 010246      MOV      R2,-(SP)      ;SAVE R2
165 022136 005037 003430      CLR      USTAB+4.      ;CLEAR 3RD WORD (ALL 0'S)
166 022142 005037 003432      CLR      USTAB+6.      ;CLEAR 4TH WORD (ALL 0'S)
167 022146 012701 003434      MOV      #USTAB+8.,R1      ;ADDRESS OF FIRST BAD SECTOR ENTRY
168 022152 012702 000374      MOV      #252.,R2      ;NUMBER OF WORDS LEFT
169 022156 012721 177777      2$:      MOV      #-1,(R1)+      ;RESET REST OF FILE TO -1
170 022162 005302      DEC      R2      ;DONE YET ?
171 022164 001374      BNE      2$      ;BR IF NO
```



```

172
173 022166 005037 004434
174 022172 005037 004436
175 022176 012701 004440
176 022202 012702 000374
177 022206 012721 177777
178 022212 005302
179 022214 001374
180 022216 012602
181 022220 012601
182 022222 104401 041502
183 022226 000207
184
185
186
187
188 022230 104401 041374
189 022234 104401 041450
190 022240 104411
191 022242 012601
192 022244 012702 000037
    022250 004537 023172
    022254 022342
    022256 022334
    022260 022334
    022262 022270
    022264 022334
    022266 022334
193 022270 006302
194 022272 016201 006064
195 022276 012702 000402
196 022302 104401 001205
197 022306 012705 000C10
198 022312 012146
199 022314 104402
200 022316 104401 036621
201 022322 005302
202 022324 001406
203 022326 005305
204 022330 001370
205 022332 000763
206 022334 104401 037174
207 022340 000735
208 022342 104401 001205
209 022346 000207
210
211
212
213
214
215 022350 104401 041513
216 022354 004537 022702
217 022360 005736
218
219 022362 005737 001362
220 022366 100442
221 022370 010446

```

```

CLR USSAV+4. ;CLEAR 3RD WORD (ALL 0'S)
CLR USSAV+6. ;CLEAR 4TH WORD (ALL 0'S)
MOV #USSAV+8.,R1 ;ADDRESS OF FIRST BAD SECTOR ENTRY
MOV #252.,R2 ;NUMBER OF WORDS LEFT
3$: MOV #-1,(R1)+ ;RESET REST OF FILE TO -1
DEC R2 ;DONE YET ?
BNE 3$ ;BR IF NO
MOV (SP)+,R2 ;RESTORE R2
MOV (SP)+,R1 ;RESTORE R1
TYPE ,MSG14 ;TYPE 'DONE !'
RTS PC ;EXIT FORM THE TABCAL CALLING

```

;THIS ROUTINE IS USED TO PRINT A SECTOR OF THE LAST TRACK (BAD SECTOR FILE)
;CYL=822., (RM05-TRK=18. OR RM02/3-TRK=4)

```

FUNCT7: TYPE ,MSG13 ;TYPE 'PRINT A SECTOR OF LAST TRACK (OCTAL)'
1$: TYPE ,MSG13A ;TYPE 'ENTER SECTOR (DECIMAL): '
RDLIN ;READ THE SECTOR NUMBER
MOV (SP)+,R1 ;ADDRESS OF READ-IN BUFFER
MOV #31.,R2 ;UPPER LIMIT OF INPUT
JSR R5,CK.DIG ;CHECK THE DIGIT(S)
6$ ;CARRIAGE RETURN ONLY ENTERED
5$ ;PERIOD ONLY ENTERED
5$ ;ILLEGAL INPUT
2$ ;TERMINATED WITH A CARRIAGE RETURN
5$ ;TERMINATED WITH A '.'
5$ ;TERMINATED WITH A '..'
2$: ASL R2 ;FOUND THE WORD INDEX
MOV ADRTBL(R2),R1 ;ADDRESS OF THE BUFFER
MOV #258.,R2 ;WC FOR WHOLE SECTOR INCLUDING HEADER
3$: TYPE ,$CRLF ;CR-LF
MOV #8.,R5 ;8 WORDS ON A LINE
4$: MOV (R1)+,-(SP) ;CONTENTS OF THE BUFFER
TYPEOC ;TYPE OCTAL WORD
TYPE ,BLNKS2 ;TYPE 2 SPACES
DEC R2 ;DECREMENT WORD CTR
BEQ 6$ ;BR IF FINISH
DEC R5 ;START ANOTHER LINE ?
BNE 4$ ;BR IF NOT
BR 3$ ;BR IF SO
5$: TYPE ,BADENT ;TYPE BAD ENTRY
BR 1$ ;TRY AGAIN
6$: TYPE ,$CRLF ;CR-LF
RTS PC ;EXIT FROM TABCAL CALLING

```

;ROUTINE TO ENTER 'MFG' DEFINED BAD SECTORS IN THE 16 BIT TABLE AND
;THE 18 BIT TABLE. THE SECTOR ADDRESS IS ENTERED AS A BYTE LOCATION
;FROM INDEX ON THE DISK

```

FUNCT8: TYPE ,MSG15 ;TYPE 'ENTER MFG BAD SECTOR ADRS (DECIMAL)'
1$: JSR R5,MANTER ;ENTER THE VALUE FROM KEYBOARD
TABLE4
TST DS.CYL ;WAS ADDRESS UPDATED ?
BMI 6$ ;BR IF NO
MOV R4,-(SP) ;SAVE R4

```

```
222 022372 013746 001344 MOV BADSEC, -(SP) :SAVE 'BADSEC' FOR 18 BIT MODE
223 022376 005004 CLR R4 :TABLE INDEX STARTS FROM 0
224 022400 023764 001344 006264 2$: CMP BADSEC, BYTE16(R4) :IS 16 BIT LOCATION FOUND ?
225 022406 101402 BLOS 3$ :BR IF YES
226 022410 005724 TST (R4)+ :TRY NEXT SECTOR
227 022412 000772 BR 2$ :LOOPING
228 022414 006204 3$: ASR R4 :SECTOR ADDRESS
229 022416 010437 001344 MOV R4, BADSEC :SAVE 16 BIT SECTOR ADDRESS
230 022422 004537 021160 JSR R5, INSERT :INSERT BAD SECTOR INTO 'MFG16' TABLE
231 022426 001424 MFG16+8.
232 022430 012637 001344 MOV (SP)+, BADSEC :GET LOCATION OF SECTOR FOR 18 BIT MODE
233 022434 005004 CLR R4 :TABLE INDEX STARTS FROM 0
234 022436 023764 001344 006364 4$: CMP BADSEC, BYTE18(R4) :IS 18 BIT LOCATION FOUND ?
235 022444 101403 BLOS 5$ :BR IF YES
236 022446 062704 000002 ADD #2, R4 :TRY NEXT SECTOR IF NOT FOUND
237 022452 000771 BR 4$ :LOOPIN BACK
238 022454 006204 5$: ASR R4 :SECTOR ADDRESS
239 022456 010437 001344 MOV R4, BADSEC :SAVE 18 BIT SECTOR ADDRESS
240 022462 004537 021160 JSR R5, INSERT :INSERT BAD SECTOR INTO 'MFG18' TABLE
241 022466 002430 MFG18+8.
242 022470 012604 MOV (SP)+, R4 :RESTORE R4
243 022472 000730 BR 1$ :NEXT ENTRY
244 022474 004537 020250 6$: JSR R5, SORT2 :SORT 'MFG16' TABLE
245 022500 001424 MFG16+8.
246 022502 004537 020250 JSR R5, SORT2 :SORT 'MFG18' TABLE
247 022506 002430 MFG18+8.
248 022510 000207 RTS PC :RETURN
```

```

1
2
3
4
5
6
7
8
9
10
11
12
13 022512 010146
14 022514 104401 001205
15 022520 005711
16 022522 100432
17 022524 011146
18 022526 004737 027100
19 022532 004737 026670
20 022536 104401 036602
21 022542 105046
22 022544 116116 000003
23 022550 004737 027100
24 022554 004737 026670
25 022560 104401 036602
26 022564 105046
27 022566 116116 000002
28 022572 004737 027100
29 022576 004737 026670
30 022602 062701 000004
31 022606 000742
32
33 022610 020126
34 022612 001002
35 022614 104401 042206
36 022620 000207

```

```

;THIS ROUTINE IS USED TO TYPE THE BAD SECTOR FILE ENTRY IN DECIMAL.
;UPON RETURN, R1 WILL BE POINTING TO THE NEXT BAD SECTOR (CYLINDER)
;ENTRY.
;CALL
;      MOV      #NUMADR,R1      ;ADDRESS OF FIRST TABLE ENTRY
;      JSR      PC,TYLIST      ;CALL TYPE LIST ROUTINE
;
;THE LIST WILL BE TYPED IN THE FOLLOWING FORMAT:
;
;      CONTENTS OF 'FILENAME' THE BAD SECTOR FILE (DECIMAL)
;      CYL,TRK,SEC
;
TYLIST: MOV      R1,-(SP)      ;SAVE ADDRESS OF FIRST TABLE ENTRY
1$:      TYPE     ,SCLF        ;CR-LF
;      TST      (R1)          ;IS IT TERMINATOR
;      BMI      2$            ;BR IF YES
;      MOV      (R1),-(SP)    ;PUT CYLINDER NUMBER ON STACK
;      JSR      PC,$SB2D      ;CONVERT IT TO DECIMAL
;      JSR      PC,$SUPRL     ;TYPE DECIMAL NUMBER, LEFT JUSTIFY
;      TYPE     ,SCLF        ;TYPE ' '
;      CLRB     -(SP)        ;CLEAR STACK LOCATION
;      MOVB     3(R1),-(SP)   ;PUT TRACK NUMBER ON STACK
;      JSR      PC,$SB2D      ;CONVERT IT TO DECIMAL
;      JSR      PC,$SUPRL     ;TYPE DECIMAL NUMBER, LEFT JUSTIFY
;      TYPE     ,SCLF        ;TYPE ' '
;      CLRB     -(SP)        ;CLEAR STACK LOCATION
;      MOVB     2(R1),-(SP)   ;PUT SECTOR NUMBER ON STACK
;      JSR      PC,$SB2D      ;CONVERT IT TO DECIMAL
;      JSR      PC,$SUPRL     ;TYPE DECIMAL NUMBER, LEFT JUSTIFY
;      ADD      #4,R1        ;ADJUST R1 TO NEXT BAD SECTOR ENTRY
;      BR       1$          ;NEXT ENTRY
;
2$:      CMP      R1,(SP)+    ;WERE THERE ANY ENTRIES ?
;      BNE      3$          ;BR IF YES
;      TYPE     ,NOENTR      ;TYPE '* NO ENTRIES *'
3$:      RTS      PC         ;RETURN

```

```

.SBTTL  TYPE PACK SERIAL NUMBER IN OCTAL

;ROUTINE TO TYPE THE PACK SERIAL NUMBER IN OCTAL
;CALL:
;
;   OR
;
;   JSR      PC,TYPCK      ;CALL ROUTINE(WITH NO HEADER MESSAGE)

TYPACK: TYPE      ,PACKSN      ;TYPE 'PACK S/N:'
TYPCK:  MOV      USTAB+2,-(SP)  ;GET HI NUMBER (MSB)
        BEQ      1$           ;BR IF ZERO
        JSR      PC,$SB20      ;CONVERT TO OCTAL NUMBER
        JSR      PC,$SUPRL     ;AND TYPE IT LEFT JUSTIFIED
        MOV      USTAB,-(SP)   ;GET LOW NUMBER (LSB)
        JSR      PC,$SB20      ;CONVERT TO OCTAL NUMBER
        JSR      R5,FILLZ      ;TYPE WITH PRECEEDING ZEROS
        .WORD    5             ;5 DIGITS
        BR       2$
1$:     MOV      USTAB,-(SP)    ;GET LOW NUMBER (LSB)
        JSR      PC,$SB20      ;CONVERT TO OCTAL NUMBER
        JSR      PC,$SUPRL     ;AND TYPE IT LEFT JUSTIFIED
2$:     RTS      PC            ;RETURN

```

.SBTTL ENTER BAD SECTOR ROUTINE

;ROUTINE TO ENTER BAD SECTOR INFORMATION MANUALLY

;CALL:

; JSR R5,MANTER ;CALL ROUTINE
; TABLE ;ADDRESS OF TABLE

MANTER:

8	022702	010446			MOV R4, -(SP)	;;PUSH R4 ON STACK
9	022704	011504			1\$: MOV (R5), R4	;;GET TABLE POINTER
10	022706	012437	022716		MOV (R4)+, 2\$;;GET ADDRESS OF MESSAGE
11	022712	001402			BEQ 3\$;;BR IF NO MESSAGE
12	022714	104401			TYPE	
13	022716	000000			2\$: .WORD 0	;;ADDRESS OF MESSAGE GOES HERE
14	022720	012774	177777	000002	3\$: MOV #-1, @2(R4)	;;INITIALIZE VALUE
15	022726	104411			RDLIN .	
16	022730	012601			MOV (SP)+, R1	;;ADDRESS OF FIRST ASCII CHARACTER
17	022732	012402			MOV (R4)+, R2	;;UPPER LIMIT OF INPUT
	022734	004537	023172		JSR R5, CK.DIG	;;CHECK THE DIGIT(S)
	022740	023036			8\$;;CARRIAGE RETURN ONLY ENTERED
	022742	023030			7\$;;PERIOD ONLY ENTERED
	022744	023030			7\$;;ILLEGAL INPUT
	022746	023030			7\$;;TERMINATED WITH A CARRIAGE RETURN
	022750	022754			4\$;;TERMINATED WITH A '...'
	022752	023030			7\$;;TERMINATED WITH A '...'
18	022754	010234			4\$: MOV R2, @2(R4)+	;;CYLINDER ADDRESS
19						
20	022756	012402			MOV (R4)+, R2	;;UPPER LIMIT OF INPUT
	022760	004537	023172		JSR R5, CK.DIG	;;CHECK THE DIGIT(S)
	022764	023030			7\$;;CARRIAGE RETURN ONLY ENTERED
	022766	023030			7\$;;PERIOD ONLY ENTERED
	022770	023030			7\$;;ILLEGAL INPUT
	022772	023030			7\$;;TERMINATED WITH A CARRIAGE RETURN
	022774	023000			5\$;;TERMINATED WITH A '...'
	022776	023030			7\$;;TERMINATED WITH A '...'
21	023000	010234			5\$: MOV R2, @2(R4)+	;;TRACK ADDRESS
22						
23	023002	012402			MOV (R4)+, R2	;;UPPER LIMIT OF INPUT
	023004	004537	023172		JSR R5, CK.DIG	;;CHECK THE DIGIT(S)
	023010	023030			7\$;;CARRIAGE RETURN ONLY ENTERED
	023012	023030			7\$;;PERIOD ONLY ENTERED
	023014	023030			7\$;;ILLEGAL INPUT
	023016	023024			6\$;;TERMINATED WITH A CARRIAGE RETURN
	023020	023030			7\$;;TERMINATED WITH A '...'
	023022	023030			7\$;;TERMINATED WITH A '...'
24	023024	010234			6\$: MOV R2, @2(R4)+	;;SECTOR OR BYTE ADDRESS
25	023026	000403			BR 8\$;;EXIT
26						
27	023030	104401	037174		7\$: TYPE ,BADENT	;;MESSAGE BAD ENTRY
28	023034	000723			BR 1\$;;ENTER SECTOR ADDRESS AGAIN
29	023036	005725			8\$: TST (R5)+	;;ADJUST RETURN ADDRESS
30	023040	012604			MOV (SP)+, R4	;;POP STACK INTO R4
31	023042	000205			RTS R5	;;EXIT

```

1
2
3
4
5
6
7
8
9
10 023044 121127 000060
11 023050 103407
12 023052 121127 000067
13 023056 101004
14 023060 111102
15 023062 042702 177770
16 023066 005725
17 023070 000205
18
19
20
21
22
23
24
25
26
27
28 023072 121127 000060
29 023076 103407
30 023100 121127 000071
31 023104 101004
32 023106 111102
33 023110 042702 000060
34 023114 005725
35 023116 000205
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50 023120 105711
51 023122 001417
52 023124 121127 000054
53 023130 001413
54 023132 121127 000056
55 023136 001407
56 023140 004537 023072
57 023144 000410

```

```

;THIS ROUTINE IS USED TO CHECK IF AN
;ASCII CHARACTER IS A DIGIT BETWEEN 0 AND 7.
;CALL
;      MOV      #ADR,R1      ;ADDRESS OF ASCII CHARACTER
;      JSR      R5,CK.OCT    ;CHECK THE CHARACTER
;      RETURN1   ;CHARACTER IS NOT BETWEEN 0-7
;      RETURN2   ;CHARACTER IS IN R2 AS A
;                  ;OCTAL DIGIT
;
CK.OCT: CMPB     (R1),#0      ;LESS THAN ZERO?
        BLO     1$          ;YES
        CMPB     (R1),#7      ;GREATER THAN SEVEN?
        BHI     1$          ;YES
        MOVB     (R1),R2      ;GET THE CHARACTER
        BIC      #07,R2      ;STRIP AWAY THE ASCII
        TST      (R5)+        ;ADJUST FOR RETURN
1$:     RTS        R5        ;RETURN

;THIS ROUTINE IS USED TO CHECK AN ASCII CHARACTER
;AND DETERMINE IF IT IS A DIGIT BETWEEN 0 AND 9.
;CALL
;      MOV      #ADR,R1      ;ADDRESS OF ASCII CHARACTER
;      JSR      R5,CK.DEC    ;CHECK THE CHARACTER
;      RETURN1   ;NOT BETWEEN 0 AND 9
;      RETURN2   ;BETWEEN 0 AND 9
;                  ;R2 - DIGIT
;
CK.DEC: CMPB     (R1),#0      ;LESS THAN ZERO?
        BLO     1$          ;YES
        CMPB     (R1),#9      ;GREATER THAN NINE?
        BHI     1$          ;YES
        MOVB     (R1),R2      ;GET THE CHARACTER
        BIC      #0,R2       ;STRIP AWAY THE ASCII
        TST      (R5)+        ;ADJUST FOR RETURN
1$:     RTS        R5        ;RETURN

;THIS ROUTINE WILL CHECK AN ASCII CHARACTER TO
;DETERMINE WHAT IT IS.
;CALL
;      MOV      #ADR,R1      ;ADDRESS OF ASCII CHARACTER
;      JSR      R5,CK.CHR    ;CHECK CHARACTER
;      RETURN    ADR1        ;UNKNOWN CHARACTER
;      RETURN    ADR2        ;CARRIAGE RETURN * (R1)-ADR+1
;      RETURN    ADR3        ;COMMA * (R1)=ADR+1
;      RETURN    ADR4        ;PERIOD * (R1)-ADR+1
;      RETURN    ADR5        ;DIGIT BETWEEN 0 AND 7.
;      RETURN    ADR6        ;DIGIT BETWEEN 8 AND 9.
;                  ;R2 = DIGIT * (R1)-ADR+1
;
CK.CHR: TSTB     (R1)         ;'CARRIAGE RETURN'?
        BEQ     3$          ;YES
        CMPB     (R1),#',    ;'COMMA'?
        BEQ     2$          ;YES
        CMPB     (R1),#'.    ;'PERIOD'?
        BEQ     1$          ;YES
        JSR      R5,CK.DEC    ;'DIGIT'?
        BR      4$          ;NO

```

```

58 023146 004537 023044      JSR      R5,CK.OCT      :OCTAL ?
59 023152 005725              TS*      (R5)+      :DIGIT BETWEEN 8-9
60 023154 005725              TST      (R5)+      :DIGIT BETWEEN 0-7
61 023156 005725      1$:      TST      (R5)+      :PERIOD
62 023160 005725      2$:      TST      (R5)+      :COMMA
63 023162 005725      3$:      TST      (R5)+      :CARRIAGE RETURN
64 023164 005201              INC      R1          :MOVE POINTER TO NEXT CHARACTER
65 023166 011505      4$:      MOV      (R5),R5    :UNKNOWN CHARACTER
66 023170 000205              RTS      R5          :RETURN
67
68                          :THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL
69                          :CHARACTERS AND FORMS A DECIMAL VALUE BINARY NUMBER IN R2.
70                          :CALL
71                          :      MOV      #ADR,R1      :ADDRESS OF ASCII STRING
72                          :      MOV      #NUM,R2      :MAX. MAGNITUDE OF INPUT NUMBER
73                          :      JSR      R5,CK.DIG    :CHECK DIGITS
74                          :      RETURN  ADR1        :'CR' ONLY ENTERED -- R2=0
75                          :      RETURN  ADR2        :'PERIOD' ONLY ENTERED -- R2=0
76                          :      RETURN  ADR3        :ILLEGAL CHARACTER OR INPUT TOO LARGE -- R2=?
77                          :      RETURN  ADR4        :'CR' -- R2 = NUMBER
78                          :      RETURN  ADR5        :'COMMA' -- R2 = NUMBER
79                          :      RETURN  ADR6        :'PERIOD' -- R2 = NUMBER
80
81 023172 010446      CK.DIG: MOV      R4,-(SP)      :SAVE R4
82 023174 010346              MOV      R3,-(SP)      :SAVE R3
83 023176 010246              MOV      R2,-(SP)      :SAVE THE MAX. SIZE ON THE STACK
84 023200 005002              CLR      R2          :START WITH 0
85 023202 005003              CLR      R3
86 023204 005004              CLR      R4
87 023206 004537 023120      JSR      R5,CK.CHR    :CHECK ONE CHARACTER
88 023212 023306      6$:      :ILLEGAL CHARACTER
89 023214 023314      9$:      :CARRIAGE RETURN
90 023216 023306      6$:      :
91 023220 023310      7$:      :
92 023222 023226      1$:      :DIGIT 0-7
93 023224 023226      1$:      :DIGIT 8-9
88 023226 062705 000004      1$:      ADD      #4,R5    :STEP RETURN POINTER PAST 'CR' & 'PERIOD' RETURNS
89 023232 006303      2$:      ASL      R3          :INPUT NUMBER *2
90 023234 010346              MOV      R3,-(SP)      :SAVE *2
91 023236 006303              ASL      R3          :*4
92 023240 006303              ASL      R3          :*8
93 023242 062603              ADD      (SP)+,R3      :(*2)+(*8) = *10
94 023244 060203              ADD      R2,R3        :UPDATE THE INPUT NUMBER
95 023246 004537 023120      JSR      R5,CK.CHR    :CHECK ONE CHARACTER
96 023252 023312      8$:      :ILLEGAL CHARACTER
97 023254 023276      5$:      :CARRIAGE RETURN
98 023256 023274      4$:      :
99 023260 023266      3$:      :
100 023262 023232      2$:      :DIGIT 0-7
101 023264 023232      2$:      :DIGIT 8-9
96 023266 105711      3$:      TSTB     (R1)        :DOES A 'CR' FOLLOW THE 'PERIOD'
97 023270 001010      BNE      8$          :BR IF NOT
98 023272 005724      TST      (R4)+      :INCREMENT THE RETURN
99 023274 005724      4$:      TST      (R4)+      :INCREMENT THE RETURN
100 023276 005724      5$:      TST      (R4)+      :INCREMENT THE RETURN
101 023300 020316      CMP      R3,(SP)      :CHECK THE MAGNITUDE OF THE NUMBER
102 023302 003004      BGT      9$          :BR IF ENTERED NUMBER TOO LARGE

```

103 023304 000402
104 023306 005725
105 023310 005725
106 023312 060405
107 023314 010302
108 023316 005726
109 023320 012603
110 023322 012604
111 023324 011505
112 023326 000205
113

6\$: BR
7\$: TST
8\$: TST
9\$: ADD
MOV R3,R2
TST (SP)+
MOV (SP)+,R3
MOV (SP)+,R4
MOV (R5),R5
RTS R5

8\$:
(R5)+
(R5)+
R4,R5
R3,R2
(SP)+
(SP)+,R3
(SP)+,R4
(R5),R5
R5
:BYPASS INCREMENT
:INCREMENT RETURN PAST INVALID RETURN
:INCREMENT RETURN
:SETUP RETURN POINTER
:ENTERED VALUE
:CLEAN MAX. SIZE OFF OF STACK
:RESTORE R3
:RESTORE R4
:GET RETURN ADDRESS
:RETURN

.SBTTL ERROR HANDLER ROUTINE

```
*****
*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
*AND GO TO TYPERR ON ERROR
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW15=1      HALT ON ERROR
*SW13=1      INHIBIT ERROR TYPEOUTS
*SW10=1      BELL ON ERROR
*SW09=1      LOOP ON ERROR
*CALL
*          ERROR      N          ;;ERROR-EMT AND N=ERROR ITEM NUMBER
```

```
023330 105037 023756 $ERROR: CLR B IBSAVE ;;CLEAR THE ITEM BYTE SAVE LOCATION
023334 104407 CKSWR ;;TEST FOR CHANGE IN SOFT-SWR
023336 010137 001366 MOV R1,DDRIVE ;;DRIVE ADDRESS IF DRIVE ERROR CALL
023342 010337 001370 MOV R3,ATTN ;;ATTENTION REGISTER CONTENTS
023346 013737 005552 001362 MOV FMTDPB+12,DS,CYL ;;CURRENT CYLINDER ADDRESS
023354 113737 005551 001364 MOV FMTDPB+11,DS,TRK ;;REQUESTED TRACK ADDRESS
023362 015737 005564 TST RM.REG+RMBA ;;NON-ZERO BUFFER ADDRESS ?
023366 001406 BEQ 7$ ;;BR IF NO BUFFER ADDRESS
023370 013746 005564 MOV RM.REG+RMBA,-(SP) ;;BUFFER ADDRESS
023374 162716 000002 SUB #2,(SP) ;;DECREMENT THE ADDRESS
023400 013637 001140 MOV @ (SP)+,$GDDAT ;;GET THE BUFFER WORD WHICH DIDN'T COMPARE
023404 105237 001117 7$: INCB $ERFLG ;;SET THE ERROR FLAG
023410 001775 BEQ 7$ ;;DON'T LET THE FLAG GO TO ZERO
023412 013777 001116 155536 MOV $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
023420 032777 002000 155526 BIT #BIT10,@SWR ;;BELL ON ERROR?
023426 001402 BEQ 1$ ;;NO - SKIP
023430 104401 001200 TYPE $BELL ;;RING BELL
023434 005237 001126 1$: INC $ERTTL ;;COUNT THE NUMBER OF ERRORS
023440 011637 001132 MOV (SP),$ERRPC ;;GET ADDRESS OF ERROR INSTRUCTION
023444 162737 000002 001132 SUB #2,$ERRPC
023452 117737 155454 001130 MOV B $ERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
023460 032777 001000 155466 BIT #BIT09,@SWR ;;SEE IF LOOP ON ERROR IS SET
023466 001060 BNE 1004$ ;;BRANCH AROUND ROUTINE IF SO
023470 122737 000177 001130 CMPB #177,$ITEMB ;;SEE IF THIS IS THE POWER FAIL CALL
023476 001454 BEQ 1004$ ;;BRANCH AROUND ROUTINE IF IT IS
023500 105737 023756 TSTB IBSAVE ;;SEE IF THIS IS THE 2ND ERROR CALL IN THIS ROUTINE
023504 001047 BNE 1003$ ;;BRANCH IF SO
023506 022737 177777 023754 CMP #-1,CPSAVE ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
023514 001445 BEQ 1004$ ;;BRANCH IF SO
023516 013746 000004 MOV ERRVEC,-(SP) ;;SAVE CONTENTS OF ERROR VECTOR
023522 012737 023540 000004 MOV #1000$,ERRVEC ;;SETUP 'TRAP' RETURN ADDRESS
023530 013737 177766 023754 MOV 177766,CPSAVE ;;MOVE CPU ERROR REGISTER TO CPSAVE FOR TEST
023536 000406 BR 1001$
023540 012737 177777 023754 1000$: MOV #-1,CPSAVE ;;SET CPU ERROR REGISTER TIMEOUT INDICATOR
023546 012716 023554 MOV #1001$,(SP) ;;SETUP RETURN ADDRESS
023552 000002 RTI
023554 012637 000004 1001$: MOV (SP)+,ERRVEC ;;RESTORE CONTENTS OF ERROR VECTOR

023560 022737 177777 023754 1002$: CMP #-1,CPSAVE ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
023566 001420 BEQ 1004$ ;;BRANCH IF SO
023570 032737 000001 023754 BIT #BIT00,CPSAVE ;;SEE IF POWER MONITOR BIT IS SET IN CPU ERR REG
023576 001414 BEQ 1004$ ;;BRANCH IF OK
023600 042737 000001 177766 BIC #BIT00,177766 ;;CLEAR THE BIT FOUND SET
```

023606	113737	001130	023756	MOVB	\$ITEMB,IBSAVE	::MAKE IBSAVE NON-ZERO FOR DUAL ERROR CALL
023614	112737	000177	001130	MOVB	#177,\$ITEMB	::SET \$ITEMB TO SPECIAL POWER FAIL POINTER
023622	000402			BR	1004\$::BRANCH OVER IBSAVE CLEARING
023624	105037	023756		1003\$: CLRB	IBSAVE	::CLEAR IBSAVE SO 2ND TIME THROUGH EXITS
023630				1004\$:		
023630	032777	020000	155316	BIT	#BIT113,@SWR	::SKIP TYPEOLT IF SET
023636	001004			BNE	20\$::SKIP TYPEOUTS
023640	004737	023760		JSR	PC,TYPERR	::GO TO USER ERROR ROUTINE
023644	104401	001205		TYPE	,\$CRLF	
023650			20\$:			
023650	122737	000001	001230	CMPB	#APTENV,\$ENV	::RUNNING IN APT MODE
023656	001007			BNE	2\$::NO,SKIP APT ERROR REPORT
023660	113737	001130	023672	MOVB	\$ITEMB,21\$::SET ITEM NUMBER AS ERROR NUMBER
023666	004737	027522		JSR	PC,\$ATY4	::REPORT FATAL ERROR TO APT
023672	000		21\$:	.BYTE	0	
023673	000			.BYTE	0	
023674	000777		22\$:	BR	22\$::APT ERROR LOOP
023676	105737	023756	2\$:	TSTB	IBSAVE	::SEE IF IBSAVE IS LOADED
023702	001005			BNE	3\$::BRANCH IF NOT - NO HALT ON PWR MON BIT ERROR
023704	005777	155244		TST	@SWR	::HALT ON ERROR
023710	100002			BPL	3\$::SKIP IF CONTINUE
023712	000000			HALT		::HALT ON ERROR!
023714	104407			CKSWR		::TEST FOR CHANGE IN SOFT-SWR
023716			3\$:			
023716	032777	001000	155230	BIT	#BIT109,@SWR	::LOOP ON ERROR SWITCH SET?
023724	001402			BEQ	4\$::BR IF NO
023726	013716	001124		MOV	\$LPERR,(SP)	::FUDGE RETURN FOR LOOPING
023732	005737	001176	4\$:	TST	\$ESCAPE	::CHECK FOR AN ESCAPE ADDRESS
023736	001402			BEQ	5\$::BR IF NONE
023740	013716	001176		MOV	\$ESCAPE,(SP)	::FUDGE RETURN ADDRESS FOR ESCAPE
023744			5\$:			
023744	105737	023756		TSTB	IBSAVE	::SEE IF ITEM BYTE SAVE LOCATION HAS AN ERROR CALL
023750	001215			BNE	7\$::BRANCH BACK TO CALL ORIGINAL ERROR
023752	000002			RTI		::RETURN
023754	000000		CPSAVE: .WORD	0		::LOCATION TO SAVE CPU ERROR REG CONTENTS
023756	000000		IBSAVE: .WORD	0		::LOCATION TO SAVE ITEM BYTE

:THIS ROUTINE USES THE "ITEM CONTROL BYTE" (\$ITEMB) TO DETERMINE
:WHICH ERROR IS TO BE REPORTED, IT THEN OBTAINS, FROM THE "ERROR
:TABLE" (\$ERRTB), AND REPORTS THE APPROPRIATE INFORMATION
:CONCERNING THE ERROR.

3							
4							
5							
6	023760	104412					
7	023762	005000					
8	023764	113700	001130				
9	023770	122700	000177				
10	023774	001006					
14	023776	013737	001214	024374			
16	024004	012700	024234				
17	024010	000407					
18	024012	010001					
19	024014	005300					
20	024016	006300					
21	024020	006300					
22	024022	006300					
23	024024	062700	006460				
24	024030	012037	024044				
25	024034	001404					
26	024036	104401	001205				
27	024042	104401					
28	024044	000000					
29	024046	012037	024062				
30	024052	001404					
31	024054	104401	001205				
32	024060	104401					
33	024062	000000					
34	024064	012001					
35	024066	001460					
36	024070	005005					
37	024072	012000					
38	024074	012002					
39	024076	001451					
40	024100	005105					
41	024102	104401	001205				
42	024106	112003					
43	024110	112004					
44	024112	006004					
45	024114	103403					
46	024116	013146					
47	024122	104402					
48	024124	000402					
	024124	013146					
	024126	104405					
49	024130	005303					
50	024132	001403					
51	024134	104401	036621				
52	024140	000764					
53	024142	005302					
54	024144	003431					
55	024146	104401	001205				
56	024152	005760	000002				
57	024156	001404					
58	024160	005105					

TYPERR:	SAVREG		
	CLR	R0	
	MOVB	\$ITEMB,R0	
	CMPB	#177,R0	
	BNE	1\$	
	MOV	\$TESTN,PFTSTN	
	MOV	#PFECB,R0	
	BR	3\$	
1\$:	MOV	R0,R1	
	DEC	R0	
	ASL	R0	
	ASL	R0	
	ASL	R0	
2\$:	ADD	#\$ERRTB,R0	
3\$:	MOV	(R0)+,4\$	
	BEQ	5\$	
	TYPE	,\$CRLF	
	TYPE		
4\$:	.WORD	0	
5\$:	MOV	(R0)+,6\$	
	BEQ	7\$	
	TYPE	,\$CRLF	
	TYPE		
6\$:	.WORD	0	
7\$:	MOV	(R0)+,R1	
	BEQ	17\$	
	CLR	R5	
	MOV	(R0)+,R0	
	MOV	(R0)+,R2	
	BEQ	16\$	
	COM	R5	
	TYPE	,\$CRLF	
8\$:	MOVB	(R0)+,R3	
	MOVB	(R0)+,R4	
9\$:	ROR	R4	
	BCS	10\$	
	MOV	@(R1)+,-(SP)	
	TYPDC		
	BR	11\$	
10\$:	MOV	@(R1)+,-(SP)	
	TYPDS		
11\$:	DEC	R3	
	BEQ	12\$	
	TYPE	,\$BLNKS2	
	BR	9\$	
12\$:	DEC	R2	
	BLE	17\$	
	TYPE	,\$CRLF	
	TST	2(R0)	
	BEQ	13\$	
	COM	R5	

:SAVE R0-R5
:CLEAR R0 FOR ERROR NUMBER
:ERROR NUMBER
:SEE IF THIS ERROR CALL IS SPECIAL POWER FAIL CALL
:BRANCH IF NOT
:GET TEST NUMBER
:MOVE POWER FAIL ERROR CALL TABLE TO R0
:AND COPY IT INTO R1
:FORM INDEX FOR ERROR TABLE
:FORM ADDRESS
:GET ERROR MESSAGE (EM) POINTER
:BR IF THERE ISN'T ONE
:CARRIAGE RETURN - LINE FEED
: 'EM' POINTER GOES HERE
:PICK UP DATA HEADER (DH) POINTER
:BR IF NONE
:CARRIAGE RETURN-LINE FEED
: 'DH' POINTER GOES HERE
:PICKUP DATA TABLE (DT) POINTER
:BR IF NONE
:SET INDENT SWITCH
:DATA FORMAT (DF) POINTER
:NUMBER OF DH'S TO TYPE
:BR IF DH NUMBER IS 0
:NO INDENT
:CARRIAGE RETURN-LINE FEED
:NUMBER OF DATA WORDS TO TYPE
:AND HOW TO TYPE THEM
:OCTAL OR DECIMAL?
:DECIMAL
:SAVE @(R1)+ FOR TYPEOUT
:GO TYPE--OCTAL ASCII(ALL DIGITS)
:SAVE @(R1)+ FOR TYPEOUT
:GO TYPE--DECIMAL ASCII WITH SIGN
:MORE NUMBERS TO TYPE?
:NO
:TYPE 2 SPACES
:LOOP
:MORE DH'S?
:NO
:YES--START A NEW LINE
:ONLY A 'DH' IN THIS REQUEST ?
:BR IF YES - BYPASS THE INDENT
:INDENT?

59	024162	001002			BNE	13\$:NO
60	024164	104401	036621		TYPE	,BLNKS2		:TYPE 2 SPACES
61	024170	012037	024176	13\$:	MOV	(R0)+,14\$:GET NEXT DH
62	024174	104401			TYPE			:AND TYPE IT
63	024176	000000		14\$:	.WORD	0		:DH POINTER GOES HERE
64	024200	005710			TST	(R0)		:TYPE A 'DT' ?
65	024202	001003			BNE	15\$:BR IF A 'DT'
66	024204	062700	000004		ADD	#4,R0		:INCREMENT THE 'DF' POINTER
67	024210	000754			BR	12\$:SEE IF END OF 'DF' BLOCK
68	024212	104401	001205	15\$:	TYPE	,SCLRF		:CARRIAGE RETURN-LINE FEED
69	024216	005705			TST	R5		:INDENT?
70	024220	001332			BNE	8\$:NO
71	024222	104401	036621	16\$:	TYPE	,BLNKS2		:TYPE 2 SPACES
72	024226	000727			BR	8\$:LOOP
73	024230	104413		17\$:	RESREG			:RESTORE R0-R5
74	024232	000207			RTS	PC		:RETURN
75	024234	024244	024326	024360	PFECH:	PFECH1,PFECH2,PFECH3,PFECH4		:WORDS DEFINING TABLES BELOW
76	024244	120	117	127	PFECH1:	.ASCIZ		?POWER MONITOR BIT IN CPU ERROR REGISTER FOUND SET?
77	024326	124	105	123	PFECH2:	.ASCIZ		?TESTNO ERR PC (PUERREG?)
78						.EVEN		
79	024360	024374	001132	23754	PFECH3:	.WORD	PFTSTN,\$ERRPC,CPSAVE,0	
80	024370	000001			PFECH4:	.WORD	1	:NUMBER OF DATA HEADERS
81	024372	003				.BYTE	3	:NUMBER OF WORDS IN DATA TABLE
82	024373	000				.BYTE	0	:ALL 3 NUMBERS ARE OCTAL
83	024374	000000			PFTSTN:	.WORD	0	:CONTAINS TEST NUMBER FOR PF BIT ERROR

.SBTTL TTY INPUT ROUTINE

024376 000000
024400 000000
024402 000000
024404 024413

```
*****
ENABL LSB
$TKCNT: .WORD 0      ;;NUMBER OF ITEMS IN QUEUE
$TKQIN: .WORD 0      ;;INPUT POINTER
$TKQOUT: .WORD 0     ;;OUTPUT POINTER
$TKQSRT: .BLKB 7     ;;TTY KEYBOARD QUEUE
$TKQEND=.
.EVEN
```

```
;;*TK INITIALIZE ROUTINE
;;*THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
;;*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
```

```
;;*CALL:
;;*      JSR      PC,$TKINT
;;*      RETURN
```

024414	005037	024376		\$TKINT: CLR	\$TKCNT	;;CLEAR COUNT OF ITEMS IN QUEUE
024420	012737	024404	024400	MOV	#\$TKQSRT,\$TKQIN	;;MOVE THE STARTING ADDRESS OF THE
024426	013737	024400	024402	MOV	\$TKQIN,\$TKQOUT	;;QUEUE INTO THE INPUT & OUTPUT POINTERS.
024434	012737	024464	000060	MOV	#\$TKSRV,@TKVEC	;;INITIALIZE THE KEYBOARD VECTOR
024442	012737	000200	000062	MOV	#200,@TKVEC+2	;;'BR' LEVEL 4
024450	005777	154506		TST	@TKB	;;CLEAR DONE FLAG
024454	012777	000100	154476	MOV	#100,@TKS	;;ENABLE TTY KEYBOARD INTERRUPT
024462	000207			RTS	PC	;;RETURN TO CALLER

```
;;*TK SERVICE ROUTINE
;;*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
;;*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
;;*IT IN THE QUEUE.
;;*IF THE CHARACTER IS A 'CONTROL-C' (^C) $TKINT IS CALLED AND
;;*UPON RETURN EXIT IS MADE TO THE 'CONTROL-C' RESTART ADDRESS (@CNTLC)
```

024464	117746	154472		\$TKSRV: MOV	@TKB,-(SP)	;;PICKUP THE CHARACTER
024470	042716	177600		BIC	^C177,(SP)	;;STRIP THE JUNK
024474	021627	000021		CM	(SP),#\$XON	;;IS IT A RANDOM XON?
024500	001002			BNE	30\$;;BRANCH IF NO
024502	005726			TST	(SP)+	;;CLEAN RANDOM XON OFF STACK
024504	000002			RTI		;;RETURN
024506				30\$:		
024506	021627	000003		CM	(SP),#3	;;IS IT A CONTROL C?
024512	001007			BNE	1\$;;BRANCH IF NO
024514	104401	025621		TYPE	,\$CNTLC	;;TYPE A CONTROL-C (^C)
024520	004737	024414		JSR	PC,\$TKINT	;;INI THE KEYBOARD
024524	005726			1\$:	(SP)+	;;CLEAN UP STACK
024526	000177	154640		JMP	@CNTLC	;;CONTROL C RESTART
024532	021627	000007		CM	(SP),#7	;;IS IT A CONTROL G?
024536	001004			BNE	2\$;;BRANCH IF NO
024540	022737	000176	001154	CM	,\$SWRFG,\$SWR	;;IS 'OFT-SWR SELECTED?
024546	001500			BEQ	6\$;;GO TO SWR CHANGE
024550				2\$:		
024550	022737	000007	024376	CM	#7,\$TKCNT	;;IS THE QUEUE FULL?
024556	001004			BNE	3\$;;BRANCH IF NO
024560	104401	001200		TYPE	,\$BELL	;;RING THE TTY BELL

```

024564 005726          TST      (SP)+      ;;CLEAN CHARACTER OFF OF STACK
024566 000451          BR       5$          ;;EXIT
024570 021627 000023 3$:    CMP      (SP),#23      ;;IS IT A CONTROL-S?
024574 001021          BNE      32$          ;;BRANCH IF NO
024576 005077 154356          CLR      @STKS      ;;DISABLE TTY KEYBOARD INTERRUPTS
024602 005726          TST      (SP)+      ;;CLEAN CHAR OFF STACK
024604 105777 154350 31$:  TSTB     @STKS      ;;WAIT FOR A CHAR
024610 100375          BPL      31$          ;;LOOP UNTIL ITS THERE
024612 117746 154344          MOVB    @STKB,-(SP)  ;;GET THE CHARACTER
024616 042716 177600          BIC      #'C177,(SP)  ;;MAKE IT 7-BIT ASCII
024622 022627 000021          CMP      (SP)+,#21      ;;IS IT A CONTROL-Q?
024626 001366          BNE      31$          ;;BRANCH IF NO
024630 012777 000100 154322      MOV     #100,@STKS  ;;REENABLE TTY KEYBOARD INTERRUPTS
024636 000002          RTI              ;;RETURN
024640 005237 024376 32$:  INC      $TKCNT      ;;COUNT THIS CHARACTER
024644 021627 000140          CMP      (SP),#140     ;;IS IT UPPER CASE?
024650 002405          BLT      4$          ;;BRANCH IF YES
024652 021627 000175          CMP      (SP),#175     ;;IS IT A SPECIAL CHAR?
024656 003002          BGT      4$          ;;BRANCH IF YES
024660 042716 000040          BIC      #40,(SP)      ;;MAKE IT UPPER CASE
024664 112677 177510 4$:    MOVB    (SP)+,@STKQIN  ;;AND PUT IT IN QUEUE
024670 005237 024400          INC      $TKQIN      ;;UPDATE THE POINTER
024674 023727 024400 024413      CMP     $TKQIN,$$TKQEND  ;;GO OFF THE END?
024702 001003          BNE      5$          ;;BRANCH IF NO
024704 012737 024404 024400      MOV     $$TKQSRST,$$TKQIN  ;;RESET THE POINTER
024712 000002 5$:    RTI              ;;RETURN

```

*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
 *ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
 *SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
 *CALL WHEN OPERATING IN TTY INTERRUPT MODE.

```

024714 022737 000176 001154 $CKSWR: CMP     #SWREG,SWR      ;;IS THE SOFT-SWR SELECTED
024722 001124          BNE      15$          ;;EXIT IF NOT
024724 105777 154230          TSTB     @STKS      ;;IS A CHAR WAITING?
024730 100121          BPL      15$          ;;IF NOT, EXIT
024732 117746 154224          MOVB    @STKB,-(SP)  ;;YES
024736 042716 177600          BIC      #'C177,(SP)  ;;MAKE IT 7-BIT ASCII
024742 021627 000007          CMP      (SP),#7      ;;IS IT A CONTROL-G?
024746 001300          BNE      2$          ;;IF NOT, PUT IT IN THE TTY QUEUE
                                ;;AND EXIT

```

*CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
 *ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
 *CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.

```

024750 123727 001150 000001 6$:  CMPB    $AUTOB,#1      ;;ARE WE RUNNING IN AUTO-MODE?
024756 001674          BEQ      2$          ;;BRANCH IF YES
024760 005726          TST      (SP)+      ;;CLEAR CONTROL-G OFF STACK
024762 004737 024414          JSR      PC,$TKINT    ;;FLUSH THE TTY INPUT QUEUE
024766 005077 154166          CLR      @STKS      ;;DISABLE TTY KEYBOARD INTERRUPTS
024772 112737 000001 001151      MOVB    #1,$INTAG  ;;SET INTERRUPT MODE INDICATOR

025000 104401 025633          TYPE     ,SCNTLG      ;;ECHO THE CONTROL-G (^G)
025004 104401 025640          $GTSWR: TYPE    ,SMSWR      ;;TYPE CURRENT CONTENTS
025010 013746 000176          MOV     SWREG,-(SP)  ;;SAVE SWREG FOR TYPEOUT
025014 104402          TYPOC      ;;GO TYPE--OCTAL ASCII(ALL DIGITS)

```

025016	104401	025651		TYPE	SMNEW	::PROMPT FOR NEW SWR
025022	005046		19\$:	CLR	-(SP)	::CLEAR COUNTER
025024	005046			CLR	-(SP)	::THE NEW SWR
025026	105777	154126	7\$:	TSTB	@STKS	::CHAR THERE?
025032	100375			BPL	7\$::IF NOT TRY AGAIN
025034	117746	154122		MOVB	@STKB, -(SP)	::PICK UP CHAR
025040	042716	177600		BIC	#^C177, (SP)	::MAKE IT 7-BIT ASCII
025044	021627	000003		CMP	(SP), #3	::IS IT A CONTROL-C?
025050	001015			BNE	9\$::BRANCH IF NOT
025052	104401	025621		TYPE	SCNTLC	::YES, ECHO CONTROL-C (^C)
025056	062706	000006		ADD	#6, SP	::CLEAN UP STACK
025062	123727	001151	000001	CMPB	\$INTAG, #1	::REENABLE TTY KEYBOARD INTERRUPTS?
025070	001003			BNE	8\$::BRANCH IF NO
025072	012777	000100	154060	MOV	#100, @STKS	::ALLOW TTY KEYBOARD INTERRUPTS
025100	000177	154266	8\$:	JMP	@CNTLC	::CONTROL-C RESTART
025104	021627	000025		CMP	(SP), #25	::IS IT A CONTROL-U?
025110	001005			BNE	10\$::BRANCH IF NOT
025112	104401	025626		TYPE	SCNTLU	::YES, ECHO CONTROL-U (^U)
025116	062706	000006		ADD	#6, SP	::IGNORE PREVIOUS INPUT
025122	000737		20\$:	BR	19\$::LET'S TRY IT AGAIN
025124	021627	000015		CMP	(SP), #15	::IS IT A <CR>?
025130	001022		10\$:	BNE	16\$::BRANCH IF NO
025132	005766	000004		TST	4(SP)	::YES, IS IT THE FIRST CHAR?
025136	001403			BEQ	11\$::BRANCH IF YES
025140	016677	000002	154006	MOV	2(SP), @SWR	::SAVE NEW SWR
025146	062706	000006		ADD	#6, SP	::CLEAN UP STACK
025152	104401	001205		TYPE	SCRLF	::ECHO <CR> AND <LF>
025156	123727	001151	000001	CMPB	\$INTAG, #1	::RE-ENABLE TTY KBD INTERRUPTS?
025164	001003			BNE	15\$::BRANCH IF NOT
025166	012777	000100	153764	MOV	#100, @STKS	::RE-ENABLE TTY KBD INTERRUPTS
025174	000002		15\$:	RTI		::RETURN
025176	004737	026074		JSR	PC, \$TYPEC	::ECHO CHAR
025202	021627	000060	16\$:	CMP	(SP), #60	::CHAR < 0?
025206	002420			BLT	18\$::BRANCH IF YES
025210	021627	000067		CMP	(SP), #67	::CHAR > 7?
025214	003015			BGT	18\$::BRANCH IF YES
025216	042726	000060		BIC	#60, (SP)+	::STRIP-OFF ASCII
025222	005766	000002		TST	2(SP)	::IS THIS THE FIRST CHAR
025226	001403			BEQ	17\$::BRANCH IF YES
025230	006316			ASL	(SP)	::NO, SHIFT PRESENT
025232	006316			ASL	(SP)	::CHAR OVER TO MAKE
025234	006316			ASL	(SP)	::ROOM FOR NEW ONE.
025236	005266	000002	17\$:	INC	2(SP)	::KEEP COUNT OF CHAR
025242	056616	177776		BIS	-2(SP), (SP)	::SET IN NEW CHAR
025246	000667			BR	7\$::GET THE NEXT ONE
025250	104401	001204	18\$:	TYPE	\$QUES	::TYPE ?<CR><LF>
025254	000720		20\$:	BR	20\$::SIMULATE CONTROL-U
				.DSABL	LSB	

::*****

```

; *THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
; *CALL:
; *      RDCHR
; *      RETURN HERE
; *
; *      GET A CHARACTER FROM THE QUEUE
; *      CHARACTER IS ON THE STACK
; *      WITH PARITY BIT STRIPPED OFF

025256 011646          SRDCHR: MOV      (SP),-(SP)      ;; PUSH DOWN THE PC AND
025260 016666 000004 000002      MOV      4(SP),2(SP)  ;; THE PS
025266 005066 000004          CLR      4(SP)          ;; GET READY FOR A CHARACTER
025272 005046          CLR      -(SP)                ;; PUT NEW PS ON STACK
025274 012746 025302          MOV      #64$,-(SP)      ;; PUT NEW PC ON STACK
025300 000002          RTI                          ;; POP NEW PC AND PS
025302
64$:
025302 005737 024376      1$:      TST      $TKCNT      ;; WAIT ON A CHARACTER
025306 001775          BEQ      1$
025310 005337 024376      DEC      $TKCNT      ;; DECREMENT THE COUNTER
025314 117766 177062 000004      MOVB     @STKQOUT,4(SP) ;; GET ONE CHARACTER
025322 005237 024402      INC      $TKQOUT      ;; UPDATE THE POINTER
025326 023727 024402 024413      CMP      $TKQOUT,$$TKQEND ;; DID IT GO OFF OF THE END?
025334 001003          BNE      2$                ;; BRANCH IF NO
025336 012737 024404 024402      MOV      $$TKQSRRT,$$TKQOUT ;; RESET THE POINTER
025344 000002          RTI                          ;; RETURN
2$:
; *****
; *THIS ROUTINE WILL INPUT A STRING FROM THE TTY
; *CALL:
; *      RDLIN
; *      RETURN HERE
; *
; *      INPUT A STRING FROM THE TTY
; *      ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
; *      TERMINATOR WILL BE A BYTE OF ALL 0'S

025346 010346          $RDLIN: MOV      R3, -(SP)      ;; SAVE R3
025350 005046          CLR      -(SP)                ;; CLEAR THE RUBOUT KEY
025352 012703 025602      1$:      MOV      $$TTYIN,R3  ;; GET ADDRESS
025356 022703 025621      2$:      CMP      $$TTYIN+15.,R3 ;; BUFFER FULL?
025362 101456          BLOS     4$                    ;; BR IF YES
025364 104410          RDCHR     ;; GO READ ONE CHARACTER FROM THE TTY
025366 112613          MOVB     (SP)+,(R3)            ;; GET CHARACTER
025370 122713 000177      10$:     CMPB     #177,(R3)   ;; IS IT A RUBOUT
025374 001022          BNE      5$                    ;; BR IF NO
025376 005716          TST      (SP)                  ;; IS THIS THE FIRST RUBOUT?
025400 001007          BNE      6$                    ;; BR IF NO
025402 112737 000134 025600      MOVB     #'\\,9$      ;; TYPE A BACK SLASH
025410 104401 025600          TYPE     ,9$
025414 012716 177777          MOV      #-1,(SP)        ;; SET THE RUBOUT KEY
025420 005303          6$:      DEC      R3            ;; BACKUP BY ONE
025422 020327 025602      CMP      R3,$$TTYIN          ;; STACK EMPTY?
025426 103434          BLO      4$                    ;; BR IF YES
025430 111337 025600      MOVB     (R3),9$            ;; SETUP TO TYPEOUT THE DELETED CHAR.
025434 104401 025600          TYPE     ,9$            ;; GO TYPE
025440 000746          BR       2$                    ;; GO READ ANOTHER CHAR.
025442 005716          5$:      TST      (SP)          ;; RUBOUT KEY SET?
025444 001406          BEQ      7$                    ;; BR IF NO
025446 112737 000134 025600      MOVB     #'\\,9$      ;; TYPE A BACK SLASH
025454 104401 025600          TYPE     ,9$
025460 005016          CLR      (SP)                  ;; CLEAR THE RUBOUT KEY
025462 122713 000025      7$:      CMPB     #25,(R3)    ;; IS CHARACTER A CTRL U?
025466 001003          BNE      8$                    ;; BR IF NO
8$:

```


025470	104401	025626		TYPE	,\$CNTLU	:: TYPE A CONTROL 'U'
025474	000726			BR	1\$:: GO START OVER
025476	122713	000022	8\$:	CMPB	#22,(R3)	:: IS CHARACTER A 'R'?
025502	001011			BNE	3\$:: BRANCH IF NO
025504	105013			CLRB	(R3)	:: CLEAR THE CHARACTER
025506	104401	001205		TYPE	,\$CRLF	:: TYPE A 'CR' & 'LF'
025512	104401	025602		TYPE	,\$TTYIN	:: TYPE THE INPUT STRING
025516	000717			BR	2\$:: GO PICKUP ANOTHER CHARACTER
025520	104401	001204	4\$:	TYPE	,\$QUES	:: TYPE A '?'
025524	000712			BR	1\$:: CLEAR THE BUFFER AND LOOP
025526	111337	025600	3\$:	MOVB	(R3),9\$:: ECHO THE CHARACTER
025532	104401	025600		TYPE	,\$	
025536	122723	000015		CMPB	#15,(R3)+	:: CHECK FOR RETURN
025542	001305			BNE	2\$:: LOOP IF NOT RETURN
025544	105063	177777		CLRB	-1(R3)	:: CLEAR RETURN (THE 15)
025550	104401	001206		TYPE	,\$LF	:: TYPE A LINE FEED
025554	005726			TST	(SP)+	:: CLEAN RUBOUT KEY FROM THE STACK
025556	012603			MOV	(SP)+,R3	:: RESTORE R3
025560	011646			MOV	(SP),-(SP)	:: ADJUST THE STACK AND PUT ADDRESS OF THE
025562	016666	000004	000002	MOV	4(SP),2(SP)	:: FIRST ASCII CHARACTER ON IT
025570	012766	025602	000004	MOV	#TTYIN,4(SP)	
025576	000002			RTI		:: RETURN
025600	000		9\$:	.BYTE	0	:: STORAGE FOR ASCII CHAR. TO TYPE
025601	000			.BYTE	0	:: TERMINATOR
025602				TTYIN:	.BLKB	15.
025621	136	103	015	\$CNTLC:	.ASCIZ	/'C'/<15><12>
025626	136	125	015	\$CNTLU:	.ASCIZ	/'U'/<15><12>
025633	136	107	015	\$CNTLG:	.ASCIZ	/'G'/<15><12>
025640	015	012	123	\$MSWR:	.ASCIZ	<15><12>/SWR = /
025651	040	040	116	\$MNEW:	.ASCIZ	/ NEW = /

.SBTTL TYPE ROUTINE

 *ROUTINE TO TYPE ASCII MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
 *THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
 *NOTE1: \$NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
 *NOTE2: \$FILLC CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
 *NOTE3: \$FILLC CONTAINS THE CHARACTER TO FILL AFTER.

*CALL:
 *1) USING A TRAP INSTRUCTION
 * TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCII STRING
 *OR
 * TYPE
 * MESADR

025662	105737	001173	\$TYPE:	TSTB	\$TFPLG	::IS THERE A TERMINAL?
025666	100002			BPL	1\$::BR IF YES
025670	000000			HALT		::HALT HERE IF NO TERMINAL
025672	000430			BR	3\$::LEAVE
025674	010046		1\$:	MOV	RO,-(SP)	::SAVE RO
025676	017600	000002		MOV	@2(SP),RO	::GET ADDRESS OF ASCII STRING
025702	122737	000001 001230		CMPB	#APTENV,\$ENV	::RUNNING IN APT MODE
025710	001011			BNE	62\$::NO,GO CHECK FOR APT CONSOLE
025712	132737	000100 001231		BITB	#APTSPOOL,\$ENV	::SPOOL MESSAGE TO APT
025720	001405			BEQ	62\$::NO,GO CHECK FOR CONSOLE
025722	010037	025732		MOV	RO,61\$::SETUP MESSAGE ADDRESS FOR APT
025726	004737	027512		JSR	PC,\$ATY3	::SPOOL MESSAGE TO APT
025732	000000		61\$:	.WORD	0	::MESSAGE ADDRESS
025734	132737	000040 001231	62\$:	BITB	#APTCSP,\$ENV	::APT CONSOLE SUPPRESSED
025742	001003			BNE	60\$::YES,SKIP TYPE OUT
025744	112046		2\$:	MOVB	(RO)+,-(SP)	::PUSH CHARACTER TO BE TYPED ONTO STACK
025746	001005			BNE	4\$::BR IF IT ISN'T THE TERMINATOR
025750	005726			TST	(SP)+	::IF TERMINATOR POP IT OFF THE STACK
025752	012600		60\$:	MOV	(SP)+,RO	::RESTORE RO
025754	062716	000002	3\$:	ADD	#2,(SP)	::ADJUST RETURN PC
025760	000002			RTI		::RETURN
025762	122716	000011	4\$:	CMPB	#HT,(SP)	::BRANCH IF <HT>
025766	001430			BEQ	8\$	
025770	122716	000200		CMPB	#CRLF,(SP)	::BRANCH IF NOT <CRLF>
025774	001006			BNE	5\$	
025776	005726			TST	(SP)+	::POP <CR><LF> EQUIV
026000	104401			TYPE		::TYPE A CR AND LF
026002	001205			\$CRLF		
026004	105037	026212		CLRB	\$CHARCNT	::CLEAR CHARACTER COUNT
026010	000755			BR	2\$::GET NEXT CHARACTER
026012	004737	026074	5\$:	JSR	PC,\$TYPEC	::GO TYPE THIS CHARACTER
026016	123726	001172	6\$:	CMPB	\$FILLC,(SP)+	::IS IT TIME FOR FILLER CHARS.?
026022	001350			BNE	2\$::IF NO GO GET NEXT CHAR.
026024	013746	001170		MOV	\$NULL,-(SP)	::GET # OF FILLER CHARS. NEEDED
						::AND THE NULL CHAR.
026030	105366	000001	7\$:	DECB	1(SP)	::DOES A NULL NEED TO BE TYPED?
026034	002770			BLT	6\$::BR IF NO--GO POP THE NULL OFF OF STACK
026036	004737	026074		JSR	PC,\$TYPEC	::GO TYPE A NULL
026042	105337	026212		DECB	\$CHARCNT	::DO NOT COUNT AS A COUNT
026046	000770			BR	7\$::LOOP

:HORIZONTAL TAB PROCESSOR

026050	112716	000040		8\$:	MOVB	#' (SP)	::REPLACE TAB WITH SPACE
026054	004737	026074		9\$:	JSR	PC,\$TYPEC	::TYPE A SPACE
026060	132737	000007	026212		BITB	#7,\$CHARCNT	::BRANCH IF NOT AT
026066	001372				BNE	9\$::TAB STOP
026070	005726				TST	(SP)+	::POP SPACE OFF STACK
026072	000724				BR	2\$::GET NEXT CHARACTER
026074				\$TYPEC:			
026074	105777	153060			TSTB	@\$TKS	::CHAR IN KYBD BUFFER?
026100	100022				BPL	10\$::BR IF NOT
026102	017746	153054			MOV	@\$TKB, -(SP)	::GET CHAR
026106	042716	177600			BIC	#177600, (SP)	::STRIP EXTRANEIOUS BITS
026112	122716	000023			CMPS	#\$XOFF, (SP)	::WAS CHAR XOFF
026116	001012				BNE	102\$::BR IF NOT
026120				101\$:			
026120	105777	153034			TSTB	@\$TKS	::WAIT FOR CHAR
026124	100375				BPL	101\$	
026126	117716	153030			MOVB	@\$TKB, (SP)	::GET CHAR
026132	042716	177600			BIC	#177600, (SP)	::STRIP IT
026136	122716	000021			CMPS	#\$XON, (SP)	::WAS IT XON?
026142	001366				BNE	101\$::BR IF NOT
026144				102\$:			
026144	005726				TST	(SP)+	::FIX STACK
026146				10\$:			
026146	105777	153012			TSTB	@\$TPS	::WAIT UNTIL PRINTER IS READY
026152	100375				BPL	10\$	
026154	116677	000002	153004		MOVB	2(SP), @\$TPB	::LOAD CHAR TO BE TYPED INTO DATA REG.
026162	122766	000015	000002		CMPS	#CR, 2(SP)	::IS CHARACTER A CARRIAGE RETURN?
026170	001003				BNE	1\$::BRANCH IF NO
026172	105037	026212			CLRB	\$CHARCNT	::YES--CLEAR CHARACTER COUNT
026176	000406				BR	\$TYPEX	::EXIT
026200	122766	000012	000002	1\$:	CMPS	#LF, 2(SP)	::IS CHARACTER A LINE FEED?
026206	001402				BEQ	\$TYPEX	::BRANCH IF YES
026210	105227				INCB	(PC)+	::COUNT THE CHARACTER
026212	000000			\$CHARCNT: .WORD	0		::CHARACTER COUNT STORAGE
026214	000207			\$TYPEX: RTS	PC		

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOS      ;;CALL FOR TYPEOUT
*      .BYTE      N      ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*      .BYTE      M      ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS

```

```

*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC

```

```

*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPON      ;;CALL FOR TYPEOUT

```

```

*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER

```

```

*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOC      ;;CALL FOR TYPEOUT

```

026216	017646	000000		\$TYPOS:	MOV	@(SP),-(SP)	;;PICKUP THE MODE
026222	116637	000001	026441		MOVB	1(SP),\$OFILL	;;LOAD ZERO FILL SWITCH
026230	112637	026443			MOVB	(SP)+,\$OMODE+1	;;NUMBER OF DIGITS TO TYPE
026234	062716	000002			ADD	#2,(SP)	;;ADJUST RETURN ADDRESS
026240	000406				BR	\$TYPON	
026242	112737	000001	026441	\$TYPOC:	MOVB	#1,\$OFILL	;;SET THE ZERO FILL SWITCH
026250	112737	000006	026443		MOVB	#6,\$OMODE+1	;;SET FOR SIX(6) DIGITS
026256	112737	000005	026440	\$TYPON:	MOVB	#5,\$OCNT	;;SET THE ITERATION COUNT
026264	010346				MOV	R3,-(SP)	;;SAVE R3
026266	010446				MOV	R4,-(SP)	;;SAVE R4
026270	010546				MOV	R5,-(SP)	;;SAVE R5
026272	113704	026443			MOVB	\$OMODE+1,R4	;;GET THE NUMBER OF DIGITS TO TYPE
026276	005404				NEG	R4	
026300	062704	000006			ADD	#6,R4	;;SUBTRACT IT FOR MAX. ALLOWED
026304	110437	026442			MOVB	R4,\$OMODE	;;SAVE IT FOR USE
026310	113704	026441			MOVB	\$OFILL,R4	;;GET THE ZERO FILL SWITCH
026314	016605	000012			MOV	12(SP),R5	;;PICKUP THE INPUT NUMBER
026320	005003				CLR	R3	;;CLEAR THE OUTPUT WORD
026322	006105			1\$:	ROL	R5	;;ROTATE MSB INTO 'C'
026324	000404				BR	3\$;;GO DO MSB
026326	006105			2\$:	ROL	R5	;;FORM THIS DIGIT
026330	006105				ROL	R5	
026332	006105				ROL	R5	
026334	010503				MOV	R5,R3	
026336	006103			3\$:	ROL	R3	;;GET LSB OF THIS DIGIT
026340	105337	026442			DECB	\$OMODE	;;TYPE THIS DIGIT?
026344	100016				BPL	7\$;;BR IF NO
026346	042703	177770			BIC	#177770,R3	;;GET RID OF JUNK
026352	001002				BNE	4\$;;TEST FOR 0
026354	005704				TST	R4	;;SUPPRESS THIS 0?
026356	001403				BEQ	5\$;;BR IF YES
026360	005204			4\$:	INC	R4	;;DON'T SUPPRESS ANYMORE 0'S

026362	052703	000060		BIS	#'0,R3	::MAKE THIS DIGIT ASCII
026366	052703	000040	5\$:	BIS	#' ,R3	::MAKE ASCII IF NOT ALREADY
026372	110337	026436		MOV8	R3,8\$::SAVE FOR TYPING
026376	104401	026436		TYPE	8\$::GO TYPE THIS DIGIT
026402	105337	026440	7\$:	DECB	\$OCNT	::COUNT BY 1
026406	003347			BGT	2\$::BR IF MORE TO DO
026410	002402			BLT	6\$::BR IF DONE
026412	005204			INC	R4	::INSURE LAST DIGIT ISN'T A BLANK
026414	000744			BR	2\$::GO DO THE LAST DIGIT
026416	012605		6\$:	MOV	(SP)+,R5	::RESTORE R5
026420	012604			MOV	(SP)+,R4	::RESTORE R4
026422	012603			MOV	(SP)+,R3	::RESTORE R3
026424	016666	000002 000004		MOV	2(SP),4(SP)	::SET THE STACK FOR RETURNING
026432	012616			MOV	(SP)+,(SP)	
026434	000002			RTI		::RETURN
026436	000		8\$:	.BYTE	0	::STORAGE FOR ASCII DIGIT
026437	000			.BYTE	0	::TERMINATOR FOR TYPE ROUTINE
026440	000		\$OCNT:	.BYTE	0	::OCTAL DIGIT COUNTER
026441	000		\$OFILL:	.BYTE	0	::ZERO FILL SWITCH
026442	000000		\$OMODE:	.WORD	0	::NUMBER OF DIGITS TO TYPE

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

 *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
 *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
 *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
 *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
 *REPLACED WITH SPACES.

*CALL:

* MOV NUM,-(SP) ;:PUT THE BINARY NUMBER ON THE STACK
 * TYPDS ;:GO TO THE ROUTINE

026444				\$TYPDS:		
026444	010046			MOV	R0,-(SP)	::PUSH R0 ON STACK
026446	010146			MOV	R1,-(SP)	::PUSH R1 ON STACK
026450	010246			MOV	R2,-(SP)	::PUSH R2 ON STACK
026452	010346			MOV	R3,-(SP)	::PUSH R3 ON STACK
026454	010546			MOV	R5,-(SP)	::PUSH R5 ON STACK
026456	012746	020200		MOV	#20200,-(SP)	::SET BLANK SWITCH AND SIGN
026462	016605	000020		MOV	20(SP),R5	::GET THE INPUT NUMBER
026466	100004			BPL	1\$::BR IF INPUT IS POS.
026470	005405			NEG	R5	::MAKE THE BINARY NUMBER POS.
026472	112766	000055	000001	MOVB	#'-,1(SP)	::MAKE THE ASCII NUMBER NEG.
026500	005000			1\$: CLR	R0	::ZERO THE CONSTANTS INDEX
026502	012703	026660		MOV	#\$DBLK,R3	::SETUP THE OUTPUT POINTER
026506	112723	000040		MOVB	#',(R3)+	::SET THE FIRST CHARACTER TO A BLANK
026512	005002			2\$: CLR	R2	::CLEAR THE BCD NUMBER
026514	016001	026650		MOV	\$DTBL(R0),R1	::GET THE CONSTANT
026520	160105			3\$: SUB	R1,R5	::FORM THIS BCD DIGIT
026522	002402			BLT	4\$::BR IF DONE
026524	005202			INC	R2	::INCREASE THE BCD DIGIT BY 1
026526	000774			BR	3\$	
026530	060105			4\$: ADD	R1,R5	::ADD BACK THE CONSTANT
026532	005702			TST	R2	::CHECK IF BCD DIGIT-0
026534	001002			BNE	5\$::FALL THROUGH IF 0
026536	105716			TSTB	(SP)	::STILL DOING LEADING 0'S?
026540	100407			BMI	7\$::BR IF YES
026542	106316			5\$: ASLB	(SP)	::MSD?
026544	103003			BCC	6\$::BR IF NO
026546	116663	000001	177777	MOVB	1(SP),-1(R3)	::YES--SET THE SIGN
026554	052702	000060		6\$: BIS	#'0,R2	::MAKE THE BCD DIGIT ASCII
026560	052702	000040		7\$: BIS	#',R2	::MAKE IT A SPACE IF NOT ALREADY A DIGIT
026564	110223			MOVB	R2,(R3)+	::PUT THIS CHARACTER IN THE OUTPUT BUFFER
026566	005720			TST	(R0)+	::JUST INCREMENTING
026570	020027	000010		CMP	R0,#10	::CHECK THE TABLE INDEX
026574	002746			BLT	2\$::GO DO THE NEXT DIGIT
026576	003002			BGT	8\$::GO TO EXIT
026600	010502			MOV	R5,R2	::GET THE LSD
026602	000764			BR	6\$::GO CHANGE TO ASCII
026604	105726			8\$: TSTB	(SP)+	::WAS THE LSD THE FIRST NON-ZERO?
026606	100003			BPL	9\$::BR IF NO
026610	116663	177777	177776	MOVB	-1(SP),-2(R3)	::YES--SET THE SIGN FOR TYPING
026616	105013			9\$: CLRB	(R3)	::SET THE TERMINATOR
026620	012605			MOV	(SP)+,R5	::POP STACK INTO R5
026622	012603			MOV	(SP)+,R3	::POP STACK INTO R3
026624	012602			MOV	(SP)+,R2	::POP STACK INTO R2
026626	012601			MOV	(SP)+,R1	::POP STACK INTO R1

026630	012600		MOV	(SP)+,R0	::POP STACK INTO R0
026632	104401	026660	TYPE	,SDBLK	::NOW TYPE THE NUMBER
026636	016666	000002 000004	MOV	2(SP),4(SP)	::ADJUST THE STACK
026644	012616		MOV	(SP)+,(SP)	
026646	000002		RTI		::RETURN TO USER
026650	023420		\$DTBL:	10000.	
026652	001750			1000.	
026654	000144			100.	
026656	000012			10.	
026660			\$DBLK:	.BLKW 4	

.SBTTL \$SUPRS - TYPE ASCII, REPLACE LEADING 0'S WITH BLANKS
 .SBTTL \$SUPRL - TYPE ASCII, LEFT JUSTIFY

```

:CALL:
:      MOV      #NUMADR,-(SP)      ;FIRST ADDRESS OF ASCII STRING
:      JSR      PC,$SUPRS
:
:      OR
:      MOV      #NUMADR,-(SP)      ;FIRST ADDRESS OF ASCII STRING
:      JSR      PC,$SUPRL
:
$SUPRL: MOV      R0,-(SP)           ;SAVE R0
:      MOV      4(SP),R0           ;GET POINTER TO MESSAGE
:      CLR      $SUPR2
:      BR       $SUPR1
:
$SUPRS: MOV      R0,-(SP)           ;SAVE R0
:      MOV      4(SP),R0           ;GET POINTER TO MESSAGE
:      MOV      R0,$SUPR2          ;GET POINTER FOR TYPING
:
$SUPR1:
1$:    TSTB     (R0)               ;TEST FOR TERMINATOR
:      BEQ      2$                 ;YES
:      CMPB     #'0',(R0)          ;IS THIS A '0' ?
:      BNE      3$                 ;NO
:      MOVB     #40,(R0)+          ;REPLACE IT WITH A 'BLANK'
:      BR       1$                 ;NEXT CHAR.
2$:    DEC      R0                 ;BACKUP 1
:      MOVB     #'0',(R0)          ;MAKE IT '0'
3$:    TST      $SUPR2             ;LEFT JUSTIFY ?
:      BNE      4$                 ;NO
:      MOV      R0,$SUPR2          ;YES
4$:    TYPE     .WORD              0
$SUPR2: MOV      (SP)+,R0           ;RESTORE R0
:      MOV      (SP)+,(SP)         ;RESTORE STACK
:      RTS      PC

```

```

2
3
4
5
6
7
8
9
10
11
12 026670 010046
13 026672 016600 000004
14 026676 005037 026760
15 026702 000405
16
17 026704 010046
18 026706 016600 000004
19 026712 010037 026760
20 026716
21 026716 105710
22 026720 001406
23 026722 122710 000060
24 026726 001006
25 026730 112720 000040
26 026734 000770
27 026736 005300
28 026740 112710 000060
29 026744 005737 026760
30 026750 001002
31 026752 010037 026760
32 026756 104401
33 026760 000000
34 026762 012600
35 026764 012616
36 026766 000207

```



```

1
2
3
4
5
6
7
8
9
10
11 026770 005237 027076
12
13 026774 010046
14 026776 016600 000004
15 027002 005737 027076
16 027006 001014
17 027010 122710 000060
18 027014 001004
19 027016 112710 000040
20 027022 005200
21 027024 000771
22 027026 105710
23 027030 001003
24 027032 005300
25 027034 112710 000060
26 027040 016600 000004
27 027044 105720
28 027046 001376
29 027050 005300
30 027052 162500
31 027054 010037 027062
32 027060 104401
33 027062 000000
34 027064 012600
35 027066 012616
36 027070 005037 027076
37 027074 000205
38
39 027076 000000

;ROUTINE TO REPLACE LEADING ZEROS IN A NUMERIC STRING WITH SPACES
;CALL:
;      MOV      #ADR, -(SP)      ;ADDRESS OF NUMBER (IN ASCII)
;      JSR      R5, REPLZ        ;REPLACE PRECEDING ZEROS WITH BLANKS
;      .WORD    N                ;'N' IS NUMBER OF DIGITS TO BE TYPED
;      OR
;      MOV      #ADR, -(SP)      ;ADDRESS OF NUMBER (IN ASCII)
;      JSR      R5, FILLZ        ;TYPE PRECEDING ZEROS
;      .WORD    N                ;'N' IS NUMBER OF DIGITS TO BE TYPED
FILLZ: INC      FILL0            ;LEAVE ZERO'S
REPLZ: MOV      R0, -(SP)        ;SAVE R0
      MOV      4(SP), R0        ;ADDRESS OF NUMBER TO R0
      TST      FILL0            ;LEAVE PRECEDING ZEROS ?
      BNE      3$               ;BR IF YES
1$: CMPB      #'0', (R0)        ;BYTE EQUAL TO ASCII '0' ?
      BNE      2$               ;BR IF NOT
      MOVB     #40, (R0)        ;REPLACE THE ZERO WITH A SPACE
      INC      R0               ;INCREMENT THE BYTE ADDRESS
      BR       1$              ;GO BACK AND LOOK FOR MORE LEADING ZEROS
2$: TSTB      (R0)              ;SEE IF ZERO BYTE TERMINATOR
      BNE      3$               ;BR IF NOT
      DEC      R0               ;BACKUP STRING POINTER
      MOVB     #'0', (R0)      ;PUT A ZERO BACK IN
3$: MOV      4(SP), R0          ;PUT ADDRESS OF FIRST CHARACTER ON STACK
4$: TSTB      (R0)+              ;SEE IF ZERO BYTE TERMINATOR
      BNE      4$               ;BR IF NOT
      DEC      R0               ;BACKUP STRING POINTER
      SUB      (R5)+, R0        ;ADJUST ADDRESS
      MOV      R0, 5$           ;GET ADDRESS FOR TYPEOUT
      TYPE     5$               ;TYPE THE NUMBER
5$: .WORD     0                 ;ADDRESS OF NUMBER
      MOV      (SP)+, R0        ;POP STACK INTO R0
      MOV      (SP)+, (SP)      ;RESTORE STACK
      CLR      FILL0            ;RESET FILL FLAG
      RTS      R5               ;RETURN
FILL0: .WORD     0              ;IF SET, LEAVE PRECEDING ZEROS FOR TYPE

```

.SBTTL SINGLE LENGTH BINARY TO DECIMAL ASCII ROUTINE

 *THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
 *UNSIGNED DECIMAL ASCII NUMBER.

*CALL
 * MOV NUMBER, -(SP) ;;PUT BINARY NUMBER ON THE STACK
 * JSR PC, @#\$SB2D ;;CALL
 * RETURN ;;ADDRESS OF THE 1ST ASCII CHAR. IS ON THE STACK

027100	016637	000002	027130	\$SB2D:	MOV	2(SP), 1\$::SAVE BINARY NUMBER
027106	012746	027130			MOV	#1\$, -(SP)	::SET POINTER
027112	004737	027134			JSR	PC, @#\$DB2D	::CALL DOUBLE LENGTH CONVERT
027116	062716	000005			ADD	#5, (SP)	::ONLY ALLOW FIVE CHARACTERS
027122	012666	000032			MOV	(SP)+, 2(SP)	::PICKUP POINTER
027126	000207				RTS	PC	::RETURN
027130	000000	000000		1\$:	.WORD	0,0	

SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE

 *THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
 *DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
 *POSITIVE.
 *CALL

MOV #PNTR, -(SP) ;; POINTER TO LOW WORD OF BINARY NUMBER
 JSR PC, @#SDB2D
 RETURN ;; THE FIRST ADDRESS OF ASCII
 ;; IS ON THE STACK

027134	104412		\$DB2D:	SAVREG	;;SAVE REGISTERS
027136	016602	000002		MOV 2(SP), R2	;;PICKUP THE DATA POINTER
027142	012700	027314		MOV #SDECVL, R0	;;GET ADDRESS OF 'SDECVL' STRING
027146	010066	000002		MOV R0, 2(SP)	;;PUT ADDRESS OF ASCII STRING ON STACK
027152	012201			MOV (R2)+, R1	;;PICKUP THE BINARY NUMBER
027154	012202			MOV (R2)+, R2	
027156	012737	0C0012	027232	MOV #10, 4\$;;SET UP TO DO 10 CONVERSIONS
027164	012704	027244		MOV #STNPWR, R4	;;ADDRESS OF TEN POWER
027170	012705	027246		MOV #STNPWR+2, R5	
027174	005003		1\$:	CLR R3	;;CLEAR PARTIAL
027176	161401		2\$:	SUB (R4), R1	;;SUBTRACT TEN POWER
027200	005602			SBC R2	
027202	161502			SUB (R5), R2	
027204	002402			BLT 3\$;;BR IF TEN POWER TOO LARGE
027206	005203			INC R3	;;ADD 1 TO PARTIAL
027210	000772			BR 2\$;;LOOP
027212	062401		3\$:	ADD (R4)+, R1	;;RESTORE SUBTRACTED VALUE
027214	005502			ADC R2	
027216	062402			ADD (R4)+, R2	
027220	022525			CMP (R5)+, (R5)+	;;MOVE TO NEXT TEN POWER
027222	052703	000060		BIS #0, R3	;;CHANGE PARTIAL TO ASCII
027226	110320			MOVB R3, (R0)+	;;SAVE IT
027230	005327			DEC (PC)+	;;DONE?
027232	000000		4\$:	.WORD 0	
027234	001357			BNE 1\$;;BR IF NO
027236	105020			CLRB (R0)+	;;TERMINATOR
027240	104413			RESREG	;;RESTORE REGISTERS
027242	000207			RTS PC	;;RETURN
027244	145000		\$TNPWR:	145000	;;1.0E09
027246	035632			35632	
027250	160400			160400	;;1.0E08
027252	002765			2765	
027254	113200			113200	;;1.0E07
027256	000230			230	
027260	041100			041100	;;1.0E06
027262	000017			17	
027264	103240			103240	;;1.0E05
027266	000001			1	
027270	023420			23420	;;1.0E04
027272	000000			0	
027274	001750			1750	;;1.0E03
027276	000000			0	
027300	000144			144	;;1.0E02
027302	000000			0	

027304 000012
027306 000000
027310 000001
027312 000000
027314

12
0
1
0
\$DECL: .BLKB 12.

::1.0E01
::1.0E00
::RESERVE STORAGE FOR ASCII STRING

.SBTTL SINGLE LENGTH BINARY TO OCTAL ASCII ROUTINE

```

*****
;THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
;UNSIGNED OCTAL ASCII NUMBER.
;CALL
;*      MOV      NUMBER, -(SP)      ;;PUT BINARY NUMBER ON THE STACK
;*      JSR      PC, @#$SB20      ;;CALL
;*      RETURN    ;;ADDRESS OF 1ST ASCII CHAR. IS ON THE STACK
  
```

027330	016637	000002	027360	\$SB20:	MOV	2(SP), 1\$::SAVE THE BINARY NUMBER
027336	012746	027360			MOV	#1\$, -(SP)	::SET POINTER
027342	004737	027364			JSR	PC, @#\$DB20	::CALL DOUBLE LENGTH CONVERT ROUTINE
027346	062716	000005			ADD	#5, (SP)	::ONLY ALLOW SIX CHARACTERS
027352	012666	000002			MOV	(SP)+, 2(SP)	::PICKUP POINTER
027356	000207				RTS	PC	::RETURN
027360	000000	000000		1\$:	.WORD	0,0	

.SBTTL DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE

 : THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
 : UNSIGNED OCTAL ASCIIZ NUMBER.

: CALL
 : * MOV #PNTR, -(SP) :: POINTER TO LOW WORD OF BINARY NUMBER
 : * JSR PC, @#SDB20 :: CALL THE ROUTINE
 : * RETURN :: THE ADDRESS OF THE FIRST ASCIIZ CHAR. IS ON THE STACK

027364	104412		\$DB20:	SAVREG	:: SAVE ALL REGISTERS
027366	016601	000002		MOV 2(SP), R1	:: PICKUP THE POINTER TO LOW WORD
027372	012705	027503		MOV #SDB20+13., R5	:: POINTER TO DATA TABLE
027376	012704	000014		MOV #12., R4	:: DO ELEVEN CHARACTERS
027402	012703	177770		MOV #^C7, R3	:: MASK
027406	012100			MOV (R1)+, R0	:: LOWER WORD
027410	012101			MOV (R1)+, R1	:: HIGH WORD
027412	005002			CLR R2	:: TERMINATOR
027414	110245		1\$:	MOVB R2, -(R5)	:: PUT CHARACTER IN DATA TABLE
027416	010002			MOV R0, R2	:: GET THIS DIGIT
027420	005304			DEC R4	:: COUNT THIS CHARACTER
027422	003007			BGT 3\$:: BR IF NOT THE LAST DIGIT
027424	001405			BEQ 2\$:: BR IF IT IS THE LAST DIGIT
027426	005205			INC R5	:: ALL DIGITS DONE-ADJUST POINTER FOR FIRST
027430	010566	000002		MOV R5, 2(SP)	:: ASCIIZ CHAR. & PUT IT ON THE STACK
027434	104413			RESREG	:: RESTORE ALL REGISTERS
027436	000207			RTS PC	:: RETURN TO USER
027440	006203		2\$:	ASR R3	:: POSITION THE MASK FOR THE LAST DIGIT
027442	006001		3\$:	ROR R1	:: POSITION THE BINARY NUMBER FOR
027444	006000			ROR R0	:: THE NEXT OCTAL DIGIT
027446	006000			ROR R1	
027450	006000			ROR R0	
027452	006001			ROR R1	
027454	006000			ROR R0	
027456	040302			BIC R3, R2	:: MASK OUT ALL JUNK
027460	062702	000060		ADD #0, R2	:: MAKE THIS CHAR. ASCII
027464	000753			BR 1\$:: GO PUT IT IN THE DATA TABLE
027466			\$OCTVL:	.BLKB 14.	:: RESERVE DATA TABLE

.SBTTL APT COMMUNICATIONS ROUTINE

```

027504 112737 000001 027750 *****
027512 112737 000001 027746 SATY1: MOVB #1,$FFLG ;;TO REPORT FATAL ERROR
027520 000403 SATY3: MOVB #1,$MFLG ;;TO TYPE A MESSAGE
027522 112737 000001 027750 SATY4: MOVB #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
027530 SATYC:
027530 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
027532 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
027534 105737 027746 TSTB $MFLG ;;SHOULD TYPE A MESSAGE?
027540 001450 BEQ 5$ ;;IF NOT: BR
027542 122737 000001 001230 CMPB #APTENV,$ENV ;;OPERATING UNDER APT?
027550 001031 BNE 3$ ;;IF NOT: BR
027552 132737 000100 001231 BITB #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
027560 001425 BEQ 3$ ;;IF NOT: BR
027562 017600 000004 MOV @4(SP),R0 ;;GET MESSAGE ADDR.
027566 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
027574 005737 001210 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
027600 001375 BNE 1$ ;;IF NOT: WAIT
027602 010037 001224 MOV R0,$MSGAD ;;PUT ADDR IN MAILBOX
027606 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
027610 001376 BNE 2$
027612 163700 001224 SUB $MSGAD,R0 ;;SUB START OF MESSAGE
027616 006200 ASR R0 ;;GET MESSAGE LNTH IN WORDS
027620 010037 001226 MOV R0,$MSGGLT ;;PUT LENGTH IN MAILBOX
027624 012737 000004 001210 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
027632 000413 BR 5$
027634 017637 000004 027660 3$: MOV @4(SP),4$ ;;PL' MSG ADDR IN JSR LINKAGE
027642 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
027650 013746 177776 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
027654 004737 025662 JSR PC,$TYPE ;;CALL TYPE MACRO
027660 000000 4$: .WORD 0
027662 5$:
027662 105737 027750 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
027666 001416 BEQ 12$ ;;IF NOT: BR
027670 005737 001230 TST $ENV ;;RUNNING UNDER APT?
027674 001413 BEQ 12$ ;;IF NOT: BR
027676 005737 001210 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
027702 001375 BNE 11$ ;;IF NOT: WAIT
027704 017637 000004 001212 MOV @4(SP),$FATAL ;;GET ERROR #
027712 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
027720 005237 001210 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
027724 105037 027750 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
027730 105037 027747 CLRB $LFLG ;;CLEAR LOG FLAG
027734 105037 027746 CLRB $MFLG ;;CLEAR MESSAGE FLAG
027740 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
027742 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
027744 000207 RTS PC ;;RETURN
027746 000 $MFLG: .BYTE 0 ;;MESSG. FLAG
027747 000 $LFLG: .BYTE 0 ;;LOG FLAG
027750 000 $FFLG: .BYTE 0 ;;FATAL FLAG
000200 .EVEN
000001 APTSIZE = 200
000100 APTENV = 001
000040 APTSPOOL = 100
APTCSUP = 040

```

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES

```

*****
;SAVE R0-R5
;CALL:
;    SAVREG
;UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
;
;TOP---(+16)
;+2---(+18)
;+4---R5
;+6---R4
;+8---R3
;+10---R2
;+12---R1
;+14---R0

```

```

027752
027752 010046
027754 010146
027756 010246
027760 010346
027762 010446
027764 010546
027766 016646 000022
027772 016646 000022
027776 016646 000022
030002 016646 000022
030006 000002

```

```

$SAVREG:
MOV R0,-(SP)    ;;PUSH R0 ON STACK
MOV R1,-(SP)    ;;PUSH R1 ON STACK
MOV R2,-(SP)    ;;PUSH R2 ON STACK
MOV R3,-(SP)    ;;PUSH R3 ON STACK
MOV R4,-(SP)    ;;PUSH R4 ON STACK
MOV R5,-(SP)    ;;PUSH R5 ON STACK
MOV 22(SP),-(SP) ;;SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP) ;;SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP) ;;SAVE PS OF CALL
MOV 22(SP),-(SP) ;;SAVE PC OF CALL
RTI

```

```

;RESTORE R0-R5
;CALL:
;    RESREG

```

```

030010
030010 012666 000022
030014 012666 000022
030020 012666 000022
030024 012666 000022
030030 012605
030032 012604
030034 012603
030036 012602
030040 012601
030042 012600
030044 000002

```

```

$RESREG:
MOV (SP)+,22(SP) ;;RESTORE PC OF CALL
MOV (SP)+,22(SP) ;;RESTORE PS OF CALL
MOV (SP)+,22(SP) ;;RESTORE PC OF MAIN FLOW
MOV (SP)+,22(SP) ;;RESTORE PS OF MAIN FLOW
MOV (SP)+,R5     ;;POP STACK INTO R5
MOV (SP)+,R4     ;;POP STACK INTO R4
MOV (SP)+,R3     ;;POP STACK INTO R3
MOV (SP)+,R2     ;;POP STACK INTO R2
MOV (SP)+,R1     ;;POP STACK INTO R1
MOV (SP)+,R0     ;;POP STACK INTO R0
RTI

```


.SBTTL TRAP DECODER

```

;*****
;THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
;AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
;OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
;GO TO THAT ROUTINE.

```

030046 010046
030050 016600 000002
030054 005740
030056 111000
030060 006300
030062 016000 030102
030066 000200

```

$TRAP:  MOV    R0,-(SP)      ;;SAVE R0
        MOV    2(SP),R0     ;;GET TRAP ADDRESS
        TST    -(R0)        ;;BACKUP BY 2
        MOVB   (R0),R0      ;;GET RIGHT BYTE OF TRAP
        ASL    R0           ;;POSITION FOR INDEXING
        MOV    $TRPAD(R0),R0 ;;INDEX TO TABLE
        RTS    R0          ;;GO TO ROUTINE

```

;;THIS IS USE TO HANDLE THE "GETPRI" MACRO

030070 011646
030072 016666 000004 000002
030100 000002

```

$TRAP2: MOV    (SP),-(SP)    ;;MOVE THE PC DOWN
        MOV    4(SP),2(SP)  ;;MOVE THE PSW DOWN
        RTI                    ;;RESTORE THE PSW

```

.SBTTL TRAP TABLE

```

;THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
;BY THE "TRAP" INSTRUCTION.

```

	ROUTINE	
030102 030070	-----	
030104 025662	\$TRPAD: .WORD \$TRAP2	
030106 026242	\$TYPE ::CALL TYPE	TRAP+1(104401) TTY TYPEOUT ROUTINE
030110 026216	\$TYPOC ::CALL=TYPOC	TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
030112 026256	\$TYPOS ::CALL=TYPOS	TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
030114 026444	\$TYPON ::CALL=TYPON	TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
	\$TYPDS ::CALL=TYPDS	TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
030116 025004	\$GTSWR ::CALL=GTSWR	TRAP+6(104406) GET SOFT-SWR SETTING
030120 024714	\$CKSWR ::CALL=CKSWR	TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
030122 025256	\$RDCHR ::CALL=RDCHR	TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
030124 025346	\$RDLIN ::CALL=RDLIN	TRAP+11(104411) TTY TYPEIN STRING ROUTINE
030126 027752	\$SAVREG ::CALL=SAVREG	TRAP+12(104412) SAVE R0-R5 ROUTINE
030130 030010	\$RESREG ::CALL=RESREG	TRAP+13(104413) RESTORE R0-R5 ROUTINE

.SBTTL POWER DOWN AND UP ROUTINES

POWER DOWN ROUTINE

030132	012737	030276	000024	\$PWRDN: MOV	#\$ILLUP,@#PWRVEC	::SET FOR FAST UP
030140	012737	000340	000026	MOV	#340,@#PWRVEC+2	::PRIO:7
030146	010046			MOV	R0,-(SP)	::PUSH R0 ON STACK
030150	010146			MOV	R1,-(SP)	::PUSH R1 ON STACK
030152	010246			MOV	R2,-(SP)	::PUSH R2 ON STACK
030154	010346			MOV	R3,-(SP)	::PUSH R3 ON STACK
030156	010446			MOV	R4,-(SP)	::PUSH R4 ON STACK
030160	010546			MOV	R5,-(SP)	::PUSH R5 ON STACK
030162	017746	150766		MOV	@SWR,-(SP)	::PUSH @SWR ON STACK
030166	010637	030302		MOV	SP,\$SAVR6	::SAVE SP
030172	012737	030204	000024	MOV	#\$PWRUP,@#PWRVEC	::SET UP VECTOR
030200	000000			HALT		
030202	000776			BR	.-2	::HANG UP

POWER UP ROUTINE

030204	012737	030276	000024	\$PWRUP: MOV	#\$ILLUP,@#PWRVEC	::SET FOR FAST DOWN
030212	013706	030302		MOV	\$SAVR6,SP	::GET SP
030216	005037	030302		CLR	\$SAVR6	::WAIT LOOP FOR THE TTY
030222	005237	030302		1\$: INC	\$SAVR6	::WAIT FOR THE INC
030226	001375			BNE	1\$::OF WORD
030230	012677	150720		MOV	(SP)+,@SWR	::POP STACK INTO @SWR
030234	012605			MOV	(SP)+,R5	::POP STACK INTO R5
030236	012604			MOV	(SP)+,R4	::POP STACK INTO R4
030240	012603			MOV	(SP)+,R3	::POP STACK INTO R3
030242	012602			MOV	(SP)+,R2	::POP STACK INTO R2
030244	012601			MOV	(SP)+,R1	::POP STACK INTO R1
030246	012600			MOV	(SP)+,R0	::POP STACK INTO R0
030250	012737	030132	000024	MOV	#\$PWRDN,@#PWRVEC	::SET UP THE POWER DOWN VECTOR
030256	012737	000340	000026	MOV	#340,@#PWRVEC+2	::PRIO:7
030264	104401			TYPE		::REPORT THE POWER FAILURE
030266	030304			\$PWRMG: .WORD	\$POWER	::POWER FAIL MESSAGE POINTER
030270	012716			MOV	(PC)+,(SP)	::RESTART AT ST3
030272	013056			\$PWRAD: .WORD	ST3	::RESTART ADDRESS
030274	000002			RTI		
030276	000000			\$ILLUP: HALT		::THE POWER UP SEQUENCE WAS STARTED
030300	000776			BR	.-2	::BEFORE THE POWER DOWN WAS COMPLETE
030302	000000			\$SAVR6: 0		::PUT THE SP HERE
030304	200	042	120	\$POWER: .ASCII	<CR LF>/'POWER UP'/	
				.EVEN		

2
3

.SBTTL SINGLE/DUAL PORT RH/RM DRIVER (REV 6.5) 1981

;NEW DRIVE TYPE ID FOR RM02 *****
 ;10-AUG-77 *****
 ;10-MAR-78 THE SC, SC5 CHANGES
 ;NEW DRIVE TYPE ID FOR RM05 *****
 ;1980 *****

;COPYRIGHT (C) 1977,1981
 ;DIGITAL EQUIPMENT CORP.
 ;MAYNARD, MA 01754
 ;AUTHOR(S): JIM LACEY/CHUCK HESS
 ;REVISED BY: MIKE LEAVITT 11-APR-80, 27-MAR-81

;;*****

;STORAGE FOR RMDS, RMER1, RMER2, AND RMMR2 ON AN ERROR '2'
 ;RMERRS - RMDS
 ;RMERRS+2 = RMER1
 ;RMERRS+4 = RMER2
 ;RMERRS+6 = RMMR2

030320 000000 000000 000000 RMERRS: .WORD 0,0,0,0

;TABLE OF DRIVE ACTIVE INDICATORS (DRVACT=8 BYTES)
 ;DRVACT=0 IF DRIVE IS IDLE
 ;DRVACT>0 IF DRIVE IS ACTIVE WITH A COMMAND
 ;DRVACT<0 IF DRIVE IS ACTIVE WITH AN ERROR RECOVERY OPERATION

030330	000	DRVACT: .BYTE 0	;DRIVE 0
030331	000	.BYTE 0	;DRIVE 1
030332	000	.BYTE 0	;DRIVE 2
030333	000	.BYTE 0	;DRIVE 3
030334	000	.BYTE 0	;DRIVE 4
030335	000	.BYTE 0	;DRIVE 5
030336	000	.BYTE 0	;DRIVE 6
030337	000	.BYTE 0	;DRIVE 7

;TABLE OF DRIVE STATUS INDICATORS (DRVSTA 8 BYTES)
 ;DRVSTA=0 IF DRIVE IS OFFLINE OR NONEXISTENT
 ;DRVSTA>0 IF DRIVE IS ONLINE
 ;DRVSTA<0 IF DRIVE IS UNSAFE

030340	000	DRVSTA: .BYTE 0	;DRIVE 0
030341	000	.BYTE 0	;DRIVE 1
030342	000	.BYTE 0	;DRIVE 2
030343	000	.BYTE 0	;DRIVE 3
030344	000	.BYTE 0	;DRIVE 4
030345	000	.BYTE 0	;DRIVE 5
030346	000	.BYTE 0	;DRIVE 6
030347	000	.BYTE 0	;DRIVE 7

;TABLE OF DRIVE TYPES (DRVTYPE=8 BYTES)
 ;DRVTYPE=0 IF DRIVE IS NONEXISTENT (DRVSTA=0, ALSO)
 ;DRVTYPE=7 IF DRIVE IS RM05 *****
 ;DRVTYPE 5 IF DRIVE IS RM02 *****
 ;DRVTYPE=4 IF DRIVE IS RM03

```

50          ;DRVTYPE=-1 IF NOT RM05/3/2
51
52 030350      000      DRVTYPE: .BYTE 0          ;DRIVE 0
53 030351      000          .BYTE 0          ;DRIVE 1
54 030352      000          .BYTE 0          ;DRIVE 2
55 030353      000          .BYTE 0          ;DRIVE 3
56 030354      000          .BYTE 0          ;DRIVE 4
57 030355      000          .BYTE 0          ;DRIVE 5
58 030356      000          .BYTE 0          ;DRIVE 6
59 030357      000          .BYTE 0          ;DRIVE 7
60
61          ;TABLE OF DUAL PORT INITIALIZATION INDICATORS
62          ;DPINT=0 IF INITIALIZATION IS NOT ACTIVE ON THE DRIVE
63          ;DPINT<0 IF INITIALIZATION IS IN PROGRESS
64
65 DPINT:      .BYTE 0          ;DRIVE 0
66          .BYTE 0          ;DRIVE 1
67          .BYTE 0          ;DRIVE 2
68          .BYTE 0          ;DRIVE 3
69          .BYTE 0          ;DRIVE 4
70          .BYTE 0          ;DRIVE 5
71          .BYTE 0          ;DRIVE 6
72          .BYTE 0          ;DRIVE 7
73
74          ;TABLE OF PENDING DUAL PORT REQUESTS
75          ;DPRQS=0 IF THAT A DUAL PORT REQUEST IS NOT PENDING FOR THAT DRIVE
76          ;DPRQS<0 IF THAT A DUAL PORT REQUEST IS PENDING FOR THAT DRIVE
77
78 DPRQS:      .BYTE 0          ;DRIVE 0
79          .BYTE 0          ;DRIVE 1
80          .BYTE 0          ;DRIVE 2
81          .BYTE 0          ;DRIVE 3
82          .BYTE 0          ;DRIVE 4
83          .BYTE 0          ;DRIVE 5
84          .BYTE 0          ;DRIVE 6
85          .BYTE 0          ;DRIVE 7
86
87          ;TRANSFER WAIT FLAG (TRNSWT=1 WORD)
88          ;THIS IS A ONE WORD QUEUE. IT WILL CONTAIN THE ADDRESS OF
89          ;'DPB' OF THE I/O OPERATION.
90
91 TRNSWT:      .WORD 0
92
93          ;SEARCH WAIT KEYS (SRCHWT=1 WORD)
94          ;THIS IS A ONE WORD QUEUE THAT WILL CONTAIN A KEY FOR EACH OF
95          ;THE DRIVES THAT ARE PERFORMING A SEARCH COMMAND FOR THE I/O
96          ;REQUEST THAT IS AT THE TOP OF THEIR REQUEST QUEUE.
97          ;EACH DRIVE IS ASSIGNED ONE BIT, STARTING AT BIT00 FOR DRIVE 0.
98
99 SRCHWT:      .WORD 0
100
101          ;RM DRIVER ACTIVE FLAG (ACTDRV=1 BYTE)
102          ;ACTDRV=0 IF DRIVER IS INACTIVE
103          ;ACTDRV>0 IF DRIVER IS ACTIVE
104
105 ACTDRV:      .BYTE 0
  
```

```

95      ;SOFTWARE TIMER ROUTINE ACTIVE FLAG (ACTSTR=1 BYTE)
96      ;ACTSTR=0 IF SOFTWARE TIMER ROUTINE IS INACTIVE
97      ;ACTSTR>0 IF SOFTWARE TIMER ROUTINE IS ACTIVE
98
99 030405      000      ACTSTR: .BYTE      0
100
101      ;UNLOAD FLAG (ULDFLG=8 BYTES)
102      ;ULDFLG=0 IF NO UNLOAD COMMAND
103      ;ULDFLG>0 IF UNLOAD COMMAND IN PROGRESS
104      ;ULDFLG<0 IF UNLOAD COMMAND IN WAIT QUEUE
105
106 030406      000      ULDFLG: .BYTE      0      ;DRIVE 0
107 030407      000      .BYTE      0      ;DRIVE 1
108 030410      000      .BYTE      0      ;DRIVE 2
109 030411      000      .BYTE      0      ;DRIVE 3
110 030412      000      .BYTE      0      ;DRIVE 4
111 030413      000      .BYTE      0      ;DRIVE 5
112 030414      000      .BYTE      0      ;DRIVE 6
113 030415      000      .BYTE      0      ;DRIVE 7
114
115      ;SAVE REGISTERS FLAG (SAVEFG -1 WORD)
116      ;SAVEFG <0 IF SAVE THE RH/RM REGISTERS WHEN THE
117      ;OPERATION IS COMPLETED AS PER (DPB+14).
118      ;SAVEFG=0 IF SAVE THE RH/RM REGISTERS, AS PER
119      ;(DPB+14), AFTER AN ERROR.
120
121 030416      000000    SAVEFG: .WORD      0
122
123      ;SEEK FLAG (SEEKFG-1 WORD)
124      ;SEEKFG=0 IF WHEN THE DISK ADDRESS ISN'T IN THE WINDOW
125      ;FOR A DATA TRANSFER START A SEARCH COMMAND
126      ;SEEKFG<0 IF DATA TRANSFER WILL DO IMPLIED SEEKS,
127      ;DISREGARD THE WINDOW
128
129 030420      177777    SEEKFG: .WORD     -1
130
131      ;TIMEOUT TABLE (TIMER=8 WORDS)
132      ;THIS TABLE CONTAINS THE TIME ALLOWED FOR AN OPERATION
133
134 030422      177777    TIMER:   .WORD     -1      ;DRIVE 0
135 030424      177777    .WORD     -1      ;DRIVE 1
136 030426      177777    .WORD     -1      ;DRIVE 2
137 030430      177777    .WORD     -1      ;DRIVE 3
138 030432      177777    .WORD     -1      ;DRIVE 4
139 030434      177777    .WORD     -1      ;DRIVE 5
140 030436      177777    .WORD     -1      ;DRIVE 6
141 030440      177777    .WORD     -1      ;DRIVE 7
142
143      ;DATA TRANSFER UNDERWAY INDICATOR (DTUW=1 WORD)
144      ;DTUW<0 IF NO DATA TRANSFER UNDERWAY
145      ;DTUW=+N (WHERE N=0 TO 7) IMPLIES DATA TRANSFER UNDERWAY ON DRIVE N
146
147 030442      177777    DTUW:    .WORD     -1
148
149      ;ATTENTION BITS TABLE (ATABIT=8 BYTES)
150      ;THIS TABLE CONTAINS THE CORRESPONDING BIT TO EACH DRIVES
151      ;ATTENTION BIT

```

```

144
145 030444      001      ATABIT: .BYTE 1      ;DRIVE 0
146 030445      002      .BYTE 2      ;DRIVE 1
147 030446      004      .BYTE 4      ;DRIVE 2
148 030447      010      .BYTE 10     ;DRIVE 3
149 030450      020      .BYTE 20     ;DRIVE 4
150 030451      040      .BYTE 40     ;DRIVE 5
151 030452      100      .BYTE 100    ;DRIVE 6
152 030453      200      .BYTE 200    ;DRIVE 7
153
154      ;NUMBER OF 'MASSBUS CONTROL PARITY ERRORS' (MCPE) ALLOWED BEFORE
155      ;CALLING IT FATAL (MCPEMX=1 WORD)
156
157 030454      000003    MCPEMX: .WORD 3
158
159      ;STORAGE FOR RMADR (THE FIRST ADDRESS (776700) OF THE RH/RM),
160      ;RMVEC (THE VECTOR ADDRESS (254)), AND RMVEC+2 (THE BR LEVEL (5)).
161
162 030456      176700    RMADR: .WORD 176700
163 030460      000254    RMVEC: .WORD 254,5*32.
164      000240
165
166      ;MAXIMUM SEARCH FOR I/O WINDOW IS 5 SECTORS (MXWNDW 1 WORD)
167
168 030464      000005    MXWNDW: .WORD 5
169
170      ;DEFINITIONS OF THE RH/RM ADDRESS INDEXES
171
172
173      000000    RMCS1      0      ;CONTROL AND STATUS REGISTER #1 (DRIVE REG. 0)
174      000002    RMWC      2      ;WORD COUNT REGISTER (NOT A DRIVE REG)
175      000004    RMBA      - 4     ;UNIBUS ADDRESS REGISTER (NOT A DRIVE REG)
176      000006    RMDA      - 6     ;DESIRED SECTOR/TRACK ADDRESS REGISTER (DRIVE REG. 5)
177      000010    RMCS2     = 10    ;CONTROL AND STATUS REGISTER #2 (NOT A DRIVE REG)
178      000012    RMDS      - 12    ;DRIVE STATUS REGISTER (DRIVE REG 1)
179      000014    RMER1     - 14    ;ERROR REGISTER #1 (DRIVE REG. 2)
180      000016    RMAS      - 16    ;ATTENTION SUMMARY PSEUDO REGISTER (DRIVE REG. 4)
181      000020    RMLA      = 20    ;LOOK AHEAD REGISTER (DRIVE REG. 7)
182      000022    RMDB      - 22    ;DATA BUFFER REGISTER (NOT A DRIVE REG.)
183      000024    RMMR1     - 24    ;MAINTAINABILITY REGISTER (DRIVE REG. 3)
184      000026    RMDT      - 26    ;DRIVE TYPE REGISTER (DRIVE REG. 6)
185      000030    RMSN      - 30    ;SERIAL NUMBER REGISTER (DRIVE REG. 10)
186      000032    RMOF      - 32    ;OFFSET REGISTER (DRIVE REG. 11)
187      000034    RMDC      = 34    ;DESIRED CYLINDER ADDRESS REGISTER (DRIVE REG. 12)
188      000036    RMHR      - 36    ;DUMMY ADDRESS REGISTER (DRIVE REG. 13)
189      000040    RMMR2     40      ;MAINTENANCE REGISTER #2
190      000042    RMER2     42      ;ERROR REGISTER #2 (DRIVE REG. 15)
191      000044    RMEC1     44      ;ECC POSITION REGISTER (DRIVE REG. 16)
192      000046    RMEC2     = 46    ;ECC PATTERN REGISTER (DRIVE REG. 17)
193
194      .SBTTL RH/RM DRIVER INITIALIZATION CODE
195
196
197
198
199
200      ;THIS ROUTINE WILL DETERMINE WHICH RM DRIVES ARE
201      ;AVAILABLE FOR TESTING AND SET THE DRVSTA INDICATOR
202      ;TO THE PROPER STATE FOR EACH DRIVE.
203      ;NOTE: THIS ROUTINE CALLS DRVINT
204      ;
205      ;CALL
206      ;
207      ;      JSR      PC,RMINIT
  
```

```

208      :      RETURN
209      :
210      :NOTE: THE 'P' OR 'L' CLOCK MUST BE STARTED
211      :
212
213 030466 104412      RMINIT: SAVREG      ;SAVE R0 - R5
214 030470 013746 177776      MOV      PS,-(SP)      ;SAVE THE PRESENT PROCESSOR STATUS
215 030474 012737 000240 177776      MOV      #<5*32.>,PS      ;CHANGE THE PRIORITY TO 5
216 030502 004737 036144      JSR      PC,CLRQUE      ;CLEAR ALL REQUEST QUEUES
217 030506 012701 030320      MOV      #RMERRS,R1      ;FIRST ADDRESS TO BE CLEARED
218 030512 012702 030420      MOV      #SEEKFG,R2      ;LAST ADDRESS TO BE CLEARED
219 030516 005021      1$:      CLR      (R1)+      ;CLEAR
220 030520 020102      CMP      R1,R2      ;ARE WE DONE?
221 030522 103775      BLO      1$      ;BR IF NO
222 030524 012702 030442      MOV      #DTUW,R2      ;LAST ADDRESS
223 030530 012721 177777      2$:      MOV      #-1,(R1)+      ;INITIALIZE
224 030534 020102      CMP      R1,R2      ;DONE?
225 030536 101774      BLOS      2$      ;LOOP IF NO
226 030540 005037 030340      CLR      DRVSTA      ;SET ALL DRIVES TO OFFLINE
227 030544 005737 030342      CLR      DRVSTA+2
228 030550 005037 030344      CLR      DRVSTA+4
229 030554 005037 030346      CLR      DRVSTA+6
230 030560 013703 030460      MOV      RMVEC,R3      ;SETUP THE RH/RM VECTOR
231 030564 012723 033114      MOV      #ISR,(R3)+
232 030570 013713 030462      MOV      RMVEC+2,(R3)
233 030574 013704 030456      MOV      RMADR,R4      ;FIRST ADDRESS OF RH/RM
234 030600 012764 000040 000010      MOV      #CLR,RMCS2(R4)      ;MASSBUS INIT
235 030606 005001      CLR      R1      ;START WITH DRIVE 0
236 030610 004037 030700      3$:      JSR      R0,DRVINT      ;INIT THE DRIVE
237 030614 000401      BR      4$      ;'DVA' NOT SET OR PARITY ERROR
238 030616 000402      BR      5$      ;NORMAL RETURN
239 030620 105061 030340      4$:      CLRB      DRVSTA(R1)      ;SET DRIVE STATUS TO OFFLINE
240 030624 005201      5$:      INC      R1      ;GO TO NEXT DRIVE
241 030626 042701 177770      BIC      #^C7,R1      ;MASK OUT UNUSED BITS
242 030632 001366      BNE      3$      ;BR IF MORE DRIVES TO GO
243 030634 012701 000007      MOV      #7,R1      ;START WITH DRIVE 7
244 030640 005037 177776      CLR      PS      ;CLEAR THE PROCESSOR STATUS
245 030644 105761 030360      6$:      TSTB      DPINT(R1)      ;WAITING FOR DRIVE TO SWITCH PORTS ?
246 030650 001405      BEQ      8$      ;BR NOT WAITING
247 030652 004737 035600      JSR      PC,SET.IE      ;SET INTERRUPT
248 030656 105761 030360      7$:      TSTB      DPINT(R1)      ;DRIVE SWITCHED PORTS ?
249 030662 001375      BNE      7$      ;BR IF NOT
250 030664 005301      8$:      DEC      R1      ;GO TO THE NEXT DRIVE
251 030666 100366      BPL      6$      ;CHECK NEXT DRIVE
252 030670 012637 177776      MOV      (SP)+,PS      ;RESTORE THE PROCESSOR STATUS
253 030674 104413      RESREG      ;RESTORE R0 - R5
254 030676 000207      RTS      PC      ;BYE-BYE
255
256      ;DRIVE INITIALIZATION ROUTINE
257      ;THIS ROUTINE DETERMINES IF A DRIVE EXIST AND IF IT IS
258      ;AN RM05/3/2. IF IT IS, A 'READ-IN PRESET' IS ISSUED AND FMT16
259      ;IS SET TO A '1'. THEN MOL, DPR, DRY, AND VV ARE CHECKED TO
260      ;INSURE THEY ARE ALL ON A '1'. AND DEPENDING ON THEIR STATE,
261      ;DRVSTA IS SET TO THE PROPER CONDITION.
262      ;CALL
263      :      MOV      #DRVNUM,R1      ;DRIVE NUMBER TO R1
264      :      MOV      RMADR,R4      ;UNIBUS ADDRESS OF RH/RM (RMCS1)

```

```

265      :      JSR      RC,DRVIN*      :CALLED BY A JSR
266      :      RETURN*      :ERROR OCCURRED (PARITY)
267      :      RETURN2      :NORMAL RETURN
268      :
269      :
270 030700 010546      • DRVIN*: MOV      R5,-(SP)      :SAVE R5
271 030702 105061 030340      CLRB      DRVSTA(R1)      :START DRIVE STATUS AS OFFLINE
272 030706 105061 030350      CLRB      DRVTP(R1)      :CLEAR THE DRIVE TYPE INDICATOR
273 030712 105061 030406      CLRB      ULDFLG(R1)      :CLEAR THE UNLOAD FLAG
274 030716 010164 000010      MOV      R1,RMCS2(R4)      :SELECT A DRIVE
275 030722 112764 000111 000000      MOVB      #11,RMCS1(R4)      :DO A DRIVE (CLEAR COMMAND & SEIZE DRIVE)
276 030730 032764 010000 000010      BIT      #BIT12,RMCS2(R4)      :NONEXISTENT DRIVE?
277 030736 001403      BEQ      1$      :NO
278 030740 004737 035600      JSR      PC,SET.IE      :GO SET 'IE' WITHOUT A 'TRE'
279 030744 000520      BR      4$      :LEAVE THIS ROUTINE
280
281 030746 105061 030340      1$: CLRB      DRVSTA(R1)      :SET DRIVE STATUS TO OFFLINE
282 030752 032764 004000 000000      BIT      #BIT11,RMCS1(R4)      :SEE IF DRIVE AVAILABLE
283 030760 001512      BEQ      4$      :BR IF DRIVE NOT AVAILABLE
284 030762 004037 035110      JSR      R0,RD.RM      :READ THE DRIVE TYPE REG.
285 030766 000026      RMDT      5$
286 030770 031210      5$      :ERROR RETURN ADDRESS
287 030772 012605      MOV      (SP)+,R5      :PUT DRIVE TYPE IN R5
288 030774 112761 000004 030350      MOVB      #4,DRVTP(R1)      :SET RM03 INDICATOR
289 031002 022705 020024      CMP      #20024,R5      :SINGLE PORT RM03 ?
290 031006 001431      BEQ      2$      :BR IF YES
291 031010 022705 024024      CMP      #24024,R5      :DUAL PORT RM03 ?
292 031014 001426      BEQ      2$      :BR IF YES
293 031016 112761 000005 030350      MOVB      #5,DRVTP(R1)      :SET RM02 INDICATOR
294 031024 022705 020025      CMP      #20025,R5      :SINGLE PORT RM02 ?
295 031030 001420      BEQ      2$      :BR IF SO
296 031032 022705 024025      CMP      #24025,R5      :DUAL PORT RM02 ?
297 031036 001415      BEQ      2$      :BR IF SO
298 031040 112761 000007 030350      MOVB      #7,DRVTP(R1)      :SET RM05 INDICATOR
299 031046 022705 020027      CMP      #20027,R5      :SINGLE PORT RM05 ?
300 031052 001407      BEQ      2$      :BR IF YES
301 031054 022705 024027      CMP      #24027,R5      :DUAL PORT RM05 ?
302 031060 001404      BEQ      2$      :BR IF YES
303 031062 112761 177777 030350      MOVB      #-1,DRVTP(R1)      :SET INDICATOR TO 'OTHER'
304 031070 000446      BR      4$      :EXIT
305
306 031072 012746 000121      2$: MOV      #121,-(SP)      :DO A 'READ-IN PRESET'
307 031076 004037 035270      JSR      R0,WRT.RM
308 031102 000000      RMCS1      5$
309 031104 031210      5$
310 031106 012746 010000      MOV      #BIT12,-(SP)      :SET FMT16=1
311 031112 004037 035270      JSR      R0,WRT.RM
312 031116 000032      RMOF      5$
313 031120 031210      5$
314 031122 004037 035110      JSR      R0,RD.RM      :READ RMD5
315 031126 000012      RMD5      5$
316 031130 031210      5$
317 031132 012605      MOV      (SP)+,R5      :AND SAVE IT IN R5
318 031134 100015      BPL      3$      :BR IF ATA=0
319 031136 116164 030444 000016      MOVB      ATABIT(R1),RMAS(R4)      :CLEAR ATTENTION BIT
320 031144 004037 035110      JSR      R0,RD.RM      :FIND OUT WHY ATA=1
321 031150 000014      RMER1

```



```

322 031152 031210          SS      (SP)+      :IS IT UNSAFE?
323 031154 006126          ROL          :BR IF NOT
324 031156 100004          BPL          :SET UNSAFE INDICATOR
325 031160 112761 177777 030340 MOV      #1,DRVSTA(R1) :EXIT
326 031166 000407          BR          :CHECK MOL, DPR, DRY, AND VV
327                                3$:      COM      R5      :BIT07:BIT06>,R5
328 031170 005105          BIC          :BR IF MOL, DPR, DRY, OR VV IS CLEAR
329 031172 042705 167077          BNE      4$      :SET DRIVE STATUS TO ONLINE
330 031176 001003          MOV      #1,DRVSTA(R1) :STEP OVER THE ERROR RETURN
331 031200 112761 000001 030340 TST      (R0)+    :RESTORE R5
332 031206 005720          4$:      TST      (R0)+    :EXIT
333 031210 012605          5$:      MOV      (SP)+,R5
334 031212 000200          RTS      R0
335                                :REQUEST PRE-PROCESSOR-HANDLES SUBSYSTEM REQUEST
336                                :CALL
337                                :
338                                :
339                                :
340                                JSR      R0,RM05      :CALL THE RM05 DRIVER
341                                PNTADR      :ADDRESS OF POINTER OF DRIVES PARAMETER BLOCK
342                                RETURN1      :RETURN HERE IF QUEUE IS FULL
343                                RETURN2      :RETURN HERE IF REQUEST IS IN QUEUE OR THERE
344                                :IS AN ERROR CONDITION
345                                :
346 031214 013746 177776 RM05: MOV      PS,-(SP)      :SAVE THE CALLING STATUS
347 031220 013737 030462 177776 MOV      RMVEC+2,PS    :DON'T ALLOW ANY RM INTERRUPTS
348 031226 112737 000001 030404 MOV      #1,ACTDRV    :SET 'ACTIVE DRIVER' FLAG
349 031234 104412          SAVREG      :SAVE R0 - R5
350 031236 011002          MOV      (R0),R2      :PICKUP THE DRIVE PARAMETER BLOCK POINTER
351 031240 005062 000016          CLR      16(R2)    :CLEAR THE STATUS/ERROR INDICATOR
352 031244 111201          MOV      (R2),R1      :PICKUP THE DRIVE NUMBER
353 031246 013704 030456          MOV      RMADR,R4    :UNIBUS ADDRESS OF RMCS1
354 031252 105761 030340          TST      DRVSTA(R1) :CHECK DRIVES STATUS
355 031256 003014          BGT      1$      :BR IF ONLINE
356 031260 105761 030406          TST      ULDFLG(R1) :UNLOAD COMMAND IN QUEUE?
357 031264 001036          BNE      3$      :BR IF YES
358 031266 105761 030360          TST      DPINT(R1)  :TRYING TO INIT THE DRIVE
359 031272 001042          BNE      5$      :BR IF YES
360 031274 004037 030700          JSR      R0,DRVINT   :GO INIT. THE DRIVE
361 031300 000434          BR          :ERROR RETURN
362 031302 105761 030340          TST      DRVSTA(R1) :IS DRIVE STATUS ONLINE?
363 031306 003445          BLE      6$      :BR IF NOT
364 031310 105761 030370          1$: TST      DPRQS(R1) :OUTSTANDING PORT REQUEST FOR THE DRIVE ?
365 031314 001031          BNE      5$      :BR IF YES
366 031316 010164 000010          MOV      R1,RMCS2(R4) :SELECT THE DRIVE
367 031322 004037 036242          JSR      R0,DRVQUE   :PUT THIS REQUEST IN QUEUE
368 031326 000460          BR          :QUEUE IS FULL
369 031330 122762 000103 000002 CMP      #103,2(R2) :IS THIS REQ. FOR AN UNLOAD?
370 031336 001003          BNE      2$      :BR IF NO
371 031340 112761 177777 030406 MOV      #1,ULDFLG(R1) :SET THE 'UNLOAD IN QUEUE' FLAG
372 031346 105761 030330          2$: TST      DRVACT(R1) :IS THIS DRIVE ACTIVE?
373 031352 001043          BNE      8$      :BR IF YES
374 031354 004737 031506          JSR      PC,OPT      :CALL THE OPTIMIZER
375 031360 000440          BR          :
376 031362 012762 120000 000016 3$: MOV      #BIT15,BIT13,16(R2) :SET THE 'UNLOAD IN QUEUE' ERROR FLAG
377 031370 000434          BR          :EXIT
378 031372 004737 032564          4$: JSR      PC,C17    :GO HANDLE THE PARITY ERROR

```

```

379 031376 000431      BR      8$
380 031400 004037 036242 5$: JSR    RC,DRVQUE      ;PUT REQUEST IN QUEUE
381 031404 000431      BR      9$      ;QUEUE IS FULL
382 031406 032714 000100      BIT    #BIT06,(R4)      ;IE BIT SET ?
383 031412 001023      BNE     8$      ;YES
384 031414 004737 035600      JSR    PC,SET.IE      ;SET THE INTERRUPT
385 031420 000420      BR      8$      ;RETURN
386 031422 105761 030340 6$: TSTB   DRVSTA(R1)      ;SEE IF DRIVE OFFLINE OR UNSAFE
387 031426 002412      BLT     7$      ;BR IF UNSAFE
388 031430 012762 140000 000016 MOV    #BIT15!BIT14,16(R2)      ;SET OFFLINE ERROR INDICATOR
389 031436 105761 030350      TSTB   DRVSTP(R1)      ;SEE IF OFFLINE OR NONEXISTENT
390 031442 001007      BNE     8$      ;BR IF OFFLINE
391 031444 012762 100002 000016 MOV    #BIT15.BIT01,16(R2)      ;REPORT DRIVE NONEXISTENT
392 031452 000403      BR      8$      ;GO TO EXIT
393 031454 012762 110000 000016 7$: MOV    #BIT15.BIT12,16(R2)      ;DRIVE IS UNSAFE
394 031462 104413      8$: RESREG      ;RESTORE R0 - R5
395 031464 005720      TST     (R0)+      ;SETUP FOR NORMAL RETURN
396 031466 000401      BR      10$      ;FINISH UP, THEN EXIT
397 031470 104413      9$: RESREG      ;RESTORE R0 - R5
398 031472 005720      10$: TST     (R0)+      ;CORRECT THE RETURN ADDRESS
399 031474 105037 030404      CLRB   ACTDRV      ;CLEAR 'ACTIVE DRIVER' FLAG
400 031500 012637 177776      MOV    (SP)+,PS      ;RETURN 'PS' TO USER LEVEL
401 031504 000200      RTS     R0      ;RETURN TO CALLER
402
403      ;OPTIMIZER-CALLED FOR A PARTICULAR DRIVE
404
405      ;CALL
406
407      ;
408      ;
409 031506 104412      OPT: SAVREG      ;SAVE R0 - R5
410 031510 013746 177776      MOV    PS,-(SP)      ;SAVE PROC. STATUS
411 031514 146137 030444 030402 BICB   ATABIT(R1),SRCHWT      ;CLEAR LA SEACH FLAG
412 031522 105061 030370      CLRB   DPRQS(R1)      ;RESET THE PORT REQ FLAG ****
413 031526 004737 036316      JSR    PC,GETREQ      ;GET 'DPB' POINTER OF REQUEST
414 031532 005702      TST     R2      ;IS THERE A REQUEST IN QUEUE?
415 031534 001466      BEQ     7$      ;NO--BR TO EXIT
416 031536 010164 000010      MOV    R1,RMCS2(R4)      ;LOAD THE DRIVE ADDRESS *****
417 031542 012764 000111 000000 MOV    #111,RMCS1(R4)      ;CLEAR THE DRIVE
418 031550 032764 004000 000000 BIT    #BIT11,RMCS1(R4)      ;DVA SET ?
419 031556 001442      BEQ     5$      ;TO PORT REQUEST, IF NOT
420 031560 105761 030340 1$: TSTB   DRVSTA(R1)      ;IS DRIVE ONLINE?
421 031564 003014      BGT     2$      ;YES
422 031566 004737 036340      JSR    PC,POPQUE      ;NO--REMOVE REQUEST FROM QUEUE
423 031572 012762 140000 000016 MOV    #BIT15!BIT14,16(R2)      ;SET OFFLINE STATUS/ERROR INDICATOR
424 031600 105761 030340      TSTB   DRVSTA(R1)      ;IS DRIVE UNSAFE ?
425 031604 100047      BPL     8$      ;BR TO EXIT IF NOT
426 031606 012762 110000 000016 MOV    #BIT15!BIT12,16(R2)      ;SET UNSAFE STATUS/ERROR INDICATOR
427 031614 000443      BR      8$      ;BR TO EXIT
428 031616
429 031616 122762 000150 000002 2$: CMPB   #150,2(R2)      ;IS THE REQUEST FOR I/O?
430 031624 002403      BLT     3$      ;YES
431 031626 004737 032150      JSR    PC,C14      ;CALL THE COMMAND INITIATOR
432 031632 000434      BR      8$      ;BR TO EXIT
433 031634 005737 030442 3$: TST     DTUW      ;DATA TRANSFER UNDERWAY?
434 031640 002006      BGE     4$      ;YES--GO START A SEARCH
435 031642 005737 030420      TST     SEEKFG      ;DO IMPLIED SEEKS?

```

```

444 031646 100003          BPL      4$          ;NO, DO A SEARCH
445 031650 004737 031734   JSR      PC,C1'      ;START A DATA TRANSFER
446 031654 000423          BR       8$
447 031656 004737 032042   4$: JSR      PC,C13    ;START A SEARCH
448 031662 000420          BR       8$          ;GO TO THE EXIT
449 031664 112761 177777 030370 5$: MOVB   #-1,DPRQS(R1) ;SET PORT REQUEST INDICATOR
450 031672 010103          MOV      R1,R3      ;SET UP TO ADDRESS WORDS
451 031674 006303          ASL      R3         ;CONVERT TO WORD INDEX
452 031676 012763 035230 030422 MOV      #15000.,TIMER(R3) ;START 15. SECOND TIMER
453 031704 000402          BR       7$          ;EXIT
454 031706 004737 032564   6$: JSR      PC,C17    ;PROCESS THE PARITY ERROR
455 031712 032714 000100   7$: BIT      #BIT06,(R4) ;SEE IF 'IE' ALREADY SET
456 031716 001002          BNE      8$          ;BR IF SET
457 031720 004737 035600   JSR      PC,SET.IE ;SET 'IE' WITHOUT A 'TRE'
458 031724 012637 177776   8$: MOV      (SP)+,PS ;RESTORE PROC. STATUS
459 031730 104413          RESREG ;RESTORE R0 - R5
460 031732 000207          RTS      PC
461
462          ;COMMAND INITIATOR
463
464          ;CALL
465          ;      MOV      #DRVNUM,R1      ;DRIVE NUMBER
466          ;      MOV      #DPB,R2        ;ADDRESS OF DPB
467          ;      JSR      PC,C1?         ;C1?= C11,C13, OR C14
468          ;      ;WHERE:
469          ;      ;C11=DATA TRANSFER
470          ;      ;C13=SEARCH REQUESTED BY DATA XFER
471          ;      ;C14=NOT DATA TRANSFER
472
473 031734 004737 036340   C11: JSR      PC,POPQUE ;REMOVE REQUEST FROM 'DRIVES WAIT' QUEUE
474 031740 010237 030400   MOV      R2,TRNSWT ;PUT REQ. IN TRANSFER WAIT QUEUE
475 031744 010203          MOV      R2,R3      ;DPB ADDRESS TO R3
476 031746 013704 030456   MOV      RMADR,R4    ;RMCS1 ADDRESS
477 031752 010164 000010   MOV      R1,RMCS2(R4) ;SELECT DRIVE
478 031756 062703 000004   ADD      #4,R3      ;DESIRED WORD COUNT
479 031762 062704 000002   ADD      #2,R4      ;RMWC ADDRESS
480 031766 012324          MOV      (R3)+,(R4)+ ;LOAD WORD COUNT
481 031770 012324          MOV      (R3)+,(R4)+ ;LOAD BUFFER ADDRESS
482 031772 012346          MOV      (R3)+,-(SP) ;LOAD SECTOR AND TRACK
483 031774 004037 035270   JSR      R0,WRT.RM ;CALL THE LOAD(WRITE) ROUTINE
484 032000 000006          RMDA          ;INDEX OF REGISTER TO LOAD
485 032002 032564          C17          ;ERROR RETURN ADDRESS
486 032004 012346          MOV      (R3)+,-(SP) ;LOAD CYLINDER ADDRESS
487 032006 004037 035270   JSR      R0,WRT.RM
488 032012 000034          RMDC          ;
489 032014 032564          C17          ;
490 032016 016246 000002   MOV      2(R2),-(SP) ;LOAD 'COMMAND+GO', 'A178A16', AND 'PSEL'
491 032022 004037 035270   JSR      R0,WRT.RM
492 032026 000000          RMCS1          ;
493 032030 032564          C17          ;
494 032032 010137 030442   MOV      R1,DTUW    ;SET 'DATA TRANSFER UNDERWAY'
495 032036 000137 032526   JMP      C15
496
497 032042 013704 030456   C13: MOV      RMADR,R4    ;RMCS1 ADDRESS
498 032046 010164 000010   MOV      R1,RMCS2(R4) ;SELECT DRIVE
499 032052 016246 000012   MOV      12(R2),-(SP) ;DESIRED CYLINDER ADDRESS
500 032056 004037 035270   JSR      R0,WRT.RM

```

501	032062	000034		RMD0		
502	032064	032564		C17		
503	032066	116203	000010	MOVB	10(R2),R3	:PICKUP SECTOR ADDRESS
504	032072	163703	030464	SUB	MXWINDW,R3	:BACKUP BY MAX. SEARCH FOR I/O WINDOW
505	032076	002002		BGE	1\$	
506	032100	062703	000040	ADD	#32,R3	
507	032104	010346		MOV	R3,-(SP)	:COMBINE THE ADJUSTED SECTOR WITH
508	032106	116266	000011 000001	MOVB	11(R2),1(SP)	:THE DESIRED TRACK
509	032114	004037	035270	JSR	R0,WRT.RM	:LOAD DESIRED TRACK & SECTOR
510	032120	000006		RMDA		
511	032122	032564		C17		
512	032124	012746	000131	MOV	#131,-(SP)	:START A SEARCH
513	032130	004037	035270	JSR	R0,WRT.RM	
514	032134	000000		RMCS1		
515	032136	032564		C17		
516	032140	156137	030444 030402	BISB	ATABIT(R1),SRCHWT	:SET "SEARCH WAIT" KEY
517	032146	000567		BR	C15	
518						
519	032150	013704	030456	MOV	RMADR,R4	:RMCS1 ADDRESS
520	032154	010164	000010	MOV	R1,RMCS2(R4)	:SELECT DRIVE
521	032160	116203	000002	MOVB	2(R2),R3	:PICKUP THE REQUESTED COMMAND
522	032164	122703	000131	CMPS	#131,R3	:IS IT A SEARCH COMMAND?
523	032170	001007		BNE	1\$:BR IF NO
524	032172	016246	000010	MOV	10(R2),-(SP)	:LOAD DESIRED TRACK & SECTOR
525	032176	004037	035270	JSR	R0,WRT.RM	
526	032202	000006		RMDA		
527	032204	032564		C17		
528	032206	000403		BR	2\$:GO LOAD CYLINDER
529	032210	122703	000105	CMPS	#105,R3	:IS IT A SEEK COMMAND
530	032214	001007		BNE	3\$:BR IF NO
531	032216	016246	000012	MOV	12(R2),-(SP)	:LOAD DESIRED CYLINDER
532	032222	004037	035270	JSR	R0,WRT.RM	
533	032226	000034		RMD0		
534	032230	032564		C17		
535	032232	000546		BR	C16	
536	032234	122703	000115	CMPS	#115,R3	:IS IT AN "OFFSET" COMMAND?
537	032240	001013		BNE	4\$:BR IF NO
538	032242	004037	035110	JSR	R0,RD.RM	:MERGE THE OFFSET VALUE INTO RMOF
539	032246	000032		RMOF		:BUT DON'T CHANGE THE UPPER
540	032250	032564		C17		
541	032252	116216	000001	MOVB	1(R2),(SP)	:BYTE WHEN LOADING THE
542	032256	004037	035270	JSR	R0,WRT.RM	:REGISTER (RMOF)
543	032262	000032		RMOF		
544	032264	032564		C17		
545	032266	000530		BR	C16	:GO START THE COMMAND
546	032270	122703	000107	CMPS	#107,R3	:IS IT A "RECALIBRATE" COMMAND?
547	032274	001525		BEQ	C16	:BR IF YES
548	032276	122703	000117	CMPS	#117,R3	:IS IT A RETURN TO CENTER?
549	032302	001522		BEQ	C16	:BR IF YES
550	032304	122703	000103	CMPS	#103,R3	:IS IT AN "UNLOAD" COMMAND?
551	032310	001016		BNE	5\$:BR IF NO
552	032312	112761	000001 030330	MOVB	#1,DRVACT(R1)	:SET THE DRIVE ACTIVE INDICATOR
553	032320	105061	030340	CLRB	DRVSTA(R1)	:PUT DRIVE STATUS TO OFFLINE
554	032324	112761	000001 030406	MOVB	#1,JLDPLG(R1)	:SET "UNLOAD IN PROGRESS" FLAG
555	032332	010346		MOV	R3,-(SP)	:START THE "UNLOAD" COMMAND
556	032334	004037	035270	JSR	R0,WRT.RM	
557	032340	000000		RMCS1		

```

558 032342 032564      :7
559 032344 000207      RTS      PC      ;RETURN TO USER
560 032346 122703 000143 6$: CMPB    #143,R3    ;IS IT A 'SET FORMAT' COMMAND?
561 032352 001014      BNE      6$      ;BR IF NO
562 032354 004037 035110 JSR      R0,RD.RM    ;READ THE OFFSET REGISTER
563 032360 000032      RMOF
564 032362 032564      C17
565 032364 116266 000001 000001 MOVB    1(R2),1(SP)    ;COMBINE 'FMT16','ECI', AND 'HCI'
566 032372 004037 035270 JSR      R0,WRT.RM    ;LOAD 'FMT16','ECI', AND/OR 'HCI'
567 032376 000032      RMOF
568 032400 032564      C17
569 032402 000436      BR      12$
570 032404 122703 000141 6$: CMPB    #141,R3    ;IS IT A 'GET REGISTER' COMMAND?
571 032410 001023      BNE      10$      ;BR IF NO
572 032412 016203 000006 7$: MOV      6(R2),R3    ;POINTS TO 1ST ADDRESS OF WHERE
573                                ;TO PUT THE REGISTER(S)
574 032416 116237 000010 032434 MOVB    10(R2),9$    ;INIT. THE INDEX FOR THE FIRST REG.
575 032424 116205 000011      MOVB    11(R2),R5    ;INDEX OF LAST REG. TO MOVE
576 032430 004037 035110 8$: JSR      R0,RD.RM    ;READ RH/RM REGISTER
577 032434 000000 9$:      RMCS1    ;INDEX OF REG. TO READ
578 032436 032564      C17
579 032440 012623      MOV      (SP)+,(R3)+    ;GET THE CONTENTS OF RH/RM REG.
580 032442 023705 032434      CMP      9$,R5      ;LAST REG. BEEN READ?
581 032446 001414      BEQ      12$      ;GET OUT IF YES
582 032450 062737 000002 032434 ADD      #2,9$    ;INCREASE THE INDEX BY 2
583 032456 000764      BR      8$      ;LOOP--MORE TO READ
584 032460 122703 000145 10$: CMPB    #145,R3    ;IS IT A 'SELECT DRIVE' COMMAND?
585 032464 001405      BEQ      12$      ;BR IF YES
586 032466 010346 11$: MOV      R3,-(SP)    ;LOAD THE COMMAND
587 032470 004037 035270 JSR      R0,WRT.RM
588 032474 000000      RMCS1
589 032476 032564      C17
590 032500 004737 036340 12$: JSR      PC,POPQUE    ;REMOVE REQ. FROM QUEUE
591 032504 052762 000200 000016 BIS      #BIT07,16(R2)    ;SET THE 'DONE' BIT
592 032512 005737 030416      TST      SAVEFG    ;SAVE THE RH/RM REGISTERS?
593 032516 100002      BPL      13$      ;BR IF NO
594 032520 004737 035462      JSR      PC,SVRM70    ;YES--GO SAVE THE REGISTERS
595 032524 000207 13$:      RTS      PC      ;RETURN TO USER
596
597 032526 006301 023420 030422 C15: ASL      R1      ;START 10. SECOND TIMER
598 032530 012761      MOV      #10000.,TIMER(R1)
599 032536 006201      ASR      R1
600 032540 112761 000001 030330 MOVB    #1,DRVACT(R1) ;SET THE DRIVE ACTIVE
601 032546 000207      RTS      PC      ;RETURN TO THE USER
602
603 032550 010346 035270 C16: MOV      R3,-(SP)    ;LOAD THE COMMAND
604 032552 004037      JSR      R0,WRT.RM
605 032556 000000      RMCS1
606 032560 032564      C17
607 032562 000761      BR      C15
608
609 032564 032764 010000 000010 C17: BIT      #BIT12,RMCS2(R4)    ;DRIVE NON-EXISTENT ?
610 032572 005702 1$:      TST      R2      ;ANYTHING IN QUEUE ?
611 032574 001001      BNE      2$      ;BR IF QUEUE IS THERE
612 032576 000207      RTS      PC      ;OTHERWISE EXIT
613 032600 012762 104000 000016 1$: MOV      #BIT15,BIT11,16(R2)    ;SET 'PARITY' ERROR INDICATOR
614

```

MMIO DRIVER INITIALIZATION CODE

```

624 032606 012746 000111 117B: MOV #111,-(SP) ;DO A 'DRIVE CLEAR'
625 032612 004037 035270 JSR R0,WRTRM
626 032616 000000 RMCS1
627 032620 032664 C18
628 032622 004737 036222 1$: JSR PC,EMPTYQ ;EMPTY THE QUEUE
629 032626 105061 030370 CLRB DPRQS(R1) ;CLEAR THE PORT REQUEST FLAG
630 032632 105061 030406 CLRB ULDFLG(R1) ;CLEAR THE UNLOAD IN QUEUE FLAG
631 032636 105061 030330 CLRB DRVACT(R1) ;DRIVE IS IDLE
632 032642 020237 030400 CMP R2,TRNSWT ;IF THIS DRIVE HAD AN I/O REQUEST
636 032646 001005 BNE 2$ ;IN PROGRESS CLEAR ALL OF THE FLAGS
637 032650 005037 030400 CLR TRNSWT
638 032654 012737 177777 030442 MOV #-1,DTUW
639 032662 000207 2$: RTS PC
640
641 032664 104412 C18: SAVREG ;SAVE R0 - R5
642 032666 005001 CLR R1
643 032670 005003 CLR R3
644 032672 105761 030330 1$: TSTB DRVACT(R1) ;DRIVE ACTIVE?
645 032676 001003 BNE 2$ ;BR IF IN ACTIVE
646 032700 105761 030370 TSTB DPRQS(R1) ;PORT REQUEST
647 032704 001443 BEQ 6$ ;BR IF NOT
648 032706 013702 030400 2$: MOV TRNSWT,R2 ;GET THE 'TRANSFER WAIT' QUEUE
649 032712 020137 030442 CMP R1,DTUW ;DID THIS DRIVE HAVE AN I/O IN PROGRESS?
650 032716 001402 BEQ 3$ ;BR IF YES
651 032720 004737 036316 JSR PC,GETREQ ;GET THE DPB POINTER
652 032724 005702 3$: TST R2 ;QUEUE ENTRY FOR DRIVE ?
653 032726 001413 BEQ 5$ ;BR IF NOT
654 032730 032764 010000 000010 BIT #BIT12,RMCS2(R4) ;'NED' SET ?
655 032736 001404 BEQ 4$ ;BR IF NOT
656 032740 012762 100002 000016 MOV #BIT15,BIT01,16(R2) ;SET 'DRIVE NON-EXISTENT' INDICATOR
657 032746 000403 BR 5$ ;CONTINUE
658 032750 012762 102000 000016 4$: MOV #BIT5,BIT10,16(R2) ;SET 'NON-CLEARABLE PARITY' ERROR INDICATOR
662 032756 012763 177777 030422 5$: MOV #-1,TIMER(R3) ;STOP THE TIMER
663 032764 105061 030330 CLRB DRVACT(R1) ;SET 'DRIVE ACTIVE' TO IDLE
664 032770 105061 030370 CLRB DPRQS(R1) ;CLEAR PORT REQUEST FLAG
665 032774 020137 030442 CMP R1,DTUW ;IS THIS DRIVE SETUP FOR A TRANSFER
666 033000 001005 BNE 6$ ;BR IF NOT
667 033002 012737 177777 030442 MOV #-1,DTUW ;RESET THE INDICATOR
668 033010 005037 030400 CLR TRNSWT ;CLEAR THE TRANSFER QUEUE
669 033014 105061 030406 6$: CLRB ULDFLG(R1) ;CLEAR UNLOAD FLAG
670 033020 032764 010000 000010 BIT #BIT12,RMCS2(R4) ;'NED' SET ?
674 033026 005201 INC R1 ;MOVE TO THE NEXT DRIVE
675 033030 062703 000002 ADD #2,R3
676 033034 042701 177770 BIC #^C7,R1
677 033040 001314 BNE 1$ ;BR IF MORE DRIVES
678 033042 012737 177777 030442 MOV #-1,DTUW ;NO DATA TRANSFERS UNDERWAY
679 033050 005037 030400 CLR TRNSWT ;CLEAR THE 'TRANSFER WAIT' QUEUE
680 033054 004737 036144 JSR PC,CLRQUE ;CLEAR ALL OF THE REQUEST QUEUES
681 033060 012764 000040 000010 MOV #CLR,RMCS2(R4) ;DO A MASSBUS INIT.
682 033066 000406 BR 8$ ;CONTINUE
683 033070 004737 036222 7$: JSR PC,EMPTYQ ;CLEAR THE DRIVE'S QUEUE
684 033074 105061 030340 CLRB DRVSTA(R1) ;SET DRIVE TO OFFLINE
685 033100 105061 030350 CLRB DRVTP(R1) ;CLEAR THE DRIVE TYPE INDICATOR
686 033104 004737 035600 8$: JSR PC,SET.IE ;SET 'IE' WITHOUT 'TRE'
687 033110 104413 RESREG ;RESTORE R0 - R5
688 033112 000207 RTS PC ;RETURN
689

```

```

; INTERRUPT SERVICE ROUTINE
692 033114 112737 000001 030404 1SR:  MOVB  #1,ACTDRV      ;SET 'ACTIVE DRIVER' FLAG
693 033122 104412          SAVREG      ;SAVE R0 - R5
694 033124 013704 030456          MOV  RMADR,R4      ;ADDRESS OF RMCS1
695 033130 013701 030442          MOV  DTUW,R1      ;GET 'DATA TRANSFER UNDERWAY' IND: A'
696 033134 002402          BLT  1$          ;BR IF NO DATA TRANSFER UNDERWAY
697 033136 004737 033156          JSR  PC,TD      ;CALL TRANSFER DONE
698 033142 004737 033326          1$: JSR  PC,SC      ;CALL SPECIAL CONDITIONS
699 033146 104413          2$:  RESREG      ;RESTORE R0 - R5
700 033150 105037 030404          CLRB  ACTDRV      ;CLEAR 'ACTIVE DRIVER' FLAG
701 033154 000002          RTI              ;RETURN
702
703
704
; TRANSFER DONE ROUTINE
705 033156 105061 030330          TD:  CLRB  DRVACT(R1)      ;SET DRIVE ACTIVE INDICATOR TO IDLE
706 033162 012737 177777 030442          MOV  #-1,DTUW      ;NO DATA TRANSFERS UNDERWAY
707 033170 006301          ASL  R1
708 033172 012761 177777 030422          MOV  #-1,TIMER(R1)      ;CANCEL TIMEOUT
709 033200 006201          ASR  R1
710 033202 013702 030400          MOV  TRNSWT,R2      ;GET 'DPB' ADDRESS FROM THE
711 033206 005037 030400          CLR  TRNSWT      ;TRANSFER WAIT QUEUE--CLEAR QUEUE
712 033212 052762 000200 000016          BIS  #BIT07,16(R2)      ;SET DONE
713 033220 010164 000010          MOV  R1,RMCS2(R4)      ;SELECT THE DRIVE
714 033224 004037 035110          JSR  R0,RD.RM      ;TRANSFER ERROR(TRE-1)?
715 033230 000000          RMCS1
716 033232 032564          CI7
717 033234 006126          ROL  (SP)+      ;IS TRE-1 ?
718 033236 100417          BMI  3$          ;BR IF YES
719 033240 005737 030416          TST  SAVEFG      ;SAVE THE RH/RM REGISTERS?
720 033244 100002          BPL  1$          ;BR IF NO
721 033246 004737 035462          JSR  PC,SVRH70      ;YES--SAVE THE REGISTERS
722 033252 004737 036316          1$: JSR  PC,GETREQ      ;GET DPB POINTER
723 033254 005702          TST  R2      ;ENTRY FOR DRIVE ?
724 033256 001403          BEQ  2$          ;BR IF NOT
725 033262 004737 031506          JSR  PC,OPT      ;CALL OPTIMIZER
726 033266 000207          RTS  PC      ;RETURN
727 033270 012714 000113          2$: MOV  #113,(R4)      ;RELEASE THE DRIVE
728 033274 000207          RTS  PC      ;RETURN
729
730
731
732
733
734
735 033276 052762 100100 000016 3$:  BIS  #BIT15,BIT06,16(R2)      ;SET DATA ERROR FLAG
736 033304 004737 036222          JSR  PC,EMPTYQ      ;EMPTY THE 'DRIVE'S WAIT' QUEUE
737 033310 004737 035462          JSR  PC,SVRH70      ;SAVE THE RH/RM REGISTERS
738 033314 012714 040111          MOV  #40111,(R4)      ;ISSUE A 'DRIVE CLEAR'
739 033320 012714 000113          MOV  #113,(R4)      ;ISSUE A RELEASE TO THE DRIVE
740 033324 000207          RTS  PC      ;RETURN
741
742
743
744
745
; SPECIAL CONDITION ROUTINE
746 033326 116403 000016          SC:  MOVB  RMAS(R4),R3      ;READ 'RMAS'
747 033332 001014          BNE  2$          ;BR IF ANY 'ATA' BITS SET
748 033334 004037 035110          JSR  R0,RD.RM      ;READ CONTROL AND STATUS REGISTER
749 033340 000000          RMCS1
750 033342 032664          CI8
751 033344 106126          ROLB  (SP)+      ;IS 'IE' 1?
752 033346 100405          BMI  1$          ;YES, NO DRIVES TO CHECK
753 033350 004037 036406          JSR  R0,ES.SAV      ;SAVE THE ADDRESS IN '$ESCAPE'

```

774	033354	104001		EMT	1		:REPORT AN ILLEGAL INTERRUPT
775	033356	004737	035600	JSR	PC,SET.IE		:SET INTERRUPT ENABLE
776	033362	000207		RTS	PC		:RETURN
777	033364	005046		CLR	-(SP)		:PROCESS ALL DRIVES THAT HAVE
778	033366	110316		MOV	R3,(SP)		:AN 'ATA'=1
779	033370	012703	000001	MOV	#1,R3		
780	033374	005001		CLR	R1		
781	033376	030316		BIT	R3,(SP)		:ATA=1?
782	033400	001005		BNE	SC5		:YES
783							
784	033402	005201		INC	R1		:MOVE TO THE NEXT DRIVE
785	033404	106303		ASLB	R3		
786	033406	001373		BNE	SC3		:BR IF MORE TO CHECK?
787	033410	005726		TST	(SP)+		:CLEAN OFF THE STACK
788	033412	000207		RTS	PC		:RETURN TO USER
789							
790	033414	105761	030360	SC5:	TSTB	DPINT(R1)	:INITIALIZING THE DRIVE ?
791	033420	001402		BEQ	1\$:BR IF NOT
792	033422	000137	034340	JMP	SC13		:PROCESS THE DRIVE
793	033426	105761	030370	1\$:	TSTB	DPRQS(R1)	:PORT REQUEST OUTSTANDING ?
794	033432	001402		BEQ	2\$:BR IF NOT
795	033434	000137	034340	JMP	SC13		:START THE OUTSTANDING COMMAND
796	033440	105761	030340	2\$:	TSTB	DRVSTA(R1)	:CHECK THE DRIVE STATUS
797	033444	003023		BGT	4\$:BR IF ONLINE
798	033446	105761	030406	TSTB	ULDFLG(R1)		:UNLOAD IN PROGRESS?
799	033452	003420		BLE	4\$:BR IF NOT
800	033454	004737	036316	JSR	PC,GETREQ		:GET DPB POINTER
801	033460	004737	035462	JSR	PC,SVRH70		:SAVE THE RH/RM REGISTERS
802	033464	004737	034270	JSR	PC,SC12		:SAVE RMD5, RMER1, RMER2, AND RMMR2
803							:ALSO DO A DRIVE INIT (DRVINT)
804	033470	105761	030340	TSTB	DRVSTA(R1)		:DID DRIVE COME ONLINE?
805	033474	003414		BLE	5\$:NO
806	033476	032737	040000 030320	BIT	#BIT14,RMERRS		:WAS THERE AN ERROR?
807	033504	001000		BNE	3\$:BR IF ERROR
811	033506	013705	030322	3\$:	MOV	RMERRS+2,R5	:YES -- PICKUP RMER1 AND
812	033512	000504		BR	SC6A		:GO PROCESS THE ERROR
813	033514	105761	030330	4\$:	TSTB	DRVACT(R1)	:DRIVE ACTIVE WITH COMMAND OR ERROR RECOVERY ?
814	033520	001033		BNE	SC6		:BR IF EITHER
815	033522	004737	034270	JSR	PC,SC12		:SAVE RMD5, RMER1, RMER2, AND RMMR2
816							:ALSO DO A DRVINT
817	033526	105761	030360	5\$:	TSTB	DPINT(R1)	:TRYING TO INIT THE DRIVE ?
818	033532	001323		BNE	SC4		:BR IF YES, CHECK ON MORE DRIVES
819	033534	105761	030340	TSTB	DRVSTA(R1)		:CHECK ON DRIVE'S STATUS
820	033540	100412		BMI	6\$:BR IF UNSAFE
821	033542	032737	020000 030324	BIT	#BIT13,RMERRS+4		:ADDRESS PLUG CHANGED ?
822	033550	001013		BNE	7\$:BR IF YES
826	033552	012746	000111	MOV	#111, -(SP)		:DRIVE CLEAR
827	033556	004037	035270	JSR	R0,WRT.RM		:WRITE THE COMMAND INTO RMCS1
828	033562	000000		RMCS1			:REGISTER INDEX
829	033564	034130		SC8			:PARITY EXIT ADDRESS
830	033566	011605		6\$:	MOV	(SP),R5	:PICKUP (RMAS) BEFORE THE ERROR CALL
831	033570	004037	036406	JSR	R0,ES.SAV		:SAVE THE ADDRESS IN '\$ESCAPE'
832	033574	104002		EMT	2		:REPORT THE UNEXPECTED ATTENTION
833	033576	000701		BR	SC4		:GO CHECK FOR MORE ATA'S
833	033600			7\$:			
	033600	004037	036406	JSR	R0,ES.SAV		:SAVE THE ADDRESS IN '\$ESCAPE'


```

834 033604 104005      EMT      5      :REPORT THE ADDRESS PLUG CHANGE
835 033606 000675      BR      SC4      :CHECK FOR MORE DRIVES
836 033610 006301      SC6:  ASL      R1      :SETUP TO ADDRESS WORDS
837 033612 012761 177777 030422  MOV    #-1,TIMER(R1) :STOP THE TIMER
838 033620 006201      ASR      R1      :RESTORE THE DRIVE ADDRESS
839 033622 004737 036316  JSR      PC,GETREQ :GET THE DPB POINTER FROM THE QUEUE
840 033626 010164 000010  MOV    R1,RMCS2(R4) :SELECT DRIVE
841 033632 000137 034160  JMP      SC11 :PROCESS THE SEARCH
842 033636 004037 035110  JSR      R0,RD.RM :READ THE RM'S STATUS REG.
843 033642 000012      RMDS      SC8
844 033644 034130      MOV    (SP),R5 :AND PUT IT IN R5
845 033646 011605      ROL    (SP)+ :WAS THERE AN ERROR?
846 033650 006126      BMI    1$ :BR IF ERROR
847 033652 100407      TSTB   DRVACT(R1) :CHECK DRIVE'S STATE
848 033654 105761 030330  BGT      SC11 :BR IF DRIVE ACTIVE WITH ORDER
849 033660 003137      BIS    #BIT15,BIT07,BIT03,16(R2) :INFORM USER OF ERROR RECOVER COMPLETION
850 033662 052762 100210 000016  BR      SC7
851 033670 000470      JSR      R0,RD.RM :READ ERROR REGISTER #1
852 033672 004037 035110 1$:  RMER1  SC8
853 033676 000014      MOV    (SP)+,R5 :AND SAVE IT IN R5
854 033700 034130      JSR      PC,SVRH70 :SAVE RH/RM REGISTERS
855 033702 012605      MOV    #11,-(SP) :ISSUE A DRIVE CLEAR
856 033704 004737 035462  JSR      R0,WRT.RM
857 033710 012746 000111  RMCS1  SC8
858 033714 004037 035270
859 033720 000000
860 033722 034130
861
862 033724 006105      SC6A:  ROL      R5      :WAS 'UNSAFE' CONDITION 1?
863 033726 100406      BMI    1$      :BR IF YES
864 033730 005702      TST      R2      :ANYTHING IN QUEUE ?
865 033732 001447      BEQ      SC7      :BR IF NOT
866 033734 052762 100240 000016  BIS    #BIT15!BIT07!BIT05,16(R2) :INFORM USER OF ERROR
867 033742 000443      BR      SC7
868 033744 004037 035110 1$:  JSR      R0,RD.RM :READ DRIVE STATUS REG. #1
869 033750 000012      RMDS      SC8
870 033752 034130      MOV    (SP),R5 :SAVE RMDS IN R5
871 033754 011605      ROL    (SP)+ :'ERR'=1?
872 033756 006126      BPL      2$      :BR IF NO--UNSAFE CLEARED
873 033760 100011      MOVB   #-1,DRVSTA(R1) :DRIVE IS UNSAFE
874 033762 112761 177777 030340  JSR      PC,SVRH70 :SAVE RH/RM REGISTERS
875 033770 004737 035462      BIS    #BIT15!BIT12,16(R2) :INFORM USER OF UNSAFE ERROR
876 033774 052762 110000 000016  BR
877 034002 000423      BIT     #BIT12,R5 :'MOL' = 1 ?
878 034004 032705 010000 2$:  BNE     1$      :BR IF YES
879 034010 001015      MOVB   #-1,DRVACT(R1) :ACTIVE ERROR RECOVER
880 034012 112761 177777 030330  MOVB   #1,DRVSTA(R1) :ONLINE
881 034020 112761 000001 030340  ASL      R1
882 034026 006301      MOV    #15000.,TIMER(R1) :START 15. SECOND TIMER
883 034030 012761 035230 030422  ASR      R1
884 034036 006201      JMP      SC4
885 034040 000137 033402      BIS    #BIT15,BIT07,BIT04,16(R2) :INFORM USER OF ERROR
886 034044 052762 100220 000016 3$:
887
888 034052 105061 030330      SC7:  (LRB   DRVACT(R1) :DRIVE IS IDLE
889 034056 004737 036340      JSR      PC,POPQUE :REMOVE THE QUEUE

```

```

893 034062 105761 030406      TSTB    ULDFLG(R1)      ;UNLOAD IN PROGRESS OR QUEUE?
894 034066 003002              BGT     1$              ;BR IF NOT
895 034070 105061 030406      CLRB    ULDFLG(R1)      ;CLEAR UNLOAD FLAG
896 034074 116164 030444      MOV     ATABIT(R1),RMAS(R4) ;CLEAR ATTENTION BIT
897 034102 105761 030340      TSTB    DRVSTA(R1)      ;IS THE DRIVE UNSAFE?
898 034106 100406              BMI     2$              ;BR IF IT IS
902 034110 012746 000111      MOV     #111,-(SP)      ;DRIVE CLEAR COMMAND
903 034114 004037 035270      JSR     R0,WRT.RM      ;WRITE THE COMMAND INTO RPCS1
904 034120 000000              RMCS1
905 034122 034130              SC8
906 034124 000137 033402      JMP     SC4              ;PARITY EXIT ADDRESS
907                                ;CHECK FOR MORE DRIVES
908 034130 105761 030330      SC8:    TSTB    DRVACT(R1)      ;IS DRIVE IDLE?
909 034134 001405              BEQ     1$              ;YES
910 034136 004737 036316      JSR     PC,GETREQ      ;GET DPB POINTER
911 034142 004737 032564      JSR     PC,C17      ;PROCESS THE PARITY ERROR
912 034146 000402              BR      2$              ;CONTINUE
913 034150              1$:
917 034150 004737 032606      JSR     PC,C17B      ;PROCESS THE UNCORRECTABLE PARITY ERROR
918 034154 000137 033402      2$:    JMP     SC4              ;CHECK MORE DRIVES
919
920 034160 105761 030406      SC11:   TSTB    ULDFLG(R1)      ;'UNLOAD IN PROGRESS'?
921 034164 003402              BLE     1$              ;BR IF NO
922 034166 105061 030406      CLRB    ULDFLG(R1)      ;CLEAR UNLOAD FLAG
923 034172 105061 030330      1$:    CLRB    DRVACT(R1)      ;SET DRIVE IDLE
924 034176 136137 030444      BITB    ATABIT(R1),SRCHWT ;DOING A SEARCH OPERATION FOR
925                                ;AN I/O COMMAND?
926 034204 001012              BNE     2$              ;BR IF YES
927 034206 004737 036340      JSR     PC,POPQUE      ;REMOVE REQUEST FROM QUEUE
928 034212 052762 000200      BIS     #BIT07,16(R2) ;SET 'DONE' BIT
929 034220 005737 030416      TST     SAVEFG      ;SAVE THE REGISTERS?
930 034224 100002              BPL     2$              ;BR IF NO
931 034226 004737 035462      JSR     PC,SVRH70      ;YES--SAVE ALL OF THE RH/RM REG'S
932 034232 116164 030444      2$:    MOV     ATABIT(R1),RMAS(R4) ;CLEAR ATTENTION BIT
933 034240 146137 030444      BICB    ATABIT(R1),SRCHWT ;CLEAR IMPLIED SEEK SET
934 034246 006301              ASL     R1              ;WORD INDEX
935 034250 012761 177777      MOV     #-1,TIMER(R1) ;STOP CLOCK
936 034256 006201              ASR     R1              ;RESTORE R1
937 034260 004737 031506      JSR     PC,OPT      ;START A REQUEST
938 034264 000137 033402      JMP     SC4              ;CHECK FOR MORE DRIVES
939
940 034270 010164 000010      SC12:   MOV     R1,RMCS2(R4) ;SELECT DRIVE
941 034274 016437 000012      MOV     RMD5(R4),RMERRS ;SAVE THE FOUR REGISTERS THAT
942 034302 016437 000014      MOV     RMER1(R4),RMERRS+2 ;WILL TELL US SOMETHING
943 034310 016437 000042      MOV     RMER2(R4),RMERRS+4
944 034316 016437 000040      MOV     RMMR2(R4),RMERRS+6
945 034324 004037 030700      JSR     R0,DRVINT      ;INIT. THE STATE OF THE DRIVE
946 034330 000401              BR      1$              ;TAKE ERROR EXIT
947 034332 000207              RTS     PC              ;RETURN
948 034334 005726              1$:    TST     (SP)+      ;POP PC OFF OF THE STACK
949 034336 000674              BR      SC8              ;PROCESS THE PARITY ERROR
950
951 034340 006301              SC13:   ASL     R1              ;SETUP TO ADDRESS WORDS
952 034342 012761 177777      MOV     #-1,TIMER(R1) ;STOP THE TIMER
953 034350 006201              ASR     R1
954 034352 010164 000010      MOV     R1,RMCS2(R4) ;SELECT THE DRIVE
955 034356 116164 030444      MOV     ATABIT(R1),RMAS(R4) ;CLEAR THE ATTENTION BIT
  
```

```

956 034364 105761 030360      1$:  TSTB  DPINT(R1)      ;INITIALIZING THE DRIVE ?
957 034370 001424              BEQ    2$          ;BR IF NOT
958 034372 105061 030360      CLRB  DPINT(R1)      ;CLEAR THE INIT INDICATOR
959 034376 004037 030700      JSR    R0,DRVINT    ;GO INIT THE DRIVE
960 034402 000240              NOP                ;DUMMY PARITY ERROR RETURN
961 034404 105761 030340      TSTB  DRVSTA(R1)     ;DRIVE ONLINE ?
962 034410 003014              BGT    2$          ;BR IF YES -- START ORDER
963 034412 005702              TST    R2          ;QUEUE ENTRY FOR THE DRIVE
964 034414 001426              BEQ    3$          ;BR IF NOT
965 034416 004737 036316      JSR    PC,GETREQ     ;GET DPB ADDRESS
966 034422 052762 140000 000016  BIS   #BIT15:BIT14,16(R2) ;INFORM USER THAT DRIVE OFFLINE
967 034430 004737 035462      JSR    PC,SVRH70     ;SAVE THE REGISTERS
971 034434 004737 036340      JSR    PC,POPQUE    ;REMOVE THE QUEUE
972 034440 000414              BR     3$
973 034442 032764 004000 000000 2$:  BIT   #BIT11,RMCS1(R4)      ;DVA SET ?
974 034450 001006              BNE    4$          ;SET THEN CALL OPT
975 034452 006301              ASL    R1
976 034454 012761 035230 030422  MOV   #15000.,TIMER(R1)      ;START 15. SECOND TIMER
977 034462 006201              ASR    R1
978 034464 000402              BR     3$
979 034466 004737 031506      4$:  JSR    PC,OPT      ;START THE PENDING REQUEST
980 034472 000137 033402      3$:  JMP    SC4        ;PROCESS OTHER DRIVES
981
982      ;RM TIMER ROUTINE
983      ;CALL
984      ;
985      ;      MOV    #TIME,-(SP)      ;ELAPSED TIME IN MILLISECONDS ON THE STACK
986      ;      JSR    PC,RMTMR        ;CALL RM05 TIME ROUTINE
987 034476 005737 030404      RMTMR: TST    ACTDRV      ;CHECK 'ACTDRV & ACTSTR'
988 034502 001027              BNE    4$          ;IF NON ZERO EXIT
989 034504 112737 000001 030405  MOVB   #1,ACTSTR      ;SET 'ACTSTR'
990 034512 104412              SAVREG      ;SAVE R0 - R5
991 034514 005001              CLR    R1          ;START WITH DRIVE 0
992 034516 005003              CLR    R3
993 034520 005763 030422      1$:  TST    TIMER(R3)     ;IS THE TIMER RUNNING?
994 034524 002406              BLT    2$          ;BR IF NO
995 034526 166663 000002 030422  SUB    2(SP),TIMER(R3) ;COUNT THE INTERVAL
996 034534 003002              BGT    2$          ;BR IF NO SOFTWARE TIMEOUT
997 034536 004737 034566      JSR    PC,STO        ;CALL SOFTWARE TIMEOUT ROUTINE
998 034542 005201      2$:  INC    R1          ;MOVE TO NEXT DRIVE
999 034544 005723              TST    (R3)+
1000 034546 022701 000010      CMP    #8.,R1        ;OUT OF DRIVES?
1001 034552 003362              BGT    1$          ;BR IF NO
1002 034554 104413              RESREG      ;RESTORE R0 - R5
1003 034556 105037 030405      CLRB  ACTSTR      ;ZERO ACTIVE SOFTWARE TIMEOUT ROUTINE FLAG
1004 034562 012616      4$:  MOV    (SP)+,(SP)      ;ADJUST THE STACK
1005 034564 000207      RTS    PC          ;RETURN
1006
1007      ;SOFTWARE TIMEOUT ROUTINE
1008
1009      ;NOTE: THIS ROUTINE MUST BE ENTERED AT PRIORITY 6
1010      ;OR GREATER
1011
1012      ;CALL:  STO
1013      ;      MOV    #DRVNUM,R1      ;DRIVE NUMBER
1014      ;      JSR    PC,STO          ;CALL
1015      ;      RETURN

```

```

1016
1017 034566 010146          STO:  MOV    R1,-(SP)      ;SAVE R1
1018 034570 010246          MOV    R2,-(SP)      ;SAVE R2
1019 034572 010346          MOV    R3,-(SP)      ;SAVE R3
1020 034574 010446          MOV    R4,-(SP)      ;SAVE R4
1021 034576 013704 030456    MOV    RMADR,R4      ;GET ADDRESS OF 'RMCS1'
1022 034602 010164 000010    MOV    R1,RMCS2(R4)    ;SELECT THE DRIVE
1023 034606 004037 035110    JSR    R0,RD.RM      ;READ 'DRIVE STATUS REG'
1024 034612 000012          RMDS
1028 034614 035076          ST09
1029 034616 105726          TSTB   (SP)+          ;IS 'DRY'=1?
1030 034620 100436          BMI    ST02          ;BR IF YES
1031 034622 105761 030360    ST01:  TSTB   DPINT(R1)    ;TRYING TO INITIALIZE THE DRIVE ?
1032 034626 001033          BNE     ST02          ;BR IF YES
1033 034630 105761 030370    TSTB   DPRQS(R1)    ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
1034 034634 001030          BNE     ST02          ;BR IF YES
1035 034636 013702 030400    MOV    TRNSWT,R2      ;PICKUP TRANSFER WAIT QUEUE
1036 034642 020137 030442    CMP     R1,DTUW      ;TRANSFER UNDERWAY ON THIS DRIVE?
1037 034646 001404          BEQ     1$          ;BR IF YES
1038 034650 000137 035076    JMP     ST09          ;IF NOT DON'T BOTHER DRIVES
1039 034654 004737 036316    JSR     PC,GETREQ    ;GET DPB ADDRESS
1040 034660 052762 101000 000016 1$:  BIS    #BIT15:BIT09,16(R2) ;SET THE ERROR FLAGS
1041 034666 004737 035462    JSR     PC,SVRH70      ;SAVE RH/RM REGISTERS
1045 034672 105061 030330    CLRB   DRVACT(R1)    ;DRIVE IS IDLE
1046 034676 105061 030406    CLRB   ULDFLG(R1)    ;CLEAR THE UNLOAD FLAG
1047 034702 005037 030400    CLR     TRNSWT      ;CLEAR DPB ADDRESS
1048 034706 012737 177777 030442    MOV    #-1,DTUW      ;CLEAR THE TRANSFER DRIVE #
1049 034714 000470          BR      ST09          ;DON'T BOTHER OTHER DRIVES
1050
1051 034716 116405 000016    ST02:  MOVB   RMAS(R4),R5    ;READ ATTENTION REG
1052 034722 136105 030444    BITB   ATABIT(R1),R5    ;IS ATTENTION FOR THIS DRIVE UP ?
1053 034726 001007          BNE     ST03          ;YES
1054 034730 105761 030360    TSTB   DPINT(R1)    ;TRYING TO INITIALIZE THE DRIVE ?
1055 034734 001021          BNE     ST06          ;BR IF YES - DRIVE NOT ONLINE
1056 034736 105761 030370    TSTB   DPRQS(R1)    ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
1057 034742 001035          BNE     ST07          ;BR IF YES - NO RESPONSE TO REQUEST
1058 034744 000454          BR      ST09          ;OTHER WISE EXIT
1059
1060 034746 105761 030360    ST03:  TSTB   DPINT(R1)    ;INITIALIZING THE DRIVE ?
1061 034752 001003          BNE     1$          ;BR IF INIT PENDING
1062 034754 105761 030370    TSTB   DPRQS(R1)    ;PORT REQUEST PENDING ?
1063 034760 001446          BEQ     ST09          ;BR IF NOT
1064 034762 012763 177777 030422 1$:  MOV    #-1,TIMER(R3)    ;STOP THE TIMER
1065 034770 000442          BR      ST09          ;EXIT
1066
1067 034772 004737 032664    ST05:  JSR     PC,C18          ;GO HANDLE THE PARITY ERROR
1068 034776 000437          BR      ST09
1069
1070 035000 105061 030360    ST06:  CLRB   DPINT(R1)    ;CLEAR THE INITIALIZE INDICATOR
1071 035004 105061 030340    CLRB   DRVSTA(R1)    ;SET UNIT OFFLINE
1072 035010 012763 177777 030422    MOV    #-1,TIMER(R3)    ;STOP THE TIMER
1073 035016 004737 036316    JSR     PC,GETREQ    ;GET THE DPB ADDRESS
1074 035022 005702          TST     R2          ;REQUEST IN QUEUE ?
1075 035024 001424          BEQ     ST09          ;BR IF NOT
1076 035026 052762 140000 000016    BIS    #BIT15:BIT14,16(R2) ;INFORM THE USER DRIVE NOT AVAILABLE
1077 035034 000414          BR      ST08          ;FINISH
1078

```

```

1079 035036 012763 177777 030422 ST07: MOV #1,TIMER(R3) :STOP THE TIMER
1080 035044 105061 030370 CLR0 DPRQS(R1) :CLEAR PORT REQUEST INDICATOR
1081 035050 004737 036316 JSR PC,GETREQ :GET DPB ADDRESS
1082 035054 005702 TST R2 :QUEUE ENTRY FOR DRIVE ?
1083 035056 001407 BEQ ST09 :BR IF NONE
1084 035060 012762 100004 000016 MOV #BIT15:BIT2,16(R2) :INFORM USER OF PORT REQUEST ERROR
1085 035066 004737 036222 ST08: JSR PC,EMPTYQ :CLEAR THE QUEUE FOR THE DRIVE
1086 035072 004737 035462 JSR PC,SVRH70 :SAVE THE REGISTERS
1087 035076 012604 ST09: MOV (SP)+,R4 :RESTORE R4
1088 035100 012603 MOV (SP)+,R3 :RESTORE R3
1089 035102 012602 MOV (SP)+,R2 :RESTORE R2
1090 035104 012601 MOV (SP)+,R1 :RESTORE R1
1091 035106 000207 RTS PC :RETURN
1092
1093 :ROUTINE TO READ A RH/RM REGISTER
1094 :CALL
1095 :JSR R0,RD.RM :GO READ A REGISTER
1096 :INDEX :REG. INDEX FROM BASE
1097 :ERRADR :ERROR ADDRESS--PROCESS ERROR STARTING
1098 :AT THIS ADDRESS
1099 :CONTENTS OF REG. IS ON THE STACK
1100 :RETURN
1101
1102 035110 013737 030454 035256 RD.RM: MOV MCPMX,RD.RM2 :MAX. RETRYS ALLOWED
1103 035116 011646 MOV (SP),-(SP) :SAVE R0 FOR RETURN
1104 035120 013737 030456 035134 MOV RMADR,RD.ADR :FORM THE DESIRED ADDRESS
1105 035126 062037 035134 ADD (R0)+,RD.ADR :USING THE BASE AND THE INDEX
1106 035132 013727 RD.RM1: MOV @PC+,(PC)+ :READ THE DESIRED REGISTER OF THE RM DRIVE
1107 035134 000000 RD.ADR: .WORD 0 :ADDRESS IS FORMED HERE
1108 035136 000000 RD.WRD: .WORD 0 :REG. CONTENTS PUT HERE
1109 035140 013766 035136 000002 MOV RD.WRD,2(SP) :RETURN IT TO THE USER
1110 035146 013746 030456 MOV RMADR,-(SP) :PUT THE ADDRESS ON THE STACK
1111 035152 062716 000010 ADD #RMCS2,(SP) :FORM THE ADDRESS OF RMCS2
1112 035156 032736 010000 BIT #BIT12,@(SP)+ :CHECK THE 'NED' BIT
1113 035162 001037 BNE RD.RM3 :BR IF DRIVE NON-EXISTENT
1114 035164 017746 173266 MOV @RMADR,-(SP) :READ RMCS1
1115 035170 032716 020000 BIT #BIT13,(SP) :DID MCPE SET?
1116 035174 001002 BNE 1$ :BR IF YES
1117 035176 022620 CMP (SP)+,(R0)+ :ADJUST FOR RETURN
1118 035200 000432 BR RD.RM4 :EXIT
1119 035202 1$: JSR R0,ES.SAV :SAVE THE ADDRESS IN '$ESCAPE'
1120 035202 004037 036406 EMT 3 :REPORT 'MCPE' ERROR
1121 035210 005737 030442 TST DTUW :DATA TRANSFER UNDERWAY?
1122 035214 100405 BMI 2$ :NO
1123 035216 032716 040000 BIT #BIT14,(SP) :'"TRE"' = 1 ?
1124 035222 001402 BEQ 2$ :NO
1125 035224 005726 TST (SP)+ :YES--CLEAN OFF THE STACK AND
1126 035226 000415 BR RD.RM3 :TAKE THE FATAL ERROR EXIT
1127 035230 052716 040000 2$: BIS #BIT14,(SP) :CLEAR 'MCPE' BY SENDING A '1' TO 'TRE'
1128 035234 000316 SWAB (SP) :POSITION BEFORE WRITING
1129 035244 005237 030456 035252 MOV RMADR,3$ :FORM ADDRESS OF HIGH BYTE
1130 035250 112637 INC 3$
1131 035252 000000 MOV (SP)+,@(PC)+ :WRITE THE HIGH BYTE OF RMCS1
1132 035254 005327 3$: .WORD 0 :ADDRESS STORAGE
1133 035256 000003 RD.RM2: .WORD 3 :EXCEEDED MAX. RETRYS

```

```

1134 035260 002324
1135 035262 011000
1136 035264 012616
1137 035266 000200
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148 035270 013737 030454 035446 WRT.RM: MOV MCPEMX,WRT.R2 ;MAX RETRYS ALLOWED
1149 035276 016637 000002 035356 MOV 2(SP),WRT.WD ;SAVE THE WORD TO WRITE
1150 035304 012616 MOV (SP)+,(SP) ;ADJUST THE STACK
1151 035306 012037 035360 MOV (R0)+,WRT.AD ;GET INDEX OF REGISTER TO BE WRITTEN
1152 035312 001015 BNE 1$ ;BR IF NOT RMCS1
1153 035314 122737 000150 035356 CMPB #150,WRT.WD ;IS THE COMMAND FOR DATA TRANSFERS?
1154 035322 002411 BLT 1$ ;YES--DON'T GET THE OLD A16 & A17, & PSEL
1155 035324 004037 035110 JSR R0,RD.RM ;NO---COMBINE A16&A17, & PSEL WITH
1156 035330 000000 RMCS1 ;THE COMMAND BEFORE SENDING IT TO
1157 035332 035452 WRT.R3 ;THE RH/RM
1158 035334 000316 SWAB (SP)
1159 035336 042716 177770 BIC #^C7,(SP)
1160 035342 112637 035357 MOV (SP)+,WRT.WD+1
1161 035346 063737 030456 055360 1$: ADD RMADR,WRT.AD ;FORM THE ADDRESS OF THE DISK REG.
1162 035354 012737 WRT.R1: MOV (PC)+,@(PC)+ ;LOAD THE DESIRED REG.
1163 035356 000000 WRT.WD: .WORD 0 ;WORD TO WRITE GOES HERE
1164 035360 000000 WRT.AD: .WORD 0 ;ADDRESS IS FORMED HERE
1165 035362 013746 030456 MOV RMADR,-(SP) ;PUT THE ADDRESS ON THE STACK
1166 035366 062716 000010 ADD #RMCS2,(SP) ;FORM THE ADDRESS OF RMCS2
1167 035372 032736 010000 BIT #BIT12,@(SP)+ ;CHECK THE 'NED' BIT
1168 035376 001025 BNE WRT.R3 ;BR IF DRIVE NON-EXISTENT
1169 035400 004037 035110 JSR R0,RD.RM ;CHECK FOR PARITY ERROR ON WRITE
1170 035404 000014 RMER1
1171 035406 035452 WRT.R3
1172 035410 032726 000010 BIT #BIT03,(SP)+
1173 035414 001420 BEQ WRT.R4 ;BR IF 'PAR 0'
1174 035416 016037 177776 035430 MOV -2(R0),1$ ;PICKUP THE INDEX
1175 035424 004037 035110 JSR R0,RD.RM ;READ THE REG.
1176 035430 000000 1$: .WORD 0 ;REG. INDEX
1177 035432 035452 WRT.R3 ;RETURN TO THIS ADDRESS ON ERROR
1178 035434 004037 036406 JSR R0,ES.SAV ;SAVE THE ADDRESS IN '$ESCAPE'
1179 035440 104004 EMT 4 ;REPORT THE PARITY ON WRITE ERROR
1180 035442 005726 TST (SP)+ ;CLEAR OFF THE STACK
1181 035444 005327 DEC (PC)+ ;DECREMENT THE ERROR COUNT
1182 035446 000003 WRT.R2: .WORD 3 ;RETRY COUNTER
1183 035450 002341 BGE WRT.R1 ;TRY AGAIN IF NOT FINISHED
1184 035452 011000 WRT.R3: MOV (R0),R0 ;TAKE THE 'PARITY ON WRITE' ERROR EXIT
1185 035454 000401 BR WRT.R5 ;EXIT
1186 035456 005720 WRT.R4: TST (R0)+ ;ADJUST FOR ERROR FREE EXIT
1187 035460 000200 WRT.R5: RTS R0
1188
1189
;ROUTINE TO SAVE THE RH/RM REGISTERS AS PER DPB+14
;

```

```

1190
1191
1192
1193
1194 035462 104412
1195 035464 005702
1196 035466 001442
1197 035470 013704 030456
1198 035474 111264 000010
1199 035500 016203 000014
1200 035504 001433
1201 035506 005037 035542
1202 035512 023727 035542 000022 1$:
1203 035520 001006
1204 035522 032764 000200 000010
1205 035530 001002
1206 035532 005023
1207 035534 000405
1208 035536 004037 035110 2$:
1209 035542 000000 3$:
1210 035544 035570
1211 035546 012623
1212 035550 023727 035542 000046 4$:
1213 035556 001406
1214 035560 062737 000002 035542
1215 035566 000751
1216 035570 004737 032564 5$:
1227 035574 104413 6$:
1229 035576 000207
1230
1231
1232
1233
1234
1235
1236
1237 035600 010446
1238 035602 013704 030456
1239 035606 010164 000010
1240 035612 011446
1241 035614 052716 040000
1242 035620 000316
1243 035622 112714 000100
1244 035626 032764 010000 000010
1245 035634 001002
1246 035636 005726
1247 035640 000402
1248 035642 112664 000001 1$:
1249 035646 012604 2$:
1250 035650 000207
1251
1252
1253
1254 035652 000
1257 035653 000
      035654 000
      035655 000

;CALL
;
;      MOV      #DPBNUM,R2      :DPB POINTER TO R2
;      JSR      PC,SVRH70      :SAVE THE DRIVES REG'S
;
SVRH70: SAVREG      :SAVE R0 - R5
      TST      R2      :QUEUE ENTRY FOR THE DRIVE ?
      BEQ      6$      :BR IF NONE
      MOV      RMADR,R4
      MOVB     (R2),RMCS2(R4) :SELECT DRIVE
      MOV      14(R2),R3 :GET THE ERROR TABLE POINTER
      BEQ      6$      :EXIT IF NO ADDRESS
      CLR      3$      :COUNTER & POINTER
      CMP      3$,#RMDB :REACHED THE BUFFER REGISTER ?
      BNE      2$      :BR IF NOT
      BIT      #BIT07,RMCS2(R4) :'OR' SET ?
      BNE      2$      :BR IF SET
      CLR      (R3)+    :STORE RMDB AS ZEROES
      BR       4$      :CONTINUE
      JSR      R0,RD.RM :READ THE SELECTED REGISTER
      .WORD    0        :REGISTER INDEX
      5$      :ERROR RETURN ADDRESS
      MOV      (SP)+,(R3)+ :STORE THE REGISTER CONTENTS
      CMP      3$,#RMEC2 :REACHED THE END ?
      BEQ      6$      :BR IF YES
      ADD      #2,3$    :INCREMENT THE REGISTER INDEX
      BR       1$      :CONTINUE READING THE REGISTERS
      JSR      PC,C17   :PROCESS THE UNCORRECTABLE PARITY ERROR
      6$      :RESTORE R0 - R5
      RTS      PC      :RETURN

;ROUTINE TO SET THE INTERRUPT WITHOUT GETTING A "TRE"
;CALL
;
;      MOV      #DRVNUM,R1      :DRIVE NUMBER TO R1
;      JSR      PC,SET.IE      :SET "IE"
;      RETURN
;
SET.IE: MOV      R4,-(SP)      :SAVE R4
      MOV      RMADR,R4      :PICKUP ADDRESS OF RMCS1
      MOV      R1,RMCS2(R4)   :SELECT DRIVE
      MOV      (R4),-(SP)     :READ RMCS1
      BIS      #BIT14,(SP)    :SET THE "TRE" BIT OF THE WORD READ
      SWAB     (SP)          :ADJUST FOR DATO
      MOVB     #BIT06,(R4)    :SET "IE"
      BIT      #BIT12,RMCS2(R4) :IS "NED" 1?
      BNE      1$          :YES--CLEAR "TRE"
      TST      (SP)+        :CLEAN OFF THE STACK
      BR       2$
      1$      :CLEAR "TRE"
      MOVB     (SP)+,1(R4)    :RESTORE R4
      2$      :RESTORE R4
      MOV      (SP)+,R4
      RTS      PC          :RETURN TO CALLER

;QUEUE COUNT
JCNT:  .BYTE    0          :DRIVE 0
      .BYTE    0          :DRIVE 1
      .BYTE    0          :DRIVE 2
      .BYTE    0          :DRIVE 3

```

```

035656 000 .BYTE 0 :DRIVE 4
035657 000 .BYTE 0 :DRIVE 5
035660 000 .BYTE 0 :DRIVE 6
035661 000 .BYTE 0 :DRIVE 7

1258
1259 ;QUEUE INPUT POINTERS
1260
1261 035662 035744 QINPT: .WORD QDRV0 :DRIVE 0
1264 035664 035764 .WORD QDRV1 :DRIVE 1
035666 036004 .WORD QDRV2 :DRIVE 2
035670 036024 .WORD QDRV3 :DRIVE 3
035672 036044 .WORD QDRV4 :DRIVE 4
035674 036064 .WORD QDRV5 :DRIVE 5
035676 036104 .WORD QDRV6 :DRIVE 6
035700 036124 .WORD QDRV7 :DRIVE 7

1265
1266 ;QUEUE OUTPUT POINTERS
1267
1268 035702 035744 QOUTPT: .WORD QDRV0 :DRIVE 0
1271 035704 035764 .WORD QDRV1 :DRIVE 1
035706 036004 .WORD QDRV2 :DRIVE 2
035710 036024 .WORD QDRV3 :DRIVE 3
035712 036044 .WORD QDRV4 :DRIVE 4
035714 036064 .WORD QDRV5 :DRIVE 5
035716 036104 .WORD QDRV6 :DRIVE 6
035720 036124 .WORD QDRV7 :DRIVE 7

1272
1273 035722 035744 QSTART: .WORD QDRV0 :DRIVE 0 START ADDRESS
1274 035724 035764 QSTOP: .WORD QDRV1 :DRIVE 0 STOP ADDRESS & DRIVE 1 START ADDRESS
1275 035726 036004 .WORD QDRV2 :STOP DRIVE 1--START DRIVE 2
1276 035730 036024 .WORD QDRV3 :STOP DRIVE 2--START DRIVE 3
1277 035732 036044 .WORD QDRV4 :STOP DRIVE 3--START DRIVE 4
1278 035734 036064 .WORD QDRV5 :STOP DRIVE 4--START DRIVE 5
1279 035736 036104 .WORD QDRV6 :STOP DRIVE 5--START DRIVE 6
1280 035740 036124 .WORD QDRV7 :STOP DRIVE 6--START DRIVE 7
1281 035742 036144 .WORD QTERM :STOP DRIVE 7
1282
1283 ;DRIVE REQUEST QUEUES
1284
1287 035744 QDRV0: .BLKW 10
035764 QDRV1: .BLKW 10
036004 QDRV2: .BLKW 10
036024 QDRV3: .BLKW 10
036044 QDRV4: .BLKW 10
036064 QDRV5: .BLKW 10
036104 QDRV6: .BLKW 10
036124 QDRV7: .BLKW 10
1288 036144 QTERM=.
1289
1290 ;ROUTINE TO CLEAR ALL OF THE REQUEST QUEUES
1291
1292 ;CALL
1293 ; JSR PC,CLRQUE
1294
1295 036144 104412 CLRQUE: SAVREG :SAVE R0 - R5
1296 036146 012702 MOV #QCNT,R2 :ZERO THE QUEUE COUNTS
1297 036152 005022 CLR (R2)+ :DRIVES 0 & 1

```



```

1298 036154 005022      CLR      (R2)+      ;DRIVES 2 & 3
1299 036156 005022      CLR      (R2)+      ;DRIVES 4 & 5
1300 036160 005022      CLR      (R2)+      ;DRIVES 6 & 7
1301 036162 012703 000010  MOV      #8,R3      ;MOVE THE STARTING
1302 036166 012701 035722  MOV      #QSTART,R1    ;ADDRESS OF THE QUEUE IN '0
1303 036172 012122      1$: MOV      (R1)+,(R2)+  ;THE QUEUE INPUT POINTER
1304 036174 005303      DEL      R3
1305 036176 001375      BNE      1$
1306 036200 012703 000010  MOV      #8,R3      ;MOVE THE STARTING ADDRESS
1307 036204 012701 035722  MOV      #QSTART,R1    ;OF THE QUEUE INTO THE
1308 036210 012122      2$: MOV      (R1)+,(R2)+  ;QUEUE OUTPUT POINTER
1309 036212 005303      DEC      R3
1310 036214 001375      BNE      2$
1311 036216 104413      RESREG
1312 036220 000207      RTS      PC      ;RESTORE R0 - R5
1313
1314      ;EMPTY THE QUEUE SPECIFIED BY R1
1315      ;CALL
1316      ;
1317      ;MOV      DRVNUM,R1      ;DRIVE NUMBER TO R1
1318      ;JSR      PC,EMPTYQ
1319
1320 036222 105061 035652  EMPTYQ: CLRB    QCNT(P1)      ;CLEAR NUMBER OF ITEMS IN QUEUE
1321 036226 006301      ASL      R1
1322 036230 016161 035662 035702  MOV      QINPT(R1),QOUTPT(R1)  ;SET OUTPUT QUEUE POINTER-INPUT POINTER
1323 036236 006201      ASR      R1
1324 036240 000207      RTS      PC
1325
1326      ;ROUTINE TO PUT A REQUEST IN QUEUE
1327      ;CALL
1328      ;
1329      ;MOV      #DRVNUM,R1      ;DRIVE NUMBER
1330      ;MOV      #DPB,R2      ;ADDRESS OF PARAMETER BLOCK
1331      ;JSR      R0,DRVQUE      ;GO PUT REQUEST IN QUEUE
1332      ;RETURN1      ;RETURN HERE IF QUEUE IS FULL
1333      ;RETURN2      ;RETURN HERE IF REQUEST IS IN QUEUE
1334
1335 036242 122761 000010 035652  DRVQUE: CMPB    #10,QCNT(R1)  ;IS QUEUE FULL?
1336 036250 001421      BEQ      2$      ;BR IF YES-TAKE RETURN1
1337 036252 105261 035652      INCB    QCNT(R1)      ;INCREMENT QUEUE COUNT
1338 036256 006301      ASL      R1
1339 036260 010271 035662      MOV      R2,QINPT(R1)  ;PUT THIS REQUEST IN QUEUE
1340 036264 062761 000002 035662  ADD      #2,QINPT(R1)  ;UPDATE THE QUEUE POINTER
1341 036272 026161 035662 035724  CMP      QINPT(R1),QSTOP(R1)  ;TIME TO RESET THE POINTER
1342 036300 001003      BNE      1$      ;BR IF NO
1343 036302 016161 035722 035662  MOV      QSTART(R1),QINPT(R1)  ;YES--RESET POINTER
1344 036310 006201      1$: ASR      R1
1345 036312 005720      TST      (R0)+      ;TAKE RETURN 2
1346 036314 000200      2$: RTS      R0      ;RETURN TO USER
1347
1348      ;ROUTINE TO GET THE 'DPB' ADDRESS OF NEXT REQUEST IN QUEUE
1349      ;CALL
1350      ;
1351      ;MOV      #DRVNUM,R1      ;DRIVE NUMBER TO R1
1352      ;JSR      PC,GETREQ      ;GO GET THE REQUEST
1353      ;RETURN      ;R2='DPB' ADDRESS OF THE REQUEST
1354      ;R2=0 IF NO REQUEST IN QUEUE

```

```
1355
1356 036316 005002          GETREQ: CLR      R2
1357 036320 105761 035652  TSTB     QCNT(R1)      ;IS THERE ANY REQUEST IN QUEUE?
1358 036324 001404          BEQ      2$           ;NO
1359 036326 006301          1$:  ASL      R1
1360 036330 017102 035702  MOV      @QOUTPT(R1),R2 ;PICKUP 'DPB' POINTER FOR THIS DRIVE
1361 036334 006201          ASR      R1
1362 036336 000207          2$:  RTS      PC           ;RETURN TO USER
1363
1364          ;ROUTINE TO 'POP' THE REQUEST FROM QUEUE
1365          ;CALL
1366          ;
1367          ;      MOV      #DRVNUM,R1      ;DRIVE NUMBER TO R1
1368          ;      JSR      PC,POPQUE      ;CALL TO REMOVE REQUEST
1369          ;      RETURN     ;R2=ADDRESS OF DPB REMOVED
1370
1371 036340 105361 035652  POPQUE: DECB     QCNT(R1)      ;DECREMENT QUEUE COUNT
1372 036344 006301          ASL      R1
1373 036346 017102 035702  MOV      @QOUTPT(R1),R2 ;GET THE 'DPB' POINTER
1374 036352 005071 035702  CLR      @QOUTPT(R1) ;REMOVE DPB ADDRESS FROM THE QUEUE
1375 036356 062761 000002 035702  ADD      #2,QOUTPT(R1) ;UPDATE THE QUEUE POINTER
1376 036364 026161 035702 035724  CMP      QOUTPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER?
1377 036372 001003          BNE      1$           ;NO--BR TO EXIT
1378 036374 016161 035722 035702  MOV      QSTART(R1),QOUTPT(R1) ;YES--RESET THE POINTER
1379 036402 006201          1$:  ASR      R1
1380 036404 000207          RTS      PC           ;RETURN TO USER
1381
1383          ;ROUTINE TO SAVE THE CONTENTS OF '$ESCAPE' WHEN THE DRIVER
1384          ;REPORTS AN ERROR DIRECTLY.
1385          ;CALL
1386          ;
1387          ;      JSR      R0,ES.SAV      ;THE ERROR CALL
1388          ;      ERROR     N              ;THE RETURN IS PAST THE ERROR CALL
1389          ;      RETURN
1390
1391 036406 012037 036422  ES.SAV: MOV      (R0)+,1$      ;GET THE ERROR CALL
1392 036412 013746 001176  MOV      $ESCAPE,-(SP) ;SAVE THE ADDRESS IN '$ESCAPE'
1393 036416 005037 001176  CLR      $ESCAPE      ;CLEAR THE ESCAPE RETURN
1394 036422 000000          1$:  .WORD     0          ;THE ERROR CALL IS MOVED HERE
1395 036424 012637 001176  MOV      (SP)+,$ESCAPE ;RESTORE THE ESCAPE ADDRESS
1396 036430 000200          RTS      R0           ;RETURN
```

.SBTIL TELETYPE MESSAGES

3	036432	040	117	106	UNTOFF: .ASCIZ / OFFLINE/
4	036443	040	117	116	UNTON: .ASCIZ / ONLINE/
5	036453	040	116	117	NOTRM: .ASCIZ @ NOT AN RM05/3/2@
6	036474	040	116	117	NOTPRS: .ASCIZ / NOT PRESENT/
7	036511	040	125	116	NOTSAF: .ASCIZ / UNSAFE/
8	036521	040	114	117	LODEV: .ASCIZ / LOAD DEVICE/
9	036536	122	115	060	\$RM02: .ASCIZ /RM02/
10	036543	122	115	060	\$RM03: .ASCIZ /RM03/
11	036550	122	115	060	\$RM05: .ASCIZ /RM05/
12	036555	200	125	116	UNSTAT: .ASCIZ <CRLF>/UNIT STATUS:/
13	036573	200	104	122	MUNIT: .ASCIZ <CRLF>/DRIVE/
14	036602	054	000		\$COMMA: .ASCIZ /./
15	036604	072	040	000	COLON: .ASCIZ /:/
16	036607	040	057	040	SLASH: .ASCIZ @ / @
17	036613	103	000		C: .ASCIZ /C/
18	036615	124	000		T: .ASCIZ /T/
19	036617	040			BLNKS4: .ASCIZ / /
20	036620	040			BLNKS3: .ASCIZ / /
21	036621	040			BLNKS2: .ASCIZ / /
22	036622	040	000		BLNKS1: .ASCIZ / /
23	036624	200	105	116	ENTADR: .ASCIZ <CRLF>/ENTER ADDRESS LIMITS:/<CRLF>
24	036654	040	077	104	MOFFLN: .ASCIZ / ?DRIVE OFFLINE/<CRLF>
25	036675	040	077	104	MDRNP: .ASCIZ / ?DRIVE NOT PRESENT/<CRLF>
26	036722	040	077	104	MER11: .ASCIZ / ?DRIVE NOT AVAILABLE/<CRLF>
27	036751	040	077	104	MUSDR: .ASCIZ / ?DRIVE UNSAFE/<CRLF>
28	036771	040	077	104	MLODEV: .ASCIZ / ?DRIVE IS LOAD DEVICE/<CRLF>
29	037021	040	123	105	MSELD: .ASCIZ / SELECTED/
30	037033	106	117	122	MFORMT: .ASCIZ /FORMAT & HEADER VERIFY/
31	037062	126	105	122	MVERFY: .ASCIZ /VERIFY HEADERS ONLY/
32	037106	054	040	117	M16BIT: .ASCIZ /, OPERATE IN 16. BIT MODE/<CRLF>
33	037141	054	040	117	M18BIT: .ASCIZ /, OPERATE IN 18. BIT MODE/<CRLF>
34	037174	040	077	111	BADENT: .ASCIZ / ?INVALID ENTRY/<CRLF>
35	037215	115	101	130	MADRER: .ASCIZ /MAX TRACK ADRS MUST BE EQUAL TO OR GREATER/<CRLF>
36	037270	124	110	101	.ASCIZ /THAN MIN TRACK ADRS/<CRLF>
37	037315	200	123	124	MSFOR: .ASCIZ <CRLF>/STARTING FORMAT/<CRLF>
38	037337	200	123	124	MSQVER: .ASCIZ <CRLF>/STARTING QUICK HEADER VERIFY/<CRLF>
39	037376	200	123	124	MSVER: .ASCIZ <CRLF>/STARTING HEADER VERIFY/<CRLF>
40	037427	200	103	117	MSCMPT: .ASCIZ <CRLF>/COMPLETED/
41	037442	054	040	124	NUMERR: .ASCIZ /, TOTAL ERRORS DETECTED /
42	037473	120	101	103	PACKSN: .ASCIZ @PACK S/N: @
43	037506	120	122	105	ADDRIS: .ASCIZ /PRESENT ADDRESS IS: /
44	037533	200	105	116	MESG1: .ASCIZ <CRLF>/ENTER SERIAL NUMBER (OCTAL): /
45	037572	200	077	111	MESG2: .ASCIZ <CRLF>/?INCORRECT 'MFG' BAD SECTOR INFORMATION/
46	037643	200	077	117	MESG3: .ASCIZ <CRLF>/?OVER 126. BAD SECTORS DETECTED/
47	037704	200	077	104	MESG4: .ASCIZ <CRLF>/?DISK IS AN ALIGNMENT PACK/
48	037740	200	123	105	MSGBLK: .ASCIZ <CRLF>/SELECT ONE OF THE FOLLOWING FUNCTIONS/<CRLF>
49	040007	125	120	104	.ASCIZ /UPDATE 'USR' BAD SECTORS.....0/<CRLF>
50	040066	120	122	111	.ASCIZ /PRINT 'MFG' BAD SECTORS.....1/<CRLF>
51	040145	120	122	111	.ASCIZ /PRINT 'USR' BAD SECTORS.....2/<CRLF>
52	040224	111	116	111	.ASCIZ /INITIALIZE 'USR' BAD SECTOR FILE.....3/<CRLF>
53	040303	120	122	111	.ASCIZ /PRINT A SECTOR OF THE LAST TRACK.....4/<CRLF>
54	040362	120	122	111	.ASCIZ /PRINT THIS MESSAGE.....5/<CRLF>
55	040441	103	117	116	.ASCIZ /CONTINUE.....<CR>/<CRLF>
56	040521	200	105	116	MULTTY: .ASCIZ <CRLF>/ENTER UTILITY FUNCTION (HELP=5): /
57	040564	200	105	116	MESG5: .ASCIZ <CRLF>/ENTER 16 BIT 'MFG' BAD SECTOR ADRS (DECIMAL)/

58	040642	200	105	116	MSG6:	.ASCIIZ	<CRLF>/ENTER 18 BIT 'MFG' BAD SECTOR ADRS (DECIMAL)/
59	040720	200	105	116	MSG7:	.ASCIIZ	<CRLF>/ENTER 16 BIT 'USR' BAD SECTOR ADRS (DECIMAL)/
60	040776	200	105	116	MSG8:	.ASCIIZ	<CRLF>/ENTER 18 BIT 'USR' BAD SECTOR ADRS (DECIMAL)/
61	041054	200	103	117	MSG9:	.ASCIIZ	<CRLF>/CONTENTS OF 16 BIT 'MFG' BAD SECTOR FILE (DECIMAL)/
62	041140	200	103	117	MSG10:	.ASCIIZ	<CRLF>/CONTENTS OF 18 BIT 'MFG' BAD SECTOR FILE (DECIMAL)/
63	041224	200	103	117	MSG11:	.ASCIIZ	<CRLF>/CONTENTS OF 16 BIT 'USR' BAD SECTOR FILE (DECIMAL)/
64	041310	200	103	117	MSG12:	.ASCIIZ	<CRLF>/CONTENTS OF 18 BIT 'USR' BAD SECTOR FILE (DECIMAL)/
65	041374	200	120	122	MSG13:	.ASCIIZ	<CRLF>/PRINT A 'SECTOR' OF THE LAST TRACK (OCTAL)/
66	041450	200	105	116	MSG13A:	.ASCIIZ	<CRLF>/ENTER SECTOR (DECIMAL): /
67	041502	200	104	117	MSG14:	.ASCIIZ	<CRLF>/DONE ./<CRLF>
68	041513	200	105	116	MSG15:	.ASCIIZ	<CRLF>/ENTER 'MFG' BAD SECTOR ADRS (DECIMAL)/<CRLF>
69	041563				MSG16:		:NOT USED
70	041563	200	077	125	MSG17:	.ASCIIZ	<CRLF>/?UNABLE TO WRITE 'BSF' SUCCESSFUL Y/
71	041630	200	077	106	MSG18:	.ASCIIZ	<CRLF>/?FATAL DRIVE ERROR DETECTED/
72	041665	200	077	106	MSG19:	.ASCIIZ	<CRLF>/?FAILURE DURING HEADER VERIFICATION/
73	041732	104	117	040	MMODE:	.ASCIIZ	/DO YOU WANT TO FORMAT (L) Y ? /
74	041771	104	117	040	MSIZE:	.ASCIIZ	/DO YOU WANT 16. BIT MODE (L) Y ? /
75	042033	200	111	116	MSINIT:	.ASCIIZ	<CRLF>/INITIALIZE BAD SECTOR FILE (L) N ? /
76	042100	200	111	116	INITUS:	.ASCIIZ	<CRLF>/INITIALIZE 'USR' BAD SECTOR FILES/
77	042143	200	111	116	INITMF:	.ASCIIZ	<CRLF>/INITIALIZE 'MFG' BAD SECTOR FILES/
78	042206	052	040	116	NOENTR:	.ASCIIZ	/* NO ENTRIES */<CRLF>
79	042226	055	117	120	ABORT:	.ASCIIZ	/-OPERATION ABORTED-/<CRLF><07><07>
80	042255	200	077	116	NOUPDT:	.ASCIIZ	<CRLF>/?NO UPDATES IN 'VERIFY' MODE/<CRLF>
81	042314	200	077	116	NOINIT:	.ASCIIZ	<CRLF>/?NO INITIALIZATION IN 'VERIFY' MODE/<CRLF>
82	042362	103	110	101	MSPRM:	.ASCIIZ	/CHANGE DRIVE PARAMETERS (L) N ? /
83	042423	200	052	052	STARS:	.ASCIIZ	<CRLF>/*****/<CRLF>
84					.EVEN		

.SBTTL ERROR MESSAGES

3	042446	122	110	040	EM1:	.ASCIIZ	/RH CONTROLLER INTERRUPT OCCURRED (RMA, 0)/
4	042520	125	116	105	EM2:	.ASCIIZ	/UNEXPECTED ATTENTION OCCURRED/
5	042556	115	101	123	EM3:	.ASCIIZ	/MASSBUS PARITY ERROR (MCPE=1)/
6	042614	115	101	123	EM4:	.ASCIIZ	/MASSBUS PARITY ERROR (PAR=1)/
7	042651	101	104	104	EM5:	.ASCIIZ	/ADDRESS PLUG CHANGE BIT SET/
8	042705	122	110	040	EM6:	.ASCIIZ	/RH CONTROLLER DIDN'T RESPOND TO ADDRESSING/
9	042760	124	122	101	EM7:	.ASCIIZ	@TRACK/SECTOR FIELD IN HEADER IS NOT CORRECT@
10	043034	104	122	111	EM10:	.ASCIIZ	/DRIVE OFFLINE/
11	043052	120	105	122	EM11:	.ASCIIZ	/PERSISTENT DRIVE UNSAFE ERROR/
12	043110	125	116	103	EM12:	.ASCIIZ	/UNCORRECTABLE MASSBUS PARITY ERROR/
13	043153	123	117	106	EM13:	.ASCIIZ	/SOFTWARE TIMEOUT/
14	043174	104	122	111	EM14:	.ASCIIZ	/DRIVE UNSAFE ERROR/
15	043217	103	117	116	EM15:	.ASCIIZ	@CONTROLLER/DRIVE ERROR DURING WRITE@
16	043263	103	117	116	EM16:	.ASCIIZ	@CONTROLLER/DRIVE ERROR DURING WRITE CHECK@
17	043335	122	105	124	EM17:	.ASCIIZ	@RETRIES NOT SUCCESSFUL - SECTOR NOT ACCEPTABLE@
18	043413	104	101	124	EM20:	.ASCIIZ	@DATA ERROR DURING WRITE CHECK@
19	043451	103	117	116	EM21:	.ASCIIZ	@CONTROLLER/DRIVE ERROR VERIFYING HEADERS@
20	043522	047	110	103	EM22:	.ASCIIZ	@'HCE' OR 'HCRC' ERROR VERIFYING HEADERS@
21	043572	103	131	114	EM23:	.ASCIIZ	@CYLINDER FIELD IN HEADER IS NOT CORRECT@
22	043642	127	122	111	EM24:	.ASCIIZ	@WRITE CHECK ERROR@
23	043664	111	114	114	EM25:	.ASCIIZ	/ILLEGAL BAD SECTOR, PACK NOT ACCEPTABLE/

```
.SBTTL DATA HEADERS
```

3	043734	122	115	101	DH1:	.ASCIIZ	/RMAS	RMCS1	RMER1	RMER2	RMDS	RMDC	RMDA/
4	044002	104	122	111	DH2:	.ASCIIZ	/DRIVE	RMDS	RMER1	RMER2	RMAS	RMCS1/	
5	044054	104	122	111	DH3:	.ASCIIZ	/DRIVE	REG ADR	DATA	RMCS1	RMER1	RMER2/	
6	044125	104	122	111	DH4:	.ASCIIZ	/DRIVE	REG ADR	GOOD	BAD	RMCS1	RMER1	RMER2/
7	044210	122	110	040	DH6:	.ASCIIZ	/RH ADDRESS/						
8	044223	104	122	111	DH10:	.ASCIIZ	/DRIVE	ERR PC	RMCS1	RMCS2	RMDS	RMER1	RMER2/
9	044310	122	115	105	DH10A:	.ASCIIZ	/RMEC1	RMEC2	RMWC	RMBA	RMDS	RMAS	RMLA/
10	044374	122	115	104	DH10B:	.ASCIIZ	/RMDB	RMMR1	RMDT	RMSN	RMOF	CYLINDER	TRACK/
11	044452	104	122	111	DH17:	.ASCIIZ	/DRIVE	ERR PC	CYLINDER	TRACK	SECTOR/		
12	044521	104	122	111	DH20:	.ASCIIZ	/DRIVE	ERR PC	CYLINDER	TRACK	SECTOR/		
13	044570	122	115	103	DH20A:	.ASCIIZ	/RMCS1	RMCS2	RMDS	RMER1	RMER2	RMMR2	RMEC1
14	044665	122	115	127	DH20B:	.ASCIIZ	/RMWC	RMBA	RMDS	RMAS	RMLA	RMDB	RMEC2/
15	044761	122	115	123	DH20C:	.ASCIIZ	/RMSN	RMOF	CYLINDER	TRACK/			RMMR1
16	045015	104	122	111	DH23:	.ASCIIZ	/DRIVE	ERR PC	EXPCTD	RECVD/			RMDT/
17	045054	040	040	040	DH24:	.ASCII	/						
18	045142	104	122	111		.ASCIIZ	/DRIVE	ERR PC	CYLNR	TRACK	SECTOR	MEMORY DATA	DISK/<<CR>><LF>
19	045227	104	122	111	DH25:	.ASCIIZ	/DRIVE	CYLNR	TRACK	SECTOR	/		DATA/
20						.EVEN							

.SBTTL DATA TABLES

1						
2						
3	045270	001370	005560	005574	DT1:	.WORD ATTN, RM.REG, RM.REG+14, RM.REG+42, RM.REG+12, RM.REG+34, RM.REG+6
4	045306	001366	030320	030322	DT2:	.WORD DDRIIVE, RMERRS, RMERRS+2, RMERRS+4, ATTN, RMCS1
5	045322	001366	035134	035136	DT3:	.WORD DDRIIVE, RD.ADR, RD.WRD, RM.REG, RM.REG+14, RM.REG+42
6	045336	001366	035360	035356	DT4:	.WORD DDRIIVE, WRT.AD, WRT.WD, RD.WRD, RM.REG, RM.REG+14, RM.REG+42
7	045354	001274			DT6:	.WORD \$RMADR
8	045356	001222	001132	046232	DT7:	.WORD DRIVE, \$ERRPC, RBUF+6, RBUF+2
9	045366	001222	001132	005560	DT10:	.WORD DRIVE, \$ERRPC, RM.REG, RM.REG+10, RM.REG+12, RM.REG+14, RM.REG+42
10	045404	005624	005626	005562		.WORD RM.REG+44, RM.REG+46, RM.REG+2, RM.REG+4, RM.REG+6, RM.REG+16, RM.REG+20
11	045422	005602	005604	005606		.WORD RM.REG+22, RM.REG+24, RM.REG+26, RM.REG+30, RM.REG+32, DS.CYL, DS.TRK
12	045440	001222	001132	001362	DT17:	.WORD DRIVE, \$ERRPC, DS.CYL, DS.TRK, BADSEC
13	045452	001222	001132	001362	DT20:	.WORD DRIVE, \$ERRPC, DS.CYL, DS.TRK, BADSEC
14	045464	005560	005570	005572		.WORD RM.REG, RM.REG+10, RM.REG+12, RM.REG+14, RM.REG+42, RM.REG+40, RM.REG+44, RM.REG+46
15	045504	005562	005564	005566		.WORD RM.REG+2, RM.REG+4, RM.REG+6, RM.REG+16, RM.REG+20, RM.REG+22, RM.REG+24, RM.REG+26
16	045524	005610	005612	001362		.WORD RM.REG+30, RM.REG+32, DS.CYL, DS.TRK
17	045534	001222	001132	046230	DT23:	.WORD DRIVE, \$ERRPC, RBUF+4, RBUF
18	045544	001222	001132	001362	DT24:	.WORD DRIVE, \$ERRPC, DS.CYL, DS.TRK, BADSEC, \$GDDAT, RM.REG+22
19	045562	005560	005570	005572		.WORD RM.REG, RM.REG+10, RM.REG+12, RM.REG+14, RM.REG+42, RM.REG+40, RM.REG+44, RM.REG+46
20	045602	005562	005564	005566		.WORD RM.REG+2, RM.REG+4, RM.REG+6, RM.REG+16, RM.REG+20, RM.REG+22, RM.REG+24, RM.REG+26
21	045622	005610	005612	001362		.WORD RM.REG+30, RM.REG+32, DS.CYL, DS.TRK
22	045632	001222	005552	001364	DT25:	.WORD DRIVE, FMTDPB+12, DS.TRK, BADSEC

.SBTTL DATA FORMAT TABLES

3	045642	000001	
4	045644	007	000
5	045646	000001	
6	045650	006	000
7	045652	000001	
8	045654	006	000
9	045656	000001	
10	045660	007	000
11	045662	000001	
12	045664	001	000
13	045666	000003	
14	045670	007	000
15	045672	044310	
16	045674	007	000
17	045676	044374	
18	045700	007	140
19	045702	000001	
20	045704	005	034
21	045706	000004	
22	045710	005	034
23	045712	044570	
24	045714	010	000
25	045716	044665	
26	045720	010	000
27	045722	044761	
28	045724	004	014
29	045726	000001	
30	045730	005	000
31	045732	000004	
32	045734	007	034
33	045736	044570	
34	045740	010	000
35	045742	044665	
36	045744	010	000
37	045746	044761	
38	045750	004	014
39	045752	000001	
40	045754	004	000

DF1:	.WORD	1
	.BYTE	7,0
DF2:	.WORD	1
	.BYTE	6,0
DF3:	.WORD	1
	.BYTE	6,0
DF4:	.WORD	1
	.BYTE	7,0
DF6:	.WORD	1
	.BYTE	1,0
DF10:	.WORD	3
	.BYTE	7,0
	.WORD	DH10A
	.BYTE	7,0
	.WORD	DH10B
	.BYTE	7,140
DF17:	.WORD	1
	.BYTE	5,34
DF20:	.WORD	4
	.BYTE	5,34
	.WORD	DH20A
	.BYTE	8,0
	.WORD	DH20B
	.BYTE	8,0
	.WORD	DH20C
	.BYTE	4,14
DF23:	.WORD	1
	.BYTE	5,0
DF24:	.WORD	4
	.BYTE	7,34
	.WORD	DH20A
	.BYTE	8,0
	.WORD	DH20B
	.BYTE	8,0
	.WORD	DH20C
	.BYTE	4,14
DF25:	.WORD	1
	.BYTE	4,0

.SBTTL BUSADR - GET BUS ADDRESS AND VECTOR ADDRESS FOR RH/RM

:THIS ROUTINE IS USED TO INSURE THE BUS ADDRESS
 :OF THE RH/RM IS SETUP FOR THE PROPER ADDRESS.
 :IT WILL ALSO READ THE ADDRESS FROM THE TTY IF
 :REQUIRED.
 :NOTE: THIS ROUTINE DESTROYS R0-R4
 :CALL

```

      JSR      PC,BUSADR
      RETURN

BUSADR: TST      CHGADR      ;INPUT FROM TTY REQUESTED?
        BEQ      3$         ;NO
        CLR      CHGADR      ;DISABLE CHANGE OF RH/RM ADDRESS
        TYPE     , $CRLF     ;CR-LF
1$:     MOV      # $RMADR,R0  ;FIRST ADDRESS
        TYPE     , MRMCS1    ;'RMCS1='
        MOV      (R0),-(SP)  ;PRESENT RMCS1 ADDRESS
        TYPOC    ;TYPE IT
        TYPE     ,BLNKS2     ;TYPE 2 SPACES
        RDLIN    ;GET THE ENTRY
        MOV      (SP)+,R1    ;ADDRESS OF ASCII TEXT
        JSR      R5,CK.NUM   ;ENTER AND STORE NEW ADDRESS
        BR       1$         ;ERROR RET
2$:     MOV      # $RMVEC,R0  ;CHECK VERC
        TYPE     , MRMVEC    ;'RMVEC='
        MOV      (R0),-(SP)  ;PRESENT RH/RM VECTOR ADDRESS ON THE STACK
        TYPOC    ;TYPE IT
        TYPE     ,BLNKS2     ;TYPE 2 SPACES
        RDLIN    ;READ THE ENTRY
        MOV      (SP)+,R1    ;ASCII TEXT ADDRESS
        JSR      R5,CK.NUM   ;ENTER AND STORE NEW ADDRESS
        BR       2$         ;ERROR RET
3$:     MOV      # $RMADR,R0  ;FIRST ADDRESS OF NEW PARAMETERS
        MOV      # $RMADR,R1 ;FIRST ADDRESS OF WHERE TO PUT THEM
        MOV      (R0)+,(R1)+ ;BUS ADDRESS
        MOV      (R0)+,(R1)+ ;VECTOR ADDRESS
        RTS      PC         ;RETURN
  
```

```

41 046076      122      115      103 MRMCS1: .ASCIIZ @RMCS1-@
42 046105      122      115      126 MRMVEC: .ASCIIZ @RMVEC @
  
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44

```
.SBTTL CK.NUM - CHECK NUMBER (OCTAL)
;THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL CHARACTERS
;AND FORMS AN OCTAL NUMBER IN R2
;CALL:
;      MOV      #ADR,R1      ;ADDRESS OF ASCII STRING
;      R0=ADDRESS TO STORE THE NUMBER
;      JSR      R5,CK.NUM
;      RET1     ERROR RETURN
;      RET2     NORMAL RET
```

```
CK.NUM: MOV      R2,-(SP)      ;SAVE R2
        MOV      R3,-(SP)      ;SAVE R3
        MOV      R4,-(SP)      ;SAVE R4
        MOV      #6,R3        ;MAX OCTAL DIGITS IN THE NUMBER
        CLR      R2           ;FINAL OCTAL VALUE
1$:      MOVB     (R1)+,R4      ;GET CURRENT POINTED BYTE
        BEQ      3$           ;BR IF TERMINATOR DETECTED
        CMPB     R4,#'0        ;SMALLER THAN ASCII-0 ?
        BLO      5$           ;YES,ERROR EXIT
        CMPB     R4,#'7        ;LARGER THAN ASCII-7 ?
        BHI      5$           ;YES,ERROR EXIT
        ASL      R2           ;SHIFT LEFT
        BCS      5$           ;
        ASL      R2           ;ONE
        BCS      5$           ;
        ASL      R2           ;OCTAL DIGIT
        BCS      5$           ;ERROR IF CARRY BIT SET
        BIC      #177770,R4    ;CHOP OFF HIGHER BITS
        ADD      R4,R2        ;APPENDING CURRENT DIGIT
        DEC      R3           ;DECREMENT BYTE COUNT
        BEQ      2$           ;BR IF LAST DIGIT
        BR       1$          ;LOOPING BACK
2$:      MOVB     (R1)+,R4      ;CHECK TERMINATOR
        BNE      5$           ;BR IF NOT FOUND
3$:      TST      R2           ;FINAL VALUE - 0 ?
        BEQ      4$           ;YES
        MOV      R2,(R0)      ;REPLACE THE ORIGINAL VALUE
4$:      TST      (R5)+        ;ADJUST FOR NORMAL RET
5$:      MOV      (SP)+,R4      ;RESTORE 4
        MOV      (SP)+,R3      ;RESTORE R3
        MOV      (SP)+,R2      ;RESTORE R2
        RTS      R5           ;EXIT
```

```
13 046114 010246
14 046116 010346
15 046120 010446
16 046122 012703 000006
17 046126 005002
18 046130 112104
19 046132 001424
20 046134 120427 000060
21 046140 103425
22 046142 120427 000067
23 046146 101022
24 046150 006302
25 046152 103420
26 046154 006302
27 046156 103416
28 046160 006302
29 046162 103414
30 046164 042704 177770
31 046170 060402
32 046172 005303
33 046174 001401
34 046176 000754
35 046200 112104
36 046202 001004
37 046204 005702
38 046206 001401
39 046210 010210
40 046212 005725
41 046214 012604
42 046216 012603
43 046220 012602
44 046222 000205
```

```

1      .SBTTL  READ/WRITE BUFFERS
2
3      ;BUFFER STARTS HERE
4
5 046224 000000 000000 000000 RBUF:  .WORD  0,0,0,0      ;BUFFER FOR HEADER CHECK
6
7 046234      BUFP:  .BLKW  <258.*32.>      ;FORMAT AND CHECK BUFFER STARTS HERE AND
8                                     ;WILL OVERLAY ALL REMAINING CODE IN PROGRAM
9 106434      BUFV:  .BLKW  <258.*32.>      ;BUFFER FOR VERIFY ONLY MODE
10
11      000200      .END      200

```

ABASE = 176700
ABORT = 042226
ACDW1 = 000000
ADW2 = 000000
ACK = 000123
ACPUOP = 000000
ACTDRV = 030404
ACTSTR = 030405
ADDRIS = 037506
ADDW0 = 000000
ADDW1 = 000000
ADDW10 = 000000
ADDW11 = 000000
ADDW12 = 000000
ADDW13 = 000000
ADDW14 = 000000
ADDW15 = 000000
ADDW2 = 000000
ADDW3 = 000000
ADDW4 = 000000
ADDW5 = 000000
ADDW6 = 000000
ADDW7 = 000000
ADDW8 = 000000
ADDW9 = 000000
ADEVCT = 000000
ADEVM = 000000
ADRTBL = 006064
AENV = 000000
AENVM = 000000
AFATAL = 000000
AMADR1 = 000000
AMADR2 = 000000
AMADR3 = 000000
AMADR4 = 000000
AMAMS1 = 000000
AMAMS2 = 000000
AMAMS3 = 000000
AMAMS4 = 000000
AMSGAD = 000000
AMSGLG = 000000
AMSGTY = 000000
AMTYP1 = 000000
AMTYP2 = 000000
AMTYP3 = 000000
AMTYP4 = 000000
AOE = 001000
APASS = 000000
APRIOR = 000000
APTCU = 000040
APTENV = 000001
APTSIZ = 000200
APTSPO = 000100
ASK0 = 010714
ASK1 = 011000
ASK2 = 011124
ASK3 = 011444

ASK3A = 011514
ASWREG = 000000
ATA = 100000
ATABIT = 030444
ATESTV = 000000
ATTN = 001370
ATO = 000001
AT1 = 000002
AT2 = 000004
AT3 = 000010
AT4 = 000020
AT5 = 000040
AT6 = 000100
AT7 = 000200
AUNIT = 000000
AJSWR = 000000
AVECT1 = 000254
AVECT2 = 000000
A16 = 000400
A17 = 001000
BADENT = 037174
BADSEC = 001344
BADTMO = 006730
BAI = 000010
BIT0 = 000001
BIT00 = 000001
BIT01 = 000002
BIT02 = 000004
BIT03 = 000010
BIT04 = 000020
BIT05 = 000040
BIT06 = 000100
BIT07 = 000200
BIT08 = 000400
BIT09 = 001000
BIT1 = 000002
BIT10 = 002000
BIT11 = 004000
BIT12 = 010000
BIT13 = 020000
BIT14 = 040000
BIT15 = 100000
BIT2 = 000004
BIT3 = 000010
BIT4 = 000020
BIT5 = 000040
BIT6 = 000100
BIT7 = 000200
BIT8 = 000400
BIT9 = 001000
BLNKS1 = 036622
BLNKS2 = 036621
BLNKS3 = 036620
BLNKS4 = 036617
BPTVEC = 000014
BSE = 100000
BSFAVL = 001404

BUFP = 046234
BUFV = 106434
BUSADR = 045756
BYTE16 = 006264
BYTE18 = 006364
C = 036613
CALIN = 012706
CHGADR = 001374
CI1 = 031734
CI3 = 032042
CI4 = 032150
CI5 = 032526
CI6 = 032550
CI7 = 032564
CI7B = 032606
CI8 = 032664
CKSWR = 104407
CKTRK = 014344
CK.CHR = 023120
CK.DEC = 023072
CK.DIG = 023172
CK.NUM = 046114
CK.OCT = 023044
CLOCK = 017616
CLR = 000040
CLRQUE = 036144
CNTLC = 001372
COLON = 036604
CPSAVE = 023754
CR = 000015
CRLF = 000200
C.ENTR = 017630
DCK = 100000
DDISP = 177570
DDRIVE = 001366
DEVMP = 001400
DF1 = 045642
DF10 = 045666
DF17 = 045702
DF2 = 045646
DF20 = 045706
DF23 = 045726
DF24 = 045732
DF25 = 045752
DF3 = 045652
DF4 = 045656
DF6 = 045662
DH1 = 043734
DH10 = 044223
DH10A = 044310
DH10B = 044374
DH17 = 044452
DH2 = 044002
DH20 = 044521
DH20A = 044570
DH20B = 044665
DH20C = 044761

DH23 = 045015
DH24 = 045054
DH25 = 045227
DH3 = 044054
DH4 = 044125
DH6 = 044210
DISPLA = 001156
DISPRE = 000174
DLT = 100000
DMD = 000001
DONE = 016366
DPINT = 030360
DPR = 000400
DPRQS = 030370
DRIVE = 001222
DRQ = 004000
DRVACT = 030330
DRVCLR = 000111
DRVINT = 030700
DRVQUE = 036242
DRVSTA = 030340
DRVTyp = 030350
DRY = 000200
DSWR = 177570
DS.CYL = 001362
DS.TRK = 001364
DTE = 010000
DTSY = 000200
DTUW = 030442
DT00 = 000001
DT01 = 000002
DT02 = 000004
DT03 = 000010
DT04 = 000020
DT05 = 000040
DT06 = 000100
DT07 = 000200
DT08 = 000400
DT1 = 045270
DT10 = 045366
DT17 = 045440
DT2 = 045306
DT20 = 045452
DT23 = 045534
DT24 = 045544
DT25 = 045632
DT3 = 045322
DT4 = 045336
DT6 = 045354
DT7 = 045356
DVA = 004000
ECH = 000100
ECI = 004000
EMPTYQ = 036222
EMTVEC = 000030
EM1 = 042446
EM10 = 043034

EM11 = 043052
EM12 = 043110
EM13 = 043153
EM14 = 043174
EM15 = 043217
EM16 = 043263
EM17 = 043335
EM2 = 042520
EM20 = 043413
EM21 = 043451
EM22 = 043522
EM23 = 043572
EM24 = 043642
EM25 = 043664
EM3 = 042556
EM4 = 042614
EM5 = 042651
EM6 = 042705
EM7 = 042760
ENTADR = 036624
ERINDX = 016550
ERR = 040000
ERROR = 104000
ERRVEC = 000004
ES.SAV = 036406
FER = 000020
FILLZ = 026770
FILL0 = 027076
FMT = 010000
FMTDPB = 005540
FMTWRT = 005630
FMT16 = 010000
FUNCT1 = 021272
FUNCT2 = 021414
FUNCT3 = 021624
FUNCT4 = 021676
FUNCT5 = 021774
FUNCT6 = 022112
FUNCT7 = 022230
FUNCT8 = 022350
F1 = 000002
F2 = 000004
F3 = 000010
F4 = 000020
F5 = 000040
GETREG = 000141
GETREQ = 036316
GO = 000001
GTSWR = 104406
HCE = 000200
HCI = 002000
HCRC = 000400
HDRBIT = 001410
HDRSET = 015010
HEDERR = 001354
HT = 000011
IAE = 002000

BSAVE	023756	MPE	- 000400	PFECH3	024360	REJEND	016534	SC6	033610
IE	= 000120	MRD	- 000020	PFECH4	024370	RELSE	= 000113	SC6A	033724
ILF	= 000001	MRMCS1	046076	PFTSTN	024374	REPLZ	026774	SC7	034052
ILR	= 000002	MRMVEC	046105	PGE	- 002000	RESET	020754	SC8	034130
INITMF	042143	MSCMPT	037427	PGM	= 001000	RESREG	= 104413	SEARCH	= 000131
INITUS	042100	MSFLD	037021	PIP	= 020000	RESTR	017522	SECCU	005434
INSERT	021160	MSFOR	037315	PIRQ	= 177772	RESVEC	= 000010	SEC30	001356
OUTVEC	= 000020	MSGBLK	037740	PIRQVE	= 000240	RETBAD	011644	SEEK	= 000105
IR	= 000100	MSG13A	041450	POPQUE	036340	RETRY	001342	SEEKFG	030420
ISR	033114	MSINIT	042033	PRO	- 000000	RMADR	030456	SELDRV	= 000145
LF	= 000012	MSIZE	041771	PR1	= 000040	RMA	- 000016	SERML	012356
LODEV	036521	MSPRM	042362	PR2	= 000100	RMA	= 000004	SETBSF	020410
OP.CK	016646	MSQVER	037337	PR3	= 000140	RMCS1	= 000000	SETDPB	016714
EST	= 002000	MSTCK	= 000010	PR4	- 000200	RMCS2	= 000010	SETFMT	= 000143
STRK	001324	MSVER	037376	PR5	= 000240	RMDA	= 000006	SETHDR	017120
MADRER	037215	MUNIT	036573	PR6	= 000300	RMDB	= 000022	SETVEC	010100
MANTR	022702	MUSDR	036751	PR7	- 000340	RMDC	= 000034	SEI.IE	035600
MAXCYL	001326	MUTLTY	040521	PS	= 177776	RMD5	= 000012	SKI	= 040000
MAXSEC	001360	MVERFY	037062	PSEL	= 002000	RMDT	= 000026	SLASH	036607
MAXTRK	001332	MWC	001352	PSW	177776	RMEC1	= 000044	SNGSEC	001322
MCLK	= 000002	MWR	= 000040	PWRVEC	= 000024	RMEC2	= 000046	SOF SW	001316
MCP	= 020000	MXF	- 001000	QCNT	035652	RMERRS	030320	SORT1	013474
MCFMX	030454	MXWWDW	030464	QDRV0	035744	RMER1	- 000014	SORT2	020250
MDRNP	036675	M16BIT	037106	QDRV1	035764	RMER2	- 000042	SRCHWT	030402
MER11	036722	M18BIT	037141	QDRV2	036004	RMHR	= 000036	STACK	= 001100
MESG1	037533	NBA	= 100000	QDRV3	036024	RMINIT	030466	STARS	042423
MESG10	041140	NED	- 010000	QDRV4	036044	RMLA	- 000020	START	007012
MESG11	041224	NEM	- 004000	QDRV5	036064	RMMR1	- 000024	START1	007020
MESG12	041310	NEXT	005536	QDRV6	036104	RMMR2	= 000040	STCLK1	017436
MESG13	041374	NOENTR	042206	QDRV7	036124	RMOF	= 000032	STCLK2	017506
MESG14	041502	NOINIT	042314	QINPT	035662	RMR	= 000004	STCLK3	017512
MESG15	041513	NOTPRS	036474	QOUTPT	035702	RMSN	= 000030	STKLMT	= 177774
MESG16	041563	NOTRM	036453	QSTART	035722	RMTMR	034476	STO	034566
MESG17	041563	NOTSAF	036511	QSTOP	035724	RMVEC	030460	STO1	034622
MESG18	041630	NOUPDT	042255	QTERM	036144	RMWC	= 000002	STO2	034716
MESG19	041665	NUMERR	037442	RBUF	046224	RM.REG	005560	STO3	034746
MESG2	037572	OFDIR	- 000001	RDCHR	= 104410	RM05	031214	STO5	034772
MESG3	037643	OFFSET	000115	RDDAT	= 000171	RTC	000117	STO6	035000
MESG4	037704	OPI	- 020000	RDDHD	= 000173	R6	0000006	STO7	035036
MESG5	040564	OPT	031506	RDLIN	= 104411	R7	0000007	STO8	035066
MESG6	040642	OR	000200	RDY	- 000200	SAVEFG	030416	STO9	035076
MESG7	040720	O.ENTR	017642	RD.ADR	035134	SAVREG	= 104412	ST.CLK	017360
MESG8	040776	PACKSN	037473	RD.RM	035110	SAVWC	001346	ST1	010446
MESG9	041054	PAR	- 000010	RD.RM1	035132	SC	033326	ST2	011566
MF	= 100000	PARENT	020032	RD.RM2	035256	SCAWC	017072	ST3	013056
MFG16	001414	PAR1	005754	RD.RM3	035262	SCOPE	- 000004	SVRH70	035462
MFG18	002420	PAR2	005764	RD.RM4	035266	SC01	= 000100	SWR	001154
MFORMT	037033	PAR3	005774	RD.WRD	035136	SC02	= 000200	SWREG	000176
MINCYL	001330	PAR4	006004	READIN	- 000121	SC04	= 000400	SW0	- 000001
MINTRK	001334	PAR5	006014	RECAL	- 000107	SC10	= 001000	SW00	= 000001
MINX	= 000004	PAR6	006032	RECORD	020146	SC11	034160	SW01	= 000002
MLODEV	036771	PAT	000020	REJCT1	016430	SC12	034270	SW02	= 000004
MMODE	041732	PATA	001336	REJCT2	016442	SC13	034340	SW03	= 000010
MODE	001320	PATB	001340	REJCT3	016464	SC20	= 002000	SW04	= 000020
MOFFLN	036654	PFECH	024234	REJCT4	016476	SC3	033376	SW05	= 000040
MNI	- 020000	PFECH1	024244	REJCT5	016510	SC4	033402	SW06	= 000100
MNI	- 010000	PFECH2	024326	REJCT6	016522	SC5	033414	SW07	- 000200

SW08 = 000400	JLDFLG 030406	\$AUTOB 001150	\$ITEMB 001130	\$SAVRE 027752
SW09 = 001000	JNS = 040000	\$BASE 001264	\$LF 001204	\$SAVR6 030302
SW1 = 000002	JNSTAT 036555	\$BDADR 001136	\$LFLG 027747	\$SB2D 027100
SW10 = 002000	JNTOFF 036432	\$BDDAT 001142	\$LKCSB 001302	\$SB20 027330
SW11 = 004000	UNTON 036443	\$BELL 001200	\$LKCSR 001300	\$SETUP= 000116
SW12 = 010000	UPDBSF 001406	\$CDW1 001270	\$LKS 001310	\$STUP = 177777
SW13 = 020000	UPDCYL 017206	\$CDW2 001272	\$LLVEC 001312	\$SUPRL 026670
SW14 = 040000	UPDTRK 017320	\$CHARC 026212	\$LPADR 001122	\$SUPRS 026704
SW15 = 100000	UPE = 020000	\$CKSWR 024714	\$LPERR 001124	\$SUPR1 026716
SW2 = 000004	USSAV 004430	\$CMTAG 001114	\$LPVEC 001304	\$SUPR2 026760
SW3 = 000010	USTAB 003424	\$CM3 = 000000	\$MADR1 001242	\$SVPC = 000210
SW4 = 000020	US1 = 000001	\$CM4 = 000001	\$MADR2 001246	\$SWR = 123000
SW5 = 000040	US2 = 000002	\$CNTLC 025621	\$MADR3 001252	\$SWREG 001232
SW6 = 000100	US4 = 000004	\$CNTLG 025633	\$MADR4 001256	\$TESTN 001214
SW7 = 000200	VFYHDR 015110	\$CNTLU 025626	\$MAIL 001210	\$TKB 001162
SW8 = 000400	VV = 000100	\$COMMA 036602	\$MAMS1 001240	\$TKCNT 024376
SW9 = 001000	WC = 001350	\$CPUOP 001236	\$MAMS2 001244	\$TKINT 024414
T 036615	WCE = 040000	\$CRLF 001205	\$MAMS3 001250	\$TKQEN= 024413
TABIAL 006052	WCF = 000040	\$DBLK 026660	\$MAMS4 001254	\$TKQIN 024400
TABINT 012146	WCKD = 000151	\$DB2D 027134	\$MBADR 001102	\$TKQOU 024402
TABLD 012226	WCKHD = 000153	\$DB20 027364	\$MFLG 027746	\$TKQSR 024404
TABLE 005650	WCTBL 006164	\$DECVL 027314	\$MNEW 025651	\$TKS 001160
TABLE2 005702	WLE = 004000	\$DEVCT 001220	\$MSGAD 001224	\$TKSRV 024464
TABLE3 005720	WRAP 001376	\$DEVM 001266	\$MSGLG 001226	\$TMP0 001174
TABLE4 005736	WRL = 004000	\$DOAGN 016362	\$MSGTY 001210	\$TN = 000002
TAB.XY= 001114	WRTDAT= 000161	\$DTBL 026650	\$MSWR 025640	\$TNPWR 027244
TAP = 040000	WRTHD = 000163	\$ENDAD 016352	\$MTYP1 001241	\$TPB 001166
TBITVE= 000014	WTRK 013214	\$ENDCT 016336	\$MTYP2 001245	\$TPFLG 001173
ID 033156	WTRKA 013676	\$ENV 001230	\$MTYP3 001251	\$TPS 001164
TIMER 030422	WTRKB 013774	\$ENVM 001231	\$MTYP4 001255	\$TRAP 030046
TKVEC = 000060	WTRKC 014060	\$EOP 015740	\$NULL 001170	\$TRAP2 030070
TPVEC = 000064	WTRKD 014142	\$EOPCT 016330	\$NWTST 000000	\$TRP = 000014
*RAPVE= 000034	WTRKE 014210	\$ERFLG 001117	\$OCNT 026440	\$TRPAD 030102
TRE = 040000	WTRKF 014124	\$ERMAX 001131	\$OCTVL 027466	\$TSTM 001104
TRKTST 016770	WTRKH 014154	\$ERROR 023330	\$OMODE 026442	\$TSTM 001116
TRK1 = 004000	WTRKX 013270	\$ERRPC 001132	\$PASS 001216	\$TTYIN 025602
TRK10 = 040000	WTRKZ 015076	\$ERRTB 006460	\$PASTM 001106	\$TYPDS 026444
TRK2 = 010000	WTRK1 013646	\$ERTTL 001126	\$POWER 030304	\$TYPE 025662
*RK20 = 100000	WTRK2 014224	\$ESCAP 001176	\$PWRAD 030272	\$TYPEC 026074
TRK4 = 020000	WRT.AD 035360	\$ETABL 001230	\$PWRDN 030132	\$TYPEX 026214
TRNSWT 030400	WRT.RM 035270	\$ETEND 001274	\$PWRMG 030266	\$TYPDC 026242
TRIVEC= 000014	WRT.R1 035354	\$FATAL 001212	\$PWRUP 030204	\$TYPON 026256
TST1 007034	WRT.R2 035446	\$FFLG 027750	\$QUES 001204	\$TYPOS 026216
TYLIST 022512	WRT.R3 035452	\$FILLC 001172	\$RDCHR 025256	\$UNIT 001222
TYPACK 022622	WRT.R4 035456	\$FILLS 001171	\$RDLIN 025346	\$UNITM 001110
TYPADR 017732	WRT.R5 035460	\$GDADR 001134	\$RDSZ = 000017	\$USWR 001234
TYPK 022626	WRT.WD 035356	\$GDDAT 001140	\$RESRE 030010	\$VECT1 001260
*YPDS = 104405	XSIZE 010406	\$GET42 016342	\$RMADR 001274	\$VECT2 001262
TYPE = 104401	XXDP 001412	\$GTSWR 025004	\$RMVEC 001276	\$XOFF = 000023
TPERR 023760	\$APTHD 001100	\$HD = 000000	\$RMO2 036536	\$XON = 000021
TYPOC = 104402	\$ATYC 027530	\$HIBTS 001100	\$RMO3 036543	\$GET4= 000000
TYPON = 104404	\$ATY1 027504	\$ICNT 001120	\$RMO5 036550	\$OFILL 026441
TYPOS = 104403	\$ATY3 027512	\$ILLUP 030276	\$RTNAD 016364	\$X = 001100
F 040000	\$ATY4 027522	\$INTAG 001151		

AB: 146634
000000

000
001

ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 53504 WORDS (209 PAGES)
DYNAMIC MEMORY AVAILABLE FOR 70 PAGES
CZRLB.BIC,CZRLB/C=CZRLB.DOC,CZRLB.SYSMAC/M

\$FILLC	6-0#	32-1	32-1	32-1					
\$FILLS	6-0#	32-1	32-1						
\$GDADR	6-0#								
\$GDDAY	6-0#	29-1*	49-18						
\$GET42	10-20	19-1#							
\$GTSWR	31-1#	43-1	43-1						
\$HND	4-62	4-62	4-62						
\$HIBTS	5-8#								
\$ICNT	6-0#								
\$ILLUP	44-1	44-1	44-1#						
\$INTAG	6-0#	31-1	31-1	31-1	31-1	31-1*			
\$ITEMB	6-0#	29-1	29-1	29-1	29-1	29-1	29-1*	29-1*	30-8
\$LF	6-0#	29-1	29-1	31-1	31-1	31-1	32-1	32-1	
\$LFLG	41-1#	41-1*							
\$LKCSB	7-0#	21-167*							
\$LKCSR	7-0#	21-162	21-168*						
\$LKS	7-0#	21-172	21-177*						
\$LLVEC	7-0#	21-173							
\$LPADR	6-0#								
\$LPERR	6-0#	11-39*	15-194*	16-7*	18-25*	21-39	29-1		
\$LPVEC	7-0#	21-163							
\$MADR1	6-0#								
\$MADR2	6-0#								
\$MADR3	6-0#								
\$MADR4	6-0#								
\$MAIL	5-8	5-8	6-0#	9-21	9-26	9-31	29-1	32-1	
\$MAMS1	6-0#								
\$MAMS2	6-0#								
\$MAMS3	6-0#								
\$MAMS4	6-0#								
\$MBADR	5-8#								
\$MFLG	41-1	41-1#	41-1*	41-1*					
\$MNEW	31-1	31-1#							
\$MSGAD	6-0#	41-1	41-1*						
\$MSGLG	6-0#	41-1*							
\$MSGTY	6-0#	41-1	41-1	41-1*	41-1*				
\$MSWR	31-1	31-1#							
\$MTYP1	6-0#								
\$MTYP2	6-0#								
\$MTYP3	6-0#								
\$MTYP4	6-0#								
\$NULL	6-0#	32-1	32-1	32-1					
\$NWTST	9-21#								
\$OCNT	33-1#	33-1*	33-1*						
\$OCTVL	40-1	40-1#							
\$OMODE	33-1	33-1#	33-1*	33-1*	33-1*	33-1*			
\$PASS	6-0#	9-26*	19-1	19-1	19-1*	19-1*			
\$PASTM	5-8#								
\$POWER	44-1	44-2#							
\$PWRAD	44-1#								
\$PWRDN	9-26	44-1	44-1#						
\$PWRMG	44-1#								
\$PWRUP	44-1	44-1#							
\$QJFS	6-0#	29-1	29-1	31-1	31-1	31-1	31-1	32-1	32-1
\$R2A	43-1								
\$RDCHR	31-1#	43-1	43-1						
\$RDDEL	43-1								

STYPE	32-1#	41-1	43-1	43-1		
STYPEC	31-1	32-1	32-1	32-1	32-1#	
STYPEX	32-1	32-1	32-1#			
STYPOC	33-1#	43-1	43-1			
STYPON	33-1	33-1#	43-1			
STYPOS	33-1#	43-1				
SUNIT	6-0#	7-0				
SUNITM	5-8#					
SUSWR	6-0#					
SVECT1	6-0#	9-78	9-80			
SVECT2	6-0#					
SXOFF	32-1	32-1				
SXON	31-1	32-1	32-1			
.SASTA	41-1	41-1				
.SX	5-8	5-8#				
A16	4-76#					
A17	4-77#					
ABASE	4-263#	6-0	6-0			
ABORT	20-29	46-79#				
ACDW1	6-0	6-0				
ACDW2	6-0	6-0				
ACK	4-251#					
ACPUOP	6-0	6-0				
ACTDRV	45-93#	45-348*	45-399*	45-692*	45-700*	45-987
ACTSTR	45-99#	45-989*	45-:03*			
ADDRIS	21-246	46-43#				
ADDW0	6-0					
ADDW1	6-0					
ADDW10	6-0					
ADDW11	6-0					
ADDW12	6-0					
ADDW13	6-0					
ADDW14	6-0					
ADDW15	6-0					
ADDW2	6-0					
ADDW3	6-0					
ADDW4	6-0					
ADDW5	6-0					
ADDW6	6-0					
ADDW7	6-0					
ADDW8	6-0					
ADDW9	6-0					
ADEVCT	6-0	6-0				
ADEVN	6-0	6-0				
ADRTBL	7-0#	15-191	16-55	19-1	24-194	
AENV	6-0	6-0				
AENVN	6-0	6-0				
AFATAL	6-0	6-0				
AMADR1	6-0	6-0				
AMADR2	6-0	6-0				
AMADR3	6-0	6-0				
AMADR4	6-0	6-0				
AMAMS1	6-0	6-0				
AMAMS2	6-0	6-0				
AMAMS3	6-0	6-0				
AMAMS4	6-0	6-0				
AMSGAD	6-0	6-0				

BIT13	4-68#	21-10	21-43	29-1	45-376	45-821	45-:15							
BIT14	4-68#	17-11	17-13	21-10	21-43	45-388	45-423	45-806	45-965	45-:76	45-:22	45-:26	45-:41	45-:41
BIT15	4-68#	12-25	12-43	15-123	15-138	15-142	15-157	15-172	45-376	45-388	45-391	45-393	45-403	45-403
	45-619	45-656	45-658	45-735	45-850	45-866	45-876	45-886	45-966	45-:40	45-:76	45-:84		
BIT2	4-68#	21-10	45-:84											
BIT3	4-68#													
BIT4	4-68#													
BIT5	4-68#													
BIT6	4-68#													
BIT7	4-68#	10-7												
BIT8	4-68#													
BIT9	4-68#													
BLNKS1	14-10	46-22#												
BLNKS2	9-134	21-251	24-200	30-51	30-60	30-71	46-21#	51-21	51-30					
BLNKS3	46-20#													
BLNKS4	9-104	46-19#												
BPTVEC	4-68#													
BSE	4-228#	18-71												
BSFAVL	7-0#	11-24*	11-86*	11-114	12-6	15-36	15-63*							
BUFP	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0
	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0	7-0
	7-0	7-0	7-0	7-0	11-29	11-69	11-73	11-75	11-77	11-79	11-81	11-84	11-118	11-126
	11-135	11-141	14-25	15-115	18-15	19-1	21-56	21-103	21-124	21-149	22-12	22-26	22-40	22-43
	22-46	22-49	22-53	22-56	53-7#									
BUFV	18-16	53-9#												
BUSADR	9-72	51-13#												
BYTE16	7-0#	24-224												
BYTE18	7-0#	24-234												
C	21-247	46-17#												
C.ENTR	10-117	21-214#	21-215	21-245										
CALIN	13-5#													
CHGADR	7-0#	9-18*	51-13	51-15*										
CI1	45-445	45-473#												
CI3	45-447	45-497#												
CI4	45-439	45-519#												
CI5	45-495	45-517	45-597#	45-607										
CI6	45-535	45-545	45-547	45-549	45-603#									
CI7	45-378	45-454	45-485	45-489	45-493	45-502	45-511	45-515	45-527	45-534	45-540	45-544	45-558	45-564
	45-568	45-578	45-589	45-606	45-609#	45-716	45-911	45-:16						
CI7B	45-624#	45-917												
CI8	45-627	45-641#	45-770	45-:67										
CK.CHR	10-124	28-50#	28-87	28-95										
CK.DEC	28-28#	28-56												
CK.DIG	21-280	24-192	27-17	27-20	27-23	28-81#								
CK.NUM	51-24	51-33	52-13#											
CK.OCT	28-10#	28-58												
CKSWR	29-1	29-1	43-1#											
CKTRK	16-6#													
CLOCK	21-164	21-174	21-208#											
CLR	4-96#	9-93	10-140	45-234	45-681									
CLROUE	45-216	45-680	45-:95#											
CNTLC	7-0#	9-67*	10-117*	21-245*	31-1	31-1								
COLON	10-121	46-15#												
CPSAVE	29-1	29-1	29-1	29-1	29-1	29-1#	29-1*	29-1*	30-79					
CR	4-68#	32-1	32-1	48-17										
CRLE	4-68#	9-6	9-31	9-31	9-45	9-56	9-62	9-63	32-1	32-1	44-2	46-12	46-13	46-23
	46-23	46-24	46-25	46-26	46-27	46-28	46-32	46-33	46-34	46-35	46-36	46-37	46-37	46-38

	46-38	46-39	46-39	46-40	46-44	46-45	46-46	46-47	46-48	46-48	46-49	46-50	46-51	46-52
	46-53	46-54	46-55	46-56	46-57	46-58	46-59	46-60	46-61	46-62	46-63	46-64	46-65	46-66
	46-67	46-67	46-68	46-68	46-70	46-71	46-72	46-75	46-76	46-77	46-78	46-79	46-80	46-80
	46-81	46-81	46-83	46-83										
DCK	4-153#	16-33												
DDISP	4-68#	6-0	9-26											
DDRIVE	7-0#	29-1*	49-4	49-5	49-6	9-133*	9-133*	9-151	9-151*	10-12*	10-13*	10-18	10-40	10-48*
DEVMP	7-0#	9-99*	9-132*	9-133	9-133*	9-151	9-151*	10-12*	10-13*	10-18	10-40	10-48*	19-1	19-1
	19-1*	21-233*	21-234*											
DF1	8-7	50-3#												
DF10	8-56	8-63	8-70	8-77	8-84	8-91	8-98	8-119	8-126	50-13#				
DF17	8-105	50-19#												
DF2	8-14	50-5#												
DF20	8-112	50-21#												
DF23	50-29#													
DF24	8-140	50-31#												
DF25	8-49	8-133	8-147	50-39#										
DF3	8-21	50-7#												
DF4	8-28	50-9#												
DF6	8-42	50-11#												
DH1	8-5	48-3#												
DH10	8-54	8-61	8-68	8-75	8-82	8-89	8-96	8-117	8-124	48-8#				
DH10A	48-9#	50-15												
DH10B	48-10#	50-17												
DH17	8-103	48-11#												
DH2	8-12	48-4#												
DH20	8-110	48-12#												
DH20A	48-13#	50-23	50-33											
DH20B	48-14#	50-25	50-35											
DH20C	48-15#	50-27	50-37											
DH23	8-47	8-131	48-16#											
DH24	8-138	48-17#												
DH25	8-145	48-19#												
DH3	8-19	48-5#												
DH4	8-26	48-6#												
DH6	8-40	48-7#												
DISPLA	6-0#	9-26*	9-26*	29-1*										
DISPRE	5-1#	9-26												
DLT	4-106#													
DMD	4-157#													
DONE	19-1	19-1	19-3#											
DPINT	45-61#	45-245	45-248	45-358	45-790	45-817	45-956	45-958*	45-:31	45-:54	45-:60	45-:70*		
DPK	4-127#													
DPRQS	45-70#	45-364	45-412*	45-449*	45-629*	45-646	45-664*	45-793	45-:33	45-:56	45-:62	45-:80*		
DRIVE	7-0#	10-47*	10-129*	10-158	11-25	14-8	21-53	22-91	49-8	49-9	49-12	49-13	49-17	49-18
	49-22													
DRQ	4-190#													
DRVACT	45-30#	45-372	45-552*	45-600*	45-631*	45-644	45-663*	45-705*	45-813	45-848	45-880*	45-888*	45-908	45-:23*
	45-:45*													
DRVCLR	4-246#													
DRVINT	45-236	45-270#	45-360	45-945	45-959									
DRVQUE	45-367	45-380	45-:35#											
DRVSTA	9-105	10-49	10-144	45-40#	45-226*	45-227*	45-228*	45-229*	45-239*	45-271*	45-281*	45-325*	45-331*	45-354
	45-362	45-386	45-420	45-424	45-553*	45-684*	45-796	45-804	45-819	45-874*	45-881*	45-897	45-961	45-:71*
DRVTYP	9-109	9-136	10-57	10-150	10-163	45-52#	45-272*	45-288*	45-293*	45-298*	45-303*	45-389	45-685*	
DRY	4-126#													
DS.CVL	7-0	7-0	7-0	7-0#	13-33*	23-13	23-23	24-16	24-29	24-62	24-75	24-219	29-1*	49-1*

ERRR	4-68#													
ERRR	4-68#	9-26	9-26*	9-26*	9-28*	9-29*	21-160*	21-161*	21-171*	21-180*	29-1	29-1*	29-1*	
ERRR	45-773	45-831	45-833	45-119	45-178	45-191#								
F1	4-116#													
F2	4-117#													
F3	4-118#													
F4	4-119#													
F5	4-120#													
FER	4-142#	16-33												
FILLO	36-11*	36-15	36-36*	36-39#										
FILLZ	26-16	36-11#												
FMT	4-240#	18-82	21-110	22-98	22-105									
FMT16	4-214#													
FMTDPB	7-0#	10-158*	11-25*	11-26*	11-27*	11-28*	11-29*	11-30*	11-31*	11-32*	11-34	11-36	11-41*	11-43
	11-45	11-67	15-8*	15-11*	15-12*	15-14	15-16	15-21	15-23	15-48	15-50	15-113*	15-114*	15-115*
	15-119*	15-127	15-141*	15-143	15-145	15-163	15-168*	15-181	15-186*	15-189	15-191*	15-193*	15-197	15-199
	16-6*	16-10	16-12	16-53*	16-55*	16-63	16-68*	16-79	18-17*	18-18*	18-22*	18-26*	18-27	18-29
	18-33*	18-34*	18-36	18-38	18-41*	18-43	18-45	18-78	18-80	18-100	18-102*	18-109*	18-110*	18-111
	18-116*	18-119*	18-120	18-123*	18-124	19-1	19-1	19-1	19-1	19-1	19-1*	19-1*	19-1*	19-1*
	19-1*	19-1*	19-1*	19-1*	19-1*	19-1*	19-1*	19-1*	20-9	21-8	21-42	21-53*	21-54*	21-55*
	21-56*	21-57*	21-58*	21-59*	21-60*	21-67*	21-68	21-73*	21-76*	21-77	21-80*	21-81	21-91*	21-92*
	21-93*	21-248	21-254	21-304	21-306	21-308	21-314	21-315	22-82	22-84	22-88	22-96	22-97	22-99
	22-101	29-1	29-1	49-22										
FMTWRT	7-0#	22-91*	22-92*	22-93*	22-94*	22-95*	22-96*	22-97*	22-108	22-110				
FUNC1	24-6#													
FUNC12	7-0	24-41#												
FUNC13	7-0	24-87#												
FUNC14	7-0	24-104#												
FUNC15	24-127#													
FUNC16	7-0	24-157#												
FUNC17	7-0	24-188#												
FUNC18	24-215#													
GETREG	4-253#													
GETREQ	45-413	45-651	45-726	45-800	45-839	45-910	45-965	45-139	45-173	45-181	45-156#			
GNS	5-1	5-1	9-6	9-31	9-45	9-56	9-62	9-63	43-1	43-1	43-1	43-1	43-1	43-1
	43-1	43-1	43-1	43-1	43-1	43-1	43-1	43-1	43-1	43-1	43-1	43-1	43-1	43-1
	43-1	43-1												
GO	4-115#													
GTSWR	9-31	43-1#												
HCE	4-145#	16-33	18-65											
HCI	4-212#													
HCRC	4-146#	16-33	18-67											
HDRBIT	7-0#	16-41*	17-7*	22-90										
HDRSET	15-147	17-3#												
HEDERR	7-0#													
HT	4-68#	32-1	32-1											
IAE	4-148#													
IBSAVE	29-1	29-1	29-1	29-1	29-1	29-1#	29-1*	29-1*	29-1*					
IE	4-74#													
ILF	4-138#													
ILR	4-139#													
INITMF	24-132	46-77#												
INITUS	24-162	46-76#												
INSERT	23-8#	24-18	24-31	24-64	24-77	24-230	24-240							
IOTVEC	4-68#													
IR	4-97#													
ISR	45-231	45-692#												

[illegible]

[illegible]

WTRK	15-50												
WTRK1	15-111#												
WTRK2	15-193#	16-70											
WTRKA	15-119#	16-96											
WTRKB	15-128	15-141#	15-144										
WTRKC	15-139	15-159#											
WTRKD	15-122	15-135	15-150	15-154	15-176#								
WTRKE	15-169	15-189#											
WTRKF	15-134	15-153	15-171#										
WTRKH	15-174	15-179#											
WTRKX	15-21#	15-130	17-5	17-23									
WTRKZ	15-25	17-20#											
XSIZE	10-5#												
XXDP	7-0#	9-36*	9-39*	9-40	9-42*	9-47	9-58	9-124	9-126	10-51	10-53	10-130	10-132

ASH	4-68#													
STARS	4-68#	5-5	5-8	5-8	5-8	6-0	6-0	6-0	9-21	19-1	29-1	31-1	31-1	31-1
	31-1	31-1	32-1	33-1	34-1	35-4	37-1	38-1	39-1	40-1	41-1	42-1	43-1	44-1
	44-1	45-15												
SWRSU	4-68#	9-26	9-26#											
TRMTRP	43-1#													
TYPBIN	4-68#													
TYPDEC	4-68#	19-1	30-48											
TYPNAM	4-68#	9-31												
TYFUM	4-68#													
TYPOCS	4-68#	9-103	14-8											
TYPOCT	4-68#	30-46	31-1											
TYPTXT	4-68#	9-6	9-45	9-56	9-62	9-63								