



.REM 6

IDENTIFICATION

PRODUCT CODE: AC-FF61A-MC

PRODUCT NAME: CZVSWAO

PRODUCT DATE: 4 JUL 85

MAINTAINER: CSS ENGINEERING

AUTHOR: JOHN BOWSKILL

Copyright (c) 1985 by
Digital Equipment Corporation, Maynard, Massachusetts
All Rights Reserved

This software is furnished under a license and may be used and copied only in accordance with the terms of such license and with the inclusion of the above copyright notice. This software or any other copies thereof may not be provided or otherwise made available to any other person. No title to and ownership of the software is hereby transferred.

The information in this software is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation.

Digital assumes no responsibility for the use or reliability of its software on equipment that is not supplied by Digital.

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DEC	PDP	UNIBUS	MASSBUS
DECUS	DECTAPE	VAX	

```

} } } } } } } }
} d } i } g } i } t } e } l }
} } } } } } } }

```

6

.REM 6

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM & HARDWARE REQUIREMENTS
2.0	OPERATING INSTRUCTIONS
2.1	COMMANDS
2.2	SWITCHES
2.3	FLAGS
2.4	HARDWARE QUESTIONS
2.7	EXTENDED P-TABLE DIALOGUE
2.8	QUICK STARTUP PROCEDURE
3.0	ERROR INFORMATION
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

THIS DIAGNOSTIC VERIFIES THAT DEVICES UNDER TEST ARE VSV21 DEVICES AND CAUSES ALL VSV21 ON-BOARD MICRODIAGNOSTICS TO BE EXECUTED. IT PROVIDES COMPLETE FUNCTION LEVEL COVERAGE AND FRU CALLOUT.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

1.2 SYSTEM & HARDWARE REQUIREMENTS

THIS DIAGNOSTIC IS DESIGNED TO RUN ON A 11/23+ OR A 11/73 WITH A MINIMUM MEMORY OF 32 K BYTES.
THE MODULE UNDER TEST IS A M7656.
TESTS 4 , 13 , 14 , 16 AND 17 REQUIRE PART NUMBER VSV21-AJ WHICH CONSISTS OF THE FOLLOWING:
1 OFF 12-15336-01 CONN, LOOPBACK EIA DATA 25-WAY
2 OFF 70-20130-01 CONN, LOOPBACK EIA DATA 9-WAY
1 OFF 70-20131-01 CONN, LOOPBACK KEYBOARD JACK

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP+ USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY BRIEF DESCRIPTION OF THEM. THE XXDP+ USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ↑C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP+ MONITOR (XXDP+ OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SECTION 4.0)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY 'DDDD'.

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDD	EXECUTE DDDDD PASSES (DDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. FLAGS ARE DESCRIBED IN SECTION 2.3.
/EOP:DDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10 12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
HOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXR*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE

LOT LOOP ON TEST
EVL EXECUTE EVALUATION (ON DIAGNOSTICS WHICH
HAVE EVALUATION SUPPORT)

*ERROR MESSAGES ARE DESCRIBED IN SECTION 3.1

SEE THE XXDP+ USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A "BELL" ON ERROR, YOU MAY USE THE FOLLOWING STRING:

/FLAGS:LOE:IER:BOE

2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 6 OF THE XXDP+ USER'S MANUAL) OR YOU WISH TO USE THE HARDCODED DEFAULTS (SEE BELOW) OR YOU HAVE JUST RUN THE DIAGNOSTICS AND WISH TO KEEP THE SAME HARDWARE INFORMATION. WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL). YOU WILL THEN BE ASKED THE FOLLOWING QUESTIONS FOR EACH UNIT.

DEVICE ADDRESS (0) 172010 ?
VECTOR ADDRESS (0) 320 ?

WHERE DEVICE AND VECTOR ADDRESS ARE DEFINED IN SECTION 5.0.

IN THE FOLLOWING EXAMPLE THE USER SELECTS 1 UNIT WITH 172020 FOR DEVICE ADDRESS INSTEAD OF THE DEFAULT 172010 AND 324 FOR VECTOR ADDRESS INSTEAD OF THE DEFAULT 320.

CHANGE HW (L) ? Y

* UNITS (D) ? 1

DEVICE ADDRESS (0) 172010 ? 172020
VECTOR ADDRESS (0) 320 ? 324

THE HARDCODED DEFAULTS ARE FOR 4 UNITS WITH THE FOLLOWING ADDRESSES:

UNIT	DEVICE ADDRESS	VECTOR ADDRESS
#1	172010	320
#2	172020	324
#3	172030	330
#4	172040	334

2.5 EXTENDED P-TABLE DIALOGUE

WHEN YOU ANSWER THE HARDWARE QUESTIONS, YOU ARE BUILDING ENTRIES IN A TABLE THAT DESCRIBES THE DEVICES UNDER TEST. THE SIMPLEST

WAY TO BUILD THIS TABLE IS TO ANSWER ALL QUESTIONS FOR EACH UNIT TO BE TESTED. IF YOU HAVE A MULTIPLEXED DEVICE SUCH AS A MASS STORAGE CONTROLLER WITH SEVERAL DRIVES OR A COMMUNICATION DEVICE WITH SEVERAL LINES, THIS BECOMES TEDIOUS SINCE MOST OF THE ANSWERS ARE REPETITIOUS.

TO ILLUSTRATE A MORE EFFICIENT METHOD, SUPPOSE YOU ARE TESTING A FICTIONAL DEVICE, THE XY11. SUPPOSE THIS DEVICE CONSISTS OF A CONTROL MODULE WITH EIGHT UNITS (SUB-DEVICES) ATTACHED TO IT. THESE UNITS ARE DESCRIBED BY THE OCTAL NUMBERS 0 THROUGH 7. THERE IS ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS CALLED THE Q-FACTOR. THIS Q-FACTOR MAY BE 0 OR 1. BELOW IS A SIMPLE WAY TO BUILD A TABLE FOR ONE XY11 WITH EIGHT UNITS.

UNITS (0) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0<CR>
Q-FACTOR (0) 0 ? 1<CR>

UNIT 2
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 1<CR>
Q-FACTOR (0) 1 ? 0<CR>

UNIT 3
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 4
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 3<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 5
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 4<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 6
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 5<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6<CR>
Q-FACTOR (0) 0 ? 1<CR>

UNIT 8
CSR ADDRESS (0) 160000<CR>
SUB-DEVICE # (0) ? 7<CR>
Q-FACTOR (0) 1 ? <CR>

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A

NON-DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER. LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION FEATURE.

* UNITS (D) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0,1<CR>
Q-FACTOR (0) 0 ? 1,0<CR>

UNIT 3
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2-5<CR>
Q-FACTOR (0) 0 ? 0<CR>

UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6,7<CR>
Q-FACTOR (0) 0 ? 1<CR>

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS TWO ENTRIES ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE "-" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES 2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS SHOWN BELOW.

* UNITS (D) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0-7<CR>
Q-FACTOR (0) 0 ? 0,1,0,...,1,1<CR>

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.

2.6 QUICK START-UP PROCEDURE (XXDP+)

TO START-UP THIS PROGRAM:

1. BOOT XXDP+
2. TYPE "R ZVSWAO"
3. TYPE "START"
4. ANSWER THE "CHANGE HW" QUESTION WITH "Y" (IF APPROPRIATE)
5. ANSWER ALL THE HARDWARE QUESTIONS IF ANSWER TO 4 WAS "Y"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS. THESE DEFAULTS ARE DESCRIBED IN SECTION 2.3.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

```
NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
ERROR MESSAGE
```

,WHERE: NAME = DIAGNOSTIC NAME
TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
NUMBER = ERROR NUMBER
UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

ERROR 1 : TEST 1 MUST BE PERFORMED FIRST

EXPLANATION: ALL TESTS (EXCEPT TEST 1) REQUIRE TEST 1 TO HAVE BEEN

RUN FIRST TO VERIFY THAT THE DEVICE IS A VSV21.
TEST 1 SHOULD NOW BE RUN.

OCCURRENCE: ANY TEST EXCEPT TEST 1.

ERROR 2 : TEST 2 MUST BE RUN FIRST TO ENABLE DMA

EXPLANATION: ALL TESTS NEEDING DMA ENABLED REQUIRE TEST 2 TO HAVE
BEEN RUN FIRST. TEST 2 SHOULD NOW BE RUN.

OCCURRENCE: TESTS 15,16,17 AND 18

ERROR 3 : TIMED OUT WHILE WAITING FOR STATUS VALID

EXPLANATION: THE STATUS VALID BIT IN THE CSR FOR THE CURRENT DEVICE
HAS NOT BEEN SET WITHIN A SUFFICIENTLY SHORT TIME.
THIS NORMALLY MEANS THAT THE ON BOARD FIRMWARE IS
WAITING FOR SOMETHING AND HAS NOT SET THE BIT.
AS THIS INDICATES WHEN THE CSR IS IN A VALID STATE TO
THE HOST FURTHER TESTING OF THIS DEVICE IS NOT POSSIBLE
UNTIL FIXED.

OCCURRENCE: ANY TEST.

ERROR 4 : THERE HAS BEEN A POWERUP - PLEASE REPEAT TEST 1

EXPLANATION: THE VSV21 HAS BEEN RESET. IT IS NECESSARY TO DO TEST 1
AGAIN. NOTE THAT DMA WILL ALSO HAVE BEEN DISABLED.

OCCURRENCE: ANY TEST.

ERROR 5 : CONTROLLER READY NOT SET IN CSR

EXPLANATION: THE CONTROLLER READY BIT IS NOT SET IN THE CSR FOR
THE CURRENT DEVICE. THIS MEANS THAT NO COMMAND CAN
BE WRITTEN TO IT BY THE HOST. TRY REPEATING TEST 1
AFTER INVESTIGATION.

OCCURRENCE: ANY TEST.

ERROR 6 : STATUS PACKET SHORTER THAN SPECIFIED LENGTH

EXPLANATION: IN PROGRAMMED I/O THE HOST PROCESSES A STATUS PACKET
BY READING THE PARAMETER REGISTER AND EXTRACTING THE
PACKET WORD BY WORD. IN THIS CASE THE LENGTH SPECIFIED
IN THE FIRST WORD INDICATES THAT THERE IS MORE DATA TO
COME BUT THE PARAMETER READY BIT IS NOT SET IN THE CSR
AND THUS THE PARAMETER REGISTER CANNOT BE READ TO GET
THE REST OF THE STATUS PACKET.

OCCURRENCE: ANY TEST WHEN DMA IS NOT ENABLED.

ERROR 7 : STATUS AVAILABLE EXPECTED BUT NOT FOUND
EXPLANATION: THE HOST HAS SENT A COMMAND TO THE VSV21 (WHICH HAS DMA ENABLED) AND IS THUS EXPECTING A 'STATUS AVAILABLE' MESSAGE IN THE CSR WHEN THE VSV21 HAS FINISHED PROCESSING. THIS HAS NOT HAPPENED.
OCCURRENCE: ANY TEST WHEN DMA IS ENABLED.

ERROR 8 : ERROR PACKET RECEIVED FROM VSV21
EXPLANATION: THE HOST HAS RECEIVED AN ERROR PACKET FROM THE VSV21.
OCCURRENCE: ANY TEST.

ERROR 9 : FAILED TO TRANSMIT STATUS ACKNOWLEDGE
EXPLANATION: THE HOST HAS ATTEMPTED TO SEND A 'STATUS ACKNOWLEDGE' COMMAND VIA THE CSR BUT THE CONTROLLER READY BIT HAS NOT BEEN SET AFTERWARDS.
OCCURRENCE: ANY TEST.

ERROR 10: TIMEOUT WAITING FOR STATUS
EXPLANATION: THE HOST HAS SENT A COMMAND TO THE VSV21 AND IS EXPECTING A STATUS ACKNOWLEDGE VIA THE PARAMETER REGISTER. THE PARAMETER READY BIT IN THE CSR HAS NOT BEEN SET WITHIN A SUFFICIENTLY SHORT TIME AS THIS INDICATES WHEN THE HOST CAN READ THE PARAMETER REGISTER.
OCCURRENCE: ANY TEST.

ERROR 11: DMA DATA MATCH ERROR
EXPLANATION: DATA RECEIVED BACK FROM THE VSV21 IS DIFFERENT TO THAT SENT. THERE IS SOMETHING WRONG WITH DMA.
OCCURRENCE: TESTS 2,16,17

ERROR 12: FAILED TO GET MICRO DIAGNOSTICS RETURN STATUS PACKET
EXPLANATION: THE HOST HAS FAILED TO GET A RETURN STATUS PACKET AFTER INVOKING A MICRODIAGNOSTICS TEST.
OCCURRENCE: TESTS 4-19

ERROR 13: MICRO DIAGNOSTIC TEST UNSUCCESSFUL
EXPLANATION: THE MICRODIAGNOSTIC TEST HAS FAILED.

OCCURRENCE: TESTS 4-19.

ERROR 14: ERROR PACKET EXPECTED BUT NOT RECEIVED

EXPLANATION: AN INVALID COMMAND IS SENT TO THE VSV21 IN TEST 3 AND SO AN ERROR PACKET IS EXPECTED. THIS DID NOT HAPPEN.

OCCURRENCE: TEST 3.

ERROR 15: TIMED OUT WAITING TO RECEIVE AN INTERRUPT

EXPLANATION: AN INTERRUPT HAS NOT BEEN RECEIVED WITHIN A SUFFICIENTLY SHORT TIME.

OCCURRENCE: TEST 20.

4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE "EOP" SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. SECTION 2.2 DESCRIBES SWITCHES.

5.0 DEVICE INFORMATION TABLES

THE VSV21 MODULE INTERFACES TO THE HOST PROCESSOR VIA THE PROGRAMMED I/O INTERFACE. THIS USES THREE REGISTERS WITHIN A BLOCK OF FOUR ADDRESSABLE WORD LOCATIONS ON THE HOST BUS. THE BLOCK IS ASSIGNED AN ADDRESS BEGINNING ON A MODULO-4 WORD BOUNDARY VIA HARDWARE ADDRESS SELECT SWITCHES. THIS ADDRESS IS TERMED THE DEVICE ADDRESS. THE BLOCK LOOKS LIKE THIS:

ADDRESS	READ	WRITE
177XXXX0	DMA ADDRESS REGISTER	HARDWARE INITIALIZE
177XXXX2	STATUS REGISTER	COMMAND REGISTER (CSR)
177XXXX4	PARAMETER REGISTER	PARAMETER REGISTER
177XXXX6	(UNDEFINED)	(UNDEFINED)

ADDRESS 177XXXX0 IS THE DEVICE ADDRESS. THE HARDWARE P-TABLE CONSISTS OF TWO VALUES FOR EACH DEVICE. THE FIRST IS THE DEVICE ADDRESS, THE SECOND IS THE VECTOR ADDRESS.

THE DMA ADDRESS REGISTER CONTAINS THE LEAST SIGNIFICANT 16 BITS OF THE PHYSICAL ADDRESS OF THE LAST DMA OPERATION PERFORMED BY THE CONTROLLER

WHEN DMA HAS BEEN ENABLED.

THE HARDWARE INITIALIZE REGISTER , WHEN WRITTEN TO , CAUSES THE VSV21 TO BE RESET.

THE STATUS REGISTER CONTAINS STATUS INFORMATION ON THE OPERATIONAL STATUS OF THE CONTROLLER AND THE PROGRESS OF OPERATIONS WHICH ARE BEING PERFORMED BY THE CONTROLLER. THE REGISTER CONTAINS THE FOLLOWING STATUS BITS.

BIT	DESCRIPTION
12	CONTROLLER READY BIT : THIS BIT IS A LOGICAL 1 WHEN THE CONTROLLER IS READY TO ACCEPT A NEW COMMAND FROM THE HOST. A LOGICAL 0 IN THIS BIT INDICATES THAT THE CONTROLLER CANNOT ACCEPT A NEW COMMAND.
13	PARAMETER READY BIT : THIS BIT IS A LOGICAL 1 WHEN THE CONTROLLER HAS INFORMATION FOR THE HOST. IT IS A LOGICAL 0 WHEN THERE IS NO MORE INFORMATION.
14	CONTROLLER ERROR BIT : THIS BIT IS A LOGICAL 1 WHEN THE VSV21 BOARD HAS BEEN RESET. IT WILL BE CLEARED WHEN A COMMAND IS WRITTEN TO THE COMMAND REGISTER OR THE PARAMETER REGISTER IS READ (PROVIDING THE PARAMETER READY BIT IS SET). THIS BIT IS A LOGICAL 0 WHEN THE VSV21 BOARD HAS NOT JUST BEEN RESET.
15	STATUS VALID BIT : THIS BIT IS A LOGICAL 1 WHEN THE STATUS OF THE ABOVE DEFINED BITS IS VALID. A LOGICAL 0 INDICATES THAT THE STATUS OF THE ABOVE DEFINED BITS IS NOT VALID AND MAY BE UPDATED. THE HOST MUST WAIT UNTIL THIS BIT IS SET BEFORE READING THE STATUS OF THE BITS AND TAKING ANY SUBSEQUENT ACTION.

THE COMMAND REGISTER IS THE REGISTER FOR PASSING COMMANDS FROM THE HOST TO THE VSV21.

THE PARAMETER REGISTER IS A READ/WRITE REGISTER. IT IS WRITTEN TO WHEN THE HOST NEEDS TO SEND PARAMETERS PRIOR TO WRITING TO THE COMMAND REGISTER. IT IS READ BY THE HOST WHEN THE VSV21 HAS SET THE PARAMETER READY BIT IN THE STATUS REGISTER. THE HOST KEEPS READING THE PARAMETER REGISTER FOR MORE INFORMATION UNTIL THE PARAMETER READY BIT IS CLEAR.

6.0 TEST SUMMARIES

TEST 1: VERIFY VSV21 PRESENCE

This test verifies that there is a VSV21 device at the current CSR. On the first pass it displays the version of the VSV21 and a message

warning the operator to attach external loopback connectors if he wishes tests 4 , 13 , 14 , 16 or 17 to be done. The test also disables interrupts.

TEST 2: IN DEPTH Q22 BUS TEST

This test performs an in-depth test of the Q22 bus by means of exercising the DMA mechanism in both directions. It sets up the DMA protocol and must be done before other tests requiring DMA.

TEST 3: FORCED ERROR TEST

This test sends an invalid command to the VSV21 to provoke an error packet.

TEST 4: FULL ON BOARD TESTS

This test invokes full on-board VSV21 microdiagnostics tests. If the HOE flag is specified the VSV21 will halt on error. If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error. If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 5: ROM CHECKSUM TEST

This test invokes the on-board VSV21 ROM CHECKSUM test. If the HOE flag is specified the VSV21 will halt on error. If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error. If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 6: NVRAM CHECKSUM TEST

This test invokes the on-board VSV21 NVRAM CHECKSUM test. If the HOE flag is specified the VSV21 will halt on error. If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error. If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 7: RAM TEST

This test invokes the on-board VSV21 RAM test. If the HOE flag is specified the VSV21 will halt on error. If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error. If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 8: RAM ADDRESSING TEST

This test invokes the on-board VSV21 RAM ADDRESSING test. If the HOE flag is specified the VSV21 will halt on error. If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error.

If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 9: 68K PROCESSOR TEST

This test invokes the on-board VSV21 68K PROCESSOR test.
If the HOE flag is specified the VSV21 will halt on error.
If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error.
If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 10: INTERNAL EXCEPTIONS TEST

This test invokes the on-board INTERNAL EXCEPTIONS test.
If the HOE flag is specified the VSV21 will halt on error.
If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error.
If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 11: ACRCI INTERNAL TEST

This test invokes the on-board ACRCI INTERNAL test.
If the HOE flag is specified the VSV21 will halt on error.
If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error.
If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 12: ACRCI EXTERNAL TEST

This test invokes the on-board VSV21 ACRCI EXTERNAL test.
If the HOE flag is specified the VSV21 will halt on error.
If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error.
If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 13: DUART BASIC TEST

This test invokes the on-board VSV21 DUART BASIC test on ports 0-3.
If the HOE flag is specified the VSV21 will halt on error.
If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on board tests to loop on error.
If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 14: DUART FULL TEST

This test invokes the on-board VSV21 DUART FULL test on ports 0-3.
If the HOE flag is specified the VSV21 will halt on error.
If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error.
If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 15: PERIPHERAL CONFIDENCE TEST

This test is not done if /FLA:UAM is specified on the START command.
This test allows the operator to select a port for either input or output.
If he selects output an ASCII string is written to that port.
If he selects input the first 16 characters read from that port are displayed in octal on the console running the tests.
If the HOE flag is specified the VSV21 will halt on error.
If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error.
If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 16: INTERNAL LOOPBACK TEST

This test causes the on-board software to perform an INTERNAL LOOPBACK test on ports 0-3.
If the HOE flag is specified the VSV21 will halt on error.
If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error.
If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 17: EXTERNAL I/O LOOPBACK TEST

This test causes the on-board software to perform an EXTERNAL LOOPBACK test on ports 0-3.
If the HOE flag is specified the VSV21 will halt on error.
If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error.
If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 18: SCREEN TEST

This test is not done if /FLA:UAM is specified on the START command.
This test displays different screen test pictures as selected by the operator. If the HOE flag is specified the VSV21 will halt on error.
If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error.
If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 19: NVRAM READ/WRITE TEST

This test is not done if /FLA:UAM is specified on the START command.
This test tests NVRAM read/write. On each pass the operator will be asked if he wishes to continue as NVRAM has a limited life in terms of read/write cycles.
If the HOE flag is specified the VSV21 will halt on error.
If the LOE flag is specified the operator will be given the choice on the first pass of whether he wishes the on-board tests to loop on error.
If he selects yes the test may hang indefinitely as the on board will not return control to the host but will continue looping.

TEST 20: ENABLE INTERRUPTS TEST

This test verifies that interrupts are received by the host when interrupts are enabled.

&

```
869          .TITLE PROGRAM HEADER AND TABLES
870          .SBTTL PROGRAM HEADER
871
872          .MCALL SVC
873 000000    SVC                                ; INITIALIZE SUPERVISOR MACROS
874
875          ;*****
876          ; IF STRUCTURED MACROS ARE TO BE USED, ADD ".MCALL STRUCT" AND "STRUCT"
877          ; TO INITIALIZE THE STRUCTURED MACROS.
878
879          177777 SVCINS= -1          ; LIST INSTRUCTIONS, SHIFTED RIGHT
880          177777 SVCTST= -1         ; LIST TEST TAGS, SHIFTED RIGHT
881          177777 SVCSUB= -1        ; LIST SUBTEST TAGS, SHIFTED RIGHT
882          177777 SVCGBL= -1       ; LIST GLOBAL TAGS, SHIFTED RIGHT
883          177777 SVCTAG= -1        ; LIST OTHER TAGS, SHIFTED RIGHT
884
885          ; CHANGE THE VALUES OF THE SVC... SYMBOLS TO BE ZERO IF YOU WISH
886          ; TO ALIGN THE MACRO CALLS AND THEIR EXPANSIONS. CHANGE THE
887          ; SYMBOLS TO BE MINUS-ONE TO NOT LIST THE EXPANSIONS. YOU MAY
888          ; CHANGE THE SYMBOLS AT ANY POINT IN YOUR PROGRAM.
889          ;*****
890
891 000000    .ENABL ABS,AMA
892          002000    =                2000
893
894 002000    BGNMOD
895
896          ;**
897          ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
898          ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
899          ; -
900
901 002000    POINTER ERR_TBL,BGNSETUP
902
903 002000    HEADER CZVSWAO,A,0,15,0
904
```

DISPATCH TABLE

```
916          .SBTTL DISPATCH TABLE
917
918          ;++
919          ; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
920          ; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
921          ;--
922
923          000004          MAXUNIT== 4          ; maximum number of units
924          000024          MAXTST == 20.         ; maximum number of tests
925
926 002122          DISPATCH MAXTST
927
```

DEFAULT HARDWARE P-TABLE

```
929          .SBTTL  DEFAULT HARDWARE P-TABLE
930
931          ;++
932          ; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
933          ; THE TEST-DEVICE PARAMETERS.  THE STRUCTURE OF THIS TABLE
934          ; IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P-TABLES,
935          ; AND IS USED AS A "TEMPLATE" FOR BUILDING THE P-TABLES.
936          ;--
937
938 002174          BGNHW  DFPTBL
939
949
950 002176 172010  .WORD  172010
951 002200 000320  .WORD  320
952
953 002202          ENDDHW
```

DEFAULT HARDWARE P-TABLE

```

955          .TITLE GLOBAL AREAS
956          .SBTTL  GLOBAL EQUATES SECTION
957
958
959          ;**
960          ; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
961          ; ARE USED IN MORE THAN ONE TEST.
962          ;--
963
964 002202          EQUALS
                    ;
                    ; BIT DIFINITIONS
                    ;
                    BIT15== 100000
                    BIT14== 40000
                    BIT13== 20000
                    BIT12== 10000
                    BIT11== 4000
                    BIT10== 2000
                    BIT09== 1000
                    BIT08== 400
                    BIT07== 200
                    BIT06== 100
                    BIT05== 40
                    BIT04== 20
                    BIT03== 10
                    BIT02== 4
                    BIT01== 2
                    BIT00== 1
                    ;
                    BIT9==  BIT09
                    BIT8==  BIT08
                    BIT7==  BIT07
                    BIT6==  BIT06
                    BIT5==  BIT05
                    BIT4==  BIT04
                    BIT3==  BIT03
                    BIT2==  BIT02
                    BIT1==  BIT01
                    BIT0==  BIT00
                    ;
                    ; EVENT FLAG DEFINITIONS
                    ;   EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
                    ;
                    ;
                    ;   BIT POSITION IN SECOND STATUS WORD
                    ; (100000) START COMMAND WAS ISSUED
                    ; (040000) RESTART COMMAND WAS ISSUED
                    ; (020000) CONTINUE COMMAND WAS ISSUED
                    ; (010000) A NEW PASS HAS BEEN STARTED
                    ; (004000) A POWER-FAIL/POWER-UP OCCURRED
                    ;
                    ;
                    ; PRIORITY LEVEL DEFINITIONS
                    ;
                    PRI07== 340
                    PRI06== 300
                    PRI05== 240

```

GLOBAL EQUATES SECTION

```

000200      PRI04== 200
000140      PRI03== 140
000100      PRI02== 100
000040      PRI01== 40
000000      PRI00== 0
;
;OPERATOR FLAG BITS
;
000004      EVL==      4
000010      LOT==     10
000020      ADR==     20
000040      IDU==     40
000100      ISR==    100
000200      UAM==    200
000400      BOE==    400
001000      PNT==   1000
002000      PRI==   2000
004000      IXE==   4000
010000      IBE==  10000
020000      IER==  20000
040000      LOE==  40000
100000      HOE== 100000

965
966
967      ;CSR bit meanings
968      100000      VS.SVL == BIT15      ; status valid
969      040000      VS.ERR == BIT14      ; error ( powerup only )
970      010000      VS.CRY == BIT12      ; controller ready
971      020000      VS.PRY == BIT13      ; parameter ready
972
973
974      ;Parallel interface commands ( these are written to the CSR by the host )
975
976      002400      PI.CMA == 5*400+0      ; command available
977      003000      PI.ACK == 6*400+0      ; status ack
978      001000      PI.SEN == 2*400+0      ; buffers sent
979      001001      PI.CAN == 2*400+1      ; buffers cancelled
980      000400      PI.IDM == 1*400+0      ; check ident. protocol.
981      002000      PI.TST == 4*400+0      ; invoke microdiagnostics
982      001400      PI.IDS == 3*400+0      ; disable interrupts
983      001403      PI.IEN == PI.IDS+3      ; enable interrupts
984      177777      PI.RUB == 177777      ; rubbish command to provoke error
985
986      ;This one is written to the parameter register by the on-board
987
988      100000      PI.AVA == BIT15      ; status available
989
990      ;These are DMA command codes that are put in the first word of the command
991      ;buffer by the host
992
993      002101      DI.RDA == 2101      ; read data
994      002102      DI.WDD == 2102      ; write dats.
995      002103      DI.RRA == 2103      ; read ram protocol code.
996      002104      DI.WRA == 2104      ; write ram protocol code.
997
998      ;return from the on-board
999

```

GLOBAL EQUATES SECTION

```

1000      000011      DI.MIC == 9.           ; micro diagnostic result code
1001      000005      DI.ERP == 5.           ; error reply packet code
1002      000176      DI.ERS == 126.        ; error log and stop packet code
1003      000177      DI.ERL == 127.        ; error log packet code
1004
1005      ;Fills in error table details
1006      .MACRO ERR.FILLIN      NUMBER,MESSAGE
1007      MOV      #2,ERRTYP      ; assume hard error for now
1008      MOV      #NUMBER,ERRNBR ; get error number
1009      MOV      #MESSAGE,ERRMSG ; get error message
1010      MOV      #ERRCODE,ERRBLK ; get error routine
1011      .ENDM
1012
1013      ;Error return
1014      .MACRO ERR.RETURN
1015      SEC
1016      RETURN
1017      .ENDM
1018
1019      ;OK return
1020      .MACRO OK.RETURN
1021      CLC
1022      RETURN
1023      .ENDM
1024
1025      ;Put at start of each test.
1026      ;Ensures that TEST1 must have been performed first.
1027      .MACRO ST.TEST,?LABEL
1028      BGNTST
1029      CALL      STTEST
1030      BCC      LABEL
1031      EXIT      TST
1032 LABEL:
1033      .ENDM
1034
1035      ;Sets up POLCNT for a delay
1036      .MACRO SET.POLCNT
1037      MOV      #1500.,POLCNT
1038      .ENDM
1039
1040      ;Writes a command to the CSR
1041      .MACRO DO.COMMAND      COM,LABEL
1042      MOV      #COM,COMAND
1043      SET.POLCNT
1044      CALL      DOCOM
1045      BCC      LABEL
1046      .ENDM
1047
1048      ;Tests manual intervention and exits test if not allowed
1049      .MACRO MAN.IGNORE      ?LABEL
1050      MANUAL
1051      BCOMPLETE      LABEL
1052      EXIT      TST
1053 LABEL:
1054      .ENDM
1055
1056      ;Tests dma done and exits test if not

```

GLOBAL EQUATES SECTION

```
1057          .MACRO DMA.IGNORE      ?LABEL
1058          TST   DMASET(R4)        ; DMA enabled ?
1059          BNE   LABEL             ; branch if yes
1060          ERRHRD 2,ERR2,ERRCODE    ; error exit if not
1061          EXIT   TST
1062 LABEL:
1063          .ENDM
1064
1065 ;Calls writeram routine
1066          .MACRO 10.WRAMS          BUFADD,BUFLEN
1067          .IF    N                 BUFADD
1068          .IFT
1069          MOV    BUFADD,COMBUF+4
1070          MOV    BUFLN,COMBUF+6
1071          .IFF
1072          MOV    #DMAOBUF,COMBUF+4
1073          MOV    #DMALEN,COMBUF+6
1074          .IFTF
1075          CALL   WRAMS
1076          .ENDC
1077          .ENDM
1078
1079 ;Calls readram routine
1080          .MACRO 00.RRAMS          BUFADD,BUFLEN
1081          .IF    NB                 BUFADD
1082          .IFT
1083          MOV    BUFADD,COMBUF+4
1084          MOV    BUFLN,COMBUF+6
1085          .IFF
1086          MOV    #DMAIBUF,COMBUF+4
1087          MOV    #DMALEN,COMBUF+6
1088          .IFTF
1089          CALL   RRAMS
1090          .ENDC
1091          .ENDM
```

GLOBAL DATA SECTION

```

1093          .SBTTL  GLOBAL DATA SECTION
1094
1095          ;**
1096          ; THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
1097          ; IN MORE THAN ONE TEST.
1098          ;--
1099
1100 002202          ERRRTBL
1100 002202 000000  ERRRTYP:: .WORD 0
1100 002204 000000  ERRNRBR:: .WORD 0
1100 002206 000000  ERRMSG:: .WORD 0
1100 002210 000000  ERRBLK:: .WORD 0
1101
1102 002212 000000  TEMP1:: .WORD 0 ; temporary storage
1103 002214 000000  TEMP2:: .WORD 0 ; temporary storage
1104 002216 000000  POLCNT:: .WORD 0 ; <0 = poll CSR forever , >0 = poll CSR
1105          ; ; required number
1106 002220 000000  LOGUNT:: .WORD 0 ; current unit number
1107 002222          PBLOC:: .BLKW 4 ; storage for sending microdiagnostic parameters
1108 002232 000000  CURCSR:: .WORD 0 ; CSR address for current unit
1109 002234 000000  CURPAR:: .WORD 0 ; parameter register address for current unit
1110 002236 000000  CURVEC:: .WORD 0 ; vector address for current unit
1111 002240 000000  INTFLG:: .WORD 0 ; <>0 = got interrupt , 0 = not got interrupt
1112 002242 000000  NOTEST:: .WORD 0 ; 0 = tests can be done , <>0 = tests cannot
1113 002244 000001 000002 000004  BITS:: .WORD BIT0,BIT1,BIT2,BIT3,BIT4,BIT5,BIT6,BIT7,BIT8
1113 002252 000010 000020 000040
1113 002260 000100 000200 000400
1114 002266 001000 002000 004000          .WORD BIT9,BIT10,BIT11,BIT12,BIT13,BIT14,BIT15
1114 002274 010000 020000 040000
1114 002302 100000
1115
1116          ;Flags per unit (globals are offset from start of flags for that unit)
1117          ;*****
1118          ; N.B. R4 POINTS TO THE FLAGS FOR THE CURRENT UNIT
1119          ;*****
1120
1121          000000          T1DONE == 0 ; 1 WORD: 0 = TEST1 not done , <>0 = TEST1 DONE
1122          000002          DMASET == T1DONE+2 ; 1 WORD: 0 = DMA disabled , <>0 = DMA enabled
1123          000004          FTHRU == DMASET+2 ; 2 WORDS: bit 'n' is clear if TEST 'n' not yet
1124          ; ; done
1125          000010          TMASKS == FTHRU+4 ; MAXTST WORDS : test masks
1126          ; ; (only applicable to Microdiagnostic tests)
1127          000030          LENFLAGS == TMASKS/2*MAXTST ; length of flags per unit in words
1128 002304 000036          FLAGS:: .BLKW <LENFLAGS*MAXUNIT> ; the flags indexed by unit
1129
1130          ;Command and status buffers
1131
1132          000024          COMLEN = 24
1133          000036          STALEN = 36
1134 002604 012000 002616 017000  BUFDES: .WORD <COMLEN*400> ,COMBUF ,<STALEN*400> ,STABUF ; buffer descriptors
1134 002612 002666
1135 002614          COMAND: .BLKW 1 ; current command
1136 002616          COMBUF: .BLKW COMLEN ; command packet buffer for DMA
1137 002666          STABUF: .BLKW STALEN ; status packet buffer for DMA.
1138
1139          ; the data to be written to RAM
1140

```

GLOBAL DATA SECTION

1141	002762		DMAOBUF::	
1142	002762	177776	.WORD	177776
1143	002764	177775	.WORD	177775
1144	002766	177774	.WORD	177774
1145	002770	177773	.WORD	177773
1146	002772	177772	.WORD	177772
1147	002774	177771	.WORD	177771
1148	002776	177770	.WORD	177770
1149	003000	177760	.WORD	177760
1150	003002	177750	.WORD	177750
1151	003004	177740	.WORD	177740
1152	003006	177730	.WORD	177730
1153	003010	177720	.WORD	177720
1154	003012	177710	.WORD	177710
1155	003014	177700	.WORD	177700
1156	003016	177600	.WORD	177600
1157	003020	177500	.WORD	177500
1158	003022	177400	.WORD	177400
1159	003024	177300	.WORD	177300
1160	003026	177200	.WORD	177200
1161	003030	177100	.WORD	177100
1162	003032	177000	.WORD	177000
1163	003034	000000	.WORD	0
1164				
1165		000054	DMALEN = .-DMAOBUF	; length of above data
1166	003036		DMAIBUF::	
1167	003036		.BLKW DMALEN	; buffer to read back into .
1168				
1169				

GLOBAL TEXT SECTION

```

1171          .SBTTL GLOBAL TEXT SECTION
1172
1173          ;**
1174          ; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
1175          ; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
1176          ; MORE THAN ONE TEST.
1177          ;--
1178          .NLIST BEX
1179
1180 003166      124      105      123  ERR1:: .ASCIZ /TEST 1 MUST BE PERFORMED FIRST/
1181 003225      124      105      123  ERR2:: .ASCIZ /TEST 2 MUST BE RUN FIRST TO ENABLE DMA/
1182 003274      124      111      115  ERR3:: .ASCIZ /TIMED OUT WHILE WAITING FOR STATUS VALID/
1183 003345      124      110      105  ERR4:: .ASCIZ /THERE HAS BEEN A POWERUP - PLEASE REPEAT TEST 1/
1184 003425      103      117      116  ERR5:: .ASCIZ /CONTROLLER READY NOT SET IN CSR/
1185 003465      123      124      101  ERR6:: .ASCIZ /STATUS PACKET SHORTER THAN SPECIFIED LENGTH/
1186 003541      123      124      101  ERR7:: .ASCIZ /STATUS AVAILABLE EXPECTED BUT NOT FOUND/
1187 003611      105      122      122  ERR8:: .ASCIZ /ERROR PACKET RECEIVED FROM VSV21/
1188 003652      106      101      111  ERR9:: .ASCIZ /FAILED TO TRANSMIT STATUS ACKNOWLEDGE/
1189 003720      124      111      115  ERR10:: .ASCIZ /TIMEOUT WAITING FOR STATUS/
1190 003753      104      115      101  ERR11:: .ASCIZ /DMA DATA MATCH ERROR/
1191 004000      106      101      111  ERR12:: .ASCIZ /FAILED TO GET MICRO DIAGNOSTICS RETURN STATUS PACKET/
1192 004065      115      111      103  ERR13:: .ASCIZ /MICRO DIAGNOSTIC TEST UNSUCCESSFUL/
1193 004130      105      122      122  ERR14:: .ASCIZ /ERROR PACKET EXPECTED BUT NOT RECEIVED/
1194 004177      124      111      115  ERR15:: .ASCIZ /TIMED OUT WAITING TO RECEIVE AN INTERRUPT/
1195
1196          ;
1197          ; NAMES OF DEVICES SUPPORTED BY PROGRAM
1198          ;
1199 004251          DEVTYP <VSV21>
1200          ; TEST DESCRIPTION
1201          ;
1202 004260          DESCRIPT      <VSV21 DIAGNOSTIC>
1203          .EVEN
1204
1205          ;
1206          ; FORMAT STATEMENTS USED IN PRINT CALLS
1207          ;
1208
1209

```

GLOBAL ERROR REPORT SECTION

1211
1212
1213
1214
1215
1216
1217
1218
1219
1220 004302
1221
1222 004302 005237 002242
1223
1224 004306
1225
1226
1227
1228 004312
1229

.SBTTL GLOBAL ERROR REPORT SECTION

;*
; THE GLOBAL ERROR REPORT SECTION CONTAINS MESSAGE PRINTING AREAS
; USED BY MORE THAN TEST TO OUTPUT ADDITIONAL ERROR INFORMATION. PRINTB
; (BASIC) AND PRINTX (EXTENDED) CALLS ARE USED TO CALL PRINT SERVICES.
;--

BGNMSG ERRCODE

INC NOTEST

;say no further tests allowed

EXIT MSG

.EVEN

ENDMSG

GLOBAL SUBROUTINES SECTION

```

1231 .SBTTL GLOBAL SUBROUTINES SECTION
1232
1233 ;**
1234 ; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
1235 ; THAT ARE USED IN MORE THAN ONE TEST.
1236 ;--
1237
1238 ;**
1239 ; FUNCTIONAL DESCRIPTION:
1240 ; SUBROUTINE TO POLL THE CSR OR STATUS VALID BIT TO BE SET.
1241
1242 ; INPUTS:
1243 ; POLCNT NUMBER OF TIMES TO POLL , -1 = INFINITE
1244
1245 ; IMPLICIT INPUTS:
1246 ; CURCSR - CSR ADDRESS TO POLL
1247 ; T1DONE - TEST 1 DONE FLAG
1248
1249 ; OUTPUTS:
1250 ; CONDITION CODE - CLEAR = SUCCESS
1251 ; - SET = FAILURE
1252
1253 ; IMPLICIT OUTPUTS:
1254 ; ERROR BLOCK - FILLED IN ON FAILURE
1255 ; T1DONE - CLEARED IF POWERUP
1256 ; DMASET - CLEARED IF POWERUP
1257
1258 ; SUBORDINATE ROUTINES USED:
1259 ; NONE
1260
1261 ; FUNCTIONAL SIDE EFFECTS:
1262 ; IF POWERUP OF VSV21 FOUND FORCES TEST1 TO BE DONE AGAIN BY CLEARING
1263 ; T1DONE. ALSO CLEARS DMASET TO SAY THAT DMA IS NOT ENABLED.
1264
1265 ; CALLING SEQUENCE:
1266 ; MOV #1500.,POLCNT ;SET UP POLL COUNT
1267 ; CALL POLL ;GO TO ROUTINE
1268 ; BCS ERROR ;CARRY SET IF ROUTINE HAD ERROR
1269 ;--
1270 004314 032777 100000 175710 POLL:: BIT #VS.SVL,@CURCSR ; SVL ?
1271 004322 001040 BNE 2$ ; branch 'f yes
1272 004324 DELAY 10. ; delay 10 un'ts
1273 004354 005737 002216 TST POLCNT ; poll forever ?
1274 004360 002755 BLT POLL ; yes
1275 004362 005337 002216 DEC POLCNT ; no reduce count
1276 004366 003352 BGT POLL ; try again 'f still some left
1277
1278 004370 ERR.FTLLIN 3,ERR3
1279 004370 012737 000002 002202 MOV #2,ERRTYP ; assume hard error for now
1280 004376 012737 000003 002204 MOV #3,ERRNBR ; get error 3
1281 004404 012737 003274 002206 MOV #ERR3,ERRMSG ; get error ERR3
1282 004412 012737 004302 002210 MOV #ERRCODE,ERRBLK ; get error routine
1283 004420 ERR.RETURN
1284 004420 000261 SEC
1285 004422 000207 RETURN
1286
1287 004424 032777 040000 175600 2$: BIT #VS.ERR,@CURCSR ; ERR ?

```

GLOBAL SUBROUTINES SECTION

```

1282 004432 001425          BEQ      3$          ; branch if not
1283
1284          ; powerup - initialise
1285 004434 005064 000002    CLR      DMASET(R4)          ; say DMA disabled
1286 004440 005764 000000    TST      T1DONE(R4)        ; Test 1 done yet ?
1287 004444 001420          BEQ      3$          ; branch if not
1288 004446 005064 000000    CLR      T1DONE(R4)        ; say Test 1 not done
1289 004452          ERR.FILLIN 4,ERR4
      004452 012737 000002 002202  MOV      #2,ERR4          ; assume hard error for now
      004460 012737 000004 002204  MOV      #4,ERR4          ; get error 4
      004466 012737 003345 002206  MOV      #ERR4,ERRMSG     ; get error ERR4
      004474 012737 004302 002210  MOV      #ERRCODE,ERRBLK ; get error routine
1290 004502          ERR.RETURN
      004502 000261          SEC
      004504 000207          RETURN
1291
1292 004506          3$:      OK.RETURN
      004506 000241          CLC
      004510 000207          RETURN
1293

```

GLOBAL SUBROUTINES SECTION

```

1295 ;**
1296 ; FUNCTIONAL DESCRIPTION:
1297 ; SUBROUTINE TO POLL THE CSR FOR STATUS VALID AND CONTROLLER READY BITS
1298 ; TO BE SET.
1299
1300 ; INPUTS:
1301 ; NONE
1302
1303 ; IMPLICIT INPUTS:
1304 ; CURCSR - CSR ADDRESS TO POLL
1305
1306 ; OUTPUTS:
1307 ; CONDITION CODE - CLEAR = SUCCESS
1308 ; - SET = FAILURE
1309
1310 ; IMPLICIT OUTPUTS:
1311 ; ERROR BLOCK - FILLED IN ON FAILURE
1312
1313 ; SUBORDINATE ROUTINES USED:
1314 ; POLL
1315
1316 ; FUNCTIONAL SIDE EFFECTS:
1317 ; NONE
1318
1319 ; CALLING SEQUENCE:
1320 ; CALL POLLCRY ;GO TO ROUTINE
1321 ; BCS ERROR ;CARRY SET IF ROUTINE HAD ERROR
1322 ;--
1323 POLLCRY::
1324 004512 004737 004314 CALL POLL ; poll for SVL
1325 004516 103001 BCC 10$ ; branch if SVL
1326 004520 000207 RETURN ; else return if not
1327 004522 032777 010000 175502 10$: BIT #VS.CRY,@CURCSR ; CRY ?
1328 004530 001016 BNE 20$ ; branch if yes
1329 004532 ERR.FILLIN 5,ERR5 ; error return if not
004532 012737 000002 002202 MOV #2,ERPTYP ; assume hard error for now
004540 012737 000005 002204 MOV #5,ERRNoR ; get error 5
004546 012737 003425 002206 MOV #ERR5,ERRMSG ; get error ERR5
004554 012737 004302 002210 MOV #ERRCODE,ERRBLK ; get error routine
1330 004562 ERR.RETURN
004562 000261 SEC
004564 000207 RETURN
1331 004566 20$: OK.RETURN ; success return
004566 000241 CLC
004570 000207 RETURN
1332

```

GLOBAL SUBROUTINES SECTION

```

1334 ;**
1335 ; FUNCTIONAL DESCRIPTION:
1336 ;   SUBROUTINE TO WRITE A COMMAND TO THE CURRENT CSR.
1337
1338 ; INPUTS:
1339 ;   POLCNT           - NUMBER OF TIMES TO POLL , -1 = INFINITE
1340
1341 ; IMPLICIT INPUTS:
1342 ;   CURCSR          - CSR ADDRESS TO POLL
1343
1344 ; OUTPUTS:
1345 ;   CONDITION CODE  - CLEAR = SUCCESS
1346 ;                   - SET   = FAILURE
1347
1348 ; IMPLICIT OUTPUTS:
1349 ;   ERROR BLOCK     - FILLED IN ON FAILURE
1350
1351 ; SUBORDINATE ROUTINES USED:
1352 ;   NONE
1353
1354 ; FUNCTIONAL SIDE EFFECTS:
1355 ;   THIS DEPENDS ON THE COMMAND. E.G. IF THE COMMAND IS 'BUFFERS SENT'
1356 ;   DMA WILL THEN BE ENABLED AND STATUS WILL COME BACK VIA DMA.
1357
1358 ; CALLING SEQUENCE:
1359 ;   MOV   #1500.,POLCNT ;SET UP POLL COUNT
1360 ;   CALL  DOCOM         ;GO TO ROUTINE
1361 ;   BCS   ERROR         ;CARRY SET IF ROUTINE HAD ERROR
1362 ;--
1363
1364 004572 004737 004314 DOCOM:: CALL POLL           ; ensure SVL
1365 004576 103003          BCC   10$           ; branch if OK
1366 004600          ERROR
1367 004602          ERR.RETURN
1368          004602 000261 SEC
1369          004604 000207 RETURN
1370
1371 1369 004606 032777 020000 175416 10$: BIT   #VS.PRY,@CURCSR ; PRY ?
1372 004614 001404          BEQ   20$           ; branch if not
1373 004616 004737 005066          CALL  GETST1        ; get status
1374 004622 103001          BCC   20$           ; branch if status OK
1375 004624 000207          RETURN             ; return if not
1376
1377 1375 004626 032777 010000 175376 20$: BIT   #VS.CRY,@CURCSR ; CRY ?
1378 004634 001017          BNE   30$           ; branch if yes
1379 004636          ERR.FILLIN 5,ERR5
1380          004636 012737 000002 002202 MOV   #2,ERRTYP ; assume hard error for now
1381          004644 012737 000005 002204 MOV   #5,ERRNBR ; get error 5
1382          004652 012737 003425 002206 MOV   #ERR5,ERRMSG ; get error ERR5
1383          004660 012737 004302 002210 MOV   #ERRCODE,ERRBLK ; get error routine
1384          1378 004666          ERROR
1385          1379 004670          ERR.RETURN
1386          004670 000261 SEC
1387          004672 000207 RETURN
1388
1389 1381 004674 013777 002614 175330 30$: MOV   COMAND,@CURCSR ; write comand to the CSR
1390 1382

```

GLOBAL SUBROUTINES SECTION

```

1383 004702 004737 004314      35$: CALL POLL           ; wait for SVL
1384 004706 103003              BCC 40$
1385 004710                    ERROR
1386 004712                    ERR.RETURN
      004712 000261              SEC
      004714 000207              RETURN

1387
1388 004716 032777 020000 175306 40$: BIT #VS.PRY,@CURCSR      ; PRY ?
1389 004724 001055              BNE 50$           ; branch if yes
1390
1391                          ;interrupt mask and buffer sent commands do not expect status from the VSV21
1392
1393 004726 022737 001400 002614      CMP #PI.IDS,COMAND      ; interrupt disable command ?
1394 004734 001453              BEQ 60$           ; branch if yes
1395 004736 022737 001403 002614      CMP #PI.IEN,COMAND      ; interrupt enable command ?
1396 004744 001447              BEQ 60$           ; branch if yes
1397 004746 022737 001000 002614      CMP #PI.SEN,COMAND      ; buf sent command ?
1398 004754 001443              BEQ 60$           ; branch if yes
1399
1400                          ;try again to get status
1401 004756                    DELAY 10.           ; delay 10 units
1402 005006 005737 002216              TST POLCNT            ; poll forever ?
1403 005012 002733              BLT 35$           ; yes
1404 005014 005337 002216              DEC POLCNT            ; no reduce count
1405 005020 003330              BGT 35$           ; try again if still some left
1406 005022                    ERR.FILLIN 10.,ERR10      ; timeout
      005022 012737 000002 002202      MOV #2,ERRTYP          ; assume hard error for now
      005030 012737 000012 002204      MOV #10.,ERRNBR        ; get error 10.
      005036 012737 003720 002206      MOV #ERR10,ERRMSG      ; get error ERR10
      005044 012737 004302 002210      MOV #ERRCODE,ERRBLK    ; get error routine
1407 005052                    ERROR
1408 005054                    ERR.RETURN
      005054 000261              SEC
      005056 000207              RETURN

1409
1410 005060 004737 005462      50$: CALL GETST2           ; get status
1411 005064 000207      60$: RETURN
1412

```

GLOBAL SUBROUTINES SECTION

```

1414 ;**
1415 ; FUNCTIONAL DESCRIPTION:
1416 ;   SUBROUTINE TO GET A STATUS PACKET FROM THE VSV21 INTO STATUS BUFFER.
1417 ;   THIS INCLUDES BOTH PROGRAMMED I/O AND DMA MODES.
1418 ;   THIS MODULE IS VERY SIMILAR TO GETST2 BUT IS CALLED BEFORE A COMMAND IS
1419 ;   SENT TO THE VSV21.
1420 ;
1421 ; INPUTS:
1422 ;   NONE
1423 ;
1424 ; IMPLICIT INPUTS:
1425 ;   DMASET          - DMA ENABLED FLAG
1426 ;   STABUF          - STATUS BUFFER
1427 ;   CURCSR          - CSR ADDRESS
1428 ;
1429 ; OUTPUTS:
1430 ;   CONDITION CODE - CLEAR = SUCCESS
1431 ;                 - SET   = FAILURE
1432 ;
1433 ; IMPLICIT OUTPUTS:
1434 ;   ERROR BLOCK    - FILLED IN ON FAILURE
1435 ;   STABUF         - STATUS BUFFER
1436 ;
1437 ; SUBORDINATE ROUTINES USED:
1438 ;   POLL
1439 ;   POLLCRY
1440 ;
1441 ; FUNCTIONAL SIDE EFFECTS:
1442 ;   NONE
1443 ;
1444 ; CALLING SEQUENCE:
1445 ;   CALL   GETST1          ;GO TO ROUTINE
1446 ;   BCS   ERROR           ;CARRY SET IF ROUTINE HAD ERROR
1447 ;--
1448
1449 005066 GETST1::
1450 005066 005764 000002      TST   DMASET(R4)          ; DMA enabled ?
1451 005072 001060          BNE   30$              ; branch if yes
1452
1453 ;DMA not enabled - get status packet via parameter register
1454
1455 ; special processing if ERR set - only one word in status packet
1456 005074 032777 040000 175130 BIT   #VS.ERR,@CURCSR      ; ERR ?
1457 005102 001407          BEQ   5$              ; branch if no
1458 005104 012737 000001 002666 MOV   #1,STABUF           ; pretend status packet has a header
1459 005112 017737 175116 002670 MOV   @CURPAR,STABUF+2     ; get rest of packet
1460 005120 000444          BR    25$
1461
1462 005122 017737 175106 002666 5$: MOV   @CURPAR,STABUF      ; get status header word
1463 005130 113701 002666      MOVB  STABUF,R1          ; get number of following status words
1464 005134 001436          BEQ   25$              ; branch if none
1465 005136 012702 002670      MOV   #<STABUF+2>,R2      ; get address of where to put them
1466 005142 004737 004314 10$: CALL  POLL                ; poll
1467 005146 103003          BCC   20$
1468 005150          ERROR
1469 005152          ERR.RETURN
          005152 000261          SEC

```

GLOBAL SUBROUTINES SECTION

```

005154 000207 RETURN
1470 005156 032777 020000 175046 20$: BIT #VS.PRY,@CURCSR ; PRY ?
1471 005164 001017 BNE 22$ ; branch if yes
1472 005166 ERR.FILLIN 6,ERR6
005166 012737 000002 002202 MOV #2,ERRTYP ; assume hard error for now
005174 012737 000006 002204 MOV #6,ERRNBR ; get error 6
005202 012737 003465 002206 MOV #ERR6,ERRMSG ; get error ERR6
005210 012737 004302 002210 MOV #ERRCODE,ERRBLK ; get error routine
1473 005216 ERROR
1474 005220 ERR.RETURN
005220 000261 SEC
005222 000207 RETURN
1475 005224 017722 175004 22$: MOV @CURPAR,(R2)+ ; get a status word
1476 005230 077134 SOB R1,10$ ; again
1477 005232 000434 25$: BR 60$
1478
1479 ;DMA enabled - status packet is written straight to status buffer
1480
1481 005234 022777 100000 174772 30$: CMP #PI.AVA,@CURPAR ; is there a packet available ?
1482 005242 001417 BEQ 40$ ; branch if yes
1483 005244 ERR.FILLIN 7,ERR7
005244 012737 000002 002202 MOV #2,ERRTYP ; assume hard error for now
005252 012737 000007 002204 MOV #7,ERRNBR ; get error 7
005260 012737 003541 002206 MOV #ERR7,ERRMSG ; get error ERR7
005266 012737 004302 002210 MOV #ERRCODE,ERRBLK ; get error routine
1484 005274 ERROR
1485 005276 ERR.RETURN
005276 000261 SEC
005300 000207 RETURN
1486
1487 005302 004737 004512 40$: CALL POLLCRY ; poll for CRY
1488 005306 103003 BCC 50$ ; branch if OK
1489 005310 ERROR
1490 005312 ERR.RETURN ; return if error
005312 000261 SEC
005314 000207 RETURN
1491 005316 012777 003000 174706 50$: MOV #PI.ACK,@CURCSR ; send status ack
1492
1493 005324 004737 004512 60$: CALL POLLCRY ; poll for CRY
1494 005330 103017 BCC 70$ ; branch if OK
1495 005332 ERR.FILLIN 9.,ERR9 ; error
005332 012737 000002 002202 MOV #2,ERRTYP ; assume hard error for now
005340 012737 000011 002204 MOV #9.,ERRNBR ; get error 9.
005346 012737 003652 002206 MOV #ERR9,ERRMSG ; get error ERR9
005354 012737 004302 002210 MOV #ERRCODE,ERRBLK ; get error routine
1496 005362 ERROR
1497 005364 ERR.RETURN
005364 000261 SEC
005366 000207 RETURN
1498
1499 005370 122737 000005 002667 70$: CMPB #DI.ERP,STABUF+1 ; error status packet ?
1500 005376 001410 BEQ 75$ ; branch if yes
1501 005400 122737 000176 002667 CMPB #DI.ERS,STABUF+1 ; error status packet ?
1502 005406 001404 BEQ 75$ ; branch if yes
1503 005410 122737 000177 002667 CMPB #DI.ERL,STABUF+1 ; error status packet ?
1504 005416 001017 BNE 80$ ; branch if not
1505 005420 75$: ERR.FILLIN 8.,ERR8

```

GLOBAL SUBROUTINES SECTION

```

005420 012737 000002 002202      MOV    #2,ERRTYP      ; assume hard error for now
005426 012737 000010 002204      MOV    #8.,ERRNBR    ; get error 8.
005434 012737 003611 002206      MOV    #ERR8,ERRMSG  ; get error ERR8
005442 012737 004302 002210      MOV    #ERRCODE,ERRBLK ; get error routine
1506 005450      ERROR
1507 005452      ERR.RETURN
      005452 000261      SEC
      005454 000207      RETURN
1508
1509 005456      80$: OK.RETURN
      005456 000241      CLC
      005460 000207      RETURN
1510

```

GLOBAL SUBROUTINES SECTION

```

1512 ;**
1513 ; FUNCTIONAL DESCRIPTION:
1514 ; SUBROUTINE TO GET A STATUS PACKET FROM THE VSV21 INTO STATUS BUFFER.
1515 ; THIS INCLUDES BOTH PROGRAMMED I/O AND DMA MODES.
1516 ; THIS MODULE IS VERY SIMILAR TO GETST1 BUT IS CALLED AFTER A COMMAND IS SENT
1517 ; TO THE VSV21.
1518 ;
1519 ; INPUTS:
1520 ; NONE
1521 ;
1522 ; IMPLICIT INPUTS:
1523 ; DMASET - DMA ENABLED FLAG
1524 ; STABUF - STATUS BUFFER
1525 ; CURCSR - CSR ADDRESS
1526 ; L$TEST - CURRENT TEST
1527 ;
1528 ; OUTPUTS:
1529 ; CONDITION CODE - CLEAR = SUCCESS
1530 ; SET = FAILURE
1531 ;
1532 ; IMPLICIT OUTPUTS:
1533 ; ERROR BLOCK - FILLED IN ON FAILURE
1534 ; STABUF - STATUS BUFFER
1535 ;
1536 ; SUBORDINATE ROUTINES USED:
1537 ; POLL
1538 ; POLLCRY
1539 ;
1540 ; FUNCTIONAL SIDE EFFECTS:
1541 ; NONE
1542 ;
1543 ; CALLING SEQUENCE:
1544 ; CALL GETST2 ;GO TO ROUTINE
1545 ; BCS ERROR ;CARRY SET IF ROUTINE HAD ERROR
1546 ;--
1547
1548 005462 GETST2::
1549 005462 005764 000002 TST DMASET(R4) ; DMA enabled ?
1550 005466 001060 BNE 30$ ; branch if yes
1551
1552 ;DMA not enabled - get status packet via parameter register
1553
1554 ; special processing if ERR set - only one word in status packet
1555 005470 032777 040000 174534 BIT #VS.ERR,@CURCSR ; ERR ?
1556 005476 001407 BEQ 5$ ; branch if no
1557 005500 012737 000001 002666 MOV #1,STABUF ; pretend status packet has a header
1558 005506 017737 174522 002670 MOV @CURPAR,STABUF+2 ; get rest of packet
1559 005514 000444 BR 25$
1560
1561 005516 017737 174512 002666 5$: MOV @CURPAR,STABUF ; get status header word
1562 005524 113701 002666 MOVB STABUF,R1 ; get number of following status words
1563 005530 001436 BEQ 25$ ; branch if none
1564 005532 012702 002670 MOV #<STABUF+2>,R2 ; get address of where to put them
1565 005536 004737 004314 10$: CALL POLL ; poll
1566 005542 103003 BCC 20$
1567 005544 ERROR
1568 005546 ERR.RETURN

```

GLOBAL SUBROUTINES SECTION

```

005546 000261 SEC
005550 000207 RETURN
1569 005552 032777 020000 174452 20$: BIT #VS.PRY,@CURCSR ; PRY ?
1570 005560 001017 BNE 22$ ; branch if yes
1571 005562 ERR.FILLIN 6,ERR6
005562 012737 000002 002202 MOV #2,ERRTYP ; assume hard error for now
005570 012737 000006 002204 MOV #6,ERRNBR ; get error 6
005576 012737 003465 002206 MOV #ERR6,ERRMSG ; get error ERR6
005604 012737 004302 002210 MOV #ERRCODE,ERRBLK ; get error routine
1572 005612 ERROR
1573 005614 ERR.RETURN
005614 000261 SEC
005616 000207 RETURN
1574 005620 017722 174410 22$: MOV @CURPAR,(R2)+ ; get a status word
1575 005624 077134 SOB R1,10$ ; again
1576 005626 000434 25$: BR 60$
1577
1578 ;DMA enabled - status packet is written straight to status buffer
1579
1580 005630 022777 100000 174376 30$: CMP #PI.AVA,@CURPAR ; is there a packet available ?
1581 005636 001417 BEQ 40$ ; branch if yes
1582 005640 ERR.FILLIN 7,ERR7
005640 012737 000002 002202 MOV #2,ERRTYP ; assume hard error for now
005646 012737 000007 002204 MOV #7,ERRNBR ; get error 7
005654 012737 003541 002206 MOV #ERR7,ERRMSG ; get error ERR7
005662 012737 004302 002210 MOV #ERRCODE,ERRBLK ; get error routine
1583 005670 ERROR
1584 005672 ERR.RETURN
005672 000261 SEC
005674 000207 RETURN
1585
1586 005676 004737 004512 40$: CALL POLLCRY ; poll for CRY
1587 005702 103003 BCC 50$ ; branch if OK
1588 005704 ERROR
1589 005706 ERR.RETURN ; return if error
005706 000261 SEC
005710 000207 RETURN
1590 005712 012777 003000 174312 50$: MOV #PI.ACK,@CURCSR ; send status ack
1591
1592 005720 004737 004512 60$: CALL POLLCRY ; poll for CRY
1593 005724 103017 BCC 70$ ; branch if OK
1594 005726 ERR.FILLIN 9,ERR9 ; error
005726 012737 000002 002202 MOV #2,ERRTYP ; assume hard error for now
005734 012737 000011 002204 MOV #9,ERRNBR ; get error 9.
005742 012737 003652 002206 MOV #ERR9,ERRMSG ; get error ERR9
005750 012737 004302 002210 MOV #ERRCODE,ERRBLK ; get error routine
1595 005756 ERROR
1596 005760 ERR.RETURN
005760 000261 SEC
005762 000207 RETURN
1597
1598 005764 122737 000005 002667 70$: CMPB #DI.ERP,STABUF+1 ; error status packet ?
1599 005772 001414 BEQ 75$ ; branch if yes
1600 005774 122737 000176 002667 CMPB #DI.ERS,STABUF+1 ; error status packet ?
1601 006002 001410 BEQ 75$ ; branch if yes
1602 006004 022737 000003 002114 CMP #3,L$TEST ; test 3 (error expected) ?
1603 006012 001423 BEQ 80$ ; branch if yes

```

GLOBAL SUBROUTINES SECTION

```

1604 006014 122737 000177 002667      CMPB  #DI.ERL,STABUF+1      ; error status packet ?
1605 006022 001017                      BNE   80$                  ; branch if not
1606 006024                      75$:  ERR.FILLIN      8.,ERR8
      006024 012737 000002 002202      MOV   #2,ERRTYP           ; assume hard error for now
      006032 012737 000010 002204      MOV   #8.,ERRNBR         ; get error 8.
      006040 012737 003611 002206      MOV   #ERR8,ERRMSG       ; get error ERR8
      006046 012737 004302 002210      MOV   #ERRCODE,ERRBLK   ; get error routine
1607 006054      ERROR
1608 006056      ERR.RETURN
      006056 000261      SEC
      006060 000207      RETURN
1609
1610 006062                      80$:  OK.RETURN
      006062 000241      CLC
      006064 000207      RETURN
1611
    
```

GLOBAL SUBROUTINES SECTION

```

1613 ;**
1614 ; FUNCTIONAL DESCRIPTION:
1615 ;   SUBROUTINE TO WRITE DATA USING DMA.
1616
1617 ; INPUTS:
1618 ;   NONE
1619
1620 ; IMPLICIT INPUTS:
1621 ;   COMBUF           - COMMAND BUFFER CONTAINING :
1622 ;                                     DMA BUFFER ADDRESS IN COMBUF+4
1623 ;                                     DMA BUFFER LENGTH IN COMBUF+6
1624
1625 ; OUTPUTS:
1626 ;   CONDITION CODE - CLEAR = SUCCESS
1627 ;                 - SET   = FAILURE
1628
1629 ; IMPLICIT OUTPUTS:
1630 ;   NONE
1631
1632 ; SUBORDINATE ROUTINES USED:
1633 ;   DOCOM
1634
1635 ; FUNCTIONAL SIDE EFFECTS:
1636 ;   NONE
1637
1638 ; CALLING SEQUENCE:
1639 ;   MOV     #8BUFADD,COMBUF+4      ;GET DMA BUFFER ADDRESS
1640 ;   MOV     #8BUFLN,COMBUF+6      ;GET DMA BUFFER LENGTH
1641 ;   CALL    WRAMS                 ;GO TO ROUTINE
1642 ;   BCS     ERROR                 ;CARRY SET IF ROUTINE HAD ERROR
1643 ;--
1644 006066 012737 002104 002616 WRAMS:: MOV     #DI.WRA,COMBUF      ; load write ram command code protocol.
1645 006074 005037 002620          CLR     COMBUF+2          ; increment address to bottom 16 bits
1646 006100 012737 000170 002626          MOV     #120.,COMBUF+8.      ; page number in ram of where to write.
1647
1648 006106          DO.COMMAND      PI.CMA,1$      ; do the DMA
1649 006106 012737 002400 002614          MOV     #PI.CMA,COMAND
1650 006114 012737 002734 002216          MOV     #1500.,POLCNT
1651 006122 004737 004572          CALL    DOCOM
1652 006126 103000          BCC     1$
1653 006130 000207          1$:   RETURN          ; return failed

```

GLOBAL SUBROUTINES SECTION

```

1652      ;**
1653      ; FUNCTIONAL DESCRIPTION:
1654      ;   SUBROUTINE TO READ DATA USING DMA.
1655
1656      ; INPUTS:
1657      ;   NONE
1658
1659      ; IMPLICIT INPUTS:
1660      ;   COMBUF           - COMMAND BUFFER CONTAINING :
1661      ;                                     DMA BUFFER ADDRESS IN COMBUF+4
1662      ;                                     DMA BUFFER LENGTH IN COMBUF+6
1663
1664      ; OUTPUTS:
1665      ;   CONDITION CODE - CLEAR = SUCCESS
1666      ;                                     - SET   = FAILURE
1667
1668      ; IMPLICIT OUTPUTS:
1669      ;   DMA BUFFER CONTAINING THE DMA'D DATA
1670      ;   CORRUPTS REGISTERS R1,R2
1671
1672      ; SUBORDINATE ROUTINES USED:
1673      ;   DOCOM
1674
1675      ; FUNCTIONAL SIDE EFFECTS:
1676      ;   NONE
1677
1678      ; CALLING SEQUENCE:
1679      ;   MOV     #BUFADD,COMBUF+4      ;GET DMA BUFFER ADDRESS
1680      ;   MOV     #BUFLEN,COMBUF+6     ;GET DMA BUFFER LENGTH
1681      ;   CALL    RRAMS                 ;GO TO ROUTINE
1682      ;   BCS    ERROR                 ;CARRY SET IF ROUTINE HAD ERROR
1683      ;-
1684
1685      RRAMS::
1686      ;clear read buffer
1687      MOV     COMBUF+4,R1              ; get address of read buffer
1688      MOV     COMBUF+6,R2              ; get length in bytes to clear
1689      10$:   CLRE    (R1)+              ; clear read buffer
1690      SOB    R2,10$                   ; next byte
1691
1692      ;read into read buffer
1693      MOV     #DI.RRA,COMBUF           ; load write ram command code protocol.
1694      CLR     COMBUF+2                 ; increment to bottom 16 bits
1695      MOV     #120.,COMBUF+8.          ; page number in ram of where to read
1696
1697      DO.COMMAND      PI.CMA,20$      ; do the DMA
1698      MOV     #PI.CMA,COMAND
1699      MOV     #1500.,POLCNT
1700      CALL    DOCOM
1701      BCC    20$
1702      20$:   RETURN                   ; return failed

```

GLOBAL SUBROUTINES SECTION

```

1700      ;**
1701      ; FUNCTIONAL DESCRIPTION:
1702      ;   SUBROUTINE TO COMPARE DATA WRITTEN BY WRAMS WITH DATA READ BACK BY RRAMS.
1703
1704      ; INPUTS:
1705      ;   NONE
1706
1707      ; IMPLICIT INPUTS:
1708      ;   DMAOBUF      - ASSUMED OUTPUT BUFFER USED BY A PREVIOUS CALL TO WRAMS
1709      ;   DMAIBUF      - ASSUMED INPUT BUFFER USED BY A PREVIOUS CALL TO RRAMS
1710      ;   DMALEN       - LENGTH OF ABOVE BUFFERS
1711
1712      ; OUTPUTS:
1713      ;   CONDITION CODE - CLEAR = SUCCESS
1714      ;                   - SET   = FAILURE
1715
1716      ; IMPLICIT OUTPUTS:
1717      ;   CORRUPTS REGISTERS R1,R2
1718
1719      ; SUBORDINATE ROUTINES USED:
1720      ;   NONE
1721
1722      ; FUNCTIONAL SIDE EFFECTS:
1723      ;   NONE
1724
1725      ; CALLING SEQUENCE:
1726      ;   CALL   CRAMS      ;GO TO ROUTINE
1727      ;   BCS   ERROR      ;CARRY SET IF ROUTINE HAD ERROR
1728      ;--
1729
1730 006212 012701 002762  CRAMS:: MOV    #DMAOBUF,R1      ; get start address of data
1731 006216 012702 003036      MOV    #DMAIBUF,R2      ; get start address of data read back
1732 006222 012703 000054      MOV    #DMALEN,R3      ; get length in bytes
1733 006226 122122      10$:  CMPB  (R1)+,(R2)+     ; are we o.k
1734 006230 001417      BEQ   20$              ; branch if yes
1735 006232      ERR.FILLIN 11.,ERR11 ; error return if not
1736      006232 012737 000002 002202  MOV    #2,ERRPTYP      ; assume hard error for now
1737      006240 012737 000013 002204  MOV    #11.,ERRNBR     ; get error 11.
1738      006246 012737 003753 002206  MOV    #ERR11,ERRMSG   ; get error ERR11
1739      006254 012737 004302 002210  MOV    #ERRCODE,ERRBLK ; get error routine
1736 006262      ERROR
1737 006264      ERR.RETURN
1738      006264 000261      SEC
1739      006266 000207      RETURN
1738 005270 077322      20$:  SOB   R3,10$          ; branch if we have not finished
1739 006272      OK.RETURN
1739      006272 000241      CLC
1740      006274 000207      RETURN

```

GLOBAL SUBROUTINES SECTION

```

1742
1743 ;**
1744 ; FUNCTIONAL DESCRIPTION:
1745 ; SUBROUTINE TO SET UP TEST MASK FOR EVERY MICRODIAGNOSTIC TEST.
1746 ;
1747 ; INPUTS:
1748 ; NONE
1749 ;
1750 ; IMPLICIT INPUTS:
1751 ; L$TEST - CURRENT TEST
1752 ;
1753 ; OUTPUTS:
1754 ; NONE
1755 ;
1756 ; IMPLICIT OUTPUTS:
1757 ; CORRUPTS REGISTERS R1,R2
1758 ; PBLOC+2 - LOCATION TO STORE TEST MASK ( TEMPORARY )
1759 ; TMASKS - LOCATION TO STORE TEST MASK ( PERMANENT )
1760 ;
1761 ; SUBORDINATE ROUTINES USED:
1762 ; NONE
1763 ;
1764 ; FUNCTIONAL SIDE EFFECTS:
1765 ; NONE
1766 ;
1767 ; CALLING SEQUENCE:
1768 ; CALL TSTMSK ;GO TO ROUTINE
1769 ;--
1770 TSTMSK::
1771 MOV L$TEST,R2 ; get current test ( 1 - MAXTST )
1772 DEC R2 ; Get offset from 0
1773 ASL R2 ; in bytes.
1774 ADD R4,R2 ; Get offset from FLAGS
1775 CALL TSTONCE ; First time through this test ?
1776 BNE 40$ ; branch if not
1777 MOV #<1*400>,PBLOC+2 ; test count = 1 ( top byte )
1778 RFLAGS R1 ; get DRS operator flag settings
1779 BIT #HOE,R1 ; HOE bit set ?
1780 BEQ 10$ ; branch if not
1781 BISB #BIT6,PBLOC+2 ; set the HOE bit
1782 BIT #LOE,R1 ; LOE bit set ?
1783 BEQ 30$ ; branch if not
1784 PRINTF #TM1 ; print warning message
1785 MANUAL ; manual allowed ?
1786 BNCOMPLETE 20$ ; no - do same as op answer yes
1787 GMANIL TM2,TEMP1,177777,NO ; op wish LOE set ?
1788 TST TEMP1
1789 BEQ 30$ ; branch if no
1790 BISB #BIT7,PBLOC+2 ; set the LOE bit
1791 MOV PBLOC+2,TMASKS(R2) ; save the mask
1792 MOV TMASKS(R2),PBLOC+2 ; copy saved mask into parameter block
1793 RETURN
1794 1794 006444 045 116 045 TM1: .ASCIZ /*N#A** AN ON-BOARD ERROR WILL HANG THIS TEST INDEFINITELY **/
1795 1795 006541 104 125 105 TM2: .ASCIZ /DUE TO ON-BOARD LOE FLAG SET - DO YOU WISH IT SET ?/
1796
1797 .EVEN

```

GLOBAL SUBROUTINES SECTION

```

1799
1800 ;**
1801 ; FUNCTIONAL DESCRIPTION:
1802 ; SUBROUTINE TO MOVE MICRODIAGNOSTIC PARAMETERS INTO THE PARAMETER REGISTER.
1803 ; INPUTS:
1804 ; NONE
1805
1806 ; IMPLICIT INPUTS:
1807 ; PBLOC - BUFFER CONTAINING MICRODIAGNOSTIC PARAMETERS
1808 ; CURPAR - CURRENT PARAMETER REGISTER ADDRESS
1809
1810 ; OUTPUTS:
1811 ; CONDITION CODE - CLEAR = SUCCESS
1812 ; - SET = FAILURE
1813
1814 ; IMPLICIT OUTPUTS:
1815 ; CORRUPTS REGISTERS R1,R2
1816
1817 ; SUBORDINATE ROUTINES USED:
1818 ; POLLCRY
1819
1820 ; FUNCTIONAL SIDE EFFECTS:
1821 ; NONE
1822
1823 ; CALLING SEQUENCE:
1824 ; CALL MVAR ;GO TO ROUTINE
1825 ; BCS ERROR ;CARRY SET IF ROUTINE HAD ERROR
1826 ;--
1827
1828 006626 012701 000004 MVAR:: MOV #4,R1 ; get length to move
1829 006632 012702 002222 MOV #PBLOC,R2 ; get start address of Pbloc
1830 006636 SET.POLCNT
1831 006636 012737 002734 002216 MOV #1500.,POLCNT
1832 006644 004737 004512 10$: CALL POLLCRY ; wait for SVL CRY
1833 006650 103003 BCC 20$ ; branch if OK
1834 006652 ERROR
1834 006654 ERR.RETURN
1834 006654 SEC
1834 006656 000207 RETURN
1835 006660 012277 173350 20$: MOV (R2)+,@CURPAR ; move parameter into parameter reg
1836 006664 077111 SOB R1,10$ ; next
1837 006666 OK.RETURN
1837 006666 000241 CLC
1837 006670 000207 RETURN
1838

```

GLOBAL SUBROUTINES SECTION

```

1840      ;++
1841      ; FUNCTIONAL DESCRIPTION:
1842      ;   SUBROUTINE TO INVOKE A MICRODIAGNOSTIC
1843
1844      ; INPUTS:
1845      ;   NONE
1846
1847      ; IMPLICIT INPUTS:
1848      ;   POLCNT           - POLL COUNT
1849      ;   PBLOC           - BUFFER FOR MICRODIAGNOSTIC PARAMETERS
1850      ;   STABUF         - STATUS BUFFER FOR RETURNS FROM VSV21
1851
1852      ; OUTPUTS:
1853      ;   CONDITION CODE - CLEAR = SUCCESS
1854      ;                   - SET   = FAILURE
1855
1856      ; IMPLICIT OUTPUTS:
1857      ;   NONE
1858
1859      ; SUBORDINATE ROUTINES USED:
1860      ;   DOCOM
1861
1862      ; FUNCTIONAL SIDE EFFECTS:
1863      ;   NONE
1864
1865      ; CALLING SEQUENCE:
1866      ;   CALL   DOMIC           ;GO TO ROUTINE
1867      ;   BCS   ERROR           ;CARRY SET IF ROUTINE HAD ERROR
1868      ;--
1869
1870 006672 012737 002000 002614 DOMIC:: MOV    #PI.TST,COMAND
1871 006700 032737 000200 002224      BIT    #BIT7,PBLOC+2      ; LOE ?
1872 006706 001004                BNE    10$                ; branch if yes
1873 006710                SET.POLCNT      ; set ordinary t'meout
1874 006710 012737 002734 002216      MOV    #1500.,POLCNT
1875 006716 000403                BR     20$
1876 006720 012737 177777 002216 10$: MOV    #-1,POLCNT      ; set infinite timeout
1877 006726 004737 004572 20$: CALL   DOCOM          ; invoke micro diagnostic.
1878 006732 103001                BCC   30$
1879 006734 000207                RETURN
1880 006736 122737 000011 002667 30$: CMPB   #DI.MIC,STABUF+1    ; correct status return ?
1881 006744 001417                BEQ   40$                ; branch if yes
1882 006746                ERR.FILLIN    12.,ERR12      ; error if no
1883 006746 012737 000002 002202      MOV    #2,ERRTYP        ; assume hard error for now
1884 006754 012737 000014 002204      MOV    #12.,ERRNBR     ; get error 12.
1885 006762 012737 004000 002206      MOV    #ERR12,ERRMSG   ; get error ERR12
1886 006770 012737 004302 002210      MOV    #ERRCODE,ERRBLK ; get error routine
1887 006776                ERROR
1888 007000                ERR.RETURN
1889 007000                SEC
1890 007002                RETURN
1891 007004 000261                TST    STABUF+2          ; test successful ?
1892 007010 001417                BEQ   50$                ; branch if YES
1893 007012                ERR.FILLIN    13.,ERR13      ; error if no
1894 007012 012737 000002 002202      MOV    #2,ERRTYP        ; assume hard error for now
1895 007020 012737 000015 002204      MOV    #13.,ERRNBR     ; get error 13.
1896 007026 012737 004065 002206      MOV    #ERR13,ERRMSG   ; get error ERR13

```

GLOBAL SUBROUTINES SECTION

	007034	012737	004302	002210		MOV	#ERRCODE,ERRBLK ; get error routine
1887	007042					ERPUR	
1888	007044					ERR.RETURN	
	007044	000261				SEC	
	007046	000207				RETURN	
1889	007050				50\$:	OK.RETURN	
	007050	000241				CIC	
	007052	000207				RETURN	
1890							



GLOBAL SUBROUTINES SECTION

```

1892 ;++
1893 ; FUNCTIONAL DESCRIPTION:
1894 ;   SUBROUTINE TO MARK CURRENT TEST AS HAVING BEEN DONE AT LEAST ONCE
1895
1896 ; INPUTS:
1897 ;   NONE
1898
1899 ; IMPLICIT INPUTS:
1900 ;   L$TEST           - CURRENT TEST
1901
1902 ; OUTPUTS:
1903 ;   NONE
1904
1905 ; IMPLICIT OUTPUTS:
1906 ;   CORRUPTS REGISTERS R0,R1
1907 ;   FTHRU           - FLAG BITS INDICATING IF TESTS HAVE BEEN DONE ONCE
1908
1909 ; SUBORDINATE ROUTINES USED:
1910 ;   NONE
1911
1912 ; FUNCTIONAL SIDE EFFECTS:
1913 ;   NONE
1914
1915 ; CALLING SEQUENCE:
1916 ;   CALL   MRKONCE           ;GO TO ROUTINE
1917 ;--
1918 007054 MRKONCE::
1919 007054 013700 002114      MOV    L$TEST,R0           ; get current test
1920 007060 010401           MOV    R4,R1             ; get address of flags
1921 007062 020027 000017      CMP    R0,#15.          ; test 1-15 ?
1922 007066 003404           BLE    10$              ; branch if yes
1923 007070 162700 000017      SUB    #15.,R0         ; get in range for a test > 15
1924 007074 062701 000002      ADD    #2,R1           ; point to second flag word (test > 15)
1925 007100 006300           10$: ASL    R0             ; get offset from start of BITS
1926 007102 056061 002244 000004  BIS    BITS(R0),FTHRU(R1) ; set appropriate flag bit
1927 007110 000207           RETURN

```

GLOBAL SUBROUTINES SECTION

```

1929
1930 ;**
1931 ; FUNCTIONAL DESCRIPTION:
1932 ;   SUBROUTINE TO TEST IF CURRENT TEST HAS BEEN DONE AT LEAST ONCE
1933
1934 ; INPUTS:
1935 ;   NONE
1936
1937 ; IMPLICIT INPUTS:
1938 ;   L$TEST           - CURRENT TEST
1939 ;   FTHRU           - FLAG BITS INDICATING IF TESTS HAVE BEEN DONE UNCE
1940
1941 ; OUTPUTS:
1942 ;   Z BIT           - SET INDICATES TEST HAS BEEN DONE AT LEAST ONCE
1943 ;                 - CLEAR INDICATES TEST HAS NOT BEEN DONE
1944
1945 ; IMPLICIT OUTPUTS:
1946 ;   CORRUPTS REGISTERS R0,R1
1947
1948 ; SUBORDINATE ROUTINES USED:
1949 ;   NONE
1950
1951 ; FUNCTIONAL SIDE EFFECTS:
1952 ;   NONE
1953
1954 ; CALLING SEQUENCE:
1955 ;   CALL TSTONCE           ;GO TO ROUTINE
1956 ;   BNE ATLEASTONCE      ;BRANCH IF TEST DONE AT LEAST ONCE
1957 ;--
1958 007112
1959 007112 013700 002114
1960 007116 010401
1961 007120 020027 000017
1962 007124 003404
1963 007126 162700 000017
1964 007132 062701 000002
1965 007136 006300
1966 007140 036061 002244 000004
1967 007146 000207

TSTONCE::
        MOV     L$TEST,R0           ; get current test
        MOV     R4,R1              ; get address of flags
        CMP     R0,#15.            ; test 1-15 ?
        BLE     10$                ; branch if yes
        SUB     #15.,R0            ; get in range for a test > 15
        ADD     #2,R1              ; point to second flag word (test > 15)
10$:    ASL     R0                  ; get offset from start of BITS
        BIT     BITS(R0),FTHRU(R1) ; test appropriate flag bit
        RETURN

```

GLOBAL SUBROUTINES SECTION

```

1969      ;**
1970      ; FUNCTIONAL DESCRIPTION:
1971      ;   SUBROUTINE TO BE CALLED AT START OF EACH TEST TO PERFORM INITIALISATION.
1972
1973      ; INPUTS:
1974      ;   NONE
1975
1976      ; IMPLICIT INPUTS:
1977      ;   L$TEST      - CURRENT TEST
1978      ;   T1DONE     - TEST 1 DONE FLAG
1979
1980      ; OUTPUTS:
1981      ;   CONDITION CODE - CLEAR = SUCCESS
1982      ;                   - SET   = FAILURE
1983
1984      ; IMPLICIT OUTPUTS:
1985      ;   CORRUPTS REGISTER R1
1986      ;   PBLOC       - FILLS IN CORRESPONDING MICRODIAGNOSTIC TEST NUMBER
1987
1988      ; SUBORDINATE ROUTINES USED:
1989      ;   NONE
1990
1991      ; FUNCTIONAL SIDE EFFECTS:
1992      ;   NONE
1993
1994      ; CALLING SEQUENCE:
1995      ;   CALL      STTEST      ;GO TO ROUTINE
1996      ;   BCS      ERROR      ;BRANCH IF ERROR
1997      ;--
1998
1999      STTEST::
2000      TST      NOTEST          ; can test be done ?
2001      BEQ      5$              ; branch if yes
2002      ERR.RETURN              ; error return if not
2003      SEC
2004      RETURN
2005      5$:      MOV      L$TEST,R1      ; get current test
2006      DEC      R1                  ; Get 'n range 0 - 40
2007      ASL      R1                  ; for offset calculations.
2008      TST      R1                  ; is it test 1 ?
2009      BEQ      20$              ; exit if yes
2010
2011      ; Test is not 1 - ensure that test 1 has already been done
2012      TST      T1DONE(R4)          ; test 1 done ?
2013      BNE      10$              ; branch if yes
2014      ERRHRD  1,ERR1,ERRCODE      ; error exit if not
2015      ERR.RETURN
2016      SEC
2017      RETURN
2018
2019      ; Set up microdiagnostic test number in PBLOC
2020      10$:     MOV      MICNUM(R1),PBLOC      ; get microdiagnostic test number
2021      20$:     OK.RETURN
2022      CLC

```

GLOBAL SUBROUTINES SECTION

```
007230 000207 RETURN
2021
2022 ;Microdiagnostic test number versus test. ( -1 is null )
2023
2024 007232 177777 177777 177777 MICNUM: .WORD 1., 1., 1.,0,1,2,3,4,5,6,7
2025 007260 000010 000011 000012 .WORD 8.,9.,10.,11.,11.,11.,12.,13.,-1.
2026
```

GLOBAL SUBROUTINES SECTION

```
2028          .TITLE MISCELLANEOUS SECTIONS
2029          .SBTTL PROTECTION TABLE
2030
2031          ;++
2032          ; THIS TABLE IS USED BY THE RUNTIME SERVICES
2033          ; TO PROTECT THE LOAD MEDIA.
2034          ;--
2035
2036 007302          BGNPROT
2037
2038 007302 000000          0          ;OFFSET INTO P-TABLE FOR CSR ADDRESS
2039 007304 177777          -1         ;OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
2040 007306 177777          -1         ;OFFSET INTO P-TABLE FOR DRIVE NUMBER
2041
2042 007310          ENDPROT
2043
```

INITIALIZE SECTION

```

2058          .SBTTL  INITIALIZE SECTION
2059
2060          ;++
2061          ; THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
2062          ; AT THE BEGINNING OF EACH PASS.
2063          ;--
2064
2065 007310      BGNINIT
2066
2090 007310      READEF  #EF.START          ; IF started by start THEN
2091 007316      BCOMPLETE 10#           ; do start coding
2092 007320      READEF  #EF.RESTART       ; IF not started by restart THEN
2093 007326      BNCOMPLETE 20#          ; skip start coding
2094 007330      012700  002304      10#:  MOV   #FLAGS,R0          ; get address of FLAGS
2095 007334      012701  000140      MOV   #<LENFLAGS*MAXUNIT>,R1 ; get length of FLAGS
2096 007340      005020              15#:  CLR   (R0)+             ; clear out FLAGS
2097 007342      077102              SOB   R1,15#             ; next
2098 007344      005037  002242      CLR   NOTEST           ; say tests can be done
2099 007350      20#:  READEF  #EF.CONTINUE ; IF started by continue THEN
2100 007356      BCOMPLETE  END          ; don't get P-table
2101 007360      READEF  #EF.NEW          ; IF not a new pass THEN
2102 007366      BNCOMPLETE  NEXT       ; skip setup
2103
2104 007370      012737  177777  002220  NEXT:  MOV   #-1,LOGUNT      ; initialise unit number
2105 007376      005237  002220      INC   LOGUNT           ; next unit number
2106 007402      023737  002220  002012  CMP   LOGUNT,L#UNIT ; IF passed operator's max unit number THEN
2107 007410      001437              BEQ   ABORT           ; abort pass
2108 007412      023727  002220  000004  CMP   LOGUNT,#MAXUNIT ; IF passed max unit number THEN
2109 007420      002033              BGE   ABORT           ; abort pass (N.B. OPERATOR'S MAX COULD BE >)
2110 007422      GPWARD LOGUNT,R1       ; Get hardware P-table address
2111 007432      BNCOMPLETE  NEXT       ; if not available get next
2112 007434      011137  002232      MOV   (R1),CURCSR      ; get current device address from P-table
2113 007440      062737  000002  002232  ADD   #2,CURCSR      ; add 2 to get current CSR
2114 007446      011137  002234      MOV   (R1),CURPAR      ; get current device address from P-table
2115 007452      062737  000004  002234  ADD   #4,CURPAR      ; add 4 to get current Parameter Register
2116 007460      016137  000002  002236  MOV   2(R1),CURVEC   ; get current vector address
2117 007466      013701  002220      MOV   LOGUNT,R1      ; get unit number
2118 007472      070127  000060      MUL   #<LENFLAGS*2>,R1 ; get offset from start of FLAGS
2119 007476      062701  002304      ADD   #FLAGS,R1     ; get true address of FLAGS for this unit
2120 007502      010104              MOV   R1,R4         ; save in R4
2121 007504      END:  EXIT  INIT
2122 007510      ABORT: DOCLN
2123 007512      ENDINIT
2124
2125          .EVEN
2126

```

AUTODROP SECTION

2128
2129
2130
2131
2132
2133
2134
2135
2136
2137 007514
2138
2145
2146 007514

.SBTTL AUTODROP SECTION

;++
; THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
; THE "ADR" FLAG WAS SET. THE UNIT(S) UNDER TEST ARE CHECKED TO
; SEE IF THEY WILL RESPOND. THOSE THAT DON'T ARE IMMEDIATELY
; DROPPED FROM TESTING.
;--

BGNAUTO

ENDAUTO

CLEANUP CODING SECTION

```

2148          .SBTTL  CLEANUP CODING SECTION
2149
2150          ;**
2151          ; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
2152          ; AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED.
2153          ;**
2154
2155 007516          BGNCLN
2156
2157 007516 023727 002220 000004      CMP      LOGUNT,#MAXUNIT      ; IF greater than max unit THEN
2158 007524 002011                    BGE      10$                    ; exit
2159 007526 013700 002232      MOV      CURCSR,R0          ; get current CSR
2160 007532 005040                    CLR      (R0)                    ; Write to the previous word (i.e. H/W
2161          ;                                ; register ) to reset VSV21.
2162
2163 007534 005064 000002      CLR      DMASET(R4)          ; say DMA disabled
2164 007540 005064 000000      CLR      T1DONE(R4)         ; say Test 1 not done
2165 007544 005037 002242      CLR      NOTEST                ; say tests can be done
2166
2167 007550          10$:  EXIT      CLN
2168
2169 007554          ENDCLN
2170

```

CLEANUP CODING SECTION

```

2172 .TITLE HARDWARE TESTS
2173
2174 .SBTTL TEST 1: VERIFY VSV21 PRESENCE
2175
2176
2177 ;**
2178 ; This test verifies that there is a VSV21 device at the current CSR.
2179 ; On the first pass it displays the version of the VSV21. It also disables
2180 ; interrupts.
2181 ; -
2182
2183 007556 ST.TEST
      007556 004737 007150 CALL STTEST
      007562 103002 BCC 30000$
2184
2185 ;SUBTEST 1 sends an interrupt mask to disable interrupts.
2186
2187 007570 BGNSUB
2188 007572 005064 000000 CLR T1DONE(R4) ; say that TEST1 has not been done
2189 007576 DO.COMMAND PI.IDS,10$ ; send over interrupt mask.
      007576 012737 001400 002614 MOV #PI.IDS,COMAND
      007604 012737 002734 002216 MOV #1500.,POLCNT
      007612 004737 004572 CALL DOCOM
      007616 103002 BCC 10$
2190 007620 ESCAPE TST
2191 007624 005264 000000 10$: INC T1DONE(R4) ; say TEST1 done so that if powerup
2192 ; ; when request firmware id will get
2193 ; ; error
2194 007630 ENDSUB
2195
2196 ;SUBTEST 2 requests firmware ID and displays it
2197
2198 007632 BGNSUB
2199 007634 DO.COMMAND PI.IDM,10$ ; request firmware id
      007634 012737 000400 002614 MOV #PI.IDM,COMAND
      007642 012737 002734 002216 MOV #1500.,POLCNT
      007650 004737 004572 CALL DOCOM
      007654 103004 BCC 10$
2200 007656 005064 000000 CLR T1DONE(R4) ; say that TEST1 has not been done
2201 007662 ESCAPE TST
2202 007666 005264 000000 10$: INC T1DONE(R4) ; say TEST1 done
2203 007672 004737 007112 CALL TSTONCE ; first time through ?
2204 007676 001044 BNE 20$ ; branch if not
2205 007700 004737 007054 CALL MRKONCE ; say not first time through
2206 007704 000337 002670 SWAB STABUF+2 ; Rearrange
2207 007710 000337 002672 SWAB STABUF+4 ; firmware ID
2208 007714 000337 002674 SWAB STABUF+6 ; so that can be printed.
2209 007720 000337 002676 SWAB STABUF+8. ; This assumes top byte zero.
2210 007724 PRINTX #TS1,#STABUF+2> ; Print firmware id.
2211 007750 PRINTX #TS2
2212 007770 PRINTX #TS3
2213 010010 20$: ENDSUB
2214
2215 010012 EXIT TST
2216
2217 010016 045 116 045 TS1: .ASCIZ /#N#AFIRMWARE ID IS : #T/
2218 010046 045 116 062 TS2: .ASCIZ /#N2#ATESTS 4,13,14,16 AND 17 WILL ABORT WITH AN ERROR IF/

```

TEST 1: VERIFY VSV21 PRESENCE

```
2219 010137      045      116      045 TS3:  .ASCIZ /NAEXTERNAL LOOPBACK CONNECTORS ARE NOT ATTACHED TO PORTS 0-3/
2220
2221
2222
2223 010236      .EVEN
2224
                                ENDTST
```

TEST 1: VERIFY VSV21 PRESENCE

```

2226
2227           .SBTTL  TEST 2:  IN DEPTH Q22 BUS TEST
2228
2229
2230           ;**
2231           ; This test performs an in depth test of the Q22 bus by means of exercising the
2232           ; DMA mechanism in both directions. It sets up the DMA protocol and must be
2233           ; done before other tests requiring DMA.
2234           ;:-
2235
2236 010240           ST.TEST
                010240 004737 007150      CALL  STTEST
                010244 103002           BCC  30001$
2237
2238           ;SUBTEST 1 moves DMA buffer descriptors through the parameter register
2239
2240 010252           BGNSUB
2241 010254 012701 002604      MOV  #BUFDES,R1           ; get address of buffer descriptors
2242 010260 012702 000004      MOV  #4,R2              ; length to move
2243
2244 010264           10$: SET.POLCNT
                010264 012737 002734 002216      MOV  #1500.,POLCNT
2245 010272 004737 004512      CALL  POLLCRY           ; wait for SVL CRY
2246 010276 103002           BCC  20$           ; branch if OK
2247 010300           ESCAPE TST
2248 010304 012177 171724      20$: MOV  (R1)+,@CURPAR       ; move buffer desc. into parameter reg
2249 010310 077213           SOB  R2,10$         ; next descriptor
2250 010312           ENDSUB
2251
2252           ;SUBTEST 2 does the buffer sent command
2253
2254 010314           BGNSUB
2255 010316           DO.COMMAND  PI.SEN,BUFOK      ; do buffers sent command
                010316 012737 001000 002614      MOV  #PI.SEN,COMAND
                010324 012737 002734 002216      MOV  #1500.,POLCNT
                010332 004737 004572      CALL  DOCOM
                010336 103016           BCC  BUFOK
2256 010340           ENDSUB
2257
2258           ;SUBTEST 3 does a buffers cancelled command if SUBTEST 2 failed
2259
2260 010342           BGNSUB
2261 010344           DO.COMMAND  PI.CAN,10$       ; do buffers cancelled command
                010344 012737 001001 002614      MOV  #PI.CAN,COMAND
                010352 012737 002734 002216      MOV  #1500.,POLCNT
                010360 004737 004572      CALL  DOCOM
                010364 103000           BCC  10$
2262 010366           10$: ESCAPE TST
2263 010372           ENDSUB
2264
2265           ;SUBTEST 3 writes to RAM using DMA. This is SUBTEST 3 if 2 is successful.
2266
2267 010374           BUFOK: BGNSUB
2268 010376 005264 000002      INC  DMASET(R4)         ; record DMA enabled
2269 010402           DO.WRAMS
                010402 012737 002762 002622      MOV  #DMAOBUF,COMBUF+4 ; write to RAM
                010410 012737 000054 002624      MOV  #DMALEN,COMBUF+6

```

TES 2: IN DEPTH Q22 BUS TEST

```

010416 004737 006066          CALL  WRAMS
2270 010422 103002          BCC  10$          ; carry on if OK
2271 010424          ESCAPE TST
2272 010430          10$: ENDSUB
2273
2274          ;SUBTEST 4 reads from RAM using DMA.
2275
2276 010432          BGNSUB
2277 010434          DO.RRAMS          ; read from RAM
      010434 012737 003036 002622  MOV  #DMAIBUF,COMBUF+4
      010442 012737 000054 002624  MOV  #DMALEN,COMBUF+6
      010450 004737 006132          CALL  RRAMS
2278 010454 103002          BCC  10$          ; carry on if OK
2279 010456          ESCAPE TST
2280 010462          10$: ENDSUB
2281
2282          ;SUBTEST 5 compares data read back with data written
2283
2284 010464          BGNSUB
2285 010466 004737 006212  CALL  CRAMS          ; compare the patterns
2286 010472 103002          BCC  10$          ; carry on if OK
2287 010474          ESCAPE TST
2288 010500          10$: ENDSUB
2289
2290 010502          EXIT  TST
2291
2292          .EVEN
2293 010506          ENDTST
2294

```

TEST 2: IN DEPTH Q22 BUS TEST

```

2296
2297
2298
2299
2300
2301
2302
2303
2304 010510
      010510 004737 007150
      010514 103002
2305
2306
2307
2308 010522
2309 010524
      010524 012737 177777 002614
      010532 012737 002734 002216
      010540 004737 004572
      010544 103000
2310 010546 122737 000177 002667 10$:
2311 010554 001002
2312 010556
2313
2314 010562
2315 010612
2316 010614
2317 010620
2318
2319 010622

.SBTTL TEST 3: FORCED ERROR TEST

; **
; This test sends an invalid command to the VSV21 to provoke an error packet.
; --

ST.TEST
CALL STTEST
BCC 30002$

;SUBTEST 1 sends an invalid command

BGNSUB
DO.COMMAND PI.RUB,10$ ; send a rubbish command
MOV #PI.RUB,COMAND
MOV #1500.,PGLCNT
CALL DOCOM
BCC 10$
CMPB #DI.ERL,STABUF+1 ; correct error return ?
BNE 20$ ; branch if not
EXIT TST ; received an error exit ok

20$: ERR.FILLIN 14.,ERR14
ERROR
ESCAPE TST
ENDSUB

ENDTST

```

TEST 3: FORCED ERROR TEST

2321
 2322
 2323
 2324
 2325
 2326
 2327
 2328
 2329
 2330
 2331
 2332
 2333
 2334 010624
 010624 004737 007150
 010630 103002
 2335
 2336 010636 004737 006276
 2337 010642 004737 007054
 2338
 2339
 2340
 2341
 2342 010646
 2343 010650 004737 006626
 2344 010654 103002
 2345 010656
 2346 010662
 2347
 2348
 2349
 2350 010664
 2351 010666 004737 006672
 2352 010672 103002
 2353 010674
 2354 010700
 2355
 2356 010702
 2357

.SBTTL TEST 4: FULL ON BOARD TESTS

```

; **
; This test invokes full on-board VSV21 microdiagnostic tests.
; If the HOE flag is specified the VSV21 will halt on error.
; If the LOE flag is specified the operator will be given the choice on the
; first pass of whether he wishes the on-board tests to loop on error. If he
; selects yes the test may hang indefinitely as the on board will not return
; control to the host but will continue looping.
; --
    
```

```

ST.TEST
CALL STTEST
BCC 30003$
    
```

```

CALL TSTMSK ; get test mask for microdiagnostic
CALL MRKONCE ; mark test as entered at least once
    
```

```

;SUBTEST 1 moves the parameters for the microdiagnostics test through the
;parameter register
    
```

```

BGNSUB
CALL MVPAR ; move the parameters
BCC 10$
ESCAPE TST
10$: ENDSUB
    
```

```

;SUBTEST 2 invokes the microdiagnostic test
    
```

```

BGNSUB
CALL DOMIC
BCC 10$
ESCAPE TST
10$: ENDSUB
    
```

```

ENDTST
    
```

TEST 4: FULL ON BOARD TESTS

```

2359
2360
2361
2362
2363
2364
2365
2366
2367
2368
2369
2370
2371
2372 010704
      010704 004737 007150
      010710 103002
2373
2374 010716 004737 006276
2375 010722 004737 007054
2376
2377
2378
2379
2380 010726
2381 010730 004737 006626
2382 010734 103002
2383 010736
2384 010742
2385
2386
2387
2388 010744
2389 010746 004737 006672
2390 010752 103002
2391 010754
2392 010760
2393
2394 010762

```

```

.SBTTL TEST 5: ROM CHECKSUM TEST

; **
; This test invokes the on-board VSV21 ROM CHECKSUM test.
; If the HOE flag is specified the VSV21 will halt on error.
; If the LOE flag is specified the operator will be given the choice on the
; first pass of whether he wishes the on-board tests to loop on error. If he
; selects yes the test may hang indefinitely as the on board will not return
; control to the host but will continue looping.
; --

      ST.TEST
      CALL STTEST
      BCC 30004$

      CALL TSTMSK ; get test mask for microdiagnostic
      CALL MRKONCE ; mark test as entered at least once

;SUBTEST 1 moves the parameters for the microdiagnostics test through the
;parameter register

      BNSUB
      CALL MVAR ; move the parameters
      BCC 10$
      ESCAPE TST
10$: ENDSUB

;SUBTEST 2 invokes the microdiagnostic test

      BGNSUB
      CALL DOMIC
      BCC 10$
      ESCAPE TST
10$: ENDSUB

      ENDTST

```

TEST 5: ROM CHECKSUM TEST

2396
 2397
 2398
 2399
 2400
 2401
 2402
 2403
 2404
 2405
 2406
 2407
 2408
 2409 010764
 010764 004737 007150
 010770 103002
 2410
 2411 010776 004737 006276
 2412 011002 004737 007054
 2413
 2414
 2415
 2416
 2417 011006
 2418 011010 004737 006626
 2419 011014 103002
 2420 011016
 2421 011022
 2422
 2423
 2424
 2425 011024
 2426 011026 004737 006672
 2427 011032 103002
 2428 011034
 2429 011040
 2430
 2431 011042

.SBTTL TEST 6: NVRAM CHECKSUM TEST

```

; **
; This test invokes the on-board VSV21 NVRAM CHECKSUM test.
; If the HOE flag is specified the VSV21 will halt on error.
; If the LOE flag is specified the operator will be given the choice on the
; first pass of whether he wishes the on-board tests to loop on error. If he
; selects yes the test may hang indefinitely as the on board will not return
; control to the host but will continue looping.
; --
    
```

```

ST.TEST
CALL STTEST
BCC 30005$
    
```

```

CALL TSTMSK ; get test mask for microdiagnostic
CALL MRKONCE ; mark test as entered at least once
    
```

```

;SUBTEST 1 moves the parameters for the microdiagnostics test through the
;parameter register
    
```

```

BGNSUB
CALL MVAR ; move the parameters
BCC 10$
ESCAPE TST
10$: ENDSUB
    
```

```

;SUBTEST 2 invokes the microdiagnostic test
    
```

```

BGNSUB
CALL DOMIC
BCC 10$
ESCAPE TST
10$: ENDSUB

ENDTST
    
```

TEST 6: NVRAM CHECKSUM TEST

2433
 2434
 2435
 2436
 2437
 2438
 2439
 2440
 2441
 2442
 2443
 2444
 2445
 2446 011044
 011044 004737 007150
 011050 103002
 2447
 2448 011056 004737 006276
 2449 011062 004737 007054
 2450
 2451
 2452
 2453
 2454 011066
 2455 011070 004737 006626
 2456 011074 103002
 2457 011076
 2458 011102
 2459
 2460
 2461
 2462 011104
 2463 011106 004737 006672
 2464 011112 103002
 2465 011114
 2466 011120
 2467
 2468 011122

.SBTTL TEST 7: RAM TEST

```

; **
; This test invokes the on-board VSV21 RAM test.
; If the HOE flag is specified the VSV21 will halt on error.
; If the LOE flag is specified the operator will be given the choice on the
; first pass of whether he wishes the on-board tests to loop on error. If he
; selects yes the test may hang indefinitely as the on board will not return
; control to the host but will continue looping.
; --
    
```

```

ST.TEST
CALL STTEST
BCC 30006$
    
```

```

CALL TSTMSK ; get test mask for microdiagnostic
CALL MRKONCE ; mark test as entered at least once
    
```

```

;SUBTEST 1 moves the parameters for the microdiagnostic's test through the
;parameter register
    
```

```

BGNSUB
CALL MVPAR ; move the parameters
BCC 10$
ESCAPE TST
10$: ENDSUB
    
```

```

;SUBTEST 2 invokes the microdiagnostic test
    
```

```

BGNSUB
CALL DOMIC
BCC 10$
ESCAPE TST
10$: ENDSUB

ENDTST
    
```

TEST 7: RAM TEST

2470
 2471
 2472
 2473
 2474
 2475
 2476
 2477
 2478
 2479
 2480
 2481
 2482
 2483
 2484
 2485
 2486
 2487
 2488
 2489
 2490
 2491
 2492
 2493
 2494
 2495
 2496
 2497
 2498
 2499
 2500
 2501
 2502
 2503
 2504
 2505

011124
 011124 004737 007150
 011130 103002
 011136 004737 006276
 011142 004737 007054
 011146
 011150 004737 006626
 011154 103002
 011156
 011162
 011164
 011166 004737 006672
 011172 103002
 011174
 011200
 011202

.SBTTL TEST 8: RAM ADDRESSING TEST

```

; **
; This test invokes the on-board VSV21 RAM ADDRESSING test.
; If the HOE flag is specified the VSV21 will halt on error.
; If the LOE flag is specified the operator will be given the choice on the
; first pass of whether he wishes the on-board tests to loop on error. If he
; selects yes the test may hang indefinitely as the on board will not return
; control to the host but will continue looping.
; --
    
```

```

ST.TEST
CALL STTEST
BCC 30007$
    
```

```

CALL TSTMSK ; get test mask for microdiagnostic
CALL MRKONCE ; mark test as entered at least once
    
```

```

;SUBTEST 1 moves the parameters for the microdiagnostics test through the
;parameter register
    
```

```

BGNSUB
CALL MVAR ; move the parameters
BCC 10$
ESCAPE TST
10$: ENDSUB
    
```

```

;SUBTEST 2 invokes the microdiagnostic test
    
```

```

BGNSUB
CALL DOMIC
BCC 10$
ESCAPE TST
10$: ENDSUB
ENDTST
    
```

TEST 8: RAM ADDRESSING TEST

2507
 2508
 2509
 2510
 2511
 2512
 2513
 2514
 2515
 2516
 2517
 2518
 2519
 2520
 2521
 2522
 2523
 2524
 2525
 2526
 2527
 2528
 2529
 2530
 2531
 2532
 2533
 2534
 2535
 2536
 2537
 2538
 2539
 2540
 2541
 2542

011204
 011204 004737 007150
 011210 103002
 011216 004737 006276
 011222 004737 007054
 011226
 011230 004737 006626
 011234 103002
 011236
 011242
 011244
 011246 004737 006672
 011252 103002
 011254
 011260
 011262

.SBTTL TEST 9: 68K PROCESSOR TEST

```

;+
; This test invokes the on-board VSV21 68K PROCESSOR test.
; If the HOE flag is specified the VSV21 will halt on error.
; If the LOE flag is specified the operator will be given the choice on the
; first pass of whether he wishes the on-board tests to loop on error. If he
; selects yes the test may hang indefinitely as the on board will not return
; control to the host but will continue looping.
;--
    
```

```

ST.TEST
CALL STTEST
BCC 30008$
    
```

```

CALL TSTMSK ; get test mask for microdiagnostic
CALL MRKONCE ; mark test as entered at least once
    
```

```

;SUBTEST 1 moves the parameters for the microdiagnostics test through the
;parameter register
    
```

```

BGNSUB
CALL MVAR ; move the parameters
BCC 10$
ESCAPE TST
10$: ENDSUB
    
```

```

;SUBTEST 2 invokes the microdiagnostic test
    
```

```

BGNSUB
CALL DOMIC
BCC 10$
ESCAPE TST
10$: ENDSUB
    
```

```

ENDTST
    
```

TEST 9: 68K PROCESSOR TEST

2544
 2545
 2546
 2547
 2548
 2549
 2550
 2551
 2552
 2553
 2554
 2555
 2556
 2557 011264
 011264 004737 007150
 011270 103002
 2558
 2559 011276 004737 006276
 2560 011302 004737 007054
 2561
 2562
 2563
 2564
 2565 011306
 2566 011310 004737 006626
 2567 011314 103002
 2568 011316
 2569 011322
 2570
 2571
 2572
 2573 011324
 2574 011326 004737 006672
 2575 011332 103002
 2576 011334
 2577 011340
 2578
 2579 011342

.SBTTL TEST 10: INTERNAL EXCEPTIONS TEST

```

; **
; This test invokes the on-board INTERNAL EXCEPTIONS test.
; If the MOE flag is specified the VSV21 will halt on error.
; If the LOE flag is specified the operator will be given the choice on the
; first pass of whether he wishes the on-board tests to loop on error. If he
; selects yes the test may hang indefinitely as the on board will not return
; control to the host but will continue looping.
; --
    
```

```

ST.TEST
CALL STTEST
BCC 30009#
    
```

```

CALL TSTMSK ; get test mask for microdiagnostic
CALL MRKONCE ; mark test as entered at least once
    
```

```

;SUBTEST 1 moves the parameters for the microdiagnostics test through the
;parameter register
    
```

```

BGNSUB
CALL MVAR ; move the parameters
BCC 10#
ESCAPE TST
10#: ENDSUB
    
```

```

;SUBTEST 2 invokes the microdiagnostic test
    
```

```

BGNSUB
CALL DOMIC
BCC 10#
ESCAPE TST
10#: ENDSUB
    
```

```

ENDTST
    
```

TEST 10: INTERNAL EXCEPTIONS TEST

```

2581
2582          .SBTTL TEST 11: ACRCT INTERNAL TEST
2583
2584
2585          ;**
2586          ; This test invokes the on board ACRCT INTERNAL test.
2587          ; If the HOE flag is specified the VSV21 will halt on error.
2588          ; If the LOE flag is specified the operator will be given the choice on the
2589          ; first pass of whether he wishes the on board tests to loop on error. If he
2590          ; selects yes the test may hang indefinitely as the on board will not return
2591          ; control to the host but will continue looping.
2592          ;--
2593
2594          011344          ST.TEST
                011344 004737 007150          CALL STTEST
                011350 103002          BCC 30010$
2595
2596          011356 004737 006276          CALL TSTMSK          ; get test mask for microdiagnostic
2597          011362 004737 007054          CALL MRKONCE          ; mark test as entered at least once
2598
2599          ;SUBTEST 1 moves the parameters for the microdiagnostic's test through the
2600          ;parameter register
2601
2602          011366          BGNSUB
2603          011370 004737 006626          CALL MVAR          ; move the parameters
2604          011374 103002          BCC 10$
2605          011376          ESCAPE TST
2606          011402          10$: ENDSUB
2607
2608          ;SUBTEST 2 invokes the microdiagnostic test
2609
2610          011404          BGNSUB
2611          011406 004737 006672          CALL DOMIC
2612          011412 103002          BCC 10$
2613          011414          ESCAPE TST
2614          011420          10$: ENDSUB
2615
2616          011422          ENDTST

```

TEST 11: ACRCT INTERNAL TEST

.SBTTL TEST 12: ACRCT EXTERNAL TEST

2618
 2619
 2620
 2621
 2622
 2623
 2624
 2625
 2626
 2627
 2628
 2629
 2630
 2631 011424
 011424 004737 007150
 011430 103002
 2632
 2633 011436 004737 006276
 2634 011442 004737 007054
 2635
 2636
 2637
 2638
 2639 011446
 2640 011450 004737 006626
 2641 011454 103002
 2642 011456
 2643 011462
 2644
 2645
 2646
 2647 011464
 2648 011466 004737 006672
 2649 011472 103002
 2650 011474
 2651 011500
 2652
 2653 011502

```

; **
; This test invokes the on-board VSV21 ACRCT EXTERNAL test.
; If the HOE flag is specified the VSV21 will halt on error.
; If the LOE flag is specified the operator will be given the choice on the
; first pass of whether he wishes the on-board tests to loop on error. If he
; selects yes the test may hang indefinitely as the on board will not return
; control to the host but will continue looping.
; -
    
```

```

ST.TEST
CALL STTEST
BCC 30011$

CALL TSTMSK ; get test mask for microdiagnost'c
CALL MRKONCE ; mark test as entered at least once

;SUBTEST 1 moves the parameters for the microdiagnost'cs test through the
;parameter register

BGNSUB
CALL MVAR ; move the parameters
BCC 10$
ESCAPE TST
10$: ENDSUB

;SUBTEST 2 invokes the microdiagnost'c test

BGNSUB
CALL DOMIC
BCC 10$
ESCAPE TST
10$: ENDSUB

ENDTST
    
```

TEST 12: ACRCT EXTERNAL TEST

2655
 2656
 2657
 2658
 2659
 2660
 2661
 2662
 2663
 2664
 2665
 2666
 2667 011504
 011504 004737 007150
 011510 103002
 2668
 2669 011516 004737 006276
 2670 011522 004737 007054
 2671
 2672
 2673
 2674 011526 005037 002226
 2675
 2676
 2677
 2678
 2679 011532
 2680 011534 004737 006626
 2681 011540 103002
 2682 011542
 2683 011546
 2684
 2685
 2686
 2687 011550
 2688 011552 004737 006672
 2689 011556 103002
 2690 011560
 2691 011564
 2692
 2693
 2694
 2695 011566 005237 002226
 2696
 2697
 2698
 2699
 2700 011572
 2701 011574 004737 006626
 2702 011600 103002
 2703 011602
 2704 011606
 2705
 2706
 2707
 2708 011610
 2709 011612 004737 006672

.SBTTL TEST 13: DUART BASIC TEST

```

;--
; This test invokes the on board VSV21 DUART BASIC test on ports 0-3.
; If the HOE flag is specified the VSV21 will halt on error.
; If the LOE flag is specified the operator will be given the choice on the
; first pass of whether he wishes the on board tests to loop on error. If he
; selects yes the test may hang indefinitely as the on board will not return
; control to the host but will continue looping.
;--
    
```

```

ST.TEST
CALL STTEST
BCC 30012$

CALL TSTMSK ; get test mask for microdiagnostic
CALL MRKONCE ; mark test as entered at least once

;FIRST PORT =====
CLR PBLOC+4 ; get port 0 into parameter block

;SUBTEST 1 moves the parameters for the microdiagnostics test through the
;parameter register

BGNSUB
CALL MVAR ; move the parameters
BCC 10$
ESCAPE TST
10$: ENDSUB

;SUBTEST 2 invokes the microdiagnostic test

BGNSUB
CALL DOMIC
BCC 10$
ESCAPE TST
10$: ENDSUB

;SECOND PORT =====
INC PBLOC+4 ; get next port into parameter block

;SUBTEST 3 moves the parameters for the microdiagnostics test through the
;parameter register

BGNSUB
CALL MVAR ; move the parameters
BCC 10$
ESCAPE TST
10$: ENDSUB

;SUBTEST 4 invokes the microdiagnostic test

BGNSUB
CALL DOMIC
    
```

TEST 13: DUART BASIC TEST

```

2710 011616 103002          BCC      10$
2711 011620                ESCAPE  TST
2712 011624                10$:    ENDSUB
2713
2714                ;THIRD PORT =====
2715
2716 011626 005237 002226          INC      PBLOC+4          ; get next port into parameter block
2717
2718                ;SUBTEST 5 moves the parameters for the microdiagnostics test through the
2719                ;parameter register
2720
2721 011632                BGNSUB
2722 011634 004737 006626          CALL     MVPAR          ; move the parameters
2723 011640 103002                BCC      10$
2724 011642                ESCAPE  TST
2725 011646                10$:    ENDSUB
2726
2727                ;SUBTEST 6 invokes the microdiagnostic test
2728
2729 011650                BGNSUB
2730 011652 004737 006672          CALL     DOMIC
2731 011656 103002                BCC      10$
2732 011660                ESCAPE  TST
2733 011664                10$:    ENDSUB
2734
2735                ;FOURTH PORT =====
2736
2737 011666 005237 002226          INC      PBLOC+4          ; get next port into parameter block
2738
2739                ;SUBTEST 7 moves the parameters for the microdiagnostics test through the
2740                ;parameter register
2741
2742 011672                BGNSUB
2743 011674 004737 006626          CALL     MVPAR          ; move the parameters
2744 011700 103002                BCC      10$
2745 011702                ESCAPE  TST
2746 011706                10$:    ENDSUB
2747
2748                ;SUBTEST 8 invokes the microdiagnostic test
2749
2750 011710                BGNSUB
2751 011712 004737 006672          CALL     DOMIC
2752 011716 103002                BCC      10$
2753 011720                ESCAPE  TST
2754 011724                10$:    ENDSUB
2755
2756
2757 011726                ENDTST

```

TEST 13: DUART BASIC TEST

2759
 2760
 2761
 2762
 2763
 2764
 2765
 2766
 2767
 2768
 2769
 2770
 2771
 2772 011730
 011730 004737 007150
 011734 103002
 2773
 2774 011742 004737 006276
 2775 011746 004737 007054
 2776
 2777
 2778
 2779 011752 005037 002226
 2780
 2781
 2782
 2783
 2784 011756
 2785 011760 004737 006626
 2786 011764 103002
 2787 011766
 2788 011772
 2789
 2790
 2791
 2792 011774
 2793 011776 004737 006672
 2794 012002 103002
 2795 012004
 2796 012010
 2797
 2798
 2799
 2800 012012 005237 002226
 2801
 2802
 2803
 2804
 2805 012016
 2806 012020 004737 006626
 2807 012024 103002
 2808 012026
 2809 012032
 2810
 2811
 2812
 2813 012034

.SBTTL TEST 14: DUART FULL TEST

```

; **
; This test invokes the on-board VSV21 DUART FULL test on ports 0-3.
; If the HOE flag is specified the VSV21 will halt on error.
; If the LOE flag is specified the operator will be given the choice on the
; first pass of whether he wishes the on-board tests to loop on error. If he
; selects yes the test may hang indefinitely as the on board will not return
; control to the host but will continue looping.
; --
    
```

```

ST.TEST
CALL STTEST
BCC 30013$

CALL TSTMSK ; get test mask for microdiagnostic
CALL MRKONCE ; mark test as entered at least once

;FIRST PORT =====
CLR PBLOC+4 ; get port 0 into parameter block

;SUBTEST 1 moves the parameters for the microdiagnostics test through the
;parameter register
BGNSUB
CALL MVAR ; move the parameters
BCC 10$
ESCAPE TST
10$: ENDSUB

;SUBTEST 2 invokes the microdiagnostic test
BGNSUB
CALL DOMIC
BCC 10$
ESCAPE TST
10$: ENDSUB

;SECOND PORT =====
INC PBLOC+4 ; get next port into parameter block

;SUBTEST 3 moves the parameters for the microdiagnostics test through the
;parameter register
BGNSUB
CALL MVAR ; move the parameters
BCC 10$
ESCAPE TST
10$: ENDSUB

;SUBTEST 4 invokes the microdiagnostic test
BGNSUB
    
```

TEST 14: DUART FULL TEST

```

2814 012036 004737 006672          CALL    DOMIC
2815 012042 103002                  BCC     10$
2816 012044                          ESCAPE TST
2817 012050          10$:          ENDSUB
2818
2819          ;THIRD PORT =====
2820
2821 012052 005237 002226          INC     PBLOC+4          ; get next port into parameter block
2822
2823          ;SUBTEST 5 moves the parameters for the microdiagnostics test through the
2824          ;parameter register
2825
2826 012056          BGNSUB
2827 012060 004737 006626          CALL    MVAR          ; move the parameters
2828 012064 103002                  BCC     10$
2829 012066                          ESCAPE TST
2830 012072          10$:          ENDSUB
2831
2832          ;SUBTEST 6 invokes the microdiagnostic test
2833
2834 012074          BGNSUB
2835 012076 004737 006672          CALL    DOMIC
2836 012102 103002                  BCC     10$
2837 012104                          ESCAPE TST
2838 012110          10$:          ENDSUB
2839
2840          ;FOURTH PORT =====
2841
2842 012112 005237 002226          INC     PBLOC+4          ; get next port into parameter block
2843
2844          ;SUBTEST 7 moves the parameters for the microdiagnostics test through the
2845          ;parameter register
2846
2847 012116          BGNSUB
2848 012120 004737 006626          CALL    MVAR          ; move the parameters
2849 012124 103002                  BCC     10$
2850 012126                          ESCAPE TST
2851 012132          10$:          ENDSUB
2852
2853          ;SUBTEST 8 invokes the microdiagnostic test
2854
2855 012134          BGNSUB
2856 012136 004737 006672          CALL    DOMIC
2857 012142 103002                  BCC     10$
2858 012144                          ESCAPE TST
2859 012150          10$:          ENDSUB
2860
2861
2862 012152          ENDTST
    
```

TEST 14: DUART FULL TEST

2864
2865
2866
2867
2868
2869
2870
2871
2872
2873
2874
2875
2876
2877
2878
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888
2889
2890
2891
2892
2893
2894
2895
2896
2897
2898
2899
2900
2901
2902
2903
2904
2905
2906
2907
2908
2909
2910
2911
2912
2913
2914
2915

000010
012154 004737 007150
012154 004737 007150
012160 103002
012166
012176
012220
012240 004737 006276
012244 004737 007054
012250
012270
012304 005737 013076
012310 001007
012312 052737 000001 002224
012320 012737 000056 002230
012326 000406
012330 052737 000002 002224
012336 012737 000020 002230
012344
012344
012346 005737 013076
012352 001013
012354
012354 012737 013020 002622
012362 012737 000056 002624
012370 004737 006066
012374 103002

.SBTTL TEST 15: PERIPHERAL CONFIDENCE TEST

```

;--
; **
; This test allows the operator to select a port for either input or output.
; If he selects output an ASCII string is written to that port.
; If he selects input the first 16 characters read from that port are displayed
; in octal on the console running the tests.
; If the HOE flag is specified the VSV21 will halt on error.
; If the LOE flag is specified the operator will be given the choice on the
; first pass of whether he wishes the on-board tests to loop on error. If he
; selects yes the test may hang indefinitely as the on board will not return
; control to the host but will continue looping.
;--

```

```

T15RLEN=8.
ST.TEST
CALL STTEST
BCC 30014$

MAN.IGNORE ; ignore test if not manual
DMA.IGNORE ; ensure DMA enabled
GMANID T15M1,PBLOC+4,D,177777,0,3,NO ; get port number
CALL TSTMSK ; get test mask for microdiagnostic
CALL MRKONCE ; mark test as entered at least once

PRINTF #T15M2
GMANIL T15M3,T15INP,177777,NO ; get whether input/output device
TST T15INP ; input device ?
BNE 30$ ; branch if yes
BIS #1,PBLOC+2 ; say normal mode + write
MOV #<T15WEN-T15WBUF>,PBLOC+6 ; put length to be DMA'd
BR 40$
30$: BIS #2,PBLOC+2 ; say normal mode + read
MOV #<T15RLEN*2>,PBLOC+6 ; put length to be DMA'd

;SUBTEST 1 DMA's test data into the VSV21 for an output device
40$: BGNSUB
TST T15INP ; input device ?
BNE 10$ ; branch if yes
DO.WRAMS #T15WBUF,#<T15WEN-T15WBUF> ; DMA the data
MOV #T15WBUF,COMBUF+4
MOV #<T15WEN-T15WBUF>,COMBUF+6
CALL WRAMS
BCC 10$
ESCAPE TST ; exit if DMA fails
10$: ENDSUB

;SUBTEST 2 moves the parameters for the microdiagnostics test through the
;parameter register

```

TEST 15: PERIPHERAL CONFIDENCE TEST

```

2916 012404
2917 012406 004737 006626
2918 012412 103002
2919 012414
2920 012420 10$:
2921
2922
2923 ;SUBTEST 3 invokes the microdiagnostic test
2924 012422
2925 012424 004737 006672
2926 012430 103002
2927 012432
2928 012436 10$:
2929
2930 ;SUBTEST 4 DMA's the data back from the VSV21 for an input device
2931
2932 012440
2933 012442 005737 013076
2934 012446 001441
2935 012450
    012450 012737 013000 002622
    012456 012737 000020 002624
    012464 004737 006132
2936 012470 103002
2937 012472
2938 012476
2939 012516 012701 000010
2940 012522 012702 013000
2941 012526
2942 012550 077112
2943 012552
2944
2945 012554
2946
2947 012560 120 114 105
2948 012611 045 116 045
2949 012645 120 114 105
2950 012743 045 116 045
2951 012773 045 117 067
2952
2953 013000
2954 013000
2955 013020
2956 013020 041 100 043
2957 013076
2958
2959 013076 000000
2960
2961 013100

```

```

BGNSUB
CALL MVPAR ; move the parameters
BCC 10$
ESCAPE TST
ENDSUB

BGNSUB
CALL DOMIC
BCC 10$
ESCAPE TST
ENDSUB

BGNSUB
TST T15INP ; input device ?
BEQ 30$ ; branch if not
DO.RRAMS #T15RBUF,#<T15RLEN*2> ; DMA the data
MOV #T15RBUF,COMBUF+4
MOV #<T15RLEN*2>,COMBUF+6
CALL RRAMS
BCC 10$
ESCAPE TST ; exit if DMA fails
10$: PRINTF #T15M4 ; print the data received
MOV #T15RLEN,R1 ; number to print
MOV #T15RBUF,R2 ; address of buffer
20$: PRINTF #T15M5,(R2)+ ; print a word
SOB R1,20$ ; next one
30$: ENDSUB

EXIT TST

T15M1: .ASCIZ /PLEASE ENTER PORT NUMBER/
T15M2: .ASCIZ /#N#AIS IT AN INPUT DEVICE ?/
T15M3: .ASCIZ /PLEASE ENTER "YES" FOR INPUT DEVICE OR "NO" FOR OUTPUT DEVICE/
T15M4: .ASCIZ /#N#ADATA RECEIVED IS : /
T15M5: .ASCIZ /#07/
.EVEN
T15RBUF:
.BLKW T15RLEN
T15WBUF:
.ASCIZ /!@#%*+&*()_+1234567890QWERTYUIOPiOasdfghjkl;'/
T15WEN:
.EVEN
T15INP: .WORD 0 ; <>0 for i/p device , 0 for o/p device

ENDTST

```

TEST 15: PERIPHERAL CONFIDENCE TEST

```

2963
2964
2965
2966
2967
2968
2969
2970
2971
2972
2973
2974
2975
2976
2977 013102          ST.TEST
      013102 004737 007150  CALL    STTEST
      013106 103002          BCC     30017$

2978
2979 013114          DMA.IGNORE          ; ensure DMA enabled
2980
2981 013136 004737 006276  CALL    TSTMSK          ; get test mask for microdiagnostic
2982 013142 004737 007054  CALL    MRKONCE        ; mark test as entered at least once
2983
2984 013146 052737 000013 002224  BIS     #13,PBLOC+2    ; say local loop + read + write
2985 013154 012737 000054 002230  MOV     #DMALEN,PBLOC+6 ; put length to be DMA'd
2986
2987          ;SUBTEST 1 DMA's test data into the VSV21
2988
2989 013162          BGNSUB
2990 013164          DO.WRAMS          ; DMA the data
      013164 012737 002762 002622  MOV     #DMAOBUF,COMBUF+4
      013172 012737 000054 002624  MOV     #DMALEN,COMBUF+6
      013200 004737 006066          CALL    WRAMS
2991 013204 103002          BCC     10$
2992 013206          ESCAPE TST          ; exit if DMA fails
2993 013212 10$:          ENDSUB
2994
2995          ;FIRST PORT =====
2996
2997 013214 005037 0022L6          CLR     PBLOC+4          ; get port 0 into parameter block
2998
2999          ;SUBTEST 2 moves the parameters for the microdiagnostics test through the
3000          ;parameter register
3001
3002 013220          BGNSUB
3003 013222 004737 006626          CALL    MVPAR          ; move the parameters
3004 013226 103002          BCC     10$
3005 013230          ESCAPE TST
3006 013234 10$:          ENDSUB
3007
3008          ;SUBTEST 3 invokes the microdiagnostic test
3009
3010 013236          BGNSUB
3011 013240 004737 006672          CALL    DOMIC
3012 013244 103002          BCC     10$
3013 013246          ESCAPE TST
3014 013252 10$:          ENDSUB

```

.SBTTL TEST 16: INTERNAL LOOPBACK TEST

```

;+
; This test causes the on-board software to perform an INTERNAL LOOPBACK
; test on ports 0 3.
; If the HOE flag is specified the VSV21 will halt on error.
; If the LOE flag is specified the operator will be given the choice on the
; first pass of whether he wishes the on-board tests to loop on error. If he
; selects yes the test may hang indefinitely as the on board will not return
; control to the host but will continue looping.
;--

```

TEST 16: INTERNAL LOOPBACK TEST

```

3015
3016           ;SUBTEST 4 DMA's the data back from the VSV21
3017
3018 013254           BGNSUB
3019 013256           DO.RRAMS           ; DMA the data
           012737 003036 002622      MOV     #DMAIBUF,COMBUF+4
           012737 000054 002624      MOV     #DMALEN,COMBUF+6
           013272 004737 006132      CALL    RRAMS
3020 013276 103002      BCC     10$
3021 013300           ESCAPE  TST           ; exit if DMA fails
3022 013304           10$: ENDSUB
3023
3024           ;SUBTEST 5 Compares data written and read
3025
3026 013306           BGNSUB
3027 013310 004737 006212      CALL    CRAMS           ; DMA the data
3028 013314 103002      BCC     10$
3029 013316           ESCAPE  TST           ; exit if DMA fails
3030 013322           10$: ENDSUB
3031
3032           ;SECOND PORT =====
3033
3034 013324 005237 002226      INC     PBLOC+4           ; get next port into parameter block
3035
3036           ;SUBTEST 6 moves the parameters for the microdiagnostics test through the
3037           ;parameter register
3038
3039 013330           BGNSUB
3040 013332 004737 006626      CALL    MVAR           ; move the parameters
3041 013336 103002      BCC     10$
3042 013340           ESCAPE  TST
3043 013344           10$: ENDSUB
3044
3045           ;SUBTEST 7 invokes the microdiagnostic test
3046
3047 013346           BGNSUB
3048 013350 004737 006672      CALL    DOMIC
3049 013354 103002      BCC     10$
3050 013356           ESCAPE  TST
3051 013362           10$: ENDSUB
3052
3053           ;SUBTEST 8 DMA's the data back from the VSV21
3054
3055 013364           BGNSUB
3056 013366           DO.RRAMS           ; DMA the data
           012737 003036 002622      MOV     #DMAIBUF,COMBUF+4
           012737 000054 002624      MOV     #DMALEN,COMBUF+6
           013402 004737 006132      CALL    RRAMS
3057 013406 103002      BCC     10$
3058 013410           ESCAPE  TST           ; exit if DMA fails
3059 013414           10$: ENDSUB
3060
3061           ;SUBTEST 9 Compares data written and read
3062
3063 013416           BGNSUB
3064 013420 004737 006212      CALL    CRAMS           ; DMA the data
3065 013424 103002      BCC     10$

```

TEST 16: INTERNAL LOOPBACK TEST

```

3066 013426          ESCAPE TST          ; exit if DMA fails
3067 013432      10$:  ENDSUB
3068
3069      ;THIRD PORT -----
3070
3071 013434  005237  002226          INC      PBLOC+4          ; get next port into parameter block
3072
3073      ;SUBTEST 10 moves the parameters for the microdiagnostics test through the
3074      ;parameter register
3075
3076 013440          BGNSUB
3077 013442  004737  006626          CALL     MVPAR          ; move the parameters
3078 013446  103002
3079 013450          BCC      10$
3080 013454      10$:  ESCAPE TST
3081      ENDSUB
3082
3083      ;SUBTEST 11 invokes the microdiagnostic test
3084
3085 013456          BGNSUB
3086 013460  004737  006672          CALL     DOMIC
3087 013464  103002          BCC      10$
3088 013472      10$:  ESCAPE TST
3089      ENDSUB
3090
3091      ;SUBTEST 12 DMA's the data back from the VSV21
3092
3093 013474          BGNSUB
3094 013476          DO.RRAMS          ; DMA the data
3095 013476  012737  003036  002622  MOV     #DMAIBUF,COMBUF+4
3096 013504  012737  000054  002624  MOV     #DMALEN,COMBUF+6
3097 013512  004737  006132          CALL     RRAMS
3098 013516  103002          BCC      10$
3099 013520          ESCAPE TST          ; exit if DMA fails
3100 013524      10$:  ENDSUB
3101
3102      ;SUBTEST 13 Compares data written and read
3103
3104 013526          BGNSUB
3105 013530  004737  006212          CALL     CRAMS          ; DMA the data
3106 013534  103002          BCC      10$
3107 013536          ESCAPE TST          ; exit if DMA fails
3108 013542      10$:  ENDSUB
3109
3110      ;FOURTH PORT -----
3111
3112 013544  005237  002226          INC      PBLOC+4          ; get next port into parameter block
3113
3114      ;SUBTEST 14 moves the parameters for the microdiagnostics test through the
3115      ;parameter register
3116
3117 013550          BGNSUB
3118 013552  004737  006626          CALL     MVPAR          ; move the parameters
3119 013556  103002          BCC      10$
3120 013560          ESCAPE TST
3121 013564      10$:  ENDSUB
3122
3123      ;SUBTEST 15 invokes the microdiagnostic test
3124

```

TEST 16: INTERNAL LOOPBACK TEST

```

3120
3121 013566          BGNSUB
3122 013570 004737 006672    CALL    DOMIC
3123 013574 103002          BCC     10$
3124 013576          ESCAPE  TST
3125 013602          10$:   ENDSUB
3126
3127          ;SUBTEST 16 DMA's the data back from the VSV21
3128
3129 013604          BGNSUB
3130 013606          DO.RRAMS          ; DMA the data
      013606 012737 003036 002622    MOV     #DMAIBUF,COMBUF+4
      013614 012737 000054 002624    MOV     #DMALEN,COMBUF+6
      013622 004737 006132          CALL    RRAMS
3131 013626 103002          BCC     10$
3132 013630          ESCAPE  TST          ; exit if DMA fails
3133 013634          10$:   ENDSUB
3134
3135          ;SUBTEST 17 Compares data written and read
3136
3137 013636          BGNSUB
3138 013640 004737 006212    CALL    CRAMS          ; DMA the data
3139 013644 103002          BCC     10$
3140 013646          ESCAPE  TST          ; exit if DMA fails
3141 013652          10$:   ENDSUB
3142
3143
3144 013654          ENDTST
    
```

TEST 16: INTERNAL LOOPBACK TEST

3146
3147
3148
3149
3150
3151
3152
3153
3154
3155
3156
3157
3158
3159
3160
3161
3162
3163
3164
3165
3166
3167
3168
3169
3170
3171
3172
3173
3174
3175
3176
3177
3178
3179
3180
3181
3182
3183
3184
3185
3186
3187
3188
3189
3190
3191
3192
3193
3194
3195
3196
3197

013656
013656 004737 007150
013662 103002

013670

013712 004737 006276
013716 004737 007054

013722 052737 000003 002224
013730 012737 000054 002230

013736
013740
013740 012737 002762 002622
013746 012737 000054 002624
013754 004737 006066
013760 103002

013770 005037 002226

013774
013776 004737 006626
014002 103002
014004
014010

014012
014014 004737 006672
014020 103002
014022
014026

```
.SBTTL TEST 17: EXTERNAL I/O LOOPBACK TEST

;--
; This test causes the on-board software to perform an EXTERNAL LOOPBACK
; test on ports 0-3.
; If the HOE flag is specified the VSV21 will halt on error.
; If the LOE flag is specified the operator will be given the choice on the
; first pass of whether he wishes the on-board tests to loop on error. If he
; selects yes the test may hang indefinitely as the on board will not return
; control to the host but will continue looping.
;--

ST.TEST
CALL STTEST
BCC 30019$

DMA.IGNORE ; ensure DMA enabled

CALL TSTMSK ; get test mask for microdiagnostic
CALL MRKONCE ; mark test as entered at least once

BIS #3,PBLOC+2 ; say normal mode + read + write
MOV #DMALEN,PBLOC+6 ; put length to be DMA'd

;SUBTEST 1 DMA's test data into the VSV21

BGNSUB
DO.WRAMS ; DMA the data
MOV #DMAOBUF,COMBUF+4
MOV #DMALEN,COMBUF+6
CALL WRAMS
BCC 10$
ESCAPE TST ; exit if DMA fails
10$: ENDSUB

;FIRST PORT .....

CLR PBLOC+4 ; get port 0 into parameter block

;SUBTEST 2 moves the parameters for the microdiagnostics test through the
;parameter register

BGNSUB
CALL MVAR ; move the parameters
BCC 10$
ESCAPE TST
10$: ENDSUB

;SUBTEST 3 invokes the microdiagnostic test

BGNSUB
CALL DOMIC
BCC 10$
ESCAPE TST
10$: ENDSUB
```

TEST 17: EXTERNAL I/O LOOPBACK TEST

```

3198
3199           ;SUBTEST 4 DMA's the data back from the VSV21
3200
3201 014030           BGNSUB
3202 014032           DO.RRAMS           ; DMA the data
           012737 003036 002622      MOV     #DMAIBUF,COMBUF+4
           014040 012737 000054 002624  MOV     #DMALEN,COMBUF+6
           014046 004737 006132      CALL    RRAMS
3203 014052 103002      BCC     10$
3204 014054           ESCAPE  TST           ; exit if DMA fails
3205 014060 10$:      ENDSUB
3206
3207           ;SUBTEST 5 Compares data written and read
3208
3209 014062           BGNSUB
3210 014064 004737 006212      CALL    CRAMS           ; DMA the data
3211 014070 103002      BCC     10$
3212 014072           ESCAPE  TST           ; exit if DMA fails
3213 014076 10$:      ENDSUB
3214
3215           ;SECOND PORT =====
3216
3217 014100 005237 002226      INC     PBLOC+4           ; get next port into parameter block
3218
3219           ;SUBTEST 6 moves the parameters for the microdiagnostics test through the
3220           ;parameter register
3221
3222 014104           BGNSUB
3223 014106 004737 006626      CALL    MVPAR           ; move the parameters
3224 014112 103002      BCC     10$
3225 014114           ESCAPE  TST
3226 014120 10$:      ENDSUB
3227
3228           ;SUBTEST 7 invokes the microdiagnostic test
3229
3230 014122           BGNSUB
3231 014124 004737 006672      CALL    DOMIC
3232 014130 103002      BCC     10$
3233 014132           ESCAPE  TST
3234 014136 10$:      ENDSUB
3235
3236           ;SUBTEST 8 DMA's the data back from the VSV21
3237
3238 014140           BGNSUB
3239 014142           DO.RRAMS           ; DMA the data
           014142 012737 003036 002622      MOV     #DMAIBUF,COMBUF+4
           014150 012737 000054 002624  MOV     #DMALEN,COMBUF+6
           014156 004737 006132      CALL    RRAMS
3240 014162 103002      BCC     10$
3241 014164           ESCAPE  TST           ; exit if DMA fails
3242 014170 10$:      ENDSUB
3243
3244           ;SUBTEST 9 Compares data written and read
3245
3246 014172           BGNSUB
3247 014174 004737 006212      CALL    CRAMS           ; DMA the data
3248 014200 103002      BCC     10$

```

TEST 17: EXTERNAL I/O LOOPBACK TEST

```

3240 014202
3250 014206          ESCAPE TST          ; exit if DMA fails
10$: ENDSUB
3251
3252
3253
3254 014210 005237 002226          INC      PBLOC+4          ; get next port into parameter block
3255
3256          ;SUBTEST 10 moves the parameters for the microdiagnostics test through the
3257          ;parameter register
3258
3259 014214
3260 014216 004737 006626          BGNSUB
3261 014222 103002          CALL      MVAR          ; move the parameters
3262 014224          BCC      10$
3263 014230          ESCAPE TST
10$: ENDSUB
3264
3265          ;SUBTEST 11 invokes the microdiagnostic test
3266
3267 014232
3268 014234 004737 006672          BGNSUB
3269 014240 103002          CALL      DOMIC
3270 014242          BCC      10$
3271 014246          ESCAPE TST
10$: ENDSUB
3272
3273          ;SUBTEST 12 DMA's the data back from the VSV21
3274
3275 014250
3276 014252          BGNSUB
3277 014252 012737 003036 002622          DO.RRAMS          ; DMA the data
3278 014260 012737 000054 002624          MOV      DMAIBUF,COMBUF+4
3279 014300          MOV      DMALEN,COMBUF+6
3280          CALL      RRAMS
3281          BCC      10$
3282          ESCAPE TST          ; exit if DMA fails
3283 014302          ENDSUB
10$:
3284 014304 004737 006212          ;SUBTEST 13 Compares data written and read
3285 014310 103002          BGNSUB
3286 014312          CALL      CRAMS          ; DMA the data
3287 014316          BCC      10$
3288          ESCAPE TST          ; exit if DMA fails
3289          ENDSUB
10$:
3290          ;FOURTH PORT *****
3291 014320 005237 002226          INC      PBLOC+4          ; get next port into parameter block
3292
3293          ;SUBTEST 14 moves the parameters for the microdiagnostics test through the
3294          ;parameter register
3295
3296 014324
3297 014326 004737 006626          BGNSUB
3298 014332 103002          CALL      MVAR          ; move the parameters
3299 014334          BCC      10$
3300 014340          ESCAPE TST
10$: ENDSUB
3301
3302          ;SUBTEST 15 invokes the microdiagnostic test

```

TEST 17: EXTERNAL I/O LOOPBACK TEST

```

3303
3304 014342          BGNSUB
3305 014344 004737 006672  CALL    DOMIC
3306 014350 103002    BCC     10$
3307 014352          ESCAPE  TST
3308 014356          10$:  ENDSUB
3309
3310          ;SUBTEST 16 DMAs the data back from the VSV21
3311
3312 014360          BGNSUB
3313 014362          DO.RRAMS          ; DMA the data
      014362 012737 003036 002622  MOV     #DMAIBUF,COMBUF+4
      014370 012737 000054 002624  MOV     #DMALEN,COMBUF+6
      014376 004737 006132    CALL    RRAMS
3314 014402 103002    BCC     10$
3315 014404          ESCAPE  TST          ; exit if DMA fails
3316 014410          10$:  ENDSUB
3317
3318          ;SUBTEST 17 Compares data written and read
3319
3320 014412          BGNSUB
3321 014414 004737 006212  CALL    CRAMS          ; DMA the data
3322 014420 103002    BCC     10$
3323 014422          ESCAPE  TST          ; exit if DMA fails
3324 014426          10$:  ENDSUB
3325
3326
3327 014430          ENDTST
    
```

TEST 18: SCREEN TEST

```

3329 .SBTTL TEST 18: SCREEN TEST
3330
3331
3332 ;**
3333 ; This test displays different screen test pictures as selected by the
3334 ; operator. If the HOE flag is specified the VSV21 will halt on error.
3335 ; If the LOE flag is specified the operator will be given the choice on the
3336 ; first pass of whether he wishes the on-board tests to loop on error. If he
3337 ; selects yes the test may hang indefinitely as the on board will not return
3338 ; control to the host but will continue looping
3339 ;--
3340
3341 014432 ST.TEST
      014432 004737 007150 CALL STTEST
      014436 103002 BCC 30021$
3342
3343 014444 MAN.IGNORE ; ignore test if not manual
3344
3345 014454 DMA.IGNORE ; ensure DMA enabled
3346
3347 014476 004737 006276 CALL TSTMSK ; get testmask
3348 014502 004737 007054 CALL MRKONCE ; mark test as entered at least once
3349
3350 ;SUBTEST 1 DMAs the operator requested picture to the VSV21
3351
3352 014506 BGNSUB
3353 014510 PRINTF #T18M1
3354 014530 GMANID T18M2,TEMP1,D,177777,1,4,NO ; get current picture number
3355 014550 013700 002212 MOV TEMP1,R0 ; and save it
3356 014554 005300 DEC R0 ; get in range 0 - 3
3357 014556 006300 ASL R0 ; get byte offset
3358 014560 DO.WRAMS PICS(R0),#<PIC2 PIC1> ; write the picture
      014560 016037 014712 002622 MOV PICS(R0),COMBUF+4
      014566 012737 000042 002624 MOV #<PIC2-PIC1>,COMBUF+6
      014574 004737 006066 CALL WRAMS
3359 014600 103002 BCC 20$
3360 014602 ESCAPE TST
3361 014606 20$: ENDSUB
3362
3363 ;SUBTEST 2 moves the parameters for the microdiagnostics test through the
3364 ;parameter register
3365
3366 014610 BGNSUB
3367 014612 012737 000042 002226 MOV #<PIC2-PIC1>,PBLOC+4 ; third parameter 's length of picture
3368 014620 004737 006626 CALL MVPAR ; move the parameters
3369 014624 103002 BCC 10$
3370 014626 ESCAPE TST
3371 014632 10$: ENDSUB
3372
3373 ;SUBTEST 3 invokes the microdiagnostic test
3374
3375 014634 BGNSUB
3376 014636 004737 006672 CALL DOMIC
3377 014642 103002 BCC 10$
3378 014644 ESCAPE TST
3379 014650 10$: ENDSUB
3380

```

TEST 18: SCREEN TEST

```

3381 014652          PRINTF  #T18M3          ; Print message
3382 014672          GMANIL  T18M4,TEMP1,177777,YES ; and wait.
3383
3384 014706          EXIT    TST
3385
3386 014712 014722 014764 015026 PICS: .WORD PIC1,PIC2,PIC3,PIC4
3387 014722 014001 000001 177777 PIC1: .WORD 014001,000001,177777,004005,000000,004006,000000,004007
3388 014742 000360 004014 040000 .WORD 000360,004014,040000,004015,000000,054000,021042,000531
3389 014762 177001 .WORD 177001
3390 014764 014001 000001 177777 PIC2: .WORD 014001,000001,177777,004005,000000,004006,000000,004007
3391 015004 000360 004014 040000 .WORD 000360,004014,040000,004015,000000,054000,042104,000531
3392 015024 177001 .WORD 177001
3393 015026 014001 000001 177777 PIC3: .WORD 014001,000001,177777,004005,000000,004006,000000,004007
3394 015046 000360 004014 040000 .WORD 000360,004014,040000,004015,000000,054000,10421,000531
3395 015066 177001 .WORD 177001
3396 015070 014001 000001 177777 PIC4: .WORD 014001,000001,177777,004005,000000,004006,000000,004007
3397 015110 000360 004014 040000 .WORD 000360,004014,040000,004015,000000,054000,177777,000531
3398 015130 177001 .WORD 177001
3399
3400 015132 045 116 045 T18M1: .ASCIZ /#N#PLEASE INPUT PICTURE NUMBER WHERE :/
3401 015202 122 105 104 T18M2: .ASCIZ /RED , GREEN , BLUE AND WHITE SCREENS ARE 1,2,3,4 RESP./
3402 015271 045 116 045 T18M3: .ASCIZ /#N#PLEASE ENTER CARRIAGE RETURN WHEN YOU HAVE FINISHED/
3403 015361 127 111 124 T18M4: .ASCIZ /WITH THE PICTURE/
3404
3405 .EVEN
3406
3407 015402          ENDTST
    
```

TEST 18: SCREEN TEST

```

3409
3410           .SBTTL TEST 19: NVRAM READ/WRITE TEST
3411
3412
3413           ;**
3414           ; This test tests NVRAM read/write. On each pass the operator will be asked if
3415           ; he wishes to continue as NVRAM has a limited life in terms of read/write
3416           ; cycles.
3417           ; If the HOE flag is specified the VSV21 will halt on error.
3418           ; If the LOE flag is specified the operator will be given the choice on the
3419           ; first pass of whether he wishes the on-board tests to loop on error. If he
3420           ; selects yes the test may hang indefinitely as the on board will not return
3421           ; control to the host but will continue looping.
3422           ;--
3423
3424 015404           ST.TEST
3425           015404 004737 007150           CALL STTEST
3426           015410 103002           BCC 30024$
3427
3428 015416           MAN.IGNORE           ; ignore test if not manual
3429
3430           CALL TSTMSK           ; get test mask for microdiagnostic
3431           CALL MRKONCE           ; mark test as entered at least once
3432
3433 015436           PRINTF #T20M1           ; Ask if operator
3434 015432 004737 006276           GMANIL T20M2,TEMP1,177777,NO           ; wants to do test.
3435 015432 004737 007054           TST TEMP1           ; operator want to do test ?
3436 015500           BNE 20$           ; branch if yes
3437 015504           EXIT TST           ; else exit if no
3438
3439           20$:
3440           ;SUBTEST 1 moves the parameters for the microdiagnostics test through the
3441           ;parameter register
3442
3443 015504           BGNSUB
3444 015506 004737 006626           CALL MVAR           ; move the parameters
3445 015512 103002           BCC 10$
3446 015514           ESCAPE TST
3447 015520           10$: ENDSUB
3448
3449           ;SUBTEST 2 invokes the microdiagnostic test
3450
3451 015522           BGNSUB
3452 015524 004737 006672           CALL DOMIC
3453 015530 103002           BCC 10$
3454 015532           ESCAPE TST
3455 015536           10$: ENDSUB
3456
3457 015540           ENDTST
3458 015542 045 116 045 T20M1: .ASCIZ /*N*A** WARNING ** WRITING TO NVRAM REDUCES IT'S LIFE/
3459 015627 104 117 040 T20M2: .ASCIZ /DO YOU STILL WANT TO DO THIS TEST ?/
3460
3461           .EVEN
    
```

TEST 19: NVRAM READ/WRITE TEST

3462
 3463
 3464
 3465
 3466
 3467
 3468
 3469
 3470
 3471 015674
 015674 004737 007150
 015700 103002
 3472
 3473 015706
 3474
 3475 015734 005037 002240
 3476
 3477
 3478
 3479 015740
 3480 015742
 015742 012737 001403 002614
 015750 012737 002734 002216
 015756 004737 004572
 015762 103001
 3481 015764 000437
 3482 015766 012701 002734 10\$:
 3483 015772 005737 002240 15\$:
 3484 015776 001032
 3485 016000
 3486 016030 077120
 3487 016032
 016032 012737 000002 002202
 016040 012737 000017 002204
 016046 012737 004177 002206
 016054 012737 004302 002210
 3488 016062
 3489 016064
 3490
 3491
 3492
 3493 016066
 3494 016070
 016070 012737 001400 002614
 015076 012737 002734 002216
 016104 004737 004572
 016110 103000
 3495 016112 10\$:
 3496 016120
 3497
 3498 016122
 3499
 3500
 3501
 3502 0161 4
 3503 016124 012737 000001 002240
 3504 016132

.SBTTL TEST 20: ENABLE INTERRUPTS TEST

; **
 ; This test verifies that interrupts are received by the host when interrupts
 ; are enabled.
 ; --

ST.TEST
 CALL STTEST
 BCC 30026\$

SETVEC CURVEC,#INTVEC,#240 ; enable the interrupt service routine
 ; and give it priority #5
 CLR INTFLG ; say no interrupts have been received

;SUBTEST 1 enables interrupts and expects to get an interrupt while doing it

BGNSUB
 DO.COMMAND PI.IEN,10\$; enable interrupts
 MOV #PI.IEN,COMAND
 MOV #1500.,POLCNT
 CALL DOCOM
 BCC 10\$
 BR 20\$; branch on error
 MOV #1500.,R1 ; count to poll
 TST INTFLG ; have we received an interrupt ?
 BNE 20\$; branch if yes
 DELAY 10. ; delay 10 units
 SOB R1,15\$; again
 ERR.FILLIN 15.,ERR15 ; time out
 MOV #2,ERRTYP ; assume hard error for now
 MOV #15.,ERRNBR ; get error 15.
 MOV #ERR15,ERRMSG ; get error ERR15
 MOV #ERRCODE,ERRBLK ; get error routine
 ERROR
 20\$: ENDSUB

;SUBTEST 2 disables interrupts

BGNSUB
 DO.COMMAND PI.IDS,10\$; disable interrupts
 MOV #PI.IDS,COMAND
 MOV #1500.,POLCNT
 CALL DOCOM
 BCC 10\$
 CLRVEC CURVEC ; disable the interrupt service routine
 ENDSUB

ENDTST

;Interrupt service routine

BGNSRV INTVEC
 MOV #1,INTFLG ; say received interrupt
 ENDSRV

TEST 20: ENABLE INTERRUPTS TEST

```

3506
3507      .TITLE PARAMETER CODING
3508
3509      .SBTTL  HARDWARE PARAMETER CODING SECTION
3510
3511
3512      ;++
3513      ; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
3514      ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
3515      ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
3516      ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
3517      ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
3518      ; WITH THE OPERATOR.
3519      ;--
3520
3521 016134      BGNHRD
3522
3523 016136      GPRMA  DEVADD,0,0,160000,177776,YES
3524
3525 016146      GPRMA  VECADD,2,0,0,776,YES
3526
3527 016156      ENDHRD
3528
3529 016156      104    105    126  DEVADD: .ASCIZ  /DEVICE ADDRESS/
3530 016175      126    105    103  VECADD: .ASCIZ  /VECTOR ADDRESS/
3531
3532      .EVEN
3533
3534
3535 016214      $PATCH::
3536 016214      .BLKW  50.
3537
3538 016360      LASTAD
3539 016364      L$LAST::
3539 016364      ENDMOD

```

HARDWARE PARAMETER CODING SECTION

3541	016364		BGNSETUP	4
3542	016364		BGNPTAB	
3543	016370	172010	.WORD	172010
3544	016372	000320	.WORD	320
3545	016374		ENDPTAB	
3546	016374		BGNPTAB	
3547	016400	172020	.WORD	172020
3548	016402	000324	.WORD	324
3549	016404		ENDPTAB	
3550	016404		BGNPTAB	
3551	016410	172030	.WORD	172030
3552	016412	000330	.WORD	330
3553	016414		ENDPTAB	
3554	016414		BGNPTAB	
3555	016420	172040	.WORD	172040
3556	016422	000334	.WORD	334
3557	016424		ENDPTAB	
3558	016424		ENDSETUP	
3559	000001		.END	

Symbol table

ABORT	007510	C\$ERDF=	000055	DMA0BU	002762 G	GETST2	005462 G	L\$CO	002032 G
ADR	= 000020 G	C\$ERHR=	000056	DMASET=	000002 G	G\$CNT0=	000200	L\$DEPO	002011 G
ASSEMB=	000010	C\$ERRO=	000060	DOCOM	004572 G	G\$DELM=	000372	L\$DESC	004260 G
BITS	002244 G	C\$ERSF=	000054	DOMIC	006672 G	G\$DISP=	000003	L\$DESP	002076 G
BIT0	= 000001 G	C\$ERSO=	000057	EF.CON=	000036 G	G\$EXCP=	000400	L\$DEVP	002060 G
BIT00	= 000001 G	C\$ESCA=	000010	EF.NEW=	000035 G	G\$HILI=	000002	L\$DISP	002124 G
BIT01	= 000002 G	C\$ESEG=	000005	EF.PWR=	000034 G	G\$LOLI=	000001	L\$DLY	002116 G
BIT02	= 000004 G	C\$ESUB=	000003	EF.RES=	000037 G	G\$NO	= 000000	L\$DTP	002040 G
BIT03	= 000010 G	C\$ETST=	000001	EF.STA=	000040 G	G\$OFFS=	000400	L\$DTYP	002034 G
BIT04	= 000020 G	C\$EXIT=	000032	END	007504	G\$OFSI=	000376	L\$DUT	002072 G
BIT05	= 000040 G	C\$FREQ=	000101	ERRBLK	002210 G	G\$PRMA=	000001	L\$DVTY	004251 G
BIT06	= 000100 G	C\$FRME=	000100	ERRCOD	004302 G	G\$PRMD=	000002	L\$EF	002052 G
BIT07	= 000200 G	C\$GETB=	000026	ERRMSG	002206 G	G\$PRML=	000000	L\$ENVI	002044 G
BIT08	= 000400 G	C\$GETW=	000027	ERRNBR	002204 G	G\$RADA=	000140	L\$ERRT	002202 G
BIT09	= 001000 G	C\$GMAN=	000043	ERRTYP	002202 G	G\$RADB=	000000	L\$ETP	002102 G
BIT1	= 000002 G	C\$GPHR=	000042	ERR1	003166 G	G\$RADD=	000040	L\$EXP1	002046 G
BIT10	= 002000 G	C\$GPRI=	000040	ERR10	003720 G	G\$RADL=	000120	L\$EXP4	002064 G
BIT11	= 004000 G	C\$INIT=	000011	ERR11	003753 G	G\$RADO=	000020	L\$EXP5	002066 G
BIT12	= 010000 G	C\$INLP=	000020	ERR12	004000 G	G\$XFER=	000004	L\$HARD	016136 G
BIT13	= 020000 G	C\$MANI=	000050	ERR13	004065 G	G\$YES	= 000010	L\$HIME	002120 G
BIT14	= 040000 G	C\$MAP	= 000102	ERR14	004130 G	HELP	= 000000	L\$HPCP	002016 G
BIT15	= 100000 G	C\$MEM	= 000031	ERR15	004177 G	HOE	= 100000 G	L\$HPTP	002022 G
BIT2	= 000004 G	C\$MMU	= 000103	ERR2	003225 G	IBE	= 010000 G	L\$HW	002176 G
BIT3	= 000010 G	C\$MSG	= 000023	ERR3	003274 G	IDU	= 000040 G	L\$ICP	002104 G
BIT4	= 000020 G	C\$OPNR=	000034	ERR4	003345 G	IER	= 020000 G	L\$INIT	007310 G
BIT5	= 000040 G	C\$OPNW=	000104	ERR5	003425 G	INTFLG	002240 G	L\$LADP	002026 G
BIT6	= 000100 G	C\$PNTB=	000014	ERR6	003465 G	INTVEC	016124 G	L\$LAST	016364 G
BIT7	= 000200 G	C\$PNTF=	000017	ERR7	003541 G	ISR	= 000100 G	L\$LOAD	002100 G
BIT8	= 000400 G	C\$PNTS=	000016	ERR8	003611 G	IXE	= 004000 G	L\$LUN	002074 G
BIT9	= 001000 G	C\$PNTX=	000015	ERR9	003652 G	I\$AU	= 000041	L\$MREV	002050 G
BOE	= 000400 G	C\$PUTB=	000072	EVL	= 000004 G	I\$AUTO=	000041	L\$NAME	002000 G
BUFDES	002604	C\$PUTW=	000073	E\$END	= 002100	I\$CLN	= 000041	L\$PRIO	002042 G
BUFOK	010374	C\$QIO	= 000377	E\$LOAD=	000035	I\$DU	= 000041	L\$PROT	007302 G
COMAND	002014	C\$RDBU=	000007	FLAGS	002304 G	I\$HRD	= 000041	L\$PRT	002112 G
COMBUF	002616	C\$REFG=	000047	FTHRU	= 000004 G	I\$INIT=	000041	L\$REPP	002062 G
COMLEN=	000024	C\$REL	= 000077	F\$AU	= 000015	I\$MOD	= 000041	L\$REV	002010 G
CRAMS	006212 G	C\$RESE=	000033	F\$AUTO=	000020	I\$MSG	= 000041	L\$SPC	002056 G
CURCSR	002232 G	C\$REVI=	000004	F\$BGN	= 000040	I\$PROT=	000040	L\$SPCP	002020 G
CURPAR	002234 G	C\$RFLA=	000021	F\$CLEA=	000007	I\$PTAB=	000041	L\$SPTP	002024 G
CURVEC	002236 G	C\$RPT	= 000025	F\$DU	= 000016	I\$PWR	= 000041	L\$STA	002030 G
C\$AU	= 000052	C\$SEFG=	000046	F\$END	= 000041	I\$RPT	= 000041	L\$TEST	002114 G
C\$AUTO=	000061	C\$SPRI=	000041	F\$HARD=	000004	I\$SEG	= 000041	L\$TIML	002014 G
C\$BRK	= 000022	C\$SVEC=	000037	F\$HW	= 000013	I\$SETU=	000041	L\$UNIT	002012 G
C\$BSEG=	000004	C\$TOME=	000076	F\$INIT=	000006	I\$SRV	= 000041	L10000	002202
C\$BSUB=	000002	DEVADD	016156	F\$JMP	= 000050	I\$SUB	= 000041	L10001	004312
C\$CLCK=	000062	DFPTBL	002176 G	F\$MOD	= 000000	I\$TST	= 000041	L10003	007512
C\$CLEA=	000012	DIAGMC=	000000	F\$MSG	= 000011	J\$JMP	= 000167	L10004	007514
C\$CLOS=	000035	DI.ERL=	000177 G	F\$PROT=	000021	LENFLA=	000030 G	L10005	007554
C\$CLP1=	000006	DI.ERP=	000005 G	F\$PWR	= 000017	LOE	= 040000 G	L10006	010236
C\$CPBF=	000074	DI.ERS=	000176 G	F\$RPT	= 000012	LOGUNT	002220 G	L10007	007630
C\$CPME=	000075	DI.MIC=	000011 G	F\$SEG	= 000003	LOT	= 000010 G	L10010	010010
C\$CVEC=	000036	DI.RDA=	002101 G	F\$SOFT=	000005	L\$ACP	002110 G	L10011	010506
C\$DCLN=	000044	DI.RRA=	002103 G	F\$SRV	= 000010	L\$APT	002036 G	L10012	010312
C\$DQDU=	000051	DI.WDD=	002102 G	F\$SUB	= 000002	L\$AUT	002070 G	L10013	010340
C\$DRPT=	000024	DI.WRA=	002104 G	F\$SW	= 000014	L\$AUTO	007514 G	L10014	010372
C\$DU	= 000053	DMAIBU	003036 G	F\$TEST=	000001	L\$CCP	002106 G	L10015	010430
C\$EDIT=	000000	DMALEN=	000054	GETST1	005066 G	L\$CLEA	007516 G	L10016	010462

Symbol table

L10017	010500	L10110	013304	NEXT	007376	TS1	010016	T12.1	011446
L10020	010622	L10111	013322	NOTEST	002242 G	TS2	010046	T12.2	011464
L10021	010620	L10112	013344	O\$APTS=	000000	TS3	010137	T13	011504 G
L10022	010702	L10113	013362	O\$AU =	000000	T\$ARGC=	000001	T13.1	011532
L10023	010662	L10114	013414	O\$BGNR=	000000	T\$CODE=	001031	T13.2	011550
L10024	010700	L10115	013432	O\$BGNS=	000000	T\$ERRN=	000002	T13.3	011572
L10025	010762	L10116	013454	O\$DU =	000000	T\$EXCP=	000000	T13.4	011610
L10026	010742	L10117	013472	O\$ERRT=	000001	T\$FLAG=	000040	T13.5	011632
L10027	010760	L10120	013524	O\$GNSW=	000000	T\$FREE=	016424	T13.6	011650
L10030	011042	L10121	013542	O\$POIN=	000001	T\$GMAN=	000000	T13.7	011672
L10031	011022	L10122	013564	O\$SETU=	000001	T\$HILI=	000776	T13.8	011710
L10032	011040	L10123	013602	PBLOC	002222 G	T\$LAST=	000001	T14	011730 G
L10033	011122	L10124	013634	PICS	014712	T\$LOLI=	000000	T14.1	011756
L10034	011102	L10125	013652	PIC1	014722	T\$LSYM=	010000	T14.2	011774
L10035	011120	L10126	014430	PIC2	014764	T\$LTNO=	000024	T14.3	012016
L10036	011202	L10127	013766	PIC3	015026	T\$NEST=	177777	T14.4	012034
L10037	011162	L10130	014010	PIC4	015070	T\$NS0 =	000000	T14.5	012056
L10040	011200	L10131	014026	PI.ACK=	003000 G	T\$NS1 =	000004	T14.6	012074
L10041	011262	L10132	014060	PI.AVA=	100000 G	T\$NS2 =	000002	T14.7	012116
L10042	011242	L10133	014076	PI.CAN=	001001 G	T\$PCNT=	000000	T14.8	012134
L10043	011260	L10134	014120	PI.CMA=	002400 G	T\$PTAB=	010173	T15	012154 G
L10044	011342	L10135	014136	PI.IDM=	000400 G	T\$PTHV=	000004	T15INP	013076
L10045	011322	L10136	014170	PI.IDS=	001400 G	T\$PTNU=	000004	T15M1	012560
L10046	011340	L10137	014206	PI.IEN=	001403 G	T\$SAVL =	177777	T15M2	012611
L10047	011422	L10140	014230	PI.RUB=	177777 G	T\$SEGL =	177777	T15M3	012645
L10050	011402	L10141	014246	PI.SEN=	001000 G	T\$SIZE=	000020	T15M4	012743
L10051	011420	L10142	014300	PI.TST=	002000 G	T\$SUBN=	000002	T15M5	012773
L10052	011502	L10143	014316	PNT =	001000 G	T\$TAGL =	177777	T15RBU	013000
L10053	011462	L10144	014340	POLCNT	002216 G	T\$TAGN=	010175	T15RLE=	000010
L10054	011500	L10145	014356	POLL	004314 G	T\$TEMP=	000000	T15WBU	013020
L10055	011726	L10146	014410	POLLCR	004512 G	T\$TEST=	000024	T15WEN	013076
L10056	011546	L10147	014426	PRI =	002000 G	T\$TSTM=	177777	T15.1	012344
L10057	011564	L10150	015402	PRI00 =	000000 G	T\$TSTS=	000001	T15.2	012404
L10060	011606	L10151	014606	PRI01 =	000040 G	T\$TAUT=	010004	T15.3	012422
L10061	011624	L10152	014632	PRI02 =	000100 G	T\$CLE=	010005	T15.4	012440
L10062	011646	L10153	014650	PRI03 =	000140 G	T\$DAT=	010174	T16	013102 G
L10063	011664	L10154	015540	PRI04 =	000200 G	T\$HAR=	010163	T16.1	013162
L10064	011706	L10155	015520	PRI05 =	000240 G	T\$HW =	010000	T16.10	013440
L10065	011724	L10156	015536	PRI06 =	000300 G	T\$INI=	010003	T16.11	013456
L10066	012152	L10157	016122	PRI07 =	000340 G	T\$MSG=	010001	T16.12	013474
L10067	011772	L10160	016064	RRAMS	006132 G	T\$PC =	000004	T16.13	013526
L10070	012010	L10161	016120	STABUF	002666	T\$PRO=	010002	T16.14	013550
L10071	012032	L10162	016132	STALEN=	000036	T\$PTA=	010173	T16.15	013566
L10072	012050	L10163	016156	STTEST	007150 G	T\$SRV=	010162	T16.16	013604
L10073	012072	L10164	016370	SVCGBL=	000000	T\$SUB=	010161	T16.17	013636
L10074	012110	L10165	016400	SVCINS=	177777	T\$TES=	010157	T16.2	013220
L10075	012132	L10166	016374	SVCSUB=	177777	T1	007556 G	T16.3	013236
L10076	012150	L10167	016410	SVCTAG=	177777	T1DUNE=	000000 G	T16.4	013254
L10077	013100	L10170	016404	SVCTST=	177777	T1 1	007570	T16.5	013306
L10100	012402	L10171	016420	S\$LSYM=	010000	T1.2	007632	T16.6	013330
L10101	012420	L10172	016414	TEMP1	002212 G	T10	011264 G	T16.7	013346
L10102	012436	L10174	016424	TEMP2	002214 G	T10.1	011306	T16.8	013364
L10103	012552	MAXTST=	000024 G	TMASKS=	000010 G	T10.2	011324	T16.9	013416
L10104	013654	MAXUNI=	000004 G	TM1	006444	T11	011344 G	T17	013656 G
L10105	013212	MICNUM	007232	TM2	006541	T11.1	011366	T17.1	013736
L10106	013234	MRKONC	007054 G	TSTMSK	006276 G	T11.2	011404	T17.10	014214
L10107	013252	MVPAR	006626 G	TSTONC	007112 G	T12	011424 G	T17.11	014232

Symbol table

T17.12	014250	T18	014432 G	T2.3	010342	T5	010704 G	T9.2	011244
T17.13	014302	T18M1	015132	T2.4	010374	T5.1	010726	UAM	= 000200 G
T17.14	014324	T18M2	015202	T2.5	010432	T5.2	010744	VECADD	016175
T17.15	014342	T18M3	015271	T2.6	010464	T6	010764 G	VS.CRY	= 010000 G
T17.16	014360	T18M4	015361	T20	015674 G	T6.1	011006	VS.ERR	= 040000 G
T17.17	014412	T18.1	014506	T20M1	015542	T6.2	011024	VS.PRY	= 020000 G
T17.2	013774	T18.2	014610	T20M2	015627	T7	011044 G	VS.SVL	= 100000 G
T17.3	014012	T18.3	014634	T20.1	015740	T7.1	011066	WRAMS	006066 G
T17.4	014030	T19	015404 G	T20.2	016066	T7.2	011104	X\$ALWA	= 000000
T17.5	014062	T19.1	015504	T3	010510 G	T8	011124 G	X\$FALS	= 000040
T17.6	014104	T19.2	015522	T3.1	010522	T8.1	011146	X\$OFFS	= 000400
T17.7	014122	T2	010240 G	T4	010624 G	T8.2	011164	X\$TRUE	= 000020
T17.8	014140	T2.1	010252	T4.1	010646	T9	011204 G	\$PATCH	016214 G
T17.9	014172	T2.2	010314	T4.2	010664	T9.1	011226		

. ABS. 016424 000 (RW,I,GBL,ABS,OVR)
000000 001 (RW,I,LCL,REL,CON)

Errors detected: 0

*** Assembler statistics

Work file reads: 303
Work file writes: 304
Size of work file: 35760 Words (140 Pages)
Size of core pool: 19714 Words (75 Pages)
Operating system: RSX-11M/PLUS (Under VAX/VMS)

Elapsed time: 00:07:25.81
ZVSWAO,ZVSWAO/ SP=SVC40.MLB/ML,ZVSWAO.MAC