

VT62

VT62/DUP11 SELF-TEST/LOOPBACK EP-DZDPG-A-DL

JAN 1978


MD-11-DZDPG-A

COPYRIGHT © 1977

digital

FICHE 1 OF 1

MADE IN USA



000000 .REPT 0

IDENTIFICATION

PRODUCT CODE MAINDEC-11-DZDPG-A-D
PRODUCT NAME VT62/DUP11 SELFTEST/LOOPBACK
DATE 1-SEP-77
MAINTAINER DIAGNOSTIC ENGINEERING
AUTHOR MICHAEL DENSMORE

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR WITHIN

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1977 DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

39
40
41
42
43
44
45

REVISION HISTORY

REVISION
A

BY
M DENSMORE ORIGINAL RELEASE

47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84

TABLE OF CONTENTS

| | | | |
|-----|----------------------------------|----|----|
| 1 | GENERAL | PG | 4 |
| 1 1 | ABSTRACT | PG | 4 |
| 1 2 | DEFINITIONS | PG | 4 |
| 1 3 | DESIGN NOTES | PG | 4 |
| 1 4 | DDCMP | PG | 5 |
| 2 | EQUIPMENT REQUIREMENTS | PG | 5 |
| 3 | LOAD PROCEDURE | PG | 5 |
| 4 | STARTING AND RUNNING THE PROGRAM | PG | 5 |
| 4 1 | START | PG | 6 |
| 4 2 | RESTART | PG | 8 |
| 4 3 | CONTINUE | PG | 8 |
| 4 4 | ZERO FLAGS | PG | 9 |
| 4 5 | ADD UNITS | PG | 9 |
| 4 6 | DROP UNITS | PG | 9 |
| 4 7 | DISPLAY PTABLE | PG | 9 |
| 4 8 | SWITCH OPTIONS | PG | 9 |
| 5 | ERROR AND INFORMATIONAL MESSAGES | PG | 10 |
| 6 | RESTRICTIONS | PG | 11 |
| 7 | MISC | PG | 11 |
| 8 | TEST DESCRIPTIONS | PG | 12 |
| 8 1 | MICRODIAGNOSTIC | PG | 12 |
| 8 2 | LOOPBACK | PG | 12 |
| 9 | INDEX | PG | 13 |

26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138

1 0 GENERAL
1 1 ABSTRACT
MAINDEC-11-DZDPG RUNS THE SELFTEST FOR THE VT62 TERMINAL AND EXERCISES THE LINK BETWEEN THE TERMINAL AND THE HOST THIS PARTICULAR VERSION SUPPORTS MULTIDROP, FULL DUPLEX COMMUNICATION VIA THE DUP-11 COMMUNICATION INTERFACE. OTHER VERSIONS (MAINDEC-11-DZDZC AND MAINDEC-11-DZDVP) SUPPORT THE DZ-11 AND DV-11 COMMUNICATION INTERFACES RESPECTIVELY. THE PROGRAM IS XXDP COMPATIBLE AND SUPPORTS SEQUENTIAL TESTING OF UP TO 8 VT62'S. PLEASE READ ALL SECTIONS OF THIS DOCUMENT CAREFULLY BEFORE USING THE PROGRAM PAY PARTICULAR ATTENTION TO SECTIONS 3 0 THROUGH 6 0

1 2 DEFINITIONS
MODEM - EQUIPMENT, ALSO KNOWN AS A "DATASET", WHICH PERFORMS THE MODULATION/DEMULATION OF DATA SIGNALS THIS UNIT PROVIDES TIMING FOR SYNCHRONOUS COMMUNICATION DEVICES
MODEM ELIMINATOR - EQUIPMENT WHICH CONNECTS TWO SYNCHRONOUS DEVICES USING A CABLE RATHER THAN TELEPHONE VOICE LINES THE ELIMINATOR HAS A CLOCK FOR TIMING.
DDCMP PROTOCOL - DEC'S COMMUNICATION LINE PROTOCOL
UUT - UNIT UNDER TEST
PTABLE - A TABLE OF INFORMATION, WITH ENTRIES FOR EACH UNIT UNDER TEST, THAT DESCRIBES THE HARDWARE (BUS ADDRESS, VECTOR, ETC.)
DUP - SINGLE LINE, SYNCHRONOUS COMMUNICATION INTERFACE
DZ - EIGHT LINE, MULTIPLEXED, SYNCHRONOUS COMMUNICATION INTERFACE
DV - SIXTEEN LINE, MULTIPLEXED, SYNCHRONOUS COMMUNICATION INTERFACE.
CRC CHECKSUM - CHECKSUM USED IN DEC NETWORK PROTOCOL (CYCLIC REDUNDANCY CHECK)
MICRODIAGNOSTIC - THE MICROCODE IN THE VT62 THAT PERFORMS THE DIAGNOSTIC CHECKOUT OF THE HARDWARE (ALSO KNOWN AS "SELF TEST")
SELF TEST - SEE "MICRODIAGNOSTIC"

1 3 DESIGN NOTES
THIS PROGRAM WAS DESIGNED AND IMPLEMENTED USING STRUCTURED TECHNIQUES. THE PROCEDURE CAUSED THE PROGRAM TO HAVE SOME OPERATIONAL CHARACTERISTICS WHICH ARE OF INTEREST TO THE USER THESE CHARACTERISTICS ARE DISCUSSED IN THIS SECTION THIS DISCUSSION IS NOT VITAL TO LEARNING HOW TO OPERATE THE PROGRAM HOWEVER

THE MOST IMPORTANT OPERATIONAL CHARACTERISTIC OF STRUCTURED DESIGN ,AS IT AFFECTS THE USER, IS HOW ERRORS ARE REPORTED THE TOP-DOWN DESIGN OF THE PROGRAM RESULTS IN A BOTTOM-UP REPORT OF ERROR INFORMATION. SEVERAL LINES OF ERROR INFORMATION ARE PRINTED AS EACH PROGRAM SECTION REPORTS ITS LEVEL OF INFORMATION AN EXAMPLE OF THIS TYPE OF ERROR LOG WOULD BE A DUP ERROR THE FIRST ERROR MESSAGE WOULD GIVE SPECIFIC DEVICE INFORMATION SUCH AS REGISTER CONTENTS AND THEN RETURN CONTROL TO THE NEXT LEVEL AT THE NEXT LEVEL, THE LOGICAL DEVICE NUMBER OR DEVICE SERIAL NUMBER WOULD BE REPORTED AT THE LEVEL ABOVE THAT, STILL MORE GENERAL INFORMATION WOULD BE GIVEN THE REPORTS CONTINUE UNTIL THE HIGHEST LEVEL IS REACHED

140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193

COMMENT FIELDS IN THE LISTING WITH SQUARE BRACKETS () REFER TO FUNCTIONAL BLOCKS IN THE DESIGN AND HAVE NO SIGNIFICANCE TO THE USER THEY ARE RETAINED FOR USE BY PROGRAM MAINTAINERS.

1 4

DDCMP

THIS SECTION GIVES A VERY BRIEF DESCRIPTION OF DDCMP AS USED BY THIS DIAGNOSTIC. THE DESCRIPTION IS BY NO MEANS COMPLETE; IT IS INTENDED TO HELP THE USER UNDERSTAND ERROR REPORTS.

THERE ARE THREE TYPES OF DDCMP MESSAGES: CONTROL, DATA AND BOOTSTRAP. THE BOOTSTRAP MESSAGE IS NOT USED BY THIS DIAGNOSTIC. THE DATA MESSAGES CONSIST OF A 6-BYTE HEADER, A 2-BYTE CRC FOR THE HEADER, THE DATA ITSELF AND A 2-BYTE CRC FOR THE DATA. CONTROL MESSAGES CONSIST OF THE HEADER (AND ITS CRC) ONLY. ALL CONTROL MESSAGES HAVE AN "ENQ" CHARACTER AS THE FIRST BYTE. ALL DATA MESSAGES ARE NUMBERED SO THAT EACH STATION ON THE LINK CAN KEEP TRACK OF WHICH MESSAGES ARE TRANSMITTED PROPERLY. ALL MESSAGES HAVE A STATION ADDRESS IN THE HEADER SO THAT MESSAGES ARE DIRECTED TO AND FROM THE PROPER STATIONS ON A MULTIDROP LINE.

THERE ARE FOUR CONTROL MESSAGES USED BY THIS DIAGNOSTIC: ACK, NAK, STRT AND STACK. ACK IS AN ACKNOWLEDGEMENT THAT THE LAST MESSAGE SENT WAS PROPERLY RECEIVED. NORMALLY, MESSAGES ARE ACKNOWLEDGED BY SENDING A DATA MESSAGE WITH THE NUMBER OF THE LAST MESSAGE IN THE HEADER. ACK'S ARE USED WHEN THERE IS NO DATA MESSAGE TO SEND BACK. NAK IS A NEGATIVE ACKNOWLEDGEMENT FOR THE LAST MESSAGE SENT AND INDICATES THE REASON FOR THE ERROR. STRT IS USED TO INITIATE COMMUNICATION BETWEEN TWO STATIONS. THE RECEIVING STATION SETS ITSELF UP AND ACKNOWLEDGES THE STRT WITH A STACK, OR START ACKNOWLEDGE. THE STRT-STACK SEQUENCE IS USED BEFORE AND AFTER EACH TEST. ALL MESSAGES ARE REQUIRED TO BE ACKNOWLEDGED WITH EITHER A DATA MESSAGE OR AN ACK.

2 0

EQUIPMENT REQUIREMENTS

THIS PROGRAM REQUIRES A PDP-11 WITH A MINIMUM OF 16K CORE AND A CONSOLE TERMINAL. A CLOCK OPTION IS NOT REQUIRED, BUT ONLY ROUGH TIMING IS AVAILABLE WITHOUT ONE. THE PDP-11 CONSOLE SWITCH REGISTER IS NOT USED. ONE OR MORE DUP-11'S MUST BE CONNECTED TO THE TERMINALS UNDER TEST VIA COMMUNICATION LINES THROUGH EITHER MODEM'S OR MODEM ELIMINATORS. THE VT62'S MUST BE IN SYNCHRONOUS MODE AND ON-LINE. THE TERMINAL ADDRESS SWITCHES ON THE CONTROL BOARD MUST BE SET TO MATCH THE TERMINAL ADDRESS ASSIGNED TO THE LOGICAL UNIT (SEE SECTION 4 0).

3 0

LOADING PROCEDURE

THIS PROGRAM MAY BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER. IT MAY ALSO BE LOADED FROM PAPER TAPE OR DISK USING XXDP PROCEDURES.

4 0

STARTING AND RUNNING THE PROGRAM

THE STARTING ADDRESS FOR THE PROGRAM IS 200. THE PROGRAM WILL FIRST ASK IF A CLOCK (KW11-L OR KW11-P) IS AVAILABLE. IT WILL THEN ASK IF A LINE

195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248

PRINTER IS AVAILABLE. IF A LINE PRINTER IS SPECIFIED, THE PROGRAM WILL ASK FOR ITS ADDRESS (DEFAULT = 177514). THE PROGRAM ALSO ASKS FOR MEMORY SIZE, Q-BUS OPTION AND LINE FREQUENCY. IF NEITHER CLOCK IS SPECIFIED, THE PROGRAM WILL ASK THE USER TO TYPE TWO CHARACTERS, FIVE SECONDS APART, IN ORDER TO PROVIDE ROUGH TIMING.

THE PROGRAM WILL THEN PROMPT THE USER BY TYPING A ">". NOW THE USER MAY TYPE ONE OF SEVEN COMMANDS STA(RT), RES(TART), CON(TINUE), ZFL(AG), ADD, DRO(P) OR DIS(PLAY), WHERE THE LETTERS IN PARENTHESIS NEED NOT BE TYPED IF A TYPING MISTAKE IS MADE, THE RUBOUT KEY IS USED TO DELETE THE LAST CHARACTER(S) TYPED THE PROGRAM WILL TYPE A MESSAGE IF THE COMMAND IS INVALID EACH OF THESE COMMANDS IS EXPLAINED IN THE SECTIONS BELOW. SWITCHES ARE USED TO SET SOFTWARE FLAGS SUCH AS "LOOP ON ERROR" THE FLAGS USED BY THIS PROGRAM ARE DESCRIBED IN SECTION 4 8

4 1

START
THE START COMMAND (STA) ZEROS ALL FLAGS (PRINT ALL ERROR MESSAGES AND DO NOT LOOP WITHIN TESTS) AND INITIATES THE OPERATOR DIALOGUE AT THIS POINT, THE DEVICE TABLE (PTABLE) IS EMPTY AND THE OPERATOR MUST USE THE DIALOGUE TO DESCRIBE ALL UUT'S AS SHOWN BELOW THE NUMBERS IN SQUARE BRACKETS, , RELATE THE TYPEOUT TO THE EXPLANATION BELOW AND ARE NOT TYPED IN ACTUAL OPERATION THE PROCEDURES FOR HANDLING TYPING ERRORS ARE ALSO DESCRIBED BELOW CR REFERS TO THE RETURN KEY (CARRIAGE RETURN).

DIALOGUE

UNITS ? (DECIMAL) 1
DUP ADDRESS ? (OCTAL) NNNNNN 2
DUP VECTOR ? (OCTAL) NNN 3
DUP BUS PRIORITY ? (OCTAL) N 4
TERMINAL ADDRESS ? (OCTAL) N 5
CHANGE S W ? (Y OR N) 6
HOWMANY INITIATE TRIES BEFORE ABORT ? (OCTAL) 10 7
USE ALL ZERO'S FOR LOOPBACK DATA ? (Y OR N) Y 8

EXPLANATION

- 1 TYPE THE TOTAL NO OF UUT'S IN DECIMAL QUESTIONS 2 THROUGH 5 WILL BE REPEATED UNTIL ALL UUT'S HAVE BEEN DESCRIBED. THE USER DOES NOT HAVE TO ANSWER THESE QUESTIONS FOR EACH DUP HOWEVER, IF THERE ARE MULTIPLE UUT'S PER DUP. THE EXPLANATION FOR QUESTION 5 SHOWS HOW TO ENTER MULTIPLE UUT'S
- 2 TYPE THE BUS ADDRESS OF THE DUP THIS MUST BE AN EVEN OCTAL NUMBER NOT GREATER THAN 177776 THE USER MAY TYPE CR TO USE

250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303

- THE DEFAULT VALUE: NNNNNN.
- 3 TYPE THE VECTOR ADDRESS FOR THE DUP THIS MUST BE AN EVEN OCTAL NUMBER NOT GREATER THAN 376. THE USER MAY TYPE CR TO USE THE DEFAULT VALUE: NNN.
- 4 TYPE THE BUS PRIORITY LEVEL OF THE DUP THIS MUST BE A DIGIT FROM 0 TO 7. AGAIN, THE USER MAY TYPE CR TO GET THE DEFAULT VALUE: N.
- 5 TYPE THE TERMINAL ADDRESS FOR EACH TERMINAL ATTACHED TO THE DUP SEPARATE EACH ADDRESS WITH A COMMA THIS IS THE ADDRESS SELECTED BY THE SWITCHES ON THE I/O BOARD IN THE TERMINAL AND IS AN OCTAL NUMBER BETWEEN 0 AND 377 THE USER MAY TYPE CR TO GET THE DEFAULT VALUE: N.
- 6 IF THE USER WISHES TO CHANGE EITHER OF THE TWO SOFTWARE PARAMETERS DESCRIBED FOR QUESTIONS 7 OR 8, HE MUST ANSWER THIS QUESTION BY TYPING "Y". IF THE USER WISHES TO BYPASS QUESTIONS 7 AND 8, HE TYPES "N".
- 7 TYPE THE NUMBER OF TIMES THE PROGRAM IS TO ATTEMPT TO INITIALIZE A DUP BEFORE ABORTING THE UNIT THE USER MAY TYPE ANY OCTAL NUMBER BETWEEN 0 AND 177777 TYPE CR TO DEFAULT TO 10 (OCTAL) ATTEMPTS
- 8 IF THE USER TYPES "Y", THE LOOPBACK DATA WILL BE 255 ZERO BYTES. IF THE USER TYPES "N", THE LOOPBACK DATA WILL BE A PATTERN OF ALTERNATING 1 AND 0 BITS SEE SECTION 8 2 FOR DETAILS ON THE LOOPBACK TEST

EXAMPLE OF DIALOGUE

ASSUME THE FOLLOWING HARDWARE CONFIGURATION A DUP (160000,300,3) WITH TWO TERMINALS (ADDRESSES 0 AND 1), A SECOND DUP (160010,320,3) WITH A SINGLE TERMINAL (ADDRESS 5) AND A THIRD DUP (170000,340,4) WITH TWO TERMINALS (ADDRESSES 1 AND 2) THE USER WOULD USE THE FOLLOWING DIALOGUE TO SET UP THE PROGRAM

>STA
UNITS ? (DECIMAL) 5
DUP ADDRESS. ? (OCTAL) 160000
DUP VECTOR. ? (OCTAL) 310 300
DUP BUS PRIORITY. ? (OCTAL) 4 3
TERMINAL ADDRESS ? (OCTAL) 0 0,1
DUP ADDRESS. ? (OCTAL) 160000 160010
DUP VECTOR ? (OCTAL) 300 320
DUP BUS PRIORITY ? (OCTAL) 3
TERMINAL ADDRESS ? (OCTAL) 1 5

305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358

DUP ADDRESS ? (OCTAL) 160010 170000
DUP VECTOR ? (OCTAL) 320 340
DUP BUS PRIORITY ? (OCTAL) 3 5
TERMINAL ADDRESS ? (OCTAL) 5 1,2
CHANGE S W. ? (Y OR N) N

(NOTE WHERE CR WAS USED TO ACCEPT THE DEFAULT)

TYPING ERRORS

- (1) THE RUBOUT KEY IS USED TO DELETE ANY CHARACTERS WHICH ARE IN ERROR
- (2) IF THE RESPONSE IS NOT WITHIN LIMITS OR IS IN THE WRONG FORMAT, THE PROGRAM WILL NOTIFY THE USER AND ASK THE QUESTION AGAIN
- (3) WHEN ENTERING MULTIPLE TERMINAL ADDRESSES FOR A SINGLE DUP, THE USER MAY NEGLECT TO TYPE ONE OR MORE ADDRESSES IN SUCH A CASE, THE USER MERELY ENTERS THE SAME DUP ADDRESS, VECTOR AND PRIORITY IN THE NEXT SERIES OF QUESTIONS AND THEN ENTERS THE REMAINING TERMINAL ADDRESSES REMEMBER, THE SERIES OF QUESTIONS (2 THROUGH 5) WILL BE RE-ASKED UNTIL ALL UUT'S HAVE BEEN ACCOUNTED FOR

4 2

RESTART

THE RESTART COMMAND (RES) STARTS THE PROGRAM WITHOUT CLEARING THE PTABLE ALL FLAGS REVERT TO THEIR INITIAL STATE UNLESS THE FLAG SWITCH IS USED TO CHANGE THEM (SECTION 4 8) THE OPERATOR DIALOGUE DESCRIBED IN 4 1 DOES NOT TAKE PLACE UNLESS REQUESTED WHEN THIS COMMAND IS USED, THE PROGRAM WILL ASK IF THE USER WISHES TO CHANGE THE HARDWARE TABLE AND IF HE WISHES TO CHANGE THE SOFTWARE TABLE IF THE USER ANSWERS YES (BY TYPING "Y") TO THE HARDWARE TABLE QUESTION, THAT PORTION OF THE DIALOGUE DESCRIBED IN SECTION 4.1 BEGINNING WITH QUESTION 1 ENDING WITH QUESTION 5 WILL TAKE PLACE IF THE USER ANSWERS YES TO THE SOFTWARE TABLE QUESTION, HE WILL BE ASKED QUESTIONS 7 AND 8

THE MOST COMMON USE OF THIS COMMAND IS TO CHANGE RUN-TIME FLAGS OR TO ADD/DROP UNITS THESE FLAGS ARE DESCRIBED IN SECTION 4 8 - SWITCH OPTIONS TYPING A " C" WILL FORCE THE SUPERVISOR TO ISSUE A PROMPT CHARACTER (">") SO THAT THE USER MAY USE THE RESTART COMMAND FOR THIS PURPOSE NOTE IF THE USER USES THE START COMMAND AFTER A C, HE WILL HAVE TO REENTER ALL DEVICE INFORMATION!

4 3

CONTINUE

THE CONTINUE COMMAND WILL RESTART THE PROGRAM AT THE TEST WHICH WAS INTERRUPTED UNLIKE THE RESTART COMMAND, THIS COMMAND DOES NOT FORCE FLAGS BACK TO THE INITIAL STATE THE FLAGS WILL REMAIN AS SET UP DURING THE LAST START OR RESTART THE USER HAS THE SAME DIALOGUE AND FLAG

360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413

OPTIONS AS DESCRIBED FOR THE RESTART COMMAND.

- 4 4 ZERO FLAGS
THIS COMMAND WILL ZERO ALL FLAGS (SECTION 4.8) AND TYPE A PROMPT
SECTION 4.8 DESCRIBES THE EFFECTS OF CLEARING ALL FLAGS, BUT ESSENTIALLY,
ALL LOOPING AND HALTS WILL BE DISABLED AND ALL ERROR INFORMATION WILL BE
PRINTED IN THE EVENT OF AN ERROR.
- 4 5 ADD UNITS
WHILE TESTING MULTIPLE UNITS, THE USER MAY WISH TO DROP A PARTICULAR UNIT
FROM THE TEST PROCEDURE AND, LATER ON, BEGIN TESTING THAT UNIT AGAIN. IN
THIS CASE, THE USER NEED NOT STOP THE DIAGNOSTIC AND REBUILD THE PTABLE.
AFTER A UNIT HAS BEEN DROPPED (SEE SECTION 4.6), THE USER MAY ADD THE
UNIT BY TYPING "C" AND USING THE ADD COMMAND AS FOLLOWS.
ADD/UNI.N
WHERE N IS A DECIMAL UNIT NUMBER THAT SPECIFIES THE UNIT TO BE ADDED
UNITS ARE NUMBERED FROM 1 TO 32 ACCORDING TO THE ORDER IN WHICH THEY WERE
SPECIFIED FOR THE HARDWARE TABLE MULTIPLE UNITS MAY BE ADDED BY TYPING
EACH UNIT NUMBER SEPARATED BY COLONS (I.E., ADD/UNI 2 4 22) OR BY TYPING
THE FIRST AND LAST UNIT NUMBERS OF A CONTIGUOUS GROUP OF UNITS SEPARATED
BY A DASH (I.E., ADD/UNI 1-10 WILL ADD THE FIRST TEN UNITS). NOTE
AFTER A START COMMAND, ALL UNITS ARE CONSIDERED ADDED THERE IS NO NEED
TO USE THE ADD COMMAND UNLESS THE UNIT WAS DROPPED
- 4 6 DROP UNITS
TO REMOVE A UNIT FROM TESTING, THE DROP COMMAND (DRO) IS USED TO USE
THIS COMMAND, TYPE "C" AND DROP THE UNIT(S) USING THE DROP COMMAND AS
FOLLOWS
DRO/UNI N
WHERE "N" IS A DECIMAL UNIT NUMBER WHICH SPECIFIES THE UNIT TO BE
DROPPED UNITS ARE NUMBERED FROM 1 TO 32 ACCORDING TO THE ORDER IN WHICH
THEY WERE SPECIFIED FOR THE HARDWARE TABLE MULTIPLE UNITS MAY BE
DROPPED BY TYPING EACH UNIT NUMBER SEPARATED BY COLONS (I.E.,
DRO/UNI 1 3 7) OR BY TYPING THE FIRST AND LAST UNIT NUMBERS OF A
CONTIGUOUS GROUP SEPARATED BY A DASH (I.E., DRO/UNI 1-9 CAUSES THE FIRST
NINE UNITS TO BE DROPPED) AFTER THE PROGRAM IS RESTARTED, THE SPECIFIED
UNIT(S) WILL NOT BE INCLUDED FOR TESTING
- 4 7 DISPLAY PTABLE
WHEN THE DISPLAY COMMAND IS TYPED, THE ENTIRE CONTENTS OF THE PTABLE WILL
BE PRINTED UNITS THAT HAVE BEEN DROPPED WILL BE SO MARKED THIS
COMMAND IS USEFUL FOR VERIFYING THE PTABLE CONTENTS
- 4 8 SWITCH OPTIONS
THERE ARE THREE SWITCH OPTIONS AVAILABLE FOR USE WITH THE COMMANDS
/TES, /PAS AND /FLA THE TEST SWITCH, /TES, IS USED ONLY WITH THE
START COMMAND AND THE PESTART COMMAND IT IS USED TO SPECIFY THE
INDIVIDUAL TEST(S) TO BE RUN IN CASES WHERE ALL TESTS ARE NOT TO BE RUN
FOR EXAMPLE, IF THE USER WISHED TO RUN THE LOOPBACK TEST ONLY, HE WOULD
TYPE

>STA/TES 2

415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468

IF THIS SWITCH IS NOT USED, ALL TESTS WILL BE RUN AS THE DEFAULT CONDITION.

THE PASS SWITCH IS USED TO SPECIFY THE NUMBER OF PASSES TO BE RUN TO RUN THE LOOPBACK TEST TWENTY TIMES, THE USER WOULD TYPE
>STA/TES 2/PAS: 20

THIS SWITCH MAY BE USED WITH THE START, RESTART AND CONTINUE COMMANDS THE DEFAULT CONDITION IS ESSENTIALLY AN INFINITE NUMBER OF PASSES

THE FLAG SWITCH IS USED TO SET FLAGS WHICH CONTROL PROGRAM OPERATION AND ERROR PRINTOUTS THIS SWITCH MAY BE USED WITH THE CONTINUE COMMAND AS WELL AS THE START COMMAND AND RESTART COMMAND THE AVAILABLE FLAGS ARE SHOWN IN THE TABLE BELOW

| FLAG | EFFECT IF SET |
|------|--|
| LOE | LOOP ON ERROR |
| HLT | HALT ON ERROR |
| IER | INHIBIT ERROR REPORTS |
| IBE | INHIBIT BASIC ERROR REPORT* |
| IXE | INHIBIT EXTENDED ERROR REPORT* |
| PRI | SEND ALL TYPEOUTS TO THE PRINTER |
| BOE | BELL ON ERROR |
| UAM | UNATTENDED MODE (NO MANUAL INTERVENTION) |
| PNT | PRINT TEST NUMBER |

*SEE SECTION 5 0

EXAMPLE

IF THE USER WISHES TO RUN THE PROGRAM WITHOUT ERROR MESSAGES AND HAVE IT LOOP ON ERROR, HE WOULD TYPE
>RES/FLA LOE IER

EXAMPLE

IF THE USER LATER WANTED TO STOP THE LOOP ON ERROR FEATURE, HE WOULD TYPE
>CON/FLA LOE=0

NOTE THE ERROR REPORTS WOULD STILL BE INHIBITED

ALL FLAGS ARE DEFAULTED TO ZERO (NOT SET)

5 0

ERROR AND INFORMATIONAL MESSAGES

AS NOTED IN THE DESIGN NOTES (SECTION 1 3), A SINGLE ERROR MAY RESULT IN SEVERAL MESSAGES BEING TYPED. THIS IS DUE TO THE STRUCTURE OF THE PROGRAM EACH SECTION, IN THE EVENT OF AN ERROR, REPORTS THE INFORMATION AVAILABLE TO IT. THE FINAL MESSAGE FOR EACH ERROR CONTAINS THE UNIT NUMBER (DECIMAL - 1 TO 32 - SEE SECTIONS 4 5 AND 4 6) AND THE PHRASE "END OF ERROR REPORT"

THERE ARE THREE LEVELS OF ERROR REPORTS BY USING THE FLAG SWITCHES (SECTION 4.8), ONE OR MORE LEVELS OF REPORT MAY BE INHIBITED THE FIRST LEVEL CONSISTS OF AN ERROR NUMBER, PC CONTENTS AND ERROR TYPE (HARD, SOFT OR FATAL) THE ERROR NUMBER CAN BE RELATED TO THE TABLE AT THE END OF

470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523

THIS SECTION. THE PC CONTENTS GIVE THE ADDRESS WHERE THE ERROR REPORT MECHANISM WAS INVOKED. THE NEXT LEVEL (BASIC ERROR REPORT) GIVES AN ENGLISH DESCRIPTION OF THE ERROR. AN EXAMPLE OF THIS TYPE OF MESSAGE IS "HEADER HAS CRC ERROR". THE FINAL LEVEL (EXTENDED ERROR REPORT) GIVES ADDITIONAL DATA CONCERNING THE ERROR, SUCH AS REGISTER CONTENTS.

TO INHIBIT SOME OR ALL ERROR MESSAGES, USE THE FLAGS DESCRIBED IN SECTION 4 8 THE INHIBIT-EXTENDED-ERROR-REPORT FLAG (IXE) INHIBITS THAT LEVEL ONLY THE INHIBIT-BASIC-ERROR-REPORT FLAG (IBE) INHIBITS BOTH BASIC AND EXTENDED ERROR REPORTS. FINALLY, THE INHIBIT-ERROR-REPORT FLAG (IER)) INHIBITS ALL TYPEOUTS

TABLE OF ERROR NUMBERS

| NO | ERROR DESCRIPTION |
|----|---|
| 00 | CANNOT INITIALIZE DUP |
| 01 | REPLY MESSAGE FROM TERM. WAS NOT AN ENQ |
| 02 | REPLY FROM TERM. WAS NOT EXPECTED TYPE OF CONTROL MESSAGE |
| 03 | TERM. ADDRESS IN RESPONSE WAS NOT CORRECT |
| 04 | RESPONSE HAD CRC ERROR IN THE HEADER |
| 20 | DUP TRANSMIT ERROR |
| 21 | DUP RECEIVE ERROR |
| 22 | MESSAGE TO TERMINAL WAS NOT ACK'ED |
| 23 | ERROR OCCURED WHILE INITIATING DUP |
| 24 | ERROR OCCURED DURING TRANSMISSION |
| 25 | DDCMP STRT MESSAGE DID NOT GET A STACK |
| 26 | ERROR DURING RECEPTION |
| 30 | CANNOT GET CLEAR TO SEND SIGNAL |
| 31 | TIMEOUT WHILE WAITING FOR RESPONSE |
| 40 | SEE 21 |
| 41 | SEE 04 |
| 42 | SEE 03 |
| 43 | MESSAGE DATA HAD CRC ERROR |
| 50 | ERROR OCCURED DURING SELFTEST (TEST #1) |
| 51 | ERROR OCCURED DURING LOOPBACK (TEST #2) |
| 52 | ERROR IN RECEIVED DATA |
| 70 | SELFTEST RESPONSE IN ERROR (NOT RECOGNIZED) |
| 71 | TERMINAL MEMORY ERROR |
| 72 | TERMINAL CONTROL-ROM ERROR |

6 0 RESTRICTIONS
THIS DIAGNOSTIC DOES NOT ATTEMPT TO TEST THE DUP11 IF A LARGE NUMBER OF COMM ERRORS OCCUR, OR IF ATTEMPTS TO SEND OR RECIEVE DATA TO AND FROM THE TERMINAL FAIL. USE THE SPECIFIC DUP11 DIAGNOSTICS TO VERIFY THE DUP11

7 0 MISCELLANEOUS
PLEASE REPORT ALL PROGRAM PROBLEMS VIA THE AIDS REPORTING SYSTEM. REFER ALL COMMENTS REGARDING DOCUMENTATION TO THE DIAGNOSTIC ENGINEERING

525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567

TERMINAL GROUP IN MAYNARD, MASS.

- 8 0 TEST DESCRIPTIONS
- 8 1 MICRODIAGNOSTIC (TEST #1)
THE MICRODIAGNOSTIC, OR SELFTEST, IS ROM RESIDENT CODE IN THE VT62 THAT IS EXECUTED UPON COMMAND FROM THE HOST COMPUTER OR DURING POWER UP. A FULL DESCRIPTION OF THE TEST IS AVAILABLE IN THE HARDWARE MANUAL FOR THE VT62. ESSENTIALLY, THE TEST VERIFIES THE MICROPROCESSOR, CHECKS ROM MEMORY, EXERCISES RAM MEMORY AND EXERCISES THE SCREEN. THE HOST MAY REQUEST THE RESULTS OF THE TEST. IN ANY CASE, THE RESULTS ARE ALWAYS DISPLAYED ON THE LAST LINE OF THE SCREEN. THE FIRST CHARACTERS ARE A CODED ERROR REPORT FOR THE HOST COMPUTER AND THE REMAINDER OF THE LINE IS AN ENGLISH DESCRIPTION OF THE ERROR STATUS.
- 8 2 LOOPBACK (TEST #2)
IN THIS TEST, THE TERMINAL IS COMMANDED TO ENTER LOOPBACK MODE AND A SINGLE, 256(DECIMAL) BYTE DATA MESSAGE IS SENT TO THE TERMINAL. THIS DATA MESSAGE WILL HAVE A DDCMP PROTOCOL ENVELOPE. LOOPBACK DATA IS DISPLAYED ON THE VT62'S SCREEN. WHEN THE DATA IS RETURNED, THE TERMINAL IS TAKEN OUT OF LOOPBACK MODE USING A DDCMP "STRT" SEQUENCE. THE CRC CHECKSUMS ARE VALIDATED FOR BOTH THE MESSAGE HEADER AND THE MESSAGE DATA. THE DATA IS THEN CHECKED, BYTE BY BYTE. THUS THERE ARE THREE POSSIBLE ERRORS DETECTED. NO TERMINAL RESPONSE, BAD CRC OR BAD DATA.
- INTERPRETATION OF ANY ERROR MESSAGES REQUIRES SOME EDUCATED GUESSWORK BECAUSE OF THE NUMBER OF COMPONENTS IN THE COMMUNICATION LINK. INTERMITTENT ERRORS WOULD GENERALLY INDICATE LINE PROBLEMS UNLESS THE LINE IS PHYSICALLY SHORT OR THE ENVIRONMENT IS RELATIVELY NOISE FREE. IF EITHER OF THESE CONDITIONS IS THE CASE OR IF THE ERROR IS NOT INTERMITTENT, THEN THE TERMINAL I/O BOARD, THE MODEM AND THE DUP ARE SUSPECT. IF THERE IS NO TERMINAL RESPONSE, RUN THE TERMINAL SELF TEST OFF-LINE. THIS WILL SHOW WHETHER THE TERMINAL IS COMPLETELY "DEAD" OR THE PORTIONS OF THE COMMUNICATION LINK MENTIONED ABOVE ARE BROKEN.
- THERE ARE TWO DATA PATTERNS AVAILABLE FOR LOOPBACK: ALL ZERO'S AND ALTERNATING 1/0 BITS (I.E., BYTES OF 252,125,252,125, . . .) THE ZERO PATTERN IS NOISE-SUSCEPTIBLE, BUT APPEARS ON THE SCREEN AS NULLS. HOWEVER THE ALTERNATING BITS PATTERN EXERCISES THE DATA PATHS BETTER. SECTION 4 0 SPECIFIES HOW TO SELECT THE PATTERN.

569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609

9 0

INDEX

| | |
|------------------|----------|
| ACK | 5, 11 |
| ADD COMMAND | 9 |
| CONTINUE COMMAND | 8, 10 |
| CRC | 4-5, 11 |
| DDCMP | 4-5 |
| DISPLAY COMMAND | 9 |
| DROP COMMAND | 9 |
| END | 5, 11 |
| ERROR NUMBER | 10-11 |
| ERROR REPORT | 10-11 |
| FLAGS | 6, 8-10 |
| LOOPBACK | 7, 11-12 |
| MULTIPLE UNITS | 9 |
| MULTIPLE UUT'S | 6 |
| NAK | 5 |
| PTABLE | 4, 6, 9 |
| RESTART COMMAND | 8-10 |
| STACK | 5, 11 |
| START COMMAND | 6, 8-10 |
| STRT | 5, 11 |
| SWITCH OPTIONS | 8-9 |
| SWITCHES | 6 |
| UNIT NUMBER | 9-10 |

ENDR

| | | |
|------|--------|-------------------------------|
| 5712 | 002000 | =2000 |
| 5713 | | |
| 5714 | | HEADER - VT62 ACCEPTANCE TEST |
| 5715 | | |
| 5725 | 002000 | ASCII 202 |
| (5) | 002001 | ASCII 222 |
| (5) | 002002 | ASCII 202 |
| (5) | 002003 | ASCII 2P2 |
| (5) | 002004 | ASCII 2G2 |
| (6) | 002005 | BYTE 0 |
| (6) | 002006 | BYTE 0 |
| (5) | 002007 | BYTE 0 |
| (4) | 002010 | ASCII 2A2 |
| (4) | 002011 | ASCII 202 |
| (4) | 002012 | BYTE C\$REVISION |
| (4) | 002013 | BYTE C\$EDIT |
| (4) | 002014 | WORD 0 |
| (4) | 002016 | WORD 0 |
| (4) | 002020 | WORD 0 |
| (4) | 002022 | WORD 0 |
| (4) | 002024 | WORD 0 |
| (5) | 002026 | WORD 0 |
| (4) | 002030 | WORD 0 |
| (4) | 002032 | WORD 0 |
| (4) | 002034 | WORD 0 |
| (4) | 002036 | WORD 0 |
| (4) | 002040 | WORD L\$DISPATCH |
| (4) | 002042 | WORD L\$INIT |
| (4) | 002044 | WORD L\$CLEAN |
| (4) | 002046 | WORD L\$HARD |
| (4) | 002050 | WORD L\$SOFT |
| (4) | 002052 | WORD L\$DVTYP |
| (4) | 002054 | WORD L\$RPT |
| (4) | 002056 | WORD L\$HW |
| (4) | 002060 | WORD L\$SW |
| (4) | 002062 | WORD L\$DR |
| (4) | 002064 | WORD L\$DRST |
| (4) | 002066 | WORD 0 |
| (4) | 002070 | WORD L\$AU |
| (4) | 002072 | WORD L\$DU |
| (4) | 002074 | WORD 0 |
| (4) | 002076 | WORD L\$LAST |

```
5745 ;*****
5746 ; GLOBAL EQUATES *
5747 ;*****
5748 ;
(1) ; BIT DIFINITIONS
(1) ;
(1) 100000 BIT15== 100000
(1) 040000 BIT14== 40000
(1) 020000 BIT13== 20000
(1) 010000 BIT12== 10000
(1) 004000 BIT11== 4000
(1) 002000 BIT10== 2000
(1) 001000 BIT09== 1000
(1) 000400 BIT08== 400
(1) 000200 BIT07== 200
(1) 000100 BIT06== 100
(1) 000040 BIT05== 40
(1) 000020 BIT04== 20
(1) 000010 BIT03== 10
(1) 000004 BIT02== 4
(1) 000002 BIT01== 2
(1) 000001 BIT00== 1
(1) ;
(1) 001000 BIT9== BIT09
(1) 000400 BIT8== BIT08
(1) 000200 BIT7== BIT07
(1) 000100 BIT6== BIT06
(1) 000040 BIT5== BIT05
(1) 000020 BIT4== BIT04
(1) 000010 BIT3== BIT03
(1) 000004 BIT2== BIT02
(1) 000002 BIT1== BIT01
(1) 000001 BIT0== BIT00
(1) ;
(1) ; EVENT FLAG DEFINITIONS
(1) ; EF32 EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
(1) ; EF16 EF01 AVAILABLE FOR PPROGRAM USE
(1) ;
(1) 000040 EF START== 32 ; START COMMAND WAS ISSUED
(1) 000037 EF RESTART== 31 ; RESTART COMMAND WAS ISSUED
(1) 000036 EF CONTINUE== 30 ; CONTINUE COMMAND WAS ISSUED
(1) 000035 EF NEW== 29 ; A NEW PASS HAS BEEN STARTED
(1) 000034 EF PWR== 28 ; A POWER-FAIL/POWER-UP OCCURRED
(1) ;
(1) 000020 EF16== 16
(1) 000017 EF15== 15
(1) 000016 EF14== 14
(1) 000015 EF13== 13
(1) 000014 EF12== 12
(1) 000013 EF11== 11
(1) 000012 EF10== 10
(1) 000011 EF09== 9
(1) 000010 EF08== 8
(1) 000007 EF07== 7
(1) 000006 EF06== 6
(1) 000005 EF05== 5
```

```
(1) 000004 EFO4== 4
(1) 000003 EFO3== 3
(1) 000002 EFO2== 2
(1) 000001 EFO1== 1
(1) ;
(1) ; PRIORITY LEVEL DEFINITIONS
(1) ;
(1) 000340 PRI07== 340
(1) 000300 PRI06== 300
(1) 000240 PRI05== 240
(1) 000200 PRI04== 200
(1) 000140 PRI03== 140
(1) 000100 PRI02== 100
(1) 000040 PRI01== 40
(1) 000000 PRI00== 0

5749
5750 ;
5751 ; VT62 DIAGNOSTIC EQUATES
5752 ;
5753 000201 SOH=201 ; START OF HEADER (DDCMP)
5754 000001 ACK=1 ; ACKNOWLEDGE ""
5755 000002 NAK=2 ; NEGATIVE ACKNOWLEDGE ""
5756 000003 REP=3 ; REPLY ""
5757 000005 ENQ=5 ; ENQUIRY ""
5758 000006 STRT=6 ; START ""
5759 000007 STACK=7 ; START ACKNOWLEDGE ""
5761 000226 SYNC=226 ; SYNCHRONIZATION CHARACTER
5766 000220 DLE=220 ; DATA LINK ESCAPE
5767 000024 OSOP=24 ; LOOPBACK.
5768 000200 PARITY=200 ; PARITY BIT
5776 000002 TSTS=2 ; NO OF TESTS
5782 000000 RCVCSR=0 ; OFFSETS RECEIVER CSR
5783 000002 RCVBUF=2 ; RECEIVER BUFFER REG
5784 000004 XMTCSR=4 ; TRANSMITTER CSR
5785 000006 XMTBUF=6 ; TRANSMITTER BUFFER REG

5787
5789 ; HARDWARE REGISTER BIT DEFINITIONS
5790 000400 TSOM=400 ; TRANSMIT, START OF MESSAGE
5791 000002 DTR=2 ; DATA TERMINAL READY
5792 000400 MASCLR=400 ; MASTER CLEAR
5793 101226 PARAM=101226 ; PARAM. REG. - DEC MODE, AUTO-CRC INHIB AND SYNC
5794 000004 RTS=4 ; REQUEST TO SEND
5795 020000 CTS=20000 ; CLEAR TO SEND
5796 000100 TXINTE=100 ; TRANSMIT INTERRUPT ENABLE
5797 000020 SENDFD=20 ; SEND -- FULL DUX
5798 000120 RXINTE=120 ; RECEIVE INTERRUPT ENABLE
5799 000020 RCENBL=20 ; RECEIVER ENABLE
5865 177400 HYBYTE=177400 ; MASK FOR HIGH BYTE OF A WORD
5866 000377 LOBYTE=377 ; MASK FOR LOW BYTE OF A WORD
```

```

5887 , *****
5888 , GLOBAL DATA *
5889 , *****
5890 002100 000000 RSSTCK 0 , FLAG TO INDICATE IF R5 STACK IS SET UP
5891 002102 000000 SCRATCH 0 , SCRATCH LOCATIONS
5892 002104 000000 TEMP 0
5893 002106 000000 ABORT 0 , TEST ABORT FLAG
5894 002110 020000 TIMLIM 20000 , TIMEOUT LIMIT (IN 100 MICROSEC INCREMENTS)
5895 002112 000000 STIME 0 , SHORT TIMEOUT LIMIT (APPROX 20 MICROSEC INCREM )
5896 002114 000010 ILIMIT 10 , LIMIT ON DEVICE INITIALIZATION ATTEMPTS
5897 002116 000000 INERR 0 , INPUT ERROR
5898 002120 000000 OUTERR 0 , OUTPUT ERROR
5899 002122 000001 PASCNT 1
5900 002124 000000 EOMSG 0 , END_OF_MESSAGES FLAG
5901 002126 000000 LOGDEV 0 , LOGICAL DEVICE NUMBER
5905 002130 000000 EXPINP 0 , EXPECT_INPUT FLAG
5906 002132 000000 OUTMSG 0 , OUTPUT MESSAGE POINTER AND SIZE
5907 002134 000000
5908 002136 000000 INMSG 0 , INPUT MESSAGE POINTER AND SIZE
5909 002140 000000
5910 002142 000000 OUTBUF 0 , OUTPUT BUFFER POINTER AND SIZE
5911 002144 000000 OUSIZ 0
5912 002146 000000 INBUF 0 , INPUT BUFFER POINTER AND SIZE
5913 002150 000000 INSIZ 0
5914
5915 002152 MSGAP
5916 002152 000000 OUT 0 , TEST MESSAGE AREA POINTER
5917 002154 000000 INITMA 0 , TEMPORARY MESSAGE POINTER AND SIZE
5918 002156 000000 INITMS 0 , USED FOR INITIALIZATION OF OUTPUT ROUTINES
5919 002160 000000 BAPNT 0 , GENERAL BUFFER AREA POINTER AND SIZE
5920 002162 000000 BASIZE 0
5921 002164 000000 MSGNO 0 , MESSAGE NUMBER (DDCMP)
5922 002166 000000 RMSGNO 0
5929 002170 000000 PTABLE 0 , PRESENT UNIT PTABLE DATA
5930 002172 000000
5931 002174 000000
5932 002176 000000
5936 002200 PTEND
5937 002200 000000 DEVPRI 0 , DEVICE PRIORITY
5949
5951 (3) 002202 052126 031066 042054 , ASCII 2VT62, DUP112
(2) 002210 050125 030461 000
5952 (6) 002216 000001 , EVEN
(4) 002220 000017 , WORD 17
(2) 002224 000004 , WORD 4
, BLKW 4
  
```

```
5963 ,*****
5964 ; GLOBAL TEXT *
5965 ,*****
5966
5967 002234 040503 020116 047516 MSG00 .ASCIZ /CAN NOT INITIALIZE COMM DEVICE/
      002242 020124 047111 052111
      002250 040511 044514 042532
      002256 041440 046517 020115
      002264 042504 044526 042503
      002272 000
5968 002273 122 050105 054514 MSG01 .ASCIZ /REPLY WAS NOT AN ENQ/
      002300 053440 051501 047040
      002306 052117 040440 020116
      002314 047105 000121
5969 002320 047111 047503 051122 MSG02 .ASCIZ /INCORPECT REPLY TYPE/
      002326 041505 020124 042522
      002334 046120 020131 054524
      002342 042520 000
5970 002345 MSG42
5971 002345 122 050105 054514 MSG03 .ASCIZ /REPLY HAS INCORRECT STATION ADDRESS/
      002352 044040 051501 044440
      002360 041516 051117 042522
      002366 052103 051440 040524
      002374 044524 047117 040440
      002402 042104 042522 051523
      002410 000
5972 002411 MSG41
5973 002411 110 040505 042504 MSG04 .ASCIZ /HEADER HAS CPC ERROR/
      002416 020122 040510 020123
      002424 051103 020103 051105
      002432 047522 000122
5974 002436 051105 047522 020122 MSG10 .ASCIZ /ERROR DURING KEYBOARD TEST ** END OF REPORT **/
      002444 052504 044522 043516
      002452 045440 054505 047502
      002460 051101 020104 042524
      002466 052123 020040 025052
      002474 042440 042116 047440
      002502 020106 042522 047520
      002510 052122 025040 000052
5975 002516 040502 020104 042522 MSG11 .ASCIZ /BAD RESPONSE FROM KEYBOARD
      002524 050123 047117 042523
      002532 043040 047522 020115
      002540 042513 041131 040517
      002546 042122 000
5976 002551 124 047517 046440 MSG12 .ASCIZ /TOO MANY CHARACTERS SENT FROM KEYBOARD
      002556 047101 020131 044103
      002564 051101 041501 042524
      002572 051522 051440 047105
      002600 020124 051106 046517
      002606 045440 054505 047502
      002614 051101 000104
5977 002620 051124 047101 046523 MSG20 .ASCIZ /TRANSMIT ERROR
      002626 052111 042440 051122
      002634 051117 000
5978 002637 MSG40
5979 002637 122 041505 050105 MSG21 .ASCIZ /RECEPTION ERROR
```

| | | | | | | |
|------|--------|--------|--------|--------|-------|--|
| | 002644 | 044524 | 047117 | 042440 | | |
| | 002652 | 051122 | 051117 | 000 | | |
| 5980 | 002657 | 116 | 020117 | 041501 | MSG22 | ASCIZ /NO ACK RECEIVED AFTER TRANSMISSION/ |
| | 002664 | 020113 | 042522 | 042503 | | |
| | 002672 | 053111 | 042105 | 040440 | | |
| | 002700 | 052106 | 051105 | 052040 | | |
| | 002706 | 040522 | 051516 | 044515 | | |
| | 002714 | 051523 | 047511 | 000116 | | |
| 5981 | 002722 | 051105 | 047522 | 020122 | MSG23 | ASCIZ /ERROR WHILE INITIALIZING DEVICE/ |
| | 002730 | 044127 | 046111 | 020105 | | |
| | 002736 | 047111 | 052111 | 040511 | | |
| | 002744 | 044514 | 044532 | 043516 | | |
| | 002752 | 042040 | 053105 | 041511 | | |
| | 002760 | 000105 | | | | |
| 5982 | 002762 | 051105 | 047522 | 020122 | MSG24 | ASCIZ /ERROR OCCURRED DURING TRANSMISSION/ |
| | 002770 | 041517 | 052503 | 051122 | | |
| | 002776 | 042105 | 042040 | 051125 | | |
| | 003004 | 047111 | 020107 | 051124 | | |
| | 003012 | 047101 | 046523 | 051511 | | |
| | 003020 | 044523 | 047117 | 000 | | |
| 5983 | 003025 | 116 | 020117 | 052123 | MSG25 | ASCIZ /NO STACK IN RESPONSE TO STRT/ |
| | 003032 | 041501 | 020113 | 047111 | | |
| | 003040 | 051040 | 051505 | 047520 | | |
| | 003046 | 051516 | 020105 | 047524 | | |
| | 003054 | 051440 | 051124 | 000124 | | |
| 5984 | 003062 | 051105 | 047522 | 020122 | MSG26 | ASCIZ /ERROR WHILE RECEIVING BUFFER/ |
| | 003070 | 044127 | 046111 | 020105 | | |
| | 003076 | 042522 | 042503 | 053111 | | |
| | 003104 | 047111 | 020107 | 052502 | | |
| | 003112 | 043106 | 051105 | 000 | | |
| 5985 | 003117 | 103 | 047101 | 052047 | MSG27 | ASCIZ /CAN'T GET CLEAR TO SEND/ |
| | 003124 | 043440 | 052105 | 041440 | | |
| | 003132 | 042514 | 051101 | 052040 | | |
| | 003140 | 020117 | 042523 | 042116 | | |
| | 003146 | 000 | | | | |
| 5986 | 003147 | 124 | 046511 | 020105 | MSG31 | ASCIZ /TIME OUT WHILE WAITING FOR TERMINAL RESPONSE/ |
| | 003154 | 052517 | 020124 | 044127 | | |
| | 003162 | 046111 | 020105 | 040527 | | |
| | 003170 | 052111 | 047111 | 020107 | | |
| | 003176 | 047506 | 020122 | 042524 | | |
| | 003204 | 046522 | 047111 | 046101 | | |
| | 003212 | 051040 | 051505 | 047520 | | |
| | 003220 | 051516 | 000105 | | | |
| 5987 | 003224 | 040504 | 040524 | 041440 | MSG33 | ASCIZ /DATA CRC ERROR/ |
| | 003232 | 041522 | 042440 | 051122 | | |
| | 003240 | 051117 | 000 | | | |
| 5988 | 003243 | 116 | 044517 | 042523 | MSG35 | ASCIZ /NOISE PATTERN SUBTEST/ |
| | 003250 | 050040 | 052101 | 042524 | | |
| | 003256 | 047122 | 051440 | 041125 | | |
| | 003264 | 042524 | 052123 | 000 | | |
| 5989 | 003271 | 105 | 051122 | 051117 | MSG50 | ASCIZ /ERROR DURING MICRODIAGNOSTIC/ |
| | 003276 | 042040 | 051125 | 047111 | | |
| | 003304 | 020107 | 044515 | 051103 | | |
| | 003312 | 042117 | 040511 | 047107 | | |
| | 003320 | 051517 | 044524 | 000103 | | |
| 5990 | 003326 | 051105 | 047522 | 020122 | MSG51 | ASCIZ /ERROR DURING LOOPBACK/ |

| | | | | | | |
|------|--------|--------|--------|--------|--------|------------------------------------|
| | 003334 | 052504 | 044522 | 043516 | | |
| | 003342 | 046040 | 047517 | 041120 | | |
| | 003350 | 041501 | 000113 | | | |
| 5991 | 003354 | 040504 | 040524 | 042440 | MSG52 | ASCIZ /DATA ERROR/ |
| | 003362 | 051122 | 051117 | 000 | | |
| 5992 | 003367 | 111 | 046114 | 043505 | MSG70 | ASCIZ /ILLEGAL SELF TEST RESPONSE/ |
| | 003374 | 046101 | 051440 | 046105 | | |
| | 003402 | 020106 | 042524 | 052123 | | |
| | 003410 | 051040 | 051505 | 047520 | | |
| | 003416 | 051516 | 000105 | | | |
| 5993 | 003422 | 042515 | 047515 | 054522 | MSG71 | ASCII /MEMORY ERROR TYPE / |
| | 003430 | 042440 | 051122 | 051117 | | |
| | 003436 | 020040 | 052040 | 050131 | | |
| | 003444 | 020105 | | | | |
| 5994 | 003446 | 000 | 000 | | MTY | BYTE 0,0 |
| 5995 | 003450 | 020115 | 020055 | 040502 | | ASCII /M - BANK # / |
| | 003456 | 045516 | 021440 | | | |
| 5996 | 003462 | 000 | 000 | | BNO | BYTE 3,0 |
| 5997 | | | | | | EVEN |
| 5998 | 003464 | 051103 | 046517 | 042440 | MSG72 | ASCIZ /CRUM ERROR/ |
| | 003472 | 051122 | 051117 | 000 | | |
| 5999 | | 003500 | | | | EVEN |
| 6000 | | | | | | |
| 6001 | 003500 | 005 | | | STRTB | BYTE ENQ |
| 6002 | 003501 | 006 | | | | BYTE STRT |
| 6003 | 003502 | 300 | | | | BYTE 300 |
| 6004 | 003503 | 000 | | | | BYTE 0 |
| 6005 | 003504 | 000 | | | | BYTE 0 |
| 6006 | 003505 | 000 | | | STPTSA | BYTE 0 |
| 6007 | 003506 | 000000 | | | STRTC | WORD 0 |
| 6008 | | | | | | |
| 6009 | | | | | | |
| 6010 | | | | | | |
| 6011 | | | | | | |
| 6013 | 003510 | 016746 | 176400 | | | |
| (7) | 003514 | 012746 | 003536 | | | |
| (6) | 003520 | 012746 | 000002 | | | |
| (3) | 003524 | 010600 | | | | |
| (4) | 003526 | 104015 | | | | |
| (4) | 003530 | 062706 | 000006 | | | |
| 6014 | 003534 | | | | L10000 | |
| (3) | 003534 | 104023 | | | | |
| 6015 | 003536 | 040445 | 043101 | 042524 | FORM00 | ASCIZ /AFTER 1061A ATTEMPTS/ |
| | 003544 | 020122 | 047445 | 022466 | | |
| | 003552 | 020101 | 052101 | 042524 | | |
| | 003560 | 050115 | 051524 | 047045 | | |
| | 003566 | 000 | | | | |
| 6016 | | 003570 | | | | EVEN |
| 6017 | | | | | | |
| 6019 | 003570 | | | | L10301 | |
| (3) | 003570 | 104023 | | | | |
| 6020 | | | | | | |
| 6022 | 003572 | 016746 | 000030 | | | |
| (8) | 003576 | 016746 | 000022 | | | |
| (7) | 003602 | 012746 | 003630 | | | |
| (6) | 003606 | 012746 | 000003 | | | |

 GLOBAL ERROR REPORT

```

MOV    !LIMIT, -(SP)
MOV    #FORM00, -(SP)
MOV    #2, -(SP)
MOV    SP, R0
EMT    C$PNTX
ADD    #6, SP

```

```

EMT    C$MSG
ASCIZ  /AFTER 1061A ATTEMPTS/

```

```

EMT    C$MSG
MOV    A02B, -(SP)
MOV    A02A, -(SP)
MOV    #FORM02, -(SP)
MOV    #3, -(SP)

```

| | | | | | | |
|------|--------|--------|--------|--------|--------|---|
| (3) | 003612 | 010600 | | | MOV | SP,RO |
| (4) | 003614 | 104015 | | | EMT | CSPNTX |
| (4) | 003616 | 062706 | 000010 | | ADD | #10,SP |
| 6023 | 003622 | | | L10002 | | |
| (3) | 003622 | 104023 | | | EMT | C\$MSG |
| 6024 | 003624 | 000000 | | A02A | 0 | |
| 6025 | 003626 | 000000 | | A02B | 0 | |
| 6026 | 003630 | 040445 | 042522 | 042503 | FORM02 | ASCIZ /%RECEIVED %03%A -- EXPECTED %03%N/ |
| | 003636 | 053111 | 042105 | 022440 | | |
| | 003644 | 031517 | 040445 | 026440 | | |
| | 003652 | 020055 | 054105 | 042520 | | |
| | 003660 | 052103 | 042105 | 022440 | | |
| | 003666 | 031517 | 047045 | 000 | | |
| 6027 | | 003674 | | | | EVEN |
| 6028 | | | | | | |
| 6030 | 003674 | | | AREA42 | | |
| 6031 | 003674 | 016746 | 176202 | | MOV | SCRATCH, -(SP) |
| (8) | 003700 | 016746 | 176200 | | MOV | TEMP, -(SP) |
| (7) | 003704 | 012746 | 003630 | | MOV | #FORM02, -(SP) |
| (6) | 003710 | 012746 | 000003 | | MOV | #3, -(SP) |
| (3) | 003714 | 010600 | | | MOV | SP,RO |
| (4) | 003716 | 104015 | | | EMT | CSPNTX |
| (4) | 003720 | 062706 | 000010 | | ADD | #10,SP |
| 6032 | 003724 | | | L10003 | | |
| (3) | 003724 | 104023 | | | EMT | C\$MSG |
| 6033 | | | | | | |
| 6035 | 003726 | | | AREA41 | | |
| 6036 | 003726 | | | AREA43 | | |
| 6037 | 003726 | 016746 | 000030 | | MOV | A04EX, -(SP) |
| (8) | 003732 | 016746 | 000022 | | MOV | A04RC, -(SP) |
| (7) | 003736 | 012746 | 003764 | | MOV | #FORM04, -(SP) |
| (6) | 003742 | 012746 | 000003 | | MOV | #3, -(SP) |
| (3) | 003746 | 010600 | | | MOV | SP,RO |
| (4) | 003750 | 104015 | | | EMT | CSPNTX |
| (4) | 003752 | 062706 | 000010 | | ADD | #10,SP |
| 6038 | 003756 | | | L10004 | | |
| (3) | 003756 | 104023 | | | EMT | C\$MSG |
| 6039 | 003760 | 000000 | | A04RC | 0 | |
| 6040 | 003762 | 000000 | | A04EX | 0 | |
| 6041 | 003764 | 040445 | 042522 | 042503 | FORM04 | ASCIZ /%RECEIVED %06%A -- EXPECTED %06%N |
| | 003772 | 053111 | 042105 | 022440 | | |
| | 004000 | 033117 | 040445 | 026440 | | |
| | 004006 | 020055 | 054105 | 042520 | | |
| | 004014 | 052103 | 042105 | 022440 | | |
| | 004022 | 033117 | 047045 | 000 | | |
| 6042 | | 004030 | | | | EVEN |
| 6043 | | | | | | |
| 6045 | 004030 | 016746 | 000030 | | MOV | KEX, -(SP) |
| (8) | 004034 | 016746 | 000022 | | MOV | KRC, -(SP) |
| (7) | 004040 | 012746 | 003764 | | MOV | #FORM04, -(SP) |
| (6) | 004044 | 012746 | 000003 | | MOV | #3, -(SP) |
| (3) | 004050 | 010600 | | | MOV | SP,RO |
| (4) | 004052 | 104015 | | | EMT | CSPNTX |
| (4) | 004054 | 062706 | 000010 | | ADD | #10,SP |
| 6046 | 004060 | | | L10005 | | |
| (3) | 004060 | 104023 | | | EMT | C\$MSG |

| | | | | | | | | |
|------|--------|--------|--------|--------|---------|-------|-------------------|-----------------------------------|
| 6047 | 004062 | 000000 | | | KRC | 0 | | |
| 6048 | 004064 | 000000 | | | KEX | 0 | | |
| 6050 | 004066 | | | | L10006 | | | |
| (3) | 004066 | 104023 | | | | EMT | C\$MSG | |
| 6052 | 004070 | | | | L10007 | | | |
| (3) | 004070 | 104023 | | | | EMT | C\$MSG | |
| 6054 | 004072 | | | | AREA24 | | | |
| 6055 | 004072 | | | | AREA40 | | | |
| 6056 | 004072 | 016767 | 176030 | 000064 | | MOV | LOGDEV, TEMP2 | |
| 6057 | 004100 | 005767 | 000060 | | | TST | TEMP2 | |
| (9) | 004104 | 002002 | | | | BGE | 50000\$ | |
| 6058 | 004106 | 005067 | 000052 | | | CLR | TEMP2 | |
| 6059 | 004112 | | | | 50000\$ | | | |
| 6060 | 004112 | 005267 | 000046 | | | INC | TEMP2 | |
| 6061 | 004116 | 016746 | 000042 | | | MOV | TEMP2, -(SP) | |
| (7) | 004122 | 012746 | 004166 | | | MOV | #FORM23, -(SP) | |
| (6) | 004126 | 012746 | 000002 | | | MOV | #2, -(SP) | |
| (3) | 004132 | 010600 | | | | MOV | SP, R0 | |
| (4) | 004134 | 104015 | | | | EMT | C\$PNTX | |
| (4) | 004136 | 062706 | 000006 | | | ADD | #6, SP | |
| 6062 | 004142 | 012746 | 004206 | | | MOV | #FORM40, -(SP) | |
| (6) | 004146 | 012746 | 000001 | | | MOV | #1, -(SP) | |
| (3) | 004152 | 010600 | | | | MOV | SP, R0 | |
| (4) | 004154 | 104015 | | | | EMT | C\$PNTX | |
| (4) | 004156 | 062706 | 000004 | | | ADC | #4, SP | |
| 6063 | 004162 | | | | L10010 | | | |
| (3) | 004162 | 104023 | | | | EMT | C\$MSG | |
| 6064 | 004164 | 000000 | | | TEMP2 | 0 | | |
| 6065 | 004166 | 040445 | 042504 | 044526 | FORM23 | ASCII | MADEVICE | %D3.N' |
| | 004174 | 042503 | 020072 | 042045 | | | | |
| | 004202 | 022463 | 000116 | | | | | |
| 6066 | 004206 | 040445 | 020040 | 020040 | FORM40 | ASCII | RA | ***** END OF ERROR REPORT *****N' |
| | 004214 | 020040 | 020040 | 025040 | | | | |
| | 004222 | 025052 | 025052 | 042440 | | | | |
| | 004230 | 042116 | 047440 | 020106 | | | | |
| | 004236 | 051105 | 047522 | 020122 | | | | |
| | 004244 | 042522 | 047520 | 052122 | | | | |
| | 004252 | 025040 | 025052 | 025052 | | | | |
| | 004260 | 047045 | 000 | | | | | |
| 6067 | | 004264 | | | | EVEN | | |
| 6068 | | | | | | | | |
| 6070 | 004264 | | | | L10011 | | | |
| (3) | 004264 | 104023 | | | | EMT | C\$MSG | |
| 6071 | | | | | | | | |
| 6074 | 004266 | | | | AREA31 | | | |
| 6075 | 004266 | 010146 | | | | MOV | R1, -(SP) | |
| 6076 | 004270 | 012701 | 002224 | | | MOV | #DUPREG, R1 | |
| 6077 | 004274 | 016146 | 000000 | | | MOV | RCVCSR(R1), -(SP) | |
| (7) | 004300 | 012746 | 004420 | | | MOV | #FORM30, -(SP) | |
| (6) | 004304 | 012746 | 000002 | | | MOV | #2, -(SP) | |
| (3) | 004310 | 010600 | | | | MOV | SP, R0 | |
| (4) | 004312 | 104015 | | | | EMT | C\$PNTX | |
| (4) | 004314 | 062706 | 000006 | | | ADD | #6, SP | |
| 6078 | 004320 | 016146 | 000002 | | | MOV | RCVBUF(R1), -(SP) | |
| (7) | 004324 | 012746 | 004442 | | | MOV | #FRM30A, -(SP) | |
| (6) | 004330 | 012746 | 000002 | | | MOV | #2, -(SP) | |

| | | | | | | | |
|------|--------|--------|--------|--------|--------|-------|-----------------------------|
| (3) | 004334 | 010600 | | | | MOV | SP, R0 |
| (4) | 004336 | 104015 | | | | EMT | CSPNTX |
| (4) | 004340 | 062706 | 000006 | | | ADD | #6, SP |
| 6079 | 004344 | 016146 | 000004 | | | MOV | XMTCSR(R1), -(SP) |
| (7) | 004350 | 012746 | 004465 | | | MOV | #FRM30B, -(SP) |
| (6) | 004354 | 012746 | 000002 | | | MOV | #2, -(SP) |
| (3) | 004360 | 010600 | | | | MOV | SP, R0 |
| (4) | 004362 | 104015 | | | | EMT | CSPNTX |
| (4) | 004364 | 062706 | 000006 | | | ADD | #6, SP |
| 6080 | 004370 | 016146 | 000006 | | | MOV | XMTBUF(R1), -(SP) |
| (7) | 004374 | 012746 | 004507 | | | MOV | #FRM30C, -(SP) |
| (6) | 004400 | 012746 | 000002 | | | MOV | #2, -(SP) |
| (3) | 004404 | 010600 | | | | MOV | SP, R0 |
| (4) | 004406 | 104015 | | | | EMT | CSPNTX |
| (4) | 004410 | 062706 | 000006 | | | ADD | #6, SP |
| 6081 | 004414 | 012601 | | | | MOV | (SP)+, R1 |
| 6082 | 004416 | | | L10012 | | | |
| (3) | 004416 | 104023 | | | | EMT | CMSG |
| 6083 | 004420 | 040445 | 052504 | 020120 | FORM30 | ASCIZ | %ADUP RCSR %06%N/ |
| | 004426 | 041522 | 051123 | 020072 | | | |
| | 004434 | 047445 | 022466 | 000116 | | | |
| 6084 | 004442 | 040445 | 052504 | 020120 | FRM30A | ASCIZ | %ADUP RBUF %06%N/ |
| | 004450 | 041122 | 043125 | 035106 | | | |
| | 004456 | 022440 | 033117 | 047045 | | | |
| | 004464 | 000 | | | | | |
| 6085 | 004465 | 045 | 042101 | 050125 | FRM30B | ASCIZ | %ADUP TCSP %06%N/ |
| | 004472 | 052040 | 051503 | 035122 | | | |
| | 004500 | 022440 | 033117 | 047045 | | | |
| | 004506 | 000 | | | | | |
| 6086 | 004507 | 045 | 042101 | 050125 | FRM30C | ASCIZ | %ADUP TBUF %06%N/ |
| | 004514 | 052040 | 052502 | 043106 | | | |
| | 004522 | 020072 | 047445 | 022466 | | | |
| | 004530 | 000116 | | | | | |
| 6087 | | | | | | EVEN | |
| 6127 | | | | | | | |
| 6129 | 004532 | 012746 | 004554 | | | MOV | #FORM60, -(SP) |
| (6) | 004536 | 012746 | 000001 | | | MOV | #1, -(SP) |
| (3) | 004542 | 010600 | | | | MOV | SP, R0 |
| (4) | 004544 | 104015 | | | | EMT | CSPNTX |
| (4) | 004546 | 062706 | 000004 | | | ADD | #4, SP |
| 6130 | 004552 | | | L10013 | | | |
| (3) | 004552 | 104023 | | | | EMT | CMSG |
| 6131 | 004554 | 040445 | 040503 | 023516 | FORM60 | ASCIZ | %ACAN'T GET INTO LOOPBACK N |
| | 004562 | 020124 | 042507 | 020124 | | | |
| | 004570 | 047111 | 047524 | 046040 | | | |
| | 004576 | 047517 | 041120 | 041501 | | | |
| | 004604 | 022513 | 000116 | | | | |
| 6132 | | | | | | EVEN | |
| 6134 | 004610 | 012746 | 004702 | | | MOV | #FORM61, -(SP) |
| (6) | 004614 | 012746 | 000001 | | | MOV | #1, -(SP) |
| (3) | 004620 | 010600 | | | | MOV | SP, R0 |
| (4) | 004622 | 104015 | | | | EMT | CSPNTX |
| (4) | 004624 | 062706 | 000004 | | | ADD | #4, SP |
| 6135 | 004630 | 016767 | 175272 | 17732e | | MOV | LOGDEV TEMP2 |
| 6136 | 004636 | 005767 | 177322 | | | TST | TEMP2 |
| (9) | 004642 | 002002 | | | | BGE | 5C0015 |

| | | | | | | |
|------|--------|--------|--------|---------|----------|--|
| 6137 | 004644 | 005067 | 177314 | | CLR | TEMP2 |
| 6138 | 004650 | | | 500015 | | |
| 6139 | 004650 | 005267 | 177310 | | INC | TEMP2 |
| 6140 | 004654 | 016746 | 177304 | | MOV | TEMP2, -(SP) |
| (7) | 004660 | 012746 | 004166 | | MOV | #FORM23, -(SP) |
| (6) | 004664 | 012746 | 000002 | | MOV | #2, -(SP) |
| (3) | 004670 | 010600 | | | MOV | SP, RO |
| (4) | 004672 | 104015 | | | EMT | CSPNTX |
| (4) | 004674 | 062706 | 000006 | | ADD | #6, SP |
| 6141 | 004700 | | | L10014 | | |
| (3) | 004700 | 104023 | | | EMT | CMSG |
| 6142 | 004702 | 040445 | 040503 | 023516 | FORM61 | ASCIZ /%ACAN'T GET OUT OF LCOPBACK%N/ |
| | 004710 | 020124 | 042507 | 020124 | | |
| | 004716 | 052517 | 020124 | 043117 | | |
| | 004724 | 046040 | 047517 | 041120 | | |
| | 004732 | 041501 | 022513 | 000116 | | |
| 6143 | | | | | EVEN | |
| 6145 | 004740 | 016746 | 000074 | | MOV | A52B, -(SP) |
| (8) | 004744 | 016746 | 000066 | | MOV | A52A, -(SP) |
| (7) | 004750 | 012746 | 004772 | | MOV | #FORM52, -(SP) |
| (6) | 004754 | 012746 | 000003 | | MOV | #3, -(SP) |
| (3) | 004760 | 010600 | | | MOV | SP, RO |
| (4) | 004762 | 104015 | | | EMT | CSPNTX |
| (4) | 004764 | 062706 | 000010 | | ADD | #10, SP |
| 6146 | 004770 | | | L10015 | | |
| (3) | 004770 | 104023 | | | EMT | CMSG |
| 6147 | 004772 | 040445 | 054105 | 042520 | FORM52 | ASCIZ /%AEXPECTED %03%A -RECEIVED %03%N/ |
| | 005000 | 052103 | 042105 | 020072 | | |
| | 005006 | 047445 | 022463 | 020101 | | |
| | 005014 | 026440 | 042522 | 042503 | | |
| | 005022 | 053111 | 042105 | 020072 | | |
| | 005030 | 047445 | 022463 | 000116 | | |
| 6148 | | | | | EVEN | |
| 6149 | 005036 | 000000 | | A52A | 0 | |
| 6150 | 005040 | 000000 | | A52B | 0 | |
| 6151 | | | | | | |
| 6153 | 005042 | | | L10016 | | |
| (3) | 005042 | 104023 | | | EMT | CMSG |
| 6154 | | | | | | |
| 6156 | 005044 | | | L10017 | | |
| (3) | 005044 | 104023 | | | EMT | CMSG |
| 6157 | | | | | | |
| 6158 | 005046 | | | TEMPBUF | | |
| 6159 | 005046 | 001452 | | | BLKW 810 | |
| 6160 | 010172 | | | TMPBUF | | |
| 6161 | 010172 | 000416 | | | BLKW 270 | |
| 6162 | 011226 | 000100 | | | BLKW 100 | |
| 6163 | 011426 | | | SSTACK | | STACK FOR SUBROUTINE LINKAGE |
| 6164 | | | | | | |

```
6173 , *****  
6174 ,          DEFAULT HARDWARE P-TABLE AND SOFTWARE P-TABLE *  
6175 , *****  
6176 011426 000004          WORD  L10020-L$HW/2  
6177 011430 160010          160010  
6178 011432 000320          320  
6179 011434 000140          140  
6180 011436 000000          0  
6184 011440          L10020  
6185 011440 000002          WORD  L10021-L$SW/2  
6186 011442 000010          000010  
6187 011444 000001          PATTERN 000001  
6191 011446          L10021  
6192 , *****  
6193 ,          DISPATCH TABLE *  
6194 , *****  
6195 , *****  
6196 011446 000002          WORD  TSTS  
   (6) 011450 017174          WORD  T1  
   (6) 011452 020200          WORD  T2
```

```

6387
6389
6390
6391
6393 011454
      (3) 011454 104025
6394
6396 011456
      (3) 011456 104054
6397
6399 011460
      (3) 011460 104055
6401
6402
6403
6404
6406
6407
6408
6409 011462 010146
6410
6411
6412
6413 011464 012700 000040
      (3) 011470 104050
6414
6415
6416
6417 011472 103005
6445
6446
6447
6448 011474 012705 011426
6449 011500 005267 170374
6450 011504 000414
      (3) 011506
6451
6452
6453
6454
6455
6456
6457
6458 011506 012700 000037
      (3) 011512 104050
6459 011514 103410
6460 011516 005267 170404
6464 011522 026767 170400 170264
      (9) 011530 001002
6465 011532 005067 170370
6469 011536
6470 011536
6471 011536
6472
6473
6474

```

```

*****
;STUB AREAS FOR SUPERVISOR COMPATIBILITY *
*****
L10022:
      EMT      CSRPT
L10023
      EMT      CSAU
L10024:
      EMT      CSDU
*****
;
;      INITIALIZE CODING
;*****
;
;SAVE R1
;
;      MOV      R1, -(SP)
;
;CHECK START EVENT FLAG TO SEE IF WE GOT HERE BECAUSE OF A START
;
;      MOV      #EF.START, R0
;      EMT      CSREFG
;
;IF A START, THEN...
;
;      BCC      50002$
;
;INITIALIZE THE SUBROUTINE LINKAGE STACK
;
;      MOV      #SSTACK, R5
;      INC      R5STCK
;      BR       50003$
50002$
;
;IF NOT START THEN.
;
;CHECK FOR RESTART AND IF IT IS.
;UPDATE LOGICAL DEVICE AND STAT TABLE ENTRY POINTER,
;BUT DON'T EXCEED THE NUMBER OF UNITS SPECIFIED
;
;      MOV      #EF.RESTART, R0
;      EMT      CSREFG
;      BCS      50004$
;      INC      LOGDEV
;      CMP      LOGDEV, LSUNIT
;      BNE      50005$
;      CLR      LOGDEV
50005$:
50004$:
50003$:
;
;CHECK FOR NEW PASS . IF IT IS, FORCE LOGICAL UNIT TO ZERO

```

| | | | | | | |
|------|--------|--------|--------|---------|-----|-----------------|
| 6475 | 011536 | 012700 | 000035 | | MOV | #EF, NEW, RO |
| (3) | 011542 | 104050 | | | EMT | CSREFG |
| 6476 | 011544 | 103002 | | | BCC | 50006\$ |
| 6477 | 011546 | 005067 | 170354 | | CLR | LOGDEV |
| 6481 | 011552 | | | 50006\$ | | |
| 6482 | | | | | | |
| 6483 | | | | | | |
| 6484 | | | | | | |
| 6485 | | | | | | |
| 6486 | 011552 | 005067 | 003640 | | CLR | INIT |
| 6487 | 011556 | 005067 | 170324 | | CLR | ABORT |
| 6488 | | | | | | |
| 6489 | | | | | | |
| 6490 | | | | | | |
| 6491 | 011562 | 012767 | 015442 | 003650 | MOV | #RQUET, RQUE |
| 6492 | 011570 | 016767 | 003644 | 003640 | MOV | RQUE, RQUEUE |
| 6493 | 011576 | 012767 | 015460 | 003652 | MOV | #RBQUET, RBQUE |
| 6494 | 011604 | 016701 | 003646 | | MOV | RBQUE, R1 |
| 6495 | 011610 | 012767 | 005046 | 170264 | MOV | #TEMBUF, SCRTCH |
| 6496 | 011616 | | | 50007\$ | | |
| 6497 | 011616 | 016721 | 170260 | | MOV | SCRTCH, (R1)+ |
| 6498 | 011622 | 062767 | 000416 | 170252 | ADD | #270, SCRTCH |
| 6499 | 011630 | 020127 | 015464 | | CMP | R1, #RBQUEB |
| (6) | 011634 | 003770 | | | BLE | 50007\$ |
| 6516 | | | | | | |
| 6517 | | | | | | |
| 6518 | | | | | | |
| 6519 | 011636 | | | 50010\$ | | |
| 6520 | 011636 | 005201 | | | INC | R1 |
| 6521 | 011640 | 016700 | 170262 | | MOV | LOGDEV, RO |
| (3) | 011644 | 104042 | | | EMT | CSGPHRD |
| (3) | 011646 | 010067 | 170230 | | MOV | RO, SCRTCH |
| 6522 | | | | | | |
| 6523 | | | | | | |
| 6524 | | | | | | |
| 6525 | 011652 | 103411 | | | BCS | 50011\$ |
| 6526 | 011654 | 005267 | 170246 | | INC | LOGDEV |
| 6530 | 011660 | 026767 | 170242 | 170126 | CMP | LOGDEV, LSUNIT |
| (9) | 011666 | 001002 | | | BNE | 50012\$ |
| 6531 | 011670 | 005067 | 170232 | | CLR | LOGDEV |
| 6535 | 011674 | | | 50012\$ | | |
| 6536 | 011674 | 005001 | | | CLR | R1 |
| 6537 | 011676 | | | 50011\$ | | |
| 6538 | 011676 | 005701 | | | TST | R1 |
| (6) | 011700 | 001756 | | | BEQ | 50010\$ |
| 6551 | | | | | | |
| 6552 | | | | | | |
| 6553 | | | | | | |
| 6554 | | | | | | |
| 6555 | 011702 | 012701 | 002170 | | MOV | #PTABLE, R1 |
| 6556 | 011706 | | | 50013\$ | | |
| 6557 | 011706 | 017711 | 170170 | | MOV | @SCRTCH, (R1) |
| 6558 | 011712 | 062701 | 000002 | | ADD | #2, R1 |
| 6559 | 011716 | 062767 | 000002 | 170156 | ADD | #2, SCRTCH |
| 6560 | 011724 | 020127 | 002200 | | CMP | R1, #PTEND |
| (6) | 011730 | 001366 | | | BNE | 50013\$ |

```
6579
6580 ; RESTORE R1 AND EXIT INIT CODE
6581 ;
6582 011732 012601          MOV      (SP)+,R1
6583 011734          L10025
(3) 011734 104011          EMT      CSINIT
6588 011736 047045 040445 052126 VMSG    .ASCIZ /%N%AVT62 ACCEPTANCE TEST -- VERSION 10 TERMINALS%/
    011744 031066 040440 041503
    011752 050105 040524 041516
    011760 020105 042524 052123
    011766 020040 026440 020055
    011774 020040 042526 051522
    012002 047511 020116 030061
    012010 052040 051105 044515
    012016 040516 051514 047045
    012024      000
6589      012026          EVEN
6590
6591 ; *****
6592 ; CLEAN-UP CODING *
6593 ; *****
6595 ;
6596 ; MAKE SURE DEVICE IS SHUT DOWN
6597 ;
6599 012026 010146          MOV      R1, -(SP)
6600 012030 016701 170134  MOV      PTABLE, R1
6601 012034 052761 000400 000004  BIS      #MASCLR, XMT(CSP(R1))
6602 012042 012601          MOV      (SP)+, R1
6611 ;
6612 ; UPDATE PASS COUNT
6613 ;
6614 012044 005267 170052          INC      PASCNT
6629 ;
6630 ; EXIT CLEAN-UP CODE
6631 ;
6632 012050          L10026
(3) 012050 104012          EMT      CSCLEAN
```

```

6636 ;*****
6637 ; GLOBAL SUBROUTINES *
6638 ;*****
6639 ;
6640 ;+++++
6641 ; ROUTINE TO PROCESS TERMINAL MESSAGES FOR ALL TESTS +
6642 ; RETURNS POINTER TO MESSAGE ("OUTMSG") AND ITS SIZE +
6643 ; IN BYTES ("OUTSIZ") +
6644 ; +
6645 ; SIZE MAY BE ANY NUMBER OF BYTES +
6646 ; +
6647 ; SETS A FLAG ("EXPINP") IF RESPONSE OTHER THAN "ACK" IS +
6648 ; TO BE EXPECTED +
6649 ; +
6650 ; SETS ANOTHER FLAG ("EOMSG") IF THIS IS THE LAST MESSAGE +
6651 ;+++++
6652 012052 MSG
6653
6656 012052 010446 MOV R4, -(SP)
(2) 012054 010604 MOV SP, R4
(3) 012056 162706 000002 SUB #2, SP
6657
6658 ; GET MESSAGE POINTER
6659 ;
6660 012062 017764 170064 177776 MOV @MSGAP, A(R4)
6661 ;
6662 ; IF MESSAGE POINTER IS ODD.
6663 ; SET END_OF_MESSAGE INDICATOR
6664 ;
6665 012070 016467 177776 170004 MOV A(R4), SCRTCH
(6) 012076 016746 170000 MOV SCRTCH, -(SP)
(6) 012102 042716 000001 BIC #1, (SP)
(6) 012106 042667 167770 BIC (SP)+, SCRTCH
6666 012112 005767 167764 TST SCRTCH
(9) 012116 001405 BEQ 50002$
6667 012120 005267 170000 INC EOMSG
6668 012124 042764 000001 177776 BIC #1, A(R4)
6669 012132 50002$
6670 ;
6671 ; IF MESSAGE_POINTER IS NEGATIVE.
6672 ; SET EXPECT_INPUT INDICATOR
6673 ;
6674 012132 005764 177776 TST A(R4)
(9) 012136 002006 BGE 50003$
6675 012140 005267 167764 INC EXPINP
6676 012144 042764 100000 177776 BIC #100000, A(R4)
6677 ;
6678 ; OTHERWISE. CLEAR EXPECT_INPUT
6679 ;
6680 012152 000402 BR 50004$
(3) 012154 50003$
6681 012154 005067 167750 CLR EXPINP
6682 012160 50004$
6683 ;
6684 ; SET MESSAGE_ADDRESS AND
6685 ; MESSAGE_SIZE

```

```
6686  
6687 012160 016467 177776 167744      MOV      A(R4), OUTMSG  
6688 012166 062767 000002 167756      ADD      #2, MSGAP  
6689 012174 017767 167752 167732      MOV      @MSGAP, OUTMSG+2  
6690  
6691      ; UPDATE MESSAGE_AREA_POINTER  
6692  
6693 012202 067767 167744 167742      ADD      @MSGAP, MSGAP  
6694 012210 062767 000002 167734      ADD      #2, MSGAP  
6695  
6696      ; IF MESSAGE_AREA_POINTER IS ODD  
6697      ; ADD 1 TO MAKE IT EVEN  
6698  
6699 012216 016767 167730 167656      MOV      MSGAP, SCRTCH  
    (6) 012224 016746 167652      MOV      SCRTCH, -(SP)  
    (6) 012230 042716 000001      BIC      #1, (SP)  
    (6) 012234 042667 167642      BIC      (SP)+, SCRTCH  
6700 012240 005767 167636      TST      SCRTCH  
    (9) 012244 001402      BEQ      50005$  
6701 012246 005267 167700      INC      MSGAP  
6702 012252      50005$  
6703 012252      50000$  
    (3) 012252      50001$  
    (3) 012252 010406      MOV      R4, SP  
    (3) 012254 012604      MOV      (SP)+, R4  
    (2) 012256 000207      RTS      PC
```

```
6704  
6705  
6706  
6707  
6708      +-----+  
6709      ROUTINE TO HANDLE OUTPUT OF MESSAGES TO THE TERMINAL      +  
6710      UNDER TEST  MESSAGES MAY BE OF ANY LENGTH SINCE      +  
6711      ROUTINES USED BY THIS ROUTINE SPLIT THE MESSAGES INTO      +  
6712      BUFFERS OF APPROPRIATE LENGTH FOR DDCMP      +  
6713      +-----+  
6714      TEREOUT  
6715 012260 005767 003132      TST      INIT  
    (9) 012264 001011      BNE      50002$  
6716 012266 004767 000222      JSR      PC, XSTPT  
6717 012272 103002      BCC      50003$  
6718 012274 000261      SEC  
    (4) 012276 000504      BR       50001$  
6719 012300      50003$  
6720 012300 005067 167660      CLR      MSGNO  
6721 012304 005067 167656      CLR      RMSGNO  
6722 012310      50002$  
6723  
6724      ; INITIALIZE THE BUFFER ROUTINES 3 2. 20 4  
6725  
6726 012310 016767 167616 167636      MOV      OUTMSG, INITMA  
6727 012316 012767 002132 167556      MOV      #OUTMSG, SCRTCH  
    (6) 012324 062767 000002 167550      ADD      #2, SCRTCH  
6728 012332 017767 167544 167616      MOV      @SCRTCH, INITMS  
6729      BUFFER #1, BAPNT  
6730 012340 012767 010172 167612      MOV      #TMPBUF, BAPNT
```

```

6731 012346 012767 000412 167606      MOV      #266.,BASIZE
6732
6733      ; GET A BUFFER OF THE MESSAGE
6734
6735 012354 162705 000004      SUB      #2*2,R5
(3) 012360 004767 000410      JSR      PC,GETOB
(4) 012364 012567 167552      MOV      (R5)+,OUTBUF
(4) 012370 012567 167550      MOV      (R5)+,OUTSIZ
6736
6737      ; PERFORM THE FOLLOWING LOOP WHILE
6738      ; A AND ABORT ARE CLEAR AND OUTSIZ
6739      ; IS GREATER THAN 0
6740
6741 012374      50004$
(6) 012374 005767 167544      TST      OUTSIZ
(9) 012400 003442      BLE      50005$
(6) 012402 005767 167500      TST      ABORT
(9) 012406 001037      BNE      50005$
6742
6743      ; ADD PROTOCOL ENVELOPE AND TRANSMIT
6744
6745 012410 162705 000004      SUB      #2*2,R5
(3) 012414 010546      MOV      R5,-(SP)
(5) 012416 016745 167502      MOV      OUTSIZ,-(R5)
(4) 012422 016745 167514      MOV      OUTBUF,-(R5)
(3) 012426 004767 000470      JSR      PC,PROBUF
(3) 012432 012605      MOV      (SP)+,R5
(4) 012434 012567 002762      MOV      (R5)+,XBUFFER
(4) 012440 012567 002760      MOV      (R5)+,XSIZE
6746 012444 004767 001756      JSR      PC,XMIT
6747
6748      ; IF TRANSMIT ERROR, REPORT IT AND SET EPPXMT
6749
6750 012450 103005      BCC      50006$
6751 012452 104423      TRAP    T$ERCODE
(5) 012454 000024      WORD    20
(5) 012456 002620      WORD    MSG20
6752 012460 000261      SEC
(4) 012462 000412      BR      50001$
6753 012464      50006$
6754
6755      ; GET THE NEXT BUFFER
6756
6757 012464 162705 000004      SUB      #2*2,R5
(3) 012470 004767 000300      JSR      PC,GETOB
(4) 012474 012567 167442      MOV      (R5)+,OUTBUF
(4) 012500 012567 167440      MOV      (R5)+,OUTSIZ
6758
6759      END OF LOOP
6760
6761 012504 000733      BR      50004$
(3) 012506      50005$
6762
6763      ; IF ERROR OCCURRED DO AN ERPCP RETURN
6764
6765 012506      50000$

```

| | | | | | | |
|------|--------|--------|--------|--------|---------|------------------------------|
| (2) | 012506 | 000241 | | | CLC | |
| (3) | 012510 | | | | 50001\$ | |
| (2) | 012510 | 000207 | | | RTS | PC |
| b766 | 012512 | 000000 | | | TYPE | 0 , TYPE OF MESSAGE EXPECTED |
| b767 | | | | | | |
| b768 | | | | | | |
| b769 | | | | | | |
| b770 | | | | | | |
| b771 | | | | | | |
| b772 | | | | | | |
| b773 | | | | | | |
| b774 | | | | | | |
| b775 | | | | | | |
| b776 | 012514 | | | | | |
| b779 | 012514 | 010446 | | | | |
| (2) | 012516 | 010604 | | | | |
| (3) | 012520 | 162706 | 000002 | | | |
| b780 | | | | | | |
| b781 | | | | | | |
| b782 | | | | | | |
| b783 | | | | | | |
| b784 | | | | | | |
| b785 | 012524 | 012767 | 000010 | 002672 | MOV | #10, XSIZE |
| b786 | 012532 | 012767 | 002500 | 002662 | MOV | #STRTB, XBUFFER |
| b787 | | | | | | |
| b788 | | | | | | |
| b789 | | | | | | |
| b790 | 012540 | 012764 | 002170 | 177776 | MOV | #PTABLE, A(R4) |
| (6) | 012546 | 062764 | 000005 | 177776 | ADD | #5, A(R4) |
| b791 | 012554 | 117467 | 177776 | 170723 | MOVB | @A(R4), STRTSA |
| b792 | | | | | | |
| b793 | | | | | | |
| b794 | | | | | | |
| b795 | | | | | | |
| b796 | 012562 | 162705 | 000002 | | SUB | #1*2, R5 |
| (3) | 012566 | 010546 | | | MOV | R5, -(SP) |
| (5) | 012570 | 012745 | 000006 | | MOV | #6, -(R5) |
| (4) | 012574 | 016745 | 002622 | | MOV | XBUFFER, -(R5) |
| (3) | 012600 | 004767 | 004014 | | JSR | PC, CRC |
| (3) | 012604 | 012605 | | | MOV | (SP)+, P5 |
| (4) | 012606 | 012567 | 170674 | | MOV | (R5)+, STPTC |
| b797 | | | | | | |
| b798 | | | | | | |
| b799 | | | | | | |
| b800 | 012612 | 005067 | 000154 | | CLR | DDSTRY |
| b801 | 012616 | | | | 50002\$ | |
| b802 | 012616 | 004767 | 001604 | | JSP | PC, XMIT |
| b803 | | | | | | |
| b804 | | | | | | |
| b805 | | | | | | |
| b806 | 012622 | 103005 | | | BCC | 50003\$ |
| b807 | 012624 | 104423 | | | TRAP | T\$ERCODE |
| (5) | 012626 | 000024 | | | WORD | 20 |
| (5) | 012630 | 002620 | | | WORD | MSG20 |
| b808 | 012632 | 000261 | | | SEC | |
| (4) | 012634 | 000453 | | | BP | 50001\$ |

ROUTINE TO SEND A "STRT" MESSAGE TO THE TERMINAL
 A "STACK" MUST BE RETURNED BY THE TERMINAL

THE DDCMP STRT MESSAGE IS 10 BYTES LONG (INCLUDING CPC) AND IS IN
 A BUFFER STARTING AT "STRTB" -- PUT THIS INFORMATION
 IN THE TRANSMIT ROUTINE'S POINTERS

GET THE TERMINAL ADDRESS AND PUT INTO THE STRT MESSAGE

COMPUTE THE CPC FOR THE STRT MESSAGE AND PUT IN THE LAST TWO BYTES
 OF THE BUFFER ("STRTC")

TRANSMIT THE MESSAGE

IF AN ERROR OCCURS, REPORT IT AND EXIT WITH THE ERROR FLAG SET

```

6809 012636          50003$
6810
6811                . OTHERWISE, GET THE TERMINAL'S RESPONSE
6812
6813 012636 010546          MOV    R5, -(SP)
   (4) 012640 012745 000001  MOV    #1, -(R5)
   (3) 012644 004767 003456  JSR    PC, RCVE
   (3) 012650 012605          MOV    (SP)+, R5
6814
6815                . IF RECEPTION ERROR, REPORT IT AND EXIT WITH THE ERROR FLAG SET
6816
6817 012652 103003          BCC    50004$
6818 012654 005267 000112  INC    DDSTRY
6819 012660 000402          BR     50005$
   (3) 012662          50004$
6820 012662 005067 000104  CLR    DDSTRY
6821 012666          50005$
6822 012666 005767 000100  TST    DDSTRY
   (6) 012672 001404          BEQ    50006$
   (4) 012674 026727 000072 000003  CMP    DDSTRY, #3
   (7) 012702 001345          BNE    50002$
   (4) 012704          50006$
6823 012704 005767 000062  TST    DDSTRY
   (9) 012710 001405          BEQ    50007$
6824 012712 104423          TRAP   TSEPCODE
   (5) 012714 000025          WORD   21
   (5) 012716 002637          WORD   MSG21
6825 012720 000261          SEC
   (4) 012722 000420          BR     50001$
6826 012724          50007$
6827
6828                . OTHERWISE, SET TYPE TO "STACK" AND CHECK TO SEE THAT IT WAS THE REPLY
6829
6830 012724 012767 000007 177560  MOV    #STACK, TYPE
6831 012732 010546          MOV    R5, -(SP)
   (4) 012734 016745 177552  MOV    TYPE, -(R5)
   (3) 012740 004767 001072  JSR    PC, CHKREP
   (3) 012744 012605          MOV    (SP)+, R5
6832
6833                . IF REPLY WASN'T A "STACK", REPORT THE ERROR AND EXIT WITH THE ERROR FLAG SET
6834
6835 012746 103005          BCC    50010$
6836 012750 104423          TRAP   TSEPCODE
   (5) 012752 000031          WORD   25
   (5) 012754 003025          WORD   MSG25
6837 012756 000261          SEC
   (4) 012760 000401          BR     50001$
6838 012762          50010$
6839
6840                . END OF XSTRT ROUTINE
6841
6842 012762          50000$
   (2) 012762 000241          CLC
   (3) 012764          50001$
   (2) 012764 01040e          MOV    R4, SP
   (3) 012766 012604          MOV    (SP)+, R4

```

| | | | | | | |
|------|--------|--------|--------|--------|--------|-----------------|
| (2) | 012770 | 000207 | | | RTS | PC |
| 6843 | 012772 | 000000 | | | DDSTRY | 0 |
| 6844 | | | | | | |
| 6845 | | | | | | |
| 6846 | | | | | | |
| 6847 | | | | | | |
| 6848 | | | | | | |
| 6849 | | | | | | |
| 6850 | | | | | | |
| 6851 | | | | | | |
| 6852 | | | | | | |
| 6853 | | | | | | |
| 6854 | | | | | | |
| 6855 | 012774 | | | | | |
| 6856 | 012774 | 010446 | | | MOV | R4, -(SP) |
| 6857 | 012776 | 010604 | | | MOV | SP, R4 |
| (3) | 013000 | 162706 | 000002 | | SUB | #2, SP |
| 6859 | | | | | | |
| 6860 | | | | | | |
| 6861 | | | | | | |
| 6862 | 013004 | 016765 | 167150 | 000000 | MOV | BAPNT, A(R5) |
| (6) | 013012 | 062765 | 000010 | 000000 | ADD | #10, A(R5) |
| 6863 | | | | | | |
| 6864 | | | | | | |
| 6865 | | | | | | |
| 6866 | 013020 | 005065 | 000002 | | CLR | B(R5) |
| 6867 | | | | | | |
| 6868 | | | | | | |
| 6869 | | | | | | |
| 6870 | 013024 | 016767 | 167132 | 167050 | MOV | BASIZE, SCRTCH |
| (6) | 013032 | 162767 | 000012 | 167042 | SUB | #12, SCRTCH |
| 6871 | | | | | | |
| 6872 | | | | | | |
| 6873 | | | | | | |
| 6874 | 013040 | 016564 | 000000 | 177776 | MOV | A(R5), C(R4) |
| 6875 | | | | | | |
| 6876 | | | | | | |
| 6877 | | | | | | |
| 6878 | 013046 | | | | | |
| (6) | 013046 | 026567 | 000002 | 167026 | CMP | B(R5), SCRTCH |
| (9) | 013054 | 002017 | | | BGE | 50003\$ |
| (6) | 013056 | 005767 | 167074 | | TST | INITMS |
| (9) | 013062 | 003414 | | | BLE | 50003\$ |
| 6879 | | | | | | |
| 6880 | | | | | | |
| 6881 | | | | | | |
| 6882 | 013064 | 117774 | 167064 | 177776 | MOVB | @INITMA, @C(R4) |
| 6883 | 013072 | 005367 | 167060 | | DEC | INITMS |
| 6884 | 013076 | 005267 | 167052 | | INC | INITMA |
| 6885 | 013102 | 005265 | 000002 | | INC | B(R5) |
| 6886 | 013106 | 005264 | 177776 | | INC | C(R4) |
| 6887 | 013112 | 000755 | | | BR | 50002\$ |
| (3) | 013114 | | | | | |
| 6888 | | | | | | |
| 6889 | | | | | | |
| 6890 | | | | | | |

 THIS ROUTINE SPLITS A MESSAGE OF ANY LENGTH INTO
 SEGMENTS OF A SIZE SUITABLE FOR TRANSMISSION OVER A DATA
 LINK -- RETURNS BUFFER ADDRESS, BUFFER SIZE AND END_OF_MESSAGE
 (BUFFER SIZE = 0 IS END_OF_MESSAGE)

GETCB
 MOV R4, -(SP)
 MOV SP, R4
 SUB #2, SP

LEAVE ENOUGH ROOM FOR A DDCMP HEADER

MOV BAPNT, A(R5)
 ADD #10, A(R5)

INIT SIZE TO ZERO

CLR B(R5)

SCRTCH HAS MAXIMUM DDCMP MESSAGE SIZE

MOV BASIZE, SCRTCH
 SUB #12, SCRTCH

GET A COPY OF THE BUFFER POINTER

MOV A(R5), C(R4)

REPEAT LOOP UNTIL MAX SIZE OF END OF DATA

50002\$
 CMP B(R5), SCRTCH
 BGE 50003\$
 TST INITMS
 BLE 50003\$

MOVE DATA INTO MESSAGE BUFFER

MOVB @INITMA, @C(R4)
 DEC INITMS
 INC INITMA
 INC B(R5)
 INC C(R4)
 BR 50002\$

50003\$

END OF LOOP

| | | | | | |
|------|--------|--------|--------|---------|---------------|
| 6891 | 013114 | | | 50000\$ | |
| (3) | 013114 | | | 50001\$ | |
| (3) | 013114 | 010406 | | MOV | R4, SP |
| (3) | 013116 | 012604 | | MOV | (SP)+, R4 |
| (2) | 013120 | 000207 | | RTS | PC |
| 6892 | | | | | |
| 6893 | | | | | |
| 6894 | | | | | |
| 6895 | | | | | |
| 6896 | | | | | |
| 6897 | | | | | |
| 6898 | | | | | |
| 6899 | | | | | |
| 6900 | | | | | |
| 6901 | | | | | |
| 6902 | 013122 | | | | |
| 6903 | 013122 | 010146 | | PROBUF | MOV R1, -(SP) |
| 6904 | 013124 | 010246 | | MOV | R2, -(SP) |
| 6905 | | | | | |
| 6906 | | | | | |
| 6907 | | | | | |
| 6908 | 013126 | 016502 | 000000 | | |
| (6) | 013132 | 162702 | 000010 | MOV | A(R5), R2 |
| 6909 | | | | SUB | #10, R2 |
| 6910 | | | | | |
| 6911 | | | | | |
| 6912 | 013136 | 112722 | 000201 | | |
| 6913 | | | | | |
| 6914 | | | | | |
| 6915 | | | | | |
| 6916 | 013142 | 016501 | 000002 | | |
| 6917 | 013146 | 110122 | | MOV | B(R5), R1 |
| 6918 | 013150 | 000301 | | MOVB | R1, (R2)+ |
| 6919 | 013152 | 110112 | | SWAB | R1 |
| 6920 | | | | MOVB | R1, (R2) |
| 6921 | | | | | |
| 6922 | | | | | |
| 6923 | 013154 | 152712 | 000200 | | |
| 6924 | 013160 | 005202 | | BISB | #200, (R2) |
| 6925 | | | | INC | R2 |
| 6926 | | | | | |
| 6927 | | | | | |
| 6928 | 013162 | 116722 | 167000 | | |
| 6929 | | | | | |
| 6930 | | | | | |
| 6931 | | | | | |
| 6932 | 013166 | 005267 | 166772 | | |
| 6933 | 013172 | 116722 | 166766 | INC | MSGNO |
| 6934 | | | | MOVB | MSGNO, (R2)+ |
| 6935 | | | | | |
| 6936 | | | | | |
| 6937 | 013176 | 012701 | 002170 | | |
| (6) | 013202 | 062701 | 000005 | MOV | #PTABLE, R1 |
| 6938 | 013206 | 111122 | | ADD | #5, R1 |
| 6939 | | | | MOVB | (R1), (R2)+ |
| 6940 | | | | | |

```

+++++
ROUTINE TO PROVIDE LINE PROTOCOL HEADER AND CHECKSUMS +
CALL WITH DATA AREA ADDRESS AND SIZE (IN BYTES) +
RETURN WITH MODIFIED ADDRESS AND SIZE +
+++++
PROBUF
MOV R1, -(SP)
MOV R2, -(SP)

CHANGE POINTER TO INCLUDE DDCMP HEADER

MOV A(R5), R2
SUB #10, R2

FIRST BYTE IS SOH (START OF HEADER)

MOVB #SOH, (R2)+

NEXT TWO BYTES GET MESSAGE SIZE

MOV B(R5), R1
MOVB R1, (R2)+
SWAB R1
MOVB R1, (R2)

SET SELECT BIT

BISB #200, (R2)
INC R2

NEXT BYTE IS LAST GOOD RESPONSE

MOVB RMSGNO, (R2)+

NEXT BYTE GETS MESSAGE NUMBER --- POP NUMBER FOR NEXT MESSAGE (IF ANY)

INC MSGNO
MOVB MSGNO, (R2)+

GET THE TERMINAL ADDRESS FOR THE NEXT HEADER BYTE

MOV #PTABLE, R1
ADD #5, R1
MOVB (R1), (R2)+

GET HEADER START ADDRESS AND SIZE IN BYTES
  
```

| | | | | | | |
|------|--------|--------|--------|--------|------|--|
| 6941 | | | | | | |
| 6942 | 013210 | 016567 | 000000 | 166664 | MOV | A(R5), SCRTCH |
| (6) | 013216 | 162767 | 000010 | 166656 | SUB | #10, SCRTCH |
| 6943 | 013224 | 012767 | 000006 | 166652 | MOV | #6, TEMP |
| 6944 | | | | | | |
| 6945 | | | | | | COMPUTE HEADER CRC |
| 6946 | | | | | | |
| 6947 | 013232 | 162705 | 000002 | | SUB | #1*2, R5 |
| (3) | 013236 | 010546 | | | MOV | R5, -(SP) |
| (5) | 013240 | 016745 | 166640 | | MOV | TEMP, -(R5) |
| (4) | 013244 | 016745 | 166632 | | MOV | SCRTCH, -(R5) |
| (3) | 013250 | 004767 | 003344 | | JSR | PC, CRC |
| (2) | 013254 | 012605 | | | MOV | (SP)+, R5 |
| (4) | 013256 | 012567 | 166622 | | MOV | (R5)+, TEMP |
| 6948 | | | | | | |
| 6949 | | | | | | PUT CRC INTO BUFFER |
| 6950 | | | | | | |
| 6951 | 013262 | 016712 | 166616 | | MOV | TEMP, (R2) |
| 6952 | | | | | | |
| 6953 | | | | | | GET ADDRESS OF MESSAGE AND MESSAGE SIZE IN BYTES |
| 6954 | | | | | | |
| 6955 | 013266 | 016567 | 000000 | 166606 | MOV | A(R5), SCRTCH |
| 6956 | 013274 | 016567 | 000002 | 166602 | MOV | B(R5), TEMP |
| 6957 | | | | | | |
| 6958 | | | | | | COMPUTE DATA CRC |
| 6959 | | | | | | |
| 6960 | 013302 | 162705 | 000002 | | SUB | #1*2, R5 |
| (3) | 013306 | 010546 | | | MOV | R5, -(SP) |
| (5) | 013310 | 016745 | 166570 | | MOV | TEMP, -(R5) |
| (4) | 013314 | 016745 | 166562 | | MOV | SCRTCH, -(R5) |
| (3) | 013320 | 004767 | 003274 | | JSR | PC, CRC |
| (3) | 013324 | 012605 | | | MOV | (SP)+, R5 |
| (4) | 013326 | 012567 | 166552 | | MOV | (R5)+, TEMP |
| 6961 | | | | | | |
| 6962 | | | | | | PUT DATA CRC IN LAST TWO BYTES OF BUFFER |
| 6963 | | | | | | |
| 6964 | 013332 | 016502 | 000000 | | MOV | A(R5), R2 |
| (6) | 013336 | 066502 | 000002 | | ADD | B(R5), R2 |
| 6965 | 013342 | 116722 | 166536 | | MOVB | TEMP, (R2)+ |
| 6966 | 013346 | 000367 | 166532 | | SWAB | TEMP |
| 6967 | 013352 | 116712 | 166526 | | MOVB | TEMP, (R2) |
| 6968 | | | | | | |
| 6969 | | | | | | RETURN WITH MODIFIED ADDRESS AND SIZE |
| 6970 | | | | | | |
| 6971 | 013356 | 016565 | 000002 | 000006 | MOV | B(R5), D(R5) |
| (6) | 013364 | 062765 | 000012 | 000006 | ADD | #12, D(R5) |
| 6972 | 013372 | 016565 | 000000 | 000004 | MOV | A(R5), C(R5) |
| (6) | 013400 | 162765 | 000010 | 000004 | SUB | #10, C(R5) |
| 6973 | 013406 | 012602 | | | MOV | (SP)+, R2 |
| 6974 | 013410 | 012601 | | | MOV | (SP)+, R1 |
| 6975 | 013412 | | | | | |
| (3) | 013412 | | | | | 500005 |
| (2) | 013412 | 000207 | | | | 500015 |
| 6976 | | | | | RTS | PC |
| 6977 | | | | | | |
| 6978 | | | | | | |

```

6979
6980
6981
6982
6983
6984 013414
6985
6986
6987
6988 013414 010146
6989
6990
6991
6992 013416 010546
(4) 013420 012745 000000
(3) 013424 004767 002676
(3) 013430 012605
6993
6994
6995
6996 013432 103007
6997 013434 104463
(5) 013436 000050
(5) 013440 002637
(5) 013442 004072
6998
6999
7000
7001 013444 012601
7002 013446 000261
(4) 013450 000571
7003 013452
7004
7005
7006
7007
7008 013452 026727 166472 000010
(9) 013460 001027
7009 013462 005065 000000
7010 013466 012767 000001 177016
7011 013474 010546
(4) 013476 016745 177010
(3) 013502 004767 000330
(3) 013506 012605
7012 013510 103003
7013 013512 012601
7014 013514 000261
(4) 013516 000546
7015 013520
7016 013520 016701 166422
(6) 013524 062701 000004
7017 013530 111167 166432
7018 013534 012601
7019 013536 000535
7020 013540
7021

```

```

;*****
; ROUTINE TO GET TERMINAL INPUT
;*****
TERIN
; SAVE R1
;
; MOV R1, -(SP)
;
; GET TERMINAL RESPONSE
;
; MOV R5, -(SP)
; MOV #0, -(R5)
; JSR PC, RCVE
; MOV (SP)+, R5
;
; IF RECEIVE ERROR, REPORT IT AND EXIT WITH THE ERROR FLAG SET
;
; BCC 50002$
; TRAP T$ERCODE
; WORD 40
; WORD MSG40
; WORD AREA40
;
; RESTORE R1 FIRST
;
; MOV (SP)+, R1
; SEC
; BR 50001$
50002$
; IF MESSAGE IS ONLY 10 BYTES, SEE IF IT IS AN ACK
; IT'S OK TO BE AN ACK, BUT RECEPTION IS INCOMPLETE (CLEAR FLAG).
;
; CMP INSIZ, #10
; BNE 50003$
; CLR A(R5)
; MOV #ACK, TYPE
; MOV R5, -(SP)
; MOV TYPE, -(R5)
; JSR PC, CHKREP
; MOV (SP)+, R5
; BCC 50004$
; MOV (SP)+, R1
; SEC
; BR 50001$
50004$
; MOV INBUF, R1
; ADD #4, R1
; MOVB (R1), RMSGNO
; MOV (SP)+, R1
; BR 50000$
50003$

```

```

7022 ; IF RECEIVE OK, CHECK THE HEADER CRC
7023 ; COMPUTE EXPECTED CRC
7024 ;
7025 013540 162705 000002          SUB    #1*2,R5
      (3) 013544 010546          MOV    R5,-(SP)
      (5) 013546 012745 000006          MOV    #6,-(R5)
      (4) 013552 016745 166370          MOV    INBUF,-(R5)
      (3) 013556 004767 003036          JSR    PC,CRC
      (3) 013562 012605          MOV    (SP)+,R5
      (4) 013564 012567 170172          MOV    (R5)+,A04EX
7026
7027 ; GET THE CRC RECEIVED
7028 ;
7029 013570 016701 166352          MOV    INBUF,R1
      (6) 013574 062701 000010          ADD    #10,R1
7030 013600 114167 170154          MOVB  -(R1),A04RC
7031 013604 000367 170150          SWAB  A04RC
7032 013610 114167 170144          MOVB  -(R1),A04RC
7033
7034 ; IF THEY AREN'T THE SAME, REPORT THE ERROR, RESTORE R1 AND EXIT WITH
7035 ; THE ERROR FLAG SET
7036 ;
7037 013614 026767 170142 170136    CMP    A04EX,A04RC
      (9) 013622 001407          BEQ    50005$
7038 013624 104463          TRAP  TSEPCODE
      (5) 013626 000051          WORD  41
      (5) 013630 002411          WORD  MSG41
      (5) 013632 003726          WORD  AREA41
7039 013634 012601          MOV    (SP)+,R1
7040 013636 000261          SEC
      (4) 013640 000475          BR     50001$
7041 013642          50005$
7042
7043 ; COMPARE TERMINAL ADDRESS RECEIVED WITH THAT EXPECTED
7044 ; AND IF THEY AREN'T THE SAME, REPORT THE ERROR, RESTORE R1 AND
7045 ; EXIT WITH THE ERROR FLAG SET
7046 ;
7047 013642 124167 167637          CMPB  -(R1),STRTSA
      (9) 013646 001407          BEQ    50006$
7048 013650 104463          TRAP  TSEPCODE
      (5) 013652 000052          WORD  42
      (5) 013654 002345          WORD  MSG42
      (5) 013656 003674          WORD  AREA42
7049 013660 012601          MOV    (SP)+,R1
7050 013662 000261          SEC
      (4) 013664 000463          BR     50001$
7051 013666          50006$
7052
7053 ; MOVE THE POINTERS PAST THE HEADER AND COMPUTE THE DATA CPC
7054 ;
7055 013666 062767 000010 166252    ADD    #10,INBUF
7056 013674 162767 000012 166246    SUB    #12,INSIZ
7057 013702 162705 000002          SUB    #1*2,R5
      (3) 013706 010546          MOV    R5,-(SP)
      (5) 013710 016745 166234          MOV    INSIZ,-(R5)
      (4) 013714 016745 166226          MOV    INBUF,-(R5)

```

```
(3) 013720 004767 002674 JSR PC,CRC
(3) 013724 012605 MOV (SP)+,R5
(4) 013726 012567 170030 MOV (R5)+,A04EX
7058
7059 ; GET THE DATA CRC RECEIVED
7060
7061 013732 016701 166210 MOV INBUF,R1
(6) 013736 066701 166206 ADD INSIZ,R1
7062 013742 062701 000002 ADD #2,R1
7063 013746 114167 170006 MOVB -(R1),A04RC
7064 013752 000367 170002 SWAB A04RC
7065 013756 114167 167776 MOVB -(R1),A04RC
7066
7067 ; IF THEY AREN'T THE SAME; REPORT THE ERROR, RESTORE R1 AND
7068 ; EXIT WITH THE ERROR FLAG SET
7069
7070 013762 026767 167772 167772 CMP A04RC,A04EX
(9) 013770 001407 BEQ 50007$
7071 013772 104463 TRAP T$ERCODE
(5) 013774 000053 .WORD 43
(5) 013776 003224 .WORD MSG43
(5) 014000 003726 .WORD AREA43
7072 014002 012601 MOV (SP)+,R1
7073 014004 000261 SEC
(4) 014006 000412 BR 50001$
7074 014010 50007$
7075
7076 ; OTHERWISE, SET COMPLETE FLAG, RESTORE R1 AND EXIT NORMALLY
7077
7078 014010 005265 000000 INC A(R5)
7079 014014 016701 166126 MOV INBUF,R1
(6) 014020 162701 000004 SUB #4,R1
7080 014024 111167 166136 MOVB (R1),RMSGNO
7081 014030 012601 MOV (SP)+,R1
7082 014032 50000$ CLC
(2) 014032 000241 50001$
(3) 014034
(2) 014034 000207 RTS PC
7083
7084
7085
7086
7087
7088
7089 *****
7090 ROUTINE TO CHECK AN INPUT BUFFER FOR A STANDAPD +
7091 RESPONSE ("ACK" OR "STACK") +
7092 +
7093 LOCATION "TYPE" CONTAINS THE RESPONSE CODE EXPECTED +
7094 INPUT BUFFER POINTER IS IN "INBUF" +
7095 +
7096 INPUT BUFFER SIZE (IN BYTES) IS IN "INSIZ" +
7097 *****
7098
7099 014036 CHKREP
7102 014036 010446 MOV R4,-(SP)
```

| | | | | | | |
|------|--------|--------|--------|--------|---|----------------|
| (2) | 014040 | 010604 | | | MOV | SP, R4 |
| (3) | 014042 | 162706 | 000002 | | SUB | #2, SP |
| 7103 | | | | | | |
| 7104 | | | | | ; IF MESSAGE IS NOT 10 BYTES LONG, IT CAN'T BE A CONTROL MESSAGE | |
| 7105 | | | | | ; TYPE AN ERROR MESSAGE AND EXIT WITH ERROR SET | |
| 7106 | | | | | | |
| 7107 | 014046 | 026727 | 166076 | 000010 | CMP | INSIZ, #10 |
| (9) | 014054 | 001406 | | | BEQ | 500025 |
| 7108 | 014056 | 104463 | | | TRAP | T\$ERCODE |
| (5) | 014060 | 000001 | | | WORD | 1 |
| (5) | 014062 | 002273 | | | WORD | MSG01 |
| (5) | 014064 | 003570 | | | WORD | AREA01 |
| 7109 | 014066 | 000261 | | | SEC | |
| (4) | 014070 | 000553 | | | BR | 500015 |
| 7110 | 014072 | | | | 500025: | |
| 7111 | | | | | | |
| 7112 | | | | | ; OTHERWISE, COMPUTE THE CRC AND CHECK IT AGAINST THAT SENT | |
| 7113 | | | | | | |
| 7114 | 014072 | 162705 | 000002 | | SUB | #1*2, R5 |
| (3) | 014076 | 010546 | | | MOV | R5, -(SP) |
| (5) | 014100 | 012745 | 000006 | | MOV | #6, -(R5) |
| (4) | 014104 | 016745 | 166036 | | MOV | INBUF, -(R5) |
| (3) | 014110 | 004767 | 002504 | | JSR | PC, CRC |
| (3) | 014114 | 012605 | | | MOV | (SP)+, R5 |
| (4) | 014116 | 012567 | 165762 | | MOV | (R5)+, TEMP |
| 7115 | 014122 | 016764 | 166020 | 177776 | MOV | INBUF, A(R4) |
| (6) | 014130 | 062764 | 000007 | 177776 | ADD | #7, A(R4) |
| 7116 | 014136 | 117467 | 177776 | 165736 | MOVB | @A(R4), SCRTCH |
| 7117 | 014144 | 000367 | 165732 | | SWAB | SCRTCH |
| 7118 | 014150 | 005364 | 177776 | | DEC | A(R4) |
| 7119 | 014154 | 117467 | 177776 | 165720 | MOVB | @A(R4), SCRTCH |
| 7120 | | | | | | |
| 7121 | | | | | ; IF CRC'S MATCH GO ON . OTHERWISE SKIP FOLLOWING CODE | |
| 7122 | | | | | | |
| 7123 | 014162 | 026767 | 165716 | 165712 | CMP | TEMP, SCRTCH |
| (9) | 014170 | 001076 | | | BNE | 500045 |
| 7124 | | | | | | |
| 7125 | | | | | ; COMPARE CONTROL MESSAGE TYPE WITH THAT PASSED AS AN ARGUMENT | |
| 7126 | | | | | | |
| 7127 | 014172 | 016764 | 165750 | 177776 | MOV | INBUF, A(R4) |
| (6) | 014200 | 005264 | 177776 | | INC | A(R4) |
| 7128 | 014204 | 117464 | 177776 | 177776 | MOVB | @A(R4), A(R4) |
| 7129 | 014212 | 042764 | 177400 | 177776 | BIC | #HYBYTE, A(R4) |
| 7130 | | | | | | |
| 7131 | | | | | ; IF NOT THE EXPECTED TYPE, PRINT ERROR MESSAGE AND EXIT WITH ERROR SET | |
| 7132 | | | | | | |
| 7133 | 014220 | 026465 | 177776 | 000000 | CMP | A(R4), B(R5) |
| (9) | 014226 | 001414 | | | BEQ | 500055 |
| 7134 | 014230 | 016467 | 177776 | 167366 | MOV | A(R4), A02A |
| 7135 | 014236 | 016567 | 000000 | 167362 | MOV | B(R5), A02B |
| 7136 | 014244 | 104463 | | | TRAP | T\$ERCODE |
| (5) | 014246 | 000002 | | | WORD | 2 |
| (5) | 014250 | 002320 | | | WORD | MSG02 |
| (5) | 014252 | 003572 | | | WORD | AREA02 |
| 7137 | 014254 | 000261 | | | SEC | |
| (4) | 014256 | 000460 | | | BR | 500015 |

```

7138
7139 ; OTHERWISE, CHECK TERMINAL ADDRESS
7140 ;
7141 014260 50005$.
7142 014260 012767 002170 165614 MOV #PTABLE, SCRTCH
(6) 014266 062767 000005 165606 ADD #5, SCRTCH
7143 014274 117767 165602 165600 MOVB @SCRTCH, SCRTCH
7144 014302 042767 177400 165572 BIC #HYBYTE, SCRTCH
7145 014310 016767 165632 165566 MOV INBUF, TEMP
(6) 014316 062767 000005 165560 ADD #5, TEMP
7146 014324 117767 165554 165552 MOVB @TEMP, TEMP
7147 014332 042767 177400 165544 BIC #HYBYTE, TEMP
7148
7149 ; IF NOT THE EXPECTED TERMINAL ADDRESS, THEN REPORT THE ERROR AND
7150 ; EXIT WITH ERROR SET
7151 ;
7152 014340 026767 165540 165534 CMP TEMP, SCRTCH
(9) 014346 001406 BEQ 50007$
7153 014350 104463 TRAP T$ERCODE
(5) 014352 000003 WORD 3
(5) 014354 002345 WORD MSG03
(5) 014356 003674 WORD AREA03
7154 014360 000261 SEC
(4) 014362 000416 BR 50001$
7155 014364 50007$
7156 014364 50006$
7157
7158 ; IF CRC WAS IN ERROR, SKIP ABOVE CODE, COME TO HEPE, REPORT ERROR AND
7159 ; EXIT WITH ERROR SET
7160 ;
7161 014364 000414 BR 50010$
(3) 014366 50004$
7162 014366 016767 165510 167364 MOV SCRTCH, A04R0
7163 014374 016767 165504 167360 MOV TEMP, A04EX
7164 014402 104463 TRAP T$ERCODE
(5) 014404 000004 WORD 4
(5) 014406 002411 WORD MSG04
(5) 014410 003726 WORD AREA04
7165 014412 000261 SEC
(4) 014414 000401 BR 50001$
7166 014416 50010$
7167 014416 50003$
7168
7169 NORMAL RETURN
7170 ;
7171 014416 50000$
(2) 014416 000241 CLC
(3) 014420 50001$
(3) 014420 010406 MOV P4, SP
(3) 014422 012604 MOV (SP)+, R4
(2) 014424 000207 RTS PC
7172
7173
7174
7175
7176

```

| | | | | | |
|------|--------|--------|--------|--------|---|
| 7177 | | | | | ***** |
| 7178 | | | | | THIS ROUTINE SETS UP AND CHECKS FOR COMPLETE TRANSMISSION + |
| 7179 | | | | | RETURNS AN ERROR FLAG IF ANY ERROR OCCURS DURING TRANSMISSION + |
| 7180 | | | | | SET "ABORT" IF INITIALIZATION OF THE DEVICE FAILS + |
| 7181 | | | | | ***** |
| 7182 | 014426 | | | | XMIT: |
| 7185 | 014426 | 010446 | | | MOV R4, -(SP) |
| (2) | 014430 | 010604 | | | MOV SP, R4 |
| (3) | 014432 | 162706 | 000002 | | SUB #2, SP |
| 7186 | | | | | |
| 7187 | | | | | CLEAR ERROR COUNT, TRANSMIT DONE FLAG AND RECEIVE DONE FLAG |
| 7188 | | | | | |
| 7189 | 014436 | 005064 | 177776 | | CLR B(R4) |
| 7190 | 014442 | 005067 | 000270 | | CLR XDONE |
| 7191 | 014446 | 005067 | 000266 | | CLR RDONE |
| 7192 | | | | | |
| 7193 | | | | | START OF LOOP |
| 7194 | | | | | |
| 7195 | 014452 | | | | 50002\$. |
| 7196 | | | | | |
| 7197 | | | | | TRY TO INIT DEVICE |
| 7198 | | | | | |
| 7199 | 014452 | 004767 | 000264 | | JSR PC, DEVINIT |
| 7200 | | | | | |
| 7201 | | | | | IF ERROR OCCURRED. |
| 7202 | | | | | |
| 7203 | 014456 | 103033 | | | BCC 50003\$ |
| 7204 | 014460 | 010146 | | | MOV R1, -(SP) |
| 7205 | 014462 | 010246 | | | MOV R2, -(SP) |
| 7206 | | | | | |
| 7207 | | | | | GET A COPY OF THE DEVICE REGISTERS |
| 7208 | | | | | |
| 7209 | 014464 | 016701 | 165500 | | MOV PTAB1 E, R1 |
| 7211 | 014470 | 012702 | 002224 | | MOV #DUPREG, R2 |
| 7217 | 014474 | 016162 | 000000 | 000000 | MOV RCVCSR(R1), RCVCSR(R2) |
| 7218 | 014502 | 016152 | 000002 | 000002 | MOV RCVBUF(R1), RCVBUF(R2) |
| 7219 | 014510 | 016162 | 000004 | 000004 | MOV XMTCSR(R1), XMTCSR(R2) |
| 7220 | 014516 | 016162 | 000006 | 000006 | MOV XMTBUF(R1), XMTBUF(R2) |
| 7231 | 014524 | 012602 | | | MOV (SP)+, R2 |
| 7232 | 014526 | 012601 | | | MOV (SP)+, R1 |
| 7233 | | | | | |
| 7234 | | | | | REPORT THE ERROR AND UPDATE THE ERROR COUNT |
| 7235 | | | | | |
| 7236 | 014530 | 104463 | | | TRAP TSERCODE |
| (5) | 014532 | 000027 | | | WORD 23 |
| (5) | 014534 | 002722 | | | WORD MSG23 |
| (5) | 014536 | 004072 | | | WORD AREA23 |
| 7237 | 014540 | 005264 | 177776 | | INC B(R4) |
| 7238 | | | | | |
| 7239 | | | | | OTHERWISE, CLEAR THE ERROR COUNT |
| 7240 | | | | | |
| 7241 | 014544 | 000402 | | | BR 50004\$ |
| (3) | 014546 | | | | 50003\$ |
| 7242 | 014546 | 005064 | 177776 | | CLR B(R4) |
| 7243 | 014552 | | | | 50004\$ |
| 7244 | | | | | |

```

7245 ; IF ERROR COUNT HAS EXCEEDED LIMITS, ABORT AND NEGATE THE COUNT
7246 ;
7247 014552 026467 177776 165334      CMP      B(R4), ILIMIT
(9) 014560 001010                      BNE      50005$
7248 014562 104462                      TRAP     TSERCODE
(5) 014564 000000                      .WORD   0
(5) 014566 002234                      .WORD   MSG00
(5) 014570 003510                      .WORD   AREA00
7249 014572 005267 165310              INC      ABORT
7250 014576 005464 177776              NEG      B(R4)
7251 014602      50005$
7252 ;
7253 ;                               END OF LOOP
7254 ;EXIT LOOP WHEN ERROR COUNT IS ZERO OR NEGATIVE (ABORT)
7255 ;
7256 014602 005764 177776              TST      B(R4)
(6) 014606 003321                      BGT      50002$
7257 ;
7258 ; IF NOT ABORT THEN EXECUTE THE FOLLOWING CODE
7259 ; OTHERWISE SKIP AND RETURN WITH ERROR SET
7260 ;
7261 014610 005764 177776              TST      B(R4)
(9) 014614 001042                      BNE      50006$
7262 ;
7263 ;WAIT FOR TRANSMIT DONE FLAG TO SET
7264 ;
7265 014616      50007$
7266 014616 104022                      EMT      C$BRK
7267 014620 005767 000112              TST      XDONE
(6) 014624 001774                      BEQ      50007$
7268 ;
7269 ; IF TRANSMIT FLAG IS NEGATIVE, AN ERROR OCCURPED
7270 ;
7271 014626 005767 000104              TST      XDONE
(9) 014632 002032                      BGE      50010$
7272 014634 010146                      MOV      R1, -(SP)
7273 014636 010246                      MOV      R2, -(SP)
7274 ;
7275 ; IF ERROR, GET COPY OF DEVICE REGISTERS, PRINT MESSAGE AND EXIT WITH ERROR SET
7276 ; OTHERWISE DO A NORMAL EXIT
7277 ;
7278 014640 016701 165324              MOV      PTABLE, R1
7280 014644 012702 002224              MOV      #DUPREG, R2
7286 014650 016162 000000 000000      MOV      RCUCSR(R1), RCUCSR(R2)
7287 014656 016162 000002 000002      MOV      RCUBUF(R1), RCUBUF(R2)
7288 014664 016162 000004 000004      MOV      XMTCSR(R1), XMTCSR(R2)
7289 014672 016162 000006 000006      MOV      XMTBUF(R1), XMTBUF(R2)
7300 014700 012602                      MOV      (SP)+, R2
7301 014702 012601                      MOV      (SP)+, R1
7302 014704 104463                      TRAP     TSERCODE
(5) 014706 000030                      .WORD   24
(5) 014710 002762                      .WORD   MSG24
(5) 014712 004072                      .WORD   AREA24
7303 014714 000261                      SEC
(4) 014716 000404                      BR       50001$
7304 014720      50010$
  
```

7305 014720 000402
 (3) 014722
 7306 014722 000261
 (4) 014724 000401
 7307 014726
 7308 014726
 (2) 014726 000241
 (3) 014730
 (3) 014730 010406
 (3) 014732 012604
 (2) 014734 000207
 7309 014736 000000
 7310 014740 000000
 7311
 7312
 7313
 7314
 7315
 7316
 7317
 7318
 7319
 7320
 7321
 7322
 7323
 7324
 7325
 7327
 7328 014742
 7331 014742 010446
 (2) 014744 010604
 (3) 014746 162706 000002
 7332 014752 010146
 7333
 7334
 7335
 7336 014754 016701 165210
 7337
 7338
 7339
 7340
 7341 014760 052761 000400 000004
 7342 014766 052761 000002 000000
 7343 014774 052761 101226 000002
 7344
 7345
 7346
 7347 015002 005067 000402
 7348
 7349
 7350
 7351 015006
 7352
 7353
 7354

50006\$: BR 50011\$
 SEC
 BR 50001\$
 50011\$
 50000\$
 CLC
 50001\$: MOV R4, SP
 MOV (SP)+, R4
 RTS PC
 XDONE 0
 RDONE 0

 ROUTINE TO INITIALIZE A DEVICE
 IF "INIT" IS NON-ZERO, THE ROUTINE WILL EXECUTE AND SET IT
 RETURNS WITH AN ERROR IF CTS CANNOT BE SET
 RETURNS WITH ERROR AND "ABORT" SET IF THE DEVICE DOES
 NOT EXIST

DEVINIT
 MOV R4, -(SP)
 MOV SP, R4
 SUB #2, SP
 MOV R1, -(SP)
 GET THE DEVICE ADDRESS
 MOV PTABLE, R1
 DO MASTER CLEAR, SET DATA TERMINAL READY, AND SET
 PARAMETER REGISTER (DEC MODE, AUTO-CRC INHIBIT, SYNC CHARACTER)
 BIS #MASCLR, XMTCSR(R1)
 BIS #DTR, RCVCSR(R1)
 BIS #PARAM, RCVBUF(R1)
 SET TIMER TO ZERO
 CLR TIMER
 LOOP
 50002\$
 SET REQUEST TO SEND AND WAIT 10000 MICROSECS

| | | | | | | |
|------|--------|--------|--------|--------|--|-----------------|
| 7355 | 015006 | 052711 | 000004 | | BIS | #RTS, (R1) |
| 7356 | 015012 | 012700 | 000100 | | MOV | #100, R0 |
| (3) | 015016 | 104027 | | | EMT | C\$WTU |
| 7357 | | | | | | |
| 7358 | | | | | GET THE CTR TO SEND BIT AND UPDATE THE TIMER | |
| 7359 | | | | | | |
| 7360 | 015020 | 011164 | 177776 | | MOV | (R1), A(R4) |
| (6) | 015024 | 016446 | 177776 | | MOV | A(R4), -(SP) |
| (6) | 015030 | 042716 | 020000 | | BIC | #CTS, (SP) |
| (6) | 015034 | 042664 | 177776 | | BIC | (SP)+, A(R4) |
| 7361 | 015040 | 005267 | 000344 | | INC | TIMER |
| 7362 | | | | | | |
| 7363 | | | | | | END LOOP |
| 7364 | | | | | LOOP ENDS WHEN TIMER EXCEEDS LIMIT OR CLEAR TO SEND IS UP | |
| 7365 | | | | | | |
| 7366 | 015044 | 026767 | 000340 | 165036 | COMP | TIMER, TIM LIM |
| (6) | 015052 | 001403 | | | BEQ | 50003\$ |
| (4) | 015054 | 005764 | 177776 | | TST | A(R4) |
| (7) | 015060 | 001752 | | | BEQ | 50002\$ |
| (4) | 015062 | | | | | 50003\$ |
| 7367 | | | | | | |
| 7368 | | | | | IF TIME LIMIT NOT EXCEEDED | |
| 7369 | | | | | | |
| 7370 | 015062 | 026767 | 000322 | 165020 | COMP | TIMER, TIM LIM |
| (9) | 015070 | 001507 | | | BEQ | 50004\$ |
| 7371 | | | | | | |
| 7372 | | | | | GET THE DEVICE PRIORITY AND SET UP THE PECEIVE INTERRUPT HANDLER | |
| 7373 | | | | | | |
| 7374 | 015072 | 012767 | 002170 | 165100 | MOV | #PTABLE, DEVPRI |
| (6) | 015100 | 062767 | 000004 | 165072 | ADD | #4, DEVPRI |
| 7375 | 015106 | 117767 | 165066 | 165064 | MOVB | @DEVPRI, DEVPRI |
| 7376 | 015114 | 042767 | 177400 | 165056 | BIC | #HYBYTE, DEVPRI |
| 7377 | 015122 | 012764 | 002170 | 177776 | MOV | #PTABLE, A(R4) |
| (6) | 015130 | 062764 | 000002 | 177776 | ADD | #2, A(R4) |
| 7378 | 015136 | 016746 | 165036 | | MOV | DEVPRI, -(SP) |
| (6) | 015142 | 012746 | 015634 | | MOV | #RINT, -(SP) |
| (5) | 015146 | 017446 | 177776 | | MOV | @A(R4), -(SP) |
| (4) | 015152 | 012746 | 000003 | | MOV | #3, -(SP) |
| (3) | 015156 | 104037 | | | EMT | C\$SVEC |
| (2) | 015160 | 062706 | 000010 | | ADD | #10, SP |
| 7379 | | | | | | |
| 7380 | | | | | CLEAR THE NEW MESSAGE FLAG | |
| 7381 | | | | | | |
| 7382 | 015164 | 005067 | 000236 | | CLR | NMSG |
| 7383 | 015170 | 017464 | 177776 | 177776 | MOV | @A(R4), A(R4) |
| (6) | 015176 | 062764 | 000004 | 177776 | ADD | #4, A(R4) |
| 7384 | | | | | | |
| 7385 | | | | | SET UP THE TRANSMIT INTERRUPT HANDLER | |
| 7386 | | | | | | |
| 7387 | 015204 | 016746 | 164770 | | MOV | DEVPRI, -(SP) |
| (6) | 015210 | 012746 | 015466 | | MOV | #XINT, -(SP) |
| (5) | 015214 | 016446 | 177776 | | MOV | A(R4), -(SP) |
| (4) | 015220 | 012746 | 000003 | | MOV | #3, -(SP) |
| (3) | 015224 | 104037 | | | EMT | C\$SVEC |
| (2) | 015226 | 062706 | 000010 | | ADD | #10, SP |
| 7388 | | | | | | |

```

7389 ; SET UP COPIES OF THE DEVICE BUFFER REGISTER ADDRESSES
7390 ;
7391 015232 010167 000146      MOV     R1,XMTADD
(6) 015236 062767 000006 000140  ADD     #6,XMTADD
7392 015244 010167 000136      MOV     R1,RCVADD
(6) 015250 062767 000002 000130  ADD     #2,RCVADD
7393 ;
7394 ; SET COUNTERS FOR FOUR SYNC'S AND FOUR FILL CHARACTERS
7395 ;
7396 015256 012767 000004 000126  MOV     #4,SYNCNT
7397 015264 012767 000004 000122  MOV     #4,FLLCNT
7398 ;
7399 ; ENABLE TRANSMIT AND RECEIVE INTERRUPTS.  SET TO FULL DUPLEX
7400 ;
7401 015272 052761 000120 000004  BIS     #TXINTE!SENDFD,XMTCSR(R1)
7402 015300 052761 000120 000000  BIS     #RXINTE,RCVCSR(R1)
7403 ;
7404 ; IF TIME LIMIT WAS EXCEEDED, GET REGISTER CONTENTS, PRINT MESSAGE,
7405 ; AND RETURN WITH ERROR SET
7406 ;
7407 015306 000427      BR      50005$
(3) 015310      50004$
7408 015310 010246      MOV     R2,-(SP)
7409 015312 012702 002224      MOV     #DUPREG,R2
7410 015316 016162 000000 000000  MOV     RCVCSR(R1),RCVCSR(R2)
7411 015324 016162 000002 000002  MOV     RCVBUF(R1),RCVBUF(R2)
7412 015332 016162 000004 000004  MOV     XMTCSR(R1),XMTCSR(R2)
7413 015340 016162 000006 000006  MOV     XMTBUF(R1),XMTBUF(R2)
7414 015346 012602      MOV     (SP)+,R2
7415 015350 012601      MOV     (SP)+,R1
7416 015352 104463      TRAP   T$ERCODE
(5) 015354 000036      WORD   30
(5) 015356 003117      WORD   MSG30
(5) 015360 004266      WORD   AREA30
7417 015362 000261      SEC
(4) 015364 000404      BR      50001$
7418 015366      50005$
7419 ;
7420 ; IF NO ERROR, DO NORMAL EXIT
7421 ;
7422 015366 012601      MOV     (SP)+,R1
7423 015370 005267 000022      INC     INIT
7424 015374      50000$
(2) 015374 000241      CLC
(3) 015376      50001$
(3) 015376 010406      MOV     R4,SP
(3) 015400 012604      MOV     (SP)+,R4
(2) 015402 000207      RTS     PC
7571 ;
7572 ;
7573 015404 000000  XMTADD 0 ; TRANSMIT BUFFER REGISTER ADDRESS
7574 015406 000000  RCVADD 0 ; RECEIVE BUFFER REGISTER ADDRESS
7575 015410 000000  TIMER  0 ; TIMER FOR CLEAR TO SEND OPERATION
7576 015412 000000  SYNCNT 0 ; NUMBER OF SYNC CHARACTERS INSERTED BEFORE DDCMP MESSAGE
7577 015414 000000  FLLCNT 0 ; NUMBER OF FILL CHARACTERS AFTER MESSAGE
7578 015416 000000  INIT   0 ; INITIALIZE COMPLETE FLAG
  
```

| | | | | | |
|------|--------|--------|---------|-----------------|--|
| 7579 | 015420 | 000377 | FIL | 377 | ; FILL CHARACTER |
| 7580 | 015422 | 000000 | XBUFFER | 0 | ; CURRENT TRANSMIT BUFFER POINTER |
| 7581 | 015424 | 000000 | XSIZE | 0 | ; CURRENT TRANSMIT BUFFER SIZE |
| 7582 | 015426 | 000000 | NMSG | 0 | ; NEW MESSAGE EXPECTED FLAG |
| 7583 | 015430 | 000000 | RTEMP1 | 0 | ; CURRENT RECEIVE BUFFER POINTER |
| 7584 | 015432 | 000000 | RTEMP2 | 0 | ; CURRENT RECEIVE BUFFER SIZE |
| 7585 | 015434 | 000000 | CNTFLG | 0 | ; CONTROL FLAG FOR INPUTTING DDCMP MESSAGES |
| 7586 | | | | | |
| 7587 | | | / | RECEIVER QUEUES | |
| 7588 | | | | | |
| 7589 | 015436 | 000000 | RQUEUE | 0 | ; QUEUE POINTER FOR BUFFER PROCESSING |
| 7590 | 015440 | 000000 | RQUE | 0 | ; QUEUE POINTER FOR NEXT AVAILABLE BUFFER |
| 7591 | 015442 | 000000 | RQUET | 0 | ; QUEUE OF BUFFER ADDRESSES AND SIZES |
| 7592 | 015444 | 000000 | | 0 | |
| 7593 | 015446 | 000000 | | 0 | |
| 7594 | 015450 | 000000 | | 0 | |
| 7595 | 015452 | 000000 | | 0 | |
| 7596 | 015454 | 000000 | RQUEB | 0 | |
| 7597 | 015456 | 000000 | RBQUE | 0 | ; QUEUE POINTER FOR NEXT AVAILABLE BUFFER AREA |
| 7598 | 015460 | 000000 | RBQUET | 0 | ; QUEUE OF BUFFER AREAS |
| 7599 | 015462 | 000000 | | 0 | |
| 7600 | 015464 | 000000 | RBQUEB | 0 | |

```

7602
7603          ; TRANSMISSION INTERRUPT HANDLER
7604          ;
7607          ;
7608          ; SET PROCESSOR PRIORITY LEVEL
7609          ;
7610 015466 016700 164506      MOV    DEVPRI,RO
      (3) 015472 104041      EMT    C$SPRI
7611          ;
7612          ; IF SYNC COUNT EQUAL TO ZERO
7613          ;
7614 015474 005767 177712      TST    SYNCNT
      (9) 015500 001047      BNE    50006$
7615          ;
7616          ; CHECK BUFFER SIZE
7617          ; IF GREATER THAN ZERO, THEN
7618          ;
7619 015502 010146      MOV    R1,-(SP)
7620 015504 005767 177714      TST    XSIZE
      (9) 015510 003416      BLE    50007$
7621          ;
7622          ; SEND THE NEXT CHARACTER AND UPDATE POINTER AND COUNT
7623          ;
7624 015512 117701 177704      MOVB   @XBUFFER,R1
7625 015516 042701 177400      BIC    #HYBYTE,R1
7628 015522 042777 000400 177654  BIC    #TSOM,@XMTADD
7631 015530 110177 177650      MOVB   R1,@XMTADD
7632 015534 005267 177662      INC    XBUFFER
7633 015540 005367 177660      DEC    XSIZE
7634          ;
7635          ; IF ALL CHARACTERS SENT, CHECK FILL COUNT
7636          ;
7637 015544 000423      BR     50010$
      (3) 015546      50007$
7638 015546 005767 177642      TST    FLLCNT
      (9) 015552 001406      BEQ    50011$
7639          ;
7640          ; IF FILL COUNT ISN'T ZERO SEND A FILL CHAR AND DECREMENT COUNT
7641          ;
7642 015554 056777 177640 177622  BIS    FIL,@XMTADD
7643 015562 005367 177626      DEC    FLLCNT
7644 015566 000412      BR     50012$
      (3) 015570      50011$
7645          ;
7646          ; IF ALL TRANSMIT DONE, DISABLE TRANSMISSION AND SET DONE FLAG
7647          ;
7648 015570 016701 177610      MOV    XMTADD,R1
      (6) 015574 162701 000006      SUB    #6,R1
7649 015600 005267 177132      INC    XDONE
7650 015604 104021      EMT    C$ABRT
7657 015606 042761 000120 000004  BIC    #TXINTE|SENDFD,XMTCSR(R1)
7660 015614      50012$
7661 015614      50010$
7662 015614 012601      MOV    (SP)+,R1
7663          ;
7664          ; OTHERWISE, SEND A SYNC AND DECREMENT THE SYNC COUNT

```

| | | | | | | |
|------|--------|--------|--------|--------|---|--------------------|
| 7665 | | | | | | |
| 7666 | 015616 | 000405 | | | BR | 500135 |
| (3) | 015620 | | | | 500065 | |
| 7669 | 015620 | 052777 | 000626 | 177551 | BIS | #SYNC!TSOM,@XMTADD |
| 7675 | 015626 | 005367 | 177560 | | DEC | SYNCNT |
| 7676 | 015632 | | | | 500135 | |
| 7677 | | | | | | |
| 7678 | | | | | DO A SUPERVISOR-TYPE RTI | |
| 7679 | | | | | | |
| 7680 | 015632 | | | | L10027 | |
| (2) | 015632 | 000002 | | | RTI | |
| 7682 | | | | | | |
| 7683 | | | | | | |
| 7684 | | | | | | |
| 7685 | | | | | | |
| 7686 | | | | | | |
| 7687 | | | | | | |
| 7688 | | | | | RECEPTION INTERRUPT ROUTINE | |
| 7689 | | | | | | |
| 7691 | | | | | | |
| 7692 | | | | | SET PROCESSOR PRIORITY | |
| 7693 | | | | | | |
| 7694 | 015634 | 016700 | 164340 | | MOV | DEVPRI,RO |
| (3) | 015640 | 104041 | | | EMT | CSSPRI |
| 7695 | 015642 | 010146 | | | MOV | R1,-(SP) |
| 7696 | | | | | | |
| 7697 | | | | | IF NEW MESSAGE FLAG IS RESET | |
| 7698 | | | | | | |
| 7699 | 015644 | 005767 | 177556 | | TST | NMSG |
| (9) | 015650 | 001111 | | | BNE | 500145 |
| 7700 | | | | | | |
| 7701 | | | | | OBTAIN A BUFFER FROM THE QUEUE AND GET THE RECEIVED BYTE | |
| 7702 | | | | | | |
| 7703 | 015652 | 017767 | 177600 | 177550 | MOV | @RBQUE,RTEMP1 |
| 7704 | 015660 | 016777 | 177544 | 177552 | MOV | RTEMP1,@RQUE |
| 7705 | 015666 | 117777 | 177514 | 177534 | MOVB | @RCVADD,@RTEMP1 |
| 7706 | 015674 | 117701 | 177530 | | MOVB | @RTEMP1,R1 |
| 7707 | | | | | | |
| 7708 | | | | | CHECK FOR SYNC/FILL CHARACTER | |
| 7709 | | | | | (LOOKING FOR FIRST NON-SYNC/NON-FILL) | |
| 7710 | | | | | | |
| 7711 | 015700 | 120127 | 000226 | | CMPB | R1,#SYNC |
| (9) | 015704 | 001472 | | | BEQ | 500155 |
| (6) | 015706 | 120167 | 177506 | | CMPB | R1,FIL |
| (9) | 015712 | 001467 | | | BEQ | 500155 |
| 7712 | | | | | | |
| 7713 | | | | | NOT FILL OR SYNC. CHECK FOR ENQ (DDCMP CONTROL MESSAGE) | |
| 7714 | | | | | | |
| 7715 | 015714 | 120127 | 000005 | | CMPB | R1,#ENQ |
| (9) | 015720 | 001027 | | | BNE | 500165 |
| 7716 | | | | | | |
| 7717 | | | | | IF IT IS AN ENQ, SET EXPECTED BYTE COUNT TO 7. SET MESSAGE SIZE | |
| 7718 | | | | | TO 10 (OCTAL) AND UPDATE THE BUFFER QUEUES | |
| 7719 | | | | | | |
| 7720 | 015722 | 012767 | 000007 | 177502 | MOV | #7,RTEMP2 |
| 7721 | 015730 | 062767 | 000002 | 177502 | ADD | #2,RQUE |

| | | | | | | |
|------|--------|--------|--------|--------|----------|--|
| 7722 | 015736 | 012777 | 000010 | 177474 | MOV | #10, RQUE |
| 7723 | 015744 | 062767 | 000002 | 177466 | ADD | #2, RQUE |
| 7724 | 015752 | 026727 | 177462 | 015454 | CMP | RQUE, #RQUEB |
| (9) | 015760 | 003403 | | | BLE | 50017\$ |
| 7725 | 015762 | 012767 | 015442 | 177450 | MOV | #RQUET, RQUE |
| 7726 | 015770 | | | | 50017\$: | |
| 7727 | | | | | ; | |
| 7728 | | | | | ; | SET COUNTER FLAG TO -1 (MESSAGE SIZE COUNT COMPLETE) |
| 7729 | | | | | ; | |
| 7730 | 015770 | 012767 | 177777 | 177436 | MOV | #-1, CNTFLG |
| 7731 | 015776 | 000417 | | | BR | 50020\$ |
| (3) | 016000 | | | | 50016\$ | |
| 7732 | | | | | ; | |
| 7733 | | | | | ; | NOT FILL, SYNC OR ENQ CHECK FOR SOH OR DLE (DDCMP DATA MESSAGE) |
| 7734 | | | | | ; | |
| 7735 | 016000 | 120127 | 000201 | | CMPB | R1, #SOH |
| (8) | 016004 | 001403 | | | BEQ | 50021\$ |
| (6) | 016006 | 120127 | 000220 | | CMPB | R1, #DLE |
| (9) | 016012 | 001007 | | | BNE | 50022\$ |
| (6) | 016014 | | | | 50021\$ | |
| 7736 | | | | | ; | |
| 7737 | | | | | ; | MOVE QUEUE POINTER TO SIZE ENTRY AND SET COUNTER FLAG TO 1 (EXPECT |
| 7738 | | | | | ; | FIRST COUNT BYTE) |
| 7739 | | | | | ; | |
| 7740 | 016014 | 062767 | 000002 | 177416 | ADD | #2, PQUE |
| 7741 | 016022 | 012767 | 000001 | 177404 | MOV | #1, CNTFLG |
| 7742 | 016030 | 000402 | | | BR | 50023\$ |
| (3) | 016032 | | | | 50022\$ | |
| 7743 | | | | | ; | |
| 7744 | | | | | ; | BYTE WASN'T ANY OF THE LEGAL CHARACTERS FORCE |
| 7745 | | | | | ; | A RESTART BY FORCING THE NEW MESSAGE FLAG TO PESET ON EXIT |
| 7746 | | | | | ; | |
| 7747 | 016032 | 005367 | 177370 | | DEC | NMSG |
| 7748 | 016036 | | | | 50023\$: | |
| 7749 | 016036 | | | | 50020\$ | |
| 7750 | | | | | ; | |
| 7751 | | | | | ; | COUNT THE CHARACTER AND UPDATE THE FREE BUFFER QUEUE |
| 7752 | | | | | ; | |
| 7753 | 016036 | 005267 | 177366 | | INC | RTEMP1 |
| 7754 | 016042 | 062767 | 000002 | 177406 | ADD | #2, RBQUE |
| 7755 | 016050 | 026727 | 177402 | 015464 | CMP | RBQUE, #RBQUEB |
| (9) | 016056 | 003403 | | | BLE | 50024\$ |
| 7756 | 016060 | 012767 | 015460 | 177370 | MOV | #RBQUET, RBQUE |
| 7757 | 016066 | | | | 50024\$: | |
| 7758 | | | | | ; | |
| 7759 | | | | | ; | SET THE NEW MESSAGE FLAG |
| 7760 | | | | | ; | EXIT ROUTINE |
| 7761 | | | | | ; | |
| 7762 | 016066 | 005267 | 177334 | | INC | NMSG |
| 7763 | 016072 | | | | 50015\$: | |
| 7764 | | | | | ; | |
| 7765 | | | | | ; | NEW MESSAGE FLAG IS SET . CONTINUE BUILDING MESSAGE |
| 7766 | | | | | ; | |
| 7767 | 016072 | 000513 | | | BR | 50025\$ |
| (3) | 016074 | | | | 50014\$: | |
| 7768 | | | | | ; | |

```

7769      ,NOT A NEW MESSAGE...GET BYTE AND STORE IT
7770
7771 016074 117777 177306 177326      MOVB   @RCVADD,@RTEMP1
7772
7773      ; IF COUNTER FLAG IS GREATER THAN ZERO, BYTE IS ALSO THE FIRST COUNT BYTE
7774      ;
7775 016102 005767 177326      TST    CNTFLG
(9) 016106 003413      BLE    50026$
7776
7777      ; PUT THE BYTE IN RTEMP2 (EXPECTED COUNT), UPDATE THE BUFFER POINTER
7778      ; DECREMENT THE COUNTER FLAG (SET TO GET SECOND COUNT BYTE) AND
7779      ; GO DO AN RTI
7780
7781 016110 117767 177314 177314      MOVB   @RTEMP1,RTEMP2
7782 016116 042767 177400 177306      BIC    #HYBYTE,RTEMP2
7783 016124 005267 177300      INC    RTEMP1
7784 016130 005367 177300      DEC    CNTFLG
7785 016134 000472      BR     50027$
(3) 016136      50026$
7786
7787      ; COUNTER FLAG NOT GREATER THAN ZERO, IS IT ZERO?
7788
7789 016136 005767 177272      TST    CNTFLG
(9) 016142 001041      BNE    50030$
7790
7791      ; IF ZERO, BYTE IS ALSO SECOND BYTE OF COUNT (6 HIGH ORDER BITS)
7792      ; GET IT, MASK IT AND PUT IT INTO RTEMP2 (EXPECTED COUNT)
7793
7794 016144 010146      MOV    R1,-(SP)
7795 016146 117701 177256      MOVB   @RTEMP1,R1
7796 016152 005267 177252      INC    RTEMP1
7797 016156 000301      SWAB   R1
7798 016160 042701 140377      BIC    #140377,R1
7799 016164 060167 177242      ADD    R1,RTEMP2
7800 016170 012601      MOV    (SP)+,R1
7801
7802      ; PUT THE COMPLETE SIZE IN THE QUEUE (EXPECTED COUNT +
7803      ; 12 (OCTAL) BYTES OF HEADER AND CRC)
7804
7805 016172 016777 177234 177240      MOV    RTEMP2,@RQUE
7806 016200 062777 000012 177232      ADD    #12,@RQUE
7807
7808      ; ADJUST EXPECTED COUNT TO INCLUDE THE REMAINDER OF THE HEADER AND
7809      ; THE DATA CRC
7810
7811 016206 062767 000007 177216      ADD    #7,RTEMP2
7812
7813      ; UPDATE THE QUEUE AND DECREMENT THE COUNTER FLAG (COUNT COMPLETE)
7814
7815 016214 062767 000002 177216      ADD    #2,RQUE
7816 016222 026727 177212 015454      CMP    RQUE,#RQUEB
(9) 016230 003403      BLE    50031$
7817 016232 012767 015442 177200      MOV    #RQUET,RQUE
7818 016240      50031$
7819 016240 005367 177170      DEC    CNTFLG
7820

```

```

7821      ; GO DO AN RTI
7822      ;
7823 016244 000426      ; BR      500325
(3) 016246      ; 500305
7824      ;
7825      ; COUNTER FLAG IS LESS THAN ZERO THIS IS A DATA BYTE
7826      ; UPDATE POINTER AND COUNT
7827      ;
7828 016246 005267 177156      ; INC      RTEMP1
7829 016252 005367 177154      ; DEC      RTEMP2
7830      ;
7831      ; IF COUNT HAS REACHED ZERO, END OF MESSAGE SET DONE FLAG
7832 016256 005767 177150      ; TST      RTEMP2
(9) 016262 001017      ; BNE      500335
7833 016264 005267 176450      ; INC      RDONE
7834      ;
7835      ;
7836      ; FORCE DUP TO RESTART RECEPTION
7837      ;
7838 016270 016701 177112      ; MOV      RCVADD,R1
(6) 016274 162701 000002      ; SUB      #2,R1
7839 016300 042761 000020 000000      ; BIC      #RCENBL,RCVCSR(R1)
7840 016306 052761 000020 000000      ; BIS      #RCENBL,RCVCSR(R1)
7841      ;
7842      ;
7843      ; ABORT ANY WAITS AND RESET NEW MESSAGE FLAG
7844      ;
7845 016314 104021      ; EMT      CSABRT
7846 016316 005067 177104      ; CLR      NMSG
7847 016322      ; 500335
7848 016322      ; 500325
7849 016322      ; 500275
7850 016322      ; 500255
7851      ;
7852      ; DO RTI
7853      ;
7854 016322 012601      ; MOV      (SP)+,R1
7855 016324      ; L10030
(2) 016324 000002      ; RTI
7856      ;
7857      ;
7858      ;
7859      ;
7860      ; ++++++
7861      ;
7862      ; ROUTINE TO GET AN INPUT BUFFER FROM THE INPUT QUEUES
7863      ;
7864      ; WILL RETURN AN ERROR IF TERMINAL DOES NOT RESPOND
7865      ;
7866      ; ARGUMENT (IF SET) INHIBITS ERROR PRINTOUT THIS ALLOWS
7867      ; THE PROGRAM TO RETRY THE STRT-STACK SEQUENCE WITHOUT HAVING
7868      ; AN ERROR MESSAGE EACH TIME
7869      ; ++++++
7870      ;
7871 016326      ; RCVE
7872      ;
7873      ; RESET TIMER
7874      ;
  
```

```

7875 016326 016767 161446 177054      MOV    O.TIMER
7876
7877      ; GO TO SUPERVISOR FOR AWHILE AND INCREMENT TIMER
7878
7879 016334      50002$.
7880 016334 012700 000100      MOV    #100,RO
(3) 016340 104027      EMT    CSWTU
7881 016342 005267 177042      INC    TIMER
7882
7883      ; LOOP UNTIL TIME LIMIT EXCEEDED OR RECEIVER DONE FLAG IS SET
7884
7885 016346 026767 177036 163534      CMP    TIMER,TIMLIM
(6) 016354 003003      BGT    50003$
(4) 016356 005767 176356      TST    RDONE
(7) 016362 001764      BEQ    50002$
(4) 016364      50003$.
7886
7887      ; RESET THE NEW MESSAGE FLAG
7888
7889 016364 005067 177036      CLR    NMSG
7890
7891      ; IF THE TIME LIMIT WASN'T EXCEEDED
7892
7893 016370 026767 177014 163512      CMP    TIMER,TIMLIM
(9) 016376 002044      BGE    50004$
7894
7895      ; RESET THE TIMER
7896      ; CHECK FOR ERROR (RDONE LESS THAN ZERO)
7897
7898 016400 005067 177004      CLR    TIMER
7899 016404 005767 176330      TST    RDONE
(9) 016410 003426      BLE    50005$
7900
7901      ; NOT ERROR, GET BUFFER ADDRESS AND SIZE FROM QUEUE AND UPDATE QUEUE
7902
7903 016412 017767 177020 163526      MOV    @RQUEUE,INBUF
7904 016420 062767 000002 177010      ADD    #2,RQUEUE
7905 016426 017767 177004 163514      MOV    @RQUEUE,INSIZ
7906 016434 062767 000002 176774      ADD    #2,RQUEUE
7907 016442 026727 176770 015454      CMP    RQUEUE,#RQUEB
(9) 016450 003403      BLE    50006$
7908 016452 012767 015442 176756      MOV    #RQUET,RQUEUE
7909 016460      50006$.
7910
7911      ; RESET DONE FLAG AND LEAVE
7912
7913 016460 005067 176254      CLR    RDONE
7914 016464 000410      BR     50007$
(3) 016466      50005$.
7915
7916      ; ERROR DID OCCUR. . RESET THE DONE FLAG, REPORT ERPOP, RETURN WITH ERROR
7917
7918 016466 005067 176246      CLR    RDONE
7919 016472 104463      TRAP  T$ERCODE
(5) 016474 000032      WORD  26
(5) 016476 003062      WORD  MSG26
  
```

```

(5) 016500 004264          WORD AREA26
7920 016502 000261          SEC
(4) 016504 000443          BR 50001$
7921 016506 50007$          BR 50010$
7922 016506 000441          BR 50010$
(3) 016510 50004$
7923
7924 ; TIME LIMIT EXCEEDED... RESET TIMER, GET REGISTER CONTENTS
7925 ;
7926 016510 005067 176674    CLR TIMER
7927 016514 010146          MOV R1, -(SP)
7928 016516 016701 176664    MOV RCVADD, R1
(6) 016522 162701 000002    SUB #2, R1
7929 016526 010246          MOV R2, -(SP)
7931 016530 012702 002224    MOV #DUPREG, R2
7936 016534 016162 000000 000000 MOV RCVCSR(R1), RCVCSR(R2)
7937 016542 016162 000002 000002 MOV RCVBUF(R1), RCVBUF(R2)
7938 016550 016162 000004 000004 MOV XMTCSR(R1), XMTCSR(R2)
7939 016556 016162 000006 000006 MOV XMTBUF(R1), XMTBUF(R2)
7940 016564 012602          MOV (SP)+, R2
7941 016566 012601          MOV (SP)+, R1
7942
7943 ; IF NOT INHIBITED, PRINT ERROR MESSAGE
7944 ;
7945 016570 005765 000000    TST DDSTRT(R5)
(9) 016574 001004          BNE 50011$
7946 016576 104463          TRAP T$ERCODE
(5) 016600 000037          WORD 31
(5) 016602 003147          WORD MSG31
(5) 016604 004266          WORD AREA31
7947 016606 50011$
7948
7949 ; RETURN WITH ERROR IN ANY CASE
7950 ;
7951 016606 000261          SEC
(4) 016610 000401          BR 50001$
7952 016612 50010$
7953 016612 50000$
(2) 016612 000241          CLC
(3) 016614 50001$
(2) 016614 000207          RTS PC
7954
7955
7956
7957
7958
7960 ; ++++++
7961 ; DUMMY ROUTINE FOR COMPATIBILITY
7962 ; ++++++
7963 ;
7964 ; ++++++
7965 016616 50000$          INSERR
7966 016616 50001$
(3) 016616 50001$
(2) 016616 000207          RTS PC
8029

```

8030
8031
8032
8033
8034
8035
8036
8037
8038
8039
8040
8041
8042
8043
8044
8045
8046 016620
8049 016620 010446
(2) 016622 010604
(3) 016624 162706 000C04
8050 016630 010146
8051 016632 010246
8052 016634 010346
8053 016636 016501 000000
8054 016642 016502 000002
8055 016646 005003
8056 016650 500025
(6) 016650 005702
(9) 016652 003500
8057 016654 112164 177776
8058 016660 042764 177400 177776
8059 016666 005302
8060 016670 010346
(6) 016672 046416 177776
(6) 016676 040364 177776
(6) 016702 052664 177776
8061 016706 016464 177776 177774
8062 016714 042764 177760 177776
8063 016722 006364 177776
8064 016726 062764 017074 177776
8065 016734 017464 177776 177776
8066 016742 042764 177417 177774
8067 016750 006264 177774
(7) 016754 006264 177774
(7) 016760 006264 177774
8068 016764 062764 017074 177774
8069 016772 062764 000040 177774
8070 017000 017464 177774 177774
8071 017006 016446 177774
(6) 017012 046416 177776
(6) 017016 046464 177774 177776
(6) 017024 052664 177776
8072 017030 042703 000377
8073 017034 000303
8074 017036 016446 177776
(6) 017042 040316

```

+++++
:
: THIS ROUTINE COMPUTES CRC-16 AND REQUIRES THREE ARGUMENTS
: DATA ADDRESS, DATA SIZE (IN BYTES) AND A WORD LOCATION
: FOR THE COMPUTED CRC
: 3 2 1 2.1, 3.2.1 2 4, 3 2.20 1 2, 3 2 20 3 1,
: 3 2.20 6 2, 3.2.20 6 4 AND 3 2 20 10.1
:
: THIS IS A STANDARD ROUTINE FROM DEC'S NETWORK GROUP
:
+++++

```

```

CRC
MOV R4, -(SP)
MOV SP, R4
SUB #4, SP
MOV R1, -(SP)
MOV R2, -(SP)
MOV R3, -(SP)
MOV A(R5), R1
MOV B(R5), R2
CLR R3
500025 TST R2
BLE 500035
MOVB (R1)+, D(R4)
BIC #HYBYTE, D(R4)
DEC R2
MOV R3, -(SP)
BIC D(R4), (SP)
BIC R3, D(R4)
BIS (SP)+, D(R4)
MOV D(R4), E(R4)
BIC #177760, D(R4)
ASL D(R4)
ADD #CRCTAB, D(R4)
MOV @D(R4), D(R4)
BIC #177417, E(R4)
ASR E(R4)
ASR E(R4)
ASR E(R4)
ADD #CRCTAB, E(R4)
ADD #32, E(R4)
MOV @E(R4), E(R4)
MOV E(R4), -(SP)
BIC D(R4), (SP)
BIC E(R4), D(R4)
BIS (SP)+, D(R4)
BIC #LOBYTE, R3
SWAB R3
MOV D(R4), -(SP)
BIC R3, (SP)

```

| | | | | | |
|------|--------|--------|----------|--------|-----------|
| (6) | 017044 | 046403 | 177776 | BIC | D(R4), R3 |
| (6) | 017050 | 052603 | | BIS | (SP)+, R3 |
| 8075 | 017052 | 000676 | | BR | 50002\$ |
| (3) | 017054 | | 50003\$ | | |
| 8076 | 017054 | 010365 | 000004 | MOV | R3, C(R5) |
| 8077 | 017060 | 012603 | | MOV | (SP)+, R3 |
| 8078 | 017062 | 012602 | | MOV | (SP)+, R2 |
| 8079 | 017064 | 012601 | | MOV | (SP)+, R1 |
| 8080 | 017066 | | 50000\$: | | |
| (3) | 017066 | | 50001\$. | | |
| (3) | 017066 | 010406 | | MOV | R4, SP |
| (3) | 017070 | 012604 | | MOV | (SP)+, R4 |
| (2) | 017072 | 000207 | | RTS | PC |
| 8081 | | | | | |
| 8082 | 017074 | 000000 | CRCTAB. | 000000 | |
| 8083 | 017076 | 140301 | | 140301 | |
| 8084 | 017100 | 140601 | | 140601 | |
| 8085 | 017102 | 000500 | | 000500 | |
| 8086 | 017104 | 141401 | | 141401 | |
| 8087 | 017106 | 001700 | | 001700 | |
| 8088 | 017110 | 001200 | | 001200 | |
| 8089 | 017112 | 141101 | | 141101 | |
| 8090 | 017114 | 143001 | | 143001 | |
| 8091 | 017116 | 003300 | | 003300 | |
| 8092 | 017120 | 003600 | | 003600 | |
| 8093 | 017122 | 143501 | | 143501 | |
| 8094 | 017124 | 002400 | | 002400 | |
| 8095 | 017126 | 142701 | | 142701 | |
| 8096 | 017130 | 142201 | | 142201 | |
| 8097 | 017132 | 002100 | | 002100 | |
| 8098 | 017134 | 000000 | | 000000 | |
| 8099 | 017136 | 146001 | | 146001 | |
| 8100 | 017140 | 154001 | | 154001 | |
| 8101 | 017142 | 012000 | | 012000 | |
| 8102 | 017144 | 170001 | | 170001 | |
| 8103 | 017146 | 036000 | | 036000 | |
| 8104 | 017150 | 024000 | | 024000 | |
| 8105 | 017152 | 162001 | | 162001 | |
| 8106 | 017154 | 120001 | | 120001 | |
| 8107 | 017156 | 066000 | | 066000 | |
| 8108 | 017160 | 074000 | | 074000 | |
| 8109 | 017162 | 132001 | | 132001 | |
| 8110 | 017164 | 050000 | | 050000 | |
| 8111 | 017166 | 116001 | | 116001 | |
| 8112 | 017170 | 104001 | | 104001 | |
| 8113 | 017172 | 042000 | | 042000 | |

| | | | | | | |
|------|--------|--------|--------|---------|---|--------------------|
| 8165 | 017300 | 010546 | | | MOV | R5, -(SP) |
| (4) | 017302 | 012745 | 000000 | | MOV | #0, -(R5) |
| (3) | 017306 | 004767 | 177304 | | JSR | PC, INSERR |
| (3) | 017312 | 012605 | | | MOV | (SP)+, R5 |
| 8166 | 017314 | 104463 | | | TRAP | T\$ERCODE |
| (5) | 017316 | 000062 | | | WORD | 50 |
| (5) | 017320 | 003271 | | | WORD | MSG50 |
| (5) | 017322 | 004072 | | | WORD | AREA40 |
| 8167 | 017324 | 104006 | | | EMT | C\$CLP1 |
| 8168 | 017326 | 104032 | | | EMT | C\$EXIT |
| (3) | 017330 | 000314 | | | WORD | L10031- |
| S169 | 017332 | | | 50005\$ | | |
| 8170 | | | | | | |
| 8171 | | | | | , IF MESSAGE WAS NOT AN ACK .. ERROR | |
| 8172 | | | | | , REPORT ERROR, LOOP IF ENABLED, EXIT TEST IF NOT | |
| 8173 | | | | | | |
| 8174 | 017332 | 005767 | 000610 | | TST | MCOMP |
| (9) | 017336 | 001407 | | | BEQ | 50006\$ |
| 8175 | 017340 | 104463 | | | TRAP | T\$ERCODE |
| (5) | 017342 | 000062 | | | WORD | 50 |
| (5) | 017344 | 003271 | | | WORD | MSG50 |
| (5) | 017346 | 004072 | | | WORD | AREA40 |
| 8176 | 017350 | 104006 | | | EMT | C\$CLP1 |
| 8177 | 017352 | 104032 | | | EMT | C\$EXIT |
| (3) | 017354 | 000270 | | | WORD | L10031- |
| 8178 | 017356 | | | 50006\$ | | |
| 8179 | | | | | | |
| 8180 | | | | | , FORCE A RESTART ON THE LINK AND WAIT FOR SELFTEST TO COMPLETE | |
| 8181 | | | | | | |
| 8182 | 017356 | 005067 | 176034 | | CLR | INIT |
| 8183 | 017362 | 012700 | 000400 | | MOV | #400, R0 |
| (3) | 017366 | 104026 | | | EMT | C\$WTM |
| 8184 | | | | | | |
| 8185 | | | | | , SET UP MESSAGE ASKING FOR RESULTS AND SEND IT | |
| 8186 | | | | | | |
| 8187 | 017370 | 016767 | 000564 | 162534 | MOV | MDMSG1, OUTMSG |
| (6) | 017376 | 042767 | 100001 | 162526 | BIC | #100001, OUTMSG |
| 8188 | 017404 | 016767 | 000552 | 162522 | MOV | MDMSG1+2, OUTMSG+2 |
| S189 | 017412 | 004767 | 172642 | | JSR | PC, TEROUT |
| 8190 | | | | | | |
| 8191 | | | | | , IF ERROR INSERT ERROR IN TABLE (MANUF. TESTS ONLY), REPORT ERROR, | |
| 8192 | | | | | , LOOP IF ENABLED, EXIT TEST IF NO LOOPING | |
| 8193 | | | | | | |
| 8194 | 017416 | 103015 | | | BCC | 50007\$ |
| 8195 | 017420 | 010546 | | | MOV | R5, -(SP) |
| (4) | 017422 | 012745 | 000000 | | MOV | #0, -(R5) |
| (3) | 017426 | 004767 | 177164 | | JSR | PC, INSERR |
| (3) | 017432 | 012605 | | | MOV | (SP)+, R5 |
| 8196 | 017434 | 104463 | | | TRAP | T\$ERCODE |
| (5) | 017436 | 000062 | | | WORD | 50 |
| (5) | 017440 | 003271 | | | WORD | MSG50 |
| (5) | 017442 | 004072 | | | WORD | AREA40 |
| 8197 | 017444 | 104006 | | | EMT | C\$CLP1 |
| 8198 | 017446 | 104032 | | | EMT | C\$EXIT |
| (3) | 017450 | 000174 | | | WORD | L10031- |
| 8199 | 017452 | | | 50007\$ | | |

```

8200
8201      ;ACK TERMINAL AND GET ITS RESPONSE
8202      ;
8203      017452      50010$
8204      017452      004767      000170      JSR      PC,OUTREP
8205
8206      ;          HANDLE ERROR IF ONE OCCURED WHILE ACK'ING
8207      ;
8208      017456      103023      BCC      50011$
8209      017460      010546      MOV      R5,-(SP)
      (4) 017462      012745      000000      MOV      #0,-(R5)
      (3) 017466      004767      177124      JSR      PC,INSERR
      (3) 017472      012605      MOV      (SP)+,R5
8210      017474      010546      MOV      R5,-(SP)
      (4) 017476      012745      000001      MOV      #1,-(R5)
      (3) 017502      004767      177110      JSR      PC,INSERR
      (3) 017506      012605      MOV      (SP)+,R5
8211      017510      104463      TRAP     T$ERCODE
      (5) 017512      000062      WORD     50
      (5) 017514      003271      WORD     MSG50
      (5) 017516      004072      WORD     AREA40
8212      017520      104006      EMT      C$CLP1
8213      017522      104032      EMT      C$EXIT
      (3) 017524      000120      WORD     L10031-
8214      017526      50011$
8215
8216      ;          GET THE RESPONSE
8217      ;
8218      017526      162705      000002      SUB      #1*2,R5
      (3) 017532      004767      173656      JSR      PC,TERIN
      (4) 017536      012567      000404      MOV      (R5)+,MCOMP
8219
8220      ;          HANDLE ERROR IF ONE OCCURED
8221      ;
8222      017542      103015      BCC      50012$
8223      017544      010546      MOV      R5,-(SP)
      (4) 017546      012745      000000      MOV      #0,-(R5)
      (3) 017552      004767      177040      JSR      PC,INSERR
      (3) 017556      012605      MOV      (SP)+,R5
8224      017560      104463      TRAP     T$ERCODE
      (5) 017562      000062      WORD     50
      (5) 017564      003271      WORD     MSG50
      (5) 017566      004072      WORD     AREA40
8225      017570      104006      EMT      C$CLP1
8226      017572      104032      EMT      C$EXIT
      (3) 017574      000050      WORD     L10031-
8227      017576      50012$
8228
8229      ;          REPEAT THE LOOP UNTIL A MESSAGE IS RECEIVED
8230      ;
8231      017576      005767      000344      TST      MCOMP
      (6) 017602      001723      BEQ      50010$
8232
8233      ;          PROCESS THE MESSAGE RECEIVED
8234      ;
8235      017604      004767      000146      JSP      PC,STINPT
  
```

```
8236  
8237      IF IN ERROR... INSERT ERROR INTO TABLE (MANUF TESTS ONLY, REPORT  
8238      ERROR, LOOP IF ENABLED, EXIT TEST IF NOT  
8239  
8240      017610 103015      BCC      50013$  
8241      017612 010546      MOV      R5, -(SP)  
      (4) 017614 012745 000001      MOV      #1, -(R5)  
      (3) 017620 004767 176772      JSR      PC, INSERR  
      (3) 017624 012605      MOV      (SP)+, R5  
8242      017626 104463      TRAP     T$ERCODE  
      (5) 017630 000062      WORD     50  
      (5) 017632 003271      WORD     MSG50  
      (5) 017634 004072      WORD     AREA40  
8243      017636 104006      EMT      C$CLP1  
8244      017640 104032      EMT      C$EXIT  
      (3) 017642 000002      WORD     L10031-  
8245      017644      50013$  
8246  
8247      END OF TEST  
8248  
8249      017644      L10031  
      (3) 017644 104001      EMT      C$ETST  
8250  
8251  
8252  
8253  
8254  
8255      ++++++  
8256      ROUTINE TO SEND AND ACK IN ORDER TO POLL A TERMINAL  
8257      ++++++  
8258  
8259      ++++++  
8260      017646      OUTREP  
8261  
8262      INSERT MESSAGE NUMBER (LAST MESSAGE SENT) AND RESPONSE NUMBER  
8263      (LAST MESSAGE RECEIVED) INSERT STATION ADDRESS  
8264  
8265      017646 116767 162312 000320      MOV      MSGNO, MSGN  
8266      017654 116767 162306 000311      MOV      RMSGNO, REPN  
8267      017662 116767 163617 000305      MOV      STRTSA, REPA  
8268  
8269      COMPUTE AND INSEPT CRC  
8270  
8271      017670 162705 000002      SUB      #1*2, R5  
      (3) 017674 010546      MOV      R5, -(SP)  
      (5) 017676 012745 000006      MOV      #6, -(R5)  
      (4) 017702 012745 020170      MOV      #REPM, -(R5)  
      (3) 017706 004767 176706      JSR      PC, CRC  
      (3) 017712 012605      MOV      (SP)+, R5  
      (4) 017714 012567 000256      MOV      (R5)+, REPCRC  
8272  
8273      SET UP BUFFER POINTER AND SIZE AND SEND THE MESSAGE  
8274  
8275      017720 012767 020170 175474      MOV      #REPM, XBUFFER  
8276      017726 012767 000010 175470      MOV      #10, XSIZE  
8277      017734 004767 174466      JSR      PC, XMIT
```

```

8278
8279      ; IF AN ERROR OCCURRED, RETURN WITH ERROR. OTHERWISE RETURN NORMALLY
8280
8281      017740 103004      BCC      50002$
8282      017742 005267 162152      INC      OUTERR
8283      017746 000261      SEC
      (4) 017750 000401      BR       50001$
8284      017752      50002$
8285      017752      50000$
      (2) 017752 000241      CLC
      (3) 017754      50001$
      (2) 017754 000207      RTS      PC
8286
8287
8288
8289
8290
8291      ; ++++++
8292      ; ROUTINE TO PROCESS TERMINAL SELFTEST RESULTS
8293      ; ++++++
8294      ; ++++++
8295      ; ++++++
8296      017756      STINPT
8297      017756 010146      MOV      R1, -(SP)
8298      017760 010246      MOV      R2, -(SP)
8299      017762 010346      MOV      R3, -(SP)
8300
8301      ; SKIP RESPONSE HEADER AND CHECK FIRST DATA BYTE
8302
8303      017764 016701 162156      MOV      INBUF, R1
      (6) 017770 062701 000004      ADD      #4, R1
8304
8305      ; IF IT IS "A", GOOD RESPONSE OTHERWISE
8306
8307      017774 121127 000101      CMPB    (R1), #101
      (9) 020000 001455      BEQ     50002$
8308
8309      ; GET THE BYTE AND CHECK TO SEE IF IT IS "M" (MEMORY ERROR)
8310
8311      020002 112103      MOVB   (R1)+, P3
8312      020004 120327 000115      CMPB   R3, #115
      (9) 020010 001026      BNE    50003$
8313
8314      ; MEMORY ERROR GET THE TYPE AND BANK NUMBER
8315      ; INSERT INTO ERROR MESSAGE, REPORT THE ERROR AND
8316      ; RETURN WITH ERROR
8317      ; (NOTE: ERROR REPORTING PROTOCOL DELIMITERS ARE
8318      ; IGNORED THIS PROGRAM WILL NOT ACCEPT INPUT FROM
8319      ; ANY OTHER INTELLIGENT TERMINAL PROPERLY)
8320
8321      020012 062701 000002      ADD     #2, R1
8322      020016 012702 003446      MOV     #MTY, R2
8323      020022 112122      MOVB   (R1)+, (R2)+
8324      020024 112122      MOVB   (R1)+, (R2)+
8325      020026 012702 003462      MOV     #BNO, R2
8326      020032 062701 000003      ADD     #3, R1
  
```

| | | | | | |
|------|--------|--------|---------|-------|--|
| 8327 | 020036 | 111103 | | MOVB | (R1), R3 |
| 8328 | 020040 | 062703 | 000060 | ADD | #60, R3 |
| 8329 | 020044 | 110312 | | MOVB | R3, (R2) |
| 8330 | 020046 | 104423 | | TRAP | T\$ERCODE |
| (5) | 020050 | 000107 | | WORD | 71 |
| (5) | 020052 | 003422 | | WORD | MSG71 |
| 8331 | 020054 | 012603 | | MOV | (SP)+, R3 |
| 8332 | 020056 | 012602 | | MOV | (SP)+, R2 |
| 8333 | 020060 | 012601 | | MOV | (SP)+, R1 |
| 8334 | 020062 | 000261 | | SEC | |
| (4) | 020064 | 000427 | | BR | 50001\$ |
| 8335 | 020066 | | 50003\$ | | |
| 8336 | | | | | |
| 8337 | | | | | NOT A MEMORY ERROR OR PASS CHECK FOR "P" (PROCESSOR ERROR) |
| 8338 | | | | | |
| 8339 | 020066 | 120327 | 000120 | CMPB | R3, #120 |
| (9) | 020072 | 001010 | | BNE | 50005\$ |
| 8340 | | | | | |
| 8341 | | | | | PROCESSOR ERROR REPORT IT AND EXIT WITH ERROR |
| 8342 | | | | | |
| 8343 | 020074 | 104423 | | TRAP | T\$ERCODE |
| (5) | 020076 | 000110 | | WORD | 72 |
| (5) | 020100 | 003464 | | WORD | MSG72 |
| 8344 | 020102 | 012603 | | MOV | (SP)+, R3 |
| 8345 | 020104 | 012602 | | MOV | (SP)+, R2 |
| 8346 | 020106 | 012601 | | MOV | (SP)+, R1 |
| 8347 | 020110 | 000261 | | SEC | |
| (4) | 020112 | 000414 | | BR | 50001\$ |
| 8348 | 020114 | | 50005\$ | | |
| 8349 | | | | | |
| 8350 | | | | | RESPONSE WAS NOT LEGAL REPORT IT AND RETURN WITH ERROR |
| 8351 | | | | | |
| 8352 | 020114 | 104423 | | TRAP | T\$ERCODE |
| (5) | 020116 | 000106 | | WORD | 70 |
| (5) | 020120 | 003367 | | WORD | MSG70 |
| 8353 | 020122 | 012603 | | MOV | (SP)+, R3 |
| 8354 | 020124 | 012602 | | MOV | (SP)+, R2 |
| 8355 | 020126 | 012601 | | MOV | (SP)+, R1 |
| 8356 | 020130 | 000261 | | SEC | |
| (4) | 020132 | 000404 | | BR | 50001\$ |
| 8357 | 020134 | | 50006\$ | | |
| 8358 | 020134 | | 50004\$ | | |
| 8359 | 020134 | | 50002\$ | | |
| 8360 | 020134 | 012603 | | MOV | (SP)+, R3 |
| 8361 | 020136 | 012602 | | MOV | (SP)+, R2 |
| 8362 | 020140 | 012601 | | MOV | (SP)+, R1 |
| 8363 | 020142 | | 50000\$ | | |
| (2) | 020142 | 000241 | | CLC | |
| (3) | 020144 | | 50001\$ | | |
| (2) | 020144 | 000207 | | RTS | PC |
| 8364 | | | | | |
| 8365 | | | | | |
| 8366 | | | | | MESSAGE AREA FOR SELFTEST |
| 8367 | | | | | |
| 8368 | 020146 | 000000 | | MCOMP | 0 |
| 8369 | 020150 | 020154 | | MDMSG | +4 |

| | | | | | | |
|------|--------|--------|--------|---------|------|--|
| 8445 | 020264 | 012701 | 021066 | | MOV | #LOOPB,R1 |
| 8446 | 020270 | 005767 | 171150 | | TST | PATTERN |
| (9) | 020274 | 001403 | | | BEQ | 500105 |
| 8447 | 020276 | 005067 | 161600 | | CLR | SCRATCH |
| 8448 | 020302 | 000403 | | | BR | 500115 |
| (3) | 020304 | | | 500105 | | |
| 8449 | 020304 | 012767 | 125125 | 161570 | MOV | #125125,SCRATCH |
| 8450 | 020312 | | | 500115. | | |
| 8451 | 020312 | | | 500125. | | |
| 8452 | 020312 | 016721 | 161564 | | MOV | SCRATCH,(R1)+ |
| 8453 | 020316 | 020127 | 021466 | | CMP | R1,#ELOOPB |
| (6) | 020322 | 001373 | | | BNE | 500125 |
| 8454 | | | | | | |
| 8455 | | | | | | PUT A 1 AT THE END TO ASSURE THAT THE FINAL BYTE IS NOT NULL (0) |
| 8456 | | | | | | |
| 8457 | 020324 | 012701 | 021466 | | MOV | #ELOOPB,R1 |
| (6) | 020330 | 005301 | | | DEC | R1 |
| 8458 | 020332 | 112711 | 000001 | | MOVB | #1,(R1) |
| 8459 | | | | | | |
| 8460 | | | | | | GET THE STATION ADDRESS AND INSERT IT IN THE HEADER |
| 8461 | | | | | | |
| 8462 | 020336 | 012701 | 002170 | | MOV | #PTABLE,R1 |
| (6) | 020342 | 062701 | 000005 | | ADD | #5,R1 |
| 8463 | 020346 | 111167 | 000511 | | MOVB | (R1),LOOSTA |
| 8464 | 020352 | 012601 | | | MOV | (SP)+,R1 |
| 8465 | | | | | | |
| 8466 | | | | | | INSERT LOOP DATA TYPE |
| 8467 | | | | | | |
| 8468 | 020354 | 112767 | 000024 | 000504 | MOVB | #OSOP,LOOPB |
| 8469 | | | | | | |
| 8470 | | | | | | SET MESSAGE NUMBER |
| 8471 | | | | | | |
| 8472 | 020362 | 112767 | 000001 | 000472 | MOVB | #1,LOOPN |
| 8473 | | | | | | |
| 8474 | | | | | | COMPUTE AND INSERT HEADER CRC |
| 8475 | | | | | | |
| 8476 | 020370 | 162705 | 000002 | | SUB | #1*2,R5 |
| (3) | 020374 | 010546 | | | MOV | R5,-(SP) |
| (5) | 020376 | 012745 | 000006 | | MOV | #6,-(R5) |
| (4) | 020402 | 012745 | 021056 | | MOV | #LOOPB,-(R5) |
| (3) | 020406 | 004767 | 176206 | | JSR | PC,CRC |
| (3) | 020412 | 012605 | | | MOV | (SP)+,R5 |
| (4) | 020414 | 012567 | 000444 | | MOV | (R5)+,LCRCH |
| 8477 | | | | | | |
| 8478 | | | | | | COMPUTE AND INSERT DATA CRC |
| 8479 | | | | | | |
| 8480 | 020420 | 162705 | 000002 | | SUB | #1*2,R5 |
| (3) | 020424 | 010546 | | | MOV | R5,-(SP) |
| (5) | 020426 | 012745 | 000400 | | MOV | #256,-(R5) |
| (4) | 020432 | 012745 | 021066 | | MOV | #LOOPB,-(R5) |
| (3) | 020436 | 004767 | 176156 | | JSR | PC,CRC |
| (3) | 020442 | 012605 | | | MOV | (SP)+,R5 |
| (4) | 020444 | 012567 | 001016 | | MOV | (R5)+,LCRCD |
| 8481 | | | | | | |
| 8482 | | | | | | SET UP BUFFER POINTER AND SIZE SEND MESSAGE |
| 8483 | | | | | | |

| | | | | | | |
|------|--------|--------|--------|--------|---------|--|
| 8484 | 020450 | 012767 | 021056 | 174744 | MOV | #LOOPH,XBUFFER |
| 8485 | 020456 | 012767 | 000412 | 174740 | MOV | #266.,XSIZE |
| 8486 | 020464 | 004767 | 173736 | | JSR | PC,XMIT |
| 8487 | | | | | | |
| 8488 | | | | | | , IF ERROR OCCURRED... INSERT THE ERROR INTO TABLE (MANUF TESTS ONLY), |
| 8489 | | | | | | , REPORT THE ERROR, LOOP IF ENABLED |
| 8490 | | | | | | |
| 8491 | 020470 | 103012 | | | BCC | 50013\$ |
| 8492 | 020472 | 010546 | | | MOV | R5, -(SP) |
| (4) | 020474 | 012745 | 000000 | | MOV | #0, -(R5) |
| (3) | 020500 | 004767 | 176112 | | JSR | PC, INSERR |
| (3) | 020504 | 012605 | | | MOV | (SP)+, R5 |
| 8493 | 020506 | 104463 | | | TRAP | T\$ERCODE |
| (5) | 020510 | 000063 | | | .WORD | 51 |
| (5) | 020512 | 003326 | | | .WORD | MSG51 |
| (5) | 020514 | 004072 | | | .WORD | AREA40 |
| 8494 | 020516 | | | | 50013\$ | |
| 8495 | 020516 | 104006 | | | EMT | C\$CLP1 |
| 8496 | | | | | | |
| 8497 | | | | | | , SEND ACK'S TO TERMINAL UNTIL IT RESPONDS |
| 8498 | | | | | | |
| 8499 | 020520 | | | | 50014\$ | |
| 8500 | 020520 | 004767 | 177122 | | JSR | PC, OUTREP |
| 8501 | | | | | | |
| 8502 | | | | | | , IF AN ERROR OCCURS INSERT IN TABLE (MAN ONLY), REPORT IT, LOOP |
| 8503 | | | | | | , IF ENABLED - EXIT TEST IF NOT |
| 8504 | | | | | | |
| 8505 | 020524 | 103023 | | | BCC | 50015\$ |
| 8506 | 020526 | 010546 | | | MOV | R5, -(SP) |
| (4) | 020530 | 012745 | 000000 | | MOV | #0, -(R5) |
| (3) | 020534 | 004767 | 176056 | | JSR | PC, INSERR |
| (3) | 020540 | 012605 | | | MOV | (SP)+, R5 |
| 8507 | 020542 | 010546 | | | MOV | R5, -(SP) |
| (4) | 020544 | 012745 | 000002 | | MOV | #2, -(R5) |
| (3) | 020550 | 004767 | 176042 | | JSR | PC, INSERR |
| (3) | 020554 | 012605 | | | MOV | (SP)+, R5 |
| 8508 | 020556 | 104463 | | | TRAP | T\$ERCODE |
| (5) | 020560 | 000063 | | | .WORD | 51 |
| (5) | 020562 | 003326 | | | .WORD | MSG51 |
| (5) | 020564 | 004072 | | | .WORD | AREA40 |
| 8509 | 020566 | 104006 | | | EMT | C\$CLP1 |
| 8510 | 020570 | 104032 | | | EMT | C\$EXIT |
| (3) | 020572 | 000134 | | | .WORD | L10032- |
| 8511 | 020574 | | | | 50015\$ | |
| 8512 | | | | | | |
| 8513 | | | | | | , GET RESPONSE |
| 8514 | | | | | | |
| 8515 | 020574 | 162705 | 000002 | | SUB | #1*2, R5 |
| (3) | 020600 | 004767 | 172610 | | JSR | PC, TERIN |
| (4) | 020604 | 012567 | 000240 | | MOV | (R5)+, LCOMP |
| 8516 | | | | | | |
| 8517 | | | | | | , IF ERROR OCCURS... INSERT IN TABLE (MAN ONLY), REPORT IT, LOOP IF |
| 8518 | | | | | | , ENABLED, EXIT TEST IF NOT |
| 8519 | | | | | | |
| 8520 | 020610 | 103012 | | | BCC | 50016\$ |
| 8521 | 020612 | 010546 | | | MOV | R5, -(SP) |

```
(4) 020614 012745 000000      MOV      #0, -(R5)
(3) 020620 004767 175772      JSR      PC, INSERR
(3) 020624 012605              MOV      (SP)+, R5
8522 020626 104463      TRAP    T$ERCODE
(5) 020630 000063      .WORD   51
(5) 020632 003326      .WORD   MSG51
(5) 020634 004072      .WORD   AREA40
8523 020636              50016$:
8524 020636 104006      EMT      C$CLP1
8525
8526      ; REPEAT LOOP UNTIL TERMINAL SENDS LOOPBACK DATA
8527      ;
8528 020640 005767 000204      TST      LCOMP
(6) 020644 001725      BEQ      50014$
8529
8530      ; PROCESS THE LOOPBACK DATA
8531      ;
8532 020646 004767 000056      JSR      PC, PROLOP
8533 020652 104004      EMT      C$BSEG
8534
8535      ; REINIT THE LINK
8536      ;
8537 020654 004767 171634      JSR      PC, XSTRT
8538
8539      ; IF ERROR OCCURS, INSERT ERROR INTO TABLE (MANUF ONLY), REPORT ERROR,
8540      ; LOOP ON REINIT IF ERROR LOOPING ENABLED  EXIT TEST IF NO LOOPING
8541      ;
8542 020660 103020      BCC      50017$
8543 020662 010546      MOV      R5, -(SP)
(4) 020664 012745 000000      MOV      #0, -(R5)
(3) 020670 004767 175722      JSR      PC, INSERR
(3) 020674 012605      MOV      (SP)+, R5
8544 020676 010546      MOV      R5, -(SP)
(4) 020700 012745 000002      MOV      #2, -(R5)
(3) 020704 004767 175706      JSR      PC, INSERR
(3) 020710 012605      MOV      (SP)+, R5
8545 020712 104463      TRAP    T$ERCODE
(5) 020714 000063      .WORD   51
(5) 020716 003326      .WORD   MSG51
(5) 020720 004610      .WORD   AREA61
8546 020722              50017$:
8547 020722 104006      EMT      C$CLP1
8548 020724              10000$:
(3) 020724 104005      EMT      C$ESEG
8549
8550      ; END OF TEST
8551      ;
8552 020726              L10032
(3) 020726 104001      EMT      C$ETST
8553
8554
8555
8556
8557
8558      ++++++
8559      +
```

```

8560          ;          ROUTINE TO PROCESS LOOPBACK DATA          +
8561          ;          ;                                         +
8562          ;          +-----+
8563 020730    PROLOP.
8564 020730    010146          MOV      R1, -(SP)
8565 020732    010246          MOV      R2, -(SP)
8566 020734    010346          MOV      R3, -(SP)
8567          ;
8568          ; R1 = POINTER TO EXPECTED DATA
8569          ; R2 = COUNT OF DATA EXPECTED
8570          ; R3 = POINTER TO DATA FROM TERMINAL
8571          ;
8572 020736    012701    021066          MOV      #LOOPB, R1
8573 020742    012702    000200          MOV      #128, R2
8574 020746    016703    161174          MOV      INBUF, R3
8575          ;
8576          ; CHECK DATA BYTE-BY-BYTE
8577          ;
8578 020752    50002$.
8579          ;
8580          ; IF ERROR. INSERT ERROR INTO TABLE (MANUF ONLY), REPORT ERROR
8581          ; (INCLUDING RECEIVED/EXPECTED BYTES), RETURN WITH ERROR
8582          ;
8583 020752    121113          CMPB     (R1), (R3)
8584 (9) 020754    001423          BEQ      50003$
8585 020756    011167    164054          MOV      (R1), A52A
8586 020762    011367    164052          MOV      (R3), A52B
8587 (4) 020766    010546          MOV      R5, -(SP)
8588 (3) 020770    012745    000002          MOV      #2, -(R5)
8589 (3) 020774    004767    175616          JSR      PC, INSERR
8590 (3) 021000    012605          MOV      (SP)+, R5
8591 021002    104464          TRAP    T$ERCODE
8592 (5) 021004    000064          WORD    52
8593 (5) 021006    003354          WORD    MSG52
8594 (5) 021010    004740          WORD    AREA52
8595 021012    012603          MOV      (SP)+, R3
8596 021014    012602          MOV      (SP)+, R2
8597 021016    012601          MOV      (SP)+, R1
8598 021020    000261          SEC
8599 (4) 021022    000411          BR      50001$
8600          ;
8601          ; 50003$
8602          ; UPDATE COUNT AND POINTERS
8603          ;
8604          ; INC      R1
8605          ; DEC      R2
8606          ; INC      R3
8607          ;
8608          ; REPEAT UNTIL ALL DATA HAS BEEN CHECKED
8609          ;
8610          ; TST      R2
8611 (6) 021032    005702          BNE     50002$
8612 021034    001346          MOV      (SP)+, R3
8613 021036    012603          MOV      (SP)+, R2
8614 021040    012602          MOV      (SP)+, R1
8615 021042    012601          ;
8616 021044    50000$

```

```

(2) 021044 000241          CLC
(3) 021046          50001$
(2) 021046 000207          RTS    PC
8607
8608
8609          ; LOOPBACK MESSAGE AREA
8610
8611 021050 000000          LCOMP  0
8612 021052 121057          LOOPMG  +100005
8613 021054 000410          ELOOPB-2-
8614 021056      220      000      201  LOOPH  BYTE DLE, 0, 201, 0
      021061      000
8615 021062      000          LOOPN  . BYTE 0
8616 021063      000          LOOSTA . BYTE  0
8617 021064 000000          LCRCH  0
8618 021066 000200          LOOPB  BLKW  128
8619 021466
8620 021466 000000          ELOOPE
8621          LCRCD  0

```

```

8877      ;
8878      ;
8879      ;
8880      021470 000022      . WORD L10033-LSHARD/2
8881      021472 000031      WORD TSCODE
      (4) 021474 021536      WORD DEVICE
      (4) 021476 000000      WORD TSLOLIM
      (4) 021500 177776      WORD TSHILIM
8882      021502 001031      WORD TSCODE
      (4) 021504 021554      WORD VECTOR
      (4) 021506 000000      WORD TSLOLIM
      (4) 021510 000400      WORD TSHILIM
8883      021512 002032      WORD TSCODE
      (4) 021514 021571      WORD PRIOR
      (4) 021516 000340      WORD 340
      (4) 021520 000000      WORD TSLOLIM
      (4) 021522 000007      WORD TSHILIM
8884      021524 002032      WORD TSCODE
      (4) 021526 021614      WORD STATION
      (4) 021530 177400      WORD 177400
      (4) 021532 000000      WORD TSLOLIM
      (4) 021534 000377      WORD TSHILIM
8895      EVEN

```

```

      (3) 021536      L10033
8896
8898      021536 052504 020120 042101 DEVICE . ASCIZ /DUP ADDRESS /
      021544 051104 051505 035123
      021552 000040
8899      021554 052504 020120 042526 VECTOR . ASCIZ /DUP VECTOR /
      021562 052103 051117 020072
      021570 000
8900      021571 104 050125 041040 PRIOR . ASCIZ /DUP BUS PRIORITY. /
      021576 051525 050040 044522
      021604 051117 052111 035131
      021612 000040
8913      021614 042524 046522 047111 STATION . ASCIZ /TERMINAL ADDRESS /
      021622 046101 040440 042104
      021630 042522 051523 020072
      021636 000
8955      021640      . EVEN
8956
8957
8958
8959

```

```

8960      021640 003010      WORD L10034-LSSOFT/2
8961      021642 000032      WORD TSCODE
      (4) 021644 021662      WORD ALIMIT
      (4) 021646 177777      WORD 177777
      (4) 021650 000000      WORD TSLOLIM
      (4) 021652 077777      WORD TSHILIM
8962      021654 001130      WORD TSCODE
      (4) 021656 021731      WORD PATTRN
      (4) 021660 177777      WORD 177777
8966      EVEN
      (3) 021662      L10034
8967      021662 047510 020127 040515 ALIMIT . ASCIZ /HOW MANY INITIATE TRIES BEFORE ACCEPT

```

| | | | | | |
|-------|--------|--------|--------|--------|--|
| | 021670 | 054516 | 044440 | 044516 | |
| | 021676 | 044524 | 052101 | 020105 | |
| | 021704 | 051124 | 042511 | 020123 | |
| | 021712 | 042502 | 047506 | 042522 | |
| | 021720 | 040440 | 047502 | 052122 | |
| | 021726 | 020077 | 000 | | |
| 8968 | 021731 | 125 | 042523 | 040440 | PATTRN .ASCIZ /USE ALL ZERO'S FOR LOOPBACK DATA? / |
| | 021736 | 046114 | 055040 | 051105 | |
| | 021744 | 023517 | 020123 | 047506 | |
| | 021752 | 020122 | 047514 | 050117 | |
| | 021760 | 040502 | 045503 | 042040 | |
| | 021766 | 052101 | 037501 | 000040 | |
| 8972 | | | | | EVEN |
| 8974 | | | | | .EVEN |
| (3) | 021774 | | | | LSLAST |
| 8975 | | | | | REQ DOCTOR P11 400,1066 |
| 8976 | | | | | TITLE PDP-11 DIAGNOSTIC SUPERVISOR |
| 20272 | | 052674 | | | END. SUPV=. +2 |
| 20274 | | 071776 | | | =71776 |
| 20275 | 071776 | 000000 | | | WORD 0 |
| 20277 | | 072000 | | | X1X1= |
| 20278 | | 000200 | | | END 200 |

| | | | | | | | | | | | | | | | | |
|--------|--------|--------|--------|--------|--------|--------|---------|--------|---------|--------|--------|---------|---------|--------|--------|---|
| A | = | 000000 | BIT06 | = | 000100 | G | CODE | 011454 | G | CSQ10 | = | 000377 | EF10 | = | 000012 | G |
| ABOFLA | 022246 | G | BIT07 | = | 000200 | G | COMMTA | 045326 | | CSRDBU | = | 000007 | EF11 | = | 000013 | G |
| ABOPAS | 022160 | G | BIT08 | = | 000400 | G | CONTCL | 051110 | G | CSREFG | = | 000050 | EF12 | = | 000014 | G |
| ABORT | 002106 | | BIT09 | = | 001000 | G | CRC | 016620 | | CSREQT | = | 000045 | EF13 | = | 000015 | G |
| ABO FM | 025122 | | BIT10 | = | 000002 | G | CRCTAB | 017074 | | CSRESE | = | 000033 | EF14 | = | 000016 | G |
| ACK | = | 000001 | BIT11 | = | 002000 | G | CRLF | 041424 | | CSREVI | = | 000001 | EF15 | = | 000017 | G |
| ALIMIT | 021662 | | BIT12 | = | 004000 | G | CTS | = | 020000 | CSRPT | = | 000025 | EF16 | = | 000020 | G |
| ALLOC | 042712 | | BIT13 | = | 010000 | G | CURR. T | 022174 | G | CSSEFG | = | 000047 | ELOOPB | 021466 | | |
| AREA00 | 003510 | G | BIT14 | = | 020000 | G | CSAAD | 034530 | | CSSPRI | = | 000041 | EMDMG1 | 020160 | | |
| AREA01 | 003570 | G | BIT15 | = | 040000 | G | CSAAE | 034542 | | CSVVEC | = | 000037 | EMDMG2 | 020170 | | |
| AREA02 | 003572 | G | BIT2 | = | 000004 | G | CSAAK | 035360 | | CSTPRI | = | 000013 | EMT. TR | 022252 | G | |
| AREA03 | 003674 | G | BIT3 | = | 000010 | G | CSAAL | 035470 | | CSUNBU | = | 000031 | END OF | 030600 | | |
| AREA04 | 003726 | G | BIT4 | = | 000020 | G | CSABRT | = | 000021 | CSWTM | = | 000026 | END SU | = | 052674 | |
| AREA11 | 004030 | G | BIT5 | = | 000040 | G | CSADR | = | 000020 | CSWTU | = | 000027 | ENQ | = | 000005 | |
| AREA21 | 004066 | G | BIT6 | = | 000100 | G | CSAU | = | 000054 | D | = | 177776 | EOMSG | 002124 | | |
| AREA22 | 004070 | G | BIT7 | = | 000200 | G | CSBRK | = | 000022 | DDSTRT | = | 000000 | EOP CH | 051352 | G | |
| AREA23 | 004072 | G | BIT8 | = | 000400 | G | CSBSEG | = | 000004 | DDSTRY | 012772 | | EOP. FM | 025136 | | |
| AREA24 | 004072 | | BIT9 | = | 001000 | G | CSBSUB | = | 000002 | DECMG | 041236 | | EOP IN | 027210 | | |
| AREA26 | 004264 | G | BLD HW | 027712 | | CSBUFF | = | 000030 | DEVICE | 021536 | | ERRFOR | 035546 | | | |
| AREA30 | 004266 | G | BLOCK | 045046 | | CSCEFG | = | 000046 | DEVIN | 014742 | | ERRHAN | 034562 | | | |
| AREA31 | 004266 | | BNC | 003462 | | CSCLEA | = | 000012 | DEVPRI | 002200 | | ERR HR | 035340 | | | |
| AREA40 | 004072 | | BSAAB | 031314 | | CSCLP1 | = | 000006 | DIAG. T | 022254 | G | ERR SF | 035344 | | | |
| AREA41 | 003726 | | BSAAF | 031226 | | CSVEC | = | 000036 | DLE | = | 000220 | ERR1FO | 035632 | | | |
| AREA42 | 003674 | | C | = | 000004 | CSODLN | = | 000044 | DPDVD | 052040 | G | ESC PC | 034554 | | | |
| AREA43 | 003726 | | CALLPC | = | 000022 | CSODDU | = | 000053 | DPMUL | 051726 | G | EXP INP | 002130 | | | |
| AREA52 | 004740 | G | CALLPS | = | 000024 | CSDRPT | = | 000024 | DTR | = | 000002 | FIL | 015420 | | | |
| AREA60 | 004532 | G | CALLSP | = | 000026 | CSDU | = | 000055 | DUNIT. | 022164 | G | FILL | 042072 | | | |
| AREA61 | 004610 | G | CALLTC | = | 000030 | CSEDIT | = | 000006 | DUPMSK | 002220 | G | FILL C | 000204 | G | | |
| AREA70 | 005042 | G | CAL CL | 047430 | | CSERDF | = | 000002 | DUPREG | 002224 | G | FLAGS | 022216 | G | | |
| AREA71 | 005044 | G | CAL TI | 047466 | G | CSERHR | = | 000003 | DUPS | = | 000001 | FLAGTA | 045244 | | | |
| ASAAW | 027032 | | CHKLUP | 031330 | | CSERSF | = | 000001 | DVC FT | 035330 | | FLAG. I | 027256 | | | |
| ASAAZ | 027046 | | CHKREP | 014036 | | CSERSO | = | 000004 | DSAG | 036200 | | FLA. SE | 045212 | | | |
| ASAAZ | 027054 | | CHKSTR | 043254 | | CSESCA | = | 000010 | DSAAH | 036216 | | FLG MA | 027216 | | | |
| ASABA | 027100 | | CHKTTY | 041342 | | CSSEEG | = | 000005 | DSAAI | 040770 | | FLLCNT | 015414 | | | |
| A02A | 003624 | | CHK FO | 023540 | | CSesub | = | 000003 | DSAAJ | 040774 | | FORM. T | 035642 | | | |
| A02B | 003626 | | CHK MA | 027470 | | CSETST | = | 000001 | DSAAK | 041012 | | FORM00 | 003536 | | | |
| A04EX | 003762 | | CHK PC | 034556 | | CSEXIT | = | 000032 | DSAAL | 041030 | | FORM02 | 003630 | | | |
| A04RC | 003760 | | CHRCNT | 042574 | | CSGMAN | = | 000043 | DSAAM | 041040 | | FORM04 | 003764 | | | |
| A52A | 005036 | | CH FLA | 027172 | | CSGPHR | = | 000042 | E | = | 177774 | FORM23 | 004166 | | | |
| A52B | 005040 | | CH PAS | 027214 | | CSGPRI | = | 000040 | EF CON | = | 000036 | G | FORM30 | 004420 | | |
| B | = | 000002 | CLEAR | 030612 | | CSGTIM | = | 000052 | EF NEW | = | 000035 | G | FORM40 | 004206 | | |
| BAPNT | 002160 | | CLKACC | 022156 | G | CSINIT | = | 000011 | EF PWR | = | 000034 | G | FORM52 | 004772 | | |
| BASIZE | 002162 | | CLKBFR | 047432 | | CSINLP | = | 000020 | EF RES | = | 000037 | G | FORM60 | 004554 | | |
| BGN SU | = | 021774 | CLKCNT | 022154 | G | CSKWF | = | 000035 | EF STA | = | 000040 | G | FORM61 | 004702 | | |
| BINMSG | 041222 | | CLKRES | 051030 | G | CSKWON | = | 000034 | EF01 | = | 000001 | G | FREE | 043150 | | |
| BIT0 | = | 000001 | CLKSER | 051330 | G | CSLOOP | = | 000100 | EF02 | = | 000002 | G | FRM30A | 004442 | | |
| BIT00 | = | 000001 | CLKSON | 022220 | G | CSMANI | = | 000051 | EF03 | = | 000003 | G | FRM30B | 004465 | | |
| BIT01 | = | 000002 | CLR MA | 027546 | | CSMSG | = | 000023 | EF04 | = | 000004 | G | FRM30C | 004507 | | |
| BIT02 | = | 000004 | CNTFLG | 015434 | | CSPNTB | = | 000014 | EF05 | = | 000005 | G | FSS | = | 000001 | |
| BIT03 | = | 000010 | CNVT | 045506 | | CSPNTF | = | 000017 | EF06 | = | 000006 | G | FSAU | = | 000015 | |
| BIT04 | = | 000020 | | | | CSPNTS | = | 000016 | EF07 | = | 000007 | G | F\$BGN | = | 000040 | |
| BIT05 | = | 000040 | | | | CSPNTX | = | 000015 | EF08 | = | 000010 | G | F\$CLEA | = | 000007 | |
| | | | | | | CSPOIN | = | 000040 | EF09 | = | 000011 | G | F\$DU | = | 000016 | |

| | | | | |
|-----------------|------------------|-----------------|-----------------|-----------------|
| FSEND = 000041 | ININIT 022176 G | LUP 047334 | L10007 004070 | MSG24 002762 |
| FSHARD= 000004 | INIT 015416 | LUP. AD 034560 | L10010 004162 | MSG25 003025 |
| FSHW = 000013 | INITIA 041252 | LSAU 011456 G | L10011 004264 | MSG26 003062 |
| FSINIT= 000006 | INITMA 002154 | LSAUT 002070 G | L10012 004416 | MSG30 003117 |
| FSJMP = 000050 | INITMS 002156 | LSCCP 002044 G | L10013 004552 | MSG31 003147 |
| FSMOD = 030000 | INIT.M 027614 | LSCLEA 012026 G | L10014 004700 | MSG40 002637 |
| FSMSG = 000011 | INIT. R 022010 G | LSDEPO 002011 G | L10015 004770 | MSG41 002411 |
| FSPWR = 000017 | INMSG 002136 | LSDEVP 002052 G | L10016 005042 | MSG42 002345 |
| FSRPT = 000012 | INPUTA 042200 | LSDISP 011450 G | L10017 005044 | MSG43 003224 |
| FSSEG = 000003 | INSERR 016616 | LSDR 002220 G | L10020 011440 | MSG45 003243 |
| FSSOFT= 000005 | INSIZ 002150 | LSDRCT 002062 G | L10021 011446 | MSG50 003271 |
| FSSRV = 000010 | INTFOR 035476 | LSDRS 002064 G | L10022 011454 | MSG51 003326 |
| FSSUB = 000002 | INVAL. 026722 | LSDRST 002224 G | L10023 011456 | MSG52 003354 |
| FSSW = 000014 | INVINT 035370 | LSDTP 002040 G | L10024 011460 | MSG70 003367 |
| FSTEST= 000001 | INV SW 023216 | LSDU 011460 G | L10025 011734 | MSG71 003422 |
| GARBAG 042576 | IN SUF 030564 | LSOUT 002072 G | L10026 012050 | MSG72 003464 |
| GETCHR 041302 | LSAU = 000041 | LSOVTY 002202 G | L10027 015632 | MTY 003446 |
| GETCMN 044666 | LSCLN = 000041 | LSEF 002024 G | L10030 016324 | MUL 051574 G |
| GETOB 012774 | LSDU = 000041 | LSEXP1 002032 G | L10031 017644 | NAK = 000002 |
| GETPAR 036360 | LSHRD = 000041 | LSEXP2 002034 G | L10032 020726 | NEWPR1 051320 G |
| GETSWI 043662 | LSINIT= 000041 | LSEXP3 002036 G | L10033 021536 | NEXTAR 045430 |
| GET. TW 043432 | LSMOD = 000041 | LSHARD 021472 G | L10034 021662 | NMSG 015426 |
| GLOB 002100 G | LSMSG = 000041 | LSHPCP 002046 G | MAJ IN 022000 G | NO. CLK 024332 |
| GSUB 012052 G | LSPWR = 000041 | LSHPTP 002056 G | MAJ LO 047434 | NO FLA 045224 |
| GSEXCP= 000400 | SRPT = 000041 | LSHW 011430 G | MAJ US 022002 G | NO LPT 042542 |
| GSHILI= 000002 | SSSEG = 000041 | LSICP 002042 G | MAN TI 024302 | NO PTA 027022 |
| GSLOLI= 000001 | SSFT = 000041 | LSINIT 011462 G | MAP16 052276 G | NR = 000001 |
| GSNO = 000000 | SSRV = 000041 | LSLADP 002076 G | MASCLR= 000400 | NUMBIN 035666 |
| GSOFFS= 000400 | SSUB = 000041 | LSLAST 021774 G | MASK B 031326 | NUM. LA 036034 |
| GSOFSI= 000376 | STST = 000041 | LSMREV 002012 G | MASK W 031324 | NUM UN 022372 |
| GSPRMA= 000001 | JSJMP = 000167 | LSNAME 002000 G | MCOMP 020146 | NUNITS 031302 |
| GSPRMD= 000002 | KBPTR 022026 G | LSREPP 002054 G | MMSG 020150 | NXTFOR 045500 |
| GSPRML= 000000 | KBUF 022030 G | LSREV 002010 G | MMSG1 020160 | OCTMSG 041230 |
| GSRADA= 000140 | KEX 004064 | LSRPT 011454 G | MEM SI 026622 | OSOP = 000024 |
| GSRADB= 000000 | KRC 004062 | LSOFT 021642 G | MIN IN 021774 G | OUT 002152 |
| GSRADD= 000040 | LCOMP 021050 | LSOFT 021642 G | MIN US 021776 G | OUTBUF 002142 |
| GSRADF= 000200 | LCRCD 021466 | LSSPC 002030 G | MODR 051640 G | OUTERR 002120 |
| GSRADL= 000120 | LCRCH 021064 | LSSPCP 002050 G | MSG 012052 | OUTMSG 002132 |
| GSRADO= 000020 | LINE F 022250 G | LSSPTP 002060 G | MSGAP 002152 | OUTREP 017646 |
| GSRADT= 000100 | LOAD F 027212 | LSSTA 002066 G | MSGN 020174 | OUTSIZ 002144 |
| GSXFER= 000004 | LOBYTE= 000377 | LSSW 011442 G | MSGNO 002164 | OSAPTS= 000001 |
| GSYES = 000010 | LOGDEV 002126 | LSTIML 002022 G | MSG00 002234 | OSAU = 000001 |
| HCORED 026754 | LOGMSG 041244 | LSTIMU 002020 G | MSG01 002273 | OSBGNR= 000001 |
| HCOREQ 026634 | LQOPB 021066 | LSTIM1 002016 G | MSG02 002320 | OSBGNS= 000001 |
| HCORET 022206 G | LQOPH 021056 | LSTST1 002074 G | MSG03 002345 | OSDU = 000001 |
| HEAD 002000 G | LQOPMG 021052 | LSUNIT 002014 G | MSG04 002411 | OSGNSW= 000001 |
| HERTZ 026574 | LOOPN 021062 | L CLK 026560 | MSG10 002436 | OSPOIN= 000001 |
| HOLDSP= 000020 | LOOSTA 021063 | L10003 003534 | MSG11 002516 | OSPRW = 000001 |
| HYBYTE= 177400 | LPBFR 022024 G | L10001 003570 | MSG12 002551 | PARAM = 101226 |
| MSAAB 046034 | LPCNTR 022022 G | L10002 003622 | MSG20 002620 | PARITY= 000200 |
| ILIMIT 002114 | LPT AD 026612 | L10003 003724 | MSG21 002637 | PARSES 044740 |
| INBUF 002146 | LPT RE 026606 | L10004 003756 | MSG22 002657 | PAR LA 040732 |
| NERP 002116 | LSI RE 026602 | L10005 004060 | MSG23 002722 | PASCNT 002122 |
| | | L10006 004066 | | |

| | | | | |
|------------------|-----------------|-----------------|-----------------|------------------|
| PATTER 011444 | RQUEUE 015436 | SYS FT 035320 | TSTAGN= 010035 | X\$OFFS= 000400 |
| PATTRN 021731 | RSTACK 051522 G | \$LSYM= 010000 | T\$TEMP= 000000 | X\$TRUE= 000020 |
| PRINTC 042552 | RSX.FL 027206 | TABLE 011426 G | T\$TEST= 000002 | X1X1 = 072000 |
| PRINTF 046054 | RTEMP1 015430 | TEMPBUF 005046 | T\$TSTM= 177777 | \$BGNLE= 177777 |
| PRIOR 021571 | RTEMP2 015432 | TEMP 002104 | T\$TSTS= 000001 | \$BREG 027270 |
| PRIO0 = 000000 G | RTS = 000004 | TEMP2 004164 | T\$SAU = 010023 | SENDAD 051360 G |
| PRIO1 = 000040 G | RXINTE= 000120 | TERIN 013414 | T\$SCLE= 010026 | SERFLG= 000400 |
| PRIO2 = 000100 G | R\$STCK 002100 | TERMI 047424 | T\$SDU = 010024 | SF\$AND= 000310 |
| PRIO3 = 000140 G | SCRCH 002102 | TERML1 045232 | T\$SHAR= 010033 | SF\$BAD= 000401 |
| PRIO4 = 000200 G | SEARCH 043400 | TERMTA 041214 | T\$SHW = 010020 | SF\$BLA= 000170 |
| PRIO5 = 000240 G | SEGSTA 022222 G | TEROUT 012260 | T\$SINI= 010025 | SF\$CAS= 000150 |
| PRIO6 = 000300 G | SENDFD= 000020 | TESTS 017174 G | T\$MSG= 010017 | SF\$DEC= 000220 |
| PRIO7 = 000340 G | SET MA 027402 | TEST.M 027124 | T\$SRPT= 010022 | SF\$DO = 000340 |
| PRNTST 042442 | SHIFT 052360 G | TIMER 015410 | T\$SSEG= 010000 | SF\$FAL= 000405 |
| PROBUF 013122 | SIZE.C 051236 G | TIMFLG 022152 G | T\$SOF= 010034 | SF\$G00= 000400 |
| PROLOP 020730 | SIZE M 051154 G | TIMLIM 002110 | T\$SSRV= 010030 | SF\$IF = 000110 |
| PROCM 027164 | SIZ TR 051314 | TIM CO 022004 G | T\$SSW = 010021 | SF\$INC= 000210 |
| PTABLE 002170 | SOM = 000201 | TIM OP 035640 | T\$STES= 010032 | SF\$LOO= 000200 |
| PTAB S 022204 G | SPEC U 027112 | TMPBUF 010172 | T1 017174 G | SF\$NAM= 000160 |
| PTCODE 021470 G | SPV SE 023614 | TOO MA 041174 | T2 020200 G | SF\$NO = 000403 |
| PTEND 002200 | SSTACK 011426 | TSOM = 000400 | UNI MA 027114 | SF\$OR = 000320 |
| PUTCHR 041256 | STACK = 000007 | TSTS = 000002 | USER P 022200 G | SF\$RTN= 000300 |
| PWR FA 052532 G | STARTC 051104 G | TST AB 031440 | USER T 022202 G | SF\$SEL= 000140 |
| PWR FL 022006 G | STATIO 021614 | TST TO 023244 | VALID. 022442 | SF\$THE= 000330 |
| PWR MS 052660 | STIME 002112 | TXINTE= 000100 | VAL LA 023172 | SF\$TRU= 000404 |
| PWR SA 052654 | STINPT 017756 | TYPE 012512 | VAL SW 027230 | SF\$UNT= 000130 |
| PWR UP 052656 | STRCHR 042132 | TYPEC 041570 | VECTOR 021554 | SF\$WHI= 000120 |
| P CLK 026566 | STREQ 026734 | TYPEPC 035464 | VMSG 011736 | SF\$YES= 000402 |
| RBQUE 015456 | STRT = 000006 | TYPFLA 045106 | WIDTH 036234 | \$IFLEV= 177777 |
| RBQUEB 015464 | STRTB 003500 | TYPLIN 041466 | XBUFFE 015422 | \$ISKO = 000001 |
| RBQUET 015460 | STRTC 003506 | TYPNUM 041054 | XDONE 014736 | \$ISK1 = 000001 |
| RCENBL= 000020 | STR TSA 003505 | TYPSTR 041506 | XEQDIA 051406 G | \$ISK2 = 000001 |
| RCVADD 015406 | STRT T 027170 | TYP ER 035350 | XEQSUB 051374 G | \$ISK3 = 000001 |
| RCVBUF= 000002 | ST REQ 027110 | TY UNI 030604 | XEQ CL 031244 | \$LOCTA= 177777 |
| RCVCSR= 000000 | ST SET 023434 | T\$ARGC= 000003 | XEQ CM 026552 | \$LSTCN= 177777 |
| RCVE 016326 | SUNIT 027176 | T\$CODE= 001130 | XEQ IN 030726 | \$LSTIN= 000000 |
| RDONE 014740 | SUPERV 025154 | T\$ERCO= 000064 | XEQ LA 025110 | \$LSTST= 177777 |
| READ P 047436 G | SUPFLA 022162 G | T\$ERRN= 000064 | XEQ OP 031020 | \$LSTTA= 000000 |
| REGBAC 052262 G | SUPV T 022340 G | T\$EXCP= 000000 | XEQ PP 024342 | \$M CALL= 000000 |
| REGSAV 052246 G | SUP PR 023206 | T\$FLAG= 000040 | XEQ TE 031064 | \$NESTL= 177777 |
| PEP = 000003 | SUCCNT= 177777 | T\$HILI= 077777 | YINT 015466 G | \$NSKO = 000300 |
| REPA 020175 | SUCGBL= 000000 | T\$LOLI= 000000 | XMIT 014426 | \$NSK1 = 000130 |
| REPCPC 020176 | SUCHAN 031506 | T\$LSYM= 010000 | XMTADD 015404 | \$NSK2 = 000110 |
| REPM 020170 | SUCINS= 000000 | T\$MCAL= 177777 | XMTBUF= 000006 | \$NSK3 = 000110 |
| REPN 020173 | SUCSTK= 177777 | T\$NEST= 177777 | XMTCSP= 000004 | \$NSK4 = 000110 |
| REQN P 027174 | SUCSUB= 177777 | T\$NSKO= 000000 | XSIZE 015424 | \$SAVLE= 177777 |
| REQN T 027166 | SUCTAG= 000000 | T\$NSK1= 000005 | XSTRT 012514 | \$SAV2 052424 G |
| RE SET 023364 | SUCTST= 177777 | T\$NSK2= 000003 | XTIME 050114 G | \$SAV3 052440 G |
| RINT 015634 G | SWCHAN 027014 | T\$SAVL= 177777 | XTIMEN 050740 | \$SAV4 052456 G |
| RMSGNO 002166 | SWITCH 045404 | T\$SEGL= 177777 | XTIMST 050136 | \$SAV5 052476 G |
| RQUE 015440 | SW PTA 027000 | T\$SEKO= 010000 | XXOP D 026762 | \$SSKO = 050003 |
| RQUEB 015454 | SYNC = 000226 | T\$SUBN= 000000 | X\$ALWA= 000000 | \$TAGLE= 177777 |
| RQUET 015442 | SINENT 015412 | T\$TAGL= 177777 | X\$FALS= 000042 | \$TAGNU= 050004 |

| | | | | |
|------------------|------------------|------------------|------------------|-------------------|
| STEMP = 000300 | \$\$BYTE= 000402 | \$\$FROM= 000000 | \$\$RTN2= 050001 | \$\$\$TAG= 050000 |
| STSK0 = 050002 | \$\$CASE= 000000 | \$\$LOC = 021034 | \$\$SRC = 000064 | = 072000 |
| STSK1 = 050003 | \$\$DST = 000003 | \$\$LOCN= 000000 | \$\$TGSV= 000000 | |
| STSK2 = 050006 | \$\$ELOC= 000402 | \$\$REG = 177777 | \$\$TGS1= 000000 | |
| STSK3 = 050033 | \$\$ERFL= 000000 | \$\$RETU= 000001 | \$\$TGS2= 000000 | |
| \$\$ARGC= 000000 | \$\$FLAG= 000001 | \$\$RTN1= 050000 | \$\$T0 = 000001 | |

ABS 072000 000

APPROS DETECTED 0

DIOPGA=DIOPGA
RUN-TIME 93 95 9 SECONDS
RUN-TIME PAGES 1402 190=7 3
RECEIVED 754 (69 PAGES)