

.REV

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZRJB-A-D
PRODUCT NAME: RFD4/5/6 FORMATTER PROGRAM
DATE CREATED: MAY 1976
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: C. HESS

COPYRIGHT (C) 1976 DIGITAL EQUIPMENT CORP., MAYNARD, MASS.

THE INFORMATION IN THIS STATEMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

ACTUAL DISTRIBUTION OF THE SOFTWARE DESCRIBED IN THIS DOCUMENT WILL BE SUBJECT TO TERMS AND CONDITIONS TO BE ANNOUNCED ON SOME FUTURE DATE BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

THIS SOFTWARE IS FURNISHED TO PURCHASER UNDER A LICENSE TO USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DEC'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DEC.

CONTENTS

1. ABSTRACT
2. REQUIREMENTS
 - 2.1 EQUIPMENT
 - 2.2 PRELIMINARY PROGRAMS
3. LOADING PROCEDURES
4. STARTING PROCEDURES
 - 4.1 STARTING ADDRESSES
 - 4.2 OPERATOR ACTION
 - 4.3 RH11 - RH70 UNIBUS ADDRESS
 - 4.4 OTHER UNIBUS ADDRESSES
5. SWITCH REGISTER SETTINGS
6. ERROR MESSAGES
7. MISCELLANEOUS
 - 7.1 FORMAT TIMES
 - 7.2 HALTING THE PROGRAM
 - 7.3 SURFACE VERIFICATION
8. PROGRAM DESCRIPTION
 - 8.1 FORMAT OPERATION
 - 8.2 CHECK OPERATION
 - 8.3 POSITIONER VERIFICATION
9. PROGRAM LISTING

1. ABSTRACT

THE RFD4/5/6 FORMATTER PROGRAM FORMATS THE DISK PACK AND PERFORMS A CURSORY CHECK OF THE PACK'S SURFACE. THE PROGRAM ALLOWS THE OPERATOR TO SPECIFY ADDRESS LIMITS, PATTERNS, AND EITHER 16 BIT OR 18 BIT FORMAT MODE. THE PROGRAM VERIFIES EACH TRACK WRITTEN AS WELL AS VERIFYING THE FORMAT OPERATION.

2. REQUIREMENTS2.1 EQUIPMENT

PDP-11 PROCESSOR
8K MEMORY
TELETYPE
PROGRAM LOAD DEVICE
KW11-L OR KW11-P CLOCK
RH11 OR RH70 WITH 1 - 8 RFD4, RFD5, RFD6 DISK DRIVES

2.2 PRELIMINARY PROGRAMS

RFD4/5/6 DISKLESS CONTROLLER TEST
PART 1 (MAINDEC-11-DZRJG)
PART 2 (MAINDEC-11-DZRJH)

RFD4/5/6 FUNCTIONAL CONTROLLER TEST
PART 1 (MAINDEC-11-DZRIJ)
PART 2 (MAINDEC-11-DZRIJ)

3. LOADING PROCEDURES

THE PROGRAM MAY BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER OR IT MAY BE LOADED FROM THE APPROPRIATE 'XXDP' MEDIA USING THE ASSOCIATED LOADER. THE PROGRAM MAY NOT BE INCLUDED IN AN 'XXDP' CHAIN.

4. STARTING PROCEDURES4.1 STARTING ADDRESSES

THE PROGRAM IS STARTED FROM LOCATION 200(9) IF THE ADDRESS OF THE

RH11 OR RH70 WILL NOT BE CHANGED

THE PROGRAM IS STARTED FROM LOCATION 204(9) IF THE ADDRESS OF THE RH11 OR RH70 IS TO BE CHANGED FROM THE PRELOADED VALUE (SEE SECTION 4.3)

4.2 OPERATION ACTION

1. LOAD THE PROGRAM INTO MEMORY (SEE SECTION 3).
2. LOAD THE STARTING ADDRESS - 200(9) OR 204(9).
3. SET THE SWITCHES AS REQUIRED AND PRESS 'START'.

IF THIS IS THE PROGRAM'S FIRST START, THE STATUS OF THE DRIVES ON THE SELECTED MASSBUS SUBSYSTEM WILL BE TYPED OUT. THIS TYPEOUT MAY BE INHIBITED ON SUBSEQUENT STARTS BY SETTING SW<02>.

4. THE PROGRAM WILL THEN TYPE THE FOLLOWING MESSAGE:

'PROGRAM MODE (C OR F):'

ENTER THE APPROPRIATE CODE: 'C' FOR 'CHECK' OPERATION OR 'F' FOR 'FORMAT & VERIFY'. IF A 'CARRIAGE RETURN' IS ENTERED IN RESPONSE TO THE REQUEST, THE PROGRAM WILL ASSUME 'FORMAT & VERIFY'.

5. THE PROGRAM WILL THEN ASK FOR THE FORMATTING MODE:

'OPERATE IN 22 SECTOR (16 BIT) MODE (Y OR N)'

ENTER THE APPROPRIATE CHARACTER: 'Y' FOR 16 BIT MODE OR 'N' FOR 18 BIT MODE. IF A 'CARRIAGE RETURN' IS ENTERED IN RESPONSE TO THIS REQUEST, THE PROGRAM WILL ASSUME 16 BIT MODE.

6. THE PROGRAM WILL THEN ASK FOR A DRIVE:

'DRIVE: '

ENTER THE ADDRESS OF THE DRIVE TO BE FORMATTED. A 'PERIOD' OR 'CARRIAGE RETURN' ENTRY WILL SELECT DRIVE 0. IF THE DRIVE SELECTED IS NOT AVAILABLE, THE PROGRAM WILL TYPE AN ERROR MESSAGE AND RETURN TO THE DRIVE ADDRESS REQUEST.

7. AFTER THE OPERATOR HAS SELECTED A DRIVE, THE PROGRAM WILL ASK FOR ADDRESS LIMITS FOR THE SELECTED DRIVE:

'ENTER ADDRESS LIMITS: '

THE PREVIOUSLY SELECTED OR DEFAULT VALUES FOR BEGINNING CYLINDER AND TRACK AND FOR ENDING CYLINDER AND TRACK WILL BE TYPED OUT. IF A 'CARRIAGE RETURN' IS TYPED AS A RESPONSE, THE PRESENT VALUE WILL BE USED; IF A 'PERIOD' IS TYPED, THE PROGRAM WILL BYPASS THE REMAINING ENTRIES AND WILL USE THEIR PRESENT VALUES. NOTE

THAT THE CYLINDER AND TRACK VALUES ARE D E C I M A L NUMBERS.
THE ADDRESS SPECIFIED BY THE BEGINNING CYLINDER AND TRACK MUST
BE LESS THAN THE ADDRESS SPECIFIED BY THE ENDING CYLINDER AND
TRACK ADDRESS.

7. THE PROGRAM WILL THEN ASK FOR THE DATA PATTERN:

'SELECT DATA PATTERN
(0) ZERO'S
(1) ONES
(2) WORST CASE:'

ENTER THE CODE FOR THE REQUIRED PATTERN. 'CARRIAGE RETURN' OR
'PERIOD' ENTRIES WILL CAUSE THE PROGRAM TO USE THE 'WORST CASE'
PATTERN.

THE 'WORST CASE' PATTERN IS THE FOLLOWING OCTAL SEQUENCE REPEATED
THROUGH THE DATA AREA OF THE SECTOR:

165555
133333

8. THE PROGRAM WILL THEN TYPE:

'STARTING FORMAT ON DRIVE N'

OR

'STARTING CHECK ON DRIVE N'

9. THE OPERATOR CAN DETERMINE WHERE THE DRIVE IS DURING THE FORMAT
OR CHECK OPERATION BY TYPING A 'CONTROL C'. THE PROGRAM WILL
TYPE THE FOLLOWING MESSAGE:

'PRESENT ADDRESS IS: CXXX TXX'

IF A 'CONTROL C' IS TYPED WHILE THE PROGRAM IS TYPING THE CURRENT
ADDRESS, THE PROGRAM WILL ABORT THE FORMAT (OR CHECK) OPERATION
AND RETURN TO THE 'DRIVE' REQUEST.

10. IF THE OPERATOR DOES NOT SELECT A DIFFERENT DRIVE WHEN THE FORMAT
OR CHECK OPERATION HAS COMPLETED, THE PROGRAM WILL NOT ALTER THE
ADDRESS LIMITS SPECIFIED AT THE START OF THE PREVIOUS OPERATION.
IF THE FORMAT OR CHECK OPERATION IS TERMINATED BY A 'CONTROL C' OR
IF A DIFFERENT DRIVE IS SELECTED, THE PROGRAM WILL RESET THE
ADDRESS LIMITS TO THE VALUES APPROPRIATE FOR THE DRIVE TYPE.

11. TO CHANGE EITHER THE ADDRESSING MODE OR THE OPERATION MODE, THE
PROGRAM MUST BE STARTED FROM LOCATION 200(8) OR 204(8) AGAIN.

4.3 RH11 - RH70 UNIBUS ADDRESS

THE PROGRAM ASSUMES THAT THE RH11 OR RH70 ADDRESSES START AT
17E700 AND THAT THE VECTOR ADDRESS IS 254. THESE ADDRESSES MAY

BE CHANGED WHEN THE PROGRAM IS STARTED FROM LOCATION 204(8).
IF THE RH11 - RH70 IS NOT AT THE DEFAULT ADDRESS, THE PROGRAM MUST
BE STARTED FROM 204(9) INITIALLY AS THE PROGRAM GOES THROUGH THE
ADDRESS CHANGE ROUTINE AT INITIAL START ONLY. ENTER THE RH11 RH70
ADDRESS IN RESPONSE TO THE REQUEST FROM THE PROGRAM.

4.4 OTHER UNIBUS ADDRESSES

LOC ---	TAG ---	CONTENTS -----	FUNCTION -----
1144	STKS	177560	TTY KEYBOARD STATUS REGISTER
1146	STKB	177562	TTY KEYBOARD BUFFER REGISTER
1150	STPS	177564	TTY PRINTER STATUS REGISTER
1152	STPB	177566	TTY PRINTER BUFFER REGISTER
1176	SLKCSR	172540	KW11-P CONTROL REGISTER
1200	SLKCSB	172542	KW11-P COUNTER REGISTER
1202	SLPVEC	104	KW11-P VECTOR ADDRESS
1206	SLKS	177546	KW11-L CONTROL REGISTER
1210	SLKV	100	:ADDRESS OF KW11-L VECTOR

5. SWITCH REGISTER SETTINGS

SW<15>=1...HALT ON ERROR
SW<13>=1...INHIBIT ERROR TYPEOUTS
SW<10>=1...BELL ON ERROR
SW<09>=1...LOOP ON ERROR
SW<02>=1...DON'T DISPLAY SYSTEM STATUS AFTER INITIAL START
SW<01>=1...LOOP ON THE CURRENT TRACK
SW<00>=1...LOOP THE PROGRAM ON THE SELECTED DRIVE

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34)
THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS
NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE
'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE
SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD
ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL
RECOGNIZE THE 'CONTROL G' AT ANY TIME EXCEPT WHEN THE PROGRAM
IS AT A HIGHER PRIORITY PROCESSING AN RPO4/5/6 INTERRUPT. THE
'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE
TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER
IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED. 'RJBOU' AND
'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS
DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH

REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

5. ERROR MESSAGES

1. 'RH11 INTERRUPT OCCURRED (RPAS=0) - AN INTERRUPT OCCURRED, BUT NOTHING ON THE MASSBUS IS INDICATING AN ATTENTION.
2. 'UNEXPECTED ATTENTION OCCURRED' - THE INDICATED DRIVE INTERRUPTED, BUT NO INTERRUPT WAS EXPECTED FROM THE INDICATED DRIVE.
3. 'MASSBUS PARITY ERROR (MCPE=1)' - A CONTROL BUS PARITY ERROR WAS DETECTED BY THE RH11 WHEN THE INDICATED REGISTER WAS READ.
4. 'MASSBUS PARITY ERROR (PAR=1)' - A CONTROL BUS PARITY ERROR OCCURRED WHEN THE INDICATED REGISTER WAS WRITTEN.
5. 'ADDRESS PLUG CHANGE BIT SET' - THE PROGRAM FOUND THE 'OPE' BIT SET FOR THE INDICATED DRIVE.
6. 'RH11 DIDN'T RESPOND TO ADDRESSING' - THE PROGRAM ACCESSED THE RH11 AT THE INDICATED ADDRESS AND RECEIVED NO RESPONSE.
7. 'DRIVE OFFLINE' - THE INDICATED DRIVE HAS GONE OFFLINE
8. 'PERSISTENT DRIVE UNSAFE ERROR' - THE INDICATED DRIVE HAS BECOME UNSAFE AND THE CONDITION CANNOT BE CLEARED BY ISSUING 'DRIVE CLEAR' INSTRUCTIONS.
9. 'UNCORRECTABLE MASSBUS PARITY ERROR' - THE PROGRAM ATTEMPTED TO PERFORM AN OPERATION AND DETECTED 3 SUCESSIVE MASSBUS PARITY ERRORS OR THE PROGRAM ATTEMPTED TO CLEAR A 'PAR' ERROR IN THE DRIVE AND A PARITY ERROR OCCURRED.
10. 'SOFTWARE TIMEOUT' - THE OPERATION FAILED TO COMPLETE WITHIN 1 SECOND.
11. 'DRIVE UNSAFE ERROR' - A NON-PERSISTENT UNSAFE ERROR OCCURRED DURING THE OPERATION.
12. 'CONTROLLER/DRIVE ERROR DURING WRITE' - THE INDICATED NON-DATA ERROR WAS DETECTED DURING A FORMAT OPERATION.
13. 'CONTROLLER/DRIVE ERROR DURING WRITE CHECK' - A NON-DATA ERROR OCCURRED DURING THE WRITE CHECK.
14. 'DATA ERROR DURING WRITE CHECK' - A DATA RELATED ERROR OCCURRED DURING A WRITE CHECK OPERATION. A DATA ERROR IS CONSIDERED

TO BE ONE OF THE FOLLOWING ERRORS: 'DCK', 'OPI', 'DTE', 'HCRC',
'HCE', OR 'FER'.

15. 'RETRIES NOT SUCCESSFUL - SECTOR NOT ACCEPTABLE' - THE INDICATED SECTOR FAILED DURING RETRY FOLLOWING A DATA ERROR.
16. 'CONTROLLER/DRIVE ERROR VERIFYING HEADERS' - AN ERROR OCCURRED DURING THE VERIFICATION PASS AFTER FORMATTING.
17. ''HCE' ERROR VERIFYING HEADERS' - A HEADER ERROR OCCURRED DURING THE VERIFICATION PASS AFTER FORMATTING.
18. 'CYLINDER FIELD IN HEADER IS NOT CORRECT' - THE CYLINDER FIELD FROM A HEADER READ DURING THE VERIFICATION PASS IS NOT CORRECT.
19. 'WRITE CHECK ERROR' - THE RH11 REPORTED A WRITE CHECK ERROR AND NO DRIVE ERRORS WERE SET.

7. MISCELLANEOUS

7.1 FORMAT TIME

IT TAKES APPROXIMATELY 8 MINUTES TO FORMAT AN ENTIRE RPO4/5 PACK AND APPROXIMATELY 16 MINUTES TO FORMAT AN RPO6 PACK. THE 'CHECK' MODE TIME FOR AN ENTIRE PACK IS 4 MINUTES FOR RPO4/5'S AND 8 MINUTES FOR RPO6'S.

7.2 HALTING THE PROGRAM

THE OPERATOR SHOULD NOT HALT THE PROGRAM DURING A FORMAT OPERATION. HALTING THE PROGRAM MAY LEAVE A SECTOR INCORRECTLY FORMATTED. TO TERMINATE THE FORMAT, TYPE A 'CONTROL C' AND WHILE THE PROGRAM IS TYPING THE ADDRESS, TYPE ANOTHER 'CONTROL C'; THIS SEQUENCE RETURNS THE PROGRAM TO THE DRIVE ADDRESS ENTRY ROUTINE.

7.3 SURFACE VERIFICATION

THE FORMATTER PROGRAM IS NOT INTENDED TO BE USED TO PERFORM DISK PACK VERIFICATION. IF THE PROGRAM REPORTS A SECTOR AS BEING 'NOT ACCEPTABLE', THIS MAY IN FACT INDICATE A BAD SURFACE; HOWEVER, SECTORS WHICH 'PASSED' MAY OR MAY NOT BE GOOD.

8. PROGRAM DESCRIPTION

8.1 FORMAT OPERATION

THE PROGRAM FORMATS THE PACK ONE TRACK AT A TIME BETWEEN THE LIMITS SPECIFIED BY THE DRIVE.

THE FORMAT OPERATION CONSISTS OF A WRITE HEADER AND DATA COMMAND FOR THE ENTIRE TRACK FOLLOWED BY A WRITE CHECK HEADER AND DATA COMMAND. IF AN ERROR OCCURS DURING THE WRITE, THE PROGRAM WILL RETRY THE WRITE BEFORE CONTINUING. IF A DATA RELATED ERROR IS DETECTED DURING THE WRITE CHECK (A DATA ERROR IS DEFINED AS ONE OF THE FOLLOWING ERRORS: 'DCK', 'OPI', 'DTE', 'HCRC', 'HCE', OR 'FER'), THE SECTOR IN ERROR WILL BE REWRITTEN. THE PROGRAM WILL CHECK THE SECTOR TWICE; IF A DATA ERROR IS DETECTED IN THE SECTOR DURING EITHER OF THE WRITE CHECKS, THE PROGRAM WILL DECLARE THE SECTOR AS BEING 'UNACCEPTABLE'. FOLLOWING THIS SEQUENCE, THE REMAINDER OF THE TRACK IS CHECKED. IF DATA ERRORS ARE ENCOUNTERED IN ANY OF THE REMAINING SECTORS, EACH SECTOR WILL BE HANDLED AS DESCRIBED ABOVE.

IF A NON-DATA RELATED ERROR OCCURS DURING THE WRITE CHECK, THE PROGRAM WILL RETRY THE COMMAND FOR THE ENTIRE TRACK BEFORE PROCEEDING TO THE NEXT TRACK.

IT SHOULD BE NOTED THAT THE FORMATTER PROGRAM FORMATS THE PACK ONLY AND IS NOT DIRECTLY VERIFYING THE SURFACE OF THE PACK. ERRORS THAT ARE ENCOUNTERED MAY BE THE RESULT OF BAD AREAS ON THE PACK BUT, AS THE PROGRAM IS NOT DESIGNED TO PERFORM AN EXHAUSTIVE CHECK OF THE DISK PACK SURFACE, THE PROGRAM CANNOT MAKE THIS CONCLUSION. IN GENERAL, HOWEVER, THE OPERATOR CAN ASSUME THAT SECTORS WHICH THE PROGRAM CALLS 'UNACCEPTABLE' INDICATE BAD AREAS OF THE PACK; UNFORTUNATELY, SECTORS WHICH 'PASS' CANNOT BE ASSUMED TO BE GOOD.

DURING THE FORMAT OPERATION, THE PROGRAM FILLS THE DATA FIELD WITH THE PATTERN SELECTED BY THE OPERATOR. THE KEYWORDS IN THE HEADER ARE ALWAYS SET TO ZERO.

8.2 CHECK OPERATION

THE CHECK OPERATION IS IDENTICAL TO THE WRITE CHECK PORTION OF THE FORMAT OPERATION DESCRIBED IN SECTION 8.1 EXCEPT THAT THE PROGRAM WILL NOT RE-WRITE ERROR SECTORS.

8.3 POSITIONER VERIFICATION

AFTER THE PROGRAM COMPLETES THE FORMAT OPERATION, THE POSITIONER IS RETURNED TO THE STARTING CYLINDER AND THE HEADER FROM SECTOR 0 ON THE STARTING TRACK IS READ. THE CYLINDER ADDRESS FIELD FROM THE HEADER IS COMPARED TO THE REQUESTED CYLINDER; IF THE CYLINDER ADDRESSES DO NOT COMPARE, AN ERROR MESSAGE IS TYPED. THE PROGRAM CHECKS THE CYLINDER ADDRESS FIELD FROM THE HEADER OF SECTOR 0 ON THE BEGINNING TRACK OF EACH CYLINDER FORMATTED. THIS CHECK IS PERFORMED TO CONFIRM THAT THE DISK'S POSITIONER ADVANCED PROPERLY DURING THE FORMAT OPERATION.

L01

.MAIN. MACY11 27(655) 27-APR-76 18:02 PAGE 10
DZRJBA.DOC

SEQ 0010

9. PROGRAM LISTING

MO1

.MAIN. MACY11 27:655) 27-APR-76 18:02 PAGE 11
DZRJBA.DOC

SEG 0011

.END

ERRORS DETECTED: 0

*.DZRJBA/SOL=DZRJBA.DOC
RUN-TIME: 1 2 0 SECONDS
CORE USED: 3K

15	OPERATIONAL SWITCH SETTINGS
20	TRAP CATCHER
37	ACT11 HOOKS
48	STARTING ADDRESS = 200
52	STARTING ADDRESS TO CHANGE THE RH11 ADDRESS = 204
55	BASIC DEFINITIONS
68	RH11 REGISTERS
214	RPO4/5/6 REGISTERS
409	RPO4/5/6 DRIVER COMMANDS
425	COMMON TAGS
624	ERROR POINTER TABLE
791	MAIN PROGRAM
799	INITIALIZE THE COMMON TAGS
841	GET VALUE FOR SOFTWARE SWITCH REGISTER
1278	END OF PASS ROUTINE
1221	SUPPORT SUBROUTINES
1674	MACRO ROUTINES
1677	ERROR HANDLER ROUTINE
1799	TYPE ROUTINE
1870	BINARY TO OCTAL (ASCII) AND TYPE
1948	CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
2016	TTY INPUT ROUTINE
2273	TYPE NUMERICAL ASCII STRING SUPPRESS LEADING ZEROS
2297	SINGLE LENGTH BINARY TO DECIMAL ASCII ROUTINE
2316	DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE
2379	SAVE AND RESTORE R0-R5 ROUTINES
2425	TRAP DECODER
2448	TRAP TABLE
2472	SINGLE/DUAL PORT RH11/RPO4/5/6 DRIVER (REV 1.0)
3898	TELETYPE MESSAGES
4037	ERROR MESSAGES
4404	BUSADR - GET BUS ADDRESS AND VECTOR ADDRESS FOR RH11
4466	CK.NUM - CHECK NUMBER (OCTAL)

802

IBM SYSTEMS DIVISION, 3924 S B FORMATTER PROGRAM

MAY 11 27.655 27-APR-76 17:59 PAGE 1

EE: 0013

MD-11-DZRJB-A, RPO4 5 6 FORMATTER PROGRAM
RPO456.OIC

```

.TITLE MD-11-DZRJB-A, RPO4/5/6 FORMATTER PROGRAM
.*COPYRIGHT (C) 1976
.*DIGITAL EQUIPMENT CORP.
.*MAYNARD, MASS. 01754
.*
.*PROGRAM BY C. HESS
.*
.*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
.*PACKAGE (MAINDEC-11-DZQAC-C1), MAR 24, 1976.
.*

```

```

.SBTTL OPERATIONAL SWITCH SETTINGS
.*
.*      SWITCH          USE
.*      -----
.*      15             HALT ON ERROR
.*      13             INHIBIT ERROR TYPEOUTS
.*      12             BELL ON ERROR
.*      11             LOOP ON ERROR
.*      10             DON'T DISPLAY SYSTEM STATUS AFTER INITIAL START
.*      9              LOOP ON THE CURRENT TRACK
.*      8              LOOP THE PROGRAM ON THE SELECTED DRIVE
.*

```

.SBTTL TRAP CATCHER

```

000000      =0
.*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A "+2,HALT"
.*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
.*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
000174      =174
DISREG: .WORD 0          ;;SOFTWARE DISPLAY REGISTER
SWREG:  .WORD 0          ;;SOFTWARE SWITCH REGISTER

```

.SBTTL ACT11 HOOKS

```

.******
.*HOOKS REQUIRED BY ACT11
000200      $SVPC=          ;;SAVE PC
000246      =46          SENDAD          ;;1)SET LOC.46 TO ADDRESS OF SENDAD IN .SECP
000252      =52          .WORD 20000     ;;2)SET LOC.52 TO 20000
000200      =52          .WORD 20000     ;;RESTORE PC

```

.SBTTL STARTING ADDRESS = 200

```

000200      =200          JMP BEGIN1          ;NORMAL STARTING ADDRESS
000137      GC207E

```

.SBTTL STARTING ADDRESS TO CHANGE THE RM11 ADDRESS = 204

```

000204      =204          JMP BEGIN          ;CHANGE THE RM11 ADDRESS
000137      GC206E

```

.SBTTL BASIC DEFINITIONS

154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000

::*****

.SBTTL RH11 REGISTERS

::*****

:CONTROL AND STATUS REGISTER 1 (RPCS1)

000100	IE=	100	: INTERRUPT ENABLE (BIT #6)
000200	RDY=	200	: READY (BIT #7)
000400	A16=	400	: HIGH ORDER BUS ADDRESS BIT (BIT #8)
001000	A17=	1000	: HIGH ORDER BUS ADDRESS BIT (BIT #9)
002000	PSEL=	2000	: PORT SELECT (BIT #10)
020000	MCPE=	20000	: MASSBUS PARITY ERROR (BIT #13)
040000	TRE=	40000	: TRANSFER ERROR (BIT #14)
	:SC=	100000	: SPECIAL CONDITION (BIT #15)

:WORD COUNT REGISTER (RPWC)
:(EACH BIT IS CALLED BY BIT NUMBER)

:BUS ADDRESS REGISTER (RPBA)
:(EACH BIT IS CALLED BY BIT NUMBER)

:CONTROL AND STATUS REGISTER 2 (RPCS2)

000001	US1=	1	: UNIT SELECT (BIT #0)
000002	US2=	2	: UNIT SELECT (BIT #1)
000004	US4=	4	: UNIT SELECT (BIT #2)
000010	BAY=	10	: BUS ADDRESS INCREMENT INHIBIT (BIT #3)
000020	FAT=	20	: MASSBUS PARITY TEST (BIT #4)
000040	CLR=	40	: CLEAR (BIT #5)
000100	IR=	100	: INPUT READY (BIT #6)
000200	OR=	200	: OUTPUT READY (BIT #7)
000400	MPE=	400	: MASS BUS PARITY ERROR (BIT #9)
001000	MXF=	1000	: MISSED TRANSFER ERROR (BIT #9)
002000	PGE=	2000	: PROGRAM ERROR (BIT #10)
004000	NEM=	4000	: NON EXISTENT MEMORY (BIT #11)
010000	NED=	10000	: NON EXISTENT DRIVE (BIT #12)
020000	UPE=	20000	: UNIBUS PARITY ERROR (BIT #13)
040000	WCE=	40000	: WRITE CHECK ERROR (BIT #14)
100000	DLT=	100000	: DATA LATE (BIT #15)

:DATA BUFFER REGISTER (RPDB)
:(EACH BIT IS CALLED BY BIT NUMBER)

::*****

.SBTTL RP04/5/6 REGISTERS

::*****

:CONTROL AND STATUS 1 REGISTER. (#00)

00000001
00000002
00000004
00000010
00000020
00000040
00400000
00000001
00000002
00000004
00000010
00000020
00000040
00010000
00020000
00040000
00100000
00200000
00400000
01000000
02000000
04000000
10000000
00000001
00000002
00000004
00000010
00000020
00000040
00010000
00020000
00040000
00100000
00200000
00400000
01000000
02000000
04000000
10000000
00000001
00000002
00000004
00000010
00000020
00000040
00010000
00020000
00040000
00100000
00200000
00400000
01000000
02000000
04000000
10000000

0000001
0000002
0000004
0000010
0000020
0000040
0040000

GO= 1
F1= 2
F2= 4
F3= 10
F4= 20
F5= 40
DVA= 4000

:GO BIT (BIT #0)
:FUNCTION CODE BIT #1
:FUNCTION CODE BIT #2
:FUNCTION CODE BIT #3
:FUNCTION CODE BIT #4
:FUNCTION CODE BIT #5
:DEVICE AVAILABLE (BIT #11)

:DRIVE STATUS REGISTER (RPS!) (#01)

0000002
0000004
0000010
0000020
0000040
0001000
0002000
0004000
0010000
0020000
0040000
0100000
0200000
0400000
1000000

:DFS= 1
:DFF20= 2
:DIGB= 4
:GRV= 10
:DLG4= 20
:DFI= 40
:VV= 100
:DRY= 200
:DPA= 400
:PCM= 1000
:LST= 2000
:WAL= 4000
:MCL= 10000
:PIF= 20000
:ERR= 40000
:ATA= 100000

DRIVE FORWARD 5"/SEC. (BIT #0)
:DRIVE FORWARD 20"/SEC. (BIT #1)
:DRIVE TO INNER GUARD BAND (BIT #2)
:GO REVERSE (BIT #3)
:DIFFERENCE LESS THAN 64 (BIT #4)
:DIFFERENCE EQUALS 1 (BIT #5)
:VOLUME VALID (BIT #6)
:DRIVE READY (BIT #7)
:DRIVE PRESENT (BIT #8)
:PROGRAMABLE (BIT #9)
:LAST SECTOR TRANSFERRED (BIT #10)
:WRITE LOCK (BIT #11)
:MEDIUM ON-LINE (BIT #12)
:POSITIONING OPERATION IN PROGRESS (BIT #13)
:COMPOSITE ERROR (BIT #14)
:ATTENTION ACTIVE (BIT #15)

:ERROR REGISTER #01 (RPER!) (#02)

0000001
0000002
0000004
0000010
0000020
0000040
0001000
0002000
0004000
0010000
0020000
0040000
0100000
0200000
0400000
1000000

:ILF= 1
:YLR= 2
:RMR= 4
:PAR= 10
:FER= 20
:WCF= 40
:ECH= 100
:HCE= 200
:HCRC= 400
:AOE= 1000
:IAE= 2000
:WLE= 4000
:DTE= 10000
:OPI= 20000
:UNS= 40000
:DCK= 100000

:ILLEGAL FUNCTION (BIT #0)
:ILLEGAL REGISTER (BIT #1)
:REGISTER MODIFICATION REFUSED (BIT #2)
:PARITY ERROR (BIT #3)
:FORMAT ERROR (BIT #4)
:WRITE CLOCK FAIL (BIT #5)
:ECC HARD ERROR (BIT #6)
:HEADER COMPARE ERROR (BIT #7)
:HEADER CRC ERROR (BIT #8)
:ADDRESS OVERFLOW ERROR (BIT #9)
:INVALID ADDRESS ERROR (BIT #10)
:WRITE LOCK ERROR (BIT #11)
:DRIVE TIMING ERROR (BIT #12)
:OPERATION INCOMPLETE (BIT #13)
:DRIVE UNSAFE (BIT #14)
:DATA CHECK ERROR (BIT #15)

:MAINTAINABILITY REGISTER (RPMR) (#03)

0000001
0000002
0000004
0000010
0000020

DMO= 1
MCLK= 2
MINX= 4
MSTCK= 10
MRD= 20

:DIAGINOSTIC MODE (BIT #0)
:MAINTAINABILITY CLOCK (BIT #1)
:MAINTAINABILITY INDEX (BIT #2)
:MAINTAINABILITY SECTOR CLOCK (BIT #3)
:MAINTAINABILITY READ (BIT #4)

336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379

000001
000002
000004
000010
000020
000040
000100
000200
000400
001000
002000
004000
010000
020000
100000

WCU= 1
CSF= 2
WSU= 4
CSU= 10
MSE= 20
TDF= 40
TUF= 100
FEN= 200
WRU= 400
MHS= 1000
NHS= 2000
IXE= 4000
VU30= 10000
PLU= 20000
ACU= 100000

;WRITE CURRENT UNSAFE (BIT #0)
;CURRENT SINK FAILURE (BIT #1)
;WRITE SELECT UNSAFE (BIT #2)
;CURRENT SWITCH UNSAFE (BIT #3)
;MOTOR SEQUENCE ERROR (BIT #4)
;TRANSITIONS DETECTOR FAILURE (BIT #5)
;TRANSITIONS UNSAFE (BIT #6)
;FAILSAFE ENABLED (BIT #7)
;WRITE READY UNSAFE (BIT #8)
;MULTIPLE HEAD SELECT (BIT #9)
;NO HEAD SELECTION (BIT #10)
;INDEX ERROR (BIT #11)
;30VOLT UNSAFE (BIT #12)
;PLO UNSAFE (BIT #13)
;AC UNSAFE (BIT #15)

;RPOS/6 ERROR REGISTER #02 (RPER2) (#10)

000001
000002
000004
000010
000020
000040
000100
000200
000400
001000
002000
004000
020000

WCU= 1
CSF= 2
WSU= 4
CSU= 10
RAW= 20
TDF= 40
TUF= 100
ABS= 200
WRU= 400
MHS= 1000
NHS= 2000
IXE= 4000
PLU= 20000

;WRITE CURRENT UNSAFE (BIT #0)
;CURRENT SINK FAILURE (BIT #1)
;WRITE SELECT UNSAFE (BIT #2)
;CURRENT SWITCH UNSAFE (BIT #3)
;READ AND WRITE (BIT #4)
;TRANSITIONS DETECTOR FAILURE (BIT #5)
;TRANSITIONS UNSAFE (BIT #6)
;ABNORMAL STOP (BIT #7)
;WRITE READY UNSAFE (BIT #8)
;MULTIPLE HEAD SELECT (BIT #9)
;NO HEAD SELECTION (BIT #10)
;INDEX ERROR (BIT #11)
;PLO UNSAFE (BIT #12)

;OFFSET REGISTER (RPCF) (#11)

000001
000002
000004
000010
000020
000040
000200
002000
004000
010000

OF25= 1
OF50= 2
OF100= 4
OF200= 10
OF400= 20
OF800= 40
OFREV= 200
HCI= 2000
ECI= 4000
FMT22= 10000

;OFFSET 25 MICRO INCHES (BIT #0)
;OFFSET 50 MICRO INCHES (BIT #1)
;OFFSET 100 MICRO INCHES (BIT #2)
;OFFSET 200 MICRO INCHES (BIT #3)
;OFFSET 400 MICRO INCHES (BIT #4)
;OFFSET 800 MICRO INCHES (BIT #5)
;OFFSET NEGATIVE (REVERSE) (BIT #5)
;HEADER COMPARE INHIBIT (BIT #10)
;ERROR CORRECTION CODE INHIBIT (BIT #11)
;FORMAT BIT (BIT #12)

;DESIRED CYLINDER ADDRESS (RPCA) (#12)
;(EACH BIT IS CALLED BY BIT NUMBER)

;CURRENT CYLINDER ADDRESS (RPCC) (#13)
;(EACH BIT IS CALLED BY BIT NUMBER)

;SERIAL NUMBER REGISTER (RPSN) (#14)
;(EACH IS CALLED BY BIT NUMBER)

380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433

000001
000002
000010
000040
000100
040000
100000

000001
000002
000040
000100
020000
040000
100000

000101
000103
000105
000107
000111
000113
000115
000117
000121
000123
000131
000141
000143
000145
000151
000153
000161
000163
000171
000173

;RPO4 ERROR REGISTER #03 (RPER3) (#15)

PSU=	1	;PACK SPEED UNSAFE (BIT #0)
VUF=	2	;VELOCITY UNSAFE (BIT #1)
UWR=	10	;ANY UNSAFE EXCEPT READ/WRITE (BIT #3)
ACL=	40	;AC LOW (BIT #5)
DCL=	100	;DC LOW (BIT #6)
SKI=	40000	;SEEK INCOMPLETE (BIT #14)
OCYL=	100000	;OFF CYLINDER (BIT #15)

;RPO5/6 ERROR REGISTER #03 (RPER3) (#15)

DCU=	1	;DC UNSAFE (BIT #0)
WAO=	2	;WRITE AND OFFSET (BIT #1)
ACL=	40	;AC LOW (BIT #5)
DCL=	100	;DC LOW (BIT #6)
OPE=	20000	;OPERATOR PLUG ERROR (BIT #13)
SKI=	40000	;SEEK INCOMPLETE (BIT #14)
OCYL=	100000	;OFF CYLINDER ERROR (BIT #15)

;ECC POSITION REGISTER (RPEC1) (#16)
 ;(EACH BIT IS CALLED BY BIT NUMBER)

;ECC PATTERN REGISTER (RPEC2) (#17)
 ;(EACH BIT IS CALLED BY BIT NUMBER)

::*****

.SBTTL RPO4/5/6 DRIVER COMMANDS

::*****

RNOP	=	101	;NO OPERATION
UNLOAD	=	103	;UNLOAD
SEEK	=	105	;SEEK
RECAL	=	107	;RECALIBRATE
DRVCLR	=	111	;DRIVE CLEAR
RELSE	=	113	;RELEASE
OFFSET	=	115	;OFFSET
RTC	=	117	;RETURN TO CENTER LINE
READIN	=	121	;READ IN PRESET
ACK	=	123	;PACK ACKNOWLEDGE
SEARCH	=	131	;SEARCH
GETREG	=	141	;GET REGISTERS
SETFMT	=	143	;SET FORMAT (& ECI OR HCI)
SELDRV	=	145	;SELECT DRIVE
WCKD	=	151	;WRITE CHECK DATA
WCKHD	=	153	;WRITE CHECK HEADER & DATA
WRDAT	=	161	;WRITE DATA
WRTHD	=	163	;WRITE HEADER & DATA
RODAT	=	171	;READ DATA
ROHD	=	173	;READ HEADER & DATA

.SBTTL COMMON TAGS

::*****
:*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
:*USED IN THE PROGRAM.

434									
435									
436									
437									
438									
439									
440		001100							
441	001100			\$CMTAG:				::	START OF COMMON TAGS
442	001100	000000		\$PASS:	.WORD	0		::	CONTAINS PASS COUNT
443	001102	000		\$TSTNM:	.BYTE	00		::	CONTAINS THE TEST NUMBER
444	001103	000		\$ERFLG:	.BYTE	00		::	CONTAINS ERROR FLAG
445	001104	000000		\$ICNT:	.WORD	00		::	CONTAINS SUBTEST ITERATION COUNT
446	001106	000000		\$LPADR:	.WORD	00		::	CONTAINS SCOPE LOOP ADDRESS
447	001110	000000		\$LPERR:	.WORD	00		::	CONTAINS SCOPE RETURN FOR ERRORS
448	001112	000000		\$ERTTL:	.WORD	00		::	CONTAINS TOTAL ERRORS DETECTED
449	001114	000		\$ITEMB:	.BYTE	00		::	CONTAINS ITEM CONTROL BYTE
450	001115	001		\$ERMAX:	.BYTE	1		::	CONTAINS MAX. ERRORS PER TEST
451	001116	000000		\$ERRPC:	.WORD	00		::	CONTAINS PC OF LAST ERROR INSTRUCTION
452	001120	000000		\$GDADR:	.WORD	00		::	CONTAINS ADDRESS OF 'GOOD' DATA
453	001122	000000		\$BDADR:	.WORD	00		::	CONTAINS ADDRESS OF 'BAD' DATA
454	001124	000000		\$GDDAT:	.WORD	00		::	CONTAINS 'GOOD' DATA
455	001126	000000		\$BDDAT:	.WORD	00		::	CONTAINS 'BAD' DATA
456	001130	000000			.WORD	00		::	RESERVED--NOT TO BE USED
457	001132	000000			.WORD	00			
458	001134	000		\$AUTOB:	.BYTE	00		::	AUTOMATIC MODE INDICATOR
459	001135	000		\$INTAG:	.BYTE	00		::	INTERRUPT MODE INDICATOR
460	001136	000000			.WORD	00			
461	001140	177570		\$SWR:	.WORD	DSWR		::	ADDRESS OF SWITCH REGISTER
462	001142	177570		\$DISPLAY:	.WORD	DDISP		::	ADDRESS OF DISPLAY REGISTER
463	001144	177560		\$TKS:	177560			::	TTY KBD STATUS
464	001146	177562		\$TKB:	177562			::	TTY KBD BUFFER
465	001150	177564		\$TPS:	177564			::	TTY PRINTER STATUS REG. ADDRESS
466	001152	177566		\$TPB:	177566			::	TTY PRINTER BUFFER REG. ADDRESS
467	001154	000		\$NULL:	.BYTE	00		::	CONTAINS NULL CHARACTER FOR FILLS
468	001155	002		\$FILLS:	.BYTE	2		::	CONTAINS # OF FILLER CHARACTERS REQUIRED
469	001156	012		\$FILLC:	.BYTE	12		::	INSERT FILL CHARS. AFTER A "LINE FEED"
470	001157	000		\$TPFLG:	.BYTE	00		::	"TERMINAL AVAILABLE" FLAG (BIT 07)=0=YES.
471	001160	000000		\$ESCAPE:	0			::	ESCAPE ON ERROR ADDRESS
472	001162	177607	000377	\$BELL:	.ASCIZ	<207><377><377>		::	CODE FOR BELL
473	001166	077		\$QJES:	.ASCII	/?/		::	QUESTION MARK
474	001167	015		\$CRLF:	.ASCII	<15>		::	CARRIAGE RETURN
475	001170	000012		\$LF:	.ASCIZ	<12>		::	LINE FEED
476								::	*****
477		000015		CR	=	15			
478		000012		LF	=	12			
479	001172	176700		\$RPADR:	.WORD	176700		::	RH11/RPO4/S/6 UNIBUS ADDRESS
480	001174	000254		\$RPVEC:	.WORD	254		::	RH11 INTERRUPT VECTOR
481	001176	172540		\$LKCSR:	.WORD	172540		::	ADDRESS OF KW11-P CSR
482	001200	172542		\$LKCSB:	.WORD	172542		::	ADDRESS OF KW11-P COUNTER BUFFER
483	001202	000104	000106	\$LPVEC:	.WORD	104,106		::	ADDRESS OF KW11-P VECTOR
484	001206	177546		\$LKS:	.WORD	177546		::	ADDRESS OF KW11-L CONTROL REGISTER
485	001210	000100	000102	\$LLVEC:	.WORD	100,102		::	ADDRESS OF KW11-L VECTOR
486	001214	000000		\$DRIVE:	.WORD	00		::	CONTAINS DRIVE NUMBER SELECTED
487	001216	000000		\$OFSW:	.WORD	00		::	CONTENTS ARE FOR SOFTWARE DECISIONS

488	001220	000000	MODE:	.WORD	0	:	'FORMAT & VERIFY' OR 'CHECK' MODE INDICATOR
489	001222	000632	ENDCYL:	.WORD	410.	:	ENDING CYLINDER
490	001224	000000	BEGCYL:	.WORD	0	:	STARTING CYLINDER
491	001226	000022	ENDTRK:	.WORD	18.	:	ENDING TRACK
492	001230	000000	BEGTRK:	.WORD	0	:	STARTING TRACK
493	001232	000000	TTRKS:	.WORD	0	:	TOTAL # OF TRACKS TO BE FORMATTED
494	001234	000000	TTRKSC:	.WORD	0	:	TOTAL # OF TRACKS COUNTER
495	001236	000000	TRKCNT:	.WORD	0	:	COUNTS TRKS FROM 0-18 PER CYL
496	001240	000000	PATSEL:	.WORD	0	:	CONTAINS PATTERN SELECTED
497	001242	000000	PATA:	.WORD	0	:	1ST WORD OF PATTERN
498	001244	000000	PATB:	.WORD	0	:	2ND WORD OF PATTERN
499	001246	000000	CYLCK:	.WORD	0	:	STORE CYLINDER ADDRESS FOR FORMAT VERIFICATION
500	001250	000000	RETRY:	.WORD	0	:	MAINTAINS # OF WRITE RETRIES MADE
501	001252	000000	SAVSEC:	.WORD	0	:	CONTAINS LAST BAD SECTOR ON FORMAT
502	001254	000000	SAVWC:	.WORD	0	:	CONTAINS WC FOR REMAINING SECTORS ON ERROR
503	001256	000000	WC:	.WORD	0	:	20 OR 22 SECTOR TRACK SIZE (IN WORDS)
504	001260	000000	MWC:	.WORD	0	:	2'S COMPLEMENT OF 'WC'
505	001262	000000	HEDERR:	.WORD	0	:	POSITIONING ERROR DURING FORMAT INDICATOR
506	001264	000000	SEC20:	.WORD	0	:	20 OR 22 SECTOR MODE INDICATOR
507						:	0 = 20 SECTOR MODE
508						:	1'S = 22 SECTOR MODE
509	001266	000000	MAXSEC:	.WORD	0	:	MAXIMUM SECTOR ADDRESS (FOR EITHER 20 OR 22 SECTOR
510						:	FORMAT)
511	001270	000000	DS.CYL:	.WORD	0	:	ADDRESS OF CURRENT CYLINDER
512	001272	000000	DS.TRK:	.WORD	0	:	ADDRESS OF CURRENT TRACK
513	001274	000000	CDRIVE:	.WORD	0	:	DRIVE NUMBER OF 'DRIVER' ERROR MESSAGES
514	001276	000000	ATTN:	.WORD	0	:	ATTENTION REGISTER IMAGE FOR 'DRIVER'
515						:	ERROR MESSAGES
516	001300	000000	CNTLC:	.WORD	0	:	ADDRESS OF '↑C' RETURN
517	001302	000000	CHGADR:	.WORD	0	:	'CHANGE RH11 ADDRESS' FLAG
518						:	
519						:	
520						:	:RH11/RP04/5/6 REGISTERS STORED HERE AFTER AN OPERATION
521	001304	000000	RP.REG:	.WORD	0	:	:RPCS1
522	001306	000000		.WORD	0	:	:RPWC
523	001310	000000		.WORD	0	:	:RPBA
524	001312	000000		.WORD	0	:	:RPDA
525	001314	000000		.WORD	0	:	:RPCS2
526	001316	000000		.WORD	0	:	:RPDS1
527	001320	000000		.WORD	0	:	:RPER1
528	001322	000000		.WORD	0	:	:RPAS
529	001324	000000		.WORD	0	:	:RPLA
530	001326	000000		.WORD	0	:	:RPDB
531	001330	000000		.WORD	0	:	:RPMR
532	001332	000000		.WORD	0	:	:RPDT
533	001334	000000		.WORD	0	:	:RPSN
534	001336	000000		.WORD	0	:	:RPOF
535	001340	000000		.WORD	0	:	:RPCA
536	001342	000000		.WORD	0	:	:RPCC
537	001344	000000		.WORD	0	:	:RPER2
538	001346	000000		.WORD	0	:	:RPER3
539	001350	000000		.WORD	0	:	:RPEC1
540	001352	000000		.WORD	0	:	:RPEC2

543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595

;DATA PARAMETER BLOCK - USED FOR ALL DRIVE OPERATION

FMTDPB:	.BYTE	0	;DRIVE NUMBER
	.BYTE	0	;OFFSET VALUE OR FMT22,ECI, AND HCI
	.BYTE	0	;COMMAND
	.BYTE	0	;PSEL AND A17 AND A16
	.WORD	0	;WORD COUNT (NEG)
	.WORD	0	;BUFFER ADDRESS
	.BYTE	0	;SECTOR ADDRESS
	.BYTE	0	;TRACK ADDRESS
	.WORD	0	;CYLINDER ADDRESS
	.WORD	RP.REG	;ERROR TABLE POINTER
	.WORD	0	;STATUS-ERROR INDICATOR
			;BIT 15 = 1: ERROR OCCURRED
			;BIT 07 = 1: DONE
			;BIT 14-10 AND BIT 06-03
			;INDICATE TYPE OF ERROR.

;PARAMETER POINTER TABLE

TABLE:	PAR1,0,BEGCYL
	PAR2,18,BEGTRK
	PAR3,0,ENDCYL
	PAR4,18,ENDTRK,0

;ASCII MESSAGES FOR ADDRESS PARAMETERS

PAR1:	.ASCIZ	2START CYL 2
PAR2:	.ASCIZ	2START TRK 2
PAR3:	.ASCIZ	2END CYL 2
PAR4:	.ASCIZ	2END TRK 2

;SECTOR BUFFER ADDRESS TABLE

ADRTBL:	.WORD	BUFP	;ADDRESS OF SECTOR 0
	.WORD	BUFP+(520.*1.)	;ADDRESS OF SECTOR 1
	.WORD	BUFP+(520.*2.)	;ADDRESS OF SECTOR 2
	.WORD	BUFP+(520.*3.)	;ADDRESS OF SECTOR 3
	.WORD	BUFP+(520.*4.)	;ADDRESS OF SECTOR 4
	.WORD	BUFP+(520.*5.)	;ADDRESS OF SECTOR 5
	.WORD	BUFP+(520.*6.)	;ADDRESS OF SECTOR 6
	.WORD	BUFP+(520.*7.)	;ADDRESS OF SECTOR 7
	.WORD	BUFP+(520.*8.)	;ADDRESS OF SECTOR 8
	.WORD	BUFP+(520.*9.)	;ADDRESS OF SECTOR 9
	.WORD	BUFP+(520.*10.)	;ADDRESS OF SECTOR 10
	.WORD	BUFP+(520.*11.)	;ADDRESS OF SECTOR 11
	.WORD	BUFP+(520.*12.)	;ADDRESS OF SECTOR 12

001354	000
001355	000
001356	000
001357	000
001360	000000
001362	000000
001364	000
001365	000
001366	000000
001370	001304
001372	000000
001426	052123
001434	054503
001441	123
001446	052040
001454	047105
001462	020114
001465	105
001472	045522
001476	025130
001500	026140
001502	027150
001504	030160
001506	031170
001510	032200
001512	033210
001514	034220
001516	035230
001520	036240
001522	037250
001524	040260
001526	041270

596 001530 042300
 597 001532 043310
 598 001534 044320
 599 001536 045330
 600 001540 046340
 601 001542 047350
 602 001544 050360
 603 001546 051370
 604 001550 052400

.WORD BUFP+(520.*13.) ;ADDRESS OF SECTOR 13
 .WORD BUFP+(520.*14.) ;ADDRESS OF SECTOR 14
 .WORD BUFP+(520.*15.) ;ADDRESS OF SECTOR 15
 .WORD BUFP+(520.*16.) ;ADDRESS OF SECTOR 16
 .WORD BUFP+(520.*17.) ;ADDRESS OF SECTOR 17
 .WORD BUFP+(520.*18.) ;ADDRESS OF SECTOR 18
 .WORD BUFP+(520.*19.) ;ADDRESS OF SECTOR 19
 .WORD BUFP+(520.*20.) ;ADDRESS OF SECTOR 20
 .WORD BUFP+(520.*21.) ;ADDRESS OF SECTOR 21

:REMAINING WORD COUNT TABLE

605
 606
 607
 608 001552 000404
 609 001554 001010
 610 001556 001414
 611 001560 002020
 612 001562 002424
 613 001564 003030
 614 001566 003434
 615 001570 004040
 616 001572 004444
 617 001574 005050
 618 001576 005454
 619 001600 006060
 620 001602 006464
 621 001604 007070
 622 001606 007474
 623 001610 010100
 624 001612 010504
 625 001614 011110
 626 001616 011514
 627 001620 012120
 628 001622 012524
 629 001624 013130

WCTBL: .WORD 260. ;REMAINING WORD COUNT AFTER SECTOR 0
 .WORD 260.+(260.*1.) ;REMAINING WORD COUNT AFTER SECTOR 1
 .WORD 260.+(260.*2.) ;REMAINING WORD COUNT AFTER SECTOR 2
 .WORD 260.+(260.*3.) ;REMAINING WORD COUNT AFTER SECTOR 3
 .WORD 260.+(260.*4.) ;REMAINING WORD COUNT AFTER SECTOR 4
 .WORD 260.+(260.*5.) ;REMAINING WORD COUNT AFTER SECTOR 5
 .WORD 260.+(260.*6.) ;REMAINING WORD COUNT AFTER SECTOR 6
 .WORD 260.+(260.*7.) ;REMAINING WORD COUNT AFTER SECTOR 7
 .WORD 260.+(260.*8.) ;REMAINING WORD COUNT AFTER SECTOR 8
 .WORD 260.+(260.*9.) ;REMAINING WORD COUNT AFTER SECTOR 9
 .WORD 260.+(260.*10.) ;REMAINING WORD COUNT AFTER SECTOR 10
 .WORD 260.+(260.*11.) ;REMAINING WORD COUNT AFTER SECTOR 11
 .WORD 260.+(260.*12.) ;REMAINING WORD COUNT AFTER SECTOR 12
 .WORD 260.+(260.*13.) ;REMAINING WORD COUNT AFTER SECTOR 13
 .WORD 260.+(260.*14.) ;REMAINING WORD COUNT AFTER SECTOR 14
 .WORD 260.+(260.*15.) ;REMAINING WORD COUNT AFTER SECTOR 15
 .WORD 260.+(260.*16.) ;REMAINING WORD COUNT AFTER SECTOR 16
 .WORD 260.+(260.*17.) ;REMAINING WORD COUNT AFTER SECTOR 17
 .WORD 260.+(260.*18.) ;REMAINING WORD COUNT AFTER SECTOR 18
 .WORD 260.+(260.*19.) ;REMAINING WORD COUNT AFTER SECTOR 19
 .WORD 260.+(260.*20.) ;REMAINING WORD COUNT AFTER SECTOR 20
 .WORD 260.+(260.*21.) ;REMAINING WORD COUNT AFTER SECTOR 21

630
 631
 632

.EVEN

E03

```

002074 005074 000403 BR BEGIN2 : START THE PROGRAM
002076 005037 001302 BEGIN1: CLR CHGADR : CLEAR THE 'CHANGE RHI1 ADDRESS' INDICATOR
002102 000005 : CLEAR THE BUS
:SBTTL INITIALIZE THE COMMON TAGS
::CLEAR THE COMMON TAGS (%CMTAG) AREA
002104 012706 001100 MOV #SCMTAG,R6 : FIRST LOCATION TO BE CLEARED
002110 005026 CLR (R6)+ : CLEAR MEMORY LOCATION
002112 022706 001140 CMP #SWR,R6 ;;DONE?
002116 001374 BNE : LOOP BACK IF NO
002120 012706 001100 MOV #STACK,SP : SETUP THE STACK POINTER
::INITIALIZE A FEW VECTORS
002124 012737 005636 000030 MOV #ERROR,%EMTVEC : EMT VECTOR FOR ERROR ROUTINE
002132 012737 000340 000032 MOV #340,%EMTVEC+2 : LEVEL 7
002140 012737 012014 000034 MOV #STRAP,%TRAPVEC : TRAP VECTOR FOR TRAP CALLS
002146 012737 000340 000036 MOV #340,%TRAPVEC+2;LEVEL 7
002154 005037 001160 CLR %ESCAPE : CLEAR THE ESCAPE ON ERROR ADDRESS
002160 112737 000001 001115 MOVB #1,%ERMAX : ALLOW ONE ERROR PER TEST
::SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
::EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
002166 013746 000004 MOV %ERRVEC, -(SP) : SAVE ERROR VECTOR
002172 012737 002226 000004 MOV #64,%ERRVEC : SET UP ERROR VECTOR
002200 012737 177570 001140 MOV #DSWR,SWR : SETUP FOR A HARDWARE SWICH REGISTER
002206 012737 177570 001142 MOV #DISP,DISPLAY : AND A HARDWARE DISPLAY REGISTER
002214 022777 177777 176716 CMP #-1,%SWR : TRY TO REFERENCE HARDWARE SWR
002222 001012 BNE 655 : BRANCH IF NO TIMEOUT TRAP OCCURRED
: AND THE HARDWARE SWR IS NOT = -1
002224 000403 BR 655 : BRANCH IF NO TIMEOUT
002226 012716 002234 645: MOV #555,(SP) : SET UP FOR TRAP RETURN
002232 000002 RTI
002234 012737 000176 001140 655: MOV #SWREG,SWR : POINT TO SOFTWARE SWR
002242 012737 000174 001142 MOV #DISPREG,DISPLAY
002250 012637 000004 665: MOV (SP)+,%ERRVEC : RESTORE ERROR VECTOR
002254 000005 RESET : CLEAR WORLD
002256 012737 000240 000036 MOV #PRS,%TRAPVEC+2 : CHANGE TRAP PRIORITY BACK TO 5
002264 012737 000240 000032 MOV #PRS,%EMTVEC+2 : CHANGE EMT PRIORITY BACK TO 5
002272 012737 002076 001300 MOV #BEGIN1,CNTLC : 'CONTROL C' ADDRESS
002300 005227 177777 INC #-1 : FIRST START
002304 001010 BNE 15 : BR IF NOT
002306 104401 025130 TYPE .TITLE : ADAS OF 'TITLE' MESSAGE
002312 122737 000011 000041 CMPB #11,41 : LOADED FROM AN RPO4/5 6
002320 001002 BNE 15 : BR IF NOT
002322 104401 025215 TYPE .LOADAV : INSTRUCT OPERATOR TO REMOVE 'XXDP'
: PACK FROM DRIVE 0
002326 004737 010204 15: JSR PC,STKINT : TURN ON THE KEYBOARD INTERRUPT
:SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
002332 005737 000042 TST %42 : ARE WE RUNNING UNDER XXDP 'ACT'
002336 001006 BNE 675 : BRANCH IF YES
002340 023727 001140 000176 CMP SWR,%SWREG : SOFTWARE SWITCH REG SELECTED?
002346 001005 BNE 685 : BRANCH IF NO
002350 104406 GTSWR : GET SOFT-SWR SETTINGS
002352 000403 BR 685
002354 112737 000001 001134 675: MOVB #1,%ALTOB : SET AUTO-MODE INDICATOR
002356 685:

```

```

049 002362 005227 177777 INC # -1 ;CHECK FOR FIRST START
050 002366 001010 BNE SETVEC ;BR IF NOT
051 002370 004737 025434 JSR PC,BUSADR ;CHECK THE RH11 ADDRESS
052 002374 013737 001172 012246 MOV $RPADR,RPADR ;RH11 ADDRESS
053 002402 013737 001174 012250 MOV $RPVEC,RPVEC ;RH11 VECTOR ADDRESS
054
055 ;DISPLAY DRIVE STATUS AND SET UP THE OTHER UNITS THE
056 ; PROGRAM WILL USE
057
058 002410 004737 005742 SETVEC: JSR PC,ST.CLK ;START THE CLOCK
059 002414 004737 012264 JSR PC,PPINIT ;INITIALIZE THE RPO4/5/6 DRIVER
060 002420 012737 177777 012206 MOV # -1,SAVEFG ;SET THE SAVE REGISTERS FLAG
061 002426 005227 177777 INC # -1 ;SEE IF FIRST START
062 002432 001404 BEQ 11$ ;BR IF YES
063 002434 032777 000004 176476 BIT #SW02,JSWR ;TYPEOUT THE DRIVE STATUS TABLE ?
064 002442 001076 BNE 10$ ;BR IF NOT
065 002444 012737 000340 177776 11$: MOV #PR7,PS ;SET PRIORITY TO 7
066 002452 005004 CLR R4 ;DRIVE TABLE POINTER
067 002454 104401 001167 TYPE .$CRLF ;CR-LF
068 002460 104401 020540 TYPE .SYSTAT ;TYPE STATUS HEADING
069
070 002464 010446 1$: MOV R4,-(SP) ;SAVE R4 FOR TYPEOUT
071
072 002466 104403 ;TYPE DRIVE NUMBER
073 002470 002 ;GO TYPE--OCTAL ASCII
074 002471 000 ;TYPE 2 DIGIT(S)
075 002472 104401 020703 TYPE .LIN4SP ;SUPPRESS LEADING ZEROS
076 002476 105764 012120 TSTB DRVSTA(R4) ;SPACES
077 002502 100416 BMI 4$ ;CHECK DRIVE'S STATUS
078 002504 001020 BNE 5$ ;BR IF UNSAFE
079 002506 105764 012130 TSTB DRVTP(R4) ;BR IF ONLINE
080 002512 001404 BEQ 2$ ;SEE IF OFFLINE OR NONEXISTENT
081 002514 100006 BPL 3$ ;BR IF NONEXISTENT
082 002516 104401 020553 TYPE .NOTRP ;BR IF OFFLINE
083 002522 000440 BR 9$ ;DRIVE NOT AN RPO4 5.6
084 002524 104401 020574 2$: TYPE .NOTPRS ;CHECK NEXT DRIVE
085 002530 000435 BR 9$ ;DRIVE NOT PRESENT
086 002532 104401 020532 3$: TYPE .UNTOFF ;CHECK NEXT DRIVE
087 002536 000405 BR 6$ ;DRIVE OFFLINE
088 002540 104401 020611 4$: TYPE .NOTSAF ;PRINT DRIVE TYPE
089 002544 000402 BR 6$ ;DRIVE UNSAFE
090 002546 104401 020543 5$: TYPE .UNTON ;PRINT DRIVE TYPE
091 002552 104401 020705 6$: TYPE .LINSF ;DRIVE ONLINE
092 002556 012737 020621 002622 MOV $RPO4B,8$ ;SPACES
093 002564 132764 000001 012130 BITB #BIT00,DRVTP(R4) ;ADDRESS OF RPO4 MESSAGE
094 002572 001012 BNE 7$ ;RPO4 ?
095 002574 012737 020626 002622 MOV $RPO5,9$ ;BR IF YES
096 002602 132764 000002 012130 BITB #BIT01,DRVTP(R4) ;ADDRESS OF RPO5 MESSAGE
097 002610 001003 BNE 7$ ;RPO5 ?
098 002612 012737 020633 002622 MOV $RPO6,9$ ;BR IF YES
099 002620 104401 7$: TYPE ;ADDRESS OF RPO6 MESSAGE
100 002622 000000 8$: .WORD 0 ;TYPE THE DRIVE TYPE MESSAGE
101 002624 104401 001167 9$: TYPE .$CRLF ;MESSAGE ADDRESS HERE
102 002630 005204 INC R4 ;CR-LF
;INCREMENT DRIVE NUMBER TABLE POINTER

```



```

957 003100 012737 000002 001240      MOV      #2,PATSEL      ;SETUP FOR WORST CASE PATTERN
958 003106 112737 177777 001354      MOVB     #-1,FMTDPB    ;SETUP INVALID DRIVE NUMBER
959 003114 000400                BR        MO           ;BRANCH TO START
960
961                ;GO FIND OUT WHAT DRIVE
962
963 003116 012737 006116 001300 MO:      MOV      #0ENTER,CNTLC ;CONTROL C ABORT ENTRANCE
964 003124 005037 001112                CLR      $ERTTL       ;CLEAR THE ERROR ACCUMULATOR
965 003130 004737 010204                JSR      PC,$TKINT     ;INITIALIZE THE TTY KEYBOARD
966 003134 104401 020657                TYPE     ,MUNIT       ;ASK FOR DRIVE NUMBER
967 003140 104411                RDLIN                    ;READ THE KEYBOARD
968 003142 012601                MOV      (SP)+,R1     ;ADDRESS OF ENTRY
969 003144 004537 005426                JSR      R5,CK.CHR    ;CHECK ONE CHARACTER
970 003150 003176                3$
971 003152 003164                2$
972 003154 003176                3$
973 003156 003164                2$
974 003160 003204                4$
975 003162 003176                3$
976 003164 005037 001214        2$:      CLR      DRIVE       ;SELECT DRIVE ZERO
977 003170 104401 020701                TYPE     ,MDRVD       ;GO TYPE DEFAULT DRIVE NUMBER
978 003174 000413                BR        $$          ;GO SEE IF DRIVE ZERO IS THERE
979 003176 104401 001166        3$:      TYPE     ,SQUES      ;TYPE ""
980 003202 000745                BR        MO         ;ASK FOR DRIVE NUMBER AGAIN
981 003204 010237 001214        4$:      MOV      R2,DRIVE    ;SAVE DRIVE NUMBER
982 003210 005702                TST     R2           ;SEE IF DRIVE 0
983 003212 001004                BNE     $$          ;BR IF NOT
984 003214 122737 000011 000041      CMPB    #11.41      ;PROGRAM LOADED FROM AN RPC4 5.6 ?
985 003222 001431                BEQ     7$          ;BR IF IT WAS, CAN'T FORMAT THE DRIVE
986 003224 004737 005742        5$:      JSR      PC,$T.CLK   ;START THE CLOCK
987 003230 004737 012264                JSR      PC,$PINIT   ;GO SEE WHAT DRIVES ARE AVAILABLE
988 003234 012737 177777 012206      MOV     #-1,$AVEFG  ;SAVE THE REGISTERS
989 003242 012737 177777 012210      MOV     #-1,$EEKFG  ;SET 'NO OPTIMIZATION' FLAG
990 003250 005037 177776                CLR     PS          ;SET PRIORITY BACK TO ZERO
991 003254 105762 012120                TSTB   DRVSTA,R2    ;LOOK AT DRIVE STATUS
992 003260 003015                BGT     8$          ;BRANCH IF ONLINE
993 003262 001403                BEQ     6$          ;BR IF DRIVE NOT AVAILABLE
994 003264 104401 021057                TYPE     ,MUSDR      ;'DRIVE UNSAFE'
995 003270 000712                BR        MO         ;GO GET DRIVE NUMBER AGAIN
996 003272 105762 012130        6$:      TSTB   DRVTP(R2)   ;'A DRIVE PRESENT?'
997 003276 001003                BNE     7$          ;BR IF SO
998 003300 104401 020762                TYPE     ,MDRNP      ;TYPE 'DRIVE NOT PRESENT'
999 003304 000704                BR        MO         ;GO GET DRIVE NUMBER AGAIN
1000 003306 104401 021007        7$:      TYPE     ,MER11     ;'DRIVE NOT AVAILABLE'
1001 003312 000701                BR        MO         ;GO GET DRIVE NUMBER AGAIN
1002 003314 123737 001214 001354      8$:      CMPB    DRIVE,FMTDPB ;SAME DRIVE AS LAST TIME ?
1003 003322 001430                BEQ     M2          ;BR IF IT IS
1004 003324 113737 001214 001354      MOVB    DRIVE,FMTDPB ;SETUP DRIVE ADDRESS
1005 003332 012737 000632 001222      MOV     #410,$ENDCYL ;SETUP FOR RPC4/5
1006 003340 132762 000003 012130      BITB    #BIT00!BIT01,DRVTP(R2) ;SEE IF DRIVE RPC4 5
1007 003346 001003                BNE     9$          ;BR IF EITHER
1008 003350 012737 001456 001222      MOV     #814,$ENDCYL ;SETUP ENDING CYLINDER FOR RPC6
1009 003356 005037 001230        9$:      CLR     BEGTRK      ;CLEAR STARTING TRACK ADDRESS
1010 003362 005037 001224                CLR     BEG0YL      ;CLEAR STARTING CYLINDER ADDRESS

```

```

1011 003366 013737 001222 001376      MOV      ENDCYL, TABLE+2 ; ENTRY LIMIT FOR BEGINNING CYLINDER
1012 003374 013737 001222 001412      MOV      ENDCYL, TABLE+16 ; ENTRY LIMIT FOR END CYLINDER
1013 003402 000400                BR        M2 ; GET ADDRESS LIMITS FROM THE OPERATOR
1014
1015                ; GET ADDRESS LIMITS
1016
1017 003404 104401 020710      M2:      TYPE      ENTADR ; 'ENTER ADDRESS LIMITS'
1018 003410 004737 006236      JSR      PC, PARENT ; GET THE ADDRESS LIMITS
1019 003414 023737 001222 001224      CMP      ENDCYL, BEGCYL ; SEE IF ENDING CYLINDER EQ TO GT THAN BEGINNING
1020 003422 101010                BHI      M4 ; BR IF HIGHER
1021 003424 103404                BLO      3$ ; BR IF LESS
1022 003426 023737 001226 001230 2$:      CMP      ENDTRK, BEGTRK ; SEE IF ENDING TRACK EQ OR GT THAN BEGINNING
1023 003434 103003                SHIS     M4 ; BR IF YES
1024 003436 104401 021456      3$:      TYPE      ,MADRER ; INVALID ADDRESS ENTERED
1025 003442 000760                BR        M2 ; TRY AGAIN
1026
1027                ; GO GET DATA PATTERN FOR FORMAT
1028
1029 003444 104401 021560      M4:      TYPE      ,MSELP ; GO TYPE 'SELECT PATTERN'
1030 003450 104411                RDLIN ; READ THE KEYBOARD
1031 003452 012601                MOV      (SP)+, R1 ; ENTRY ADDRESS
1032 003454 004537 006426      JSR      R5, CK.CHR ; CHECK ONE CHARACTER
1033 003460 003514                3$      ; ILLEGAL CHARACTER
1034 003462 003474                1$      ; CARRIAGE RETURN
1035 003464 003514                3$      ; " "
1036 003466 003474                1$      ; " "
1037 003470 003506                2$      ; DIGIT 0-7
1038 003472 003514                3$      ; DIGIT 8-9
1039 003474 104401 021660      1$:      TYPE      ,MPATD ; TYPE DEFAULT PATTERN
1040 003500 012702 000002      MOV      #2, R2 ; WORST CASE PATTERN
1041 003504 000406                BR        4$ ; GO SAVE PATTERN
1042 003506 020227 000002      2$:      CMP      R2, #2 ; IS # LARGER THAN 2
1043 003512 101403                BLOS     4$ ; BRANCH IF NOT
1044 003514 104401 001165      3$:      TYPE      ,SQUES ; TYPE ''
1045 003520 000751                BR        M4 ; RETYPE LINE
1046 003522 010237 001240      4$:      MOV      R2, PATSEL ; SAVE PATTERN SELECTED
1047
1048                ; GO TYPE 'STARTING FORMAT ON DRIVE N'
1049
1050 003526 012737 006136 001300 M5:      MOV      #TYPADR, CNTLC ; CHANGE IC ENTRANCE
1051 003534 005737 001220                TST      MODE ; 'FORMAT' OR 'CHECK' MODE
1052 003540 001403                BEQ      1$ ; BR IF 'CHECK' MODE
1053 003542 104401 021673      TYPE      ,MSFOU ; TYPE 'STARTING FORMAT ON DRIVE N'
1054 003546 000402                BR        2$
1055 003550 104401 021730      1$:      TYPE      ,MSCHK ; TYPE 'STARTING CHECK ON DRIVE N'
1056 003554
1057 003554 013746 001214      2$:      MOV      DRIVE, -(SP) ; SAVE DRIVE FOR TYPEOUT
1058
1059 003560 104403                TYPOS ; TYPE DRIVE NUMBER
1060 003562 001                .BYTE 1 ; GO TYPE--OCTAL ASCII
1061 003563 000                .BYTE 0 ; TYPE 1 DIGIT(S)
1062 003564 104401 001167      TYPE      ,SCLF ; SUPPRESS LEADING ZEROS
1063
1064                ; SETUP TOTAL TRACK COUNT FOR FORMAT
    
```

```

1065
1066 003570 023737 001222 001224 CKADRS: CMP ENDCYL,BEGCYL ;STARTING AND ENDING CYLINDERS THE SAME ?
1067 003576 001011 BNE 1$ ;BRANCH IF BEG CYL NOT EQUAL TO ENDCYL
1068 003600 013737 001226 001232 MOV ENDRK,TTRKS ;END TRACK ADDRESS
1069 003606 163737 001230 001232 SUB BEGTRK,TTRKS ;SUBTRACT THE STARTING TRACK ADDRESS
1070 003614 005237 001232 INC TTRKS ;MAKE THE NUMBER OF TRACKS INCLUSIVE
1071 003620 000427 SR SETPAT ;SETUP THE DATA PATTERN
1072 003622 013702 001222 1$: MOV ENDCYL,R2 ;ENDING CYLINDER
1073 003626 163702 001224 SUB BEG CYL,R2 ;SUBTRACT THE STARTING CYLINDER
1074 003632 013737 001226 001232 MOV ENDRK,TTRKS ;CALCULATE THE RESIDUAL TRACKS
1075 003640 163737 001230 001232 SUB BEGTRK,TTRKS ;SUBTRACT THE STARTING TRACK
1076 003646 100004 BPL 2$ ;BR IF ENDING TRACK GREAT
1077 003650 062737 000023 001232 ADD #19.,TTRKS ;CORRECT THE VALUE
1078 003656 005302 DEC R2 ;COUNT THE PARTIAL TRACK
1079 003660 005237 001232 2$: INC TTRKS ;MAKE THE NUMBER INCLUSIVE
1080 003664 005302 3$: DEC R2 ;DECREMENT THE CYLINDER COUNT
1081 003666 100404 BMI SETPAT ;BR IF DONE
1082 003670 062737 000023 001232 ADD #19.,TTRKS ;ADD CYLINDER WORTH OF TRACKS
1083 003676 000772 BR 3$ ;CONTINUE
    
```

;THIS CODE SETS UP THE SELECTED DATA PATTERN TO BE WRITTEN ON EACH SECTOR IMAGE

```

1084
1085
1086
1087 003700 005037 001242 SETPAT: CLR PATA ;CLEAR DATA PATTERN A
1088 003704 005037 001244 CLR PATB ;CLEAR DATA PATTERN B
1089 003710 005737 001240 TST PATSEL ;SEE IF PATTERN OF ONES
1090 003714 001416 BEQ 1$ ;BR IF SO
1091 003716 005137 001242 COM PATA ;SET PATA TO ONES
1092 003722 005137 001244 COM PATB ;SET PATB TO ONES
1093 003726 022737 000001 001240 CMP #1,PATSEL ;SEE IF PATTERN OF ZEROS
1094 003734 001406 BEQ 1$ ;BRANCH IF SO
1095 003736 012737 165555 001242 MOV #165555,PATA ;SET UP WORST CASE
1096 003744 012737 133333 001244 MOV #133333,PATB ;SET UP WORST CASE
1097 003752 013703 001256 1$: MOV WC,R3 ;SET UP COUNTER
1098 003756 012700 025130 MOV #BUF,PC ;SET UP MEMORY POINTER
1099 003762 013701 001242 MOV PATA,R1 ;SET UP PATTERN IN R1
1100 003766 013702 001244 MOV PATB,R2 ;SET UP PATTERN IN R2
1101 003772 010120 2$: MOV R1,(R0)+ ;MOV 1ST PAT INTO MEM
1102 003774 010220 MOV R2,(R0)+ ;MOV 2ND PAT INTO MEM
1103 003776 005303 DEC R3 ;KEEP COUNT
1104 004000 005303 DEC R3 ;KEEP COUNT
1105 004002 001373 BNE 2$ ;DO IT AGAIN IF R3 NOT 0
    
```

;THIS CODE SETS UP FOR THE ACTUAL FORMAT

```

1106
1107
1108
1109 004004 004737 005402 WTRK: JSR PC,SETTBL ;GO SET UP DRIVER TABLE
1110 004010 004737 005602 JSR PC,SETHDR ;GO INITIALIZE HEADERS IN THE SECTOR BUFFER IN CORE
1111 004014 112737 000020 001355 MOV #20,FMTDPB+1 ;LOAD FMT22 BIT
1112 004022 005737 001264 TST SEC20 ;18 BIT MODE ?
1113 004026 001002 BNE 1$ ;BR IF NOT
1114 004030 105037 001355 CLRB FMTDPB+1 ;CLEAR THE FMT22 BIT
1115 004034 112737 000143 001356 1$: MOV #SETFMT,FMTDPB+2 ;'LOAD FORMAT' COMMAND
1116 004042 004037 013034 2$: JSR RO,RPO4 ;START THE COMMAND
1117 004046 001354 FMTDPB ;DPB ADDRESS
1118 004050 000774 BR 2$ ;QUEUE FULL RETURN
    
```

```

1119 004052 005737 001372 3$: TST FMTDPB+16 ;LOOK FOR DONE
1120 004056 001775 BEQ 3$ ;LOOP UNTIL FINISHED
1121 004060 005037 001216 WRTRK1: CLR SOFSW ;CLEAR ERROR COUNTER
1122 004064 005037 001250 CLR RETRY ;ZERO THE RETRY COUNTER
1123 004070 105037 001364 CLR FMTDPB+10 ;RESTORE SECTOR
1124 004074 013737 001260 001360 MOV MWC,FMTDPB+4 ;RESTORE WC
1125 004102 012737 025130 001362 MOV #BUFP,FMTDPB+6 ;RESTORE BA
1126 004110 005737 001220 TST MODE ;'FORMAT' OR 'CHECK' MODE ?
1127 004114 001450 BEQ CKTRK ;BR IF 'CHECK' MODE
1128 004116 112737 000163 001356 WRTRK2: MOV #WRTHD,FMTDPB+2 ;SET WRITE HEADER & DATA COMMAND IN TBL
1129 004124 012737 004124 001110 MOV #,$LPEERR ;SETUP LOOP ON ERROR ADDRESS
1130 004132 012706 001100 MOV #STACK,SP ;LOAD STACK POINTER
1131 004136 004037 013034 1$: JSR RD,RPO4 ;GO FORMAT A TRACK
1132 004142 001354 FMTDPB ;ADRS OF PARAMETERS - TBL
1133 004144 000774 BR 1$ ;WAIT FOR QUEUE IF FULL
1134 004146 005737 001372 2$: TST FMTDPB+16 ;WAIT FOR COMMAND TO COMPLETE
1135 004152 001775 BEQ 2$ ;BRANCH IF NOT DONE
1136 004154 100024 BPL 4$ ;BRANCH IF NO ERROR
1137 004156 012737 004204 001160 MOV #3$, $ESCAPE ;ESCAPE TO 3$ ON ERROR
1138 004164 004737 005234 JSR PC,ERINDX ;SEE WHICH ERROR
1139 004170 104010 ERROR 10 ;DRIVE OFFLINE
1140 004172 104011 ERROR 11 ;PERSISTENT DRIVE UNSAFE ERROR
1141 004174 104012 ERROR 12 ;UNCORRECTABLE MASSBUS PARITY ERROR
1142 004176 104013 ERROR 13 ;SOFTWARE TIMEOUT
1143 004200 104014 ERROR 14 ;DRIVE UNSAFE ERROR
1144 004202 104015 ERROR 15 ;DRIVE/CONTROLLER ERROR DURING WRITE
1145 004204 004737 005334 3$: JSR PC,LOP.CK ;LOOP ON THE ERROR ?
1146 004210 022737 000003 001250 CMP #3,RETRY ;ERROR RETRY LIMIT ?
1147 004216 001403 BEQ 4$ ;BR IF REACHED
1148 004220 005237 001250 INC RETRY ;COUNT THE ERROR
1149 004224 000744 BR 1$ ;TRY AGAIN
1150 004226 005037 001160 4$: CLR $ESCAPE ;C' ERROR ESCAPE ADDRESS
1151 004232 005037 001250 CLR RETRY ;CLEAR THE RETRY COUNTER
1152
1153 ;CHECK THE TRACK JUST WRITTEN
1154
1155 004236 112737 000153 001356 CKTRK: MOV #WCKHD,FMTDPB+2 ;SET WRITE CHECK HEADER & DATA COMMAND IN TBL
1156 004244 012737 004244 001110 MOV #,$LPEERR ;SETUP LOOP ON ERROR ADDRESS
1157 004252 012706 001100 MOV #STACK,SP ;LOAD STACK POINTER
1158 004256 004037 013034 1$: JSR RD,RPO4 ;GO CHECK THE TRACK JUST FORMATTED
1159 004262 001354 FMTDPB ;ADRS OF PARAMETERS - TBL
1160 004264 000774 BR 1$ ;WAIT FOR QUEUE IF FULL
1161 004266 005737 001372 2$: TST FMTDPB+16 ;WAIT FOR COMMAND TO COMPLETE
1162 004272 001775 BEQ 2$ ;BRANCH IF NOT DONE
1163 004274 100112 BPL 8$ ;BRANCH IF NO ERROR
1164 004276 113737 001312 001252 MOV #RP.REG+RPDA.SAVSEC ;GET THE SECTOR ADDRESS
1165 004304 001005 BNE 3$ ;BRANCH IF NOT SECTOR 0
1166 004306 013737 001266 001252 MOV MAXSEC,SAVSEC ;RESTORE TO LAST SECTOR +1
1167 004314 005237 001252 INC SAVSEC ;INCREMENT TO LAST SECTOR +1
1168 004320 005337 001252 3$: DEC SAVSEC ;ADJUST SECTOR TO THE ONE THAT FAILED
1169 004324 012737 004570 001160 MOV #10$, $ESCAPE ;ESCAPE TO 10$ ON ERROR
1170 004332 004737 005234 JSR PC,ERINDX ;SEE WHICH ERROR
1171 004336 104010 ERROR 10 ;DRIVE OFFLINE
1172 004340 104011 ERROR 11 ;PERSISTENT DRIVE UNSAFE ERROR

```

1173	004342	104012			ERROR	12		;UNCORRECTABLE MASSBUS PARITY ERROR
1174	004344	104013			ERROR	13		;SOFTWARE TIMEOUT
1175	004346	104014			ERROR	14		;DRIVE UNSAFE ERROR
1176	004350	032737	040000	001314	BIT	#WCE,RP.REG+RPCS2		;WRITE CHECK ERROR ?
1177	004356	001005			BNE	4\$;BR IF SET
1178	004360	033727	001320		BIT	RP.REG+RPER1.(PC)+		;CHECK FOR DATA ERRORS
1179	004364	130620			.WORD	DCK!OFI!DTE!HCRC!HCE!FER		;DATA ERROR BITS
1180	004366	001001			BNE	4\$;BR IF SET
1181	004370	104016			ERROR	16		;CONTROLLER/DRIVE ERROR DURING WRITE CHECK
1182	004372	005737	001220	4\$:	TST	MODE		;FORMAT OR CHECK MODE ?
1183	004376	001407			BEQ	5\$;BR IF CHECK
1184	004400	005737	001216		TST	SOF5W		;RETRYING THE SECTOR ?
1185	004404	001404			BEQ	5\$;BR IF NOT
1186	004406	012737	004612	001160	MOV	#11\$, \$ESCAPE		;ESCAPE TO 11\$ ON ERROR
1187	004414	104017			ERROR	17		;SECTOR NOT ACCEPTABLE
1188	004416	005037	001160	5\$:	CLR	\$ESCAPE		;CLEAR THE ERROR ESCAPE ADDRESS
1189	004422	032737	040000	001316	BIT	#ERR,RP.REG+RPDS1		;DATA ERROR ?
1190	004430	001002			BNE	6\$;BR IF IT IS
1191	004432	104024			ERROR	24		;WRITE CHECK ERROR
1192	004434	000401			BR	7\$;CONTINUE
1193	004436	104020		6\$:	ERROR	20		;DATA ERROR DURING WRITE CHECK
1194	004440	013701	001252	7\$:	MOV	SAVSEC,R1		;FAILING SECTOR ADDRESS
1195	004444	113737	001252	001364	MOVB	SAVSEC,FMTDPB+10		;SECTOR ADDRESS
1196	004452	006301			ASL	R1		;SETUP INDEX TO ADDRESS WORDS
1197	004454	016137	001476	001362	MOV	ADRTBL(R1),FMTDPB+6		;BUFFER ADDRESS FOR FAILING SECTOR
1198	004462	013746	001260		MOV	MWC,-(SP)		;GET MAXIMUM WORD COUNT VALUE (2'S COMP)
1199	004466	066116	001552		ADD	WCTBL(R1),(SP)		;ADD WORD COUNT THROUGH FAILING SECTOR
1200	004472	012637	001254		MOV	(SP)+,SAVWC		;STORE WORD COUNT FOR REMAINDER OF TRACK
1201	004476	005737	001220		TST	MODE		;FORMAT OR CHECK MODE ?
1202	004502	001421			BEQ	9\$;BR IF CHECK
1203	004504	012737	177374	001360	MOV	#-260.,FMTDPB+4		;WORD COUNT FOR 1 SECTOR
1204	004512	005237	001216		INC	SOF5W		;INDICATE THAT A RETRY IS IN PROGRESS
1205	004516	000137	004116		JMP	WRTRK2		;REFORMAT ERROR SECTOR
1206	004522	005737	001216	8\$:	TST	SOF5W		;RETRY IN PROGRESS ?
1207	004526	001431			BEQ	11\$;BR IF NOT
1208	004530	022737	000002	001216	CMP	#2,SOF5W		;SEE IF LAST RETRY
1209	004536	001403			BEQ	9\$;BR IF IT IS
1210	004540	005237	001216		INC	SOF5W		;INCREMENT RETRY COUNT
1211	004544	000644			BR	1\$;READ AGAIN
1212	004546	123737	001266	001364	9\$:	CMPB	MAXSEC,FMTDPB+10	;SEE IF LAST SECTOR ON THE TRACK
1213	004554	001416			BEQ	11\$;BR IF IT IS
1214	004556	004737	005554		JSR	PC,SCAWC		;SETUP TO CHECK REMAINING SECTORS ON THE TRACK
1215	004562	005037	001216		CLR	SOF5W		;CLEAR RETRY COUNTER
1216	004566	000633			BR	1\$;FINISH CHECKING THE TRACK
1217	004570	004737	005334	10\$:	JSR	PC,LOP.CK		;CHECK FOR LOOP ON ERROR
1218	004574	022737	000003	001250	CMP	#3,RETRY		;ERROR RETRY REACHED ?
1219	004602	001403			BEQ	11\$;BR IF IT IS
1220	004604	005237	001250		INC	RETRY		;COUNT THE RETRY
1221	004610	000622			BR	1\$;DO THE WRITE CHECK AGAIN
1222	004612	005037	001160	11\$:	CLR	\$ESCAPE		;CLEAR THE ERROR RETURN ESCAPE ADDRESS
1223	004616	005037	001250		CLR	RETRY		;CLEAR THE RETRY COUNTER
1224	004622	032777	000002	174310	BIT	#BIT1,\$SWR		;LOOP ON CURRENT TRACK ?
1225	004630	001402			BEQ	12\$;BR IF NOT
1226	004632	000137	004060		JMP	WRTRK1		;START AGAIN ON THE SAME TRACK


```

1281                                     ;*IF THERES A MONITOR GO TO IT
1282                                     ;*IF THERE ISN'T JUMP TO DONE
1283
1294 $EOP:                                TST      MODE      ;'FORMAT' OR 'CHECK' MODE ^
1285 005100 005737 001220                 BEQ      3$        ;BR IF 'CHECK'
1286 005104 001403                       TYPE     MFCMPT    ;'FORMAT COMPLETE'
1287 005106 104401 021764                 BR       4$        ;FINISH THE END MESSAGE
1288 005112 000402                       3$:     TYPE     ,MCCMPT ;'CHECK COMPLETE'
1289 005114 104401 022011                 4$:     TYPE     ,NUMERR ;'TOTAL ERRORS DETECTED: '
1290 005120 104401 022035                 MOV      $ERTTL,-(SP) ;SAVE $ERTTL FOR TYPEOUT
1291 005124 013746 001112                 TYPDS   $SCLF     ;GO TYPE--DECIMAL ASCII WITH SIGN
1292 005130 104405                       TYPE     $PASS     ;CR-LF
1293 005132 104401 001167                 INC      $PASS     ;INCREMENT THE PASS NUMBER
1294 005136 005237 001100                 BIC     #100000,$PASS ;DON'T ALLOW A NEG. NUMBER
1295 005142 042737 100000 001100        DEC      (PC)+    ;LOOP?
1296 005150 005327                       $EOPCT: .WORD    1
1297 005152 000001                       BGT     $DOAGN    ;; YES
1298 005154 003013                       MOV     (PC)+,a(PC)+ ;RESTORE COUNTER
1299 005156 012737                       $ENDCT: .WORD    1
1300 005160 000001                       $GET42: MOV     a#42,RO ;GET MONITOR ADDRESS
1301 005162 005152                       BEQ     $DOAGN    ;BRANCH IF NO MONITOR
1302 005164 013700 000042                 RESET   ;CLEAR THE WORLD
1303 005170 001405                       $ENDAD: JSR     PC,(RO) ;GO TO MONITOR
1304 005172 000005                       NOP     ;SAVE ROOM
1305 005174 004710                       NOP     ;FOR
1306 005176 000240                       NOP     ;ACT11
1307 005200 000240
1308 005202 000240
1309 005204
1310 005204 000137                       JMP     a(PC)+    ;;RETURN
1311 005206 005210                       $RTNAD: .WORD    DONE
1312 005210 032777 000001 173722        -DONE: .BIT     #SW0,aSWR ;SEE IF SWR 0 SET
1313 005216 001002                       BNE     1$        ;BR IF SET
1314 005220 000137 003116                 JMP     MD        ;ASK FOR NEXT DRIVE
1315 005224 012706 001100                 1$:     MOV     #STACK,SP ;RESET STACK POINTER
1316 005230 000137 003526                 JMP     M5        ;DO THE FORMAT OR CHECK AGAIN
1317
1319                                     ;*****
1319                                     .SBTTL  SUPPORT SUBROUTINES
1320
1321                                     ;*****
1322
1323                                     ;THIS ROUTINE DETERMINES THE ERROR TYPE
1324
1325
1326 005234 010146                       ERINDX: MOV     R1,-(SP) ;STORE R1
1327 005236 005001                       CLR     R1        ;CLEAR R1
1328 005240 033727 001372                 BIT     FMTDPB+16,(PC)+ ;CHECK ERROR TYPE
1329 005244 060006                       .WORD  BIT14!BIT13!BIT2!BIT1 ;DRIVE OFFLINE
1330 005246 001025                       BNE     5$        ;BR IF OFFLINE
1331 005250 033727 001372                 BIT     FMTDPB+16,(PC)+ ;CHECK ERROR TYPE
1332 005254 010000                       .WORD  BIT12     ;DRIVE PERSISTENTLY UNSAFE
1333 005256 001020                       BNE     4$        ;BR IF UNSAFE
1334 005260 033727 001372                 BIT     FMTDPB+16,(PC)+ ;CHECK ERROR TYPE

```

```

005334 006000 .WORD BIT11!BIT10 :UNCORRECTABLE MASSBUS PARITY ERROR ?
005336 001013 BNE 3$ :BR IF PARITY ERROR
005338 001372 BIT FMTDPB+16,(PC)+ :CHECK ERROR TYPE
005340 001400 .WORD BIT09!BIT08 :SOFTWARE TIMEOUT ?
005342 001006 BNE 2$ :BR IF YES
005344 001372 BIT FMTDPB+16,(PC)+ :CHECK ERROR TYPE
005346 000020 .WORD BIT04 :DRIVE UNSAFE ERROR ?
005348 001001 BNE 1$ :BR IF YES
005350 005301 INC R1 :INCREMENT THE RETURN INDEX
005352 005301 INC R1 :INCREMENT THE RETURN INDEX
005354 005301 INC R1 :INCREMENT THE RETURN INDEX
005356 005301 INC R1 :INCREMENT THE RETURN INDEX
005358 005301 INC R1 :INCREMENT THE RETURN INDEX
005360 006301 5$: ASL R1 :DOUBLE THE INCREMENT
005362 060166 ADD R1,2(SP) :DEVELOP THE RETURN ADDRESS
005364 012601 MOV (SP)+,R1 :RESTORE R1
005366 000207 RTS PC :RETURN

```

:ROUTINE TO CHECK FOR LOOP ON ERROR

```

005334 032777 001000 173575 LOP.LCK: BIT #SW09,JSWR :LOOP ON ERROR ?
005336 001402 BEQ 1$ :BR IF NOT
005338 000177 173540 JMP JSLPERR :GO TO THE LOOP ON ERROR ADDRESS
005340 005337 001160 1$: CLR $ESCAPE :CLEAR THE ERROR ESCAPE ADDRESS
005342 033727 001372 BIT FMTDPB+16,(PC)+ :CHECK FOR 'FATAL' ERROR
005344 072002 .WORD BIT14!BIT13!BIT12!BIT10!BIT01 :'FATAL' ERROR BITS
005346 001004 BNE 2$ :BR IF NOT
005348 032737 004000 001320 BIT #WLE,RP.REG+RPER1 :WRITE LOCK ERROR ?
005350 001402 BEQ 3$ :BR IF NOT
005352 000137 005100 2$: JMP $EOP :TERMINATE THE FORMAT
005354 000207 3$: RTS PC :RETURN

```

:THIS ROUTINE SETS UP THE INPUT TABLE FOR THE DRIVER ROUTINE

```

005402 113737 001214 001354 SETTB.L: MOVB DRIVE,FMTDPB :SET UP DRIVE #
005404 105037 001357 CLRB FMTDPB+3 :CLEAR HIGH ORDER ADRS BITS
005406 013737 001260 001360 MOV MWC,FMTDPB+4 :LOAD UP WORD COUNT
005408 012737 025130 001362 MOV #BUFP,FMTDPB+6 :LOAD UP CURRENT ADRS
005410 105037 001364 CLRB FMTDPB+10 :SET SECTOR TO ZERO
005412 113737 001230 001365 MOVB BEGTRK,FMTDPB+11 :SET UP STARTING TRK ADRS
005414 013737 001224 001366 MOV BEGCYL,FMTDPB+12 :SET UP STARTING CYL
005416 005037 001372 CLR FMTDPB+16 :CLEAR RPO4 STATUS
005418 013737 001230 001236 MOV BEGTRK,TRKCNT :SET UP PARTIAL CYL TRACK COUNT
005420 013737 001232 001234 MOV TTRKS,TTRKSC :SET UP TOTAL TRACKS COUNTER
005422 000207 RTS PC :RETURN FROM SETUP

```

:THIS ROUTINE CONTROLS THE DISK ADDRESSING AND TOTAL TRK COUNT
:IT IS ENTERED AFTER EVERY TRK OPERATION

```

005472 005337 001234 TRKTST: DEC TTRKSC :SEE IF LAST TRACK
005474 001425 BEQ 3$ :BRANCH IF LAST TRACK
005476 022737 000022 001236 CMP #19.,TRKCNT :IS THIS THE LAST TRACK IN THE CYLINDER ?
005478 001407 BEQ 1$ :BRANCH IF SO
005480 005237 001236 INC TRKCNT :COUNT UP TRACK WITHIN CYLINDER

```

```

005514 105237 001365      INCB      FMTDPB+11      ; INCREMENT TRACK NUMBER
005520 004737 005712      JSR      PC,UPDATK    ; UPDATE TRACK ADDRESS IN BUFFER
005524 000410          BR       2$           ; EXIT
005526 005037 001236      1$: CLR   TRKCNT      ; CLEAR TRACK COUNT FOR NEXT CYLINDER
005532 105037 001365      CLRAB   FMTDPB+11    ; RESET TRACK ADDRESS TO 0
005536 005237 001366      INC     FMTDPB+12    ; UPDATE CYLINDER NUMBER
005542 004737 005562      JSR      PC,UPDACY   ; UPDATE CYLINDER NUMBER IN BUFFER
005546 062716 000002      2$: ADD   #2,(SP)    ; ADD TWC TO RETURN ADRS
005552 000207 000002      3$: RTS   PC         ; RETURN

; THIS ROUTINE SETS UP WC & BA FOR REMAINING SECTORS
; AFTER A WRITE CHECK ERROR

005554 013737 001254 001360  SCANC:  MOV   SAVWC,FMTDPB+4 ; SET UP WC FOR REMAINING SECTORS
005556 062737 001010 001362  ADD   #520,FMTDPB+6 ; SET UP BA FOR REMAINING SECTORS
005560 005237 001264      INC   FMTDPB+10    ; ADVANCE TO NEXT SECTOR IN TBL
005564 005037 001216      CLR   SOFSW        ; RESET RETRY COUNTER
005568 000207 000002      RTS   PC         ; RETURN TO COMPLETE TRK FORMAT

; THIS ROUTINE SETS UP THE CYLINDER ADRS, FORMAT BIT, TRACK AND
; SECTOR ADRS IN MEMORY WITH THE STARTING CYL - TRK INFORMATION

005569 013737 001266  SETHDR: MOV   MAXSEC,R1    ; SET UP SECTOR COUNT
005571 013737 002530      MOV   #BUFP,R0      ; SET UP HEADER POINTER IN R0
005573 013737 001224      MOV   BEGCYL,R2     ; PUT STARTING CYL # IN R2
005575 013737 001230      MOV   BECTRK,R3     ; PUT STARTING TRK # IN R3
005577 000303 001230      SLJAB R3            ; JUSTIFY TRACK ADRS
005579 005737 001254      TST   SEC20         ; SEE IF 20 OR 22 SECTOR MODE
005581 001402          BEQ   1$           ; BR IF 20 SECTOR MODE
005583 005737 001000  1$: BIC   #10000,R2    ; SET THE 22 SECTOR FORMAT BIT
005585 013737 001000  1$: MOV   R2,(R0)+      ; WRITE IN HEADER AREA OF CORE THE CYL ADRS
005587 013737 001000  1$: MOV   R3,(R0)+      ; WRITE IN HEADER AREA OF CORE THE TRK ADRS
005589 005037 001000  1$: CLR   (R0)+        ; CLR 1ST KEYWORD
005591 005037 001000  1$: CLR   (R0)         ; CLR 2ND KEYWORD
005593 005737 001000  1$: ADD   #514,(R0)    ; SET UP FOR NEXT HEADER
005595 005737 001000  1$: INC   R3            ; UPDATE SECTOR ADRS FOR NEXT HEADER
005597 005737 001000  1$: DMC   R1            ; MAINTAIN COUNT OF SECTORS
005599 005737 001000  1$: BGE   1$           ; BRANCH IF NOT LAST SECTOR
005601 000207 000002  1$: RTS   PC         ; EXIT - HEADERS ARE LOADED INTO CORE

; THIS ROUTINE UPDATES THE CYLINDER ADRS OF THE HEADER WORDS IN CORE

005602 013737 001266  UPDACY: MOV   MAXSEC,R1    ; SET UP SECTOR COUNT
005604 013737 002530      MOV   #BUFP,R0      ; SET UP HEADER POINTER IN R0
005606 005237 001266  1$: INC   (R0)+        ; INCREMENT FOR NEXT CYLINDER
005608 042710 00177400  BIC   #177400,(R0)  ; RESET TRK ADRS TO 0
005610 062710 001006  1$: ADD   #518,(R0)    ; SET UP FOR NEXT HEADER
005612 005037 001006  1$: DFC   R1            ; COUNT SECTORS
005614 005737 001006  1$: BGE   1$           ; BRANCH IF NOT LAST SECTOR
005616 000207 000002  1$: RTS   PC         ; EXIT

; THIS ROUTINE UPDATES THE TRACK ADRS OF THE HEADER WORDS IN CORE

```

```

1443 005712 013701 001266 JPCATK: MOV MAXSEC,R1 :SET UP SECTOR COUNT
1444 005716 012700 025130 MOV #BUFF,RO :SET UP HEADER POINTER IN RO
1445 005720 005720 TST (RO)+ :POINT HEADER POINTER TO TRK - SEC ADPS
1446 005724 062710 000400 IS: ADD #400,(RO) :INDEX TRK ADPS
1447 005730 062700 021010 ADD #520,RO :SET UP FOR NEXT HEADER
1448 005734 005301 DEC R1 :COUNT SECTORS
1449 005736 002372 SGE IS :BRANCH IF NOT LAST SECTOR
1450 005740 000207 RTS PC :EXIT

```

:ROUTINE TO CHECK FOR KW11-L OR KW11-P CLOCKS

```

1451 005742 012737 006020 000004 ST.CLK: MOV #STCLK1,0#ERRVEC :SET UP VECTOR FOR P CLK
1452 005750 005037 000006 CLR 0#ERRVEC+2 :NEW PSW
1453 005754 005777 173216 TST 0$CLKCSR :CHECK FOR KW11-P
1454 005760 013746 001202 MOV $LPVEC,-(SP) :VECTOR ADDRESS
1455 005764 012776 006104 000000 MOV #CLOCK,0(SP) :SET UP KW11-P VECTOR
1456 005772 062716 000002 ADD #2,(SP) :POINT TO PSW
1457 005776 012736 000300 MOV #PR6,0(SP)+ :PSW - PRI 6
1458 006002 012777 177777 173170 MOV #-1,0$CLKCSB :LOAD COUNTER BUFFER
1459 006010 012777 000135 173160 MOV #135,0$CLKCSR :SET CLK - CNT UP
1460 006016 000426 BR STCLK3
1461 006020 062706 000004 STCLK1: ADD #4,SP :RESTORE THE STACK POINTER
1462 006024 012737 006070 000004 MOV #STCLK2,0#ERRVEC :CHANGE ERROR VECTOR
1463 006032 005777 173150 TST 0$CLKS :LOOK FOR KW11-L
1464 006036 013746 001210 MOV $LLVEC,-(SP) :KW11-L VECTOR ADDRESS
1465 006042 012776 006104 000000 MOV #CLOCK,0(SP) :SET UP KW11-L VECTOR
1466 006050 062716 000002 ADD #2,(SP) :INCREMENT VECTOR ADDRESS
1467 006054 012736 000300 MOV #PR6,0(SP)+ :PSW - PRI 6
1468 006060 012777 000100 173120 MOV #100,0$CLKS :SET KW11-L INTERRUPT ENABLE
1469 006066 000402 BR STCLK3
1470 006070 062706 000004 STCLK2: ADD #4,SP :RESTORE THE STACK POINTER
1471 006074 012737 000006 000004 STCLK3: MOV #6,0#ERRVEC :RESTORE THE ERROR VECTOR
1472 006102 000207 RTS PC

```

:THIS CODE SERVICES A CLOCK INTERRUPT EVERY 16MS

```

1473 006104 012746 000020 CLOCK: MOV #16,-(SP) :PUT MILLISECONDS ON THE STACK
1474 006110 004737 016456 JSR PC,RPTMR :GO REPORT TIME
1475 006114 000002 RTI :RETURN AND CONTINUE

```

:ROUTINE TO INTERCEPT 'CONTROL C' TYPED DURING PARAMETER ENTRY TIME

```

1476 006116 012706 001100 CENTER: MOV #STACK,SP :INITIALIZE THE STACK
1477 006122 005737 012160 IS: TST TRNSWT :ALL ACTIVITY STOPPED
1478 006126 001375 BNE IS :BR IF NOT
1479 006130 000005 RESET :CLEAR THE BUS
1480 006132 000137 003062 JMP MIB :START AGAIN WITH DRIVE SELECTION

```

:ROUTINE TO TYPE THE PRESENT DISK ADDRESS. ENTERED BY TYPING 'CONTROL C'

```

1481 006136 005037 177776 TYPADR: CLR PSW :SET PROCESSOR TO PRIORITY 0
1482 006142 012737 006116 001300 MOV #CENTER,CNTLC :CHANGE 'CONTROL C' RETURN ADDRESS
1483 006150 104401 022065 TYPE ,ADDRIS :PRESENT ADDRESS IS:
1484 006154 104101 020675 TYPE ,C :

```

```

149 006160 013746 001366 MOV FMTDPB+12, -(SP) ; PUT THE CYLINDER ADDRESS ON THE STACK
150 006164 004737 011470 JSR PC, $S820 ; CONVERT IT TO DECIMAL
151 006170 004737 011430 JSR PC, $S5JPRS ; TYPE IT
152 006174 104401 020705 TYPE .L INSP ; SPACES
153 006200 104401 020677 TYPE .T ; T
154 006204 005046 CLR -(SP) ; CLEAR THE STACK
155 006206 113716 001365 MOVF FMTDPB+11, (SP) ; PUT THE TRACK ADDRESS ON THE STACK
156 006212 004737 011470 JSR PC, $S820 ; CONVERT IT TO DECIMAL
157 006216 004737 011430 JSR PC, $S5JPRS ; TYPE IT
158 006222 104401 001167 TYPE .SRLF ; CR-LF
159 006226 012737 006136 MOV #TYPADR, ONTLC ; RESTORE ENTRANCE TO THIS ROUTINE
160 006234 000002 RTI ; RETURN

```

:PARAMETER ENTRY ROUTINE

```

:CALL
: MOV #ADR, R3 ; PARAMETER TABLE ADDRESS
: JSR PC, PARENT ; GET THE PARAMETERS

PARENT: MOV R3, -(SP) ; SAVE R3
: MOV #TABLE, R3 ; PARAMETER TABLE ADDRESS
1$: MOV (R3)+, 3$ ; ADDRESS OF PARAMETER NAME
: BEQ 9$ ; BR IF AT END OF TABLE
: TYPE THE PARAMETER NAME
3$: .WORD 0 ; ADDRESS OF PARAMETER NAME TEXT
: MOV (R3)+, R2 ; MAXIMUM PARAMETER VALUE
: MOV (R3)+, R5 ; ADDRESS OF PARAMETER
: MOV (R5), -(SP) ; CURRENT VALUE OF PARAMETER
: TYPE THE CURRENT VALUE OF THE PARAMETER
: .SLASH
: READ THE KEYBOARD
: MOV (SP)+, R1 ; INPUT ASCII STRING ADDRESS
: JSR PC, $S, OK, DIG ; CHECK THE DIGIT(S)
: 1$ ; CARRIAGE RETURN ONLY ENTERED
: 2$ ; PERIOD ONLY ENTERED
: 3$ ; ILLEGAL INPUT
: 4$ ; TERMINATED WITH A CARRIAGE RETURN
: 5$ ; TERMINATED WITH A "."
: 6$ ; TERMINATED WITH A "-"
5$: MOV R2, (R5) ; MOVE NEW VALUE TO PARAMETER LOCATION
: BR 1$ ; GET MORE PARAMETERS
6$: TYPE 'BAD ENTRY' ; 'BAD ENTRY'
: SUB #6, R3 ; DECREMENT THE TABLE POINTER
: BR 1$ ; TRY AGAIN
7$: MOV R2, (R5) ; NEW VALUE
: BR 9$ ; EXIT
8$: MOV #TABLE, R3 ; RELOAD THE PARAMETER TABLE ADDRESS
: BR 1$ ; TRY AGAIN
9$: MOV (SP)+, R3 ; RESTORE R3
: RTS PC ; RETURN

```

: THIS ROUTINE IS USED TO CHECK IF AN
: ASCII CHARACTER IS A DIGIT BETWEEN 0 AND 7.
: CALL

```

:551      :      MOV      #ADR,R1      :ADDRESS OF ASCII CHARACTER
:552      :      JSR      R5,CK.OCT     :CHECK THE CHARACTER
:553      :      RETURN1     :CHARACTER IS NOT BETWEEN 0-7
:554      :      RETURN2     :CHARACTER IS IN R2 AS A
:555      :      :           :OCTAL DIGIT
:556
:557      006352 121127 000060  CK.OCT:  CMPB      (R1),#'0     :LESS THAN ZERO?
:558      006356 103407      BLO      1$           :YES -- BRANCH
:559      006360 121127 000067  CMPB      (R1),#'7     :GREATER THAN SEVEN?
:560      006364 101004      BHI      1$           :YES -- BRANCH
:561      006366 111102      MOVB     (R1),R2      :GET THE CHARACTER
:562      006370 042702 177770  BIC      #'C?,R2     :STRIP AWAY THE ASCII
:563      006374 005725      TST     (R5)+        :ADJUST FOR RETURN
:564      006376 000205 1$:      RTS      R5      :RETURN

```

:THIS ROUTINE IS USED TO CHECK AN ASCII CHARACTER
AND DETERMINE IF IT IS A DIGIT BETWEEN 0 AND 9.

```

:565      :CALL
:566      :      MOV      #ADR,R1      :ADDRESS OF ASCII CHARACTER
:567      :      JSR      R5,CK.DEC     :CHECK THE CHARACTER
:568      :      RETURN1     :NOT BETWEEN 0 AND 9
:569      :      RETURN2     :BETWEEN 0 AND 9
:570      :      :           :R2 = DIGIT
:571
:572      006400 121127 000063  CK.DEC:  CMPB      (R1),#'0     :LESS THAN ZERO?
:573      006404 103407      BLO      1$           :YES -- BRANCH
:574      006406 121127 000071  CMPB      (R1),#'9     :GREATER THAN NINE?
:575      006412 101004      BHI      1$           :YES -- BRANCH
:576      006414 111102      MOVB     (R1),R2      :GET THE CHARACTER
:577      006416 042702 000060  BIC      #'0,R2     :STRIP AWAY THE ASCII
:578      006422 005725      TST     (R5)+        :ADJUST FOR RETURN
:579      006424 000205 1$:      RTS      R5      :RETURN

```

:THIS ROUTINE WILL CHECK AN ASCII CHARACTER TO
DETERMINE WHAT IT IS.

```

:580      :CALL
:581      :      MOV      #ADR,R1      :ADDRESS OF ASCII CHARACTER
:582      :      JSR      R5,CK.CHR     :CHECK CHARACTER
:583      :      RETURN  ADR1     :UNKNOWN CHARACTER
:584      :      RETURN  ADR2     :CARRIAGE RETURN * (R1)=ADR+1
:585      :      RETURN  ADR3     :COMMA * (R1)=ADR+1
:586      :      RETURN  ADR4     :PERIOD * (R1)=ADR+1
:587      :      RETURN  ADR5     :DIGIT BETWEEN 0 AND 7.
:588      :      RETURN  ADR6     :DIGIT BETWEEN 8 AND 9.
:589      :      :           :R2 = DIGIT * (R1)=ADR+1
:590
:591      006426 105711  CK.CHR:  TSTB     (R1)      :"CARRIAGE RETURN"
:592      006430 001417      BEQ     3$           :YES -- BRANCH
:593      006432 121127 000054  CMPB     (R1),#',     :"COMMA"
:594      006436 001413      BEQ     2$           :YES -- BRANCH
:595      006440 121127 000056  CMPB     (R1),#'.     :"PERIOD"
:596      006444 001407      BEQ     1$           :YES -- BRANCH
:597      006446 004537 006403  JSR     R5,CK.DEC     :"DIGIT"
:598      006452 000410      BR     4$           :NO -- BRANCH

```

```

:605 006454 004537 006352 JSR R5,CK.OCT ;OCTAL ?
:606 006460 005725 TST (R5)+ ;DIGIT BETWEEN 8-9
:607 006462 005725 TST (R5)+ ;DIGIT BETWEEN 0-7
:608 006464 005725 15: TST (R5)+ ;PERIOD
:609 006466 005725 25: TST (R5)+ ;COMMA
:610 006470 005725 35: TST (R5)+ ;CARRIAGE RETURN
:611 006472 005201 INC R1 ;MOVE POINTER TO NEXT CHARACTER
:612 006474 011505 45: MOV (R5),R5 ;UNKNOW CHARACTER
:613 006476 000205 RTS R5 ;RETURN

:THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL
:CHARACTERS AND FORMS A DECIMAL VALUE BINARY NUMBER IN R2.
CALL
:618 MOV #ADR,R1 ;ADDRESS OF ASCII STRING
:619 MOV #NUM,R2 ;MAX. MAGNITUDE OF INPUT NUMBER
:620 JSR R5,CK.DIG ;CHECK DIGITS
:621 RETURN ADR1 ;"CR" ONLY ENTERED -- R2=0
:622 RETURN ADR2 ;"PERIOD" ONLY ENTERED -- R2=C
:623 RETURN ADR3 ;ILLEGAL CHARACTER OR INPUT TOO LARGE -- R2=?
:624 RETURN ADR4 ;"CR" -- R2 = NUMBER
:625 RETURN ADR5 ;"COMMA" -- R2 = NUMBER
:626 RETURN ADR6 ;"PERIOD" -- R2 = NUMBER

:627 006500 010446 CK.DIG: MOV R4,-(SP) ;SAVE R4
:628 006502 010346 MOV R3,-(SP) ;SAVE R3
:629 006504 010246 MOV R2,-(SP) ;SAVE THE MAX. SIZE ON THE STACK
:630 006506 005002 CLR R2 ;START WITH 0
:631 006510 005002 CLR R3
:632 006512 005004 CLR R4
:633 006514 004537 006426 JSR R5,CK.CHR ;CHECK ONE CHARACTER
:634 006520 006514 55: ;ILLEGAL CHARACTER
:635 006522 006622 55: ;CARRIAGE RETURN
:636 006524 006514 55: ;"
:637 006526 006616 75: ;"
:638 006530 006534 15: ;DIGIT 0-7
:639 006532 006534 15: ;DIGIT 8-9
:640 006534 062705 000004 15: ADD #4,R5 ;STEP RETURN POINTER PAST "CR" & "PERIOD" RETURNS
:641 006540 006302 25: R3 ;INPUT NUMBER *2
:642 006542 010346 MOV R3,-(SP) ;SAVE *2
:643 006544 006302 R3 ;*4
:644 006546 006302 R3 ;*8
:645 006550 062603 ADD (SP)+,R3 ;(*2)+(*8) = *10
:646 006552 060203 ADD R2,R3 ;UPDATE THE INPUT NUMBER
:647 006554 004537 006426 JSR R5,CK.CHR ;CHECK ONE CHARACTER
:648 006560 006620 55: ;ILLEGAL CHARACTER
:649 006562 006604 55: ;CARRIAGE RETURN
:650 006564 006602 45: ;"
:651 006566 006574 35: ;"
:652 006570 006540 25: ;DIGIT 0-7
:653 006572 006540 25: ;DIGIT 8-9
:654 006574 105711 38: TSTB (R1) ;DOES A "CR" FOLLOW THE "PERIOD"
:655 006576 001010 BNE 95 ;BR IF NOT
:656 006580 005724 TST (R4)+ ;INCREMENT THE RETURN
:657 006582 005724 TST (R4)+ ;INCREMENT THE RETURN

```

```

1659 006604 005724 55: TST (R4)+ ; INCREMENT THE RETURN
1660 006606 020316 CMP R3, (SP) ; CHECK THE MAGNITUDE OF THE NUMBER
1661 006610 101004 BHI 9$ ; BR IF ENTERED NUMBER TOO LARGE
1662 006612 000402 BR 8$ ; BYPASS INCREMENT
1663 006614 005725 6$: TST (R5)+ ; INCREMENT RETURN PAST INVALID RETURN
1664 006616 005725 7$: TST (R5)+ ; INCREMENT RETURN
1665 006620 060405 8$: ADD R4, R5 ; SETUP RETURN POINTER
1666 006622 010302 9$: MOV R3, R2 ; ENTERED VALUE
1667 006624 005726 TST (SP)+ ; CLEAN MAX. SIZE OFF OF STACK
1668 006626 012603 MOV (SP)+, R3 ; RESTORE R3
1669 006630 012604 MOV (SP)+, R4 ; RESTORE R4
1670 006632 011505 MOV (R5), R5 ; GET RETURN ADDRESS
1671 006634 000205 RTS R5 ; RETURN

```

.SBTTL MACRO ROUTINES

.SBTTL ERROR HANDLER ROUTINE

```

:*****
:* THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT.
:* SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
:* AND GO TO TYPERR ON ERROR
:* THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
:* SW15=1 HALT ON ERROR
:* SW13=1 INHIBIT ERROR TYPEOUTS
:* SW10=1 BELL ON ERROR
:* SW09=1 LOOP ON ERROR
:* CALL
:* ERROR N ;; ERROR=EMT AND N=ERROR ITEM NUMBER

```

```

1692 006636 104407 $ERROR: CKSWR ; TEST FOR CHANGE IN SOFT-SWR
1693 006636 010137 001274 MOV R1, DRIVE ; DRIVE ADDRESS IF DRIVE ERROR CALL
1694 006640 010137 001274 MOV R3, ATTN ; ATTENTION REGISTER CONTENTS
1695 006644 010337 001276 001270 MOV FMTDPB+12, DS, CYL ; CURRENT CYLINDER ADDRESS
1696 006650 013737 001366 001272 MOVE FMTDPB+11, DS, TRK ; REQUESTED TRACK ADDRESS
1697 006656 113737 001365 001272 *ST RP, REG+RPBA ; NON-ZERO BUFFER ADDRESS
1698 006664 005737 001310 BEQ 7$ ; BR IF NO BUFFER ADDRESS
1699 006670 001406 BEQ 7$ ; BUFFER ADDRESS
1700 006672 013746 001310 MOV RP, REG+RPBA, -(SP) ; DECREMENT THE ADDRESS
1701 006676 162716 000002 SUB #2, (SP) ; GET THE BUFFER WORD WHICH DIDN'T COMPARE
1702 006702 013637 001124 MOV 2, (SP)+, $GDDAT ; SET THE ERROR FLAG
1703 006706 105237 001103 7$: INCB $ERFLG ; DON'T LET THE FLAG GO TO ZERO
1704 006712 001775 BEQ 7$ ; DISPLAY TEST NUMBER AND ERROR FLAG
1705 006714 013777 001102 172220 MOV $STNM, $DISPLAY ; BELL ON ERROR?
1706 006722 032777 002000 172210 BIT #BIT10, $SWR ; NO - SKIP
1707 006730 001402 BEQ 1$ ; RING BELL
1708 006732 104401 001162 TYPE $BELL ; COUNT THE NUMBER OF ERRORS
1709 006736 005237 001112 1$: INC $ERCTL ; GET ADDRESS OF ERROR INSTRUCTION
1710 006742 011637 001116 MOV (SP), $ERRPC ; STRIP AND SAVE THE ERROR ITEM CODE
1711 006746 162737 000002 001116 SUB #2, $ERRPC ; SKIP TYPEOUT IF SET
1712 006754 117737 172136 001114 MOVE $ERRPC, $ITEMB ; SKIP TYPEOUTS
1713 006762 032777 020000 172150 BIT #BIT13, $SWR
1714 006770 001004 BNE EOS

```

```

1713 006772 004737 007044 JSR PC,TYPERR ;:GO TO USER ERROR ROUTINE
1714 006776 104401 001167 TYPE ,SCRLF
1715 007002 20$:
1716 007002 005777 172132 2$: TST QSWR ;:HALT ON ERROR
1717 007006 100002 BPL 3$ ;:SKIP IF CONTINUE
1718 007010 000000 HALT ;:HALT ON ERROR!
1719 007012 104407 CKSWR ;:TEST FOR CHANGE IN SOFT-SWR
1720 007014 032777 001000 172116 3$: BIT #BIT09,QSWR ;:LOOP ON ERROR SWITCH SET?
1721 007022 001402 BEQ 4$ ;:BR IF NO
1722 007024 013716 001110 MOV $LFERR,(SP) ;:FUDGE RETURN FOR LOOPING
1723 007030 005737 001160 4$: TST $ESCAPE ;:CHECK FOR AN ESCAPE ADDRESS
1724 007034 001402 BEQ 5$ ;:BR IF NONE
1725 007036 013716 001160 MOV $ESCAPE,(SP) ;:FUDGE RETURN ADDRESS FOR ESCAPE
1726 007042 000002 5$: RTI ;:RETURN

```

```

:THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE
:WHICH ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR
:TABLE" ($ERRTB), AND REPORTS THE APPROPRIATE INFORMATION
:CONCERNING THE ERROR.

```

```

1735 007044 104412 TYPERR: SAVREG ;:SAVE R0-R5
1736 007046 005000 CLR R0 ;:CLEAR R0 FOR ERROR NUMBER
1737 007050 113700 001114 MOVB $ITEMB,R0 ;:ERROR NUMBER
1738 007054 005300 DEC R0 ;:FORM INDEX FOR ERROR TABLE
1739 007056 006300 ASL R0
1740 007060 006300 ASL R0
1741 007062 006300 ASL R0
1742 007064 062700 001626 1$: ADD $ERRTB,R0 ;:FORM ADDRESS
1743 007070 012037 007104 MOV (R0)+,2$ ;:GET ERROR MESSAGE (EM) POINTER
1744 007074 001404 BEQ 3$ ;:BRANCH IF THERE ISN'T ONE
1745 007076 104401 001167 TYPE ,SCRLF ;:"CARRIAGE RETURN - LINE FEED
1746 007102 104401 TYPE
1747 007104 000000 2$: .WORD 0 ;:"EM" POINTER GOES HERE
1748 007106 012037 007122 3$: MOV (R0)+,4$ ;:PICK UP DATA HEADER (DH) POINTER
1749 007112 001404 BEQ 5$ ;:BRANCH IF NONE
1750 007114 104401 001167 TYPE ,SCRLF ;:CARRIAGE RETURN-LINE FEED
1751 007120 104401 TYPE
1752 007122 000000 4$: .WORD 0 ;:"DH" POINTER GOES HERE
1753 007124 012001 5$: MOV (R0)+,R1 ;:PICKUP DATA TABLE (DT) POINTER
1754 007126 001460 BEQ 20$ ;:BRANCH IF NONE
1755 007130 005005 CLR R5 ;:SET INDENT SWITCH
1756 007132 012000 MOV (R0)+,R0 ;:DATA FORMAT (DF) POINTER
1757 007134 012002 MOV (R0)+,R2 ;:NUMBER OF DH'S TO TYPE
1758 007136 001451 BEQ 17$ ;:BRANCH IF DH NUMBER IS 0
1759 007140 005105 COM R5 ;:NO INDENT
1760 007142 104401 001167 TYPE ,SCRLF ;:CARRIAGE RETURN-LINE FEED
1761 007146 112003 10$: MOVB (R0)+,R3 ;:NUMBER OF DATA WORDS TO TYPE
1762 007150 112004 MOVB (R0)+,R4 ;:AND HOW TO TYPE THEM
1763 007152 006004 11$: ROR R4 ;:OCTAL OR DECIMAL?
1764 007154 103403 BCS 12$ ;:DECIMAL--BRANCH
1765 007156 013146 MOV @R1)+,-(SP) ;:SAVE J(R1)+ FOR TYPEOUT
1766 007160 104402 TYPOC ;:GO TYPE--OCTAL ASCII:ALL DIGITS

```

```

1767 007162 000402          BR      13$
1768 007164          12$:
1769 007164 013146          MOV     3(R1)+,-(SP)      ;;SAVE 3(R1)+ FOR TYPEOUT
1770 007166 104405          TYPDS          ;;GO TYPE--DECIMAL ASCII WITH SIGN
1771 007170 005303          13$: DEC     R3          ;;MORE NUMBERS TO TYPE?
1772 007172 001403          BEQ     14$          ;;NO--BRANCH
1773 007174 104401 020705  TYPE    LINSF        ;;YES--TYPE SEPERATORS
1774 007200 000764          BR      11$          ;;LOOP
1775 007202 005302          14$: DEC     R2          ;;MORE DH'S?
1776 007204 003431          BLE     20$          ;;NO--BRANCH
1777 007206 104401 001167  TYPE    $CRLF        ;;YES--START A NEW LINE
1778 007212 005760 000002  TST     2(R0)        ;;ONLY A 'DH' IN THIS REQUEST ?
1779 007216 001404          BEQ     15$          ;;BR IF YES - BYPASS THE INDENT
1780 007220 005105          COM     R5          ;;INDENT?
1781 007222 001002          BNE     15$          ;;NO--BRANCH
1782 007224 104401 020705  TYPE    LINSF        ;;YES--TYPE SPACES
1783 007230 012037 007236  15$: MOV     (R0)+,16$   ;;GET NEXT DH
1784 007234 104401          TYPE          ;;AND TYPE IT
1785 007236 000000          16$: .WORD 0          ;;DH POINTER GOES HERE
1786 007240 005710          TST     (R0)        ;;TYPE A 'DT' ?
1787 007242 001003          BNE     21$          ;;BR IF A 'DT'
1788 007244 062700 000004  ADD     #4,R0        ;;INCREMENT THE 'DF' POINTER
1789 007250 000754          BR      14$          ;;SEE IF END OF 'DF' BLOCK
1790 007252 104401 001167  TYPE    $CRLF        ;;CARRIAGE RETURN-LINE FEED
1791 007256 005705          TST     R5          ;;INDENT?
1792 007260 001332          BNE     10$          ;;NO--BRANCH
1793 007262 104401 020705  TYPE    LINSF        ;;YES--TYPE SPACES
1794 007266 000727          BR      10$          ;;LOOP
1795 007270 104413          20$: RESREG          ;;RESTORE R0-R5
1796 007272 000207          RTS     PC          ;;RETURN
1797
1798          .SBTTL  TYPE ROUTINE
1799
1800          ;*****
1801          ;ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
1802          ;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
1803          ;*NOTE1:          $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
1804          ;*NOTE2:          $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQLIED.
1805          ;*NOTE3:          $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
1806          ;
1807          ;*CALL:
1808          ;*1) USING A TRAP INSTRUCTION
1809          ;*      TYPE    ,MESADR          ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
1810          ;*OR
1811          ;*      TYPE
1812          ;*      MESADR
1813          ;*
1814
1815 007274 105737 001157  $TYPE: TSTB    $TPFLG          ;; IS THERE A TERMINAL?
1816 007300 100002          BPL     1$          ;; BR IF YES
1817 007302 000000          HALT          ;; HALT HERE IF NO TERMINAL
1818 007304 000407          BR      3$          ;; LEAVE
1819 007306 010046          1$:  MOV     R0,-(SP)      ;; SAVE R0
1820 007310 017600 000002  MOV     22(SP),R0     ;; GET ADDRESS OF ASCIZ STRING

```

```

1821 007314 112046      2$:  MOVB   (RO)+, -(SP)    ;; PUSH CHARACTER TO BE TYPED ONTC STACK.
1822 007316 001005      BNE    4$                ;; BR IF IT ISN'T THE TERMINATOR.
1823 007320 005726      TST   (SP)+              ;; IF TERMINATOR POP IT OFF THE STACK
1824 007322 012600      60$:  MOV   (SP)+, RO        ;; RESTORE RO
1825 007324 062716 000002 3$:  ADD   #2, (SP)          ;; ADJUST RETURN PC
1826 007330 000002      RTI                      ;; RETURN
1827 007332 122716 000011 4$:  CMPB  #HT, (SP)          ;; BRANCH IF <HT>
1828 007336 001430      BEQ   8$                ;; BRANCH IF NOT <CRLF>
1829 007340 122716 000200      CMPB  #CRLF, (SP)
1830 007344 001006      BNE   5$                ;; POP <CR><LF> EQUIV
1831 007346 005726      TST   (SP)+              ;; TYPE A CR AND LF
1832 007350 104401      TYPE
1833 007352 001167      $CRLF
1834 007354 105037 007510      CLRB  $CHARCNT          ;; CLEAR CHARACTER COUNT
1835 007360 000755      BR    2$                ;; GET NEXT CHARACTER
1836 007362 004737 007444      5$:  JSR   PC, $TYPEPC       ;; GO TYPE THIS CHARACTER
1837 007366 123726 001156      6$:  CMPB  $FILLC, (SP)+    ;; IS IT TIME FOR FILLER CHARS.?
1838 007372 001350      BNE   2$                ;; IF NO GO GET NEXT CHAR.
1839 007374 013746 001154      MOV   $NULL, -(SP)      ;; GET # OF FILLER CHARS. NEEDED
1840                                     AND THE NULL CHAR.
1841 007400 105366 000001 7$:  DECB  1(SP)             ;; DOES A NULL NEED TO BE TYPED?
1842 007404 002770      BLT   6$                ;; BR IF NO--GO POP THE NULL OFF OF STACK
1843 007406 004737 007444      JSR   PC, $TYPEPC       ;; GO TYPE A NULL
1844 007412 105337 007510      DECB  $CHARCNT          ;; DO NOT COUNT AS A COUNT
1845 007416 000770      BR    7$                ;; LOOP

```

:HORIZONTAL TAB PROCESSOR

```

1849 007420 112716 000040 8$:  MOVB  #' (SP)           ;; REPLACE TAB WITH SPACE
1850 007424 004737 007444 9$:  JSR   PC, $TYPEPC       ;; TYPE A SPACE
1851 007430 132737 000007 007510 BITB  #7, $CHARCNT       ;; BRANCH IF NOT AT
1852 007436 001372      BNE   9$                ;; TAB STOP
1853 007440 005726      TST   (SP)+              ;; POP SPACE OFF STACK
1854 007442 000724      BR    2$                ;; GET NEXT CHARACTER
1855 007444 105777 171500 $TYPEPC: TSTB  $STPS          ;; WAIT UNTIL PRINTER IS READY
1856 007450 100375      BPL   $TYPEPC
1857 007452 116677 000002 171472 MOVB  2(SP), $STPB       ;; LOAD CHAR TO BE TYPED INTO DATA REG.
1858 007460 122766 000015 000032 CMPB  #CR, 2(SP)         ;; IS CHARACTER A CARRIAGE RETURN?
1859 007466 001003      BNE   1$                ;; BRANCH IF NO
1860 007470 105037 007510      CLRB  $CHARCNT          ;; YES--CLEAR CHARACTER COUNT
1861 007474 000406      BR    $TYPEPC           ;; EXIT
1862 007476 122766 000012 000002 1$:  CMPB  #LF, 2(SP)        ;; IS CHARACTER A LINE FEED?
1863 007504 001402      BEQ   $TYPEPC           ;; BRANCH IF YES
1864 007506 105227      INCB  (PC)+              ;; COUNT THE CHARACTER
1865 007510 000000 $CHARCNT: .WORD 0        ;; CHARACTER COUNT STORAGE
1866 007512 000207 $TYPEPC: RTS   PC

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```

1871 ;;*****
1872 ;;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
1873 ;;*OCTAL (ASCII) NUMBER AND TYPE IT.
1874 ;;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE

```

```

1875          ;*CALL:
1876          ;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
1877          ;*      TYPOS   ;;CALL FOR TYPEOUT
1878          ;*      .BYTE   N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
1879          ;*      .BYTE   M              ;;M=1 OR 0
1880          ;*                               ;;1=TYPE LEADING ZEROS
1881          ;*                               ;;0=SUPPRESS LEADING ZEROS
1882          ;*
1883          ;*$TYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
1884          ;*$TYPOS OR $TYPOC
1885          ;*CALL:
1886          ;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
1887          ;*      TYPON   ;;CALL FOR TYPEOUT
1888          ;*
1889          ;*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
1890          ;*CALL:
1891          ;*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
1892          ;*      TYPOC   ;;CALL FOR TYPEOUT
1893          ;*
1894          007514 017646 000000          $TYPOS: MOV      2(SP),-(SP)      ;;PICKUP THE MODE
1895          007520 116637 000001 007737  MOVB     1(SP), $OFILL      ;;LOAD ZERO FILL SWITCH
1896          007526 112637 007741          MOVB     (SP)+, $OMODE+1    ;;NUMBER OF DIGITS TO TYPE
1897          007532 062716 000002          ADD      #2, (SP)        ;;ADJUST RETURN ADDRESS
1898          007536 000406          BR       $TYPON
1899          007540 112737 000001 007737  $TYPOC: MOVB     #1, $OFILL      ;;SET THE ZERO FILL SWITCH
1900          007546 112737 000006 007741  MOVB     #6, $OMODE+1    ;;SET FOR SIX(6) DIGITS
1901          007554 112737 000005 007736  $TYPON: MOVB     #5, $OCNT      ;;SET THE ITERATION COUNT
1902          007562 010346          MOV      R3, -(SP)      ;;SAVE R3
1903          007564 010446          MOV      R4, -(SP)      ;;SAVE R4
1904          007566 010546          MOV      R5, -(SP)      ;;SAVE R5
1905          007570 113704 007741          MOVB     $OMODE+1, R4    ;;GET THE NUMBER OF DIGITS TO TYPE
1906          007574 005404          NEG      R4
1907          007576 062704 000006          ADD      #6, R4          ;;SUBTRACT IT FOR MAX. ALLOWED
1908          007602 110437 007740          MOVB     R4, $OMODE      ;;SAVE IT FOR USE
1909          007606 113704 007737          MOVB     $OFILL, R4      ;;GET THE ZERO FILL SWITCH
1910          007612 016605 000012          MOV      12(SP), R5     ;;PICKUP THE INPUT NUMBER
1911          007616 005003          CLR      R3              ;;CLEAR THE OUTPUT WORD
1912          007620 006105          1$:    ROL      R5        ;;ROTATE MSB INTO "C"
1913          007622 000404          BR       3$
1914          007624 006105          2$:    ROL      R5        ;;GO DO MSB
1915          007626 006105          ROL      R5              ;;FORM THIS DIGIT
1916          007630 006105          ROL      R5
1917          007632 010503          MOV      R5, R3
1918          007634 006103          3$:    ROL      R3        ;;GET LSB OF THIS DIGIT
1919          007636 105337 007740          DECB     $OMODE          ;;TYPE THIS DIGIT?
1920          007642 100016          BPL      7$              ;;BR IF NO
1921          007644 042703 177770          BIC      #177770, R3     ;;GET RID OF JUNK
1922          007650 001002          BNE      4$              ;;TEST FOR 0
1923          007652 005704          TST     R4              ;;SUPPRESS THIS 0?
1924          007654 001403          BEQ     5$              ;;BR IF YES
1925          007656 005204          4$:    INC      R4        ;;DON'T SUPPRESS ANYMORE 0'S
1926          007660 052703 000060          BIS      #'0, R3        ;;MAKE THIS DIGIT ASCII
1927          007664 052703 000040          5$:    BIS      #' , R3   ;;MAKE ASCII IF NOT ALREADY
1928          007670 110337 007734          MOVB     R3, 9$        ;;SAVE FOR TYP'NG

```

DZRJB.013 BINARY TO OCTAL (ASCII) AND TYPE

```

1929 007674 104401 007734          TYPE      8$          ;; GO TYPE THIS DIGIT
1930 007700 105337 007736          7$:  DECB      $OCNT      ;; COUNT BY 1
1931 007704 003347          BGT      2$          ;; BR IF MORE TO DO
1932 007706 002402          BLT      6$          ;; BR IF DONE
1933 007710 005204          INC      R4          ;; INSURE LAST DIGIT ISN'T A BLANK
1934 007712 000744          BR      2$          ;; GO DO THE LAST DIGIT
1935 007714 012605          6$:  MOV      (SP)+,R5  ;; RESTORE R5
1936 007716 012604          MOV      (SP)+,R4  ;; RESTORE R4
1937 007720 012603          MOV      (SP)+,R3  ;; RESTORE R3
1939 007722 016666 000002 000004  MOV      2(SP),4(SP) ;; SET THE STACK FOR RETURNING
1939 007730 012616          MOV      (SP)+,(SP)
1940 007732 000002          RTI          ;; RETURN
1941 007734          000          8$:  .BYTE     0          ;; STORAGE FOR ASCII DIGIT
1942 007735          000          .BYTE     0          ;; TERMINATOR FOR TYPE ROUTINE
1943 007736          000          $OCNT:   .BYTE     0          ;; OCTAL DIGIT COUNTER
1944 007737          000          $OFILL:  .BYTE     0          ;; ZERO FILL SWITCH
1945 007740 000000          $OMODE:  .WORD     0          ;; NUMBER OF DIGITS TO TYPE
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959 007742          $TYPDS:
1960 007742 010046          MOV      R0,-(SP)  ;; PUSH R0 ON STACK
1961 007744 010146          MOV      R1,-(SP)  ;; PUSH R1 ON STACK
1962 007746 010246          MOV      R2,-(SP)  ;; PUSH R2 ON STACK
1963 007750 010346          MOV      R3,-(SP)  ;; PUSH R3 ON STACK
1964 007752 010546          MOV      R5,-(SP)  ;; PUSH R5 ON STACK
1965 007754 012746 020200          MOV      #20200,-(SP) ;; SET BLANK SWITCH AND SIGN
1966 007760 016605 000020          MOV      20(SP),R5  ;; GET THE INPUT NUMBER
1967 007764 100004          BPL      1$          ;; BR IF INPUT IS POS.
1968 007766 005405          NEG      R5          ;; MAKE THE BINARY NUMBER POS.
1969 007770 112766 000055 000001  MOVB     #'-.1(SP)  ;; MAKE THE ASCII NUMBER NEG.
1970 007776 005000          1$:  CLR      R0          ;; ZERO THE CONSTANTS INDEX
1971 010000 012703 010156          MOV      #5DBLK,R3  ;; SETUP THE OUTPUT POINTER
1972 010004 112723 000040          MOVB     #' ,(R3)+  ;; SET THE FIRST CHARACTER TO A BLANK
1973 010010 005002          2$:  CLR      R2          ;; CLEAR THE BCD NUMBER
1974 010012 016001 010146          MOV      $DTBL(R0),R1 ;; GET THE CONSTANT
1975 010016 160105          3$:  SUB      R1,R5      ;; FORM THIS BCD DIGIT
1976 010020 002402          BLT      4$          ;; BR IF DONE
1977 010022 005202          INC      R2          ;; INCREASE THE BCD DIGIT BY 1
1978 010024 000774          BR      3$
1979 010026 060105          4$:  ADD      R1,R5      ;; ADD BACK THE CONSTANT
1980 010030 005702          TST      R2          ;; CHECK IF BCD DIGIT=0
1981 010032 001002          BNE     5$          ;; FALL THROUGH IF 0
1982 010034 105716          TSTB     (SP)       ;; STILL DOING LEADING 0'S

```

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```

;*****
;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
;SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
;NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
;BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
;REPLACED WITH SPACES.

```

```

;CALL:
;*      MOV      NUM,-(SP)      ;; PUT THE BINARY NUMBER ON THE STACK
;*      TYPDS          ;; GO TO THE ROUTINE

```

```

$TYPDS:
MOV      R0,-(SP)  ;; PUSH R0 ON STACK
MOV      R1,-(SP)  ;; PUSH R1 ON STACK
MOV      R2,-(SP)  ;; PUSH R2 ON STACK
MOV      R3,-(SP)  ;; PUSH R3 ON STACK
MOV      R5,-(SP)  ;; PUSH R5 ON STACK
MOV      #20200,-(SP) ;; SET BLANK SWITCH AND SIGN
MOV      20(SP),R5  ;; GET THE INPUT NUMBER
BPL      1$        ;; BR IF INPUT IS POS.
NEG      R5        ;; MAKE THE BINARY NUMBER POS.
MOVB     #'-.1(SP) ;; MAKE THE ASCII NUMBER NEG.
1$:  CLR      R0        ;; ZERO THE CONSTANTS INDEX
MOV      #5DBLK,R3  ;; SETUP THE OUTPUT POINTER
MOVB     #' ,(R3)+  ;; SET THE FIRST CHARACTER TO A BLANK
2$:  CLR      R2        ;; CLEAR THE BCD NUMBER
MOV      $DTBL(R0),R1 ;; GET THE CONSTANT
3$:  SUB      R1,R5      ;; FORM THIS BCD DIGIT
BLT      4$        ;; BR IF DONE
INC      R2        ;; INCREASE THE BCD DIGIT BY 1
BR      3$
4$:  ADD      R1,R5      ;; ADD BACK THE CONSTANT
TST      R2        ;; CHECK IF BCD DIGIT=0
BNE     5$        ;; FALL THROUGH IF 0
5$:  TSTB     (SP)       ;; STILL DOING LEADING 0'S

```

```

1983 010036 100407      BMI      7$          ;; BR IF YES
1984 010040 106316      5$: ASLB      (SP)      ;; MSD?
1985 010042 103003      BCC      6$          ;; BR IF NO
1986 010044 116663 000001 177777  MOVB     1(SP),-1(R3) ;; YES--SET THE SIGN
1987 010052 052702 000060      6$: BIS      #'0,R2    ;; MAKE THE BCD DIGIT ASCII
1988 010056 052702 000040      7$: BIS      #' ,R2     ;; MAKE IT A SPACE IF NOT ALREADY A DIGIT
1989 010062 110223      MOVB     R2,(R3)+    ;; PUT THIS CHARACTER IN THE OUTPUT BUFFER
1990 010064 005720      TST      (R0)+      ;; JUST INCREMENTING
1991 010066 020027 000010      CMP      R0,#10     ;; CHECK THE TABLE INDEX
1992 010072 002746      BLT      2$          ;; GO DO THE NEXT DIGIT
1993 010074 003002      BGT      8$          ;; GO TO EXIT
1994 010076 010502      MOV      R5,R2      ;; GET THE LSD
1995 010100 000764      BR       6$          ;; GO CHANGE TO ASCII
1996 010102 105726      8$: TSTB     (SP)+    ;; WAS THE LSD THE FIRST NON-ZERO?
1997 010104 100003      BPL      9$          ;; BR IF NO
1998 010106 116663 177777 177776  MOVB     -1(SP),-2(R3) ;; YES--SET THE SIGN FOR TYPING
1999 010114 105013      9$: CLRB     (R3)     ;; SET THE TERMINATOR
2000 010116 012605      MOV      (SP)+,R5   ;; POP STACK INTO R5
2001 010120 012603      MOV      (SP)+,R3   ;; POP STACK INTO R3
2002 010122 012602      MOV      (SP)+,R2   ;; POP STACK INTO R2
2003 010124 012601      MOV      (SP)+,R1   ;; POP STACK INTO R1
2004 010126 012600      MOV      (SP)+,R0   ;; POP STACK INTO R0
2005 010130 104401 010156  TYPE     $DBLK      ;; NOW TYPE THE NUMBER
2006 010134 016566 000002 000004  MOV      2(SP),4(SP) ;; ADJUST THE STACK
2007 010142 012616      MOV      (SP)+,(SP)
2008 010144 000002      RTI                          ;; RETURN TO USER
2009 010146 023420      $DTBL: 10000.
2010 010150 001750      1000.
2011 010152 000144      100.
2012 010154 000012      10.
2013 010156 000004      $DBLK: .BLKW 4
2014
2015      .SBTTL TTY INPUT ROUTINE
2016
2017      ;;*****
2018      .ENABL  LSB
2019 010166 000000  $TKCNT: .WORD 0      ;; NUMBER OF ITEMS IN QUEUE
2020 010170 000000  $TKQIN: .WORD 0      ;; INPUT POINTER
2021 010172 000000  $TKQOUT: .WORD 0     ;; OUTPUT POINTER
2022 010174 000007  $TKQSRT: .BLKB 7     ;; TTY KEYBOARD QUEUE
2023      $TKQEND=.
2024      .EVEN
2025
2026      ;*TK INITIALIZE ROUTINE
2027      ;*THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
2028      ;*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
2029
2030      ;*CALL:
2031      *      JSR      PC,$TKINT
2032      *      RETURN
2033
2034 010204 005037 010166  $TKINT: CLR      $TKCNT      ;; CLEAR COUNT OF ITEMS IN QUEUE
2035 010210 012737 010174 010170  MOV      #$TKQSRT,$TKQIN ;; MOVE THE STARTING ADDRESS OF THE
2036 010216 013737 010170 010172  MOV      $TKQIN,$TKQOUT ;; QUEUE INTO THE INPUT & OUTPUT POINTERS.

```

```

010254 012737 010254 000060
010255 012737 000200 000062
010256 012737 170770 170672
010257 000207
010258
010259
010260
010261
010262
010263
010264
010265
010266
010267
010268
010269
010270
010271
010272
010273
010274
010275
010276
010277
010278
010279
010280
010281
010282
010283
010284
010285
010286
010287
010288
010289
010290
010291
010292
010293
010294
010295
010296
010297
010298
010299
010300
010301
010302
010303
010304
010305
010306
010307
010308
010309
010310
010311
010312
010313
010314
010315
010316
010317
010318
010319
010320
010321
010322
010323
010324
010325
010326
010327
010328
010329
010330
010331
010332
010333
010334
010335
010336
010337
010338
010339
010340
010341
010342
010343
010344
010345
010346
010347
010348
010349
010350
010351
010352
010353
010354
010355
010356
010357
010358
010359
010360
010361
010362
010363
010364
010365
010366
010367
010368
010369
010370
010371
010372
010373
010374
010375
010376
010377
010378
010379
010380
010381
010382
010383
010384
010385
010386
010387
010388
010389
010390
010391
010392
010393
010394
010395
010396
010397
010398
010399
010400
010401
010402
010403
010404
010405
010406
010407
010408
010409
010410
010411
010412
010413
010414
010415
010416
010417
010418
010419
010420
010421
010422
010423
010424
010425
010426
010427
010428
010429
010430
010431
010432
010433
010434
010435
010436
010437
010438
010439
010440
010441
010442
010443
010444
010445
010446
010447
010448
010449
010450
010451
010452
010453
010454
010455
010456
010457
010458
010459
010460

```

```

MOV    #STKSRV, @STKVEC    ;; INITIALIZE THE KEYBOARD VECTOR
MOV    #200, @STKVEC+2    ;; "BR" LEVEL 4
TST    @STKB               ;; CLEAR DONE FLAG
MOV    #100, @STKS        ;; ENABLE TTY KEYBOARD INTERRUPT
RTS    PC                  ;; RETURN TO CALLER

;; *TK SERVICE ROUTINE
;; *THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
;; *BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
;; *IT IN THE QUEUE.
;; *IF THE CHARACTER IS A "CONTROL-C" (10) STKINT IS CALLED AND
;; *UPON RETURN EXIT IS MADE TO THE "CONTROL-C" RESTART ADDRESS (@CNTLC).

$TKSRV: MOV    @STKB, -(SP)    ;; PICKUP THE CHARACTER
        BIC    #10177, (SP)   ;; STRIP THE JUNK
        CMP    (SP), #3      ;; IS IT A CONTROL C?
        BNE    1$           ;; BRANCH IF NO
        TYPE   @CNTLC        ;; TYPE A CONTROL-C (10)
        JSR    PC, $TKINT    ;; INIT THE KEYBOARD
        TST    (SP)+         ;; CLEAN UP STACK
        JMP    @CNTLC        ;; CONTROL C RESTART
1$:     CMP    (SP), #7      ;; IS IT A CONTROL G?
        BNE    2$           ;; BRANCH IF NO
        CMP    @SWREG, SWR   ;; IS SOFT-SWR SELECTED?
        BEQ    6$           ;; GO TO SWR CHANGE

2$:     CMP    #7, $TKCNT    ;; IS THE QUEUE FULL?
        BNE    3$           ;; BRANCH IF NO
        TYPE   @SBELL        ;; RING THE TTY BELL
        TST    (SP)+         ;; CLEAN CHARACTER OFF OF STACK
        BR     5$           ;; EXIT
3$:     CMP    (SP), #23     ;; IS IT A CONTROL-S?
        BNE    32$          ;; BRANCH IF NO
        CLR    @STKS        ;; DISABLE TTY KEYBOARD INTERRUPTS
        TST    (SP)+         ;; CLEAN CHAR OFF STACK
        TSTB   @STKS        ;; WAIT FOR A CHAR
        BPL    31$          ;; LOOP UNTIL ITS THERE
        MOV    @STKB, -(SP)  ;; GET THE CHARACTER
        BIC    #10177, (SP)  ;; MAKE IT 7-BIT ASCII
        CMP    (SP)+, #21    ;; IS IT A CONTROL-Q?
        BNE    31$          ;; BRANCH IF NO
        MOV    #100, @STKS   ;; REENABLE TTY KEYBOARD INTERRUPTS
        RTI                    ;; RETURN
32$:    INC    $TKCNT        ;; COUNT THIS CHARACTER
        CMP    (SP), #140    ;; IS IT UPPER CASE?
        BLT    4$           ;; BRANCH IF YES
        CMP    (SP), #175    ;; IS IT A SPECIAL CHAR?
        BGT    4$           ;; BRANCH IF YES
        BIC    #40, (SP)     ;; MAKE IT UPPER CASE
        MOV    (SP)+, @STKQIN ;; AND PUT IT IN QUEUE
        INC    $TKQIN        ;; UPDATE THE POINTER
        CMP    $TKQIN, #STKQEND ;; GO OFF THE END?
        BNE    5$           ;; BRANCH IF NO

```

010462 012737 010174 010170
010470 000002
010472 022737 000176 001140
010500 001124
010502 105777 170436
010506 100121
010510 117746 170432
010514 042716 177600
010520 021627 000007
010524 001300
010526 123727 001134 000001
010534 001674
010536 005726
010540 004737 010204
010544 005077 170374
010550 112737 000001 001135
010556 104401 011401
010562 104401 011406
010566 013746 000176
010572 104402
010574 104401 011417
010600 005046
010602 005046
010604 105777 170324
010610 100375
010612 117746 170330
010616 042716 177600
010622 021627 000003
010626 001015
010630 104401 011367
010634 062706 000006
010640 123727 001135 000001
010646 001003
010650 012777 000100 170266
010656 000177 170416
010662 021627 000025
010666 001005

MOV #STKQRT,\$TKQIN ;; RESET THE POINTER
RTI ;; RETURN

*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
*CALL WHEN OPERATING IN TTY INTERRUPT MODE.
\$CKSWR: CMP #SWREG,SWR ;; IS THE SOFT-SWR SELECTED
BNE 15\$;; EXIT IF NOT
TSTB \$TKS ;; IS A CHAR WAITING?
BPL 15\$;; IF NOT, EXIT
MOVB \$TKB,-(SP) ;; YES
BIC #177,(SP) ;; MAKE IT 7-BIT ASCII
CMP (SP),#7 ;; IS IT A CONTROL-G?
BNE 25 ;; IF NOT, PUT IT IN THE TTY QLELE
 ;; AND EXIT

*CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
*ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
*CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.
5\$: CMPB \$AUTOB,#1 ;; ARE WE RUNNING IN AUTO-MODE?
BEQ 25 ;; BRANCH IF YES
TST (SP)+ ;; CLEAR CONTROL-G OFF STACK
JSR PC,\$TKINT ;; FLUSH THE TTY INPUT QUEUE
CLR \$TKS ;; DISABLE TTY KEYBOARD INTERRUPTS
MOVB #1,\$INTAG ;; SET INTERRUPT MODE INDICATOR
\$GTSWR: TYPE \$CNTLG ;; ECHO THE CONTROL-G (13)
TYPE \$MSWR ;; TYPE CURRENT CONTENTS
MOV \$SWREG,-(SP) ;; SAVE SWREG FOR TYPEOUT
TYPOC ;; GO TYPE--OCTAL ASCII ALL DIGITS:
TYPE \$MNEW ;; PROMPT FOR NEW SWR
19\$: CLR -(SP) ;; CLEAR COUNTER
CLR -(SP) ;; THE NEW SWR
7\$: TSTB \$TKS ;; CHAR THERE?
BPL 7\$;; IF NOT TRY AGAIN
MOVB \$TKB,-(SP) ;; PICK UP CHAR
BIC #177,(SP) ;; MAKE IT 7-BIT ASCII
CMP (SP),#3 ;; IS IT A CONTROL-C?
BNE 9\$;; BRANCH IF NOT
TYPE \$CNTLC ;; YES, ECHO CONTROL-C (*C)
ADD #6,SP ;; CLEAN UP STACK
CMPB \$INTAG,#1 ;; REENABLE TTY KEYBOARD INTERRUPTS?
BNE 8\$;; BRANCH IF NO
MOV #100,\$TKS ;; ALLOW TTY KEYBOARD INTERRUPTS
JMP \$CNTLC ;; CONTROL-C RESTART
9\$: CMP (SP),#25 ;; IS IT A CONTROL-U?
BNE 10\$;; BRANCH IF NOT

5\$: MOV #STKQRT,\$TKQIN ;; RESET THE POINTER
RTI ;; RETURN

*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP
*CALL WHEN OPERATING IN TTY INTERRUPT MODE.
\$CKSWR: CMP #SWREG,SWR ;; IS THE SOFT-SWR SELECTED
BNE 15\$;; EXIT IF NOT
TSTB \$TKS ;; IS A CHAR WAITING?
BPL 15\$;; IF NOT, EXIT
MOVB \$TKB,-(SP) ;; YES
BIC #177,(SP) ;; MAKE IT 7-BIT ASCII
CMP (SP),#7 ;; IS IT A CONTROL-G?
BNE 25 ;; IF NOT, PUT IT IN THE TTY QLELE
 ;; AND EXIT

*CONTROL IS PASSED TO THIS POINT FROM EITHER THE TTY INTERRUPT SERVICE
*ROUTINE OR FROM THE SOFTWARE SWITCH REGISTER TRAP CALL, AS A RESULT OF A
*CONTROL-G BEING TYPED, AND THE SOFTWARE SWITCH REGISTER BEING SELECTED.
5\$: CMPB \$AUTOB,#1 ;; ARE WE RUNNING IN AUTO-MODE?
BEQ 25 ;; BRANCH IF YES
TST (SP)+ ;; CLEAR CONTROL-G OFF STACK
JSR PC,\$TKINT ;; FLUSH THE TTY INPUT QUEUE
CLR \$TKS ;; DISABLE TTY KEYBOARD INTERRUPTS
MOVB #1,\$INTAG ;; SET INTERRUPT MODE INDICATOR
\$GTSWR: TYPE \$CNTLG ;; ECHO THE CONTROL-G (13)
TYPE \$MSWR ;; TYPE CURRENT CONTENTS
MOV \$SWREG,-(SP) ;; SAVE SWREG FOR TYPEOUT
TYPOC ;; GO TYPE--OCTAL ASCII ALL DIGITS:
TYPE \$MNEW ;; PROMPT FOR NEW SWR
19\$: CLR -(SP) ;; CLEAR COUNTER
CLR -(SP) ;; THE NEW SWR
7\$: TSTB \$TKS ;; CHAR THERE?
BPL 7\$;; IF NOT TRY AGAIN
MOVB \$TKB,-(SP) ;; PICK UP CHAR
BIC #177,(SP) ;; MAKE IT 7-BIT ASCII
CMP (SP),#3 ;; IS IT A CONTROL-C?
BNE 9\$;; BRANCH IF NOT
TYPE \$CNTLC ;; YES, ECHO CONTROL-C (*C)
ADD #6,SP ;; CLEAN UP STACK
CMPB \$INTAG,#1 ;; REENABLE TTY KEYBOARD INTERRUPTS?
BNE 8\$;; BRANCH IF NO
MOV #100,\$TKS ;; ALLOW TTY KEYBOARD INTERRUPTS
JMP \$CNTLC ;; CONTROL-C RESTART
9\$: CMP (SP),#25 ;; IS IT A CONTROL-U?
BNE 10\$;; BRANCH IF NOT

010570	004401	011374		203:	TYPE	.SCNTLU	:: YES, ECHO CONTROL-U (U)
010570	004401	000006			ADD	#6,SP	:: IGNORE PREVIOUS INPUT
010570	000737				BR	196	:: LET'S TRY IT AGAIN
010570	001162	000015		105:	CMP	SP, #15	:: IS IT A <CR>?
010570	001162				BNE	166	:: BRANCH IF NO
010570	000766	000004			TST	4(SP)	:: YES, IS IT THE FIRST CHAR?
010570	001403				BEC	116	:: BRANCH IF YES
010570	011667	000002	170214		MOV	2(SP), 2SWR	:: SAVE NEW SWR
010570	002706	000006		116:	ADD	#6,SP	:: CLEAR UP STACK
010570	004401	001167		148:	TYPE	\$CRLF	:: ECHO <CR> AND <LF>
010570	002727	001135	000001		CMPB	\$INTAG, #1	:: RE-ENABLE TTY KBD INTERRUPTS
010570	001162				BNE	156	:: BRANCH IF NOT
010570	002727	000100	170172		MOV	#100, 2STKS	:: RE-ENABLE TTY KBD INTERRUPTS
010570	000002			156:	RTI		:: RETURN
010570	004401	007447		156:	PC	\$TYPEC	:: ECHO CHAR
010570	002706	000060			(SP), #60		:: CHAR < 0?
010570	002706				BGT	106	:: BRANCH IF YES
010570	002706	000067			(SP), #67		:: CHAR > 7?
010570	002706				BGT	106	:: BRANCH IF YES
010570	042726	000060			#60, SP, +		:: STRIP-OFF ASCII
010570	005766	000002			2(SP)		:: IS THIS THE FIRST CHAR
010570	001403				BEC	116	:: BRANCH IF YES
010570	006316				(SP)		:: NO, SHIFT PRESENT
010570	006316				(SP)		:: CHAR OVER TO MAKE
010570	006316				(SP)		:: ROOM FOR NEW ONE.
010570	005766	000002		178:	INC	2(SP)	:: KEEP COUNT OF CHAR
010570	005766	177776			(SP), #SP		:: SET IN NEW CHAR
010570	000667				BR	75	:: GET THE NEXT ONE
010570	004401	001166		182:	TYPE	\$CJES	:: TYPE 'CR' <LF>
010570	000720				BR	206	:: SIMULATE CONTROL-J
				.DEABL	LSB		

*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
*CALL:

* * * *	ROCHR RETURN HERE	:: GET A CHARACTER FROM THE QUEUE :: CHARACTER IS ON THE STACK :: WITH PARITY BIT STRIPPED OFF
------------------	----------------------	--

011034	011646	000004	000002	648:	MOV	(SP), -SP)	:: PUSH DOWN THE PC AND
011034	016666	000004			MOV	4(SP), 2(SP)	:: THE PS
011034	005066	000004			CLR	4(SP)	:: GET READY FOR A CHARACTER
011034	005046				CLR	-SP)	:: PUT NEW PS ON STACK
011034	012746	011060			MOV	#648, -SP	:: PUT NEW PC ON STACK
011034	000002				RTI		:: POP NEW PC AND PS
011060	005737	010166		15:	TST	\$TKCNT	:: WAIT ON A CHARACTER
011060	001776				BEC	15	
011060	005337	010166			DEC	\$TKCNT	:: DECREMENT THE COUNTER
011060	177776	177776	000004		MOV	\$TKCNT, 4 SP	:: GET ONE CHARACTER

```

0011100 0005237 010172 INC STKQOUT :: UPDATE THE POINTER
0011104 0237277 010172 010203 CMP STKQOUT,#STKQEND :: DID IT GO OFF OF THE END?
0011112 0010003 BNE 25 :: BRANCH IF NO
0011114 011372 010172 MOV #STKQSR,STKQOUT :: RESET THE POINTER
0011118 000002 RTI :: RETURN
25:
*****
*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
*CALL:
* RDLIN :: INPUT A STRING FROM THE TTY
* RETURN HERE :: ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
* :: TERMINATOR WILL BE A BYTE OF ALL 0'S

0111124 0113246 SRDLIN: MOV R3,-(SP) :: SAVE R3
0111126 005046 CLR -(SP) :: CLEAR THE RUBOUT KEY
0111130 012703 011360 15: MOV #STTYIN,R3 :: GET ADDRESS
0111134 022703 011367 25: CMP #STTYIN+7,R3 :: BUFFER FULL?
0111140 101456 BLOS 45 :: BR IF YES
0111144 104410 RDCHR :: GO READ ONE CHARACTER FROM THE TTY
0111148 112613 MOVB (SP)+,R3 :: GET CHARACTER
0111152 122713 000177 105: CMPB #177,R3 :: IS IT A RUBOUT
0111156 001022 BNE 55 :: BR IF NO
0111158 005716 TST (SP) :: IS THIS THE FIRST RUBOUT?
0111160 001007 BNE 65 :: BR IF NO
0111166 112737 000134 011356 65: MOVB #1,95 :: TYPE A BACK SLASH
0111168 104401 011356 TYPE 95
0111172 012716 177777 55: MOV #1,(SP) :: SET THE RUBOUT KEY
0111176 005303 011360 65: DEC R3 :: BACKUP BY ONE
0111180 020327 011360 75: CMP R3,#STTYIN :: STACK EMPTY?
0111184 103434 BLOS 45 :: BR IF YES
0111188 111337 011356 55: MOVB (R3),95 :: SETUP TO TYPEOUT THE DELETED CHAR.
0111192 104401 011356 TYPE 95
0111196 000746 BR 25 :: GO TYPE
0111200 005716 55: TST (SP) :: GO READ ANOTHER CHAR.
0111204 001406 75: BEQ 75 :: RUBOUT KEY SET?
0111208 112737 000134 011356 55: MOVB #1,95 :: BR IF NO
0111212 104401 011356 TYPE 95 :: TYPE A BACK SLASH
0111216 005016 CLR (SP) :: CLEAR THE RUBOUT KEY
0111220 122713 000025 75: CMPB #25,(R3) :: IS CHARACTER A CTRL "U"
0111224 001003 BNE 85 :: BR IF NO
0111228 104401 011374 TYPE #CNTLU :: TYPE A CONTROL "U"
0111232 000725 BR 15 :: GO START OVER
0111236 122713 000022 55: CMPB #22,(R3) :: IS CHARACTER A "R"
0111240 001011 BNE 35 :: BRANCH IF NO
0111244 105013 CLRB (R3) :: CLEAR THE CHARACTER
0111248 104401 001167 TYPE #CR LF :: TYPE A "CR" & "LF"
0111252 104401 011360 TYPE STTYIN :: TYPE THE INPUT STRING
0111256 000717 BR 25 :: GO PICKUP ANOTHER CHARACTER
0111260 104401 001166 45: TYPE #QUES :: TYPE A '?'
0111264 000712 BR 15 :: CLEAR THE BUFFER AND LOOP
0111268 111337 011356 35: MOVB (R3),95 :: ECHO THE CHARACTER
0111272 104401 011356 TYPE 95
0111276 122723 000015 35: CMPB #15,(R3)+ :: CHECK FOR RETURN
0111280 001305 BNE 25 :: LOOP IF NOT RETURN
0111284 105063 177777 CLRB -1,R3 :: CLEAR RETURN ,THE 15

```

```

011326 104401 001170 TYPE $LF ;; TYPE A LINE FEED
011332 005726 TST (SP)+ ;; CLEAN RUBOUT KEY FROM THE STACK
011334 012603 MOV (SP)+,R3 ;; RESTORE R3
011336 011646 MOV (SP)-,(SP) ;; ADJUST THE STACK AND PUT ADDRESS OF THE
011340 016656 000004 000002 MOV 4(SP),2(SP) ;; FIRST ASCII CHARACTER ON IT
011346 012766 011360 000004 MOV $TTYIN,4(SP)
011354 000002 RTI ;; RETURN
011356 000 .95: .BYTE 0 ;; STORAGE FOR ASCII CHAR. TO TYPE
011357 000 .BYTE 0 ;; TERMINATOR
011360 000007 $TTYIN: .BLKB 7 ;; RESERVE 7 BYTES FOR TTY INPUT
011367 136 006503 000012 $CNTLC: .ASCIZ /?C/<15><12> ;; CONTROL "C"
011374 352536 005015 000 $CNTLU: .ASCIZ /?U/<15><12> ;; CONTROL "U"
011401 136 006507 000012 $CNTLG: .ASCIZ /?G/<15><12> ;; CONTROL "G"
011406 005015 053523 020122 $MSWR: .ASCIZ <15><12>/SWR = /
011414 020075 000 $MNEW: .ASCIZ NEW = /
011427 036440 000040

.SBTTL TYPE NUMERICAL ASCIZ STRING SUPPRESS LEADING ZEROS
*****
*THIS ROUTINE IS USED TO TYPE AN ASCIZ NUMBER SUPPRESSING THE
*LEADING NUMBERS.
*CALL
* MOV $NUMADR,-(SP) ;; FIRST ADDRESS OF ASCIZ STRING
* JSR PC,2*$SUPRS

$SUPRS: MOV R0,-(SP) ;; SAVE R0
MOV 4(SP),R0 ;; PICKUP THE POINTER
15: TSTB (R0) ;; TERMINATOR?
BEQ 25: BR IF YES
CMPB #'0',(R0)+ ;; IS THIS AN ASCII "0" ?
BEQ 15: BR IF YES
25: DEC R0 ;; BACKUP BY "1"
MOV R0,35: ;; SAVE FOR TYPING
TYPE GO TYPE
35: .WORD 0 ;; ASCII POINTER GOES HERE
MOV (SP)+,R0 ;; RESTORE R0
MOV (SP)+,(SP) ;; RESTORE THE STACK
RTS PC ;; RETURN

.SBTTL SINGLE LENGTH BINARY TO DECIMAL ASCIZ ROUTINE
*****
*THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
*UNSIGNED DECIMAL ASCIZ NUMBER.
*CALL
* MOV NUMBER,-(SP) ;; PUT BINARY NUMBER ON THE STACK
* JSR PC,2*$SB2D ;; CALL
* RETURN ;; ADDRESS OF THE 1ST ASCII CHAR. IS ON THE STACK

011470 016637 000002 011500 $SB2D: MOV 2,SP,15 ;; SAVE BINARY NUMBER

```

```

011476 012746 011520
011502 004737 011524
011506 062716 000005
011512 012666 000002
011516 000207
011520 000000 000000

```

```

MOV #15, -(SP) ;; SET POINTER
JSR PC, 2*$DB2D ;; CALL DOUBLE LENGTH CONVERT
ADD #5, (SP) ;; ONLY ALLOW FIVE CHARACTERS
MOV (SP)+, 2(SP) ;; PICKUP POINTER
RTS PC ;; RETURN

1$: .WORD 0,0

.SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE

```

```

*****
*THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
*DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
*POSITIVE.
*CALL

```

```

* MOV #PNTR, -(SP) ;; POINTER TO LOW WORD OF BINARY NUMBER
* JSR PC, 2*$DB2D
* RETURN ;; THE FIRST ADDRESS OF ASCII
;; IS ON THE STACK

```

```

011524 104412
011526 016602 000002
011532 012700 011704
011536 010066 000002
011542 012201
011544 012202
011546 012737 000012 011622
011554 012704 011634
011560 012705 011636
011564 005003
011566 161401
011570 005602
011572 161502
011574 002402
011576 005203
011600 000772
011602 062401
011604 005502
011606 062402
011610 022525
011612 052703 000060
011616 110320
011620 005327
011622 000000
011624 001357
011626 105020
011630 104413
011632 000207
011634 145000
011636 035632
011640 160400
011642 002765
011644 113200
011646 000200 230

```

```

$DB2D: SAVREG ;; SAVE REGISTERS
MOV 2(SP), R2 ;; PICKUP THE DATA POINTER
MOV #SDECVL, R0 ;; GET ADDRESS OF "SDECVL" STRING
MOV R0, 2(SP) ;; PUT ADDRESS OF ASCII STRING ON STACK
MOV (R2)+, R1 ;; PICKUP THE BINARY NUMBER
MOV (R2)+, R2
MOV #10, 4$ ;; SET UP TO DO 10 CONVERSIONS
MOV #STNPNR, R4 ;; ADDRESS OF TEN POWER
MOV #STNPNR+2, R5
1$: CLR R3 ;; CLEAR PARTIAL
2$: SUB (R4), R1 ;; SUBTRACT TEN POWER
SBC R2
SUB (R5), R2
BLT 3$ ;; BR IF TEN POWER TOO LARGE
INC R3 ;; ADD 1 TO PARTIAL
BR 2$ ;; LOOP
3$: ADD (R4)+, R1 ;; RESTORE SUBTRACTED VALUE
ADD R2
ADD (R4)+, R2
CMP (R5)+, (R5)+ ;; MOVE TO NEXT TEN POWER
BIS #0, R3 ;; CHANGE PARTIAL TO ASCII
MOVB R3, (R0)+ ;; SAVE IT
DEC (PC)+ ;; DONE
4$: .WORD 0
BNE 1$ ;; BR IF NO
CLRB (R0)+ ;; TERMINATOR
RESREG ;; RESTORE REGISTERS
RTS PC ;; RETURN
STNPNR: 145000 ;; 1.0E09
35632
160400 ;; 1.0E08
2765
113200 ;; 1.0E07
230

```



```

011776 012605
012000 012604
012002 012603
012004 012602
012006 012601
012010 012600
012012 000002

```

```

MOV (SP)+,R5 ;;POP STACK INTO R5
MOV (SP)+,R4 ;;POP STACK INTO R4
MOV (SP)+,R3 ;;POP STACK INTO R3
MOV (SP)+,R2 ;;POP STACK INTO R2
MOV (SP)+,R1 ;;POP STACK INTO R1
MOV (SP)+,R0 ;;POP STACK INTO R0
RTI

```

.SBTTL TRAP DECODER

```

*****
*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
*GO TO THAT ROUTINE.

```

```

012014 010046
012016 016600 000002
012022 005740
012024 111000
012026 006300
012030 016000 012050
012034 000200

```

```

$TRAP: MOV R0, -(SP) ;;SAVE R0
MOV 2(SP), R0 ;;GET TRAP ADDRESS
TST -(R0) ;;BACKUP BY 2
MOV3 (R0), R0 ;;GET RIGHT BYTE OF TRAP
ASL R0 ;;POSITION FOR INDEXING
MOV $TRPAD(R0), R0 ;;INDEX TO TABLE
RTS R0 ;;GO TO ROUTINE

```

;;THIS IS USE TO HANDLE THE "GETPRI" MACRO

```

012036 011646
012040 016666 000004 000002
012046 000002

```

```

$TRAP2: MOV (SP), -(SP) ;;MOVE THE PC DOWN
MOV 4(SP), 2(SP) ;;MOVE THE PSW DOWN
RTI ;;RESTORE THE PSW

```

.SBTTL TRAP TABLE

```

*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
*BY THE "TRAP" INSTRUCTION.

```

```

012050 012036
012052 007274
012054 007540
012056 007514
012060 007554
012062 007742
012064 010562
012066 010472
012070 011034
012072 011124
012074 011720
012076 011756

```

```

ROUTINE
-----
$TRPAD: .WORD $TRAP2
$TYPE ;;CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
$TYPOC ;;CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
$TYPOS ;;CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
$TYPON ;;CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
$TYPDS ;;CALL=TYPDS TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)

$GTSWR ;;CALL=GTSWR TRAP+6(104406) GET SOFT-SWR SETTING

$CKSWR ;;CALL=CKSWR TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
$RDCHR ;;CALL=RDCHR TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
$RDLIN ;;CALL=RDLIN TRAP+11(104411) TTY TYPEIN STRING ROUTINE
$SAVREG ;;CALL=SAVREG TRAP+12(104412) SAVE R0-R5 ROUTINE
$RESREG ;;CALL=RESREG TRAP+13(104413) RESTORE R0-R5 ROUTINE

```

249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322

.SBTTL SINGLE/DUAL PORT RH11/RPO4/5/6 DRIVER (REV 1.0)

;COPYRIGHT (C) 1976
;DIGITAL EQUIPMENT CORP.
;MAYNARD, MA 01754
;AUTHOR(S): JIM LACEY/CHUCK HESS

;*****

;STORAGE FOR RPDS1, RPER1, RPER2, AND RPER3 ON AN ERROR "2"

;RPERRS = RPDS1
;RPERRS+2 = RPER1
;RPERRS+4 = RPER2
;RPERRS+6 = RPER3

012100 000000 000000 000000 RPERRS: .WORD 0,0,0,0
012106 000000

;TABLE OF DRIVE ACTIVE INDICATORS (DRVACT=8 BYTES)

;DRVACT=0 IF DRIVE IS IDLE
;DRVACT>0 IF DRIVE IS ACTIVE WITH A COMMAND
;DRVACT<0 IF DRIVE IS ACTIVE WITH AN ERROR RECOVERY OPERATION

012110 000 DRVACT: .BYTE 0 ;DRIVE 0
012111 000 .BYTE 0 ;DRIVE 1
012112 000 .BYTE 0 ;DRIVE 2
012113 000 .BYTE 0 ;DRIVE 3
012114 000 .BYTE 0 ;DRIVE 4
012115 000 .BYTE 0 ;DRIVE 5
012116 000 .BYTE 0 ;DRIVE 6
012117 000 .BYTE 0 ;DRIVE 7

;TABLE OF DRIVE STATUS INDICATORS (DRVSTA=8 BYTES)

;DRVSTA=0 IF DRIVE IS OFFLINE OR NONEXISTENT
;DRVSTA>0 IF DRIVE IS ONLINE
;DRVSTA<0 IF DRIVE IS UNSAFE

012120 000 DRVSTA: .BYTE 0 ;DRIVE 0
012121 000 .BYTE 0 ;DRIVE 1
012122 000 .BYTE 0 ;DRIVE 2
012123 000 .BYTE 0 ;DRIVE 3
012124 000 .BYTE 0 ;DRIVE 4
012125 000 .BYTE 0 ;DRIVE 5
012126 000 .BYTE 0 ;DRIVE 6
012127 000 .BYTE 0 ;DRIVE 7

;TABLE OF DRIVE TYPES (DRV TYP=8 BYTES)

;DRV TYP=0 IF DRIVE IS NONEXISTENT (DRVSTA=0, ALSO)
;DRV TYP=1 IF DRIVE IS RPO4
;DRV TYP=2 IF DRIVE IS RPO5
;DRV TYP=4 IF DRIVE IS RPO6
;DRV TYP=-1 IF NOT RPO4/5/6

```

2523 012130 000          DRVTyp: .BYTE 0          ;DRIVE 0
2524 012131 000          .BYTE 0          ;DRIVE 1
2525 012132 000          .BYTE 0          ;DRIVE 2
2526 012133 000          .BYTE 0          ;DRIVE 3
2527 012134 000          .BYTE 0          ;DRIVE 4
2528 012135 000          .BYTE 0          ;DRIVE 5
2529 012136 000          .BYTE 0          ;DRIVE 6
2530 012137 000          .BYTE 0          ;DRIVE 7
2531
2532          ;TABLE OF DUAL PORT INITIALIZATION INDICATORS
2533          ;DPINT=0 IF INITIALIZATION IS NOT ACTIVE ON THE DRIVE
2534          ;DPINT<C IF INITIALIZATION IS IN PROGRESS
2535
2536 012140 000          DPINT: .BYTE 0          ;DRIVE 0
2537 012141 000          .BYTE 0          ;DRIVE 1
2538 012142 000          .BYTE 0          ;DRIVE 2
2539 012143 000          .BYTE 0          ;DRIVE 3
2540 012144 000          .BYTE 0          ;DRIVE 4
2541 012145 000          .BYTE 0          ;DRIVE 5
2542 012146 000          .BYTE 0          ;DRIVE 6
2543 012147 000          .BYTE 0          ;DRIVE 7
2544
2545          ;TABLE OF PENDING DUAL PORT REQUESTS
2546          ;DPRQS=0 IF THAT A DUAL PORT REQUEST IS NOT PENDING FOR THAT DRIVE
2547          ;DPRQS<C IF THAT A DUAL PORT REQUEST IS PENDING FOR THAT DRIVE
2548
2549 012150 000          DPRQS: .BYTE 0          ;DRIVE 0
2550 012151 000          .BYTE 0          ;DRIVE 1
2551 012152 000          .BYTE 0          ;DRIVE 2
2552 012153 000          .BYTE 0          ;DRIVE 3
2553 012154 000          .BYTE 0          ;DRIVE 4
2554 012155 000          .BYTE 0          ;DRIVE 5
2555 012156 000          .BYTE 0          ;DRIVE 6
2556 012157 000          .BYTE 0          ;DRIVE 7
2557
2558          ;TRANSFER WAIT FLAG (TRNSWT=1 WORD)
2559          ;THIS IS A ONE WORD QUEUE. IT WILL CONTAIN THE ADDRESS OF
2560          ;"DPB" OF THE I/O OPERATION.
2561
2562 012160 000000          TRNSWT: .WORD 0
2563
2564          ;SEARCH WAIT KEYS (SRCHWT=1 WORD)
2565          ;THIS IS A ONE WORD QUEUE THAT WILL CONTAIN A KEY FOR EACH OF
2566          ;THE DRIVES THAT ARE PERFORMING A SEARCH COMMAND FOR THE I/O
2567          ;REQUEST THAT IS AT THE TOP OF THEIR REQUEST QUEUE.
2568          ;EACH DRIVE IS ASSIGNED ONE BIT, STARTING AT BIT00 FOR DRIVE 0.
2569
2570 012162 000000          SRCHWT: .WORD 0
2571
2572          ;RPO4/5/6 DRIVER ACTIVE FLAG (ACTDRV=1 BYTE)
2573          ;ACTDRV=0 IF DRIVER IS INACTIVE
2574          ;ACTDRV>0 IF DRIVER IS ACTIVE
2575
2576 012164 000          ACTDRV: .BYTE 0

```

```

2577
2578 ;SOFTWARE TIMER ROUTINE ACTIVE FLAG (ACTSTR=1 BYTE)
2579 ;ACTSTR=0 IF SOFTWARE TIMER ROUTINE IS INACTIVE
2580 ;ACTSTR>0 IF SOFTWARE TIMER ROUTINE IS ACTIVE
2581
2582 012165 000 ACTSTR: .BYTE 0
2583
2584 ;UNLOAD FLAG (ULDFLG=8 BYTES)
2585 ;ULDFLG=0 IF NO UNLOAD COMMAND
2586 ;ULDFLG>0 IF UNLOAD COMMAND IN PROGRESS
2587 ;ULDFLG<0 IF UNLOAD COMMAND IN WAIT QUEUE
2588
2589 012166 000 ULDFLG: .BYTE 0 ;DRIVE 0
2590 012167 000 .BYTE 0 ;DRIVE 1
2591 012170 000 .BYTE 0 ;DRIVE 2
2592 012171 000 .BYTE 0 ;DRIVE 3
2593 012172 000 .BYTE 0 ;DRIVE 4
2594 012173 000 .BYTE 0 ;DRIVE 5
2595 012174 000 .BYTE 0 ;DRIVE 6
2596 012175 000 .BYTE 0 ;DRIVE 7
2597
2598 ;LOOK AHEAD COUNT (LACNT=8 BYTES)
2599 ;LACNT WILL INDICATE THE NUMBER OF LOOK AHEADS PERFORMED
2600
2601 012176 000 LACNT: .BYTE 0 ;DRIVE 0
2602 012177 000 .BYTE 0 ;DRIVE 1
2603 012200 000 .BYTE 0 ;DRIVE 2
2604 012201 000 .BYTE 0 ;DRIVE 3
2605 012202 000 .BYTE 0 ;DRIVE 4
2606 012203 000 .BYTE 0 ;DRIVE 5
2607 012204 000 .BYTE 0 ;DRIVE 6
2608 012205 000 .BYTE 0 ;DRIVE 7
2609
2610 ;SAVE REGISTERS FLAG (SAVEFG =1 WORD)
2611 ;SAVEFG <0 IF SAVE THE RH11/RPO4/5/6 REGISTERS WHEN THE
2612 ;OPERATION IS COMPLETED AS PER (DPB+14).
2613 ;SAVEFG=0 IF SAVE THE RH11/RPO4/5/6 REGISTERS, AS PER
2614 ;(DPB+14), AFTER AN ERROR.
2615
2616 012206 00000C SAVEFG: .WORD 0
2617
2618 ;SEEK FLAG (SEEKFG=1 WORD)
2619 ;SEEKFG=0 IF WHEN THE DISK ADDRESS ISN'T IN THE WINDOW
2620 ;FOR A DATA TRANSFER START A SEARCH COMMAND
2621 ;SEEKFG<0 IF DATA TRANSFER WILL DO IMPLIED SEEKS.
2622 ;DISREGARD THE WINDOW
2623
2624 012210 000000 SEEKFG: .WORD 0
2625
2626 ;TIMEOUT TABLE (TIMER=8 WORDS)
2627 ;THIS TABLE CONTAINS THE TIME ALLOWED FOR AN OPERATION
2628
2629 012212 177777 TIMER: .WORD -1 ;DRIVE 0
2630 012214 177777 .WORD -1 ;DRIVE 1
    
```

```

2631 012216 177777 .WORD -1 ;DRIVE 2
2632 012220 177777 .WORD -1 ;DRIVE 3
2633 012222 177777 .WORD -1 ;DRIVE 4
2634 012224 177777 .WORD -1 ;DRIVE 5
2635 012226 177777 .WORD -1 ;DRIVE 6
2636 012230 177777 .WORD -1 ;DRIVE 7
2637
2638 ;DATA TRANSFER UNDERWAY INDICATOR (DTUW=1 WORD)
2639 ;DTUW<0 IF NO DATA TRANSFER UNDERWAY
2640 ;DTUW=+N (WHERE N=0 TO 7) IMPLIES DATA TRANSFER UNDERWAY ON DRIVE N
2641
2642 012232 177777 DTUW: .WORD -1
2643
2644 ;ATTENTION BITS TABLE (ATABIT=8 BYTES)
2645 ;THIS TABLE CONTAINS THE CORRESPONDING BIT TO EACH DRIVES
2646 ;ATTENTION BIT
2647
2648 012234 001 ATABIT: .BYTE 1 ;DRIVE 0
2649 012235 002 .BYTE 2 ;DRIVE 1
2650 012236 004 .BYTE 4 ;DRIVE 2
2651 012237 010 .BYTE 10 ;DRIVE 3
2652 012240 020 .BYTE 20 ;DRIVE 4
2653 012241 040 .BYTE 40 ;DRIVE 5
2654 012242 100 .BYTE 100 ;DRIVE 6
2655 012243 200 .BYTE 200 ;DRIVE 7
2656
2657 ;RPO4/5/6 TO RH11 "MASSBUS CONTROL BUS PARITY ERRORS" (MCPE) ALLOWED BEFORE
2658 ;CALLING IT FATAL (MCPEM=1 WORD)
2659
2660 012244 000003 MCPEM: .WORD 3
2661
2662 ;STORAGE FOR RPADR (THE FIRST ADDRESS (776700) OF THE RH11/RPO4/5/6),
2663 ;RPVEC (THE VECTOR ADDRESS (254)), AND RPVEC+2 (THE BR LEVEL (5)).
2664
2665 012246 176700 RPADR: .WORD 176700
2666 012250 000254 000240 RPVEC: .WORD 254,5*32.
2667
2668 ;MAXIMUM NUMBER OF LOOK AHEADS ALLOWED IS 4 (MXLACT=1 WORD)
2669
2670 012254 000004 MXLACT: .WORD 4
2671 ;MAXIMUM DELTA DELAY IS 8 SECTORS (MXDLTA=1 WORD)
2672
2673 012256 001000 MXDLTA: .WORD 8.*64.
2674 ;MINIMUM DELTA DELAY IS 2 SECTORS (MNDLTA=1 WORD)
2675
2676 012260 000200 MNDLTA: .WORD 2*64.
2677 ;MAXIMUM SEARCH FOR I/O WINDOW IS 5 SECTORS (MXWNDW=1 WORD)
2678
2679 012262 000005 MXWNDW: .WORD 5
2680
2681 ;DEFINITIONS OF THE RH11/RPO4/5/6 ADDRESS INDEXES
2682
2683 000000 RPCS1=0 ;CONTROL AND STATUS REGISTER #1 (DRIVE REG. 00)
2684 000002 RPIC=2 ;WORD COUNT REGISTER (NOT A DRIVE REG)

```

2585	000004	RPBA=4	;UNIBUS ADDRESS REGISTER (NOT A DRIVE REG)
2586	000006	RPDA=6	;DESIRED SECTOR/TRACK ADDRESS REGISTER (DRIVE REG. 05)
2587	000010	RPCS2=10	;CONTROL AND STATUS REGISTER #2 (NOT A DRIVE REG)
2598	000012	RPDS1=12	;DRIVE STATUS REGISTER (DRIVE REG 01)
2689	000014	RPER1=14	;ERROR REGISTER #1 (DRIVE REG. 02)
2690	000016	RPAS=16	;ATTENTION SUMMARY PSEUDO REGISTER (DRIVE REG. 04)
2591	000020	RPLA=20	;LOOK AHEAD REGISTER (DRIVE REG. 07)
2692	000022	RPDB=22	;DATA BUFFER REGISTER (NOT A DRIVE REG.)
2693	000024	RPMB=24	;MAINTAINABILITY REGISTER (DRIVE REG. 03)
2694	000026	RPDT=26	;DRIVE TYPE REGISTER (DRIVE REG. 06)
2695	000030	RPSN=30	;SERIAL NUMBER REGISTER (DRIVE REG. 10)
2696	000032	RPOF=32	;OFFSET REGISTER (DRIVE REG. 11)
2697	000034	RPCA=34	;DESIRED CYLINDER ADDRESS REGISTER (DRIVE REG. 12)
2698	000036	RPCC=36	;CURRENT CYLINDER ADDRESS REGISTER (DRIVE REG. 13)
2699	000040	RPER2=40	;ERROR REGISTER #2 (DRIVE REG. 14)
2700	000042	RPER3=42	;ERROR REGISTER #3 (DRIVE REG. 15)
2701	000044	RPEC1=44	;ECC POSITION REGISTER (DRIVE REG. 16)
2702	000046	RPEC2=46	;ECC PATTERN REGISTER (DRIVE REG. 17)

```

;RH11/RPO4/5/6 DRIVER INITIALIZATION CODE
;THIS ROUTINE WILL DETERMINE WHICH RPO4/5/6 DRIVES ARE
;AVAILABLE FOR TESTING AND SET THE DRVSTA INDICATOR
;TO THE PROPER STATE FOR EACH DRIVE.
;NOTE: THIS ROUTINE CALLS DRVINT
    
```

```

;CALL
    
```

```

        JSR    PC,RPINIT
        RETURN
    
```

```

;NOTE: THE 'P' OR 'L' CLOCK MUST BE STARTED
    
```

2717	012264	104412	RPINIT: SAVREG	;SAVE R0 - R5
2718	012266	013746	MOV	2*PS, -(SP)
2719	012272	012737	MOV	5*32, 2*PS
2720	012300	004737	JSR	PC, CLRQUE
2721	012304	012701	MOV	*RPERRS, R1
2722	012310	012702	MOV	*SEEKFG, R2
2723	012314	005021	1\$: CLR	(R1)+
2724	012316	020102	CMP	R1, R2
2725	012320	101775	BLOS	1\$
2726	012322	012702	MOV	*DTUW, R2
2727	012326	012721	2\$: MOV	*-1, (R1)+
2728	012332	020102	CMP	R1, R2
2729	012334	101774	BLOS	2\$
2730	012336	005037	CLR	DRVSTA
2731	012342	005037	CLR	DRVSTA+2
2732	012346	005037	CLR	DRVSTA+4
2733	012352	005037	CLR	DRVSTA+6
2734	012356	013703	MOV	RPVEC, R3
2735	012362	012723	MOV	*ISR, (R3)+
2736	012366	013713	MOV	RPVEC+2, (R3)
2737	012372	013704	MOV	RPADR, R4
2738	012376	012764	MOV	*BIT05, RPCS2(R4)

;CHANGE THE PRIORITY TO 5
 ;CLEAR ALL REQUEST QUEUES
 ;FIRST ADDRESS TO BE CLEARED
 ;LAST ADDRESS TO BE CLEARED
 ;CLEAR
 ;ARE WE DONE?
 ;BRANCH IF NO
 ;LAST ADDRESS
 ;INITIALIZE
 ;DONE?
 ;LOOP IF NO
 ;SET ALL DRIVES TO OFFLINE
 ;SETUP THE RH11/RPO4/5/6 VECTOR
 ;FIRST ADDRESS OF RH11 RPO4
 ;MASSBUS INIT

```

012476 005001
012477 004037
012478 000401
012479 000402
012480 105061
012481 005001
012482 042701
012483 001366
012484 012701
012485 005001
012486 105761
012487 001405
012488 004737
012489 005761
012490 001375
012491 005301
012492 100366
012493 012503
012494 104413
012495 000207
012546 010546
012547 105061
012548 105061
012549 105061
012550 105061
012551 010164
012552 112764
012553 032764
012554 001403
012555 004737
012556 000520
012557 105061
012558 032764
012559 001514
012560 004037
012561 000026
012562 013030
012563 012605
012564 112761
012565 022705
012120 012130
012130 012166
000010 000000
010000 000010
000000 000000
004000 000000
017214
000001 012130
020020

```

```

35: CLR R1 ; START WITH DRIVE 0
JSR R0,DRVINT ; INIT THE DRIVE
BR 45 ; 'DVA' NOT SET OR PARITY ERROR
BR 55 ; NORMAL RETURN
45: CLRB DRVSTA(R1) ; SET DRIVE STATUS TO OFFLINE
INC R1 ; GO TO NEXT DRIVE
BIC #107,R1 ; MASK OUT UNUSED BITS
BNE 35 ; BR IF MORE DRIVES TO GO
MOV #7,R1 ; START WITH DRIVE 7
CLR #0,PS ; CLEAR THE PROCESSOR STATUS
TSTB DPINT(R1) ; WAITING FOR DRIVE TO SWITCH PORTS ?
BEQ 65 ; BR NOT WAITING
JSR PC,SET,IE ; SET INTERRUPT
TSTB DPINT(R1) ; DRIVE SWITCHED PORTS ?
BNE 75 ; BR IF NOT
JEC R1 ; GO TO THE NEXT DRIVE
BPL 65 ; CHECK NEXT DRIVE
MOV (SP)+,D#PS ; RESTORE THE PROCESSOR STATUS
RESREG ; RESTORE R0 - R5
RTS PC ; BYE-BYE

```

```

:DRIVE INITIALIZATION ROUTINE
:THIS ROUTINE DETERMINES IF A DRIVE EXIST AND IF IT IS
:AN RPO4/5/6. IF IT IS, A "READ-IN PRESET" IS ISSUED AND FMT22
:IS SET TO A "1". THEN MOL, DPR, DRY, AND VV ARE CHECKED TO
:INSURE THEY ARE ALL ON A "1". AND DEPENDING ON THEIR STATE,
:DRVSTA IS SET TO THE PROPER CONDITION.

```

```

:CALL
MOV #DRVNUM,R1 ; DRIVE NUMBER TO R1
MOV RPADR,R4 ; UNIBUS ADDRESS OF RH11 RPO4/5/6 RPO51
JSR R0,DRVINT ; CALLED BY A JSR
RETURN1 ; ERROR OCCURRED (PARITY)
RETURN2 ; NORMAL RETURN

```

```

DRVINT: MOV R5, -(SP) ; SAVE R5
CLRB DRVSTA(R1) ; START DRIVE STATUS AS OFFLINE
CLRB DRVSTYP(R1) ; CLEAR THE DRIVE TYPE INDICATOR
CLRB ULDFLG(R1) ; CLEAR THE UNLOAD FLAG
MOV R1,RPCS2(R4) ; SELECT A DRIVE
MOV #11,RPCS1(R4) ; DO A DRIVE CLEAR COMMAND (& SEIZE DRIVE)
BIT #BIT12,RPCS2(R4) ; NONEXISTENT DRIVE?
IS ; NO---BRANCH
JSR PC,SET,IE ; GO SET "IE" WITHOUT A "TRE"
BR 65 ; LEAVE THIS ROUTINE
15: CLRB DRVSTA(R1) ; SET DRIVE STATUS TO OFFLINE
BIT #BIT11,RPCS1(R4) ; SEE IF DRIVE AVAILABLE
BEQ 75 ; BR IF DRIVE NOT AVAILABLE
JSR R0,RC,RP ; READ THE DRIVE TYPE REG.
RPT 85 ; ERROR RETURN ADDRESS
MOV (SP)+,R5 ; PRT DRIVE TYPE IN R5
MOV #1,DRVSTYP,R1 ; SET RPO4 INDICATOR
CMP #20020,R5 ; IS IT A SINGLE PORT RPO4?

```

```

012604 001421 BEQ 2$ :BRANCH IF YES
012606 024020 CMP #24020,R5 :IS IT A DUAL PORT RPO4?
012612 001428 BEQ 2$ :BR IF YES
012614 000002 012130 MOVB #2,DRVTP(R1) :SET RPOS INDICATOR
012622 020021 CMP #20021,R5 :SINGLE PORT RPOS ?
012626 001420 BEQ 2$ :BR IF YES
012630 024021 CMP #24021,R5 :DUAL PORT RPOS ?
012634 001415 BEQ 2$ :BR IF YES
012636 112761 000004 012130 MOVB #4,DRVTP(R1) :SET RPO6 INDICATOR
012644 020022 CMP #20022,R5 :SINGLE PORT RPO6 ?
012650 001407 BEQ 2$ :BR IF YES
012652 024022 CMP #24022,R5 :DUAL PORT RPO6 ?
012656 001404 BEQ 2$ :BR IF YES
012660 112761 177777 012130 MOVB #-1,DRVTP(R1) :SET INDICATOR TO 'OTHER'
012666 000446 BR 6$ :EXIT
012670 001274 000121 2$: MOV #121,-(SP) :DO A "READ-IN PRESET"
012674 004037 017374 JSR RO,WRT.RP
012700 000030 RPOS1
012702 013030 BS
012704 001274 010000 MOV #BIT12,-(SP) :SET FMT22=1
012710 004037 017374 JSR RO,WRT.RP
012714 000032 RPOF
012716 013030 BS
012720 004037 017214 JSR RO,RO.RF :READ PPOS1
012724 000012 RPOS1
012726 013030 BS
012730 012605 MOV (SP)+,R5 :AND SAVE IT IN R5
012734 100015 BPL 4$ :BRANCH IF ATA=0
012742 004037 012234 000016 MOVB ATABIT(R1),RPAS(R4) :CLEAR ATTENTION BIT
012746 000014 JSR RO,RO.RP :FIND OUT WHY ATA=1
012750 013030 RPER1
012752 006126 BS
012754 100004 ROL (SP)+ :IS IT UNSAFE?
012756 112761 177777 012120 BPL 4$ :BR IF NOT
012764 000407 MOVB #-1,DRVSTA(R1) :SET UNSAFE INDICATOR
012766 005105 BR 6$ :EXIT
012770 042705 167077 4$: COM R5 :CHECK MOL, DPR, DRY, AND VV
012774 001003 BIC #0<BIT12:BIT08:BIT07:BIT06>,R5 :BRANCH IF MOL, DPR, DRY, OR VV IS CLEAR
012776 112761 000001 012120 MOVB #1,DRVSTA(R1) :SET DRIVE STATUS TO ONLINE
013004 005720 6$: TST (R0)+ :STEP OVER THE ERROR RETURN
013006 000410 BR 8$ :EXIT
013010 006301 7$: ASL R1 :CHANGE INDEX TO ADDRESS WORDS
013012 012761 003720 012212 MOV #2000.,TIMER(R1) :START 2 SEC TIMER
013020 006201 ASR R1 :RESTORE R1
013022 112761 177777 012140 MOVB #-1,DPINT(R1) :SET PORT INITIALIZE INDICATOR
013030 012605 8$: MOV (SP)+,R5 :RESTORE R5
013032 000200 RTS RO :EXIT

:REQUEST PRE-PROCESSOR-HANDLES SUBSYSTEM REQUEST
:CALL
: JSR RO,3#RPO4 :CALL THE RPO4.5.6 DRIVER

```

```

: PNTADR : ADDRESS OF POINTER OF DRIVES PARAMETER BLOCK
: RETURN1 : RETURN HERE IF QUEUE IS FULL
: RETURN2 : RETURN HERE IF REQUEST IS IN QUEUE OR THERE
: IS AN ERROR CONDITION

RPC4:  MOV 2#FS - SP) : SAVE THE CALLING STATUS
      MOV RPVEC+2,2#FS : DON'T ALLOW ANY RPC4/5/6 INTERRUPTS
      MOVB #1,ACTDRV : SET "ACTIVE DRIVER" FLAG
      SAVREG : SAVE R0 - R5
      MOV (R0),R2 : PICKUP THE DRIVE PARAMETER BLOCK POINTER
      CLR 16(R2) : CLEAR THE STATUS/ERROR INDICATOR
      MOVB (R2),R1 : PICKUP THE DRIVE NUMBER
      MOV RPADR,R4 : UNIBUS ADDRESS OF RPCS1
      TSTB DRVSTA(R1) : CHECK DRIVES STATUS
      BGT 1$ : BRANCH IF ONLINE
      TSTB UNLDFLG(R1) : UNLOAD COMMAND IN QUEUE?
      BNE 3$ : BRANCH IF YES
      TSTB OPINT(R1) : TRYING TO INIT THE DRIVE
      BNE 5$ : BR IF YES
      JSR R0,DRVINT : GO INIT. THE DRIVE
      BR 4$ : ERROR RETURN
      TSTB DRVSTA(R1) : IS DRIVE STATUS ONLINE?
      BLE 6$ : BR IF NOT
      TSTB DPRQS(R1) : OUTSTANDING PORT REQUEST FOR THE DRIVE
      BNE 5$ : BR IF YES
      MOV R1,RPCS2(R4) : SELECT THE DRIVE
      JSR R0,DRVQUE : PUT THIS REQUEST IN QUEUE
      BR 9$ : QUEUE IS FULL
      CMPB #103,2(R2) : IS THIS REQ. FOR AN UNLOAD?
      BNE 2$ : BR IF NO
      MOVB #-1,UNLDFLG(R1) : SET THE "UNLOAD IN QUEUE" FLAG
      TSTB DRVACT(R1) : IS THIS DRIVE ACTIVE?
      BNE 8$ : BR IF YES
      JSR PC,OPT : CALL THE OPTIMIZER
      BR 8$
      MOV #BIT15!BIT13,16(R2) : SET THE "UNLOAD IN QUEUE" ERROR FLAG
      BR 8$ : EXIT
      JSR PC,OPT : GO HANDLE THE PARITY ERROR
      BR 8$
      JSR R0,DRVQUE : PUT REQUEST IN QUEUE
      BR 9$ : QUEUE IS FULL
      BIT #BIT06,(R4) : IS "IE" SET ALREADY?
      BNE 8$ : BR IF IT IS
      JSR PC,SET,IE : SET INTERRUPT
      BR 8$ : RETURN, REQUEST IN QUEUE
      TSTB DRVSTA(R1) : SEE IF DRIVE OFFLINE OR UNSAFE
      BLT 7$ : BR IF UNSAFE
      MOV #BIT15!BIT14,16(R2) : SET OFFLINE ERROR INDICATOR
      TSTB DRV*P(R1) : SEE IF OFFLINE OR NONEXISTENT
      BNE 8$ : BR IF OFFLINE
      MOV #BIT15!BIT01,16(R2) : REPORT DRIVE NONEXISTENT
      BR 8$ : GO TO EXIT
      MOV #BIT15!BIT12,16(R2) : DRIVE IS UNSAFE
      RESREG : RES*URE R0 - R5

```

```

001 013304 005720          TST      (R0 +          :SETUP FOR NORMAL RETURN
002 013306 000401          BR       10$          :FINISH UP THEN EXIT
003 013310 104413          9$: RESREG          :RESTORE R0 - R5
004 013312 005720          10$: TST      (R0)+    :CORRECT THE RETURN ADDRESS
005 013314 105037 012164  CLAB     ACTDRV     :CLEAR "ACTIVE DRIVER" FLAG
006 013320 012527 177776  MOV     (SP)+,0#PS   :RETURN "PS" TO USER LEVEL
007 013324 000200          RTS      RC          :RETURN TO CALLER

:OPTIMIZER-CALLED FOR A PARTICULAR DRIVE
:CALL
:MOV     #DRVNUM,R1    :DRIVE NUMBER TO R1
:JSR    PC,OPT        :SETUP A COMMAND

OPT: SAVREG          :SAVE R0 - R5
MOV     0#PS,-(SP)    :SAVE PROC. STATUS
BITCB   ATABIT(R1),SRCHWT :CLEAR "SEARCH WAIT" KEY
JSR     PC,GETREQ    :GET "DPA" POINTER OF REQUEST
TST     R2           :IS THERE A REQUEST IN QUEUE?
BEQ     7$          :NO--BRANCH TO EXIT
BIT     #BIT12,RPOS1(R4) :IS MOL STILL SET?
BEQ     9$          :BR IF NOT
BIT     #BIT6,RPOS1(R4) :IS VV SET?
BNE     10$         :BR IF IT IS
9$: JSR     RD,DRVINT :SEE IF DRIVE STILL ONLINE?
BR      6$          :PARITY OR 'DVA' NOT SET
10$: TSTB   DRVSTA(R1) :IS DRIVE ONLINE?
BGT     1$          :YES--BRANCH
JSR     PC,POPQUE    :NO--REMOVE REQUEST FROM QUEUE
MOV     #BIT15!BIT14,16(R2) :SET OFFLINE STATUS ERROR INDICATOR
TSTB   DRVSTA(R1)   :IS DRIVE UNSAFE?
BPL     8$          :BR TO EXIT IF NOT
MOV     #BIT15!BIT12,16(R2) :SET UNSAFE STATUS ERROR INDICATOR
BR      9$          :BRANCH TO EXIT
1$: MOV     #111,-(SP) :LOAD COMMAND ONTO THE STACK
JSR     RD,WRT,RP    :LOAD THE REGISTER
RPOCS1 :REGISTER INCREMENT
6$:      :ERROR RETURN ADDRESS
BIT     #BIT11,(R4)  :DRIVE AVAILABLE?
BEQ     5$          :BR IF NOT
CMPB   #150,2(R2)   :IS THE REQUEST FOR I/O?
BLT     2$          :YES--BRANCH
JSR     PC,C14      :CALL THE COMMAND INITIATOR
BR      8$          :BRANCH TO EXIT
2$: TST     DTUW     :DATA TRANSFER UNDERWAY?
BGE     4$          :YES--GO START A SEARCH
TST     SEEKFG     :DO IMPLIED SEEKS?
BMI     3$          :YES---BRANCH
JSR     RD,LA      :NO--DO LOOK AHEAD
BR      8$          :RETURN HERE ON A PARITY ERROR
BR      4$          :GO START A SEARCH
3$: JSR     PC,C11   :START A DATA TRANSFER
BR      8$
4$: JSR     PC,C13   :START A SEARCH

```

```

2955 013534 000420 BR BS ;GO TO THE EXIT
2956 013536 112761 177777 012150 5S: MOVB #-1,DPRES(R1) ;SET PORT REQUEST INDICATOR
2957 013544 010103 MOV R1,R3 ;SET UP TO ADDRESS WORDS
2958 013546 006303 ASL R3 ;CONVERT TO WORD INDEX
2959 013550 012763 023420 012212 MOV #10000.,TIMER(R3) ;START 10 SEC TIMER
2960 013556 000402 BR 7S ;EXIT
2961 013560 004737 014436 6S: JSR PC,C17 ;PROCESS THE PARITY ERROR
2962 013564 032714 000100 7S: BIT #BIT06,(R4) ;SEE IF 'IE' ALREADY SET
2963 013570 001002 BNE BS ;BR IF SET
2964 013572 004737 017704 JSR PC,SET.IE ;SET "IE" WITHOUT A "TRE"
2965 013576 012637 177776 8S: MOV (SP)+,A#PS ;RESTORE PROC. STATUS
2966 013602 104413 RESREG ;RESTORE R0 - R5
2967 013604 000207 RTS PC

:COMMAND INITIATOR
:CALL
:MOV #DRVNUM,R1 ;DRIVE NUMBER
:MOV #DPB,R2 ;ADDRESS OF DPB
:JSR PC,C17 ;C17= C11,C13, OR C14
:WHERE:
:C11=DATA TRANSFER
:C12=SEARCH REQUESTED BY DATA XFER
:C14=NOT DATA TRANSFER

2980 013606 004737 020444 C11: JSR PC,POPQUE ;REMOVE REQUEST FROM "DRIVES WAIT" QUEUE
2981 013612 010237 012160 MOV R2,TRANSW ;PUT REQ. IN TRANSFER WAIT QUEUE
2982 013616 010203 MOV R2,R3 ;DPB ADDRESS TO R3
2983 013620 013704 012246 MOV RPADR,R4 ;RPCS1 ADDRESS
2984 013624 010164 000010 MOV R1,RPCS2(R4) ;SELECT DRIVE
2985 013630 062703 000004 ADD #4,R3 ;DESIRED WORD COUNT
2986 013634 062704 000002 ADD #2,R4 ;RPWC ADDRESS
2987 013640 012324 MOV (R3)+(R4)+ ;LOAD WORD COUNT
2988 013642 012324 MOV (R3)+(R4)+ ;LOAD BUFFER ADDRESS
2989 013644 012346 MOV (R3)+-(SP) ;LOAD SECTOR AND TRACK
2990 013646 004037 017374 JSR R0,WRT.RP ;CALL THE LOAD(WRITE) ROUTINE
2991 013652 000006 RPOA ;INDEX OF REGISTER TO LOAD
2992 013654 014436 C17 ;ERROR RETURN ADDRESS
2993 013656 012346 MOV (R3)+-(SP) ;LOAD CYLINDER ADDRESS
2994 013660 004037 017374 JSR R0,WRT.RP
2995 013664 000034 RPOA
2996 013666 014436 C17
2997 013670 016246 000002 MOV 2(R2)-(SP) ;LOAD "COMMAND+30", "A173A16", AND "FSEL"
2998 013674 004037 017374 JSR R0,WRT.RP
2999 013700 000000 RPCS:
3000 013702 014436 C17
3001 013704 010137 012232 MOV R1,CTJW ;SET "DATA TRANSFER UNDERWAY"
3002 013710 000137 014400 JMP C15
3003 013714 013704 012246 C13: MOV RPADR,R4 ;RPCS1 ADDRESS
3004 013720 010164 000010 MOV R1,RPCS2(R4) ;SELECT DRIVE
3005 013724 016246 000012 MOV 12(R2)-(SP) ;DESIRED CYLINDER ADDRESS
3006 013730 004037 017374 JSR R0,WRT.RP
3007 013734 000034 RPOA
3008 013736 014436 C17

```

```

3009 013740 116203 000010      MOVB      10(R2),R3      ;PICKUP SECTOR ADDRESS
3010 013744 163703 012262      SUB       MXWINDW,R3    ;BACKUP BY MAX. SEARCH FOR I-C WINDOW
3011 013750 002002      BGE      1$            ;
3012 013752 062703 000026      ADD      #22,R3        ;
3013 013756 010346      MOV      R3,-(SP)      ;COMBINE THE ADJUSTED SECTOR WITH
3014 013760 116266 000011 000001 1$:      MOVB     11(R2),1(SP)   ;THE DESIRED TRACK
3015 013766 004037 017374      JSR      RC,WRT.RP     ;LOAD DESIRED TRACK & SECTOR
3016 013772 000006      RPOA
3017 013774 014436      CI7
3018 013776 012746 000131      MOV      #131,-(SP)    ;START A SEARCH
3019 014002 004037 017374      JSR      RC,WRT.RP
3020 014006 000000      RPOA
3021 014010 014436      CI7
3022 014012 156137 012234 012152  BITB     ATABIT(R1),SRCHWT ;SET "SEARCH WAIT" KEY
3023 014020 000567      BR      C15
3024 014022 013704 012246 014:      MOV      RPOA,R4      ;RPOA ADDRESS
3025 014026 010164 000010      MOV      R1,RPOA2(R4) ;SELECT DRIVE
3026 014032 116203 000002      MOVB     2(R2),R3      ;PICKUP THE REQUESTED COMMAND
3027 014036 122703 000131      CMPB     #131,R3       ;IS IT A SEARCH COMMAND?
3028 014042 001007      BNE      1$           ;BRANCH IF NO
3029 014044 016246 000010      MOV      10(R2),-(SP)  ;LOAD DESIRED TRACK & SECTOR
3030 014050 004037 017374      JSR      RC,WRT.RP
3031 014054 000006      RPOA
3032 014056 014436      CI7
3033 014060 000403      BR      2$
3034 014062 122703 000105 1$:      CMPB     #105,R3       ;GO LOAD CYLINDER
3035 014066 001007      BNE      3$           ;IS IT A SEEK COMMAND
3036 014070 016246 000012 2$:      MOV      12(R2),-(SP)  ;BRANCH IF NO
3037 014074 004037 017374      JSR      RC,WRT.RP     ;LOAD DESIRED CYLINDER
3038 014100 000034      RPOA
3039 014102 014436      CI7
3040 014104 000546      BR      C16
3041 014106 122703 000115 3$:      CMPB     #115,R3       ;IS IT AN "OFFSET" COMMAND?
3042 014112 001013      BNE      4$           ;BR IF NO
3043 014114 004037 017214      JSR      RC,RC.RP      ;MERGE THE OFFSET VALUE INTO RPOA
3044 014120 000032      RPOF     ;BUT DON'T CHANGE THE UPPER
3045 014122 014436      CI7
3046 014124 116216 000001      MOVB     1(R2),-(SP)   ;BYTE WHEN LOADING THE
3047 014130 004037 017374      JSR      RC,WRT.RP     ;REGISTER (RPOF)
3048 014134 000032      RPOF
3049 014136 014436      CI7
3050 014140 000530      BR      C16
3051 014142 122703 000107 4$:      CMPB     #107,R3       ;GO START THE COMMAND
3052 014146 001525      BEQ      C16          ;IS IT A "RECALIBRATE" COMMAND?
3053 014150 122703 000117      CMPB     #117,R3       ;BRANCH IF YES
3054 014154 001522      BEQ      C16          ;IS IT A RETURN TO CENTER?
3055 014156 122703 000103      CMPB     #103,R3       ;BRANCH IF YES
3056 014162 001016      BNE      5$           ;IS IT AN "UNLOAD" COMMAND?
3057 014164 112761 000001 012110 5$:      MOVB     #1,DRVACT(R1) ;SET THE DRIVE ACTIVE INDICATOR
3058 014172 105061 012120      CLRB     DRVSTA(R1)    ;PUT DRIVE STATUS TO OFFLINE
3059 014176 112761 000001 012166      MOVB     #1,ULDFLG(R1) ;SET "UNLOAD IN PROGRESS" FLAG
3060 014204 010346      MOV      R3,-(SP)     ;START THE "UNLOAD" COMMAND
3061 014206 004037 017374      JSR      RC,WRT.RP
3062 014212 000000      RPOA

```

H06

3063	014214	014436				C17			
3064	014216	000207				RTS	PC		:RETURN TO USER
3065	014220	122703	000143		55:	CMPB	#143,R3		:IS IT A "SET FORMAT" COMMAND?
3066	014224	001014				BNE	65		:BRANCH IF NO
3067	014226	004037	017214			JSR	RO,RO.RP		:READ THE OFFSET REGISTER
3068	014232	000032				RPOF			
3069	014234	014436				C17			
3070	014236	116266	000001	000001		MOVB	1(R2),1(SP)		:COMBINE "FMT22" "ECI" AND "HCI"
3071	014244	004037	017374			JSR	RO,WRT.RP		:LOAD "FMT22", "ECI", AND/OR "HCI".
3072	014250	000032				RPOF			
3073	014252	014436				C17			
3074	014254	000436				BR	125		
3075	014256	122703	000141		65:	CMPB	#141,R3		:IS IT A "GET REGISTER" COMMAND?
3076	014262	001023				BNE	105		:BRANCH IF NO
3077	014264	016203	000006		75:	MOV	6(R2),R3		:POINTS TO 1ST ADDRESS OF WHERE
3078									:TO PUT THE REGISTER(S)
3079	014270	116237	000010	014306		MOVB	10(R2),95		:INIT. THE INDEX FOR THE FIRST REG
3080	014276	116205	000011			MOVB	11(R2),R5		:INDEX OF LAST REG. TO MOVE
3081	014302	004037	017214		95:	JSR	RO,RO.RP		:READ RPO4/5/6 REGISTER
3082	014306	000000			95:	RPCS1			:INDEX OF REG. TO READ
3083	014310	014436				C17			
3084	014312	012623				MOV	(SP)+,(R3)+		:GET THE CONTENTS OF RH11 RPO4 5 6 REG.
3085	014314	023705	014306			CMP	95,R5		:LAST REG. BEEN READ?
3086	014320	001414				BEQ	125		:GET OUT IF YES
3087	014322	062737	000002	014306		ADD	#2,95		:INCREASE THE INDEX BY 2
3088	014330	000764				BR	85		:LOOP--MORE TO READ
3089	014332	122703	000145		105:	CMPB	#145,R3		:IS IT A "SELECT DRIVE" COMMAND?
3090	014336	001405				BEQ	125		:BRANCH IF YES
3091	014340	010346			115:	MOV	R3,-(SP)		:LOAD THE COMMAND
3092	014342	004037	017374			JSR	RO,WRT.RP		
3093	014346	000000				RPCS1			
3094	014350	014436				C17			
3095	014352	004737	020444		125:	JSR	PC,POPQUE		:REMOVE REG. FROM QUEUE
3096	014356	052762	000200	000016		BIT	#BIT07,16(R2)		:SET THE "DONE" BIT
3097	014364	005737	012206			TST	SAVEFG		:SAVE THE RH11/RPO4/5/6 REGISTERS
3098	014370	100002				BPL	135		:BRANCH IF NO
3099	014372	004737	017566			JSR	PC,SVRH11		:YES--GO SAVE THE REGISTERS
3100	014376	000207			135:	RTS	PC		:RETURN TO USER
3101	014400	006301			C15:	ASL	R1		
3102	014402	012761	001750	012212		MOV	#1000.,TIMER(R1)		:SET A ONE SECOND TIMER
3103	014410	006201				ASR	R1		
3104	014412	012761	000001	012110		MOVB	#1,DRVACT(R1)		:SET THE DRIVE ACTIVE
3105	014420	000207				RTS	PC		:RETURN TO THE USER
3106	014422	010346			C16:	MOV	R3,-(SP)		:LOAD THE COMMAND
3107	014424	004037	017374			JSR	RO,WRT.RP		
3108	014430	000000				RPCS1			
3109	014432	014436				C17			
3110	014434	000761				BR	C15		
3111	014436	032764	010000	000010	C17:	BIT	#BIT12,RPCS2(R4)		:DRIVE NON-EXISTENT "
3112	014444	001034				BNE	C18		:BR IF YES
3113	014446	005702			15:	TST	R2		:ANYTHING IN QUEUE "
3114	014450	001405				BEQ	C17B		:BR IF NOT
3115	014452	012762	104000	000016		MOV	#BIT15:BIT11,16(R2)		:SET "PARITY" ERROR INDICATOR
3116	014460	004737	017566			JSR	PC,SVRH11		:GO SAVE THE RH11 RPO4 5 6 REGISTERS

```

3117 014464 012746 000111          C17B: MOV      #111, -(SP)      ;DO A "DRIVE CLEAR"
3119 014470 004037 017374          JSR      RO, WRT.RP
3119 014474 000000          RPCS1
3120 014476 014536          C18      C18
3121 014500 004737 020326          JSR      PC, EMPTYQ      ;EMPTY THE QUEUE
3122 014504 105061 012166          CLRB    ULDFLG(R1)      ;CLEAR THE UNLOAD IN QUEUE FLAG
3123 014510 105061 012110          CLRB    DRVACT(R1)     ;DRIVE IS IDLE
3124 014514 020137 012232          CMP     R1, DTUW      ;IF THIS DRIVE HAD AN I/O REQUEST
3125 014520 001005          BNE     1$           ;IN PROGRESS CLEAR ALL OF THE FLAGS
3126 014522 005037 012160          CLR     TRNSWT
3127 014526 012737 177777 012232          MOV     #-1, DTJW
3128 014534 000207          RTS
3129 014536 104412          C18:    SAVREG      ;SAVE R0 - R5
3130 014540 032764 010000 000010          BIT     #BIT12, RPCS2(R4) ;IS 'NED' SET ?
3131 014546 001002          BNE     1$           ;BR IF YES
3132 014550 005001          CLR     R1
3133 014552 005003          CLR     R3
3134 014554 105761 012110          1$:    TSTB    DRVACT(R1) ;DRIVE ACTIVE?
3135 014560 001443          BEQ     5$           ;BRANCH IF NO
3136 014562 013702 012160          MOV     TRNSWT, R2     ;GET THE "TRANSFER WAIT" QUEUE
3137 014566 020137 012232          CMP     R1, DTJW      ;DID THIS DRIVE HAVE AN I/O IN PROGRESS?
3138 014572 001402          BEQ     2$           ;BRANCH IF YES
3139 014574 004737 020422          JSR      PC, GETREQ    ;GET THE DPB POINTER
3140 014600 005702          2$:    TST     R2         ;QUEUE ENTRY FOR DRIVE ?
3141 014602 001415          BEQ     4$           ;BR IF NOT
3142 014604 032764 010000 000010          BIT     #BIT12, RPCS2(R4) ;'NED' SET ?
3143 014612 001404          BEQ     3$           ;BR IF NOT
3144 014614 012762 100002 000016          MOV     #BIT15!BIT01, 16(R2) ;SET 'DRIVE NON-EXISTENT' INDICATOR
3145 014622 000405          BR     4$           ;CONTINUE
3146 014624 012762 102000 000016          3$:    MOV     #BIT15!BIT10, 16(R2) ;SET "NON-CLEARABLE PARITY" ERROR INDICATOR
3147 014632 004737 017566          JSR      PC, SVRH11    ;SAVE RH11/RPO4/5/6 REGISTERS
3148 014636 012763 177777 012212          4$:    MOV     #-1, TIMER, R3 ;STOP THE TIMER
3149 014644 105061 012110          CLRB    DRVACT(R1)    ;SET "DRIVE ACTIVE" TO IDLE
3150 014650 020137 012232          CMP     R1, DTUW      ;IS THIS DRIVE SETUP FOR A TRANSFER
3151 014654 001005          BNE     5$           ;BR IF NOT
3152 014656 012737 177777 012232          MOV     #-1, DTUW     ;RESET THE INDICATOR
3153 014664 005037 012160          CLR     TRNSWT        ;CLEAR THE TRANSFER QUEUE
3154 014670 105061 012166          5$:    CLRB    ULDFLG(R1)  ;CLEAR UNLOAD FLAG
3155 014674 032764 010000 000010          BIT     #BIT12, RPCS2(R4) ;'NED' SET ?
3156 014702 001021          BNE     6$           ;BR IF YES
3157 014704 005201          INC     R1            ;MOVE TO THE NEXT DRIVE
3158 014706 062703 000002          ADD     #2, R3
3159 014712 042701 177770          BIC     #107, R1
3160 014716 001316          BNE     1$           ;BRANCH IF MORE DRIVES
3161 014720 012737 177777 012232          MOV     #-1, DTJW    ;NO DATA TRANSFERS UNDERWAY
3162 014726 005037 012160          CLR     TRNSWT        ;CLEAR THE 'TRANSFER WAIT' QUEUE
3163 014732 004737 020250          JSR      PC, CLRQUE    ;CLEAR ALL OF THE REQUEST QUEUES
3164 014736 012764 000040 000010          MOV     #BIT05, RPCS2(R4) ;DO A MASSBUS INIT.
3165 014744 000406          BR     7$           ;CONTINUE
3166 014746 004737 020326          6$:    JSR      PC, EMPTYQ ;CLEAR THE DRIVE'S QUEUE
3167 014752 105061 012120          CLRB    DRVSTA(R1)    ;SET DRIVE TO OFFLINE
3168 014756 105061 012130          CLRB    DRVTP(R1)    ;CLEAR THE DRIVE TYPE INDICATOR
3169 014762 004737 017704          7$:    JSR      PC, SET.IE ;SET "IE" WITHOUT "TRE"
3170 014766 104412          RESREG      ;RESTORE R0 - R5
    
```

```

3171 014770 000207          RTS      PC      ;RETURN
3172
3173          ;LOOK AHEAD ROUTINE
3174          ;CALL
3175          ;MOV      #DRVNUM,R1      ;DRIVE NUMBER
3176          ;MOV      #DPB,R2        ;POINT TO DPB
3177          ;JSR      RD,LA          ;GO CHECK THE WINDOW
3178          ;RETURN1      ;ERROR RETURN
3179          ;RETURN2      ;START A SEARCH
3180          ;RETURN3      ;START A DATA TRANSFER
3181
3182
3183 014772 013704 012246 LA:      MOV      RPADR,R4      ;GET RPCS1'S ADDRESS
3184 014776 010164 000010      MOV      R1,RPCS2(R4) ;SELECT DRIVE
3185 015002 004037 017214      JSR      RD,RD.RP      ;READ CURRENT CYLINDER
3186 015006 000036          RPCC
3187 015010 015122          4$
3188 015012 022662 000012      CMP      (SP)+,12(R2) ;ERROR RETURN ADDRESS
3189          ;IS CURRENT CYLINDER=DESIRED
3190          ;CYLINDER?
3191 015016 001037          BNE      3$           ;EXIT IF NO
3192 015020 105261 012176      INCB     LACNT(R1)    ;INCREMENT THE LOOK AHEAD COUNT
3193 015024 126137 012176 012254      CMPB    LACNT(R1),MXLACT ;EXCEED MAX?
3194 015032 003026          BGT      2$           ;BRANCH IF YES
3195 015034 116203 000010      MOVB    10(R2),R3    ;GET DESIRED SECTOR ADDRESS AND
3196 015040 000303          SWAB    R3           ;MULT. BY 64--ALIGN WITH
3197 015042 006203          ASR     R3           ;LOOK AHEAD REGISTER
3198 015044 006203          ASR     R3
3199 015046 012737 000340 177776      MOV     #340,2*PS    ;PRIORITY LEVEL "7"
3200 015054 004037 017214      JSR     RD,RD.RP      ;READ LOOK AHEAD REGISTER
3201 015060 000020          RPLA
3202 015062 015122          4$
3203 015064 162603          SUB     (SP)+,R3     ;CALCULATE THE DELTA
3204 015066 002002          BGE     1$           ;MAKE THE DELTA POSITIVE
3205 015070 062703 002600      ADD     #(<22.*64.>,R3 ;CHECK THE DELTA TO SEE
3206 015074 023703 012256      CMP     MXDLTA,R3    ;IF IT IS WITHIN THE
3207 015100 002406          BLT     3$           ;WINDOW---IF YES, ZERO
3208 015102 023703 012260      CMP     MNDLTA,R3   ;THE LOOK AHEAD COUNT
3209 015106 002003          BGE     3$           ;AND TAKE THE I/O EXIT
3210 015110 105061 012176      CLRB   LACNT(R1)
3211 015114 005720          TST    (R0)+
3212 015116 005720          3$:    TST    (R0)+      ;ADJUST THE RETURN ADDRESS
3213 015120 000402          BR     5$           ;EXIT
3214 015122 004737 014436      4$:    JSR    PC,C17    ;PROCESS THE ERROR
3215 015126 000200          5$:    RTS     RD      ;RETURN
3216
3217          ;INTERRUPT SERVICE ROUTINE
3218 015130 112737 000001 012164 ISR:   MOVB    #1,ACTDRV    ;SET "ACTIVE DRIVER" FLAG
3219 015136 104412          SAVREG ;SAVE R0 - R5
3220 015140 013704 012246      MOV     RPADR,R4    ;ADDRESS OF RHSCS1
3221 015144 013701 012232      MOV     DTUW,R1     ;GET "DATA TRANSFER UNDERWAY" INDICATOR
3222 015150 002403          BLT     1$           ;BRANCH IF NO DATA TRANSFER UNDERWAY
3223 015152 004737 015174      JSR     PC,TD       ;CALL TRANSFER DONE
3224 015156 000402          BR     2$           ;EXIT

```

```

3225 015160 004737 015334 1$: JSR PC,SC ;CALL SPECIAL CONDITIONS
3226 015164 104413 2$: RESREG ;RESTORE R0 - R5
3227 015166 105037 012164 CLR B ACTDRV ;CLEAR "ACTIVE DRIVER" FLAG
3228 015172 000002 RTI ;RETURN
3229
3230 ;TRANSFER DONE ROUTINE
3231
3232 015174 105061 012110 TD: CLR B DRVACT(R1) ;SET DRIVE ACTIVE INDICATOR TO IDLE
3233 015200 012737 177777 012232 MOV #-1,DTUW ;NO DATA TRANSFERS UNDERWAY
3234 015206 006301 ASL R1
3235 015210 012761 177777 012212 MOV #-1,TIMER(R1) ;CANCEL TIMEOUT
3236 015216 006201 ASR R1
3237 015220 013702 012160 MOV TRANSW,R2 ;GET "DPB" ADDRESS FROM THE
3238 015224 005037 012160 CLR TRANSW ;TRANSFER WAIT QUEUE--CLEAR QUEUE
3239 015230 052762 000200 000016 BIS #BIT07,16(R2) ;SET DONE
3240 015236 010164 000010 MOV R1,RPCS2(R4) ;SELECT THE DRIVE
3241 015242 004037 017214 JSR RD,RD.RP ;TRANSFER ERROR(TRE=1)?
3242 015246 000000 RPCS1
3243 015250 014436 CIB
3244 015252 006126 ROL (SP)+
3245 015254 100413 BMI 3$ ;BR IF YES
3246 015256 005737 012206 TST SAVEFG ;SAVE THE RH11/RPO4/5/6 REGISTERS?
3247 015262 100002 BPL 1$ ;BRANCH IF NO
3248 015264 004737 017566 JSR PC,SVRH11 ;YES--SAVE THE REGISTERS
3249 015270 004737 013326 1$: JSR PC,OPT ;CALL OPTIMIZER
3250 015274 000417 BR SC ;CHECK OTHER DRIVES
3251 015276 012714 000113 2$: MOV #113,(R4) ;RELEASE THE DRIVE
3252 015302 000414 BR SC ;CHECK FOR OTHER DRIVES
3253 015304 052762 100100 000016 3$: BIS #BIT15:BIT06,16(R2) ;SET DATA ERROR FLAG
3254 015312 004737 020326 JSR PC,EMPTYQ ;EMPTY THE "DRIVE'S WAIT" QUEUE
3255 015316 004737 017566 JSR PC,SVRH11 ;SAVE THE RH11/RPO4/5/6 REGISTERS
3256 015322 012714 040111 MOV #40111,(R4) ;ISSUE A "DRIVE CLEAR"
3257 015326 012714 000113 MOV #113,(R4) ;ISSUE A RELEASE TO THE DRIVE
3258 015332 000400 BR SC ;CHECK FOR OTHER DRIVES
3259
3260 ;SPECIAL CONDITION ROUTINE
3261
3262 015334 116403 000016 SC: MOV B RPAS(R4),R3 ;READ "RPAS"
3263 015340 001014 BNE 2$ ;BRANCH IF ANY 'ATA' BITS SET
3264 015342 004037 017214 JSR RD,RD.RP ;READ CONTROL AND STATUS REGISTER
3265 015346 000000 RPCS1
3266 015350 014536 CIB
3267 015352 106126 ROL B (SP)+ ;IS "IE"=1?
3268 015354 100405 BMI 1$ ;YES, NO DRIVES TO CHECK
3269 015356 004037 020506 JSR RD,ES.SAV ;SAVE THE ADDRESS IN 'ESCAPE'
3270 015362 104001 ERROR 1 ;REPORT AN ILLEGAL INTERRUPT
3271 015364 004737 017704 JSR PC,SET.IE ;SET INTERRUPT ENABLE
3272 015370 000207 1$: RTS PC ;RETURN
3273 015372 005046 2$: CLR -(SP) ;PROCESS ALL DRIVES THAT HAVE
3274 015374 110316 MOV B R3,(SP) ;AN "ATA"=1
3275 015376 012703 000001 MOV #1,R3
3276 015402 005001 CLR R1
3277 015404 030316 SC3: BIT R3,(SP) ;ATA=1?
3278 015406 001005 BNE SC5 ;YES--BRANCH

```

```

3279 015410 005201          SC4:  INC      R1          ;MOVE TO THE NEXT DRIVE
3280 015412 106303          ASLB     R3
3281 015414 001373          BNE     SC3          ;BRANCH IF MORE TO CHECK?
3282 015416 005726          TST     (SP)+       ;CLEAN OFF THE STACK
3283 015420 000207          RTS     PC          ;RETJRN TO USER
3284 015422 105761 012140        SC5:  TSTB    DPINT(R1)   ;INITIALIZING THE DRIVE ?
3285 015426 001402          BEQ     1$          ;BR IF NOT
3286 015430 000137 016326        JMP     SC13        ;PROCESS THE DRIVE
3287 015434 105761 012150        1$:  TSTB    DPRQS(R1)  ;PORT REQUEST OUTSTANDING ?
3288 015440 001402          BEQ     2$          ;BR IF NOT
3289 015442 000137 016326        JMP     SC13        ;START THE OUTSTANDING COMMAND
3290 015446 105761 012120        2$:  TSTB    DRVSTA(R1) ;CHECK THE DRIVE STATUS
3291 015452 003025          BGT     5$          ;BRANCH IF ONLINE
3292 015454 105761 012166        TSTB    ULDFLG(R1) ;UNLOAD IN PROGRESS?
3293 015460 003422          BLE     5$          ;BRANCH IF NOT
3294 015462 004737 020422        JSR     PC,GETREQ   ;GET DPB POINTER
3295 015466 004737 017566        JSR     PC,SVRH11  ;SAVE THE RH11/RPO4/5/6 REGISTERS
3296 015472 004737 016256        JSR     PC,SC12    ;SAVE RPO51, RPER1, RPER2, AND RPER3
3297                                     ;ALSO DO A DRIVE INIT (DRVINT)
3298 015476 105761 012120        TSTB    DRVSTA(R1) ;DID DRIVE COME ONLINE?
3299 015502 003416          BLE     6$          ;NO---BRANCH
3300 015504 032737 040000 012100        BIT     #BIT14,RPERRS ;WAS THERE AN ERROR?
3301 015512 001002          BNE     3$          ;BR IF ERROR
3302 015514 000137 016166        JMP     SC11        ;NO ERROR
3303 015520 013705 012102        3$:  MOV     RPERRS+2,R5 ;YES -- PICKUP RPER1 AND
3304 015524 000502          BR     SC6A        ;GO PROCESS THE ERROR
3305 015526 105761 012110        5$:  TSTB    DRVACT(R1) ;DRIVE ACTIVE WITH COMMAND OR ERROR RECOVERY ?
3306 015532 001033          BNE     SC6        ;BR IF EITHER
3307 015534 004737 016256        JSR     PC,SC12    ;SAVE RPO51, RPER1, RPER2, AND RPER3
3308                                     ;ALSO DO A DRVINT
3309 015540 105761 012140        6$:  TSTB    DPINT(R1)   ;TRYING TO INIT THE DRIVE ?
3310 015544 001321          BNE     SC4        ;BR IF YES, CHECK ON MORE DRIVES
3311 015546 105761 012120        TSTB    DRVSTA(R1) ;CHECK ON DRIVE'S STATUS
3312 015552 100412          BMI     7$          ;BR IF UNSAFE
3313 015554 032737 020000 012106        BIT     #BIT13,RPERRS+6 ;ADDRESS PLUG CHANGED ?
3314 015562 001013          BNE     8$          ;BR IF YES
3315 015564 012746 000113        MOV     #113,-(SP) ;RELEASE COMMAND
3316 015570 004037 017374        JSR     RO,WRT.RP  ;WRITE THE COMMAND INTO RPO51
3317 015574 000000          RPO51
3318 015576 016136          SC8
3319 015600 011605          7$:  MOV     (SP),R5    ;PARITY EXIT ADDRESS
3320 015602 004037 020506        JSR     RO,ES.SAV  ;PICKUP (RPAS) BEFORE THE ERROR CALL
3321 015606 104002          ERROR  2          ;SAVE THE ADDRESS IN '$ESCAPE'
3322 015610 000677          BR     SC4         ;REPORT THE UNEXPECTED ATTENTION
3323 015612                                     ;GO CHECK FOR MORE ATA'S
3324 015612 004037 020506        8$:  JSR     RO,ES.SAV  ;SAVE THE ADDRESS IN '$ESCAPE'
3325 015616 104005          ERROR  5          ;REPORT THE ADDRESS PLUG CHANGE
3326 015620 000673          BR     SC4        ;CHECK FOR MORE DRIVES
3327 015622 006301          SC6:  ASL     R1        ;SETUP TO ADDRESS WORDS
3328 015624 012761 177777 012212        MOV     #-1,TIMER(R1) ;STOP THE TIMER
3329 015632 006201          ASR     R1        ;RESTORE THE DRIVE ADDRESS
3330 015634 004737 020422        JSR     PC,GETREQ  ;GET THE DPB POINTER FROM THE QUEUE
3331 015640 010164 000010        MOV     R1,RPCS2(R4) ;SELECT DRIVE
3332 015644 004037 017214        JSR     RO,RO.RP   ;READ THE RPO4'S STATUS REG.

```

```

3333 015650 000012          RPDS1
3334 015652 016136          SC8
3335 015654 011605          MOV      (SP),R5          ;AND PUT IT IN R5
3336 015656 006126          ROL      (SP)+          ;WAS THERE AN ERROR?
3337 015660 100407          BMI      1$            ;BR IF ERROR
3338 015662 105761 012110          TSTB    DRVACT(R1)      ;CHECK DRIVE'S STATE
3339 015666 003137          SGT      SC11          ;BR IF DRIVE ACTIVE WITH ORDER
3340 015670 052762 100210 000016          BIS     #BIT15:BIT07:BIT03,16(R2) ;INFORM USER OF ERROR RECOVER COMPLETION
3341 015676 000470          BR
3342 015700 004037 017214          1$:    JSR      RD, RD.RP          ;READ ERROR REGISTER #1
3343 015704 000014          RPER1
3344 015706 016136          SC8
3345 015710 012605          MOV      (SP)+,R5       ;AND SAVE IT IN R5
3346 015712 004737 017566          JSR     PC,SVRH11       ;SAVE RH11/RPO4/5/6 REGISTERS
3347 015716 012746 000111          MOV     #111,-(SP)      ;ISSUE A DRIVE CLEAR
3348 015722 004037 017374          JSR     RD,WRT.RP
3349 015726 000000          RPCS1
3350 015730 016136          SC8
3351 015732 006105          SC6A:  ROL      R5          ;WAS "UNSAFE" CONDITION =1?
3352 015734 100406          BMI     1$            ;BRANCH IF YES
3353 015736 005702          TST     R2            ;ANYTHING IN QUEUE ?
3354 015740 001447          BEQ     SC7           ;BR IF NOT
3355 015742 052762 100240 000016          BIS     #BIT15:BIT07:BIT05,16(R2) ;INFORM USER OF ERROR
3356 015750 000443          BR
3357 015752 004037 017214          1$:    JSR      RD, RD.RP          ;READ DRIVE STATUS REG. #1
3358 015756 000012          RPDS1
3359 015760 016136          SC8
3360 015762 011605          MOV      (SP),R5       ;SAVE RPDS1 IN R5
3361 015764 006126          ROL      (SP)+          ;"ERR"=1?
3362 015766 100011          BPL     2$            ;BR IF NO--UNSAFE CLEARED
3363 015770 112761 177777 012120          MOVB   #-1,DRVSTA(R1) ;DRIVE IS UNSAFE
3364 015776 004737 017566          JSR     PC,SVRH11       ;SAVE RH11/RPO4/5/6 REGISTERS
3365 016002 052762 110000 000016          BIS     #BIT15:BIT12,16(R2) ;INFORM USER OF UNSAFE ERROR
3366 016010 000423          BR
3367 016012 032705 010000          2$:    BIT     #BIT12,R5      ;"MOL" = 1 ?
3368 016016 001015          BNE     3$            ;BR IF YES
3369 016020 112761 177777 012110          MOVB   #-1,DRVACT(R1) ;ACTIVE ERROR RECOVER
3370 016026 112761 000001 012120          MOVB   #1,DRVSTA(R1)  ;ONLINE
3371 016034 006301          ASL     R1
3372 016036 012761 072460 012212          MOV     #30000.,TIMER(R1) ;START 30 SECOND TIMER
3373 016044 006201          ASR     R1
3374 016046 000137 015410          JMP     SC4
3375 016052 052762 100220 000016          3$:    BIS     #BIT15:BIT07:BIT04,16(R2) ;INFORM USER OF ERROR
3376 016060 105061 012110          SC7:   CLRB   DRVACT(R1)   ;DRIVE IS IDLE
3377 016064 004737 020326          JSR     PC,EMPTYQ      ;DUMP THE QUEUE
3378 016070 105761 012166          TSTB   ULDFLG(R1)     ;UNLOAD IN PROGRESS OR QUEUE?
3379 016074 003002          BGT     1$            ;BR IF NOT
3380 016076 105061 012166          CLRB   ULDFLG(R1)     ;CLEAR UNLOAD FLAG
3381 016102 116164 012234 000016          1$:    MOVB   ATABIT(R1),RPAS(R4) ;CLEAR ATTENTION BIT
3382 016110 105761 012120          TSTB   DRVSTA(R1)     ;IS THE DRIVE UNSAFE ?
3383 016114 100406          BMI     2$            ;BR IF IT IS
3384 016116 012746 000113          MOV     #113,-(SP)     ;RELEASE COMMAND
3385 016122 004037 017374          JSR     RD,WRT.RP      ;WRITE THE COMMAND INTO RPCS1
3386 016126 000000          RPCS1 ;REGISTER INDEX
    
```

```

3387 016130 016136          SC8      ;PARITY EXIT ADDRESS
3388 016132 000137 015410 2$:      JMP      SC4      ;CHECK FOR MORE DRIVES
3389 016136 105761 012110 SC8:    TSTB     DRVACT(R1) ;IS DRIVE IDLE?
3390 016142 001405          BEQ      1$      ;YES--BRANCH
3391 016144 004737 020422 JSR      PC,GETREQ ;GET DPB POINTER
3392 016150 004737 014436 JSR      PC,CI7   ;PROCESS THE PARITY ERROR
3393 016154 000402          BR       2$      ;CONTINUE
3394 016156 004737 014464 1$:     JSR      PC,CI7B ;PROCESS THE UNCORRECTABLE PARITY ERROR
3395 016162 000137 015410 2$:      JMP      SC4      ;CHECK MORE DRIVES
3396 016166 105761 012166 SC11:   TSTB     ULDFLG(R1) ;"UNLOAD IN PROGRESS"?
3397 016172 003402          BLE      1$      ;BRANCH IF NO
3398 016174 105061 012166 CLR      ULDFLG(R1) ;CLEAR UNLOAD FLAG
3399 016200 105061 012110 1$:     CLR      DRVACT(R1) ;SET DRIVE IDLE
3400 016204 136137 012234 012162 BITB     ATABIT(R1),SRCHWT ;DOING A SEARCH OPERATION FOR
3401                                     ;AN I/O COMMAND?
3402 016212 001012          BNE      2$      ;BRANCH IF YES
3403 016214 004737 020444 JSR      PC,POPQUE ;REMOVE REQUEST FROM QUEUE
3404 016220 052762 000200 000016 BIS      #BIT07,16(R2) ;SET "DONE" BIT
3405 016226 005737 012206 TST      SAVEFG   ;SAVE THE REGISTERS?
3406 016232 100002          BPL      2$      ;BRANCH IF NO
3407 016234 004737 017566 JSR      PC,SVRH11 ;YES--SAVE ALL OF THE RH11/RPO4/5/6 REG'S
3408 016240 116164 012234 000016 2$:     MOV      ATABIT(R1),RPAS(R4) ;CLEAR ATTENTION BIT
3409 016246 004737 013326 JSR      PC,OPT   ;START A REQUEST
3410 016252 000137 015410 JMP      SC4      ;CHECK FOR MORE DRIVES
3411 016256 010164 000010 SC12:   MOV      R1,RPCS2(R4) ;SELECT DRIVE
3412 016262 016437 000012 012100 MOV      RPO51(R4),RPERRS ;SAVE THE FOUR REGISTERS THAT
3413 016270 016437 000014 012102 MOV      RPER1(R4),RPERRS+2 ;WILL TELL US SOMETHING
3414 016276 016437 000040 012104 MOV      RPER2(R4),RPERRS+4
3415 016304 016437 000042 012106 MOV      RPER3(R4),RPERRS+6
3416 016312 004037 012476 JSR      RO,DRVINT ;INIT. THE STATE OF THE DRIVE
3417 016316 000401          BR       1$      ;TAKE ERROR EXIT
3418 016320 000207          RTS      PC      ;RETURN
3419 016322 005726          1$:     TST      (SP)+   ;POP PC OFF OF THE STACK
3420 016324 000704          BR       SC8     ;PROCESS THE PARITY ERROR
3421 016326 006301          SC13:   ASL      R1      ;SETUP TO ADDRESS WORDS
3422 016330 012761 177777 012212 MOV      #-1,TIMER(R1) ;STOP THE TIMER
3423 016336 006201          ASR      R1
3424 016340 010164 000010 MOV      R1,RPCS2(R4) ;SELECT THE DRIVE
3425 016344 116164 012234 000016 MOV      ATABIT(R1),RPAS(R4) ;CLEAR THE ATTENTION BIT
3426 016352 032714 004000 BIT      #BIT11,(R4) ;DRIVE AVAILABLE ?
3427 016356 001006          BNE      1$      ;BR IF AVAILABLE
3428 016360 006301          ASL      R1
3429 016362 012761 023420 012212 MOV      #10000.,TIMER(R1) ;START 10 SEC TIMER AGAIN
3430 016370 006201          ASR      R1
3431 016372 000433          BR       3$
3432 016374 105761 012140 1$:     TSTB     DPINT(R1) ;EXIT
3433 016400 001424          BEQ      2$      ;INITIALIZING THE DRIVE ?
3434 016402 105061 012140 CLR      DPINT(R1) ;BR IF NOT
3435 016406 004037 012476 JSR      RO,DRVINT ;CLEAR THE INIT INDICATOR
3436 016412 000240          NOP
3437 016414 105761 012120 TSTB     DRVSTA(R1) ;GO INIT THE DRIVE
3438 016420 003014          BGT      2$      ;DUMMY PARITY ERROR RETURN
3439 016422 005702          TST      R2      ;DRIVE ONLINE ?
3440 016424 001416          BEQ      3$      ;BR IF YES -- START ORDER
                                     ;QUEUE ENTRY FOR THE DRIVE
                                     ;BR IF NOT
    
```

```

016426 004737 020422 JSR PC,GETREQ ;GET DPB ADDRESS
016432 052762 140000 BIS #BIT15:BIT:4,16(R2) ;INFORM USER THAT DRIVE OFFLINE
016440 004737 017566 JSR PC,SVRH11 ;SAVE THE REGISTERS
016444 004737 020326 JSR PC,EMPTYQ ;EMPTY THE REQUEST QUEUE
016450 000404 BR 3$
016452 105061 012150 2$: CLRB DPRQS(R1) ;CLEAR THE PORT REQUEST INDICATOR
016456 004737 013326 JSR PC,OPT ;START THE PENDING REQUEST
016462 000137 015410 3$: JMP SC4 ;PROCESS OTHER DRIVES

```

:RPO4 5 6 TIMER ROUTINE

```

:CALL
: MOV #TIME, -(SP) ;ELAPSED TIME IN MILLISECONDS ON THE STACK
: JSR PC,RPTMR ;CALL RPO4/5/6 TIME ROUTINE

RPTMR: TST ACTDRV ;CHECK "ACTDRV" & "ACTSTR"
BNE 4$ ;IF NON ZERO EXIT
MOVB #1,ACTSTR ;SET "ACTSTR"
SAVREG ;SAVE R0 - R5
CLR R1 ;START WITH DRIVE 0
CLR R3
1$: TST TIMER(R3) ;IS THE TIMER RUNNING?
BRT 2$ ;BRANCH IF NO
SUB 2(SP),TIMER(R3) ;COUNT THE INTERVAL
BGT 2$ ;BR IF NO SOFTWARE TIMEOUT
JSR PC,STO ;CALL SOFTWARE TIMEOUT ROUTINE
BR 3$ ;GO TO THE EXIT
2$: INC R1 ;MOVE TO NEXT DRIVE
TST (R3)+
CMP #8,R1 ;OUT OF DRIVES?
BGT 1$ ;BRANCH IF NO
3$: RESREG ;RESTORE R0 - R5
CLRB ACTSTR ;ZERO ACTIVE SOFTWARE TIMEOUT ROUTINE FLAG
4$: MOV (SP)+,(SP) ;ADJUST THE STACK
RTS PC ;RETURN

```

:SOFTWARE TIMEOUT ROUTINE

:NOTE: THIS ROUTINE MUST BE ENTERED AT PRIORITY 6 OR GREATER

```

:CALL: STO ;DRIVE NUMBER
: MOV #DRVNUM,R1 ;DRIVE NUMBER
: JSR PC,STO ;CALL
: RETURN

STO: MOV R1, -(SP) ;SAVE R1
MOV R3, -(SP) ;SAVE R3
MOV RPADR,R4 ;GET ADDRESS OF "RPOS1"
MOV R1,RPOS2(R4) ;SELECT THE DRIVE
JSR PC,RO,RP ;READ "DRIVE STATUS REG"
RPOS1
S*05
016550 010146 TSTB (SP)+ ;IS "DRY"=1?
016552 010346 BMI ST02 ;BR IF YES
016564 013704
016570 010164
016574 004037 017214
016600 000012
016602 017102
016604 105726
016606 100177

```

3495	016610	105761	012140	ST01:	TSTB	DPINT(R1)	: TRYING TO INITIALIZE THE DRIVE ?
3496	016614	001074			BNE	ST02	: BR IF YES
3497	016616	105761	012150		TSTB	DPRQS(R1)	: OUTSTANDING PORT REQUEST FOR THE DRIVE ?
3498	016622	001074			BNE	ST02	: BR IF YES
3499	016624	013702	012150		MOV	TRNSWT,R2	: PICKUP TRANSFER WAIT QUEUE
3500	016630	020137	012232		CMP	R1,DTUW	: TRANSFER UNDERWAY ON THIS DRIVE?
3501	016634	001402			BEQ	1\$: BRANCH IF YES
3502	016636	004737	020422		JSR	PC,GETREQ	: GET DPB ADDRESS
3503	016642	052762	101000	000016	1\$:	BIS	#BIT15!BIT09,16(R2) : SET THE ERROR FLAGS
3504	016650	004737	017566		JSR	PC,SVRH11	: SAVE RH11/RPO4/5/6 REGISTERS
3505	016654	012764	000040	000010		MOV	#BIT05,RPCS2(R4) : "INIT" THE MASS BUS
3506	016652	105061	012110		CLRB	DRVACT(R1)	: DRIVE IS IDLE
3507	016656	105061	012166		CLRB	ULDFLG(R1)	: CLEAR THE UNLOAD FLAG
3508	016672	005001			CLR	R1	: START WITH DRIVE 0
3509	016674	005003			CLR	R3	
3510	016675	004037	012476	2\$:	JSR	RC,DRVINT	: INIT. THIS DRIVE
3511	016702	000477			BR	ST05	: PARITY ERROR RETURN
3512	016704	105761	012110		TSTB	DRVACT(R1)	: DRIVE IDLE BEFORE THE INIT.?
3513	016710	001414			BEQ	4\$: YES--BRANCH
3514	016712	013702	012160		MOV	TRNSWT,R2	: GET TRANSFER WAIT QUEUE
3515	016716	023701	012232		CMP	DTUW,R1	: WAS THERE I/O ON THIS DRIVE?
3516	016722	001402			BEQ	3\$: YES--BRANCH
3517	016724	004737	020422		JSR	PC,GETREQ	: GET THE DPB POINTER FROM QUEUE
3518	016730	052762	100400	000016	3\$:	BIS	#BIT15!BIT08,15(R2) : INFORM USER OF INIT.
3519	016736	105061	012110		CLRB	DRVACT(R1)	: SET DRIVE ACTIVE TO IDLE
3520	016742	105061	012166	4\$:	CLRB	ULDFLG(R1)	: NO UNLOAD
3521	016746	012763	177777	012212	MOV	#-1,TIMER(R3)	: STOP THE TIMER
3522	016754	005723			TST	(R3)+	: UPDATE THE INDEX
3523	016756	005201			INC	R1	: INCREMENT THE DRIVE NUMBER
3524	016760	022701	000010		CMP	#8.,R1	: LAST DRIVE BEEN CHECKED?
3525	016764	003344			BGT	2\$: NO--LOOP
3526	016766	012737	177777	012232	MOV	#-1,DTUW	: NO DATA TRANSFERS UNDERWAY
3527	016774	005037	012160		CLR	TRNSWT	: CLEAR TRANSFER WAIT QUEUE
3528	017000	004737	020250		JSR	PC,CLRQUE	: CLEAR ALL REQUEST QUEUES
3529	017004	000500			BR	ST09	: EXIT
3530	017006	116405	000016	ST02:	MOVW	RPAS(R4),R5	: READ ATTENTION REG
3531	017012	136105	012234		BITB	ATABIT(R1),R5	: IS ATTENTION FOR THIS DRIVE UP ?
3532	017016	001017			BNE	ST03	: YES--BRANCH
3533	017020	105761	012140		TSTB	DPINT(R1)	: TRYING TO INITIALIZE THE DRIVE ?
3534	017024	001031			BNE	ST06	: BR IF YES - DRIVE NOT ONLINE
3535	017026	105761	012150		TSTB	DPRQS(R1)	: OUTSTANDING PORT REQUEST FOR THE DRIVE ?
3536	017032	001045			BNE	ST07	: BR IF YES - NO RESPONSE TO REQUEST
3537	017034	020137	012232		CMP	R1,DTUW	: DATA TRANSFER UNDERWAY FOR THIS DRIVE
3538	017040	001263			BNE	ST01	: BR IF NO
3539	017042	004037	017214		JSR	RC,RD,RP	: YES--CHECK "RDY"
3540	017046	000000			RPCS1		
3541	017050	017102			STOS		
3542	017052	105726			TSTB	(SP)+	
3543	017054	100255			BPL	ST01	: BR IF "RDY"=0
3544	017056	105761	012140	ST03:	TSTB	DPINT(R1)	: INITIALIZING THE DRIVE ?
3545	017062	001003			BNE	1\$: BR IF INIT PENDING
3546	017064	105761	012150		TSTB	DPRQS(R1)	: PORT REQUEST PENDING ?
3547	017070	001446			BEQ	ST09	: BR IF NOT
3548	017072	012763	177777	012212	1\$:	MOV	#-1,TIMER(R3) : STOP THE TIMER

```

017100 000442          BH      ST09      :EXIT
017102 004737 214536 ST05: JSR      PC,C18      :GO HANDLE THE PARITY ERROR
017106 000437          BR      ST09
017110 105061 012140 ST06: CLRB     DPINT(R1)   :CLEAR THE INITIALIZE INDICATOR
017114 105061 012120          CLRB     DRVSTA(R1)  :SET UNIT OFFLINE
017120 012763 177777 012212 MOV     #-1,TIMER(R3) :STOP THE TIMER
017126 004737 020422          JSR      PC,GETREQ   :GET THE DPB ADDRESS
017132 005702          TST     R2          :REQUEST IN QUEUE ?
017134 001424          BEQ     ST09        :BR IF NOT
017136 052762 140000 000016 BIS     #BIT15:BIT14,16(R2) :INFORM THE USER DRIVE NOT AVAILABLE
017144 000414          BR      ST08
017146 012763 177777 012212 ST07: MOV     #-1,TIMER(R3)   :STOP THE TIMER
017154 105061 012150          CLRB     DPRQS(R1)   :CLEAR PORT REQUEST INDICATOR
017160 004737 020422          JSR      PC,GETREQ   :GET DPB ADDRESS
017164 005702          TST     R2          :QUEUE ENTRY FOR DRIVE ?
017166 001407          BEQ     ST09        :BR IF NONE
017170 012762 100004 000016 MOV     #BIT15:BIT2,15(R2) :INFORM USER OF PORT REQUEST ERROR
017176 004737 020326 ST08: JSR      PC,EMPTYQ   :CLEAR THE QUEUE FOR THE DRIVE
017202 004737          JSR      PC,SVRPH1   :SAVE THE REGISTERS
017206 012603 ST09: MOV     (SP)+,R3      :RESTORE R3
017210 012601          MOV     (SP)+,R1      :RESTORE R1
017212 000207          RTS     PC          :RETURN

```

:ROUTINE TO READ A RH11.RPO4.5 6 REGISTER

```

CALL
:JSR      RD,RC,RP      :GO READ A REGISTER
:INDEX   ERRADR        :REG. INDEX FROM BASE
:ERRADR  :PROCESS ERROR STARTING
:AT THIS ADDRESS
:RETURN               :CONTENTS OF REG. IS ON THE STACK

```

```

017214 013737 012244 017362 RD,RP: MOV     MCPEMX,RD,RP2   :MAX. RETRYs ALLOWED
017222 011646          MOV     (SP)-,(SP)    :SAVE RD FOR RETURN
017224 013737 012246 017240          MOV     RPADR,RD,ADR  :FORM THE DESIRED ADDRESS
017232 062716 017240          ADD     (RC)+,RD,ADR :USING THE BASE AND THE INDEX
017236 013727          RD,RP1: MOV     @((PC)+),(PC)+ :READ THE DESIRED REGISTER OF THE RPO4
017240 000000          RD,ADR: .WORD    0   :ADDRESS IS FORMED HERE
017242 000000          RD,WRC: .WORD    0   :REG. CONTENTS PUT HERE
017244 013766 017242 000002          MOV     RD,WRC,2,(SP) :RETURN IT TO THE USER
017252 013746 012246          MOV     RPADR,-(SP)  :PUT THE ADDRESS ON THE STACK
017256 062716 000010          ADD     #RPCS2,(SP) :FORM THE ADDRESS OF RPCS2
017262 032736 010000          BIT     #BIT12,@(SP)+ :CHECK THE 'NED' BIT
017266 001037          BNE     RD,RP3      :BR IF DRIVE NON-EXISTENT
017270 017746 172752          MOV     @RPADR,-(SP) :READ RPCS1
017274 032716 020000          BIT     #BIT13,(SP) :DID MCPE SET?
017300 001002          BNE     IS          :BRANCH IF YES
017302 022620          CMP     (SP)+,(RD)+ :ADJUST FOR RETURN
017304 000432          BR      RD,RP4     :EXIT
017306          IS:
017306 004037 020506          JSR      RD,ES,SAV   :SAVE THE ADDRESS IN 'ESCAPE'
017312 104003          ERROR 3          :REPORT "MCPE" ERROR
017314 005737 012232          TST     DTUW        :DATA TRANSFER UNDERWAY?
017320 000405          BMI     ES        :NO--BRANCH

```

E07

27-APR-76 17:59
PAGE 69

RPC4 5 6 FORMATTER PROGRAM
SINGLE DUAL PORT RH11 RPC4 5 6 DRIVER (REV 1.0)

SEQ 0081

```

017322 J32716 040000 BIT #BIT14,(SP) :NO--"TRE"=1?
017326 001402 BEQ 2$ :NO--BRANCH
017330 005726 TST (SP)+ :YES--CLEAN OFF THE STACK AND
017334 000415 BR RD.RP3 :TAKE THE FATAL ERROR EXIT
017338 052716 040000 2$: BIS #BIT14,(SP) :CLEAR "MCPE" BY SENDING A "1" TO "TRE"
017340 000316 SWAB (SP) :POSITION BEFORE WRITING
017342 012246 017356 MOV RPADR,3$ :FORM ADDRESS OF HIGH BYTE
017344 005237 017356 INC 3$
017346 112637 MOVB (SP)+,2(PC)+ :WRITE THE HIGH BYTE OF RPCS1
017348 000000 3$: .WORD 0 :ADDRESS STORAGE
017350 005237 DEC (PC)+ :EXCEEDED MAX. RETRYS
017352 J000003 RD.RP2: .WORD 3
017354 002324 SGE RD.RP1 :BRANCH IF NO
017356 011000 RD.RP3: MOV (RD),RD :FATAL ERROR EXIT
017358 012616 RD.RP4: MOV (SP)+,(SP)
017360 000200 RD.RP4: RTS RC

:ROUTINE TO WRITE A REGISTER
:CALL
:MOV DATA,-(SP) :DATA TO BE LOADED ON THE STACK
:JSR RC,WRT.RP :CALL THE ROUTINE TO LOAD(WRITE) THE REG.
:INDEX :INDEX OF THE REGISTER TO BE LOADED
:ERRADR :ADDRESS TO RETURN TO ON AN ERROR
:RETURN :ERROR FREE RETURN

WRT.RP: MOV MPEMX,WRT.R2 :MAX RETRYS ALLOWED
MOV 2(SP),WRT.WD :SAVE THE WORD TO WRITE
MOV (SP)+,(SP) :ADJUST THE STACK
MOV (RD)+,WRT.RD :GET INDEX OF REGISTER TO BE WRITTEN
BNE 1$ :BRANCH IF NOT RPCS1
CMPB #150,WRT.WD :IS THE COMMAND FOR DATA TRANSFER?
BLT 1$ :YES--DON'T GET THE OLD R16 & R17 & R22
JSR RC,RD.RP :NO---COMBINE R16&R17 & R22 WITH R23
RPCS1 :THE COMMAND BEFORE SENDING IT TO
WRT.R3 :THE RH11/RPC4
SWAB (SP)
BIC #107,(SP)
MOVB (SP)+,WRT.WD+1
1$: ADD RPADR,WRT.RD :FORM THE ADDRESS OF THE DISK REG.
WRT.R1: MOV (PC)+,2(PC)+ :LOAD THE DESIRED REG.
WRT.WD: .WORD 0 :WORD TO WRITE GOES HERE
WRT.RD: .WORD 0 :ADDRESS IS FORMED HERE
MOV RPADR,-(SP) :PUT THE ADDRESS ON THE STACK
ADD #RPCS2,(SP) :FORM THE ADDRESS OF RPCS2
BIT #BIT12,2(SP)+ :CHECK THE 'NEO' BIT
BNE WRT.R3 :BR IF DRIVE NON-EXISTENT
JSR RD,RD.RP :CHECK FOR PARITY ERROR ON WRITE
WRT.R3
RPER1
WRT.R3
BIT #BIT03,(SP)+
WRT.R4 :BRANCH IF "PAR=0"
MOV -2(RD),1$ :PICKUP THE INDEX
JSR RD,RD.RP :READ THE REG.

```

```

3657 017534 000000 1$: .WORD 0 ;REG. INDEX
3658 017536 017556 ;RETURN TO THIS ADDRESS ON ERROR
3659 017540 004037 020506 JSR RO,ES,SA' ;SAVE THE ADDRESS IN 'SESCAPE'
3660 017544 104004 ERROR 4 ;REPORT THE PARITY ON WRITE ERROR
3661 017546 005327 DEC (PC)+ ;DECREMENT THE ERROR COUNT
3662 017550 000003 WRT.R2: .WORD 3 ;RETRY COUNTER
3663 017552 002342 SGE WRT.R1 ;TRY AGAIN IF NOT FINISHED
3664 017554 005726 TST (SP)+ ;CLEAN OFF THE STACK
3665 017556 011000 WRT.R3: MOV (RO),RO ;TAKE THE "PARITY ON WRITE" ERROR EXIT
3666 017560 000401 BR WRT.R5 ;EXIT
3667 017562 005720 WRT.R4: TST (RO)+ ;ADJUST FOR ERROR FREE EXIT
3668 017564 000200 WRT.R5: RTS RO

```

:ROUTINE TO SAVE THE RH11 RPO4 5 & 6 REGISTERS AS PER DPB+14

```

:CALL
: MOV #DPBNUM,R2 ;DPB POINTER TO R2
: JSR PC,SVRH11 ;SAVE THE DRIVES REG'S
SVRH11: SAVREG ;SAVE RO - R5
: TST R2 ;QUEUE ENTRY FOR THE DRIVE
: BEQ 4$ ;BR IF NONE
: MOV RPOADR,R4
: MOVB (R2),RPOCS2,R4 ;SELECT DRIVE
: MOV (R2),R3 ;SET THE ERROR TABLE POINTER
: BEQ 6$ ;EXIT IF NO ADDRESS
: CLR 3$ ;COUNTER & POINTER
: CMP 3$,#RPOB ;REACHED THE BUFFER REGISTER
: BNE 2$ ;BR IF NOT
: BIT #BIT07,RPOCS2,R4 ;'OR' SET
: BNE 2$ ;BR IF SET
: CLR (R3)+ ;STORE RPOB AS ZEROES
: BR 4$ ;CONTINUE
: JSR RO,RO,RP ;READ THE SELECTED REGISTER
: .WORD 0 ;REGISTER INDEX
: S$ ;ERROR RETURN ADDRESS
: MOV (SP)+(R3)+ ;STORE THE REGISTER CONTENTS
: CMP 3$,#RPOE2 ;REACHED THE END
: BEQ 6$ ;BR IF YES
: ADD #2,3$ ;INCREMENT THE REGISTER INDEX
: BR 1$ ;CONTINUE READING THE REGISTERS
: JSR PC,CIT ;PROCESS THE UNCORRECTABLE PARITY ERROR
: RESREG ;RESTORE RO - R5
: RTS PC ;RETURN

```

:ROUTINE TO SET THE INTERRUPT WITHOUT GETTING A "TRE"

```

:CALL
: MOV #DRVNUM,R1 ;DRIVE NUMBER TO R1
: JSR PC,SET.IE ;SET "IE"
: RETURN
SET.IE: MOV R4,(SP) ;SAVE R4
: MOV RPOADR,R4 ;PICKUP ADDRESS OF RPOCS1
: MOV R1,RPOCS2(R4) ;SELECT DRIVE

```

```

017711 011446      MOV      (R4),-(SP)      ;READ RPCS1
017712 052716 040000  BIS      #BIT14,(SP)    ;SET THE "TRE" BIT OF THE WORD READ
017713 000316      SWAB      (SP)          ;ADJUST FOR DATO
017714 000100      MOVB     #BIT06,(R4)   ;SET "IE"
017715 013000 000010  BIT      #BIT12,RPCS2(R4) ;IS "NED"=1?
017716 001002      SNE      1$           ;YES--CLEAR "TRE"
017717 005726      TST      (SP)+        ;CLEAN OFF THE STACK
017718 000402      BR       2$           ;
017719 112664 000001 1$:  MOVB     (SP)+,1(R4)   ;CLEAR "TRE"
017720 012604      MOV      (SP)+,R4     ;RESTORE R4
017721 000207      RTS       PC          ;RETURN TO CALLER

:QUEUE COUNT
JCONT:  .BYTE  0           ;DRIVE 0
        .BYTE  000000    ;DRIVE 1
        .BYTE  000000    ;DRIVE 2
        .BYTE  000000    ;DRIVE 3
        .BYTE  000000    ;DRIVE 4
        .BYTE  000000    ;DRIVE 5
        .BYTE  000000    ;DRIVE 6
        .BYTE  0         ;DRIVE 7

:QUEUE INPUT POINTERS
JINPT:  .WORD  QDRV0      ;DRIVE 0
        .WORD  QDRV1      ;DRIVE 1
        .WORD  QDRV2      ;DRIVE 2
        .WORD  QDRV3      ;DRIVE 3
        .WORD  QDRV4      ;DRIVE 4
        .WORD  QDRV5      ;DRIVE 5
        .WORD  QDRV6      ;DRIVE 6
        .WORD  QDRV7      ;DRIVE 7

:QUEUE OUTPUT POINTERS
JOUTPT: .WORD  QDRV0      ;DRIVE 0
        .WORD  QDRV1      ;DRIVE 1
        .WORD  QDRV2      ;DRIVE 2
        .WORD  QDRV3      ;DRIVE 3
        .WORD  QDRV4      ;DRIVE 4
        .WORD  QDRV5      ;DRIVE 5
        .WORD  QDRV6      ;DRIVE 6
        .WORD  QDRV7      ;DRIVE 7

JSTART: .WORD  QDRV0      ;DRIVE 0 START ADDRESS
JSTOP:  .WORD  QDRV1      ;DRIVE 0 STOP ADDRESS & DRIVE 1 START ADDRESS
        .WORD  QDRV2      ;STOP DRIVE 1--START DRIVE 2
        .WORD  QDRV3      ;STOP DRIVE 2--START DRIVE 3
        .WORD  QDRV4      ;STOP DRIVE 3--START DRIVE 4
        .WORD  QDRV5      ;STOP DRIVE 4--START DRIVE 5
        .WORD  QDRV6      ;STOP DRIVE 5--START DRIVE 6
        .WORD  QDRV7      ;STOP DRIVE 6--START DRIVE 7
        .WORD  QTERM     ;STOP DRIVE 7

```

020050
020070
020110
020130
020150
020170
020210
020230
020250
020250
020252
020256
020260
020262
020264
020266
020272
020276
020300
020302
020304
020310
020314
020316
020320
020322
020324
020326
020332
020334
020342
020344
020346
020348
020350
020352
020354
020356
020358
020360
020362
020364
020366
020368
020370
020372
020374
020376
020378
020380
020382
020384
020386
020388
020390
020392
020394
020396
020398
020400
020402
020404
020406
020408
020410
020412
020414
020416
020418
020420
020422
020424
020426
020428
020430
020432
020434
020436
020438
020440
020442
020444
020446
020448
020450
020452
020454
020456
020458
020460
020462
020464
020466
020468
020470
020472
020474
020476
020478
020480
020482
020484
020486
020488
020490
020492
020494
020496
020498
020500
020502
020504
020506
020508
020510
020512
020514
020516
020518
020520
020522
020524
020526
020528
020530
020532
020534
020536
020538
020540
020542
020544
020546
020548
020550
020552
020554
020556
020558
020560
020562
020564
020566
020568
020570
020572
020574
020576
020578
020580
020582
020584
020586
020588
020590
020592
020594
020596
020598
020600
020602
020604
020606
020608
020610
020612
020614
020616
020618
020620
020622
020624
020626
020628
020630
020632
020634
020636
020638
020640
020642
020644
020646
020648
020650
020652
020654
020656
020658
020660
020662
020664
020666
020668
020670
020672
020674
020676
020678
020680
020682
020684
020686
020688
020690
020692
020694
020696
020698
020700
020702
020704
020706
020708
020710
020712
020714
020716
020718
020720
020722
020724
020726
020728
020730
020732
020734
020736
020738
020740
020742
020744
020746
020748
020750
020752
020754
020756
020758
020760
020762
020764
020766
020768
020770
020772
020774
020776
020778
020780
020782
020784
020786
020788
020790
020792
020794
020796
020798
020800
020802
020804
020806
020808
020810
020812
020814
020816
020818
020820
020822
020824
020826
020828
020830
020832
020834
020836
020838
020840
020842
020844
020846
020848
020850
020852
020854
020856
020858
020860
020862
020864
020866
020868
020870
020872
020874
020876
020878
020880
020882
020884
020886
020888
020890
020892
020894
020896
020898
020900
020902
020904
020906
020908
020910
020912
020914
020916
020918
020920
020922
020924
020926
020928
020930
020932
020934
020936
020938
020940
020942
020944
020946
020948
020950
020952
020954
020956
020958
020960
020962
020964
020966
020968
020970
020972
020974
020976
020978
020980
020982
020984
020986
020988
020990
020992
020994
020996
020998
021000
021002
021004
021006
021008
021010
021012
021014
021016
021018
021020
021022
021024
021026
021028
021030
021032
021034
021036
021038
021040
021042
021044
021046
021048
021050
021052
021054
021056
021058
021060
021062
021064
021066
021068
021070
021072
021074
021076
021078
021080
021082
021084
021086
021088
021090
021092
021094
021096
021098
021100
021102
021104
021106
021108
021110
021112
021114
021116
021118
021120
021122
021124
021126
021128
021130
021132
021134
021136
021138
021140
021142
021144
021146
021148
021150
021152
021154
021156
021158
021160
021162
021164
021166
021168
021170
021172
021174
021176
021178
021180
021182
021184
021186
021188
021190
021192
021194
021196
021198
021200
021202
021204
021206
021208
021210
021212
021214
021216
021218
021220
021222
021224
021226
021228
021230
021232
021234
021236
021238
021240
021242
021244
021246
021248
021250
021252
021254
021256
021258
021260
021262
021264
021266
021268
021270
021272
021274
021276
021278
021280
021282
021284
021286
021288
021290
021292
021294
021296
021298
021300
021302
021304
021306
021308
021310
021312
021314
021316
021318
021320
021322
021324
021326
021328
021330
021332
021334
021336
021338
021340
021342
021344
021346
021348
021350
021352
021354
021356
021358
021360
021362
021364
021366
021368
021370
021372
021374
021376
021378
021380
021382
021384
021386
021388
021390
021392
021394
021396
021398
021400
021402
021404
021406
021408
021410
021412
021414
021416
021418
021420
021422
021424
021426
021428
021430
021432
021434
021436
021438
021440
021442
021444
021446
021448
021450
021452
021454
021456
021458
021460
021462
021464
021466
021468
021470
021472
021474
021476
021478
021480
021482
021484
021486
021488
021490
021492
021494
021496
021498
021500
021502
021504
021506
021508
021510
021512
021514
021516
021518
021520
021522
021524
021526
021528
021530
021532
021534
021536
021538
021540
021542
021544
021546
021548
021550
021552
021554
021556
021558
021560
021562
021564
021566
021568
021570
021572
021574
021576
021578
021580
021582
021584
021586
021588
021590
021592
021594
021596
021598
021600
021602
021604
021606
021608
021610
021612
021614
021616
021618
021620
021622
021624
021626
021628
021630
021632
021634
021636
021638
021640
021642
021644
021646
021648
021650
021652
021654
021656
021658
021660
021662
021664
021666
021668
021670
021672
021674
021676
021678
021680
021682
021684
021686
021688
021690
021692
021694
021696
021698
021700
021702
021704
021706
021708
021710
021712
021714
021716
021718
021720
021722
021724
021726
021728
021730
021732
021734
021736
021738
021740
021742
021744
021746
021748
021750
021752
021754
021756
021758
021760
021762
021764
021766
021768
021770
021772
021774
021776
021778
021780
021782
021784
021786
021788
021790
021792
021794
021796
021798
021800
021802
021804
021806
021808
021810
021812
021814
021816
021818
021820
021822
021824
021826
021828
021830
021832
021834
021836
021838
021840
021842
021844
021846
021848
021850
021852
021854
021856
021858
021860
021862
021864
021866
021868
021870
021872
021874
021876
021878
021880
021882
021884
021886
021888
021890
021892
021894
021896
021898
021900
021902
021904
021906
021908
021910
021912
021914
021916
021918
021920
021922
021924
021926
021928
021930
021932
021934
021936
021938
021940
021942
021944
021946
021948
021950
021952
021954
021956
021958
021960
021962
021964
021966
021968
021970
021972
021974
021976
021978
021980
021982
021984
021986
021988
021990
021992
021994
021996
021998
022000
022002
022004
022006
022008
022010
022012
022014
022016
022018
022020
022022
022024
022026
022028
022030
022032
022034
022036
022038
022040
022042
022044
022046
022048
022050
022052
022054
022056
022058
022060
022062
022064
022066
022068
022070
022072
022074
022076
022078
022080
022082
022084
022086
022088
022090
022092
022094
022096
022098
022100
022102
022104
022106
022108
022110
022112
022114
022116
022118
022120
022122
022124
022126
022128
022130
022132
022134
022136
022138
022140
022142
022144
022146
022148
022150
022152
022154
022156
022158
022160
022162
022164
022166
022168
022170
022172
022174
022176
022178
022180
022182
022184
022186
022188
022190
022192
022194
022196
022198
022200
022202
022204
022206
022208
022210
022212
022214
022216
022218
022220
022222
022224
022226
022228
022230
022232
022234
022236
022238
022240
022242
022244
022246
022248
022250

:DRIVE REQUEST QUEUES

QDRV0: .BLKW 10
QDRV1: .BLKW 10
QDRV2: .BLKW 10
QDRV3: .BLKW 10
QDRV4: .BLKW 10
QDRV5: .BLKW 10
QDRV6: .BLKW 10
QDRV7: .BLKW 10
QTERM=.

:ROUTINE TO CLEAR ALL OF THE REQUEST QUEUES

:CALL

JSR PC,CLRQLE

CLRQLE: SAVREG

MOV #QCNT,R2
CLR (R2)+
CLR (R2)+
CLR (R2)+
CLR (R2)+
MOV #8,R3
MOV #QSTART,R1
1\$: MOV (R1)+,(R2)+
DEC R3
BNE 1\$
MOV #8,R3
MOV #QSTART,R1
2\$: MOV (R1)+,(R2)+
DEC R3
BNE 2\$
RESREG
RTS PC

:SAVE R0 - R5
:ZERO THE QUEUE COUNTS
:DRIVES 0 & 1
:DRIVES 2 & 3
:DRIVES 4 & 5
:DRIVES 6 & 7
:MOVE THE STARTING
:ADDRESS OF THE QUEUE INTO
:THE QUEUE INPUT POINTER
:MOVE THE STARTING ADDRESS
:OF THE QUEUE INTO THE
:QUEUE OUTPUT POINTER
:RESTORE R0 - R5

:EMPTY THE QUEUE SPECIFIED BY R1:

:CALL

MOV DRVNUM,R1 ;DRIVE NUMBER TO R1
JSR PC,EMPTYQ

EMPTYQ: CLRB QCNT(R1)

ASL R1 ;CLEAR NUMBER OF ITEMS IN QUEUE
MOV QINPT(R1),QOUTPT(R1) ;SET OUTPUT QUEUE POINTER=INPUT POINTER
ASR R1
RTS PC

:ROUTINE TO PUT A REQUEST IN QUEUE

:CALL

MOV #DRVNUM,R1 ;DRIVE NUMBER
MOV #DPB,R2 ;ADDRESS OF PARAMETER BLOCK
JSR R0,DRVQLE ;GO PUT REQUEST IN QUEUE

```

3819          : RETURN1          ;RETURN HERE IF QUEUE IS FULL
3820          : RETURN2          ;RETURN HERE IF REQUEST IS IN QUEUE
3821          :
3822 020346 122761 000010 017756 DRVQUE: CMPB   #10,QCNT(R1)  ;IS QUEUE FULL?
3823 020354 001421          BEQ     2$          ;BR IF YES-TAKE RETURN1
3824 020356 105261 017756          INCB   QCNT(R1)    ;INCREMENT QUEUE COUNT
3825 020362 006301          ASL    R1
3826 020364 010271 017766          MOV    R2,QINPT(R1) ;PUT THIS REQUEST IN QUEUE
3827 020370 062761 000002 017766          ADD    #2,QINPT(R1) ;UPDATE THE QUEUE POINTER
3828 020376 026161 017766 020030          CMP    QINPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER
3829 020404 001003          BNE   1$          ;BRANCH IF NO
3830 020406 016161 020026 017766          MOV    QSTART(R1),QINPT(R1) ;YES--RESET POINTER
3831 020414 006201          1$: ASR    R1
3832 020416 005720          TST   (R0)+       ;TAKE RETURN 2
3833 020420 000200          2$: RTS    R0     ;RETURN TO USER
3834          :
3835          ;ROUTINE TO GET THE "DPB" ADDRESS OF NEXT REQUEST IN QUEUE
3836          :
3837          :CALL
3838          :
3839          :   MOV    #DRVNUM,R1      ;DRIVE NUMBER TO R1
3840          :   JSR    PC,GETREQ     ;GO GET THE REQUEST
3841          :   :
3842          :   RETURN              ;R2="DPB" ADDRESS OF THE REQUEST
3843          :   :
3844          :   :R2=0 IF NO REQUEST IN QUEUE
3845          :
3846 020422 005002          GETREQ: CLR    R2
3847 020424 105761 017756          TSTB  QCNT(R1)    ;IS THERE ANY REQUEST IN QUEUE?
3848 020430 001404          BEQ   2$          ;NO---BRANCH
3849 020432 006301          1$: ASL    R1
3850 020434 017102 020036          MOV    QOUTPT(R1),R2 ;PICKUP "DPB" POINTER FOR THIS DRIVE
3851 020440 006201          ASR   R1
3852 020442 000207          2$: RTS    PC     ;RETURN TO USER
3853          :
3854          ;ROUTINE TO "POP" THE REQUEST FROM QUEUE
3855          :
3856          :CALL
3857          :
3858          :   MOV    #DRVNUM,R1      ;DRIVE NUMBER TO R1
3859          :   JSR    PC,POPQUE     ;CALL TO REMOVE REQUEST
3860          :   :
3861          :   RETURN              ;R2=ADDRESS OF DPB REMOVED
3862          :
3863 020444 105361 017756          POPQUE: DECB  QCNT(R1) ;DECREMENT QUEUE COUNT
3864 020450 006301          ASL   R1
3865 020452 017102 020036          MOV    QOUTPT(R1),R2 ;GET THE "DPB" POINTER
3866 020456 062761 000002 020006          ADD    #2,QOUTPT(R1) ;UPDATE THE QUEUE POINTER
3867 020464 026161 020006 020030          CMP    QOUTPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER?
3868 020472 001003          BNE   1$          ;NO--BRANCH TO EXIT
3869 020474 016161 020026 020006          MOV    QSTART(R1),QOUTPT(R1) ;YES--RESET THE POINTER
3870 020502 006201          1$: ASR   R1
3871 020504 000207          RTS   PC         ;RETURN TO USER
3872          :
3873          ;ROUTINE TO SAVE THE CONTENTS OF 'SESCAPE' WHEN THE DRIVER
3874          :REPORTS AN ERROR DIRECTLY.
3875          :
3876          :CALL
3877          :
3878          :   JSR    R0,ES.SAV

```

```

3873          :      ERROR      N      ;: THE ERROR CALL
3874          :      RETURN      ;: THE RETURN IS PAST THE ERROR CALL
3875
3876 020506 012037 020522 ES.SAV: MOV      (RO)+,IS      ;GET THE ERROR CALL
3877 020512 013746 001160      MOV      $ESCAPE,-(SP) ;SAVE THE ADDRESS IN '$ESCAPE'
3878 020516 005037 001160      CLR      $ESCAPE      ;CLEAR THE ESCAPE RETURN
3879 020522 000000      IS:      .WORD      0      ;THE ERROR CALL IS MOVED HERE
3880 020524 012637 001160      MOV      (SP)+,$ESCAPE ;RESTORE THE ESCAPE ADDRESS
3881 020530 000200      RTS      RO      ;RETURN

```

;*****

.SBTTL TELETYPE MESSAGES

```

3888 020532 047440 043106 044514 UNTOFF: .ASCIZ / OFFLINE/
3889 020540 042516 000      UNTON: .ASCIZ / ONLINE/
3890 020543 040      047117 044514
3891 020550 042516 000      NOTRP: .ASCIZ @ NOT AN RPO4/5/6@
3892 020553 040      047516 020124
3893 020560 047101 051040 030120
3894 020566 027464 027465 000066
3895 020574 047040 052117 050040 NOTPRS: .ASCIZ / NOT PRESENT/
3896 020602 042522 042523 052116
3897 020610 000
3898 020611 040      047125 040523 NOTSAF: .ASCIZ / UNSAFE/
3899 020616 042506 000
3900 020621 122      030120 000064 RPO4B: .ASCIZ /RPO4/
3901 020626 050122 032460 000      RPO5: .ASCIZ /RPO5/
3902 020633 122      030120 000066 RPC6: .ASCIZ /RPO6/
3903 020640 047125 052111 051440 SYSTAT: .ASCIZ /UNIT STATUS/<CR><LF><LF>
3904 020646 040524 052524 006523
3905 020654 005012 000
3906 020657 015      042012 044522 MUNIT: .ASCIZ <CR><LF>/DRIVE: /
3907 020664 042526 020072 000
3908 020671 040      020057 000 SLASH: .ASCIZ @ / @
3909 020675 103      000      C: .ASCIZ /C/
3910 020677 124      000      T: .ASCIZ /T/
3911 020701 060      000      MDRVD: .ASCIZ /D/
3912 020703 040      040      LIN4SP: .ASCII / /
3913 020705 040      000040 LINS: .ASCIZ / /
3914 020710 047105 042524 020122 ENTADR: .ASCIZ /ENTER ADDRESS LIMITS:<CR><LF>
3915 020716 042101 051104 051505
3916 020724 020123 044514 044515
3917 020732 051524 006472 000012
3918 020740 020040 051104 053111 MOFFLN: .ASCIZ / DRIVE OFFLINE/<CR><LF>
3919 020746 020105 043117 046106
3920 020754 047111 006505 000012
3921 020762 042040 044522 042526 MDRNP: .ASCIZ / DRIVE NOT PRESENT/<CR><LF>
3922 020770 047040 052117 050040
3923 020776 042522 042523 052116
3924 021004 005015 000
3925 021007 040      051104 053111 MER11: .ASCIZ / DRIVE NOT AVAILABLE/<CR><LF>
3926 021014 020105 047516 020124

```

3927	021022	053101	044501	040514	
3928	021030	046102	006505	000012	
3929	021036	042040	044522	042526	MNRPO4: .ASCIZ 3 DRIVE NOT AN RPO4/5/62<CR><LF>
3930	021044	047040	052117	040440	
3931	021052	020116	050122	032060	
3932	021060	032457	033057	005015	
3933	021066	000			
3934	021067	040	051104	053111	MUSDR: .ASCIZ / DRIVE UNSAFE/<CR><LF>
3935	021074	020105	047125	040523	
3936	021102	042506	005015	000	
3937	021107	040	042523	042514	MSELD: .ASCIZ / SELECTED/
3938	021114	052103	042105	000	
3939	021121	015	050012	047522	MMODE: .ASCIZ <CR><LF>/PROGRAM MODE (C OR F): /
3940	021126	051107	046501	046440	
3941	021134	042117	020105	041450	
3942	021142	047440	020122	024506	
3943	021150	020072	000		
3944	021153	040	047506	046522	MFORMAT: .ASCIZ / FORMAT & VERIFY/
3945	021160	052101	023040	053040	
3946	021166	051105	043111	000131	
3947	021174	044103	041505	020113	MHECK: .ASCIZ /CHECK ONLY/
3948	021202	047117	054514	000	
3949	021207	106	051117	040515	MORMAT: .ASCIZ /FORMAT & VERIFY/
3950	021214	020124	020046	042526	
3951	021222	044522	054506	000	
3952	021227	015	005012	050117	MSIZE: .ASCIZ <CR><LF><LF>/OPERATE IN 22 SECTOR MODE (Y OR N) ? /
3953	021234	051105	052101	020105	
3954	021242	047111	031040	020062	
3955	021250	042523	052103	051117	
3956	021256	046440	042117	020105	
3957	021264	054450	047440	020122	
3958	021272	024516	037440	000040	
3959	021300	050117	051105	052101	MSEC22: .ASCIZ /OPERATION WILL BE IN 22 SECTOR (16 BIT) MODE/<CR><LF>
3960	021306	047511	020116	044527	
3961	021314	046114	041040	020105	
3962	021322	047111	031040	020062	
3963	021330	042523	052103	051117	
3964	021336	024040	033061	041040	
3965	021344	052111	020051	047515	
3966	021352	042504	005015	000	
3967	021357	117	042520	040522	MSEC20: .ASCIZ /OPERATION WILL BE IN 20 SECTOR (18 BIT) MODE/<CR><LF>
3968	021364	044524	047117	053440	
3969	021372	046111	020114	042502	
3970	021400	044440	020116	030062	
3971	021406	051440	041505	047524	
3972	021414	020122	030450	020070	
3973	021422	044502	024524	046440	
3974	021430	042117	006505	000012	
3975	021436	047111	040526	044514	BADENT: .ASCIZ /INVALID ENTRY/<CR><LF>
3976	021444	020104	047105	051124	
3977	021452	006531	000012		
3978	021456	047105	044504	043516	MADRER: .ASCII .ENDING DSK ADRS MUST BE EQUAL TO OR GREATER/<CR><LF>
3979	021464	042040	045523	040440	
3980	021472	051104	020123	052515	

3981	021500	052123	041040	020105	
3982	021506	050505	040525	020114	
3983	021514	047524	047440	020122	
3984	021522	051107	040505	042524	
3985	021530	006522	012		
3986	021533	124	040510	020116	.ASCIZ /THAN STARTING ADRS/<CR><LF>
3987	021540	052123	051101	044524	
3988	021546	043516	040440	051104	
3989	021554	006523	000012		
3990	021560	042523	042514	052103	MSELP: .ASCII /SELECT DATA PATTERN<CR><LF>
3991	021566	042040	052101	020101	
3992	021574	040520	052124	051105	
3993	021602	006516	012		
3994	021605	040	030050	020051	.ASCII / (0) ZERO'S/<CR><LF>
3995	021612	042532	047522	051447	
3996	021620	005015			
3997	021622	024040	024461	047440	.ASCII / (1) ONE'S/<CR><LF>
3998	021630	042516	051447	005015	
3999	021636	024040	024462	053440	.ASCIZ / (2) WORST CASE: /
4000	021644	051117	052123	041440	
4001	021652	051501	035105	000040	
4002					
4003	021660	047527	051522	020124	MPATD: .ASCIZ /WORST CASE/
4004	021666	040503	042523	000	
4005	021673	015	005012	052123	MSFOU: .ASCIZ <CR><LF><LF>/STARTING FORMAT ON DRIVE /
4006	021700	051101	044524	043516	
4007	021706	043040	051117	040515	
4008	021714	020124	047117	042040	
4009	021722	044522	042526	000040	
4010	021730	005015	051412	040524	MSCHK: .ASCIZ <CR><LF><LF>/STARTING CHECK ON DRIVE /
4011	021736	052122	047111	020107	
4012	021744	044103	041505	020113	
4013	021752	047117	042040	044522	
4014	021760	042526	000040		
4015	021764	005015	043012	051117	MFCMPT: .ASCIZ <CR><LF><LF>/FORMAT COMPLETE, /
4016	021772	040515	020124	047503	
4017	022000	050115	042514	042524	
4018	022006	020054	000		
4019	022011	015	005012	044103	MCCMPT: .ASCIZ <CR><LF><LF>/CHECK COMPLETE, /
4020	022016	041505	020113	047503	
4021	022024	050115	042514	042524	
4022	022032	020054	000		
4023	022035	124	052117	046101	NUMERR: .ASCIZ /TOTAL ERRORS DETECTED: /
4024	022042	042440	051122	051117	
4025	022050	020123	042504	042524	
4026	022056	052103	042105	020072	
4027	022064	000			
4028	022065	120	042522	042523	ADDRIS: .ASCIZ /PRESENT ADDRESS IS: .
4029	022072	052116	040440	042104	
4030	022100	042522	051523	044440	
4031	022106	035123	000040		
4032					
4033					
4034					

;;*****

.SBTTL ERROR MESSAGES

;*****

4035					
4036					
4037					
4038					
4039	022112	044122	030461	044440	EM1: .ASCIZ /RH11 INTERRUPT OCCURRED (RPAS=0)/
4040	022120	052116	051105	052522	
4041	022126	052120	047440	041503	
4042	022134	051125	042522	020104	
4043	022142	051050	040520	036523	
4044	022150	024460	000		
4045	022153	125	042516	050130	EM2: .ASCIZ /UNEXPECTED ATTENTION OCCURRED/
4046	022150	041505	042524	020104	
4047	022166	052101	042524	052116	
4048	022174	047511	020116	041517	
4049	022202	052503	051122	042105	
4050	022210	000			
4051	022211	115	051501	041123	EM3: .ASCIZ /MASSBUS PARITY ERROR (MCPE=1)/
4052	022216	051525	050040	051101	
4053	022224	052111	020131	051105	
4054	022232	047522	020122	046450	
4055	022240	050103	036505	024461	
4056	022246	000			
4057	022247	115	051501	041123	EM4: .ASCIZ /MASSBUS PARITY ERROR (PAR=1).
4058	022254	051525	050040	051101	
4059	022262	052111	020131	051105	
4060	022270	047522	020122	050050	
4061	022276	051101	030475	000051	
4062	022304	042101	051104	051505	EM5: .ASCIZ /ADDRESS PLUG CHANGE BIT SET.
4063	022312	020123	046120	043525	
4064	022320	041440	040510	043516	
4065	022326	020105	044502	020124	
4066	022334	042523	000124		
4067	022340	044122	030461	042040	EM6: .ASCIZ /RH11 DIDN'T RESPOND TO ADDRESSING/
4068	022346	042111	023516	020124	
4069	022354	042522	050123	047117	
4070	022362	020104	047524	040440	
4071	022370	042104	042522	051523	
4072	022376	047111	000107		
4073	022402	051104	053111	020105	EM10: .ASCIZ /DRIVE OFFLINE/
4074	022410	043117	046106	047111	
4075	022416	000105			
4076	022420	042520	051522	051511	EM11: .ASCIZ /PERSISTENT DRIVE UNSAFE ERROR/
4077	022426	042524	052116	042040	
4078	022434	044522	042526	052440	
4079	022442	051516	043101	020105	
4080	022450	051105	047522	000122	
4081	022456	047125	047503	051122	EM12: .ASCIZ /UNCORRECTABLE MASSBUS PARITY ERROR
4082	022464	041505	040524	046102	
4083	022472	020105	040515	051523	
4084	022500	052502	020123	040520	
4085	022506	044522	054524	042440	
4086	022514	051122	051117	000	
4087	022521	123	043117	053524	EM13: .ASCIZ /SOFTWARE TIMEOUT/
4088	022526	051101	020105	044524	

4099	022534	042515	052517	000124		
4090	022542	051104	053111	020105	EM14:	.ASCIZ /DRIVE UNSAFE ERROR/
4091	022550	047125	040523	042506		
4092	022556	042440	051122	051117		
4093	022564	000				
4094	022565	103	047117	051124	EM15:	.ASCIZ @CONTROLLER/DRIVE ERROR DURING WRITE@
4095	022572	046117	042514	027522		
4096	022600	051104	053111	020105		
4097	022606	051105	047522	020122		
4098	022614	052504	044522	043516		
4099	022622	053440	044522	042524		
4100	022630	000				
4101	022631	103	047117	051124	EM16:	.ASCIZ @CONTROLLER/DRIVE ERROR DURING WRITE CHECK@
4102	022636	046117	042514	027522		
4103	022644	051104	053111	020105		
4104	022652	051105	047522	020122		
4105	022660	052504	044522	043516		
4106	022666	053440	044522	042524		
4107	022674	041440	042510	045503		
4108	022702	000				
4109	022703	122	052105	044522	EM17:	.ASCIZ @RETRIES NOT SUCCESSFUL - SECTOR NOT ACCEPTABLE@
4110	022710	051505	047040	052117		
4111	022716	051440	041525	051505		
4112	022724	043123	046125	026440		
4113	022732	051440	041505	047524		
4114	022740	020122	047516	020124		
4115	022746	041501	042503	052120		
4116	022754	041101	042514	000		
4117	022761	104	052101	020101	EM20:	.ASCIZ @DATA ERROR DURING WRITE CHECK@
4118	022766	051105	047522	020122		
4119	022774	052504	044522	043516		
4120	023002	053440	044522	042524		
4121	023010	041440	042510	045503		
4122	023016	000				
4123	023017	103	047117	051124	EM21:	.ASCIZ @CONTROLLER/DRIVE ERROR VERIFYING HEADERS@
4124	023024	046117	042514	027522		
4125	023032	051104	053111	020105		
4126	023040	051105	047522	020122		
4127	023046	042526	044522	054506		
4128	023054	047111	020107	042510		
4129	023062	042101	051105	000123		
4130	023070	042510	042101	051105	EM22:	.ASCIZ @HEADER COMPARE ERROR VERIFYING HEADERS@
4131	023076	041440	046517	040520		
4132	023104	042522	042440	051122		
4133	023112	051117	053040	051105		
4134	023120	043111	044531	043516		
4135	023126	044040	040505	042504		
4136	023134	051522	000			
4137	023137	103	046131	047111	EM23:	.ASCIZ @CYLINDER FIELD IN HEADER IS NOT CORRECT@
4138	023144	042504	020122	044506		
4139	023152	046105	020104	047111		
4140	023160	044040	040505	042504		
4141	023166	020122	051511	047040		
4142	023174	052117	041440	051117		

	024310	040440	052103	040525						
	024316	020114	042510	042101						
	024324	051105	000							
	024332	040	020040	020040	DM24:	.ASCII			MEMORY	DISK//CR//LF/
	024334	020040	020040	020040						
	024342	020040	020040	020040						
	024350	020040	020040	020040						
	024356	020040	020040	020040						
	024364	020040	020040	020040						
	024372	020040	020040	046440						
	024400	046505	051117	020131						
	024406	042040	051511	006513						
	024414	012								
	024415	104	044522	042526		.ASCII	DRIVE	ERR PC	CYLNR	TRACK
	024422	020040	042440	051122					SECTOR	DATA
	024430	050040	020103	041440					DATA/	
	024436	046131	042116	020122						
	024444	052040	040522	045503						
	024452	020040	051440	041505						
	024460	047524	020122	042040						
	024466	052101	020101	020040						
	024474	042040	052101	000101						
	024502	001276			DT1:	.WORD	ATTN			
	024504	001274	012100	012102	DT2:	.WORD	DDRIVE, RPERRS, RPERRS+2, RPERRS+4, RPERRS+6, ATTN			
	024512	012104	012106	001276						
	024520	001274	017240	017242	DT3:	.WORD	DDRIVE, RD, ADR, FD, WRD			
	024526	001274	017464	017462	DT4:	.WORD	DDRIVE, WRT, AC, WRT, WD, RC, WRD			
	024534	017242								
	024536	001172			DT6:	.WORD	\$RPADR			
	024540	001214	001116	001304	DT10:	.WORD	DRIVE, \$ERRPC, RP, REG, RP, REG+10, RP, REG+12, RP, REG+14, RP, REG+40, RP, REG+42			
	024546	001314	001316	001320						
	024554	001344	001346							
	024560	001350	001352	001306		.WORD	RP, REG+44, RP, REG+46, RP, REG+2, PP, REG+4, RP, REG+6, RP, REG+16, RP, REG+20			
	024566	001310	001312	001322						
	024574	001324								
	024576	001326	001330	001332		.WORD	RP, REG+22, RP, REG+24, RP, REG+26, RP, REG+30, RP, REG+32, RP, REG+34, RP, REG+36			
	024604	001334	001336	001340						
	024612	001342								
	024614	001214	001116	001270	DT17:	.WORD	DRIVE, \$ERRPC, DS, CYL, DS, TRK, SAVSEC			
	024622	001272	001252							
	024628	001214	001116	001270	DT20:	.WORD	DRIVE, \$ERRPC, DS, CYL, DS, TRK, SAVSEC			
	024634	001272	001252							
	024640	001304	001314	001316		.WORD	RP, REG, RP, REG+10, RP, REG+12, RP, REG+14, RP, REG+40, RP, REG+42, RP, REG+44, RP, RE			
	024646	001320	001344	001346						
	024654	001350	001352							
	024660	001306	001310	001312		.WORD	RP, REG+2, RP, REG+4, RP, REG+6, RP, REG+16, RP, REG+20, RP, REG+22, RP, REG+24, RP, RE			
	024666	001322	001324	001326						
	024674	001330	001332							
	024700	001334	001336	001340		.WORD	RP, REG+30, RP, REG+32, RP, REG+34, RP, REG+36			
	024706	001342								
	024710	001214	001116	025130	DT23:	.WORD	DRIVE, \$ERRPC, \$RBUF, \$RBUF+2, \$RBUF+4, \$RBUF+6			
	024716	025120	025122	025124						

E08

MP-11-CIRJB-A.
CIRJB.013

RPO4 5,6 FORMATTER PROGRAM
ERROR MESSAGES

MACY11 27:655) 27-APR-76 17:59 PAGE 82

SEQ 0094

024724	025126						
024726	001214	001116	001270	DF24:	.WORD	*DRIVE,\$ERRPC,DS.CYL,DS.TRK,\$AVSEC,\$GDDAT,RP.REG+22	
024734	001272	001252	001124				
024742	001326						
024744	001334	001314	001316		.WORD	RP.REG,RP.REG+10,RP.REG+12,RP.REG+14,RP.REG+40,RP.REG+42,RP.REG+44,RP.REG	
024752	001320	001344	001346				
024750	001350	001352					
024764	001306	001310	001312		.WORD	RP.REG+2,RP.REG+4,RP.REG+6,RP.REG+16,RP.REG+20,RP.REG+22,RP.REG+24,RP.REG	
024772	001322	001324	001326				
025000	001330	001332					
025004	001334	001336	001340		.WORD	RP.REG+30,RP.REG+32,RP.REG+34,RP.REG+36	
025012	001342						
025014	000001			DF1:	.WORD	1	
025016	001	000			.BYTE	1,0	
025020	000001			DF2:	.WORD	1	
025022	006	000			.BYTE	6,0	
025024	000001			DF3:	.WORD	1	
025026	003	000			.BYTE	3,0	
025030	000001			DF4:	.WORD	1	
025032	004	000			.BYTE	4,0	
025034	000003			DF10:	.WORD	3	
025036	010	000			.BYTE	8,0	
025040	023511				.WORD	DH10A	
025042	007	000			.BYTE	7,0	
025044	023576				.WORD	DH10B	
025046	007	000			.BYTE	7,0	
025050	000001			DF17:	.WORD	1	
025052	005	034			.BYTE	5,34	
025054	000004			DF20:	.WORD	4	
025056	005	034			.BYTE	5,34	
025060	024001				.WORD	DH20A	
025062	010	000			.BYTE	8,0	
025064	024077				.WORD	DH20B	
025066	010	000			.BYTE	8,0	
025070	024174				.WORD	DH20C	
025072	004	000			.BYTE	4,0	
025074	000001			DF23:	.WORD	1	
025076	007	000			.BYTE	7,0	
025100	000004			DF24:	.WORD	4	
025102	007	034			.BYTE	7,34	
025104	024001				.WORD	DH20A	
025106	010	000			.BYTE	8,0	
025110	024077				.WORD	DH20B	
025112	010	000			.BYTE	8,0	
025114	024174				.WORD	DH20C	
025116	004	000			.BYTE	4,0	

:BLFFER STARTS HERE

1
 2
 3
 4
 5
 6
 7
 8
 9
 10
 11
 12
 13
 14
 15
 16
 17
 18
 19
 20
 21
 22
 23
 24
 25
 26
 27
 28
 29
 30
 31
 32
 33
 34
 35
 36
 37
 38
 39
 40
 41
 42
 43
 44
 45
 46
 47
 48
 49
 50
 51
 52
 53
 54
 55
 56
 57
 58
 59
 60
 61
 62
 63
 64
 65
 66
 67
 68
 69
 70
 71
 72
 73
 74
 75
 76
 77
 78
 79
 80
 81
 82
 83
 84
 85
 86
 87
 88
 89
 90
 91
 92
 93
 94
 95
 96
 97
 98
 99
 100

025120	000000	000000	000000
025126	000000		
025130			
025130	005015	046412	044501
025136	042116	041505	030455
025144	026461	055104	045122
025152	026502	006501	012
025157	122	030120	027454
025164	027465	020066	047506
025172	046522	052101	042524
025200	020122	051120	043517
025206	040522	006515	005012
025214	000		
025215	015	052012	020117
025222	043047	051117	040515
025230	023524	047440	020122
025236	041447	042510	045503
025244	020047	051104	053111
025252	020105	026060	051040
025260	050105	040514	042503
025266	052040	042510	023440
025274	054130	050104	006447
025302	012		
025303	120	041501	020113
025310	047117	042040	044522
025316	042526	030040	053440
025324	052111	020110	047101
025332	052117	042510	020122
025340	040520	045503	020054
025346	046103	040505	020122
025354	042515	047515	054522
025362	046040	041517	052101
025370	047511	020116	030064
025376	006454	012	
025401	101	042116	051040
025406	051505	040524	052122
025414	052040	042510	050040
025422	047522	051107	046501
025430	005015	000	

```

RSUF: .WORD 0,0,0,0 ;BUFFER FOR HEADER CHECK

BUF: ;FORMAT AND CHECK BUFFER STARTS HEPE

TITLE: .ASCII <CR><LF><LF> 'MAINDEC-11-DZRJB-A/<CR><LF>
       .ASCII2 JRP04 5/6 FORMATTER PROGRAM<CR><LF><LF>

LOADRV: .ASCII <CR><LF> 'TO 'FORMAT' OR 'CHECK' DRIVE D, REPLACE THE 'XXDP'<CR><LF>
        .ASCII  PACK ON DRIVE C WITH ANOTHER PACK, CLEAR MEMORY LOCATION 40,<CR><LF>
        .ASCII2  AND RESTART THE PROGRAM<CR><LF>

```

```

:SBTTL BUSADR - GET BUS ADDRESS AND VECTOR ADDRESS FOR RH11
:THIS ROUTINE IS USED TO INSURE THE BUS ADDRESS
:OF THE RH11 IS SETUP FOR THE PROPER ADDRESS.
:IT WILL ALSO READ THE ADDRESS FROM THE TTY IF
:REQUIRED.
:NOTE: THIS ROUTINE DESTROYS RC-R4
:CALL
:
:       JSR      PC,BUSADR
:       RETURN

```

```

4413 025434 005737 001302      BUSADR: TST      CHGADR      ; INPUT FROM TTY REQUESTED?
4414 025440 001450          BEQ        7$          ; NO--BRANCH
4415 025442 005037 001302      CLR        CHGADR      ; YES--CLEAR THE REQUEST FLAG
4416 025446 012700 001172      1$: MOV      *$RPADR,RO  ; FIRST ADDRESS
4417 025452 104401 025534      TYPE     MRPCS1      ; "RPCS1="
4418 025456 012046          MOV      (RO)+, -(SP) ; PRESENT RPCS1 ADDRESS
4419 025460 104402          TYPOC          ; TYPE IT
4420 025462 104401 020705      TYPE     .LINSF      ; 2 SPACES
4421 025466 104411          RDLIN          ; GET THE ENTRY
4422 025470 012501          MOV      (SP)+, R1    ; ADDRESS OF ASCII TEXT
4423 025472 004537 025656      JSR      R5,CK.NUM    ; CHECK THE NUMBER
4424 025476 025516          3$          ; CARRIAGE RETURN ONLY ENTERED
4425 025500 025562          7$          ; PERIOD ONLY ENTERED
4426 025502 025446          1$          ; ILLEGAL INPUT
4427 025504 025512          2$          ; TERMINATED WITH A CARRIAGE RETURN
4428 025506 025446          1$          ; TERMINATED WITH A "."
4429 025510 025556          4$          ; TERMINATED WITH A ":"
4430 025512 010260 177776      2$: MOV      R2, -2(R0) ; SAVE NEW RPCS1
4431 025516 104401 025645      3$: TYPE     MRHVEC     ; "RHVEC="
4432 025522 012046          MOV      (RO)+, -(SP) ; PRESENT RH11 VECTOR ADDRESS ON THE STACK
4433 025524 104402          TYPOC          ; TYPE IT
4434 025526 104401 020705      TYPE     .LINSF      ; 2 SPACES
4435 025532 104411          RDLIN          ; READ THE ENTRY
4436 025534 012501          MOV      (SP)+, R1    ; ASCII TEXT ADDRESS
4437 025536 004537 025656      JSR      R5,CK.NUM    ; CHECK THE NUMBER
4438 025542 025562          7$          ; CARRIAGE RETURN ONLY ENTERED
4439 025544 025562          7$          ; PERIOD ONLY ENTERED
4440 025546 025516          3$          ; ILLEGAL INPUT
4441 025550 025556          4$          ; TERMINATED WITH A CARRIAGE RETURN
4442 025552 025516          3$          ; TERMINATED WITH A "."
4443 025554 025556          4$          ; TERMINATED WITH A ":"
4444 025556 010260 177776      4$: MOV      R2, -2(R0) ; SAVE INPUT
4445 025562 013701 000004      7$: MOV      ERHVEC, R1 ; SAVE THE ERROR VECTOR
4446 025566 012737 025622 000004      MOV      *$ERHVEC    ; SETUP FOR TRAP
4447 025574 005777 153372      TST      JSR$PADR     ; CHECK FOR RH11
4448 025600 010137 000004      MOV      R1, ERHVEC   ; RESTORE ERROR VECTOR
4449 025604 012700 001172      MOV      *$RPADR,RO  ; FIRST ADDRESS OF NEW PARAMETERS
4450 025610 012701 012246      MOV      *$RPADR, R1 ; FIRST ADDRESS OF WHERE TO PUT THEM
4451 025614 012021          MOV      (RO)+, (R1)+ ; BUS ADDRESS
4452 025616 012021          MOV      (RO)+, (R1)+ ; VECTOR ADDRESS
4453 025620 000207          RTS          PC        ; RETURN
4454 025622 010137 000004      5$: MOV      R1, ERHVEC ; RESTORE ERROR VECTOR
4455 025626 022526          CMP      (SP)+, (SP)+ ; CLEAN OFF THE STACK
4456 025630 104006          ERROR     6          ; REPORT THE ERROR
4457 025632 000705          BR        1$         ; ASK FOR BUS ADDRESS
4458
4459 025634 050122 051503 020061 MRPCS1: .ASCIZ 2RPCS1 = 2
4460 025642 020075 000          000
4461 025646 122 053110 041505 MRHVEC: .ASCIZ 2RHVEC = 2
4462 025652 036440 000040

```

```

.SBTTL CK.NUM - CHECK NUMBER (OCTAL)
; THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL CHARACTERS
; AND FORMS AN OCTAL NUMBER IN R2

```


ABS = 000200	ACK = 000123	ACL = 000040	ACTDRV 012154
ACTSTR 012165	ACU = 100000	ADDRIS 022065	ADRTBL 001476
AJE = 001000	ATA = 100000	ATABIT 012234	ATTN 001276
ATO = 000001	ATI = 000002	AT2 = 000004	AT3 = 000010
AT4 = 000020	ATS = 000040	AT6 = 000100	AT7 = 000200
A16 = 000400	A17 = 001000	BADENT 021436	BAI = 000010
BEGCYL 001224	BEGIN = 002066	BEGIN1 002076	BEGIN2 002102
BEGTRK 001230	BIT0 = 000001	BIT00 = 000001	BIT01 = 000002
BIT02 = 000004	BIT03 = 000010	BIT04 = 000020	BIT05 = 000040
BIT06 = 000100	BIT07 = 000200	BIT08 = 000400	BIT09 = 001000
BIT1 = 000002	BIT10 = 002000	BIT11 = 004000	BIT12 = 010000
BIT13 = 020000	BIT14 = 040000	BIT15 = 100000	BIT2 = 000004
BIT3 = 020010	BIT4 = 000020	SIT5 = 000040	BIT6 = 000100
BIT7 = 000200	BIT8 = 000400	BIT9 = 001000	BPTVEC= 000014
BUFP 025130	BUSADR 025434	C 020675	CHGADR 001302
CI1 013606	CI3 013714	CI4 014022	CI5 014400
CI6 014422	CI7 014436	CI78 014464	CI8 014536
CKADRS 003570	CKSWR = 104407	CKTRK 004236	CK.CHR 006426
CK.DEC 006400	CK.DIG 006500	CK.NUM 025656	CK.OCT 006352
CLOCK 006104	CLR = 000040	CLRQUE 020250	CNTLC 001300
CR = 000015	CRLF = 000200	CSF = 000002	CSU = 000010
CYLCK 001246	DCK = 100000	DCL = 000100	DCU = 000001
DDISP = 177570	DDRIVE 001274	DE1 = 000040	DF20 = 000002
DF1 025014	DF10 025034	DF17 025050	DF2 025020
DF20 025054	DF23 025074	DF24 025100	DF3 025024
DF4 025030	DH1 023231	DH10 023413	DH10A 023511
DH10B 023576	DH17 023663	DH2 023236	DH20 023732
DH20A 024001	DH20B 024077	DH20C 024174	D423 024231
DH24 024327	DH3 023313	DH4 023341	DH6 023400
DIGB = 000004	DISPLA 001142	DISPRE 000174	DLT = 100000
L64 = 000020	DMC = 000001	DONE 005210	DPINT = 012140
DPR = 000400	DPRQS 012150	DRIVE 001214	DRQ = 004000
DRVACT 012110	DRVCLR= 000111	DRVINT 012476	DRVQUE 020346
DRVSTA 012120	DRVTyp 012130	DRY = 000200	DSWR = 177570
DS.CYL 001270	DS.TRK 001272	DTE = 010000	DTSY = 000200
DTJW 012232	DT00 = 000001	DT01 = 000002	DT02 = 000004
DT03 = 000010	DT04 = 000020	DT05 = 000040	DT06 = 000100
DT07 = 000200	DT08 = 000400	DT1 024502	DT10 024540
DT17 024614	DT2 = 024504	DT20 024626	DT23 024710
DT24 024726	DT3 = 024520	DT4 024526	DT6 024536
DVA = 004000	ECH = 000100	ECI = 004000	EMPTYQ 020326
EMTVEC= 000030	EM1 022112	EM10 022402	EM11 022420
EM12 022456	EM13 022521	EM14 022542	EM15 022565
EM16 022631	EM17 022703	EM2 022153	EM20 022761
EM21 023017	EM22 023070	EM23 023137	EM24 023207
EM3 022211	EM4 022247	EM5 022304	EM6 022340
ENDCYL 001222	ENDTRK 001226	ENTADR 020710	ERINDX 005234
ERR = 040000	ERPVEC= 000004	ES.SAV 020506	EXT1 = 000001
EXT10 = 000010	EXT2 = 000002	EXT20 = 000020	EXT4 = 000004
EXT40 = 000040	FEN = 000200	FER = 000020	FMTDPB 001354
FMT22 = 010000	F1 = 000002	F2 = 000004	F3 = 000010
F4 = 000020	F5 = 000040	GETREG= 000141	GETREQ 020422
GC = 000001	GRV = 000010	GTSWR = 104406	HCE = 000200
HCI = 002000	HCRC = 000400	HOREAD 004650	HEDERR 001262

HT	=	000011	IAE	=	002000	IE	=	000100	ILF	=	000001
ILR	=	000002	IOTVEC	=	000020	IR	=	000100	ISR	=	015130
IXE	=	004000	LA	=	014772	LACNT	=	012176	LF	=	000012
LINSP	=	020705	LIN4SP	=	020703	LOADRV	=	025215	LOP.CK	=	005334
LST	=	002000	MADRES	=	021456	MAXSEC	=	001266	MCCMPT	=	022011
MCLK	=	000002	MCPE	=	020000	MCPEMX	=	012244	MDRNP	=	020762
MDRVD	=	020701	MER11	=	021007	MFCMPT	=	021764	MFORMT	=	021153
MHECK	=	021174	MHS	=	001000	MINX	=	000004	MMODE	=	021121
MNOLTA	=	012260	MNRPO4	=	021036	MODE	=	001220	MOFFLN	=	020740
MOH	=	020000	MOL	=	010000	MORMAT	=	021207	MPATD	=	021660
MPE	=	000400	MRD	=	000020	MRHVEC	=	025645	MRPCS1	=	025634
MSCHK	=	021730	MSE	=	000020	MSEC20	=	021357	MSEC22	=	021300
MSELD	=	021107	MSELP	=	021560	MSFOU	=	021673	MSIZE	=	021227
MSTCK	=	000010	MUNIT	=	020557	MUSDR	=	021067	MWC	=	001260
MWR	=	000040	MXDLTA	=	012256	MXF	=	001000	MXLACT	=	012254
MXWNDW	=	012262	MO	=	003116	M1	=	002644	M1A	=	002734
M1B	=	003062	M2	=	003404	M4	=	003444	M5	=	003526
NBA	=	100000	NED	=	010000	NEM	=	004000	NHS	=	002000
NOTPRS	=	020574	NOTRP	=	020553	NOTSAF	=	020611	NUMERR	=	022035
CCYL	=	100000	OENTER	=	006116	OFFSET	=	000115	OFREV	=	000200
OF100	=	000004	OF200	=	000010	OF25	=	000001	OF400	=	000020
OF50	=	000002	OF800	=	000040	OPE	=	020000	OPI	=	020000
JFT	=	013326	OR	=	000200	PAR	=	000010	PARENT	=	006236
PAR1	=	001426	PAR2	=	001441	PAR3	=	001454	PAR4	=	001465
PAT	=	000020	PATA	=	001242	PATB	=	001244	PATSEL	=	001240
PC	=	000007	PGE	=	002000	PGM	=	001000	PIP	=	020000
PIRQ	=	177772	PIRQVE	=	000240	PLU	=	020000	POPQUE	=	020444
PRO	=	000000	PR1	=	000040	PR2	=	000100	PR3	=	000140
PR4	=	000200	PR5	=	000240	PR6	=	000300	PR7	=	000340
PS	=	177776	PSEL	=	002000	PSU	=	000001	PSW	=	177776
PWRVEC	=	000024	QCNT	=	017756	QDRV0	=	020050	QDRV1	=	020070
QDRV2	=	020110	QDRV3	=	020130	QDRV4	=	020150	QDRV5	=	020170
QDRV6	=	020210	QDRV7	=	020230	QINPT	=	017766	QOUTPT	=	020006
QSTART	=	020026	QSTOP	=	020030	QTERM	=	020250	RAW	=	000020
RBJF	=	025120	RDCHR	=	104410	RODAT	=	000171	RDHD	=	000173
RDLIN	=	104411	ROY	=	000200	RD.ADR	=	017240	RD.RP	=	017214
RD.RP1	=	017236	RD.RP2	=	017362	RD.RP3	=	017366	RD.RP4	=	017372
RD.WRD	=	017242	READIN	=	000121	RECAL	=	000107	RELS2	=	000113
RESREG	=	104413	RESVEC	=	000010	RETRY	=	001250	RMR	=	000004
RNOP	=	000101	RPADR	=	012246	RPAS	=	000016	RPBA	=	000004
RPCA	=	000034	RPCC	=	000036	RPCS1	=	000000	RPCS2	=	000010
RPDA	=	000006	RPDB	=	000022	RPDS1	=	000012	RPDT	=	000026
RPEC1	=	000044	RPEC2	=	000046	RPERRS	=	012100	RPER1	=	000014
RPER2	=	000040	RPER3	=	000042	RPINIT	=	012264	RPLA	=	000020
RPMR	=	000024	RPOF	=	000032	RPSN	=	000030	RPTMR	=	016466
RPVEC	=	012250	RPWC	=	000002	RP.REG	=	001304	RP04	=	013034
RP04B	=	020621	RP05	=	020626	RP06	=	020633	RTC	=	000117
RD	=	000000	R1	=	000001	R2	=	000002	R3	=	000003
R4	=	000004	R5	=	000005	R6	=	000006	R7	=	000007
SAVEFG	=	012206	SAVREG	=	104412	SAVSEC	=	001252	SAVWC	=	001254
SC	=	015334	SCAWC	=	005554	SC1	=	000100	SC10	=	001000
SC11	=	016166	SC12	=	016256	SC13	=	016326	SC2	=	000200
SC20	=	002000	SC3	=	015404	SC4	=	015410	SC5	=	015422
SC6	=	015622	SC6A	=	015732	SC7	=	016060	SC8	=	016136

SEARCH= 000131	SEC20 001264	SEEK = 000105	SEEKFG 012210
SELDIV= 000145	SETFMT= 000143	SETHDR 005602	SETPAT 003700
SETTBL 005402	SETVEC 002410	SET.IE 017704	SKI = 040000
SLASH 020671	SJFSW 001216	SP =%000006	SRCHWT 012162
STACK = 001100	STCLK1 006020	STCLK2 006070	STCLK3 006074
STKLMT= 177774	ST0 016560	ST01 016610	ST02 017006
ST03 017056	ST05 017102	ST06 017110	ST07 017146
ST08 017176	ST09 017206	ST.CLK 005742	SVRH11 017566
SWR 001140	SWREG 000176	SW0 = 000001	SW00 = 000001
SW01 = 000002	SW02 = 000004	SW03 = 000010	SW04 = 000020
SW05 = 000040	SW06 = 000100	SW07 = 000200	SW08 = 000400
SW09 = 001000	SW1 = 000002	SW10 = 002000	SW11 = 004000
SW12 = 010000	SW13 = 020000	SW14 = 040000	SW15 = 100000
SW2 = 000004	SW3 = 000010	SW4 = 000020	SW5 = 000040
SW6 = 000100	SW7 = 000200	SW8 = 000400	SW9 = 001000
SYSTAT 020640	T 020677	TABLE 001374	TAP = 040000
TBITVE= 000014	TD 015174	TDF = 000040	TIMER 012212
TITLE 025130	TKVEC = 000060	TPVEC = 000064	TRAPVE= 000034
TRE = 040000	TRKNT 001236	TRKTST 005472	TRK1 = 004000
TRK10 = 040000	TRK2 = 010000	TRK20 = 100000	TRK4 = 020000
TRNSWT 012160	TRTVEC= 000014	TTRKS 001232	TTRKSC 001234
TUF = 000100	TYPADR 006136	TYPDS = 104405	TYPE = 104401
TYPERR 007044	TYPOC = 104402	TYPON = 104404	TYPOS = 104403
ULDFLG 012166	UNLOAD= 000103	UNS = 040000	UNTOFF 020532
UNTON 020543	UPDACY 005662	UPDATK 005712	UPE = 020000
US1 = 000001	US2 = 000002	US4 = 000004	UWR = 000010
VUF = 000002	VU30 = 010000	VV = 000100	WAO = 000002
WC 001256	WCE = 040000	WCF = 000040	WCKD = 000151
WCKHD = 000153	WCTBL 001552	WCU = 000001	WLE = 004000
WRL = 004000	WRTDAT= 000161	WRTHD = 000163	WRTRK 004004
WRTRK1 004060	WRTRK2 004116	WRT.AD 017464	WRT.RP 017374
WRT.R1 017460	WRT.R2 017550	WRT.R3 017556	WRT.R4 017562
WRT.R5 017564	WRT.W0 017462	WRU = 000400	WSU = 000004
\$AUTOB 001134	\$BDADR 001122	\$BCDAT 001126	\$BELL 001162
\$CHARC 007510	\$CKSWR 010472	\$CMTAG 001100	\$CM3 = 000000
\$CNTLC 011367	\$CNTLG 011401	\$CNTLU 011374	\$CRLF 001167
\$DBLK 010156	\$DB20 011524	\$DECVL 011704	\$DOAGN 005204
\$DTBL 010146	\$ENDAD 005174	\$ENDCT 005160	\$ECP 005100
\$EOPCT 005152	\$ERFLG 001103	\$ERMAX 001115	\$ERROR 006636
\$ERRPC 001116	\$ERRTB 001626	\$ERTTL 001112	\$ESCAP 001160
\$FILLC 001156	\$FILLS 001155	\$GDADR 001120	\$GDDAT 001124
\$GET42 005164	\$GTSWR 010562	\$HD = 000000	\$ICNT 001104
\$INTAG 001135	\$ITEMB 001114	\$LF 001170	\$LKCSB 001200
\$LKCSR 001176	\$LKS 001206	\$LLVEC 001210	\$LPADR 001196
\$LPERR 001110	\$LPVEC 001202	\$MNEW 011417	\$MSWR 011406
\$NULL 001154	\$OCNT 007736	\$OMODE 007740	\$PASS 001100
\$QUES 001166	\$RDCHR 011034	\$RDLIN 011124	\$RDSZ = 000007
\$RESRE 011756	\$RPADR 001172	\$RPVEC 001174	\$RTNAD 005206
\$SAVRE 011720	\$SB20 011470	\$SETUP= 000106	\$STUP = 177777
\$SJPRS 011430	\$SVPC = 000200	\$SWR = 123000	\$TKB 001146
\$TKCNT 010166	\$TKINT 010204	\$TKQEN= 010203	\$TKQIN 010170
\$TKGOU 010172	\$TKQSR 010174	\$TKS 001144	\$TKSRV 010254
\$TN = 000000	\$TNPWR 011634	\$TPB 001152	\$TPFLG 001157
\$TFS 001150	\$TRAP 012014	\$TRAP2 012036	\$TRP = 000014

\$TRPAD 012050	\$STNM 001102	\$ITYIN 011360	\$TYPDS 007742
\$TYPE 007274	\$TYPEC 007444	\$TYPEX 007512	\$TYPEC 007540
\$TYPON 007554	\$TYPDS 007514	\$SET4= 000000	\$OFILL 007737
= 026016			

ERRORS DETECTED: 0

*DZRJBA DZRJE SOL LI:ME NL:MC:MD:CNO=RPO456.010.DZRJB.013
RUN-TIME: 72 49 0 SECONDS
CORE USED: 35K

