

TE16

UTILITY DRIVER
MD-11-DZTEF-A

EP-DZTEF-A-DL-A
COPYRIGHT © 1977
FICHE 1 OF 1

JUN 1977
digital
MADE IN USA



B01

EOF1DZTEERSE0

00010000

770608

PDP10 411

5:HDR1DZTEFASE0

00010000

770608

1

.REM %

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZTEF-A-D
PRODUCT NAME: TU16/TE16 UTILITY DRIVER
DATE CREATED: 21 APRIL 77
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: J. G. ADAMS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1977 BY DIGITAL EQUIPMEN CORPORATION

;TABLE OF CONTENTS

PARAGRAPH	SUBJECT	PAGE
1.	ABSTRACT	1
2.	REQUIREMENTS	1
3.	LOADING PROCEDURE	1
4.	STARTING PROCEDURE	1
5.	CONSOLE SWITCHES	1
6.	OPERATION	2
7.	PROGRAM DESCRIPTION	5
8.	LISTING	

1. ABSTRACT

THIS PROGRAM IS INTENDED AS A BRUTE FORCE ROUTINE TO EXECUTE AN OPERATION OR SERIES OF OPERATIONS, CONTINUOUSLY REGARDLESS OF THE RESULTS OF THE OPERATION. BECAUSE OF THE COMPLEXITY OF THE TUI6/TE16 MAG TAPE SYSTEM AS OPERATED ON THE MASSBUS, IT IS NOT ALWAYS POSSIBLE TO PROVIDE FOR EVERY CONTINGENCY IN THE NORMAL PROGRAMS. THEREFORE THIS UTILITY DRIVER WILL ALLOW AN OPERATOR TO EXECUTE ANYTHING DESIRED IN ANY ORDER. THERE ARE NO ERROR CHECKS OR PRINTOUTS MADE, AND ANY VARIATION FROM PRESET SEQUENCES AND VALUES ARE MADE BY CHANGING THE APPROPRIATE MEMORY LOCATIONS.

2. REQUIREMENTS2.1 HARDWARE:

- A. ANY PDP-11 PROCESSOR - WITH OR WITHOUT HARDWARE SWITCH REGISTER.
- B. RM MASSBUS CONTROLLER
- C. TMO2/TMO3 MAG TAPE CONTROLLER
- D. AT LEAST ONE (1) TUI6/TE16 SLAVE

2.2 STORAGE:

THIS PROGRAM REQUIRES AT LEAST 3K OF CORE

3. LOADING PROCEDURE:

USE STANDARD BINARY LOADING PROCEDURE

4. STARTING PROCEDURE

THE PROGRAM IS ALWAYS STARTED AT LOCATION 200 (8)

***LOC. 176 (SWREG) IS DEFINED AS THE SOFTWARE SWITCH REGISTER
(REFER TO SECTION 5 FOR MORE DETAIL)

***IF THE SOFTWARE SWITCH REGISTER IS USED THE DIAGNOSTIC TYPES OUT THE FOLLOWING
MESSAGE: SWR=XXXXXX NEW= (REFER TO SECTION 5 FOR OPERATOR OPTIONS)
AT THE START OF THE PROGRAM.

5. CONSOLE SWITCH SETTINGS

IF THE DIAGNOSTIC IS RUN ON A CPU WITHOUT A SWITCH REGISTER THEN A SOFTWARE SWITCH REGISTER IS USED WHICH ALLOWS THE USER THE SAME SWITCH OPTIONS AS THE HARDWARE SWITCH REGISTER. IF THE HARDWARE SWITCH REGISTER DOES NOT EXIST OR IF ONE DOES AND IT CONTAINS ALL ONES (177777) THEN THE SOFTWARE SWITCH REGISTER (LOC. 176) IS USED.

CONTROL:

THIS PROGRAM ALSO SUPPORTS THE DYNAMIC LOADING OF THE SOFTWARE SWITCH REGISTER (LOC. 176) FROM THE TTY. THIS CAN BE ACCOMPLISHED BY DOING THE FOLLOWING:

- 1) TYPE CONTROL G (<↑G>); THIS WILL ALLOW THE TTY TO ENTER DATA INTO LOC. 176 AT SELECTED POINTS WITHIN THE PROGRAM.
- 2) THE MACHINE WILL THEN TYPE: SWR=XXXXXXNEW= (XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWITCH REGISTER.)
- 3) AFTER THE "NEW=" HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE OF THE FOLLOWING AT THE TTY:
 - A) TYPE A NUMBER TO BE LOADED INTO LOC. 176 FOLLOWED BY A <CR> (ONLY NUMBERS BETWEEN 0-7 WILL BE ACCEPTED AND ONLY 6 NUMBERS WILL BE ALLOWED)
IF A <CR> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH REGISTER CONTENTS WILL NOT BE CHANGED.
 - B) IF A CONTROL U (<↑U>) IS DEPRESSED THEN THE PROGRAM WILL SEND YOU BACK TO STEP 2.

SW15(100000): 1=STOP AFTER EACH OPERATION

0=PROCEED

SW14(040000): 1=STOP AT THE END OF THE OPERATION SEQUENCE

0=PROCEED

SW13(020000): 1=IGNORE END OF TAPE (EOT)

0=REWIND AT END OF TAPE (EOT)

5.1 HALT

TO CHANGE THE CONTENTS OF SWREG TYPE (<↑G>) BEFORE PRESSING CONTINUE AFTER A HALT.

6. OPERATION

THE PROGRAM OPERATION IS QUITE SIMPLE, BUT DOES REQUIRE THE OPERATOR TO HAVE KNOWLEDGE OF THE TU16/TE16 TAPE SYSTEM AS OPERATED ON THE RH MASSBUS CONTROLLER. THE OPERATOR MUST BE ABLE TO DECIDE WHICH SEQUENCE OF OPERATION IS REQUIRED, AND WHAT VALUES TO ASSIGN TO THE VARIOUS PARAMETERS REQUIRED TO EXECUTE THEM. THE OPERATION SEQUENCE IS SET UP BY LOADING A TABLE WITH THE FUNCTION CODES OF THE DESIRED OPERATIONS AND SETTING THE NUMBER OF OPERATIONS IN A COUNTER. THE PROGRAM IS SET UP TO DO A WRITE OF TEN (8) WORDS OF ALL ONES DATA TO SLAVE ZERO (0) ON DRIVE ZERO (0) IN PE (1600 BPI) WITH A NINE TRACK NORMAL DATA FORMAT. THE DATA ADDRESS IS 3000 (8). THE OPERATION SEQUENCE IS SET TO DO A SINGLE WRITE. IF LOADED AND STARTED AT 200 (8) WITH NO CHANGES MADE AND SWITCH 14 AND 15 SET TO A ZERO (0), THIS OPERATION WILL BE EXECUTED CONTINUOUSLY.

THE FOLLOWING IS THE LIST OF PARAMETERS WHICH MAY BE VARIED AND A DESCRIPTION OF EACH ALONG WITH THEIR CORE LOCATION:

PARAMETER	LOCATION	DESCRIPTION
RH ADDRESS	600	ADDRESS OF RH (THE FIRST REGISTER ADDRESS: CS1)
DRIVE NUMBER	700	SET TO SELECT TMO2/TMO3 NUMBER ADDRESS 0-7
UNIT DESCRIPTION	702	SET SELECTED SLAVE NUMBER (0-7) IN BITS 0,1,2 SELECT PARITY IN BIT 3 (0=ODD 1=EVEN) SELECT DATA FORMAT IN BITS 4,5,6,7 SELECT DENSITY IN BITS 8,9,10
FRAME COUNT	704	SET NUMBER OF FRAMES TO WRITE PER WORD COUNT AND FORMAT IN TWOS' COMPLIMENT
WORD COUNT	706	SET NUMBER OF WORDS TO BE TRANSFERRED IN TWOS' COMPLIMENT
READ ADDRESS	710	SET DESIRED ADDRESS FOR START OF READ BUFFER.
WRITE ADDRESS	712	SET DESIRED ADDRESS FOR START OF WRITE BUFFER.
READY DELAY	714	THIS DELAY VALUE IS USED BY THE PROGRAM TO ESTABLISH A MAXIMUM TIME TO AWAIT THE COMPLETION OF AN OPERATION BEFORE PROCEEDING TO THE NEXT. ** (DEFAULT IS APPROX 435 MS FOR PDP-11/20)**
READY MULTIPLIER	716	IF THE VALUE SET INTO 714 DOES NOT ALLOW ENOUGH TIME, INCREASE THE SIZE OF THE MULTIPLIER. EACH INCREMENT OF THE MULTIPLIER WILL CAUSE THE 714 DELAY TO BE EXECUTED THAT MANY MORE TIMES.

OPERATION DELAY	720	THIS DELAY IS USED TO ALLOW FOR SOME AMOUNT OF TIME BETWEEN THE EXECUTION OF EACH OPERATION. IT IS LOADED AND USED JUST AS IN THE READY DELAY(714) ** (DEFAULT IS APPROX 54 MS FOR POP-11/20) **
OPER MULTIPLIER	722	THIS IS USED JUST AS THE READY DELAY MULTIPLIER(716)
OPERATION NUMBER	724	THIS IS THE NUMBER OF OPERATIONS TO BE PERFORMED IN A SEQUENCE AND SHOULD REFLECT THE NUMBERS OF OPERATIONS SET INTO THE OPERATION TABLE.
OPERATION TABLE	740-770	THIS TABLE (CONSISTING OF 15 LOCATIONS) IS TO BE LOADED WITH THE FUNCTION CODES FOR EACH OPERATION TO BE PERFORMED IN SEQUENCE. THE NUMBER OF ENTIRES MAY BE FROM ONE (1) TO FIFTEEN (15). MAKE SURE THAT THE NUMBER OF FUNCTION CODES SET IN THE TABLE IS REFLECTED BY THE NUMBER IN LOCATION 724 (OPNUM)

6.1 FUNCTION CODES

20=READ IN PRESET
 02=REWIND-OFF LINE
 06=REWIND
 10=DRIVE CLEAR
 26=WRITE TAPE MARK
 24=ERASE
 30=SPACE FORWARD
 32=SPACE REVERSE
 50=WRITE CHECK FORWARD
 56=WRITE CHECK REVERSE
 60=WRITE FORWARD
 70=READ FORWARD
 76=READ REVERSE

6.2 DATA FORMATS (BIT 7,6,5,4 OF UNIT DESCRIPTION)

14=NINE TRACK NORMAL: 2 FRAMES PER WORD
15=CORE DUMP: 4 FRAMES PER WORD

6.3 DENSITY (BITS 10,9,8 OF UNIT DESCRIPTION)

4=1600 BPI:PE (PE USES ONLY ODD PARITY)
3=800 BPI:NRZI
2=800 BPI:NRZI (TU16 ONLY)
1=556 BPI:NRZI (TU16 ONLY)
0=200 BPI:NRZI (TU16 ONLY)

6.4 PARITY (BIT 3 OF UNIT DESCRIPTION)

1=EVEN PARITY
0=ODD PARITY

6.5 SLAVE SELECT (BITS 2,1,0 OF UNIT DESCRIPTIONS)

SET TO DEVICE SLAVE ADDRESS (0-7)

7. PROGRAM DESCRIPTION

IN ORDER TO MAINTAIN THE CONTINUOUS EXECUTION OF THE OPERATIONS DESCRIBED THE PROGRAM IS ORGANIZED AS FOLLOWS:

START
INITIALIZE THE RM
SET UP TAPE PARAMETERS (DENSITY, PARITY, FORMAT: WORD COUNT, FRAME COUNT, BUS ADDRESS)
SELECT DEVICE TO TEST (DRIVE NUMBER, SLAVE NUMBER)
EXECUTE OPERATION (SET FUNCTION AND FROM OP TABLE AND SET GO=1)
AWAIT END OF OPERATION (READY DELAY)
STOP IF SWITCH 15=1
DO OPERATION DELAY (OP DELAY)
STOP IF LAST OPERATION IN SEQUENCE AND SWITCH 14=1
POINT TO NEXT FUNCTION CODE IN OP TABLE
JUMP BACK TO START

7.1 FLOW: START: HOUSEKEEPING
 INIT: CLEAR MASSBUS AND TMD2/TMD3
 SET UP: SET UP REQUIRED REGISTERS
 EXECUTE: SET FUNCTION AND GO=1
 AWAIT END: LOOP ON DRY=1 AS LONG AS ALLOWED BY READY DELAY
 STOP: IF SWITCH 15=1
 DELAY: PER OP DELAY
 END OF RSEQUENCE? IF NOT JUMP TO START
 STOP: IF SWITCH 14=1
 JUMP TO START RESTART SEQUENCE

7.2 VARIATIONS: THERE ARE TWO VARIATIONS MADE FROM THIS FLOW.
BOTH ARE CAUSED BY A PARTICULAR FUNCTION CODE.
IF A READ REVERSE IS TO BE EXECUTED, THEN THE
BUS ADDRESS IS INCREMENTED BY THE SIZE OF THE
RECORD BECAUSE THE DATA IS LOADED INTO MEMORY
IN REVERSE (I.E: HIGH ADDRESS TO LOW ADDRESS)
THE SECOND VARIATION IS CAUSED BY A SPACE (FORWARD OR REVERSE)
OPERATION AND IT IS THAT THE FRAME COUNTER IS SET TO A -1
SO THAT ONLY ONE (1) RECORD IS SPACED OVER. IF YOU WISH
TO SPACE OVER MORE THAN ONE (1) RECORD, SET LOCATION 1100 (8)
TO THE TWO'S COMPLIMENT OF THE NUMBER OF RECORDS DESIRED.

8. LISTING

310

%

.LIST BIN,LOC,SEQ

311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366

```
.TITLE TU16/TE16 UTILITY DRIVER
:MAINDEC-11-DZTUE-E-D
:15 APR 77
:J. G. ADAMS
:REVISED APRIL 1976 BY S. CARPENTER
:1) SUPPORTS SOFTWARE SWITCH REGISTER
:2) SUPPORTS THE DYNAMIC LOADING OF THE SOFTWARE SWITCH REGISTER
:REVISED APRIL 1977 BY J. G. ADAMS
```

```
:1) DOCUMENTATION CHANGES TO REFLECT TMO3/TE16 CAPABILITY
:ABS
```

;CONSOLE SWITCHES

```
;SW 15=1(100000) STOP ON EACH OPERATION
:0 CONTINUE
;SW 14=1(040000) STOP AT END OF SEQUENCE
:0 CONTINUE
;SW 13=1(020000) IGNORE END OF TAPE (EOT)
:0 REWIND AT END OF TAPE (EOT)
```

;REGISTER EQUIVES

```
R0=%0
R1=%1
R2=%2
R3=%3
R4=%4
R5=%5
SP=%6
PC=%7
```

```
000000
000001
000002
000003
000004
000005
000006
000007
```

```
.=46
RESTART: 170 ;ALLOW RESTART WHEN <LF> IS PRESSED
;DURING CHANGING OF SWREG IF SOFTWARE SWITCH
;REGISTER IS USED.
```

;SOFTWARE SWITCH REGISTER*****

```
000176
000176 000000
```

```
.=176
SWREG: 0 ;SOFTWARE SWITCH REGISTER
```

```
;THIS PROGRAM SUPPORTS THE SOFTWARE SWITCH REGISTER LOC.176.
;REFER TO SECTION 5 OF DOCUMENT FOR DESCRIPTION
```

;STARTING ADDRESS

```
000200
000200 000167 001110
```

```
.=200
JMP SETUP
```

367 000600 . =600

368
369 ; TM02/TM03 REGISTERS

370				
371	000600	172440	CI:	172440
372	000602	172442	MC:	172442
373	000604	172444	BA:	172444
374	000606	172446	FC:	172446
375	000610	172450	CS:	172450
376	000612	172452	DS:	172452
377	000614	172454	ER:	172454
378	000616	172456	AS:	172456
379	000620	172460	CC:	172460
380	000622	172462	DB:	172462
381	000624	172464	MR:	172464
382	000626	172466	DT:	172466
383	000630	172470	SN:	172470
384	000632	172472	C2:	172472

385
386 ; PROCESSOR ADDRESSES

387				
388	000634	177776	PSW:	177776 ; PROCESSOR STATUS
389	000636	177570	SWR:	177570 ; SWITCH REGISTER

390
391 ; TTY REGISTERS

392				
393	000640	177560	TKS:	177560 ; TTY READER STATUS
394	000642	177562	TKB:	177562 ; TTY READ BUFFER
395	000644	177564	TPS:	177564 ; TTY PUNCH STATUS
396	000646	177566	TPB:	177566 ; TTY PUNCH BUFFER


```

452          001000          . = 1000
453          ; START OF PROGRAM*****
454
455 001000 012706 000500 START: MOV #500, SP
456 001004 012777 000340 177622 MOV #340, @PSW
457
458 001012 016700 177706          MOV OPNUM, R0          ; SET COUNTER
459 001016 012701 000740          MOV #OPTBL, R1         ; SET POINTER
460 001022 012777 000040 177560 A:  MOV #40, @CS          ; INIT
461 001030 016777 177644 177552  MOV DRVN, @CS         ; DRIVE NUMBER
462 001036 016777 177640 177566  MOV UDES, @C2        ; UNIT DESCRIPTION
463 001044 016777 177636 177530  MOV WCNT, @MC        ; WORD COUNT
464 001052 016777 177626 177526  MOV FCNT, @FC        ; FRAME COUNT
465 001060 012102          MOV (R1), R2         ; SET OP CODE
466 001062 022702 000030          CMP #30, R2         ; SEE IF SPACE FORWARD
467 001066 001403          BEQ AA             ; IF SO: BR
468 001070 022702 000032          CMP #32, R2         ; SEE IF SPACE REVERSE
469 001074 001003          BNE AD             ; IF NOT: BR
470 001076 012777 177777 177502 AA:  MOV #-1, @FC         ; SET TO SPACE ONE RECORD
471 001104 022702 000060  AD:  CMP #60, R2         ; SEE IF READ OP
472 001110 103404          BLO A1             ; IF SO: BR
473 001112 016777 177574 177464  MOV WADDR, @BA      ; SET WRITE ADDRESS
474 001120 000413          BR A3
475 001122 016777 177562 177454 A1:  MOV RADDR, @BA      ; SET READ ADDRESS
476 001130 022702 000070          CMP #70, R2         ; SEE IF READ OPERATION
477 001134 001405          BEQ A3             ; IF SO: BR
478 001136 016703 177542          MOV FCNT, R3        ; GET FRAME COUNT
479 001142 005403          NEG R3
480 001144 060377 177434          ADD R3, @BA         ; SET BUS ADDRESS FOR READ REVERSE
481 001150 052702 000001  A3:  BIS #1, R2          ; SET GO BIT
482 001154 000240          NOP
483 001156 000240          NOP
484 001160 010277 177414          MOV R2, @C1         ; START OPERATION
485 001164 000240          NOP
486 001166 000240          NOP
487 001170 016704 177522          MOV ROYDX, R4        ; SET DELAY MULTIPLIER
488 001174 016703 177514  BO:  MOV ROYDLY, R3       ; SET READY DELAY
489 001200 032777 000200 177404 B:   BIT #200, @DS
490 001206 001005          BNE C
491 001210 005303          DEC R3
492 001212 001372          BNE B
493 001214 005304          DEC R4
494 001216 001366          BNE BO             ; DELAY FOR DRIVE READY
495 001220 000240          NOP
496 001222 005777 177410  C:   TST @SWR           ; SEE IF STOP ON OPERATION
497 001226 100001          BPL D              ; IF NOT: BR
498 001230 000000          HALT
499 001232 004767 000302  D:   JSR PC, @CKSWR     ; CHECK FOR CNTL G
500 001236 000240          NOP
501 001240 000240          NOP
502 001242 016704 177454          MOV OPDX, R4        ; SET DELAY MULTIPLIER
503 001246 016703 177446  EO:  MOV OPDLY, R3       ; SET OPERATION DELAY
504 001252 005303          DEC R3
505 001254 001376          BNE E
506 001256 005304          DEC R4
507 001260 001372          BNE EO             ; DELAY BETWEEN OPERATIONS

```

```

508 001262 004767 000152      JSR    PC,RWIND      ;GO SEE IF REWIND
509 001266 005300              DEC    RO
510 001270 001254              BNE    A              ;IF SEQUENCE NOT DONE: BR
511
512 001272 032777 040000 177336  BIT    #40000,2SMR   ;SEE IF HALT ON SEQUENCE
513 001300 001401              BEQ    IS
514 001302 000000              HALT
515 001304 004767 000230      1S:   JSR    PC,CKSMR    ;CHECK FOR CNTL G
516 001310 000167 177464              JMP
517
518                                ;RM REGISTER SETUP*****
519
520 001314 000240      SETUP:  NOP
521 001316 016701 177256      MOV    C1,R1          ;GET ADDRESS OF CS1
522 001322 012700 000015      MOV    #15,RO        ;SET NUMBER OF REGISTERS
523 001326 012702 000602      MOV    #WC,R2        ;GET FIRST ADDRESS
524 001332 062701 000002      SETA:  ADD    #2,R1   ;INCREMENT
525 001336 010122      MOV    R1,(R2)+      ;LOAD ADDRESS
526 001340 005300      DEC    RO             ;SEE IF DONE
527 001342 001373              BNE    SETA          ;IF NOT: BR
528 001344 012706 000500      MOV    #500,SP
529 001350 013746 000006      SUSMR: MOV    #6,-(SP)     ;SAVE VECTORS
530 001354 013746 000004      MOV    #4,-(SP)
531 001360 012737 001400 000004  MOV    #15,#4        ;SET UP FOR TIMEOUT
532 001366 022777 177777 177242  CMP    #1,2SMR      ;REFERENCE HARDWARE SWITCH REGISTER
533 001374 001402      BEQ    2S
534 001376 000404      BR     3S
535 001400 022626      1S:   CMP    (SP)+,(SP)+  ;ADJUST STACK
536 001402 012767 000176 177226  2S:   MOV    #SMREG,SMR  ;POINT TO SOFTWARE SWITCH REG
537 001410 012637 000004      3S:   MOV    (SP)+,#4     ;RESTORE VECTORS
538 001414 012637 000006      MOV    (SP)+,#6
539 001420 023727 000636 000176  CMP    #SMR,#SMREG  ;IS SOFTWARE REG USED
540 001426 001002      BNE    GO            ;BRANCH IF NO
541 001430 004767 000156      JSR    PC,CNTLU     ;ALLOW SOFTWARE SWITCH REGISTER TO BE CHANGED
542 001434 000167 177340      GO:   JMP    START       ;ELSE GO START EXECUTION
543
544                                ;REWIND FROM EOT (PER SW13)
545
546 001440 032777 020000 177170  RWIND: BIT    #20000,2SMR  ;SEE IF IGNORE EOT
547 001446 001033              BNE    RWINDX        ;IF SO: BR
548 001450 032777 002000 177134  BIT    #2000,2DS     ;SEE IF AT EOT
549 001456 001427              BEQ    RWINDX        ;IF NOT: BR
550 001460 012777 000040 177122  MOV    #40,2CS      ;INIT
551 001466 016777 177206 177114  MOV    DRVN,2CS     ;SET DRIVE NUMBER
552 001474 016777 177202 177130  MOV    UDES,2C2     ;SET SLAVE NUMBER
553 001502 012777 000007 177070  MOV    #7,2C1       ;START REWIND
554 001510 032777 000200 177074  RWINDA: BIT    #200,2DS ;SEE IF DRY
555 001516 001774              BEQ    RWINDA        ;IF NOT: BR
556 001520 032777 020000 177064  RWINDB: BIT    #20000,2DS ;SEE IF PIP RESET
557 001526 001374              BNE    RWINDB        ;IF NOT: BR
558 001530 005726              TST    (SP)+         ;RESET STACK
559 001532 000167 177242      JMP    START         ;RESTART SEQUENCE
560 001536 000207      RWINDX: RTS    PC   ;RETURN

```

```

561
562
563
564
565 001540 022767 000176 177070 CKSWR:  CMP      #SWREG,SWR      ;SOFTWARE SWITCH REG PRESENT
566 001546 001041          BNE      OUT      ;NO GET OUT
567 001550 105777 177064      TSTB     #TKS      ;YES WAIT FOR
568 001554 100036          BPL      OUT      ;READY GET CHARACTER
569 001556 017767 177060 177142      MOV      #TKB,TIB  ;AND STRIP OFF
570 001564 042767 177600 177134      BIC      #177600,TIB ;THE GARBAGE
571 001572 022767 000007 177126      CMP      #7,TIB    ;IS IT A <IG>
572 001600 001024          BNE      OUT
573 001602 012704 002512      MOV      #SCNTG,R4
574 001606 004767 000242      JSR      PC,TTOUT
575 001612 012704 002516      CNTLU:  MOV      #SWR,R4
576 001616 004767 000232      JSR      PC,TTOUT
577 001622 017703 177010      MOV      #SWR,R3
578 001626 004767 000354      JSR      PC,CTPE
579 001632 012704 002525      MOV      #SWNEW,R4
580 001636 004767 000212      JSR      PC,TTOUT
581 001642 005037 000736      CLR      #TEMPST
582 001646 004767 000002      JSR      PC,SREAD
583 001652 000207          OUT:      RTS      ;GO READ A LINE
584                                     ;RETURN TO MAIN BODY OF PROGRAM
585 001654 005067 177056      SREAD:  CLR      TEMPST
586 001660 012767 000007 177044      MOV      #7,COUNT
587 001666 004767 000546      1S:     JSR      PC,TTIN
588 001672 042767 177600 177026      BIC      #177600,TIB ;GO READ A CHARACTER
589 001700 122767 000025 177020      CMPB     #25,TIB    ;STRIP OFF GARBAGE
590 001706 001002          BNE      2S
591 001710 005726          3S:     TST      (SP)+
592 001712 000737          BR      CNTLU
593 001714 122767 000015 177004      2S:     CMPB     #15,TIB
594 001722 001013          BNE      4S
595 001724 012767 000200 177002      MOV      #200,RDSW
596 001732 004767 000150      JSR      PC,TCRLF
597 001736 022767 000007 176766      CMP      #7,COUNT
598 001744 001037          BNE      7S
599 001746 005726          8S:     TST      (SP)+
600 001750 000740          BR      OUT
601 001752 122767 000060 176746      4S:     CMPB     #60,TIB
602 001760 003004          BGT      5S
603 001762 122767 000067 176736      CMPB     #67,TIB
604 001770 003005          BGT      6S
605 001772 012704 002535      5S:     MOV      #SQUEST,R4
606 001776 004767 000052      JSR      PC,TTOUT
607 002002 000742          BR      3S
608 002004 006367 176726      6S:     ASL      TEMPST
609 002010 006367 176722      ASL      TEMPST
610 002014 006367 176716      ASL      TEMPST
611 002020 142767 000060 176700      BICB     #60,TIB    ;GET NITTY-GRITTY
612 002026 156767 176674 176702      BISB     TIB,TEMPST
613 002034 005367 176672      DEC      COUNT
614 002040 001754          BEQ      5S
615 002042 000711          BR      1S
616 002044 016777 176666 176564      7S:     MOV      TEMPST,#SWR ;CHANGE SWITCH REGISTER CONTENTS

```

```

617 002052 000735 BR BS
618
619
620 ;TTY OUTPUT SUBROUTINE*****
621
622 002054 112467 176650 TTOUT: MOVB (R4)+,TOB
623 002050 122767 000043 176642 CHPB #43,TOB
624 002056 001446 BEQ TEX
625 002070 122767 000045 176632 CHPB #45,TOB
626 002076 001403 BEQ TCRLF
627 002100 004767 000064 JSR PC,TOG
628 002104 000763 BR TTOUT
629 002106 112767 000015 176614 TCRLF: MOVB #15,TOB
630 002114 004767 000050 JSR PC,TOG
631 002120 012703 000004 MOV #4,R3
632 002124 005067 176600 TCRLFA: CLR TOB
633 002130 004767 000034 JSR PC,TOG
634 002134 005303 DEC R3
635 002136 001372 BNE TCRLFA ;DO FILLERS
636 002140 112767 000012 176562 MOVB #12,TOB
637 002146 004767 000016 JSR PC,TOG
638 002152 105767 176556 TSTB RDSW
639 002156 100401 BMI IS
640 002160 000735 BR TTOUT
641 002162 005067 176546 IS: CLR RDSW
642 002166 000406 BR TEX
643 002170 105777 176450 TOG: TSTB #TPS
644 002174 100375 BPL TOG
645 002176 116777 176526 176442 TEX: MOVB TOB,#TPB
646 002204 000207 RTS PC

```

```

647
648 ;OCTAL OUTPUT SUBROUTINE*****
649
650 002206 012767 000001 000222 OCTPE: MOV #1,OFL
651 002214 010304 MOV R3,R4
652 002216 000410 BR OCTPO
653 002220 005067 000212 OCTP: CLR OFL ;CLEAR FLAG FOR LEADING ZERO
654 002224 010304 OCTPE1: MOV R3,R4 ;SEE IF NUMBER IS ZERO
655 002226 001004 BNE OCTPO ;IF NOT ZERO: BR
656 002230 004767 000162 JSR PC,OCTPG1 ;ELSE PRINT ZERO
657 002234 000167 000120 JMP OCTP3 ;SPACE AND EXIT
658 002240 032704 100000 OCTPO: BIT #100000,R4 ;SEE IF MSD = 1
659 002244 001406 BEQ OCTP1 ;IF NOT: BR
660 002246 012704 000001 MOV #1,R4
661 002252 004767 000116 JSR PC,OCTPG ;PRINT 1
662 002256 000167 000006 JMP OCTP2
663 002262 005004 OCTP1: CLR R4 ;PRINT 0
664 002264 004767 000104 JSR PC,OCTPG
665 002270 010304 OCTP2: MOV R3,R4
666 002272 006004 ROR R4
667 002274 006004 ROR R4
668 002276 006004 ROR R4 ;POSITION DIGIT
669 002300 006004 ROR R4
670 002302 000304 SWAB R4
671 002304 004767 000064 JSR PC,OCTPG ;PRINT DIGIT 2
672 002310 010304 MOV R3,R4

```

```

673 002312 006004 ROR R4
674 002314 000304 SWAB R4
675 002316 004767 000052 JSR PC,OCTPG ;PRINT DIGIT 3
676 002322 010304 MOV R3,R4
677 002324 006104 ROL R4
678 002326 006104 ROL R4
679 002330 000304 SWAB R4
680 002332 004767 000036 JSR PC,OCTPG ;PRINT DIGIT 4
681 002336 010304 MOV R3,R4
682 002340 006004 ROR R4
683 002342 006004 ROR R4
684 002344 006004 ROR R4
685 002346 004767 000022 JSR PC,OCTPG
686 002352 010304 MOV R3,R4
687 002354 004767 000014 JSR PC,OCTPG ;PRINT DIGIT 5
688 002360 012767 000240 176342 OCTP3: MOV #240,T0B
689 002366 004767 177576 JSR PC,T0G ;PRINT SPACE
690 002372 000207 RTS PC ;EXIT
691 002374 042704 177770 OCTPG: BIC #177770,R4
692 002400 001004 BNE OCTPGO
693 002402 005767 000030 TST OFL
694 002406 001001 BNE OCTPGO
695 002410 000207 RTS PC
696 002412 005267 000020 OCTPGO: INC OFL
697 002416 052704 000260 OCTPG1: BIS #260,R4
698 002422 010467 176302 MOV R4,T0B
699 002426 004767 177536 JSR PC,T0G
700 002432 010304 MOV R3,R4
701 002434 000207 RTS PC
702 002436 000000 OFL: 0 ;FIRST CHAR FLAG
703
704 ;TTY READ SUBROUTINE*****
705
706 002440 005077 176174 TTIN: CLR @TKS
707 002444 005077 176172 CLR @TKB
708 002450 005067 176252 CLR TIB
709 002454 005277 176160 INC @TKS
710 002460 105777 176154 TTIN1: TSTB @TKS
711 002464 100375 BPL TTIN1
712 002466 017767 176150 176232 MOV @TKB,TIB
713 002474 105777 176144 TTIN2: TSTB @TPS
714 002500 100375 BPL TTIN2
715 002502 116777 176220 176136 MOVB TIB,@TPB
716 002510 000207 RTS PC
717
718 002512 057045 021507 SCNTG: .ASCII /%IG#/
719 002516 051445 051127 020075 SMSWR: .ASCII /%SMR= #/
720 002524 043
721 002525 040 047040 053505 SMNEW: .ASCII / NEW= #/
722 002532 020075 043
723 002535 077 021445 SQUEST: .ASCII /?%#/
724 004000
725 000100 .=4000
726 .REPT 100
727 0
728 .ENDR

```

TU16/TE16 UTILITY DRIVER
DZTEFA.P11 06-APR-77 09:55

MACY11 27(1006) 06-APR-77 09:56 PAGE 17

729	005000	.=5000	
730	000100	REPT	100
731		i77777	
732		.ENDR	
733			
734	000001	.END	

A	001022	DB	000622	OCTP1	002262	RWIDX	001536	TPS	000644
AA	001076	DRVN	000700	OCTP2	002270	SETA	001332	TTIN	002440
AS	000616	DS	000612	OCTP3	002360	SETUP	001314	TTIN1	002460
AO	001104	DT	000626	OFL	002436	SN	000630	TTIN2	002474
A1	001122	E	001252	OPDLY	000720	START	001000	TTOUT	002054
A3	001150	ER	000614	OPDX	000722	SUSWR	001350	UDES	000702
B	001200	EO	001246	OPNUM	000724	SWR	000636	WADR	000712
BA	000604	FC	000606	OPTBL	000740	SWREG	000176	WC	000602
BO	001174	FCNT	000704	OUT	001652	TCRLF	002106	WCNT	000706
C	001222	GO	001434	PSW	000634	TCRLFA	002124	SCHTG	002512
CC	000620	MR	000624	RADR	000710	TEMPST	000736	SMNEW	002525
CKSMR	001540	OCTP	002220	RDSW	000734	TEX	002204	SMSWR	002516
CNTLU	001612	OCTPE	002206	RDYDLY	000714	TIB	000726	SQUEST	002535
COUNT	000732	OCTPE1	002224	RDYDX	000716	TKB	000642	SREAD	001654
CS	000610	OCTPG	002374	RESTAR	000046	TKS	000640	.	= 005200
C1	000600	OCTPG0	002412	RWID	001440	TOB	000730		
C2	000632	OCTPG1	002416	RWIDA	001510	TOG	002170		
D	001232	OCTPO	002240	RWIDB	001520	TPB	000646		

. ABS. 005200 000

ERRORS DETECTED: 0
DEFAULT GLOBALS GENERATED: 0DZTEFA, DZTEFA/SOL+DZTEFA.P11
RUN-TIME: .6 1 0 SECONDS
RUN-TIME RATIO: 32/1=17.3
CORE USED: 5K (9 PAGES)