

IDENTIFICATION

PRODUCT CODE:	MAINDEC-8E-DBCC-D
PRODUCT NAME:	8E ADDER TESTS
DATE CREATED:	SEPT. 1, 1971
MAINTAINER:	DIAGNOSTIC GROUP
AUTHOR:	M. DAVIS & J. VROBEL

COPYRIGHT © 1971
DIGITAL EQUIPMENT CORPORATION

1,

ABSTRACT

THIS PROGRAM TESTS THE ADDER CIRCUITS OF THE PDP-8E. THE PROGRAM IS COMPOSED OF FIVE PARTS,

A SIMULATOR FOR THE TAD INSTRUCTION WHICH TESTS ALL COMBINATIONS OF TWO ARGUMENT ADDITIONS,

A SIMULATOR FOR ROTATE INSTRUCTIONS THAT TESTS ROTATION OF ALL POSSIBLE ARGUMENTS WITH RAL, RAR, RTL, RTR AND BSW,

A CARRY GENERATION TEST

A SERIES OF RANDOM NUMBER TESTS

A FIELD RELOCATION ADDER TEST

2,

REQUIREMENTS

2,1

EQUIPMENT

PDP-8E EQUIPPED WITH AT LEAST 4K OF MEMORY AND A TELETYPE

2,2

STORAGE

THE PROGRAM IS STORED IN LOCATIONS 0000-6000 AND UTILIZES LOCATIONS 7775-7777 AS A TEST AREA,

2,3

PRELIMINARY PROGRAMS

MAINDEC-8E-D0AA, D0BA

RUN ALL EXTENDED MEMORY TESTS PRIOR TO RUNNING RELOCATION ADDER TEST,

3,

LOADING PROCEDURE

THE STANDARD PROCEDURE FOR LOADING BINARY TAPES IS TO BE USED,

4,

STARTING PROCEDURE

4,1

CONTROL SWITCH SETTINGS

SR00=1 SUPPRESS HALT ON ERROR

SR01=1 SUPPRESS ERROR TYPEOUT

SR02=1 LOOP ON ERROR

SR03=1 FAST TEST

SR04=0 LOOP IN CURRENT MEMORY BANK

SR04=1 RELOCATE TO NEXT EXISTING BANK

SR06=08 AMOUNT OF EXTENDED BANKS OF MEMORY

SR09=1 HALT AT END OF TEST

SR10=1 SUPPRESS END OF TEST TYPEOUT

SR11=1 LOOP ON PRESENT TEST

4,2

STARTING ADDRESSES

NORMAL STARTING ADDRESS=0200

RESTORE LOADERS=7600

4,3 OPERATOR ACTION

4,3,1 SET SR=0200

4,3,2 PRESS ADDR LOAD SWITCH

4,3,3 SET SR=0000

4,3,4 SET SWITCH REGISTER TO DESIRED FUNCTIONS SEE 4,1

4,3,5 PRESS CLEAR AND CONT SWITCHES

5, OPERATING PROCEDURE

5,1 FAST TEST

THE ADDITION SIMULATOR NORMALLY STARTS WITH ARG1 AND ARG2 0000, TO SPEED UP THE TEST, THE VALUE OF ARG2 MAY BE SET AT SOME OTHER VALUE INITIALLY, TO DO THIS, DEPOSIT THE DESIRED VALUE IN LOCATION 170, AND PROCEED AS IN 4,, BUT WITH SR=0400 INSTEAD OF 0000 IN 4,3,3

5,2 TO RESTORE AND START BINARY LOADER, STOP PROGRAM, LOAD ADDRESS 7600 AND START COMPUTER,

5,3 RELOCATION ADDER TEST

IF SR04=1 THE ADDER TEST WILL RELOCATE TO THE NEXT SEQUENTIAL EXISTING MEMORY BANK AT THE COMPLETION OF EVERY PASS, THE EXACT AMOUNT OF EXISTING EXTENDED MEMORY BANKS MUST BE IN SR06=00 TO RUN THIS PORTION OF THE ADDER TEST, PRIOR TO EACH RELOCATION THE PROGRAM WILL COMPARE THE BANKS FOUND UNDER TEST TO THE BANK AMOUNT IN SR04=00 AND START RELOCATION, THE FOLLOWING MESSAGE WILL BE TYPED ON TELETYPE,

***** X EXTENDED BANKS OF MEMORY TO BANK X *****

5,4 OPTIONS

SEE 4,1

6, ERRORS

6,1 ERROR MESSAGES

6,1,1 SIMULATED ADDITION TEST

IF A FAILURE OCCURS DURING THE SIMULATED ADDITION TEST, THE PROGRAM WILL TYPE THE FOLLOWING MESSAGE AND THEN HALT:

SIMULATED ADD TEST FAILED
ARG1 ARG2 SIMULATED ARG1+ARG2 ARG2+ARG1
XXXXXXXXXXXXX XXXXXXXXXXXXXXXX X XXXXXXXXXXXXXXXX X XXXXXXXXXXXXXXXX X XXXXXXXXXXXXXXXX

ARG1 AND ARG2 ARE THE TWO NUMBERS THAT WERE ADDED,
SIMULATED IS THE ANSWER PRODUCED BY THE ADDITION SIMULATOR
(K AND AC)

1+ARG2 IS THE RESULT OF ADDING ARG2 TO ARG1

(ARG1 IS IN AC INITIALLY)
ARG2+ARG1 IS THE RESULT OF ADDING ARG1 TO ARG2
(ARG2 IS IN AC INITIALLY),

NOTE: EITHER THE SIMULATION OR THE ACTUAL ADDITIONS MAY
HAVE FAILED,

6.1.2 SIMULATED ROTATE TEST

IF A FAILURE OCCURS DURING THE SIMULATED ROTATE TEST, THE
PROGRAM WILL TYPE THE FOLLOWING MESSAGE AND THEN HALT:

SIMULATED AAA TEST FAILED
ORIGINAL SIMULATED ACTUAL
XXXXXXXXXXXXX X XXXXXXXXXXXXX X XXXXXXXXXXXXX

ORIGINAL IS THE LINK AND ACCUMULATOR TO BE ROTATED
SIMULATED IS THE SIMULATED RESULT OF ROTATION
ACTUAL IS THE REAL RESULT OF ROTATION
AAA IS THE INSTRUCTION BEING TESTED, I'E, RAL,RAR,RTL,RTR,BSW

6.1.3 FALSE CARRY TEST

IF A FAILURE OCCURS DURING THE FALSE CARRY TEST, THE PROGRAM
WILL TYPE THE FOLLOWING MESSAGE AND THEN HALT:

DATA ERROR
AAAA X XXXXXXXXXXXXX

AAAA IS THE STARTING ADDRESS OF THE TEST THAT FAILED
X XXXXXXXXXXXXX ARE THE CONTENTS OF THE LINK AND AC

NOTE: EACH FALSE CARRY TEST EXPECTS LINK=1 AND AC=0
AS A RESULT,

6.1.4 RANDOM ADD TEST 1

IF A FAILURE OCCURS DURING RANDOM ADD TEST 1, THE PROGRAM WILL
TYPE THE FOLLOWING MESSAGE AND THEN HALT:

RANDOM ADD TEST 1 FAILED
RANDA RANDC RESULT
XXXXXXXXXXXXX XXXXXXXXXXXXX X XXXXXXXXXXXXX

RANDA IS A RANDOM NUMBER
RANDC IS THE COMPLEMENT OF RANDA
RESULT IS THE RESULT OF CONSECUTIVE ADDITIONS OF
RANDA AND RANDC

NOTE: THE EXPECTED RESULT IS LINK=1, AC=0

6.1.5 RANDOM ADD TEST 2

IF A FAILURE OCCURS DURING RANDOM ADD TEST 2, THE PROGRAM
WILL TYPE THE FOLLOWING MESSAGE AND HALT:

RANDOM ADD TEST 2 FAILED
ARG1 ARG2 EXPECTED ARG1+ARG2
XXXXXXXXXXXXX XXXXXXXXXXXXX X XXXXXXXXXXXXX X XXXXXXXXXXXXX

6.1.6 RANDOM ROTATE TESTS

IF A FAILURE OCCURS DURING ONE OF THE RANDOM ROTATE TESTS,
THE PROGRAM WILL TYPE THE FOLLOWING MESSAGE AND THEN HALT:

RANDOM AAA TEST FAILED

ORIGINAL	ACTUAL
X XXXXXXXXXXXX	X XXXXXXXXXXXX

AAA=RAR, RAL, RTR OR RTL

6.2 ERROR HALTS

THE FOLLOWING TABLE LISTS ERROR HALT LOCATIONS AND THE TEST
THAT THEY APPLY TO

LOCATION	TEST
502	SIMAD
1066	SIMROT (WITH LOCATION OF SPECIFIC TEST IN AC)
3035	FCT (WITH LOCATION OF SPECIFIC TEST IN AC)
3510	RNAD1
4041	RNAD2
5061	RANDOM ROTATE (WITH LOCATION OF SPECIFIC TEST IN AC)

6.2 ERROR RECOVERY

DEPRESS CONT TO RESUME TEST

6.3 LOOPING ON ERROR

6.3.1 SWITCH REGISTER CONTROL

SET SR00=1 TO SUPPRESS ERROR HALT
SET SR01=1 TO SUPPRESS ERROR TYPEOUT
SET SR02=2 TO LOOP
DEPRESS CONT

6.3.2 PROGRAM MODIFICATION

THERE ARE NOPS IN EACH TEST PROVIDED TO ALLOW THE OPERATOR
TO SET UP LOOPS TIGHTER THAN THOSE AVAILABLE IN 6.3.1,

7. RESTRICTIONS

EXTENDED MEMORY TESTS SHOULD BE RUN PRIOR TO
RUNNING RELOCATION ADDER TEST,

8, EXECUTION TIME

TIME DEPENDENT ON AMOUNT OF MEMORY, FOR EACH BANK
APPROXIMATELY 35 MINUTES; IF SR03=1, AND KXXXX=7777(SEE 5,1)
ONE PASS TAKES APPROXIMATELY 40 SECONDS,

AS EACH TEST OR GROUP OF TESTS IS COMPLETED, THE NAME OF THAT
TEST WILL BE TYPED; THE SEQUENCE IS:

SIMAD
SIMROT
FCT
RANDOM

9, PROGRAM DESCRIPTION

9.1 SIMULATED ADDITION TEST

THE SIMULATED ADDITION TESTS SIMULATES THE ADDITION OF TWO
ARGUMENTS, ARG1 AND ARG2. ACTUAL ADDITIONS ARE PERFORMED, AND
THEN THE ACTUAL RESULTS ARE COMPARED TO THE SIMULATED
ANSWER,

THE SIMULATOR OPERATES IN THE FOLLOWING MANNER:
THE ARGUMENTS ARE "ANDED" TOGETHER, AND ANY BITS IN THE
RESULT THAT ARE 1'S WILL BE CARRY BITS. THE ARGUMENTS ARE
"OR'D" TOGETHER AND THE RESULT IS STORED. THE PREVIOUSLY
GENERATED CARRIES ARE ROTATED ONCE TO THE LEFT AND THEN
"ANDED" WITH THE "OR" OF THE TWO ARGUMENTS. ANY BITS THAT ARE
1'S ARE ALSO CARRIES AND THESE ARE COMBINED WITH THE PREVIOUS
CARRIES. THE PROCEDURE CONTINUES UNTIL NO NEW CARRIES ARE
GENERATED. THE FINAL CARRY RESULT IS EXCLUSIVE "OR" WITH THE
"OR" OF THE ARGUMENTS TO GET THE SIMULATED SUM.

9.2 SIMULATED ROTATE TESTS

EACH OF THE ROTATE INSTRUCTIONS, RAR, RAL, RTR, RTL AND BSW
IS SIMULATED FOR ALL POSSIBLE COMBINATIONS OF AC AND LINK,
AND THE RESULTS ARE COMPARED TO THE RESULTS OF THE ACTUAL
ROTATE,

9.3 FALSE CARRY TEST

VARIOUS COMBINATIONS OF INSTRUCTIONS AND DATA ARE USED TO
DETECT EITHER FALSE CARRIES, OR MISSINGCARRIES,

9,4 RANDOM ADD TEST 1

A RANDOM NUMBER AND ITS COMPLEMENT ARE ADDED SUCCESSIVELY
AND THE EXPECTED RESULT IS ALWAYS LINK=1, AC=0,

9,5 RANDOM ADD TEST 2

A RANDOM NUMBER, AND ITS MODIFIED COMPLIMENT ARE ADDED TO
PRODUCE 1 KNOW BIT IN THE AC, WITH THE LINK=1,

9,6 RANDOM ROTATE TEST

A RANDOM NUMBER IS SUCCESSIVELY ROTATED AND THE EXPECTED
RESULT IS THE ORIGINAL NUMBER,

9,6 RELOCATION ADDER TEST

ALL TESTS LISTED ABOVE ARE RELOCATED TO EXTENDED BANKS
AND RUN,

10, LISTING

/

/ADDER TEST

/FOR PDP-8/E

/COPYRIGHT 1970 DIGITAL EQUIPMENT CORP, MAYNARD MASS,

/V 82 07552

/

/INSTRUCTION DEFINITIONS

7501 MQA=7501

7421 MQL=7421

7002 BSW=7002

6007 CAF=6007

/SWITCH REGISTER MASK BITS

0103 SR00=K4000

0104 SR01=K2000

0105 SR02=K1000

0106 SR03=K0400

0107 SR04=K0200

0110 SR05=K0100

0111 SR06=K0040

0112 SR07=K0020

0113 SR08=K0010

0114 SR09=K0004

0115 SR10=K0002

0116 SR11=K0001

/LOCATION EQUIVALENCIES

0023 RAC=ARG1

0024 RLNK=ARG2

0031 RRAC=SUM1

0033 RRLNK=SUM2

0025 TEMPAC=SIMAC

0026 TEMPL=SIMLNK

0037 TEMP1=WD1

0037 W1=WD1

0040 W2=WD2

0035 RHFLG=AHFLG

0067 NERROP=XLOOP

/AC TO BE ROTATED

/LINK TO BE ROTATED

/AC AFTER REAL ROTATE

/LINK AFTER REAL ROTATE

/TEMPORARY AC STORAGE

/TEMPORARY LINK STORAGE

/TEMPORARY DATA STORAGE

/ " " "

/ " " "

/ " " "

/ROTATE TEST ERROR HEADER FLAG

7775 *7775

7775 0000 TSTA0, 0

7776 0000 TSTA1, 0

7777 0000 TSTA2, 0

0000 *0000

0000 0000 TSTA3, 0

0001 0001 TSTA4, JMP

0002 0002 TSTA5, 2

0003 0003 TSTA6, 3

0004 0000 TSTA7, 0

0010 *10

/ INDEX REGISTERS

0010 0000 TSTIND, 0
0011 0000 POINT1, 0
0012 0000 POINT2, 0

0020 0020 *20
0020 0000 CNTR1, 0
0021 0022 ADA1, ADA2
0022 7777 ADA2, 7777

/ SIMULATION VARIABLES

0023 0000 ARG1, 0
0024 0000 ARG2, 0
0025 0000 SIMAC, 0
0026 0000 SIMLNK, 0
0027 0000 A1ORA2, 0
0030 0000 CARRY, 0
0031 0000 SUM1, 0
0032 0000 LINK1, 0
0033 0000 SUM2, 0
0034 0000 LINK2, 0

/ MESSAGE OUTPUT VARIABLES

0035 0000 AMPLG, 0
0036 0000 CHAR, 0
0037 0000 WQ1, 0
0040 0000 WQ2, 0

/ RANDOM VARIABLES

0041 0037 RANDA, 37
0042 0000 RANDB, 0
0043 0000 RANDC, 0
0044 0000 LINKR, 0
0045 0000 LINKRC, 0

/ INDIRECT POINTERS

0046 1600 XPRINT, PRINT /CHARACTER STRING TYPE
0047 1652 XTYPE, TYPE /CHARACTER TYPE
0050 1133 XRHD, RHD /TYPE ROTATE ERROR HEADER

PAL10

V141

13-SEP-71

13131

E 1-2

0051	1200	XSROT,	SROTAL	/COMMON ROTATE SIMULATOR
0052	0756	XRALTA,	RALTAB=1	/RAL MASK TABLE
0053	1157	XRTLTA,	RTLTA=1	/RTL MASK TABLE
0054	1140	XRTRTA,	RRTTAB=1	/RTR MASK TABLE
0055	1657	XBSWTA,	BSWTAB=1	/BYTE SWAP MASK TABLE
0056	1000	XCOMRO,	COMROT	/ROTATE COMPARISON FOR SIMULATION
0057	1031	XNXTRO,	NXTROT	/ROTATE SETUP FOR SIMULATION
0060	0504	XLNKOU,	LNKOUT	/TYPE LINK
0061	0523	XWDOUT,	WDOUT	/TYPE DATA WORD
0062	3000	XAMEAS,	SAMEAS	/COMPARE DATA
0063	3730	XAMEA,	SAMEA	
0064	3017	XAVREG,	SAVREG	/SAVE AC AND LINK
0065	3037	XDATER,	DATER	/DATA ERROR HANDLER FOR FCT
0066	3027	XHALT2,	HALT2	/DATA ERROR HALT FOR FCT
0067	3046	XLOOP,	LOOP	/LOOP ON TEST
0070	7775	XSTA0,	TSTA0	
0071	7776	XSTA1,	TSTA1	
0072	7777	XSTA2,	TSTA2	
0073	3512	XRAND,	RANDOM	/RANDOM NUMBER GENERATOR
0074	0410	XLOOP2,	HLTA=4	
0075	0552	XLOOP1,	LOOP1	

/WIDELY USED CONSTANTS

0076	0240	K240,	240
0077	0260	K260,	260
0100	0261	K261,	261
0101	6000	K6000,	6000

0102	0102	XRARTA,	,
0103	4000	K4000,	4000
0104	2000	K2000,	2000
0105	1000	K1000,	1000
0106	0400	K0400,	400
0107	0200	K0200,	200
0110	0100	K0100,	100
0111	0040	K0040,	40
0112	0020	K0020,	20
0113	0010	K0010,	10
0114	0004	K0004,	4
0115	0002	K0002,	2
0116	0001	K0001,	1
0117	0000		0
0120	4000		4000
0121	0001		1

/TEST POINTERS FOR FCT

0122	2004	SEQ1,	FCT1
0123	2043	SEQ2,	FCT2
0124	2076	SEQ3,	FCT3
0125	2200	SEQ4,	FCT4
0126	2232	SEQ5,	FCT5

```
0127 2270 SEQ6, FCT6
0130 2400 SEQ7, FCT7
0131 2436 SEQ8, FCT8
0132 2472 SEQ9, FCT9
0133 2600 SEQ10, FCT10
0134 2634 SEQ11, FCT11
0135 2667 SEQ12, FCT12
```

/

/

/SETUP INSTRUCTIONS FOR FCT

/

```
0136 1376 INS1, 1376 /TAD 1, -1 IN 7777
0137 7001 INS3, 7001 /IAC
0140 5404 INS4, 5404 /JMP I, +2 IN 0000
0141 5402 INS5, 5402 /JMP I, +1 IN 0001
0142 7070 INS6, 7070 /CMA CML RAR
0143 2376 INS7, 2376 /ISZ 1, -1 IN 7777
0144 2000 INS8, 2000 /ISZ 1, +1 IN 7777
0145 2410 INS9, 2410 /ISZ 1 TSTIND
0146 4000 INS10, 4000 /JMS 1, +1 IN 7777
0147 4776 INS11, 4776 /JMS 1, -1 IN 7777
0150 4410 INS12, 4410 /JMS 1 TSTIND
0151 5403 INS13, 5403 /JMP I, +1 IN 0000
0152 5401 INS14, 5401 /JMP I, +1 IN 0000
0153 4377 INS15, 4377 /JMS 1 IN 7777
0154 2004 SEQ, FCT1
0155 5301 BIN, 5301
```

/

/TEST FOR FAST TAD SIMULATION

/

```
0156 6007 START, CAP /CLEAR ALL FLAGS
0157 7604 LAS /GET SWITCHES
0160 0100 AND SR03 /TEST SR03
0161 7650 SNA CLA /IS SR03=1
0162 5177 JMP GOTEST /DO TEST WITH ALL NUMBERS
0163 7240 CLA CMA
0164 0170 AND KXXXX /YES, START AT XXXX
0165 3024 DCA ARG2
0166 5567 JMP I, +1
0167 0202 RSIMAD*2
0170 0000 KXXXX, 0 /INSERT DESIRED STARTING VALUE FOR ARG2 HERE
0171 0000 K0, 0000
0172 0007 K0007, 0007
0173 0070 K0070, 0070
0174 0000 FL0NUM, 0
0175 0000 FLDSAV, 0
0176 0000 FLDCNT, 0
0177 *177
0177 7410 GOTEST, SKP /SKIP JMP TO START
```

/

/

/SIMULATED ADDITION TEST

/

```

) / PAL10 V141 13-SEP-71 13131 E 1-4

0200 *200
0200 5156 RSIMAD, JMP START /GO TO FAST TEST CHECK
0201 3024 DCA ARG2
0202 3023 DCA ARG1 /CLEAR SIMULATION VARIABLES
0203 3035 DCA AHFLG /CLEAR ERROR MESSAGE FLAG
/
/SIMULATE ADDITION BY SIMULATED GENERATEION OF SUM
/AND CARRY BITS
/
/FORM OR OF ARG1 WITH ARG2
/
0204 7340 SIMAD, CLA CLL CMA
0205 0023 AND ARG1 /LOAD AC WITH ARG1
0206 7421 MQL /PLACE IN MQ
0207 7040 CMA
0210 0024 AND ARG2 /LOAD AC WITH ARG2
0211 7501 MQA /FORM ARG1 OR ARG2
0212 3027 DCA A10RA2 /SAVE ARG1 OR ARG2
/
/FORM XOR(EXCLUSIVE OR) OF ARG1 WITH ARG2
/BY A XOR B=(A AND NOTB)OR(NOTA AND B)
/
0213 7501 MQA /GET ARG1 FROM MQ
0214 7040 CMA /FORM NOTARG1
0215 0024 AND ARG2 /AND WITH ARG2 TO GET ARG2 AND NOTARG1
0216 7421 MQL /SAVE IN MQ
0217 7040 CMA
0220 0024 AND ARG2 /LOAD AC WITH ARG2
0221 7040 CMA /FORM NOTARG2
0222 0023 AND ARG1 /AND WITH ARG1 TO GET ARG1 AND NOTARG2
0223 7501 MQA /OR WITH ARG2 AND NOTARG1
0224 3025 DCA SIMAC /TO GET ARG1 XOR ARG2
0225 3026 DCA SIMLNK
/
/AND ARG1 WITH ARG2
/TEST FOR CARRIES
/IF THERE ARE NO BITS IN COMMON BETWEEN ARG1 AND ARG2
/THERE WILL BE NO CARRIES GENERATED
/
0226 7040 CMA
0227 0023 AND ARG1 /LOAD AC WITH ARG1
0230 0024 AND ARG2 /AND WITH ARG2
0231 7450 SNA /ARE THERE ANY CARRIES
0232 5274 JMP ADD /NO, TERMINATE SIMULATION
/
/GENERATE CARRIES
/
0233 7421 MQL /SAVE FIRST CARRIES
0234 7521 NXTCAR, MQA MQL /GET CARRIES FROM MQ
0235 0027 AND A10RA2 /AND WITH A10RA2 TO SEE IF MORE CARRIES ARE GENERATED

```

```

/ PAL10 V141 13-SEP-71 13131 PAGE 1-5

0236 7450 SNA /ARE THERE ANY MORE CARRIES
0237 5244 JMP ENCAR /NO, END SIMULATION OF CARRIES
0240 7104 CLL RAL /PROPIGATE CARRIES
0241 7521 MQA MQL /GET PREVIOUS CARRIES FROM MQ, SAVE NEW CARRIES
0242 7501 MQA /OR NEW CARRIES WITH PREVIOUS CARRIES
0243 5234 JMP NXTCAR /CONTINUE
/
/TEST FOR CARRY INTO LINK
/
0244 7501 ENCAR, MQA /GET CARRIES
0245 0027 AND A10RA2 /AND WITH A10RA2
0246 0103 AND K4000 /TEST BIT 00
0247 7450 SNA /IS BIT 00 1
0250 5253 JMP ENCAR1 /NO, CARRIES DID NOT PROPIGATE INTO LINK
0251 3026 DCA SIMLNK /YES, SAVE CARRY INTO LINK
0252 5260 JMP XORALL /COMPLETE SIMULATION
0253 7130 ENCAR1, CLL CML RAR /SET AC=4000
0254 0023 AND ARG1 /AND WITH ARG1
0255 0024 AND ARG2 /AND WITH ARG2 TO SEE IF ORIGINAL
0256 7440 SEA /NUMBERS GENERATED CARRY INTO LINK
0257 3026 DCA SIMLNK /SAVE SIMULATED LINK
/
/FORM XOR OF ARG1, ARG2 AND CARRIES
/TO GET FINAL SIMULATED SUM
/
0260 7501 XORALL, MQA /SAVE SIMULATED CARRIES
0261 3030 DCA CARRY
0262 7501 MQA
0263 7040 CMA
0264 0025 AND SIMAC /FORM A10RA2 AND NOTCARRY
0265 7421 MQL /SAVE IN MQ
0266 7040 CMA
0267 0025 AND SIMAC
0270 7040 CMA
0271 0030 AND CARRY /FORM CARRY AND NOTA10RA2
0272 7501 MQA /OR WITH CONTENTS OF MQ
0273 3025 DCA SIMAC /TO GET FINAL SIMULATED SUM
/
/PERFORM ADDITIONS ARG1+ARG2 AND ARG2+ARG1
0274 7340 ADD, CLA CLL CMA
0275 0023 AND ARG1 /LOAD AC WITH ARG1
0276 1024 TAD ARG2 /ADD ARG2
0277 7000 NOP
0300 3031 DCA SUM1 /SAVE RESULT
0301 7010 RAR
0302 3032 DCA LINK1 /SAVE LINK
0303 7040 CMA
0304 0024 AND ARG2 /LOAD AC WITH ARG2
0305 1023 TAD ARG1 /ADD ARG1
0306 7000 NOP
0307 3033 DCA SUM2 /SAVE RESULT
0310 7010 RAR

```

PAL10 V141

13-SEP-71

13131

1-6

0311 3034
0312 7000DCA LINK2 /SAVE LINK
NOP/
/
/COMPARE RESULTS OF REAL ADDS
/IF A=B, A XOR B=0, THIS IS USED TO COMPARE RESULTS
/0313 7340
0314 0031
0315 7040
0316 0033
0317 7440
0320 5377
0321 7040
0322 0033
0323 7040
0324 0031
0325 7440
0326 5377CLA CLL CMA
AND SUM1 /GET RESULT OF ARG1+ARG2
CMA /COMPLEMENT
AND SUM2 /AND RESULTS OF ARG2+ARG1
SZA /IS SUM2 AND NOTSUM1=0
JMP ERROR1 /NO, ERROR
CMA
AND SUM2 /LOAD AC WITH RESULTS OF ARG2+ARG1
CMA /COMPLEMENT
AND SUM1 /AND WITH SUM1
SZA /IS SUM1 AND NOTSUM2=0
JMP ERROR1 /NO, ERROR
/
/
/COMPARE REAL AND SIMULATED ADDS
/0327 7340
0330 0031
0331 7040
0332 0025
0333 7440
0334 5377
0335 7040
0336 0025
0337 7040
0340 0031
0341 7440
0342 5377CLA CLL CMA
AND SUM1 /LOAD AC WITH RESULTS OF ARG1+ARG2
CMA /COMPLEMENT
AND SIMAC /AND WITH RESULTS OF SIMULATION
SZA /IS SIMAC AND NOTSUM1=0
JMP ERROR1 /NO, ERROR
CMA
AND SIMAC /LOAD AC WITH SIMULATION RESULTS
CMA /COMPLEMENT
AND SUM1 /AND WITH RESULTS OF ARG1+ARG2
SZA /IS SUM1 AND NOTSIMAC=0
JMP ERROR1 /NO, ERROR
/
/
/COMPARE LINKS GENERATED BY REAL ADDS
/0343 7340
0344 0032
0345 7004
0346 7240
0347 0034
0350 7640
0351 7020
0352 7430
0353 5377CLA CLL CMA
AND LINK1 /GET LINK FROM ARG1+ARG2
RAL
CLA CMA
AND LINK2 /GET LINK FROM ARG2+ARG1
SZA CLA
CML
SZL /ARE THEY THE SAME
JMP ERROR1 /NO, ERROR
/
/
/COMPARE LINKS GENERATED BY REAL AND SIMULATED ADDS

```

0354 7340      CLA CLL CMA
0355 0032      AND      LINK1      /GET LINK FROM ARG1+ARG2
0356 7004      RAL
0357 7240      CLA CMA
0360 0026      AND      SIMLNK      /GET LINK FROM SIMULATION
0361 7640      SZA CLA
0362 7020      CML
0363 7430      SZL
0364 5377      JMP      ERROR1      /ARE THEY THE SAME
                                         /NO, ERROR

```

/

/SET UP FOR NEXT ADDITION

```

0365 5474      NXTADD, JMP I   XLOOP2      /TEST FOR SIMULATION WITH SAME DATA
0366 2023      ISZ      ARG1      /INCREMENT ARG1
0367 5204      JMP      SIMAD      /GO TO SIMULATION
0370 2024      ISZ      ARG2      /INCREMENT ARG2
0371 7410      SKP
0372 5475      JMP I   XLOOP1      /GO TO SIMULATION
0373 7240      CLA CMA      /TEST FOR TRANSFER TO NEXT TEST
0374 0024      AND      ARG2      /TRANSFER ARG2 TO ARG1
0375 3023      DCA      ARG1
0376 5204      JMP      SIMAD      /CONTINUE SIMULATION
0377 0377      *377
0377 7000      ERROR1, NOP

```

/

/ERROR HANDLER FOR ADDITION TEST

```

0400 0400      *400
0400 7604      ADDERR, LAS
0401 0104      AND      SR01      /GET SWITCHES
0402 7650      SNA CLA      /TEST SR01
0403 4217      JMS      ADPRT      /SUPPRESS TYPEOUT IF SR01=1
0404 7604      HALTA, LAS      /TYPE ERROR MESSAGE
0405 0103      AND      SR00
0406 7650      SNA CLA      /HALT IF SR00=0
0407 4277      JMS      HALTA      /HALT WITH ADDRESS OF TEST IN AC
0410 7604      LAS
0411 0105      AND      SR02      /TEST SR02
0412 7640      SZA CLA      /LOOP WITH SAME DATA IF SR02=1
0413 5615      JMP I   XADD      /LOOP WITH SAME DATA
0414 5616      JMP I   XNXTAD
0415 0274      XADD, ADD
0416 0366      XNXTAD, NXTADD+1

```

/

/TYPE ERROR MESSAGE FOR ADDITION TEST

```

0417 0000      ADPRT, 0
0420 7340      CLA CLL CMA
0421 0035      AND      AHFLG      /GET FLAG FOR ERROR MESSAGE HEADER TYPEOUT
0422 7650      SNA CLA      /HAS HEADER FOR TEST BEEN TYPED
0423 4267      JMS      AHOUT      /NO TYPE HEADER

```


) / PAL10 V141 13-SEP-71 13131 PAGE 1-8

```

0424 7040 CMA
0425 0023 AND ARG1
0426 3037 DCA WD1
0427 4323 JMS WDOUT /OUTPUT ARG1
0430 7040 CMA
0431 0024 AND ARG2
0432 3037 DCA WD1
0433 4323 JMS WDOUT /OUTPUT ARG2
0434 7040 CMA
0435 0026 AND SIMLNK
0436 3040 DCA WD2
0437 7040 CMA
0440 0025 AND SIMAC
0441 3037 DCA WD1
0442 4304 JMS LNKOUT /OUTPUT SIMULATED LINK
0443 4323 JMS WDOUT /OUTPUT SIMULATED SUM
0444 7040 CMA
0445 0032 AND LINK1
0446 3040 DCA WD2
0447 7040 CMA
0450 0031 AND SUM1
0451 3037 DCA WD1
0452 4304 JMS LNKOUT /OUTPUT LINK1
0453 4323 JMS WDOUT /OUTPUT SUM1
0454 7040 CMA
0455 0034 AND LINK2
0456 3040 DCA WD2
0457 7040 CMA
0460 0033 AND SUM2
0461 3037 DCA WD1
0462 4304 JMS LNKOUT /OUTPUT LINK2
0463 4323 JMS WDOUT /OUTPUT SUM2
0464 4446 JMS I XPRINT
0465 5742 CRLF-1
0466 5204 JMP HLTA /TEST FOR HALT

```

/
/TYPE HEADER FOR ADDITION TEST ERROR MESSAGE
/

```

0467 0000 AHOUT, 0
0470 4446 JMS I XPRINT /TYPE "SIMULATED ADD TEST FAILED"
0471 5417 EM1-1
0472 4446 JMS I XPRINT /TYPE ARG1, ARG2, SIMULATED, ARG1+ARG2, ARG2+ARG1
0473 5177 DH1-1
0474 7240 CLA CMA /SET ADD TEST HEADER FLAG
0475 3035 DCA AHFLG /TO PREVENT MULTIPLE HEADER TYPEOUTS
0476 5667 JMP I AHOUT

```

/
/HAUT WITH ADDRESS OF TEST IN AC
/

```

0477 0000 HALTA, 0
0500 7240 CLA CMA
0501 0351 AND ADT
0502 7402 HLT /HAUT WITH ADDRESS OF ADDITION TEST IN AC
0503 5677 JMP I HALTA

```

```

/
/
/TYPE LINK
/
0504 0000 LNKOUT, 0
0505 7340 CLA CLL CMA
0506 0040 AND WD2
0507 7640 SEA CLA
0510 5320 JMP OUT1
0511 7040 CMA
0512 0077 AND K260
0513 4447 TYLNK, JMS I XTYPE
0514 7040 CMA
0515 0076 AND K240
0516 4447 JMS I XTYPE
0517 5704 JMP I LNKOUT
0520 7040 OUT1, CMA
0521 0100 AND K261
0522 5313 JMP TYLNK
/
/TYPE DATA WORD
/
0523 0000 WDOUT, 0
0524 7340 CLA CLL CMA
0525 0102 AND XRARTA
0526 3011 DCA POINT1
0527 7040 NXBIT, CMA
0530 0411 AND I POINT1
0531 7450 SNA
0532 5345 JMP SP1
0533 0037 AND WD1
0534 7640 SEA CLA
0535 5342 JMP OUT1A
0536 7040 CMA
0537 0077 AND K260

0540 4447 TYBIT, JMS I XTYPE
0541 5327 JMP NXBIT
0542 7040 OUT1A, CMA
0543 0100 AND K261
0544 5340 JMP TYBIT
0545 7040 SP1, CMA
0546 0076 AND K240
0547 4447 JMS I XTYPE
0550 5723 JMP I WDOUT
0551 0204 ADT, SIMAD
/
/END OF SIMULATED ADD TEST
/
0552 7604 LOOP1, LAS
0553 0115 AND SR10 /TEST SR10
0554 7650 SNA CLA /IS SR10=1

```

```

) / PAL10 V141 13-SEP-71 13131 F. 2 1-10
0555 5370 JMP SADOK /NO, TYPE END OF TEST MESSAGE
0556 7604 ADHLT, LAS
0557 0114 AND SR09 /TEST SR09
0560 7640 SZA CLA /IS SR09=1
0561 7402 HLT /YES, HALT AT END OF TEST
0562 7604 LAS
0563 0116 AND SR11 /TEST SR11
0564 7650 SNA CLA /IS SR11=1
0565 5377 JMP SIMR /NO, GO TO NEXT TEST
0566 5767 JMP I ,+1 /REPEAT SIMAD
0567 0204 SIMAD
0570 4446 SADOK, JMS I XPRINT
0571 5721 OK1=1
0572 5356 JMP ADHLT
0577 0577 *577
0577 7000 SIMR, NOP

```

```

/
/
/TEST ROTATION BY COMPARISON OF REAL AND SIMULATED
/ROTATES
/

```

```

0600 0600 *600
0600 4752 SIMR01, JMS I XR1 /SET UP FOR RAL TEST
/
/TEST RAL
/
0601 7340 SIMRAL, CLA CLL CMA
0602 0052 AND XRALTA /GET MASK TABLE FOR
0603 3012 DCA POINT2 /SIMULATED RAL
0604 4451 JMS I XSROT /SIMULATE RAL
0605 7340 RRAL, CLA CLL CMA
0606 0024 AND RLNK /SET UP TO DO REAL ROTATES
0607 7640 SZA CLA
0610 7020 CML
0611 7040 CMA
0612 0023 AND RAC
0613 7004 RAL /DO REAL RAL
0614 7000 NOP
0615 3031 DCA RRAC /SAVE ROTATED ACCUMULATOR
0616 7430 SEL
0617 7040 CMA
0620 3033 DCA RRLNK /SAVE ROTATED LINK
0621 4456 JMS I XCOMRO /COMPARE ROTATES
0622 5205 JMP RRAL /RETURN HERE FOR LOOP ON ERROR
0623 4457 JMS I XNXTRO /SET UP FOR NEXT ROTATE
0624 5201 JMP SIMRAL /CONTINUE RAL TEST

```

```

0625 4753 SIMR02, JMS I XR2
/
/TEST RAR

```

```

0626 7340 SIMRAR, CLA CLL CMA
0627 0102 AND XRARTA /GET MASK TABLE FOR
0630 3012 DCA POINT2 /SIMULATED RAR
0631 4451 JMS I XSROT /SIMULATED RAR
0632 7340 RRAR, CLA CLL CMA
0633 0024 AND RLNK /SET UP TP DO REAL RAR
0634 7640 SZA CLA
0635 7020 CML
0636 7040 CMA
0637 0023 AND RAC
0640 7010 RAR /DO REAL RAR
0641 7000 NOP
0642 3031 DCA RRAC /SAVE ROTATED ACCUMULATOR
0643 7430 SZL
0644 7040 CMA
0645 3033 DCA RRLNK /SAVE ROTATED LINK
0646 4456 JMS I XCOMRO /COMPARE ROTATES
0647 5232 JMP RRAR /RETURN HERE FOR LOOP ON ERROR
0650 4457 JMS I XNXTRO /SET UP FOR NEXT ROTATE
0651 5226 JMP SIMRAR /CONTINUE RAR TEST

```

```

0652 4754 SIMR03, JMS I XR3

```

```

/TEST RTL
/

```

```

0653 7340 SIMRTL, CLA CLL CMA
0654 0053 AND XRTLTA /GET MASK TABLE FOR
0655 3012 DCA POINT2 /SIMULATED RTL
0656 4451 JMS I XSROT /SIMULATE RTL
0657 7340 RRTL, CLA CLL CMA
0660 0024 AND RLNK /SET UP TO DO REAL ROTATE
0661 7640 SZA CLA
0662 7020 CML
0663 7040 CMA
0664 0023 AND RAC
0665 7006 RTL /DO REAL ROTATE
0666 7000 NOP
0667 3031 DCA RRAC /SAVE ROTATED ACCUMULATOR
0670 7430 SZL
0671 7040 CMA
0672 3033 DCA RRLNK /SAVE ROTATED LINK
0673 4456 JMS I XCOMRO /COMPARE ROTATES
0674 5257 JMP RRTL /RETURN HERE FOR LOOP ON ERROR
0675 4457 JMS I XNXTRO /SET UP TO DO NEXT ROTATE
0676 5253 JMP SIMRTL /CONTINUE RTL TEST

```

```

0677 4755 SIMR04, JMS I XR4

```

```

/TEST RTR
/

```

PAL10

V141

13-SEP-71

13131

1-12

```

0700 7340 SIMRTR, CLA CLL CMA
0701 0054 AND XRTRTA /GET MASK TABLE FOR
0702 3012 DCA POINT2 /SIMULATED RTR
0703 4451 JMS I XSROT /SIMULATE RTR
0704 7340 RRTR, CLA CLL CMA
0705 0024 AND RLNK /SET UP TO DO REAL ROTATE
0706 7640 SZA CLA
0707 7020 CML
0710 7040 CMA
0711 0023 AND RAC
0712 7012 RTR /DO REAL ROTATE
0713 7000 NOP
0714 3031 DCA RRAC /SAVE ROTATED ACCUMULATOR
0715 7430 SZL
0716 7040 CMA
0717 3033 DCA RRLNK /SAVE ROTATED LINK
0720 4456 JMS I XCOMRO /COMPARE ROTATES
0721 5304 JMP RTR /RETURN HERE FOR LOOP ON ERROR
0722 4457 JMS I XNXTRO /SET UP TO DO NEXT ROTATE
0723 5300 JMP SIMRTR /CONTINUE RTR TEST

```

```

0724 4736 SIMR05, JMS I XR5
/
/TEST BYTE SWAP
/
0725 7340 SIMBSW, CLA CLL CMA
0726 0055 AND XBSWTA /GET MASK TABLE FOR
0727 3012 DCA POINT2 /SIMULATED BSW
0730 4776 JMS I XSBSW /SIMULATE BSW
0731 7340 RBSW, CLA CLL CMA
0732 0024 AND RLNK /SET UP FOR REAL BSW
0733 7640 SZA CLA
0734 7020 CML
0735 7040 CMA
0736 0023 AND RAC
0737 7002 BSW /DO REAL BSW
0740 7000 NOP
0741 3031 DCA RRAC /SAVE ROTATED ACCUMULATOR
0742 7430 SZL
0743 7040 CMA
0744 3033 DCA RRLNK /SAVE ROTATED LINK
0745 4456 JMS I XCOMRO /COMPARE ROTATES
0746 5331 JMP RBSW /RETURN HERE FOR LOOP ON ERROR
0747 4457 JMS I XNXTRO /SET UP FOR NEXT ROTATE
0750 5325 JMP SIMBSW /CONTINUE BSW TEST
0751 5777 JMP I XROTDN /END OF ROTATE SIMULATION TESTS

```

```

0752 1400 XR1, R1
0753 1410 XR2, R2
0754 1420 XR3, R3
0755 1430 XR4, R4
0756 1440 XR5, R5
0757 0001 RALTAB, 1

```

0760	0002	2
0761	0004	4
0762	0010	10
0763	0020	20
0764	0040	40
0765	0100	100
0766	0200	200
0767	0400	400
0770	1000	1000
0771	2000	2000
0772	4000	4000
0773	0000	0
0774	0001	1
0775	4000	4000
0776	1236	XSBW, SBW
0777	1323	XROT, ROTDNE

/

/ (TAPE 2)

/ COMPARE RESULTS OF REAL AND SIMULATED ROTATES

/

1000 1000 *1000

1000 0000 COMROT, 0

/

/ COMPARE ROTATED ACCUMULATORS

/

1001	7340	CLA CLL CMA	
1002	0005	AND SIMAC	/GET SIMULATED ROTATED ACCUMULATOR
1003	7040	CMA	/COMPLEMENT
1004	0031	AND RRAC	/AND WITH REAL ROTATED ACCUMULATOR
1005	7440	SZA	/IS NOTSIMAC AND RRAC=0
1006	5226	JMP ERROT	/NO, ERROR
1007	7040	CMA	
1010	0031	AND RRAC	/GET REAL ROTATED ACCUMULATOR
1011	7040	CMA	/COMPLEMENT
1012	0025	AND SIMAC	/AND WITH SIMULATED ROTATED ACCUMULATOR
1013	7440	SZA	/IS SIMAC AND NOTRRAC=0
1014	5226	JMP ERROT	/NO, ERROR

/

/ COMPARE ROTATED LINKS

/

1015	7340	CLA CLL CMA	
1016	0026	AND SIMLNK	/GET SIMULATED LINK
1017	7640	SZA CLA	
1020	7020	CML	
1021	7040	CMA	
1022	0033	AND RRLNK	/GET REAL ROTATED LINK
1023	7440	SZA	
1024	7020	CML	
1025	7430	SZL	/ARE THEY THE SAME
1026	5246	JMP ERROR2	/NO, ERROR

ERROT,

PAL18

V141

13-SEP-71

13131

DE 1-14

```

1027 2200      ISZ      COMROT      /RETURN HERE IF NO LOOP ON ERROR
1030 5600      JMP I    COMROT
/
/
/SET UP TO DO NEXT ROTATE
/
1031 0000      NXTROT, 0
1032 7340      CLA CLL CMA
1033 0024      AND      RLNK      /GET LINK OF WORD TO BE ROTATED
1034 7640      SZA CLA      /IS IT 0
1035 5244      JMP      NEWLNK    /NO, CLEAR IT
1036 7040      CMA      /YES, SET IT
1037 3024      DCA      RLNK
1040 2023      ISZ      RAC      /INCREMENT NUMBER TO BE ROTATED
1041 5631      JMP I    NXTROT    /CONTINUE SIMULATION OF PRESENT ROTATE INSTRUCTION
1042 2231      ISZ      NXTROT    /PRESENT SIMULATION DONE
1043 5631      JMP I    NXTROT    /GO TO NEXT TEST
1044 3024      NEWLNK, DCA      RLNK
1045 5631      JMP I    NXTROT

```

```

/
/
/ERROR HANDLER FOR ROTATE TEST
/

```

```

1046 7604      ERROR2, LAS
1047 0104      AND      SR01      /TEST SR01
1050 7650      SNA CLA      /IS SR01=1
1051 4271      JMS      ROTPRY    /NO, TYPE ERROR MESSAGE
1052 7604      HLTB,  LAS
1053 0103      AND      SR00      /TEST SR00
1054 7650      SNA CLA      /IS SR00=1
1055 5263      JMP      HALTB     /NO, HALT WITH ADDRESS OF TEST IN AC
1056 7604      LAS
1057 0105      AND      SR02      /TEST SR02
1060 7650      SNA CLA      /IS SR02=1
1061 5227      JMP      ERROT+1    /NO, GO TO NEW DATA
1062 5230      JMP      ERROT+2    /YES, LOOP WITH SAME DATA
1063 7340      HALTB,  CLA CLL CMA
1064 0451      AND I    XSROT
1065 1270      TAD      M4
1066 7402      HLT
1067 5256      JMP      HLTB+4
1070 7774      M4,      =4

```

```

/
/ERROR TYPEOUT FOR SIMULATED ROTATE TEST ERRORS
/

```

```

1071 0000      ROTPRY, 0
1072 7340      CLA CLL CMA
1073 0035      AND      RHFLG     /GET ROTATE TEST HEADER FLAG
1074 7650      SNA CLA      /HAS HEADER BEEN TYPED

```

1075	4331	JMS	RHOUT	/NO, TYPE HEADER
1076	7040	CMA		
1077	0023	AND	RAC	
1100	3037	DCA	WD1	
1101	7040	CMA		
1102	0024	AND	RLNK	
1103	3040	DCA	WD2	
1104	4460	JMS I	XLNKOU	/OUTPUT ORIGINAL LINK
1105	4461	JMS I	XWDOUT	/OUTPUT ORIGINAL WORD
1106	7040	CMA		
1107	0025	AND	SIMAC	
1110	3037	DCA	WD1	
1111	7040	CMA		
1112	0026	AND	SIMLNK	
1113	3040	DCA	WD2	
1114	4460	JMS I	XLNKOU	/OUTPUT SIMULATED ROTATED LINK
1115	4461	JMS I	XWDOUT	/OUTPUT SIMULATED ROTATED WORD
1116	7040	CMA		
1117	0031	AND	RRAC	
1120	3037	DCA	WD1	
1121	7040	CMA		
1122	0033	AND	RRLNK	
1123	3040	DCA	WD2	
1124	4460	JMS I	XLNKOU	/OUTPUT ACTUAL ROTATED LINK
1125	4461	JMS I	XWDOUT	/OUTPUT ACTUAL ROTATED WORD
1126	4446	JMS I	XPRINT	
1127	5742	CRLF-1		
1130	5671	JMP I	ROTPRT	

/

/OUTPUT HEADER FOR ROTATE ERROR MESSAGE

/

1131	0000	RHOUT,	0	
1132	4446	JMS I	XPRINT	/TYPE SIMULATED XXX TEST FAILED
1133	0000	RHD,	0	/WHERE XXX IS THE INSTRUCTION THAT FAILED
1134	4446	JMS I	XPRINT	/TYPE ORIGINAL, SIMULATED ACTUAL
1135	5244	DH2-1		
1136	7240	CLA CMA		
1137	3035	DCA	RHFLG	
1140	5731	JMP I	RHOUT	

1141	2000	RIRTAB,	2000
1142	0400		400
1143	0100		100
1144	0020		20
1145	0004		4
1146	0001		1
1147	4000		4000
1150	1000		1000
1151	0200		200
1152	0040		40
1153	0010		10
1154	0002		2

) / PAL10 V141 13-SEP-71 13131 1-16)

1155	0000	0
1156	2000	2000
1157	0002	2
1160	0002	RTL TAB, 2
1161	0010	10
1162	0040	40
1163	0200	200
1164	1000	1000
1165	4000	4000
1166	0001	1
1167	0004	4
1170	0020	20
1171	0100	100
1172	0400	400
1173	2000	2000
1174	0000	0
1175	0002	2
1176	2000	2000

/

/

/ROTATION SIMULATOR COMMON ROUTINE

/ROTATE FUNCTION SIMULATED DEPENDS

/UPON MASK TABLE SELECTED

/

1200	0000	*1200	
1201	7300	SROTAL, 0	
1202	3025	CLA CLL	
1203	3026	DCA SIMAC	/CLEAR SIMULATION ARGUMENTS
1204	7040	DCA SIMLNK	
1205	0412	CMA	
1206	3037	AND I POINT2	/GET FIRST MASK BIT FROM TABLE
1207	7040	DCA WD1	
1210	0412	CMA	
1211	7450	AND I POINT2	/GET MASK BIT FROM TABLE
1212	5303	SNA	/IS IT 0
1213	3040	JMP ENDROT	/YES, FINISH SIMULATION
1214	7040	DCA WD2	
1215	0023	CMA	
1216	0037	AND RAC	/LOAD AC WITH WORD TO BE ROTATED
1217	7440	AND WD1	/TEST BIT TO BE ROTATED
1220	4225	SEA	/IS IS 0
1221	7040	JMS OR1	/NO, PLACE BIT INTO NEW POSITION
1222	0040	CMA	
1223	3037	AND WD2	/BIT TO BE ROTATED
1224	5207	DCA WD1	/BECOMES NEW MASK
		JMP NBIT	/CONTINUE SIMULATION
		/	
		/OR BITS TO FORM PARTIALLY ROTATED WORD	
		/	
1225	0000	OR1, 0	
1226	7240	CLA CMA	

/	PAL10	V141	13-SEP-71	13131	PAGE 1-17
1227	0040		AND	WD2	/GET BIT TO BE INSERTED
1230	7421		MQL		/SAVE IN MQ
1231	7040		CMA		
1232	0025		AND	SIMAC	/GET SIMULATED ROTATED WORD
1233	7501		MQA		/OR BIT INTO POSITION
1234	3025		DCA	SIMAC	/SAVE PARTIALLY ROTATED WORD
1235	5625		JMP I	OR1	

		/			
		/SIMULATE BYTE SWAP			
		/			
1236	0000	SBSW,	0		
1237	7340		CLA CLL CMA		
1240	0236		AND	SBSW	/SET UP FOR ERROR RETURN
1241	3451		DCA I	XSR0T	
1242	3025		DCA	SIMAC	/CLEAR SIMULATION ARGUMENTS
1243	3026		DCA	SIMLNK	
1244	7040	N1BIT,	CMA		
1245	0412		AND I	POINT2	/GET MASK FROM TABLE
1246	7450		SNA		/IS IT 0
1247	5277		JMP	ENDBSW	/YES, FINISH SIMULATION
1250	3037		DCA	WD1	
1251	7040		CMA		
1252	0412		AND I	POINT2	
1253	3040		DCA	WD2	
1254	7040		CMA		
1255	0023		AND	RAC	/GET WORD TO BE ROTATED
1256	0037		AND	WD1	/TEST BIT TO BE ROTATED
1257	7440		SZA		/IS IT 0
1260	4225		JMS	OR1	/NO, PLACE BIT IN NEW POSITION
1261	7040		CMA		
1262	0037		AND	WD1	/INTERCHANGE MASK AND BIT TO BE ROTATED
1263	7421		MQL		
1264	7040		CMA		
1265	0040		AND	WD2	
1266	3037		DCA	WD1	
1267	7501		MQA		
1270	3040		DCA	WD2	
1271	7040		CMA		
1272	0023		AND	RAC	/GET WORD TO BE ROTATED
1273	0037		AND	WD1	/TEST BIT TO BE ROTATED
1274	7440		SZA		/IS IT 0
1275	4225		JMS	OR1	/NO, PLACE BIT IN NEW POSITION
1276	5244		JMP	N1BIT	/CONTINUE SIMULATION
1277	7340	ENDBSW,	CLA CLL CMA		
1300	0024		AND	RLNK	
1301	3026		DCA	SIMLNK	
1302	5636		JMP I	SBSW	

/

/END OF ROTATE, SHIFT LINK

```

1303 7340 ENDROT, CLA CLL CMA
1304 0412 AND I POINT2 /GET BIT TO BE ROTATED FROM LINK
1305 3040 DCA WD2
1306 7040 CMA
1307 0116 AND K0001 /GET MASK FOR LINK
1310 0024 AND RLNK /TEST LINK
1311 7440 SZA /IS LINK 0
1312 4225 JMS OR1 /PLACE LINK IN NEW POSITION
1313 7040 CMA
1314 0412 AND I POINT2 /GET MASK FOR BIT TO BE ROTATED INTO LINK
1315 0023 AND RAC /TEST BIT IN WORD TO BE ROTATED INTO LINK
1316 7440 SZA /IS IT 0
1317 7240 CLA CMA /NO, SET LINK=1
1320 0116 AND K0001
1321 3026 DCA SIMLNK
1322 5600 JMP I SROTAL

1323 7604 ROTONE, LAS
1324 0115 AND SR10 /TEST SR10
1325 7650 SNA CLA /IS SR10=1
1326 5342 JMP SROTOK /NO, TYPE "SIMROT"
1327 7604 ROTHLT, LAS
1328 0114 AND SR09 /TEST SR09
1331 7640 SZA CLA /IS SR09=1
1332 7402 HLT /YES, HALT AT END OF ROTATE TESTS
1333 7604 LAS
1334 0116 AND SR11 /TEST SR11
1335 7650 SNA CLA /IS SR11=1
1336 5740 JMP I ,+2 /NO, GO TO NEXT TEST
1337 5741 JMP I ,+2 /YES, REPEAT ROTATE TESTS
1340 2000 FCT
1341 0600 SIMROT
1342 4446 SROTOK, JMS I XPRINT
1343 5725 OK2-1
1344 5327 JMP ROTHLT

```

/
/
/SET UP FOR ROTATE TESTS
/

```

1400 1400 PAGE
1400 0000 R1, 0
1401 7340 CLA CLL CMA
1402 0250 AND XM2 /SET UP HEADER
1403 3450 DCA I XRHD /FOR RAL TEST ERROR MESSAGE
1404 3035 DCA RHFLG /CLEAR ROTATE HEADER FLAG
1405 3024 DCA RLNK
1406 3023 DCA RAC
1407 5600 JMP I R1
1410 0000 R2, 0
1411 7340 CLA CLL CMA

```

/	PAL10	V141	13-SEP-71	13131	PAGE 1-19
1412	0251		AND	XM3	/SET UP HEADER
1413	3450		DCA I	XRWD	/FOR RAR TEST ERROR MESSAGE
1414	3035		DCA	RHFLG	
1415	3024		DCA	RLNK	
1416	3023		DCA	RAC	
1417	5610		JMP I	R2	
1420	0000	R3,		0	
1421	7340		CLA CLL	CMA	
1422	0252		AND	XM4	/SET UP HEADER
1423	3450		DCA I	XRWD	/FOR RTR TEST ERROR MESSAGE
1424	3035		DCA	RHFLG	
1425	3024		DCA	RLNK	
1426	3023		DCA	RAC	
1427	5620		JMP I	R3	
1430	0000	R4,		0	
1431	7340		CLA CLL	CMA	
1432	0253		AND	XM5	/SET UP HEADER
1433	3450		DCA I	XRWD	/FOR RTL TEST ERROR MESSAGE
1434	3035		DCA	RHFLG	
1435	3024		DCA	RLNK	
1436	3023		DCA	RAC	
1437	5630		JMP I	R4	
1440	0000	R5,		0	
1441	7340		CLA CLL	CMA	
1442	0254		AND	XM6	/SET UP HEADER
1443	3450		DCA I	XRWD	/FOR BSW TEST ERROR MESSAGE
1444	3035		DCA	RHFLG	
1445	3024		DCA	RLNK	
1446	3023		DCA	RAC	
1447	5640		JMP I	R5	
1450	5440	XM2,		EM2-1	
1451	5461	XM3,		EM3-1	
1452	5502	XM4,		EM4-1	
1453	5523	XM5,		EM5-1	
1454	5544	XM6,		EM6-1	

/

/

/CHARACTER STRING TYPE ROUTINE

/*=RETURN, +=LINE FEED

1600	0000	PAGE	
1601	7300	PRINT,	0
1602	1600		CLA CLL
1603	3011		TAD I PRINT
1604	2200		DCA POINT1
1605	1411		ISZ PRINT
1606	3036		TAD I POINT1
1607	1036		DCA CHAR
1610	7012		TAD CHAR
1611	7012		RTR
1612	7012		RTR
1613	4217		RTR
1614	1036		JMS TYPSET
1615	4217		TAD CHAR
			JMS TYPSET

```

1616 5205      JMP      PRINT+5
1617 0000      TYPSET, 0
1620 0245      AND      K0077
1621 7450      SNA
1622 5600      JMP I    PRINT
1623 1246      TAD      M40
1624 7510      SPA
1625 5230      JMP      ,+3
1626 1076      TAD      K240
1627 5243      JMP      MTP
1638 7001      IAC
1631 7440      SEA
1632 5235      JMP      ,+3
1633 1251      TAD      K215
1634 5243      JMP      MTP
1635 7001      IAC
1636 7440      SEA
1637 5242      JMP      ,+3
1640 1250      TAD      K212
1641 5243      JMP      MTP
1642 1247      TAD      K336
1643 4447      MTP,     JMS I  XTYPE
1644 5617      JMP I    TYPSET
1645 0077      K0077, 0077
1646 7740      M40,    7740
1647 0336      K336,   0336
1650 0212      K212,   0212
1651 0215      K215,   0215
1652 0000      TYPE,   0
1653 6046      TLS
1654 6041      TSP
1655 5254      JMP      ,+1
1656 7200      CLA
1657 5652      JMP I    TYPE

```

```

1660 0001      BSWTAB, 1
1661 0100      100
1662 0002      2
1663 0200      200
1664 0004      4
1665 0400      400
1666 0010      10
1667 1000      1000
1670 0020      20
1671 2000      2000
1672 0040      40
1673 4000      4000
1674 0000      0

```

```

2000 2000      PAGE
2000 7300      FCT,   CLA CLL
2001 1122      TAD      SEQ1
2002 3154      DCA      SEQ

```

2003 3020 DCA CNTR1

/

/

/FALSE CARRY TEST#1

2004 7300 FCT1,

CLA CLL

/PLACE INSTRUCTIONS AND DATA IN TEST ADDRESSES

2005 7300 FCS1,

CLA CLL

/DATA=0000

2006 3471

DCA I XSTA1

/LOC,=7776

2007 1136

TAD INS1

/INSTRUCTION=TAD ,+1

2010 3472

DCA I XSTA2

/LOC,=7777

2011 1332

TAD INS2

/INSTRUCTION=TAD ,+3

2012 3000

DCA TSTA3

/LOC,=0000

2013 1137

TAD INS3

/INSTRUCTION=IAC

2014 3001

DCA TSTA4

/LOC,=0001

2015 1140

TAD INS4

/INSTRUCTION=JMP I ,+2

2016 3002

DCA TSTA5

/LOC,=0002

2017 7240

CLA CMA

/DATA=7777

2020 3003

DCA TSTA6

/LOC,=0003

2021 1327

TAD ADI

/ADDRESS=RETI

2022 3004

DCA TSTA7

/LOC,=0004

/

/EXECUTE INSTRUCTIONS PREVIOUSLY ASSEMBLED IN TEST

/ADDRESSES

2023 7300 FCL1,

CLA CLL

2024 3472

JMP I XSTA2

2025 7000 RET1,

NOP

/PROVIDED FOR PROGRAM MODIFICATION

2026 7000

NOP

2027 4464

JMS I XAVREG

/SAVE LINK AND AC

/

/EXPECTED RESULTS ARE AC=0, LINK=1

2030 7430

SZL

2031 7440

SZA

2032 4465

JMS I XDATER

/COMPUTATION ERROR HAS OCCURED

2033 7410

SKP

2034 4466

JMS I XHALT2

/TEST FOR HALT

2035 4467

JMS I XLOOP

/TEST FOR LOOP

2036 5223

JMP FCL1

2037 7200

CLA

2040 1123

TAD SEQ2

/ADDRESS OF NEXT TEST

2041 3154

DCA SEQ

2042 5554

JMP I SEQ

/GO TO NEXT TEST

/

/

/FALSE CARRY TEST#2

2043 7300 FCT2,

CLA CLL

```

/
/PLACE INSTRUCTIONS AND DATA IN TEST ADDRESSES
/
2044 7340 FCS2, CLA CLL CMA /DATA=7777
2045 3471 DCA I XSTA1 /LOC,=7776
2046 1136 TAD INS1 /INSTRUCTION=TAD I ,+1
2047 3472 DCA I XSTA2 /LOC,=7777
2050 1137 TAD INS3 /INSTRUCTION=IAC
2051 3000 DCA TSTA3 /LOC,=0000
2052 1141 TAD INS5 /INSTRUCTION=JMP I ,+1
2053 3001 DCA TSTA4 /LOC,=0001
2054 1330 TAD AD2 /ADDRESS=RET2
2055 3002 DCA TSTA5 /LOC,=0002
/
/EXECUTE INSTRUCTIONS PREVIOUSLY ASSEMBLED IN TEST
/ADDRESSES
/
2056 7300 FCL2, CLA CLL
2057 3472 JMP I XSTA2
2060 7000 RET2, NOP
2061 7000 NOP
2062 4464 JMS I XAVREG /SAVE AC AND LINK
/
/EXPECTED RESULTS ARE AC=0, LINK=1
/
2063 7430 SZL
2064 7440 SZA
2065 4465 JMS I XDATER
2066 7410 SKP
2067 4466 JMS I XHALT2
2070 4467 JMS I XLOOP
2071 5256 JMP FCL2
2072 7200 CLA
2073 1124 TAD SEQ3
2074 3154 DCA SEQ
2075 5554 JMP I SEQ
/
/
/FALSE CARRY TEST #3
/
2076 7300 FCT3, CLA CLL
/
/
2077 1137 FCS3, TAD INS3 /INSTRUCTION=IAC
2100 3471 DCA I XSTA1 /LOC,=7776
2101 1333 TAD INS16 /INSTRUCTION=TAD I 21
2102 3472 DCA I XSTA2 /LOC,=7777
2103 1152 TAD INS14 /INSTRUCTION=JMP I ,+1
2104 3000 DCA TSTA3 /LOC,=0000
2105 1331 TAD AD3 /ADDRESS=RET3
2106 3001 DCA TSTA4 /LOC,=0001
/

```

```

/
/
/
2107 7300 FCL3, CLA CLL
2110 5471 JMP I XSTA1
2111 7000 RET3, NOP
2112 7000 NOP
2113 4464 JMS I XAVREG
/
/
/
2114 7430 SEL
2115 7440 SZA
2116 4465 JMS I XDATER
2117 7410 SKP
2120 4466 JMS I XHALT2
2121 4467 JMS I XLOOP
2122 5307 JMP FCL3
2123 7200 CLA
2124 1125 TAD SEQ4
2125 3154 DCA SEQ
2126 5554 JMP I SEQ
2127 2025 AD1, RET1
2130 2060 AD2, RET2
2131 2111 AD3, RET3
2132 1003 INS2, 1003
2133 1421 INS16, 1421

```

/STAD ,+3 IN 0000

2200 PAGE

```

/
/
/ FALSE CARRY TEST #4
/
2200 7300 FCT4, CLA CLL
/
/
/
2201 7340 FCS4, CLA CLL CMA
2202 3471 DCA I XSTA1
2203 1136 TAD INS1
2204 3472 DCA I XSTA2
2205 1142 TAD INS6
2206 3000 DCA TSTA3
2207 1141 TAD INS5
2210 3001 DCA TSTA4
2211 1324 TAD AD4
2212 3002 DCA TSTA5
/
/
/
2213 7340 FCL4, CLA CLL CMA

```

```

/ DATA=7777
/ LOC,=7776
/ INSTRUCTION=TAD ,+1
/ LOC,=7777
/ INSTRUCTION=CMA CHL RAR
/ LOC,=0000
/ INSTRUCTION=JMP I ,+1
/ LOC,=0001
/ ADDRESS=RET4
/ LOC,=0002

```


2214 5472 JMP I XSTA2
 2215 7000 RET4, NOP
 2216 7000 NOP
 2217 4464 JMS I XAVREG

/

2220 7430 SZL
 2221 7440 SEA
 2222 4465 JMS I XDATER
 2223 7410 SKP
 2224 4466 JMS I XHALT2
 2225 4467 JMS I XLOOP
 2226 5213 JMP FCL4
 2227 1126 TAD SEQ5
 2230 3154 DCA SEQ
 2231 5554 JMP I SEQ

/

/FALSE CARRY TEST #5

2232 7300 FCT5, CLA CLL

2233 7300 FCS5, CLA CLL
 2234 1143 TAD INS7 /INSTRUCTION=ISE ,+1
 2235 3472 DCA I XSTA2 /LOC,=7777
 2236 1137 TAD INS3 /INSTRUCTION=IAC
 2237 3000 DCA TSTA3 /LOC,=0000
 2240 1137 TAD INS3 /INSTRUCTION=IAC
 2241 3001 DCA TSTA4 /LOC,=0001
 2242 1151 TAD INS13 /INSTRUCTION=JMP I ,+1
 2243 3002 DCA TSTA5 /LOC,=0002
 2244 1325 TAD AD5 /ADDRESS=RET5
 2245 3003 DCA TSTA6 /LOC,=0003

/

2246 7340 FCL5, CLA CLL CMA
 2247 3471 DCA I XSTA1
 2250 7040 CMA
 2251 5472 JMP I XSTA2
 2252 7000 RET5, NOP
 2253 7000 NOP
 2254 4464 JMS I XAVREG

/

2255 7430 SZL
 2256 7440 SEA
 2257 4465 JMS I XDATER

2260	7418	SKP
2261	4466	JMS I XHALT2
2262	4467	JMS I XLOOP
2263	5246	JMP FCL5
2264	7200	CLA
2265	1127	TAD SEQ6
2266	3154	DCA SEQ
2267	5554	JMP I SEQ

/

/

/FALSE CARRY TEST #6

2270	7300	FCT6,	CLA CLL	
2271	7300	FCS6,	CLA CLL	
2272	1144		TAD INS8	/INSTRUCTION=ISE ,+1
2273	3472		DCA I XSTA2	/LOC.=7777
2274	1137		TAD INS3	/INSTRUCTION=IAC
2275	3001		DCA TSTA4	/LOC.=0001
2276	1151		TAD INS13	/INSTRUCTION=JMP I ,+1
2277	3002		DCA TSTA5	/LOC.=0002
2300	1326		TAD AD6	/ADDRESS=RET6
2301	3003		DCA TSTA6	/LOC.=0003

2302	7340	FCL6,	CLA CLL CMA	
2303	3000		DCA TSTA3	
2304	7240		CLA CMA	
2305	5472		JMP I XSTA2	
2306	7000	RET6,	NOP	
2307	7000		NOP	
2310	4464		JMS I XAVREG	

2311	7430		SZL	
2312	7440		SZA	
2313	4465		JMS I XDATER	
2314	7410		SKP	
2315	4466		JMS I XHALT2	
2316	4467		JMS I XLOOP	
2317	5302		JMP FCL6	
2320	7200		CLA	
2321	1130		TAD SEQ7	
2322	3154		DCA SEQ	
2323	5554		JMP I SEQ	
2324	2215	AD4,	RET4	
2325	2252	AD5,	RET5	
2326	2306	AD6,	RET6	

2400 PAGE

```

/
/
/ FALSE CARRY TEST#7
/
2400 7300 FCT7, CLA CLL
/
/
2401 7300 FCS7, CLA CLL
2402 1145 TAD INS9 /INSTRUCTION=ISZ I TSTIND
2403 3472 DCA I XSTA2 /LOC,=7777
2404 1137 TAD INS3 /INSTRUCTION=IAC
2405 3001 DCA TSTA4 /LOC,=0001
2406 1151 TAD INS13 /INSTRUCTION=JMP I ,+1
2407 3002 DCA TSTA5 /LOC,=0002
2410 1326 TAD AD7 /ADDRESS=RET7
2411 3003 DCA TSTA6 /LOC,=0003
/
/
2412 7340 FCL7, CLA CLL CMA
2413 3010 DCA TSTIND
2414 7040 CMA
2415 3000 DCA TSTA3
2416 7040 CMA
2417 5472 JMP I XSTA2
2420 7000 RET7, NOP
2421 7000 NOP
2422 4464 JMS I XAVREG
/
/
2423 7430 SZL
2424 7440 SEA
2425 4465 JMS I XDATER
2426 7410 SKP
2427 4466 JMS I XHALT2
2430 4467 JMS I XLOOP
2431 5212 JMP FCL7
2432 7200 CLA
2433 1131 TAD SEQ8
2434 3154 DCA SEQ
2435 5554 JMP I SEQ
/
/
/ FALSE CARRY TEST #8
/
2436 7300 FCT8, CLA CLL
/
/
2437 7300 FCS8, CLA CLL
2440 1137 TAD INS3 /INSTRUCTION=IAC

```

/	PAL10	V141	13=SEP=71	13131	PAGE 1=27
2441	3000		DCA	TSTA3	/LOC,=0000
2442	1137		TAD	INS3	/INSTRUCTION=IAC
2443	3001		DCA	TSTA4	/LOC,=0001
2444	1140		TAD	INS4	/INSTRUCTION=JMP I ,+2
2445	3002		DCA	TSTA5	/LOC,=0002
2446	1327		TAD	AD8	/ADDRESS=RET8
2447	3004		DCA	TSTA7	/LOC,=0004
/					
/					
2450	7300	FCL8,	CLA CLL		
2451	1146		TAD	INS10	/INSTRUCTION=JMS I ,+1
2452	3472		DCA I	XSTA2	/LOC,=7777
2453	7240		CLA CMA		
2454	5472		JMP I	XSTA2	
2455	7000	RET8,	NOP		
2456	7000		NOP		
/					
/					
2457	7430		SZL		
2460	7440		SEA		
2461	4465		JMS I	XDATA2	
2462	7410		SKP		
2463	4466		JMS I	XHALT2	
2464	4467		JMS I	XLOOP	
2465	5250		JMP	FCL8	
2466	7200		CLA		
2467	1132		TAD	SEQ9	
2470	3154		DCA	SEQ	
2471	5554		JMP I	SEQ	
/					
/					
/FALSE CARRY TEST #9					
/					
2472	7300	FCT9,	CLA CLL		
/					
/					
2473	7340	FCS9,	CLA CLL	CMA	/DATA=7777
2474	3471		DCA I	XSTA1	/LOC,=7776
2475	1137		TAD	INS3	/INSTRUCTION=IAC
2476	3000		DCA	TSTA3	/LOC,=0000
2477	1141		TAD	INS5	/INSTRUCTION=JMP I ,+1
2500	3001		DCA	TSTA4	/LOC,=0001
2501	1330		TAD	AD9	/ADDRESS=RET9
2502	3002		DCA	TSTA5	/LOC,=0002
/					
/					
/					
2503	7300	FCL9,	CLA CLL		
2504	1147		TAD	INS11	/INSTRUCTION=JMS I ,+1

) / PAL10 V141 13-SEP-71 13131 1-28

2505	3472		DCA I	XSTA2
2506	7240		CLA CMA	
2507	5472		JMP I	XSTA2
2510	7000	RET9,	NOP	
2511	7000		NOP	
2512	4464		JMS I	XAVREG
/				
/				
/				
2513	7430		SZL	
2514	7440		SZA	
2515	4465		JMS I	XDATER
2516	7410		SKP	
2517	4466		JMS I	XHALT2
2520	4467		JMS I	XLOOP
2521	5303		JMP	FCL9
2522	7200		CLA	
2523	1133		TAD	SEQ10
2524	3154		DCA	SEQ
2525	5554		JMP I	SEQ
2526	2420	AD7,	RET7	
2527	2455	AD8,	RET8	
2530	2510	AD9,	RET9	

2600 PAGE

/				
/				
/FALSE CARRY TEST #10				
/				
2600	7300	FCT10,	CLA CLL	
/				
/				
2601	7300	FCS10,	CLA CLL	
2602	1150		TAD	INS12
2603	3472		DCA I	XSTA2
2604	1137		TAD	INS3
2605	3001		DCA	TSTA4
/INSTRUCTION=JMS I TSTIND				
/LOC,=7777				
/INSTRUCTION=IAC				
/LOC,=0001				
2606	1151		TAD	INS13
2607	3002		DCA	TSTA5
2610	1315		TAD	AD10
2611	3003		DCA	TSTA6
/INSTRUCTION=JMP I ,+1				
/LOC,=0002				
/ADDRESS=RET10				
/LOC,=0003				
/				
/				
2612	7340	FCL10,	CLA CLL CMA	
2613	3010		DCA	TSTIND
2614	7040		CMA	
2615	5472		JMP I	XSTA2
2616	7000	RET10,	NOP	
2617	7000		NOP	

```

2620 4464      JMS I   XAVREG
/
/
/
2621 7430      SZL
2622 7440      SEA
2623 4465      JMS I   XDATER
2624 7410      SKP
2625 4466      JMS I   XHALT2
2626 4467      JMS I   XLOOP
2627 5212      JMP      FCL10
2630 7200      CLA
2631 1134      TAD      SEQ11
2632 3134      DCA      SEQ
2633 5534      JMP I    SEQ

```

```

/
/
/ FALSE CARRY TEST #11
/

```

```

2634 7300      FCT11, CLA CLL
/
/

```

```

2635 7300      FCS11, CLA CLL
2636 1137      TAD      INS3
2637 3000      DCA      TSTA3
2640 1141      TAD      INS5
2641 3001      DCA      TSTA4
2642 1316      TAD      AD11
2643 3002      DCA      TSTA5
/
/

```

```

/INSTRUCTION=IAC
/LOC,=0000
/INSTRUCTION=JMP I ,+1
/ADDRESS=0001
/ADDRESS=RET11
/LOC,=0002

```

```

2644 7300      FCL11, CLA CLL
2645 1153      TAD      INS15
2646 3472      DCA I    XSTA2
2647 7240      CLA CMA
2650 3472      JMP I    XSTA2
2651 7000      RET11, NOP
2652 7000      NOP
2653 4464      JMS I    XAVREG
/
/

```

```

/INSTRUCTION=JMS ;
/LOC,=7777

```

```

2654 7430      SZL
2655 7440      SEA
2656 4465      JMS I    XDATER
2657 7410      SKP
2660 4466      JMS I    XHALT2
2661 4467      JMS I    XLOOP
2662 5244      JMP      FCL11
2663 7200      CLA
2664 1135      TAD      SEQ12

```

PAL10	V141	13=SEP=71	13131	1=30
2665	3154	DCA	SEQ	
2666	5554	JMP I	SEQ	
/				
/				
/FALSE CARRY TEST #12				
/				
2667	7300	FCT12,	CLA CLL	
/				
/				
2670	7300	FCS12,	CLA CLL	
2671	1137	TAD	INS3	/INSTRUCTION=IAC
2672	3472	DCA I	XSTA2	/LOC,=7777
2673	1152	TAD	INS14	/INSTRUCTION=JMP I ,+1
2674	3000	DCA	TSTA3	/LOC,=0000
2675	1317	TAD	AD12	/ADDRESS=RET12
2676	3001	DCA	TSTA4	/LOC,=0001
/				
/				
/				
2677	7340	FCL12,	CLA CLL CMA	
2700	5472	JMP I	XSTA2	
2701	7000	RET12,	NOP	
2702	7000	NOP		
2703	4464	JMS I	XAVREG	
/				
/				
/				
2704	7430	SZL		
2705	7440	SZA		
2706	4465	JMS I	XDATER	
2707	7410	SKP		
2710	4466	JMS I	XHALT2	
2711	4467	JMS I	XLOOP	
2712	5277	JMP	FCL12	
2713	5714	JMP I	,+1	
2714	3200	ENDFCT		
2715	2616	AD10,	RET10	
2716	2051	AD11,	RET11	
2717	2701	AD12,	RET12	
3000	PAGE	/(TAPE 3)		
/COMPARE TWO NUMBERS! W1*NOT(W2)+W2*NOT(W1)=0, W1=W2				
/				
3000	0000	SAMEAS,	0	
3001	7340	CLA CLL CMA		
3002	0040	AND	W2	
3003	7040	CMA		

```

/      PAL10  V141  13-SEP-71  13131  PAGE 1-31

3004 0037      AND      W1
3005 7640      SZA CLA      /W1*NOT(W2)=0
3006 5600      JMP I      SAMEAS      /W1*NOT(W2)NOT 0, ERROR
3007 7040      CMA
3010 0037      AND      W1
3011 7040      CMA
3012 0040      AND      W2
3013 7640      SZA CLA      /W2*NOT(W1)=0
3014 5600      JMP I      SAMEAS      /W2*NOT(W1) NOT 0, ERROR
3015 2200      ISZ      SAMEAS
3016 5600      JMP I      SAMEAS      /W1=W2
/
/SAVE AC AND LINK
/
3017 0000      SAVREG, 0
3020 3025      DCA      TEMPAC
3021 7430      SEL
3022 7040      CMA
3023 3026      DCA      TEMPL
3024 7040      CMA
3025 0025      AND      TEMPAC
3026 5617      JMP I      SAVREG
/
/HAUT ON ERROR, DISPLAY ADDRESS OF FAILED TEST IN AC
/
3027 0000      HALT2, 0
3030 7604      LAS
3031 0103      AND      SR00      /TEST SR00
3032 7640      SZA CLA      /SUPPRESS HALT IF SR00=1
3033 5627      JMP I      HALT2
3034 1154      TAD      SEQ      /PUT ADDRESS OF FAILED TEST IN
3035 7402      HLT      /AC AND STOP
3036 5627      JMP I      HALT2      /CONTINUE TESTING

/
/
/ DATA ERROR HAS OCCURED
/
3037 0000      DATER, 0
3040 7604      LAS
3041 0104      AND      SR01      /TEST SR01
3042 7450      SNA      /SUPPRESS ERROR TYPE IF SR01=1
3043 4256      JMS      TYP52      /SET UP FOR ERROR TYPE
3044 2237      ISZ      DATER
3045 5637      JMP I      DATER
/
/
/
/
/ LOOP ON DATA ERROR
/
3046 0000      LOOP, 0
3047 7604      LAS

```



```

) / PAL10 V141 13-SEP-71 13131 E 1-32
3050 0105 AND SR02 /TEST SR02
3051 7650 SNA CLA /LOOP IF SR02=1
3052 5254 JMP NLOOP /DO NOT LOOP
3053 5646 JMP I LOOP
3054 2246 NLOOP, ISZ LOOP
3055 5646 JMP I LOOP

/
/TYPE DATA ERROR MESSAGE
/
3056 0000 TYP2, 0
3057 4448 JMS I XPRINT
3060 5744 DATE=1 /TYPE "DATA ERROR"
3061 1037 TAD W1
3062 4673 JMS I XADOUT /TYPE TEST ADDRESS
3063 7340 CLA CLL CMA
3064 0025 AND TEMPAC
3065 3037 DCA WD1
3066 0026 AND TEMPL
3067 3040 DCA WD2
3070 4460 JMS I XLNKOU /OUTPUT RECEIVED LINK
3071 4461 JMS I XWDOUT /OUTPUT RECEIVED AC
3072 5656 JMP I TYP2
3073 3227 XADOUT, ADOUT

/
/END OF PASS
/
3200 3200 PAGE
3200 7300 ENDFCT, CLA CLL
3201 2020 ISZ CNTR1 /INCREMENT PASS COUNT
3202 5224 JMP OUT /PASS NOT COMPLETE
3203 7604 LAS
3204 0115 AND SR10 /TEST SR10
3205 7650 SNA CLA /IS SR10=1
3206 5221 JMP FCTOK /NO, TYPE FCT
3207 7604 FCTHLT, LAS
3210 0114 AND SR09 /TEST SR09
3211 7640 SZA CLA /IS SR09=1
3212 7402 HLT /YES, HALT
3213 7604 LAS
3214 0116 AND SR11 /TEST SR11
3215 7640 SZA CLA /IS SR11=1
3216 5224 JMP OUT /YES, LOOP ON FCT
3217 5620 JMP I ,+1 /NO, GO TO NEXT TEST
3220 3400 RNAD1
3221 4446 FCTOK, JMS I XPRINT
3222 5732 OK3=1
3223 5207 JMP FCTHLT
3224 1122 OUT, TAD SEQ1
3225 3154 DCA SEQ
3226 5554 JMP I SEQ

/
/

```

/CONVERT ADDRESS TO ASCII AND OUTPUT

3227	0000	ADOUT,	0
3230	3037	DCA	TEMP1
3231	1037	TAD	TEMP1
3232	0172	AND	K0007
3233	3264	DCA	A2
3234	1037	TAD	TEMP1
3235	7006	RTL	
3236	7004	RAL	
3237	0266	AND	K0700
3240	1264	TAD	A2
3241	1267	TAD	K6060
3242	3264	DCA	A2
3243	1037	TAD	TEMP1
3244	7012	RTR	
3245	7012	RTR	
3246	7012	RTR	
3247	0172	AND	K0007
3250	3263	DCA	A1
3251	1037	TAD	TEMP1
3252	7012	RTR	
3253	7010	RAR	
3254	0266	AND	K0700
3255	1263	TAD	A1
3256	1267	TAD	K6060
3257	3263	DCA	A1
3260	4446	JMS I	XPRINT
3261	3262	A1=1	
3262	5627	JMP I	ADOUT
3263	0000	A1,	0
3264	0000	A2,	0
3265	4000		4000
3266	0700	K0700,	0700
3267	6060	K6060,	6060

/MULTIPLE ADDITIONS OF RANDOM NUMBER AND ITS TWO'S COMPLEMENT

3400	3400	PAGE	CLA CLL	
3400	7300	RNADI,	JMS I	XRAND /GENERATE RANDOM NUMBERS
3401	4473		CLA CLL	
3402	7300		TAD	RANDA
3403	1041		TAD	RANDC /AC=0
3404	1043		TAD	RANDC
3405	1043		TAD	RANDA /AC=0
3406	1041		TAD	RANDA
3407	1041		TAD	RANDA
3410	1041		TAD	RANDA
3411	1043		TAD	RANDC /AC=0
3412	1043		TAD	RANDC
3413	1041		TAD	RANDA
3414	1041		TAD	RANDA
3415	1043		TAD	RANDC
3416	1041		TAD	RANDA
3417	1043		TAD	RANDC /AC=0
3420	1043		TAD	RANDC

PAL10 V141 13-SEP-71 13131 E 1-34

3421	1041	TAD	RANDA	
3422	1041	TAD	RANDA	
3423	1043	TAD	RANDC	
3424	1043	TAD	RANDC	/AC=0
3425	1043	TAD	RANDC	
3426	1041	TAD	RANDA	
3427	1043	TAD	RANDC	
3430	1041	TAD	RANDA	/AC=0
3431	1041	TAD	RANDA	
3432	1041	TAD	RANDA	
3433	1043	TAD	RANDC	
3434	1043	TAD	RANDC	/AC=0
3435	7000	NOP		
3436	4464	JMS I	XAVREG	/SAVE AC AND LINK
3437	7430	SZL		/IS LINK=1, AND AC=0
3440	7440	SZA		
3441	4646	JMS I	XRN1ER	/ERROR, AC NOT 0, OR LINK NOT 1 OR BOTH
3442	4467	JMS I	NERR0P	/RESULTS OK
3443	5202	JMP	RNAD1+2	
3444	5645	JMP I	,+1	
3445	3600	RNAD2		
3446	3447	XRN1ER, RN1ER		

```

/
/RANDOM ADD TEST 1 ERROR HANDLER
/
3447 0000 RN1ER, 0
3450 7604 LAS
3451 0104 AND SR01 /TEST SR01
3452 7640 SZA CLA /IS SR01=1
3453 5302 JMP SKHLT /YES, SUPPRESS ERROR TYPEOUT
3454 4446 JMS I XPRINT /TYPE "RANDOM ADD TEST1 FAILED"
3455 5565 EM10-1
3456 4446 JMS I XPRINT /TYPE "RANDA, RANDC, RESULT"
3457 5316 DM4-1
3460 7340 CLA CLL CMA
3461 0041 AND RANDA
3462 3037 DCA WD1
3463 4461 JMS I XWDOUT /OUTPUT RANDA
3464 7340 CLA CLL CMA
3465 0043 AND RANDC
3466 3037 DCA WD1
3467 4461 JMS I XWDOUT /OUTPUT RANDC
3470 7340 CLA CLL CMA
3471 0025 AND TEMPAC
3472 3037 DCA WD1
3473 7040 CMA
3474 0026 AND TEMPL
3475 3040 DCA WD2
3476 4460 JMS I XLNKOU /OUTPUT RESULTANT LINK
3477 4461 JMS I XWDOUT /OUTPUT RESULTANT AC
3500 4446 JMS I XPRINT
3501 5742 CRLF-1

```

3502	7604	SKHLT,	LAS		
3503	0103		AND	SR00	/TEST SR00
3504	7640		SZA	CLA	/IS SR00=1
3505	5647		JMP	I RN1ER	/YES, SUPPRESS ERROR HALT
3506	7300		CLA	CLL	
3507	1247		TAD	RN1ER	
3510	7402		HLT		/HALT WITH ADDRESS OF RNAD1 IN AC
3511	5647		JMP	I RN1ER	

/
/RANDOM NUMBER GENERATOR
/

3512	0000	RANDOM,	0		
3513	7300		CLA	CLL	
3514	1041		TAD	RANDA	
3515	7004		RAL		
3516	7430		SZL		
3517	1342		TAD	K0003	
3520	3041		DCA	RANDA	
3521	1041		TAD	RANDA	
3522	7041		CIA		
3523	3043		DCA	RANDC	
3524	7100		CLL		
3525	1341		TAD	R2A	
3526	7004		RAL		
3527	7430		SZL		
3530	1342		TAD	K0003	
3531	3341		DCA	R2A	
3532	7430		SZL		
3533	7040		CMA		
3534	3044		DCA	LINKR	
3535	1044		TAD	LINKR	
3536	7040		CMA		
3537	3045		DCA	LINKRC	
3540	5712		JMP	I RANDOM	
3541	0001	R2A,	1		
3542	0003	K0003,	3		

/ADDITION OF RANDOM NUMBER AND MODIFIED
/COMPLEMENT TO PRODUCE ONE KNOWN BIT
/SET IN AC
/
/

3600	7340	PAGE			
3600	0041	RNAD2,	CLA	CLL	CMA
3601	0041		AND		RANDA
3602	3346		DCA		APOS
3603	7040		CMA		
3604	0041		AND		RANDA
3605	7040		CMA		
3606	3347		DCA		ANEG

/GET RANDOM NUMBER
/STORE IT

/ONE'S COMPLEMENT OF RANDOM NUMBER

		PAL10	V141	13-SEP-71	13131	E 1-36
3607	7040			CMA		
3610	0103			AND	K4000	/GET MASK
3611	3352			DCA	MASK	
3612	7040	NXTBT,		CMA		
3613	0352			AND	MASK	
3614	7040			CMA		
3615	3353			DCA	NMASK	/COMPLIMENT MASK
3616	7040	ALT1BT,		CMA		
3617	0346			AND	APOS	/GET RANDOM NUMBER
3620	0352			AND	MASK	/TEST SIGN BIT
3621	7440			SZA		/IS NUMBER NEGATIVE
3622	5232			JMP	MODNEG	/YES, MODIFY COMPLIMENT OF NUMBER
3623	7040			CMA		
3624	0346			AND	APOS	/GET RANDOM NUMBER
3625	4301			JMS	XQR1	/MODIFY WITH MASK
3626	7040			CMA		
3627	0347			AND	ANEG	/GET COMPLIMENT OF RANDOM NUMBER
3630	3351			DCA	BNEG	/AND USE AS IS
3631	5240			JMP	CBTST1	
3632	7240	MODNEG,	CMA CLA			/MODIFY NEGATIVE NUMBER
3633	0347			AND	ANEG	/GET COMPLEMENT OF RANDOM NUMBER
3634	4315			JMS	XQR2	/MODIFY WITH MASK
3635	7040			CMA		
3636	0346			AND	APOS	/GET RANDOM NUMBER
3637	3351			DCA	BNEG	/AND USE AS IS
3640	7340	CBTST1,	CLA CLL	CMA		
3641	0350			AND	BPOS	/LOAD AC WITH MODIFIED ARGUMENT
3642	1351			TAD	BNEG	/ADD UNMODIFIED ARGUMENT
3643	7430			SZL		/DID CARRY PROPAGATE INTO LINK
3644	7001			IAC		/NO, INCREMENT NUMBER
3645	4464			JMS I	XAVREG	/SAVE AC
3646	4463			JMS I	XAMEA	/COMPARE MODIFIED BIT AND MASK
3647	7410			SKP		
3650	4756			JMS I	XRN2ER	/AC AND MASK DIFFERENT, ERROR
3651	4467			JMS I	NERROP	/NO ERROR, AC AND MASK THE SAME
3652	5240			JMP	CBTST1	/RETURN HERE FOR LOOPING
3653	5254			JMP	CBTST2	
3654	7340	CBTST2,	CLL CLA	CMA		
3655	0351			AND	BNEG	/LOAD AC WITH UNMODIFIED ARGUMENT
3656	1350			TAD	BPOS	/ADD MODIFIED ARGUMENT
3657	7430			SZL		/DID CARRY PROPAGATE INTO LINK
3660	7001			IAC		/NO, INCREMENT NUMBER
3661	4464			JMS I	XAVREG	/SAVE AC
3662	4463			JMS I	XAMEA	/COMPARE AC AND MASK
3663	7410			SKP		
3664	4756			JMS I	XRN2ER	/AC AND MASK NOT THE SAME, ERROR
3665	4467			JMS I	NERROP	/NOERROR, AC AND MASK THE SAME
3666	5254			JMP	CBTST2	/RETURN HERE FOR LOOPING
3667	7340	MOVMSK,	CLA CLL	CMA		/SHIFT MASK ONE PLACE TO RIGHT
3670	0352			AND	MASK	
3671	7010			RAR		
3672	3352			DCA	MASK	

3673	7420		SNL		/HAVE ALL BITS BEEN TESTED
3674	5212		JMP	NXTBT	/NO, CONTINUE
3675	4467		JMS I	NERR0P	/YES, TEST FOR LOOP ON RNAD2
3676	5200		JMP	RNAD2	
3677	5700		JMP I	,+1	
3700	4200		RARR		
3701	0000	XQR1,	0		
3702	0353		AND	NMASK	
3703	7040		CMA		
3704	3354		DCA	ABNOT	
3705	7040		CMA		
3706	0347		AND	ANEG	
3707	0352		AND	MASK	
3710	7040		CMA		
3711	0354		AND	ABNOT	
3712	7040		CMA		
3713	3350		DCA	BPOS	
3714	5701		JMP I	XOR1	
3715	0000	XQR2,	0		
3716	0352		AND	MASK	
3717	7040		CMA		
3720	3354		DCA	ABNOT	
3721	7040		CMA		
3722	0346		AND	APOS	
3723	0353		AND	NMASK	
3724	7040		CMA		
3725	0354		AND	ABNOT	
3726	3350		DCA	BPOS	
3727	5715		JMP I	XOR2	

3730	0000	SAMEA,	0		
3731	7040		CMA		
3732	3355		DCA	NOTAC	
3733	7040		CMA		
3734	0025		AND	TEMPAC	
3735	0353		AND	NMASK	
3736	7440		SZA		
3737	5344		JMP	EROUT1	
3740	7040		CMA		
3741	0352		AND	MASK	
3742	0355		AND	NOTAC	
3743	7440		SZA		
3744	2330	EROUT1,	ISE	SAMEA	
3745	5730		JMP I	SAMEA	
3746	0000	APOS,	0		
3747	0000	ANEG,	0		
3750	0000	BPOS,	0		
3751	0000	BNEG,	0		
3752	0000	MASK,	0		
3753	0000	NMASK,	0		
3754	0000	ABNOT,	0		
3755	0000	NOTAC,	0		
3756	4000	XRN2ER,	RN2ER		

```

4000 PAGE
/ERROR HANDLER FOR RANDOM ADD TEST 2,
/
RNZER, 0
4000 0000 LAS
4001 7604 AND SR01 /TEST SR01
4002 0104 SZA CLA /IS SR01 = 1
4003 7640 JMP SHLT /YES SUPPRESS ERROR TYPEOUT
4004 5233 JMS I XPRINT /NO, TYPE "RANDOM ADD TEST 2 FAILED"
4005 4446 EM11=1
4006 5605 JMS I XPRINT /TYPE ARG1, ARG2, ARG1+ARG2, EXPECTED
4007 4446 DH6=1
4010 5364 CLA CLL CMA
4011 7340 AND BPOS /OUTPUT ARG1
4012 0777 DCA WD1
4013 3037 JMS I XWDOUT
4014 4461 CMA
4015 7040 AND BNEG /OUTPUT ARG2
4016 0776 DCA WD1
4017 3037 JMS I XWDOUT
4020 4461 CMA
4021 7040 AND MASK /OUTPUT EXPECTED RESULT
4022 0775 DCA WD1
4023 3037 JMS I XWDOUT
4024 4461 CMA
4025 7040 AND TEMPAC /OUTPUT RESULTANT AC
4026 0025 DCA WD1
4027 3037 JMS I XWDOUT
4030 4461 JMS I XPRINT
4031 4446 CRLF=1
4032 5742 SHLT, LAS
4033 7604 AND SR00 /TEST SR00
4034 0103 SZA CLA /IS SR00 = 1
4035 7640 JMP I RNZER /YES, DO NOT HALT
4036 5600 CLA CLL /NO, HALT WITH ADDRESS IN AC
4037 7300 TAD RNZER
4040 1200 HLT
4041 7402 JMP I RNZER
4042 5600

```

/ROTATE RANDOM NUMBER RIGHT USING RAR

```

4175 3752
4176 3751
4177 3750
4200 PAGE
4200 RARR, CLA CLL

```

/	PAL10	V141	13-SEP-71	13131	PAGE 1-39
4201	1044		TAD	LINKR	/GET LINK TO BE ROTATED
4202	7440		SEA		
4203	7220		CLA	CML	
4204	1041		TAD	RANDA	/GET NUMBER TO BE ROTATED
4205	7010		RAR		
4206	7010		RAR		
4207	7010		RAR		
4210	7010		RAR		
4211	7010		RAR		
4212	7010		RAR		
4213	7010		RAR		
4214	7010		RAR		
4215	7010		RAR		
4216	7010		RAR		
4217	7010		RAR		
4220	7010		RAR		
4221	7010		RAR		
4222	7010		RAR		
4223	7010		RAR		
4224	7010		RAR		
4225	7010		RAR		
4226	7010		RAR		
4227	7010		RAR		
4230	7010		RAR		
4231	7010		RAR		
4232	7010		RAR		
4233	7010		RAR		
4234	7010		RAR		
4235	7010		RAR		
4236	7010		RAR		
4237	7000		NOP		
4240	7000		NOP		
4241	4464		JMS I	XAVREG	/SAVE AC AND LINK
4242	1043		TAD	RANDC	/ADD COMPLEMENT OF NUMBER TO AC
4243	7640		SEA	CLA	/ARE THEY EQUAL
4244	5250		JMP	,+4	/NO, ERROR
4245	1044		TAD	LINKR	
4246	3037		DCA	WD1	
4247	1026		TAD	TEMPL	
4250	3040		DCA	WD2	
4251	4462		JMS I	XAMEAS	/ARE LINKS THE SAME
4252	4735		JMS I	XRARR	/NO, ERROR
4253	4467		JMS I	NERROP	/TEST FOR LOOPING
4254	5200		JMP	RARR	/LOOP ON RARR
4255	7300	RALR,	/ROTATE RANDOM NUMBER LEFT USING RAL		
4256	1044		CLA	CLL	
4257	7440		TAD	LINKR	/GET LINK TO BE ROTATED
4260	7220		SEA		
4261	1041		CLA	CML	
4262	7004		TAD	RANDA	/GET NUMBER TO BE ROTATED
4263	7004		RAL		
4264	7004		RAL		
4264	7004		RAL		

) / PAL10 V141 13-SEP-71 13131 E 1-40)

4265	7004	RAL	
4266	7004	RAL	
4267	7004	RAL	
4270	7004	RAL	
4271	7004	RAL	
4272	7004	RAL	
4273	7004	RAL	
4274	7004	RAL	
4275	7004	RAL	
4276	7004	RAL	
4277	7004	RAL	
4300	7004	RAL	
4301	7004	RAL	
4302	7004	RAL	
4303	7004	RAL	
4304	7004	RAL	
4305	7004	RAL	
4306	7004	RAL	
4307	7004	RAL	
4310	7004	RAL	
4311	7004	RAL	
4312	7004	RAL	
4313	7004	RAL	
4314	7000	NOP	
4315	7000	NOP	
4316	4464	JMS I	XAVREG
4317	1043	TAD	RANDC
4320	7440	SZA	
4321	5325	JMP	,+4
4322	1044	TAD	LINKR
4323	3037	DCA	WD1
4324	1026	TAD	TEMPL
4325	3040	DCA	WD2
4326	4462	JMS I	XAMEAS
4327	4734	JMS I	XRALR
4330	4467	JMS I	NERROP
4331	5255	JMP	RALR
4332	5733	JMP I	,+1
4333	4400	RTL	
4334	5013	XRALR,	
4335	5000	XRARR,	

/SAVE AC AND LINK
/ADD COMPLIMENT OF ORIGINAL NUMBER TO AC
/ARE THEY THE SAME
/NO, ERROR

/COMPARE ORIGINAL AND ROTATED LINKS
/LINKS NOT THE SAME, ERROR

/ROTATE RANDOM NUMBER LEFT USING RTL

4400	7300	CLA CLL	
4401	1044	TAD	LINKR
4402	7440	SZA	
4403	7220	CLA CML	
4404	1041	TAD	RANDA
4405	7006	RTL	
4406	7006	RTL	
4407	7006	RTL	
4410	7006	RTL	

/GET LINK TO BE ROTATED

/GET NUMBER TO BE ROTATED

4411	7006	RTL	
4412	7006	RTL	
4413	7006	RTL	
4414	7006	RTL	
4415	7006	RTL	
4416	7006	RTL	
4417	7006	RTL	
4420	7006	RTL	
4421	7006	RTL	
4422	7006	RTL	
4423	7006	RTL	
4424	7006	RTL	
4425	7006	RTL	
4426	7006	RTL	
4427	7006	RTL	
4430	7006	RTL	
4431	7006	RTL	
4432	7006	RTL	
4433	7006	RTL	
4434	7006	RTL	
4435	7006	RTL	
4436	7006	RTL	
4437	7000	NOP	
4440	7000	NOP	
4441	4464	JMS I	XAVREG
4442	1043	TAD	RANDC
4443	7440	SZA	
4444	5250	JMP	,+4
4445	1044	TAD	LINKR
4446	3037	DCA	WD1
4447	1026	TAD	TEMPL
4450	3040	DCA	WD2
4451	4462	JMS I	XAMEAS
4452	4771	JMS I	XRTL
4453	4467	JMS I	NERROP
4454	5200	JMP	RTL

/SAVE AC AND LINK
/ADD COMPLEMENT OF ORIGINAL NUMBER TO AC
/ARE THEY THE SAME
/NO, ERROR

/COMPARE ORIGINAL AND ROTATED LINKS
/LINKS NOT THE SAME, ERROR

/ROTATE RANDOM NUMBER RIGHT USING RTR

4455	7300	RTRR,	CLA CLL	
4456	1044		TAD	LINKR
4457	7440		SZA	
4460	7220		CLA CML	
4461	1041		TAD	RANDA
4462	7012		RTR	
4463	7012		RTR	
4464	7012		RTR	
4465	7012		RTR	
4466	7012		RTR	
4467	7012		RTR	
4470	7012		RTR	
4471	7012		RTR	
4472	7012		RTR	
4473	7012		RTR	

/GET LINK TO BE ROTATED

/GET NUMBER TO BE ROTATED

4474	7012	RTR		
4475	7012	RTR		
4476	7012	RTR		
4477	7012	RTR		
4500	7012	RTR		
4501	7012	RTR		
4502	7012	RTR		
4503	7012	RTR		
4504	7012	RTR		
4505	7012	RTR		
4506	7012	RTR		
4507	7012	RTR		
4510	7012	RTR		
4511	7012	RTR		
4512	7012	RTR		
4513	7012	RTR		
4514	7000	NOP		
4515	7000	NOP		
4516	4464	JMS I	XAVREG	/SAVE AC AND LINK
4517	1043	TAD	RANOC	/ADD COMPLEMENT OF ORIGINAL NUMBER TO AC
4520	7440	SEA		/ARE THEY THE SAME
4521	5325	JMP	,+4	/NO, ERROR
4522	1044	TAD	LINKR	
4523	3037	DCA	WD1	
4524	1026	TAD	TEMPL	
4525	3040	DCA	WD2	
4526	4462	JMS I	XAMEAS	/ARE LINKS THE SAME
4527	4770	JMS I	XRTRR	/NO, ERROR
4530	4467	JMS I	NERROP	
4531	5255	JMP	RTRR	

4532	2020	ISE	CNTR1	/INCREMENT PASS COUNTER
4533	5366	JMP	ENRN	/NOT END OF PASS
4534	7604	LAS		
4535	0115	AND	SR10	/TEST SR10
4536	7650	SNA CLA		/IS SR10=1
4537	5363	JMP	RNDOK	/NO, TYPE RANDOM
4540	7604	RNDHLT, LAS		
4541	0114	AND	SR09	/TEST SR09
4542	7640	SEA CLA		/IS SR09=1
4543	7402	HLT		/YES, HALT AT END OF RANDOM
4544	7604	LAS		
4545	0116	AND	SR11	/TEST SR11
4546	7640	SEA CLA		/IS SR11=1
4547	5366	JMP	ENRN	/YES, LOOP ON RANDOM TESTS
4550	7604	FLDSW, LAS		
4551	0173	AND K0070		
4552	7110	RAR CLL		
4553	7012	RTR		
4554	3175	DCA FLDSAV		/SAVE THE SWITCHES
4555	7604	LAS		
4556	0107	AND SR04		/MASK FIELD RELOCATION SWITCH
4557	7640	SEA CLA		

```

4560 5772      JMP I XFLOCK      /GOT FIELD RELOCATION SWITCH AND GO
4561 5762      JMP I      ,+1      /NO, GO TO SIMULATED ADDITION TEST
4562 0200      RSIMAD
4563 4446      RNDOK, JMS I      XPRINT
4564 5735      OK4-1
4565 5340      JMP      RNDHLT
4566 5767      ENRN,  JMP I      ,+1
4567 3400      RNAD1
4570 5026      XRTRR, RTRER
4571 5041      XRCLR, RTLER
4572 4600      XFLOCK, FLOCKHK

```

4600 PAGE

/ROUTINE TO SORT AND COMPARE RELOCATION INFORMATION

```

4600 4231      FLDCHK, JMS FLDEND      /YES, FIND NUMBER OF FIELDS PRESENT
4601 4264      JMS RELOC      /RELOCATE TO NEXT BANK PRESENT OR BANK 0
4602 7346      CLA CLL CHA RTL      /AC TO 7775
4603 4341      JMS LFCR      /PRINT SOME CR-LF
4604 4331      JMS ASTRK      /PRINT SOME *****
4605 4352      JMS FLN0      /PRINT AMOUNT OF MEMORY
4606 4446      JMS I XPRINT      /PRINT " EXTENDED BANKS OF MEMORY TO BANK "
4607 5755      BKMS      /TEXT FOR EXTENDED BANKS OF MEMORY TO BANK
4610 4360      JMS FLNHR      /PRINT NEW FIELD
4611 4331      JMS ASTRK      /PRINT SOME *****
4612 7344      CLA CLL CHA RAL      /AC TO 7776
4613 4341      JMS LFCR      /PRINT SOME CR - LF
4614 1175      TAD FLD0AV
4615 7041      CIA
4616 1174      TAD FLN0UM
4617 7050      SNA CLA      /COMPARE SWITCHES
4620 5223      JMP ,+3
4621 7602      HLT CLA
4622 5770      JMP I XFLOSW      /TRY IT AGAIN
4623 1314      TAD FL0GO
4624 1115      TAD K0002
4625 3226      DCA ,+1
4626 0000      0000      /MODIFIED FOR NEW FIELD
4627 5630      FLDEX,  JMP I ,+1
4630 0200      RSIMAD      /START POINTER

```

/ROUTINE TO DETERMINE NUMBER OF BANKS OF MEM;

```

4631 0000      /
4632 7300      FLDEND, 0
4633 3174      CLA CLL
4634 1371      DCA FLN0UM
4635 3176      TAD KSTOP
4636 6201      DCA FLDCNT      /JUST A COUNTER
4637 3571      CDF      0      /TO FIELD 0
4640 1372      DCA I K0
4641 1113      TAD KCDF
4642 3243      TAD K0010
4643 0000      DCA FLDDF
4643 0000      FLDDF, 0      /MODIFIED BY TEST

```

4644	7340	CLA CLL CMA	
4645	3571	DCA I K0	/TRY EXTENDED FIELD
4646	1571	TAD I K0	
4647	7650	SNA CLA	/SAME IF FIELD PRESENT
4650	5255	JMP ,+5	/DATA BAD OR FIELD NOT THERE
4651	2174	ISZ FLDRAM	/UPDATE FIELD COUNT
4652	1243	TAD FLD0F	/GET LAST FIELD CDF
4653	2176	ISZ FLDCNT	/STOP AFTER 7
4654	5241	JMP FLD0F -2	/TRY NEXT FIELD
4655	7300	CLA CLL	
4656	6201	CDF 0	/BACK TO FIELD 0
4657	1571	TAD I K0	
4660	7650	SNA CLA	/DID FIELD 0 CHANGE
4661	5631	JMP I FLDEND	/FIELD 0 O.K, EXIT
4662	7602	HLT CLA	/FIELD ERROR
4663	5274	JMP FLDEND ,+1	/TRY AGAIN

/ROUTINE TO MOVE PROGRAM TO NEXT FIELD OR FIELD 0

4664	0000	RELOC, 0	
4665	7300	CLA CLL	
4666	3176	DCA FLDCNT	
4667	6224	RIF	/GET CURRENT FIELD
4670	1113	TAD K0010	/UPDATE TO NEXT FIELD
4671	0375	AND K0070	/MASK 6-8
4672	3312	DCA FLDFRM	/NEW FIELD POINTER
4673	7301	CLA CLL IAC	
4674	1174	TAD FLDRAM	
4675	7804	RAL	
4676	7806	RTL	/MOVE TO 6-8
4677	7041	CIA	
4700	1312	TAD FLDFRM	
4701	7620	SNL CLA	/COMPARE TO FIELDS PRESENT
4702	1312	TAD FLDFRM	/YES, GOOD FIELD
4703	1372	TAD K00F	/GO BACK TO FIELD 0
4704	3314	DCA FLDOO	/SET POINTER FOR NEW FIELD
4705	6224	RIF	/WHERE IS PROGRAM
4706	1372	TAD K00F	
4707	3312	DCA FLDFRM	/SET POINTER FOR FIELD JUST TESTED
4710	1312	TAD FLDFRM	
4711	3317	DCA FLDRM1	/SAME MOVE
4712	0000	FLDFRM, 0000	/MODIFIED TO CURRENT FIELD
4713	1576	TAD I FLDCNT	/GET DATA WORD
4714	0000	FLDOO, 0000	
4715	3576	DCA I FLDCNT	/STORE DATA
4716	1576	TAD I FLDCNT	
4717	0000	FLDRM1, 0000	
4720	7041	CIA	
4721	1576	TAD I FLDCNT	/THIS THE GOOD ONE
4722	7650	SNA CLA	/DID DATA CHANGE
4723	5326	JMP ,+3	/DATA O.K,
4724	7602	HLT CLA	/RELOCATION ERROR
4725	5312	JMP FLDFRM	/TRY SAME WORD AGAIN
4726	2176	ISZ FLDCNT	/UPDATE TO NEXT ADDRESS
4727	5312	JMP FLDFRM	/TRANSFER NEXT WORD

/	PAL10	V141	13=SEP=71	13131	PAGE 1=45
4730	5664		JMP I RELOC		/CORE LOADED EXIT
4731	0000	/	ASTRK, 0		
4732	1371		TAD KSTOP		
4733	3176		DCA FLDCNT		
4734	1376		TAD K252		/GET ASTRK CHAR,
4735	4447		JMS I XTYPE		
4736	2176		ISZ FLDCNT		
4737	5334		JMP ,=3		
4740	5731		JMP I ASTRK		
4741	0000	/	LFCR, 0		
4742	3176		DCA FLDCNT		
4743	1374		TAD KCR		
4744	4447		JMS I XTYPE		
4745	1373		TAD KLF		
4746	4447		JMS I XTYPE		
4747	2176		ISZ FLDCNT		
4750	5343		JMP ,=5		
4751	5741		JMP I LFCR		
4752	0000	/	FLDNO, 0		
4753	1174		TAD FLDBUM		
4754	0172		AND K0007		
4755	1077		TAD K260		
4756	4447		JMS I XTYPE		
4757	5752		JMP I FLDNO		
4760	0000	/	FLDHR, 0		
4761	1314		TAD FLDBO		
4762	0173		AND K0070		
4763	7010		RAR		
4764	7012		RTR		
4765	1077		TAD K260		
4766	4447		JMS I XTYPE		
4767	5760		JMP I FLDHR		
4770	4550	/	XFLD SW, FLDSW		
4771	7771		KSTOP, 7771		
4772	6201		KCDF, 6201		
4773	0212		KLF, 0212		
4774	0215		KCR, 0215		
4775	0170		K0170, 0170		
4776	0252		K252, 0252		
	5000	/	PAGE		
5000	0000	/	RARER, 0		
5001	7604		LAS		
5002	0104		AND SR01		
5003	7640		SZA CLA		
5004	5210		JMP ,+4		
5005	4446		JMS I XPRINT		
5006	5625		EM12=1		
5007	4264		JMS ROPRT		

5010 7300 CLA CLL
5011 1200 TAD RARER
5012 5253 JMP ROHLT

5013 0000 RALER, 0
5014 7604 LAS
5015 0104 AND SR01
5016 7640 SEA CLA
5017 5223 JMP ,+4
5020 4446 JMS I XPRINT
5021 5644 EM13-1
5022 4264 JMS ROPRT
5023 7300 CLA CLL
5024 1213 TAD RALER
5025 5253 JMP ROHLT
5026 0000 RTRER, 0
5027 7604 LAS
5030 0104 AND SR01
5031 7640 SEA CLA
5032 5236 JMP ,+4
5033 4446 JMS I XPRINT
5034 5663 EM14-1
5035 4264 JMS ROPRT
5036 7300 CLA CLL
5037 1226 TAD RTRER
5040 5253 JMP ROHLT
5041 0000 RTLER, 0
5042 7604 LAS
5043 0104 AND SR01
5044 7640 SEA CLA
5045 5251 JMP ,+4
5046 4446 JMS I XPRINT
5047 5702 EM15-1
5050 4264 JMS ROPRT
5051 7300 CLA CLL
5052 1241 TAD RTLER
5053 3243 ROHLT, DCA ROBACK
5054 7604 LAS
5055 0103 AND SR00
5056 7640 SEA CLA
5057 3242 JMP ,+3
5060 1263 TAD ROBACK
5061 7402 HLT
5062 5663 JMP I ROBACK
5063 0000 ROBACK, 0

5064 0000 ROPRT, 0
5065 4446 JMS I XPRINT
5066 5347 DM5-1
5067 7340 CLA CLL CMA
5070 0044 AND LINKR
5071 3040 DCA WD2

5072	7040	CMA
5073	0041	AND
5074	3037	DCA
5075	4460	JMS I
5076	4461	JMS I
5077	7040	CMA
5100	0026	AND
5101	3040	DCA
5102	4460	JMS I
5103	7040	CMA
5104	0025	AND
5105	3037	DCA
5106	4461	JMS I
5107	4446	JMS I
5110	5742	CRLF-1
5111	5664	JMP I

ROPR

/

	PAGE	TEXT	/* ARG1	ARG2	SIMULATED	ARG1+ARG2	ARG2+ARG1+*/
5200	3736						
5201	4040						
5202	4001						
5203	2207						
5204	6140						
5205	4040						
5206	4040						
5207	4040						
5210	4040						
5211	0122						
5212	0762						
5213	4040						
5214	4040						
5215	4040						
5216	4040						
5217	4023						
5220	1115						
5221	2514						
5222	0124						
5223	0504						
5224	4040						
5225	4040						
5226	4040						
5227	4001						
5230	2207						
5231	6153						
5232	0122						
5233	0762						
5234	4040						
5235	4040						
5236	4001						
5237	2207						
5240	6253						
5241	0122						

5242	0761					
5243	3736					
5244	0000					
5245	3736	DH2,	TEXT	/** ORIGINAL	SIMULATED	ACTUAL**/
5246	4040					
5247	4040					
5250	4017					
5251	2211					
5252	0711					
5253	1601					
5254	1440					
5255	4040					
5256	4040					
5257	4023					
5260	1115					
5261	2514					
5262	0124					
5263	0504					
5264	4040					
5265	4040					
5266	4040					
5267	4001					
5270	0324					
5271	2501					
5272	1437					
5273	3600					
5274	3736	DH3,	TEXT	/**RANDA	RANDC	RESULT**/
5275	2201					
5276	1604					
5277	0140					
5300	4040					
5301	4040					
5302	4040					
5303	4022					
5304	0116					
5305	0403					
5306	4040					
5307	4040					
5310	4040					
5311	4040					
5312	2205					
5313	2325					
5314	1424					
5315	3736					
5316	0000					
5317	3736	DH4,	TEXT	/**RANDA	BPOS	BNEG
5320	2201					RESULT**/
5321	1604					
5322	0140					
5323	4040					
5324	4040					
5325	4040					
5326	4002					
5327	2017					
5330	2340					

5331	4040					
5332	4040					
5333	4040					
5334	4040					
5335	0216					
5336	0507					
5337	4040					
5340	4040					
5341	4040					
5342	4040					
5343	4022					
5344	0523					
5345	2514					
5346	2437					
5347	3600					
5350	3736	DH5,	TEXT	/**ORIGINAL	ACTUAL**/	
5351	1722					
5352	1107					
5353	1116					
5354	0114					
5355	4040					
5356	4040					
5357	4040					
5360	0103					
5361	2425					
5362	0114					
5363	3736					
5364	0000					
5365	3736	DH6,	TEXT	/** ARG1	ARG2	EXPECTED ACTUAL**/
5366	4040					
5367	4040					
5370	0122					
5371	0761					
5372	4040					
5373	4040					
5374	4040					
5375	4040					
5376	4001					
5377	2207					
5400	6240					
5401	4040					
5402	4040					
5403	4040					
5404	0530					
5405	2005					
5406	0324					
5407	0504					
5410	4040					
5411	4040					
5412	4040					
5413	0103					
5414	2425					
5415	0114					
5416	3736					
5417	0000					

5420	3736	EM1,	TEXT	/**	SIMULATED ADD TEST FAILED/
5421	4040				
5422	4040				
5423	4023				
5424	1115				
5425	2514				
5426	0124				
5427	0504				
5430	4001				
5431	0404				
5432	4024				
5433	0523				
5434	2440				
5435	0601				
5436	1114				
5437	0504				
5440	0000				
5441	3736	EM2,	TEXT	/**	SIMULATED RAL TEST FAILED/
5442	4040				
5443	4040				
5444	4023				
5445	1115				
5446	2514				
5447	0124				
5450	0504				
5451	4022				
5452	0114				
5453	4024				
5454	0523				
5455	2440				
5456	0601				
5457	1114				
5460	0504				
5461	0000				
5462	3736	EM3,	TEXT	/**	SIMULATED RAR TEST FAILED/
5463	4040				
5464	4040				
5465	4023				
5466	1115				
5467	2514				
5470	0124				
5471	0504				
5472	4022				
5473	0122				
5474	4024				
5475	0523				
5476	2440				
5477	0601				
5500	1114				
5501	0504				
5502	0000				
5503	3736	EM4,	TEXT	/**	SIMULATED RTL TEST FAILED/
5504	4040				
5505	4040				
5506	4023				

5507	1115			
5510	2514			
5511	0124			
5512	0504			
5513	4022			
5514	2414			
5515	4024			
5516	0523			
5517	2440			
5520	0601			
5521	1114			
5522	0504			
5523	0000			
5524	3736	EM5,	TEXT	/* SIMULATED RTR TEST FAILED/
5525	4040			
5526	4040			
5527	4023			
5530	1115			
5531	2514			
5532	0124			
5533	0504			
5534	4022			
5535	2422			
5536	4024			
5537	0523			
5540	2440			
5541	0601			
5542	1114			
5543	0504			
5544	0000			
5545	3736	EM6,	TEXT	/* SIMULATED BSW TEST FAILED/
5546	4040			
5547	4040			
5550	4023			
5551	1115			
5552	2514			
5553	0124			
5554	0504			
5555	4002			
5556	2327			
5557	4024			
5560	0523			
5561	2440			
5562	0601			
5563	1114			
5564	0504			
5565	0000			
5566	3736	EM10,	TEXT	/* RANDOM ADD TEST 1 FAILED/
5567	4040			
5570	4040			
5571	4022			
5572	0116			
5573	0417			
5574	1540			
5575	0104			

) /	PAL10	V141	13-SEP-71	13131) 1-50
5420	3736	EM1,	TEXT	/**	SIMULATED ADD TEST FAILED/
5421	4040				
5422	4040				
5423	4023				
5424	1115				
5425	2514				
5426	0124				
5427	0504				
5430	4001				
5431	0404				
5432	4024				
5433	0523				
5434	2440				
5435	0601				
5436	1114				
5437	0504				
5440	0000				
5441	3736	EM2,	TEXT	/**	SIMULATED RAL TEST FAILED/
5442	4040				
5443	4040				
5444	4023				
5445	1115				
5446	2514				
5447	0124				
5450	0504				
5451	4022				
5452	0114				
5453	4024				
5454	0523				
5455	2440				
5456	0601				
5457	1114				
5460	0504				
5461	0000				
5462	3736	EM3,	TEXT	/**	SIMULATED RAR TEST FAILED/
5463	4040				
5464	4040				
5465	4023				
5466	1115				
5467	2514				
5470	0124				
5471	0504				
5472	4022				
5473	0122				
5474	4024				
5475	0523				
5476	2440				
5477	0601				
5500	1114				
5501	0504				
5502	0000				
5503	3736	EM4,	TEXT	/**	SIMULATED RTL TEST FAILED/
5504	4040				
5505	4040				
5506	4023				

5507	1115		
5510	2514		
5511	0124		
5512	0504		
5513	4022		
5514	2414		
5515	4024		
5516	0523		
5517	2440		
5520	0601		
5521	1114		
5522	0504		
5523	0000		
5524	3736	EM5,	TEXT /** SIMULATED RTR TEST FAILED/
5525	4040		
5526	4040		
5527	4023		
5530	1115		
5531	2514		
5532	0124		
5533	0504		
5534	4022		
5535	2422		
5536	4024		
5537	0523		
5540	2440		
5541	0601		
5542	1114		
5543	0504		
5544	0000		
5545	3736	EM6,	TEXT /** SIMULATED BSW TEST FAILED/
5546	4040		
5547	4040		
5550	4023		
5551	1115		
5552	2514		
5553	0124		
5554	0504		
5555	4002		
5556	2327		
5557	4024		
5560	0523		
5561	2440		
5562	0601		
5563	1114		
5564	0504		
5565	0000		
5566	3736	EM10,	TEXT /** RANDOM ADD TEST 1 FAILED/
5567	4040		
5570	4040		
5571	4022		
5572	0116		
5573	0417		
5574	1540		
5575	0104		

PAL10

V141

13=SEP=71

13131

1=52

5576 0440
5577 2405
5580 2324
5581 4061
5582 4006
5583 0111
5584 1405
5585 0400
5586 3736
5587 4040
5588 4040
5589 4022
5592 0116
5593 0417
5594 1540
5595 0104
5596 0440
5597 2405
5598 2324
5599 4062
5602 4006
5603 0111
5604 1405
5605 0400
5606 3736
5607 4040
5608 4040
5609 4022
5612 0116
5613 0417
5614 1540
5615 2201
5616 2240
5617 2405
5618 2324
5621 4006
5622 0111
5623 1405
5624 0400
5625 3736
5626 4040
5627 4040
5628 4022
5631 4022
5632 0116
5633 0417
5634 1540
5635 2201
5636 2240
5637 2405
5640 2324
5641 4006
5642 0111
5643 1405
5644 0400
5645 3736
5646 4040
5647 4040
5650 4022
5651 0116
5652 0417
5653 1540
5654 2201
5655 1440
5656 2405
5657 2324
5660 4006
5661 0111
5662 1405
5663 0400
5664 3736

EM11, TEXT /** RANDOM ADD TEST 2 FAILED/

EM12, TEXT /** RANDOM RAR TEST FAILED/

EM13, TEXT /** RANDOM RAL TEST FAILED/

EM14, TEXT /** RANDOM RTL TEST FAILED/

5665	4040		
5666	4040		
5667	4022		
5670	0116		
5671	0417		
5672	1540		
5673	2224		
5674	1440		
5675	2405		
5676	2324		
5677	4006		
5700	0111		
5701	1405		
5702	0400		
5703	3736	EM15, TEXT	/* RANDOM RTR TEST FAILED?
5704	4040		
5705	4040		
5706	4022		
5707	0116		
5710	0417		
5711	1540		
5712	2224		
5713	2240		
5714	2405		
5715	2324		
5716	4006		
5717	0111		
5720	1405		
5721	0400		
5722	3736	OK1, TEXT	/*SIMAD/
5723	2311		
5724	1501		
5725	0400		
5726	3736	OK2, TEXT	/*SIMROT/
5727	2311		
5730	1522		
5731	1724		
5732	0000		
5733	3736	OK3, TEXT	/*FCT/
5734	0603		
5735	2400		
5736	3736	OK4, TEXT	/*RANDOM/
5737	2201		
5740	1604		
5741	1715		
5742	0000		
5743	3736	CRLF, TEXT	/*
5744	0000		
5745	3736	DATE, TEXT	/* DATA ERROR*/
5746	4004		
5747	0124		
5750	0140		
5751	0522		
5752	2217		
5753	2237		

5754 3600

5755	7777	BKMS,	7777	/TEXT FOR EXTENDED BANKS OF MEMORY TO BANK
5756	4005		4005	
5757	3024		3024	
5760	0516		0516	
5761	0405		0405	
5762	0440		0440	
5763	0201		0201	
5764	1613		1613	
5765	2340		2340	
5766	1706		1706	
5767	4015		4015	
5770	0515		0515	
5771	1722		1722	
5772	3140		3140	
5773	2417		2417	
5774	4002		4002	
5775	0116		0116	
5776	1340		1340	
5777	0000		0000	

/

/

/RESTORE BINARY LOADER AND START LOADER

/

7600 7600

7601 1155

7602 3377

7603 5377

*7600

CLA CLL

TAD BIN

DCA TSTA2

JMP TSTA2

S

[illegible]

```

7600 11110000 00000000 00000000 00000000 00000000 00000000 00000000 00000000
7700 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000111

```

A1	3263	DH5	5350	FCT12	2667	K0010	0113
A10KA2	0027	DH6	5365	FCT2	2043	K0020	0112
A2	3264	EM1	5420	FCT3	2076	K0040	0111
ABNOT	3754	EM10	5566	FCT4	2200	K0070	0173
AD1	2127	EM11	5606	FCT5	2232	K0077	1645
AD10	2715	EM12	5626	FCT6	2270	K0100	0110
AD11	2716	EM13	5640	FCT7	2400	K0170	4775
AD12	2717	EM14	5664	FCT8	2436	K0200	0107
AD2	2130	EM15	5703	FCT9	2472	K0400	0106
AD3	2131	EM2	5441	FCTHLT	3207	K0700	3266
AD4	2324	EM3	5462	FCTOK	3221	K1000	0105
AD5	2325	EM4	5503	FLOCHK	4600	K2000	0104
AD6	2326	EM5	5524	FLOCNF	0176	K212	1650
AD7	2526	EM6	5545	FLODF	4643	K213	1651
AD8	2527	ENCAR	0244	FLODEX	4627	K240	0076
AD9	2530	ENCAR1	0253	FLODFND	4631	K252	4776
ADA1	0021	ENDBSW	1277	FLOFRM	4712	K260	0077
ADA2	0022	ENDFCT	3200	FLOGO	4714	K261	0100
ADD	0274	ENDROT	1303	FLOHR	4760	K336	1647
ADDERR	0400	ENRN	4566	FLONO	4752	K4000	0103
ADHLT	0536	EROUT1	3744	FLONUM	0174	K6000	0101
ADOUT	3227	ERROR1	0377	FLORM1	4717	K6060	3267
ADPRT	0417	ERROR2	1046	FLOSAV	0175	KCDF	4772
ADT	0531	ERROT	1026	FLOSW	4550	KCR	4774
AHFLG	0035	FCL1	2023	GOTEST	0177	KLF	4773
AHOVT	0467	FCL10	2612	HALT2	3027	KSTOP	4771
ALT1BT	3616	FCL11	2644	HALTA	0477	KXXXX	0170
ANEG	3747	FCL12	2677	HALTB	1063	LPCR	4741
APOS	3746	FCL2	2056	HLTA	0404	LINK1	0032
ARG1	0023	FCL3	2107	HLTB	1052	LINK2	0034
ARG2	0024	FCL4	2213	INS1	0136	LINKR	0044
ASTRK	4731	FCL5	2246	INS10	0146	LINKRC	0045
BJN	0155	FCL6	2302	INS11	0147	LNKOUT	0504
BKMS	5755	FCL7	2412	INS12	0150	LOOP	3046
BNEG	3751	FCL8	2450	INS13	0151	LOOP1	0552
BPOS	3750	FCL9	2503	INS14	0152	M4	1070
BSW	7002	FCS1	2005	INS15	0153	M40	1646
BSWIAB	1660	FCS10	2601	INS16	2133	MASK	3752
CAF	6007	FCS11	2635	INS2	2132	MODNEG	3632
CARRY	0030	FCS12	2670	INS3	0137	MOVMSK	3667
CBTST1	3640	FCS2	2044	INS4	0140	MQA	7501
CBTST2	3654	FCS3	2077	INS5	0141	MQL	7421
CHAR	0036	FCS4	2201	INS6	0142	MTP	1643
CNTR1	0020	FCS5	2233	INS7	0143	N1BIT	1244
COMROT	1000	FCS6	2271	INS8	0144	NBIT	1207
CRLF	5743	FCS7	2401	INS9	0145	NERRORP	0067
DATE	5745	FCS8	2437	K0	0171	NEWLNK	1044
DATER	3037	FCS9	2473	K0001	0116	NLOOP	3054
DH1	5200	FCT	2000	K0002	0115	NMASK	3753
DH2	5245	FCT1	2004	K0003	3542	NOTAC	3755
DH3	5274	FCT10	2600	K0004	0114	NXBIT	0527
DH4	5317	FCT11	2634	K0007	0172	NXTADD	0365

PAL18

V141

13=SEP=71

13131

E 1=58

NXTBT 3612
 NXTCAR 0234
 NXTROT 1031
 OK1 5722
 OK2 5726
 OK3 5733
 OK4 5736
 OR1 1225
 OUT 3224
 OUT1 0520
 OUT1A 0542
 POINT1 0011
 POINT2 0012
 PRINT 1600
 R1 1400
 R2 1410
 R2A 3541
 R3 1420
 R4 1430
 R5 1440
 RAC 0023
 RALR 5013
 RALR 4255
 RALTAB 0757
 RANDA 0041
 RAND08 0042
 RANDC 0043
 RANDOM 3512
 RARER 5000
 RARR 4200
 RBSW 0731
 RELOC 4664
 RET1 2025
 RET10 2616
 RET11 2651
 RET12 2701
 RET2 2060
 RET3 2111
 RET4 2215
 RET5 2252
 RET6 2306
 RET7 2420
 RET8 2455
 RET9 2510
 RHD 1133
 RHFLG 0035
 RHOUT 1131
 RLNK 0024
 RN1ER 3447
 RN2ER 4000
 RNAD1 3400
 RNAD2 3600

RNDHLT 4540
 RNDOK 4563
 ROBACK 5063
 ROHLT 5053
 ROPRT 5064
 ROTDNE 1323
 ROTHLY 1327
 ROTPRT 1071
 RRAC 0031
 RRAL 0605
 RRAR 0632
 RRLNK 0033
 RRTL 0657
 RRRR 0704
 RSIMAD 0200
 RTLER 5041
 RTLRL 4400
 RTLTAB 1160
 RTRER 5026
 RTRR 4455
 RTRTAB 1141
 SADOK 0570
 SAMEA 3730
 SAMEAS 3000
 SAVREG 3017
 SBSW 1236
 SEQ 0154
 SEQ1 0122
 SEQ10 0133
 SEQ11 0134
 SEQ12 0135
 SEQ2 0123
 SEQ3 0124
 SEQ4 0125
 SEQ5 0126
 SEQ6 0127
 SEQ7 0130
 SEQ8 0131
 SEQ9 0132
 SHLT 4033
 SIMAC 0025
 SIMAD 0204
 SIMBSW 0725
 SIMLNK 0026
 SIMR 0577
 SIMRAL 0601
 SIMRAR 0626
 SIMRO1 0600
 SIMRO2 0625
 SIMRO3 0652
 SIMRO4 0677
 SIMRO5 0724

SIMRTL 0653
 SIMRTR 0700
 SKHLT 3502
 SP1 0545
 SR00 0103
 SR01 0104
 SR02 0105
 SR03 0106
 SR04 0107
 SR05 0110
 SR06 0111
 SR07 0112
 SR08 0113
 SR09 0114
 SR10 0115
 SR11 0116
 SROTAL 1200
 SROTOK 1342
 START 0156
 SUM1 0031
 SUM2 0033
 TEMP1 0037
 TEMPAC 0025
 TEMPL 0026
 TSTA0 7775
 TSTA1 7776
 TSTA2 7777
 TSTA3 0000
 TSTA4 0001
 TSTA5 0002
 TSTA6 0003
 TSTA7 0004
 TSTIND 0010
 TYBIT 0540
 TYLNK 0513
 TYPE 1652
 TYP52 3056
 TYPSET 1617
 W1 0037
 W2 0040
 WD1 0037
 WD2 0040
 WQOUT 0523
 XADD 0415
 XADOUT 3073
 XAMEA 0063
 XAMEAS 0062
 XAVREG 0064
 XBSWA 0055
 XCOMRO 0056
 XDATE 0065
 XFLOCK 4572

XFLOSW 4770
 XHALT2 0066
 XLNK00 0060
 XLOOP 0067
 XLOOP1 0075
 XLOOP2 0074
 XM2 1450
 XM3 1451
 XM4 1452
 XM5 1453
 XM6 1454
 XNXTAD 0416
 XNXTRO 0057
 XOR1 3701
 XOR2 3715
 XORALL 0260
 XPRINT 0046
 XR1 0752
 XR2 0753
 XR3 0754
 XR4 0755
 XR5 0756
 XRALR 4334
 XRALTA 0052
 XRAND 0073
 XRARR 4335
 XRARTA 0102
 XRWD 0050
 XRN1ER 3446
 XRN2ER 3756
 XROTDN 0777
 XRTLRL 4571
 XRTLTA 0053
 XRTTR 4570
 XRTRTA 0054
 XSBSW 0776
 XSROT 0051
 XSTA0 0070
 XSTA1 0071
 XSTA2 0072
 XTYPE 0047
 XWDOUT 0061

ERRORS DETECTED: 0

LINKS GENERATED: 3

RUN-TIME: 32 SECONDS

3K CORE USED