

## Chapter 4 Operation

Introduction.....	4-1
Front Panel.....	4-1
Rear Panel.....	4-5
TK50-R, TK50-D Tape Drive.....	4-6
Labeling a TK50 Tape Cartridge.....	4-7
Write-Protecting a Tape Cartridge.....	4-7
Care and Handling of TK50 Tape Drive and Tapes.....	4-8
Backing Up Files on a TK50 Tape Cartridge.....	4-8
Inserting a TK50 Tape Cartridge.....	4-9
Removing a TK50 Tape Cartridge.....	4-14

## Chapter 5 Technical Description

Introduction.....	5-1
Physical Features.....	5-1
TK50 Subsystem.....	5-3
M7547 Controller Module.....	5-3
Operating Features.....	5-5
Environmental Requirements.....	5-5
Power Supply.....	5-5
DC Cooling Fan.....	5-5
Front Panel Controls and Indicators.....	5-6
On/Off Switch.....	5-6
Load/Unload Button.....	5-6
LED Indicators.....	5-7
Red LED.....	5-7
Green LED.....	5-7
Rear Panel.....	5-8
Logical Unit Numbers.....	5-9
Configuration.....	5-9
Power Requirements.....	5-9
Module Starting Addresses/Interrupt Vectors.....	5-10
Unit Number Dip Switch (E4, 4-B7).....	5-11
Revision Level Switchpack (E5, 4-C7).....	5-12
System Controller and Cable Options.....	5-12
Troubleshooting Table.....	5-13

## Chapter 6 Removal and Replacement

Introduction.....	6-1
TK50 Tape Drive Removal.....	6-2
Power Supply Removal.....	6-6
Fan Assembly Removal.....	6-8

## Appendix A Connector Pin Numbers and Signals

## Appendix B System Specifications

## Appendix C Related Documentation

## Appendix D Service Options