

**EK-RX012-PS-002**

# **RX01/RX02**

## **Pocket Service Guide**

1st Edition, November 1980  
2nd Edition, September 1981

Copyright © 1981  
by Digital Equipment Corporation.  
All Rights Reserved.

The reproduction of this material, in part or whole, is strictly prohibited. For copy information, contact the Educational Services Department, Digital Equipment Corporation, Maynard, Massachusetts 01754.

The information in this document is subject to change without notice. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

Printed in U.S.A.

The following are trademarks of Digital Equipment Corporation, Maynard, Massachusetts.

DEC	DECnet	OMNIBUS
DECUS	DECsystem-10	OS/8
DIGITAL	DECSYSTEM-20	PDT
Digital Logo	DECwriter	RSTS
PDP	DIBOL	RSX
UNIBUS	EduSystem	VMS
VAX	IAS	VT
	MASSBUS	

# CONTENTS

## 1 TROUBLESHOOTING

1.1	General .....	1
1.2	Troubleshooting Charts .....	2
1.3	Power Supply Voltages .....	8
1.4	RX8/RX28 Subsystem .....	9
1.4.1	Bootstrap .....	13
1.4.2	Registers .....	13
1.4.3	Interface (M8357) .....	15
1.5	RX11/RXV11 Subsystem .....	15
1.5.1	Bootstrap .....	16
1.5.2	Registers .....	16
1.5.3	Interfaces (M7846 and M7946) .....	18
1.6	RX211/RXV21 Subsystem .....	18
1.6.1	Bootstrap .....	20
1.6.2	Registers .....	20
1.6.3	Interfaces (M8256 and M8029) .....	20

## 2 MECHANICAL SERVICING

2.1	General .....	25
2.2	RX01/RX02 Disk Drive Assembly .....	26
2.2.1	Rack-Mount .....	26
2.2.2	Case-Mount .....	27
2.3	Controller Board .....	29
2.4	Read/Write Board .....	30
2.5	Drive .....	32
2.6	Power Supply .....	35
2.7	Power Board Assembly (Regulators) .....	36
2.8	Drive Belt and AC Motor Pulley .....	37
2.9	Door Handle .....	38
2.9.1	Door Handle Removal .....	38
2.9.2	Door Handle Installation .....	38
2.10	Read/Write Head .....	39
2.11	Stepper Motor Lead Shaft .....	39

## 3 ALIGNMENT AND ADJUSTMENT

3.1	Handle Latch Wire .....	41
3.2	Drive Belt and AC Motor Pulley .....	41
3.3	Head Gap .....	43

## APPENDIX A SPARE PARTS LIST

## FIGURES

1-1	What System/Subsystem Is This? .....	3
1-2	Diskette Media .....	4
1-3	Head Plug (P3) to M7727 .....	7
1-4	Power Supply Voltage Checks .....	9
1-5	RX8/RX28 Registers .....	14
1-6	M8357 Interface (RX8/RX28) .....	16
1-7	RX11/RXV11 Registers .....	17
1-8	M7846 Interface (RX11) .....	18
1-9	M7946 Interface (RXV11) .....	19
1-10	RX211/RXV21 Registers .....	21
1-11	M8256 Interface (RX211) .....	23
1-12	M8029 Interface (RXV21) .....	24
2-1	Subassembly Removal and Replacement ....	25
2-2	Removing and Replacing RX01/RX02 (Case-Mount) .....	27
2-3	Controller Board Connections .....	28
2-4	RX01 Read/Write Board Connections ....	30
2-5	RX02 Read/Write Board Connections ....	31
2-6	Plenum/Fan Assembly .....	33
2-7	Drive and Power Supply Removal .....	34
2-8	Power Supply Components .....	35
2-9	Capacitor C1 and C2 Connections .....	36
2-10	Drive Belt and AC Motor Pulley .....	37
2-11	Door Handle Assembly .....	39
2-12	Head Carriage Components (Top View) ....	40
3-1	Motor Pulley Alignment .....	41
3-2	Underside View of Drive .....	42
3-3	Head Gap Adjustment .....	43
3-4	RX01 Pressure Pad Mechanism (Front View) .....	44
3-5	RX02 Pressure Pad Mechanism (Front View) .....	45

## TABLES

1-1	Reference Documentation .....	1
1-2	RX01/RX02 Field Replaceable Units .....	2
1-3	RX01/RX02 Troubleshooting Chart .....	3
1-4	Intermittent Problems .....	7
1-5	Voltages .....	8
1-6	Diagnostic Error Code Definitions and Probable Causes .....	10
1-7	Diagnostic Printout Troubleshooting Chart .....	12
1-8	RX8/RX28 Bootstraps .....	13
1-9	RX11/RXV11 Bootstrap .....	16
1-10	RX211/RXV21 Bootstrap .....	20
2-1	Switch Configuration for M7744 .....	29